Function List

AutoMaker:Chrysler

NOTES:

√ This function is supported.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

YEAR	VehicleType	Control unit	Ecu info.	Read codes	Erase codes	Live Data	Freeze Frame	Active Test	ECU Configure Info.	Special Function
1996~2003	All Model	PCM	√	√	√	√	√	√	○	0480, 1279, 1280, 1281, 0927, 1282, 0205, 1283, 1284, 1285, 1286, 1287, 1288, 1289, 1290, 1291, 1292, 1293, 1294, 0741, 1291, 1296, 0215, 1291, 1294, 1299, 0628, 1300, 1296, 0892, 1302, 1303
1996~2003	All Model	TCM	○	√	√	√	√	√	○	1283, 1284, 1315, 0346, 0166, 1316, 1107, 1317
1996~2003	All Model	ABS	○	√	√	√	○	√	○	0168, 0171
1996~2003	All Model	ORC	○	√	√	√	○	○	○	0271
1996~2003	All Model	SKM	○	√	√	√	○	√	○	1305, 1306, 1307, 1308, 1309, 1310, 1311, 1312
1996~2003	All Model	APM	○	√	√	√	○	√	○	
1996~2003	All Model	ATC	○	√	√	√	○	√	○	0928, 1191
1996~2003	All Model	AUD	○	√	√	√	○	○	○	0156, 0863
1996~2003	All Model	BCM	○	√	√	√	○	√	○	0150, 0207, 0797, 0418, 0928, 0933, 0859, 0989, 0152, 0651, 0586, 0506, 0728, 0918, 0925, 1180, 0675
1996~2003	All Model	CMT	○	√	√	○	○	○	○	
1996~2003	All Model	DAA	○	√	√	○	○	○	○	0595, 0273, 0739, 0916, 0657
1996~2003	All Model	DDM	○	√	√	√	○	√	○	0928, 0586
1996~2003	All Model	DSD	○	√	√	√	○	√	○	0928
1996~2003	All Model	ECM	○	√	√	√	○	√	○	0402, 0207, 0580, 0270, 1268
1996~2003	All Model	FDC	○	√	√	√	○	○	○	
1996~2003	All Model	HPM	○	√	√	√	○	√	○	0928
1996~2003	All Model	HVA	○	√	√	√	○	√	○	0123
1996~2003	All Model	LSA	○	√	√	○	○	○	○	
1996~2003	All Model	MIC	○	√	√	√	○	√	○	
1996~2003	All Model	MSM	○	√	√	√	○	√	○	
1996~2003	All Model	NAV	○	√	√	○	○	○	○	0693
1996~2003	All Model	OCM	○	○	○	√	○	○	○	0928
1996~2003	All Model	PAM	○	√	√	√	○	○	○	
1996~2003	All Model	PDM	○	√	√	√	○	√	○	0580, 0928, 0586
1996~2003	All Model	PLM	○	√	√	√	○	√	○	0622, 0624, 0928, 1206
1996~2003	All Model	PSD	○	√	√	√	○	√	○	0622, 0624, 0928
1996~2003	All Model	RSA	○	√	√	○	○	○	○	
1996~2003	All Model	RSM	○	√	√	○	○	○	○	
1996~2003	All Model	SAR	○	√	√	○	○	√	○	
1996~2003	All Model	SLA	○	○	○	√	○	√	○	
1996~2003	All Model	SDM	○	○	○	√	○	√	○	
1996~2003	All Model	VIC	○	√	√	○	○	○	○	
1996~200	All Model	VTS	○	○	○	√	○	√	○	0150, 0797, 0859, 0265
1996~2003	All Model	XCM	○	○	○	√	○	√	○	
2004	HB-Durango	PCM	√	√	√	√	√	√	√	0215, 0216, 0359, 0378, 0589, 0628, 0692, 0709, 0710, 0827, 0927, 1054, 1055, 0454, 1123
2004	HB-Durango	TCM	√	√	√	√	√	√	√	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0243, 0830, 0979, 0983, 1062, 1063, 1107
2004	HB-Durango	CGW	√	√	√	√	√	√	√	0096, 0129, 0207, 0331, 0402, 0412, 0465, 0508, 0509, 0527, 0560, 0795, 1075, 1164
2004	HB-Durango	ORC	√	√	√	√	√	○	√	

2004	HB-Durango	MIC CCN	√	√	√	√	√	√	√	0150, 0152, 0187, 0210, 0332, 1184
2004	HB-Durango	HVAC	√	√	√	√	√	√	○	0888, 0121, 0124, 0277, 0092
2004	HB-Durango	MSM	√	√	√	√	√	○	○	0604, 1023, 1084, 1151, 0341, 0382, 0110
2004	HB-Durango	OCM	√	√	√	√	√	○	○	0715
2004	HB-Durango	WCM	√	√	√	√	√	○	√	0439, 0741, 0789, 0790, 1244
2004	HB-Durango	EDM	√	√	√	√	√	※	√	0370, 1023
2004	HB-Durango	ABS	√	√	√	√	√	√	√	0171, 0805, 0169, 0170
2004	HB-Durango	RADIO	√	√	√	√	√	○	○	
2004	HB-Durango	SDAR	√	√	√	√	√	○	○	
2004	HB-Durango	AMP	√	√	√	√	√	○	√	0070, 0072, 0074, 0078, 0080, 0083, 0084
2004	HB-Durango	HFM	√	√	√	√	√	√	○	0492
2004	HB-Durango	VES	√	√	√	√	√	√	○	
2004	HB-Durango	DDM	√	√	√	√	√	√	√	0668
2004	HB-Durango	PDM	√	√	√	√	√	√	√	
2004	HB-Durango	HSM	√	√	√	√	√	√	○	
2005	HB-Durango	PCM	√	√	√	√	√	√	√	0378, 0629, 0359, 0827, 0590, 1042, 0202, 0215, 0216, 0589, 0628, 0692, 0709, 0710, 0927, 1054, 1055, 0454, 1123
2005	HB-Durango	TCM	√	√	√	√	√	√	√	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0243, 0830, 0979, 0983, 1062, 1063, 1107
2005	HB-Durango	CGW	√	√	√	√	√	√	√	0096, 0129, 0207, 0331, 0402, 0412, 0465, 0508, 0509, 0527, 0560, 0795, 1075, 1164
2005	HB-Durango	OBC	√	√	√	√	√	○	√	
2005	HB-Durango	MIC CCN	√	√	√	√	√	√	√	0150, 0152, 0187, 0210, 0332, 1184
2005	HB-Durango	HVAC	√	√	√	√	√	√	○	0121, 0124, 0277, 0092, 0888
2005	HB-Durango	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2005	HB-Durango	OCM	√	√	√	√	√	○	○	0715
2005	HB-Durango	WCM	√	√	√	√	√	○	√	0439, 0741, 0789, 0790, 1244
2005	HB-Durango	EDM	√	√	√	√	√	○	√	1023
2005	HB-Durango	ABS	√	√	√	√	√	√	√	0171, 0805, 0169, 0170
2005	HB-Durango	RADIO	√	√	√	√	√	○	○	
2005	HB-Durango	SDAR	√	√	√	√	√	○	○	
2005	HB-Durango	AMP	√	√	√	√	√	○	√	0070, 0072, 0074, 0078, 0080, 0083, 0084
2005	HB-Durango	HFM	√	√	√	√	√	√	○	0492
2005	HB-Durango	VES	√	√	√	√	√	√	○	
2005	HB-Durango	DDM	√	√	√	√	√	√	√	0668
2005	HB-Durango	PDM	√	√	√	√	√	√	√	
2005	**HB-Durango**	**HSM**	√	√	√	√	√	√	○	
2005	LX-300, Charger, Magnum, Grand Voyager	PCM	√	√	√	√	√	√	√	0378, 0629, 0359, 0827, 1042, 0590, 0202, 0215, 0216, 0589, 0628, 0692, 0709, 0710, 0927, 1054, 1055, 0454, 1123
2005	LX-300, Charger, Magnum, Grand Voyager	TCM	√	√	√	√	√	※	※	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0242, 0243, 0829, 0979, 0983, 1062, 1063, 1107, 0671, 0924, 1094
2005	LX-300, Charger, Magnum, Grand Voyager	ESM	√	√	√	√	√	√	○	
2005	LX-300, Charger, Magnum, Grand Voyager	CGW	√	√	√	√	√	√	√	0096, 0129, 0207, 0331, 0402, 0412, 0465, 0508, 0509, 0527, 0560, 0795, 0805, 1075
2005	LX-300, Charger, Magnum, Grand Voyager	OBC	√	√	√	√	√	○	√	
2005	LX-300, Charger, Magnum, Grand Voyager	MIC CCN	√	√	√	√	√	√	○	0209, 1186, 1184, 0152, 0150
2005	LX-300, Charger, Magnum, Grand Voyager	HVAC	√	√	√	√	√	√	○	0277, 0121
2005	LX-300, Charger, Magnum, Grand Voyager	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2005	LX-300, Charger, Magnum, Grand Voyager	OCM	√	√	√	√	√	○	○	0715
2005	LX-300, Charger, Magnum, Grand Voyager	SCM	√	√	√	√	√	√	√	
2005	LX-300, Charger, Magnum, Grand Voyager	WCM	√	√	√	√	√	○	√	0439, 0741, 0789, 0790, 1244
2005	LX-300, Charger, Magnum, Grand Voyager	SUNR	√	√	√	√	√	√	○	
2005	LX-300, Charger, Magnum, Grand Voyager	HIDT	√	√	√	√	√	√	○	0196
2005	LX-300, Charger, Magnum, Grand Voyager	PTS	√	√	√	√	√	√	○	1028, 1030, 1031
2005	LX-300, Charger, Magnum, Grand Voyager	EDM	√	√	√	√	√	※	√	0370, 1023
2005	LX-300, Charger, Magnum, Grand Voyager	HSM	√	√	√	√	√	○	※	0582
2005	LX-300, Charger, Magnum, Grand Voyager	ABS	√	√	√	√	√	√	√	0173, 0174, 0288, 0567, 0574, 0576, 0577, 0585
2005	LX-300, Charger, Magnum, Grand Voyager	RADIO	√	√	√	√	√	○	○	
2005	LX-300, Charger, Magnum, Grand Voyager	SDAR	√	√	√	√	√	○	○	
2005	LX-300, Charger, Magnum, Grand Voyager	AMP	√	√	√	√	√	○	√	0070, 0072, 0074, 0078, 0080, 0083, 0084
2005	LX-300, Charger, Magnum, Grand Voyager	HFM	√	√	√	√	√	√	○	0492
2005	LX-300, Charger, Magnum, Grand Voyager	DDM	√	√	√	√	√	√	※	0668
2005	LX-300, Charger, Magnum, Grand Voyager	PDM	√	√	√	√	√	√	※	0668
2005	LX-300, Charger, Magnum, Grand Voyager	HSM	√	√	√	√	√	√	○	
2005	ND-Dakota	PCM	√	√	√	√	√	√	√	0378, 0629, 0359, 0827, 1042, 0590, 0202, 0215, 0216, 0589, 0628, 0692, 0709, 0710, 0927, 1054, 1055, 0454, 1123
2005	ND-Dakota	TCM	√	√	√	√	√	√	√	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0243, 0830, 0979, 0983, 1062, 1063, 1107

2005	ND-Dakota	CGW	√	√	√	√	√	√	√	0129, 0207, 0331, 0401, 0402, 0412, 0465, 0508, 0527, 0560, 0795, 0805, 1075
2005	ND-Dakota	ORC	√	√	√	√	√	○	√	
2005	ND-Dakota	MIC CCN	√	√	√	√	√	√	√	0150, 0152, 0187, 0210, 0332, 1184
2005	ND-Dakota	HVAC	√	√	√	√	√	√	√	0121, 0124, 0277
2005	ND-Dakota	OCM	√	√	√	√	√	○	○	0715
2005	ND-Dakota	WCM	√	√	√	√	√	○	√	0439, 0741, 0789, 0790, 1244
2005	ND-Dakota	EDM	√	√	√	√	√	○	√	1023
2005	ND-Dakota	ABS	√	√	√	√	√	√	√	0168, 0288, 0567
2005	ND-Dakota	RADIO	√	√	√	√	√	○	○	
2005	ND-Dakota	SDAR	√	√	√	√	√	○	○	
2005	ND-Dakota	AMP	√	√	√	√	√	○	√	0070, 0072, 0074, 0078, 0080, 0083, 0084
2005	ND-Dakota	HFM	√	√	√	√	√	√	○	0492
2005	NK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0216, 0257, 0293, 0294, 0449, 0471, 0538, 0589, 0591, 0689, 0690, 1051, 0454, 1123, 0378, 0629, 0359, 0827, 1042, 0590, 0202, 0215, 0628, 0692, 0709, 0710, 0927, 1054, 1055
2005	NK-Grand Cherokee	TCM	√	√	√	√	√	※	※	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0243, 0830, 0979, 0983, 1062, 1063, 1107, 0571, 0924, 1094
2005	NK-Grand Cherokee	ESM	√	√	√	√	√	√	○	
2005	NK-Grand Cherokee	FDCM	√	√	√	√	√	√	√	
2005	NK-Grand Cherokee	CGW	√	√	√	√	√	√	√	0096, 0129, 0207, 0331, 0402, 0412, 0465, 0508, 0509, 0527, 0560, 0795, 0806, 0807, 1075, 1164
2005	NK-Grand Cherokee	ORC	√	√	√	√	√	○	√	
2005	NK-Grand Cherokee	MIC CCN	√	√	√	√	√	√	√	0150, 0152, 0185, 0187, 0210, 1184
2005	NK-Grand Cherokee	HVAC	√	√	√	√	√	√	○	0121, 0277
2005	NK-Grand Cherokee	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2005	NK-Grand Cherokee	OCM	√	√	√	√	√	○	○	0715
2005	NK-Grand Cherokee	SCM	√	√	√	√	√	○	√	
2005	NK-Grand Cherokee	WCM	√	√	√	√	√	○	√	0439, 0741, 0789, 0790, 0793, 0794, 0799, 0800, 0801, 1188, 1244, 1251
2005	NK-Grand Cherokee	SUNR	√	√	√	√	√	√	○	
2005	NK-Grand Cherokee	AHSM	√	√	√	√	√	√	○	
2005	NK-Grand Cherokee	PTS	√	√	√	√	√	√	○	1028, 1030, 1031
2005	NK-Grand Cherokee	EDM	√	√	√	√	√	○	√	1023
2005	NK-Grand Cherokee	ITM	√	√	√	√	√	√	√	0550
2005	NK-Grand Cherokee	RSM	√	√	√	√	√	○	○	0582
2005	NK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0173, 0174, 0288, 0567, 0574, 0576, 0577, 0585
2005	NK-Grand Cherokee	RADIO	√	√	√	√	√	○	○	
2005	NK-Grand Cherokee	SDAR	√	√	√	√	√	○	○	
2005	NK-Grand Cherokee	AMP	√	√	√	√	√	○	√	0070, 0072, 0074, 0078, 0080, 0083, 0084
2005	NK-Grand Cherokee	HFM	√	√	√	√	√	√	○	0492
2005	NK-Grand Cherokee	VES	√	√	√	√	√	√	○	
2005	NK-Grand Cherokee	DDM	√	√	√	√	√	√	√	0668
2005	NK-Grand Cherokee	PDM	√	√	√	√	√	√	√	
2005	NK-Grand Cherokee	HSM	√	√	√	√	√	√	○	
2006	DR-RAM	PCM	※	√	√	√	√	√	※	0378, 0629, 0359, 0827, 1042, 0590, 0409, 0202, 0215, 0589, 0628, 0692, 0709, 0710, 0927, 1054, 1055, 0454, 1123, 0396, 1134, 1135, 0480, 1197, 0160, 0295, 0474, 1159, 0216, 0191, 0192, 0456, 0457, 0536, 1052, 1053, 1124, 1195
2006	DR-RAM	TCM	√	√	√	√	√	√	√	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0243, 0830, 0979, 0983, 1062, 1063, 1107
2006	DR-RAM	FDCM	√	√	√	√	√	○	○	0113, 0114, 0115, 0116, 0117, 0118
2006	DR-RAM	CGW	※	√	√	※	√	※	※	0119, 0465, 0508, 0510, 0527, 0897, 1076, 0125, 0425, 0331, 0254, 0560, 0095, 0402, 0810, 0816, 0817, 0752
2006	DR-RAM	ORC	√	√	√	√	√	○	√	
2006	DR-RAM	MIC CCN	√	√	√	√	√	√	○	0150, 0152, 0187, 1184
2006	DR-RAM	HVAC	√	√	√	√	√	√	※	0122, 0124, 0277, 0121
2006	DR-RAM	OCM	√	√	√	√	√	○	○	0715
2006	DR-RAM	WCM	√	√	√	√	√	○	√	0789, 0790, 0439, 0741, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255
2006	DR-RAM	SUNR	√	√	√	√	√	√	○	
2006	DR-RAM	EDM	√	√	√	√	√	○	√	1023
2006	DR-RAM	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578
2006	DR-RAM	RADIO	√	√	√	√	√	○	√	
2006	DR-RAM	SDAR	√	√	√	√	√	○	○	
2006	DR-RAM	AMP	√	√	√	√	√	○	√	0072, 0073, 0074, 0080, 0081, 0083, 0084
2006	DR-RAM	HFM	√	√	√	√	√	√	○	0492
2006	DR-RAM	VES	√	√	√	√	√	√	○	
2006	HB-Durango	PCM	√	√	√	√	√	√	√	0378, 0629, 0359, 0827, 1042, 0590, 0202, 0215, 0589, 0628, 0692, 0709, 0710, 0927, 1054, 1055, 0454, 1123

2006	HB-Durango	TCM	√	√	√	√	√	√	√	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0243, 0830, 0979, 0983, 1062, 1063, 1107
2006	HB-Durango	CGW	√	√	√	√	√	√	√	0096, 0129, 0207, 0331, 0402, 0412, 0465, 0508, 0509, 0527, 0560, 0795, 0805, 1075, 1154, 1164
2006	HB-Durango	ORC	√	√	√	√	√	○	√	
2006	HB-Durango	MIC CCN	√	√	√	√	√	√	√	0150, 0152, 0187, 0210, 0332, 1184
2006	HB-Durango	HVAC	√	√	√	√	√	√	○	0121, 0124, 0277, 0092, 0888
2006	HB-Durango	PLGM	√	√	√	√	√	√	√	0199, 0200
2006	HB-Durango	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2006	HB-Durango	OCM	√	√	√	√	√	○	○	0715
2006	HB-Durango	WCM	√	√	√	√	√	○	√	0439, 0741, 0789, 0790, 1244, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255
2006	HB-Durango	EDM	√	√	√	√	√	○	√	1023
2006	HB-Durango	SAS	√	√	√	√	√	○	○	
2006	HB-Durango	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578
2006	HB-Durango	RADIO	√	√	√	√	√	○	√	
2006	HB-Durango	SDAR	√	√	√	√	√	○	○	
2006	HB-Durango	AMP	√	√	√	√	√	○	√	0070, 0072, 0074, 0078, 0080, 0083, 0084, 0069, 0077, 0086
2006	HB-Durango	HFM	√	√	√	√	√	√	○	0492
2006	HB-Durango	VES	√	√	√	√	√	√	○	
2006	HB-Durango	DDM	√	√	√	√	√	√	√	0668
2006	HB-Durango	PDM	√	√	√	√	√	√	√	
2006	HB-Durango	HESM	√	√	√	√	√	√	○	
2006	KJ-Liberty	PCM	※	√	√	√	√	√	※	0378, 0629, 0359, 0827, 1042, 0590, 0202, 0215, 0589, 0628, 0692, 0709, 0710, 0927, 1054, 1055, 0454, 1123
2006	KJ-Liberty	TCM	※	√	√	√	√	√	※	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0243, 0830, 0979, 0983, 1062, 1063, 1107
2006	KJ-Liberty	ORC	○	√	√	○	√	○	○	
2006	KJ-Liberty	MIC CCN	○	√	√	○	√	√	○	0187, 0227, 0263, 1016, 1017
2006	KJ-Liberty	OCM	○	√	√	√	√	○	○	0282, 0715, 0730, 0928
2006	KJ-Liberty	BCM	○	√	√	√	√	√	○	
2006	KJ-Liberty	EDM	○	√	√	○	√	○	○	
2006	KJ-Liberty	ITM	√	√	√	○	√	√	○	
2006	KJ-Liberty	SKM	○	√	√	○	√	√	○	0405, 0406, 0439, 0442, 0742, 0743, 0746, 0785, 0791, 0801, 0940, 1227, 1228, 1233, 1245, 1246, 1250, 1256, 1257
2006	KJ-Liberty	SAS	√	√	√	√	√	○	○	
2006	KJ-Liberty	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578
2006	KJ-Liberty	RADIO	√	√	√	√	√	√	√	
2006	KJ-Liberty	SDAR	○	√	√	√	√	√	○	
2006	KJ-Liberty	HFM	○	√	√	√	√	√	○	
2006	LX-300, Charger, Magnum, Grand Voyager	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0538, 0591, 0660, 0689, 0690, 0454, 1123, 0378, 0629, 0359, 0827, 1042, 0590, 0202, 0215, 0628, 0692, 0709, 0710, 0927, 1054, 1055
2006	LX-300, Charger, Magnum, Grand Voyager	TCM	√	√	√	√	√	※	※	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0243, 0830, 0979, 0983, 1062, 1063, 1107, 0924, 1094
2006	LX-300, Charger, Magnum, Grand Voyager	ESM	√	√	√	√	√	√	○	
2006	LX-300, Charger, Magnum, Grand Voyager	CGW	√	√	√	√	√	√	√	0560, 0096, 0129, 0207, 0331, 0402, 0412, 0465, 0508, 0509, 0795, 0805, 1075
2006	LX-300, Charger, Magnum, Grand Voyager	ORC	√	√	√	√	√	○	√	
2006	LX-300, Charger, Magnum, Grand Voyager	MIC CCN	√	√	√	√	√	√	○	0209, 0150, 0152, 1186, 1014, 1184
2006	LX-300, Charger, Magnum, Grand Voyager	HVAC	√	√	√	√	√	√	○	0121, 0277
2006	LX-300, Charger, Magnum, Grand Voyager	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2006	LX-300, Charger, Magnum, Grand Voyager	OCM	√	√	√	√	√	○	○	0715
2006	LX-300, Charger, Magnum, Grand Voyager	SCM	√	√	√	√	√	√	√	
2006	LX-300, Charger, Magnum, Grand Voyager	WCM	√	√	√	√	√	○	√	0439, 0741, 0789, 0790, 1244, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255
2006	LX-300, Charger, Magnum, Grand Voyager	SUNR	√	√	√	√	√	√	○	
2006	LX-300, Charger, Magnum, Grand Voyager	PTIM	√	√	√	√	√	√	√	
2006	LX-300, Charger, Magnum, Grand Voyager	HIDT	√	√	√	√	√	√	○	0196
2006	LX-300, Charger, Magnum, Grand Voyager	AHBM	√	√	√	√	√	√	○	
2006	LX-300, Charger, Magnum, Grand Voyager	PTS	√	√	√	√	√	√	○	1028, 1030, 1031, 0267
2006	LX-300, Charger, Magnum, Grand Voyager	EDM	√	√	√	√	√	○	√	0370, 1023
2006	LX-300, Charger, Magnum, Grand Voyager	ITM	√	√	√	√	√	√	√	0550
2006	LX-300, Charger, Magnum, Grand Voyager	RSM	√	√	√	√	√	○	○	0582
2006	LX-300, Charger, Magnum, Grand Voyager	ABS	√	√	√	√	√	√	√	0173, 0174, 0288, 0567, 0574, 0576, 0577, 0585, 0566, 0168, 0568, 0578
2006	LX-300, Charger, Magnum, Grand Voyager	RADIO	√	√	√	√	√	○	√	
2006	LX-300, Charger, Magnum, Grand Voyager	SDAR	√	√	√	√	√	○	○	
2006	LX-300, Charger, Magnum, Grand Voyager	AMP	√	√	√	√	√	○	√	-
2006	LX-300, Charger, Magnum, Grand Voyager	HFM	√	√	√	√	√	√	○	0492
2006	LX-300, Charger, Magnum, Grand Voyager	VES	√	√	√	√	√	√	○	

2006	LX-300,Charger,Magnum,Grand Voyager	DDM	√	√	√	√	√	√	※	0668
2006	LX-300,Charger,Magnum,Grand Voyager	PDM	√	√	√	√	√	√	※	0668
2006	LX-300,Charger,Magnum,Grand Voyager	HESM	√	√	√	√	√	√	○	
2006	ND-Dakota	PCM	√	√	√	√	√	√	√	0378,0629,0359,0827,1042,0590,0202,0215,0589,0628,0692,0709,0710,0927,1054,1055,0454,1123
2006	ND-Dakota	TCM	√	√	√	√	√	√	√	0011,0015,0016,0028,0032,0045,0049,0243,0830,0979,0983,1062,1063,1107
2006	ND-Dakota	CGW	√	√	√	√	√	√	√	0096,0129,0207,0331,0401,0402,0412,0465,0508,0527,0560,0795,0815,1075,1164
2006	ND-Dakota	ORC	√	√	√	√	√	○	√	
2006	ND-Dakota	MIC_CCN	√	√	√	√	√	√	√	0150,0152,0187,0210,0332,1184
2006	ND-Dakota	HVAC	√	√	√	√	√	√	√	0121,0124,0277
2006	ND-Dakota	OCM	√	√	√	√	√	○	○	0715
2006	ND-Dakota	WCM	√	√	√	√	√	○	√	0439,0741,0789,0790,1244,0793,0794,0799,0800,0801,0802,1131,1188,1247,1248,1252,1255
2006	ND-Dakota	EOM	√	√	√	√	√	○	√	1023
2006	ND-Dakota	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578
2006	ND-Dakota	RADIO	√	√	√	√	√	○	√	
2006	ND-Dakota	SDAR	√	√	√	√	√	○	○	
2006	ND-Dakota	AMP	√	√	√	√	√	○	√	0070,0072,0074,0078,0080,0083,0084,0069,0077,0086
2006	ND-Dakota	HFM	√	√	√	√	√	√	○	0492
2006	NM-Raider	PCM	√	√	√	√	√	√	√	0378,0629,0359,0827,1042,0590,0202,0215,0589,0628,0692,0709,0710,0927,1054,1055,0454,1123
2006	NM-Raider	TCM	√	√	√	√	√	√	√	0011,0015,0016,0028,0032,0045,0049,0243,0830,0979,0983,1062,1063,1107
2006	NM-Raider	CGW	√	√	√	√	√	√	√	0096,0129,0207,0331,0401,0402,0412,0465,0508,0527,0560,0795,0815,1075,1164
2006	NM-Raider	ORC	√	√	√	√	√	○	√	
2006	NM-Raider	MIC_CCN	√	√	√	√	√	√	√	0150,0152,0187,0210,0332,1184
2006	NM-Raider	HVAC	√	√	√	√	√	√	√	0121,0124,0277
2006	NM-Raider	OCM	√	√	√	√	√	○	○	0715
2006	NM-Raider	WCM	√	√	√	√	√	○	√	0439,0741,0789,0790,1244,0793,0794,0799,0800,0801,0802,1131,1188,1247,1248,1252,1255
2006	NM-Raider	EOM	√	√	√	√	√	○	√	1023
2006	NM-Raider	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578
2006	NM-Raider	RADIO	√	√	√	√	√	○	√	
2006	NM-Raider	SDAR	√	√	√	√	√	○	○	
2006	NM-Raider	AMP	√	√	√	√	√	○	√	0070,0072,0074,0078,0080,0083,0084,0069,0077,0086
2006	NM-Raider	HFM	√	√	√	√	√	√	○	0492
2006	PT-PT Cruiser	PCM	※	√	√	√	√	√	※	0257,0293,0294,0538,0589,1051,0216,0591,0454,1123,0378,0629,0359,0827,1042,0590,0409,0202,0215,0628,0692,0709,0710,0927,1054,1055
2006	PT-PT Cruiser	TCM	√	√	√	√	√	√	√	0011,0015,0016,0028,0032,0045,0049,0243,0830,0979,0983,1062,1063,1107,0230,0834
2006	PT-PT Cruiser	CGW	※	√	√	※	√	※	※	0108,0119,0331,0465,0508,0510,0527,0560,1076,0095,0125,0425,0402,0810,0816,0817,0752
2006	PT-PT Cruiser	ORC	√	√	√	√	√	○	√	
2006	PT-PT Cruiser	MIC_CCN	√	√	√	√	√	√	√	0150,0152,0187,0619,0666,1015
2006	PT-PT Cruiser	OCM	√	√	√	√	√	○	○	0715
2006	PT-PT Cruiser	WCM	√	√	√	√	√	○	√	0789,0790,0439,0741,0793,0794,0799,0800,0801,0802,1131,1188,1247,1248,1252,1255
2006	PT-PT Cruiser	ITM	√	√	√	√	√	√	√	0579
2006	PT-PT Cruiser	ABS	√	√	√	√	√	√	√	0056,0168,0567,0575,0585
2006	PT-PT Cruiser	RADIO	√	√	√	√	√	○	√	
2006	PT-PT Cruiser	SDAR	√	√	√	√	√	○	○	
2006	PT-PT Cruiser	AMP	√	√	√	√	√	○	√	0070,0072,0074,0078,0080,0083,0084
2006	PT-PT Cruiser	HFM	√	√	√	√	√	√	○	0492
2006	PT-PT Cruiser	DDM	√	√	√	√	√	√	○	
2006	PT-PT Cruiser	PDM	√	√	√	√	√	√	○	
2006	WK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0216,0257,0293,0294,0449,0471,0538,0589,0591,0689,0690,1051,0454,1123,0378,0629,0359,0827,1042,0590,0202,0215,0628,0692,0709,0710,0927,1054,1055
2006	WK-Grand Cherokee	TCM	√	√	√	√	√	※	※	0011,0015,0016,0028,0032,0045,0049,0243,0830,0979,0983,1062,1063,1107,0924,1094
2006	WK-Grand Cherokee	ESM	√	√	√	√	√	√	○	
2006	WK-Grand Cherokee	FDCM	√	√	√	√	√	√	√	
2006	WK-Grand Cherokee	CGW	√	√	√	√	√	√	√	0096,0129,0207,0331,0402,0412,0465,0508,0509,0527,0560,0795,0805,1075,1164
2006	WK-Grand Cherokee	ORC	√	√	√	√	√	○	√	
2006	WK-Grand Cherokee	MIC_CCN	√	√	√	√	√	√	√	0150,0152,0185,0187,0210,0619,1035,1036,1184

2006	WK-Grand Cherokee	HVAC	√	√	√	√	√	√	○	0121,0277
2006	WK-Grand Cherokee	MSM	√	√	√	√	√	○	○	0341,0382,0604,1023,1084,1151,0110
2006	WK-Grand Cherokee	OCM	√	√	√	√	√	○	○	0715
2006	WK-Grand Cherokee	SCM	√	√	√	√	√	○	√	
2006	WK-Grand Cherokee	WCM	√	√	√	√	√	○	√	0789,0790,0439,0741,0793,0794,0799,0800,0801,0802,1131,1188,1247,1248,1252,1255
2006	WK-Grand Cherokee	TM	○	√	√	○	√	○	○	
2006	WK-Grand Cherokee	SUNR	√	√	√	√	√	√	○	
2006	WK-Grand Cherokee	AHBM	√	√	√	√	√	√	○	
2006	WK-Grand Cherokee	PTS	√	√	√	√	√	√	○	1028,1030,1031,0267
2006	WK-Grand Cherokee	EDM	√	√	√	√	√	○	√	0370,1023
2006	WK-Grand Cherokee	ITM	√	√	√	√	√	√	√	0550
2006	WK-Grand Cherokee	RSM	√	√	√	√	√	○	○	0582
2006	WK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578
2006	WK-Grand Cherokee	RADIO	√	√	√	√	√	○	√	
2006	WK-Grand Cherokee	SDAR	√	√	√	√	√	○	○	
2006	WK-Grand Cherokee	AMP	√	√	√	√	√	○	√	0070,0072,0074,0078,0080,0083,0084
2006	WK-Grand Cherokee	HFM	√	√	√	√	√	√	○	0492
2006	WK-Grand Cherokee	VES	√	√	√	√	√	√	○	
2006	WK-Grand Cherokee	DDM	√	√	√	√	√	√	※	0668,0319
2006	WK-Grand Cherokee	PDM	√	√	√	√	√	√	※	0668,0319
2006	WK-Grand Cherokee	HSM	√	√	√	√	√	√	○	
2006	XK-Commander	PCM	√	√	√	√	√	√	√	0257,0293,0294,0589,1051,1199,0216,0320,0321,0449,0471,0538,0591,0660,0689,0690,0454,1123,0378,0629,0359,0827,1042,0590,0202,0215,0628,0692,0709,0710,0927,1054,1055
2006	XK-Commander	TCM	√	√	√	√	√	※	※	0011,0015,0016,0028,0032,0045,0049,0243,0830,0979,0983,1062,1063,1107,0924,1094
2006	XK-Commander	ESM	√	√	√	√	√	√	○	
2006	XK-Commander	FDCM	√	√	√	√	√	√	√	
2006	XK-Commander	CGW	√	√	√	√	√	√	√	0096,0129,0207,0331,0402,0412,0465,0508,0509,0527,0560,0795,0805,1075,1164
2006	XK-Commander	ORC	√	√	√	√	√	○	√	
2006	XK-Commander	MIC_CCN	√	√	√	√	√	√	√	0150,0152,0185,0187,0210,0619,1035,1036,1184
2006	XK-Commander	HVAC	√	√	√	√	√	√	○	0121,0277
2006	XK-Commander	MSM	√	√	√	√	√	○	○	0341,0382,0604,1023,1084,1151,0110
2006	XK-Commander	OCM	√	√	√	√	√	○	○	0715
2006	XK-Commander	SCM	√	√	√	√	√	○	√	
2006	XK-Commander	WCM	√	√	√	√	√	○	√	0789,0790,0439,0741,0793,0794,0799,0800,0801,0802,1131,1188,1247,1248,1252,1255
2006	XK-Commander	TM	○	√	√	○	√	○	○	
2006	XK-Commander	SUNR	√	√	√	√	√	√	○	
2006	XK-Commander	AHBM	√	√	√	√	√	√	○	
2006	XK-Commander	PTS	√	√	√	√	√	√	○	0267,1028,1030,1031
2006	XK-Commander	ITM	√	√	√	√	√	√	√	0550
2006	XK-Commander	RSM	√	√	√	√	√	○	√	0582
2006	XK-Commander	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578
2006	XK-Commander	RADIO	√	√	√	√	√	○	√	
2006	XK-Commander	SDAR	√	√	√	√	√	○	○	
2006	XK-Commander	AMP	√	√	√	√	√	○	√	0070,0072,0074,0078,0080,0083,0084
2006	XK-Commander	HFM	√	√	√	√	√	√	○	0492
2006	XK-Commander	VES	√	√	√	√	√	√	○	
2006	XK-Commander	DDM	√	√	√	√	√	√	※	0668,0319
2006	XK-Commander	PDM	√	√	√	√	√	√	※	0668,0319
2006	XK-Commander	HSM	√	√	√	√	√	√	○	
2007	CS-Pacifica	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,0229,0590,1107,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012
2007	CS-Pacifica	FDCM	√	√	√	√	√	○	√	
2007	CS-Pacifica	CGW	√	√	√	√	√	√	√	
2007	CS-Pacifica	ORC	√	√	√	√	√	○	√	
2007	CS-Pacifica	MIC_CCN	○	√	√	√	√	√	○	
2007	CS-Pacifica	PCM	○	√	√	√	√	√	○	
2007	CS-Pacifica	PLGM	√	√	√	√	√	√	√	0199,0200
2007	CS-Pacifica	ATC	○	√	√	√	√	√	○	
2007	CS-Pacifica	MTC	○	√	√	○	√	√	○	
2007	CS-Pacifica	MSM	○	√	√	√	√	√	○	
2007	CS-Pacifica	OCM	○	√	√	√	√	○	○	0282,0504,0715,0730,1073
2007	CS-Pacifica	PTS	○	√	√	√	√	○	○	
2007	CS-Pacifica	EDM	○	√	√	○	√	○	○	

2007	CS-Pacifica	SKM	○	√	√	○	√	√	○	0405, 0406, 0439, 0442, 0742, 0743, 0746, 0785, 0791, 0801, 0940, 1227, 1228, 1233, 1245, 1246, 1250, 1256, 1257
2007	CS-Pacifica	SAS	√	√	√	√	√	○	○	
2007	CS-Pacifica	ABS	√	√	√	√	√	√	√	0666, 0168, 0568, 0578
2007	CS-Pacifica	RADIO	○	√	√	○	√	√	○	
2007	CS-Pacifica	SDAR	○	√	√	√	√	√	○	
2007	CS-Pacifica	AMP	○	√	√	○	√	○	○	
2007	CS-Pacifica	NAV	○	√	√	○	√	○	○	
2007	CS-Pacifica	HPM	○	√	√	√	√	√	○	
2007	CS-Pacifica	DDM	○	√	√	√	√	√	○	
2007	CS-Pacifica	PDM	○	√	√	√	√	√	○	
2007	DR-RAM	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 0397, 0480, 0160, 0478, 0515, 0473, 0914, 0939, 1197, 0216, 0398, 0399, 0456, 0457, 0591, 0670, 0671, 0929, 0936, 1052, 1053, 1195, 0672, 1196, 0673, 0138, 0295, 0396, 0474, 1159, 1134, 1135, 0191, 0192, 0536, 1124
2007	DR-RAM	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0051, 0324, 1140, 0974, 0975, 0976, 0977, 1107, 0010, 0011, 0015, 0016, 0027, 0028, 0032, 0043, 0044, 0045, 0049, 0063, 0243, 0325, 0978, 0979, 0983, 0732, 0735, 0832, 0833, 0420
2007	DR-RAM	FDCM	√	√	√	√	√	○	○	0113, 0114, 0115, 0116, 0117, 0118
2007	DR-RAM	CGW	√	√	√	√	√	√	√	0331, 0465, 0508, 0510, 0527, 0660, 0795, 0897, 0900, 1076, 1155, 1219, 1224, 0095, 0125, 0254, 0425, 1225, 1226, 0129, 0402, 0810, 0816, 0817, 0752
2007	DR-RAM	ORC	√	√	√	√	√	○	√	
2007	DR-RAM	MIC_CCN	√	√	√	√	√	√	√	0152, 1023, 0150, 0187, 1184
2007	DR-RAM	HVAC	√	√	√	√	√	√	※	0122, 0124, 0277, 0461, 0680, 0121
2007	DR-RAM	WCM	√	√	√	√	√	○	√	0789, 0790, 0439, 0741, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255
2007	DR-RAM	SUNR	√	√	√	√	√	√	○	
2007	DR-RAM	EDM	√	√	√	√	√	√	√	0370, 1023
2007	DR-RAM	SAS	√	√	√	√	√	○	○	
2007	DR-RAM	ABS	√	√	√	√	√	√	√	0666, 0168, 0568, 0578
2007	DR-RAM	RADIO	√	√	√	√	√	○	√	
2007	DR-RAM	SDAR	√	√	√	√	√	○	○	
2007	DR-RAM	AMP	√	√	√	√	√	○	√	0072, 0073, 0074, 0080, 0081, 0083, 0084
2007	DR-RAM	HPM	√	√	√	√	√	√	○	0492
2007	DR-RAM	VES	√	√	√	√	√	√	○	
2007	HB-Durango	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012
2007	HB-Durango	CGW	√	√	√	√	√	√	√	0506, 0510, 0560, 1076, 1139, 0095, 0863, 0425, 0465, 1164, 0096, 0129, 0207, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 1075, 1154, 1262, 1263, 1274
2007	HB-Durango	ORC	√	√	√	√	√	○	√	
2007	HB-Durango	MIC_CCN	√	√	√	√	√	√	√	1014, 1023, 0150, 0152, 0332, 1184
2007	HB-Durango	HVAC	√	√	√	√	√	√	※	0121, 0124, 0277, 0461, 0680, 0888, 0546
2007	HB-Durango	PLGM	√	√	√	√	√	√	√	0199, 0200
2007	HB-Durango	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2007	HB-Durango	WCM	√	√	√	√	√	○	√	0789, 0790, 0439, 0741, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255
2007	HB-Durango	PTIM	√	√	√	√	√	√	√	
2007	HB-Durango	PTS	√	√	√	√	√	√	√	0267, 1028, 1030, 1031
2007	HB-Durango	EDM	√	√	√	√	√	※	√	1023, 0370
2007	HB-Durango	SAS	√	√	√	√	√	○	○	
2007	HB-Durango	ABS	√	√	√	√	√	√	√	0666, 0168, 0568, 0578
2007	HB-Durango	RADIO	√	√	√	√	√	○	√	
2007	HB-Durango	SDAR	√	√	√	√	√	○	○	
2007	HB-Durango	AMP	√	√	√	√	√	○	√	0069, 0074, 0077, 0083, 0085
2007	HB-Durango	HPM	√	√	√	√	√	√	○	0492
2007	HB-Durango	VES	√	√	√	√	√	√	○	
2007	HB-Durango	DDM	√	√	√	√	√	√	※	0668, 0319
2007	HB-Durango	PDM	√	√	√	√	√	√	※	0668, 0319
2007	HB-Durango	HSM	√	√	√	√	√	√	√	

2007	HG-Aspen	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012
2007	HG-Aspen	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1076, 1139, 1164, 0096, 0129, 0207, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 1075, 1154, 1262, 1263, 1274
2007	HG-Aspen	ORC	√	√	√	√	√	○	√	
2007	HG-Aspen	MIC_CCN	√	√	√	√	√	√	√	1014, 1023, 0150, 0152, 0332, 1184
2007	HG-Aspen	HVAC	√	√	√	√	√	√	※	0121, 0124, 0277, 0461, 0680, 0888, 0546
2007	HG-Aspen	PLGM	√	√	√	√	√	√	√	0199, 0200
2007	HG-Aspen	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2007	HG-Aspen	WCM	√	√	√	√	√	○	√	0789, 0790, 0439, 0741, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255
2007	HG-Aspen	PTS	√	√	√	√	√	√	√	0267, 1028, 1030, 1031
2007	HG-Aspen	EDM	√	√	√	√	√	※	√	0370
2007	HG-Aspen	SAS	√	√	√	√	√	○	○	
2007	HG-Aspen	ABS	√	√	√	√	√	√	√	0666, 0168, 0568, 0578
2007	HG-Aspen	RADIO	√	√	√	√	√	○	√	
2007	HG-Aspen	SDAR	√	√	√	√	√	○	○	
2007	HG-Aspen	AMP	√	√	√	√	√	○	√	0069, 0074, 0077, 0083, 0086, 0085
2007	HG-Aspen	HFM	√	√	√	√	√	○	○	0492
2007	HG-Aspen	VES	√	√	√	√	√	√	○	
2007	HG-Aspen	DDM	√	√	√	√	√	√	※	0668, 0319
2007	HG-Aspen	PDM	√	√	√	√	√	√	※	0668, 0319
2007	HG-Aspen	HSM	√	√	√	√	√	√	√	
2007	JK-Wrangler	PCM	√	√	√	√	√	√	※	0257, 0293, 0294, 0322, 0323, 0336, 0356, 0471, 0538, 0589, 0591, 0820, 0216, 0923, 0926, 1034, 1047, 1222, 1123, 0355, 1051, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 0202, 1012
2007	JK-Wrangler	TCM	√	√	√	√	√	√	○	0007, 0008, 0009, 0033, 0024, 0025, 0026, 0040, 0041, 0042, 1140, 0975, 0976, 0977, 0005, 0022, 0038, 0051, 0243, 0324, 0974, 1107, 0732, 0735, 0832, 0833
2007	JK-Wrangler	CGW	√	√	√	√	√	√	√	0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 1182, 1220, 0152, 0108, 0095, 0150, 0402, 0795, 0812
2007	JK-Wrangler	ORC	√	√	√	√	√	○	√	
2007	JK-Wrangler	MIC_CCN	√	√	√	√	√	√	√	1023, 1186, 1014
2007	JK-Wrangler	OCM	√	√	√	√	√	○	○	0715
2007	JK-Wrangler	ASBS	√	√	√	√	√	○	○	1071, 1098, 1099, 1100, 1101
2007	JK-Wrangler	WCM	√	√	√	√	√	○	√	1131, 0439, 0741, 0793, 0794, 0800, 0801, 1244, 1251
2007	JK-Wrangler	ITM	√	√	√	√	√	√	√	
2007	JK-Wrangler	SAS	√	√	√	√	√	○	○	
2007	JK-Wrangler	ABS	√	√	√	√	√	√	√	0666, 0168, 0568, 0578
2007	JK-Wrangler	RADIO	√	√	√	√	√	※	※	0426, 0861, 0867, 0871
2007	JK-Wrangler	AMP	√	√	√	√	√	○	√	0083, 0074
2007	JS-Avenger,Sebring,Convertible/Sedan	PCM	√	√	√	√	√	√	√	1048, 0257, 0294, 0311, 0216, 0820, 0281, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012, 0340, 0377, 0480, 1054, 0127
2007	JS-Avenger,Sebring,Convertible/Sedan	TCM	√	√	√	√	√	√	※	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0051, 0324, 1140, 0974, 0975, 0976, 0977, 1107, 0010, 0011, 0015, 0016, 0027, 0028, 0032, 0043, 0044, 0045, 0049, 0053, 0243, 0325, 0978, 0979, 0983, 0732, 0735, 0832, 0833, 0230, 0834, 0830, 1062, 1063
2007	JS-Avenger,Sebring,Convertible/Sedan	FDCM	√	√	√	√	√	○	√	
2007	JS-Avenger,Sebring,Convertible/Sedan	CGW	√	√	√	√	√	√	√	0331, 0465, 0508, 0510, 0527, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0254, 0425, 0503, 0402, 0810, 0816, 0817, 0752
2007	JS-Avenger,Sebring,Convertible/Sedan	ORC	√	√	√	√	√	○	√	
2007	JS-Avenger,Sebring,Convertible/Sedan	MIC_CCN	√	√	√	√	√	√	√	1186, 1023, 0152, 1014, 0150, 0187, 0619, 0666, 1015
2007	JS-Avenger,Sebring,Convertible/Sedan	HVAC	√	√	√	√	√	√	√	0121, 0277, 0462, 0680
2007	JS-Avenger,Sebring,Convertible/Sedan	WCM	√	√	√	√	√	○	√	0789, 0790, 0439, 0741, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255

2007	JS-Avenger,Sebring,Convertible/Sedan	ITM	√	√	√	√	√	√	√	0550
2007	JS-Avenger,Sebring,Convertible/Sedan	PTCM	√	√	√	√	√	○	√	0661,0893
2007	JS-Avenger,Sebring,Convertible/Sedan	SAS	√	√	√	√	√	○	○	
2007	JS-Avenger,Sebring,Convertible/Sedan	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578
2007	JS-Avenger,Sebring,Convertible/Sedan	RADIO	√	√	√	√	√	※	※	0861,0867,0871,0426
2007	JS-Avenger,Sebring,Convertible/Sedan	AMP	√	√	√	√	√	○	√	0069,0074,0077,0083,0086
2007	JS-Avenger,Sebring,Convertible/Sedan	HFM	√	√	√	√	√	√	○	0492
2007	JS-Avenger,Sebring,Convertible/Sedan	VES3	√	√	√	√	√	√	√	
2007	JS-Avenger,Sebring,Convertible/Sedan	DDM	√	√	√	√	√	√	○	0319
2007	JS-Avenger,Sebring,Convertible/Sedan	PDM	√	√	√	√	√	√	○	0319
2007	KA-Nitro	PCM	√	√	√	√	√	√	※	0257,0293,0294,0322,0323,0336,0356,1123,0471,0538,0589,0591,0820,0923,0926,1034,1047,1222,0216,0355,1051,0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0709,0710,0927,0981,1111,0698,0699,0732,0735,0830,0833,1140,0454,0202,1
2007	KA-Nitro	TCM	√	√	√	√	√	○	○	0924,1094
2007	KA-Nitro	ESM	√	√	√	√	√	√	○	
2007	KA-Nitro	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152,0402,0795,0812
2007	KA-Nitro	ORC	√	√	√	√	√	○	√	
2007	KA-Nitro	MIC CCN	√	√	√	√	√	√	√	1186,1014,1023
2007	KA-Nitro	HVAC	√	√	√	√	√	√	√	0121,0277,0462,0680
2007	KA-Nitro	OCM	√	√	√	√	√	○	○	0715
2007	KA-Nitro	WCM	√	√	√	√	√	○	√	1131,0439,0741,0793,0794,0800,0801,1244,1251
2007	KA-Nitro	PTS	√	√	√	√	√	√	√	0267,1028,1030,1031
2007	KA-Nitro	ITM	√	√	√	√	√	√	√	0550
2007	KA-Nitro	SAS	√	√	√	√	√	○	○	
2007	KA-Nitro	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578
2007	KA-Nitro	RADIO	√	√	√	√	√	※	※	0861,0867,0871,0426
2007	KA-Nitro	AMP	√	√	√	√	√	○	√	0083,0074
2007	KA-Nitro	HFM	√	√	√	√	√	√	○	0492
2007	KA-Nitro	VES3	√	√	√	√	√	√	√	
2007	KA-Nitro	DMFR	√	√	√	√	√	√	√	
2007	KA-Nitro	DMFL	√	√	√	√	√	√	√	
2007	KJ-Liberty	PCM	※	√	√	√	√	√	※	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012,0629,0692,0927,1054,1055
2007	KJ-Liberty	TCM	○	√	√	√	√	√	○	
2007	KJ-Liberty	ORC	○	√	√	○	√	○	○	
2007	KJ-Liberty	MIC CCN	○	√	√	○	√	√	○	0187,0227,0263,1016,1017
2007	KJ-Liberty	OCM	○	√	√	√	√	○	○	0282,0715,0730,0928
2007	KJ-Liberty	BCM	○	√	√	√	√	√	○	
2007	KJ-Liberty	EDM	○	√	√	○	√	○	○	
2007	KJ-Liberty	ITM	√	√	√	○	√	√	○	
2007	KJ-Liberty	SKM	○	√	√	○	√	√	○	0405,0406,0439,0442,0742,0743,0746,0785,0791,0801,0940,1227,1228,1233,1245,1246,1250,1256,1257
2007	KJ-Liberty	SAS	√	√	√	√	√	○	○	
2007	KJ-Liberty	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578
2007	KJ-Liberty	RADIO	√	√	√	√	√	√	√	
2007	KJ-Liberty	SDAR	○	√	√	√	√	√	○	
2007	KJ-Liberty	HFM	○	√	√	√	√	√	○	
2007	LX-300,Charger,Magnum,Grand Voyager	PCM	√	√	√	√	√	√	√	0257,0293,0294,0589,1051,1199,0216,0320,0321,0449,0471,0538,0591,0660,0689,0690,0454,1123,0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0010,0013,0027,0030,0043,0047,0053,0215,0243,0709,0710,0927,0981,1111,0698,0699,0732,0735,0830,0833,1140,0202,1012
2007	LX-300,Charger,Magnum,Grand Voyager	TCM	√	√	√	√	√	○	○	0924,1094
2007	LX-300,Charger,Magnum,Grand Voyager	ESM	√	√	√	√	√	√	○	
2007	LX-300,Charger,Magnum,Grand Voyager	ACC	√	√	√	√	√	○	√	0139,0208,0064,0062,0063
2007	LX-300,Charger,Magnum,Grand Voyager	CGW	√	√	√	√	√	√	√	0768,0096,0129,0207,0331,0402,0412,0465,0508,0509,0527,0560,0795,0805,1075
2007	LX-300,Charger,Magnum,Grand Voyager	ORC	√	√	√	√	√	○	√	
2007	LX-300,Charger,Magnum,Grand Voyager	MIC CCN	√	√	√	√	√	√	○	0209,1186,1014,1184,0150,0152
2007	LX-300,Charger,Magnum,Grand Voyager	HVAC	√	√	√	√	√	√	○	0121,0277,0461,0680
2007	LX-300,Charger,Magnum,Grand Voyager	MSM	√	√	√	√	√	○	○	0341,0382,0604,1023,1084,1151,0110
2007	LX-300,Charger,Magnum,Grand Voyager	SCM	√	√	√	√	√	√	√	

2007	LX-300,Charger,Magnum,Grand Voyager	WCM	√	√	√	√	√	○	√	0439,0741,0789,0790,1244,0793,0794,0799,0800,0801,0802,1131,1188,1247,1248,1252,1255
2007	LX-300,Charger,Magnum,Grand Voyager	SUNR	√	√	√	√	√	√	○	
2007	LX-300,Charger,Magnum,Grand Voyager	PTIM	√	√	√	√	√	√	√	
2007	LX-300,Charger,Magnum,Grand Voyager	HIDT	√	√	√	√	√	√	○	0196
2007	LX-300,Charger,Magnum,Grand Voyager	AHBM	√	√	√	√	√	√	○	0068
2007	LX-300,Charger,Magnum,Grand Voyager	PTS	√	√	√	√	√	√	○	0267,1028,1030,1031
2007	LX-300,Charger,Magnum,Grand Voyager	EDM	√	√	√	√	√	○	√	0370,1023
2007	LX-300,Charger,Magnum,Grand Voyager	ITM	√	√	√	√	√	√	√	0550
2007	LX-300,Charger,Magnum,Grand Voyager	RSM	√	√	√	√	√	○	○	0582
2007	LX-300,Charger,Magnum,Grand Voyager	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578
2007	LX-300,Charger,Magnum,Grand Voyager	RADIO	√	√	√	√	√	○	√	
2007	LX-300,Charger,Magnum,Grand Voyager	SDAR	√	√	√	√	√	○	○	
2007	LX-300,Charger,Magnum,Grand Voyager	AMP	√	√	√	√	√	○	√	0069,0074,0079,0083,0084,0070,0071,0072,0078,0080
2007	LX-300,Charger,Magnum,Grand Voyager	HFM	√	√	√	√	√	√	○	0492
2007	LX-300,Charger,Magnum,Grand Voyager	VES	√	√	√	√	√	√	○	
2007	LX-300,Charger,Magnum,Grand Voyager	DDM	√	√	√	√	√	√	※	
2007	LX-300,Charger,Magnum,Grand Voyager	PDM	√	√	√	√	√	√	※	0668
2007	LX-300,Charger,Magnum,Grand Voyager	HSM	√	√	√	√	√	√	√	
2007	MK-Compass,Patriot	PCM	√	√	√	√	√	√	√	1048,0257,0294,0311,0216,0281,0454,1123,0820,0340,0373,0377,0378,0480,0590,0827,1042,0409,0215,0589,0628,0927,1054,0127
2007	MK-Compass,Patriot	TCM	√	√	√	√	√	√	√	
2007	MK-Compass,Patriot	FDCM	√	√	√	√	√	√	√	
2007	MK-Compass,Patriot	CGW	√	√	√	√	√	√	√	0331,0465,0508,0510,0527,0560,0796,0900,1076,1155,1219,1224,1225,1226,0095,0125,0129,0425,0402,0810,0816,0817,0752
2007	MK-Compass,Patriot	ORC	√	√	√	√	√	○	√	
2007	MK-Compass,Patriot	MIC_CCN	√	√	√	√	√	√	√	1014,1186,1023,0152,0150,0187,0619,0666,1015
2007	MK-Compass,Patriot	OCM	√	√	√	√	√	○	○	0715
2007	MK-Compass,Patriot	WCM	√	√	√	√	√	○	√	0789,0790,0439,0741,0793,0794,0799,0800,0801,0802,1131,1188,1247,1248,1252,1255
2007	MK-Compass,Patriot	ITM	√	√	√	√	√	√	√	0550
2007	MK-Compass,Patriot	SAS	√	√	√	√	√	○	○	
2007	MK-Compass,Patriot	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578
2007	MK-Compass,Patriot	RADIO	√	√	√	√	√	○	√	
2007	MK-Compass,Patriot	SDAR	√	√	√	√	√	○	○	
2007	MK-Compass,Patriot	AMP	√	√	√	√	√	○	√	0070,0072,0074,0078,0080,0083,0084
2007	MK-Compass,Patriot	HFM	√	√	√	√	√	※	○	0492
2007	ND-Dakota	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0927,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012
2007	ND-Dakota	CGW	√	√	√	√	√	√	√	0095,0863,0425,0465,0506,0510,0560,1076,1139,1164,0096,0129,0207,0331,0412,0489,0490,0508,0509,0527,0684,0685,0686,0795,1075,1154,1262,1263,1274
2007	ND-Dakota	ORC	√	√	√	√	√	○	√	
2007	ND-Dakota	MIC_CCN	√	√	√	√	√	√	√	1014,1023,0150,0152,0332,1184
2007	ND-Dakota	HVAC	√	√	√	√	√	√	√	0121,0124,0277,0461,0680
2007	ND-Dakota	OCM	√	√	√	√	√	○	○	0715
2007	ND-Dakota	WCM	√	√	√	√	√	○	√	0789,0790,0439,0741,0793,0794,0799,0800,0801,0802,1131,1188,1247,1248,1252,1255
2007	ND-Dakota	EDM	√	√	√	√	√	※	√	0370,1023
2007	ND-Dakota	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578
2007	ND-Dakota	RADIO	√	√	√	√	√	○	√	
2007	ND-Dakota	SDAR	√	√	√	√	√	○	○	
2007	ND-Dakota	AMP	√	√	√	√	√	○	√	0069,0074,0077,0083,0086,0085
2007	NM-Raider	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0927,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012
2007	NM-Raider	CGW	√	√	√	√	√	√	√	0095,0863,0425,0465,0506,0510,0560,1076,1139,1164,0096,0129,0207,0331,0412,0489,0490,0508,0509,0527,0684,0685,0686,0795,1075,1154,1262,1263,1274
2007	NM-Raider	ORC	√	√	√	√	√	○	√	
2007	NM-Raider	MIC_CCN	√	√	√	√	√	√	√	1014,1023,0150,0152,0332,1184
2007	NM-Raider	HVAC	√	√	√	√	√	√	√	0121,0124,0277,0461,0680
2007	NM-Raider	OCM	√	√	√	√	√	○	○	0715
2007	NM-Raider	WCM	√	√	√	√	√	○	√	0789,0790,0439,0741,0793,0794,0799,0800,0801,0802,1131,1188,1247,1248,1252,1255
2007	NM-Raider	EDM	√	√	√	√	√	※	√	0370,1023

2007	NM-Raider	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578
2007	NM-Raider	RADIO	√	√	√	√	√	○	√	
2007	NM-Raider	SDAR	√	√	√	√	√	○	○	
2007	NM-Raider	AMP	√	√	√	√	√	○	√	0069, 0074, 0077, 0083, 0086, 0085
2007	PM-Caliber	PCM	√	√	√	√	√	√	√	1048, 0257, 0294, 0311, 0216, 0281, 0454, 1123, 0820, 0340, 0373, 0377, 0378, 0480, 0590, 0827, 1042, 0409, 0215, 0589, 0628, 0927, 1054, 0127
2007	PM-Caliber	TCM	√	√	√	√	√	√	√	
2007	PM-Caliber	FDCM	√	√	√	√	√	√	√	
2007	PM-Caliber	CGW	√	√	√	√	√	√	√	0331, 0465, 0508, 0510, 0527, 0560, 0795, 0900, 1076, 1155, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0425, 0402, 0810, 0816, 0817, 0752
2007	PM-Caliber	ORC	√	√	√	√	√	○	√	
2007	PM-Caliber	MIC_CCN	√	√	√	√	√	√	√	1014, 1186, 1023, 0152, 0150, 0187, 0619, 0666, 1015
2007	PM-Caliber	OCM	√	√	√	√	√	○	○	0715
2007	PM-Caliber	WCM	√	√	√	√	√	○	√	0789, 0790, 0439, 0741, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255
2007	PM-Caliber	ITM	√	√	√	√	√	√	√	0550
2007	PM-Caliber	SAS	√	√	√	√	√	○	○	
2007	PM-Caliber	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578
2007	PM-Caliber	RADIO	√	√	√	√	√	○	√	
2007	PM-Caliber	SDAR	√	√	√	√	√	○	○	
2007	PM-Caliber	AMP	√	√	√	√	√	○	√	0070, 0072, 0074, 0078, 0080, 0083, 0084
2007	PM-Caliber	HFM	√	√	√	√	√	※	○	0492
2007	PT-PT Cruiser	PCM	※	√	√	√	√	√	※	0257, 0293, 0294, 0538, 0589, 1051, 0216, 0691, 0454, 1123, 0378, 0629, 0359, 0827, 1042, 0590, 0409, 0202, 0215, 0628, 0692, 0709, 0710, 0927, 1054, 1055
2007	PT-PT Cruiser	TCM	√	√	√	√	√	√	√	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0243, 0830, 0979, 0983, 1062, 1063, 1107, 0230, 0834
2007	PT-PT Cruiser	CGW	※	√	√	※	√	※	※	0108, 0119, 0331, 0465, 0508, 0510, 0527, 0560, 1076, 0095, 0125, 0425, 0402, 0810, 0816, 0817, 0752
2007	PT-PT Cruiser	ORC	√	√	√	√	√	○	√	
2007	PT-PT Cruiser	MIC_CCN	√	√	√	√	√	√	√	0150, 0152, 0187, 0619, 0666, 1015
2007	PT-PT Cruiser	OCM	√	√	√	√	√	○	○	0715
2007	PT-PT Cruiser	WCM	√	√	√	√	√	○	√	0789, 0790, 0439, 0741, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255
2007	PT-PT Cruiser	ITM	√	√	√	√	√	√	√	0579
2007	PT-PT Cruiser	ABS	√	√	√	√	√	√	√	0056, 0168, 0567, 0575, 0585
2007	PT-PT Cruiser	RADIO	√	√	√	√	√	○	√	
2007	PT-PT Cruiser	SDAR	√	√	√	√	√	○	○	
2007	PT-PT Cruiser	AMP	√	√	√	√	√	○	√	0070, 0072, 0074, 0078, 0080, 0083, 0084
2007	PT-PT Cruiser	HFM	√	√	√	√	√	√	○	0492
2007	PT-PT Cruiser	DDM	√	√	√	√	√	√	○	
2007	PT-PT Cruiser	PDM	√	√	√	√	√	√	○	
2007	VB-Sprinter	ECM	√	√	√	√	√	√	√	0350, 0203, 0220, 0433, 0475, 0711, 0911, 1147, 0294, 0320, 0321, 0359, 0448, 0689, 0660, 0662, 0805, 0874, 1043, 0257, 0591
2007	VB-Sprinter	TCM	√	√	√	√	√	○	○	0350, 1117, 0677, 1065, 1112, 1174
2007	VB-Sprinter	ESM	√	√	√	√	√	√	○	
2007	VB-Sprinter	CGW	√	√	√	√	√	○	√	0904, 0350
2007	VB-Sprinter	ORC	√	√	√	○	√	○	○	0930, 1033, 0717, 0350
2007	VB-Sprinter	MIC_CCN	√	√	√	√	√	○	○	0350, 0184, 0283, 0284, 0285, 0286, 0287, 0481, 0723, 0765, 1078, 1190, 0828, 0186
2007	VB-Sprinter	HVAC	√	√	√	√	√	√	√	0632
2007	VB-Sprinter	BCM	√	√	√	√	√	√	○	
2007	VB-Sprinter	ACM	√	√	√	√	√	√	○	
2007	VB-Sprinter	SCM	√	√	√	√	√	√	○	
2007	VB-Sprinter	BCM	√	√	√	√	√	√	○	0327
2007	VB-Sprinter	PSM	√	√	√	√	√	√	○	0350
2007	VB-Sprinter	TM	√	√	√	√	√	○	○	
2007	VB-Sprinter	AHLM	√	√	√	√	√	√	○	0193, 0350
2007	VB-Sprinter	RCM	√	√	√	√	√	√	○	
2007	VB-Sprinter	AEHM	√	√	√	√	√	○	○	0065
2007	VB-Sprinter	PTS	√	√	√	√	√	√	√	0140, 0608
2007	VB-Sprinter	TPM	√	√	√	√	√	○	○	0350, 0636, 0637, 0984, 0985, 1156, 1205, 1207, 1213
2007	VB-Sprinter	ABS	√	√	√	√	√	○	√	0168, 0195, 0342, 0100, 0350
2007	VB-Sprinter	SBM	√	√	√	√	√	√	○	
2007	VB-Sprinter	CDC	√	√	√	√	√	○	○	
2007	VB-Sprinter	RADIO	√	√	√	√	√	○	○	0350
2007	VB-Sprinter	HFM	√	√	√	√	√	○	○	0350
2007	VB-Sprinter	DDM	√	√	√	√	√	√	○	

2007	WK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0538, 0591, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012
2007	WK-Grand Cherokee	TCM	√	√	√	√	√	○	○	0924, 1094
2007	WK-Grand Cherokee	ESM	√	√	√	√	√	√	○	
2007	WK-Grand Cherokee	FDCM	√	√	√	√	√	√	√	
2007	WK-Grand Cherokee	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1076, 1139, 1164, 0096, 0129, 0207, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 1075, 1154, 1262, 1263, 1274
2007	WK-Grand Cherokee	OBC	√	√	√	√	√	○	√	
2007	WK-Grand Cherokee	MIC_CCN	√	√	√	√	√	√	√	1184, 1186, 1023, 0150, 0152, 0185, 0187, 0210, 0619, 1035, 1036
2007	WK-Grand Cherokee	HVAC	√	√	√	√	√	√	○	0121, 0277, 0461, 0680
2007	WK-Grand Cherokee	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2007	WK-Grand Cherokee	SCM	√	√	√	√	√	○	√	
2007	WK-Grand Cherokee	WCM	√	√	√	√	√	○	√	0789, 0790, 0439, 0741, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255
2007	WK-Grand Cherokee	TM	○	√	√	○	√	○	○	
2007	WK-Grand Cherokee	SUNR	√	√	√	√	√	√	○	
2007	WK-Grand Cherokee	AHBM	√	√	√	√	√	√	○	0068
2007	WK-Grand Cherokee	PTS	√	√	√	√	√	√	○	0267, 1028, 1030, 1031
2007	WK-Grand Cherokee	EDM	√	√	√	√	√	○	√	0370, 1023
2007	WK-Grand Cherokee	ITM	√	√	√	√	√	√	√	0550
2007	WK-Grand Cherokee	RSM	√	√	√	√	√	○	○	0582
2007	WK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0666, 0168, 0568, 0578
2007	WK-Grand Cherokee	RADIO	√	√	√	√	√	○	√	
2007	WK-Grand Cherokee	SDAR	√	√	√	√	√	○	○	
2007	WK-Grand Cherokee	AMP	√	√	√	√	√	○	√	0069, 0074, 0079, 0083, 0084, 0070, 0072, 0078, 0080
2007	WK-Grand Cherokee	HFM	√	√	√	√	√	√	○	0492
2007	WK-Grand Cherokee	VES	√	√	√	√	√	√	○	
2007	WK-Grand Cherokee	DDM	√	√	√	√	√	√	※	0668, 0319
2007	WK-Grand Cherokee	PDM	√	√	√	√	√	√	※	0668, 0319
2007	WK-Grand Cherokee	HESM	√	√	√	√	√	√	√	
2007	XK-Commander	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0538, 0591, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012
2007	XK-Commander	TCM	√	√	√	√	√	○	○	0924, 1094
2007	XK-Commander	ESM	√	√	√	√	√	√	○	
2007	XK-Commander	FDCM	√	√	√	√	√	√	√	
2007	XK-Commander	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1076, 1139, 1164, 0096, 0129, 0207, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 1075, 1154, 1262, 1263, 1274
2007	XK-Commander	OBC	√	√	√	√	√	○	√	
2007	XK-Commander	MIC_CCN	√	√	√	√	√	√	√	1184, 1186, 1023, 0150, 0152, 0185, 0187, 0210, 0619, 1035, 1036
2007	XK-Commander	HVAC	√	√	√	√	√	√	○	0121, 0277, 0461, 0680
2007	XK-Commander	PLGM	√	√	√	√	√	√	√	0199, 0200
2007	XK-Commander	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2007	XK-Commander	SCM	√	√	√	√	√	○	√	
2007	XK-Commander	WCM	√	√	√	√	√	○	√	0789, 0790, 0439, 0741, 0793, 0794, 0799, 0800, 0801, 0802, 1131, 1188, 1247, 1248, 1252, 1255
2007	XK-Commander	TM	○	√	√	○	√	○	○	
2007	XK-Commander	SUNR	√	√	√	√	√	√	○	
2007	XK-Commander	AHBM	√	√	√	√	√	√	○	0068
2007	XK-Commander	PTS	√	√	√	√	√	√	○	0267, 1028, 1030, 1031
2007	XK-Commander	ITM	√	√	√	√	√	√	√	0550
2007	XK-Commander	RSM	√	√	√	√	√	○	○	0582
2007	XK-Commander	ABS	√	√	√	√	√	√	√	0666, 0168, 0568, 0578
2007	XK-Commander	RADIO	√	√	√	√	√	○	√	
2007	XK-Commander	SDAR	√	√	√	√	√	○	○	
2007	XK-Commander	AMP	√	√	√	√	√	○	√	0069, 0074, 0079, 0083, 0084, 0070, 0072, 0078, 0080
2007	XK-Commander	HFM	√	√	√	√	√	√	○	0492
2007	XK-Commander	VES	√	√	√	√	√	√	○	
2007	XK-Commander	DDM	√	√	√	√	√	√	※	0668, 0319
2007	XK-Commander	PDM	√	√	√	√	√	√	※	0668, 0319

2007	XK-Commander	HSM	√	√	√	√	√	√	√	
2007	ZH-Crossfire(NAFTA)	PCM	√	√	√	√	√	√	○	
2007	ZH-Crossfire(NAFTA)	TCM	√	√	√	√	√	○	○	
2007	ZH-Crossfire(NAFTA)	SLA	√	√	√	√	√	√	○	
2007	ZH-Crossfire(NAFTA)	ORC	√	√	√	√	√	○	○	
2007	ZH-Crossfire(NAFTA)	HVAC	√	√	√	√	√	√	○	
2007	ZH-Crossfire(NAFTA)	OCM	√	√	√	√	√	○	○	
2007	ZH-Crossfire(NAFTA)	BCM	√	√	√	√	√	√	○	
2007	ZH-Crossfire(NAFTA)	PTCM	√	√	√	√	√	√	○	
2007	ZH-Crossfire(NAFTA)	SKM	√	√	√	√	√	√	○	
2007	ZH-Crossfire(NAFTA)	TPM	√	√	√	√	√	○	○	1093,1130
2007	ZH-Crossfire(NAFTA)	ESP	√	√	√	√	√	√	○	
2007	ZH-Crossfire(NAFTA)	IC	√	√	√	√	√	√	○	
2007	ZH-Crossfire(NAFTA)	CLP	√	√	√	○	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	PCM	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	TCM	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	ORC	○	√	√	√	√	○	○	
2007	RS-Caravan, Voyager, Town & Country	MIC CCN	○	√	√	○	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	PCM	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	PLGM	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	ATC	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	MTC	○	√	√	○	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	MSM	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	OCM	○	√	√	√	√	○	○	
2007	RS-Caravan, Voyager, Town & Country	BCM	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	PTS	○	√	√	√	√	○	○	
2007	RS-Caravan, Voyager, Town & Country	EDM	○	√	√	○	√	○	○	
2007	RS-Caravan, Voyager, Town & Country	SKM	○	√	√	○	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	ABS	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	RADIO	√	√	√	√	√	√	√	
2007	RS-Caravan, Voyager, Town & Country	SDAR	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	AMP	○	○	○	○	○	○	○	
2007	RS-Caravan, Voyager, Town & Country	HPM	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	PSDMR	○	√	√	√	√	√	○	
2007	RS-Caravan, Voyager, Town & Country	PSDML	○	√	√	√	√	√	○	
2008	CS-Pacifica	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012
2008	CS-Pacifica	FDCM	√	√	√	√	√	○	√	
2008	CS-Pacifica	CGW	√	√	√	√	√	√	√	
2008	CS-Pacifica	CGW	√	√	√	√	√	√	√	
2008	CS-Pacifica	ORC	√	√	√	√	√	○	√	
2008	CS-Pacifica	MIC CCN	○	√	√	√	√	√	○	
2008	CS-Pacifica	PCM	○	√	√	√	√	√	○	
2008	CS-Pacifica	PLGM	√	√	√	√	√	√	√	0199, 0200
2008	CS-Pacifica	ATC	○	√	√	√	√	√	○	
2008	CS-Pacifica	MTC	○	√	√	○	√	√	○	
2008	CS-Pacifica	MSM	○	√	√	√	√	√	○	
2008	CS-Pacifica	OCM	○	√	√	√	√	○	○	0282, 0504, 0715, 0730, 1073
2008	CS-Pacifica	PTS	○	√	√	√	√	○	○	
2008	CS-Pacifica	EDM	○	√	√	○	√	○	○	
2008	CS-Pacifica	SKM	○	√	√	○	√	√	○	0405, 0406, 0439, 0442, 0742, 0743, 0746, 0785, 0791, 0801, 0940, 1227, 1228, 1233, 1245, 1246, 1250, 1256, 1257
2008	CS-Pacifica	SAS	√	√	√	√	√	○	○	
2008	CS-Pacifica	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578
2008	CS-Pacifica	RADIO	○	√	√	○	√	√	○	
2008	CS-Pacifica	SDAR	○	√	√	√	√	√	○	
2008	CS-Pacifica	SDAR	○	√	√	√	√	√	○	
2008	CS-Pacifica	AMP	○	√	√	○	√	○	○	
2008	CS-Pacifica	NAV	○	√	√	○	√	○	○	
2008	CS-Pacifica	HPM	○	√	√	√	√	√	○	
2008	CS-Pacifica	DDM	○	√	√	√	√	√	○	
2008	CS-Pacifica	PDM	○	√	√	√	√	√	○	
2008	DR-RAM	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 0478, 0515, 0397, 0473, 0480, 0914, 0939, 1197, 0160, 0216, 0398, 0399, 0456, 0457, 0591, 0670, 0671, 0929, 0936, 1052, 1053, 1195, 0672, 1196, 0673, 0138, 0295, 0396, 0474, 1159, 1134, 1135, 0191, 0192, 0536, 1124

2008	DR-RAM	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0651, 0324, 1140, 0974, 0975, 0976, 0977, 1107, 0010, 0011, 0015, 0016, 0027, 0028, 0032, 0043, 0044, 0045, 0049, 0053, 0243, 0325, 0978, 0979, 0983, 0732, 0735, 0832 0833, 0420
2008	DR-RAM	FDCM	√	√	√	√	√	○	○	0113, 0114, 0115, 0116, 0117, 0118
2008	DR-RAM	CGW	√	√	√	√	√	√	√	0119, 0331, 0465, 0508, 0510, 0527, 0560, 0795, 0897, 0900, 1076, 1155, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0254, 0425, 0402, 0810, 0816, 0817, 0752
2008	DR-RAM	ORC	√	√	√	√	√	○	√	
2008	DR-RAM	MIC_CCN	√	√	√	√	√	√	√	1023, 0152, 0150, 0187, 1184
2008	DR-RAM	HVAC	√	√	√	√	√	√	※	0122, 0124, 0277, 0461, 0680, 0121
2008	DR-RAM	WCM	√	√	√	√	√	○	√	1131, 0789, 0790, 0439, 0741, 0793, 0799, 0802, 1247, 1248, 1252, 1255, 1132
2008	DR-RAM	SUNR	√	√	√	※	√	√	○	
2008	DR-RAM	EDM	√	√	√	√	√	√	√	0370, 1023
2008	DR-RAM	SAS	√	√	√	√	√	○	○	
2008	DR-RAM	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2008	DR-RAM	RADIO	√	√	√	√	√	○	√	
2008	DR-RAM	SDAR	√	√	√	√	√	○	○	
2008	DR-RAM	AMP	√	√	√	√	√	○	√	0072, 0073, 0074, 0080, 0081, 0083, 0084
2008	DR-RAM	HFM	√	√	√	√	√	√	○	0492
2008	DR-RAM	VES	√	√	√	√	√	√	○	
2008	HB-Durango	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123 0202, 1012
2008	HB-Durango	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274
2008	HB-Durango	ORC	√	√	√	√	√	○	√	
2008	HB-Durango	MIC_CCN	√	√	√	√	√	√	√	1014, 1023, 0150, 0152, 0332, 1184
2008	HB-Durango	HVAC	√	√	√	√	√	√	※	0121, 0124, 0277, 0461, 0680, 0888, 0546
2008	HB-Durango	PLGM	√	√	√	√	√	√	√	0199, 0200
2008	HB-Durango	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2008	HB-Durango	WCM	√	√	√	√	√	○	√	1131, 0439, 0741, 0789, 0790, 0793, 0799, 0800, 0801, 1248, 1252
2008	HB-Durango	PTIM	√	√	√	√	√	√	√	
2008	HB-Durango	PTS	√	√	√	√	√	√	√	0267, 1028, 1030, 1031
2008	HB-Durango	EDM	√	√	√	√	√	√	√	0370, 1023
2008	HB-Durango	SAS	√	√	√	√	√	○	○	
2008	HB-Durango	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2008	HB-Durango	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2008	HB-Durango	AMP	√	√	√	√	√	○	√	0083, 0074
2008	HB-Durango	HFM	√	√	√	√	√	√	○	0492
2008	HB-Durango	VES3	√	√	√	√	√	√	√	
2008	HB-Durango	DDM	√	√	√	√	√	√	※	0668, 0319
2008	HB-Durango	PDM	√	√	√	√	√	√	※	0668, 0319
2008	HB-Durango	HSM	√	√	√	√	√	√	√	
2008	HG-Aspen	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123 0202, 1012
2008	HG-Aspen	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274
2008	HG-Aspen	ORC	√	√	√	√	√	○	√	
2008	HG-Aspen	MIC_CCN	√	√	√	√	√	√	√	1014, 1023, 0150, 0152, 0332, 1184
2008	HG-Aspen	HVAC	√	√	√	√	√	√	※	0121, 0124, 0277, 0461, 0680, 0888, 0546
2008	HG-Aspen	PLGM	√	√	√	√	√	√	√	0199, 0200
2008	HG-Aspen	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2008	HG-Aspen	WCM	√	√	√	√	√	○	√	1131, 0439, 0741, 0789, 0790, 0793, 0799, 0800, 0801, 1248, 1252
2008	HG-Aspen	PTIM	√	√	√	√	√	√	√	
2008	HG-Aspen	PTS	√	√	√	√	√	√	√	0267, 1028, 1030, 1031
2008	HG-Aspen	EDM	√	√	√	√	√	√	√	0370
2008	HG-Aspen	SAS	√	√	√	√	√	○	○	

2008	HG-Aspen	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2008	HG-Aspen	RADIO	√	√	√	√	√	√	○	0861,0867,0871,0426
2008	HG-Aspen	AMP	√	√	√	√	√	○	√	0083,0074
2008	HG-Aspen	HFM	√	√	√	√	√	√	○	0492
2008	HG-Aspen	VES3	√	√	√	√	√	√	√	
2008	HG-Aspen	DDM	√	√	√	√	√	√	※	0668,0319
2008	HG-Aspen	PDM	√	√	√	√	√	√	※	0668,0319
2008	HG-Aspen	HES3	√	√	√	√	√	√	√	
2008	JK-Wrangler	PCM	√	√	√	√	√	√	※	0257,0293,0294,0322,0323,0336,0356,1123,0471,0538,0589,0591,0820,0923,0926,1034,1047,1222,0216,0355,1051,0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0709,0710,0927,0981,1111,0698,0699,0732,0735,0830,0833,1140,0454,0202,1012
2008	JK-Wrangler	TCM	√	√	√	√	√	√	○	0005,0007,0008,0009,0033,0022,0024,0025,0026,0038,0040,0041,0042,0051,0243,0324,1140,0974,0975,0976,0977,1107,0732,0735,0832,0833
2008	JK-Wrangler	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152,0402,0795,0812
2008	JK-Wrangler	ORC	√	√	√	√	√	○	√	
2008	JK-Wrangler	MIC CCN	√	√	√	√	√	√	√	1186,1014,1023
2008	JK-Wrangler	ASBS	√	√	√	√	√	○	○	1071,1098,1099,1100,1101
2008	JK-Wrangler	WCM	√	√	√	√	√	○	√	1131,0439,0741,0793,0794,0800,0801,1244,1251
2008	JK-Wrangler	ITM	√	√	√	√	√	√	√	
2008	JK-Wrangler	SAS	√	√	√	√	√	○	○	
2008	JK-Wrangler	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2008	JK-Wrangler	RADIO	√	√	√	√	√	※	※	0861,0867,0871,0426
2008	JK-Wrangler	AMP	√	√	√	√	√	○	√	0083,0074
2008	JS-Avenger,Sebring,Convertible/Sedan	PCM	√	√	√	√	√	√	√	1048,0257,0294,0311,0216,0820,0281,0454,1123,0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0927,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0202,1012,0340,0377,0480,1054,0127
2008	JS-Avenger,Sebring,Convertible/Sedan	TCM	√	√	√	√	√	※	※	0005,0007,0008,0009,0033,0022,0024,0025,0026,0038,0040,0041,0042,0051,0324,1140,0974,0975,0976,0977,1107,0010,0011,0015,0016,0027,0028,0032,0043,0044,0045,0049,0053,0243,0325,0978,0979,0983,0732,0735,0832,0833,0230,0834,0830,1062,1063
2008	JS-Avenger,Sebring,Convertible/Sedan	FDCM	√	√	√	√	√	○	√	
2008	JS-Avenger,Sebring,Convertible/Sedan	CGW	√	√	√	√	√	√	√	0108,0119,0331,0465,0508,0510,0527,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,0254,0425,0503,0402,0810,0816,0817,0752
2008	JS-Avenger,Sebring,Convertible/Sedan	ORC	√	√	√	√	√	○	√	
2008	JS-Avenger,Sebring,Convertible/Sedan	MIC CCN	√	√	√	√	√	√	√	1014,1186,1023,0152,0150,0187,0619,0666,1015
2008	JS-Avenger,Sebring,Convertible/Sedan	HVAC	√	√	√	√	√	√	√	0121,0277,0462,0680
2008	JS-Avenger,Sebring,Convertible/Sedan	WCM	√	√	√	√	√	○	√	1131,0789,0790,0439,0741,0793,0794,0800,0802,1247,1248,1252,1255,1188
2008	JS-Avenger,Sebring,Convertible/Sedan	ITM	√	√	√	√	√	√	√	0550
2008	JS-Avenger,Sebring,Convertible/Sedan	PTCM	√	√	√	√	√	○	√	0661,0893
2008	JS-Avenger,Sebring,Convertible/Sedan	SAS	√	√	√	√	√	○	○	
2008	JS-Avenger,Sebring,Convertible/Sedan	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2008	JS-Avenger,Sebring,Convertible/Sedan	RADIO	√	√	√	√	√	※	※	0861,0867,0871,0426
2008	JS-Avenger,Sebring,Convertible/Sedan	AMP	√	√	√	√	√	○	√	0069,0074,0077,0083,0086
2008	JS-Avenger,Sebring,Convertible/Sedan	HFM	√	√	√	√	√	√	○	0492
2008	JS-Avenger,Sebring,Convertible/Sedan	VES3	√	√	√	√	√	√	√	
2008	JS-Avenger,Sebring,Convertible/Sedan	DDM	√	√	√	√	√	√	○	0319
2008	JS-Avenger,Sebring,Convertible/Sedan	PDM	√	√	√	√	√	√	○	0319
2008	KA-Nitro	PCM	√	√	√	√	√	√	※	0257,0293,0294,0322,0323,0336,0356,1123,0471,0538,0589,0591,0820,0923,0926,1034,1047,1222,0216,0355,1051,0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0709,0710,0927,0981,1111,0698,0699,0732,0735,0830,0833,1140,0454,0202,1012
2008	KA-Nitro	TCM	√	√	√	√	√	○	○	0924,1094
2008	KA-Nitro	ESM	√	√	√	√	√	√	○	
2008	KA-Nitro	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152,0402,0795,0812

2008	KA-Nitro	ORC	√	√	√	√	√	○	√	
2008	KA-Nitro	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2008	KA-Nitro	HVAC	√	√	√	√	√	√	√	0121, 0277, 0462, 0680
2008	KA-Nitro	OCM	√	√	√	√	√	○	○	0715
2008	KA-Nitro	WCM	√	√	√	√	√	○	√	1131, 0439, 0741, 0793, 0794, 0800, 0801, 1244, 1251
2008	KA-Nitro	PTS	√	√	√	√	√	√	√	0267, 1028, 1030, 1031
2008	KA-Nitro	ITM	√	√	√	√	√	√	√	0550
2008	KA-Nitro	SAS	√	√	√	√	√	○	○	
2008	KA-Nitro	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2008	KA-Nitro	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2008	KA-Nitro	AMP	√	√	√	√	√	○	√	0083, 0074
2008	KA-Nitro	HFM	√	√	√	√	√	√	○	0492
2008	KA-Nitro	VES3	√	√	√	√	√	√	√	
2008	KA-Nitro	DMFR	√	√	√	√	√	√	√	
2008	KA-Nitro	DMFL	√	√	√	√	√	√	√	
2008	KK-Liberty	PCM	√	√	√	√	√	√	※	0257, 0293, 0294, 0322, 0323, 0336, 0356, 1123, 0471, 0538, 0589, 0591, 0820, 0923, 0926, 1034, 1047, 1222, 0216, 0355, 1051, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 0202, 1012
2008	KK-Liberty	TCM	√	√	√	√	√	○	○	0924, 1094
2008	KK-Liberty	ESM	√	√	√	√	√	√	○	
2008	KK-Liberty	FDCM	√	√	√	√	√	√	○	0706
2008	KK-Liberty	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2008	KK-Liberty	ORC	√	√	√	√	√	○	√	
2008	KK-Liberty	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2008	KK-Liberty	HVAC	√	√	√	√	√	√	√	0121, 0277, 0462, 0680
2008	KK-Liberty	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0381, 0110
2008	KK-Liberty	OCM	√	√	√	√	√	○	○	0715
2008	KK-Liberty	WCM	√	√	√	√	√	○	√	1131, 0439, 0741, 0793, 0794, 0800, 0801, 1244, 1251
2008	KK-Liberty	SUNR	√	√	√	√	√	○	○	
2008	KK-Liberty	PTS	√	√	√	√	√	√	√	0267, 1028, 1030, 1031
2008	KK-Liberty	ITM	√	√	√	√	√	√	√	0550
2008	KK-Liberty	SAS	√	√	√	√	√	○	○	
2008	KK-Liberty	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2008	KK-Liberty	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2008	KK-Liberty	AMP	√	√	√	√	√	○	√	0083, 0074
2008	KK-Liberty	HFM	√	√	√	√	√	√	○	0492
2008	KK-Liberty	VES3	√	√	√	√	√	√	√	
2008	KK-Liberty	DMFR	√	√	√	√	√	√	√	
2008	KK-Liberty	DMFL	√	√	√	√	√	√	√	
2008	LX-300,Charger,Magnum,Grand Voyager	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0538, 0591, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012
2008	LX-300,Charger,Magnum,Grand Voyager	TCM	√	√	√	√	√	○	○	0924, 1094
2008	LX-300,Charger,Magnum,Grand Voyager	ESM	√	√	√	√	√	√	○	
2008	LX-300,Charger,Magnum,Grand Voyager	ACC	√	√	√	√	√	○	√	0062, 0063, 0139, 0208, 0064
2008	LX-300,Charger,Magnum,Grand Voyager	CGW	√	√	√	√	√	√	√	0119, 0155, 0331, 0465, 0508, 0510, 0560, 1226, 0900, 1076, 1155, 1189, 1219, 1224, 1225
2008	LX-300,Charger,Magnum,Grand Voyager	ORC	√	√	√	√	√	○	√	0581
2008	LX-300,Charger,Magnum,Grand Voyager	MIC_CCN	√	√	√	√	√	√	√	0209, 1186, 1014, 1184, 0150, 0152
2008	LX-300,Charger,Magnum,Grand Voyager	HVAC	√	√	√	√	√	√	√	0121, 0277, 0461, 0680
2008	LX-300,Charger,Magnum,Grand Voyager	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2008	LX-300,Charger,Magnum,Grand Voyager	SCM	√	√	√	√	√	√	√	
2008	LX-300,Charger,Magnum,Grand Voyager	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2008	LX-300,Charger,Magnum,Grand Voyager	SUNR	√	√	√	※	√	√	○	
2008	LX-300,Charger,Magnum,Grand Voyager	PTIM	√	√	√	√	√	√	√	
2008	LX-300,Charger,Magnum,Grand Voyager	HIDT	√	√	√	√	√	√	○	0196
2008	LX-300,Charger,Magnum,Grand Voyager	AHBM	√	√	√	√	√	○	○	0153, 1023
2008	LX-300,Charger,Magnum,Grand Voyager	PTS	√	√	√	√	√	√	○	0267, 1028, 1030, 1031
2008	LX-300,Charger,Magnum,Grand Voyager	EOM	√	√	√	√	√	○	√	0370, 1023
2008	LX-300,Charger,Magnum,Grand Voyager	ITM	√	√	√	√	√	√	√	0550
2008	LX-300,Charger,Magnum,Grand Voyager	RSM	√	√	√	√	√	○	○	0582
2008	LX-300,Charger,Magnum,Grand Voyager	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2008	LX-300,Charger,Magnum,Grand Voyager	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426

2008	LX-300,Charger,Magnum,Grand Voyager	SDARV	√	√	√	√	√	○	○	
2008	LX-300,Charger,Magnum,Grand Voyager	AMP	√	√	√	√	√	○	√	0083,0074
2008	LX-300,Charger,Magnum,Grand Voyager	HFM	√	√	√	√	√	√	○	0492
2008	LX-300,Charger,Magnum,Grand Voyager	YES3	√	√	√	√	√	√	√	
2008	LX-300,Charger,Magnum,Grand Voyager	DDM	√	√	√	√	√	√	※	
2008	LX-300,Charger,Magnum,Grand Voyager	PDM	√	√	√	√	√	√	※	0668
2008	LX-300,Charger,Magnum,Grand Voyager	HSM	√	√	√	√	√	√	√	
2008	MK-Compass,Patriot	PCM	√	√	√	√	√	√	√	1048,0311,0257,0294,0349,0216,0281,0454,1123,0659,0820,0340,0373,0377,0378,0480,0590,0827,1042,0409,0215,0589,0628,0927,1054,0127
2008	MK-Compass,Patriot	TCM	√	√	√	√	√	√	√	
2008	MK-Compass,Patriot	FDCM	√	√	√	√	√	√	√	
2008	MK-Compass,Patriot	CGW	√	√	√	√	√	√	√	0108,0119,0331,0465,0508,0510,0527,0560,0795,0900,1076,1155,1219,1224,1225,1226,0095,0125,0129,0425,0402,0810,0816,0817,0752
2008	MK-Compass,Patriot	ORC	√	√	√	√	√	○	√	
2008	MK-Compass,Patriot	MIC_CCN	√	√	√	√	√	√	√	1014,1186,1023,0152,0150,0187,0619,0666,1015
2008	MK-Compass,Patriot	WCM	√	√	√	√	√	○	√	1131,0789,0790,0439,0741,0793,0799,0802,1247,1248,1252,1255,1188
2008	MK-Compass,Patriot	ITM	√	√	√	√	√	√	√	0550
2008	MK-Compass,Patriot	SAS	√	√	√	√	√	○	○	
2008	MK-Compass,Patriot	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2008	MK-Compass,Patriot	RADIO	√	√	√	√	√	○	√	
2008	MK-Compass,Patriot	SDAR	√	√	√	√	√	○	○	
2008	MK-Compass,Patriot	AMP	√	√	√	√	√	○	√	0069,0074,0079,0083,0084,0070,0072,0078,0080
2008	MK-Compass,Patriot	HFM	√	√	√	√	√	√	○	0492
2008	ND-Dakota	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0927,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012
2008	ND-Dakota	CGW	√	√	√	√	√	√	√	0095,0863,0425,0465,0506,0510,0560,1138,1076,1139,1219,1224,1225,1226,0096,0129,0207,0226,0233,0234,0331,0412,0489,0490,0508,0509,0527,0684,0685,0686,0795,0899,1075,1154,1164,1262,1263,1274
2008	ND-Dakota	ORC	√	√	√	√	√	○	√	0581
2008	ND-Dakota	MIC_CCN	√	√	√	√	√	√	√	1014,1023,0150,0152,0332,1184
2008	ND-Dakota	HVAC	√	√	√	√	√	√	√	0121,0124,0277,0461,0680
2008	ND-Dakota	WCM	√	√	√	√	√	○	√	1131,0439,0741,0789,0790,0793,0799,0800,0801,1248,1252
2008	ND-Dakota	EDM	√	√	√	√	√	○	√	0370
2008	ND-Dakota	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2008	ND-Dakota	RADIO	√	√	√	√	√	√	○	0861,0867,0871,0426
2008	ND-Dakota	AMP	√	√	√	√	√	○	√	0083,0074
2008	ND-Dakota	HFM	√	√	√	√	√	√	○	0492
2008	NM-Raider	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0927,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012
2008	NM-Raider	CGW	√	√	√	√	√	√	√	0095,0863,0465,0506,0510,1138,1076,1139,1219,1224,1225,1226,0096,0129,0207,0226,0233,0234,0331,0412,0489,0490,0508,0509,0527,0560,0684,0685,0686,0795,0899,1075,1154,1164,1262,1263,1274
2008	NM-Raider	ORC	√	√	√	√	√	○	√	0581
2008	NM-Raider	MIC_CCN	√	√	√	√	√	√	√	1014,1023,0150,0152,0332,1184
2008	NM-Raider	HVAC	√	√	√	√	√	√	√	0121,0124,0277,0461,0680
2008	NM-Raider	WCM	√	√	√	√	√	○	√	1131,0439,0741,0789,0790,0793,0799,0800,0801,1248,1252
2008	NM-Raider	EDM	√	√	√	√	√	○	√	0370
2008	NM-Raider	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2008	NM-Raider	RADIO	√	√	√	√	√	√	○	0861,0867,0871,0426
2008	NM-Raider	AMP	√	√	√	√	√	○	√	0083,0074
2008	NM-Raider	HFM	√	√	√	√	√	√	○	0492
2008	PM-Caliber	PCM	√	√	√	√	√	√	√	1048,0311,0257,0294,0349,0216,0281,0454,1123,0659,0820,0340,0373,0377,0378,0480,0590,0827,1042,0409,0215,0589,0628,0927,1054,0127
2008	PM-Caliber	TCM	√	√	√	√	√	√	√	
2008	PM-Caliber	FDCM	√	√	√	√	√	√	√	
2008	PM-Caliber	CGW	√	√	√	√	√	√	√	0108,0119,0331,0465,0508,0510,0527,0560,0795,0900,1076,1155,1219,1224,1225,1226,0095,0125,0129,0425,0402,0810,0816,0817,0752
2008	PM-Caliber	ORC	√	√	√	√	√	○	√	

2008	PM-Caliber	MIC_CCN	√	√	√	√	√	√	√	1014, 1186, 1023, 0152, 0150, 0187, 0619, 0666, 1015
2008	PM-Caliber	WCM	√	√	√	√	√	○	√	1131, 0789, 0790, 0439, 0741, 0793, 0799, 0802, 1247, 1248, 1252, 1255, 1188
2008	PM-Caliber	ITM	√	√	√	√	√	√	√	0550
2008	PM-Caliber	SAS	√	√	√	√	√	○	○	
2008	PM-Caliber	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2008	PM-Caliber	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2008	PM-Caliber	SDAR	√	√	√	√	√	○	○	
2008	PM-Caliber	AMP	√	√	√	√	√	○	√	0069, 0074, 0079, 0083, 0084, 0070, 0072, 0078, 0080
2008	PM-Caliber	HFM	√	√	√	√	√	√	○	0492
2008	PM-Caliber	EBG	√	√	√	√	√	○	○	
2008	PT-PT Cruiser	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0538, 0589, 1051, 0216, 0691, 0454, 1123, 0378, 0629, 0359, 0827, 1042, 0590, 0409, 0202, 0215, 0628, 0692, 0709, 0710, 0927, 1054, 1055
2008	PT-PT Cruiser	TCM	√	√	√	√	√	√	√	0011, 0015, 0016, 0028, 0032, 0045, 0049, 0243, 0830, 0979, 0983, 1062, 1063, 1107, 0230, 0834
2008	PT-PT Cruiser	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0527, 0560, 1076, 0095, 0125, 0425, 0402, 0810, 0816, 0817, 0752
2008	PT-PT Cruiser	ORC	√	√	√	√	√	○	√	
2008	PT-PT Cruiser	MIC_CCN	√	√	√	√	√	√	√	0150, 0152, 0187, 0619, 0666, 1015
2008	PT-PT Cruiser	OCM	√	√	√	√	√	○	○	0715
2008	PT-PT Cruiser	WCM	√	√	√	√	√	○	√	1131, 0789, 0790, 0439, 0741, 0793, 0799, 0802, 1247, 1248, 1252, 1255, 1188
2008	PT-PT Cruiser	ITM	√	√	√	√	√	√	√	0579
2008	PT-PT Cruiser	ABS	√	√	√	√	√	√	√	0056, 0168, 0567, 0575, 0585
2008	PT-PT Cruiser	RADIO	√	√	√	√	√	○	√	
2008	PT-PT Cruiser	SDAR	√	√	√	√	√	○	○	
2008	PT-PT Cruiser	AMP	√	√	√	√	√	○	√	0069, 0074, 0079, 0083, 0084, 0070, 0072, 0078, 0080
2008	PT-PT Cruiser	HFM	√	√	√	√	√	√	○	0492
2008	PT-PT Cruiser	DDM	√	√	√	√	√	√	○	
2008	PT-PT Cruiser	PDM	√	√	√	√	√	√	○	
2008	RT-Caravan, Town & Country	PCM	√	√	√	√	√	√	※	0257, 0293, 0294, 0322, 0323, 0336, 0356, 1123, 0471, 0538, 0589, 0591, 0820, 0923, 0926, 1034, 1047, 1222, 0216, 0355, 1051, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 0202, 1013
2008	RT-Caravan, Town & Country	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0051, 0243, 0324, 0694, 0841, 0974, 0975, 0976, 0977, 1107, 1140
2008	RT-Caravan, Town & Country	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2008	RT-Caravan, Town & Country	ORC	√	√	√	√	√	○	√	0581
2008	RT-Caravan, Town & Country	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2008	RT-Caravan, Town & Country	HVAC	√	√	√	√	√	√	√	0121, 0277, 0501, 0461, 0680, 0462
2008	RT-Caravan, Town & Country	PLGM	√	√	√	√	√	√	√	0199, 0200, 0877
2008	RT-Caravan, Town & Country	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2008	RT-Caravan, Town & Country	PSM	√	√	√	√	√	√	○	0194, 0201, 1269, 1272
2008	RT-Caravan, Town & Country	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2008	RT-Caravan, Town & Country	SUNR	√	√	√	√	√	√	○	
2008	RT-Caravan, Town & Country	HIDT	√	√	√	√	√	√	○	0493
2008	RT-Caravan, Town & Country	PTS	√	√	√	√	√	√	√	0267, 1028, 1030, 1031
2008	RT-Caravan, Town & Country	ITM	√	√	√	√	√	√	√	0550
2008	RT-Caravan, Town & Country	SAS	√	√	√	√	√	○	○	
2008	RT-Caravan, Town & Country	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2008	RT-Caravan, Town & Country	DVD	√	√	√	√	√	○	○	
2008	RT-Caravan, Town & Country	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2008	RT-Caravan, Town & Country	SDARV	√	√	√	√	√	○	○	
2008	RT-Caravan, Town & Country	AMP	√	√	√	√	√	○	√	0083, 0074
2008	RT-Caravan, Town & Country	HFM	√	√	√	√	√	√	○	0492
2008	RT-Caravan, Town & Country	VES2	√	√	√	√	√	√	√	
2008	RT-Caravan, Town & Country	VES3	√	√	√	√	√	√	√	
2008	RT-Caravan, Town & Country	DMFR	√	√	√	√	√	√	√	
2008	RT-Caravan, Town & Country	DMFL	√	√	√	√	√	√	√	
2008	RT-Caravan, Town & Country	DMRL	√	√	√	√	√	√	√	0622, 0624, 0630
2008	RT-Caravan, Town & Country	DMRR	√	√	√	√	√	√	√	0622, 0624, 0630
2008	RT-Caravan, Town & Country	PSDMR	√	√	√	√	√	○	√	0106, 0633, 1067, 1070, 0877
2008	RT-Caravan, Town & Country	PSDML	√	√	√	√	√	○	√	0106, 0633, 1067, 1070, 0877

2008	VB-Sprinter	ECM	√	√	√	√	√	√	√	0350, 0203, 0220, 0433, 0475, 0711, 0911, 1147, 0257, 0591, 0294, 0320, 0321, 0359, 0448, 0589, 0660, 0662, 0805, 0874, 1043
2008	VB-Sprinter	TCM	√	√	√	√	√	○	○	0350, 1117, 0677, 1065, 1112, 1174
2008	VB-Sprinter	ESM	√	√	√	√	√	√	○	
2008	VB-Sprinter	CGW	√	√	√	√	√	○	√	0904, 0350
2008	VB-Sprinter	ORC	√	√	√	○	√	○	○	0717, 0930, 1033, 0350
2008	VB-Sprinter	MIC_CCN	√	√	√	√	√	○	○	0350, 0184, 0283, 0284, 0285, 0286, 0287, 0481, 0723, 0765, 1078, 0828, 0186
2008	VB-Sprinter	HVAC	√	√	√	√	√	√	√	0632
2008	VB-Sprinter	BCM	√	√	√	√	√	√	○	
2008	VB-Sprinter	ACM	√	√	√	√	√	√	○	
2008	VB-Sprinter	SCM	√	√	√	√	√	√	○	
2008	VB-Sprinter	RCM	√	√	√	√	√	√	○	0327
2008	VB-Sprinter	PSM	√	√	√	√	√	√	○	0350
2008	VB-Sprinter	TM	√	√	√	√	√	○	○	
2008	VB-Sprinter	AHLM	√	√	√	√	√	√	○	0193, 0350
2008	VB-Sprinter	RCM	√	√	√	√	√	√	○	
2008	VB-Sprinter	AEHM	√	√	√	√	√	○	○	0065
2008	VB-Sprinter	PTS	√	√	√	√	√	√	√	0140, 0608
2008	VB-Sprinter	TPM	√	√	√	√	√	○	○	0350, 0636, 0637, 0984, 0985, 1156, 1205, 1207, 1213
2008	VB-Sprinter	ABS	√	√	√	√	√	○	√	0168, 0195, 0342, 0100, 0350
2008	VB-Sprinter	SBM	√	√	√	√	√	√	○	
2008	VB-Sprinter	CDC	√	√	√	√	√	○	○	
2008	VB-Sprinter	RADIO	√	√	√	√	√	○	※	0350
2008	VB-Sprinter	HFM	√	√	√	√	√	○	○	0350
2008	VB-Sprinter	PSDMR	√	√	√	√	√	√	○	
2008	VB-Sprinter	PSDML	√	√	√	√	√	√	○	
2008	VB-Sprinter	DDM	√	√	√	√	√	√	○	
2008	WK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0538, 0591, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012
2008	WK-Grand Cherokee	TCM	√	√	√	√	√	○	○	0924, 1094
2008	WK-Grand Cherokee	ESM	√	√	√	√	√	√	○	
2008	WK-Grand Cherokee	FDCM	√	√	√	√	√	√	√	
2008	WK-Grand Cherokee	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1219, 1224, 1225, 1226, 1188, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274
2008	WK-Grand Cherokee	ORC	√	√	√	√	√	○	√	0581
2008	WK-Grand Cherokee	MIC_CCN	√	√	√	√	√	√	√	1184, 1186, 1023, 0150, 0152, 0185, 0187, 0210, 0619, 1035, 1036
2008	WK-Grand Cherokee	HVAC	√	√	√	√	√	√	√	0121, 0277, 0461, 0680
2008	WK-Grand Cherokee	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2008	WK-Grand Cherokee	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2008	WK-Grand Cherokee	TM	○	√	√	○	√	○	○	
2008	WK-Grand Cherokee	SUNR	√	√	√	※	√	√	○	
2008	WK-Grand Cherokee	AHLM	√	√	√	√	√	√	○	0193
2008	WK-Grand Cherokee	AHBM	√	√	√	√	√	○	○	0153, 1023
2008	WK-Grand Cherokee	PTS	√	√	√	√	√	√	※	0267, 1028, 1030, 1031, 0266, 1106
2008	WK-Grand Cherokee	EDM	√	√	√	√	√	○	√	0370, 1023
2008	WK-Grand Cherokee	ITM	√	√	√	√	√	√	√	0550
2008	WK-Grand Cherokee	RSM	√	√	√	√	√	○	○	0582
2008	WK-Grand Cherokee	SAS	√	√	√	√	√	○	○	
2008	WK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2008	WK-Grand Cherokee	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2008	WK-Grand Cherokee	SDARV	√	√	√	√	√	○	○	
2008	WK-Grand Cherokee	AMP	√	√	√	√	√	○	√	0083, 0074
2008	WK-Grand Cherokee	HFM	√	√	√	√	√	√	○	0492
2008	WK-Grand Cherokee	VES3	√	√	√	√	√	√	√	
2008	WK-Grand Cherokee	DDM	√	√	√	√	√	√	※	0668, 0319
2008	WK-Grand Cherokee	PDM	√	√	√	√	√	√	※	0668, 0319
2008	WK-Grand Cherokee	HSM	√	√	√	√	√	√	√	

2008	XK-Commander	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0538, 0691, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012
2008	XK-Commander	TCM	√	√	√	√	√	○	○	0924, 1094
2008	XK-Commander	ESM	√	√	√	√	√	√	○	
2008	XK-Commander	FDCM	√	√	√	√	√	√	√	
2008	XK-Commander	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1188, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274
2008	XK-Commander	ORC	√	√	√	√	√	○	√	0581
2008	XK-Commander	MIC_CCN	√	√	√	√	√	√	√	1184, 1186, 1023, 0150, 0152, 0185, 0187, 0210, 0619, 1035, 1036
2008	XK-Commander	HVAC	√	√	√	√	√	√	√	0121, 0277, 0461, 0680
2008	XK-Commander	PLGM	√	√	√	√	√	√	√	0199, 0200
2008	XK-Commander	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2008	XK-Commander	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2008	XK-Commander	TM	○	√	√	○	√	○	○	
2008	XK-Commander	SUNR	√	√	√	※	√	√	○	
2008	XK-Commander	AHBM	√	√	√	√	√	○	○	0153, 1023
2008	XK-Commander	PTS	√	√	√	√	√	√	○	0267, 1028, 1030, 1031
2008	XK-Commander	ITM	√	√	√	√	√	√	√	0550
2008	XK-Commander	RSM	√	√	√	√	√	○	○	0582
2008	XK-Commander	SAS	√	√	√	√	√	○	○	
2008	XK-Commander	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2008	XK-Commander	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2008	XK-Commander	SDARV	√	√	√	√	√	○	○	
2008	XK-Commander	AMP	√	√	√	√	√	○	√	0083, 0074
2008	XK-Commander	HFM	√	√	√	√	√	√	○	0492
2008	XK-Commander	VES3	√	√	√	√	√	√	√	
2008	XK-Commander	DDM	√	√	√	√	√	√	※	0668, 0319
2008	XK-Commander	PDM	√	√	√	√	√	√	※	0668, 0319
2008	XK-Commander	HSM	√	√	√	√	√	√	√	
2008	ZB-Viper	PCM	√	√	√	√	√	√	○	0377, 0626, 0590, 0625, 0826, 1146, 1208, 0215, 0216, 0378, 0480, 0589, 0606, 0628, 0827, 0919, 1051
2008	ZB-Viper	CGW	○	√	√	√	√	○	○	
2008	ZB-Viper	ORC	○	√	√	○	√	○	○	
2008	ZB-Viper	MIC_CCN	○	√	√	○	√	○	○	0928
2008	ZB-Viper	HVAC	○	√	√	√	√	√	○	
2008	ZB-Viper	OCM	√	√	√	√	√	○	○	0715, 0714
2008	ZB-Viper	BCM	○	√	√	√	√	√	○	
2008	ZB-Viper	ABS	○	√	√	√	√	√	○	
2008	ZB-Viper	RADIO	○	√	√	○	√	√	○	
2008	ZB-Viper	SDAR	○	√	√	√	√	√	○	
2008	ZH-Crossfire(NAFTA)	PCM	√	√	√	√	√	√	○	
2008	ZH-Crossfire(NAFTA)	TCM	√	√	√	√	√	○	○	
2008	ZH-Crossfire(NAFTA)	SLA	√	√	√	√	√	√	○	
2008	ZH-Crossfire(NAFTA)	ORC	√	√	√	√	√	○	○	
2008	ZH-Crossfire(NAFTA)	HVAC	√	√	√	√	√	√	○	
2008	ZH-Crossfire(NAFTA)	OCM	√	√	√	√	√	○	○	
2008	ZH-Crossfire(NAFTA)	BCM	√	√	√	√	√	√	○	
2008	ZH-Crossfire(NAFTA)	PTCM	√	√	√	√	√	√	○	
2008	ZH-Crossfire(NAFTA)	SKM	√	√	√	√	√	√	○	
2008	ZH-Crossfire(NAFTA)	TPM	√	√	√	√	√	○	○	1093, 1130
2008	ZH-Crossfire(NAFTA)	ESP	√	√	√	√	√	√	○	
2008	ZH-Crossfire(NAFTA)	IC	√	√	√	√	√	√	○	
2008	ZH-Crossfire(NAFTA)	CLP	√	√	√	○	√	√	○	
2008	JS-Wrangler	PCM	√	√	√	√	√	√	○	0257, 0293, 0294, 0322, 0323, 0336, 0356, 1123, 0471, 0538, 0589, 0591, 0820, 0923, 0926, 1034, 1047, 1222, 0216, 0355, 1051
2008	JS-Wrangler	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0051, 0243, 0324, 1140, 0974, 0975, 0976, 0977, 1107, 0732, 0735, 0832, 0833
2008	JS-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0465, 0402, 0795, 0812
2008	JS-Wrangler	ORC	√	√	√	√	√	○	√	
2008	JS-Wrangler	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2008	JS-Wrangler	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2008	JS-Wrangler	WCM	√	√	√	√	√	○	√	0439, 0613, 0614

2008	JS-Wrangler	SAS	√	√	√	√	√	○	○	
2008	JS-Wrangler	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2008	JS-Wrangler	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2008	JC-Journey	PCM	√	√	√	√	√	√	√	1048, 0311, 0257, 0294, 0349, 0216, 0281, 0454, 1123, 0820, 0659, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012, 0340, 0377, 0480, 1054, 0127
2008	JC-Journey	TCM	√	√	√	√	√	※	√	0011, 0028, 0045, 0230, 0834, 0979, 1107, 0015, 0016, 0032, 0049, 0243, 0830, 0983, 1062, 1063
2008	JC-Journey	FDCM	√	√	√	√	√	○	√	
2008	JC-Journey	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2008	JC-Journey	ORC	√	√	√	√	√	○	√	0581
2008	JC-Journey	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2008	JC-Journey	HVAC	√	√	√	√	√	√	√	0461, 0680, 0121, 0277, 0501, 0462
2008	JC-Journey	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2008	JC-Journey	ITM	√	√	√	√	√	√	√	0550
2008	JC-Journey	SAS	√	√	√	√	√	○	○	
2008	JC-Journey	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2008	JC-Journey	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2008	JC-Journey	AMP	√	√	√	√	√	○	√	0083, 0074
2008	JC-Journey	HFM	√	√	√	√	√	√	○	0492
2008	JC-Journey	VES3	√	√	√	√	√	√	√	
2008	JC-Journey	DISP	√	√	√	○	√	○	○	
2008	JC-Journey	DMFR	√	√	√	√	√	√	√	
2008	JC-Journey	DMFL	√	√	√	√	√	√	√	
2008	LC-Challenger	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012
2008	LC-Challenger	TCM	√	√	√	√	√	○	○	0924, 1094
2008	LC-Challenger	ESM	√	√	√	√	√	√	○	
2008	LC-Challenger	CGW	√	√	√	√	√	√	√	0155, 0331, 0465, 0508, 0510, 0660, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 0095
2008	LC-Challenger	ORC	√	√	√	√	√	○	√	0581
2008	LC-Challenger	MIC_CCN	√	√	√	√	√	√	√	0209, 1186, 1014, 1184, 0150, 0152
2008	LC-Challenger	HVAC	√	√	√	√	√	√	√	0121, 0277, 0462, 0680
2008	LC-Challenger	SCM	√	√	√	√	√	√	√	
2008	LC-Challenger	WCM	√	√	√	√	√	√	√	0143, 0439, 0366, 0613, 0741, 0790
2008	LC-Challenger	SUNR	√	√	√	※	√	√	○	
2008	LC-Challenger	EDM	√	√	√	√	√	○	√	0370, 1023
2008	LC-Challenger	TPM	√	√	√	√	√	○	√	1129, 0793, 0794, 0799, 0800
2008	LC-Challenger	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2008	LC-Challenger	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2008	LC-Challenger	AMP	√	√	√	√	√	○	√	0083, 0074
2008	LC-Challenger	HFM	√	√	√	√	√	√	○	0492
2008	LC-Challenger	DDM	√	√	√	√	√	√	○	0319
2008	LC-Challenger	PDM	√	√	√	√	√	√	○	0319
2008	LC-Challenger	HSM	√	√	√	√	√	√	√	
2008	LC-Challenger	PEM	√	√	√	√	√	○	√	0609, 0648
2008	KR2-Mini-Van	PCM	○	√	√	√	√	√	○	
2008	KR2-Mini-Van	TCM	○	√	√	√	√	√	○	
2008	KR2-Mini-Van	ORC	○	√	√	√	√	○	○	
2008	KR2-Mini-Van	MIC_CCN	○	√	√	○	√	√	○	
2008	KR2-Mini-Van	PCM	○	√	√	√	√	√	○	
2008	KR2-Mini-Van	PLGM	○	√	√	√	√	√	○	
2008	KR2-Mini-Van	ATC	○	√	√	√	√	√	○	
2008	KR2-Mini-Van	MTC	○	√	√	○	√	√	○	
2008	KR2-Mini-Van	MSM	○	√	√	√	√	√	○	
2008	KR2-Mini-Van	OCM	○	√	√	√	√	○	○	0282, 0504, 0715, 0730, 1073
2008	KR2-Mini-Van	BCM	○	√	√	√	√	√	○	
2008	KR2-Mini-Van	PTS	○	√	√	√	√	○	○	
2008	KR2-Mini-Van	EDM	○	√	√	○	√	○	○	
2008	KR2-Mini-Van	SKM	○	√	√	○	√	√	○	0405, 0406, 0439, 0442, 0742, 0743, 0746, 0785, 0791, 0801, 0940, 1227, 1228, 1233, 1245, 1246, 1250, 1256, 1257
2008	KR2-Mini-Van	ABS	○	√	√	√	√	√	○	
2008	KR2-Mini-Van	SDAR	○	√	√	√	√	√	○	
2008	KR2-Mini-Van	HFM	○	√	√	√	√	√	○	

2008	R2-Mini-Van	PSDMR	○	√	√	√	√	√	○	
2008	R2-Mini-Van	PSDML	○	√	√	√	√	√	○	
2009	DR-RAM	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 1201, 0446, 0705, 0437, 0478, 0515, 0397, 0473, 0480, 0914, 0160, 0936, 0929, 1195, 0216, 0398, 0399, 0456, 0457, 0591, 0670, 0671, 0939, 1052, 1053, 1197, 0672, 1196, 0673, 0138, 0380, 0755, 0295, 0396, 0474, 1159, 1134, 1135, 0191, 0192, 0536, 1124
2009	DR-RAM	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0051, 0324, 1140, 0974, 0975, 0976, 0977, 1107, 0010, 0011, 0015, 0016, 0027, 0028, 0032, 0043, 0044, 0045, 0049, 0053, 0243, 0325, 0978, 0979, 0983, 0732, 0735, 0832 0833, 0420
2009	DR-RAM	FDCM	√	√	√	√	√	○	○	0113, 0114, 0115, 0116, 0117, 0118
2009	DR-RAM	CGW	√	√	√	√	√	√	√	0119, 0331, 0465, 0508, 0510, 0527, 0560, 0795, 0897, 0900, 1076, 1155, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0254, 0425, 0402, 0810, 0816, 0817, 0752
2009	DR-RAM	ORC	√	√	√	√	√	○	√	
2009	DR-RAM	MIC_CCN	√	√	√	√	√	√	√	1023, 0152, 0150, 0187, 1184
2009	DR-RAM	HVAC	√	√	√	√	√	√	※	0122, 0124, 0277, 0461, 0680, 0121
2009	DR-RAM	WCM	√	√	√	√	√	○	√	1131, 0789, 0790, 0439, 0741, 0793, 0799, 0902, 1247, 1248, 1252, 1255, 1132
2009	DR-RAM	SUNR	√	√	√	※	√	√	○	
2009	DR-RAM	EDM	√	√	√	√	√	√	√	0370, 1023
2009	DR-RAM	SAS	√	√	√	√	√	○	○	
2009	DR-RAM	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2009	DR-RAM	RADIO	√	√	√	√	√	○	√	
2009	DR-RAM	SDARV	√	√	√	√	√	○	○	
2009	DR-RAM	AMP	√	√	√	√	√	○	√	0072, 0073, 0074, 0080, 0081, 0083, 0084
2009	DR-RAM	HFM	√	√	√	√	√	√	○	0492
2009	DR-RAM	VES	√	√	√	√	√	√	○	
2009	HB-Durango	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 1201, 0446, 0705, 0437
2009	HB-Durango	TCM	√	√	√	√	√	○	○	1067, 0219, 0905, 1166, 1169, 1170, 1172
2009	HB-Durango	FDCM	√	√	√	√	√	√	○	0706
2009	HB-Durango	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274
2009	HB-Durango	ORC	√	√	√	√	√	○	√	
2009	HB-Durango	MIC_CCN	√	√	√	√	√	√	√	1014, 1184, 1023, 0150, 0152, 0332
2009	HB-Durango	HVAC	√	√	√	√	√	√	※	0121, 0277, 0461, 0680, 0158, 0379, 0124, 0888
2009	HB-Durango	PLGM	√	√	√	√	√	√	√	0199, 0200
2009	HB-Durango	APM	√	○	○	○	○	○	○	0212
2009	HB-Durango	MSM	√	√	√	√	√	○	○	0341, 0382, 0110, 0604, 1023, 1084, 1151
2009	HB-Durango	WCM	√	√	√	√	√	○	√	1131, 0439, 0741, 0789, 0790, 0793, 0799, 0800, 0801, 1248, 1252
2009	HB-Durango	PTS	√	√	√	√	√	√	√	0267, 1028, 1030, 1031
2009	HB-Durango	EDM	√	√	√	√	√	√	√	0370, 1023
2009	HB-Durango	SAS	√	√	√	√	√	○	○	
2009	HB-Durango	ABS	√	√	√	√	√	√	√	1202, 0058, 0056, 0168, 0568, 0578
2009	HB-Durango	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	HB-Durango	SDARV	√	√	√	√	√	○	○	
2009	HB-Durango	AMP	√	√	√	√	√	○	√	0083, 0074
2009	HB-Durango	HFM	√	√	√	√	√	√	○	0492
2009	HB-Durango	VES3	√	√	√	√	√	√	√	
2009	HB-Durango	DDM	√	√	√	√	√	√	※	0668, 0319
2009	HB-Durango	PDM	√	√	√	√	√	√	※	0668, 0319
2009	HB-Durango	HESM	√	√	√	√	√	√	√	
2009	HB-Durango	BPCM	√	○	○	√	○	○	○	0167, 0502, 0528, 0529, 0910, 0946, 1209, 1211, 1218, 1215, 1230, 1231
2009	HB-Durango	EAC	√	√	√	○	√	○	○	
2009	HB-Durango	EPS	√	√	√	√	√	○	○	
2009	HB-Durango	HCP	√	√	√	√	√	○	○	0414, 1210, 0518, 0896, 0902, 0922, 1057, 1167, 1173, 1214, 1232
2009	HB-Durango	HGM	√	√	√	√	√	√	√	

2009	HB-Durango	MCPA	√	○	○	√	○	○	○	0960
2009	HB-Durango	MCPB	√	○	○	√	○	○	○	0960
2009	HG-Aspen	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 1201, 0446, 0705, 0437
2009	HG-Aspen	TCM	√	√	√	√	√	○	○	1067, 0219, 0905, 1166, 1169, 1170, 1172
2009	HG-Aspen	FDCM	√	√	√	√	√	√	○	0706
2009	HG-Aspen	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274
2009	HG-Aspen	ORC	√	√	√	√	√	○	√	
2009	HG-Aspen	MIC_CCN	√	√	√	√	√	√	√	1014, 1184, 1023, 0150, 0152, 0332
2009	HG-Aspen	HVAC	√	√	√	√	√	√	※	0121, 0277, 0461, 0680, 0158, 0379, 0124, 0888
2009	HG-Aspen	PLGM	√	√	√	√	√	√	√	0199, 0200
2009	HG-Aspen	APM	√	○	○	○	○	○	○	0212
2009	HG-Aspen	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2009	HG-Aspen	WCM	√	√	√	√	√	○	√	1131, 0439, 0741, 0789, 0790, 0793, 0799, 0800, 0801, 1248, 1252
2009	HG-Aspen	PTS	√	√	√	√	√	√	√	0267, 1028, 1030, 1031
2009	HG-Aspen	EOM	√	√	√	√	√	√	√	0370
2009	HG-Aspen	SAS	√	√	√	√	√	○	○	
2009	HG-Aspen	ABS	√	√	√	√	√	√	√	0058, 1202, 0056, 0168, 0568, 0578
2009	HG-Aspen	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	HG-Aspen	SDARV	√	√	√	√	√	○	○	
2009	HG-Aspen	AMP	√	√	√	√	√	○	√	0083, 0074
2009	HG-Aspen	HPM	√	√	√	√	√	√	○	0492
2009	HG-Aspen	VES3	√	√	√	√	√	√	√	
2009	HG-Aspen	DDM	√	√	√	√	√	√	※	0668, 0319
2009	HG-Aspen	PDM	√	√	√	√	√	√	※	0668, 0319
2009	HG-Aspen	HSM	√	√	√	√	√	√	√	
2009	HG-Aspen	BPCM	√	○	○	√	○	○	○	0167, 0502, 0528, 0529, 0910, 0946, 1209, 1211, 1218, 1215, 1230, 1231
2009	HG-Aspen	EAC	√	√	√	○	√	○	○	
2009	HG-Aspen	EPS	√	√	√	√	√	○	○	
2009	HG-Aspen	HCP	√	√	√	√	√	○	○	0414, 1210, 0518, 0896, 0902, 0922, 1067, 1167, 1173, 1214, 1232
2009	HG-Aspen	HBCM	√	√	√	√	√	√	√	
2009	HG-Aspen	MCPA	√	○	○	√	○	○	○	0960
2009	HG-Aspen	MCPB	√	○	○	√	○	○	○	0960
2009	JK-Wrangler	PCM	√	√	√	√	√	√	※	0257, 0293, 0294, 0322, 0323, 0336, 0356, 1123, 0471, 0538, 0589, 0591, 0820, 0923, 0926, 1034, 1047, 1222, 0216, 0355, 1051, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 0202, 1012, 1201, 0446, 0705, 0437
2009	JK-Wrangler	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0051, 0243, 0324, 1140, 0974, 0975, 0976, 0977, 1107, 0732, 0735, 0832, 0833
2009	JK-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2009	JK-Wrangler	ORC	√	√	√	√	√	○	√	
2009	JK-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2009	JK-Wrangler	ASBS	√	√	√	√	√	○	○	1071, 1098, 1099, 1100, 1101
2009	JK-Wrangler	WCM	√	√	√	√	√	○	√	1131, 0439, 0741, 0793, 0794, 0800, 0801, 1244, 1251
2009	JK-Wrangler	ITM	√	√	√	√	√	√	√	
2009	JK-Wrangler	SAS	√	√	√	√	√	○	○	
2009	JK-Wrangler	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2009	JK-Wrangler	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2009	JK-Wrangler	AMP	√	√	√	√	√	○	√	0083, 0074
2009	JK-Wrangler	HPM	√	√	√	√	√	√	○	0492

2009	JS-Avenger,Sebring,Convertible/Sedan	PCM	√	√	√	√	√	√	√	1048,0257,0294,0311,0216,0820,0281,0454,1123,0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0927,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0202,1012,1201,0446,0705,0437,0340,0377,0480,1054,0127
2009	JS-Avenger,Sebring,Convertible/Sedan	TCM	√	√	√	√	√	※	※	0005,0007,0008,0009,0033,0022,0024,0025,0026,0038,0040,0041,0042,0051,0324,1140,0974,0975,0976,0977,1107,0010,0011,0015,0016,0027,0028,0032,0043,0044,0045,0049,0053,0243,0325,0978,0979,0983,0732,0735,0832,0833,0230,0834,0830,1062,1063
2009	JS-Avenger,Sebring,Convertible/Sedan	FDCM	√	√	√	√	√	○	√	
2009	JS-Avenger,Sebring,Convertible/Sedan	CGW	√	√	√	√	√	√	√	0108,0119,0331,0465,0508,0510,0527,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,0254,0425,0503,0402,0810,0816,0817,0752
2009	JS-Avenger,Sebring,Convertible/Sedan	ORC	√	√	√	√	√	○	√	
2009	JS-Avenger,Sebring,Convertible/Sedan	MIC_CCN	√	√	√	√	√	√	√	1014,1186,1023,0152,0150,0187,0619,0666,1015
2009	JS-Avenger,Sebring,Convertible/Sedan	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680,0277
2009	JS-Avenger,Sebring,Convertible/Sedan	WCM	√	√	√	√	√	○	√	1131,0789,0790,0439,0741,0793,0794,0800,0802,1247,1248,1252,1255,1188
2009	JS-Avenger,Sebring,Convertible/Sedan	ITM	√	√	√	√	√	√	√	0550
2009	JS-Avenger,Sebring,Convertible/Sedan	PTCM	√	√	√	√	√	○	√	0661,0893
2009	JS-Avenger,Sebring,Convertible/Sedan	SAS	√	√	√	√	√	○	○	
2009	JS-Avenger,Sebring,Convertible/Sedan	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2009	JS-Avenger,Sebring,Convertible/Sedan	RADIO	√	√	√	√	√	※	※	0861,0867,0871,0426
2009	JS-Avenger,Sebring,Convertible/Sedan	AMP	√	√	√	√	√	○	√	0083,0074
2009	JS-Avenger,Sebring,Convertible/Sedan	HFM	√	√	√	√	√	√	○	0492
2009	JS-Avenger,Sebring,Convertible/Sedan	VES3	√	√	√	√	√	√	√	
2009	JS-Avenger,Sebring,Convertible/Sedan	DDM	√	√	√	√	√	√	○	0319
2009	JS-Avenger,Sebring,Convertible/Sedan	PDM	√	√	√	√	√	√	○	0319
2009	KA-Nitro	PCM	√	√	√	√	√	√	※	0257,0293,0294,0322,0323,0336,0356,1123,0471,0538,0589,0591,0820,0923,0926,1034,1047,1222,0216,0355,1051,0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0709,0710,0927,0981,1111,0698,0699,0732,0735,0830,0833,1140,0454,0202,1012,1201,0446,0705,0437
2009	KA-Nitro	TCM	√	√	√	√	√	○	○	0924,1094
2009	KA-Nitro	ESM	√	√	√	√	√	√	○	
2009	KA-Nitro	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152,0402,0795,0812
2009	KA-Nitro	ORC	√	√	√	√	√	○	√	
2009	KA-Nitro	MIC_CCN	√	√	√	√	√	√	○	1186,1014,1023,0187,0210,0619,1015
2009	KA-Nitro	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680,0277
2009	KA-Nitro	OCM	√	√	√	√	√	○	○	0715
2009	KA-Nitro	WCM	√	√	√	√	√	○	√	1131,0439,0741,0793,0794,0800,0801,1244,1251
2009	KA-Nitro	PTS	√	√	√	√	√	√	√	0267,1028,1030,1031
2009	KA-Nitro	ITM	√	√	√	√	√	√	√	0550
2009	KA-Nitro	SAS	√	√	√	√	√	○	○	
2009	KA-Nitro	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2009	KA-Nitro	RADIO	√	√	√	√	√	√	○	0861,0867,0871,0426
2009	KA-Nitro	AMP	√	√	√	√	√	○	√	0083,0074
2009	KA-Nitro	HFM	√	√	√	√	√	√	○	0492
2009	KA-Nitro	VES3	√	√	√	√	√	√	√	
2009	KA-Nitro	DMFR	√	√	√	√	√	√	√	
2009	KA-Nitro	DMFL	√	√	√	√	√	√	√	
2009	KK-Liberty	PCM	√	√	√	√	√	√	※	0257,0293,0294,0322,0323,0336,0356,1123,0471,0538,0589,0591,0820,0923,0926,1034,1047,1222,0216,0355,1051,0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0709,0710,0927,0981,1111,0698,0699,0732,0735,0830,0833,1140,0454,0202,1012,1201,0446,0705,0437
2009	KK-Liberty	TCM	√	√	√	√	√	○	○	0924,1094
2009	KK-Liberty	ESM	√	√	√	√	√	√	○	
2009	KK-Liberty	FDCM	√	√	√	√	√	√	○	0706
2009	KK-Liberty	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0510,0560,0900,1076,1155,1189,1219,1224,1225,1226,0095,1182,1220,0150,0152,1235,0508,0402,0795,0812

2009	KK-Liberty	ORC	√	√	√	√	√	○	√	
2009	KK-Liberty	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2009	KK-Liberty	HVAC	√	√	√	√	√	√	√	0121, 0498, 0482, 0680, 0277
2009	KK-Liberty	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2009	KK-Liberty	OCM	√	√	√	√	√	○	○	0715
2009	KK-Liberty	WCM	√	√	√	√	√	○	√	0439, 0613, 0614
2009	KK-Liberty	SUNR	√	√	√	√	√	○	○	
2009	KK-Liberty	PTS	√	√	√	√	√	√	√	0267, 1028, 1030, 1031
2009	KK-Liberty	ITM	√	√	√	√	√	√	√	0550
2009	KK-Liberty	SAS	√	√	√	√	√	○	○	
2009	KK-Liberty	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2009	KK-Liberty	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	KK-Liberty	AMP	√	√	√	√	√	○	√	0083, 0074
2009	KK-Liberty	HFM	√	√	√	√	√	√	○	0492
2009	KK-Liberty	VES3	√	√	√	√	√	√	√	
2009	KK-Liberty	DMFR	√	√	√	√	√	√	√	
2009	KK-Liberty	DMFL	√	√	√	√	√	√	√	
2009	LX-300, Charger, Magnum, Grand Voyager	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0538, 0591, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012, 1201, 0446, 0705, 0487
2009	LX-300, Charger, Magnum, Grand Voyager	TCM	√	√	√	√	√	○	○	0924, 1094
2009	LX-300, Charger, Magnum, Grand Voyager	ESM	√	√	√	√	√	√	○	
2009	LX-300, Charger, Magnum, Grand Voyager	ACC	√	√	√	√	√	○	√	0062, 0063, 0139, 0208, 0064
2009	LX-300, Charger, Magnum, Grand Voyager	CGW	√	√	√	√	√	√	√	0155, 0331, 0465, 0508, 0510, 0560, 1226, 0900, 1076, 1155, 1189, 0095, 1219, 1224, 1225
2009	LX-300, Charger, Magnum, Grand Voyager	ORC	√	√	√	√	√	○	√	0581
2009	LX-300, Charger, Magnum, Grand Voyager	MIC_CCN	√	√	√	√	√	√	√	0209, 1186, 1014, 1184, 0150, 0152
2009	LX-300, Charger, Magnum, Grand Voyager	HVAC	√	√	√	√	√	√	√	0121, 0277, 0461, 0680
2009	LX-300, Charger, Magnum, Grand Voyager	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2009	LX-300, Charger, Magnum, Grand Voyager	SCM	√	√	√	√	√	√	√	
2009	LX-300, Charger, Magnum, Grand Voyager	WCM	√	√	√	√	√	√	√	0439, 0143, 0741, 0793, 0794, 0799, 0800, 1256, 0366, 0613, 1131, 0790
2009	LX-300, Charger, Magnum, Grand Voyager	SUNR	√	√	√	※	√	√	○	
2009	LX-300, Charger, Magnum, Grand Voyager	PTIM	√	√	√	√	√	√	√	
2009	LX-300, Charger, Magnum, Grand Voyager	HIDT	√	√	√	√	√	√	○	0196
2009	LX-300, Charger, Magnum, Grand Voyager	AHSM	√	√	√	√	√	○	○	0153, 1023
2009	LX-300, Charger, Magnum, Grand Voyager	PTS	√	√	√	√	√	√	√	0266, 1106
2009	LX-300, Charger, Magnum, Grand Voyager	EDM	√	√	√	√	√	○	√	0370, 1023
2009	LX-300, Charger, Magnum, Grand Voyager	ITM	√	√	√	√	√	√	√	0550
2009	LX-300, Charger, Magnum, Grand Voyager	RSM	√	√	√	√	√	○	○	0582
2009	LX-300, Charger, Magnum, Grand Voyager	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1129
2009	LX-300, Charger, Magnum, Grand Voyager	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2009	LX-300, Charger, Magnum, Grand Voyager	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	LX-300, Charger, Magnum, Grand Voyager	SDARV	√	√	√	√	√	○	○	
2009	LX-300, Charger, Magnum, Grand Voyager	AMP	√	√	√	√	√	○	√	0083, 0074
2009	LX-300, Charger, Magnum, Grand Voyager	HFM	√	√	√	√	√	√	○	0492
2009	LX-300, Charger, Magnum, Grand Voyager	VES3	√	√	√	√	√	√	√	
2009	LX-300, Charger, Magnum, Grand Voyager	DDM	√	√	√	√	√	√	※	
2009	LX-300, Charger, Magnum, Grand Voyager	PDM	√	√	√	√	√	√	※	0668
2009	LX-300, Charger, Magnum, Grand Voyager	HSM	√	√	√	√	√	√	√	
2009	LX-300, Charger, Magnum, Grand Voyager	DTCM	√	√	√	√	√	√	○	
2009	LX-300, Charger, Magnum, Grand Voyager	PEM	√	√	√	√	√	○	√	0609, 0648
2009	MK-Compass, Patriot	PCM	√	√	√	√	√	√	√	1048, 0311, 0257, 0294, 0349, 0216, 0281, 0454, 1123, 0659, 0820, 0340, 0373, 0377, 0378, 0480, 0590, 0827, 1042, 0409, 0215, 0589, 0628, 0927, 1054, 0127
2009	MK-Compass, Patriot	TCM	√	√	√	√	√	√	√	
2009	MK-Compass, Patriot	FDCM	√	√	√	√	√	√	√	
2009	MK-Compass, Patriot	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0527, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0425, 0402, 0810, 0816, 0817, 0752
2009	MK-Compass, Patriot	ORC	√	√	√	√	√	○	√	
2009	MK-Compass, Patriot	MIC_CCN	√	√	√	√	√	√	√	1014, 1186, 1023, 0152, 0150, 0187, 0619, 0666, 1015
2009	MK-Compass, Patriot	WCM	√	√	√	√	√	○	√	1131, 0789, 0790, 0439, 0741, 0793, 0799, 0802, 1247, 1248, 1252, 1255, 1188
2009	MK-Compass, Patriot	ITM	√	√	√	√	√	√	√	0550
2009	MK-Compass, Patriot	SAS	√	√	√	√	√	○	○	
2009	MK-Compass, Patriot	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2009	MK-Compass, Patriot	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	MK-Compass, Patriot	AMP	√	√	√	√	√	○	√	0083, 0074

2009	MK-Compass,Patriot	HFM	√	√	√	√	√	√	○	0492
2009	ND-Dakota	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 1201, 0446, 0705, 0437
2009	ND-Dakota	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274
2009	ND-Dakota	ORC	√	√	√	√	√	○	√	0581
2009	ND-Dakota	MIC_CCN	√	√	√	√	√	√	√	1014, 1023, 0150, 0152, 0332, 1184
2009	ND-Dakota	HVAC	√	√	√	√	√	√	√	0121, 0124, 0277, 0461, 0680
2009	ND-Dakota	WCM	√	√	√	√	√	○	√	1131, 0439, 0741, 0789, 0790, 0793, 0799, 0800, 0801, 1248, 1252
2009	ND-Dakota	EOM	√	√	√	√	√	○	√	0370
2009	ND-Dakota	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2009	ND-Dakota	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	ND-Dakota	AMP	√	√	√	√	√	○	√	0083, 0074
2009	ND-Dakota	HFM	√	√	√	√	√	√	○	0492
2009	NM-Raider	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 1201, 0446, 0705, 0437
2009	NM-Raider	CGW	√	√	√	√	√	√	√	0095, 0863, 0465, 0506, 0510, 1138, 1076, 1139, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0560, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274
2009	NM-Raider	ORC	√	√	√	√	√	○	√	0581
2009	NM-Raider	MIC_CCN	√	√	√	√	√	√	√	1014, 1023, 0150, 0152, 0332, 1184
2009	NM-Raider	HVAC	√	√	√	√	√	√	√	0121, 0124, 0277, 0461, 0680
2009	NM-Raider	WCM	√	√	√	√	√	○	√	1131, 0439, 0741, 0789, 0790, 0793, 0799, 0800, 0801, 1248, 1252
2009	NM-Raider	EOM	√	√	√	√	√	○	√	0370
2009	NM-Raider	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2009	NM-Raider	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	NM-Raider	AMP	√	√	√	√	√	○	√	0083, 0074
2009	NM-Raider	HFM	√	√	√	√	√	√	○	0492
2009	PM-Caliber	PCM	√	√	√	√	√	√	√	1048, 0311, 0257, 0294, 0349, 0216, 0281, 0454, 1123, 0659, 0820, 0340, 0373, 0377, 0378, 0480, 0590, 0827, 1042, 0409, 0215, 0689, 0628, 0927, 1054, 0127
2009	PM-Caliber	TCM	√	√	√	√	√	√	√	
2009	PM-Caliber	FDCM	√	√	√	√	√	√	√	
2009	PM-Caliber	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0527, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 0096, 0125, 0129, 0425, 0402, 0810, 0816, 0817, 0752
2009	PM-Caliber	ORC	√	√	√	√	√	○	√	
2009	PM-Caliber	MIC_CCN	√	√	√	√	√	√	√	1014, 1186, 1023, 0152, 0150, 0187, 0619, 0666, 1015
2009	PM-Caliber	WCM	√	√	√	√	√	○	√	1131, 0789, 0790, 0439, 0741, 0793, 0799, 0802, 1247, 1248, 1252, 1255, 1188
2009	PM-Caliber	ITM	√	√	√	√	√	√	√	0550
2009	PM-Caliber	SAS	√	√	√	√	√	○	○	
2009	PM-Caliber	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2009	PM-Caliber	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	PM-Caliber	AMP	√	√	√	√	√	○	√	0083, 0074
2009	PM-Caliber	HFM	√	√	√	√	√	√	○	0492
2009	PM-Caliber	EBG	√	√	√	√	√	○	○	
2009	PT-PT Cruiser	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0538, 0589, 1051, 0216, 0691, 0454, 1123, 0378, 0629, 0359, 0827, 1042, 0590, 0409, 0202, 0215, 0628, 0692, 0709, 0710, 0927, 1054, 1055
2009	PT-PT Cruiser	TCM	√	√	√	√	√	√	√	0011, 0028, 0045, 0230, 0834, 0979, 1107, 0015, 0016, 0032, 0049, 0243, 0830, 0983, 1062, 1063
2009	PT-PT Cruiser	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0527, 0560, 1076, 0095, 0125, 0425, 0402, 0810, 0816, 0817, 0752
2009	PT-PT Cruiser	ORC	√	√	√	√	√	○	√	
2009	PT-PT Cruiser	MIC_CCN	√	√	√	√	√	√	√	0150, 0152, 0187, 0619, 0666, 1015
2009	PT-PT Cruiser	OCM	√	√	√	√	√	○	○	0715
2009	PT-PT Cruiser	WCM	√	√	√	√	√	○	√	1131, 0789, 0790, 0439, 0741, 0793, 0799, 0802, 1247, 1248, 1252, 1255, 1188
2009	PT-PT Cruiser	ITM	√	√	√	√	√	√	√	0579

2009	PT-PT Cruiser	ABS	√	√	√	√	√	√	√	0056,0168,0567,0575,0585
2009	PT-PT Cruiser	RADIO	√	√	√	√	√	○	√	
2009	PT-PT Cruiser	SDAR	√	√	√	√	√	○	○	
2009	PT-PT Cruiser	AMP	√	√	√	√	√	○	√	0069,0074,0079,0083,0084,0070,0072,0078,0080
2009	PT-PT Cruiser	HFM	√	√	√	√	√	√	○	0492
2009	PT-PT Cruiser	DDM	√	√	√	√	√	√	○	
2009	PT-PT Cruiser	PDM	√	√	√	√	√	√	○	
2009	RT-Caravan,Town & Country	PCM	√	√	√	√	√	√	※	0257,0293,0294,0322,0323,0336,0356,1123,0471,0538,0589,0591,0820,0923,0926,1034,1047,1222,0216,0355,1051,0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0709,0710,0927,0981,1111,0698,0699,0732,0735,0830,0833,1140,0454,0202,1012,1201,0446,0705,0437
2009	RT-Caravan,Town & Country	TCM	√	√	√	√	√	√	○	0005,0007,0008,0009,0033,0022,0024,0025,0026,0038,0040,0041,0042,0651,0243,0324,1140,0694,0841,0974,0975,0976,0977,1107
2009	RT-Caravan,Town & Country	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0795,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152
2009	RT-Caravan,Town & Country	ORC	√	√	√	√	√	○	√	0581
2009	RT-Caravan,Town & Country	MIC_CCN	√	√	√	√	√	√	○	1186,1014,1023,0187,0210,0619,1015
2009	RT-Caravan,Town & Country	HVAC	√	√	√	√	√	√	√	0121,0277,0501,0461,0680,0498,0462
2009	RT-Caravan,Town & Country	PLGM	√	√	√	√	√	√	√	0199,0200,0877
2009	RT-Caravan,Town & Country	MSM	√	√	√	√	√	○	○	0341,0382,0604,1023,1084,1151,0110,0381
2009	RT-Caravan,Town & Country	PSM	√	√	√	√	√	√	○	0194,0201,1269,1272
2009	RT-Caravan,Town & Country	WCM	√	√	√	√	√	√	√	0143,0366,0613,0439,1131,0741,0790,0793,0794,0799,0800,1256
2009	RT-Caravan,Town & Country	SUNR	√	√	√	√	√	√	○	
2009	RT-Caravan,Town & Country	HIDT	√	√	√	√	√	√	○	0493
2009	RT-Caravan,Town & Country	AHBM	√	√	√	√	√	○	○	0153,1023
2009	RT-Caravan,Town & Country	PTS	√	√	√	√	√	√	√	0266,1106
2009	RT-Caravan,Town & Country	ITM	√	√	√	√	√	√	√	0550
2009	RT-Caravan,Town & Country	SAS	√	√	√	√	√	○	○	
2009	RT-Caravan,Town & Country	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2009	RT-Caravan,Town & Country	DVD	√	√	√	√	√	○	○	
2009	RT-Caravan,Town & Country	RADIO	√	√	√	√	√	√	○	0861,0867,0871,0426
2009	RT-Caravan,Town & Country	SDMRV	√	√	√	√	√	○	○	
2009	RT-Caravan,Town & Country	AMP	√	√	√	√	√	○	√	0083,0074
2009	RT-Caravan,Town & Country	HFM	√	√	√	√	√	√	○	0492
2009	RT-Caravan,Town & Country	VES2	√	√	√	√	√	√	√	
2009	RT-Caravan,Town & Country	VES3	√	√	√	√	√	√	√	
2009	RT-Caravan,Town & Country	DMFR	√	√	√	√	√	√	√	
2009	RT-Caravan,Town & Country	DMFL	√	√	√	√	√	√	√	
2009	RT-Caravan,Town & Country	DMRL	√	√	√	√	√	√	√	0622,0624,0630
2009	RT-Caravan,Town & Country	DMRR	√	√	√	√	√	√	√	0622,0624,0630
2009	RT-Caravan,Town & Country	PSDMR	√	√	√	√	√	○	√	0106,1067,0633,1070,0877
2009	RT-Caravan,Town & Country	PSDML	√	√	√	√	√	○	√	0106,1067,0633,1070,0877
2009	RT-Caravan,Town & Country	BSM	√	√	√	○	√	○	○	1027
2009	VB-Sprinter	ECM	√	√	√	√	√	√	√	0350,0203,0220,0433,0475,0711,0911,1147,0294,0257,0320,0321,0359,0448,0589,0591,0660,0662,0805,0874,1043
2009	VB-Sprinter	TCM	√	√	√	√	√	○	○	0350,1117,0677,1065,1112,1174
2009	VB-Sprinter	ESM	√	√	√	√	√	√	○	
2009	VB-Sprinter	CGW	√	√	√	√	√	○	√	0904,0440,0796,0350
2009	VB-Sprinter	ORC	√	√	√	○	√	○	○	0717,0930,1033,0350
2009	VB-Sprinter	MIC_CCN	√	√	√	√	√	○	○	0350,0184,0283,0284,0285,0286,0287,0481,0723,0765,1078,0828,0186
2009	VB-Sprinter	HVAC	√	√	√	√	√	√	√	0632
2009	VB-Sprinter	BCH	√	√	√	√	√	√	○	
2009	VB-Sprinter	ACH	√	√	√	√	√	√	○	
2009	VB-Sprinter	SCM	√	√	√	√	√	√	○	
2009	VB-Sprinter	RCM	√	√	√	√	√	√	○	0327
2009	VB-Sprinter	PSM	√	√	√	√	√	√	○	0350
2009	VB-Sprinter	TM	√	√	√	√	√	○	○	
2009	VB-Sprinter	AHLM	√	√	√	√	√	√	○	0193,0350
2009	VB-Sprinter	RCM	√	√	√	√	√	√	○	
2009	VB-Sprinter	AEHM	√	√	√	√	√	○	○	0065
2009	VB-Sprinter	PTS	√	√	√	√	√	√	√	0140,0608
2009	VB-Sprinter	TPM	√	√	√	√	√	○	○	0350,0636,0637,0984,0985,1156,1205,1207,1213
2009	VB-Sprinter	ABS	√	√	√	√	√	○	√	0168,0195,0342,0100,0350
2009	VB-Sprinter	SBM	√	√	√	√	√	√	○	
2009	VB-Sprinter	CDC	√	√	√	√	√	○	○	

2009	VB-Sprinter	RADIO	√	√	√	√	√	○	※	0350
2009	VB-Sprinter	HFM	√	√	√	√	√	○	○	0350
2009	VB-Sprinter	PSDMR	√	√	√	√	√	√	○	
2009	VB-Sprinter	PSDML	√	√	√	√	√	√	○	
2009	VB-Sprinter	DDM	√	√	√	√	√	√	○	
2009	WK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0538, 0591, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012, 1201, 0446, 0705, 0437
2009	WK-Grand Cherokee	TCM	√	√	√	√	√	○	○	0924, 1094
2009	WK-Grand Cherokee	ESM	√	√	√	√	√	√	○	
2009	WK-Grand Cherokee	FDCM	√	√	√	√	√	√	√	
2009	WK-Grand Cherokee	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1188, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274, 0805
2009	WK-Grand Cherokee	ORC	√	√	√	√	√	○	√	0581
2009	WK-Grand Cherokee	MIC_CCN	√	√	√	√	√	√	√	1184, 1186, 1023, 0150, 0152, 0185, 0187, 0210, 0619, 1035, 1036
2009	WK-Grand Cherokee	HVAC	√	√	√	√	√	√	√	0121, 0277, 0461, 0680
2009	WK-Grand Cherokee	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2009	WK-Grand Cherokee	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2009	WK-Grand Cherokee	TM	○	√	√	○	√	○	○	
2009	WK-Grand Cherokee	SUNR	√	√	√	※	√	√	○	
2009	WK-Grand Cherokee	AHLM	√	√	√	√	√	√	○	0193
2009	WK-Grand Cherokee	AHBM	√	√	√	√	√	○	○	0153, 1023
2009	WK-Grand Cherokee	PTS	√	√	√	√	√	√	√	0266, 1106
2009	WK-Grand Cherokee	EDM	√	√	√	√	√	○	√	0370, 1023
2009	WK-Grand Cherokee	ITM	√	√	√	√	√	√	√	0550
2009	WK-Grand Cherokee	RSM	√	√	√	√	√	○	○	0582
2009	WK-Grand Cherokee	SAS	√	√	√	√	√	○	○	
2009	WK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2009	WK-Grand Cherokee	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	WK-Grand Cherokee	SDMRV	√	√	√	√	√	○	○	
2009	WK-Grand Cherokee	AMP	√	√	√	√	√	○	√	0083, 0074
2009	WK-Grand Cherokee	HFM	√	√	√	√	√	√	○	0492
2009	WK-Grand Cherokee	VES3	√	√	√	√	√	√	√	
2009	WK-Grand Cherokee	DDM	√	√	√	√	√	√	※	0668, 0319
2009	WK-Grand Cherokee	PDM	√	√	√	√	√	√	※	0668, 0319
2009	WK-Grand Cherokee	IESM	√	√	√	√	√	√	√	
2009	XK-Commander	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0538, 0591, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0927, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012, 1201, 0446, 0705, 0437
2009	XK-Commander	TCM	√	√	√	√	√	○	○	0924, 1094
2009	XK-Commander	ESM	√	√	√	√	√	√	○	
2009	XK-Commander	FDCM	√	√	√	√	√	√	√	
2009	XK-Commander	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1188, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274, 0805
2009	XK-Commander	ORC	√	√	√	√	√	○	√	0581
2009	XK-Commander	MIC_CCN	√	√	√	√	√	√	√	1184, 1186, 1023, 0150, 0152, 0185, 0187, 0210, 0619, 1035, 1036
2009	XK-Commander	HVAC	√	√	√	√	√	√	√	0121, 0277, 0461, 0680
2009	XK-Commander	PLGM	√	√	√	√	√	√	√	0199, 0200
2009	XK-Commander	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2009	XK-Commander	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2009	XK-Commander	TM	○	√	√	○	√	○	○	
2009	XK-Commander	SUNR	√	√	√	※	√	√	○	
2009	XK-Commander	AHLM	√	√	√	√	√	√	○	0193
2009	XK-Commander	AHBM	√	√	√	√	√	○	○	0153, 1023
2009	XK-Commander	PTS	√	√	√	√	√	√	√	0266, 1106
2009	XK-Commander	ITM	√	√	√	√	√	√	√	0550
2009	XK-Commander	RSM	√	√	√	√	√	○	○	0582
2009	XK-Commander	SAS	√	√	√	√	√	○	○	

2009	XK-Commander	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2009	XK-Commander	RADIO	√	√	√	√	√	√	○	0861,0867,0871,0426
2009	XK-Commander	SDARV	√	√	√	√	√	○	○	
2009	XK-Commander	AMP	√	√	√	√	√	○	√	0083,0074
2009	XK-Commander	HFM	√	√	√	√	√	√	○	0492
2009	XK-Commander	VES3	√	√	√	√	√	√	√	
2009	XK-Commander	DDM	√	√	√	√	√	√	※	0668,0319
2009	XK-Commander	PDM	√	√	√	√	√	√	※	0668,0319
2009	XK-Commander	HSM	√	√	√	√	√	√	√	
2009	ZB-Viper	PCM	√	√	√	√	√	√	○	0377,0626,0826,1146,0590,0625,1208,0215,0216,0378,0480,0589,0606,0628,0827,0919,1051
2009	ZB-Viper	CGW	○	√	√	√	√	○	○	
2009	ZB-Viper	ORC	○	√	√	○	√	○	○	
2009	ZB-Viper	MIC CCN	○	√	√	○	√	○	○	0928
2009	ZB-Viper	HVAC	○	√	√	√	√	√	○	
2009	ZB-Viper	OCM	√	√	√	√	√	○	○	0715,0714
2009	ZB-Viper	BCM	○	√	√	√	√	√	○	
2009	ZB-Viper	ABS	○	√	√	√	√	√	○	
2009	ZB-Viper	RADIO	○	√	√	○	√	√	○	
2009	ZB-Viper	SDAR	○	√	√	√	√	√	○	
2009	DS-Ram Truck	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0927,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012,1201,0446,0705,0437
2009	DS-Ram Truck	CGW	√	√	√	√	√	√	√	0331,0465,0508,0510,0560,0897,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152,0254,0805,0402
2009	DS-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2009	DS-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186,1014,1023
2009	DS-Ram Truck	HVAC	√	√	√	√	√	※	√	0121,0498,0462,0680,0277
2009	DS-Ram Truck	MSM	√	√	√	√	√	○	○	0341,0382,0604,1023,1084,1151,0110,0381
2009	DS-Ram Truck	WCM	√	√	√	√	√	√	√	0439,0143,0801,0613
2009	DS-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2009	DS-Ram Truck	SAS	√	√	√	√	√	○	○	
2009	DS-Ram Truck	ABS	√	√	√	√	√	√	√	0056,0168
2009	DS-Ram Truck	RADIO	√	√	√	√	√	√	○	0861,0867,0871,0426
2009	DS-Ram Truck	SDARV	√	√	√	√	√	○	○	
2009	DS-Ram Truck	AMP	√	√	√	√	√	○	√	0083,0074
2009	DS-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2009	DS-Ram Truck	VES3	√	√	√	√	√	√	√	
2009	DS-Ram Truck	DMFR	√	√	√	√	√	√	○	
2009	DS-Ram Truck	DMFL	√	√	√	√	√	√	○	
2009	DS-Ram Truck	HSM	√	√	√	○	√	√	○	
2009	DS-Ram Truck	DTCM	√	√	√	√	√	√	○	
2009	JS-Wrangler	PCM	√	√	√	√	√	√	○	0257,0293,0294,0322,0323,0336,0356,1123,0471,0538,0589,0591,0820,0923,0926,1034,1047,1222,0216,0355,1051
2009	JS-Wrangler	TCM	√	√	√	√	√	√	○	0005,0007,0008,0009,0033,0022,0024,0025,0026,0038,0040,0041,0042,0051,0243,0324,1140,0974,0975,0976,0977,1107,0732,0735,0832,0833
2009	JS-Wrangler	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152,0402,0795,0812
2009	JS-Wrangler	ORC	√	√	√	√	√	○	√	
2009	JS-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186,1014,1023,0187,0210,0619,1015
2009	JS-Wrangler	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2009	JS-Wrangler	WCM	√	√	√	√	√	○	√	0439,0613,0614
2009	JS-Wrangler	SAS	√	√	√	√	√	○	○	
2009	JS-Wrangler	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2009	JS-Wrangler	RADIO	√	√	√	√	√	※	○	0861,0867,0871,0426
2009	JC-Journey	PCM	√	√	√	√	√	√	√	1048,0257,0294,0349,0311,0216,0281,0454,1123,0820,0659,0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0927,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0202,1012,1201,0446,0705,0437,0340,0377,0480,1054,0197
2009	JC-Journey	TCM	√	√	√	√	√	※	√	0011,0028,0045,0230,0834,0979,1107,0015,0016,0032,0049,0243,0830,0983,1062,1063
2009	JC-Journey	FDCM	√	√	√	√	√	○	√	

2009	JC-Journey	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2009	JC-Journey	ORC	√	√	√	√	√	○	√	0581
2009	JC-Journey	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2009	JC-Journey	HVAC	√	√	√	√	√	√	√	0121, 0277, 0501, 0461, 0680, 0498, 0462
2009	JC-Journey	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2009	JC-Journey	ITM	√	√	√	√	√	√	√	0550
2009	JC-Journey	SAS	√	√	√	√	√	○	○	
2009	JC-Journey	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2009	JC-Journey	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	JC-Journey	SDARV	√	√	√	√	√	○	○	
2009	JC-Journey	AMP	√	√	√	√	√	○	√	0083, 0074
2009	JC-Journey	HFM	√	√	√	√	√	√	○	0492
2009	JC-Journey	VESS	√	√	√	√	√	√	√	
2009	JC-Journey	DISP	√	√	√	○	√	○	○	
2009	JC-Journey	DMFR	√	√	√	√	√	√	√	
2009	JC-Journey	DMFL	√	√	√	√	√	√	√	
2009	LC-Challenger	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 1201, 0446, 0705, 0437
2009	LC-Challenger	TCM	√	√	√	√	√	○	○	0924, 1094
2009	LC-Challenger	ESM	√	√	√	√	√	√	○	
2009	LC-Challenger	CGW	√	√	√	√	√	√	√	0155, 0331, 0465, 0508, 0510, 0560, 1226, 0900, 1076, 1155, 1189, 0095, 1219, 1224, 1225
2009	LC-Challenger	ORC	√	√	√	√	√	○	√	0581
2009	LC-Challenger	MIC_CCN	√	√	√	√	√	√	√	0209, 1186, 1014, 1184, 0150, 0152
2009	LC-Challenger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680, 0277
2009	LC-Challenger	SCM	√	√	√	√	√	√	√	
2009	LC-Challenger	WCM	√	√	√	√	√	√	√	0439, 0143, 0793, 0794, 0799, 0800, 1256, 0366, 0613, 0741, 0790
2009	LC-Challenger	SUNR	√	√	√	※	√	√	○	
2009	LC-Challenger	EDM	√	√	√	√	√	○	√	0370, 1023
2009	LC-Challenger	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1129
2009	LC-Challenger	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2009	LC-Challenger	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	LC-Challenger	AMP	√	√	√	√	√	○	√	0083, 0074
2009	LC-Challenger	HFM	√	√	√	√	√	√	○	0492
2009	LC-Challenger	DDM	√	√	√	√	√	√	○	0319
2009	LC-Challenger	PDM	√	√	√	√	√	√	○	0319
2009	LC-Challenger	HESM	√	√	√	√	√	√	√	
2009	LC-Challenger	PEM	√	√	√	√	√	○	√	0609, 0648
2009	R2-Mini-Van	PCM	○	√	√	√	√	√	○	
2009	R2-Mini-Van	TCM	○	√	√	√	√	√	○	
2009	R2-Mini-Van	ORC	○	√	√	√	√	○	○	
2009	R2-Mini-Van	MIC_CCN	○	√	√	○	√	√	○	
2009	R2-Mini-Van	FCM	○	√	√	√	√	√	○	
2009	R2-Mini-Van	PLGM	○	√	√	√	√	√	○	
2009	R2-Mini-Van	ATC	○	√	√	√	√	√	○	
2009	R2-Mini-Van	MTC	○	√	√	○	√	√	○	
2009	R2-Mini-Van	MESM	○	√	√	√	√	√	○	
2009	R2-Mini-Van	OCM	○	√	√	√	√	○	○	0282, 0504, 0715, 0730, 1073
2009	R2-Mini-Van	BCM	○	√	√	√	√	√	○	
2009	R2-Mini-Van	PTS	○	√	√	√	√	○	○	
2009	R2-Mini-Van	EDM	○	√	√	○	√	○	○	
2009	R2-Mini-Van	SKM	○	√	√	○	√	√	○	0405, 0406, 0439, 0442, 0742, 0743, 0746, 0785, 0791, 0801, 0940, 1227, 1228, 1233, 1245, 1246, 1250, 1256, 1257
2009	R2-Mini-Van	ABS	○	√	√	√	√	√	○	
2009	R2-Mini-Van	SDAR	○	√	√	√	√	√	○	
2009	R2-Mini-Van	HFM	○	√	√	√	√	√	○	
2009	R2-Mini-Van	PSDMR	○	√	√	√	√	√	○	
2009	R2-Mini-Van	PSDML	○	√	√	√	√	√	○	
2009	RM-	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0927, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 1201, 0446, 0705, 0437
2009	RM-	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0812
2009	RM-	ORC	√	√	√	√	√	○	√	0581

2009	RM-	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2009	RM-	HVAC	√	√	√	√	√	√	√	0121, 0277, 0501, 0461, 0680, 0498, 0462
2009	RM-	PLGM	√	√	√	√	√	√	√	0199, 0200, 0877
2009	RM-	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2009	RM-	FSM	√	√	√	√	√	√	○	0194, 0201, 1269, 1272
2009	RM-	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2009	RM-	SUNR	√	√	√	√	√	√	○	
2009	RM-	PTS	√	√	√	√	√	√	√	0266, 1106
2009	RM-	SAS	√	√	√	√	√	○	○	
2009	RM-	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2009	RM-	DVD	√	√	√	√	√	○	○	
2009	RM-	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2009	RM-	AMP	√	√	√	√	√	○	√	0083, 0074
2009	RM-	HFM	√	√	√	√	√	√	○	0492
2009	RM-	VES2	√	√	√	√	√	√	√	
2009	RM-	VES3	√	√	√	√	√	√	√	
2009	RM-	DMFR	√	√	√	√	√	√	√	
2009	RM-	DMFL	√	√	√	√	√	√	√	
2009	RM-	DMRL	√	√	√	√	√	√	√	0622, 0624, 0630
2009	RM-	DMRR	√	√	√	√	√	√	√	0622, 0624, 0630
2009	RM-	PSDMR	√	√	√	√	√	○	√	0106, 1067, 0633, 1070, 0877
2009	RM-	PSDML	√	√	√	√	√	○	√	0106, 1067, 0633, 1070, 0877
2010	DR-RAM	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 1201, 0446, 0705, 0437, 0927, 0478, 0515, 0397, 0473, 0480, 0914, 0936, 0929, 1195, 0160, 0216, 0398, 0399, 0456, 0457, 0591, 0670, 0671, 0939, 1052, 1053, 1197, 0672, 1196, 0673, 0138, 0380, 0755, 0295, 0396, 0474, 1159, 1134, 1135, 0191, 0192, 0536, 1124
2010	DR-RAM	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0651, 0324, 1140, 0974, 0975, 0976, 0977, 1107, 0010, 0011, 0015, 0016, 0027, 0028, 0032, 0043, 0044, 0045, 0049, 0053, 0243, 0325, 0978, 0979, 0983, 0732, 0735, 0832, 0833, 0420
2010	DR-RAM	FDCM	√	√	√	√	√	○	○	0113, 0114, 0115, 0116, 0117, 0118
2010	DR-RAM	CGW	√	√	√	√	√	√	√	0119, 0331, 0465, 0508, 0510, 0527, 0560, 0795, 0897, 0900, 1076, 1155, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0254, 0425, 0402, 0810, 0816, 0817, 0752
2010	DR-RAM	ORC	√	√	√	√	√	○	√	
2010	DR-RAM	MIC_CCN	√	√	√	√	√	√	√	1023, 0152, 0150, 0187, 1184
2010	DR-RAM	HVAC	√	√	√	√	√	√	※	0122, 0124, 0277, 0461, 0680, 0121
2010	DR-RAM	WCM	√	√	√	√	√	○	√	1131, 0789, 0790, 0439, 0741, 0793, 0799, 0802, 1247, 1248, 1252, 1255, 1132
2010	DR-RAM	SUNR	√	√	√	○	√	√	○	
2010	DR-RAM	EOM	√	√	√	√	√	√	√	0370, 1023
2010	DR-RAM	SAS	√	√	√	√	√	○	○	
2010	DR-RAM	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2010	DR-RAM	RADIO	√	√	√	√	√	○	√	
2010	DR-RAM	SDAR	√	√	√	√	√	○	○	
2010	DR-RAM	AMP	√	√	√	√	√	○	√	0072, 0073, 0074, 0080, 0081, 0083, 0084
2010	DR-RAM	HFM	√	√	√	√	√	√	○	0492
2010	DR-RAM	VES	√	√	√	√	√	√	○	
2010	JK-Wrangler	PCM	√	√	√	√	√	√	※	0257, 0293, 0294, 0322, 0323, 0336, 0356, 1123, 0471, 0538, 0589, 0591, 0820, 0923, 0926, 1034, 1047, 1222, 0216, 0355, 1051, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 0202, 1012, 1201, 0446, 0705, 0437, 0927
2010	JK-Wrangler	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0651, 0243, 0324, 1140, 0974, 0975, 0976, 0977, 1107, 0732, 0735, 0832, 0833
2010	JK-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2010	JK-Wrangler	ORC	√	√	√	√	√	○	√	0098, 0581
2010	JK-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015

2010	JK-Wrangler	ASBS	√	√	√	√	√	○	○	1071, 1098, 1099, 1100, 1101
2010	JK-Wrangler	BCM	√	√	√	√	√	○	√	0439
2010	JK-Wrangler	ITM	√	√	√	√	√	√	√	
2010	JK-Wrangler	SAS	√	√	√	√	√	○	○	
2010	JK-Wrangler	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2010	JK-Wrangler	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0602, 0426
2010	JK-Wrangler	AMP	√	√	√	√	√	○	√	0083, 0074
2010	JK-Wrangler	HFM	√	√	√	√	√	√	○	0492
2010	JS-Avenger, Sebring, Convertible/Sedan	PCM	√	√	√	√	√	√	√	1048, 0257, 0294, 0311, 0216, 0820, 0281, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012, 1201, 0446, 0705, 0437, 0927, 0340, 0377, 0480, 1054, 0127
2010	JS-Avenger, Sebring, Convertible/Sedan	TCM	√	√	√	√	√	※	※	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0051, 0324, 1140, 0974, 0975, 0976, 0977, 1107, 0010, 0011, 0015, 0016, 0027, 0028, 0032, 0043, 0044, 0045, 0049, 0053, 0243, 0325, 0978, 0979, 0983, 0732, 0735, 0832, 0833, 0230, 0834, 0830, 1062, 1063
2010	JS-Avenger, Sebring, Convertible/Sedan	FDCM	√	√	√	√	√	○	√	
2010	JS-Avenger, Sebring, Convertible/Sedan	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0527, 0660, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0254, 0425, 0503, 0402, 0810, 0816, 0817, 0752
2010	JS-Avenger, Sebring, Convertible/Sedan	ORC	√	√	√	√	√	○	√	0098
2010	JS-Avenger, Sebring, Convertible/Sedan	MIC_CCN	√	√	√	√	√	√	√	1014, 1186, 1023, 0152, 0150, 0187, 0619, 0666, 1015
2010	JS-Avenger, Sebring, Convertible/Sedan	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680, 0277
2010	JS-Avenger, Sebring, Convertible/Sedan	BCM	√	√	√	√	√	○	√	0143, 0366, 1131, 0789, 0790, 0439, 0741, 0793, 0794, 0802, 1247, 1248, 1252, 1255
2010	JS-Avenger, Sebring, Convertible/Sedan	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2010	JS-Avenger, Sebring, Convertible/Sedan	PTCM	√	√	√	√	√	○	√	0661, 0893
2010	JS-Avenger, Sebring, Convertible/Sedan	SAS	√	√	√	√	√	○	○	
2010	JS-Avenger, Sebring, Convertible/Sedan	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2010	JS-Avenger, Sebring, Convertible/Sedan	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	JS-Avenger, Sebring, Convertible/Sedan	AMP	√	√	√	√	√	○	√	0083, 0074
2010	JS-Avenger, Sebring, Convertible/Sedan	HFM	√	√	√	√	√	√	○	0492
2010	JS-Avenger, Sebring, Convertible/Sedan	VES3	√	√	√	√	√	√	√	
2010	JS-Avenger, Sebring, Convertible/Sedan	DDM	√	√	√	√	√	√	○	0319
2010	JS-Avenger, Sebring, Convertible/Sedan	PDM	√	√	√	√	√	√	○	0319
2010	KA-Nitro	PCM	√	√	√	√	√	√	※	0257, 0293, 0294, 0322, 0323, 0336, 0356, 1123, 0471, 0538, 0589, 0591, 0820, 0923, 0926, 1034, 1047, 1222, 0216, 0355, 1051, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 0202, 1012, 1201, 0446, 0705, 0437, 0927
2010	KA-Nitro	TCM	√	√	√	√	√	○	○	0924, 1094
2010	KA-Nitro	ESM	√	√	√	√	√	√	○	
2010	KA-Nitro	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0660, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2010	KA-Nitro	ORC	√	√	√	√	√	○	√	0098
2010	KA-Nitro	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2010	KA-Nitro	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680, 0277
2010	KA-Nitro	OCM	√	√	√	√	√	○	○	0715
2010	KA-Nitro	BCM	√	√	√	√	√	○	√	0439
2010	KA-Nitro	PTS	√	√	√	√	√	√	√	0266, 1106
2010	KA-Nitro	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2010	KA-Nitro	SAS	√	√	√	√	√	○	○	
2010	KA-Nitro	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2010	KA-Nitro	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	KA-Nitro	AMP	√	√	√	√	√	○	√	0083, 0074
2010	KA-Nitro	HFM	√	√	√	√	√	√	○	0492
2010	KA-Nitro	DMFR	√	√	√	√	√	√	○	
2010	KA-Nitro	DMFL	√	√	√	√	√	√	√	

2010	KK-Liberty	PCM	√	√	√	√	√	√	※	0257, 0293, 0294, 0322, 0323, 0336, 0356, 1123, 0471, 0538, 0589, 0591, 0820, 0923, 0926, 1034, 1047, 1222, 0216, 0355, 1051, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 0202, 1012, 1201, 0446, 0705, 0437, 0927
2010	KK-Liberty	TCM	√	√	√	√	√	○	○	0924, 1094
2010	KK-Liberty	ESM	√	√	√	√	√	√	○	
2010	KK-Liberty	FDCM	√	√	√	√	√	√	○	0706
2010	KK-Liberty	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0660, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2010	KK-Liberty	OHC	√	√	√	√	√	○	√	0098
2010	KK-Liberty	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2010	KK-Liberty	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680, 0277
2010	KK-Liberty	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2010	KK-Liberty	OCM	√	√	√	√	√	○	○	0715
2010	KK-Liberty	WCM	√	√	√	√	√	○	√	0439, 0613, 0614
2010	KK-Liberty	SUNR	√	√	√	√	√	○	○	
2010	KK-Liberty	PTS	√	√	√	√	√	√	√	0266, 1106
2010	KK-Liberty	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2010	KK-Liberty	SAS	√	√	√	√	√	○	○	
2010	KK-Liberty	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2010	KK-Liberty	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	KK-Liberty	AMP	√	√	√	√	√	○	√	0083, 0074
2010	KK-Liberty	HFM	√	√	√	√	√	√	○	0492
2010	KK-Liberty	DMFR	√	√	√	√	√	√	○	
2010	KK-Liberty	DMFL	√	√	√	√	√	√	√	
2010	LX-300, Charger, Magnum, Grand Voyager	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0591, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012, 1201, 0446, 0705, 0437, 0927
2010	LX-300, Charger, Magnum, Grand Voyager	TCM	√	√	√	√	√	○	○	0924, 1094
2010	LX-300, Charger, Magnum, Grand Voyager	ESM	√	√	√	√	√	√	○	
2010	LX-300, Charger, Magnum, Grand Voyager	ACC	√	√	√	√	√	○	√	0062, 0063, 0139, 0208, 0064
2010	LX-300, Charger, Magnum, Grand Voyager	CGW	√	√	√	√	√	√	√	0155, 0331, 0465, 0508, 0510, 0660, 1226, 0900, 1076, 1155, 1189, 1219, 1224, 1225
2010	LX-300, Charger, Magnum, Grand Voyager	OHC	√	√	√	√	√	○	√	0581
2010	LX-300, Charger, Magnum, Grand Voyager	MIC_CCN	√	√	√	√	√	√	√	0209, 1186, 1014, 1184, 0150, 0152
2010	LX-300, Charger, Magnum, Grand Voyager	HVAC	√	√	√	√	√	√	√	0121, 0277, 0461, 0680
2010	LX-300, Charger, Magnum, Grand Voyager	MSM	√	√	√	√	√	○	○	0110
2010	LX-300, Charger, Magnum, Grand Voyager	SCM	√	√	√	√	√	√	√	
2010	LX-300, Charger, Magnum, Grand Voyager	WCM	√	√	√	√	√	√	√	0741, 0143, 0439, 0793, 0794, 0799, 0800, 1256, 0366, 0613, 1131, 0790
2010	LX-300, Charger, Magnum, Grand Voyager	SUNR	√	√	√	○	√	√	○	
2010	LX-300, Charger, Magnum, Grand Voyager	PTIM	√	√	√	√	√	√	√	
2010	LX-300, Charger, Magnum, Grand Voyager	HIDT	√	√	√	√	√	√	○	0196
2010	LX-300, Charger, Magnum, Grand Voyager	AHBM	√	√	√	√	√	○	○	0153, 1023
2010	LX-300, Charger, Magnum, Grand Voyager	PTS	√	√	√	√	√	√	√	0266, 1106
2010	LX-300, Charger, Magnum, Grand Voyager	EDM	√	√	√	√	√	○	√	1023
2010	LX-300, Charger, Magnum, Grand Voyager	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2010	LX-300, Charger, Magnum, Grand Voyager	RSM	√	√	√	√	√	○	○	0582
2010	LX-300, Charger, Magnum, Grand Voyager	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2010	LX-300, Charger, Magnum, Grand Voyager	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2010	LX-300, Charger, Magnum, Grand Voyager	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	LX-300, Charger, Magnum, Grand Voyager	SDARV	√	√	√	√	√	○	○	
2010	LX-300, Charger, Magnum, Grand Voyager	AMP	√	√	√	√	√	○	√	0083, 0074
2010	LX-300, Charger, Magnum, Grand Voyager	HFM	√	√	√	√	√	√	○	0492
2010	LX-300, Charger, Magnum, Grand Voyager	VESS	√	√	√	√	√	√	√	
2010	LX-300, Charger, Magnum, Grand Voyager	DDM	√	√	√	√	√	√	※	
2010	LX-300, Charger, Magnum, Grand Voyager	PDM	√	√	√	√	√	√	※	0668
2010	LX-300, Charger, Magnum, Grand Voyager	HESM	√	√	√	√	√	√	√	
2010	LX-300, Charger, Magnum, Grand Voyager	DTCM	√	√	√	√	√	√	○	
2010	LX-300, Charger, Magnum, Grand Voyager	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2010	MK-Compass, Patriot	PCM	√	√	√	√	√	√	※	0340, 0373, 0377, 0378, 0480, 0590, 0827, 1042, 0409, 0215, 0216, 0589, 0628, 0927, 1054, 0454, 1123, 0127, 0434, 1191, 0258, 0310, 0432, 0477, 0514, 0494, 0588, 0663, 0704, 0821, 1102, 1194, 1148, 0363
2010	MK-Compass, Patriot	TCM	√	√	√	√	√	√	√	
2010	MK-Compass, Patriot	FDCM	√	√	√	√	√	√	√	

2010	MK-Compass,Patriot	CGW	√	√	√	√	√	√	√	0108,0119,0331,0465,0508,0510,0560,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,0425,0527,0795,0402,0810,0816,0817,0752
2010	MK-Compass,Patriot	ORC	√	√	√	√	√	○	√	0098
2010	MK-Compass,Patriot	MIC_CCN	√	√	√	√	√	√	√	1014,1186,1023,0152,0150,0187,0619,0666,1015
2010	MK-Compass,Patriot	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2010	MK-Compass,Patriot	WCM	√	√	√	√	√	○	√	0143,0366,0439
2010	MK-Compass,Patriot	ITM	√	√	√	√	√	√	√	0555,1066,1178
2010	MK-Compass,Patriot	SAS	√	√	√	√	√	○	○	
2010	MK-Compass,Patriot	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2010	MK-Compass,Patriot	RADIO	√	√	√	√	√	※	○	0861,0867,0871,0426
2010	MK-Compass,Patriot	AMP	√	√	√	√	√	○	√	0069,0074,0077,0083,0085
2010	MK-Compass,Patriot	HFM	√	√	√	√	√	√	○	0492
2010	ND-Dakota	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012,1201,0446,0705,0437,0927
2010	ND-Dakota	CGW	√	√	√	√	√	√	√	0095,0863,0425,0465,0506,0510,0560,1138,1076,1139,1219,1224,1225,1226,0096,0129,0207,0226,0233,0234,0331,0412,0489,0490,0508,0509,0527,0684,0685,0686,0795,0899,1075,1154,1164,1262,1263,1274
2010	ND-Dakota	ORC	√	√	√	√	√	○	√	0581
2010	ND-Dakota	MIC_CCN	√	√	√	√	√	√	√	1014,1023,0150,0152,0332,1184
2010	ND-Dakota	HVAC	√	√	√	√	√	√	√	0121,0124,0277,0461,0680
2010	ND-Dakota	WCM	√	√	√	√	√	○	√	1131,0439,0741,0789,0790,0793,0799,0800,0801,1248,1252
2010	ND-Dakota	EDM	√	√	√	√	√	○	√	0370
2010	ND-Dakota	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2010	ND-Dakota	RADIO	√	√	√	√	√	※	○	0861,0867,0871,0426
2010	ND-Dakota	AMP	√	√	√	√	√	○	√	0083,0074
2010	ND-Dakota	HFM	√	√	√	√	√	√	○	0492
2010	NM-Raider	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012,1201,0446,0705,0437,0927
2010	NM-Raider	CGW	√	√	√	√	√	√	√	0095,0863,0425,0465,0506,0510,0560,1138,1076,1139,1219,1224,1225,1226,0096,0129,0207,0226,0233,0234,0331,0412,0489,0490,0508,0509,0527,0684,0685,0686,0795,0899,1075,1154,1164,1262,1263,1274
2010	NM-Raider	ORC	√	√	√	√	√	○	√	0581
2010	NM-Raider	MIC_CCN	√	√	√	√	√	√	√	1014,1023,0150,0152,0332,1184
2010	NM-Raider	HVAC	√	√	√	√	√	√	√	0121,0124,0277,0461,0680
2010	NM-Raider	WCM	√	√	√	√	√	○	√	1131,0439,0741,0789,0790,0793,0799,0800,0801,1248,1252
2010	NM-Raider	EDM	√	√	√	√	√	○	√	0370
2010	NM-Raider	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2010	NM-Raider	RADIO	√	√	√	√	√	※	○	0861,0867,0871,0426
2010	NM-Raider	AMP	√	√	√	√	√	○	√	0083,0074
2010	NM-Raider	HFM	√	√	√	√	√	√	○	0492
2010	PM-Caliber	PCM	√	√	√	√	√	√	※	0340,0373,0377,0378,0480,0690,0827,1042,0409,0215,0216,0589,0628,0927,1054,0454,1123,0127,0434,1191,0258,0310,0432,0477,0514,0494,0588,0663,0704,0821,1102,1194,1148,0363
2010	PM-Caliber	TCM	√	√	√	√	√	√	√	
2010	PM-Caliber	FDCM	√	√	√	√	√	√	√	
2010	PM-Caliber	CGW	√	√	√	√	√	√	√	0108,0119,0331,0465,0508,0510,0527,0660,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,0425,0402,0810,0816,0817,0752
2010	PM-Caliber	ORC	√	√	√	√	√	○	√	0098
2010	PM-Caliber	MIC_CCN	√	√	√	√	√	√	√	1014,1186,1023,0152,0150,0187,0619,0666,1015
2010	PM-Caliber	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2010	PM-Caliber	WCM	√	√	√	√	√	○	√	0143,0366,0439
2010	PM-Caliber	ITM	√	√	√	√	√	√	√	0555,1066,1178
2010	PM-Caliber	SAS	√	√	√	√	√	○	○	
2010	PM-Caliber	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2010	PM-Caliber	RADIO	√	√	√	√	√	※	○	0861,0867,0871,0426
2010	PM-Caliber	AMP	√	√	√	√	√	○	√	0069,0074,0077,0083,0085
2010	PM-Caliber	HFM	√	√	√	√	√	√	○	0492
2010	PM-Caliber	EBG	√	√	√	√	√	○	○	

2010	PT-PT Cruiser	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0538, 0589, 1051, 0216, 0691, 0454, 1123, 0378, 0629, 0359, 0827, 1042, 0590, 0409, 0202, 0215, 0628, 0692, 0709, 0710, 0927, 1054, 1055
2010	PT-PT Cruiser	TCM	√	√	√	√	√	√	√	0011, 0028, 0045, 0230, 0834, 0979, 1107, 0015, 0016, 0032, 0049, 0243, 0830, 0983, 1062, 1063
2010	PT-PT Cruiser	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0527, 0560, 1076, 0095, 0125, 0425, 0402, 0810, 0816, 0817, 0752
2010	PT-PT Cruiser	ORC	√	√	√	√	√	○	√	
2010	PT-PT Cruiser	MIC_CCN	√	√	√	√	√	√	√	0150, 0152, 0187, 0619, 0666, 1015
2010	PT-PT Cruiser	OCM	√	√	√	√	√	○	○	0715
2010	PT-PT Cruiser	WCM	√	√	√	√	√	○	√	1131, 0789, 0790, 0439, 0741, 0793, 0799, 0802, 1247, 1248, 1252, 1255
2010	PT-PT Cruiser	ITM	√	√	√	√	√	√	√	0655, 1066, 1178, 0579
2010	PT-PT Cruiser	ABS	√	√	√	√	√	√	√	0056, 0168, 0567, 0575, 0585
2010	PT-PT Cruiser	RADIO	√	√	√	√	√	○	√	
2010	PT-PT Cruiser	SDAR	√	√	√	√	√	○	○	
2010	PT-PT Cruiser	AMP	√	√	√	√	√	○	√	0069, 0074, 0079, 0083, 0084, 0070, 0072, 0078, 0080
2010	PT-PT Cruiser	HFM	√	√	√	√	√	√	○	0492
2010	PT-PT Cruiser	DDM	√	√	√	√	√	√	○	
2010	PT-PT Cruiser	PDM	√	√	√	√	√	√	○	
2010	RT-Caravan, Town & Country	PCM	√	√	√	√	√	√	※	0257, 0293, 0294, 0322, 0323, 0336, 0356, 1123, 0471, 0538, 0589, 0591, 0820, 0923, 0926, 1034, 1047, 1222, 0216, 0355, 1051, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 0202, 1012, 1201, 0446, 0705, 0437, 0927
2010	RT-Caravan, Town & Country	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0651, 0243, 0324, 1140, 0694, 0841, 0974, 0975, 0976, 0977, 1107
2010	RT-Caravan, Town & Country	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2010	RT-Caravan, Town & Country	ORC	√	√	√	√	√	○	√	0098, 0581
2010	RT-Caravan, Town & Country	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2010	RT-Caravan, Town & Country	HVAC	√	√	√	√	√	√	√	0121, 0277, 0501, 0461, 0680, 0498, 0462
2010	RT-Caravan, Town & Country	PLGM	√	√	√	√	√	√	√	0199, 0200, 0877
2010	RT-Caravan, Town & Country	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2010	RT-Caravan, Town & Country	PSM	√	√	√	√	√	√	○	0194, 0201, 1269, 1272
2010	RT-Caravan, Town & Country	WCM	√	√	√	√	√	√	√	0439, 0143, 0613, 0801, 0366, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2010	RT-Caravan, Town & Country	SUNR	√	√	√	√	√	√	○	
2010	RT-Caravan, Town & Country	HIDT	√	√	√	√	√	√	○	0493
2010	RT-Caravan, Town & Country	AHBM	√	√	√	√	√	○	○	0153, 1023
2010	RT-Caravan, Town & Country	PTS	√	√	√	√	√	√	√	0266, 1106
2010	RT-Caravan, Town & Country	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2010	RT-Caravan, Town & Country	SAS	√	√	√	√	√	○	○	
2010	RT-Caravan, Town & Country	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2010	RT-Caravan, Town & Country	DVD	√	√	√	√	√	○	○	
2010	RT-Caravan, Town & Country	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	RT-Caravan, Town & Country	SDARV	√	√	√	√	√	○	○	
2010	RT-Caravan, Town & Country	AMP	√	√	√	√	√	○	√	0083, 0074
2010	RT-Caravan, Town & Country	HFM	√	√	√	√	√	√	○	0492
2010	RT-Caravan, Town & Country	VES2	√	√	√	√	√	√	√	
2010	RT-Caravan, Town & Country	VES3	√	√	√	√	√	√	√	
2010	RT-Caravan, Town & Country	DMFR	√	√	√	√	√	√	○	
2010	RT-Caravan, Town & Country	DMFL	√	√	√	√	√	√	√	
2010	RT-Caravan, Town & Country	DMRL	√	√	√	√	√	√	√	0622, 0624, 0630
2010	RT-Caravan, Town & Country	DMRR	√	√	√	√	√	√	√	0622, 0624, 0630
2010	RT-Caravan, Town & Country	PSDMR	√	√	√	√	√	○	√	0106, 1067, 0633, 1070, 0877
2010	RT-Caravan, Town & Country	PSDML	√	√	√	√	√	○	√	0106, 1067, 0633, 1070, 0877
2010	RT-Caravan, Town & Country	BSM	√	√	√	○	√	○	○	1027
2010	WK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0538, 0591, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012, 1201, 0446, 0705, 0437, 0927
2010	WK-Grand Cherokee	TCM	√	√	√	√	√	○	○	0924, 1094
2010	WK-Grand Cherokee	ESM	√	√	√	√	√	√	○	
2010	WK-Grand Cherokee	FDCM	√	√	√	√	√	√	√	

2010	WK-Grand Cherokee	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1188, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274, 0805
2010	WK-Grand Cherokee	ORC	√	√	√	√	√	○	√	0581
2010	WK-Grand Cherokee	MIC_CCN	√	√	√	√	√	√	√	1184, 1186, 1023, 0150, 0152, 0185, 0187, 0210, 0619, 1035, 1036
2010	WK-Grand Cherokee	HVAC	√	√	√	√	√	√	√	0121, 0277, 0461, 0680
2010	WK-Grand Cherokee	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2010	WK-Grand Cherokee	WCM	√	√	√	√	√	√	√	0439, 0143, 0801, 0366, 0613, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2010	WK-Grand Cherokee	TM	○	√	√	○	√	○	○	
2010	WK-Grand Cherokee	SUNR	√	√	√	○	√	√	○	
2010	WK-Grand Cherokee	AHLM	√	√	√	√	√	√	○	0193
2010	WK-Grand Cherokee	AHBM	√	√	√	√	√	○	○	0153, 1023
2010	WK-Grand Cherokee	PTS	√	√	√	√	√	√	√	0266, 1106
2010	WK-Grand Cherokee	EOM	√	√	√	√	√	○	√	1023
2010	WK-Grand Cherokee	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2010	WK-Grand Cherokee	RSM	√	√	√	√	√	○	○	0582
2010	WK-Grand Cherokee	SAS	√	√	√	√	√	○	○	
2010	WK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2010	WK-Grand Cherokee	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	WK-Grand Cherokee	SDARV	√	√	√	√	√	○	○	
2010	WK-Grand Cherokee	AMP	√	√	√	√	√	○	√	0083, 0074
2010	WK-Grand Cherokee	HFM	√	√	√	√	√	√	○	0492
2010	WK-Grand Cherokee	VES3	√	√	√	√	√	√	√	
2010	WK-Grand Cherokee	DDM	√	√	√	√	√	√	※	0668, 0319
2010	WK-Grand Cherokee	PDM	√	√	√	√	√	√	※	0668, 0319
2010	WK-Grand Cherokee	HSM	√	√	√	√	√	√	√	
2010	XK-Commander	PCM	√	√	√	√	√	√	√	0257, 0293, 0294, 0589, 1051, 1199, 0216, 0320, 0321, 0449, 0471, 0591, 0660, 0689, 0690, 0454, 1123, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0709, 0710, 0981, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012, 1201, 0446, 0705, 0437, 0927
2010	XK-Commander	TCM	√	√	√	√	√	○	○	0924, 1094
2010	XK-Commander	ESM	√	√	√	√	√	√	○	
2010	XK-Commander	FDCM	√	√	√	√	√	√	√	
2010	XK-Commander	CGW	√	√	√	√	√	√	√	0095, 0863, 0425, 0465, 0506, 0510, 0560, 1138, 1076, 1139, 1188, 1219, 1224, 1225, 1226, 0096, 0129, 0207, 0226, 0233, 0234, 0331, 0412, 0489, 0490, 0508, 0509, 0527, 0684, 0685, 0686, 0795, 0899, 1075, 1154, 1164, 1262, 1263, 1274, 0805
2010	XK-Commander	ORC	√	√	√	√	√	○	√	0581
2010	XK-Commander	MIC_CCN	√	√	√	√	√	√	√	1184, 1186, 1023, 0150, 0152, 0185, 0187, 0210, 0619, 1035, 1036
2010	XK-Commander	HVAC	√	√	√	√	√	√	√	0121, 0277, 0461, 0680
2010	XK-Commander	PLGM	√	√	√	√	√	√	√	0199, 0200
2010	XK-Commander	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110
2010	XK-Commander	WCM	√	√	√	√	√	√	√	0439, 0143, 0801, 0366, 0613, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2010	XK-Commander	TM	○	√	√	○	√	○	○	
2010	XK-Commander	SUNR	√	√	√	○	√	√	○	
2010	XK-Commander	AHLM	√	√	√	√	√	√	○	0193
2010	XK-Commander	AHBM	√	√	√	√	√	○	○	0153, 1023
2010	XK-Commander	PTS	√	√	√	√	√	√	√	0266, 1106
2010	XK-Commander	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2010	XK-Commander	RSM	√	√	√	√	√	○	○	0582
2010	XK-Commander	SAS	√	√	√	√	√	○	○	
2010	XK-Commander	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2010	XK-Commander	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	XK-Commander	SDARV	√	√	√	√	√	○	○	
2010	XK-Commander	AMP	√	√	√	√	√	○	√	0083, 0074
2010	XK-Commander	HFM	√	√	√	√	√	√	○	0492
2010	XK-Commander	VES3	√	√	√	√	√	√	√	
2010	XK-Commander	DDM	√	√	√	√	√	√	※	0668, 0319
2010	XK-Commander	PDM	√	√	√	√	√	√	※	0668, 0319
2010	XK-Commander	HSM	√	√	√	√	√	√	√	
2010	ZB-Viper	PCM	√	√	√	√	√	√	○	0377, 0626, 0826, 1146, 0590, 0625, 1208, 0215, 0216, 0378, 0480, 0589, 0606, 0628, 0827, 0919, 1051
2010	ZB-Viper	CGW	○	√	√	√	√	○	○	
2010	ZB-Viper	ORC	○	√	√	○	√	○	○	
2010	ZB-Viper	MIC_CCN	○	√	√	○	√	○	○	0928

2010	ZB-Viper	HVAC	○	√	√	√	√	√	○	
2010	ZB-Viper	OCM	√	√	√	√	√	○	○	0715,0714
2010	ZB-Viper	BCM	○	√	√	√	√	√	○	
2010	ZB-Viper	ABS	○	√	√	√	√	√	○	
2010	ZB-Viper	RADIO	○	√	√	○	√	√	○	
2010	ZB-Viper	SDAR	○	√	√	√	√	√	○	
2010	D2-Ram Truck	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012,1201,0446,0705,0437,0927,0591,0658,0722,0755,0004,0021,0037,0438,1240,1237,1238,0973,0734,0456,0398,0457,0936,0473
2010	D2-Ram Truck	CGW	√	√	√	√	√	√	√	0331,0465,0508,0510,0560,0897,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0254,0805,0402
2010	D2-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2010	D2-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186,1014,1023
2010	D2-Ram Truck	HVAC	√	√	√	√	√	※	√	0121,0498,0462,0680,0277
2010	D2-Ram Truck	MSM	√	√	√	√	√	○	○	0341,0382,0604,1023,1084,1151,0110,0381
2010	D2-Ram Truck	WCM	√	√	√	√	√	√	√	0439,0143,0613
2010	D2-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2010	D2-Ram Truck	SAS	√	√	√	√	√	○	○	
2010	D2-Ram Truck	ABS	√	√	√	√	√	√	√	0056,0168
2010	D2-Ram Truck	RADIO	√	√	√	√	√	※	○	0861,0867,0871,0426
2010	D2-Ram Truck	SDARV	√	√	√	√	√	○	○	
2010	D2-Ram Truck	AMP	√	√	√	√	√	○	√	0083,0074
2010	D2-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2010	D2-Ram Truck	VES3	√	√	√	√	√	√	√	
2010	D2-Ram Truck	DMFR	√	√	√	√	√	√	√	
2010	D2-Ram Truck	DMFL	√	√	√	√	√	√	√	
2010	D2-Ram Truck	HSM	√	√	√	○	√	√	○	
2010	D2-Ram Truck	DTCM	√	√	√	√	√	√	○	
2010	D2-Ram Truck	ITBM	√	√	√	√	√	○	○	
2010	DJ-Ram Truck	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012,1201,0446,0705,0437,0927,0591,0658,0722,0755,1240,1237,1238,0004,0021,0037,0973,0734,0438,0456,0398,0457,0936,0473
2010	DJ-Ram Truck	FDCM	√	√	√	√	√	○	○	0113,0114,0115,0116,0117,0118
2010	DJ-Ram Truck	CGW	√	√	√	√	√	√	√	0331,0465,0508,0510,0560,0897,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152,0254,0805,0402
2010	DJ-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2010	DJ-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186,1014,1023
2010	DJ-Ram Truck	HVAC	√	√	√	√	√	※	√	0121,0498,0462,0680,0277
2010	DJ-Ram Truck	MSM	√	√	√	√	√	○	○	0341,0382,0604,1023,1084,1151,0110,0381
2010	DJ-Ram Truck	WCM	√	√	√	√	√	√	√	0439,0143,0613
2010	DJ-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2010	DJ-Ram Truck	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800
2010	DJ-Ram Truck	SAS	√	√	√	√	√	○	○	
2010	DJ-Ram Truck	ABS	√	√	√	√	√	√	√	0056,0168
2010	DJ-Ram Truck	RADIO	√	√	√	√	√	※	○	0861,0867,0871,0426
2010	DJ-Ram Truck	SDARV	√	√	√	√	√	○	○	
2010	DJ-Ram Truck	AMP	√	√	√	√	√	○	√	0083,0074
2010	DJ-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2010	DJ-Ram Truck	VES3	√	√	√	√	√	√	√	
2010	DJ-Ram Truck	DMFR	√	√	√	√	√	√	√	
2010	DJ-Ram Truck	DMFL	√	√	√	√	√	√	√	
2010	DJ-Ram Truck	HSM	√	√	√	○	√	√	○	
2010	DJ-Ram Truck	DTCM	√	√	√	√	√	√	○	
2010	DJ-Ram Truck	ITBM	√	√	√	√	√	○	○	
2010	DS-Ram Truck	PCM	√	√	√	√	√	√	√	0014,0017,0031,0048,0378,0628,0831,0978,0982,0359,0373,0827,1042,1107,0229,0590,0409,0010,0013,0027,0030,0043,0047,0053,0215,0243,0589,0709,0710,0981,1051,1111,0698,0699,0732,0735,0830,0833,1140,0454,1123,0202,1012,1201,0446,0705,0437,0927
2010	DS-Ram Truck	CGW	√	√	√	√	√	√	√	0331,0465,0508,0510,0560,0897,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152,0254,0805,0402

2010	DS-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2010	DS-Ram Truck	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2010	DS-Ram Truck	HVAC	√	√	√	√	√	※	√	0121, 0498, 0462, 0680, 0277
2010	DS-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2010	DS-Ram Truck	WCM	√	√	√	√	√	√	√	0439, 0143, 0793, 0794, 0799, 0800, 1256, 0801, 0613
2010	DS-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2010	DS-Ram Truck	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2010	DS-Ram Truck	SAS	√	√	√	√	√	○	○	
2010	DS-Ram Truck	ABS	√	√	√	√	√	√	√	0056, 0168
2010	DS-Ram Truck	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	DS-Ram Truck	SDARV	√	√	√	√	√	○	○	
2010	DS-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2010	DS-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2010	DS-Ram Truck	VES3	√	√	√	√	√	√	√	
2010	DS-Ram Truck	DMFR	√	√	√	√	√	√	√	
2010	DS-Ram Truck	DMFL	√	√	√	√	√	√	√	
2010	DS-Ram Truck	HSM	√	√	√	○	√	√	○	
2010	DS-Ram Truck	DTCM	√	√	√	√	√	√	○	
2010	DS-Ram Truck	ITBM	√	√	√	√	√	○	○	
2010	DX-Ram Truck	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 0437, 1201, 0446, 0705, 0927, 0591, 0558, 0722, 0755, 1240, 1237, 1238, 0004, 0021, 0037, 0973, 0734, 0438, 0456, 0398, 0457, 0936, 0473
2010	DX-Ram Truck	CGW	√	√	√	√	√	√	√	0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0254, 0805, 0402
2010	DX-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2010	DX-Ram Truck	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2010	DX-Ram Truck	HVAC	√	√	√	√	√	※	√	0121, 0498, 0462, 0680, 0277
2010	DX-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2010	DX-Ram Truck	WCM	√	√	√	√	√	√	√	0439, 0143, 0793, 0794, 0799, 0800, 1256, 0801, 0613
2010	DX-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2010	DX-Ram Truck	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2010	DX-Ram Truck	SAS	√	√	√	√	√	○	○	
2010	DX-Ram Truck	ABS	√	√	√	√	√	√	√	0056, 0168
2010	DX-Ram Truck	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	DX-Ram Truck	SDARV	√	√	√	√	√	○	○	
2010	DX-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2010	DX-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2010	DX-Ram Truck	VES3	√	√	√	√	√	√	√	
2010	DX-Ram Truck	DMFR	√	√	√	√	√	√	√	
2010	DX-Ram Truck	DMFL	√	√	√	√	√	√	√	
2010	DX-Ram Truck	HSM	√	√	√	○	√	√	○	
2010	DX-Ram Truck	DTCM	√	√	√	√	√	√	○	
2010	DX-Ram Truck	ITBM	√	√	√	√	√	○	○	
2010	JS-Wrangler	PCM	√	√	√	√	√	√	○	0257, 0293, 0294, 0322, 0323, 0336, 0356, 1123, 0471, 0538, 0589, 0591, 0820, 0923, 0926, 1034, 1047, 1222, 0216, 0355, 1051
2010	JS-Wrangler	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0051, 0243, 0324, 1140, 0974, 0975, 0976, 0977, 1107, 0732, 0735, 0832, 0833
2010	JS-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2010	JS-Wrangler	ORC	√	√	√	√	√	○	√	0098, 0581
2010	JS-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2010	JS-Wrangler	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2010	JS-Wrangler	WCM	√	√	√	√	√	○	√	0439, 0613, 0614
2010	JS-Wrangler	SAS	√	√	√	√	√	○	○	
2010	JS-Wrangler	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2010	JS-Wrangler	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	JC-Journey	PCM	√	√	√	√	√	√	√	1048, 0311, 0257, 0294, 0349, 0216, 0281, 0454, 1123, 0820, 0659, 0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0202, 1012, 1201, 0446, 0705, 0437, 0927, 0340, 0377, 0480, 1054, 0127

2010	JC-Journey	TCM	√	√	√	√	√	※	√	0011, 0028, 0045, 0230, 0834, 0979, 1107, 0015, 0016, 0032, 0049, 0243, 0830, 0983, 1062, 1063
2010	JC-Journey	FDCM	√	√	√	√	√	○	√	
2010	JC-Journey	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2010	JC-Journey	OBC	√	√	√	√	√	○	√	0098, 0581
2010	JC-Journey	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2010	JC-Journey	HVAC	√	√	√	√	√	√	√	0121, 0277, 0501, 0461, 0680, 0498, 0462
2010	JC-Journey	BCM	√	√	√	√	√	√	√	0439, 0143, 0801, 0368, 0613, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2010	JC-Journey	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2010	JC-Journey	SAS	√	√	√	√	√	○	○	
2010	JC-Journey	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2010	JC-Journey	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	JC-Journey	SDARV	√	√	√	√	√	○	○	
2010	JC-Journey	AMP	√	√	√	√	√	○	√	0083, 0074
2010	JC-Journey	HFM	√	√	√	√	√	√	○	0492
2010	JC-Journey	VESS	√	√	√	√	√	√	√	
2010	JC-Journey	DISP	√	√	√	○	√	○	○	
2010	JC-Journey	DMFR	√	√	√	√	√	√	○	
2010	JC-Journey	DMFL	√	√	√	√	√	√	√	
2010	LC-Challenger	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 1201, 0446, 0705, 0437, 0927
2010	LC-Challenger	TCM	√	√	√	√	√	○	○	0924, 1094
2010	LC-Challenger	ESM	√	√	√	√	√	√	○	
2010	LC-Challenger	CGW	√	√	√	√	√	√	√	0155, 0331, 0465, 0508, 0510, 0560, 1226, 0900, 1076, 1155, 1189, 1219, 1224, 1225
2010	LC-Challenger	OBC	√	√	√	√	√	○	√	0581
2010	LC-Challenger	MIC_CCN	√	√	√	√	√	√	√	0209, 1186, 1014, 1184, 0150, 0152
2010	LC-Challenger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680, 0277
2010	LC-Challenger	SCM	√	√	√	√	√	√	√	
2010	LC-Challenger	WCM	√	√	√	√	√	√	√	0439, 0143, 0793, 0794, 0799, 0800, 1256, 0366, 0613
2010	LC-Challenger	SUNR	√	√	√	○	√	√	○	
2010	LC-Challenger	EDM	√	√	√	√	√	○	√	1023
2010	LC-Challenger	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2010	LC-Challenger	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2010	LC-Challenger	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	LC-Challenger	AMP	√	√	√	√	√	○	√	0083, 0074
2010	LC-Challenger	HFM	√	√	√	√	√	√	○	0492
2010	LC-Challenger	DDM	√	√	√	√	√	√	○	0319
2010	LC-Challenger	PDM	√	√	√	√	√	√	○	0319
2010	LC-Challenger	HSM	√	√	√	√	√	√	√	
2010	LC-Challenger	PEM	√	√	√	√	√	○	√	0609
2010	R2-Mini-Van	TCM	○	√	√	√	√	√	○	
2010	R2-Mini-Van	OBC	○	√	√	√	√	○	○	
2010	R2-Mini-Van	MIC_CCN	○	√	√	○	√	√	○	
2010	R2-Mini-Van	PCM	○	√	√	√	√	√	○	
2010	R2-Mini-Van	PLGM	○	√	√	√	√	√	○	
2010	R2-Mini-Van	ATC	○	√	√	√	√	√	○	
2010	R2-Mini-Van	MTC	○	√	√	○	√	√	○	
2010	R2-Mini-Van	MSM	○	√	√	√	√	√	○	
2010	R2-Mini-Van	OCM	○	√	√	√	√	○	○	
2010	R2-Mini-Van	BCM	○	√	√	√	√	√	○	
2010	R2-Mini-Van	PTS	○	√	√	√	√	○	○	
2010	R2-Mini-Van	EDM	○	√	√	○	√	○	○	
2010	R2-Mini-Van	SKM	○	√	√	○	√	√	○	
2010	R2-Mini-Van	ABS	○	√	√	√	√	√	○	
2010	R2-Mini-Van	SDAR	○	√	√	√	√	√	○	
2010	R2-Mini-Van	HFM	○	√	√	√	√	√	○	
2010	R2-Mini-Van	PSDMR	○	√	√	√	√	√	○	
2010	R2-Mini-Van	PSDML	○	√	√	√	√	√	○	
2010	RM-	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0378, 0628, 0831, 0978, 0982, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0202, 1012, 1201, 0446, 0705, 0437, 0927
2010	RM-	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0402, 0812

2010	RM-	ORC	√	√	√	√	√	○	√	0098, 0581
2010	RM-	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2010	RM-	HVAC	√	√	√	√	√	√	√	0121, 0277, 0501, 0461, 0680, 0498, 0462
2010	RM-	PLGM	√	√	√	√	√	√	√	0199, 0200, 0877
2010	RM-	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2010	RM-	PSM	√	√	√	√	√	√	○	0194, 0201, 1269, 1272
2010	RM-	WCM	√	√	√	√	√	√	√	0439, 0143, 0613, 0614, 0801, 0366, 1131, 0741, 0790, 0793, 0794, 0799, 0800, 1256
2010	RM-	SUNR	√	√	√	√	√	√	○	
2010	RM-	PTS	√	√	√	√	√	√	√	0266, 1106
2010	RM-	SAS	√	√	√	√	√	○	○	
2010	RM-	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2010	RM-	DVD	√	√	√	√	√	○	○	
2010	RM-	RADIO	√	√	√	√	√	※	○	0861, 0867, 0871, 0426
2010	RM-	AMP	√	√	√	√	√	○	√	0083, 0074
2010	RM-	HFM	√	√	√	√	√	√	○	0492
2010	RM-	VES2	√	√	√	√	√	√	√	
2010	RM-	VES3	√	√	√	√	√	√	√	
2010	RM-	DMFR	√	√	√	√	√	√	○	
2010	RM-	DMFL	√	√	√	√	√	√	√	
2010	RM-	DMRL	√	√	√	√	√	√	√	0622, 0624, 0630
2010	RM-	DMRR	√	√	√	√	√	√	√	0622, 0624, 0630
2010	RM-	PSDMR	√	√	√	√	√	○	√	0106, 1067, 0633, 1070, 0877
2010	RM-	PSDML	√	√	√	√	√	○	√	0106, 1067, 0633, 1070, 0877
2011	JK-Wrangler	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 1123, 0257, 0322, 0908, 0472, 0537, 0591, 0821, 0615, 1092, 0216
2011	JK-Wrangler	TCM	√	√	√	√	√	○	○	0924, 1094
2011	JK-Wrangler	ESM	√	√	√	√	√	√	○	
2011	JK-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2011	JK-Wrangler	ORC	√	√	√	√	√	○	√	0098, 0581
2011	JK-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2011	JK-Wrangler	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2011	JK-Wrangler	ASBS	√	√	√	√	√	○	○	1071, 1098, 1099, 1100, 1101
2011	JK-Wrangler	WCM	√	√	√	√	√	○	√	0439
2011	JK-Wrangler	ITM	√	√	√	√	√	√	√	0584, 0547, 0551, 1066, 1179
2011	JK-Wrangler	SAS	√	√	√	√	√	○	○	
2011	JK-Wrangler	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2011	JK-Wrangler	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0602, 0426
2011	JK-Wrangler	AMP	√	√	√	√	√	○	√	0083, 0074
2011	JK-Wrangler	HFM	√	√	√	√	√	√	○	0492
2011	JS-Avenger, Sebring, Convertible/Sedan	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409
2011	JS-Avenger, Sebring, Convertible/Sedan	TCM	√	√	√	√	√	√	※	0961, 0176, 0531, 0627, 0703, 0829, 0011, 0028, 0045, 0230, 0834, 0979, 1107, 0015, 0016, 0032, 0049, 0243, 0830, 0983, 1062, 1063
2011	JS-Avenger, Sebring, Convertible/Sedan	ESM	√	√	√	√	√	√	√	
2011	JS-Avenger, Sebring, Convertible/Sedan	FDCM	√	√	√	√	√	○	√	
2011	JS-Avenger, Sebring, Convertible/Sedan	CGW	√	√	√	√	√	√	√	0108, 0119, 0465, 0508, 0510, 0527, 0560, 0424, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0254, 0425, 0503
2011	JS-Avenger, Sebring, Convertible/Sedan	ORC	√	√	√	√	√	○	√	0098
2011	JS-Avenger, Sebring, Convertible/Sedan	MIC_CCN	√	√	√	√	√	√	√	1014, 1186, 1023, 0150, 0152, 1184
2011	JS-Avenger, Sebring, Convertible/Sedan	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680, 0277
2011	JS-Avenger, Sebring, Convertible/Sedan	WCM	√	√	√	√	√	○	√	0143, 0366, 0439
2011	JS-Avenger, Sebring, Convertible/Sedan	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2011	JS-Avenger, Sebring, Convertible/Sedan	PTCM	√	√	√	√	√	○	√	0661, 0893
2011	JS-Avenger, Sebring, Convertible/Sedan	SAS	√	√	√	√	√	○	○	
2011	JS-Avenger, Sebring, Convertible/Sedan	ABS	√	√	√	√	√	√	√	0056, 0168
2011	JS-Avenger, Sebring, Convertible/Sedan	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	JS-Avenger, Sebring, Convertible/Sedan	AMP	√	√	√	√	√	○	√	0083, 0074
2011	JS-Avenger, Sebring, Convertible/Sedan	HFM	√	√	√	√	√	√	○	0492
2011	JS-Avenger, Sebring, Convertible/Sedan	VES3	√	√	√	√	√	√	√	
2011	JS-Avenger, Sebring, Convertible/Sedan	DDM	√	√	√	√	√	√	○	0319
2011	JS-Avenger, Sebring, Convertible/Sedan	PDM	√	√	√	√	√	√	○	0319

2011	KA-Nitro	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409
2011	KA-Nitro	TCM	√	√	√	√	√	○	○	0924, 1094
2011	KA-Nitro	ESM	√	√	√	√	√	√	○	
2011	KA-Nitro	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2011	KA-Nitro	ORC	√	√	√	√	√	○	√	0098
2011	KA-Nitro	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2011	KA-Nitro	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680, 0277
2011	KA-Nitro	OCM	√	√	√	√	√	○	○	0715
2011	KA-Nitro	WCM	√	√	√	√	√	○	√	0439
2011	KA-Nitro	PTS	√	√	√	√	√	√	√	0266, 1106
2011	KA-Nitro	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2011	KA-Nitro	SAS	√	√	√	√	√	○	○	
2011	KA-Nitro	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2011	KA-Nitro	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	KA-Nitro	AMP	√	√	√	√	√	○	√	0083, 0074
2011	KA-Nitro	HFM	√	√	√	√	√	√	○	0492
2011	KA-Nitro	DMFR	√	√	√	√	√	√	○	
2011	KA-Nitro	DMFL	√	√	√	√	√	√	√	
2011	KK-Liberty	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0697, 0628, 0409, 1123, 0257, 0322, 0908, 0472, 0537, 0591, 0821, 0615, 0216
2011	KK-Liberty	TCM	√	√	√	√	√	○	○	0924, 1094
2011	KK-Liberty	ESM	√	√	√	√	√	√	○	
2011	KK-Liberty	FDCM	√	√	√	√	√	√	○	0706
2011	KK-Liberty	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2011	KK-Liberty	ORC	√	√	√	√	√	○	√	0098
2011	KK-Liberty	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2011	KK-Liberty	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680, 0277
2011	KK-Liberty	MSM	√	√	√	√	√	※	※	0112, 0222, 0381, 0603, 0658, 1083, 1150, 0341, 0382, 0604, 1023, 1084, 1151, 0110
2011	KK-Liberty	OCM	√	√	√	√	√	○	○	0715
2011	KK-Liberty	WCM	√	√	√	√	√	○	√	0439, 0613, 0614
2011	KK-Liberty	SUNR	√	√	√	√	√	○	○	
2011	KK-Liberty	PTS	√	√	√	√	√	√	√	0266, 1106
2011	KK-Liberty	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2011	KK-Liberty	SAS	√	√	√	√	√	○	○	
2011	KK-Liberty	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2011	KK-Liberty	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	KK-Liberty	AMP	√	√	√	√	√	○	√	0083, 0074
2011	KK-Liberty	HFM	√	√	√	√	√	√	○	0492
2011	KK-Liberty	DMFR	√	√	√	√	√	√	○	
2011	KK-Liberty	DMFL	√	√	√	√	√	√	√	
2011	LX-300, Charger, Magnum, Grand Voyager	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0257, 0216, 0133, 0312, 0616, 0821, 0952, 0932, 0948, 1034, 1148
2011	LX-300, Charger, Magnum, Grand Voyager	TCM	√	√	√	√	√	○	√	0924, 1094
2011	LX-300, Charger, Magnum, Grand Voyager	ESM	√	√	√	√	√	√	○	
2011	LX-300, Charger, Magnum, Grand Voyager	ACC	√	√	√	√	√	○	√	
2011	LX-300, Charger, Magnum, Grand Voyager	ORC	√	√	√	√	√	○	√	0581
2011	LX-300, Charger, Magnum, Grand Voyager	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2011	LX-300, Charger, Magnum, Grand Voyager	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2011	LX-300, Charger, Magnum, Grand Voyager	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2011	LX-300, Charger, Magnum, Grand Voyager	PTS	√	√	√	√	√	√	√	0266, 1106
2011	LX-300, Charger, Magnum, Grand Voyager	TPM	√	√	√	√	√	○	√	1029, 0099, 0793, 0794, 0799, 0800, 1127
2011	LX-300, Charger, Magnum, Grand Voyager	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2011	LX-300, Charger, Magnum, Grand Voyager	AMP	√	√	√	√	√	○	○	0083, 0074
2011	LX-300, Charger, Magnum, Grand Voyager	HFM	√	√	√	√	√	○	○	0492
2011	LX-300, Charger, Magnum, Grand Voyager	DDM	√	√	√	√	√	√	√	

2011	LX-300,Charger,Magnum,Grand Voyager	PDM	√	√	√	√	√	√	√	
2011	LX-300,Charger,Magnum,Grand Voyager	HSM	√	√	√	√	√	√	√	
2011	LX-300,Charger,Magnum,Grand Voyager	BSM	√	√	√	○	√	○	○	1027
2011	LX-300,Charger,Magnum,Grand Voyager	DTCM	√	√	√	√	√	√	○	
2011	LX-300,Charger,Magnum,Grand Voyager	EPS	√	√	√	√	√	○	○	
2011	LX-300,Charger,Magnum,Grand Voyager	AFLS	√	√	√	√	√	√	○	0066
2011	LX-300,Charger,Magnum,Grand Voyager	ICS	√	√	√	√	√	√	○	
2011	LX-300,Charger,Magnum,Grand Voyager	IPC	√	√	√	√	√	√	○	0334
2011	LX-300,Charger,Magnum,Grand Voyager	RFH	√	√	√	√	√	√	√	0561,0338,0648
2011	LX-300,Charger,Magnum,Grand Voyager	SCCM	√	√	√	√	√	○	○	
2011	LX-300,Charger,Magnum,Grand Voyager	TGW	√	√	√	√	√	○	√	0144,1121
2011	MK-Compass,Patriot	PCM	√	√	√	√	√	√	※	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0434,1191,0258,0310,0432,0477,0514,0494,0588,0663,0704,0821,1102,1194,1148,0363
2011	MK-Compass,Patriot	TCM	√	√	√	√	√	√	√	
2011	MK-Compass,Patriot	FDCM	√	√	√	√	√	√	√	
2011	MK-Compass,Patriot	CGW	√	√	√	√	√	√	√	0108,0119,0465,0508,0510,0527,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,0425,0402,0810,0816,0817,0752
2011	MK-Compass,Patriot	ORC	√	√	√	√	√	○	√	0098
2011	MK-Compass,Patriot	MIC_CCN	√	√	√	√	√	√	√	1014,1184,1186,1023,0150,0152
2011	MK-Compass,Patriot	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2011	MK-Compass,Patriot	WCM	√	√	√	√	√	○	√	0143,0366,0439
2011	MK-Compass,Patriot	ITM	√	√	√	√	√	√	√	0555,1066,1178
2011	MK-Compass,Patriot	SAS	√	√	√	√	√	○	○	
2011	MK-Compass,Patriot	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2011	MK-Compass,Patriot	RADIO	√	√	√	√	√	※	※	0861,0867,0871,0426
2011	MK-Compass,Patriot	AMP	√	√	√	√	√	○	√	0069,0074,0077,0083,0085
2011	MK-Compass,Patriot	HFM	√	√	√	√	√	√	○	0492
2011	ND-Dakota	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628
2011	ND-Dakota	CGW	√	√	√	√	√	√	√	0095,0863,0425,0465,0506,0510,1138,1076,1139,1219,1224,1225,1226,0560,0096,0129,0207,0226,0233,0234,0331,0412,0489,0490,0508,0509,0527,0684,0685,0686,0795,0899,1075,1154,1164,1262,1263,1274
2011	ND-Dakota	ORC	√	√	√	√	√	○	√	0581
2011	ND-Dakota	MIC_CCN	√	√	√	√	√	√	√	1014,1023,0150,0152,0332,1184
2011	ND-Dakota	HVAC	√	√	√	√	√	√	√	0121,0124,0277,0461,0680
2011	ND-Dakota	WCM	√	√	√	√	√	○	√	1131,0439,0741,0789,0790,0793,0799,0800,0801,1248,1252
2011	ND-Dakota	EOM	√	√	√	√	√	○	√	0370
2011	ND-Dakota	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2011	ND-Dakota	RADIO	√	√	√	√	√	※	※	0861,0867,0871,0426
2011	ND-Dakota	AMP	√	√	√	√	√	○	√	0083,0074
2011	ND-Dakota	HFM	√	√	√	√	√	√	○	0492
2011	PM-Caliber	PCM	√	√	√	√	√	√	※	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0434,1191,0258,0310,0432,0477,0514,0494,0588,0663,0704,0821,1102,1194,1148,0363
2011	PM-Caliber	TCM	√	√	√	√	√	√	√	
2011	PM-Caliber	CGW	√	√	√	√	√	√	√	0108,0119,0331,0465,0508,0510,0527,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,0425,0402,0810,0816,0817,0752
2011	PM-Caliber	ORC	√	√	√	√	√	○	√	0098
2011	PM-Caliber	MIC_CCN	√	√	√	√	√	√	√	1014,1186,1023,0152,0150,0187,0619,0666,1015
2011	PM-Caliber	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2011	PM-Caliber	WCM	√	√	√	√	√	○	√	0143,0366,0439
2011	PM-Caliber	ITM	√	√	√	√	√	√	√	0555,1066,1178
2011	PM-Caliber	SAS	√	√	√	√	√	○	○	
2011	PM-Caliber	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2011	PM-Caliber	RADIO	√	√	√	√	√	※	※	0861,0867,0871,0426
2011	PM-Caliber	AMP	√	√	√	√	√	○	√	0069,0074,0077,0083,0085
2011	PM-Caliber	HFM	√	√	√	√	√	√	○	0492

2011	RT-Caravan,Town & Country	PCM	√	√	√	√	√	√	※	0257, 0293, 0294, 0322, 0323, 0336, 0356, 1123, 0471, 0538, 0589, 0591, 0820, 0923, 0926, 1034, 1047, 1222, 0216, 0355, 1051, 0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0908, 0472, 0537, 0821, 0615
2011	RT-Caravan,Town & Country	TCM	√	√	√	√	√	√	○	0005, 0007, 0008, 0009, 0033, 0022, 0024, 0025, 0026, 0038, 0040, 0041, 0042, 0651, 0243, 0324, 1140, 0694, 0841, 0974, 0975, 0976, 0977, 1107
2011	RT-Caravan,Town & Country	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152
2011	RT-Caravan,Town & Country	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2011	RT-Caravan,Town & Country	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2011	RT-Caravan,Town & Country	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680, 0462, 0120, 0277, 0463, 0469
2011	RT-Caravan,Town & Country	PLGM	√	√	√	√	√	√	√	0199, 0200, 0877
2011	RT-Caravan,Town & Country	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2011	RT-Caravan,Town & Country	FSM	√	√	√	√	√	√	○	0194, 0201, 1269, 1272
2011	RT-Caravan,Town & Country	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439
2011	RT-Caravan,Town & Country	SUNR	√	√	√	√	√	√	○	
2011	RT-Caravan,Town & Country	HIDT	√	√	√	√	√	√	○	0493
2011	RT-Caravan,Town & Country	AHBM	√	√	√	√	√	○	○	0153, 1023
2011	RT-Caravan,Town & Country	PTS	√	√	√	√	√	√	√	0266, 1106
2011	RT-Caravan,Town & Country	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2011	RT-Caravan,Town & Country	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1127
2011	RT-Caravan,Town & Country	SAS	√	√	√	√	√	○	○	
2011	RT-Caravan,Town & Country	ABS	√	√	√	√	√	※	※	0168, 0182, 0056
2011	RT-Caravan,Town & Country	DVD	√	√	√	√	√	○	○	
2011	RT-Caravan,Town & Country	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	RT-Caravan,Town & Country	SDARV	√	√	√	√	√	○	○	
2011	RT-Caravan,Town & Country	AMP	√	√	√	√	√	○	√	0083, 0074
2011	RT-Caravan,Town & Country	HFM	√	√	√	√	√	√	○	0492
2011	RT-Caravan,Town & Country	VES2	√	√	√	√	√	√	√	
2011	RT-Caravan,Town & Country	VES3	√	√	√	√	√	√	√	
2011	RT-Caravan,Town & Country	DMFR	√	√	√	√	√	√	○	
2011	RT-Caravan,Town & Country	DMFL	√	√	√	√	√	√	√	
2011	RT-Caravan,Town & Country	DMRL	√	√	√	√	√	√	√	0622, 0624, 0630
2011	RT-Caravan,Town & Country	DMRR	√	√	√	√	√	√	√	0622, 0624, 0630
2011	RT-Caravan,Town & Country	PSDMR	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2011	RT-Caravan,Town & Country	PSDML	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2011	RT-Caravan,Town & Country	HESM	√	√	√	√	√	√	√	0512
2011	RT-Caravan,Town & Country	BSM	√	√	√	○	√	○	○	1027
2011	RT-Caravan,Town & Country	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2011	WK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0257, 0216, 0133, 0312, 0616, 0821, 0952, 0932, 0948, 1034, 1148
2011	WK-Grand Cherokee	TCM	√	√	√	√	√	○	○	0924, 1094
2011	WK-Grand Cherokee	ESM	√	√	√	√	√	√	○	
2011	WK-Grand Cherokee	ACC	√	√	√	√	√	○	○	
2011	WK-Grand Cherokee	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2011	WK-Grand Cherokee	ORC	√	√	√	√	√	○	√	0098, 0581
2011	WK-Grand Cherokee	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2011	WK-Grand Cherokee	HVAC	√	√	√	√	√	√	√	0120, 0277, 0463, 0469, 0680
2011	WK-Grand Cherokee	PLGM	√	√	√	√	√	√	√	0199, 0200
2011	WK-Grand Cherokee	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2011	WK-Grand Cherokee	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2011	WK-Grand Cherokee	AHLM	√	√	√	√	√	√	○	0894
2011	WK-Grand Cherokee	AHBM	√	√	√	√	√	√	○	0132
2011	WK-Grand Cherokee	PTS	√	√	√	√	√	√	√	0266, 1106
2011	WK-Grand Cherokee	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 1066, 1178
2011	WK-Grand Cherokee	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2011	WK-Grand Cherokee	SAS	√	√	√	√	√	√	○	
2011	WK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0055, 0056
2011	WK-Grand Cherokee	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	WK-Grand Cherokee	SDARV	√	√	√	√	√	○	○	
2011	WK-Grand Cherokee	AMP	√	√	√	√	√	○	√	0083, 0074

2011	WK-Grand Cherokee	HPM	√	√	√	√	√	√	○	0492
2011	WK-Grand Cherokee	VES3	√	√	√	√	√	√	√	
2011	WK-Grand Cherokee	DMFR	√	√	√	√	√	√	√	
2011	WK-Grand Cherokee	DMFL	√	√	√	√	√	√	√	
2011	WK-Grand Cherokee	HSM	√	√	√	√	√	√	√	0512
2011	WK-Grand Cherokee	BSM	√	√	√	○	√	○	○	1027
2011	WK-Grand Cherokee	DTCM	√	√	√	√	√	√	√	
2011	WK-Grand Cherokee	EPS	√	√	√	√	√	○	○	
2011	WK-Grand Cherokee	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2011	WK-Grand Cherokee	ASCM	√	√	√	√	√	○	○	0134, 0147, 0268, 1081, 1082, 0330, 0423, 0459, 1056, 0513, 0865, 1105
2011	WK-Grand Cherokee	ELSD	√	√	√	○	√	√	○	1104
2011	D2-Ram Truck	PCM	√	√	√	√	√	√	√	0591, 0397, 0558, 0722, 0755, 1240, 1237, 0004, 0021, 0037, 0973, 1042, 0734, 0438, 0590, 0456, 0589, 0457, 0936
2011	D2-Ram Truck	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0254
2011	D2-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2011	D2-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2011	D2-Ram Truck	HVAC	√	√	√	√	√	※	√	0121, 0498, 0462, 0680, 0277
2011	D2-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2011	D2-Ram Truck	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2011	D2-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2011	D2-Ram Truck	SAS	√	√	√	√	√	○	○	
2011	D2-Ram Truck	ABS	√	√	√	√	√	√	√	0168, 0056
2011	D2-Ram Truck	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	D2-Ram Truck	SDARV	√	√	√	√	√	○	○	
2011	D2-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2011	D2-Ram Truck	HPM	√	√	√	√	√	√	○	0492
2011	D2-Ram Truck	VES3	√	√	√	√	√	√	√	
2011	D2-Ram Truck	DMFR	√	√	√	√	√	√	√	
2011	D2-Ram Truck	DMFL	√	√	√	√	√	√	√	
2011	D2-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2011	D2-Ram Truck	DTCM	√	√	√	√	√	√	○	
2011	D2-Ram Truck	ITBM	√	√	√	√	√	○	○	
2011	DJ-Ram Truck	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0697, 0628, 0409, 0591, 0397, 0558, 0722, 0755, 1240, 1237, 0438, 0456, 0589, 0457, 0936
2011	DJ-Ram Truck	FDCM	√	√	√	√	√	○	○	0113, 0114, 0115, 0116, 0117, 0118
2011	DJ-Ram Truck	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0897, 1235
2011	DJ-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2011	DJ-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2011	DJ-Ram Truck	HVAC	√	√	√	√	√	※	√	0121, 0498, 0462, 0680, 0277
2011	DJ-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2011	DJ-Ram Truck	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2011	DJ-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2011	DJ-Ram Truck	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2011	DJ-Ram Truck	SAS	√	√	√	√	√	○	○	
2011	DJ-Ram Truck	ABS	√	√	√	√	√	√	√	0056, 0168
2011	DJ-Ram Truck	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	DJ-Ram Truck	SDARV	√	√	√	√	√	○	○	
2011	DJ-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2011	DJ-Ram Truck	HPM	√	√	√	√	√	√	○	0492
2011	DJ-Ram Truck	VES3	√	√	√	√	√	√	√	
2011	DJ-Ram Truck	DMFR	√	√	√	√	√	√	√	
2011	DJ-Ram Truck	DMFL	√	√	√	√	√	√	√	
2011	DJ-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2011	DJ-Ram Truck	DTCM	√	√	√	√	√	√	○	
2011	DJ-Ram Truck	ITBM	√	√	√	√	√	○	○	
2011	DS-Ram Truck	PCM	√	√	√	√	√	√	√	0014, 0017, 0031, 0048, 0437, 0378, 0628, 0831, 0978, 0982, 1201, 0359, 0373, 0827, 1042, 1107, 0229, 0590, 0409, 1019, 0010, 0013, 0027, 0030, 0043, 0047, 0053, 0215, 0243, 0589, 0709, 0710, 0981, 1051, 1111, 0698, 0699, 0732, 0735, 0830, 0833, 1140, 0454, 1123, 0446, 0705, 0202, 1012, 0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0838, 0835, 0840, 0971, 0972, 0973, 1141, 1142, 1143, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0386, 0447, 0596, 0597
2011	DS-Ram Truck	TCM	√	√	√	√	√	○	○	1168, 1057, 1165, 0218

2011	DS-Ram Truck	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0805, 0897
2011	DS-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2011	DS-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2011	DS-Ram Truck	HVAC	√	√	√	√	√	※	√	0501, 0461, 0680, 0121, 0498, 0462, 0277
2011	DS-Ram Truck	APM	√	○	○	○	○	○	○	0212
2011	DS-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2011	DS-Ram Truck	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2011	DS-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2011	DS-Ram Truck	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2011	DS-Ram Truck	SAS	√	√	√	√	√	○	○	
2011	DS-Ram Truck	ABS	√	√	√	√	√	√	√	0058, 0168, 1202, 0056
2011	DS-Ram Truck	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	DS-Ram Truck	SDARV	√	√	√	√	√	○	○	
2011	DS-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2011	DS-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2011	DS-Ram Truck	VES3	√	√	√	√	√	√	√	
2011	DS-Ram Truck	DMFR	√	√	√	√	√	√	√	
2011	DS-Ram Truck	DMFL	√	√	√	√	√	√	√	
2011	DS-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2011	DS-Ram Truck	BPCM	√	√	√	√	√	√	○	0497, 0910
2011	DS-Ram Truck	DTCM	√	√	√	√	√	√	※	
2011	DS-Ram Truck	EAC	√	√	√	○	√	○	○	
2011	DS-Ram Truck	EPS	√	√	√	√	√	○	○	
2011	DS-Ram Truck	HCP	√	√	√	√	√	○	○	0272, 1057, 0525, 0530, 0922, 0214
2011	DS-Ram Truck	HGM	√	√	√	√	√	√	√	
2011	DS-Ram Truck	ITBM	√	√	√	√	√	○	○	
2011	DS-Ram Truck	MCPA	√	○	○	√	○	○	○	0960
2011	DS-Ram Truck	MCPB	√	○	○	√	○	○	○	0960
2011	DS-Ram Truck	BTM	√	√	√	√	√	√	○	
2011	DS-Ram Truck	DRM	√	√	√	√	√	○	○	
2011	DS-Ram Truck	OBCM	√	√	√	√	√	※	○	
2011	DS-Ram Truck	PHGM	√	√	√	√	√	√	○	
2011	DX-Ram Truck	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0297, 0298, 1236, 0591, 0300, 0301, 0302, 0303, 0558, 0722, 1050, 1240, 1237, 1238, 0438, 0456, 0398, 0589, 0457, 0936
2011	DX-Ram Truck	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2011	DX-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2011	DX-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2011	DX-Ram Truck	HVAC	√	√	√	√	√	※	√	0121, 0498, 0462, 0680, 0277
2011	DX-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2011	DX-Ram Truck	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2011	DX-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2011	DX-Ram Truck	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2011	DX-Ram Truck	SAS	√	√	√	√	√	○	○	
2011	DX-Ram Truck	ABS	√	√	√	√	√	√	√	0056, 0168
2011	DX-Ram Truck	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	DX-Ram Truck	SDARV	√	√	√	√	√	○	○	
2011	DX-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2011	DX-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2011	DX-Ram Truck	VES3	√	√	√	√	√	√	√	
2011	DX-Ram Truck	DMFR	√	√	√	√	√	√	√	
2011	DX-Ram Truck	DMFL	√	√	√	√	√	√	√	
2011	DX-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2011	DX-Ram Truck	DTCM	√	√	√	√	√	√	○	
2011	DX-Ram Truck	ITBM	√	√	√	√	√	○	○	
2011	JS-Wrangler	PCM	√	√	√	√	√	√	√	1123, 0257, 0322, 0472, 0537, 0591, 0821, 0615, 1092, 0216, 0908
2011	JS-Wrangler	TCM	√	√	√	√	√	○	○	0924, 1094
2011	JS-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2011	JS-Wrangler	ORC	√	√	√	√	√	○	√	0098, 0581
2011	JS-Wrangler	MIC CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2011	JS-Wrangler	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2011	JS-Wrangler	WCM	√	√	√	√	√	○	√	0439, 0613
2011	JS-Wrangler	SAS	√	√	√	√	√	○	○	

2011	JS-Wrangler	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2011	JS-Wrangler	RADIO	√	√	√	√	√	√	○	0861, 0867, 0871, 0426
2011	JC-Journey	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0697, 0628, 0257, 0216, 0133, 0312, 0616, 0821, 0932, 1148, 0952, 0948, 1034
2011	JC-Journey	OBC	√	√	√	√	√	○	√	0098, 0990, 0581
2011	JC-Journey	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2011	JC-Journey	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2011	JC-Journey	PTS	√	√	√	√	√	√	√	0266, 1106
2011	JC-Journey	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2011	JC-Journey	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2011	JC-Journey	ABS	√	√	√	√	√	√	√	0181, 0056, 0055
2011	JC-Journey	AMP	√	√	√	√	√	○	○	0083, 0074
2011	JC-Journey	HFM	√	√	√	√	√	○	○	0492
2011	JC-Journey	VES3	√	√	√	√	√	√	○	
2011	JC-Journey	DDM	√	√	√	√	√	√	√	
2011	JC-Journey	PDM	√	√	√	√	√	√	√	
2011	JC-Journey	HSM	√	√	√	√	√	√	√	
2011	JC-Journey	DTCM	√	√	√	√	√	√	√	
2011	JC-Journey	LCS	√	√	√	√	√	√	○	
2011	JC-Journey	IPC	√	√	√	√	√	√	○	
2011	JC-Journey	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2011	JC-Journey	SCCM	√	√	√	√	√	○	○	
2011	JC-Journey	TGW	√	√	√	√	√	○	√	0144, 1121
2011	LC-Challenger	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409
2011	LC-Challenger	TCM	√	√	√	√	√	○	○	0924, 1094
2011	LC-Challenger	ESM	√	√	√	√	√	√	○	
2011	LC-Challenger	CGW	√	√	√	√	√	√	√	0155, 0331, 0465, 0508, 0510, 0560, 1226, 0900, 1076, 1155, 1189, 0095, 1219, 1224, 1225
2011	LC-Challenger	OBC	√	√	√	√	√	○	√	0581
2011	LC-Challenger	MIC CCN	√	√	√	√	√	√	√	0209, 1186, 1014, 1184, 0150, 0152
2011	LC-Challenger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2011	LC-Challenger	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2011	LC-Challenger	SUNR	√	√	√	○	√	√	○	
2011	LC-Challenger	EDM	√	√	√	√	√	○	√	0370, 1023
2011	LC-Challenger	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2011	LC-Challenger	SAS	√	√	√	√	√	√	○	
2011	LC-Challenger	ABS	√	√	√	√	√	√	√	0056, 0055
2011	LC-Challenger	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	LC-Challenger	AMP	√	√	√	√	√	○	√	0083, 0074
2011	LC-Challenger	HFM	√	√	√	√	√	√	○	0492
2011	LC-Challenger	DDM	√	√	√	√	√	√	○	0319
2011	LC-Challenger	PDM	√	√	√	√	√	√	○	0319
2011	LC-Challenger	HSM	√	√	√	√	√	√	√	
2011	LC-Challenger	EPS	√	√	√	√	√	○	○	
2011	LC-Challenger	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2011	R2-Mini-Van	TCM	○	√	√	√	√	√	○	
2011	R2-Mini-Van	OBC	○	√	√	√	√	○	○	
2011	R2-Mini-Van	MIC CCN	○	√	√	○	√	√	○	
2011	R2-Mini-Van	PCM	○	√	√	√	√	√	○	
2011	R2-Mini-Van	PLGM	○	√	√	√	√	√	○	
2011	R2-Mini-Van	ATC	○	√	√	√	√	√	○	
2011	R2-Mini-Van	MTC	○	√	√	○	√	√	○	
2011	R2-Mini-Van	MSM	○	√	√	√	√	√	○	
2011	R2-Mini-Van	OCM	○	√	√	√	√	○	○	
2011	R2-Mini-Van	BCM	○	√	√	√	√	√	○	
2011	R2-Mini-Van	PTS	○	√	√	√	√	○	○	
2011	R2-Mini-Van	EDM	○	√	√	○	√	○	○	
2011	R2-Mini-Van	SKM	○	√	√	○	√	√	○	
2011	R2-Mini-Van	ABS	○	√	√	√	√	√	○	
2011	R2-Mini-Van	SDAR	○	√	√	√	√	√	○	
2011	R2-Mini-Van	HFM	○	√	√	√	√	√	○	
2011	R2-Mini-Van	PSDMR	○	√	√	√	√	√	○	
2011	R2-Mini-Van	PSDML	○	√	√	√	√	√	○	

2011	RM-	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409
2011	RM-	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0402, 0812
2011	RM-	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2011	RM-	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2011	RM-	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680, 0462, 0277
2011	RM-	PLGM	√	√	√	√	√	√	√	0199, 0200, 0877
2011	RM-	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2011	RM-	FSM	√	√	√	√	√	√	○	0194, 0201, 1269, 1272
2011	RM-	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439
2011	RM-	SUNR	√	√	√	√	√	√	○	
2011	RM-	PTS	√	√	√	√	√	√	√	0266, 1106
2011	RM-	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1127
2011	RM-	SAS	√	√	√	√	√	○	○	
2011	RM-	ABS	√	√	√	√	√	√	√	0056, 0168
2011	RM-	DVD	√	√	√	√	√	○	○	
2011	RM-	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	RM-	AMP	√	√	√	√	√	○	√	0083, 0074
2011	RM-	HFM	√	√	√	√	√	√	○	0492
2011	RM-	VES2	√	√	√	√	√	√	√	
2011	RM-	VES3	√	√	√	√	√	√	√	
2011	RM-	DMFR	√	√	√	√	√	√	○	
2011	RM-	DMFL	√	√	√	√	√	√	√	
2011	RM-	DMRL	√	√	√	√	√	√	√	0622, 0624, 0630
2011	RM-	DMRR	√	√	√	√	√	√	√	0622, 0624, 0630
2011	RM-	PSDMR	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2011	RM-	PSDML	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2011	RM-	IESM	√	√	√	√	√	√	√	0512
2011	RM-	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2011	DD-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0973, 1042, 0705, 0734, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0002, 0003, 0019, 0020, 0035, 0036, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 1141, 1142, 1143, 1201, 0695, 0696, 0733, 0927, 1108, 1109, 0591, 0558, 0722, 1050, 0438, 0297, 0298, 1236, 0300, 0301, 0302, 0303, 0456, 0398, 0589, 0457, 0936
2011	DD-Ram Truck	TCM	√	√	√	√	√	√	○	0420
2011	DD-Ram Truck	CGW	√	√	√	√	√	√	√	0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0254, 0805, 0402
2011	DD-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2011	DD-Ram Truck	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2011	DD-Ram Truck	HVAC	√	√	√	√	√	※	√	0121, 0498, 0462, 0680, 0277
2011	DD-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2011	DD-Ram Truck	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2011	DD-Ram Truck	SAS	√	√	√	√	√	○	○	
2011	DD-Ram Truck	ABS	√	√	√	√	√	√	√	0056, 0168
2011	DD-Ram Truck	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	DD-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2011	DD-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2011	DD-Ram Truck	DMFR	√	√	√	√	√	√	√	
2011	DD-Ram Truck	DMFL	√	√	√	√	√	√	√	
2011	DD-Ram Truck	IESM	√	√	√	√	√	√	√	0512
2011	DD-Ram Truck	DTCM	√	√	√	√	√	√	○	
2011	DD-Ram Truck	ITBM	√	√	√	√	√	○	○	
2011	DD-Ram Truck	DCU	√	○	○	○	○	○	○	
2011	DP-Ram Truck	PCM	√	√	√	√	√	√	√	0297, 0298, 1236, 0591, 0300, 0301, 0302, 0303, 0558, 0722, 1050, 1042, 0438, 0590, 0456, 0398, 0589, 0457, 0936
2011	DP-Ram Truck	TCM	√	√	√	√	√	√	○	0420
2011	DP-Ram Truck	CGW	√	√	√	√	√	√	√	0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0254, 0402
2011	DP-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2011	DP-Ram Truck	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2011	DP-Ram Truck	HVAC	√	√	√	√	√	※	√	0121, 0498, 0462, 0680, 0277
2011	DP-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2011	DP-Ram Truck	WCM	√	√	√	√	√	√	√	0143, 0613, 0439

2011	DP-Ram Truck	SAS	√	√	√	√	√	○	○	
2011	DP-Ram Truck	ABS	√	√	√	√	√	√	√	0056,0168
2011	DP-Ram Truck	RADIO	√	√	√	√	√	※	※	0861,0867,0871,0426
2011	DP-Ram Truck	AMP	√	√	√	√	√	○	√	0083,0074
2011	DP-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2011	DP-Ram Truck	DMFR	√	√	√	√	√	√	√	
2011	DP-Ram Truck	DMFL	√	√	√	√	√	√	√	
2011	DP-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2011	DP-Ram Truck	DTCM	√	√	√	√	√	√	○	
2011	DP-Ram Truck	ITBM	√	√	√	√	√	○	○	
2011	DP-Ram Truck	DCU	√	○	○	○	○	○	○	
2011	JP-Freemont	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0257,0216,0133,0312,0616,0821,0952,0932,0948,1034,1148
2011	JP-Freemont	OBC	√	√	√	√	√	○	√	0098,0581,0990
2011	JP-Freemont	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680
2011	JP-Freemont	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2011	JP-Freemont	PTS	√	√	√	√	√	√	√	0266,1106
2011	JP-Freemont	ITM	√	√	√	√	√	√	√	0584,0555,0551,0553,1178
2011	JP-Freemont	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2011	JP-Freemont	ABS	√	√	√	√	√	√	√	0181,0055,0056
2011	JP-Freemont	AMP	√	√	√	√	√	○	○	0083,0074
2011	JP-Freemont	HFM	√	√	√	√	√	○	○	0492
2011	JP-Freemont	VES3	√	√	√	√	√	√	○	
2011	JP-Freemont	DDM	√	√	√	√	√	√	√	
2011	JP-Freemont	PDM	√	√	√	√	√	√	√	
2011	JP-Freemont	HSM	√	√	√	√	√	√	√	
2011	JP-Freemont	DTCM	√	√	√	√	√	√	√	
2011	JP-Freemont	ICS	√	√	√	√	√	√	○	
2011	JP-Freemont	IPC	√	√	√	√	√	√	○	
2011	JP-Freemont	BFH	√	√	√	√	√	√	√	0561,0338,0648
2011	JP-Freemont	SCCM	√	√	√	√	√	○	○	
2011	JP-Freemont	TGW	√	√	√	√	√	○	√	0144,1121
2011	LD-Charger	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628
2011	LD-Charger	TCM	√	√	√	√	√	○	√	0924,1094
2011	LD-Charger	ESM	√	√	√	√	√	√	○	
2011	LD-Charger	ACC	√	√	√	√	√	○	√	
2011	LD-Charger	OBC	√	√	√	√	√	○	√	0581
2011	LD-Charger	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680
2011	LD-Charger	MSM	√	√	√	√	√	√	√	0112,0222,0381,0803,0658,1083,1150
2011	LD-Charger	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2011	LD-Charger	PTS	√	√	√	√	√	√	√	0266,1106
2011	LD-Charger	TPM	√	√	√	√	√	○	√	0099,1127,0793,0794,0799,0800,1029
2011	LD-Charger	ABS	√	√	√	√	√	√	√	0055,0056,0181
2011	LD-Charger	AMP	√	√	√	√	√	○	○	0083,0074
2011	LD-Charger	HFM	√	√	√	√	√	○	○	0492
2011	LD-Charger	DDM	√	√	√	√	√	√	√	
2011	LD-Charger	PDM	√	√	√	√	√	√	√	
2011	LD-Charger	HSM	√	√	√	√	√	√	√	
2011	LD-Charger	BSM	√	√	√	○	√	○	○	1027
2011	LD-Charger	DTCM	√	√	√	√	√	√	○	
2011	LD-Charger	EPS	√	√	√	√	√	○	○	
2011	LD-Charger	ICS	√	√	√	√	√	√	○	
2011	LD-Charger	IPC	√	√	√	√	√	√	○	0334
2011	LD-Charger	BFH	√	√	√	√	√	√	√	0561,0338,0648
2011	LD-Charger	SCCM	√	√	√	√	√	○	○	
2011	LD-Charger	TGW	√	√	√	√	√	○	√	0144,1121
2011	LD-Charger	VSIM	√	√	√	○	√	√	√	
2011	WD-Durango	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409
2011	WD-Durango	TCM	√	√	√	√	√	○	○	0924,1094
2011	WD-Durango	ESM	√	√	√	√	√	√	○	
2011	WD-Durango	ACC	√	√	√	√	√	○	○	

2011	WD-Durango	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2011	WD-Durango	ORC	√	√	√	√	√	○	√	0098, 0581
2011	WD-Durango	MIC CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2011	WD-Durango	HVAC	√	√	√	√	√	√	√	0120, 0277, 0463, 0469, 0680
2011	WD-Durango	PLGM	√	√	√	√	√	√	√	0199, 0200
2011	WD-Durango	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2011	WD-Durango	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2011	WD-Durango	AHLM	√	√	√	√	√	√	○	0894
2011	WD-Durango	AHBM	√	√	√	√	√	√	○	0132
2011	WD-Durango	PTS	√	√	√	√	√	√	√	0266, 1106
2011	WD-Durango	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 1066, 1178
2011	WD-Durango	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2011	WD-Durango	SAS	√	√	√	√	√	√	○	
2011	WD-Durango	ABS	√	√	√	√	√	√	√	0055, 0056
2011	WD-Durango	RADIO	√	√	√	√	√	※	※	0861, 0867, 0871, 0426
2011	WD-Durango	SDARV	√	√	√	√	√	○	○	
2011	WD-Durango	AMP	√	√	√	√	√	○	√	0083, 0074
2011	WD-Durango	HFM	√	√	√	√	√	√	○	0492
2011	WD-Durango	VES3	√	√	√	√	√	√	√	
2011	WD-Durango	DMFR	√	√	√	√	√	√	√	
2011	WD-Durango	DMFL	√	√	√	√	√	√	√	
2011	WD-Durango	HSM	√	√	√	√	√	√	√	0512
2011	WD-Durango	BSM	√	√	√	○	√	○	○	1027
2011	WD-Durango	DTCM	√	√	√	√	√	√	√	
2011	WD-Durango	EPS	√	√	√	√	√	○	○	
2011	WD-Durango	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2011	NY-Ypsilon	ECM	√	√	√	※	√	√	√	
2011	NY-Ypsilon	TCM	√	√	√	○	√	√	√	
2011	NY-Ypsilon	ORC	√	√	√	√	√	√	√	
2011	NY-Ypsilon	HVAC	√	√	√	√	√	√	√	
2011	NY-Ypsilon	BCM	√	√	√	○	√	√	○	
2011	NY-Ypsilon	ABS	√	√	√	√	√	√	√	
2011	NY-Ypsilon	EPS	√	√	√	√	√	○	√	
2011	NY-Ypsilon	IPC	√	√	√	※	√	√	○	0542
2011	NY-Ypsilon	AHM	√	√	√	√	√	√	○	
2012	JK-Wrangler	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 1123, 0257, 0322, 0908, 0472, 0537, 0591, 0821, 0615, 1092, 0216
2012	JK-Wrangler	TCM	√	√	√	√	√	○	○	0924, 1094
2012	JK-Wrangler	ESM	√	√	√	√	√	√	○	
2012	JK-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0402, 0812
2012	JK-Wrangler	ORC	√	√	√	√	√	○	√	0098, 0581
2012	JK-Wrangler	MIC CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2012	JK-Wrangler	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2012	JK-Wrangler	ASBS	√	√	√	√	√	○	○	1071, 1098, 1099, 1100, 1101
2012	JK-Wrangler	WCM	√	√	√	√	√	○	√	0439
2012	JK-Wrangler	ITM	√	√	√	√	√	√	√	0584, 0547, 0551, 1066, 1179
2012	JK-Wrangler	SAS	√	√	√	√	√	○	○	
2012	JK-Wrangler	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2012	JK-Wrangler	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0602, 0426
2012	JK-Wrangler	AMP	√	√	√	√	√	○	√	0083, 0074
2012	JK-Wrangler	HFM	√	√	√	√	√	√	○	0492
2012	JS-Avenger, Sebring, Convertible/Sedan	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409
2012	JS-Avenger, Sebring, Convertible/Sedan	CGW	√	√	√	√	√	√	√	0108, 0119, 0465, 0508, 0510, 0527, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0254, 0425, 0503, 0424
2012	JS-Avenger, Sebring, Convertible/Sedan	ORC	√	√	√	√	√	○	√	0098
2012	JS-Avenger, Sebring, Convertible/Sedan	MIC CCN	√	√	√	√	√	√	√	1014, 1184, 1186, 1023, 0150, 0152
2012	JS-Avenger, Sebring, Convertible/Sedan	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680, 0277
2012	JS-Avenger, Sebring, Convertible/Sedan	WCM	√	√	√	√	√	○	√	0143, 0366, 0439
2012	JS-Avenger, Sebring, Convertible/Sedan	PTCM	√	√	√	√	√	○	√	0661, 0893
2012	JS-Avenger, Sebring, Convertible/Sedan	SAS	√	√	√	√	√	○	○	
2012	JS-Avenger, Sebring, Convertible/Sedan	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056

2012	JS-Avenger,Sebring,Convertible/Sedan	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2012	JS-Avenger,Sebring,Convertible/Sedan	AMP	√	√	√	√	√	○	√	0083,0074
2012	JS-Avenger,Sebring,Convertible/Sedan	HFM	√	√	√	√	√	√	○	0492
2012	JS-Avenger,Sebring,Convertible/Sedan	DDM	√	√	√	√	√	√	○	0319
2012	JS-Avenger,Sebring,Convertible/Sedan	PDM	√	√	√	√	√	√	○	0319
2012	KA-Nitro	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409
2012	KA-Nitro	TCM	√	√	√	√	√	○	○	0924,1094
2012	KA-Nitro	ESM	√	√	√	√	√	√	○	
2012	KA-Nitro	CGW	√	√	√	√	√	√	√	0108,0119,0155,0465,0508,0510,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152,0402,0812
2012	KA-Nitro	ORC	√	√	√	√	√	○	√	0098
2012	KA-Nitro	MIC_CCN	√	√	√	√	√	√	○	1186,1014,1023,0187,0210,0619,1015
2012	KA-Nitro	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680,0277
2012	KA-Nitro	OCM	√	√	√	√	√	○	○	0715
2012	KA-Nitro	WCM	√	√	√	√	√	○	√	0439
2012	KA-Nitro	PTS	√	√	√	√	√	√	√	0266,1106
2012	KA-Nitro	ITM	√	√	√	√	√	√	√	0555,1066,1178
2012	KA-Nitro	SAS	√	√	√	√	√	○	○	
2012	KA-Nitro	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2012	KA-Nitro	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2012	KA-Nitro	AMP	√	√	√	√	√	○	√	0083,0074
2012	KA-Nitro	HFM	√	√	√	√	√	√	○	0492
2012	KA-Nitro	DMFR	√	√	√	√	√	√	○	
2012	KA-Nitro	DMFL	√	√	√	√	√	√	√	
2012	KK-Liberty	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,1123,0257,0322,0908,0472,0537,0591,0821,0615,0216
2012	KK-Liberty	TCM	√	√	√	√	√	○	○	0924,1094
2012	KK-Liberty	ESM	√	√	√	√	√	√	○	
2012	KK-Liberty	FDCM	√	√	√	√	√	√	○	0706
2012	KK-Liberty	CGW	√	√	√	√	√	√	√	0108,0119,0155,0465,0508,0510,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152,0402,0812
2012	KK-Liberty	ORC	√	√	√	√	√	○	√	0098
2012	KK-Liberty	MIC_CCN	√	√	√	√	√	√	√	1186,1014,1023,0187,0210,0619,1015
2012	KK-Liberty	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680,0277
2012	KK-Liberty	MSM	√	√	√	√	√	※	※	0112,0222,0381,0603,0658,1083,1150,0341,0382,0604,1023,1084,1151,0110
2012	KK-Liberty	OCM	√	√	√	√	√	○	○	0715
2012	KK-Liberty	WCM	√	√	√	√	√	○	√	0439,0613
2012	KK-Liberty	SUNR	√	√	√	√	√	○	○	
2012	KK-Liberty	PTS	√	√	√	√	√	√	√	0266,1106
2012	KK-Liberty	ITM	√	√	√	√	√	√	√	0555,1066,1178
2012	KK-Liberty	SAS	√	√	√	√	√	○	○	
2012	KK-Liberty	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2012	KK-Liberty	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2012	KK-Liberty	AMP	√	√	√	√	√	○	√	0083,0074
2012	KK-Liberty	HFM	√	√	√	√	√	√	○	0492
2012	KK-Liberty	DMFR	√	√	√	√	√	√	○	
2012	KK-Liberty	DMFL	√	√	√	√	√	√	√	
2012	LX-300,Charger,Magnum,Grand Voyager	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0257,0216,0133,0312,0616,0821,0952,0932,0948,1034,1148
2012	LX-300,Charger,Magnum,Grand Voyager	TCM	√	√	√	√	√	○	√	0924,1094,0912
2012	LX-300,Charger,Magnum,Grand Voyager	ESM	√	√	√	√	√	※	○	
2012	LX-300,Charger,Magnum,Grand Voyager	ACC	√	√	√	√	√	○	√	
2012	LX-300,Charger,Magnum,Grand Voyager	ORC	√	√	√	√	√	○	√	0581
2012	LX-300,Charger,Magnum,Grand Voyager	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680
2012	LX-300,Charger,Magnum,Grand Voyager	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2012	LX-300,Charger,Magnum,Grand Voyager	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2012	LX-300,Charger,Magnum,Grand Voyager	PTS	√	√	√	√	√	√	√	0266,1106

2012	LX-300,Charger,Magnum,Grand Voyager	ITM	√	√	√	√	√	√	√	0584,0555,0551,0553,1178
2012	LX-300,Charger,Magnum,Grand Voyager	TPM	√	√	√	√	√	○	√	0099,1127,0793,0794,0799,0800,1029
2012	LX-300,Charger,Magnum,Grand Voyager	ABS	√	√	√	√	√	√	√	0181,0055,0056
2012	LX-300,Charger,Magnum,Grand Voyager	AMP	√	√	√	√	√	○	○	0083,0074
2012	LX-300,Charger,Magnum,Grand Voyager	HFM	√	√	√	√	√	○	○	0492
2012	LX-300,Charger,Magnum,Grand Voyager	DDM	√	√	√	√	√	√	√	
2012	LX-300,Charger,Magnum,Grand Voyager	PDM	√	√	√	√	√	√	√	
2012	LX-300,Charger,Magnum,Grand Voyager	HSM	√	√	√	√	√	√	√	
2012	LX-300,Charger,Magnum,Grand Voyager	BSM	√	√	√	○	√	○	○	1027
2012	LX-300,Charger,Magnum,Grand Voyager	DTCM	√	√	√	√	√	√	○	
2012	LX-300,Charger,Magnum,Grand Voyager	EPS	√	√	√	√	√	○	○	
2012	LX-300,Charger,Magnum,Grand Voyager	ADCM	√	√	√	√	√	○	○	
2012	LX-300,Charger,Magnum,Grand Voyager	AFLS	√	√	√	√	√	√	○	0066
2012	LX-300,Charger,Magnum,Grand Voyager	LCS	√	√	√	√	√	√	○	
2012	LX-300,Charger,Magnum,Grand Voyager	IPC	√	√	√	√	√	√	○	0334
2012	LX-300,Charger,Magnum,Grand Voyager	RFH	√	√	√	√	√	√	√	0561,0338,0648
2012	LX-300,Charger,Magnum,Grand Voyager	SCCM	√	√	√	√	√	○	○	
2012	LX-300,Charger,Magnum,Grand Voyager	TGW	√	√	√	√	√	○	√	0144,1121
2012	MK-Compass,Patriot	PCM	√	√	√	√	√	√	※	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0434,1191,0258,0310,0432,0477,0514,0494,0588,0663,0704,0821,1102,1194,1148,0363
2012	MK-Compass,Patriot	TCM	√	√	√	√	√	√	√	
2012	MK-Compass,Patriot	FDCM	√	√	√	√	√	√	√	
2012	MK-Compass,Patriot	CGW	√	√	√	√	√	√	√	0108,0119,0465,0508,0510,0527,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,0425,0402,0810,0816,0817,0752
2012	MK-Compass,Patriot	ORC	√	√	√	√	√	○	√	0098
2012	MK-Compass,Patriot	MIC_CCN	√	√	√	√	√	√	√	1014,1184,1186,1023,0150,0152
2012	MK-Compass,Patriot	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2012	MK-Compass,Patriot	WCM	√	√	√	√	√	○	√	0143,0366,0439
2012	MK-Compass,Patriot	ITM	√	√	√	√	√	√	√	0555,1066,1178
2012	MK-Compass,Patriot	SAS	√	√	√	√	√	○	○	
2012	MK-Compass,Patriot	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2012	MK-Compass,Patriot	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2012	MK-Compass,Patriot	AMP	√	√	√	√	√	○	√	0069,0074,0077,0083,0085
2012	MK-Compass,Patriot	HFM	√	√	√	√	√	√	○	0492
2012	ND-Dakota	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628
2012	ND-Dakota	CGW	√	√	√	√	√	√	√	0095,0863,0425,0465,0560,1225,1226,0506,1138,1139,1219,1224,0510,1076,0096,0129,0207,0226,0233,0234,0331,0412,0489,0490,0508,0509,0527,0684,0685,0686,0795,0899,1075,1154,1164,1262,1263,1274
2012	ND-Dakota	ORC	√	√	√	√	√	○	√	0581
2012	ND-Dakota	MIC_CCN	√	√	√	√	√	√	√	1014,1023,0150,0152,0332,1184
2012	ND-Dakota	HVAC	√	√	√	√	√	√	√	0121,0124,0277,0461,0680
2012	ND-Dakota	WCM	√	√	√	√	√	○	√	1131,0439,0741,0789,0790,0793,0799,0800,0801,1248,1252
2012	ND-Dakota	EDM	√	√	√	√	√	○	√	0370
2012	ND-Dakota	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2012	ND-Dakota	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2012	ND-Dakota	AMP	√	√	√	√	√	○	√	0083,0074
2012	ND-Dakota	HFM	√	√	√	√	√	√	○	0492
2012	PM-Caliber	PCM	√	√	√	√	√	√	※	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0434,1191,0258,0310,0432,0477,0514,0494,0588,0663,0704,0821,1102,1194,1148,0363
2012	PM-Caliber	TCM	√	√	√	√	√	√	√	
2012	PM-Caliber	FDCM	√	√	√	√	√	√	√	
2012	PM-Caliber	CGW	√	√	√	√	√	√	√	0108,0119,0331,0465,0508,0510,0527,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,0425,0402,0810,0816,0817,0752
2012	PM-Caliber	ORC	√	√	√	√	√	○	√	0098
2012	PM-Caliber	MIC_CCN	√	√	√	√	√	√	√	1014,1186,1023,0152,0150,0187,0619,0666,1015

2012	PM-Caliber	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2012	PM-Caliber	WCM	√	√	√	√	√	○	√	0143, 0366, 0439
2012	PM-Caliber	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2012	PM-Caliber	SAS	√	√	√	√	√	○	○	
2012	PM-Caliber	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0056
2012	PM-Caliber	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2012	PM-Caliber	AMP	√	√	√	√	√	○	√	0069, 0074, 0077, 0083, 0085
2012	PM-Caliber	HFM	√	√	√	√	√	√	○	0492
2012	RT-Caravan, Town & Country	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 1123, 0257, 0322, 0908, 0472, 0537, 0591, 0821, 0615, 0216
2012	RT-Caravan, Town & Country	TCM	√	√	√	√	√	√	√	0006, 0023, 0039, 0052, 0229, 0971, 1107
2012	RT-Caravan, Town & Country	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0402, 0812
2012	RT-Caravan, Town & Country	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2012	RT-Caravan, Town & Country	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2012	RT-Caravan, Town & Country	HVAC	√	√	√	√	√	√	√	0120, 0277, 0463, 0469, 0680, 0121, 0498, 0461, 0462
2012	RT-Caravan, Town & Country	PLGM	√	√	√	√	√	√	√	0199, 0200, 0877
2012	RT-Caravan, Town & Country	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2012	RT-Caravan, Town & Country	PSM	√	√	√	√	√	√	○	0194, 0201, 1269, 1272
2012	RT-Caravan, Town & Country	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439
2012	RT-Caravan, Town & Country	SUNR	√	√	√	√	√	√	○	
2012	RT-Caravan, Town & Country	HIDT	√	√	√	√	√	√	○	0493
2012	RT-Caravan, Town & Country	AHBM	√	√	√	√	√	○	○	1023, 0153
2012	RT-Caravan, Town & Country	PTS	√	√	√	√	√	√	√	0266, 1106
2012	RT-Caravan, Town & Country	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2012	RT-Caravan, Town & Country	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1127
2012	RT-Caravan, Town & Country	SAS	√	√	√	√	√	○	○	
2012	RT-Caravan, Town & Country	ABS	√	√	√	√	√	√	√	0566, 0168, 0568, 0578, 0055, 0056
2012	RT-Caravan, Town & Country	DVD	√	√	√	√	√	○	○	
2012	RT-Caravan, Town & Country	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2012	RT-Caravan, Town & Country	AMP	√	√	√	√	√	○	√	0083, 0074
2012	RT-Caravan, Town & Country	HFM	√	√	√	√	√	√	○	0492
2012	RT-Caravan, Town & Country	VES2	√	√	√	√	√	√	√	
2012	RT-Caravan, Town & Country	VES3	√	√	√	√	√	√	√	
2012	RT-Caravan, Town & Country	DMFR	√	√	√	√	√	√	○	
2012	RT-Caravan, Town & Country	DMFL	√	√	√	√	√	√	√	
2012	RT-Caravan, Town & Country	DMRL	√	√	√	√	√	√	√	0622, 0624, 0630
2012	RT-Caravan, Town & Country	DMRR	√	√	√	√	√	√	√	0622, 0624, 0630
2012	RT-Caravan, Town & Country	PSDMR	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2012	RT-Caravan, Town & Country	PSDML	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2012	RT-Caravan, Town & Country	HSM	√	√	√	√	√	√	√	0512
2012	RT-Caravan, Town & Country	BSM	√	√	√	○	√	○	○	1027
2012	RT-Caravan, Town & Country	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2012	RT-Caravan, Town & Country	EPPM	√	√	√	√	√	○	√	
2012	WK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0257, 0216, 0133, 0312, 0616, 0821, 0952, 0932, 0948, 1034, 1148
2012	WK-Grand Cherokee	TCM	√	√	√	√	√	○	○	0924, 1094
2012	WK-Grand Cherokee	ESM	√	√	√	√	√	√	○	
2012	WK-Grand Cherokee	ACC	√	√	√	√	√	○	○	
2012	WK-Grand Cherokee	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2012	WK-Grand Cherokee	ORC	√	√	√	√	√	○	√	0098, 0581
2012	WK-Grand Cherokee	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2012	WK-Grand Cherokee	HVAC	√	√	√	√	√	√	√	0120, 0277, 0463, 0469, 0680
2012	WK-Grand Cherokee	PLGM	√	√	√	√	√	√	√	0199, 0200
2012	WK-Grand Cherokee	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2012	WK-Grand Cherokee	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2012	WK-Grand Cherokee	AHLM	√	√	√	√	√	√	○	0894
2012	WK-Grand Cherokee	AHBM	√	√	√	√	√	√	○	0132
2012	WK-Grand Cherokee	PTS	√	√	√	√	√	√	√	0266, 1106
2012	WK-Grand Cherokee	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 1066, 1178
2012	WK-Grand Cherokee	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2012	WK-Grand Cherokee	SAS	√	√	√	√	√	√	○	

2012	WK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0055,0056
2012	WK-Grand Cherokee	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2012	WK-Grand Cherokee	AMP	√	√	√	√	√	○	※	0083,0074
2012	WK-Grand Cherokee	HFM	√	√	√	√	√	√	○	0492
2012	WK-Grand Cherokee	VES3	√	√	√	√	√	√	√	
2012	WK-Grand Cherokee	DMFR	√	√	√	√	√	√	√	
2012	WK-Grand Cherokee	DMFL	√	√	√	√	√	√	√	
2012	WK-Grand Cherokee	HSM	√	√	√	√	√	√	√	0512
2012	WK-Grand Cherokee	BSM	√	√	√	○	√	○	○	1027
2012	WK-Grand Cherokee	DTCM	√	√	√	√	√	√	√	
2012	WK-Grand Cherokee	EPS	√	√	√	√	√	○	○	
2012	WK-Grand Cherokee	PEM	√	√	√	√	√	○	√	0338,0609,0648
2012	WK-Grand Cherokee	ADCM	√	√	√	√	√	○	○	
2012	WK-Grand Cherokee	ASCM	√	√	√	√	√	○	○	0134,0147,0268,1081,1082,0330,0423,0459,1056,0513,0885,1105
2012	WK-Grand Cherokee	ELSD	√	√	√	○	√	√	○	1104
2012	D2-Ram Truck	PCM	√	√	√	√	√	√	√	0591,0397,0558,0722,0755,1240,1237,0004,0021,0037,0973,1042,0734,0438,0590,0456,0589,0457,0936
2012	D2-Ram Truck	CGW	√	√	√	√	√	√	√	0108,0119,0331,0465,0508,0510,0560,0897,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152
2012	D2-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2012	D2-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186,1014,1023
2012	D2-Ram Truck	HVAC	√	√	√	√	√	※	√	0121,0498,0462,0680,0277
2012	D2-Ram Truck	MSM	√	√	√	√	√	○	○	0341,0382,0604,1023,1084,1151,0110,0381
2012	D2-Ram Truck	WCM	√	√	√	√	√	√	√	0143,0613,0439
2012	D2-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2012	D2-Ram Truck	SAS	√	√	√	√	√	○	○	
2012	D2-Ram Truck	ABS	√	√	√	√	√	√	√	0056,0168
2012	D2-Ram Truck	RADIO	√	√	√	√	√	※	※	0867,0871,0862,0426,0861
2012	D2-Ram Truck	AMP	√	√	√	√	√	○	√	0083,0074
2012	D2-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2012	D2-Ram Truck	VES3	√	√	√	√	√	√	√	
2012	D2-Ram Truck	DMFR	√	√	√	√	√	√	√	
2012	D2-Ram Truck	DMFL	√	√	√	√	√	√	√	
2012	D2-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2012	D2-Ram Truck	DTCM	√	√	√	√	√	√	○	
2012	D2-Ram Truck	LTBM	√	√	√	√	√	○	○	
2012	DJ-Ram Truck	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0591,0397,0558,0722,0755,1240,1237,0438,0456,0589,0457,0936,0102,0237,0278,0103,0188,0279,0944
2012	DJ-Ram Truck	FDCM	√	√	√	√	√	○	○	0113,0114,0115,0116,0117,0118
2012	DJ-Ram Truck	CGW	√	√	√	√	√	√	√	0108,0119,0331,0465,0508,0510,0560,0897,0900,1076,1155,1189,1235,1219,1224,1225,1226,0095,1182,1220,0150,0152
2012	DJ-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2012	DJ-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186,1014,1023
2012	DJ-Ram Truck	HVAC	√	√	√	√	√	※	√	0121,0498,0462,0680,0277
2012	DJ-Ram Truck	MSM	√	√	√	√	√	○	○	0341,0382,0604,1023,1084,1151,0110,0381
2012	DJ-Ram Truck	WCM	√	√	√	√	√	√	√	0143,0613,0439
2012	DJ-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2012	DJ-Ram Truck	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800
2012	DJ-Ram Truck	SAS	√	√	√	√	√	○	○	
2012	DJ-Ram Truck	ABS	√	√	√	√	√	√	√	0056,0168
2012	DJ-Ram Truck	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2012	DJ-Ram Truck	AMP	√	√	√	√	√	○	√	0083,0074
2012	DJ-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2012	DJ-Ram Truck	VES3	√	√	√	√	√	√	√	
2012	DJ-Ram Truck	DMFR	√	√	√	√	√	√	√	
2012	DJ-Ram Truck	DMFL	√	√	√	√	√	√	√	
2012	DJ-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2012	DJ-Ram Truck	DTCM	√	√	√	√	√	√	○	
2012	DJ-Ram Truck	LTBM	√	√	√	√	√	○	○	
2012	DS-Ram Truck	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409

2012	DS-Ram Truck	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2012	DS-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2012	DS-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2012	DS-Ram Truck	HVAC	√	√	√	√	√	※	√	0501, 0461, 0680, 0121, 0498, 0462, 0277
2012	DS-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2012	DS-Ram Truck	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2012	DS-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2012	DS-Ram Truck	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2012	DS-Ram Truck	SAS	√	√	√	√	√	○	○	
2012	DS-Ram Truck	ABS	√	√	√	√	√	√	√	0056, 0168
2012	DS-Ram Truck	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2012	DS-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2012	DS-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2012	DS-Ram Truck	VES3	√	√	√	√	√	√	√	
2012	DS-Ram Truck	DMFR	√	√	√	√	√	√	√	
2012	DS-Ram Truck	DMFL	√	√	√	√	√	√	√	
2012	DS-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2012	DS-Ram Truck	DTCM	√	√	√	√	√	√	※	
2012	DS-Ram Truck	ITBM	√	√	√	√	√	○	○	
2012	DX-Ram Truck	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0297, 0298, 1044, 1045, 1236, 0591, 0300, 0301, 0302, 0303, 0558, 0722, 1050, 1240, 1237, 1238, 0438, 0456, 0398, 0589, 0457, 0936
2012	DX-Ram Truck	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2012	DX-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2012	DX-Ram Truck	MIC CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2012	DX-Ram Truck	HVAC	√	√	√	√	√	※	√	0121, 0498, 0462, 0680, 0277
2012	DX-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2012	DX-Ram Truck	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2012	DX-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2012	DX-Ram Truck	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2012	DX-Ram Truck	SAS	√	√	√	√	√	○	○	
2012	DX-Ram Truck	ABS	√	√	√	√	√	√	√	0056, 0168
2012	DX-Ram Truck	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2012	DX-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2012	DX-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2012	DX-Ram Truck	VES3	√	√	√	√	√	√	√	
2012	DX-Ram Truck	DMFR	√	√	√	√	√	√	√	
2012	DX-Ram Truck	DMFL	√	√	√	√	√	√	√	
2012	DX-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2012	DX-Ram Truck	DTCM	√	√	√	√	√	√	○	
2012	DX-Ram Truck	ITBM	√	√	√	√	√	○	○	
2012	JS-Wrangler	PCM	√	√	√	√	√	√	√	1123, 0257, 0322, 0908, 0472, 0637, 0591, 0821, 0615, 1092, 0216
2012	JS-Wrangler	TCM	√	√	√	√	√	○	○	0924, 1094
2012	JS-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0795, 0402, 0812
2012	JS-Wrangler	ORC	√	√	√	√	√	○	√	0098, 0581
2012	JS-Wrangler	MIC CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2012	JS-Wrangler	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2012	JS-Wrangler	WCM	√	√	√	√	√	○	√	0439
2012	JS-Wrangler	SAS	√	√	√	√	√	○	○	
2012	JS-Wrangler	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2012	JS-Wrangler	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2012	JC-Journey	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0257, 0216, 0133, 0312, 0616, 0821, 0952, 0932, 0948, 1034, 1148
2012	JC-Journey	TCM	√	√	√	√	√	√	√	0006, 0023, 0039, 0052, 0229, 0971, 1107
2012	JC-Journey	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2012	JC-Journey	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2012	JC-Journey	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150

2012	JC-Journey	PTS	√	√	√	√	√	√	√	0266, 1106
2012	JC-Journey	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2012	JC-Journey	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2012	JC-Journey	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2012	JC-Journey	AMP	√	√	√	√	√	○	○	0083, 0074
2012	JC-Journey	HFM	√	√	√	√	√	○	○	0492
2012	JC-Journey	VES3	√	√	√	√	√	√	○	
2012	JC-Journey	DDM	√	√	√	√	√	√	√	
2012	JC-Journey	PDM	√	√	√	√	√	√	√	
2012	JC-Journey	HESM	√	√	√	√	√	√	√	
2012	JC-Journey	DTCM	√	√	√	√	√	√	√	
2012	JC-Journey	EPPM	√	√	√	√	√	○	√	
2012	JC-Journey	ICS	√	√	√	√	√	√	○	
2012	JC-Journey	IPC	√	√	√	√	√	√	○	
2012	JC-Journey	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2012	JC-Journey	SCCM	√	√	√	√	√	○	○	
2012	JC-Journey	TGW	√	√	√	√	√	○	√	0144, 1121
2012	LC-Challenger	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409
2012	LC-Challenger	TCM	√	√	√	√	√	○	○	0924, 1094
2012	LC-Challenger	ESM	√	√	√	√	√	√	○	
2012	LC-Challenger	CGW	√	√	√	√	√	√	√	0155, 0331, 0465, 0508, 0510, 0560, 1226, 0900, 1076, 1155, 1189, 0095, 1219, 1224, 1225
2012	LC-Challenger	ORC	√	√	√	√	√	○	√	0581
2012	LC-Challenger	MIC_CCN	√	√	√	√	√	√	√	0209, 1186, 1014, 1184, 0150, 0152
2012	LC-Challenger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2012	LC-Challenger	BCM	√	√	√	√	√	√	√	0143, 0613, 0439
2012	LC-Challenger	SUNR	√	√	√	○	√	√	○	
2012	LC-Challenger	EDM	√	√	√	√	√	○	√	0370, 1023
2012	LC-Challenger	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2012	LC-Challenger	SAS	√	√	√	√	√	√	○	
2012	LC-Challenger	ABS	√	√	√	√	√	√	√	0055, 0056
2012	LC-Challenger	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2012	LC-Challenger	AMP	√	√	√	√	√	○	※	0083, 0074
2012	LC-Challenger	HFM	√	√	√	√	√	√	○	0492
2012	LC-Challenger	DDM	√	√	√	√	√	√	○	0319
2012	LC-Challenger	PDM	√	√	√	√	√	√	○	0319
2012	LC-Challenger	HESM	√	√	√	√	√	√	√	
2012	LC-Challenger	EPS	√	√	√	√	√	○	○	
2012	LC-Challenger	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2012	LC-Challenger	ADCM	√	√	√	√	√	○	○	
2012	R2-Mini-Van	TCM	○	√	√	√	√	√	○	
2012	R2-Mini-Van	ORC	○	√	√	√	√	○	○	
2012	R2-Mini-Van	MIC_CCN	○	√	√	○	√	√	○	
2012	R2-Mini-Van	PCM	○	√	√	√	√	√	○	
2012	R2-Mini-Van	PLGM	○	√	√	√	√	√	○	
2012	R2-Mini-Van	ATC	○	√	√	√	√	√	○	
2012	R2-Mini-Van	MTC	○	√	√	○	√	√	○	
2012	R2-Mini-Van	MSM	○	√	√	√	√	√	○	
2012	R2-Mini-Van	OCM	○	√	√	√	√	○	○	
2012	R2-Mini-Van	BCM	○	√	√	√	√	√	○	
2012	R2-Mini-Van	PTS	○	√	√	√	√	○	○	
2012	R2-Mini-Van	EDM	○	√	√	○	√	○	○	
2012	R2-Mini-Van	SKM	○	√	√	○	√	√	○	
2012	R2-Mini-Van	ABS	○	√	√	√	√	√	○	
2012	R2-Mini-Van	SDAR	○	√	√	√	√	√	○	
2012	R2-Mini-Van	HFM	○	√	√	√	√	√	○	
2012	R2-Mini-Van	PSDMR	○	√	√	√	√	√	○	
2012	R2-Mini-Van	PSDML	○	√	√	√	√	√	○	
2012	RM-	PCM	√	√	√	√	√	√	√	0002, 0019, 0035, 0050, 0359, 0827, 0838, 0971, 1042, 1141, 1201, 0705, 0695, 0927, 1108, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409
2012	RM-	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0402, 0812
2012	RM-	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2012	RM-	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2012	RM-	HVAC	√	√	√	√	√	√	√	0120, 0277, 0463, 0469, 0680, 0121, 0498, 0461, 0462
2012	RM-	PLGM	√	√	√	√	√	√	√	0199, 0200, 0877
2012	RM-	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150

2012	RM-	PSM	√	√	√	√	√	√	○	0194, 0201, 1269, 1272
2012	RM-	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439
2012	RM-	SUNR	√	√	√	√	√	√	○	
2012	RM-	PTS	√	√	√	√	√	√	√	0266, 1106
2012	RM-	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1127
2012	RM-	SAS	√	√	√	√	√	○	○	
2012	RM-	ABS	√	√	√	√	√	√	√	0055, 0056, 0168
2012	RM-	DVD	√	√	√	√	√	○	○	
2012	RM-	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2012	RM-	AMP	√	√	√	√	√	○	√	0083, 0074
2012	RM-	HFM	√	√	√	√	√	√	○	0492
2012	RM-	VES2	√	√	√	√	√	√	√	
2012	RM-	VES3	√	√	√	√	√	√	√	
2012	RM-	DMFR	√	√	√	√	√	√	○	
2012	RM-	DMFL	√	√	√	√	√	√	√	
2012	RM-	DMRL	√	√	√	√	√	√	√	0622, 0624, 0630
2012	RM-	DMRR	√	√	√	√	√	√	√	0622, 0624, 0630
2012	RM-	PSDMR	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2012	RM-	PSDML	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2012	RM-	HSM	√	√	√	√	√	√	√	0512
2012	RM-	BSM	√	√	√	○	√	○	○	1027
2012	RM-	PEM	√	√	√	√	√	○	√	0338, 0809, 0648
2012	DD-Ram Truck	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0297, 0298, 1044, 1045, 1236, 0591, 0300, 0301, 0302, 0303, 0558, 0722, 1050, 0438, 0456, 0398, 0589, 0457, 0936
2012	DD-Ram Truck	TCM	√	√	√	√	√	√	○	0420
2012	DD-Ram Truck	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0254
2012	DD-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2012	DD-Ram Truck	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2012	DD-Ram Truck	HVAC	√	√	√	√	√	※	√	0121, 0498, 0462, 0680, 0277
2012	DD-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2012	DD-Ram Truck	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2012	DD-Ram Truck	SAS	√	√	√	√	√	○	○	
2012	DD-Ram Truck	ABS	√	√	√	√	√	√	√	0056, 0168
2012	DD-Ram Truck	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2012	DD-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2012	DD-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2012	DD-Ram Truck	DMFR	√	√	√	√	√	√	√	
2012	DD-Ram Truck	DMFL	√	√	√	√	√	√	√	
2012	DD-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2012	DD-Ram Truck	DTCM	√	√	√	√	√	√	○	
2012	DD-Ram Truck	ITBM	√	√	√	√	√	○	○	
2012	DD-Ram Truck	DCU	√	○	○	○	○	○	○	
2012	DP-Ram Truck	PCM	√	√	√	√	√	√	√	0297, 0298, 1044, 1045, 1236, 0591, 0300, 0301, 0302, 0303, 0558, 0722, 1050, 1042, 0438, 0590, 0456, 0398, 0589, 0457, 0936
2012	DP-Ram Truck	TCM	√	√	√	√	√	√	○	0420
2012	DP-Ram Truck	CGW	√	√	√	√	√	√	√	0108, 0119, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152, 0254
2012	DP-Ram Truck	ORC	√	√	√	√	√	○	√	0581
2012	DP-Ram Truck	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2012	DP-Ram Truck	HVAC	√	√	√	√	√	※	√	0121, 0498, 0462, 0680, 0277
2012	DP-Ram Truck	MSM	√	√	√	√	√	○	○	0341, 0382, 0604, 1023, 1084, 1151, 0110, 0381
2012	DP-Ram Truck	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2012	DP-Ram Truck	SAS	√	√	√	√	√	○	○	
2012	DP-Ram Truck	ABS	√	√	√	√	√	√	√	0056, 0168
2012	DP-Ram Truck	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2012	DP-Ram Truck	AMP	√	√	√	√	√	○	√	0083, 0074
2012	DP-Ram Truck	HFM	√	√	√	√	√	√	○	0492
2012	DP-Ram Truck	DMFR	√	√	√	√	√	√	√	
2012	DP-Ram Truck	DMFL	√	√	√	√	√	√	√	
2012	DP-Ram Truck	HSM	√	√	√	√	√	√	√	0512
2012	DP-Ram Truck	DTCM	√	√	√	√	√	√	○	
2012	DP-Ram Truck	ITBM	√	√	√	√	√	○	○	
2012	DP-Ram Truck	DCU	√	○	○	○	○	○	○	

2012	JF-Freemont	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0257, 0216, 0133, 0312, 0616, 0821, 0952, 0932, 0948, 1034, 1148
2012	JF-Freemont	TCM	√	√	√	√	√	√	√	0006, 0023, 0039, 0052, 0229, 0971, 1107
2012	JF-Freemont	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2012	JF-Freemont	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2012	JF-Freemont	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2012	JF-Freemont	PTS	√	√	√	√	√	√	√	0266, 1106
2012	JF-Freemont	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2012	JF-Freemont	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2012	JF-Freemont	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2012	JF-Freemont	AMP	√	√	√	√	√	○	○	0083, 0074
2012	JF-Freemont	HFM	√	√	√	√	√	○	○	0492
2012	JF-Freemont	VES3	√	√	√	√	√	√	○	
2012	JF-Freemont	DDM	√	√	√	√	√	√	√	
2012	JF-Freemont	PDM	√	√	√	√	√	√	√	
2012	JF-Freemont	HSM	√	√	√	√	√	√	√	
2012	JF-Freemont	DTCM	√	√	√	√	√	√	√	
2012	JF-Freemont	EPPM	√	√	√	√	√	○	√	
2012	JF-Freemont	LCS	√	√	√	√	√	√	○	
2012	JF-Freemont	IPC	√	√	√	√	√	√	○	
2012	JF-Freemont	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2012	JF-Freemont	SCCM	√	√	√	√	√	○	○	
2012	JF-Freemont	TGW	√	√	√	√	√	○	√	0144, 1121
2012	LD-Charger	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628
2012	LD-Charger	TCM	√	√	√	√	√	○	√	0924, 1094, 0912
2012	LD-Charger	ESM	√	√	√	√	√	※	○	
2012	LD-Charger	ACC	√	√	√	√	√	○	√	
2012	LD-Charger	ORC	√	√	√	√	√	○	√	0581
2012	LD-Charger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2012	LD-Charger	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2012	LD-Charger	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2012	LD-Charger	PTS	√	√	√	√	√	√	√	0266, 1106
2012	LD-Charger	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2012	LD-Charger	TPM	√	√	√	√	√	○	√	0099, 1127, 0793, 0794, 0799, 0800, 1029
2012	LD-Charger	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2012	LD-Charger	AMP	√	√	√	√	√	○	○	0083, 0074
2012	LD-Charger	HFM	√	√	√	√	√	○	○	0492
2012	LD-Charger	DDM	√	√	√	√	√	√	√	
2012	LD-Charger	PDM	√	√	√	√	√	√	√	
2012	LD-Charger	HSM	√	√	√	√	√	√	√	
2012	LD-Charger	BSM	√	√	√	○	√	○	○	1027
2012	LD-Charger	DTCM	√	√	√	√	√	√	○	
2012	LD-Charger	EPS	√	√	√	√	√	○	○	
2012	LD-Charger	ADCM	√	√	√	√	√	○	○	
2012	LD-Charger	LCS	√	√	√	√	√	√	○	
2012	LD-Charger	IPC	√	√	√	√	√	√	○	0334
2012	LD-Charger	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2012	LD-Charger	SCCM	√	√	√	√	√	○	○	
2012	LD-Charger	TGW	√	√	√	√	√	○	√	0144, 1121
2012	LD-Charger	VSIM	√	√	√	○	√	√	√	
2012	WD-Durango	PCM	√	√	√	√	√	√	√	0002, 0003, 0004, 0019, 0020, 0021, 0035, 0036, 0037, 0050, 0359, 0827, 0838, 0835, 0840, 0971, 0972, 0973, 1042, 1141, 1142, 1143, 1201, 0705, 0695, 0696, 0733, 0734, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409
2012	WD-Durango	TCM	√	√	√	√	√	○	○	0924, 1094
2012	WD-Durango	ESM	√	√	√	√	√	√	○	
2012	WD-Durango	ACC	√	√	√	√	√	○	○	
2012	WD-Durango	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2012	WD-Durango	ORC	√	√	√	√	√	○	√	0098, 0581
2012	WD-Durango	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2012	WD-Durango	HVAC	√	√	√	√	√	√	√	0120, 0277, 0463, 0469, 0680

2012	WD-Durango	PLGM	√	√	√	√	√	√	√	0199,0200
2012	WD-Durango	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2012	WD-Durango	WCM	√	√	√	√	√	√	√	0143,0613,0439
2012	WD-Durango	AHLM	√	√	√	√	√	√	○	0894
2012	WD-Durango	AHBM	√	√	√	√	√	√	○	0132
2012	WD-Durango	PTS	√	√	√	√	√	√	√	0266,1106
2012	WD-Durango	ITM	√	√	√	√	√	√	√	0584,0555,0551,1066,1178
2012	WD-Durango	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800
2012	WD-Durango	SAS	√	√	√	√	√	√	○	
2012	WD-Durango	ABS	√	√	√	√	√	√	√	0055,0056
2012	WD-Durango	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2012	WD-Durango	AMP	√	√	√	√	√	○	√	0083,0074
2012	WD-Durango	HFM	√	√	√	√	√	√	○	0492
2012	WD-Durango	VES3	√	√	√	√	√	√	√	
2012	WD-Durango	DMFR	√	√	√	√	√	√	√	
2012	WD-Durango	DMFL	√	√	√	√	√	√	√	
2012	WD-Durango	HSM	√	√	√	√	√	√	√	0512
2012	WD-Durango	BSM	√	√	√	○	√	○	○	1027
2012	WD-Durango	DTCM	√	√	√	√	√	√	√	
2012	WD-Durango	EPS	√	√	√	√	√	○	○	
2012	WD-Durango	PEM	√	√	√	√	√	○	√	0338,0609,0648
2012	PF-Dart	PCM	√	√	√	√	√	√	√	0102,0237,0278,0944,0359,0827,1042,1201,0705,0927,0103,0188,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0137,0183,0231,1145,0216,0909
2012	PF-Dart	TCM	√	√	√	√	√	√	√	0176,0531,0627,0703,0829,0951,0228
2012	PF-Dart	ESM	√	√	√	√	√	○	√	
2012	PF-Dart	ORC	√	√	√	√	√	○	√	0581
2012	PF-Dart	HVAC	√	√	√	√	√	√	√	0121,0462,0680
2012	PF-Dart	OCM	√	√	√	√	√	○	√	0715
2012	PF-Dart	BCM	√	√	√	√	√	√	√	0095,0400,0155,0452,0255,0424,0465,0506,0510,0559,0422,1076,1077,1219,1221,1224,1225,1226,1235,1138,0152,0150
2012	PF-Dart	PAM	√	√	√	√	√	○	○	
2012	PF-Dart	ABS	√	√	√	√	√	○	√	0653,1089,0181
2012	PF-Dart	RADIO	※	※	※	※	※	※	※	
2012	PF-Dart	AMP	√	√	√	√	√	○	○	
2012	PF-Dart	EPS	√	√	√	√	√	○	○	
2012	PF-Dart	ICS	√	√	√	√	√	√	○	
2012	PF-Dart	IPC	√	√	√	√	√	√	√	
2012	PF-Dart	HFM	√	√	√	√	√	√	√	0338,0561,0609,0648
2012	PF-Dart	SCCM	√	√	√	√	√	○	○	
2012	PF-Dart	CSWM	√	√	√	√	√	√	√	
2012	PF-Dart	CTM	√	√	√	√	√	○	○	
2012	PF-Dart	LBSS	√	√	√	○	√	√	√	
2012	PF-Dart	RBSS	√	√	√	○	√	√	√	
2012	PF-Dart	EDM	√	√	√	○	√	√	○	
2012	FF-500	PCM	√	√	√	√	√	√	√	0136
2012	FF-500	TCM	√	√	√	√	√	√	○	0355,0176,0531,0627,0634,0703,0829,0951
2012	FF-500	ORC	√	√	√	√	√	○	√	
2012	FF-500	HVAC	√	√	√	√	√	√	○	
2012	FF-500	BCM	√	√	√	√	√	√	√	
2012	FF-500	PTS	√	√	√	√	√	○	○	
2012	FF-500	TPM	√	√	√	√	√	√	√	
2012	FF-500	ABS	√	√	√	√	√	√	○	0057
2012	FF-500	RADIO	√	√	√	√	√	○	○	
2012	FF-500	EPS	√	√	√	√	√	○	○	0236,0573
2012	FF-500	IPC	√	√	√	√	√	√	○	0541,0542
2012	FF-500	CTM	√	√	√	√	√	√	○	
2012	FF-500	VTM	√	√	√	√	√	○	○	
2013	JK-Wrangler	PCM	√	√	√	√	√	√	√	0359,0827,1042,1201,0705,0927,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,1123,0257,0322,0908,0472,0537,0591,0821,0615,1092,0216,0102,0237,0278,0944,0103,0279
2013	JK-Wrangler	TCM	√	√	√	√	√	○	○	0924,1094
2013	JK-Wrangler	ESM	√	√	√	√	√	√	○	
2013	JK-Wrangler	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0660,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152,0402,0795,0812
2013	JK-Wrangler	ORC	√	√	√	√	√	○	√	0098,0581
2013	JK-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186,1014,1023,0187,0210,0619,1015
2013	JK-Wrangler	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2013	JK-Wrangler	ASBS	√	√	√	√	√	○	○	1071,1098,1099,1100,1101
2013	JK-Wrangler	WCM	√	√	√	√	√	○	√	0439
2013	JK-Wrangler	ITM	√	√	√	√	√	√	√	0584,0547,0551,1066,1179

2013	JK-Wrangler	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800
2013	JK-Wrangler	SAS	√	√	√	√	√	○	○	
2013	JK-Wrangler	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2013	JK-Wrangler	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0602,0426
2013	JK-Wrangler	AMP	√	√	√	√	√	○	√	0083,0074
2013	JK-Wrangler	HFM	√	√	√	√	√	√	○	0492
2013	JS-Avenger,Sebring,Convertible/Sedan	PCM	√	√	√	√	√	√	√	0002,0003,0019,0020,0035,0036,0050,0359,0827,0838,0835,0971,0972,1042,1141,1142,1201,0705,0695,0696,0733,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0102,0237,0278,0944,0103,0279
2013	JS-Avenger,Sebring,Convertible/Sedan	CGW	√	√	√	√	√	√	√	0108,0119,0465,0508,0510,0527,0560,0424,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,025d,0425,0503
2013	JS-Avenger,Sebring,Convertible/Sedan	OBC	√	√	√	√	√	○	√	0098
2013	JS-Avenger,Sebring,Convertible/Sedan	MIC_CCN	√	√	√	√	√	√	√	1014,1184,1186,1023,0150,0152
2013	JS-Avenger,Sebring,Convertible/Sedan	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680,0277
2013	JS-Avenger,Sebring,Convertible/Sedan	WCM	√	√	√	√	√	○	√	0143,0366,0439
2013	JS-Avenger,Sebring,Convertible/Sedan	PTCM	√	√	√	√	√	○	√	0661,0893
2013	JS-Avenger,Sebring,Convertible/Sedan	SAS	√	√	√	√	√	○	○	
2013	JS-Avenger,Sebring,Convertible/Sedan	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2013	JS-Avenger,Sebring,Convertible/Sedan	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2013	JS-Avenger,Sebring,Convertible/Sedan	AMP	√	√	√	√	√	○	√	0083,0074
2013	JS-Avenger,Sebring,Convertible/Sedan	HFM	√	√	√	√	√	√	○	0492
2013	JS-Avenger,Sebring,Convertible/Sedan	DDM	√	√	√	√	√	√	○	0319
2013	JS-Avenger,Sebring,Convertible/Sedan	PDM	√	√	√	√	√	√	○	0319
2013	KK-Liberty	PCM	√	√	√	√	√	√	√	0003,0020,0036,0359,0827,0835,0972,1042,1142,1201,0705,0696,0733,0927,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,1123,0257,0322,0908,0472,0537,0591,0821,0615,0216,0002,0004,0019,0021,0035,0037,0050,0838,0840,0971,0973,1141,1143,0695,0734,1108,0102,0237,0278,0944,0103,0279
2013	KK-Liberty	TCM	√	√	√	√	√	○	○	0924,1094
2013	KK-Liberty	ESM	√	√	√	√	√	√	○	
2013	KK-Liberty	FDCM	√	√	√	√	√	√	○	0706
2013	KK-Liberty	CGW	√	√	√	√	√	√	√	0108,0119,0155,0465,0508,0510,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152,0402,0812
2013	KK-Liberty	OBC	√	√	√	√	√	○	√	0098
2013	KK-Liberty	MIC_CCN	√	√	√	√	√	√	√	1186,1014,1023,0187,0210,0619,1015
2013	KK-Liberty	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680,0277
2013	KK-Liberty	WCM	√	√	√	√	√	※	※	0112,0222,0381,0603,0658,1083,1150,0341,0382,0604,1023,1084,1151,0110
2013	KK-Liberty	OCM	√	√	√	√	√	○	○	0715
2013	KK-Liberty	WCM	√	√	√	√	√	○	√	0439,0613,0614
2013	KK-Liberty	SUNR	√	√	√	√	√	○	○	
2013	KK-Liberty	PTS	√	√	√	√	√	√	√	0266,1106
2013	KK-Liberty	ITM	√	√	√	√	√	√	√	0555,1066,1178
2013	KK-Liberty	SAS	√	√	√	√	√	○	○	
2013	KK-Liberty	ABS	√	√	√	√	√	√	√	0056,0168,0568,0578
2013	KK-Liberty	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2013	KK-Liberty	AMP	√	√	√	√	√	○	√	0083,0074
2013	KK-Liberty	HFM	√	√	√	√	√	√	○	0492
2013	KK-Liberty	DMFR	√	√	√	√	√	√	○	
2013	KK-Liberty	DMFL	√	√	√	√	√	√	√	
2013	LX-300,Charger,Magnum,Grand Voyager	PCM	√	√	√	√	√	√	√	0359,0827,1042,1201,0705,0927,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0257,0216,0133,0312,0616,0821,0952,0932,0948,1034,1148,0102,0237,0278,0944,0103,0279
2013	LX-300,Charger,Magnum,Grand Voyager	TCM	√	√	√	√	√	○	√	0924,1094,0912
2013	LX-300,Charger,Magnum,Grand Voyager	ESM	√	√	√	√	√	※	○	
2013	LX-300,Charger,Magnum,Grand Voyager	ACC	√	√	√	√	√	○	√	
2013	LX-300,Charger,Magnum,Grand Voyager	OBC	√	√	√	√	√	○	√	0581
2013	LX-300,Charger,Magnum,Grand Voyager	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680
2013	LX-300,Charger,Magnum,Grand Voyager	WCM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2013	LX-300,Charger,Magnum,Grand Voyager	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2013	LX-300,Charger,Magnum,Grand Voyager	PTS	√	√	√	√	√	√	√	0266,1106
2013	LX-300,Charger,Magnum,Grand Voyager	ITM	√	√	√	√	√	√	√	0584,0555,0551,0553,1178
2013	LX-300,Charger,Magnum,Grand Voyager	TPM	√	√	√	√	√	○	√	0099,1127,0793,0794,0799,0800,1029
2013	LX-300,Charger,Magnum,Grand Voyager	ABS	√	√	√	√	√	√	√	0181,0055,0056
2013	LX-300,Charger,Magnum,Grand Voyager	AMP	√	√	√	√	√	○	○	0083,0074
2013	LX-300,Charger,Magnum,Grand Voyager	HFM	√	√	√	√	√	○	○	0492

2013	LX-300,Charger,Magnum,Grand Voyager	DDM	√	√	√	√	√	√	√	
2013	LX-300,Charger,Magnum,Grand Voyager	PDM	√	√	√	√	√	√	√	
2013	LX-300,Charger,Magnum,Grand Voyager	HSM	√	√	√	√	√	√	√	
2013	LX-300,Charger,Magnum,Grand Voyager	DTCM	√	√	√	√	√	√	○	
2013	LX-300,Charger,Magnum,Grand Voyager	EPS	√	√	√	√	√	○	○	
2013	LX-300,Charger,Magnum,Grand Voyager	ADCM	√	√	√	√	√	○	○	
2013	LX-300,Charger,Magnum,Grand Voyager	AFLS	√	√	√	√	√	√	○	0066
2013	LX-300,Charger,Magnum,Grand Voyager	ICS	√	√	√	√	√	√	○	
2013	LX-300,Charger,Magnum,Grand Voyager	IPC	√	√	√	√	√	√	○	0334
2013	LX-300,Charger,Magnum,Grand Voyager	HPH	√	√	√	√	√	√	√	0561,0338,0648
2013	LX-300,Charger,Magnum,Grand Voyager	SCCM	√	√	√	√	√	○	○	
2013	LX-300,Charger,Magnum,Grand Voyager	TGW	√	√	√	√	√	○	√	0144,1121
2013	LX-300,Charger,Magnum,Grand Voyager	LBSS	√	√	√	○	√	○	○	
2013	LX-300,Charger,Magnum,Grand Voyager	RBSS	√	√	√	○	√	○	○	
2013	MK-Compass,Patriot	PCM	√	√	√	√	√	√	※	0359,0827,1042,1201,0705,0927,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0434,1191,0310,0432,0477,0514,0494,0588,0663,0704,0821,1102,1194,1148,0363,0258,0102,0237,0278,0944,0103,0279
2013	MK-Compass,Patriot	TCM	√	√	√	√	√	√	√	
2013	MK-Compass,Patriot	FDCM	√	√	√	√	√	√	√	
2013	MK-Compass,Patriot	CGW	√	√	√	√	√	√	√	0108,0119,0465,0508,0510,0527,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,0425,0402,0810,0816,0817,0752
2013	MK-Compass,Patriot	ORC	√	√	√	√	√	○	√	0098
2013	MK-Compass,Patriot	MIC_CCN	√	√	√	√	√	√	√	1014,1184,1186,1023,0150,0152
2013	MK-Compass,Patriot	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2013	MK-Compass,Patriot	WCM	√	√	√	√	√	○	√	0143,0366,0439
2013	MK-Compass,Patriot	ITM	√	√	√	√	√	√	√	0555,1066,1178
2013	MK-Compass,Patriot	SAS	√	√	√	√	√	○	○	
2013	MK-Compass,Patriot	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2013	MK-Compass,Patriot	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2013	MK-Compass,Patriot	AMP	√	√	√	√	√	○	√	0069,0074,0077,0083,0085
2013	MK-Compass,Patriot	HFM	√	√	√	√	√	√	○	0492
2013	RT-Caravan,Town & Country	PCM	√	√	√	√	√	√	√	0002,0019,0035,0050,0359,0827,0838,0971,1042,1141,1201,0705,0695,0927,1108,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,1123,0257,0322,0908,0472,0537,0591,0821,0615,0216,0102,0237,0278,0944,0103,0279
2013	RT-Caravan,Town & Country	TCM	√	√	√	√	√	√	√	0006,0023,0039,0052,0229,0971,1107
2013	RT-Caravan,Town & Country	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152
2013	RT-Caravan,Town & Country	ORC	√	√	√	√	√	○	√	0098,0581
2013	RT-Caravan,Town & Country	MIC_CCN	√	√	√	√	√	√	√	1186,1014,1023,0187,0210,0619,1015
2013	RT-Caravan,Town & Country	HVAC	√	√	√	√	√	√	√	0120,0277,0463,0469,0680,0121,0498,0461,0462
2013	RT-Caravan,Town & Country	PLGM	√	√	√	√	√	√	√	0199,0200,0877
2013	RT-Caravan,Town & Country	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2013	RT-Caravan,Town & Country	PSM	√	√	√	√	√	√	○	0194,0201,1269,1272
2013	RT-Caravan,Town & Country	WCM	√	√	√	√	√	√	√	0143,0366,0613,0439
2013	RT-Caravan,Town & Country	SUNR	√	√	√	√	√	√	○	
2013	RT-Caravan,Town & Country	HIDT	√	√	√	√	√	√	○	0493
2013	RT-Caravan,Town & Country	AHBM	√	√	√	√	√	√	○	0132
2013	RT-Caravan,Town & Country	PTS	√	√	√	√	√	√	√	0266,1106
2013	RT-Caravan,Town & Country	ITM	√	√	√	√	√	√	√	0555,1066,1178
2013	RT-Caravan,Town & Country	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1127
2013	RT-Caravan,Town & Country	SAS	√	√	√	√	√	○	○	
2013	RT-Caravan,Town & Country	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0055,0056
2013	RT-Caravan,Town & Country	DVD	√	√	√	√	√	○	○	
2013	RT-Caravan,Town & Country	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2013	RT-Caravan,Town & Country	AMP	√	√	√	√	√	○	√	0083,0074
2013	RT-Caravan,Town & Country	HFM	√	√	√	√	√	√	○	0492
2013	RT-Caravan,Town & Country	VES2	√	√	√	√	√	√	√	
2013	RT-Caravan,Town & Country	VES3	√	√	√	√	√	√	√	
2013	RT-Caravan,Town & Country	DMFR	√	√	√	√	√	√	○	
2013	RT-Caravan,Town & Country	DMFL	√	√	√	√	√	√	√	
2013	RT-Caravan,Town & Country	DMRL	√	√	√	√	√	√	√	0622,0624,0630
2013	RT-Caravan,Town & Country	DMRR	√	√	√	√	√	√	√	0622,0624,0630
2013	RT-Caravan,Town & Country	PSDMR	√	√	√	√	√	○	○	0106,1067,0633,1070,0877
2013	RT-Caravan,Town & Country	PSDML	√	√	√	√	√	○	○	0106,1067,0633,1070,0877
2013	RT-Caravan,Town & Country	HSM	√	√	√	√	√	√	√	0512
2013	RT-Caravan,Town & Country	PDM	√	√	√	√	√	○	√	0338,0609,0648
2013	RT-Caravan,Town & Country	EPPM	√	√	√	√	√	○	√	
2013	RT-Caravan,Town & Country	LBSS	√	√	√	○	√	○	○	

2013	RT-Caravan,Town & Country	RBSS	√	√	√	○	√	○	○	
2013	WK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0927, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0257, 0216, 0133, 0616, 0821, 0952, 0948, 1034, 0312, 0932, 1148, 0002, 0003, 0019, 0020, 0035, 0036, 0050, 0838, 0835, 0971, 0972, 1141, 1142, 0695, 0696, 0733, 0734, 1108, 1109
2013	WK-Grand Cherokee	TCM	√	√	√	√	√	○	○	0924, 1094
2013	WK-Grand Cherokee	ESM	√	√	√	√	√	√	○	
2013	WK-Grand Cherokee	ACC	√	√	√	√	√	○	○	
2013	WK-Grand Cherokee	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2013	WK-Grand Cherokee	ORC	√	√	√	√	√	○	√	0098, 0581
2013	WK-Grand Cherokee	MIC CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2013	WK-Grand Cherokee	HVAC	√	√	√	√	√	√	√	0120, 0277, 0463, 0469, 0680
2013	WK-Grand Cherokee	PLGM	√	√	√	√	√	√	√	0199, 0200
2013	WK-Grand Cherokee	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2013	WK-Grand Cherokee	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2013	WK-Grand Cherokee	AHLM	√	√	√	√	√	√	○	0894
2013	WK-Grand Cherokee	AHBM	√	√	√	√	√	√	○	0132
2013	WK-Grand Cherokee	PTS	√	√	√	√	√	√	√	0266, 1106
2013	WK-Grand Cherokee	ITM	√	√	√	√	√	√	√	1066, 1178, 0584, 0555, 0551
2013	WK-Grand Cherokee	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2013	WK-Grand Cherokee	SAS	√	√	√	√	√	√	○	
2013	WK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0055, 0056
2013	WK-Grand Cherokee	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2013	WK-Grand Cherokee	AMP	√	√	√	√	√	○	※	0083, 0074
2013	WK-Grand Cherokee	HFM	√	√	√	√	√	√	○	0492
2013	WK-Grand Cherokee	VES3	√	√	√	√	√	√	√	
2013	WK-Grand Cherokee	DMFR	√	√	√	√	√	√	√	
2013	WK-Grand Cherokee	DMFL	√	√	√	√	√	√	√	
2013	WK-Grand Cherokee	HSM	√	√	√	√	√	√	√	0512
2013	WK-Grand Cherokee	BSM	√	√	√	○	√	○	○	1027
2013	WK-Grand Cherokee	DTCM	√	√	√	√	√	√	√	
2013	WK-Grand Cherokee	EPS	√	√	√	√	√	○	○	
2013	WK-Grand Cherokee	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2013	WK-Grand Cherokee	ADCM	√	√	√	√	√	○	○	
2013	WK-Grand Cherokee	ASCM	√	√	√	√	√	○	○	0134, 0147, 0268, 1081, 1082, 0330, 0423 0459, 1056, 0513, 0665, 1105
2013	WK-Grand Cherokee	ELSD	√	√	√	○	√	√	○	1104
2013	D2-Ram Truck	PCM	√	√	√	√	√	√	√	0558, 0973, 1143, 0842, 1042, 1176, 0142, 0299, 0303, 0590, 0204, 1044, 1045, 0004, 0021, 0037, 0344, 0438, 0311, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 1201, 0705, 0734, 0927, 0103, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0596 0597, 0628
2013	D2-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2013	D2-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2013	D2-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2013	D2-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2013	D2-Ram Truck	BCM	√	√	√	√	√	√	√	1219, 1221, 1224, 1225, 1226, 1235, 0452 0150, 0153, 0900
2013	D2-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2013	D2-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2013	D2-Ram Truck	RADIO	√	√	√	√	√	√	√	
2013	D2-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2013	D2-Ram Truck	DDM	√	√	√	√	√	√	√	
2013	D2-Ram Truck	PDM	√	√	√	√	√	√	√	
2013	D2-Ram Truck	HSM	√	√	√	√	√	√	√	
2013	D2-Ram Truck	DTCM	√	√	√	√	√	√	√	
2013	D2-Ram Truck	ITBM	√	√	√	√	√	○	○	
2013	D2-Ram Truck	ASCM	√	√	√	√	√	○	√	0513, 1081, 0459, 1056, 0256
2013	D2-Ram Truck	DCU	√	√	√	○	√	○	○	
2013	D2-Ram Truck	ICS	√	√	√	√	√	√	√	
2013	D2-Ram Truck	IPC	√	√	√	○	√	√	√	0334, 0467
2013	D2-Ram Truck	RFH	√	√	√	√	√	√	√	0338, 0648, 0609
2013	D2-Ram Truck	SCCM	√	√	√	√	√	○	○	
2013	D2-Ram Truck	VSIM	√	√	√	○	√	√	○	
2013	D2-Ram Truck	VGT	√	√	√	○	√	○	○	
2013	D2-Ram Truck	EDM	√	√	√	○	√	√	○	
2013	DJ-Ram Truck	PCM	√	√	√	√	√	√	√	1044, 1045, 0558, 0004, 0021, 0037, 0973, 1143, 0842, 1042, 1176, 0142, 0299, 0303, 0590, 0204, 0311, 0344, 0438, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 1201, 0705, 0734, 0927, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0596, 0597, 0628

2013	DJ-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2013	DJ-Ram Truck	FDCM	√	√	√	√	√	○	○	
2013	DJ-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2013	DJ-Ram Truck	HVAC	√	√	√	√	√	√	√	0498,0461,0680,0121
2013	DJ-Ram Truck	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2013	DJ-Ram Truck	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2013	DJ-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2013	DJ-Ram Truck	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2013	DJ-Ram Truck	ABS	√	√	√	√	√	√	√	0181,0055,0056
2013	DJ-Ram Truck	RADIO	√	√	√	√	√	√	√	
2013	DJ-Ram Truck	AMP	√	√	√	√	√	○	○	0083,0074
2013	DJ-Ram Truck	DDM	√	√	√	√	√	√	√	
2013	DJ-Ram Truck	PDM	√	√	√	√	√	√	√	
2013	DJ-Ram Truck	HSM	√	√	√	√	√	√	√	
2013	DJ-Ram Truck	DTCM	√	√	√	√	√	√	√	
2013	DJ-Ram Truck	ITBM	√	√	√	√	√	○	○	
2013	DJ-Ram Truck	ASCM	√	√	√	√	√	○	√	0513,1081,0459,1056,0256
2013	DJ-Ram Truck	DCU	√	√	√	○	√	○	○	
2013	DJ-Ram Truck	ICS	√	√	√	√	√	√	√	
2013	DJ-Ram Truck	IPC	√	√	√	○	√	√	√	0334,0467
2013	DJ-Ram Truck	RFH	√	√	√	√	√	√	√	0609,0338,0648
2013	DJ-Ram Truck	SCCM	√	√	√	√	√	○	○	
2013	DJ-Ram Truck	VSIM	√	√	√	○	√	√	○	
2013	DJ-Ram Truck	VGT	√	√	√	○	√	○	○	
2013	DJ-Ram Truck	EDM	√	√	√	○	√	√	○	
2013	DS-Ram Truck	PCM	√	√	√	√	√	√	√	0004,0021,0037,0102,0237,0278,0944,0359,0827,0840,0973,1042,1143,1201,0705,0734,0927,0103,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628
2013	DS-Ram Truck	TCM	√	√	√	√	√	○	√	0912
2013	DS-Ram Truck	ESM	√	√	√	√	√	○	○	
2013	DS-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2013	DS-Ram Truck	HVAC	√	√	√	√	√	√	√	0498,0461,0680,0121
2013	DS-Ram Truck	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2013	DS-Ram Truck	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2013	DS-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2013	DS-Ram Truck	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2013	DS-Ram Truck	ABS	√	√	√	√	√	√	√	0181,0055,0056
2013	DS-Ram Truck	RADIO	√	√	√	√	√	√	√	
2013	DS-Ram Truck	AMP	√	√	√	√	√	○	○	0083,0074
2013	DS-Ram Truck	DDM	√	√	√	√	√	√	√	
2013	DS-Ram Truck	PDM	√	√	√	√	√	√	√	
2013	DS-Ram Truck	HSM	√	√	√	√	√	√	√	
2013	DS-Ram Truck	DTCM	√	√	√	√	√	√	√	
2013	DS-Ram Truck	EPS	√	√	√	√	√	○	○	0236
2013	DS-Ram Truck	ITBM	√	√	√	√	√	○	○	
2013	DS-Ram Truck	ASCM	√	√	√	√	√	○	√	0513,0134,1081,1082,0330,0459,1056,0256
2013	DS-Ram Truck	ICS	√	√	√	√	√	√	√	
2013	DS-Ram Truck	IPC	√	√	√	○	√	√	√	0334
2013	DS-Ram Truck	RFH	√	√	√	√	√	√	√	0609,0338,0648
2013	DS-Ram Truck	SCCM	√	√	√	√	√	○	○	
2013	DS-Ram Truck	EDM	√	√	√	○	√	√	○	
2013	DX-Ram Truck	PCM	√	√	√	√	√	√	√	1044,1045,0558,0722,1050,0004,0021,0037,0973,1143,0842,1042,1176,0756,0142,0299,0303,0397,0590,0395,0204,0311,0344,0438,0102,0237,0278,0944,0359,0827,0840,1201,0705,0734,0927,0103,0279,0202,0215,0229,0386,0373,0378,0446,0447,0596,0597,0628
2013	DX-Ram Truck	TCM	√	√	√	√	√	※	√	0829,0912
2013	DX-Ram Truck	ESM	√	√	√	√	√	○	○	
2013	DX-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2013	DX-Ram Truck	HVAC	√	√	√	√	√	√	√	0498,0461,0680,0121
2013	DX-Ram Truck	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2013	DX-Ram Truck	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2013	DX-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2013	DX-Ram Truck	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2013	DX-Ram Truck	ABS	√	√	√	√	√	√	√	0181,0055,0056
2013	DX-Ram Truck	RADIO	√	√	√	√	√	√	√	
2013	DX-Ram Truck	AMP	√	√	√	√	√	○	○	0083,0074
2013	DX-Ram Truck	DDM	√	√	√	√	√	√	√	
2013	DX-Ram Truck	PDM	√	√	√	√	√	√	√	
2013	DX-Ram Truck	HSM	√	√	√	√	√	√	√	
2013	DX-Ram Truck	DTCM	√	√	√	√	√	√	√	
2013	DX-Ram Truck	EPS	√	√	√	√	√	○	○	0236

2013	DX-Ram Truck	ITBM	√	√	√	√	√	○	○	
2013	DX-Ram Truck	ASCM	√	√	√	√	√	○	√	0134, 1081, 1082, 0330, 0459, 1056, 0513, 0256
2013	DX-Ram Truck	DCU	√	√	√	○	√	○	○	
2013	DX-Ram Truck	ICS	√	√	√	√	√	√	√	
2013	DX-Ram Truck	IPC	√	√	√	○	√	√	√	0334
2013	DX-Ram Truck	RFH	√	√	√	√	√	√	√	0609, 0338, 0648
2013	DX-Ram Truck	SCCM	√	√	√	√	√	○	○	
2013	DX-Ram Truck	VSIM	√	√	√	○	√	√	○	
2013	DX-Ram Truck	VGT	√	√	√	○	√	○	○	
2013	DX-Ram Truck	EDM	√	√	√	○	√	√	○	
2013	JS-Wrangler	PCM	√	√	√	√	√	√	√	1123, 0322, 0908, 0472, 0537, 0591, 0821, 0615, 1092, 0216, 0257
2013	JS-Wrangler	TCM	√	√	√	√	√	○	○	0924, 1094
2013	JS-Wrangler	ESM	√	√	√	√	√	√	○	
2013	JS-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0402, 0795, 0812
2013	JS-Wrangler	ORC	√	√	√	√	√	○	√	0098, 0581
2013	JS-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2013	JS-Wrangler	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2013	JS-Wrangler	BCM	√	√	√	√	√	○	√	0439
2013	JS-Wrangler	SAS	√	√	√	√	√	○	○	
2013	JS-Wrangler	ABS	√	√	√	√	√	√	√	0056, 0168, 0568, 0578
2013	JS-Wrangler	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2013	JC-Journey	PCM	√	√	√	√	√	√	√	0002, 0003, 0019, 0020, 0035, 0036, 0050, 0359, 0827, 0838, 0835, 0971, 0972, 1042, 1141, 1142, 1201, 0705, 0695, 0696, 0733, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0257, 0216, 0133, 0312, 0616, 0821, 0952, 0932, 0948, 1034, 1148, 0102, 0237, 0278, 0944, 0103, 0279, 1271
2013	JC-Journey	TCM	√	√	√	√	√	√	√	0006, 0023, 0039, 0052, 0229, 0971, 1107
2013	JC-Journey	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2013	JC-Journey	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2013	JC-Journey	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2013	JC-Journey	PTS	√	√	√	√	√	√	√	0266, 1106
2013	JC-Journey	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2013	JC-Journey	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2013	JC-Journey	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2013	JC-Journey	AMP	√	√	√	√	√	○	○	0083, 0074
2013	JC-Journey	HFM	√	√	√	√	√	○	○	0492
2013	JC-Journey	VESS	√	√	√	√	√	√	○	
2013	JC-Journey	DDM	√	√	√	√	√	√	√	
2013	JC-Journey	PDM	√	√	√	√	√	√	√	
2013	JC-Journey	HSM	√	√	√	√	√	√	√	
2013	JC-Journey	DTCM	√	√	√	√	√	√	√	
2013	JC-Journey	EPPM	√	√	√	√	√	○	√	
2013	JC-Journey	ICS	√	√	√	√	√	√	○	
2013	JC-Journey	IPC	√	√	√	√	√	√	○	
2013	JC-Journey	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2013	JC-Journey	SCCM	√	√	√	√	√	○	○	
2013	JC-Journey	TGW	√	√	√	√	√	○	√	0144, 1121
2013	JC-Journey	VTM	√	√	√	√	√	○	○	
2013	LC-Challenger	PCM	√	√	√	√	√	√	√	0359, 0827, 1042, 1201, 0705, 0927, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0102, 0237, 0278, 0944, 0103, 0279
2013	LC-Challenger	TCM	√	√	√	√	√	○	○	0924, 1094
2013	LC-Challenger	ESM	√	√	√	√	√	√	○	
2013	LC-Challenger	CGW	√	√	√	√	√	√	√	0331, 0465, 0508, 0560, 1226, 0900, 1076, 1155, 1189, 0095, 1219, 1224, 1225, 0155, 0510
2013	LC-Challenger	ORC	√	√	√	√	√	○	√	0581
2013	LC-Challenger	MIC_CCN	√	√	√	√	√	√	√	0209, 1186, 1014, 1184, 0150, 0152
2013	LC-Challenger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2013	LC-Challenger	BCM	√	√	√	√	√	√	√	0143, 0613, 0439
2013	LC-Challenger	SUNR	√	√	√	○	√	√	○	
2013	LC-Challenger	PTS	√	√	√	√	√	○	√	1106
2013	LC-Challenger	EDM	√	√	√	√	√	○	√	0370, 1023
2013	LC-Challenger	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2013	LC-Challenger	SAS	√	√	√	√	√	√	○	
2013	LC-Challenger	ABS	√	√	√	√	√	√	√	0055, 0056
2013	LC-Challenger	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2013	LC-Challenger	AMP	√	√	√	√	√	○	※	0083, 0074
2013	LC-Challenger	HFM	√	√	√	√	√	√	○	0492
2013	LC-Challenger	DDM	√	√	√	√	√	√	○	0319
2013	LC-Challenger	PDM	√	√	√	√	√	√	○	0319

2013	LC-Challenger	HSM	√	√	√	√	√	√	√	
2013	LC-Challenger	EPS	√	√	√	√	√	○	○	
2013	LC-Challenger	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2013	LC-Challenger	ADCM	√	√	√	√	√	○	○	
2013	RM-	PCM	√	√	√	√	√	√	√	0002, 0019, 0035, 0050, 0359, 0827, 0838, 0971, 1042, 1141, 1201, 0705, 0695, 0927, 1108, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0102, 0237, 0278, 0944, 0103, 0279
2013	RM-	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152
2013	RM-	ORC	√	√	√	√	√	○	√	0098, 0581
2013	RM-	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2013	RM-	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680, 0462, 0277
2013	RM-	PLGM	√	√	√	√	√	√	√	0199, 0200, 0877
2013	RM-	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2013	RM-	FSM	√	√	√	√	√	√	○	0194, 0201, 1269, 1272
2013	RM-	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2013	RM-	SUNR	√	√	√	√	√	√	○	
2013	RM-	PTS	√	√	√	√	√	√	√	0266, 1106
2013	RM-	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1127
2013	RM-	SAS	√	√	√	√	√	○	○	
2013	RM-	ABS	√	√	√	√	√	√	√	0055, 0056, 0168
2013	RM-	DVD	√	√	√	√	√	○	○	
2013	RM-	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2013	RM-	AMP	√	√	√	√	√	○	√	0083, 0074
2013	RM-	HFM	√	√	√	√	√	√	○	0492
2013	RM-	VES2	√	√	√	√	√	√	√	
2013	RM-	VES3	√	√	√	√	√	√	√	
2013	RM-	DMFR	√	√	√	√	√	√	○	
2013	RM-	DMFL	√	√	√	√	√	√	√	
2013	RM-	DMRL	√	√	√	√	√	√	√	0622, 0624, 0630
2013	RM-	DMRR	√	√	√	√	√	√	√	0622, 0624, 0630
2013	RM-	PSDMR	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2013	RM-	PSDML	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2013	RM-	HSM	√	√	√	√	√	√	√	0512
2013	RM-	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2013	RM-	LBSS	√	√	√	○	√	○	○	
2013	RM-	RBSS	√	√	√	○	√	○	○	
2013	DD-Ram Truck	PCM	√	√	√	√	√	√	√	1044, 1045, 0558, 0722, 1042, 1176, 0142, 0299, 0303, 0397, 0590, 0395, 0204, 1050, 0756, 0311, 0344, 0438, 0004, 0021, 0037, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 0973, 1143, 1201, 0705, 0734, 0927, 0103, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0596, 0597, 0628
2013	DD-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2013	DD-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2013	DD-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2013	DD-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2013	DD-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2013	DD-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2013	DD-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2013	DD-Ram Truck	RADIO	√	√	√	√	√	√	√	
2013	DD-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2013	DD-Ram Truck	DDM	√	√	√	√	√	√	√	
2013	DD-Ram Truck	PDM	√	√	√	√	√	√	√	
2013	DD-Ram Truck	HSM	√	√	√	√	√	√	√	
2013	DD-Ram Truck	DTCM	√	√	√	√	√	√	√	
2013	DD-Ram Truck	ITBM	√	√	√	√	√	○	○	
2013	DD-Ram Truck	DCU	√	√	√	○	√	○	○	
2013	DD-Ram Truck	ICS	√	√	√	√	√	√	√	
2013	DD-Ram Truck	IPC	√	√	√	○	√	√	√	0334, 0467
2013	DD-Ram Truck	RFH	√	√	√	√	√	√	√	0609, 0338, 0648
2013	DD-Ram Truck	SCCM	√	√	√	√	√	○	○	
2013	DD-Ram Truck	VSIM	√	√	√	○	√	√	○	
2013	DD-Ram Truck	VGT	√	√	√	○	√	○	○	
2013	DD-Ram Truck	EDM	√	√	√	○	√	√	○	
2013	DP-Ram Truck	PCM	√	√	√	√	√	√	√	1044, 1045, 0558, 0722, 1050, 1042, 1176, 0756, 0142, 0299, 0303, 0397, 0590, 0395, 0204, 0311, 0344, 0438, 0004, 0021, 0037, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 0973, 1143, 1201, 0705, 0734, 0927, 0103, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0596, 0597, 0628
2013	DP-Ram Truck	TCM	√	√	√	√	√	√	√	0829

2013	DP-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2013	DP-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2013	DP-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2013	DP-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2013	DP-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2013	DP-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2013	DP-Ram Truck	RADIO	√	√	√	√	√	√	√	
2013	DP-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2013	DP-Ram Truck	DDM	√	√	√	√	√	√	√	
2013	DP-Ram Truck	PDM	√	√	√	√	√	√	√	
2013	DP-Ram Truck	HSM	√	√	√	√	√	√	√	
2013	DP-Ram Truck	DTCM	√	√	√	√	√	√	√	
2013	DP-Ram Truck	ITBM	√	√	√	√	√	○	○	
2013	DP-Ram Truck	DCU	√	√	√	○	√	○	○	
2013	DP-Ram Truck	ICS	√	√	√	√	√	√	√	
2013	DP-Ram Truck	IPC	√	√	√	○	√	√	√	0334, 0467
2013	DP-Ram Truck	RFH	√	√	√	√	√	√	√	0609, 0338, 0648
2013	DP-Ram Truck	SCCM	√	√	√	√	√	○	○	
2013	DP-Ram Truck	VSIM	√	√	√	○	√	√	○	
2013	DP-Ram Truck	VGT	√	√	√	○	√	○	○	
2013	DP-Ram Truck	EDM	√	√	√	○	√	√	○	
2013	JF-Freemont	PCM	√	√	√	√	√	√	√	0002, 0003, 0019, 0020, 0035, 0036, 0050, 0359, 0827, 0838, 0835, 0971, 0972, 1042, 1141, 1142, 1201, 0705, 0695, 0696, 0733, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0257, 0216, 0133, 0312, 0616, 0821, 0952, 0932, 0948, 1034, 1148, 0102, 0237, 0278, 0944, 1271, 0103, 0279
2013	JF-Freemont	TCM	√	√	√	√	√	√	√	0006, 0023, 0039, 0052, 0229, 0971, 1107
2013	JF-Freemont	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2013	JF-Freemont	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2013	JF-Freemont	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2013	JF-Freemont	PTS	√	√	√	√	√	√	√	0266, 1106
2013	JF-Freemont	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2013	JF-Freemont	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2013	JF-Freemont	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2013	JF-Freemont	AMP	√	√	√	√	√	○	○	0083, 0074
2013	JF-Freemont	HFM	√	√	√	√	√	○	○	0492
2013	JF-Freemont	VES3	√	√	√	√	√	√	○	
2013	JF-Freemont	DDM	√	√	√	√	√	√	√	
2013	JF-Freemont	PDM	√	√	√	√	√	√	√	
2013	JF-Freemont	HSM	√	√	√	√	√	√	√	
2013	JF-Freemont	DTCM	√	√	√	√	√	√	√	
2013	JF-Freemont	EPPM	√	√	√	√	√	○	√	
2013	JF-Freemont	ICS	√	√	√	√	√	√	○	
2013	JF-Freemont	IPC	√	√	√	√	√	√	○	
2013	JF-Freemont	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2013	JF-Freemont	SCCM	√	√	√	√	√	○	○	
2013	JF-Freemont	TGW	√	√	√	√	√	○	√	0144, 1121
2013	JF-Freemont	VTM	√	√	√	√	√	○	○	
2013	LD-Charger	PCM	√	√	√	√	√	√	√	0359, 0827, 1042, 1201, 0705, 0927, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0102, 0237, 0278, 0944, 0103, 0279
2013	LD-Charger	TCM	√	√	√	√	√	○	√	0924, 1094, 0912
2013	LD-Charger	ESM	√	√	√	√	√	※	○	
2013	LD-Charger	ACC	√	√	√	√	√	○	√	
2013	LD-Charger	ORC	√	√	√	√	√	○	√	0581
2013	LD-Charger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2013	LD-Charger	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2013	LD-Charger	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2013	LD-Charger	PTS	√	√	√	√	√	√	√	0266, 1106
2013	LD-Charger	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2013	LD-Charger	TPM	√	√	√	√	√	○	√	0099, 1127, 0793, 0794, 0799, 0800, 1029
2013	LD-Charger	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2013	LD-Charger	AMP	√	√	√	√	√	○	○	0083, 0074
2013	LD-Charger	HFM	√	√	√	√	√	○	○	0492
2013	LD-Charger	DDM	√	√	√	√	√	√	√	
2013	LD-Charger	PDM	√	√	√	√	√	√	√	
2013	LD-Charger	HSM	√	√	√	√	√	√	√	
2013	LD-Charger	DTCM	√	√	√	√	√	√	○	
2013	LD-Charger	EPS	√	√	√	√	√	○	○	
2013	LD-Charger	ADCM	√	√	√	√	√	○	○	
2013	LD-Charger	ICS	√	√	√	√	√	√	○	
2013	LD-Charger	IPC	√	√	√	√	√	√	○	0334

2013	LD-Charger	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2013	LD-Charger	SCCM	√	√	√	√	√	○	○	
2013	LD-Charger	TGW	√	√	√	√	√	○	√	0144, 1121
2013	LD-Charger	VSIM	√	√	√	○	√	√	√	
2013	LD-Charger	LBSS	√	√	√	○	√	○	○	
2013	LD-Charger	RBSS	√	√	√	○	√	○	○	
2013	WD-Durango	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0927, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0002, 0003, 0019, 0020, 0035, 0036, 0050, 0838, 0835, 0971, 0972, 1141, 1142, 0695, 0696, 0733, 0734, 1108, 1109
2013	WD-Durango	TCM	√	√	√	√	√	○	○	0924, 1094
2013	WD-Durango	ESM	√	√	√	√	√	√	○	
2013	WD-Durango	ACC	√	√	√	√	√	○	○	
2013	WD-Durango	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0897, 0900, 1076, 1155, 1189, 1235, 1219, 1224, 1225, 1226, 0095, 1182, 1220, 0150, 0152
2013	WD-Durango	ORC	√	√	√	√	√	○	√	0098, 0581
2013	WD-Durango	HTC CCN	√	√	√	√	√	√	√	1186, 1014, 1023
2013	WD-Durango	HVAC	√	√	√	√	√	√	√	0120, 0277, 0463, 0469, 0680
2013	WD-Durango	PLGM	√	√	√	√	√	√	√	0199, 0200
2013	WD-Durango	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2013	WD-Durango	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2013	WD-Durango	AHLM	√	√	√	√	√	√	○	0894
2013	WD-Durango	AHBM	√	√	√	√	√	√	○	0132
2013	WD-Durango	PTS	√	√	√	√	√	√	√	0266, 1106
2013	WD-Durango	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 1066, 1178
2013	WD-Durango	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2013	WD-Durango	SAS	√	√	√	√	√	√	○	
2013	WD-Durango	ABS	√	√	√	√	√	√	√	0055, 0056
2013	WD-Durango	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2013	WD-Durango	AMP	√	√	√	√	√	○	√	0083, 0074
2013	WD-Durango	HFM	√	√	√	√	√	√	○	0492
2013	WD-Durango	VES3	√	√	√	√	√	√	√	
2013	WD-Durango	DMFR	√	√	√	√	√	√	√	
2013	WD-Durango	DMFL	√	√	√	√	√	√	√	
2013	WD-Durango	HSM	√	√	√	√	√	√	√	0512
2013	WD-Durango	BSM	√	√	√	○	√	○	○	1027
2013	WD-Durango	DTCM	√	√	√	√	√	√	√	
2013	WD-Durango	EPS	√	√	√	√	√	○	○	
2013	WD-Durango	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2013	PF-Dart	PCM	√	√	√	√	√	√	√	0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0103, 0188, 0279, 0202, 0215, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0909, 0137, 0183, 0231, 1145, 0216
2013	PF-Dart	TCM	√	√	√	√	√	√	√	0176, 0531, 0627, 0703, 0951, 0829, 0228
2013	PF-Dart	ESM	√	√	√	√	√	○	√	
2013	PF-Dart	ORC	√	√	√	√	√	○	√	0581
2013	PF-Dart	HVAC	√	√	√	√	√	√	√	0121, 0462, 0680
2013	PF-Dart	OCM	√	√	√	√	√	○	√	0715
2013	PF-Dart	BCM	√	√	√	√	√	√	√	0095, 0400, 0155, 0452, 0255, 0424, 0465, 0506, 0510, 0559, 0422, 1076, 1077, 1219, 1221, 1224, 1225, 1226, 1235, 1138, 0150, 0152
2013	PF-Dart	PAM	√	√	√	√	√	○	○	
2013	PF-Dart	ABS	√	√	√	√	√	○	√	0181, 0653, 1089
2013	PF-Dart	RADIO	※	※	※	※	※	※	※	
2013	PF-Dart	AMP	√	√	√	√	√	○	○	
2013	PF-Dart	EPS	√	√	√	√	√	○	○	
2013	PF-Dart	ICS	√	√	√	√	√	√	○	
2013	PF-Dart	IPC	√	√	√	√	√	√	√	
2013	PF-Dart	RFH	√	√	√	√	√	√	√	0338, 0561, 0609, 0648
2013	PF-Dart	SCCM	√	√	√	√	√	○	○	
2013	PF-Dart	CSWM	√	√	√	√	√	√	√	
2013	PF-Dart	CTM	√	√	√	√	√	○	○	
2013	PF-Dart	LBSS	√	√	√	○	√	√	√	
2013	PF-Dart	RBSS	√	√	√	○	√	√	√	
2013	PF-Dart	EDM	√	√	√	○	√	√	○	
2013	BK-Forza	ORC	√	√	√	√	√	√	○	
2013	BK-Forza	IPC	√	√	√	√	√	√	○	
2013	ZD-Viper (Post-2013)	PCM	√	√	√	√	√	√	○	0215, 0628, 0377, 0590, 0625, 0626, 0631, 0826, 0927, 1146
2013	ZD-Viper (Post-2013)	ORC	√	√	√	√	√	√	√	0581
2013	ZD-Viper (Post-2013)	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2013	ZD-Viper (Post-2013)	OCM	√	√	√	√	√	○	○	0715
2013	ZD-Viper (Post-2013)	BCM	√	√	√	√	√	√	√	1219, 1221, 1224, 1225, 1226, 1235, 0900, 0150, 0452

2013	ZD-Viper (Post-2013)	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2013	ZD-Viper (Post-2013)	ABS	√	√	√	√	√	√	√	
2013	ZD-Viper (Post-2013)	RADIO	√	√	√	√	√	√	√	
2013	ZD-Viper (Post-2013)	AMP	√	√	√	√	√	○	○	0083,0074
2013	ZD-Viper (Post-2013)	DDM	√	√	√	√	√	√	√	
2013	ZD-Viper (Post-2013)	PDM	√	√	√	√	√	√	√	
2013	ZD-Viper (Post-2013)	ADCM	√	√	√	√	√	○	○	
2013	ZD-Viper (Post-2013)	ICS	√	√	√	√	√	√	√	
2013	ZD-Viper (Post-2013)	IPC	√	√	√	√	√	√	√	
2013	ZD-Viper (Post-2013)	HPM	√	√	√	√	√	√	√	0561,0648
2013	ZD-Viper (Post-2013)	SCCM	√	√	√	√	√	○	○	
2013	NY-Ypsilon	ECM	√	√	√	※	√	√	√	
2013	NY-Ypsilon	TCM	√	√	√	○	√	√	√	
2013	NY-Ypsilon	ORC	√	√	√	√	√	√	√	
2013	NY-Ypsilon	HVAC	√	√	√	√	√	√	√	
2013	NY-Ypsilon	BCM	√	√	√	○	√	√	○	
2013	NY-Ypsilon	ABS	√	√	√	√	√	√	√	
2013	NY-Ypsilon	EPS	√	√	√	√	√	○	√	
2013	NY-Ypsilon	IPC	√	√	√	※	√	√	○	0542
2013	NY-Ypsilon	AHM	√	√	√	√	√	√	○	
2013	FF-500	PCM	√	√	√	√	√	√	√	0136
2013	FF-500	TCM	√	√	√	√	√	√	○	0355,0176,0531,0627,0634,0703,0829,0951
2013	FF-500	ESM	√	√	√	○	√	○	○	
2013	FF-500	ORC	√	√	√	√	√	○	√	
2013	FF-500	HVAC	√	√	√	√	√	√	○	
2013	FF-500	BCM	√	√	√	√	√	√	√	
2013	FF-500	PTS	√	√	√	√	√	○	○	
2013	FF-500	TPM	√	√	√	√	√	√	√	
2013	FF-500	ABS	√	√	√	√	√	※	○	0057
2013	FF-500	RADIO	√	√	√	√	√	○	○	
2013	FF-500	BPCM	√	√	√	√	√	√	○	
2013	FF-500	EAC	√	√	√	√	√	○	○	
2013	FF-500	EPS	√	√	√	√	√	○	○	0236,0573
2013	FF-500	IPC	√	√	√	√	√	√	○	0541,0542
2013	FF-500	OBCM	√	√	√	√	√	○	○	
2013	FF-500	CTM	√	√	√	√	√	√	○	
2013	FF-500	VTM	√	√	√	√	√	○	○	
2013	FF-500	RBC	√	√	√	√	√	○	○	0757,0844
2013	FF-500	EVCU	√	√	√	√	√	√	○	0094,0520,0519,0213,0681
2013	FF-500	PIM	√	√	√	√	√	○	○	
2014	JK-Wrangler	PCM	√	√	√	√	√	√	√	1123,0257,0322,0908,0472,0537,0591,0821,0615,1092,0216,0102,0278,0359,0827,1042,1201,0705,0927,0920,0103,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0280
2014	JK-Wrangler	TCM	√	√	√	√	√	○	○	0924,1094
2014	JK-Wrangler	ESM	√	√	√	√	√	√	○	
2014	JK-Wrangler	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152
2014	JK-Wrangler	ORC	√	√	√	√	√	○	√	0098,0581
2014	JK-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186,1014,1023,0187,0210,0619,1015
2014	JK-Wrangler	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2014	JK-Wrangler	ASBS	√	√	√	√	√	○	○	1071,1098,1099,1100,1101
2014	JK-Wrangler	WCM	√	√	√	√	√	○	√	0439
2014	JK-Wrangler	ITM	√	√	√	√	√	√	√	0584,0547,0551,1066,1179
2014	JK-Wrangler	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800
2014	JK-Wrangler	SAS	√	√	√	√	√	○	○	
2014	JK-Wrangler	ABS	√	√	√	√	√	√	√	0056,0168
2014	JK-Wrangler	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0602,0426
2014	JK-Wrangler	AMP	√	√	√	√	√	○	√	0083,0074
2014	JK-Wrangler	HPM	√	√	√	√	√	√	○	0492
2014	JS-Avenger,Sebring,Convertible/Sedan	PCM	√	√	√	√	√	√	√	0002,0003,0019,0020,0035,0036,0050,0102,0278,0359,0827,0838,0835,0971,0972,1042,1141,1142,1201,0705,0695,0696,0733,0927,1108,1109,0920,0103,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0280
2014	JS-Avenger,Sebring,Convertible/Sedan	CGW	√	√	√	√	√	√	√	0108,0119,0465,0508,0510,0527,0560,0424,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0125,0129,0254,0425,0503
2014	JS-Avenger,Sebring,Convertible/Sedan	ORC	√	√	√	√	√	○	√	0098
2014	JS-Avenger,Sebring,Convertible/Sedan	MIC_CCN	√	√	√	√	√	√	√	1014,1184,1186,1023,0150,0152
2014	JS-Avenger,Sebring,Convertible/Sedan	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680,0277
2014	JS-Avenger,Sebring,Convertible/Sedan	WCM	√	√	√	√	√	○	√	0143,0366,0439
2014	JS-Avenger,Sebring,Convertible/Sedan	PTCM	√	√	√	√	√	○	√	0893,0661
2014	JS-Avenger,Sebring,Convertible/Sedan	SAS	√	√	√	√	√	○	○	

2014	JS-Avenger,Sebring,Convertible/Sedan	ABS	√	√	√	√	√	√	√	0168,0056
2014	JS-Avenger,Sebring,Convertible/Sedan	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2014	JS-Avenger,Sebring,Convertible/Sedan	AMP	√	√	√	√	√	○	√	0083,0074
2014	JS-Avenger,Sebring,Convertible/Sedan	HFM	√	√	√	√	√	√	○	0492
2014	JS-Avenger,Sebring,Convertible/Sedan	DDM	√	√	√	√	√	√	○	0319
2014	JS-Avenger,Sebring,Convertible/Sedan	PDM	√	√	√	√	√	√	○	0319
2014	KK-Liberty	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0102,0237,0278,0944,0103,0279,0920,0280
2014	KK-Liberty	TCM	√	√	√	√	√	○	○	0924,1094
2014	KK-Liberty	ESM	√	√	√	√	√	√	○	
2014	KK-Liberty	FDCM	√	√	√	√	√	√	○	0706
2014	KK-Liberty	CGW	√	√	√	√	√	√	√	0108,0119,0155,0465,0508,0510,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152,0402,0812
2014	KK-Liberty	ORC	√	√	√	√	√	○	√	0098
2014	KK-Liberty	MIC_CCN	√	√	√	√	√	√	√	1186,1014,1023,0187,0210,0619,1015
2014	KK-Liberty	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680,0277
2014	KK-Liberty	MSM	√	√	√	√	√	※	※	0112,0222,0381,0603,0658,1083,1150
2014	KK-Liberty	OCM	√	√	√	√	√	○	○	0715
2014	KK-Liberty	WCM	√	√	√	√	√	○	√	0439,0613
2014	KK-Liberty	SUNR	√	√	√	√	√	○	○	
2014	KK-Liberty	PTS	√	√	√	√	√	√	√	0266,1106
2014	KK-Liberty	ITM	√	√	√	√	√	√	√	0555,1066,1178
2014	KK-Liberty	SAS	√	√	√	√	√	○	○	
2014	KK-Liberty	ABS	√	√	√	√	√	√	√	0056,0168
2014	KK-Liberty	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2014	KK-Liberty	AMP	√	√	√	√	√	○	√	0083,0074
2014	KK-Liberty	HFM	√	√	√	√	√	√	○	0492
2014	KK-Liberty	DMFR	√	√	√	√	√	√	○	
2014	KK-Liberty	DMFL	√	√	√	√	√	√	√	
2014	LX-300,Charger,Magnum,Grand Voyager	PCM	√	√	√	√	√	√	√	0257,0216,0133,0312,0616,0821,0952,0932,0948,1034,1148,0102,0278,0359,0827,1042,1201,0705,0927,0920,0103,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0280
2014	LX-300,Charger,Magnum,Grand Voyager	TCM	√	√	√	√	√	○	√	0924,1094,0912
2014	LX-300,Charger,Magnum,Grand Voyager	ESM	√	√	√	√	√	※	○	
2014	LX-300,Charger,Magnum,Grand Voyager	ACC	√	√	√	√	√	○	√	
2014	LX-300,Charger,Magnum,Grand Voyager	ORC	√	√	√	√	√	○	√	0581
2014	LX-300,Charger,Magnum,Grand Voyager	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680
2014	LX-300,Charger,Magnum,Grand Voyager	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2014	LX-300,Charger,Magnum,Grand Voyager	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2014	LX-300,Charger,Magnum,Grand Voyager	PTS	√	√	√	√	√	√	√	0266,1106
2014	LX-300,Charger,Magnum,Grand Voyager	ITM	√	√	√	√	√	√	√	0584,0555,0551,0553,1178
2014	LX-300,Charger,Magnum,Grand Voyager	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2014	LX-300,Charger,Magnum,Grand Voyager	ABS	√	√	√	√	√	√	√	0181,0055,0056
2014	LX-300,Charger,Magnum,Grand Voyager	AMP	√	√	√	√	√	○	○	0083,0074
2014	LX-300,Charger,Magnum,Grand Voyager	HFM	√	√	√	√	√	○	○	0492
2014	LX-300,Charger,Magnum,Grand Voyager	DDM	√	√	√	√	√	√	√	
2014	LX-300,Charger,Magnum,Grand Voyager	PDM	√	√	√	√	√	√	√	
2014	LX-300,Charger,Magnum,Grand Voyager	HSM	√	√	√	√	√	√	√	
2014	LX-300,Charger,Magnum,Grand Voyager	DTCM	√	√	√	√	√	√	○	
2014	LX-300,Charger,Magnum,Grand Voyager	EPS	√	√	√	√	√	○	○	
2014	LX-300,Charger,Magnum,Grand Voyager	ADCM	√	√	√	√	√	○	○	
2014	LX-300,Charger,Magnum,Grand Voyager	AFLS	√	√	√	√	√	√	○	0066
2014	LX-300,Charger,Magnum,Grand Voyager	ICS	√	√	√	√	√	√	○	
2014	LX-300,Charger,Magnum,Grand Voyager	IPC	√	√	√	√	√	√	○	0334
2014	LX-300,Charger,Magnum,Grand Voyager	RFH	√	√	√	√	√	√	√	0561,0338,0648
2014	LX-300,Charger,Magnum,Grand Voyager	SCCM	√	√	√	√	√	○	○	
2014	LX-300,Charger,Magnum,Grand Voyager	TGW	√	√	√	√	√	○	√	0144,1121
2014	LX-300,Charger,Magnum,Grand Voyager	LBSS	√	√	√	○	√	○	○	
2014	LX-300,Charger,Magnum,Grand Voyager	RBSS	√	√	√	○	√	○	○	
2014	MK-Compass,Patriot	PCM	√	√	√	√	√	√	※	0359,0827,1042,1201,0705,0927,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0102,0278,0103,0279,0434,0258,0432,0663,0821,0363,1191,0477,0514,0494,0588,0704,1102,1148,1194,0310,0920,0280
2014	MK-Compass,Patriot	TCM	√	√	√	√	√	√	√	0228
2014	MK-Compass,Patriot	FDCM	√	√	√	√	√	√	√	

2014	MK-Compass,Patriot	CGW	√	√	√	√	√	√	√	0108,0119,0465,0508,0510,0527,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,0095,0129,0125,0425,0402,0810,0816,0817,0752
2014	MK-Compass,Patriot	ORC	√	√	√	√	√	○	√	0098
2014	MK-Compass,Patriot	MIC CCN	√	√	√	√	√	√	√	1014,1184,1186,1023,0150,0152
2014	MK-Compass,Patriot	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2014	MK-Compass,Patriot	BCM	√	√	√	√	√	○	√	0143,0366,0439
2014	MK-Compass,Patriot	ITM	√	√	√	√	√	√	√	0555,1066,1178
2014	MK-Compass,Patriot	SAS	√	√	√	√	√	○	○	
2014	MK-Compass,Patriot	ABS	√	√	√	√	√	√	√	0566,0168,0568,0578,0056
2014	MK-Compass,Patriot	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2014	MK-Compass,Patriot	AMP	√	√	√	√	√	○	√	0083,0074
2014	MK-Compass,Patriot	HFM	√	√	√	√	√	√	○	0492
2014	RT-Caravan,Town & Country	PCM	√	√	√	√	√	√	√	1123,0257,0322,0908,0472,0537,0591,0821,0615,0216,0002,0019,0035,0650,0102,0278,0359,0827,0838,0971,1042,1141,1201,0705,0695,0927,1108,0920,0103,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0280
2014	RT-Caravan,Town & Country	TCM	√	√	√	√	√	√	√	0006,0023,0039,0052,0229,0971,1107
2014	RT-Caravan,Town & Country	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0795,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152
2014	RT-Caravan,Town & Country	ORC	√	√	√	√	√	○	√	0098,0581
2014	RT-Caravan,Town & Country	MIC CCN	√	√	√	√	√	√	√	1186,1014,1023,0187,0210,0619,1015
2014	RT-Caravan,Town & Country	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680,0462,0120,0277,0463,0469
2014	RT-Caravan,Town & Country	PLGM	√	√	√	√	√	√	√	0199,0200,0877
2014	RT-Caravan,Town & Country	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2014	RT-Caravan,Town & Country	FSM	√	√	√	√	√	√	○	0194,0201,1269,1272
2014	RT-Caravan,Town & Country	BCM	√	√	√	√	√	√	√	0143,0366,0613,0439
2014	RT-Caravan,Town & Country	SUNR	√	√	√	√	√	√	○	
2014	RT-Caravan,Town & Country	HIDT	√	√	√	√	√	√	○	0493
2014	RT-Caravan,Town & Country	AHBM	√	√	√	√	√	√	○	0132
2014	RT-Caravan,Town & Country	PTS	√	√	√	√	√	√	√	0266,1106
2014	RT-Caravan,Town & Country	ITM	√	√	√	√	√	√	√	0555,1066,1178
2014	RT-Caravan,Town & Country	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1127
2014	RT-Caravan,Town & Country	SAS	√	√	√	√	√	○	○	
2014	RT-Caravan,Town & Country	ABS	√	√	√	√	√	√	√	0055,0056
2014	RT-Caravan,Town & Country	DVD	√	√	√	√	√	○	○	
2014	RT-Caravan,Town & Country	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2014	RT-Caravan,Town & Country	AMP	√	√	√	√	√	○	√	0083,0074
2014	RT-Caravan,Town & Country	HFM	√	√	√	√	√	√	○	0492
2014	RT-Caravan,Town & Country	VES2	√	√	√	√	√	√	√	
2014	RT-Caravan,Town & Country	VES3	√	√	√	√	√	√	√	
2014	RT-Caravan,Town & Country	DMFR	√	√	√	√	√	√	○	
2014	RT-Caravan,Town & Country	DMFL	√	√	√	√	√	√	√	
2014	RT-Caravan,Town & Country	DMRL	√	√	√	√	√	√	√	0622,0624,0630
2014	RT-Caravan,Town & Country	DMRR	√	√	√	√	√	√	√	0622,0624,0630
2014	RT-Caravan,Town & Country	PSDMR	√	√	√	√	√	○	○	0106,1067,0633,1070,0877
2014	RT-Caravan,Town & Country	PSDML	√	√	√	√	√	○	○	0106,1067,0633,1070,0877
2014	RT-Caravan,Town & Country	HESM	√	√	√	√	√	√	√	0512
2014	RT-Caravan,Town & Country	PEM	√	√	√	√	√	○	√	0338,0609,0648
2014	RT-Caravan,Town & Country	EPPM	√	√	√	√	√	○	√	
2014	RT-Caravan,Town & Country	LBSS	√	√	√	○	√	○	○	
2014	RT-Caravan,Town & Country	RBSS	√	√	√	○	√	○	○	
2014	WK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0278,0359,0827,1042,1201,0705,0927,0103,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0102,0293,0224,1000,0954,0921,0304,0999,1004,1005,1002,1007,1008,0216,0712,0821,0953,0133,0932,0948,1034,1148,0312,0920,0280
2014	WK-Grand Cherokee	TCM	√	√	√	√	√	○	√	0912
2014	WK-Grand Cherokee	ESM	√	√	√	√	√	○	○	
2014	WK-Grand Cherokee	ACC	√	√	√	√	√	○	○	0061
2014	WK-Grand Cherokee	ORC	√	√	√	√	√	○	√	0098,0581
2014	WK-Grand Cherokee	HVAC	√	√	√	√	√	√	○	0498,0680,0121
2014	WK-Grand Cherokee	PLGM	√	√	√	√	√	√	○	
2014	WK-Grand Cherokee	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2014	WK-Grand Cherokee	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2014	WK-Grand Cherokee	PTS	√	√	√	√	√	√	√	0266,1106
2014	WK-Grand Cherokee	ITM	√	√	√	√	√	√	√	0584,0555,0551,0553,1178
2014	WK-Grand Cherokee	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2014	WK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0181,0055,0056
2014	WK-Grand Cherokee	RADIO	√	√	√	√	√	√	√	

2014	WK-Grand Cherokee	AMP	√	√	√	√	√	○	○	0083,0074
2014	WK-Grand Cherokee	VES2	√	√	√	√	√	√	○	
2014	WK-Grand Cherokee	VES3	√	√	√	√	√	√	○	
2014	WK-Grand Cherokee	DDM	√	√	√	√	√	√	√	
2014	WK-Grand Cherokee	PDM	√	√	√	√	√	√	√	
2014	WK-Grand Cherokee	HSM	√	√	√	√	√	√	√	
2014	WK-Grand Cherokee	DTCM	√	√	√	√	√	√	√	
2014	WK-Grand Cherokee	EPS	√	√	√	√	√	○	○	
2014	WK-Grand Cherokee	ADCM	√	√	√	√	√	○	○	
2014	WK-Grand Cherokee	AFLS	√	√	√	√	√	○	√	0066
2014	WK-Grand Cherokee	ASCM	√	√	√	√	√	○	√	0134,1081,1082,0330,0459,1056,0513,0256
2014	WK-Grand Cherokee	ELSD	√	√	√	○	√	√	○	0364,1104
2014	WK-Grand Cherokee	ICS	√	√	√	√	√	○	○	
2014	WK-Grand Cherokee	IPC	√	√	√	√	√	√	√	0428
2014	WK-Grand Cherokee	RFH	√	√	√	√	√	√	√	0561,0338,0648
2014	WK-Grand Cherokee	SCCM	√	√	√	√	√	○	√	
2014	WK-Grand Cherokee	TPCM	○	○	○	○	○	○	○	
2014	WK-Grand Cherokee	LBSS	√	√	√	○	√	○	○	
2014	WK-Grand Cherokee	RBSS	√	√	√	○	√	○	○	
2014	WK-Grand Cherokee	EDM	√	√	√	○	√	√	○	
2014	D2-Ram Truck	PCM	√	√	√	√	√	√	√	0004,0021,0037,0102,0278,0359,0827,0840,0973,1042,1143,1201,0705,0734,0927,0103,0188,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0141,0225,0280,0435,0436,0664,0920,1044,1045,0558,0311,0842,1176,0142,0299,0303,0344,0345,0438,0204
2014	D2-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2014	D2-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2014	D2-Ram Truck	HVAC	√	√	√	√	√	√	√	0498,0461,0680,0121
2014	D2-Ram Truck	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2014	D2-Ram Truck	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150,0892
2014	D2-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2014	D2-Ram Truck	ABS	√	√	√	√	√	√	√	0181,0055,0056
2014	D2-Ram Truck	RADIO	√	√	√	√	√	√	√	
2014	D2-Ram Truck	AMP	√	√	√	√	√	○	○	0083,0074
2014	D2-Ram Truck	DDM	√	√	√	√	√	√	√	
2014	D2-Ram Truck	PDM	√	√	√	√	√	√	√	
2014	D2-Ram Truck	HSM	√	√	√	√	√	√	√	
2014	D2-Ram Truck	DTCM	√	√	√	√	√	√	√	
2014	D2-Ram Truck	ITBM	√	√	√	√	√	○	○	
2014	D2-Ram Truck	ASCM	√	√	√	√	√	○	√	0513,1081,0459,1056,0256
2014	D2-Ram Truck	DCU	√	√	√	○	√	○	○	
2014	D2-Ram Truck	ICS	√	√	√	√	√	√	√	
2014	D2-Ram Truck	IPC	√	√	√	○	√	√	√	0334,0467
2014	D2-Ram Truck	RFH	√	√	√	√	√	√	√	0609,0338,0648
2014	D2-Ram Truck	SCCM	√	√	√	√	√	○	○	
2014	D2-Ram Truck	VSIM	√	√	√	○	√	√	○	
2014	D2-Ram Truck	VGT	√	√	√	○	√	○	○	
2014	D2-Ram Truck	EDM	√	√	√	○	√	√	○	
2014	DJ-Ram Truck	PCM	√	√	√	√	√	√	√	0004,0021,0037,0102,0278,0359,0827,0840,0973,1042,1143,1201,0705,0734,0927,0664,0920,0103,0188,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0141,0225,0280,0435,0436,1044,1045,0558,0311,0842,1176,0142,0299,0303,0344,0345,0438,0204
2014	DJ-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2014	DJ-Ram Truck	FDCM	√	√	√	√	√	○	○	
2014	DJ-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2014	DJ-Ram Truck	HVAC	√	√	√	√	√	√	√	0498,0461,0680,0121
2014	DJ-Ram Truck	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2014	DJ-Ram Truck	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150,0892
2014	DJ-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2014	DJ-Ram Truck	ABS	√	√	√	√	√	√	√	0181,0055,0056
2014	DJ-Ram Truck	RADIO	√	√	√	√	√	√	√	
2014	DJ-Ram Truck	AMP	√	√	√	√	√	○	○	0083,0074
2014	DJ-Ram Truck	DDM	√	√	√	√	√	√	√	
2014	DJ-Ram Truck	PDM	√	√	√	√	√	√	√	
2014	DJ-Ram Truck	HSM	√	√	√	√	√	√	√	
2014	DJ-Ram Truck	DTCM	√	√	√	√	√	√	√	
2014	DJ-Ram Truck	ITBM	√	√	√	√	√	○	○	
2014	DJ-Ram Truck	ASCM	√	√	√	√	√	○	√	0513,1081,0459,1056,0256
2014	DJ-Ram Truck	DCU	√	√	√	○	√	○	○	
2014	DJ-Ram Truck	ICS	√	√	√	√	√	√	√	
2014	DJ-Ram Truck	IPC	√	√	√	○	√	√	√	0334,0467

2014	DJ-Ram Truck	RFH	√	√	√	√	√	√	√	0609, 0338, 0648
2014	DJ-Ram Truck	SCCM	√	√	√	√	√	○	○	
2014	DJ-Ram Truck	VSIM	√	√	√	○	√	√	○	
2014	DJ-Ram Truck	VGT	√	√	√	○	√	○	○	
2014	DJ-Ram Truck	EDM	√	√	√	○	√	√	○	
2014	DS-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0278, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 0358, 0224, 1005, 1002, 1007, 1008, 0216, 0312, 0822, 0712, 0133, 0932, 0948, 1034, 1148, 0101, 0293, 1000, 0954, 0921, 0304, 0999, 1004, 0953, 0664
2014	DS-Ram Truck	TCM	√	√	√	√	√	○	√	0912
2014	DS-Ram Truck	ESM	√	√	√	√	√	○	○	
2014	DS-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2014	DS-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2014	DS-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2014	DS-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2014	DS-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2014	DS-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2014	DS-Ram Truck	RADIO	√	√	√	√	√	√	√	
2014	DS-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2014	DS-Ram Truck	DDM	√	√	√	√	√	√	√	
2014	DS-Ram Truck	PDM	√	√	√	√	√	√	√	
2014	DS-Ram Truck	HSM	√	√	√	√	√	√	√	
2014	DS-Ram Truck	DTCM	√	√	√	√	√	√	√	
2014	DS-Ram Truck	EPS	√	√	√	√	√	○	○	0236
2014	DS-Ram Truck	ITBM	√	√	√	√	√	○	○	
2014	DS-Ram Truck	ASCM	√	√	√	√	√	○	√	0134, 1081, 1082, 0330, 0459, 1056, 0513, 0256
2014	DS-Ram Truck	ICS	√	√	√	√	√	√	√	
2014	DS-Ram Truck	IPC	√	√	√	○	√	√	√	0334
2014	DS-Ram Truck	RFH	√	√	√	√	√	√	√	0609, 0338, 0648
2014	DS-Ram Truck	SCCM	√	√	√	√	√	○	○	
2014	DS-Ram Truck	EDM	√	√	√	○	√	√	○	
2014	DX-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0278, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 1044, 1045, 0558, 0722, 1050, 0311, 0842, 1176, 0756, 0142, 0299, 0303, 0344, 0345, 0397, 0438, 0395, 0204, 0664
2014	DX-Ram Truck	TCM	√	√	√	√	√	※	√	0829, 0912
2014	DX-Ram Truck	ESM	√	√	√	√	√	○	○	
2014	DX-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2014	DX-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2014	DX-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2014	DX-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2014	DX-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2014	DX-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2014	DX-Ram Truck	RADIO	√	√	√	√	√	√	√	
2014	DX-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2014	DX-Ram Truck	DDM	√	√	√	√	√	√	√	
2014	DX-Ram Truck	PDM	√	√	√	√	√	√	√	
2014	DX-Ram Truck	HSM	√	√	√	√	√	√	√	
2014	DX-Ram Truck	DTCM	√	√	√	√	√	√	√	
2014	DX-Ram Truck	EPS	√	√	√	√	√	○	○	0236
2014	DX-Ram Truck	ITBM	√	√	√	√	√	○	○	
2014	DX-Ram Truck	ASCM	√	√	√	√	√	○	√	0134, 1081, 1082, 0330, 0459, 1056, 0513, 0256
2014	DX-Ram Truck	DCU	√	√	√	○	√	○	○	
2014	DX-Ram Truck	ICS	√	√	√	√	√	√	√	
2014	DX-Ram Truck	IPC	√	√	√	○	√	√	√	0334
2014	DX-Ram Truck	RFH	√	√	√	√	√	√	√	0609, 0338, 0648
2014	DX-Ram Truck	SCCM	√	√	√	√	√	○	○	
2014	DX-Ram Truck	VSIM	√	√	√	○	√	√	○	
2014	DX-Ram Truck	VGT	√	√	√	○	√	○	○	
2014	DX-Ram Truck	EDM	√	√	√	○	√	√	○	
2014	JS-Wrangler	PCM	√	√	√	√	√	√	√	1123, 0257, 0322, 0908, 0472, 0637, 0591, 0821, 0615, 1092, 0216
2014	JS-Wrangler	TCM	√	√	√	√	√	○	○	0924, 1094
2014	JS-Wrangler	ESM	√	√	√	√	√	√	○	
2014	JS-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0096, 1182, 1220, 0150, 0152
2014	JS-Wrangler	ORC	√	√	√	√	√	○	√	0098, 0581

2014	JS-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2014	JS-Wrangler	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2014	JS-Wrangler	WCM	√	√	√	√	√	○	√	0439
2014	JS-Wrangler	SAS	√	√	√	√	√	○	○	
2014	JS-Wrangler	ABS	√	√	√	√	√	√	√	0056, 0168
2014	JS-Wrangler	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2014	JC-Journey	PCM	√	√	√	√	√	√	√	0002, 0003, 0019, 0020, 0035, 0036, 0050, 0359, 0827, 0838, 0835, 0971, 0972, 1042, 1141, 1142, 1201, 0705, 0695, 0896, 0733, 0927, 1108, 1109, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0257, 0216, 0821, 0133, 0312, 0616, 0952, 0932, 0948, 1034, 1148, 0102, 0237, 0278, 0944, 1271, 0103, 0279, 0920, 0280
2014	JC-Journey	TCM	√	√	√	√	√	√	√	0006, 0023, 0039, 0052, 0229, 0971, 1107
2014	JC-Journey	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2014	JC-Journey	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2014	JC-Journey	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2014	JC-Journey	PTS	√	√	√	√	√	√	√	0266, 1106
2014	JC-Journey	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2014	JC-Journey	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2014	JC-Journey	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2014	JC-Journey	AMP	√	√	√	√	√	○	○	0083, 0074
2014	JC-Journey	HFM	√	√	√	√	√	○	○	0492
2014	JC-Journey	VES3	√	√	√	√	√	√	○	
2014	JC-Journey	DDM	√	√	√	√	√	√	√	
2014	JC-Journey	PDM	√	√	√	√	√	√	√	
2014	JC-Journey	HSM	√	√	√	√	√	√	√	
2014	JC-Journey	DTCM	√	√	√	√	√	√	√	
2014	JC-Journey	EPPM	√	√	√	√	√	○	√	
2014	JC-Journey	LCS	√	√	√	√	√	√	○	
2014	JC-Journey	IPC	√	√	√	√	√	√	○	
2014	JC-Journey	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2014	JC-Journey	SCCM	√	√	√	√	√	○	○	
2014	JC-Journey	TGW	√	√	√	√	√	○	√	0144, 1121
2014	JC-Journey	VTM	√	√	√	√	√	○	○	
2014	LC-Challenger	PCM	√	√	√	√	√	√	√	0102, 0278, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0279, 0202, 0215, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0280
2014	LC-Challenger	TCM	√	√	√	√	√	○	○	0924, 1094
2014	LC-Challenger	ESM	√	√	√	√	√	√	○	
2014	LC-Challenger	CGW	√	√	√	√	√	√	√	0155, 0331, 0465, 0508, 0510, 0560, 1226, 0900, 1076, 1155, 1189, 0095, 1219, 1224, 1225
2014	LC-Challenger	ORC	√	√	√	√	√	○	√	0581
2014	LC-Challenger	MIC_CCN	√	√	√	√	√	√	√	0209, 1186, 1014, 1184, 0150, 0152
2014	LC-Challenger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2014	LC-Challenger	WCM	√	√	√	√	√	√	√	0143, 0613, 0439
2014	LC-Challenger	SUNR	√	√	√	○	√	√	○	
2014	LC-Challenger	PTS	√	√	√	√	√	○	√	1106
2014	LC-Challenger	EDM	√	√	√	√	√	○	√	1023
2014	LC-Challenger	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2014	LC-Challenger	SAS	√	√	√	√	√	√	○	
2014	LC-Challenger	ABS	√	√	√	√	√	√	√	0055, 0056
2014	LC-Challenger	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2014	LC-Challenger	AMP	√	√	√	√	√	○	※	0083, 0074
2014	LC-Challenger	HFM	√	√	√	√	√	√	○	0492
2014	LC-Challenger	DDM	√	√	√	√	√	√	○	0319
2014	LC-Challenger	PDM	√	√	√	√	√	√	○	0319
2014	LC-Challenger	HSM	√	√	√	√	√	√	√	
2014	LC-Challenger	EPS	√	√	√	√	√	○	○	
2014	LC-Challenger	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2014	LC-Challenger	ADCM	√	√	√	√	√	○	○	
2014	RM-	PCM	√	√	√	√	√	√	√	0002, 0019, 0035, 0050, 0102, 0278, 0359, 0827, 0838, 0971, 1042, 1141, 1201, 0705, 0695, 0927, 1108, 0920, 0103, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0280
2014	RM-	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152
2014	RM-	ORC	√	√	√	√	√	○	√	0098, 0581
2014	RM-	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2014	RM-	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680, 0462, 0277
2014	RM-	PLGM	√	√	√	√	√	√	√	0199, 0200, 0877
2014	RM-	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150

2014	RM-	PSM	√	√	√	√	√	√	○	0194, 0201, 1269, 1272
2014	RM-	WCM	√	√	√	√	√	√	√	0143, 0366, 0613, 0439
2014	RM-	SUNR	√	√	√	√	√	√	○	
2014	RM-	PTS	√	√	√	√	√	√	√	0266, 1106
2014	RM-	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1127
2014	RM-	SAS	√	√	√	√	√	○	○	
2014	RM-	ABS	√	√	√	√	√	√	√	0055, 0056
2014	RM-	DVD	√	√	√	√	√	○	○	
2014	RM-	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2014	RM-	AMP	√	√	√	√	√	○	√	0083, 0074
2014	RM-	HPM	√	√	√	√	√	√	○	0492
2014	RM-	VES2	√	√	√	√	√	√	√	
2014	RM-	VES3	√	√	√	√	√	√	√	
2014	RM-	DMFR	√	√	√	√	√	√	○	
2014	RM-	DMFL	√	√	√	√	√	√	√	
2014	RM-	DMRL	√	√	√	√	√	√	√	0622, 0624, 0630
2014	RM-	DMRR	√	√	√	√	√	√	√	0622, 0624, 0630
2014	RM-	PSDMR	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2014	RM-	PSDML	√	√	√	√	√	○	○	0106, 1067, 0633, 1070, 0877
2014	RM-	HSM	√	√	√	√	√	√	√	0512
2014	RM-	PEM	√	√	√	√	√	○	√	0338, 0609, 0648
2014	RM-	LBSS	√	√	√	○	√	○	○	
2014	RM-	RBSS	√	√	√	○	√	○	○	
2014	DD-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0278, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0664, 0920, 0103, 0188, 0279, 0202, 0215, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 1044, 1045, 0558, 0722, 1050, 0311, 1176, 0756, 0142, 0299, 0303, 0344, 0345, 0397, 0438, 0395, 0204
2014	DD-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2014	DD-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2014	DD-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2014	DD-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2014	DD-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2014	DD-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2014	DD-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2014	DD-Ram Truck	RADIO	√	√	√	√	√	√	√	
2014	DD-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2014	DD-Ram Truck	DDM	√	√	√	√	√	√	√	
2014	DD-Ram Truck	PDM	√	√	√	√	√	√	√	
2014	DD-Ram Truck	HSM	√	√	√	√	√	√	√	
2014	DD-Ram Truck	DTCM	√	√	√	√	√	√	√	
2014	DD-Ram Truck	ITBM	√	√	√	√	√	○	○	
2014	DD-Ram Truck	DCU	√	√	√	○	√	○	○	
2014	DD-Ram Truck	ICS	√	√	√	√	√	√	√	
2014	DD-Ram Truck	IPC	√	√	√	○	√	√	√	0334, 0467
2014	DD-Ram Truck	RPH	√	√	√	√	√	√	√	0609, 0338, 0648
2014	DD-Ram Truck	SCCM	√	√	√	√	√	○	○	
2014	DD-Ram Truck	VSIM	√	√	√	○	√	√	○	
2014	DD-Ram Truck	VGT	√	√	√	○	√	○	○	
2014	DD-Ram Truck	EDM	√	√	√	○	√	√	○	
2014	DP-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0278, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0664, 0920, 0103, 0188, 0279, 0202, 0215, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 1044, 1045, 0558, 0722, 1050, 0311, 1176, 0756, 0142, 0299, 0303, 0344, 0345, 0397, 0438, 0395, 0204
2014	DP-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2014	DP-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2014	DP-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2014	DP-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2014	DP-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2014	DP-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2014	DP-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2014	DP-Ram Truck	RADIO	√	√	√	√	√	√	√	
2014	DP-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2014	DP-Ram Truck	DDM	√	√	√	√	√	√	√	
2014	DP-Ram Truck	PDM	√	√	√	√	√	√	√	
2014	DP-Ram Truck	HSM	√	√	√	√	√	√	√	
2014	DP-Ram Truck	DTCM	√	√	√	√	√	√	√	
2014	DP-Ram Truck	ITBM	√	√	√	√	√	○	○	
2014	DP-Ram Truck	DCU	√	√	√	○	√	○	○	
2014	DP-Ram Truck	ICS	√	√	√	√	√	√	√	

2014	DP-Ram Truck	IPC	√	√	√	○	√	√	√	0334,0467
2014	DP-Ram Truck	RFH	√	√	√	√	√	√	√	0609,0338,0648
2014	DP-Ram Truck	SCCM	√	√	√	√	√	○	○	
2014	DP-Ram Truck	VSIM	√	√	√	○	√	√	○	
2014	DP-Ram Truck	VGT	√	√	√	○	√	○	○	
2014	DP-Ram Truck	EDM	√	√	√	○	√	√	○	
2014	JF-Freemont	PCM	√	√	√	√	√	√	√	0002,0003,0019,0020,0035,0036,0050,0359,0827,0838,0835,0971,0972,1042,1141,1142,1201,0705,0695,0696,0733,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0257,0216,0821,0133,0312,0616,0952,0932,0948,1034,1148,0102,0237,0278,0944,1271,0103,0279,0920,0280
2014	JF-Freemont	TCM	√	√	√	√	√	√	√	0006,0023,0039,0052,0229,0971,1107
2014	JF-Freemont	ORC	√	√	√	√	√	○	√	0098,0581,0990
2014	JF-Freemont	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680
2014	JF-Freemont	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2014	JF-Freemont	PTS	√	√	√	√	√	√	√	0266,1106
2014	JF-Freemont	ITM	√	√	√	√	√	√	√	0584,0555,0551,0553,1178
2014	JF-Freemont	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2014	JF-Freemont	ABS	√	√	√	√	√	√	√	0181,0055,0056
2014	JF-Freemont	AMP	√	√	√	√	√	○	○	0083,0074
2014	JF-Freemont	HFM	√	√	√	√	√	○	○	0492
2014	JF-Freemont	VES3	√	√	√	√	√	√	○	
2014	JF-Freemont	DDM	√	√	√	√	√	√	√	
2014	JF-Freemont	PDM	√	√	√	√	√	√	√	
2014	JF-Freemont	HSM	√	√	√	√	√	√	√	
2014	JF-Freemont	DTCM	√	√	√	√	√	√	√	
2014	JF-Freemont	EPPM	√	√	√	√	√	○	√	
2014	JF-Freemont	LCS	√	√	√	√	√	√	○	
2014	JF-Freemont	IPC	√	√	√	√	√	√	○	
2014	JF-Freemont	RFH	√	√	√	√	√	√	√	0561,0338,0648
2014	JF-Freemont	SCCM	√	√	√	√	√	○	○	
2014	JF-Freemont	TGW	√	√	√	√	√	○	√	0144,1121
2014	JF-Freemont	VTM	√	√	√	√	√	○	○	
2014	LD-Charger	PCM	√	√	√	√	√	√	√	0102,0278,0359,0827,1042,1201,0705,0927,0920,0103,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0280
2014	**LD-Charger**	**TCM**	**√**	**√**	**√**	**√**	**√**	**○**	**√**	**0924,1094,0912**
2014	LD-Charger	ESM	√	√	√	√	√	※	○	
2014	LD-Charger	ACC	√	√	√	√	√	○	√	
2014	LD-Charger	ORC	√	√	√	√	√	○	√	0581
2014	LD-Charger	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680
2014	LD-Charger	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2014	LD-Charger	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2014	LD-Charger	PTS	√	√	√	√	√	√	√	0266,1106
2014	LD-Charger	ITM	√	√	√	√	√	√	√	0584,0555,0551,0553,1178
2014	LD-Charger	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2014	LD-Charger	ABS	√	√	√	√	√	√	√	0181,0055,0056
2014	LD-Charger	AMP	√	√	√	√	√	○	○	0083,0074
2014	LD-Charger	HFM	√	√	√	√	√	○	○	0492
2014	LD-Charger	DDM	√	√	√	√	√	√	√	
2014	LD-Charger	PDM	√	√	√	√	√	√	√	
2014	LD-Charger	HSM	√	√	√	√	√	√	√	
2014	LD-Charger	DTCM	√	√	√	√	√	√	○	
2014	LD-Charger	EPS	√	√	√	√	√	○	○	
2014	LD-Charger	ADCM	√	√	√	√	√	○	○	
2014	LD-Charger	ICS	√	√	√	√	√	√	○	
2014	LD-Charger	IPC	√	√	√	√	√	√	○	0334
2014	LD-Charger	RFH	√	√	√	√	√	√	√	0561,0338,0648
2014	LD-Charger	SCCM	√	√	√	√	√	○	○	
2014	LD-Charger	TGW	√	√	√	√	√	○	√	0144,1121
2014	LD-Charger	VSIM	√	√	√	○	√	√	√	
2014	LD-Charger	LBSS	√	√	√	○	√	○	○	
2014	LD-Charger	RBSS	√	√	√	○	√	○	○	
2014	WD-Durango	PCM	√	√	√	√	√	√	√	0102,0278,0359,0827,1042,1201,0705,0927,0920,0103,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0280
2014	WD-Durango	TCM	√	√	√	√	√	○	√	0912
2014	WD-Durango	ESM	√	√	√	√	√	○	○	
2014	WD-Durango	ACC	√	√	√	√	√	○	○	0061
2014	WD-Durango	ORC	√	√	√	√	√	○	√	0581,0098
2014	WD-Durango	HVAC	√	√	√	√	√	√	○	0498,0680,0121
2014	WD-Durango	PLGM	√	√	√	√	√	√	○	

2014	WD-Durango	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2014	WD-Durango	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2014	WD-Durango	AHLM	√	√	√	√	√	○	○	0193
2014	WD-Durango	PTS	√	√	√	√	√	√	√	0266, 1106
2014	WD-Durango	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2014	WD-Durango	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2014	WD-Durango	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2014	WD-Durango	RADIO	√	√	√	√	√	√	√	
2014	WD-Durango	AMP	√	√	√	√	√	○	○	0083, 0074
2014	WD-Durango	VES2	√	√	√	√	√	√	○	
2014	WD-Durango	VES3	√	√	√	√	√	√	○	
2014	WD-Durango	DDM	√	√	√	√	√	√	√	
2014	WD-Durango	PDM	√	√	√	√	√	√	√	
2014	WD-Durango	HSM	√	√	√	√	√	√	√	
2014	WD-Durango	DTCM	√	√	√	√	√	√	√	
2014	WD-Durango	EPS	√	√	√	√	√	○	○	0236
2014	WD-Durango	ELSD	√	√	√	○	√	√	○	0364, 1104
2014	WD-Durango	ICS	√	√	√	√	√	○	○	
2014	WD-Durango	IPC	√	√	√	√	√	√	√	0428
2014	WD-Durango	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2014	WD-Durango	SCCM	√	√	√	√	√	○	√	
2014	WD-Durango	FFCM	○	○	○	○	○	○	○	
2014	WD-Durango	HVACR	√	√	√	√	√	√	√	0121
2014	WD-Durango	LBSS	√	√	√	○	√	○	○	
2014	WD-Durango	RBSS	√	√	√	○	√	○	○	
2014	WD-Durango	EDM	√	√	√	○	√	√	○	
2014	PF-Dart	PCM	√	√	√	√	√	√	√	0102, 0237, 0278, 0944, 0359, 0827, 1042, 0927, 0920, 0103, 0279, 0202, 0215, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0280, 0225, 0909, 0137, 0183, 0231, 1145, 0216
2014	PF-Dart	TCM	√	√	√	√	√	√	√	0176, 0531, 0627, 0703, 0951, 0829, 0228
2014	PF-Dart	ESM	√	√	√	√	√	○	√	
2014	PF-Dart	ORC	√	√	√	√	√	○	√	0581
2014	PF-Dart	HVAC	√	√	√	√	√	√	√	0121, 0462, 0680
2014	PF-Dart	OCM	√	√	√	√	√	○	√	0715
2014	PF-Dart	BCM	√	√	√	√	√	√	√	1219, 1221, 1224, 1225, 1226, 1235, 0150, 0152, 0095, 0400, 0155, 0452, 0424, 0465, 0506, 0510, 0559, 1076, 1077, 0255, 0422, 1138
2014	PF-Dart	PAM	√	√	√	√	√	○	○	
2014	PF-Dart	ABS	√	√	√	√	√	○	√	0181, 0653, 1089, 0059
2014	PF-Dart	RADIO	※	※	※	※	※	※	※	
2014	PF-Dart	AMP	√	√	√	√	√	○	○	
2014	PF-Dart	EPS	√	√	√	√	√	○	○	
2014	PF-Dart	ICS	√	√	√	√	√	√	○	
2014	PF-Dart	IPC	√	√	√	√	√	√	√	
2014	PF-Dart	RFH	√	√	√	√	√	√	√	0338, 0561, 0609, 0648
2014	PF-Dart	SCCM	√	√	√	√	√	○	○	
2014	PF-Dart	CSWM	√	√	√	√	√	√	√	
2014	PF-Dart	CTM	√	√	√	√	√	○	○	
2014	PF-Dart	LBSS	√	√	√	○	√	√	√	
2014	PF-Dart	RBSS	√	√	√	○	√	√	√	
2014	PF-Dart	EDM	√	√	√	○	√	√	○	
2014	BK-Forza	ORC	√	√	√	√	√	√	○	
2014	BK-Forza	IPC	√	√	√	√	√	√	○	
2014	ZD-Viper (Post-2013)	PCM	√	√	√	√	√	√	○	0826, 0927, 1146, 0215, 0628, 0377, 0590, 0625, 0626, 0631
2014	ZD-Viper (Post-2013)	ORC	√	√	√	√	√	√	√	0581
2014	ZD-Viper (Post-2013)	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2014	ZD-Viper (Post-2013)	OCM	√	√	√	√	√	○	○	0715
2014	ZD-Viper (Post-2013)	BCM	√	√	√	√	√	√	√	1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2014	ZD-Viper (Post-2013)	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2014	ZD-Viper (Post-2013)	ABS	√	√	√	√	√	√	√	
2014	ZD-Viper (Post-2013)	RADIO	√	√	√	√	√	√	√	
2014	ZD-Viper (Post-2013)	AMP	√	√	√	√	√	○	○	0083, 0074
2014	ZD-Viper (Post-2013)	DDM	√	√	√	√	√	√	√	
2014	ZD-Viper (Post-2013)	PDM	√	√	√	√	√	√	√	
2014	ZD-Viper (Post-2013)	ADCM	√	√	√	√	√	○	○	
2014	ZD-Viper (Post-2013)	ICS	√	√	√	√	√	√	√	
2014	ZD-Viper (Post-2013)	IPC	√	√	√	√	√	√	√	
2014	ZD-Viper (Post-2013)	RFH	√	√	√	√	√	√	√	0561, 0648
2014	ZD-Viper (Post-2013)	SCCM	√	√	√	√	√	○	○	
2014	BF-Fiat 500L	PCM	√	√	√	√	√	√	√	0136
2014	BF-Fiat 500L	TCM	√	√	√	√	√	√	※	0531, 0176, 0627, 0703, 0829, 0951
2014	BF-Fiat 500L	ESM	√	√	√	√	√	√	√	
2014	BF-Fiat 500L	ORC	√	√	√	√	√	○	√	
2014	BF-Fiat 500L	HVAC	※	√	√	√	√	√	○	

2014	BF-Fiat 500L	BCM	√	√	√	√	√	√	√	0411,0264
2014	BF-Fiat 500L	PAM	√	√	√	√	√	○	○	
2014	BF-Fiat 500L	TPM	√	√	√	√	√	√	√	
2014	BF-Fiat 500L	ABS	√	√	√	√	√	○	√	
2014	BF-Fiat 500L	EPS	√	√	√	√	√	○	○	
2014	BF-Fiat 500L	IPC	√	√	√	√	√	√	○	
2014	BF-Fiat 500L	ETM	√	√	√	√	√	○	√	
2014	KL-Cherokee	PCM	√	√	√	√	√	√	√	0102,0237,0278,0944,0359,0827,1042,0927,0920,0103,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0280,0225,0216,0353,0569,0591,0616,0701,0952,0948,1034,0312
2014	KL-Cherokee	TCM	√	√	√	√	√	○	√	0912,1119
2014	KL-Cherokee	ESM	√	√	√	√	√	○	○	
2014	KL-Cherokee	ACC	√	√	√	√	√	○	√	0061
2014	KL-Cherokee	ORC	√	√	√	√	√	√	√	0581
2014	KL-Cherokee	HVAC	√	√	√	√	√	√	√	0121,0462,0680
2014	KL-Cherokee	PLGM	√	√	√	√	√	√	○	
2014	KL-Cherokee	MSM	√	√	√	√	√	○	○	
2014	KL-Cherokee	OCM	√	√	√	√	√	○	√	0715
2014	KL-Cherokee	BCM	√	√	√	√	√	√	√	0095,0400,0155,0452,0424,0417,0465,0506,0510,0559,0422,1076,1077,1219,1221,1224,1225,1226,1235,1138,0150,0152
2014	KL-Cherokee	AHLM	√	√	√	√	√	○	○	0193
2014	KL-Cherokee	PAM	√	√	√	√	√	√	√	
2014	KL-Cherokee	ABS	√	√	√	√	√	○	√	0653,0055
2014	KL-Cherokee	RADIO	√	√	√	√	√	√	√	
2014	KL-Cherokee	AMP	√	√	√	√	√	○	○	
2014	KL-Cherokee	DDM	√	√	√	√	√	√	√	
2014	KL-Cherokee	PDM	√	√	√	√	√	√	√	
2014	KL-Cherokee	DTCM	√	√	√	√	√	√	√	
2014	KL-Cherokee	EPS	√	√	√	√	√	○	○	
2014	KL-Cherokee	ICS	√	√	√	√	√	√	√	
2014	KL-Cherokee	IPC	√	√	√	√	√	√	○	
2014	KL-Cherokee	RFH	√	√	√	√	√	√	√	0338,0609,0648
2014	KL-Cherokee	SCCM	√	√	√	√	√	√	○	
2014	KL-Cherokee	CSWM	√	√	√	√	√	√	√	
2014	KL-Cherokee	EPB	√	√	√	√	√	○	√	1136
2014	KL-Cherokee	ESL	√	√	√	√	√	○	√	
2014	KL-Cherokee	FPCM	※	※	※	※	※	○	※	
2014	KL-Cherokee	LBSS	√	√	√	○	√	○	√	
2014	KL-Cherokee	PTU	√	√	√	○	√	○	○	0934
2014	KL-Cherokee	RBSS	√	√	√	○	√	○	√	
2014	KL-Cherokee	RDM	√	√	√	○	√	○	○	0937
2014	KL-Cherokee	SDM	√	√	√	○	√	√	○	
2014	YF-ProMaster	PCM	√	√	√	√	√	√	√	0002,0019,0035,0050,0102,0278,0359,0827,0838,0971,1042,1141,0695,0927,1108,0920,0103,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0141,0225,0280,0435,0436,0517,0664,0247,0353,0569,0591,0712,0309,0953,1001,0998,1004,1006,1007,1008,1079,1034
2014	YF-ProMaster	TCM	√	√	√	√	√	√	√	0355,0176,0531,0627,0703,0829,0951
2014	YF-ProMaster	ORC	√	√	√	√	√	○	√	
2014	YF-ProMaster	HVAC	√	√	√	√	√	√	○	
2014	YF-ProMaster	BCM	√	√	√	√	√	√	√	0452,0413,0412
2014	YF-ProMaster	PAM	√	√	√	√	√	○	○	
2014	YF-ProMaster	TPM	√	√	√	√	√	√	√	
2014	YF-ProMaster	ABS	√	√	√	√	√	○	√	
2014	YF-ProMaster	IPC	√	√	√	√	√	√	○	
2014	YF-ProMaster	ETM	√	√	√	√	√	○	√	
2014	NY-Ypsilon	ECM	√	√	√	※	√	√	√	
2014	NY-Ypsilon	TCM	√	√	√	○	√	√	√	
2014	NY-Ypsilon	ORC	√	√	√	√	√	√	√	
2014	NY-Ypsilon	HVAC	√	√	√	√	√	√	√	
2014	NY-Ypsilon	BCM	√	√	√	○	√	√	○	
2014	NY-Ypsilon	ABS	√	√	√	√	√	√	√	
2014	NY-Ypsilon	EPS	√	√	√	√	√	○	√	
2014	NY-Ypsilon	IPC	√	√	√	※	√	√	○	0542
2014	NY-Ypsilon	AHM	√	√	√	√	√	√	○	
2014	FF-500	PCM	√	√	√	√	√	√	√	0136
2014	FF-500	TCM	√	√	√	√	√	√	○	0355,0176,0531,0627,0634,0703,0829,0951
2014	FF-500	ESM	√	√	√	○	√	○	○	
2014	FF-500	ORC	√	√	√	√	√	○	√	
2014	FF-500	HVAC	√	√	√	√	√	√	○	
2014	FF-500	BCM	√	√	√	√	√	√	√	
2014	FF-500	PTS	√	√	√	√	√	○	○	

2014	FF-500	TPM	√	√	√	√	√	√	√	
2014	FF-500	ABS	√	√	√	√	√	※	○	0057
2014	FF-500	RADIO	√	√	√	√	√	○	○	
2014	FF-500	BPCM	√	√	√	√	√	√	○	
2014	FF-500	EAC	√	√	√	√	√	○	○	
2014	FF-500	EPS	√	√	√	√	√	○	○	0236,0573
2014	FF-500	IPC	√	√	√	√	√	√	○	0541,0542
2014	FF-500	OBCM	√	√	√	√	√	○	○	
2014	FF-500	CTM	√	√	√	√	√	√	○	
2014	FF-500	VTM	√	√	√	√	√	○	○	
2014	FF-500	RBC	√	√	√	√	√	○	○	0757,0844
2014	FF-500	EVCU	√	√	√	√	√	√	○	0094,0520,0519,0681,0213
2014	FF-500	PDM	√	√	√	√	√	○	○	
2014	4C	PCM	√	√	√	√	√	√	√	0373,0927
2014	4C	TCM	√	√	√	√	√	√	※	
2014	4C	ORC	√	√	√	√	√	○	√	
2014	4C	BCM	√	√	√	○	√	√	√	0792,0460
2014	4C	PAM	√	√	√	√	√	○	○	
2014	4C	TPM	√	√	√	√	√	○	√	
2014	4C	ABS	√	√	√	√	√	※	√	1089
2014	4C	IPC	√	√	√	○	√	√	○	
2014	BU-Renegade	ECM	√	√	√	○	√	√	√	0128,0766,1026,0702,0729,0958,0959,0388,0458,0691,0593,0289,0290,0291,0292,0617,0725,0323,0907,0486,0360,1149,0760,0761,0361,0362
2014	BU-Renegade	TCM	√	√	√	√	√	○	○	
2014	BU-Renegade	ESM	√	√	√	○	√	√	√	
2014	BU-Renegade	ACC	√	√	√	○	√	√	√	
2014	BU-Renegade	ORC	√	√	√	○	√	○	√	
2014	BU-Renegade	HVAC	√	√	√	○	√	√	√	1275
2014	BU-Renegade	BCM	√	√	√	○	√	√	√	0460,0610,0611,0612,1180,0674,0675,0676
2014	BU-Renegade	PAM	√	√	√	○	√	○	○	
2014	BU-Renegade	ABS	√	√	√	√	√	√	√	0385,0655,1264
2014	BU-Renegade	AMP	√	√	√	○	√	√	√	
2014	BU-Renegade	DTCM	√	√	√	○	√	○	○	
2014	BU-Renegade	EPS	√	√	√	√	√	○	√	
2014	BU-Renegade	IPC	√	√	√	○	√	√	√	
2014	BU-Renegade	RFH	√	√	√	○	√	√	○	0238,0239,0338
2014	BU-Renegade	CSWM	√	√	√	√	√	√	○	
2014	BU-Renegade	ESL	○	√	√	○	√	○	○	
2014	BU-Renegade	ETM	√	√	√	○	√	√	√	
2014	BU-Renegade	LBSS	√	√	√	○	√	√	○	
2014	BU-Renegade	RBSS	√	√	√	○	√	√	○	
2014	BU-Renegade	HALF	√	√	√	○	√	○	√	
2014	BU-Renegade	RRDM	√	√	√	○	√	√	√	
2014	BU-Renegade	TTM	√	√	√	○	√	√	○	
2015	JK-Wrangler	PCM	√	√	√	√	√	√	√	0102,0237,0278,0944,0359,0827,1042,1201,0705,0927,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0225,0280,1123,0257,0322,0908,0472,0537,0591,0821,0615,1092,0216
2015	JK-Wrangler	TCM	√	√	√	√	√	○	○	0924,1094
2015	JK-Wrangler	ESM	√	√	√	√	√	√	○	
2015	JK-Wrangler	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152
2015	JK-Wrangler	ORC	√	√	√	√	√	○	√	0098,0581
2015	JK-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186,1014,1023,0187,0210,0619,1015
2015	JK-Wrangler	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2015	JK-Wrangler	ASBS	√	√	√	√	√	○	○	1071,1098,1099,1100,1101
2015	JK-Wrangler	WCM	√	√	√	√	√	○	√	0439
2015	JK-Wrangler	ITM	√	√	√	√	√	√	√	1066,1179,0584,0547,0551
2015	JK-Wrangler	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800
2015	JK-Wrangler	SAS	√	√	√	√	√	○	○	
2015	JK-Wrangler	ABS	√	√	√	√	√	√	√	0056,0168
2015	JK-Wrangler	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426,0602
2015	JK-Wrangler	AMP	√	√	√	√	√	○	√	0083,0074
2015	JK-Wrangler	HPM	√	√	√	√	√	√	○	0492
2015	KK-Liberty	PCM	√	√	√	√	√	√	√	0002,0003,0004,0019,0020,0021,0035,0036,0037,0050,0359,0827,0838,0835,0840,0971,0972,0973,1042,1141,1142,1143,1201,0705,0695,0696,0733,0734,0927,1108,1109,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0102,0237,0278,0944,0103,0279,0920,0280
2015	KK-Liberty	TCM	√	√	√	√	√	○	○	0924,1094

2015	KK-Liberty	ESM	√	√	√	√	√	√	○	
2015	KK-Liberty	FDCM	√	√	√	√	√	√	○	0706
2015	KK-Liberty	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0465, 0508, 0510, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152, 0402, 0812
2015	KK-Liberty	ORC	√	√	√	√	√	○	√	0098
2015	KK-Liberty	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015
2015	KK-Liberty	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680, 0277
2015	KK-Liberty	MSM	√	√	√	√	√	※	※	0112, 0222, 0381, 0603, 0658, 1083, 1150, 0341, 0382, 0604, 1023, 1084, 1151, 0110
2015	KK-Liberty	OCM	√	√	√	√	√	○	○	0715
2015	KK-Liberty	WCM	√	√	√	√	√	○	√	0439, 0613
2015	KK-Liberty	SUNR	√	√	√	√	√	○	○	
2015	KK-Liberty	PTS	√	√	√	√	√	√	√	0266, 1106
2015	KK-Liberty	ITM	√	√	√	√	√	√	√	0555, 1066, 1178
2015	KK-Liberty	SAS	√	√	√	√	√	○	○	
2015	KK-Liberty	ABS	√	√	√	√	√	√	√	0056, 0168
2015	KK-Liberty	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2015	KK-Liberty	AMP	√	√	√	√	√	○	√	0083, 0074
2015	KK-Liberty	HPM	√	√	√	√	√	√	○	0492
2015	KK-Liberty	DMFR	√	√	√	√	√	√	○	
2015	KK-Liberty	DMFL	√	√	√	√	√	√	√	
2015	LX-300, Charger, Magnum, Grand Voyager	PCM	√	√	√	√	√	√	√	0257, 0216, 0133, 0312, 0616, 0821, 0952, 0932, 0948, 1034, 1148, 0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2015	LX-300, Charger, Magnum, Grand Voyager	TCM	√	√	√	√	√	○	√	0924, 1094, 0912
2015	LX-300, Charger, Magnum, Grand Voyager	ESM	√	√	√	√	√	※	○	
2015	LX-300, Charger, Magnum, Grand Voyager	ACC	√	√	√	√	√	○	○	
2015	LX-300, Charger, Magnum, Grand Voyager	ORC	√	√	√	√	√	○	√	0581
2015	LX-300, Charger, Magnum, Grand Voyager	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2015	LX-300, Charger, Magnum, Grand Voyager	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2015	LX-300, Charger, Magnum, Grand Voyager	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2015	LX-300, Charger, Magnum, Grand Voyager	PTS	√	√	√	√	√	○	√	1106
2015	LX-300, Charger, Magnum, Grand Voyager	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2015	LX-300, Charger, Magnum, Grand Voyager	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2015	LX-300, Charger, Magnum, Grand Voyager	ABS	√	√	√	√	√	√	√	0056, 0181, 0055
2015	LX-300, Charger, Magnum, Grand Voyager	RADIO	√	√	√	√	√	√	√	
2015	LX-300, Charger, Magnum, Grand Voyager	AMP	√	√	√	√	√	○	○	0083, 0074
2015	LX-300, Charger, Magnum, Grand Voyager	DDM	√	√	√	√	√	√	√	
2015	LX-300, Charger, Magnum, Grand Voyager	PDM	√	√	√	√	√	√	√	
2015	LX-300, Charger, Magnum, Grand Voyager	HSM	√	√	√	√	√	√	√	
2015	LX-300, Charger, Magnum, Grand Voyager	DTCM	√	√	√	√	√	√	○	
2015	LX-300, Charger, Magnum, Grand Voyager	EPS	√	√	√	√	√	○	○	
2015	LX-300, Charger, Magnum, Grand Voyager	ADCM	√	√	√	√	√	○	○	
2015	LX-300, Charger, Magnum, Grand Voyager	AFLS	√	√	√	√	√	√	○	0066
2015	LX-300, Charger, Magnum, Grand Voyager	ICS	√	√	√	√	√	√	○	
2015	LX-300, Charger, Magnum, Grand Voyager	IPC	√	√	√	√	√	√	√	0428
2015	LX-300, Charger, Magnum, Grand Voyager	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2015	LX-300, Charger, Magnum, Grand Voyager	SCCM	√	√	√	√	√	○	√	
2015	LX-300, Charger, Magnum, Grand Voyager	FPCM	○	○	○	○	○	○	○	
2015	LX-300, Charger, Magnum, Grand Voyager	LBSS	√	√	√	○	√	○	○	
2015	LX-300, Charger, Magnum, Grand Voyager	RBSS	√	√	√	○	√	○	○	
2015	MK-Compass, Patriot	PCM	√	√	√	√	√	√	※	0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0225, 0280, 1491
2015	MK-Compass, Patriot	TCM	√	√	√	√	√	√	√	0190, 0228
2015	MK-Compass, Patriot	FDCM	√	√	√	√	√	√	√	
2015	MK-Compass, Patriot	CGW	√	√	√	√	√	√	√	0108, 0119, 0465, 0508, 0510, 0527, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0425, 0402, 0810, 0816, 0817, 0752
2015	MK-Compass, Patriot	ORC	√	√	√	√	√	○	√	0098
2015	MK-Compass, Patriot	MIC_CCN	√	√	√	√	√	√	√	1014, 1184, 1186, 1023, 0150, 0152
2015	MK-Compass, Patriot	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2015	MK-Compass, Patriot	WCM	√	√	√	√	√	○	√	0143, 0366, 0439
2015	MK-Compass, Patriot	ITM	√	√	√	√	√	√	√	1066, 1178, 0579
2015	MK-Compass, Patriot	SAS	√	√	√	√	√	○	○	
2015	MK-Compass, Patriot	ABS	√	√	√	√	√	√	√	0566, 0168, 0578, 0568, 0056
2015	MK-Compass, Patriot	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2015	MK-Compass, Patriot	AMP	√	√	√	√	√	○	√	0083, 0074
2015	MK-Compass, Patriot	HPM	√	√	√	√	√	√	○	0492

2015	RT-Caravan,Town & Country	PCM	√	√	√	√	√	√	√	0002,0019,0035,0050,0102,0237,0278,0944,0359,0827,0838,0971,1042,1141,1201,0705,0695,0927,1108,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0225,0280,1123,0257,0322,0908,0472,0537,0591,0821,0615,0216
2015	RT-Caravan,Town & Country	TCM	√	√	√	√	√	√	√	0006,0023,0039,0052,0229,0971,1107
2015	RT-Caravan,Town & Country	CGW	√	√	√	√	√	√	√	0108,0155,0331,0465,0508,0510,0560,0795,1225,1226,0095,0150,0152,0119,0900,1076,1155,1189,1219,1224,1182,1220,1235
2015	RT-Caravan,Town & Country	ORC	√	√	√	√	√	○	√	0098,0581
2015	RT-Caravan,Town & Country	MIC_CCN	√	√	√	√	√	√	√	1186,1014,1023,0187,0210,0619,1015
2015	RT-Caravan,Town & Country	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680,0462,0120,0277,0463,0469
2015	RT-Caravan,Town & Country	PLGM	√	√	√	√	√	√	√	0877,0199,0200
2015	RT-Caravan,Town & Country	MSM	√	√	√	√	√	√	√	0658,1083,1150,0112,0222,0381,0603
2015	RT-Caravan,Town & Country	FSM	√	√	√	√	√	√	○	1269,1272,0194,0201
2015	RT-Caravan,Town & Country	WCM	√	√	√	√	√	√	√	0143,0366,0613,0439
2015	RT-Caravan,Town & Country	SUNR	√	√	√	√	√	√	○	
2015	RT-Caravan,Town & Country	HIDT	√	√	√	√	√	√	○	0493
2015	RT-Caravan,Town & Country	AHBM	√	√	√	√	√	√	○	0132
2015	RT-Caravan,Town & Country	PTS	√	√	√	√	√	√	√	1106,0266
2015	RT-Caravan,Town & Country	ITM	√	√	√	√	√	√	√	1066,1178,0555
2015	RT-Caravan,Town & Country	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800
2015	RT-Caravan,Town & Country	SAS	√	√	√	√	√	○	○	
2015	RT-Caravan,Town & Country	ABS	√	√	√	√	√	√	√	0055,0056
2015	RT-Caravan,Town & Country	DVD	√	√	√	√	√	○	○	
2015	RT-Caravan,Town & Country	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2015	RT-Caravan,Town & Country	AMP	√	√	√	√	√	○	√	0083,0074
2015	RT-Caravan,Town & Country	HPM	√	√	√	√	√	√	○	0492
2015	RT-Caravan,Town & Country	VES2	√	√	√	√	√	√	√	
2015	RT-Caravan,Town & Country	VES3	√	√	√	√	√	√	√	
2015	RT-Caravan,Town & Country	DMFR	√	√	√	√	√	√	○	
2015	RT-Caravan,Town & Country	DMFL	√	√	√	√	√	√	√	
2015	RT-Caravan,Town & Country	DMRL	√	√	√	√	√	√	√	0622,0624,0630
2015	RT-Caravan,Town & Country	DMRR	√	√	√	√	√	√	√	0622,0624,0630
2015	RT-Caravan,Town & Country	PSDMR	√	√	√	√	√	○	○	1067,1070,0877,0106,0633
2015	RT-Caravan,Town & Country	PSDML	√	√	√	√	√	○	○	1067,1070,0877,0106,0633
2015	RT-Caravan,Town & Country	HSM	√	√	√	√	√	√	√	0512
2015	RT-Caravan,Town & Country	PDM	√	√	√	√	√	○	√	0338,0609,0648
2015	RT-Caravan,Town & Country	EPPM	√	√	√	√	√	○	√	
2015	RT-Caravan,Town & Country	LBSS	√	√	√	○	√	○	○	
2015	RT-Caravan,Town & Country	RBSS	√	√	√	○	√	○	○	
2015	WK-Grand Cherokee	PCM	√	√	√	√	√	√	√	0102,0237,0278,0944,0359,0827,1042,1201,0705,0927,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0225,0280,0293,0224,1000,0954,0921,0304,0999,1004,1005,1002,1007,1008,0216,0821,0312,0712,0953,0133,0932,0948,1034,1148
2015	WK-Grand Cherokee	TCM	√	√	√	√	√	○	√	0912
2015	WK-Grand Cherokee	ESM	√	√	√	√	√	○	○	
2015	WK-Grand Cherokee	ACC	√	√	√	√	√	○	○	0061
2015	WK-Grand Cherokee	ORC	√	√	√	√	√	○	√	0098,0581
2015	WK-Grand Cherokee	HVAC	√	√	√	√	√	√	○	0498,0680,0121
2015	WK-Grand Cherokee	PLGM	√	√	√	√	√	√	○	
2015	WK-Grand Cherokee	MSM	√	√	√	√	√	√	√	0658,1083,1150,0112,0222,0381,0603
2015	WK-Grand Cherokee	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2015	WK-Grand Cherokee	PTS	√	√	√	√	√	√	√	1106,0266
2015	WK-Grand Cherokee	ITM	√	√	√	√	√	√	√	1178,0584,0555,0551,0553
2015	WK-Grand Cherokee	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2015	WK-Grand Cherokee	ABS	√	√	√	√	√	√	√	0181,0055,0056
2015	WK-Grand Cherokee	RADIO	√	√	√	√	√	√	√	
2015	WK-Grand Cherokee	AMP	√	√	√	√	√	○	※	0083,0074
2015	WK-Grand Cherokee	VES2	√	√	√	√	√	√	○	
2015	WK-Grand Cherokee	VES3	√	√	√	√	√	√	○	
2015	WK-Grand Cherokee	DDM	√	√	√	√	√	√	√	
2015	WK-Grand Cherokee	PDM	√	√	√	√	√	√	√	
2015	WK-Grand Cherokee	HSM	√	√	√	√	√	√	√	
2015	WK-Grand Cherokee	DTCM	√	√	√	√	√	√	√	
2015	WK-Grand Cherokee	EPS	√	√	√	√	√	○	○	
2015	WK-Grand Cherokee	ADCM	√	√	√	√	√	○	○	
2015	WK-Grand Cherokee	AFLS	√	√	√	√	√	○	√	0068
2015	WK-Grand Cherokee	ASCM	√	√	√	√	√	○	√	0134,1081,1082,0330,0459,1056,0513,0256
2015	WK-Grand Cherokee	ELSD	√	√	√	○	√	√	○	1104,0364

2015	WK-Grand Cherokee	ICS	√	√	√	√	√	○	○	
2015	WK-Grand Cherokee	IPC	√	√	√	√	√	√	√	0428
2015	WK-Grand Cherokee	RFH	√	√	√	√	√	√	√	0561,0338,0648
2015	WK-Grand Cherokee	SCCM	√	√	√	√	√	○	√	
2015	WK-Grand Cherokee	FPCM	○	○	○	○	○	○	○	
2015	WK-Grand Cherokee	LBSS	√	√	√	○	√	○	○	
2015	WK-Grand Cherokee	RBSS	√	√	√	○	√	○	○	
2015	WK-Grand Cherokee	EDM	√	√	√	○	√	√	○	
2015	WK-Grand Cherokee	ANC	√	√	√	√	√	○	√	
2015	WK-Grand Cherokee	DTV	√	√	√	√	√	√	√	
2015	D2-Ram Truck	PCM	√	√	√	√	√	√	√	0004,0021,0037,0102,0237,0278,0944,0359,0827,0840,0973,1042,1143,1201,0705,0734,0927,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0141,0225,0280,0435,0436,1044,1045,0558,0311,0842,1176,0142,0299,0303,0344,0345,0438,0204,1072
2015	D2-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2015	D2-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2015	D2-Ram Truck	HVAC	√	√	√	√	√	√	√	0498,0461,0680,0121
2015	D2-Ram Truck	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2015	D2-Ram Truck	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150,0892
2015	D2-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2015	D2-Ram Truck	ABS	√	√	√	√	√	√	√	0181,0055,0056
2015	D2-Ram Truck	RADIO	√	√	√	√	√	√	√	
2015	D2-Ram Truck	AMP	√	√	√	√	√	○	○	0083,0074
2015	D2-Ram Truck	DDM	√	√	√	√	√	√	√	
2015	D2-Ram Truck	PDM	√	√	√	√	√	√	√	
2015	D2-Ram Truck	HSM	√	√	√	√	√	√	√	
2015	D2-Ram Truck	DTCM	√	√	√	√	√	√	√	
2015	D2-Ram Truck	ITBM	√	√	√	√	√	○	○	
2015	D2-Ram Truck	ASCM	√	√	√	√	√	○	√	0513,1081,0459,1056,0256
2015	D2-Ram Truck	DCU	√	√	√	○	√	○	○	
2015	D2-Ram Truck	ICS	√	√	√	√	√	√	√	
2015	D2-Ram Truck	IPC	√	√	√	○	√	√	√	0334,0467
2015	D2-Ram Truck	RFH	√	√	√	√	√	√	√	0609,0338,0648
2015	D2-Ram Truck	SCCM	√	√	√	√	√	○	○	
2015	D2-Ram Truck	VSIM	√	√	√	○	√	√	○	
2015	D2-Ram Truck	VGT	√	√	√	○	√	○	○	
2015	D2-Ram Truck	EDM	√	√	√	○	√	√	○	
2015	DJ-Ram Truck	PCM	√	√	√	√	√	√	√	0004,0021,0037,0102,0237,0278,0944,0359,0827,0840,0973,1042,1143,1201,0705,0734,0927,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0141,0225,0280,0435,0436,1044,1045,0558,0311,0842,1072,1176,0142,0299,0303,0344,0345,0438,0204
2015	DJ-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2015	DJ-Ram Truck	FDCM	√	√	√	√	√	○	○	
2015	DJ-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2015	DJ-Ram Truck	HVAC	√	√	√	√	√	√	√	0498,0461,0680,0121
2015	DJ-Ram Truck	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2015	DJ-Ram Truck	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150,0892
2015	DJ-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2015	DJ-Ram Truck	ABS	√	√	√	√	√	√	√	0181,0055,0056
2015	DJ-Ram Truck	RADIO	√	√	√	√	√	√	√	
2015	DJ-Ram Truck	AMP	√	√	√	√	√	○	○	0083,0074
2015	DJ-Ram Truck	DDM	√	√	√	√	√	√	√	
2015	DJ-Ram Truck	PDM	√	√	√	√	√	√	√	
2015	DJ-Ram Truck	HSM	√	√	√	√	√	√	√	
2015	DJ-Ram Truck	DTCM	√	√	√	√	√	√	√	
2015	DJ-Ram Truck	ITBM	√	√	√	√	√	○	○	
2015	DJ-Ram Truck	ASCM	√	√	√	√	√	○	√	0513,1081,0459,1056,0256
2015	DJ-Ram Truck	DCU	√	√	√	○	√	○	○	
2015	DJ-Ram Truck	ICS	√	√	√	√	√	√	√	
2015	DJ-Ram Truck	IPC	√	√	√	○	√	√	√	0334,0467
2015	DJ-Ram Truck	RFH	√	√	√	√	√	√	√	0609,0338,0648
2015	DJ-Ram Truck	SCCM	√	√	√	√	√	○	○	
2015	DJ-Ram Truck	VSIM	√	√	√	○	√	√	○	
2015	DJ-Ram Truck	VGT	√	√	√	○	√	○	○	
2015	DJ-Ram Truck	EDM	√	√	√	○	√	√	○	

2015	DS-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 0101, 0293, 0358, 0224, 1000, 0954, 0921, 0304, 0999, 1004, 0216, 0312, 0822, 0712, 0953, 0133, 0932, 0948, 1034, 1148, 1005, 1002, 1007, 1008
2015	DS-Ram Truck	TCM	√	√	√	√	√	○	√	0912
2015	DS-Ram Truck	ESM	√	√	√	√	√	○	○	
2015	DS-Ram Truck	OBC	√	√	√	√	√	√	√	0581
2015	DS-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2015	DS-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2015	DS-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2015	DS-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2015	DS-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2015	DS-Ram Truck	RADIO	√	√	√	√	√	√	√	
2015	DS-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2015	DS-Ram Truck	DDM	√	√	√	√	√	√	√	
2015	DS-Ram Truck	PDM	√	√	√	√	√	√	√	
2015	DS-Ram Truck	HSM	√	√	√	√	√	√	√	
2015	DS-Ram Truck	DTCM	√	√	√	√	√	√	√	
2015	DS-Ram Truck	EPS	√	√	√	√	√	○	○	0236
2015	DS-Ram Truck	ITBM	√	√	√	√	√	○	○	
2015	DS-Ram Truck	ASCM	√	√	√	√	√	○	√	0134, 1081, 1082, 0330, 0459, 1056, 0513, 0256
2015	DS-Ram Truck	ICS	√	√	√	√	√	√	√	
2015	DS-Ram Truck	IPC	√	√	√	○	√	√	√	0334
2015	DS-Ram Truck	RFH	√	√	√	√	√	√	√	0609, 0338, 0648
2015	DS-Ram Truck	SCCM	√	√	√	√	√	○	○	
2015	DS-Ram Truck	VSIM	√	√	√	○	√	√	○	
2015	DS-Ram Truck	EDM	√	√	√	○	√	√	○	
2015	DX-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 1044, 1045, 0558, 0722, 1050, 0311, 0842, 1072, 1176, 0756, 0142, 0299, 0303, 0344, 0345, 0397, 0438, 0395, 0204
2015	**DX-Ram Truck**	**TCM**	√	√	√	√	√	**※**	√	**0829, 0912**
2015	DX-Ram Truck	ESM	√	√	√	√	√	○	○	
2015	DX-Ram Truck	OBC	√	√	√	√	√	√	√	0581
2015	DX-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2015	DX-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2015	DX-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2015	DX-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2015	DX-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2015	DX-Ram Truck	RADIO	√	√	√	√	√	√	√	
2015	DX-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2015	DX-Ram Truck	DDM	√	√	√	√	√	√	√	
2015	DX-Ram Truck	PDM	√	√	√	√	√	√	√	
2015	DX-Ram Truck	HSM	√	√	√	√	√	√	√	
2015	DX-Ram Truck	DTCM	√	√	√	√	√	√	√	
2015	DX-Ram Truck	EPS	√	√	√	√	√	○	○	0236
2015	DX-Ram Truck	ITBM	√	√	√	√	√	○	○	
2015	DX-Ram Truck	ASCM	√	√	√	√	√	○	√	0134, 1081, 1082, 0330, 0459, 1056, 0513, 0256
2015	DX-Ram Truck	DCU	√	√	√	○	√	○	○	
2015	DX-Ram Truck	ICS	√	√	√	√	√	√	√	
2015	DX-Ram Truck	IPC	√	√	√	○	√	√	√	0334
2015	DX-Ram Truck	RFH	√	√	√	√	√	√	√	0609, 0338, 0648
2015	DX-Ram Truck	SCCM	√	√	√	√	√	○	○	
2015	DX-Ram Truck	VSIM	√	√	√	○	√	√	○	
2015	DX-Ram Truck	VGT	√	√	√	○	√	○	○	
2015	DX-Ram Truck	EDM	√	√	√	○	√	√	○	
2015	JS-Wrangler	PCM	√	√	√	√	√	√	√	1123, 0257, 0322, 0908, 0472, 0537, 0591, 0821, 0615, 1092, 0216
2015	JS-Wrangler	TCM	√	√	√	√	√	○	○	0924, 1094
2015	JS-Wrangler	ESM	√	√	√	√	√	√	○	
2015	JS-Wrangler	CGW	√	√	√	√	√	√	√	0108, 0119, 0155, 0331, 0465, 0508, 0510, 0560, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 1235, 0095, 1182, 1220, 0150, 0152
2015	JS-Wrangler	OBC	√	√	√	√	√	○	√	0098, 0581
2015	JS-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2015	JS-Wrangler	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2015	JS-Wrangler	BCM	√	√	√	√	√	○	√	0439

2015	JS-Wrangler	SAS	√	√	√	√	√	○	○	
2015	JS-Wrangler	ABS	√	√	√	√	√	√	√	0056, 0168
2015	JS-Wrangler	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2015	JC-Journey	PCM	√	√	√	√	√	√	√	0257, 0216, 0821, 0133, 0312, 0616, 0952, 0932, 0948, 1034, 1148, 0002, 0003, 0019, 0020, 0035, 0036, 0050, 0102, 0237, 0278, 0944, 0359, 0827, 0838, 0835, 0971, 0972, 1042, 1141, 1142, 1201, 0705, 0695, 0696, 0733, 0927, 1108, 1109, 0920, 1271, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2015	JC-Journey	TCM	√	√	√	√	√	√	√	0006, 0023, 0039, 0052, 0229, 0971, 1107
2015	JC-Journey	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2015	JC-Journey	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2015	JC-Journey	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2015	JC-Journey	PTS	√	√	√	√	√	√	√	0266, 1106
2015	JC-Journey	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2015	JC-Journey	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2015	JC-Journey	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2015	JC-Journey	AMP	√	√	√	√	√	○	○	0083, 0074
2015	JC-Journey	HPM	√	√	√	√	√	○	○	0492
2015	JC-Journey	VES3	√	√	√	√	√	√	○	
2015	JC-Journey	DDM	√	√	√	√	√	√	√	
2015	JC-Journey	PDM	√	√	√	√	√	√	√	
2015	JC-Journey	HSM	√	√	√	√	√	√	√	
2015	JC-Journey	DTCM	√	√	√	√	√	√	√	
2015	JC-Journey	EPPM	√	√	√	√	√	○	√	
2015	JC-Journey	ICS	√	√	√	√	√	√	○	
2015	JC-Journey	IPC	√	√	√	√	√	√	○	
2015	JC-Journey	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2015	JC-Journey	SCCM	√	√	√	√	√	○	○	
2015	JC-Journey	TGW	√	√	√	√	√	○	√	0144, 1121
2015	JC-Journey	VTM	√	√	√	√	√	○	○	
2015	DD-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 1044, 1045, 0558, 0722, 1050, 0311, 1072, 1176, 0756, 0142, 0299, 0303, 0344, 0345, 0397, 0438, 0395, 0304
2015	DD-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2015	DD-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2015	DD-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2015	DD-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2015	DD-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2015	DD-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2015	DD-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2015	DD-Ram Truck	RADIO	√	√	√	√	√	√	√	
2015	DD-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2015	DD-Ram Truck	DDM	√	√	√	√	√	√	√	
2015	DD-Ram Truck	PDM	√	√	√	√	√	√	√	
2015	DD-Ram Truck	HSM	√	√	√	√	√	√	√	
2015	DD-Ram Truck	DTCM	√	√	√	√	√	√	√	
2015	DD-Ram Truck	ITBM	√	√	√	√	√	○	○	
2015	DD-Ram Truck	DCU	√	√	√	○	√	○	○	
2015	DD-Ram Truck	ICS	√	√	√	√	√	√	√	
2015	DD-Ram Truck	IPC	√	√	√	○	√	√	√	0334, 0467
2015	DD-Ram Truck	RFH	√	√	√	√	√	√	√	0609, 0338, 0648
2015	DD-Ram Truck	SCCM	√	√	√	√	√	○	○	
2015	DD-Ram Truck	VSIM	√	√	√	○	√	√	○	
2015	DD-Ram Truck	VGT	√	√	√	○	√	○	○	
2015	DD-Ram Truck	EDM	√	√	√	○	√	√	○	
2015	DP-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 1044, 1045, 0558, 0722, 1050, 0311, 1072, 1176, 0756, 0142, 0299, 0303, 0344, 0345, 0397, 0438, 0395, 0304
2015	DP-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2015	DP-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2015	DP-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2015	DP-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2015	DP-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2015	DP-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106

2015	DP-Ram Truck	ABS	√	√	√	√	√	√	√	0181,0055,0056
2015	DP-Ram Truck	RADIO	√	√	√	√	√	√	√	
2015	DP-Ram Truck	AMP	√	√	√	√	√	○	○	0083,0074
2015	DP-Ram Truck	DDM	√	√	√	√	√	√	√	
2015	DP-Ram Truck	PDM	√	√	√	√	√	√	√	
2015	DP-Ram Truck	HSM	√	√	√	√	√	√	√	
2015	DP-Ram Truck	DTCM	√	√	√	√	√	√	√	
2015	DP-Ram Truck	ITBM	√	√	√	√	√	○	○	
2015	DP-Ram Truck	DCU	√	√	√	○	√	○	○	
2015	DP-Ram Truck	ICS	√	√	√	√	√	√	√	
2015	DP-Ram Truck	IPC	√	√	√	○	√	√	√	0334,0467
2015	DP-Ram Truck	BPH	√	√	√	√	√	√	√	0609,0338,0648
2015	DP-Ram Truck	SCCM	√	√	√	√	√	○	○	
2015	DP-Ram Truck	VSIM	√	√	√	○	√	√	○	
2015	DP-Ram Truck	VGT	√	√	√	○	√	○	○	
2015	DP-Ram Truck	EDM	√	√	√	○	√	√	○	
2015	JF-Freemont	PCM	√	√	√	√	√	√	√	0257,0216,0821,0133,0312,0616,0952,0932,0948,1034,1148,0002,0003,0019,0020,0035,0036,0050,0102,0237,0278,0944,0359,0827,0838,0835,0971,0972,1042,1141,1142,1201,0705,0695,0696,0733,0927,1108,1109,0920,1271,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0225,0280
2015	JF-Freemont	TCM	√	√	√	√	√	√	√	0006,0023,0039,0052,0229,0971,1107
2015	JF-Freemont	OBC	√	√	√	√	√	○	√	0098,0581,0990
2015	JF-Freemont	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680
2015	JF-Freemont	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2015	JF-Freemont	PTS	√	√	√	√	√	√	√	0266,1106
2015	JF-Freemont	ITM	√	√	√	√	√	√	√	0584,0555,0551,0553,1178
2015	JF-Freemont	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2015	JF-Freemont	ABS	√	√	√	√	√	√	√	0181,0055,0056
2015	JF-Freemont	AMP	√	√	√	√	√	○	○	0083,0074
2015	JF-Freemont	HPM	√	√	√	√	√	○	○	0492
2015	JF-Freemont	VES3	√	√	√	√	√	√	○	
2015	JF-Freemont	DDM	√	√	√	√	√	√	√	
2015	JF-Freemont	PDM	√	√	√	√	√	√	√	
2015	JF-Freemont	HSM	√	√	√	√	√	√	√	
2015	JF-Freemont	DTCM	√	√	√	√	√	√	√	
2015	JF-Freemont	EPPM	√	√	√	√	√	○	√	
2015	JF-Freemont	ICS	√	√	√	√	√	√	○	
2015	JF-Freemont	IPC	√	√	√	√	√	√	○	
2015	JF-Freemont	BPH	√	√	√	√	√	√	√	0561,0338,0648
2015	JF-Freemont	SCCM	√	√	√	√	√	○	○	
2015	JF-Freemont	TGW	√	√	√	√	√	○	√	1121,0144
2015	JF-Freemont	VTM	√	√	√	√	√	○	○	
2015	LD-Charger	PCM	√	√	√	√	√	√	√	0102,0237,0278,0944,0359,0827,1042,1201,0705,0927,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0225,0280
2015	LD-Charger	TCM	√	√	√	√	√	○	√	0924,1094,0912
2015	LD-Charger	ESM	√	√	√	√	√	√	○	
2015	LD-Charger	ACC	√	√	√	√	√	○	○	
2015	LD-Charger	OBC	√	√	√	√	√	○	√	0581
2015	LD-Charger	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680
2015	LD-Charger	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2015	LD-Charger	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2015	LD-Charger	PTS	√	√	√	√	√	○	√	1106
2015	LD-Charger	ITM	√	√	√	√	√	√	√	0584,0555,0551,0553,1178
2015	LD-Charger	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2015	LD-Charger	ABS	√	√	√	√	√	√	√	0056,0181,0055
2015	LD-Charger	RADIO	√	√	√	√	√	√	√	
2015	LD-Charger	AMP	√	√	√	√	√	○	○	0083,0074
2015	LD-Charger	DDM	√	√	√	√	√	√	√	
2015	LD-Charger	PDM	√	√	√	√	√	√	√	
2015	LD-Charger	HSM	√	√	√	√	√	√	√	
2015	LD-Charger	DTCM	√	√	√	√	√	√	○	
2015	LD-Charger	EPS	√	√	√	√	√	○	○	
2015	LD-Charger	ADCM	√	√	√	√	√	○	○	
2015	LD-Charger	ICS	√	√	√	√	√	√	○	
2015	LD-Charger	IPC	√	√	√	√	√	√	√	0428
2015	LD-Charger	BPH	√	√	√	√	√	√	√	0561,0338,0648
2015	LD-Charger	SCCM	√	√	√	√	√	○	√	
2015	LD-Charger	VSIM	√	√	√	○	√	√	○	
2015	LD-Charger	FFCM	○	○	○	○	○	○	○	
2015	LD-Charger	LBSS	√	√	√	○	√	○	○	

2015	LD-Charger	RBSS	√	√	√	○	√	○	○	
2015	WD-Durango	PCM	√	√	√	√	√	√	√	0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2015	WD-Durango	TCM	√	√	√	√	√	○	√	0912
2015	WD-Durango	ESM	√	√	√	√	√	○	○	
2015	WD-Durango	ACC	√	√	√	√	√	○	○	0061
2015	WD-Durango	ORC	√	√	√	√	√	○	√	0098, 0581
2015	WD-Durango	HVAC	√	√	√	√	√	√	○	0498, 0680, 0121
2015	WD-Durango	PLGM	√	√	√	√	√	√	○	
2015	WD-Durango	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0803, 0658, 1083, 1150
2015	WD-Durango	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2015	WD-Durango	AHLM	√	√	√	√	√	○	○	0193
2015	WD-Durango	PTS	√	√	√	√	√	√	√	0266, 1106
2015	WD-Durango	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2015	WD-Durango	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2015	WD-Durango	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2015	WD-Durango	RADIO	√	√	√	√	√	√	√	
2015	WD-Durango	AMP	√	√	√	√	√	○	○	0083, 0074
2015	WD-Durango	VES2	√	√	√	√	√	√	○	
2015	WD-Durango	VES3	√	√	√	√	√	√	○	
2015	WD-Durango	DDM	√	√	√	√	√	√	√	
2015	WD-Durango	PDM	√	√	√	√	√	√	√	
2015	WD-Durango	HSM	√	√	√	√	√	√	√	
2015	WD-Durango	DTCM	√	√	√	√	√	√	√	
2015	WD-Durango	EPS	√	√	√	√	√	○	○	0238
2015	WD-Durango	ELSD	√	√	√	○	√	√	○	0364, 1104
2015	WD-Durango	ICS	√	√	√	√	√	○	○	
2015	WD-Durango	IPC	√	√	√	√	√	√	√	0428
2015	WD-Durango	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2015	WD-Durango	SCCM	√	√	√	√	√	○	√	
2015	WD-Durango	FFCM	○	○	○	○	○	○	○	
2015	WD-Durango	HVACR	√	√	√	√	√	√	√	0121
2015	WD-Durango	LBSS	√	√	√	○	√	○	○	
2015	WD-Durango	RBSS	√	√	√	○	√	○	○	
2015	WD-Durango	EDM	√	√	√	○	√	√	○	
2015	PF-Dart	PCM	√	√	√	√	√	√	√	0909, 0927, 0102, 0103, 0137, 0183, 0215, 0231, 1145, 0216, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0920, 0188, 0279, 0202, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2015	PF-Dart	TCM	√	√	√	√	√	√	√	0961, 0176, 0531, 0627, 0703, 0829, 0228
2015	PF-Dart	ESM	√	√	√	√	√	○	√	
2015	PF-Dart	ORC	√	√	√	√	√	○	√	0581
2015	PF-Dart	HVAC	√	√	√	√	√	√	√	0121, 0462, 0680
2015	PF-Dart	OCM	√	√	√	√	√	○	√	0715
2015	PF-Dart	BCM	√	√	√	√	√	√	√	0095, 0400, 0155, 0452, 0255, 0424, 0465, 0606, 0510, 0559, 0422, 1076, 1077, 1219, 1221, 1224, 1225, 1226, 1235, 1138, 0150, 0152
2015	PF-Dart	PAM	√	√	√	√	√	○	○	
2015	PF-Dart	ABS	√	√	√	√	√	○	√	0181, 0653, 0059, 1089
2015	PF-Dart	RADIO	※	※	※	※	※	※	※	
2015	PF-Dart	AMP	√	√	√	√	√	○	○	
2015	PF-Dart	EPS	√	√	√	√	√	○	○	
2015	PF-Dart	ICS	√	√	√	√	√	√	○	
2015	PF-Dart	IPC	√	√	√	√	√	√	√	
2015	PF-Dart	RFH	√	√	√	√	√	√	√	0338, 0561, 0609, 0648
2015	PF-Dart	SCCM	√	√	√	√	√	○	○	
2015	PF-Dart	CSWM	√	√	√	√	√	√	√	
2015	PF-Dart	CTM	√	√	√	√	√	○	○	
2015	PF-Dart	LBSS	√	√	√	○	√	√	√	
2015	PF-Dart	RBSS	√	√	√	○	√	√	√	
2015	PF-Dart	EDM	√	√	√	○	√	√	○	
2015	BK-Forza	ORC	√	√	√	√	√	√	○	
2015	BK-Forza	IPC	√	√	√	√	√	√	○	
2015	ZD-Viper (Post-2013)	PCM	√	√	√	√	√	√	○	0826, 0927, 1146, 0215, 0628, 0377, 0590, 0625, 0626, 0631
2015	ZD-Viper (Post-2013)	ORC	√	√	√	√	√	√	√	0581
2015	ZD-Viper (Post-2013)	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2015	ZD-Viper (Post-2013)	OCM	√	√	√	√	√	○	○	0715
2015	ZD-Viper (Post-2013)	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2015	ZD-Viper (Post-2013)	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2015	ZD-Viper (Post-2013)	ABS	√	√	√	√	√	√	√	
2015	ZD-Viper (Post-2013)	RADIO	√	√	√	√	√	√	√	
2015	ZD-Viper (Post-2013)	AMP	√	√	√	√	√	○	○	0083, 0074

2015	ZD-Viper (Post-2013)	DDM	√	√	√	√	√	√	√	
2015	ZD-Viper (Post-2013)	PDM	√	√	√	√	√	√	√	
2015	ZD-Viper (Post-2013)	ADCM	√	√	√	√	√	○	○	
2015	ZD-Viper (Post-2013)	ICS	√	√	√	√	√	√	√	
2015	ZD-Viper (Post-2013)	IPC	√	√	√	√	√	√	√	
2015	ZD-Viper (Post-2013)	RFH	√	√	√	√	√	√	√	0581,0648
2015	ZD-Viper (Post-2013)	SCCM	√	√	√	√	√	○	○	
2015	BF-Fiat 500L	PCM	√	√	√	√	√	√	√	0909,0927,0137,0183,0215,0231,0216,1145
2015	BF-Fiat 500L	TCM	√	√	√	√	√	√	※	0531,0176,0627,0703,0829,0951
2015	BF-Fiat 500L	ESM	√	√	√	√	√	√	√	
2015	BF-Fiat 500L	ORC	√	√	√	√	√	○	√	
2015	BF-Fiat 500L	HVAC	※	√	√	√	√	√	○	
2015	BF-Fiat 500L	BCM	√	√	√	√	√	√	√	0411,0264
2015	BF-Fiat 500L	PAM	√	√	√	√	√	○	○	
2015	BF-Fiat 500L	TPM	√	√	√	√	√	√	√	
2015	BF-Fiat 500L	ABS	√	√	√	√	√	○	√	
2015	BF-Fiat 500L	EPS	√	√	√	√	√	○	○	
2015	BF-Fiat 500L	IPC	√	√	√	√	√	√	○	
2015	BF-Fiat 500L	ETM	√	√	√	√	√	○	√	
2015	KL-Cherokee	PCM	√	√	√	√	√	√	√	0216,0312,0353,0569,0591,0616,0701,0952,0948,1034,0102,0237,0278,0944,0359,0827,1042,1201,0705,0927,0920,0103,0188,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0225,0280
2015	KL-Cherokee	TCM	√	√	√	√	√	○	√	0912,1119
2015	KL-Cherokee	ESM	√	√	√	√	√	○	○	
2015	KL-Cherokee	ACC	√	√	√	√	√	○	√	0061
2015	KL-Cherokee	ORC	√	√	√	√	√	√	√	0581
2015	KL-Cherokee	HVAC	√	√	√	√	√	√	√	0121,0462,0680
2015	KL-Cherokee	PLGM	√	√	√	√	√	√	○	
2015	KL-Cherokee	MSM	√	√	√	√	√	○	○	
2015	KL-Cherokee	OCM	√	√	√	√	√	○	√	0715
2015	KL-Cherokee	BCM	√	√	√	√	√	√	√	0095,0400,0155,0452,0424,0417,0465,0506,0510,0559,0422,1076,1077,1219,1221,1224,1225,1226,1235,1138,0150,0152,0326
2015	KL-Cherokee	AHLM	√	√	√	√	√	○	○	0193
2015	KL-Cherokee	PAM	√	√	√	√	√	√	√	
2015	KL-Cherokee	ABS	√	√	√	√	√	○	√	0065,0653
2015	KL-Cherokee	RADIO	√	√	√	√	√	√	√	
2015	KL-Cherokee	AMP	√	√	√	√	√	○	○	
2015	KL-Cherokee	DDM	√	√	√	√	√	√	√	
2015	KL-Cherokee	PDM	√	√	√	√	√	√	√	
2015	KL-Cherokee	DTCM	√	√	√	√	√	√	√	
2015	KL-Cherokee	EPS	√	√	√	√	√	○	○	
2015	KL-Cherokee	ICS	√	√	√	√	√	√	√	
2015	KL-Cherokee	IPC	√	√	√	√	√	√	○	
2015	KL-Cherokee	RFH	√	√	√	√	√	√	√	0338,0609,0648
2015	KL-Cherokee	SCCM	√	√	√	√	√	√	○	
2015	KL-Cherokee	CSWM	√	√	√	√	√	√	√	
2015	KL-Cherokee	EPB	√	√	√	√	√	○	√	1136
2015	KL-Cherokee	ESL	√	√	√	√	√	○	√	
2015	KL-Cherokee	FFCM	※	※	※	※	※	○	※	
2015	KL-Cherokee	LBSS	√	√	√	○	√	○	√	
2015	KL-Cherokee	PTU	√	√	√	○	√	○	○	0934
2015	KL-Cherokee	RBSS	√	√	√	○	√	○	√	
2015	KL-Cherokee	RDM	√	√	√	○	√	○	○	0937
2015	KL-Cherokee	EDM	√	√	√	○	√	√	○	
2015	KL-Cherokee	DTV	√	√	√	√	√	√	√	
2015	YF-ProMaster	PCM	√	√	√	√	√	√	√	0247,0309,0353,0569,0591,0712,0963,1001,0998,1004,1006,1007,1008,1079,1034,0002,0019,0035,0050,0102,0237,0278,0944,0359,0827,0838,0971,1042,1141,1201,0705,0695,0927,1108,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0225,0280,0517,0664
2015	YF-ProMaster	TCM	√	√	√	√	√	√	√	0355,0176,0531,0627,0703,0829,0951
2015	YF-ProMaster	ORC	√	√	√	√	√	○	√	
2015	YF-ProMaster	HVAC	√	√	√	√	√	√	○	
2015	YF-ProMaster	BCM	√	√	√	√	√	√	√	0413,0412,0452
2015	YF-ProMaster	PAM	√	√	√	√	√	○	○	
2015	YF-ProMaster	TPM	√	√	√	√	√	√	√	
2015	YF-ProMaster	ABS	√	√	√	√	√	○	√	
2015	YF-ProMaster	IPC	√	√	√	√	√	√	○	
2015	YF-ProMaster	ETM	√	√	√	√	√	○	√	
2015	NY-Ypsilon	ECM	√	√	√	※	√	√	√	
2015	NY-Ypsilon	TCM	√	√	√	○	√	√	√	
2015	NY-Ypsilon	ORC	√	√	√	√	√	√	√	

2015	NY-Ypsilon	HVAC	√	√	√	√	√	√	√	
2015	NY-Ypsilon	BCM	√	√	√	○	√	√	○	
2015	NY-Ypsilon	ABS	√	√	√	√	√	√	√	
2015	NY-Ypsilon	EPS	√	√	√	√	√	○	√	
2015	NY-Ypsilon	IPC	√	√	√	※	√	√	○	0542
2015	NY-Ypsilon	AHM	√	√	√	√	√	√	○	
2015	FF-500	PCM	√	√	√	√	√	√	√	0136
2015	FF-500	TCM	√	√	√	√	√	√	○	0355, 0176, 0531, 0627, 0703, 0829, 0951, 0634
2015	FF-500	ESM	√	√	√	○	√	○	○	
2015	FF-500	ORC	√	√	√	√	√	○	√	
2015	FF-500	HVAC	√	√	√	√	√	√	○	
2015	FF-500	BCM	√	√	√	√	√	√	√	
2015	FF-500	PTS	√	√	√	√	√	○	○	
2015	FF-500	TPM	√	√	√	√	√	√	√	
2015	FF-500	ABS	√	√	√	√	√	※	○	0057
2015	FF-500	RADIO	√	√	√	√	√	○	○	
2015	FF-500	BPCM	√	√	√	√	√	√	○	
2015	FF-500	EAC	√	√	√	√	√	○	○	
2015	FF-500	EPS	√	√	√	√	√	○	○	0236, 0573
2015	FF-500	IPC	√	√	√	√	√	√	○	0541, 0542
2015	FF-500	OBCM	√	√	√	√	√	○	○	
2015	FF-500	CTM	√	√	√	√	√	√	○	
2015	FF-500	VTM	√	√	√	√	√	○	○	
2015	FF-500	RBC	√	√	√	√	√	○	○	0757, 0844
2015	FF-500	EVCU	√	√	√	√	√	√	○	0094, 0520, 0519, 0681, 0213
2015	FF-500	PDM	√	√	√	√	√	○	○	
2015	4C	PCM	√	√	√	√	√	√	√	0927, 0373
2015	4C	TCM	√	√	√	√	√	√	※	
2015	4C	ORC	√	√	√	√	√	○	√	
2015	4C	BCM	√	√	√	○	√	√	√	0460, 0792
2015	4C	PAM	√	√	√	√	√	○	○	
2015	4C	TPM	√	√	√	√	√	○	√	
2015	4C	ABS	√	√	√	√	√	※	√	1089
2015	4C	IPC	√	√	√	○	√	√	○	
2015	BU-Renegade	ECM	√	√	√	○	√	√	√	0128, 0766, 1026, 0702, 0729, 0958, 0959, 0388, 0458, 0691, 0760, 0761, 0593, 0289, 0290, 0291, 0292, 0617, 0725, 0323, 0907, 0486, 0360, 1149, 0361, 0362
2015	BU-Renegade	TCM	√	√	√	√	√	○	○	
2015	BU-Renegade	ESM	√	√	√	○	√	√	√	
2015	BU-Renegade	ACC	√	√	√	○	√	√	√	
2015	BU-Renegade	ORC	√	√	√	○	√	○	√	
2015	BU-Renegade	HVAC	√	√	√	○	√	√	√	1275
2015	BU-Renegade	BCM	√	√	√	○	√	√	√	0460, 0610, 0611, 0612, 1180, 0674, 0675, 0676
2015	BU-Renegade	PAM	√	√	√	○	√	○	○	
2015	BU-Renegade	ABS	√	√	√	√	√	√	√	0385, 0655, 1264
2015	BU-Renegade	AMP	√	√	√	○	√	√	√	
2015	BU-Renegade	DTCM	√	√	√	○	√	○	○	
2015	BU-Renegade	EPS	√	√	√	√	√	○	√	
2015	BU-Renegade	IPC	√	√	√	○	√	√	√	
2015	BU-Renegade	RFH	√	√	√	○	√	√	○	0238, 0239, 0338
2015	BU-Renegade	CSWM	√	√	√	√	√	√	○	
2015	BU-Renegade	ESL	○	√	√	○	√	○	○	
2015	BU-Renegade	ETM	√	√	√	○	√	√	√	
2015	BU-Renegade	LBSS	√	√	√	○	√	√	○	
2015	BU-Renegade	RBSS	√	√	√	○	√	√	○	
2015	BU-Renegade	HALF	√	√	√	○	√	○	√	
2015	BU-Renegade	RRM	√	√	√	○	√	√	√	
2015	BU-Renegade	TTM	√	√	√	○	√	√	○	
2015	DV-Vision	ORC	√	√	√	√	√	√	○	
2015	DV-Vision	BCM	√	√	√	√	√	√	○	
2015	DV-Vision	IPC	√	√	√	√	√	√	○	
2015	LA-Challenger	PCM	√	√	√	√	√	√	√	0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2015	LA-Challenger	TCM	√	√	√	√	√	○	√	0912
2015	LA-Challenger	ESM	√	√	√	√	√	√	○	
2015	LA-Challenger	ACC	√	√	√	√	√	○	○	
2015	LA-Challenger	ORC	√	√	√	√	√	○	√	0581
2015	LA-Challenger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2015	LA-Challenger	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0803, 0658, 1083, 1150
2015	LA-Challenger	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2015	LA-Challenger	PTS	√	√	√	√	√	○	√	1106
2015	LA-Challenger	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029

2015	LA-Challenger	ABS	√	√	√	√	√	√	√	0181,0055,0056
2015	LA-Challenger	RADIO	√	√	√	√	√	√	√	
2015	LA-Challenger	AMP	√	√	√	√	√	○	○	0083,0074
2015	LA-Challenger	DDM	√	√	√	√	√	√	√	
2015	LA-Challenger	PDM	√	√	√	√	√	√	√	
2015	LA-Challenger	HSM	√	√	√	√	√	√	√	
2015	LA-Challenger	EPS	√	√	√	√	√	○	○	
2015	LA-Challenger	ADCM	√	√	√	√	√	○	○	
2015	LA-Challenger	ICS	√	√	√	√	√	√	○	
2015	LA-Challenger	IPC	√	√	√	√	√	√	√	0428
2015	LA-Challenger	RFH	√	√	√	√	√	√	√	0561,0338,0648
2015	LA-Challenger	SCCM	√	√	√	√	√	○	√	
2015	LA-Challenger	LBSS	√	√	√	○	√	○	○	
2015	LA-Challenger	RBSS	√	√	√	○	√	○	○	
2015	R7-750	ORC	√	√	√	√	√	√	○	
2015	R7-750	BCM	√	√	√	√	√	√	○	
2015	R7-750	IPC	√	√	√	√	√	√	○	
2015	UF-200	PCM	√	√	√	√	√	√	√	0102,0237,0278,0944,0359,0827,1042,1201,0705,0927,0920,0103,0188,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0225,0280
2015	UF-200	TCM	√	√	√	√	√	○	√	0912,1119
2015	UF-200	ESM	√	√	√	√	√	○	○	
2015	UF-200	ACC	√	√	√	√	√	○	√	0061
2015	UF-200	ORC	√	√	√	√	√	√	√	0581
2015	UF-200	HVAC	√	√	√	√	√	√	√	0121,0462,0680
2015	UF-200	MSM	√	√	√	√	√	○	○	
2015	UF-200	OCM	√	√	√	√	√	○	√	0715
2015	UF-200	BCM	√	√	√	√	√	√	√	0095,0400,0155,0452,0424,0465,0506,0610,0559,0422,1076,1077,1138,0150,0152,1219,1221,1224,1225,1226,1235
2015	UF-200	PAM	√	√	√	√	√	√	√	
2015	UF-200	ABS	√	√	√	√	√	○	√	0653,0055
2015	UF-200	RADIO	√	√	√	√	√	√	√	
2015	UF-200	AMP	√	√	√	√	√	○	○	
2015	UF-200	DDM	√	√	√	√	√	√	√	
2015	UF-200	PDM	√	√	√	√	√	√	√	
2015	UF-200	DTCM	√	√	√	√	√	√	√	
2015	UF-200	DTCM	√	√	√	√	√	√	√	
2015	UF-200	EPS	√	√	√	√	√	○	○	
2015	UF-200	ICS	√	√	√	√	√	√	√	
2015	UF-200	IPC	√	√	√	√	√	√	√	0544
2015	UF-200	RFH	√	√	√	√	√	√	√	0338,0561,0609,0648
2015	UF-200	SCCM	√	√	√	√	√	○	√	
2015	UF-200	CSWM	√	√	√	√	√	√	√	
2015	UF-200	EPB	√	√	√	√	√	○	√	1136
2015	UF-200	FFCM	○	○	○	○	○	○	○	
2015	UF-200	LBSS	√	√	√	○	√	○	√	
2015	UF-200	PTU	√	√	√	○	√	○	○	0934
2015	UF-200	RBSS	√	√	√	○	√	○	√	
2015	UF-200	RRM	√	√	√	√	√	○	√	
2015	VM-ProMaster City	PCM	√	√	√	√	√	√	√	0102,0237,0278,0944,0359,0827,1042,1201,0705,0927,0920,0103,0188,0279,0202,0215,0386,0373,0378,0446,0447,0590,0596,0597,0628,0225,0280
2015	VM-ProMaster City	TCM	√	√	√	√	√	○	√	0912,1119
2015	VM-ProMaster City	ESM	√	√	√	√	√	○	○	
2015	VM-ProMaster City	ORC	○	√	√	√	√	○	○	
2015	VM-ProMaster City	HVAC	√	√	√	√	√	√	○	
2015	VM-ProMaster City	BCM	√	√	√	√	√	√	√	0452
2015	VM-ProMaster City	PAM	√	√	√	√	√	○	○	
2015	VM-ProMaster City	TPM	√	√	√	√	√	√	√	
2015	VM-ProMaster City	TPM	√	√	√	√	√	√	√	
2015	VM-ProMaster City	ABS	√	√	√	√	√	√	○	1089
2015	VM-ProMaster City	RADIO	√	√	√	√	√	○	√	
2015	VM-ProMaster City	IPC	√	√	√	√	√	√	○	
2015	VM-ProMaster City	ETM	√	√	√	√	√	○	√	
2015	VM-ProMaster City	TTM	√	√	√	√	√	○	√	
2016	JK-Wrangler	PCM	√	√	√	√	√	√	√	0102,0237,0278,0944,0359,0827,1042,1201,0705,0927,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0409,0225,0280,1123,0257,0322,0908,0472,0537,0691,0821,0615,1092,0216
2016	JK-Wrangler	TCM	√	√	√	√	√	○	○	0924,1094
2016	JK-Wrangler	ESM	√	√	√	√	√	√	○	
2016	JK-Wrangler	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152
2016	JK-Wrangler	ORC	√	√	√	√	√	○	√	0098,0581

2016	JK-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186, 1014, 1023, 0187, 0210, 0619, 1015
2016	JK-Wrangler	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2016	JK-Wrangler	ASBS	√	√	√	√	√	○	○	1071, 1098, 1099, 1100, 1101
2016	JK-Wrangler	WCM	√	√	√	√	√	○	√	0439
2016	JK-Wrangler	ITM	√	√	√	√	√	√	√	1066, 1179, 0584, 0547, 0551
2016	JK-Wrangler	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800
2016	JK-Wrangler	SAS	√	√	√	√	√	○	○	
2016	JK-Wrangler	ABS	√	√	√	√	√	√	√	0056, 0168
2016	JK-Wrangler	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426, 0602
2016	JK-Wrangler	AMP	√	√	√	√	√	○	√	0083, 0074
2016	JK-Wrangler	HFM	√	√	√	√	√	√	○	0492
2016	LX-300, Charger, Magnum, Grand Voyager	PCM	√	√	√	√	√	√	√	0257, 0216, 0133, 0312, 0616, 0821, 0952, 0932, 0948, 1034, 1148, 0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2016	LX-300, Charger, Magnum, Grand Voyager	TCM	√	√	√	√	√	○	√	0924, 1094, 0912
2016	LX-300, Charger, Magnum, Grand Voyager	ESM	√	√	√	√	√	※	○	
2016	LX-300, Charger, Magnum, Grand Voyager	ACC	√	√	√	√	√	○	○	
2016	LX-300, Charger, Magnum, Grand Voyager	ORC	√	√	√	√	√	○	√	0581
2016	LX-300, Charger, Magnum, Grand Voyager	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2016	LX-300, Charger, Magnum, Grand Voyager	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2016	LX-300, Charger, Magnum, Grand Voyager	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2016	LX-300, Charger, Magnum, Grand Voyager	PTS	√	√	√	√	√	○	√	1106
2016	LX-300, Charger, Magnum, Grand Voyager	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2016	LX-300, Charger, Magnum, Grand Voyager	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2016	LX-300, Charger, Magnum, Grand Voyager	ABS	√	√	√	√	√	√	√	0056, 0181, 0055
2016	LX-300, Charger, Magnum, Grand Voyager	RADIO	√	√	√	√	√	√	√	
2016	LX-300, Charger, Magnum, Grand Voyager	AMP	√	√	√	√	√	○	○	0083, 0074
2016	LX-300, Charger, Magnum, Grand Voyager	DDM	√	√	√	√	√	√	√	
2016	LX-300, Charger, Magnum, Grand Voyager	PDM	√	√	√	√	√	√	√	
2016	LX-300, Charger, Magnum, Grand Voyager	HSM	√	√	√	√	√	√	√	
2016	LX-300, Charger, Magnum, Grand Voyager	DTCM	√	√	√	√	√	√	○	
2016	LX-300, Charger, Magnum, Grand Voyager	EPS	√	√	√	√	√	○	○	
2016	LX-300, Charger, Magnum, Grand Voyager	ADCM	√	√	√	√	√	○	○	
2016	LX-300, Charger, Magnum, Grand Voyager	AFLS	√	√	√	√	√	√	○	0066
2016	LX-300, Charger, Magnum, Grand Voyager	LCS	√	√	√	√	√	√	○	
2016	LX-300, Charger, Magnum, Grand Voyager	IPC	√	√	√	√	√	√	√	0428
2016	LX-300, Charger, Magnum, Grand Voyager	BPTI	√	√	√	√	√	√	√	0581, 0338, 0648
2016	LX-300, Charger, Magnum, Grand Voyager	SCCM	√	√	√	√	√	○	√	
2016	LX-300, Charger, Magnum, Grand Voyager	FFCM	○	○	○	○	○	○	○	
2016	LX-300, Charger, Magnum, Grand Voyager	LBSS	√	√	√	○	√	○	○	
2016	LX-300, Charger, Magnum, Grand Voyager	RBSS	√	√	√	○	√	○	○	
2016	MK-Compass, Patriot	PCM	√	√	√	√	√	√	※	0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0225, 0280, 1191
2016	MK-Compass, Patriot	TCM	√	√	√	√	√	√	√	0190, 0228
2016	MK-Compass, Patriot	FDCM	√	√	√	√	√	√	√	
2016	MK-Compass, Patriot	CGW	√	√	√	√	√	√	√	0108, 0119, 0465, 0508, 0510, 0527, 0560, 0795, 0900, 1076, 1155, 1189, 1219, 1224, 1225, 1226, 0095, 0125, 0129, 0425, 0402, 0810, 0816, 0817, 0752
2016	MK-Compass, Patriot	ORC	√	√	√	√	√	○	√	0098
2016	MK-Compass, Patriot	MIC_CCN	√	√	√	√	√	√	√	1014, 1184, 1186, 1023, 0150, 0152
2016	MK-Compass, Patriot	HVAC	√	√	√	√	√	√	√	0121, 0498, 0462, 0680
2016	MK-Compass, Patriot	WCM	√	√	√	√	√	○	√	0143, 0366, 0439
2016	MK-Compass, Patriot	ITM	√	√	√	√	√	√	√	1066, 1178, 0579
2016	MK-Compass, Patriot	SAS	√	√	√	√	√	○	○	
2016	MK-Compass, Patriot	ABS	√	√	√	√	√	√	√	0566, 0168, 0578, 0568, 0056
2016	MK-Compass, Patriot	RADIO	√	√	√	√	√	※	※	0862, 0867, 0871, 0861, 0426
2016	MK-Compass, Patriot	AMP	√	√	√	√	√	○	√	0083, 0074
2016	MK-Compass, Patriot	HFM	√	√	√	√	√	√	○	0492
2016	RT-Caravan, Town & Country	PCM	√	√	√	√	√	√	√	0002, 0019, 0035, 0050, 0102, 0237, 0278, 0944, 0359, 0827, 0838, 0971, 1042, 1141, 1201, 0705, 0695, 0927, 1108, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0409, 0225, 0280, 1123, 0257, 0322, 0908, 0472, 0537, 0591, 0821, 0615, 0216
2016	RT-Caravan, Town & Country	TCM	√	√	√	√	√	√	√	0006, 0023, 0039, 0052, 0229, 0971, 1107
2016	RT-Caravan, Town & Country	CGW	√	√	√	√	√	√	√	0108, 0155, 0331, 0465, 0508, 0510, 0560, 0795, 1225, 1226, 0095, 0150, 0152, 0119, 0900, 1076, 1155, 1189, 1219, 1224, 1182, 1220, 1235
2016	RT-Caravan, Town & Country	ORC	√	√	√	√	√	○	√	0098, 0581
2016	RT-Caravan, Town & Country	MIC_CCN	√	√	√	√	√	√	√	1186, 1014, 1023, 0187, 0210, 0619, 1015

2016	RT-Caravan,Town & Country	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680,0462,0120,0277,0463,0469
2016	RT-Caravan,Town & Country	PLGM	√	√	√	√	√	√	√	0877,0199,0200
2016	RT-Caravan,Town & Country	MSM	√	√	√	√	√	√	√	0658,1083,1150,0112,0222,0381,0603
2016	RT-Caravan,Town & Country	FSM	√	√	√	√	√	√	○	1269,1272,0194,0201
2016	RT-Caravan,Town & Country	WCM	√	√	√	√	√	√	√	0143,0366,0613,0439
2016	RT-Caravan,Town & Country	SUNR	√	√	√	√	√	√	○	
2016	RT-Caravan,Town & Country	HIDT	√	√	√	√	√	√	○	0493
2016	RT-Caravan,Town & Country	AHBM	√	√	√	√	√	√	○	0132
2016	RT-Caravan,Town & Country	PTS	√	√	√	√	√	√	√	1106,0266
2016	RT-Caravan,Town & Country	ITM	√	√	√	√	√	√	√	1066,1178,0555
2016	RT-Caravan,Town & Country	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800
2016	RT-Caravan,Town & Country	SAS	√	√	√	√	√	○	○	
2016	RT-Caravan,Town & Country	ABS	√	√	√	√	√	√	√	0055,0056
2016	RT-Caravan,Town & Country	DVD	√	√	√	√	√	○	○	
2016	RT-Caravan,Town & Country	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2016	RT-Caravan,Town & Country	AMP	√	√	√	√	√	○	√	0083,0074
2016	RT-Caravan,Town & Country	HPM	√	√	√	√	√	√	○	0492
2016	RT-Caravan,Town & Country	VES2	√	√	√	√	√	√	√	
2016	RT-Caravan,Town & Country	VES3	√	√	√	√	√	√	√	
2016	RT-Caravan,Town & Country	DMFR	√	√	√	√	√	√	○	
2016	RT-Caravan,Town & Country	DMFL	√	√	√	√	√	√	√	
2016	RT-Caravan,Town & Country	DMRL	√	√	√	√	√	√	√	0622,0624,0630
2016	RT-Caravan,Town & Country	DMRR	√	√	√	√	√	√	√	0622,0624,0630
2016	RT-Caravan,Town & Country	PSDMR	√	√	√	√	√	○	○	1067,1070,0877,0106,0633
2016	RT-Caravan,Town & Country	PSDML	√	√	√	√	√	○	○	1067,1070,0877,0106,0633
2016	RT-Caravan,Town & Country	HSM	√	√	√	√	√	√	√	0512
2016	RT-Caravan,Town & Country	PEM	√	√	√	√	√	○	√	0338,0609,0648
2016	RT-Caravan,Town & Country	EPPM	√	√	√	√	√	○	√	
2016	RT-Caravan,Town & Country	LBSS	√	√	√	○	√	○	○	
2016	RT-Caravan,Town & Country	RBSS	√	√	√	○	√	○	○	
2016	D2-Ram Truck	PCM	√	√	√	√	√	√	√	0004,0021,0037,0102,0237,0278,0944,0359,0827,0840,0973,1042,1143,1201,0705,0734,0927,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0141,0225,0280,0435,0436,1044,1045,0558,0311,0842,1176,0142,0299,0303,0344,0345,0438,0204,1072
2016	D2-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2016	D2-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2016	D2-Ram Truck	HVAC	√	√	√	√	√	√	√	0498,0461,0680,0121
2016	D2-Ram Truck	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2016	D2-Ram Truck	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150,0892
2016	D2-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2016	D2-Ram Truck	ABS	√	√	√	√	√	√	√	0181,0055,0056
2016	D2-Ram Truck	RADIO	√	√	√	√	√	√	√	
2016	D2-Ram Truck	AMP	√	√	√	√	√	○	○	0083,0074
2016	D2-Ram Truck	DDM	√	√	√	√	√	√	√	
2016	D2-Ram Truck	PDM	√	√	√	√	√	√	√	
2016	D2-Ram Truck	HSM	√	√	√	√	√	√	√	
2016	D2-Ram Truck	DTCM	√	√	√	√	√	√	√	
2016	D2-Ram Truck	ITBM	√	√	√	√	√	○	○	
2016	D2-Ram Truck	ASCM	√	√	√	√	√	○	√	0513,1081,0459,1056,0256
2016	D2-Ram Truck	DCU	√	√	√	○	√	○	○	
2016	D2-Ram Truck	ICS	√	√	√	√	√	√	√	
2016	D2-Ram Truck	IPC	√	√	√	○	√	√	√	0334,0467
2016	D2-Ram Truck	RFH	√	√	√	√	√	√	√	0609,0338,0648
2016	D2-Ram Truck	SCCM	√	√	√	√	√	○	○	
2016	D2-Ram Truck	VSIM	√	√	√	○	√	√	○	
2016	D2-Ram Truck	VGT	√	√	√	○	√	○	○	
2016	D2-Ram Truck	EDM	√	√	√	○	√	√	○	
2016	DJ-Ram Truck	PCM	√	√	√	√	√	√	√	0004,0021,0037,0102,0237,0278,0944,0359,0827,0840,0973,1042,1143,1201,0705,0734,0927,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0141,0225,0280,0435,0436,1044,1045,0558,0311,0842,1072,1176,0142,0299,0303,0344,0345,0438,0204
2016	DJ-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2016	DJ-Ram Truck	FDCM	√	√	√	√	√	○	○	
2016	DJ-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2016	DJ-Ram Truck	HVAC	√	√	√	√	√	√	√	0498,0461,0680,0121
2016	DJ-Ram Truck	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2016	DJ-Ram Truck	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150,0892
2016	DJ-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106

2016	DJ-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2016	DJ-Ram Truck	RADIO	√	√	√	√	√	√	√	
2016	DJ-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2016	DJ-Ram Truck	DDM	√	√	√	√	√	√	√	
2016	DJ-Ram Truck	PDM	√	√	√	√	√	√	√	
2016	DJ-Ram Truck	HSM	√	√	√	√	√	√	√	
2016	DJ-Ram Truck	DTCM	√	√	√	√	√	√	√	
2016	DJ-Ram Truck	ITBM	√	√	√	√	√	○	○	
2016	DJ-Ram Truck	ASCM	√	√	√	√	√	○	√	0513, 1081, 0459, 1056, 0256
2016	DJ-Ram Truck	DCU	√	√	√	○	√	○	○	
2016	DJ-Ram Truck	ICS	√	√	√	√	√	√	√	
2016	DJ-Ram Truck	IPC	√	√	√	○	√	√	√	0334, 0467
2016	DJ-Ram Truck	BFH	√	√	√	√	√	√	√	0609, 0338, 0648
2016	DJ-Ram Truck	SCCM	√	√	√	√	√	○	○	
2016	DJ-Ram Truck	VSIM	√	√	√	○	√	√	○	
2016	DJ-Ram Truck	EDM	√	√	√	○	√	√	○	
2016	DS-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 0101, 0293, 0358, 0224, 1000, 0954, 0921, 0304, 0999, 1004, 0216, 0312, 0822, 0712, 0953, 0133, 0932, 0948, 1034, 1148, 1005, 1002, 1007, 1008
2016	DS-Ram Truck	TCM	√	√	√	√	√	○	√	0912
2016	DS-Ram Truck	ESM	√	√	√	√	√	○	○	
2016	DS-Ram Truck	OBC	√	√	√	√	√	√	√	0581
2016	DS-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2016	DS-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2016	DS-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2016	DS-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2016	DS-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2016	DS-Ram Truck	RADIO	√	√	√	√	√	√	√	
2016	DS-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2016	DS-Ram Truck	DDM	√	√	√	√	√	√	√	
2016	DS-Ram Truck	PDM	√	√	√	√	√	√	√	
2016	DS-Ram Truck	HSM	√	√	√	√	√	√	√	
2016	DS-Ram Truck	DTCM	√	√	√	√	√	√	√	
2016	DS-Ram Truck	EPS	√	√	√	√	√	○	○	0236
2016	DS-Ram Truck	ITBM	√	√	√	√	√	○	○	
2016	DS-Ram Truck	ASCM	√	√	√	√	√	○	√	0134, 1081, 1082, 0330, 0459, 1056, 0513, 0256
2016	DS-Ram Truck	ICS	√	√	√	√	√	√	√	
2016	DS-Ram Truck	IPC	√	√	√	○	√	√	√	0334
2016	DS-Ram Truck	BFH	√	√	√	√	√	√	√	0609, 0338, 0648
2016	DS-Ram Truck	SCCM	√	√	√	√	√	○	○	
2016	DS-Ram Truck	VSIM	√	√	√	○	√	√	○	
2016	DS-Ram Truck	EDM	√	√	√	○	√	√	○	
2016	DX-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 1044, 1045, 0558, 0722, 1050, 0311, 0842, 1072, 1176, 0756, 0142, 0299, 0303, 0344, 0345, 0397, 0438, 0395, 0204
2016	DX-Ram Truck	TCM	√	√	√	√	√	※	√	0829, 0912
2016	DX-Ram Truck	ESM	√	√	√	√	√	○	○	
2016	DX-Ram Truck	OBC	√	√	√	√	√	√	√	0581
2016	DX-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2016	DX-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2016	DX-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2016	DX-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2016	DX-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2016	DX-Ram Truck	RADIO	√	√	√	√	√	√	√	
2016	DX-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2016	DX-Ram Truck	DDM	√	√	√	√	√	√	√	
2016	DX-Ram Truck	PDM	√	√	√	√	√	√	√	
2016	DX-Ram Truck	HSM	√	√	√	√	√	√	√	
2016	DX-Ram Truck	DTCM	√	√	√	√	√	√	√	
2016	DX-Ram Truck	EPS	√	√	√	√	√	○	○	0236
2016	DX-Ram Truck	ITBM	√	√	√	√	√	○	○	
2016	DX-Ram Truck	ASCM	√	√	√	√	√	○	√	0134, 1081, 1082, 0330, 0459, 1056, 0513, 0256
2016	DX-Ram Truck	DCU	√	√	√	○	√	○	○	
2016	DX-Ram Truck	ICS	√	√	√	√	√	√	√	

2016	DX-Ram Truck	IPC	√	√	√	○	√	√	√	0334
2016	DX-Ram Truck	HFH	√	√	√	√	√	√	√	0609,0338,0648
2016	DX-Ram Truck	SCCM	√	√	√	√	√	○	○	
2016	DX-Ram Truck	VSIM	√	√	√	○	√	√	○	
2016	DX-Ram Truck	VGT	√	√	√	○	√	○	○	
2016	DX-Ram Truck	EDM	√	√	√	○	√	√	○	
2016	JS-Wrangler	PCM	√	√	√	√	√	√	√	1123,0257,0322,0908,0472,0637,0591,0821,0615,1092,0216
2016	JS-Wrangler	TCM	√	√	√	√	√	○	○	0924,1094
2016	JS-Wrangler	ESM	√	√	√	√	√	√	○	
2016	JS-Wrangler	CGW	√	√	√	√	√	√	√	0108,0119,0155,0331,0465,0508,0510,0560,0900,1076,1155,1189,1219,1224,1225,1226,1235,0095,1182,1220,0150,0152
2016	JS-Wrangler	ORC	√	√	√	√	√	○	√	0098,0581
2016	JS-Wrangler	MIC_CCN	√	√	√	√	√	√	○	1186,1014,1023,0187,0210,0619,1015
2016	JS-Wrangler	HVAC	√	√	√	√	√	√	√	0121,0498,0462,0680
2016	JS-Wrangler	WCM	√	√	√	√	√	○	√	0439
2016	JS-Wrangler	SAS	√	√	√	√	√	○	○	
2016	JS-Wrangler	ABS	√	√	√	√	√	√	√	0056,0168
2016	JS-Wrangler	RADIO	√	√	√	√	√	※	※	0862,0867,0871,0861,0426
2016	JC-Journey	PCM	√	√	√	√	√	√	√	0257,0216,0821,0133,0312,0616,0952,0932,0948,1034,1148,0002,0003,0019,0020,0035,0036,0050,0102,0237,0278,0944,0359,0827,0838,0835,0971,0972,1042,1141,1142,1201,0705,0695,0696,0733,0927,1108,1109,0920,1271,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0225,0280
2016	JC-Journey	TCM	√	√	√	√	√	√	√	0006,0023,0039,0052,0229,0971,1107
2016	JC-Journey	ORC	√	√	√	√	√	○	√	0098,0581,0990
2016	JC-Journey	HVAC	√	√	√	√	√	√	√	0121,0498,0461,0680
2016	JC-Journey	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150
2016	JC-Journey	PTS	√	√	√	√	√	√	√	0266,1106
2016	JC-Journey	ITM	√	√	√	√	√	√	√	0584,0555,0551,0553,1178
2016	JC-Journey	TPM	√	√	√	√	√	○	√	0793,0794,0799,0800,1029
2016	JC-Journey	ABS	√	√	√	√	√	√	√	0181,0055,0056
2016	JC-Journey	AMP	√	√	√	√	√	○	○	0083,0074
2016	JC-Journey	HPM	√	√	√	√	√	○	○	0492
2016	JC-Journey	VES3	√	√	√	√	√	√	○	
2016	JC-Journey	DDM	√	√	√	√	√	√	√	
2016	JC-Journey	PDM	√	√	√	√	√	√	√	
2016	JC-Journey	HSM	√	√	√	√	√	√	√	
2016	JC-Journey	DTCM	√	√	√	√	√	√	√	
2016	JC-Journey	EPPM	√	√	√	√	√	○	√	
2016	JC-Journey	ICS	√	√	√	√	√	√	○	
2016	JC-Journey	IPC	√	√	√	√	√	√	○	
2016	JC-Journey	HFH	√	√	√	√	√	√	√	0561,0338,0648
2016	JC-Journey	SCCM	√	√	√	√	√	○	○	
2016	JC-Journey	TGW	√	√	√	√	√	○	√	0144,1121
2016	JC-Journey	VTM	√	√	√	√	√	○	○	
2016	DD-Ram Truck	PCM	√	√	√	√	√	√	√	0004,0021,0037,0102,0237,0278,0944,0359,0827,0840,0973,1042,1143,1201,0705,0734,0927,0920,0103,0188,0279,0202,0215,0229,0386,0373,0378,0446,0447,0590,0596,0597,0628,0141,0225,0280,0435,0436,1044,1045,0558,0722,1050,0311,1072,1176,0756,0142,0299,0303,0344,0345,0397,0438,0395,0394
2016	DD-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2016	DD-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2016	DD-Ram Truck	HVAC	√	√	√	√	√	√	√	0498,0461,0680,0121
2016	DD-Ram Truck	MSM	√	√	√	√	√	√	√	0112,0222,0381,0603,0658,1083,1150
2016	DD-Ram Truck	BCM	√	√	√	√	√	√	√	0153,1219,1221,1224,1225,1226,1235,0452,0900,0150,0892
2016	DD-Ram Truck	PTS	√	√	√	√	√	√	√	0266,1106
2016	DD-Ram Truck	ABS	√	√	√	√	√	√	√	0181,0055,0056
2016	DD-Ram Truck	RADIO	√	√	√	√	√	√	√	
2016	DD-Ram Truck	AMP	√	√	√	√	√	○	○	0083,0074
2016	DD-Ram Truck	DDM	√	√	√	√	√	√	√	
2016	DD-Ram Truck	PDM	√	√	√	√	√	√	√	
2016	DD-Ram Truck	HSM	√	√	√	√	√	√	√	
2016	DD-Ram Truck	DTCM	√	√	√	√	√	√	√	
2016	DD-Ram Truck	ITBM	√	√	√	√	√	○	○	
2016	DD-Ram Truck	DCU	√	√	√	○	√	○	○	
2016	DD-Ram Truck	ICS	√	√	√	√	√	√	√	
2016	DD-Ram Truck	IPC	√	√	√	○	√	√	√	0334,0467
2016	DD-Ram Truck	HFH	√	√	√	√	√	√	√	0609,0338,0648
2016	DD-Ram Truck	SCCM	√	√	√	√	√	○	○	

2016	DD-Ram Truck	VSIM	√	√	√	○	√	√	○	
2016	DD-Ram Truck	VGT	√	√	√	○	√	○	○	
2016	DD-Ram Truck	EDM	√	√	√	○	√	√	○	
2016	DP-Ram Truck	PCM	√	√	√	√	√	√	√	0004, 0021, 0037, 0102, 0237, 0278, 0944, 0359, 0827, 0840, 0973, 1042, 1143, 1201, 0705, 0734, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0141, 0225, 0280, 0435, 0436, 1044, 1045, 0558, 0722, 1050, 0311, 1072, 1176, 0756, 0142, 0299, 0303, 0344, 0345, 0397, 0438, 0396, 0394
2016	DP-Ram Truck	TCM	√	√	√	√	√	√	√	0829
2016	DP-Ram Truck	ORC	√	√	√	√	√	√	√	0581
2016	DP-Ram Truck	HVAC	√	√	√	√	√	√	√	0498, 0461, 0680, 0121
2016	DP-Ram Truck	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2016	DP-Ram Truck	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150, 0892
2016	DP-Ram Truck	PTS	√	√	√	√	√	√	√	0266, 1106
2016	DP-Ram Truck	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2016	DP-Ram Truck	RADIO	√	√	√	√	√	√	√	
2016	DP-Ram Truck	AMP	√	√	√	√	√	○	○	0083, 0074
2016	DP-Ram Truck	DDM	√	√	√	√	√	√	√	
2016	DP-Ram Truck	PDM	√	√	√	√	√	√	√	
2016	DP-Ram Truck	HSM	√	√	√	√	√	√	√	
2016	DP-Ram Truck	DTCM	√	√	√	√	√	√	√	
2016	DP-Ram Truck	ITBM	√	√	√	√	√	○	○	
2016	DP-Ram Truck	DCU	√	√	√	○	√	○	○	
2016	DP-Ram Truck	ICS	√	√	√	√	√	√	√	
2016	DP-Ram Truck	IPC	√	√	√	○	√	√	√	0334, 0467
2016	DP-Ram Truck	RFH	√	√	√	√	√	√	√	0609, 0338, 0648
2016	DP-Ram Truck	SCCM	√	√	√	√	√	○	○	
2016	DP-Ram Truck	VSIM	√	√	√	○	√	√	○	
2016	DP-Ram Truck	VGT	√	√	√	○	√	○	○	
2016	DP-Ram Truck	EDM	√	√	√	○	√	√	○	
2016	JF-Freemont	PCM	√	√	√	√	√	√	√	0257, 0216, 0821, 0133, 0312, 0616, 0962, 0932, 0948, 1034, 1148, 0002, 0003, 0019, 0020, 0035, 0036, 0050, 0102, 0237, 0278, 0944, 0359, 0827, 0838, 0835, 0971, 0972, 1042, 1141, 1142, 1201, 0705, 0695, 0696, 0733, 0927, 1108, 1109, 0920, 1271, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2016	JF-Freemont	TCM	√	√	√	√	√	√	√	0006, 0023, 0039, 0052, 0229, 0971, 1107
2016	JF-Freemont	ORC	√	√	√	√	√	○	√	0098, 0581, 0990
2016	JF-Freemont	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2016	JF-Freemont	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2016	JF-Freemont	PTS	√	√	√	√	√	√	√	0266, 1106
2016	JF-Freemont	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178
2016	JF-Freemont	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2016	JF-Freemont	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2016	JF-Freemont	AMP	√	√	√	√	√	○	○	0083, 0074
2016	JF-Freemont	HPM	√	√	√	√	√	○	○	0492
2016	JF-Freemont	VES3	√	√	√	√	√	√	○	
2016	JF-Freemont	DDM	√	√	√	√	√	√	√	
2016	JF-Freemont	PDM	√	√	√	√	√	√	√	
2016	JF-Freemont	HSM	√	√	√	√	√	√	√	
2016	JF-Freemont	DTCM	√	√	√	√	√	√	√	
2016	JF-Freemont	EPPM	√	√	√	√	√	○	√	
2016	JF-Freemont	ICS	√	√	√	√	√	√	○	
2016	JF-Freemont	IPC	√	√	√	√	√	√	○	
2016	JF-Freemont	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2016	JF-Freemont	SCCM	√	√	√	√	√	○	○	
2016	JF-Freemont	TGW	√	√	√	√	√	○	√	1121, 0144
2016	JF-Freemont	VTM	√	√	√	√	√	○	○	
2016	LD-Charger	PCM	√	√	√	√	√	√	√	0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2016	LD-Charger	TCM	√	√	√	√	√	○	√	0924, 1094, 0912
2016	LD-Charger	ESM	√	√	√	√	√	√	○	
2016	LD-Charger	ACC	√	√	√	√	√	○	○	
2016	LD-Charger	ORC	√	√	√	√	√	○	√	0581
2016	LD-Charger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2016	LD-Charger	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2016	LD-Charger	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2016	LD-Charger	PTS	√	√	√	√	√	○	√	1106
2016	LD-Charger	ITM	√	√	√	√	√	√	√	0584, 0555, 0551, 0553, 1178

2016	LD-Charger	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2016	LD-Charger	ABS	√	√	√	√	√	√	√	0056, 0181, 0055
2016	LD-Charger	RADIO	√	√	√	√	√	√	√	
2016	LD-Charger	AMP	√	√	√	√	√	○	○	0083, 0074
2016	LD-Charger	DDM	√	√	√	√	√	√	√	
2016	LD-Charger	PDM	√	√	√	√	√	√	√	
2016	LD-Charger	HSM	√	√	√	√	√	√	√	
2016	LD-Charger	DTCM	√	√	√	√	√	√	○	
2016	LD-Charger	EPS	√	√	√	√	√	○	○	
2016	LD-Charger	ADCM	√	√	√	√	√	○	○	
2016	LD-Charger	ICS	√	√	√	√	√	√	○	
2016	LD-Charger	IPC	√	√	√	√	√	√	√	0428
2016	LD-Charger	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2016	LD-Charger	SCCM	√	√	√	√	√	○	√	
2016	LD-Charger	VSIM	√	√	√	○	√	√	○	
2016	LD-Charger	FFCM	○	○	○	○	○	○	○	
2016	LD-Charger	LBSS	√	√	√	○	√	○	○	
2016	LD-Charger	RBSS	√	√	√	○	√	○	○	
2016	PF-Dart	PCM	√	√	√	√	√	√	√	0909, 0927, 0102, 0103, 0137, 0183, 0215, 0231, 1145, 0216, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0920, 0188, 0279, 0202, 0396, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2016	PF-Dart	TCM	√	√	√	√	√	√	√	0961, 0176, 0531, 0627, 0703, 0829, 0228
2016	PF-Dart	ESM	√	√	√	√	√	○	√	
2016	PF-Dart	ORC	√	√	√	√	√	○	√	0581
2016	PF-Dart	HVAC	√	√	√	√	√	√	√	0121, 0462, 0680
2016	PF-Dart	OCM	√	√	√	√	√	○	√	0715
2016	PF-Dart	BCM	√	√	√	√	√	√	√	0095, 0400, 0155, 0452, 0255, 0424, 0465, 0606, 0510, 0559, 0422, 1076, 1077, 1219, 1221, 1224, 1225, 1226, 1235, 1138, 0150, 0152
2016	PF-Dart	PAM	√	√	√	√	√	○	○	
2016	PF-Dart	ABS	√	√	√	√	√	○	√	0181, 0653, 0059, 1089
2016	PF-Dart	RADIO	※	※	※	※	※	※	※	
2016	PF-Dart	AMP	√	√	√	√	√	○	○	
2016	PF-Dart	EPS	√	√	√	√	√	○	○	
2016	PF-Dart	ICS	√	√	√	√	√	√	○	
2016	PF-Dart	IPC	√	√	√	√	√	√	√	
2016	PF-Dart	RFH	√	√	√	√	√	√	√	0338, 0561, 0609, 0648
2016	PF-Dart	SCCM	√	√	√	√	√	○	○	
2016	PF-Dart	CSWM	√	√	√	√	√	√	√	
2016	PF-Dart	CTM	√	√	√	√	√	○	○	
2016	PF-Dart	LBSS	√	√	√	○	√	√	√	
2016	PF-Dart	RBSS	√	√	√	○	√	√	√	
2016	PF-Dart	EDM	√	√	√	○	√	√	○	
2016	ZD-Viper (Post-2013)	PCM	√	√	√	√	√	√	○	0826, 0927, 1146, 0215, 0628, 0377, 0590, 0625, 0626, 0631
2016	ZD-Viper (Post-2013)	ORC	√	√	√	√	√	√	√	0581
2016	ZD-Viper (Post-2013)	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2016	ZD-Viper (Post-2013)	OCM	√	√	√	√	√	○	○	0715
2016	ZD-Viper (Post-2013)	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2016	ZD-Viper (Post-2013)	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2016	ZD-Viper (Post-2013)	ABS	√	√	√	√	√	√	√	
2016	ZD-Viper (Post-2013)	RADIO	√	√	√	√	√	√	√	
2016	ZD-Viper (Post-2013)	AMP	√	√	√	√	√	○	○	0083, 0074
2016	ZD-Viper (Post-2013)	DDM	√	√	√	√	√	√	√	
2016	ZD-Viper (Post-2013)	PDM	√	√	√	√	√	√	√	
2016	ZD-Viper (Post-2013)	ADCM	√	√	√	√	√	○	○	
2016	ZD-Viper (Post-2013)	ICS	√	√	√	√	√	√	√	
2016	ZD-Viper (Post-2013)	IPC	√	√	√	√	√	√	√	
2016	ZD-Viper (Post-2013)	RFH	√	√	√	√	√	√	√	0561, 0648
2016	ZD-Viper (Post-2013)	SCCM	√	√	√	√	√	○	○	
2016	BF-Fiat 500L	PCM	√	√	√	√	√	√	√	0909, 0927, 0137, 0183, 0215, 0231, 0216, 1145
2016	BF-Fiat 500L	TCM	√	√	√	√	√	√	※	0531, 0176, 0627, 0703, 0829, 0951
2016	BF-Fiat 500L	ESM	√	√	√	√	√	√	√	
2016	BF-Fiat 500L	ORC	√	√	√	√	√	○	√	
2016	BF-Fiat 500L	HVAC	※	√	√	√	√	√	○	
2016	BF-Fiat 500L	BCM	√	√	√	√	√	√	√	0411, 0264
2016	BF-Fiat 500L	PAM	√	√	√	√	√	○	○	
2016	BF-Fiat 500L	TPM	√	√	√	√	√	√	√	
2016	BF-Fiat 500L	ABS	√	√	√	√	√	○	√	
2016	BF-Fiat 500L	EPS	√	√	√	√	√	○	○	
2016	BF-Fiat 500L	IPC	√	√	√	√	√	√	○	
2016	BF-Fiat 500L	ETM	√	√	√	√	√	○	√	

2016	KL-Cherokee	PCM	√	√	√	√	√	√	√	0216, 0312, 0353, 0569, 0591, 0616, 0701, 0952, 0948, 1034, 0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2016	KL-Cherokee	TCM	√	√	√	√	√	○	√	0912, 1119
2016	KL-Cherokee	ESM	√	√	√	√	√	○	○	
2016	KL-Cherokee	ACC	√	√	√	√	√	○	√	0061
2016	KL-Cherokee	ORC	√	√	√	√	√	√	√	0581
2016	KL-Cherokee	HVAC	√	√	√	√	√	√	√	0121, 0462, 0680
2016	KL-Cherokee	PLGM	√	√	√	√	√	√	○	
2016	KL-Cherokee	MSM	√	√	√	√	√	○	○	
2016	KL-Cherokee	OCM	√	√	√	√	√	○	√	0715
2016	KL-Cherokee	BCM	√	√	√	√	√	√	√	0095, 0400, 0155, 0452, 0424, 0417, 0465, 0506, 0510, 0559, 0422, 1076, 1077, 1219, 1221, 1224, 1225, 1226, 1235, 1138, 0150, 0152, 0326
2016	KL-Cherokee	AHLM	√	√	√	√	√	○	○	0193
2016	KL-Cherokee	PAM	√	√	√	√	√	√	√	
2016	KL-Cherokee	ABS	√	√	√	√	√	○	√	0065, 0653
2016	KL-Cherokee	RADIO	√	√	√	√	√	√	√	
2016	KL-Cherokee	AMP	√	√	√	√	√	○	○	
2016	KL-Cherokee	DDM	√	√	√	√	√	√	√	
2016	KL-Cherokee	PDM	√	√	√	√	√	√	√	
2016	KL-Cherokee	DTCM	√	√	√	√	√	√	√	
2016	KL-Cherokee	EPS	√	√	√	√	√	○	○	
2016	KL-Cherokee	ICS	√	√	√	√	√	√	√	
2016	KL-Cherokee	IPC	√	√	√	√	√	√	○	
2016	KL-Cherokee	HFH	√	√	√	√	√	√	√	0338, 0609, 0648
2016	KL-Cherokee	SCCM	√	√	√	√	√	√	○	
2016	KL-Cherokee	CSWM	√	√	√	√	√	√	√	
2016	KL-Cherokee	EPB	√	√	√	√	√	○	√	1136
2016	KL-Cherokee	ESL	√	√	√	√	√	○	√	
2016	KL-Cherokee	FFCM	※	※	※	※	※	○	※	
2016	KL-Cherokee	LBSS	√	√	√	○	√	○	√	
2016	KL-Cherokee	PTU	√	√	√	○	√	○	○	0934
2016	KL-Cherokee	RBSS	√	√	√	○	√	○	√	
2016	KL-Cherokee	RDM	√	√	√	○	√	○	○	0937
2016	KL-Cherokee	EDM	√	√	√	○	√	√	○	
2016	KL-Cherokee	DTV	√	√	√	√	√	√	√	
2016	YF-ProMaster	PCM	√	√	√	√	√	√	√	0247, 0309, 0353, 0569, 0591, 0712, 0963, 1001, 0998, 1004, 1006, 1007, 1008, 1079, 1034, 0002, 0019, 0035, 0050, 0102, 0237, 0278, 0944, 0359, 0827, 0838, 0971, 1042, 1141, 1201, 0705, 0695, 0927, 1108, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280, 0517, 0664
2016	YF-ProMaster	TCM	√	√	√	√	√	√	√	0355, 0176, 0531, 0627, 0703, 0829, 0951
2016	YF-ProMaster	ORC	√	√	√	√	√	○	√	
2016	YF-ProMaster	HVAC	√	√	√	√	√	√	○	
2016	YF-ProMaster	BCM	√	√	√	√	√	√	√	0413, 0412, 0452
2016	YF-ProMaster	PAM	√	√	√	√	√	○	○	
2016	YF-ProMaster	TPM	√	√	√	√	√	√	√	
2016	YF-ProMaster	ABS	√	√	√	√	√	○	√	
2016	YF-ProMaster	IPC	√	√	√	√	√	√	○	
2016	YF-ProMaster	ETM	√	√	√	√	√	○	√	
2016	NY-Ypsilon	ECM	√	√	√	※	√	√	√	
2016	NY-Ypsilon	TCM	√	√	√	○	√	√	√	
2016	NY-Ypsilon	ORC	√	√	√	√	√	√	√	
2016	NY-Ypsilon	HVAC	√	√	√	√	√	√	√	
2016	NY-Ypsilon	BCM	√	√	√	○	√	√	○	
2016	NY-Ypsilon	ABS	√	√	√	√	√	√	√	
2016	NY-Ypsilon	EPS	√	√	√	√	√	○	√	
2016	NY-Ypsilon	IPC	√	√	√	※	√	√	○	0542
2016	NY-Ypsilon	AHM	√	√	√	√	√	√	○	
2016	FF-500	PCM	√	√	√	√	√	√	√	0136
2016	FF-500	TCM	√	√	√	√	√	√	○	0355, 0176, 0531, 0627, 0703, 0829, 0951, 0634
2016	FF-500	ESM	√	√	√	○	√	○	○	
2016	FF-500	ORC	√	√	√	√	√	○	√	
2016	FF-500	HVAC	√	√	√	√	√	√	○	
2016	FF-500	BCM	√	√	√	√	√	√	√	
2016	FF-500	PTS	√	√	√	√	√	○	○	
2016	FF-500	TPM	√	√	√	√	√	√	√	
2016	FF-500	ABS	√	√	√	√	√	※	○	0057
2016	FF-500	RADIO	√	√	√	√	√	○	○	
2016	FF-500	BPCM	√	√	√	√	√	√	○	
2016	FF-500	EAC	√	√	√	√	√	○	○	
2016	FF-500	EPS	√	√	√	√	√	○	○	0236, 0573

2016	FF-500	IPC	√	√	√	√	√	√	○	0541, 0542
2016	FF-500	OBCM	√	√	√	√	√	○	○	
2016	FF-500	CTM	√	√	√	√	√	√	○	
2016	FF-500	VTM	√	√	√	√	√	○	○	
2016	FF-500	RBC	√	√	√	√	√	○	○	0757, 0844
2016	FF-500	EVCU	√	√	√	√	√	√	○	0094, 0520, 0519, 0681, 0213
2016	FF-500	PIM	√	√	√	√	√	○	○	
2016	4C	PCM	√	√	√	√	√	√	√	0927, 0373
2016	4C	TCM	√	√	√	√	√	√	※	
2016	4C	ORC	√	√	√	√	√	○	√	
2016	4C	BCM	√	√	√	○	√	√	√	0460, 0792
2016	4C	PAM	√	√	√	√	√	○	○	
2016	4C	TPM	√	√	√	√	√	○	√	
2016	4C	ABS	√	√	√	√	√	※	√	1089
2016	4C	IPC	√	√	√	○	√	√	○	
2016	BU-Renegade	ECM	√	√	√	○	√	√	√	0128, 0766, 1026, 0702, 0729, 0958, 0959, 0388, 0458, 0691, 0760, 0761, 0593, 0289, 0290, 0291, 0292, 0617, 0725, 0323, 0907, 0486, 0360, 1149, 0361, 0362
2016	BU-Renegade	TCM	√	√	√	√	√	○	○	
2016	BU-Renegade	ESM	√	√	√	○	√	√	√	
2016	BU-Renegade	ACC	√	√	√	○	√	√	√	
2016	BU-Renegade	ORC	√	√	√	○	√	○	√	
2016	BU-Renegade	HVAC	√	√	√	○	√	√	√	1275
2016	BU-Renegade	BCM	√	√	√	○	√	√	√	0460, 0610, 0611, 0612, 1180, 0674, 0675, 0676
2016	BU-Renegade	PAM	√	√	√	○	√	○	○	
2016	BU-Renegade	ABS	√	√	√	√	√	√	√	0385, 0655, 1264
2016	BU-Renegade	AMP	√	√	√	○	√	√	√	
2016	BU-Renegade	DTCM	√	√	√	○	√	○	○	
2016	BU-Renegade	EPS	√	√	√	√	√	○	√	
2016	BU-Renegade	IPC	√	√	√	○	√	√	√	
2016	BU-Renegade	RFH	√	√	√	○	√	√	○	0238, 0239, 0338
2016	BU-Renegade	CSWM	√	√	√	√	√	√	○	
2016	BU-Renegade	ESL	○	√	√	○	√	○	○	
2016	BU-Renegade	ETM	√	√	√	○	√	√	√	
2016	BU-Renegade	LBSS	√	√	√	○	√	√	○	
2016	BU-Renegade	RBSS	√	√	√	○	√	√	○	
2016	BU-Renegade	RBSS	√	√	√	○	√	√	○	
2016	BU-Renegade	HALF	√	√	√	○	√	○	√	
2016	BU-Renegade	RRM	√	√	√	○	√	√	√	
2016	BU-Renegade	TTM	√	√	√	○	√	√	○	
2016	DV-Vision	ORC	√	√	√	√	√	√	○	
2016	DV-Vision	BCM	√	√	√	√	√	√	○	
2016	DV-Vision	IPC	√	√	√	√	√	√	○	
2016	LA-Challenger	PCM	√	√	√	√	√	√	√	0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0229, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2016	LA-Challenger	TCM	√	√	√	√	√	○	√	0912
2016	LA-Challenger	ESM	√	√	√	√	√	√	○	
2016	LA-Challenger	ACC	√	√	√	√	√	○	○	
2016	LA-Challenger	ORC	√	√	√	√	√	○	√	0581
2016	LA-Challenger	HVAC	√	√	√	√	√	√	√	0121, 0498, 0461, 0680
2016	LA-Challenger	MSM	√	√	√	√	√	√	√	0112, 0222, 0381, 0603, 0658, 1083, 1150
2016	LA-Challenger	BCM	√	√	√	√	√	√	√	0153, 1219, 1221, 1224, 1225, 1226, 1235, 0452, 0900, 0150
2016	LA-Challenger	PTS	√	√	√	√	√	○	√	1106
2016	LA-Challenger	TPM	√	√	√	√	√	○	√	0793, 0794, 0799, 0800, 1029
2016	LA-Challenger	ABS	√	√	√	√	√	√	√	0181, 0055, 0056
2016	LA-Challenger	RADIO	√	√	√	√	√	√	√	
2016	LA-Challenger	AMP	√	√	√	√	√	○	○	0083, 0074
2016	LA-Challenger	DDM	√	√	√	√	√	√	√	
2016	LA-Challenger	PDM	√	√	√	√	√	√	√	
2016	LA-Challenger	HSM	√	√	√	√	√	√	√	
2016	LA-Challenger	EPS	√	√	√	√	√	○	○	
2016	LA-Challenger	ADCM	√	√	√	√	√	○	○	
2016	LA-Challenger	ICS	√	√	√	√	√	√	○	
2016	LA-Challenger	IPC	√	√	√	√	√	√	√	0428
2016	LA-Challenger	RFH	√	√	√	√	√	√	√	0561, 0338, 0648
2016	LA-Challenger	SCCM	√	√	√	√	√	○	√	
2016	LA-Challenger	LBSS	√	√	√	○	√	○	○	
2016	LA-Challenger	RBSS	√	√	√	○	√	○	○	
2016	R7-750	ORC	√	√	√	√	√	√	○	
2016	R7-750	BCM	√	√	√	√	√	√	○	
2016	R7-750	IPC	√	√	√	√	√	√	○	

2016	UF-200	PCM	√	√	√	√	√	√	√	0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2016	UF-200	TCM	√	√	√	√	√	○	√	0912, 1119
2016	UF-200	ESM	√	√	√	√	√	○	○	
2016	UF-200	ACC	√	√	√	√	√	○	√	0061
2016	UF-200	ORC	√	√	√	√	√	√	√	0581
2016	UF-200	HVAC	√	√	√	√	√	√	√	0121, 0462, 0680
2016	UF-200	MSM	√	√	√	√	√	○	○	
2016	UF-200	OCM	√	√	√	√	√	○	√	0715
2016	UF-200	BCM	√	√	√	√	√	√	√	0095, 0400, 0155, 0452, 0424, 0465, 0506, 0610, 0559, 0422, 1076, 1077, 1138, 0150, 0152, 1219, 1221, 1224, 1225, 1226, 1235
2016	UF-200	PAM	√	√	√	√	√	√	√	
2016	UF-200	ABS	√	√	√	√	√	○	√	0653, 0055
2016	UF-200	RADIO	√	√	√	√	√	√	√	
2016	UF-200	AMP	√	√	√	√	√	○	○	
2016	UF-200	DDM	√	√	√	√	√	√	√	
2016	UF-200	PDM	√	√	√	√	√	√	√	
2016	UF-200	DTCM	√	√	√	√	√	√	√	
2016	UF-200	EPS	√	√	√	√	√	○	○	
2016	UF-200	LCS	√	√	√	√	√	√	√	
2016	UF-200	IPC	√	√	√	√	√	√	√	0544
2016	UF-200	RFH	√	√	√	√	√	√	√	0338, 0561, 0609, 0648
2016	UF-200	SCCM	√	√	√	√	√	○	√	
2016	UF-200	CSWM	√	√	√	√	√	√	√	
2016	UF-200	EPB	√	√	√	√	√	○	√	1136
2016	UF-200	FFCM	○	○	○	○	○	○	○	
2016	UF-200	LBSS	√	√	√	○	√	○	√	
2016	UF-200	PTU	√	√	√	○	√	○	○	0934
2016	UF-200	RBSS	√	√	√	○	√	○	√	
2016	UF-200	RBM	√	√	√	√	√	○	√	
2016	VM-ProMaster City	PCM	√	√	√	√	√	√	√	0102, 0237, 0278, 0944, 0359, 0827, 1042, 1201, 0705, 0927, 0920, 0103, 0188, 0279, 0202, 0215, 0386, 0373, 0378, 0446, 0447, 0590, 0596, 0597, 0628, 0225, 0280
2016	VM-ProMaster City	TCM	√	√	√	√	√	○	√	0912, 1119
2016	VM-ProMaster City	ESM	√	√	√	√	√	○	○	
2016	VM-ProMaster City	ORC	○	√	√	√	√	○	○	
2016	VM-ProMaster City	HVAC	√	√	√	√	√	√	○	
2016	VM-ProMaster City	BCM	√	√	√	√	√	√	√	0452
2016	VM-ProMaster City	PAM	√	√	√	√	√	○	○	
2016	VM-ProMaster City	TPM	√	√	√	√	√	√	√	
2016	VM-ProMaster City	ABS	√	√	√	√	√	√	○	1089
2016	VM-ProMaster City	RADIO	√	√	√	√	√	○	√	
2016	VM-ProMaster City	IPC	√	√	√	√	√	√	○	
2016	VM-ProMaster City	ETM	√	√	√	√	√	○	√	
2016	VM-ProMaster City	TTM	√	√	√	√	√	○	√	
2016	B1-Renegade	PCM	√	√	√	√	√	○	○	
2016	B1-Renegade	TCM	√	√	√	√	√	○	√	
2016	B1-Renegade	ESM	√	√	√	√	√	○	○	
2016	B1-Renegade	ORC	○	√	√	√	√	○	○	
2016	B1-Renegade	HVAC	√	√	√	√	√	√	○	
2016	B1-Renegade	BCM	√	√	√	√	√	√	√	
2016	B1-Renegade	PAM	√	√	√	√	√	○	○	
2016	B1-Renegade	TPM	√	√	√	√	√	√	√	
2016	B1-Renegade	ABS	√	√	√	√	√	√	○	
2016	B1-Renegade	RADIO	√	√	√	√	√	○	√	
2016	B1-Renegade	IPC	√	√	√	√	√	√	○	
2016	B1-Renegade	ETM	√	√	√	√	√	○	√	
2016	B1-Renegade	TTM	√	√	√	√	√	○	√	
2016	DF-Ram 3500 Cad Chassis 10K	PCM	√	√	√	√	√	○	○	
2016	DF-Ram 3500 Cad Chassis 10K	TCM	√	√	√	√	√	○	√	
2016	DF-Ram 3500 Cad Chassis 10K	ORC	○	√	√	√	√	○	○	
2016	DF-Ram 3500 Cad Chassis 10K	HVAC	√	√	√	√	√	√	○	
2016	DF-Ram 3500 Cad Chassis 10K	BCM	√	√	√	√	√	√	√	
2016	DF-Ram 3500 Cad Chassis 10K	PAM	√	√	√	√	√	○	○	
2016	DF-Ram 3500 Cad Chassis 10K	TPM	√	√	√	√	√	√	√	
2016	DF-Ram 3500 Cad Chassis 10K	ABS	√	√	√	√	√	√	○	
2016	DF-Ram 3500 Cad Chassis 10K	RADIO	√	√	√	√	√	○	√	
2016	DF-Ram 3500 Cad Chassis 10K	IPC	√	√	√	√	√	√	○	
2016	DF-Ram 3500 Cad Chassis 10K	EDM	√	√	√	√	√	○	√	
2016	FB-500X	PCM	√	√	√	√	√	○	○	
2016	FB-500X	TCM	√	√	√	√	√	○	√	
2016	FB-500X	ORC	○	√	√	√	√	○	○	
2016	FB-500X	HVAC	√	√	√	√	√	√	○	

2016	FB-500X	BCM	√	√	√	√	√	√	√	
2016	FB-500X	PAM	√	√	√	√	√	〇	〇	
2016	FB-500X	ABS	√	√	√	√	√	√	〇	
2016	FB-500X	RADIO	√	√	√	√	√	〇	√	
2016	FB-500X	IPC	√	√	√	√	√	√	〇	
2016	FB-500X	ETM	√	√	√	√	√	〇	√	
2017	4C-ALFA 4C COUPE/CONV	ABS	√	√	√	√	○	√	√	
2017	4C-ALFA 4C COUPE/CONV	BCM	√	√	√	√	○	√	√	
2017	4C-ALFA 4C COUPE/CONV	ECM	√	√	√	√	○	√	√	
2017	4C-ALFA 4C COUPE/CONV	IPC	√	√	√	√	○	√	○	
2017	4C-ALFA 4C COUPE/CONV	ORC	√	√	√	√	○	○	√	
2017	4C-ALFA 4C COUPE/CONV	PAM	√	√	√	√	○	○	○	
2017	4C-ALFA 4C COUPE/CONV	TCM	√	√	√	√	○	○	○	
2017	4C-ALFA 4C COUPE/CONV	TPM	√	√	√	√	○	○	√	
2017	B1-RENEGADE (LATM)	ABS	√	√	√	√	○	√	√	
2017	B1-RENEGADE (LATM)	ACC	√	√	√	√	○	√	√	
2017	B1-RENEGADE (LATM)	AMP	√	√	√	√	○	√	√	
2017	B1-RENEGADE (LATM)	BCM	√	√	√	√	※	√	※	
2017	B1-RENEGADE (LATM)	CSWM	√	√	√	√	○	√	○	
2017	B1-RENEGADE (LATM)	DTCM	√	√	√	√	○	○	○	
2017	B1-RENEGADE (LATM)	ECM	√	√	√	√	※	√	※	
2017	B1-RENEGADE (LATM)	EPS	√	√	√	√	○	○	√	
2017	B1-RENEGADE (LATM)	ESL	√	√	√	√	○	√	√	
2017	B1-RENEGADE (LATM)	ESM	√	√	√	√	○	√	√	
2017	B1-RENEGADE (LATM)	ETM	√	√	√	√	○	※	√	
2017	B1-RENEGADE (LATM)	HALF	√	√	√	√	○	○	√	
2017	B1-RENEGADE (LATM)	HVAC	√	√	√	√	○	√	√	
2017	B1-RENEGADE (LATM)	IPC	√	√	√	√	※	√	√	
2017	B1-RENEGADE (LATM)	LBSS	√	√	√	√	○	√	○	
2017	B1-RENEGADE (LATM)	ORC	√	√	√	√	○	○	√	
2017	B1-RENEGADE (LATM)	PAM	√	√	√	√	○	○	○	
2017	B1-RENEGADE (LATM)	RBSS	√	√	√	√	○	√	○	
2017	B1-RENEGADE (LATM)	RFH	√	√	√	√	○	√	○	
2017	B1-RENEGADE (LATM)	RRM	√	√	√	√	○	√	√	
2017	B1-RENEGADE (LATM)	TCM	√	√	√	※	※	※	※	
2017	B1-RENEGADE (LATM)	TTM	√	√	√	√	○	√	○	
2017	BF-SODL	ABS	√	√	√	√	○	○	√	
2017	BF-SODL	BCM	√	√	√	√	○	√	√	
2017	BF-SODL	ECM	√	√	√	√	√	√	√	
2017	BF-SODL	EPS	√	√	√	√	○	○	○	
2017	BF-SODL	ESM	√	√	√	√	○	√	√	
2017	BF-SODL	ETM	√	√	√	√	○	※	√	
2017	BF-SODL	HVAC	√	√	√	√	○	√	○	
2017	BF-SODL	IPC	√	√	√	√	○	√	○	
2017	BF-SODL	ORC	√	√	√	√	○	○	※	
2017	BF-SODL	PAM	√	√	√	√	○	○	○	
2017	BF-SODL	TCM	√	√	√	√	※	※	※	
2017	BF-SODL	TPM	√	√	√	√	○	√	√	
2017	BQ-RENEGADE (CHINA)	ABS	√	√	√	√	○	√	√	
2017	BQ-RENEGADE (CHINA)	ACC	√	√	√	√	○	√	√	
2017	BQ-RENEGADE (CHINA)	AMP	√	√	√	√	○	√	√	
2017	BQ-RENEGADE (CHINA)	BCM	√	√	√	√	○	√	√	
2017	BQ-RENEGADE (CHINA)	CSWM	√	√	√	√	○	√	○	
2017	BQ-RENEGADE (CHINA)	DTCM	√	√	√	√	○	○	○	
2017	BQ-RENEGADE (CHINA)	ECM	√	√	√	√	※	√	※	
2017	BQ-RENEGADE (CHINA)	EPS	√	√	√	√	○	○	√	
2017	BQ-RENEGADE (CHINA)	ESL	√	√	√	√	○	√	√	
2017	BQ-RENEGADE (CHINA)	ESM	√	√	√	√	○	※	√	
2017	BQ-RENEGADE (CHINA)	ETM	√	√	√	√	○	※	√	
2017	BQ-RENEGADE (CHINA)	HALF	√	√	√	√	○	○	√	
2017	BQ-RENEGADE (CHINA)	HVAC	√	√	√	√	○	√	√	
2017	BQ-RENEGADE (CHINA)	IPC	√	√	√	√	※	√	√	
2017	BQ-RENEGADE (CHINA)	LBSS	√	√	√	√	○	√	○	
2017	BQ-RENEGADE (CHINA)	ORC	√	√	√	√	○	○	√	
2017	BQ-RENEGADE (CHINA)	PAM	√	√	√	√	○	○	○	
2017	BQ-RENEGADE (CHINA)	RBSS	√	√	√	√	○	√	○	
2017	BQ-RENEGADE (CHINA)	RFH	√	√	√	√	○	√	○	
2017	BQ-RENEGADE (CHINA)	RRM	√	√	√	√	○	√	√	
2017	BQ-RENEGADE (CHINA)	TCM	√	√	√	※	※	※	※	
2017	BQ-RENEGADE (CHINA)	TTM	√	√	√	√	○	√	○	
2017	BU-RENEGADE	ABS	√	√	√	√	○	√	√	
2017	BU-RENEGADE	ACC	√	√	√	√	○	√	√	
2017	BU-RENEGADE	AMP	√	√	√	√	○	√	√	
2017	BU-RENEGADE	BCM	√	√	√	√	○	√	√	
2017	BU-RENEGADE	CSWM	√	√	√	√	○	√	○	
2017	BU-RENEGADE	DTCM	√	√	√	√	○	○	○	
2017	BU-RENEGADE	ECM	√	√	√	※	※	※	※	

2017	BU-RENEGADE	EPS	√	√	√	√	o	○	√	
2017	BU-RENEGADE	ESL	√	√	√	√	o	√	√	
2017	BU-RENEGADE	ESM	√	√	√	√	o	√	√	
2017	BU-RENEGADE	ETM	√	√	√	√	o	※	√	
2017	BU-RENEGADE	HALF	√	√	√	√	o	○	√	
2017	BU-RENEGADE	HVAC	√	√	√	√	o	√	√	
2017	BU-RENEGADE	IPC	√	√	√	√	※	√	√	
2017	BU-RENEGADE	LBSS	√	√	√	√	o	√	○	
2017	BU-RENEGADE	ORC	√	√	√	√	o	○	√	
2017	BU-RENEGADE	PAM	√	√	√	√	o	○	○	
2017	BU-RENEGADE	RBSS	√	√	√	√	o	√	○	
2017	BU-RENEGADE	RFH	√	√	√	√	o	√	○	
2017	BU-RENEGADE	RRM	√	√	√	√	o	√	√	
2017	BU-RENEGADE	TCM	√	√	√	※	※	※	※	
2017	BU-RENEGADE	TTM	√	√	√	√	o	√	○	
2017	D2-Ram 3500 Pickup	ABS	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	AMP	√	√	√	√	o	○	√	
2017	D2-Ram 3500 Pickup	ASCM	√	√	√	√	o	○	√	
2017	D2-Ram 3500 Pickup	BCM	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	DCU	√	√	√	○	o	○	○	
2017	D2-Ram 3500 Pickup	DOORS	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	DTCM	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	ECM	√	√	√	√	√	√	√	
2017	D2-Ram 3500 Pickup	EDM	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	HSM	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	HVAC	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	ICS	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	IPC	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	ITBM	√	√	√	√	o	○	○	
2017	D2-Ram 3500 Pickup	MSM	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	ORC	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	PTS	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	RADIO	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	RFH	√	√	√	√	o	√	√	
2017	D2-Ram 3500 Pickup	SCCM	√	√	√	√	o	○	○	
2017	D2-Ram 3500 Pickup	TCM	√	√	√	√	√	√	√	
2017	D2-Ram 3500 Pickup	VGT	√	√	√	○	○	○	○	
2017	D2-Ram 3500 Pickup	VSIM	√	√	√	√	o	√	○	
2017	DD-Ram 3500 Cab Chassis	ABS	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	AMP	√	√	√	√	o	○	√	
2017	DD-Ram 3500 Cab Chassis	BCM	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	DCU	√	√	√	○	o	○	○	
2017	DD-Ram 3500 Cab Chassis	DOORS	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	DTCM	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	ECM	√	√	√	√	√	√	√	
2017	DD-Ram 3500 Cab Chassis	EDM	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	HSM	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	HVAC	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	ICS	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	IPC	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	ITBM	√	√	√	√	o	○	○	
2017	DD-Ram 3500 Cab Chassis	MSM	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	ORC	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	PTS	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	RADIO	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	RFH	√	√	√	√	o	√	√	
2017	DD-Ram 3500 Cab Chassis	SCCM	√	√	√	√	o	○	○	
2017	DD-Ram 3500 Cab Chassis	TCM	√	√	√	√	√	√	√	
2017	DD-Ram 3500 Cab Chassis	VGT	√	√	√	√	o	○	○	
2017	DD-Ram 3500 Cab Chassis	VSIM	√	√	√	√	o	√	○	
2017	DF-Ram 3500 cab chassis 10K	ABS	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	AMP	√	√	√	√	o	○	√	
2017	DF-Ram 3500 cab chassis 10K	BCM	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	DCU	√	√	√	○	o	○	○	
2017	DF-Ram 3500 cab chassis 10K	DOORS	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	DTCM	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	ECM	√	√	√	√	√	√	√	
2017	DF-Ram 3500 cab chassis 10K	EDM	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	HSM	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	HVAC	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	ICS	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	IPC	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	ITBM	√	√	√	√	o	○	○	
2017	DF-Ram 3500 cab chassis 10K	MSM	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	ORC	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	PTS	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	RADIO	√	√	√	√	o	√	√	

2017	DF-Ram 3500 cab chassis 10K	RFH	√	√	√	√	o	√	√	
2017	DF-Ram 3500 cab chassis 10K	SCCM	√	√	√	√	o	o	o	
2017	DF-Ram 3500 cab chassis 10K	TCM	√	√	√	√	√	√	√	
2017	DF-Ram 3500 cab chassis 10K	VGT	√	√	√	o	o	o	o	
2017	DF-Ram 3500 cab chassis 10K	VSIM	√	√	√	√	o	√	o	
2017	DJ-Ram 2500	ABS	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	AMP	√	√	√	√	o	o	√	
2017	DJ-Ram 2500	ASCM	√	√	√	√	o	o	√	
2017	DJ-Ram 2500	BCM	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	DCU	√	√	√	o	o	o	o	
2017	DJ-Ram 2500	DOORS	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	DTCM	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	ECM	√	√	√	√	√	√	√	
2017	DJ-Ram 2500	EDM	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	FDCM	√	√	√	√	o	o	o	
2017	DJ-Ram 2500	HSM	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	HVAC	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	ICS	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	IPC	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	ITBM	√	√	√	√	o	o	o	
2017	DJ-Ram 2500	MSM	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	ORC	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	PTS	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	RADIO	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	RFH	√	√	√	√	o	√	√	
2017	DJ-Ram 2500	SCCM	√	√	√	√	o	o	o	
2017	DJ-Ram 2500	TCM	√	√	√	√	√	√	√	
2017	DJ-Ram 2500	VGT	√	√	√	o	o	o	o	
2017	DJ-Ram 2500	VSIM	√	√	√	√	o	√	o	
2017	DP-Ram 4500/5500	ABS	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	AMP	√	√	√	√	o	o	√	
2017	DP-Ram 4500/5500	BCM	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	DCU	√	√	√	o	o	o	o	
2017	DP-Ram 4500/5500	DOORS	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	DTCM	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	ECM	√	√	√	√	√	√	√	
2017	DP-Ram 4500/5500	EDM	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	HSM	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	HVAC	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	ICS	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	IPC	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	ITBM	√	√	√	√	o	o	o	
2017	DP-Ram 4500/5500	MSM	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	ORC	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	PTS	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	RADIO	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	RFH	√	√	√	√	o	√	√	
2017	DP-Ram 4500/5500	SCCM	√	√	√	√	o	o	o	
2017	DP-Ram 4500/5500	TCM	√	√	√	√	√	√	√	
2017	DP-Ram 4500/5500	VGT	√	√	√	o	o	o	o	
2017	DP-Ram 4500/5500	VSIM	√	√	√	√	o	√	o	
2017	DS-Ram 1500	ABS	√	√	√	√	o	√	√	
2017	DS-Ram 1500	AMP	√	√	√	√	o	o	√	
2017	DS-Ram 1500	ASCM	√	√	√	√	o	o	√	
2017	DS-Ram 1500	BCM	√	√	√	√	o	√	√	
2017	DS-Ram 1500	DOORS	√	√	√	√	o	√	√	
2017	DS-Ram 1500	DTCM	√	√	√	√	o	√	√	
2017	DS-Ram 1500	ECM	√	√	√	√	※	√	√	
2017	DS-Ram 1500	EDM	√	√	√	√	o	√	√	
2017	DS-Ram 1500	EPS	√	√	√	√	o	o	o	
2017	DS-Ram 1500	ESM	√	√	√	√	o	o	o	
2017	DS-Ram 1500	HSM	√	√	√	√	o	√	√	
2017	DS-Ram 1500	HVAC	√	√	√	√	o	√	√	
2017	DS-Ram 1500	ICS	√	√	√	√	o	√	√	
2017	DS-Ram 1500	IPC	√	√	√	√	o	√	√	
2017	DS-Ram 1500	ITBM	√	√	√	√	o	o	o	
2017	DS-Ram 1500	MSM	√	√	√	√	o	√	√	
2017	DS-Ram 1500	ORC	√	√	√	√	o	√	√	
2017	DS-Ram 1500	PTS	√	√	√	√	o	√	√	
2017	DS-Ram 1500	RADIO	√	√	√	√	o	√	√	
2017	DS-Ram 1500	RFH	√	√	√	√	o	√	√	
2017	DS-Ram 1500	SCCM	√	√	√	√	o	o	o	
2017	DS-Ram 1500	TCM	√	√	√	√	√	o	√	
2017	DS-Ram 1500	VSIM	√	√	√	√	o	√	o	
2017	DX-Ram (Mexico)	ABS	√	√	√	√	o	√	√	
2017	DX-Ram (Mexico)	AMP	√	√	√	√	o	o	√	
2017	DX-Ram (Mexico)	ASCM	√	√	√	√	o	o	√	

2017	DX-Ram (Mexico)	BCM	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	DCU	√	√	√	○	○	○	○	
2017	DX-Ram (Mexico)	DOORS	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	DTCM	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	ECM	√	√	√	√	√	√	√	
2017	DX-Ram (Mexico)	EDM	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	EPS	√	√	√	√	○	○	○	
2017	DX-Ram (Mexico)	ESM	√	√	√	√	○	○	○	
2017	DX-Ram (Mexico)	HSM	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	HVAC	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	ICS	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	IPC	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	ITBM	√	√	√	√	○	○	○	
2017	DX-Ram (Mexico)	MSM	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	ORC	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	PTS	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	RADIO	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	RFH	√	√	√	√	○	√	√	
2017	DX-Ram (Mexico)	SCCM	√	√	√	√	○	○	○	
2017	DX-Ram (Mexico)	TCM	√	√	√	√	※	※	√	
2017	DX-Ram (Mexico)	VGT	√	√	√	○	○	○	○	
2017	DX-Ram (Mexico)	VSIM	√	√	√	√	○	√	○	
2017	FB-500X	ABS	√	√	√	√	○	√	√	
2017	FB-500X	ACC	√	√	√	√	○	√	√	
2017	FB-500X	AMP	√	√	√	√	○	√	√	
2017	FB-500X	BCM	√	√	√	√	○	√	√	
2017	FB-500X	CSWM	√	√	√	√	○	√	○	
2017	FB-500X	DTCM	√	√	√	√	○	○	○	
2017	FB-500X	ECM	√	√	√	√	※	√	√	
2017	FB-500X	EPS	√	√	√	√	○	○	√	
2017	FB-500X	ESL	√	√	√	√	○	√	√	
2017	FB-500X	ESM	√	√	√	√	○	√	√	
2017	FB-500X	ETM	√	√	√	√	○	※	√	
2017	FB-500X	HALF	√	√	√	√	○	○	√	
2017	FB-500X	HVAC	√	√	√	√	○	√	√	
2017	FB-500X	IPC	√	√	√	√	○	√	√	
2017	FB-500X	LBSS	√	√	√	√	○	√	○	
2017	FB-500X	ORC	√	√	√	√	○	○	√	
2017	FB-500X	PAM	√	√	√	√	○	○	○	
2017	FB-500X	RBSS	√	√	√	√	○	√	○	
2017	FB-500X	RFH	√	√	√	√	○	√	○	
2017	FB-500X	RRM	√	√	√	√	○	√	√	
2017	FB-500X	TCM	√	√	√	※	※	○	※	
2017	FF-500	ABS	√	√	√	√	○	※	○	
2017	FF-500	BCM	√	√	√	√	○	√	√	
2017	FF-500	BPCM	√	√	√	√	○	√	○	
2017	FF-500	EAC	√	√	√	√	○	○	○	
2017	FF-500	ECM	√	√	√	√	※	√	√	
2017	FF-500	EPS	√	√	√	√	○	○	○	
2017	FF-500	ESM	√	√	√	○	○	○	○	
2017	FF-500	ETM	√	√	√	√	○	√	√	
2017	FF-500	EVCU	√	√	√	√	○	√	○	
2017	FF-500	HVAC	√	√	√	√	○	√	○	
2017	FF-500	IPC	√	√	√	√	○	√	※	
2017	FF-500	OBCM	√	√	√	√	○	○	○	
2017	FF-500	ORC	√	√	√	√	○	○	√	
2017	FF-500	PIM	√	√	√	√	○	○	○	
2017	FF-500	PTS	√	√	√	√	○	○	○	
2017	FF-500	RBC	√	√	√	√	○	○	○	
2017	FF-500	TCM	√	√	√	√	○	√	○	
2017	FF-500	TPM	√	√	√	√	○	√	√	
2017	FF-500	VTM	√	√	√	√	○	○	○	
2017	JT-Wrangler	ABS	√	√	√	√	○	√	√	
2017	JT-Wrangler	CGW	√	√	√	√	○	√	√	
2017	JT-Wrangler	ECM	√	√	√	√	○	√	√	
2017	JT-Wrangler	ESM	√	√	√	√	○	√	○	
2017	JT-Wrangler	HVAC	√	√	√	√	○	√	√	
2017	JT-Wrangler	MIC/CCN	√	√	√	√	○	√	√	
2017	JT-Wrangler	ORC	√	√	√	√	○	○	√	
2017	JT-Wrangler	RADIO	√	√	√	√	○	※	※	
2017	JT-Wrangler	SAS	√	√	√	√	○	○	○	
2017	JT-Wrangler	TCM	√	√	√	√	○	○	○	
2017	JT-Wrangler	WCM/TPMS	√	√	√	√	○	○	√	
2017	JC-Journey	ABS	√	√	√	√	○	√	√	
2017	JC-Journey	AMP	√	√	√	√	○	○	√	
2017	JC-Journey	BCM	√	√	√	√	○	√	√	
2017	JC-Journey	DOORS	√	√	√	√	○	√	√	

2017	JC-Journey	DTCM	√	√	√	√	o	√	√	
2017	JC-Journey	ECM	√	√	√	√	※	√	√	
2017	JC-Journey	EPPM	√	√	√	√	o	o	√	
2017	JC-Journey	HFM	√	√	√	√	o	o	√	
2017	JC-Journey	HSM	√	√	√	√	o	√	√	
2017	JC-Journey	HVAC	√	√	√	√	o	√	√	
2017	JC-Journey	ICS	√	√	√	√	o	√	√	
2017	JC-Journey	IPC	√	√	√	√	o	√	√	
2017	JC-Journey	ITM	√	√	√	√	o	√	√	
2017	JC-Journey	ORC	√	√	√	√	o	o	√	
2017	JC-Journey	PTS	√	√	√	√	o	√	√	
2017	JC-Journey	RFH	√	√	√	√	o	√	√	
2017	JC-Journey	SCCM	√	√	√	√	o	o	o	
2017	JC-Journey	TCM	√	√	√	√	√	√	√	
2017	JC-Journey	TGW	√	√	√	√	o	o	√	
2017	JC-Journey	TPM	√	√	√	√	o	o	√	
2017	JC-Journey	VES3	√	√	√	√	o	√	o	
2017	JC-Journey	VTM	√	√	√	√	o	o	o	
2017	JF-Freemont	ABS	√	√	√	√	o	√	√	
2017	JF-Freemont	AMP	√	√	√	√	o	o	√	
2017	JF-Freemont	BCM	√	√	√	√	o	√	√	
2017	JF-Freemont	DOORS	√	√	√	√	o	√	√	
2017	JF-Freemont	DTCM	√	√	√	√	o	√	√	
2017	JF-Freemont	ECM	√	√	√	√	※	√	√	
2017	JF-Freemont	EPPM	√	√	√	√	o	o	√	
2017	JF-Freemont	HFM	√	√	√	√	o	o	√	
2017	JF-Freemont	HSM	√	√	√	√	o	√	√	
2017	JF-Freemont	HVAC	√	√	√	√	o	√	√	
2017	JF-Freemont	ICS	√	√	√	√	o	√	√	
2017	JF-Freemont	IPC	√	√	√	√	o	√	√	
2017	JF-Freemont	ITM	√	√	√	√	o	√	√	
2017	JF-Freemont	ORC	√	√	√	√	o	o	√	
2017	JF-Freemont	PTS	√	√	√	√	o	√	√	
2017	JF-Freemont	RFH	√	√	√	√	o	√	√	
2017	JF-Freemont	SCCM	√	√	√	√	o	o	o	
2017	JF-Freemont	TCM	√	√	√	√	√	√	√	
2017	JF-Freemont	TGW	√	√	√	√	o	o	√	
2017	JF-Freemont	TPM	√	√	√	√	o	o	√	
2017	JF-Freemont	VES3	√	√	√	√	o	√	o	
2017	JF-Freemont	VTM	√	√	√	√	o	o	o	
2017	JK-Wrangler	ABS	√	√	√	√	o	√	√	
2017	JK-Wrangler	AMP	√	√	√	√	o	o	√	
2017	JK-Wrangler	ASBS	√	√	√	√	o	o	o	
2017	JK-Wrangler	CGW	√	√	√	√	o	√	√	
2017	JK-Wrangler	ECM	√	√	√	√	※	√	√	
2017	JK-Wrangler	ESM	√	√	√	√	o	√	o	
2017	JK-Wrangler	HFM	√	√	√	√	o	√	o	
2017	JK-Wrangler	HVAC	√	√	√	√	o	√	√	
2017	JK-Wrangler	ITM	√	√	√	√	o	√	√	
2017	JK-Wrangler	MIC/CCN	√	√	√	√	o	√	√	
2017	JK-Wrangler	ORC	√	√	√	√	o	o	√	
2017	JK-Wrangler	RADIO	√	√	√	√	o	※	※	
2017	JK-Wrangler	SAS	√	√	√	√	o	o	o	
2017	JK-Wrangler	TCM	√	√	√	√	o	o	o	
2017	JK-Wrangler	TPM	√	√	√	√	o	o	√	
2017	JK-Wrangler	WCM/TPMS	√	√	√	√	o	o	√	
2017	KL-Cherokee	ABS	√	√	√	√	o	√	√	
2017	KL-Cherokee	ACC	√	√	√	√	o	o	√	
2017	KL-Cherokee	AHLM	√	√	√	√	o	o	o	
2017	KL-Cherokee	AMP	√	√	√	√	o	o	o	
2017	KL-Cherokee	BCM	√	√	√	√	o	√	√	
2017	KL-Cherokee	CSWM	√	√	√	√	o	√	√	
2017	KL-Cherokee	DOORS	√	√	√	√	o	√	√	
2017	KL-Cherokee	DTCM	√	√	√	√	o	√	√	
2017	KL-Cherokee	DTV	√	√	√	√	o	√	√	
2017	KL-Cherokee	ECM	√	√	√	√	※	√	√	
2017	KL-Cherokee	EDM	√	√	√	o	o	√	o	
2017	KL-Cherokee	EPB	√	√	√	√	o	o	√	
2017	KL-Cherokee	EPS	√	√	√	√	o	o	o	
2017	KL-Cherokee	ESL	√	√	√	√	o	o	√	
2017	KL-Cherokee	ESM	√	√	√	√	o	√	o	
2017	KL-Cherokee	FFCM	√	√	√	√	o	o	√	
2017	KL-Cherokee	HVAC	√	√	√	√	o	√	√	
2017	KL-Cherokee	ICS	√	√	√	√	o	√	√	
2017	KL-Cherokee	IPC	√	√	√	√	o	√	√	
2017	KL-Cherokee	LBSS	√	√	√	√	o	o	√	
2017	KL-Cherokee	MSM	√	√	√	√	o	o	o	

2017	KL-Cherokee	OCM	√	√	√	√	o	○	√	
2017	KL-Cherokee	ORC	√	√	√	√	o	√	√	
2017	KL-Cherokee	PAM	√	√	√	√	o	√	√	
2017	KL-Cherokee	PLGM	√	√	√	√	o	√	○	
2017	KL-Cherokee	PTU	√	√	√	○	o	○	○	
2017	KL-Cherokee	RADIO	√	√	√	√	o	√	√	
2017	KL-Cherokee	RBSS	√	√	√	√	o	○	√	
2017	KL-Cherokee	RDM	√	√	√	○	o	○	○	
2017	KL-Cherokee	RFH	√	√	√	√	o	√	√	
2017	KL-Cherokee	SCCM	√	√	√	√	o	√	○	
2017	KL-Cherokee	TCM	√	√	√	√	√	○	√	
2017	LA-Challenger	ABS	√	√	√	√	o	√	√	
2017	LA-Challenger	ACC	√	√	√	√	o	○	○	
2017	LA-Challenger	ADCM	√	√	√	√	o	○	○	
2017	LA-Challenger	AMP	√	√	√	√	o	○	√	
2017	LA-Challenger	BCM	√	√	√	√	o	√	√	
2017	LA-Challenger	DOORS	√	√	√	√	o	√	√	
2017	LA-Challenger	DTCM	√	√	√	√	o	√	○	
2017	LA-Challenger	ECM	√	√	√	√	√	√	√	
2017	LA-Challenger	EPS	√	√	√	√	o	○	※	
2017	LA-Challenger	ESM	√	√	√	√	o	√	○	
2017	LA-Challenger	HSM	√	√	√	√	o	√	√	
2017	LA-Challenger	HVAC	√	√	√	√	o	√	√	
2017	LA-Challenger	ICS	√	√	√	√	o	√	√	
2017	LA-Challenger	IPC	√	√	√	√	o	√	√	
2017	LA-Challenger	LBSS	√	√	√	√	o	○	○	
2017	LA-Challenger	MSM	√	√	√	√	o	√	√	
2017	LA-Challenger	ORC	√	√	√	√	o	○	√	
2017	LA-Challenger	PTS	√	√	√	√	o	※	√	
2017	LA-Challenger	RADIO	√	√	√	√	o	√	√	
2017	LA-Challenger	RBSS	√	√	√	√	o	○	○	
2017	LA-Challenger	RFH	√	√	√	√	o	√	√	
2017	LA-Challenger	SCCM	√	√	√	√	o	○	√	
2017	LA-Challenger	TCM	√	√	√	√	√	○	√	
2017	LA-Challenger	TPM	√	√	√	√	o	○	√	
2017	LD-Charger	ABS	√	√	√	√	o	√	√	
2017	LD-Charger	ACC	√	√	√	√	o	○	○	
2017	LD-Charger	ADCM	√	√	√	√	o	○	○	
2017	LD-Charger	AMP	√	√	√	√	o	○	√	
2017	LD-Charger	BCM	√	√	√	√	o	√	√	
2017	LD-Charger	DOORS	√	√	√	√	o	√	√	
2017	LD-Charger	DSM	√	√	√	√	o	○	○	
2017	LD-Charger	DTCM	√	√	√	√	o	√	○	
2017	LD-Charger	ECM	√	√	√	√	√	√	√	
2017	LD-Charger	EPS	√	√	√	√	o	○	※	
2017	LD-Charger	ESM	√	√	√	√	o	√	○	
2017	LD-Charger	FFCM	√	√	√	√	o	○	○	
2017	LD-Charger	HSM	√	√	√	√	o	√	√	
2017	LD-Charger	HVAC	√	√	√	√	o	√	√	
2017	LD-Charger	ICS	√	√	√	√	o	√	√	
2017	LD-Charger	IPC	√	√	√	√	o	√	√	
2017	LD-Charger	ITM	√	√	√	√	o	√	√	
2017	LD-Charger	LBSS	√	√	√	√	o	○	○	
2017	LD-Charger	MSM	√	√	√	√	o	√	√	
2017	LD-Charger	ORC	√	√	√	√	o	○	√	
2017	LD-Charger	PTS	√	√	√	√	o	※	√	
2017	LD-Charger	RADIO	√	√	√	√	o	√	√	
2017	LD-Charger	RBSS	√	√	√	√	o	○	○	
2017	LD-Charger	RFH	√	√	√	√	o	√	√	
2017	LD-Charger	SCCM	√	√	√	√	o	○	√	
2017	LD-Charger	TCM	√	√	√	√	※	○	√	
2017	LD-Charger	TPM	√	√	√	√	o	○	√	
2017	LD-Charger	VSIM	√	√	√	√	o	√	○	
2017	LX-300,Charger,Magnum,Grand voyager	ABS	√	√	√	√	o	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	ACC	√	√	√	√	o	○	○	
2017	LX-300,Charger,Magnum,Grand voyager	ADCM	√	√	√	√	o	○	○	
2017	LX-300,Charger,Magnum,Grand voyager	AFLS	√	√	√	√	o	√	○	
2017	LX-300,Charger,Magnum,Grand voyager	AMP	√	√	√	√	o	○	√	
2017	LX-300,Charger,Magnum,Grand voyager	BCM	√	√	√	√	o	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	DOORS	√	√	√	√	o	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	DTCM	√	√	√	√	o	√	○	
2017	LX-300,Charger,Magnum,Grand voyager	ECM	√	√	√	√	√	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	EPS	√	√	√	√	o	○	※	
2017	LX-300,Charger,Magnum,Grand voyager	ESM	√	√	√	√	o	※	○	
2017	LX-300,Charger,Magnum,Grand voyager	FFCM	√	√	√	√	o	○	○	
2017	LX-300,Charger,Magnum,Grand voyager	HSM	√	√	√	√	o	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	HVAC	√	√	√	√	o	√	√	

2017	LX-300,Charger,Magnum,Grand voyager	ICS	√	√	√	√	○	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	IPC	√	√	√	√	○	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	ITM	√	√	√	√	○	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	LBSS	√	√	√	√	○	○	○	
2017	LX-300,Charger,Magnum,Grand voyager	MSM	√	√	√	√	○	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	ORC	√	√	√	√	○	○	√	
2017	LX-300,Charger,Magnum,Grand voyager	PTS	√	√	√	√	○	※	√	
2017	LX-300,Charger,Magnum,Grand voyager	RADIO	√	√	√	√	○	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	RBSS	√	√	√	√	○	○	○	
2017	LX-300,Charger,Magnum,Grand voyager	RFH	√	√	√	√	○	√	√	
2017	LX-300,Charger,Magnum,Grand voyager	SCCM	√	√	√	√	○	○	√	
2017	LX-300,Charger,Magnum,Grand voyager	TCM	√	√	√	√	※	○	√	
2017	LX-300,Charger,Magnum,Grand voyager	TPM	√	√	√	√	○	○	√	
2017	M1-COMPASS (BRAZIL)	ABS	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	ACC	√	√	√	√	○	○	√	
2017	M1-COMPASS (BRAZIL)	AMP	√	√	√	√	○	√	○	
2017	M1-COMPASS (BRAZIL)	BCM	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	CSWM	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	DTCM	√	√	√	√	○	○	○	
2017	M1-COMPASS (BRAZIL)	DTV	√	√	√	√	○	√	○	
2017	M1-COMPASS (BRAZIL)	ECM	√	√	√	√	※	√	※	
2017	M1-COMPASS (BRAZIL)	EPS	√	√	√	√	○	○	√	
2017	M1-COMPASS (BRAZIL)	ESL	√	√	√	√	○	※	※	
2017	M1-COMPASS (BRAZIL)	ESM	√	√	√	√	○	○	√	
2017	M1-COMPASS (BRAZIL)	ETM	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	FFCM	√	√	√	√	○	○	√	
2017	M1-COMPASS (BRAZIL)	HVAC	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	ICS	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	IPC	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	LBSS	√	√	√	√	○	√	○	
2017	M1-COMPASS (BRAZIL)	MSM	√	√	√	√	○	√	○	
2017	M1-COMPASS (BRAZIL)	OCM	√	√	√	√	○	○	√	
2017	M1-COMPASS (BRAZIL)	ORC	√	√	√	√	○	○	√	
2017	M1-COMPASS (BRAZIL)	PAM	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	PLGM	√	√	√	√	○	√	※	
2017	M1-COMPASS (BRAZIL)	RBSS	√	√	√	√	○	√	○	
2017	M1-COMPASS (BRAZIL)	RFH	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	RRM	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	TBM	√	√	√	√	○	√	√	
2017	M1-COMPASS (BRAZIL)	TCM	√	√	√	√	※	※	※	
2017	M1-COMPASS (BRAZIL)	TTM	√	√	√	√	○	√	※	
2017	M4-COMPASS (CHINA)	ABS	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	ACC	√	√	√	√	○	○	√	
2017	M4-COMPASS (CHINA)	AMP	√	√	√	√	○	√	○	
2017	M4-COMPASS (CHINA)	BCM	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	CSWM	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	DTCM	√	√	√	√	○	○	○	
2017	M4-COMPASS (CHINA)	DTV	√	√	√	√	○	√	○	
2017	M4-COMPASS (CHINA)	ECM	√	√	√	√	※	√	※	
2017	M4-COMPASS (CHINA)	EPS	√	√	√	√	○	○	√	
2017	M4-COMPASS (CHINA)	ESL	√	√	√	√	○	※	※	
2017	M4-COMPASS (CHINA)	ESM	√	√	√	√	○	○	√	
2017	M4-COMPASS (CHINA)	ETM	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	FFCM	√	√	√	√	○	○	√	
2017	M4-COMPASS (CHINA)	HVAC	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	ICS	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	IPC	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	LBSS	√	√	√	√	○	√	○	
2017	M4-COMPASS (CHINA)	MSM	√	√	√	√	○	√	○	
2017	M4-COMPASS (CHINA)	OCM	√	√	√	√	○	○	√	
2017	M4-COMPASS (CHINA)	ORC	√	√	√	√	○	○	√	
2017	M4-COMPASS (CHINA)	PAM	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	PLGM	√	√	√	√	○	√	※	
2017	M4-COMPASS (CHINA)	RBSS	√	√	√	√	○	√	○	
2017	M4-COMPASS (CHINA)	RFH	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	RRM	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	TBM	√	√	√	√	○	√	√	
2017	M4-COMPASS (CHINA)	TCM	√	√	√	√	※	※	※	
2017	M4-COMPASS (CHINA)	TTM	√	√	√	√	○	√	※	
2017	M6-S56	ABS	√	√	√	√	○	√	√	
2017	M6-S56	ACC	√	√	√	√	○	○	√	
2017	M6-S56	AMP	√	√	√	√	○	√	○	
2017	M6-S56	BCM	√	√	√	√	○	√	√	
2017	M6-S56	CSWM	√	√	√	√	○	√	√	
2017	M6-S56	DTCM	√	√	√	√	○	○	○	
2017	M6-S56	DTV	√	√	√	√	○	√	○	
2017	M6-S56	ECM	√	√	√	√	※	√	※	

2017	M6-SS6	EPS	√	√	√	√	o	○	√	
2017	M6-SS6	ESL	√	√	√	√	o	※	※	
2017	M6-SS6	ESM	√	√	√	√	o	○	√	
2017	M6-SS6	ETM	√	√	√	√	o	√	√	
2017	M6-SS6	FFCM	√	√	√	√	o	○	√	
2017	M6-SS6	HVAC	√	√	√	√	o	√	√	
2017	M6-SS6	ICS	√	√	√	√	o	√	√	
2017	M6-SS6	IPC	√	√	√	√	o	√	√	
2017	M6-SS6	LBSS	√	√	√	√	o	√	○	
2017	M6-SS6	MSM	√	√	√	√	o	√	○	
2017	M6-SS6	OCM	√	√	√	√	o	○	√	
2017	M6-SS6	ORC	√	√	√	√	o	○	√	
2017	M6-SS6	PAM	√	√	√	√	o	√	√	
2017	M6-SS6	PLGM	√	√	√	√	o	√	※	
2017	M6-SS6	RBSS	√	√	√	√	o	√	○	
2017	M6-SS6	RFH	√	√	√	√	o	√	√	
2017	M6-SS6	RRM	√	√	√	√	o	√	√	
2017	M6-SS6	TBM	√	√	√	√	o	√	√	
2017	M6-SS6	TCM	√	√	√	√	※	※	※	
2017	M6-SS6	TTM	√	√	√	√	o	√	※	
2017	MK-Compass,Patriot	ABS	√	√	√	√	o	√	√	
2017	MK-Compass,Patriot	AMP	√	√	√	√	o	○	√	
2017	MK-Compass,Patriot	CGW	√	√	√	√	o	√	√	
2017	MK-Compass,Patriot	ECM	√	√	√	√	※	√	※	
2017	MK-Compass,Patriot	FDCM	√	√	√	√	o	√	√	
2017	MK-Compass,Patriot	HFM	√	√	√	√	o	√	○	
2017	MK-Compass,Patriot	HVAC	√	√	√	√	o	√	√	
2017	MK-Compass,Patriot	ITM	√	√	√	√	o	√	√	
2017	MK-Compass,Patriot	MIC/CCN	√	√	√	√	o	√	√	
2017	MK-Compass,Patriot	ORC	√	√	√	√	o	○	√	
2017	MK-Compass,Patriot	RADIO	√	√	√	√	o	※	※	
2017	MK-Compass,Patriot	SAS	√	√	√	√	o	○	○	
2017	MK-Compass,Patriot	TCM	√	√	√	√	※	√	√	
2017	MK-Compass,Patriot	WCM/TPMS	√	√	√	√	o	○	√	
2017	MP-COMPASS	ABS	√	√	√	√	o	√	√	
2017	MP-COMPASS	ACC	√	√	√	√	o	○	√	
2017	MP-COMPASS	AMP	√	√	√	√	o	√	○	
2017	MP-COMPASS	BCM	√	√	√	√	o	√	√	
2017	MP-COMPASS	CSWM	√	√	√	√	o	√	√	
2017	MP-COMPASS	DTCM	√	√	√	√	o	○	○	
2017	MP-COMPASS	DTV	√	√	√	√	o	√	○	
2017	MP-COMPASS	ECM	√	√	√	√	※	√	※	
2017	MP-COMPASS	EPS	√	√	√	√	o	○	√	
2017	MP-COMPASS	ESL	√	√	√	√	o	※	※	
2017	MP-COMPASS	ESM	√	√	√	√	o	○	√	
2017	MP-COMPASS	ETM	√	√	√	√	o	√	√	
2017	MP-COMPASS	FFCM	√	√	√	√	o	○	√	
2017	MP-COMPASS	HVAC	√	√	√	√	o	√	√	
2017	MP-COMPASS	ICS	√	√	√	√	o	√	√	
2017	MP-COMPASS	IPC	√	√	√	√	o	√	√	
2017	MP-COMPASS	LBSS	√	√	√	√	o	√	○	
2017	MP-COMPASS	MSM	√	√	√	√	o	√	○	
2017	MP-COMPASS	OCM	√	√	√	√	o	○	√	
2017	MP-COMPASS	ORC	√	√	√	√	o	○	√	
2017	MP-COMPASS	PAM	√	√	√	√	o	√	√	
2017	MP-COMPASS	PLGM	√	√	√	√	o	√	※	
2017	MP-COMPASS	RBSS	√	√	√	√	o	√	○	
2017	MP-COMPASS	RFH	√	√	√	√	o	√	√	
2017	MP-COMPASS	RRM	√	√	√	√	o	√	√	
2017	MP-COMPASS	TBM	√	√	√	√	o	√	√	
2017	MP-COMPASS	TCM	√	√	√	√	※	※	※	
2017	MP-COMPASS	TTM	√	√	√	√	o	√	※	
2017	PD-Neon	ABS	√	√	√	√	o	√	√	
2017	PD-Neon	ACC	√	√	√	√	o	√	√	
2017	PD-Neon	AHM	√	√	√	√	o	○	√	
2017	PD-Neon	BCM	√	√	√	√	o	√	√	
2017	PD-Neon	ECM	√	√	√	√	o	√	※	
2017	PD-Neon	EPS	√	√	√	√	o	○	○	
2017	PD-Neon	ESM	√	√	√	√	o	√	√	
2017	PD-Neon	ETM	√	√	√	√	o	√	√	
2017	PD-Neon	HVAC	√	√	√	√	o	√	√	
2017	PD-Neon	IPC	√	√	√	√	o	√	√	
2017	PD-Neon	ORC	√	√	√	√	o	○	√	
2017	PD-Neon	PAM	√	√	√	√	o	○	○	
2017	PD-Neon	RRM	√	√	√	√	o	√	√	
2017	PD-Neon	TCM	√	√	√	√	o	○	○	
2017	RT-Caravan,Voyater,Town & country	ABS	√	√	√	√	o	√	√	

2017	RT-Caravan,Voyater,Town & country	AHBM	√	√	√	√	o	√	o	
2017	RT-Caravan,Voyater,Town & country	AMP	√	√	√	√	o	o	√	
2017	RT-Caravan,Voyater,Town & country	CGW	√	√	√	√	o	√	√	
2017	RT-Caravan,Voyater,Town & country	DOORS	√	√	√	√	o	※	※	
2017	RT-Caravan,Voyater,Town & country	DVD	√	√	√	√	o	o	o	
2017	RT-Caravan,Voyater,Town & country	ECM	√	√	√	√	※	√	√	
2017	RT-Caravan,Voyater,Town & country	EPPM	√	√	√	√	o	o	√	
2017	RT-Caravan,Voyater,Town & country	FSM	√	√	√	√	o	√	o	
2017	RT-Caravan,Voyater,Town & country	HFM	√	√	√	√	o	√	o	
2017	RT-Caravan,Voyater,Town & country	HIDT	√	√	√	√	o	√	o	
2017	RT-Caravan,Voyater,Town & country	HSM	√	√	√	√	o	√	√	
2017	RT-Caravan,Voyater,Town & country	HVAC	√	√	√	√	o	√	※	
2017	RT-Caravan,Voyater,Town & country	ITM	√	√	√	√	o	√	√	
2017	RT-Caravan,Voyater,Town & country	LBSS	√	√	√	√	o	o	o	
2017	RT-Caravan,Voyater,Town & country	MIC/CCN	√	√	√	√	o	√	√	
2017	RT-Caravan,Voyater,Town & country	MSM	√	√	√	√	o	√	√	
2017	RT-Caravan,Voyater,Town & country	ORC	√	√	√	√	o	o	√	
2017	RT-Caravan,Voyater,Town & country	PEM	√	√	√	√	o	o	√	
2017	RT-Caravan,Voyater,Town & country	PLGM	√	√	√	√	o	√	√	
2017	RT-Caravan,Voyater,Town & country	PTS	√	√	√	√	o	√	√	
2017	RT-Caravan,Voyater,Town & country	RADIO	√	√	√	√	o	※	※	
2017	RT-Caravan,Voyater,Town & country	RBSS	√	√	√	√	o	o	o	
2017	RT-Caravan,Voyater,Town & country	SAS	√	√	√	√	o	o	o	
2017	RT-Caravan,Voyater,Town & country	SUNR	√	√	√	√	o	√	o	
2017	RT-Caravan,Voyater,Town & country	TCM	√	√	√	√	√	√	√	
2017	RT-Caravan,Voyater,Town & country	TPM	√	√	√	√	o	o	√	
2017	RT-Caravan,Voyater,Town & country	VES2	√	√	√	√	o	√	√	
2017	RT-Caravan,Voyater,Town & country	VES3	√	√	√	√	o	√	√	
2017	RT-Caravan,Voyater,Town & country	WCM/TPMS	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	ABS	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	ABSD	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	ACC	√	√	√	√	o	o	o	
2017	RU-CHRYSLER PACIFICA	AHCP	√	√	√	o	o	o	o	
2017	RU-CHRYSLER PACIFICA	AHLM	√	√	√	√	o	√	o	
2017	RU-CHRYSLER PACIFICA	AMP	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	ANC	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	APM	√	√	√	√	o	o	o	
2017	RU-CHRYSLER PACIFICA	BCM	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	BPCM	√	√	√	√	o	√	o	
2017	RU-CHRYSLER PACIFICA	CVPM	√	√	√	√	o	o	o	
2017	RU-CHRYSLER PACIFICA	DOORS	√	√	√	√	o	※	※	
2017	RU-CHRYSLER PACIFICA	DSM	√	√	√	√	o	o	o	
2017	RU-CHRYSLER PACIFICA	EAC	√	√	√	√	o	o	o	
2017	RU-CHRYSLER PACIFICA	EAM	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	EBBM	√	√	√	√	o	o	o	
2017	RU-CHRYSLER PACIFICA	ECM	√	√	√	√	√	√	√	
2017	RU-CHRYSLER PACIFICA	EDM	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	EOMR	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	EPS	√	√	√	√	o	o	√	
2017	RU-CHRYSLER PACIFICA	ESL	√	√	√	√	o	o	o	
2017	RU-CHRYSLER PACIFICA	ESM	√	√	√	√	o	√	o	
2017	RU-CHRYSLER PACIFICA	FFCM	√	√	√	√	o	o	√	
2017	RU-CHRYSLER PACIFICA	FSM	√	√	√	√	o	√	o	
2017	RU-CHRYSLER PACIFICA	HCP	√	√	√	√	o	√	o	
2017	RU-CHRYSLER PACIFICA	HSM	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	HVAC	√	√	√	√	o	√	o	
2017	RU-CHRYSLER PACIFICA	HVACR	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	ICS	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	IPC	√	√	√	√	o	√	o	
2017	RU-CHRYSLER PACIFICA	LBSS	√	√	√	o	o	o	o	
2017	RU-CHRYSLER PACIFICA	MSM	√	√	√	√	o	o	√	
2017	RU-CHRYSLER PACIFICA	OBCM	√	√	√	√	o	o	o	
2017	RU-CHRYSLER PACIFICA	OCM	√	√	√	√	o	o	o	
2017	RU-CHRYSLER PACIFICA	ORC	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	PLGM	√	√	√	√	o	√	o	
2017	RU-CHRYSLER PACIFICA	PTS	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	RADIO	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	RBSS	√	√	√	o	o	o	o	
2017	RU-CHRYSLER PACIFICA	RFH	√	√	√	√	o	√	√	
2017	RU-CHRYSLER PACIFICA	SCCM	√	√	√	√	o	o	o	
2017	RU-CHRYSLER PACIFICA	TCM	√	√	√	√	√	o	√	
2017	RU-CHRYSLER PACIFICA	VRM	√	√	√	√	o	o	o	
2017	UF-CHRYSLER 200	ABS	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	ACC	√	√	√	√	o	o	√	
2017	UF-CHRYSLER 200	AMP	√	√	√	√	o	o	o	
2017	UF-CHRYSLER 200	BCM	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	CSWM	√	√	√	√	o	√	√	

2017	UF-CHRYSLER 200	DOORS	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	DTCM	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	ECM	√	√	√	√	√	√	√	
2017	UF-CHRYSLER 200	EPB	√	√	√	√	o	○	√	
2017	UF-CHRYSLER 200	EPS	√	√	√	√	o	○	○	
2017	UF-CHRYSLER 200	ESM	√	√	√	√	o	○	○	
2017	UF-CHRYSLER 200	FFCM	√	√	√	√	o	○	√	
2017	UF-CHRYSLER 200	HVAC	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	ICS	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	IPC	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	LBSS	√	√	√	√	o	○	√	
2017	UF-CHRYSLER 200	MSM	√	√	√	√	o	○	○	
2017	UF-CHRYSLER 200	OCM	√	√	√	√	o	○	√	
2017	UF-CHRYSLER 200	ORC	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	PAM	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	PTU	√	√	√	○	o	○	○	
2017	UF-CHRYSLER 200	RADIO	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	RBSS	√	√	√	√	o	○	√	
2017	UF-CHRYSLER 200	RFH	√	√	√	√	o	√	√	
2017	UF-CHRYSLER 200	RRM	√	√	√	√	o	○	√	
2017	UF-CHRYSLER 200	SCCM	√	√	√	√	o	○	√	
2017	UF-CHRYSLER 200	TCM	√	√	√	√	√	○	√	
2017	VF-ProMaster	ABS	√	√	√	√	o	※	√	
2017	VF-ProMaster	BCM	√	√	√	√	o	√	√	
2017	VF-ProMaster	ECM	√	√	√	√	※	√	√	
2017	VF-ProMaster	EPB	√	√	√	√	o	√	○	
2017	VF-ProMaster	ETM	√	√	√	√	o	※	√	
2017	VF-ProMaster	HVAC	√	√	√	√	o	√	○	
2017	VF-ProMaster	IPC	√	√	√	√	o	√	○	
2017	VF-ProMaster	ORC	√	√	√	√	o	○	√	
2017	VF-ProMaster	PAM	√	√	√	√	o	○	○	
2017	VF-ProMaster	RADIO	√	√	√	√	o	√	√	
2017	VF-ProMaster	TCM	√	√	√	√	o	√	√	
2017	VF-ProMaster	TPM	√	√	√	√	o	√	√	
2017	VM-ProMaster city	ABS	√	√	√	√	o	√	○	
2017	VM-ProMaster city	BCM	√	√	√	√	o	√	√	
2017	VM-ProMaster city	ECM	√	√	√	√	√	√	√	
2017	VM-ProMaster city	ESM	√	√	√	√	o	√	○	
2017	VM-ProMaster city	ETM	√	√	√	√	o	√	√	
2017	VM-ProMaster city	HVAC	√	√	√	√	o	√	※	
2017	VM-ProMaster city	IPC	√	√	√	√	o	√	○	
2017	VM-ProMaster city	ORC	√	√	√	√	o	○	○	
2017	VM-ProMaster city	PAM	√	√	√	√	o	○	○	
2017	VM-ProMaster city	RADIO	√	√	√	√	o	√	√	
2017	VM-ProMaster city	TCM	√	√	√	※	※	○	※	
2017	VM-ProMaster city	TPM	√	√	√	√	o	√	√	
2017	VM-ProMaster city	TTM	√	√	√	√	o	○	√	
2017	WD-Durango	ABS	√	√	√	√	o	√	√	
2017	WD-Durango	ACC	√	√	√	√	o	○	○	
2017	WD-Durango	AHLM	√	√	√	√	o	○	○	
2017	WD-Durango	AMP	√	√	√	√	o	○	√	
2017	WD-Durango	BCM	√	√	√	√	o	√	√	
2017	WD-Durango	DOORS	√	√	√	√	o	√	√	
2017	WD-Durango	DTCM	√	√	√	√	o	√	√	
2017	WD-Durango	ECM	√	√	√	√	√	√	√	
2017	WD-Durango	EDM	√	√	√	√	o	√	√	
2017	WD-Durango	ELSD	√	√	√	√	o	○	○	
2017	WD-Durango	EPS	√	√	√	√	o	○	※	
2017	WD-Durango	ESM	√	√	√	√	o	※	○	
2017	WD-Durango	FFCM	√	√	√	※	o	○	※	
2017	WD-Durango	HSM	√	√	√	√	o	√	√	
2017	WD-Durango	HVAC	√	√	√	√	o	√	○	
2017	WD-Durango	HVACR	√	√	√	√	o	√	√	
2017	WD-Durango	ICS	√	√	√	√	o	※	※	
2017	WD-Durango	IPC	√	√	√	√	o	√	√	
2017	WD-Durango	ITM	√	√	√	√	o	√	√	
2017	WD-Durango	LBSS	√	√	√	○	o	○	○	
2017	WD-Durango	MSM	√	√	√	√	o	√	√	
2017	WD-Durango	ORC	√	√	√	√	o	○	√	
2017	WD-Durango	PLGM	√	√	√	√	o	√	○	
2017	WD-Durango	PTS	√	√	√	√	o	√	√	
2017	WD-Durango	RADIO	√	√	√	√	o	√	√	
2017	WD-Durango	RBSS	√	√	√	○	o	○	○	
2017	WD-Durango	RFH	√	√	√	√	o	√	√	
2017	WD-Durango	SCCM	√	√	√	√	o	○	√	
2017	WD-Durango	TCM	√	√	√	√	√	○	√	
2017	WD-Durango	VES2	√	√	√	√	o	√	○	

2017	WD-Durango	VES3	√	√	√	√	o	√	o	
2017	WK-Grand cherokee	ABS	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	ACC	√	√	√	√	o	o	o	
2017	WK-Grand cherokee	ADCM	√	√	√	√	o	o	o	
2017	WK-Grand cherokee	AFLS	√	√	√	√	o	o	√	
2017	WK-Grand cherokee	AMP	√	√	√	√	o	※	※	
2017	WK-Grand cherokee	ANC	√	√	√	√	o	o	√	
2017	WK-Grand cherokee	ASCM	√	√	√	√	o	o	√	
2017	WK-Grand cherokee	BCM	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	DOORS	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	DTCM	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	DTV	√	√	√	o	o	o	o	
2017	WK-Grand cherokee	EAM	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	ECM	√	√	√	√	※	√	√	
2017	WK-Grand cherokee	EDM	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	ELSD	√	√	√	√	o	o	o	
2017	WK-Grand cherokee	EPS	√	√	√	√	o	o	※	
2017	WK-Grand cherokee	ESM	√	√	√	√	o	※	o	
2017	WK-Grand cherokee	FFCM	√	√	√	※	o	o	※	
2017	WK-Grand cherokee	HSM	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	HVAC	√	√	√	√	o	√	o	
2017	WK-Grand cherokee	ICS	√	√	√	√	o	※	※	
2017	WK-Grand cherokee	IPC	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	ITM	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	LBSS	√	√	√	o	o	o	o	
2017	WK-Grand cherokee	MSM	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	ORC	√	√	√	√	o	o	√	
2017	WK-Grand cherokee	PLGM	√	√	√	√	o	√	o	
2017	WK-Grand cherokee	PTS	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	RADIO	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	RBSS	√	√	√	o	o	o	o	
2017	WK-Grand cherokee	RFH	√	√	√	√	o	√	√	
2017	WK-Grand cherokee	SCCM	√	√	√	√	o	o	√	
2017	WK-Grand cherokee	TCM	√	√	√	√	√	o	√	
2017	WK-Grand cherokee	TPM	√	√	√	√	o	o	√	
2017	WK-Grand cherokee	VES2	√	√	√	√	o	√	o	
2017	WK-Grand cherokee	VES3	√	√	√	√	o	√	o	
2017	ZD-Viper (Post-2013)	ABS	√	√	√	√	o	√	√	
2017	ZD-Viper (Post-2013)	ADCM	√	√	√	√	o	o	o	
2017	ZD-Viper (Post-2013)	AMP	√	√	√	√	o	o	√	
2017	ZD-Viper (Post-2013)	BCM	√	√	√	√	o	√	√	
2017	ZD-Viper (Post-2013)	DOORS	√	√	√	√	o	√	√	
2017	ZD-Viper (Post-2013)	ECM	√	√	√	√	√	√	o	
2017	ZD-Viper (Post-2013)	HVAC	√	√	√	√	o	√	√	
2017	ZD-Viper (Post-2013)	ICS	√	√	√	√	o	√	√	
2017	ZD-Viper (Post-2013)	IPC	√	√	√	√	o	√	√	
2017	ZD-Viper (Post-2013)	OCM	√	√	√	√	o	o	o	
2017	ZD-Viper (Post-2013)	ORC	√	√	√	√	o	√	√	
2017	ZD-Viper (Post-2013)	RADIO	√	√	√	√	o	√	√	
2017	ZD-Viper (Post-2013)	RFH	√	√	√	√	o	√	√	
2017	ZD-Viper (Post-2013)	SCCM	√	√	√	√	o	o	o	
2017	ZD-Viper (Post-2013)	TPM	√	√	√	√	o	o	√	
2018	B1-RENEGADE (LATM)	ABS	√	√	√	√	o	√	√	
2018	B1-RENEGADE (LATM)	ACC	√	√	√	√	o	√	√	
2018	B1-RENEGADE (LATM)	AMP	√	√	√	√	o	√	√	
2018	B1-RENEGADE (LATM)	BCM	√	√	√	√	※	√	※	
2018	B1-RENEGADE (LATM)	CSWM	√	√	√	√	o	√	o	
2018	B1-RENEGADE (LATM)	DTCM	√	√	√	√	o	o	o	
2018	B1-RENEGADE (LATM)	ECM	√	√	√	√	※	√	※	
2018	B1-RENEGADE (LATM)	EPS	√	√	√	√	o	o	√	
2018	B1-RENEGADE (LATM)	ESL	√	√	√	√	o	√	√	
2018	B1-RENEGADE (LATM)	ESM	√	√	√	√	o	√	√	
2018	B1-RENEGADE (LATM)	ETM	√	√	√	√	o	※	√	
2018	B1-RENEGADE (LATM)	HALF	√	√	√	√	o	o	√	
2018	B1-RENEGADE (LATM)	HVAC	√	√	√	√	o	√	√	
2018	B1-RENEGADE (LATM)	IPC	√	√	√	√	※	√	√	
2018	B1-RENEGADE (LATM)	LBSS	√	√	√	√	o	√	o	
2018	B1-RENEGADE (LATM)	ORC	√	√	√	√	o	o	√	
2018	B1-RENEGADE (LATM)	PAM	√	√	√	√	o	o	o	
2018	B1-RENEGADE (LATM)	RBSS	√	√	√	√	o	√	o	
2018	B1-RENEGADE (LATM)	RFH	√	√	√	√	o	√	o	
2018	B1-RENEGADE (LATM)	RRM	√	√	√	√	o	√	√	
2018	B1-RENEGADE (LATM)	TCM	√	√	√	※	※	※	※	
2018	B1-RENEGADE (LATM)	TTM	√	√	√	√	o	√	o	
2018	BQ-RENEGADE (CHINA)	ABS	√	√	√	√	o	√	√	
2018	BQ-RENEGADE (CHINA)	ACC	√	√	√	√	o	√	√	
2018	BQ-RENEGADE (CHINA)	AMP	√	√	√	√	o	√	√	

2018	BQ-RENEGADE (CHINA)	BCM	√	√	√	√	o	√	√	
2018	BQ-RENEGADE (CHINA)	CSWM	√	√	√	√	o	√	o	
2018	BQ-RENEGADE (CHINA)	DTCM	√	√	√	√	o	o	o	
2018	BQ-RENEGADE (CHINA)	ECM	√	√	√	√	※	√	※	
2018	BQ-RENEGADE (CHINA)	EPS	√	√	√	√	o	o	√	
2018	BQ-RENEGADE (CHINA)	ESL	√	√	√	√	o	√	√	
2018	BQ-RENEGADE (CHINA)	ESM	√	√	√	√	o	※	√	
2018	BQ-RENEGADE (CHINA)	ETM	√	√	√	√	o	※	√	
2018	BQ-RENEGADE (CHINA)	HALF	√	√	√	√	o	o	√	
2018	BQ-RENEGADE (CHINA)	HVAC	√	√	√	√	o	√	√	
2018	BQ-RENEGADE (CHINA)	ICS	√	√	√	√	o	√	√	
2018	BQ-RENEGADE (CHINA)	IPC	√	√	√	√	※	√	√	
2018	BQ-RENEGADE (CHINA)	LBSS	√	√	√	√	o	√	o	
2018	BQ-RENEGADE (CHINA)	ORC	√	√	√	√	o	o	√	
2018	BQ-RENEGADE (CHINA)	PAM	√	√	√	√	o	o	o	
2018	BQ-RENEGADE (CHINA)	RBSS	√	√	√	√	o	√	o	
2018	BQ-RENEGADE (CHINA)	RFH	√	√	√	√	o	√	o	
2018	BQ-RENEGADE (CHINA)	RRM	√	√	√	√	o	√	√	
2018	BQ-RENEGADE (CHINA)	TCM	√	√	√	※	※	※	※	
2018	BQ-RENEGADE (CHINA)	TTM	√	√	√	√	o	√	o	
2018	BU-RENEGADE	ABS	√	√	√	√	o	√	√	
2018	BU-RENEGADE	ACC	√	√	√	√	o	√	√	
2018	BU-RENEGADE	AMP	√	√	√	√	o	√	√	
2018	BU-RENEGADE	BCM	√	√	√	√	o	√	√	
2018	BU-RENEGADE	CSWM	√	√	√	√	o	√	o	
2018	BU-RENEGADE	DTCM	√	√	√	√	o	o	o	
2018	BU-RENEGADE	ECM	√	√	√	※	※	※	※	
2018	BU-RENEGADE	EPS	√	√	√	√	o	o	√	
2018	BU-RENEGADE	ESL	√	√	√	√	o	√	√	
2018	BU-RENEGADE	ESM	√	√	√	√	o	√	√	
2018	BU-RENEGADE	ETM	√	√	√	√	o	※	√	
2018	BU-RENEGADE	HALF	√	√	√	√	o	o	√	
2018	BU-RENEGADE	HVAC	√	√	√	√	o	√	√	
2018	BU-RENEGADE	IPC	√	√	√	√	※	√	√	
2018	BU-RENEGADE	LBSS	√	√	√	√	o	√	o	
2018	BU-RENEGADE	ORC	√	√	√	√	o	o	√	
2018	BU-RENEGADE	PAM	√	√	√	√	o	o	o	
2018	BU-RENEGADE	RBSS	√	√	√	√	o	√	o	
2018	BU-RENEGADE	RFH	√	√	√	√	o	√	o	
2018	BU-RENEGADE	RRM	√	√	√	√	o	√	√	
2018	BU-RENEGADE	TCM	√	√	√	※	※	※	※	
2018	BU-RENEGADE	TTM	√	√	√	√	o	√	o	
2018	D2-Ram 3500 Pickup	ABS	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	AMP	√	√	√	√	o	o	√	
2018	D2-Ram 3500 Pickup	ASCM	√	√	√	√	o	o	√	
2018	D2-Ram 3500 Pickup	BCM	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	DCU	√	√	√	o	o	o	o	
2018	D2-Ram 3500 Pickup	DOORS	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	DTCM	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	ECM	√	√	√	√	√	√	√	
2018	D2-Ram 3500 Pickup	EDM	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	HSM	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	HVAC	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	ICS	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	IPC	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	ITBM	√	√	√	√	o	o	o	
2018	D2-Ram 3500 Pickup	MSM	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	ORC	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	PTS	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	RADIO	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	RFH	√	√	√	√	o	√	√	
2018	D2-Ram 3500 Pickup	SCCM	√	√	√	√	o	o	o	
2018	D2-Ram 3500 Pickup	TCM	√	√	√	√	√	√	√	
2018	D2-Ram 3500 Pickup	VGT	√	√	√	o	o	o	o	
2018	D2-Ram 3500 Pickup	VSIM	√	√	√	√	o	√	o	
2018	DD-Ram 3500 Cab Chassis	ABS	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	AMP	√	√	√	√	o	o	√	
2018	DD-Ram 3500 Cab Chassis	BCM	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	DCU	√	√	√	o	o	o	o	
2018	DD-Ram 3500 Cab Chassis	DOORS	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	DTCM	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	ECM	√	√	√	√	√	√	√	
2018	DD-Ram 3500 Cab Chassis	EDM	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	HSM	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	HVAC	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	ICS	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	IPC	√	√	√	√	o	√	√	

2018	DD-Ram 3500 Cab Chassis	ITBM	√	√	√	√	o	o	o	
2018	DD-Ram 3500 Cab Chassis	MSM	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	ORC	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	PTS	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	RADIO	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	RFH	√	√	√	√	o	√	√	
2018	DD-Ram 3500 Cab Chassis	SCCM	√	√	√	√	o	o	o	
2018	DD-Ram 3500 Cab Chassis	TCM	√	√	√	√	√	√	√	
2018	DD-Ram 3500 Cab Chassis	VGT	√	√	√	o	o	o	o	
2018	DD-Ram 3500 Cab Chassis	VSIM	√	√	√	√	o	√	o	
2018	DF-Ram 3500 cab chassis 10K	ABS	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	AMP	√	√	√	√	o	o	√	
2018	DF-Ram 3500 cab chassis 10K	BCM	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	DCU	√	√	√	o	o	o	o	
2018	DF-Ram 3500 cab chassis 10K	DOORS	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	DTCM	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	ECM	√	√	√	√	√	√	√	
2018	DF-Ram 3500 cab chassis 10K	EDM	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	HSM	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	HVAC	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	ICS	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	IPC	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	ITBM	√	√	√	√	o	o	o	
2018	DF-Ram 3500 cab chassis 10K	MSM	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	ORC	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	PTS	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	RADIO	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	RFH	√	√	√	√	o	√	√	
2018	DF-Ram 3500 cab chassis 10K	SCCM	√	√	√	√	o	o	o	
2018	DF-Ram 3500 cab chassis 10K	TCM	√	√	√	√	√	√	√	
2018	DF-Ram 3500 cab chassis 10K	VGT	√	√	√	o	o	o	o	
2018	DF-Ram 3500 cab chassis 10K	VSIM	√	√	√	√	o	√	o	
2018	DJ-Ram 2500	ABS	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	AMP	√	√	√	√	o	o	√	
2018	DJ-Ram 2500	ASCM	√	√	√	√	o	o	√	
2018	DJ-Ram 2500	BCM	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	DCU	√	√	√	o	o	o	o	
2018	DJ-Ram 2500	DOORS	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	DTCM	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	ECM	√	√	√	√	√	√	√	
2018	DJ-Ram 2500	EDM	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	FDCM	√	√	√	√	o	o	o	
2018	DJ-Ram 2500	HSM	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	HVAC	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	ICS	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	IPC	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	ITBM	√	√	√	√	o	o	o	
2018	DJ-Ram 2500	MSM	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	ORC	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	PTS	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	RADIO	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	RFH	√	√	√	√	o	√	√	
2018	DJ-Ram 2500	SCCM	√	√	√	√	o	o	o	
2018	DJ-Ram 2500	TCM	√	√	√	√	√	√	√	
2018	DJ-Ram 2500	VGT	√	√	√	o	o	o	o	
2018	DJ-Ram 2500	VSIM	√	√	√	√	o	√	o	
2018	DP-Ram 4500/5500	ABS	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	AMP	√	√	√	√	o	o	√	
2018	DP-Ram 4500/5500	BCM	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	DCU	√	√	√	o	o	o	o	
2018	DP-Ram 4500/5500	DOORS	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	DTCM	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	ECM	√	√	√	√	√	√	√	
2018	DP-Ram 4500/5500	EDM	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	HSM	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	HVAC	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	ICS	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	IPC	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	ITBM	√	√	√	√	o	o	o	
2018	DP-Ram 4500/5500	MSM	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	ORC	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	PTS	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	RADIO	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	RFH	√	√	√	√	o	√	√	
2018	DP-Ram 4500/5500	SCCM	√	√	√	√	o	o	o	
2018	DP-Ram 4500/5500	TCM	√	√	√	√	√	√	√	
2018	DP-Ram 4500/5500	VGT	√	√	√	o	o	o	o	

2018	DP-Ram 4500/5500	VSIM	√	√	√	√	○	√	○	
2018	DS-Ram 1500	ABS	√	√	√	√	○	√	√	
2018	DS-Ram 1500	AMP	√	√	√	√	○	○	√	
2018	DS-Ram 1500	ASCM	√	√	√	√	○	○	√	
2018	DS-Ram 1500	BCM	√	√	√	√	○	√	√	
2018	DS-Ram 1500	DOORS	√	√	√	√	○	√	√	
2018	DS-Ram 1500	DTCM	√	√	√	√	○	√	√	
2018	DS-Ram 1500	ECM	√	√	√	√	※	√	√	
2018	DS-Ram 1500	EDM	√	√	√	√	○	√	√	
2018	DS-Ram 1500	EPS	√	√	√	√	○	○	○	
2018	DS-Ram 1500	ESM	√	√	√	√	○	○	○	
2018	DS-Ram 1500	HSM	√	√	√	√	○	√	√	
2018	DS-Ram 1500	HVAC	√	√	√	√	○	√	√	
2018	DS-Ram 1500	ICS	√	√	√	√	○	√	√	
2018	DS-Ram 1500	IPC	√	√	√	√	○	√	√	
2018	DS-Ram 1500	ITBM	√	√	√	√	○	○	○	
2018	DS-Ram 1500	MSM	√	√	√	√	○	√	√	
2018	DS-Ram 1500	ORC	√	√	√	√	○	√	√	
2018	DS-Ram 1500	PTS	√	√	√	√	○	√	√	
2018	DS-Ram 1500	RADIO	√	√	√	√	○	√	√	
2018	DS-Ram 1500	RFH	√	√	√	√	○	√	√	
2018	DS-Ram 1500	SCCM	√	√	√	√	○	○	○	
2018	DS-Ram 1500	TCM	√	√	√	√	※	○	√	
2018	DS-Ram 1500	VSIM	√	√	√	√	○	√	○	
2018	DX-Ram (Mexico)	ABS	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	AMP	√	√	√	√	○	○	√	
2018	DX-Ram (Mexico)	ASCM	√	√	√	√	○	○	√	
2018	DX-Ram (Mexico)	BCM	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	DCU	√	√	√	○	○	○	○	
2018	DX-Ram (Mexico)	DOORS	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	DTCM	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	ECM	√	√	√	√	√	√	√	
2018	DX-Ram (Mexico)	EDM	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	EPS	√	√	√	√	○	○	○	
2018	DX-Ram (Mexico)	ESM	√	√	√	√	○	○	○	
2018	DX-Ram (Mexico)	HSM	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	HVAC	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	ICS	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	IPC	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	ITBM	√	√	√	√	○	○	○	
2018	DX-Ram (Mexico)	MSM	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	ORC	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	PTS	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	RADIO	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	RFH	√	√	√	√	○	√	√	
2018	DX-Ram (Mexico)	SCCM	√	√	√	√	○	○	○	
2018	DX-Ram (Mexico)	TCM	√	√	√	√	※	※	√	
2018	DX-Ram (Mexico)	VGT	√	√	√	○	○	○	○	
2018	DX-Ram (Mexico)	VSIM	√	√	√	√	○	√	○	
2018	JB-Wrangler	ABS	√	√	√	√	○	√	√	
2018	JB-Wrangler	CGW	√	√	√	√	○	√	√	
2018	JB-Wrangler	ECM	√	√	√	√	○	√	√	
2018	JB-Wrangler	ESM	√	√	√	√	○	√	○	
2018	JB-Wrangler	HVAC	√	√	√	√	○	√	√	
2018	JB-Wrangler	MIC/CCN	√	√	√	√	○	√	√	
2018	JB-Wrangler	ORC	√	√	√	√	○	○	√	
2018	JB-Wrangler	RADIO	√	√	√	√	○	※	※	
2018	JB-Wrangler	SAS	√	√	√	√	○	○	○	
2018	JB-Wrangler	TCM	√	√	√	√	○	○	○	
2018	JB-Wrangler	WCM/TPMS	√	√	√	√	○	○	√	
2018	JC-Journey	ABS	√	√	√	√	○	√	√	
2018	JC-Journey	AMP	√	√	√	√	○	○	√	
2018	JC-Journey	BCM	√	√	√	√	○	√	√	
2018	JC-Journey	DOORS	√	√	√	√	○	√	√	
2018	JC-Journey	DTCM	√	√	√	√	○	√	√	
2018	JC-Journey	ECM	√	√	√	√	※	√	√	
2018	JC-Journey	EPPM	√	√	√	√	○	○	√	
2018	JC-Journey	HFM	√	√	√	√	○	○	√	
2018	JC-Journey	HSM	√	√	√	√	○	√	√	
2018	JC-Journey	HVAC	√	√	√	√	○	√	√	
2018	JC-Journey	ICS	√	√	√	√	○	√	√	
2018	JC-Journey	IPC	√	√	√	√	○	√	√	
2018	JC-Journey	ITM	√	√	√	√	○	√	√	
2018	JC-Journey	ORC	√	√	√	√	○	○	√	
2018	JC-Journey	PTS	√	√	√	√	○	√	√	
2018	JC-Journey	RFH	√	√	√	√	○	√	√	
2018	JC-Journey	SCCM	√	√	√	√	○	○	○	

2018	JC-Journey	TCM	√	√	√	√	○	√	√	
2018	JC-Journey	TGW	√	√	√	√	○	○	√	
2018	JC-Journey	TPM	√	√	√	√	○	○	√	
2018	JC-Journey	VES3	√	√	√	√	○	√	○	
2018	JC-Journey	VTM	√	√	√	√	○	○	○	
2018	JK-Wrangler	ABS	√	√	√	√	○	√	√	
2018	JK-Wrangler	AMP	√	√	√	√	○	○	√	
2018	JK-Wrangler	ASBS	√	√	√	√	○	○	○	
2018	JK-Wrangler	CGW	√	√	√	√	○	√	√	
2018	JK-Wrangler	ECM	√	√	√	√	※	√	√	
2018	JK-Wrangler	ESM	√	√	√	√	○	√	○	
2018	JK-Wrangler	HFM	√	√	√	√	○	√	○	
2018	JK-Wrangler	HVAC	√	√	√	√	○	√	√	
2018	JK-Wrangler	ITM	√	√	√	√	○	√	√	
2018	JK-Wrangler	MIC/CCN	√	√	√	√	○	√	√	
2018	JK-Wrangler	ORC	√	√	√	√	○	○	√	
2018	JK-Wrangler	RADIO	√	√	√	√	○	※	※	
2018	JK-Wrangler	SAS	√	√	√	√	○	○	○	
2018	JK-Wrangler	TCM	√	√	√	√	○	○	○	
2018	JK-Wrangler	TPM	√	√	√	√	○	○	√	
2018	JK-Wrangler	WCM/TPMS	√	√	√	√	○	○	√	
2018	JL-Wrangler	ABS	√	√	√	√	○	√	√	
2018	JL-Wrangler	AHLM	√	√	√	√	○	√	○	
2018	JL-Wrangler	AMP	√	√	√	√	○	○	√	
2018	JL-Wrangler	ASBS	√	√	√	√	○	○	○	
2018	JL-Wrangler	BCM	√	√	√	√	○	√	√	
2018	JL-Wrangler	BPCM	√	√	√	√	○	√	○	
2018	JL-Wrangler	CSWM	√	√	√	√	○	√	○	
2018	JL-Wrangler	DPDM	√	√	√	√	○	○	○	
2018	JL-Wrangler	DTCM	√	√	√	√	○	√	√	
2018	JL-Wrangler	DTV	√	√	√	√	○	√	√	
2018	JL-Wrangler	EAM	√	√	√	√	○	√	√	
2018	JL-Wrangler	ECM	√	√	√	√	○	√	√	
2018	JL-Wrangler	EPS	√	√	√	√	○	○	√	
2018	JL-Wrangler	ESL	√	√	√	√	○	○	○	
2018	JL-Wrangler	ESM	√	√	√	√	○	√	○	
2018	JL-Wrangler	HCP	√	√	√	√	√	○	○	
2018	JL-Wrangler	HVAC	√	√	√	√	○	√	※	
2018	JL-Wrangler	ICS	√	√	√	√	○	√	√	
2018	JL-Wrangler	IPC	√	√	√	√	○	√	※	
2018	JL-Wrangler	ITM	√	√	√	√	○	√	√	
2018	JL-Wrangler	LBSS	√	√	√	○	○	○	○	
2018	JL-Wrangler	OCM	√	√	√	√	○	○	√	
2018	JL-Wrangler	ORC	√	√	√	√	○	○	√	
2018	JL-Wrangler	PTCM	√	√	√	√	○	○	√	
2018	JL-Wrangler	PTS	√	√	√	√	○	√	√	
2018	JL-Wrangler	RADIO	√	√	√	√	○	√	√	
2018	JL-Wrangler	RBSS	√	√	√	○	○	○	○	
2018	JL-Wrangler	RFH	√	√	√	√	○	√	√	
2018	JL-Wrangler	SCCM	√	√	√	√	○	○	√	
2018	JL-Wrangler	TCM	√	√	√	√	※	○	※	
2018	JL-Wrangler	TPM	√	√	√	√	○	○	√	
2018	KB-Grand Commander	ABS	√	√	√	√	○	√	√	
2018	KB-Grand Commander	ACC	√	√	√	√	○	○	√	
2018	KB-Grand Commander	AFLS	√	√	√	○	○	○	○	
2018	KB-Grand Commander	AHLM	√	√	√	√	○	○	○	
2018	KB-Grand Commander	AMP	√	√	√	√	○	○	○	
2018	KB-Grand Commander	ANC	√	√	√	√	○	√	√	
2018	KB-Grand Commander	BCM	√	√	√	√	○	√	√	
2018	KB-Grand Commander	CSWM	√	√	√	√	○	√	√	
2018	KB-Grand Commander	DOORS	√	√	√	√	○	√	√	
2018	KB-Grand Commander	DTCM	√	√	√	√	○	√	√	
2018	KB-Grand Commander	DTV	√	√	√	√	○	√	√	
2018	KB-Grand Commander	ECM	√	√	√	√	※	√	√	
2018	KB-Grand Commander	EDM	√	√	√	○	○	√	○	
2018	KB-Grand Commander	EPB	√	√	√	√	○	○	√	
2018	KB-Grand Commander	EPS	√	√	√	√	○	○	○	
2018	KB-Grand Commander	ESL	√	√	√	√	○	○	○	
2018	KB-Grand Commander	ESM	√	√	√	√	○	√	○	
2018	KB-Grand Commander	FFCM	√	√	√	√	○	○	√	
2018	KB-Grand Commander	HVAC	√	√	√	√	○	√	√	
2018	KB-Grand Commander	HVACR	√	√	√	√	○	√	○	
2018	KB-Grand Commander	ICS	√	√	√	√	○	√	√	
2018	KB-Grand Commander	IPC	√	√	√	√	○	√	√	
2018	KB-Grand Commander	LBSS	√	√	√	√	○	○	√	
2018	KB-Grand Commander	MSM	√	√	√	√	○	○	○	
2018	KB-Grand Commander	OCM	√	√	√	√	○	○	√	

2018	K8-Grand Commander	ORC	√	√	√	√	o	√	√	
2018	K8-Grand Commander	PAM	√	√	√	√	o	√	√	
2018	K8-Grand Commander	PLGM	√	√	√	√	o	√	o	
2018	K8-Grand Commander	PTU	√	√	√	o	o	o	o	
2018	K8-Grand Commander	RADIO	√	√	√	√	o	√	√	
2018	K8-Grand Commander	RBSS	√	√	√	√	o	o	√	
2018	K8-Grand Commander	RCCC	√	√	√	√	o	√	o	
2018	K8-Grand Commander	RDM	√	√	√	o	o	o	o	
2018	K8-Grand Commander	RFH	√	√	√	√	o	√	√	
2018	K8-Grand Commander	SCCM	√	√	√	√	o	√	√	
2018	K8-Grand Commander	TBM	√	√	√	√	o	√	√	
2018	K8-Grand Commander	TCM	√	√	√	√	√	o	√	
2018	KL-Cherokee	ABS	√	√	√	√	o	√	√	
2018	KL-Cherokee	ACC	√	√	√	√	o	o	√	
2018	KL-Cherokee	AHLM	√	√	√	√	o	o	o	
2018	KL-Cherokee	AMP	√	√	√	√	o	o	o	
2018	KL-Cherokee	ANC	√	√	√	√	o	√	√	
2018	KL-Cherokee	BCM	√	√	√	√	o	√	√	
2018	KL-Cherokee	CSWM	√	√	√	√	o	√	√	
2018	KL-Cherokee	DOORS	√	√	√	√	o	√	√	
2018	KL-Cherokee	DTCM	√	√	√	√	o	√	√	
2018	KL-Cherokee	DTV	√	√	√	√	o	√	√	
2018	KL-Cherokee	ECM	√	√	√	√	※	√	√	
2018	KL-Cherokee	EDM	√	√	√	o	o	√	o	
2018	KL-Cherokee	EPB	√	√	√	√	o	o	√	
2018	KL-Cherokee	EPS	√	√	√	√	o	o	o	
2018	KL-Cherokee	ESL	√	√	√	√	o	o	√	
2018	KL-Cherokee	ESM	√	√	√	√	o	√	o	
2018	KL-Cherokee	FFCM	√	√	√	√	o	o	√	
2018	KL-Cherokee	HVAC	√	√	√	√	o	√	√	
2018	KL-Cherokee	ICS	√	√	√	√	o	√	√	
2018	KL-Cherokee	IPC	√	√	√	√	o	√	√	
2018	KL-Cherokee	LBSS	√	√	√	√	o	o	√	
2018	KL-Cherokee	MSM	√	√	√	√	o	o	o	
2018	KL-Cherokee	OCM	√	√	√	√	o	o	√	
2018	KL-Cherokee	ORC	√	√	√	√	o	√	√	
2018	KL-Cherokee	PAM	√	√	√	√	o	√	√	
2018	KL-Cherokee	PLGM	√	√	√	√	o	√	o	
2018	KL-Cherokee	PTU	√	√	√	o	o	o	o	
2018	KL-Cherokee	RADIO	√	√	√	√	o	√	√	
2018	KL-Cherokee	RBSS	√	√	√	√	o	o	√	
2018	KL-Cherokee	RDM	√	√	√	o	o	o	o	
2018	KL-Cherokee	RFH	√	√	√	√	o	√	√	
2018	KL-Cherokee	SCCM	√	√	√	√	o	√	o	
2018	KL-Cherokee	TCM	√	√	√	√	√	o	√	
2018	LA-Challenger	ABS	√	√	√	√	o	√	√	
2018	LA-Challenger	ACC	√	√	√	√	o	o	o	
2018	LA-Challenger	ADCM	√	√	√	√	o	√	o	
2018	LA-Challenger	AMP	√	√	√	√	o	o	√	
2018	LA-Challenger	BCM	√	√	√	√	o	√	√	
2018	LA-Challenger	DOORS	√	√	√	√	o	√	√	
2018	LA-Challenger	DTCM	√	√	√	√	o	√	o	
2018	LA-Challenger	ECM	√	√	√	√	※	√	√	
2018	LA-Challenger	EPS	√	√	√	√	o	o	※	
2018	LA-Challenger	ESM	√	√	√	√	o	√	o	
2018	LA-Challenger	HSM	√	√	√	√	o	√	√	
2018	LA-Challenger	HVAC	√	√	√	√	o	√	√	
2018	LA-Challenger	ICS	√	√	√	√	o	√	√	
2018	LA-Challenger	IPC	√	√	√	√	o	√	√	
2018	LA-Challenger	LBSS	√	√	√	√	o	o	o	
2018	LA-Challenger	MSM	√	√	√	√	o	√	√	
2018	LA-Challenger	ORC	√	√	√	√	o	o	√	
2018	LA-Challenger	PTS	√	√	√	√	o	※	√	
2018	LA-Challenger	RADIO	√	√	√	√	o	√	√	
2018	LA-Challenger	RBSS	√	√	√	√	o	o	o	
2018	LA-Challenger	RFH	√	√	√	√	o	√	√	
2018	LA-Challenger	SCCM	√	√	√	√	o	o	√	
2018	LA-Challenger	TCM	√	√	√	√	※	o	√	
2018	LA-Challenger	TPM	√	√	√	√	o	o	√	
2018	LD-Charger	ABS	√	√	√	√	o	√	√	
2018	LD-Charger	ACC	√	√	√	√	o	o	o	
2018	LD-Charger	ADCM	√	√	√	√	o	√	o	
2018	LD-Charger	AMP	√	√	√	√	o	o	√	
2018	LD-Charger	BCM	√	√	√	√	o	√	√	
2018	LD-Charger	DOORS	√	√	√	√	o	√	√	
2018	LD-Charger	DSM	√	√	√	√	o	o	o	
2018	LD-Charger	DTCM	√	√	√	√	o	√	o	

2018	LD-Charger	ECM	√	√	√	√	※	√	√	
2018	LD-Charger	EPS	√	√	√	√	○	○	※	
2018	LD-Charger	ESM	√	√	√	√	○	√	○	
2018	LD-Charger	FFCM	√	√	√	√	○	○	○	
2018	LD-Charger	HSM	√	√	√	√	○	√	√	
2018	LD-Charger	HVAC	√	√	√	√	○	√	√	
2018	LD-Charger	ICS	√	√	√	√	○	√	√	
2018	LD-Charger	IPC	√	√	√	√	○	√	√	
2018	LD-Charger	ITM	√	√	√	√	○	√	√	
2018	LD-Charger	LBSS	√	√	√	√	○	○	○	
2018	LD-Charger	MSM	√	√	√	√	○	√	√	
2018	LD-Charger	ORC	√	√	√	√	○	○	√	
2018	LD-Charger	PTS	√	√	√	√	○	※	√	
2018	LD-Charger	RADIO	√	√	√	√	○	√	√	
2018	LD-Charger	RBSS	√	√	√	√	○	○	○	
2018	LD-Charger	RFH	√	√	√	√	○	√	√	
2018	LD-Charger	SCCM	√	√	√	√	○	○	√	
2018	LD-Charger	TCM	√	√	√	√	※	○	√	
2018	LD-Charger	TPM	√	√	√	√	○	○	√	
2018	LD-Charger	VSIM	√	√	√	√	○	√	○	
2018	LX-300,Charger,Magnum,Grand voyager	ABS	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	ACC	√	√	√	√	○	○	○	
2018	LX-300,Charger,Magnum,Grand voyager	ADCM	√	√	√	√	○	√	○	
2018	LX-300,Charger,Magnum,Grand voyager	AFLS	√	√	√	√	○	√	○	
2018	LX-300,Charger,Magnum,Grand voyager	AMP	√	√	√	√	○	○	√	
2018	LX-300,Charger,Magnum,Grand voyager	BCM	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	DOORS	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	DTCM	√	√	√	√	○	√	○	
2018	LX-300,Charger,Magnum,Grand voyager	ECM	√	√	√	√	※	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	EPS	√	√	√	√	○	○	※	
2018	LX-300,Charger,Magnum,Grand voyager	ESM	√	√	√	√	○	※	○	
2018	LX-300,Charger,Magnum,Grand voyager	FFCM	√	√	√	√	○	○	○	
2018	LX-300,Charger,Magnum,Grand voyager	HSM	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	HVAC	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	ICS	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	IPC	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	ITM	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	LBSS	√	√	√	√	○	○	○	
2018	LX-300,Charger,Magnum,Grand voyager	MSM	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	ORC	√	√	√	√	○	○	√	
2018	LX-300,Charger,Magnum,Grand voyager	PTS	√	√	√	√	○	※	√	
2018	LX-300,Charger,Magnum,Grand voyager	RADIO	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	RBSS	√	√	√	√	○	○	○	
2018	LX-300,Charger,Magnum,Grand voyager	RFH	√	√	√	√	○	√	√	
2018	LX-300,Charger,Magnum,Grand voyager	SCCM	√	√	√	√	○	○	√	
2018	LX-300,Charger,Magnum,Grand voyager	TCM	√	√	√	√	※	○	√	
2018	LX-300,Charger,Magnum,Grand voyager	TPM	√	√	√	√	○	○	√	
2018	M1-COMPASS (BRAZIL)	ABS	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	ACC	√	√	√	√	○	○	√	
2018	M1-COMPASS (BRAZIL)	AMP	√	√	√	√	○	√	○	
2018	M1-COMPASS (BRAZIL)	BCM	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	CSWM	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	DTCM	√	√	√	√	○	○	○	
2018	M1-COMPASS (BRAZIL)	DTV	√	√	√	√	○	√	○	
2018	M1-COMPASS (BRAZIL)	ECM	√	√	√	√	※	√	※	
2018	M1-COMPASS (BRAZIL)	EPS	√	√	√	√	○	○	√	
2018	M1-COMPASS (BRAZIL)	ESL	√	√	√	√	○	※	※	
2018	M1-COMPASS (BRAZIL)	ESM	√	√	√	√	○	○	√	
2018	M1-COMPASS (BRAZIL)	ETM	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	FFCM	√	√	√	√	○	○	√	
2018	M1-COMPASS (BRAZIL)	HVAC	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	ICS	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	IPC	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	LBSS	√	√	√	√	○	√	○	
2018	M1-COMPASS (BRAZIL)	MSM	√	√	√	√	○	√	○	
2018	M1-COMPASS (BRAZIL)	OCM	√	√	√	√	○	○	√	
2018	M1-COMPASS (BRAZIL)	ORC	√	√	√	√	○	○	√	
2018	M1-COMPASS (BRAZIL)	PAM	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	PLGM	√	√	√	√	○	√	※	
2018	M1-COMPASS (BRAZIL)	RBSS	√	√	√	√	○	√	○	
2018	M1-COMPASS (BRAZIL)	RFH	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	RRM	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	TBM	√	√	√	√	○	√	√	
2018	M1-COMPASS (BRAZIL)	TCM	√	√	√	√	※	※	※	
2018	M1-COMPASS (BRAZIL)	TTM	√	√	√	√	○	√	※	
2018	M4-COMPASS (CHINA)	ABS	√	√	√	√	○	√	√	
2018	M4-COMPASS (CHINA)	ACC	√	√	√	√	○	○	√	

2018	M4-COMPASS (CHINA)	AMP	√	√	√	√	o	√	o	
2018	M4-COMPASS (CHINA)	BCM	√	√	√	√	o	√	√	
2018	M4-COMPASS (CHINA)	CSWM	√	√	√	√	o	√	√	
2018	M4-COMPASS (CHINA)	DTCM	√	√	√	√	o	o	o	
2018	M4-COMPASS (CHINA)	DTV	√	√	√	√	o	√	o	
2018	M4-COMPASS (CHINA)	ECM	√	√	√	√	※	√	※	
2018	M4-COMPASS (CHINA)	EPS	√	√	√	√	o	o	√	
2018	M4-COMPASS (CHINA)	ESL	√	√	√	√	o	※	※	
2018	M4-COMPASS (CHINA)	ESM	√	√	√	√	o	o	√	
2018	M4-COMPASS (CHINA)	ETM	√	√	√	√	o	√	√	
2018	M4-COMPASS (CHINA)	FFCM	√	√	√	√	o	o	√	
2018	M4-COMPASS (CHINA)	HVAC	√	√	√	√	o	√	√	
2018	M4-COMPASS (CHINA)	ICS	√	√	√	√	o	√	√	
2018	M4-COMPASS (CHINA)	IPC	√	√	√	√	o	√	√	
2018	M4-COMPASS (CHINA)	LBSS	√	√	√	√	o	√	o	
2018	M4-COMPASS (CHINA)	MSM	√	√	√	√	o	√	o	
2018	M4-COMPASS (CHINA)	OCM	√	√	√	√	o	o	√	
2018	M4-COMPASS (CHINA)	ORC	√	√	√	√	o	o	√	
2018	M4-COMPASS (CHINA)	PAM	√	√	√	√	o	√	√	
2018	M4-COMPASS (CHINA)	PLGM	√	√	√	√	o	√	※	
2018	M4-COMPASS (CHINA)	RBSS	√	√	√	√	o	√	o	
2018	M4-COMPASS (CHINA)	RFH	√	√	√	√	o	√	√	
2018	M4-COMPASS (CHINA)	RRM	√	√	√	√	o	√	√	
2018	M4-COMPASS (CHINA)	TBM	√	√	√	√	o	√	√	
2018	M4-COMPASS (CHINA)	TCM	√	√	√	√	※	※	※	
2018	M4-COMPASS (CHINA)	TTM	√	√	√	√	o	√	※	
2018	M6-SS6	ABS	√	√	√	√	o	√	√	
2018	M6-SS6	ACC	√	√	√	√	o	o	√	
2018	M6-SS6	AMP	√	√	√	√	o	√	o	
2018	M6-SS6	BCM	√	√	√	√	o	√	√	
2018	M6-SS6	CSWM	√	√	√	√	o	√	√	
2018	M6-SS6	DTCM	√	√	√	√	o	o	o	
2018	M6-SS6	DTV	√	√	√	√	o	√	o	
2018	M6-SS6	ECM	√	√	√	√	※	√	※	
2018	M6-SS6	EPS	√	√	√	√	o	o	√	
2018	M6-SS6	ESL	√	√	√	√	o	※	※	
2018	M6-SS6	ESM	√	√	√	√	o	o	√	
2018	M6-SS6	ETM	√	√	√	√	o	√	√	
2018	M6-SS6	FFCM	√	√	√	√	o	o	√	
2018	M6-SS6	HVAC	√	√	√	√	o	√	√	
2018	M6-SS6	ICS	√	√	√	√	o	√	√	
2018	M6-SS6	IPC	√	√	√	√	o	√	√	
2018	M6-SS6	LBSS	√	√	√	√	o	√	o	
2018	M6-SS6	MSM	√	√	√	√	o	√	o	
2018	M6-SS6	OCM	√	√	√	√	o	o	√	
2018	M6-SS6	ORC	√	√	√	√	o	o	√	
2018	M6-SS6	PAM	√	√	√	√	o	√	√	
2018	M6-SS6	PLGM	√	√	√	√	o	√	※	
2018	M6-SS6	RBSS	√	√	√	√	o	√	o	
2018	M6-SS6	RFH	√	√	√	√	o	√	√	
2018	M6-SS6	RRM	√	√	√	√	o	√	√	
2018	M6-SS6	TBM	√	√	√	√	o	√	√	
2018	M6-SS6	TCM	√	√	√	√	※	※	※	
2018	M6-SS6	TTM	√	√	√	√	o	√	※	
2018	MK-Compass,Patriot	ABS	√	√	√	√	o	√	√	
2018	MK-Compass,Patriot	AMP	√	√	√	√	o	o	√	
2018	MK-Compass,Patriot	CGW	√	√	√	√	o	√	√	
2018	MK-Compass,Patriot	ECM	√	√	√	√	※	√	※	
2018	MK-Compass,Patriot	FDCM	√	√	√	√	o	√	√	
2018	MK-Compass,Patriot	HFM	√	√	√	√	o	√	o	
2018	MK-Compass,Patriot	HVAC	√	√	√	√	o	√	√	
2018	MK-Compass,Patriot	ITM	√	√	√	√	o	√	√	
2018	MK-Compass,Patriot	MIC/CCN	√	√	√	√	o	√	√	
2018	MK-Compass,Patriot	ORC	√	√	√	√	o	o	√	
2018	MK-Compass,Patriot	RADIO	√	√	√	√	o	※	※	
2018	MK-Compass,Patriot	SAS	√	√	√	√	o	o	o	
2018	MK-Compass,Patriot	TCM	√	√	√	√	※	√	√	
2018	MK-Compass,Patriot	WCM/TPMS	√	√	√	√	o	o	√	
2018	MP-COMPASS	ABS	√	√	√	√	o	√	√	
2018	MP-COMPASS	ACC	√	√	√	√	o	o	√	
2018	MP-COMPASS	AMP	√	√	√	√	o	√	o	
2018	MP-COMPASS	BCM	√	√	√	√	o	√	√	
2018	MP-COMPASS	CSWM	√	√	√	√	o	√	√	
2018	MP-COMPASS	DTCM	√	√	√	√	o	o	o	
2018	MP-COMPASS	DTV	√	√	√	√	o	√	o	
2018	MP-COMPASS	ECM	√	√	√	√	※	√	※	
2018	MP-COMPASS	EPS	√	√	√	√	o	o	√	

2018	MP-COMPASS	ESL	√	√	√	√	o	※	※	
2018	MP-COMPASS	ESM	√	√	√	√	o	○	√	
2018	MP-COMPASS	ETM	√	√	√	√	o	√	√	
2018	MP-COMPASS	FFCM	√	√	√	√	o	○	√	
2018	MP-COMPASS	HVAC	√	√	√	√	o	√	√	
2018	MP-COMPASS	ICS	√	√	√	√	o	√	√	
2018	MP-COMPASS	IPC	√	√	√	√	o	√	√	
2018	MP-COMPASS	LBSS	√	√	√	√	o	√	○	
2018	MP-COMPASS	MSM	√	√	√	√	o	√	○	
2018	MP-COMPASS	OCM	√	√	√	√	o	○	√	
2018	MP-COMPASS	ORC	√	√	√	√	o	○	√	
2018	MP-COMPASS	PAM	√	√	√	√	o	√	√	
2018	MP-COMPASS	PLGM	√	√	√	√	o	√	※	
2018	MP-COMPASS	RBSS	√	√	√	√	o	√	○	
2018	MP-COMPASS	RFH	√	√	√	√	o	√	√	
2018	MP-COMPASS	RRM	√	√	√	√	o	√	√	
2018	MP-COMPASS	TBM	√	√	√	√	o	√	√	
2018	MP-COMPASS	TCM	√	√	√	√	※	※	※	
2018	MP-COMPASS	TTM	√	√	√	√	o	√	※	
2018	PD-Neon	ABS	√	√	√	√	o	√	√	
2018	PD-Neon	ACC	√	√	√	√	o	√	√	
2018	PD-Neon	AHM	√	√	√	√	o	○	√	
2018	PD-Neon	BCM	√	√	√	√	o	√	√	
2018	PD-Neon	ECM	√	√	√	√	o	√	※	
2018	PD-Neon	EPS	√	√	√	√	o	○	○	
2018	PD-Neon	ESM	√	√	√	√	o	√	√	
2018	PD-Neon	ETM	√	√	√	√	o	√	√	
2018	PD-Neon	HVAC	√	√	√	√	o	√	√	
2018	PD-Neon	IPC	√	√	√	√	o	√	√	
2018	PD-Neon	ORC	√	√	√	√	o	○	√	
2018	PD-Neon	PAM	√	√	√	√	o	○	○	
2018	PD-Neon	RRM	√	√	√	√	o	√	√	
2018	PD-Neon	TCM	√	√	√	√	o	○	○	
2018	RT-Caravan,Voyater,Town & country	ABS	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	AHBM	√	√	√	√	o	√	○	
2018	RT-Caravan,Voyater,Town & country	AMP	√	√	√	√	o	○	√	
2018	RT-Caravan,Voyater,Town & country	CGW	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	DOORS	√	√	√	√	o	※	※	
2018	RT-Caravan,Voyater,Town & country	DVD	√	√	√	√	o	○	○	
2018	RT-Caravan,Voyater,Town & country	ECM	√	√	√	√	※	√	√	
2018	RT-Caravan,Voyater,Town & country	EPPM	√	√	√	√	o	○	√	
2018	RT-Caravan,Voyater,Town & country	FSM	√	√	√	√	o	√	○	
2018	RT-Caravan,Voyater,Town & country	HFM	√	√	√	√	o	√	○	
2018	RT-Caravan,Voyater,Town & country	HIDT	√	√	√	√	o	√	○	
2018	RT-Caravan,Voyater,Town & country	HSM	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	HVAC	√	√	√	√	o	√	※	
2018	RT-Caravan,Voyater,Town & country	ITM	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	LBSS	√	√	√	√	o	○	○	
2018	RT-Caravan,Voyater,Town & country	MIC/CCN	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	MSM	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	ORC	√	√	√	√	o	○	√	
2018	RT-Caravan,Voyater,Town & country	PEM	√	√	√	√	o	○	√	
2018	RT-Caravan,Voyater,Town & country	PLGM	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	PTS	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	RADIO	√	√	√	√	o	※	※	
2018	RT-Caravan,Voyater,Town & country	RBSS	√	√	√	√	o	○	○	
2018	RT-Caravan,Voyater,Town & country	SAS	√	√	√	√	o	○	○	
2018	RT-Caravan,Voyater,Town & country	SUNR	√	√	√	√	o	√	○	
2018	RT-Caravan,Voyater,Town & country	TCM	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	TPM	√	√	√	√	o	○	√	
2018	RT-Caravan,Voyater,Town & country	VES2	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	VES3	√	√	√	√	o	√	√	
2018	RT-Caravan,Voyater,Town & country	WCM/TPMS	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	ABS	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	ABSD	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	ACC	√	√	√	√	o	○	○	
2018	RU-CHRYSLER PACIFICA	AHCP	√	√	√	o	o	○	○	
2018	RU-CHRYSLER PACIFICA	AHLM	√	√	√	√	o	√	○	
2018	RU-CHRYSLER PACIFICA	AMP	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	ANC	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	APM	√	√	√	√	o	○	○	
2018	RU-CHRYSLER PACIFICA	BCM	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	BPCM	√	√	√	√	o	√	○	
2018	RU-CHRYSLER PACIFICA	CVPM	√	√	√	√	o	○	○	
2018	RU-CHRYSLER PACIFICA	DOORS	√	√	√	√	o	※	※	
2018	RU-CHRYSLER PACIFICA	DSM	√	√	√	√	o	○	○	
2018	RU-CHRYSLER PACIFICA	EAC	√	√	√	√	o	○	○	

2018	RU-CHRYSLER PACIFICA	EAM	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	EBBM	√	√	√	√	o	o	o	
2018	RU-CHRYSLER PACIFICA	ECM	√	√	√	√	√	√	√	
2018	RU-CHRYSLER PACIFICA	EDM	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	EOMR	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	EPS	√	√	√	√	o	o	√	
2018	RU-CHRYSLER PACIFICA	ESL	√	√	√	√	o	o	o	
2018	RU-CHRYSLER PACIFICA	ESM	√	√	√	√	o	√	o	
2018	RU-CHRYSLER PACIFICA	FFCM	√	√	√	√	o	o	√	
2018	RU-CHRYSLER PACIFICA	FSM	√	√	√	√	o	√	o	
2018	RU-CHRYSLER PACIFICA	HCP	√	√	√	√	o	√	o	
2018	RU-CHRYSLER PACIFICA	HSM	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	HVAC	√	√	√	√	o	√	o	
2018	RU-CHRYSLER PACIFICA	HVACR	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	ICS	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	IPC	√	√	√	√	o	√	o	
2018	RU-CHRYSLER PACIFICA	LBSS	√	√	√	o	o	o	o	
2018	RU-CHRYSLER PACIFICA	MSM	√	√	√	√	o	o	√	
2018	RU-CHRYSLER PACIFICA	OBCM	√	√	√	√	o	o	o	
2018	RU-CHRYSLER PACIFICA	OCM	√	√	√	√	o	o	o	
2018	RU-CHRYSLER PACIFICA	ORC	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	PLGM	√	√	√	√	o	√	o	
2018	RU-CHRYSLER PACIFICA	PTS	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	RADIO	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	RBSS	√	√	√	o	o	o	o	
2018	RU-CHRYSLER PACIFICA	RFH	√	√	√	√	o	√	√	
2018	RU-CHRYSLER PACIFICA	SCCM	√	√	√	√	o	o	o	
2018	RU-CHRYSLER PACIFICA	TCM	√	√	√	√	√	o	√	
2018	RU-CHRYSLER PACIFICA	VRM	√	√	√	√	o	o	o	
2018	UF-CHRYSLER 200	ABS	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	ACC	√	√	√	√	o	o	√	
2018	UF-CHRYSLER 200	AMP	√	√	√	√	o	o	o	
2018	UF-CHRYSLER 200	BCM	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	CSWM	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	DOORS	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	DTCM	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	ECM	√	√	√	√	√	√	√	
2018	UF-CHRYSLER 200	EPB	√	√	√	√	o	o	√	
2018	UF-CHRYSLER 200	EPS	√	√	√	√	o	o	o	
2018	UF-CHRYSLER 200	ESM	√	√	√	√	o	o	o	
2018	UF-CHRYSLER 200	FFCM	√	√	√	√	o	o	√	
2018	UF-CHRYSLER 200	HVAC	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	ICS	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	IPC	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	LBSS	√	√	√	√	o	o	√	
2018	UF-CHRYSLER 200	MSM	√	√	√	√	o	o	o	
2018	UF-CHRYSLER 200	OCM	√	√	√	√	o	o	√	
2018	UF-CHRYSLER 200	ORC	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	PAM	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	PTU	√	√	√	o	o	o	o	
2018	UF-CHRYSLER 200	RADIO	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	RBSS	√	√	√	√	o	o	√	
2018	UF-CHRYSLER 200	RFH	√	√	√	√	o	√	√	
2018	UF-CHRYSLER 200	RRM	√	√	√	√	o	o	√	
2018	UF-CHRYSLER 200	SCCM	√	√	√	√	o	o	√	
2018	UF-CHRYSLER 200	TCM	√	√	√	√	√	o	√	
2018	VF-ProMaster	ABS	√	√	√	√	o	※	√	
2018	VF-ProMaster	BCM	√	√	√	√	o	√	√	
2018	VF-ProMaster	ECM	√	√	√	√	※	√	√	
2018	VF-ProMaster	EPB	√	√	√	√	o	√	o	
2018	VF-ProMaster	ETM	√	√	√	√	o	※	√	
2018	VF-ProMaster	HVAC	√	√	√	√	o	√	o	
2018	VF-ProMaster	IPC	√	√	√	√	o	√	o	
2018	VF-ProMaster	ORC	√	√	√	√	o	o	√	
2018	VF-ProMaster	PAM	√	√	√	√	o	o	o	
2018	VF-ProMaster	RADIO	√	√	√	√	o	√	√	
2018	VF-ProMaster	TCM	√	√	√	√	o	√	√	
2018	VF-ProMaster	TPM	√	√	√	√	o	√	√	
2018	VM-ProMaster city	ABS	√	√	√	√	o	√	o	
2018	VM-ProMaster city	BCM	√	√	√	√	o	√	√	
2018	VM-ProMaster city	ECM	√	√	√	√	√	√	√	
2018	VM-ProMaster city	ESM	√	√	√	√	o	√	o	
2018	VM-ProMaster city	ETM	√	√	√	√	o	√	√	
2018	VM-ProMaster city	HVAC	√	√	√	√	o	√	※	
2018	VM-ProMaster city	IPC	√	√	√	√	o	√	o	
2018	VM-ProMaster city	ORC	√	√	√	√	o	o	o	
2018	VM-ProMaster city	PAM	√	√	√	√	o	o	o	

2018	VM-ProMaster city	RADIO	√	√	√	√	o	√	√	
2018	VM-ProMaster city	TCM	√	√	√	※	※	o	※	
2018	VM-ProMaster city	TPM	√	√	√	√	o	√	√	
2018	VM-ProMaster city	TTM	√	√	√	√	o	o	√	
2018	WD-Durango	ABS	√	√	√	√	o	√	√	
2018	WD-Durango	ACC	√	√	√	√	o	o	o	
2018	WD-Durango	AHLM	√	√	√	√	o	o	o	
2018	WD-Durango	AMP	√	√	√	√	o	o	√	
2018	WD-Durango	BCM	√	√	√	√	o	√	√	
2018	WD-Durango	DOORS	√	√	√	√	o	√	√	
2018	WD-Durango	DTCM	√	√	√	√	o	√	√	
2018	WD-Durango	ECM	√	√	√	√	√	√	√	
2018	WD-Durango	EDM	√	√	√	√	o	√	√	
2018	WD-Durango	ELSD	√	√	√	√	o	o	o	
2018	WD-Durango	EPS	√	√	√	√	o	o	※	
2018	WD-Durango	ESM	√	√	√	√	o	※	o	
2018	WD-Durango	FFCM	√	√	√	※	o	o	※	
2018	WD-Durango	HSM	√	√	√	√	o	√	√	
2018	WD-Durango	HVAC	√	√	√	√	o	√	o	
2018	WD-Durango	HVACR	√	√	√	√	o	√	√	
2018	WD-Durango	ICS	√	√	√	√	o	※	※	
2018	WD-Durango	IPC	√	√	√	√	o	√	√	
2018	WD-Durango	ITM	√	√	√	√	o	√	√	
2018	WD-Durango	LBSS	√	√	√	o	o	o	o	
2018	WD-Durango	MSM	√	√	√	√	o	√	√	
2018	WD-Durango	ORC	√	√	√	√	o	o	√	
2018	WD-Durango	PLGM	√	√	√	√	o	√	o	
2018	WD-Durango	PTS	√	√	√	√	o	√	√	
2018	WD-Durango	RADIO	√	√	√	√	o	√	√	
2018	WD-Durango	RBSS	√	√	√	o	o	o	o	
2018	WD-Durango	RFH	√	√	√	√	o	√	√	
2018	WD-Durango	SCCM	√	√	√	√	o	o	√	
2018	WD-Durango	TCM	√	√	√	√	※	o	√	
2018	WD-Durango	VES2	√	√	√	√	o	√	o	
2018	WD-Durango	VES3	√	√	√	√	o	√	o	
2018	WK-Grand cherokee	ABS	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	ACC	√	√	√	√	o	o	o	
2018	WK-Grand cherokee	ADCM	√	√	√	√	o	√	o	
2018	WK-Grand cherokee	AFLS	√	√	√	√	o	o	√	
2018	WK-Grand cherokee	AMP	√	√	√	√	o	※	※	
2018	WK-Grand cherokee	ANC	√	√	√	√	o	o	√	
2018	WK-Grand cherokee	ASCM	√	√	√	√	o	o	√	
2018	WK-Grand cherokee	BCM	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	DOORS	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	DTCM	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	DTV	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	EAM	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	ECM	√	√	√	√	※	√	√	
2018	WK-Grand cherokee	EDM	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	ELSD	√	√	√	√	o	o	o	
2018	WK-Grand cherokee	EPS	√	√	√	√	o	o	※	
2018	WK-Grand cherokee	ESM	√	√	√	√	o	※	o	
2018	WK-Grand cherokee	FFCM	√	√	√	※	o	o	※	
2018	WK-Grand cherokee	HSM	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	HVAC	√	√	√	√	o	√	o	
2018	WK-Grand cherokee	ICS	√	√	√	√	o	※	※	
2018	WK-Grand cherokee	IPC	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	ITM	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	LBSS	√	√	√	o	o	o	o	
2018	WK-Grand cherokee	MSM	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	ORC	√	√	√	√	o	o	√	
2018	WK-Grand cherokee	PLGM	√	√	√	√	o	√	o	
2018	WK-Grand cherokee	PTS	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	RADIO	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	RBSS	√	√	√	o	o	o	o	
2018	WK-Grand cherokee	RFH	√	√	√	√	o	√	√	
2018	WK-Grand cherokee	SCCM	√	√	√	√	o	o	√	
2018	WK-Grand cherokee	TCM	√	√	√	√	※	o	√	
2018	WK-Grand cherokee	TPM	√	√	√	√	o	o	√	
2018	WK-Grand cherokee	VES2	√	√	√	√	o	√	o	
2018	WK-Grand cherokee	VES3	√	√	√	√	o	√	o	
2018	ZD-Viper (Post-2013)	ABS	√	√	√	√	o	√	√	
2018	ZD-Viper (Post-2013)	ADCM	√	√	√	√	o	o	o	
2018	ZD-Viper (Post-2013)	AMP	√	√	√	√	o	o	√	
2018	ZD-Viper (Post-2013)	BCM	√	√	√	√	o	√	√	
2018	ZD-Viper (Post-2013)	DOORS	√	√	√	√	o	√	√	
2018	ZD-Viper (Post-2013)	ECM	√	√	√	√	√	√	o	

2018	ZD-Viper (Post-2013)	HVAC	√	√	√	√	o	√	√	
2018	ZD-Viper (Post-2013)	ICS	√	√	√	√	o	√	√	
2018	ZD-Viper (Post-2013)	IPC	√	√	√	√	o	√	√	
2018	ZD-Viper (Post-2013)	OCM	√	√	√	√	o	○	○	
2018	ZD-Viper (Post-2013)	ORC	√	√	√	√	o	√	√	
2018	ZD-Viper (Post-2013)	RADIO	√	√	√	√	o	√	√	
2018	ZD-Viper (Post-2013)	RFH	√	√	√	√	o	√	√	
2018	ZD-Viper (Post-2013)	SCCM	√	√	√	√	o	○	○	
2018	ZD-Viper (Post-2013)	TPM	√	√	√	√	o	○	√	
2019	B1-RENEGADE (LATM)	ABS	√	√	√	√	o	√	√	
2019	B1-RENEGADE (LATM)	ACC	√	√	√	√	o	√	√	
2019	B1-RENEGADE (LATM)	AMP	√	√	√	√	o	√	√	
2019	B1-RENEGADE (LATM)	BCM	√	√	√	√	※	√	※	
2019	B1-RENEGADE (LATM)	CSWM	√	√	√	√	o	√	○	
2019	B1-RENEGADE (LATM)	DTCM	√	√	√	√	o	○	○	
2019	B1-RENEGADE (LATM)	ECM	√	√	√	√	※	√	※	
2019	B1-RENEGADE (LATM)	EPS	√	√	√	√	o	○	√	
2019	B1-RENEGADE (LATM)	ESL	√	√	√	√	o	√	√	
2019	B1-RENEGADE (LATM)	ESM	√	√	√	√	o	√	√	
2019	B1-RENEGADE (LATM)	ETM	√	√	√	√	o	※	√	
2019	B1-RENEGADE (LATM)	HALF	√	√	√	√	o	○	√	
2019	B1-RENEGADE (LATM)	HVAC	√	√	√	√	o	√	√	
2019	B1-RENEGADE (LATM)	IPC	√	√	√	√	※	√	√	
2019	B1-RENEGADE (LATM)	LBSS	√	√	√	√	o	√	○	
2019	B1-RENEGADE (LATM)	ORC	√	√	√	√	o	○	√	
2019	B1-RENEGADE (LATM)	PAM	√	√	√	√	o	○	○	
2019	B1-RENEGADE (LATM)	RBSS	√	√	√	√	o	√	○	
2019	B1-RENEGADE (LATM)	RFH	√	√	√	√	o	√	○	
2019	B1-RENEGADE (LATM)	RRM	√	√	√	√	o	√	√	
2019	B1-RENEGADE (LATM)	TCM	√	√	√	※	※	※	※	
2019	B1-RENEGADE (LATM)	TTM	√	√	√	√	o	√	○	
2019	BV-RENEGADE	ABS	√	√	√	√	o	√	√	
2019	BV-RENEGADE	ACC	√	√	√	√	o	√	√	
2019	BV-RENEGADE	AMP	√	√	√	√	o	√	√	
2019	BV-RENEGADE	BCM	√	√	√	√	o	√	√	
2019	BV-RENEGADE	CSWM	√	√	√	√	o	√	○	
2019	BV-RENEGADE	DCU	○	√	√	○	○	○	○	
2019	BV-RENEGADE	DTCM	√	√	√	√	o	○	○	
2019	BV-RENEGADE	ECM	√	√	√	√	※	√	※	
2019	BV-RENEGADE	EPS	√	√	√	√	o	○	√	
2019	BV-RENEGADE	ESL	√	√	√	√	o	√	√	
2019	BV-RENEGADE	ESM	√	√	√	√	o	√	√	
2019	BV-RENEGADE	ETM	√	√	√	√	o	√	√	
2019	BV-RENEGADE	HVAC	√	√	√	√	o	√	√	
2019	BV-RENEGADE	ICS	√	√	√	√	o	√	√	
2019	BV-RENEGADE	IPC	√	√	√	√	o	√	√	
2019	BV-RENEGADE	LBSS	√	√	√	√	o	√	○	
2019	BV-RENEGADE	PAM	√	√	√	√	o	○	○	
2019	BV-RENEGADE	RBSS	√	√	√	√	o	√	○	
2019	BV-RENEGADE	RFH	√	√	√	√	o	√	○	
2019	BV-RENEGADE	RRM	√	√	√	√	o	√	√	
2019	BV-RENEGADE	TCM	√	√	√	√	o	※	※	
2019	BV-RENEGADE	TTM	√	√	√	√	o	√	○	
2019	D2-Ram 3500 Pickup	ABS	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	AMP	√	√	√	√	o	○	√	
2019	D2-Ram 3500 Pickup	ASCM	√	√	√	√	o	○	√	
2019	D2-Ram 3500 Pickup	BCM	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	DCU	√	√	√	○	o	○	○	
2019	D2-Ram 3500 Pickup	DOORS	√	√	√	√	o	√	※	
2019	D2-Ram 3500 Pickup	DTCM	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	ECM	√	√	√	√	√	√	√	
2019	D2-Ram 3500 Pickup	EDM	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	HSM	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	HVAC	√	√	√	√	o	√	※	
2019	D2-Ram 3500 Pickup	ICS	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	IPC	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	ITBM	√	√	√	√	o	○	○	
2019	D2-Ram 3500 Pickup	MSM	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	ORC	√	√	√	√	o	※	√	
2019	D2-Ram 3500 Pickup	PTS	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	RADIO	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	RFH	√	√	√	√	o	√	√	
2019	D2-Ram 3500 Pickup	SCCM	√	√	√	√	o	○	○	
2019	D2-Ram 3500 Pickup	TCM	√	√	√	√	√	√	√	
2019	D2-Ram 3500 Pickup	VGT	√	√	√	○	o	○	○	
2019	D2-Ram 3500 Pickup	VSIM	√	√	√	√	o	√	○	
2019	DJ-Ram 2500	ABS	√	√	√	√	o	√	√	

2019	DJ-Ram 2500	AMP	√	√	√	√	o	○	√	
2019	DJ-Ram 2500	ASCM	√	√	√	√	o	○	√	
2019	DJ-Ram 2500	BCM	√	√	√	√	o	√	√	
2019	DJ-Ram 2500	DCU	√	√	√	○	o	○	○	
2019	DJ-Ram 2500	DOORS	√	√	√	√	o	√	※	
2019	DJ-Ram 2500	DTCM	√	√	√	√	o	√	√	
2019	DJ-Ram 2500	ECM	√	√	√	√	√	√	√	
2019	DJ-Ram 2500	EDM	√	√	√	√	o	√	√	
2019	DJ-Ram 2500	ESM	√	√	√	√	o	○	○	
2019	DJ-Ram 2500	FDCM	√	√	√	√	o	○	○	
2019	DJ-Ram 2500	HSM	√	√	√	√	o	√	√	
2019	DJ-Ram 2500	HVAC	√	√	√	√	o	√	※	
2019	DJ-Ram 2500	ICS	√	√	√	√	o	√	√	
2019	DJ-Ram 2500	IPC	√	√	√	√	o	√	√	
2019	DJ-Ram 2500	ITBM	√	√	√	√	o	○	○	
2019	DJ-Ram 2500	MSM	√	√	√	√	o	√	√	
2019	DJ-Ram 2500	ORC	√	√	√	√	o	※	√	
2019	DJ-Ram 2500	PTS	√	√	√	√	o	√	√	
2019	DJ-Ram 2500	RADIO	√	√	√	√	o	√	√	
2019	DJ-Ram 2500	RFH	√	√	√	√	o	√	√	
2019	DJ-Ram 2500	SCCM	√	√	√	√	o	○	○	
2019	DJ-Ram 2500	TCM	√	√	√	√	√	√	√	
2019	DJ-Ram 2500	VGT	√	√	√	o	o	○	○	
2019	DJ-Ram 2500	VSIM	√	√	√	√	o	√	○	
2019	DP-Ram 4500/5500	ABS	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	AMP	√	√	√	√	o	○	√	
2019	DP-Ram 4500/5500	BCM	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	DCU	√	√	√	○	o	○	○	
2019	DP-Ram 4500/5500	DOORS	√	√	√	√	o	√	※	
2019	DP-Ram 4500/5500	DTCM	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	ECM	√	√	√	√	√	√	√	
2019	DP-Ram 4500/5500	EDM	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	HSM	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	HVAC	√	√	√	√	o	√	※	
2019	DP-Ram 4500/5500	ICS	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	IPC	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	ITBM	√	√	√	√	o	○	○	
2019	DP-Ram 4500/5500	MSM	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	ORC	√	√	√	√	o	※	√	
2019	DP-Ram 4500/5500	PTS	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	RADIO	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	RFH	√	√	√	√	o	√	√	
2019	DP-Ram 4500/5500	SCCM	√	√	√	√	o	○	○	
2019	DP-Ram 4500/5500	TCM	√	√	√	√	※	√	√	
2019	DP-Ram 4500/5500	VGT	√	√	√	○	o	○	○	
2019	DP-Ram 4500/5500	VSIM	√	√	√	√	o	√	○	
2019	DS-Ram 1500	ABS	√	√	√	√	o	√	√	
2019	DS-Ram 1500	AMP	√	√	√	√	o	○	√	
2019	DS-Ram 1500	ASCM	√	√	√	√	o	○	√	
2019	DS-Ram 1500	BCM	√	√	√	√	o	√	√	
2019	DS-Ram 1500	DOORS	√	√	√	√	o	√	√	
2019	DS-Ram 1500	DTCM	√	√	√	√	o	√	√	
2019	DS-Ram 1500	ECM	√	√	√	√	※	√	√	
2019	DS-Ram 1500	EDM	√	√	√	√	o	√	√	
2019	DS-Ram 1500	EPS	√	√	√	√	o	○	○	
2019	DS-Ram 1500	ESM	√	√	√	√	o	○	○	
2019	DS-Ram 1500	HSM	√	√	√	√	o	√	√	
2019	DS-Ram 1500	HVAC	√	√	√	√	o	√	√	
2019	DS-Ram 1500	ICS	√	√	√	√	o	√	√	
2019	DS-Ram 1500	IPC	√	√	√	√	o	√	√	
2019	DS-Ram 1500	MSM	√	√	√	√	o	√	√	
2019	DS-Ram 1500	ORC	√	√	√	√	o	○	√	
2019	DS-Ram 1500	PTS	√	√	√	√	o	√	√	
2019	DS-Ram 1500	RADIO	√	√	√	√	o	√	√	
2019	DS-Ram 1500	RFH	√	√	√	√	o	○	√	
2019	DS-Ram 1500	SCCM	√	√	√	√	o	○	○	
2019	DS-Ram 1500	TCM	√	√	√	√	o	○	√	
2019	DS-Ram 1500	VSIM	√	√	√	√	o	√	○	
2019	DT-Ram 1500	ABS	√	√	√	√	o	√	√	
2019	DT-Ram 1500	BCM	√	√	√	√	o	√	√	
2019	DT-Ram 1500	CSWM	√	√	√	√	o	√	○	
2019	DT-Ram 1500	DOORS	√	√	√	√	o	√	※	
2019	DT-Ram 1500	ECM	√	√	√	√	o	√	√	
2019	DT-Ram 1500	EDM	√	√	√	√	o	√	√	
2019	DT-Ram 1500	EPS	√	√	√	√	o	○	√	
2019	DT-Ram 1500	ESM	√	√	√	√	o	○	○	
2019	DT-Ram 1500	HVAC	√	√	√	√	o	√	○	

2019	DT-Ram 1500	ICS	√	√	√	√	o	√	√	
2019	DT-Ram 1500	IPC	√	√	√	√	o	√	√	
2019	DT-Ram 1500	ORC	√	√	√	√	o	√	√	
2019	DT-Ram 1500	RADIO	√	√	√	√	o	√	√	
2019	DT-Ram 1500	RFH	√	√	√	√	o	√	√	
2019	DT-Ram 1500	SCCM	√	√	√	√	o	○	√	
2019	DT-Ram 1500	TCM	√	√	√	√	√	○	√	
2019	JC-Journey	ABS	√	√	√	√	o	√	√	
2019	JC-Journey	AMP	√	√	√	√	o	○	√	
2019	JC-Journey	BCM	√	√	√	√	o	√	√	
2019	JC-Journey	DOORS	√	√	√	√	o	√	√	
2019	JC-Journey	DTCM	√	√	√	√	o	√	√	
2019	JC-Journey	ECM	√	√	√	√	※	√	√	
2019	JC-Journey	EPPM	√	√	√	√	o	○	√	
2019	JC-Journey	HFM	√	√	√	√	o	○	√	
2019	JC-Journey	HSM	√	√	√	√	o	√	√	
2019	JC-Journey	HVAC	√	√	√	√	o	√	√	
2019	JC-Journey	ICS	√	√	√	√	o	√	√	
2019	JC-Journey	IPC	√	√	√	√	o	√	√	
2019	JC-Journey	ITM	√	√	√	√	o	√	√	
2019	JC-Journey	ORC	√	√	√	√	o	○	√	
2019	JC-Journey	PTS	√	√	√	√	o	√	√	
2019	JC-Journey	RFH	√	√	√	√	o	√	√	
2019	JC-Journey	SCCM	√	√	√	√	o	○	○	
2019	JC-Journey	TCM	√	√	√	√	o	√	√	
2019	JC-Journey	TGW	√	√	√	√	o	○	√	
2019	JC-Journey	TPM	√	√	√	√	o	○	√	
2019	JC-Journey	VES3	√	√	√	√	o	√	○	
2019	JC-Journey	VTM	√	√	√	√	o	○	○	
2019	JL-Wrangler	ABS	√	√	√	√	o	√	√	
2019	JL-Wrangler	AHLM	√	√	√	√	o	√	○	
2019	JL-Wrangler	AMP	√	√	√	√	o	○	√	
2019	JL-Wrangler	ASBS	√	√	√	√	o	○	○	
2019	JL-Wrangler	BCM	√	√	√	√	o	√	√	
2019	JL-Wrangler	BPCM	√	√	√	√	o	√	○	
2019	JL-Wrangler	CSWM	√	√	√	√	o	√	○	
2019	JL-Wrangler	DPDM	√	√	√	√	o	○	○	
2019	JL-Wrangler	DTCM	√	√	√	√	o	√	√	
2019	JL-Wrangler	DTV	√	√	√	√	o	√	√	
2019	JL-Wrangler	EAM	√	√	√	√	o	√	√	
2019	JL-Wrangler	ECM	√	√	√	√	o	√	√	
2019	JL-Wrangler	EPS	√	√	√	√	o	○	※	
2019	JL-Wrangler	ESL	√	√	√	√	o	○	○	
2019	JL-Wrangler	ESM	√	√	√	√	o	√	○	
2019	JL-Wrangler	HCP	√	√	√	√	√	○	○	
2019	JL-Wrangler	HVAC	√	√	√	√	o	√	※	
2019	JL-Wrangler	ICS	√	√	√	√	o	√	√	
2019	JL-Wrangler	IPC	√	√	√	√	o	√	※	
2019	JL-Wrangler	ITM	√	√	√	√	o	√	√	
2019	JL-Wrangler	LBSS	√	√	√	○	○	○	○	
2019	JL-Wrangler	OCM	√	√	√	√	o	○	√	
2019	JL-Wrangler	ORC	√	√	√	√	o	○	√	
2019	JL-Wrangler	PTCM	√	√	√	√	o	○	√	
2019	JL-Wrangler	PTS	√	√	√	√	o	√	√	
2019	JL-Wrangler	RADIO	√	√	√	√	o	√	√	
2019	JL-Wrangler	RBSS	√	√	√	○	○	○	○	
2019	JL-Wrangler	RFH	√	√	√	√	o	√	√	
2019	JL-Wrangler	SCCM	√	√	√	√	o	○	√	
2019	JL-Wrangler	TCM	√	√	√	√	※	○	※	
2019	JL-Wrangler	TPM	√	√	√	√	o	○	√	
2019	K8-Grand Commander	ABS	√	√	√	√	o	√	√	
2019	K8-Grand Commander	ACC	√	√	√	√	o	○	√	
2019	K8-Grand Commander	AFLS	√	√	√	○	○	○	○	
2019	K8-Grand Commander	AHLM	√	√	√	√	o	○	○	
2019	K8-Grand Commander	AMP	√	√	√	√	o	○	○	
2019	K8-Grand Commander	ANC	√	√	√	√	o	√	√	
2019	K8-Grand Commander	BCM	√	√	√	√	o	√	√	
2019	K8-Grand Commander	CSWM	√	√	√	√	o	√	√	
2019	K8-Grand Commander	DOORS	√	√	√	√	o	√	√	
2019	K8-Grand Commander	DTCM	√	√	√	√	o	√	√	
2019	K8-Grand Commander	DTV	√	√	√	√	o	√	√	
2019	K8-Grand Commander	ECM	√	√	√	√	o	√	√	
2019	K8-Grand Commander	EDM	√	√	√	○	○	√	○	
2019	K8-Grand Commander	EPB	√	√	√	√	o	○	√	
2019	K8-Grand Commander	EPS	√	√	√	√	o	○	○	
2019	K8-Grand Commander	ESL	√	√	√	√	o	○	○	
2019	K8-Grand Commander	ESM	√	√	√	√	o	√	○	

2019	K8-Grand Commander	FFCM	√	√	√	√	o	○	√	
2019	K8-Grand Commander	HVAC	√	√	√	√	o	√	√	
2019	K8-Grand Commander	HVACR	√	√	√	√	o	√	○	
2019	K8-Grand Commander	ICS	√	√	√	√	o	√	√	
2019	K8-Grand Commander	IPC	√	√	√	√	o	√	√	
2019	K8-Grand Commander	LBSS	√	√	√	√	o	○	√	
2019	K8-Grand Commander	MSM	√	√	√	√	o	○	○	
2019	K8-Grand Commander	OCM	√	√	√	√	o	○	√	
2019	K8-Grand Commander	ORC	√	√	√	√	o	√	√	
2019	K8-Grand Commander	PAM	√	√	√	√	o	√	√	
2019	K8-Grand Commander	PLGM	√	√	√	√	o	√	○	
2019	K8-Grand Commander	PTU	√	√	√	○	o	○	○	
2019	K8-Grand Commander	RADIO	√	√	√	√	o	√	√	
2019	K8-Grand Commander	RBSS	√	√	√	√	o	○	√	
2019	K8-Grand Commander	RCCC	√	√	√	√	o	√	○	
2019	K8-Grand Commander	RDM	√	√	√	○	o	○	○	
2019	K8-Grand Commander	RFH	√	√	√	√	o	√	√	
2019	K8-Grand Commander	SCCM	√	√	√	√	o	√	√	
2019	K8-Grand Commander	TBM	√	√	√	√	o	√	√	
2019	K8-Grand Commander	TCM	√	√	√	√	√	○	√	
2019	KL-Cherokee	ABS	√	√	√	√	o	√	√	
2019	KL-Cherokee	ACC	√	√	√	√	o	○	√	
2019	KL-Cherokee	AFLS	√	√	√	○	o	○	○	
2019	KL-Cherokee	AHLM	√	√	√	√	o	○	○	
2019	KL-Cherokee	AMP	√	√	√	√	o	○	○	
2019	KL-Cherokee	ANC	√	√	√	√	o	√	√	
2019	KL-Cherokee	BCM	√	√	√	√	o	√	√	
2019	KL-Cherokee	CSWM	√	√	√	√	o	√	√	
2019	KL-Cherokee	DCU	○	√	√	○	o	○	○	
2019	KL-Cherokee	DOORS	√	√	√	√	o	√	√	
2019	KL-Cherokee	DTCM	√	√	√	√	o	√	√	
2019	KL-Cherokee	DTV	√	√	√	√	o	√	√	
2019	KL-Cherokee	ECM	√	√	√	√	※	√	√	
2019	KL-Cherokee	EDM	√	√	√	○	o	√	○	
2019	KL-Cherokee	EPB	√	√	√	√	o	○	√	
2019	KL-Cherokee	EPS	√	√	√	√	o	○	○	
2019	KL-Cherokee	ESL	√	√	√	√	o	○	√	
2019	KL-Cherokee	ESM	√	√	√	√	o	√	○	
2019	KL-Cherokee	FFCM	√	√	√	√	o	○	√	
2019	KL-Cherokee	HVAC	√	√	√	√	o	√	√	
2019	KL-Cherokee	ICS	√	√	√	√	o	√	√	
2019	KL-Cherokee	IPC	√	√	√	√	o	√	√	
2019	KL-Cherokee	LBSS	√	√	√	√	o	○	√	
2019	KL-Cherokee	MSM	√	√	√	√	o	○	○	
2019	KL-Cherokee	OCM	√	√	√	√	o	○	√	
2019	KL-Cherokee	ORC	√	√	√	√	o	√	√	
2019	KL-Cherokee	PAM	√	√	√	√	o	√	√	
2019	KL-Cherokee	PLGM	√	√	√	√	o	√	○	
2019	KL-Cherokee	PTU	√	√	√	○	o	○	○	
2019	KL-Cherokee	RADIO	√	√	√	√	o	√	√	
2019	KL-Cherokee	RBSS	√	√	√	√	o	○	√	
2019	KL-Cherokee	RDM	√	√	√	○	o	○	○	
2019	KL-Cherokee	RFH	√	√	√	√	o	√	√	
2019	KL-Cherokee	SCCM	√	√	√	√	o	√	√	
2019	KL-Cherokee	TBM	√	√	√	√	o	√	√	
2019	KL-Cherokee	TCM	√	√	√	√	√	○	√	
2019	LA-Challenger	ABS	√	√	√	√	o	√	√	
2019	LA-Challenger	ACC	√	√	√	√	o	○	○	
2019	LA-Challenger	ADCM	√	√	√	√	o	√	○	
2019	LA-Challenger	AMP	√	√	√	√	o	○	√	
2019	LA-Challenger	BCM	√	√	√	√	o	√	√	
2019	LA-Challenger	DOORS	√	√	√	√	o	√	√	
2019	LA-Challenger	DTCM	√	√	√	√	o	√	○	
2019	LA-Challenger	ECM	√	√	√	√	o	√	√	
2019	LA-Challenger	EPS	√	√	√	√	o	○	√	
2019	LA-Challenger	ESM	√	√	√	√	o	√	○	
2019	LA-Challenger	HSM	√	√	√	√	o	√	√	
2019	LA-Challenger	HVAC	√	√	√	√	o	√	√	
2019	LA-Challenger	ICS	√	√	√	√	o	√	√	
2019	LA-Challenger	IPC	√	√	√	√	o	√	√	
2019	LA-Challenger	LBSS	√	√	√	√	o	○	○	
2019	LA-Challenger	MSM	√	√	√	√	o	√	√	
2019	LA-Challenger	ORC	√	√	√	√	o	○	√	
2019	LA-Challenger	PTS	√	√	√	√	o	※	√	
2019	LA-Challenger	RADIO	√	√	√	√	o	√	√	
2019	LA-Challenger	RBSS	√	√	√	√	o	○	○	
2019	LA-Challenger	RFH	√	√	√	√	o	√	√	

2019	LA-Challenger	SCCM	√	√	√	√	o	○	√	
2019	LA-Challenger	TCM	√	√	√	√	√	○	√	
2019	LA-Challenger	TPM	√	√	√	√	o	○	√	
2019	LD-Charger	ABS	√	√	√	√	o	√	√	
2019	LD-Charger	ACC	√	√	√	√	o	○	o	
2019	LD-Charger	ADCM	√	√	√	√	o	√	o	
2019	LD-Charger	AMP	√	√	√	√	o	○	√	
2019	LD-Charger	BCM	√	√	√	√	o	√	√	
2019	LD-Charger	DOORS	√	√	√	√	o	√	√	
2019	LD-Charger	DSM	√	√	√	√	o	○	o	
2019	LD-Charger	DTCM	√	√	√	√	o	√	o	
2019	LD-Charger	ECM	√	√	√	√	o	√	√	
2019	LD-Charger	EPS	√	√	√	√	o	○	√	
2019	LD-Charger	ESM	√	√	√	√	o	√	o	
2019	LD-Charger	FFCM	√	√	√	√	o	○	o	
2019	LD-Charger	HSM	√	√	√	√	o	√	√	
2019	LD-Charger	HVAC	√	√	√	√	o	√	√	
2019	LD-Charger	ICS	√	√	√	√	o	√	√	
2019	LD-Charger	IPC	√	√	√	√	o	√	√	
2019	LD-Charger	ITM	√	√	√	√	o	√	√	
2019	LD-Charger	LBSS	√	√	√	√	o	○	o	
2019	LD-Charger	MSM	√	√	√	√	o	√	√	
2019	LD-Charger	ORC	√	√	√	√	o	○	√	
2019	LD-Charger	PTS	√	√	√	√	o	※	√	
2019	LD-Charger	RADIO	√	√	√	√	o	√	√	
2019	LD-Charger	RBSS	√	√	√	√	o	○	o	
2019	LD-Charger	RFH	√	√	√	√	o	√	√	
2019	LD-Charger	SCCM	√	√	√	√	o	○	√	
2019	LD-Charger	TCM	√	√	√	√	※	○	√	
2019	LD-Charger	TPM	√	√	√	√	o	○	√	
2019	LD-Charger	VSIM	√	√	√	√	o	√	o	
2019	LX-300,Charger,Magnum,Grand voyager	ABS	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	ACC	√	√	√	√	o	○	o	
2019	LX-300,Charger,Magnum,Grand voyager	ADCM	√	√	√	√	o	√	o	
2019	LX-300,Charger,Magnum,Grand voyager	AFLS	√	√	√	√	o	√	o	
2019	LX-300,Charger,Magnum,Grand voyager	AMP	√	√	√	√	o	○	√	
2019	LX-300,Charger,Magnum,Grand voyager	BCM	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	DOORS	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	DTCM	√	√	√	√	o	√	o	
2019	LX-300,Charger,Magnum,Grand voyager	ECM	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	EPS	√	√	√	√	o	○	√	
2019	LX-300,Charger,Magnum,Grand voyager	ESL	√	√	√	√	o	○	o	
2019	LX-300,Charger,Magnum,Grand voyager	ESM	√	√	√	√	o	√	o	
2019	LX-300,Charger,Magnum,Grand voyager	FFCM	√	√	√	√	o	○	o	
2019	LX-300,Charger,Magnum,Grand voyager	HSM	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	HVAC	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	ICS	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	IPC	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	ITM	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	LBSS	√	√	√	√	o	○	o	
2019	LX-300,Charger,Magnum,Grand voyager	MSM	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	ORC	√	√	√	√	o	○	√	
2019	LX-300,Charger,Magnum,Grand voyager	PTS	√	√	√	√	o	※	√	
2019	LX-300,Charger,Magnum,Grand voyager	RADIO	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	RBSS	√	√	√	√	o	○	o	
2019	LX-300,Charger,Magnum,Grand voyager	RFH	√	√	√	√	o	√	√	
2019	LX-300,Charger,Magnum,Grand voyager	SCCM	√	√	√	√	o	○	√	
2019	LX-300,Charger,Magnum,Grand voyager	TCM	√	√	√	√	※	○	√	
2019	LX-300,Charger,Magnum,Grand voyager	TPM	√	√	√	√	o	○	√	
2019	M4-COMPASS (CHINA)	ABS	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	ACC	√	√	√	√	o	○	√	
2019	M4-COMPASS (CHINA)	AMP	√	√	√	√	o	√	o	
2019	M4-COMPASS (CHINA)	BCM	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	CSWM	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	DCU	○	√	√	○	o	○	o	
2019	M4-COMPASS (CHINA)	DTCM	√	√	√	√	o	○	o	
2019	M4-COMPASS (CHINA)	DTV	√	√	√	√	o	√	o	
2019	M4-COMPASS (CHINA)	ECM	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	EPS	√	√	√	√	o	○	√	
2019	M4-COMPASS (CHINA)	ESL	√	√	√	√	o	○	o	
2019	M4-COMPASS (CHINA)	ESM	√	√	√	√	o	○	√	
2019	M4-COMPASS (CHINA)	ETM	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	FFCM	√	√	√	√	o	○	√	
2019	M4-COMPASS (CHINA)	HVAC	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	ICS	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	IPC	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	LBSS	√	√	√	√	o	√	o	

2019	M4-COMPASS (CHINA)	MSM	√	√	√	√	o	√	o	
2019	M4-COMPASS (CHINA)	OCM	√	√	√	√	o	o	√	
2019	M4-COMPASS (CHINA)	ORC	√	√	√	√	o	o	√	
2019	M4-COMPASS (CHINA)	PAM	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	PLGM	√	√	√	√	o	√	※	
2019	M4-COMPASS (CHINA)	RBSS	√	√	√	√	o	√	o	
2019	M4-COMPASS (CHINA)	RFH	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	RRM	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	TBM	√	√	√	√	o	√	√	
2019	M4-COMPASS (CHINA)	TCM	√	√	√	√	o	※	※	
2019	M4-COMPASS (CHINA)	TTM	√	√	√	√	o	√	※	
2019	MP-COMPASS	ABS	√	√	√	√	o	√	√	
2019	MP-COMPASS	ACC	√	√	√	√	o	o	√	
2019	MP-COMPASS	AMP	√	√	√	√	o	√	o	
2019	MP-COMPASS	BCM	√	√	√	√	o	√	√	
2019	MP-COMPASS	CSWM	√	√	√	√	o	√	√	
2019	MP-COMPASS	DTCM	√	√	√	√	o	o	o	
2019	MP-COMPASS	DTV	√	√	√	√	o	√	o	
2019	MP-COMPASS	ECM	√	√	√	√	※	√	※	
2019	MP-COMPASS	EPS	√	√	√	√	o	o	√	
2019	MP-COMPASS	ESL	√	√	√	√	o	o	o	
2019	MP-COMPASS	ESM	√	√	√	√	o	o	√	
2019	MP-COMPASS	ETM	√	√	√	√	o	√	√	
2019	MP-COMPASS	FFCM	√	√	√	√	o	o	√	
2019	MP-COMPASS	HVAC	√	√	√	√	o	√	√	
2019	MP-COMPASS	ICS	√	√	√	√	o	√	√	
2019	MP-COMPASS	IPC	√	√	√	√	o	√	√	
2019	MP-COMPASS	LBSS	√	√	√	√	o	√	o	
2019	MP-COMPASS	MSM	√	√	√	√	o	√	o	
2019	MP-COMPASS	OCM	√	√	√	√	o	o	√	
2019	MP-COMPASS	ORC	√	√	√	√	o	o	√	
2019	MP-COMPASS	PAM	√	√	√	√	o	√	√	
2019	MP-COMPASS	PLGM	√	√	√	√	o	※	※	
2019	MP-COMPASS	RBSS	√	√	√	√	o	√	o	
2019	MP-COMPASS	RFH	√	√	√	√	o	√	√	
2019	MP-COMPASS	RRM	√	√	√	√	o	√	√	
2019	MP-COMPASS	TBM	√	√	√	√	o	√	√	
2019	MP-COMPASS	TCM	√	√	√	√	※	※	※	
2019	MP-COMPASS	TTM	√	√	√	√	o	√	※	
2019	RT-Caravan,Voyater,Town & country	ABS	√	√	√	√	o	√	√	
2019	RT-Caravan,Voyater,Town & country	AMP	√	√	√	√	o	o	√	
2019	RT-Caravan,Voyater,Town & country	CGW	√	√	√	√	o	√	√	
2019	RT-Caravan,Voyater,Town & country	ECM	√	√	√	√	o	√	√	
2019	RT-Caravan,Voyater,Town & country	EPPM	√	√	√	√	o	o	√	
2019	RT-Caravan,Voyater,Town & country	HFM	√	√	√	√	o	√	o	
2019	RT-Caravan,Voyater,Town & country	HSM	√	√	√	√	o	√	√	
2019	RT-Caravan,Voyater,Town & country	HVAC	√	√	√	√	o	√	※	
2019	RT-Caravan,Voyater,Town & country	ITM	√	√	√	√	o	√	√	
2019	RT-Caravan,Voyater,Town & country	MIC/CCN	√	√	√	√	o	√	√	
2019	RT-Caravan,Voyater,Town & country	MSM	√	√	√	√	o	√	√	
2019	RT-Caravan,Voyater,Town & country	ORC	√	√	√	√	o	o	√	
2019	RT-Caravan,Voyater,Town & country	PTS	√	√	√	√	o	√	√	
2019	RT-Caravan,Voyater,Town & country	RADIO	√	√	√	√	o	※	※	
2019	RT-Caravan,Voyater,Town & country	SAS	√	√	√	√	o	o	o	
2019	RT-Caravan,Voyater,Town & country	TCM	√	√	√	√	o	√	√	
2019	RT-Caravan,Voyater,Town & country	TPM	√	√	√	√	o	o	√	
2019	RT-Caravan,Voyater,Town & country	VES3	√	√	√	√	o	√	√	
2019	RT-Caravan,Voyater,Town & country	WCM/TPMS	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	ABS	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	ABSD	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	ACC	√	√	√	√	o	o	o	
2019	RU-CHRYSLER PACIFICA	AHCP	√	√	√	o	o	o	o	
2019	RU-CHRYSLER PACIFICA	AHLM	√	√	√	√	o	√	o	
2019	RU-CHRYSLER PACIFICA	AMP	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	ANC	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	APM	√	√	√	√	o	o	o	
2019	RU-CHRYSLER PACIFICA	BCM	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	BPCM	√	√	√	√	o	o	o	
2019	RU-CHRYSLER PACIFICA	CVPM	√	√	√	√	o	o	o	
2019	RU-CHRYSLER PACIFICA	DOORS	√	√	√	√	o	※	※	
2019	RU-CHRYSLER PACIFICA	DSM	√	√	√	√	o	o	o	
2019	RU-CHRYSLER PACIFICA	EAC	√	o	o	√	o	o	o	
2019	RU-CHRYSLER PACIFICA	EAM	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	EBBM	√	√	√	√	o	o	o	
2019	RU-CHRYSLER PACIFICA	ECM	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	EDM	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	EPS	√	√	√	√	o	o	√	

2019	RU-CHRYSLER PACIFICA	ESL	√	√	√	√	o	○	o	
2019	RU-CHRYSLER PACIFICA	ESM	√	√	√	√	o	√	o	
2019	RU-CHRYSLER PACIFICA	FFCM	√	√	√	√	o	○	√	
2019	RU-CHRYSLER PACIFICA	FSM	√	√	√	√	o	√	o	
2019	RU-CHRYSLER PACIFICA	HCP	√	√	√	√	o	√	o	
2019	RU-CHRYSLER PACIFICA	HSM	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	HVAC	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	HVACR	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	ICS	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	IPC	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	LBSS	√	√	√	√	o	○	o	
2019	RU-CHRYSLER PACIFICA	MSM	√	√	√	√	o	○	√	
2019	RU-CHRYSLER PACIFICA	OBCM	√	√	√	√	o	○	o	
2019	RU-CHRYSLER PACIFICA	OCM	√	√	√	√	o	○	o	
2019	RU-CHRYSLER PACIFICA	ORC	√	√	√	√	o	○	√	
2019	RU-CHRYSLER PACIFICA	PLGM	√	√	√	√	o	√	o	
2019	RU-CHRYSLER PACIFICA	PTS	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	RADIO	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	RBSS	√	√	√	o	o	o	o	
2019	RU-CHRYSLER PACIFICA	RCCC	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	RFH	√	√	√	√	o	√	√	
2019	RU-CHRYSLER PACIFICA	SCCM	√	√	√	√	o	○	√	
2019	RU-CHRYSLER PACIFICA	TCM	√	√	√	√	√	○	√	
2019	RU-CHRYSLER PACIFICA	VRM	√	√	√	√	o	○	o	
2019	VF-ProMaster	ABS	√	√	√	√	o	※	√	
2019	VF-ProMaster	BCM	√	√	√	√	o	√	√	
2019	VF-ProMaster	ECM	√	√	√	√	※	√	√	
2019	VF-ProMaster	EPB	√	√	√	√	o	√	o	
2019	VF-ProMaster	ETM	√	√	√	√	o	※	√	
2019	VF-ProMaster	HVAC	√	√	√	√	o	√	o	
2019	VF-ProMaster	IPC	√	√	√	√	o	√	o	
2019	VF-ProMaster	ORC	√	√	√	√	o	○	√	
2019	VF-ProMaster	PAM	√	√	√	√	o	○	o	
2019	VF-ProMaster	RADIO	√	√	√	√	o	√	√	
2019	VF-ProMaster	TCM	√	√	√	√	o	√	√	
2019	VF-ProMaster	TPM	√	√	√	√	o	√	√	
2019	VM-ProMaster city	ABS	√	√	√	√	o	√	o	
2019	VM-ProMaster city	BCM	√	√	√	√	o	√	√	
2019	VM-ProMaster city	ECM	√	√	√	√	√	√	√	
2019	VM-ProMaster city	ESM	√	√	√	√	o	√	o	
2019	VM-ProMaster city	ETM	√	√	√	√	o	√	√	
2019	VM-ProMaster city	HVAC	√	√	√	√	o	√	※	
2019	VM-ProMaster city	IPC	√	√	√	√	o	√	o	
2019	VM-ProMaster city	ORC	√	√	√	√	o	○	o	
2019	VM-ProMaster city	PAM	√	√	√	√	o	○	o	
2019	VM-ProMaster city	RADIO	√	√	√	√	o	√	√	
2019	VM-ProMaster city	TCM	√	√	√	※	※	○	※	
2019	VM-ProMaster city	TPM	√	√	√	√	o	√	√	
2019	VM-ProMaster city	TTM	√	√	√	√	o	○	√	
2019	WD-Durango	ABS	√	√	√	√	o	√	√	
2019	WD-Durango	ACC	√	√	√	√	o	○	o	
2019	WD-Durango	ADCM	√	√	√	√	o	√	o	
2019	WD-Durango	AHLM	√	√	√	√	o	○	o	
2019	WD-Durango	AMP	√	√	√	√	o	○	√	
2019	WD-Durango	BCM	√	√	√	√	o	√	√	
2019	WD-Durango	CSWM	√	√	√	√	o	○	√	
2019	WD-Durango	DOORS	√	√	√	√	o	√	√	
2019	WD-Durango	DTCM	√	√	√	√	o	√	√	
2019	WD-Durango	ECM	√	√	√	√	o	√	√	
2019	WD-Durango	EDM	√	√	√	√	o	√	√	
2019	WD-Durango	ELSD	√	√	√	√	o	○	o	
2019	WD-Durango	EPS	√	√	√	√	o	○	√	
2019	WD-Durango	ESM	√	√	√	√	o	√	o	
2019	WD-Durango	FFCM	√	√	√	※	o	○	※	
2019	WD-Durango	HSM	√	√	√	√	o	√	√	
2019	WD-Durango	HVAC	√	√	√	√	o	√	o	
2019	WD-Durango	HVACR	√	√	√	√	o	√	√	
2019	WD-Durango	ICS	√	√	√	√	o	√	√	
2019	WD-Durango	IPC	√	√	√	√	o	√	√	
2019	WD-Durango	ITBM	√	√	√	√	o	○	o	
2019	WD-Durango	ITM	√	√	√	√	o	√	√	
2019	WD-Durango	LBSS	√	√	√	o	o	○	o	
2019	WD-Durango	MSM	√	√	√	√	o	√	√	
2019	WD-Durango	ORC	√	√	√	√	o	○	√	
2019	WD-Durango	PLGM	√	√	√	√	o	√	o	
2019	WD-Durango	PTS	√	√	√	√	o	√	√	
2019	WD-Durango	RADIO	√	√	√	√	o	√	√	

2019	WD-Durango	RBSS	√	√	√	○	○	○	○	
2019	WD-Durango	RFH	√	√	√	√	○	√	√	
2019	WD-Durango	SCCM	√	√	√	√	○	○	√	
2019	WD-Durango	TCM	√	√	√	√	○	○	√	
2019	WD-Durango	VES2	√	√	√	√	○	√	○	
2019	WD-Durango	VES3	√	√	√	√	○	√	○	
2019	WK-Grand cherokee	ABS	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	ACC	√	√	√	√	○	○	○	
2019	WK-Grand cherokee	ADCM	√	√	√	√	○	√	○	
2019	WK-Grand cherokee	AFLS	√	√	√	√	○	○	√	
2019	WK-Grand cherokee	AMP	√	√	√	√	○	※	※	
2019	WK-Grand cherokee	ANC	√	√	√	√	○	○	√	
2019	WK-Grand cherokee	ASCM	√	√	√	√	○	○	√	
2019	WK-Grand cherokee	BCM	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	CSWM	√	√	√	√	○	○	√	
2019	WK-Grand cherokee	DOORS	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	DSM	√	√	√	√	○	○	○	
2019	WK-Grand cherokee	DTCM	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	DTV	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	EAM	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	ECM	√	√	√	√	※	√	√	
2019	WK-Grand cherokee	EDM	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	ELSD	√	√	√	√	○	○	○	
2019	WK-Grand cherokee	EPS	√	√	√	√	○	○	√	
2019	WK-Grand cherokee	ESM	√	√	√	√	○	√	○	
2019	WK-Grand cherokee	FFCM	√	√	√	※	○	○	※	
2019	WK-Grand cherokee	HSM	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	HVAC	√	√	√	√	○	√	○	
2019	WK-Grand cherokee	ICS	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	IPC	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	ITM	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	LBSS	√	√	√	○	○	○	○	
2019	WK-Grand cherokee	MSM	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	ORC	√	√	√	√	○	○	√	
2019	WK-Grand cherokee	PLGM	√	√	√	√	○	√	○	
2019	WK-Grand cherokee	PTS	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	RADIO	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	RBSS	√	√	√	○	○	○	○	
2019	WK-Grand cherokee	RFH	√	√	√	√	○	√	√	
2019	WK-Grand cherokee	SCCM	√	√	√	√	○	○	√	
2019	WK-Grand cherokee	TCM	√	√	√	√	√	○	√	
2019	WK-Grand cherokee	TPM	√	√	√	√	○	○	√	
2019	WK-Grand cherokee	VES2	√	√	√	√	○	√	○	
2019	WK-Grand cherokee	VES3	√	√	√	√	○	√	○	
2020	JT-Gladiator	ABS	√	√	√	√	○	√	√	
2020	JT-Gladiator	AMP	√	√	√	√	○	√	√	
2020	JT-Gladiator	BCM	√	√	√	√	○	√	√	
2020	JT-Gladiator	CSWM	√	√	√	√	○	√	○	
2020	JT-Gladiator	DPDM	√	√	√	√	○	○	○	
2020	JT-Gladiator	DTCM	√	√	√	√	○	√	√	
2020	JT-Gladiator	ECM	√	√	√	√	○	√	√	
2020	JT-Gladiator	EPS	√	√	√	√	○	○	○	
2020	JT-Gladiator	ESM	√	√	√	√	○	√	○	
2020	JT-Gladiator	HVAC	√	√	√	√	○	√	√	
2020	JT-Gladiator	ICS	√	√	√	√	○	√	√	
2020	JT-Gladiator	IPC	√	√	√	√	○	√	√	
2020	JT-Gladiator	LBSS	√	√	√	√	○	√	√	
2020	JT-Gladiator	OCM	√	√	√	√	○	○	○	
2020	JT-Gladiator	ORC	√	√	√	√	○	○	√	
2020	JT-Gladiator	PTS	√	√	√	√	○	√	√	

Special Function

Index	Special Function	Index	Special Function
0001	1st Gear Clutch Test	0640	Liftgate Close Test
0002	1st Gear Clutch Test (62TE)	0641	Liftgate Internal Relay Test
0003	1st Gear Clutch Test (Non-RFE)	0642	Liftgate Latch Cinch Test
0004	1st Gear Clutch Test (RFE)	0643	Liftgate Latch Release Test
0005	1st Gear Clutch Test - 62TE	0644	Liftgate Open Test
0006	1st Gear Clutch Test 62TE	0645	Light Rain Sensor Calibration
0007	1st Gear Clutch Test 68RFE	0646	Light Rain Sensor Re-Adaption
0008	1st Gear Clutch Test FWD	0647	Load Coding
0009	1st Gear Clutch Test RFE	0648	Locate Learned Keys
0010	1st Gear Clutch Test:62TE	0649	Lock Config Via Blinker System
0011	1st Gear Clutch Test:FWD	0650	Lock Door When Driving
0012	1st Gear Clutch Test:Non RFE	0651	Lock Ignition FOBIKs
0013	1st Gear Clutch Test:NonRFE	0652	Lock driving during CL inter-sw
0014	1st Gear Clutch Test:RFE	0653	Longitudinal G-Sensor Calibration
0015	1st Gear Clutch Test:RWD	0654	Longitudinal G-Sensor Calibration Test
0016	2 Prime Gear Clutch Test	0655	Longitudinal and Lateral sensor calibration
0017	2 Prime Gear Clutch Test:RFE	0656	Longitudinal and Lateral sensor decalibration
0018	2nd Gear Clutch Test	0657	MODULE SERVICE REPLACEMENT
0019	2nd Gear Clutch Test (62TE)	0658	MSMD Self Test
0020	2nd Gear Clutch Test (Non-RFE)	0659	Manual DPF Regeneration
0021	2nd Gear Clutch Test (RFE)	0660	Manual Diesel Particulate Filter Regeneration

0022	2nd Gear Clutch Test - 62TE	0661	Manual Top Movement
0023	2nd Gear Clutch Test 62TE	0662	Mass Air Flow Sensor Initialization
0024	2nd Gear Clutch Test 68RFE	0663	Mass Airflow Sensor Replace
0025	2nd Gear Clutch Test FWD	0664	Max Vehicle Speed Adjustment
0026	2nd Gear Clutch Test RFE	0665	Measure System Air Mass
0027	2nd Gear Clutch Test:62TE	0666	Measurement Unit
0028	2nd Gear Clutch Test:FWD	0667	Midtronics Warranty Code Validation
0029	2nd Gear Clutch Test:Non RFE	0668	Mirror Position Test
0030	2nd Gear Clutch Test:NonRFE	0669	Misfire Monitor Test
0031	2nd Gear Clutch Test:RFE	0670	Mobile DeSoot - Minimum Required Soot Load
0032	2nd Gear Clutch Test:RWD	0671	Mobile DeSoot - No Minimum Required Soot Load
0033	2nd Prime Clutch Test RFE	0672	Mobile DeSoot - No Minimum Required Soot Load_Var03
0034	3rd Gear Clutch Test	0673	Mobile DeSoot - No Minimum Required Soot Load_Var05
0035	3rd Gear Clutch Test (62TE)	0674	Modify lateral anti-tilt sensor
0036	3rd Gear Clutch Test (Non-RFE)	0675	Modify longitudinal anti-tilt sensor
0037	3rd Gear Clutch Test (RFE)	0676	Modify volumetric sensors sensibility
0038	3rd Gear Clutch Test - 62TE	0677	Modulator Solenoid Test
0039	3rd Gear Clutch Test 62TE	0678	Module Reset
0040	3rd Gear Clutch Test 68RFE	0679	Module Service Replacement
0041	3rd Gear Clutch Test FWD	0680	Most Recent Cool Down Test Results
0042	3rd Gear Clutch Test RFE	0681	Motor Resolver Offset Learn
0043	3rd Gear Clutch Test:62TE	0682	Motorised throttle replacement
0044	3rd Gear Clutch Test:68RFE	0683	NAV in Motion Menu
0045	3rd Gear Clutch Test:FWD	0684	ND:Enable Cruise Control

0046	3rd Gear Clutch Test:Non RFE	0685	ND:Enable DRL
0047	3rd Gear Clutch Test:NonRFE	0686	ND:Program Tire Size
0048	3rd Gear Clutch Test:RFE	0687	NOx Catalyst (New) Initialization
0049	3rd Gear Clutch Test:RWD	0688	NOx Catalyst (Used) Learning
0050	4th Gear Clutch Test (62TE)	0689	NOx Catalyst(New) Initialization
0051	4th Gear Clutch Test - 62TE	0690	NOx Catalyst(Used) Learning
0052	4th Gear Clutch Test 62TE	0691	NOx replacement
0053	4th Gear Clutch Test:62TE	0692	NVLD Forced Monitor Test
0054	75 MPH Warning	0693	Navigation Voice Test
0055	ABS Bleed Brakes	0694	Neutral Gate Test
0056	ABS Initialization	0695	Neutral Gate Test (62TE)
0057	ABS Static Test	0696	Neutral Gate Test (Non-RFE)
0058	ABS System Calibration	0697	Neutral Gate Test (RFE)
0059	ABS Valve Calibration	0698	Neutral Gate Test:NOT_RFE
0060	AC Cool Down Test	0699	Neutral Gate Test:RFE
0061	ACC Aim Mode - Auto Alignment	0700	Neutral Position Self-Learning
0062	ACC Cutout Reasons Clear	0701	Neutral gear position learning
0063	ACC Exit In-Plant Mode	0702	Neutral signal learning
0064	ACC Post Service Flash Process	0703	New Actuators
0065	AEHM Actuate Heater Booster	0704	New DPF Initialize
0066	AFLS Calibration	0705	New Engine Installed
0067	AGW Initialization	0706	Non-Volatile Memory Reset
0068	AHBM Self Test	0707	Non-Volatile Memory Reset (Clear T-Case Adaptives)
0069	AMP Channel Output Channel Test	0708	O2 Heater System Test

0070	AMP Channel Output Channel Test:6 Channel	0709	02 Heater System Test:1bank
0071	AMP Channel Output Channel Test:7 Channel	0710	02 Heater System Test:2bank
0072	AMP Channel Output Channel Test:8 Channel	0711	02 Sensor Monitor Test
0073	AMP Channel Output Channel Test:No Channel 7	0712	02 Sensor Replace
0074	AMP Input Test	0713	02 System Heater Test
0075	AMP Microphone Output Short Test	0714	OCM Rezero Procedure
0076	AMP Microphone Tone Test	0715	OCM System Verification Test
0077	AMP Multiple Mute Channel	0716	ORC Automatic Variant Coding (Restore ECU Config)
0078	AMP Mute Channel:6 Channel	0717	ORC Initialize ECU
0079	AMP Mute Channel:7 Channel	0718	Odd and/or even gear clutch replacement
0080	AMP Mute Channel:8 Channel	0719	Odd gear clutch (K1) control solenoid valve command
0081	AMP Mute Channel:No Channel 7	0720	Odd no. gear clutch position sensor replacement
0082	AMP Output Short Test	0721	Oil Change
0083	AMP Software Test	0722	Oil Change Monitor Type
0084	AMP Tone Test	0723	Oil Change Reset
0085	AMP Tone Test with volume control	0724	Oil Life Backup and Restore
0086	AMP Tone Test without volume control	0725	Oil change
0087	ANC Input Test	0726	Open Failure Info
0088	ANC Microphone Output Short Test	0727	Open Mode Info
0089	ANC Microphone Tone Test	0728	Optical Horn Chirp
0090	ANC Output Short Test	0729	Original VIN Lock
0091	ANC Tone Test	0730	Original VIN Read
0092	ATC Data Display	0731	Output Short Test
0093	AUX Electric Fan	0732	Overdrive Switch Test

0094	Accelerator Pedal Learn	0733	Overdrive Switch Test (Non-RFE)
0095	Accessory Delay Time	0734	Overdrive Switch Test (RFE)
0096	Accessory Time Delay	0735	Overdrive Switch Test:RFE
0097	Acoustic alarm notification	0736	Oxidation Catalyst Initialization
0098	Activate Driver and Passenger Head Restraint	0737	P2262 Fault Diagnosis Test (Before Repair)
0099	Activate TPM High Gain Mode	0738	PAM Self Test
0100	Activate/Deactivate Cruise Control	0739	PCI Amplifier Test
0101	Active Grill Shutter	0740	PCM Configuration
0102	Active Grille Shutter Replaced	0741	PCM Replaced
0103	Active Grille Shutter Test	0742	PCM Replaced - Diesel
0104	Active alignment procedure: radar calibration.	0743	PCM Replaced - Gas
0105	Actuate All LEDs	0744	PCM Replaced 1.6L Only
0106	Actuate Drive Clutch Engage	0745	PCM Replaced Cummins
0107	Actuate Engine ASD	0746	PCM Replaced ENG_SCI - Gas
0108	Actuate Engine Battery Feed	0747	PCM Replaced SRT-10 Only
0109	Actuate Front TracRite Locker	0748	PEM Replace
0110	Actuate Memory Seat and Pedals	0749	PROXI alignment procedure
0111	Actuate Rear TracRite Locker	0750	PSM Automatic Variant Coding (Restore ECU Config)
0112	Actuate Seat Recall	0751	PSM Reset ECU
0113	Actuate SmartBar Motor	0752	PT Restore Customer Preference
0114	Actuate SmartBar Off-Road LED	0753	PT WCM Replaced SCI
0115	Actuate SmartBar On-Road LED	0754	PTCM Reset ECU
0116	Actuate TracRite Unlock FR/RR LED	0755	PTO RPM Adjustment
0117	Actuate TracRite Unlock LED	0756	PTO Single Speed RPM

0118	Actuate TracRite Unlock RR LED	0757	PTS Calibration
0119	Actuate Transmission Relay	0758	PTU Replacement
0120	Actuator Calibration	0759	Panic Alarm
0121	Actuator Calibration Test	0760	Particulate Filter Regeneration
0122	Actuator Calibration Test DR	0761	Particulate filter with integrated pre-cat replacement
0123	Actuator Circuit Test	0762	Passenger Passive Entry Handle Delete
0124	Actuator DTC Detection	0763	Passenger Seatbelt Minder Chime
0125	Acutate Fuel Pump	0764	Permanently Block Keyfob
0126	Adaptation Reset	0765	Personalize with Electronic Ignition Switch
0127	Adaptive Numerator Learn	0766	Phase Front reset
0128	Adaptive parameters reset	0767	Phonic wheel replacement
0129	Add Navigation Radio	0768	Police VTA
0130	Adjust Idle Speed in Gear	0769	Power Down
0131	Adjust Idle Speed in P/N	0770	Power Electronics Coolant Fill
0132	Aim Test	0771	Power Roof Module Anti-Theft Alarm System Horn
0133	Air Flow Meter Replace	0772	Power Roof Module Normalize Sunroof
0134	Air Spring Circuit Test	0773	Power Roof Module Rain Light Sensor Learn
0135	Air flow meter sensor replacement	0774	Power Sliding Door Operation
0136	Air-Conditioning Self Learning	0775	Power on Reset
0137	Air-Conditioning Self-Learning	0776	Power on and Disable User Inputs
0138	Aisin Trans Data	0777	Pressure Sensor Calibration
0139	Align ACC Sensor	0778	Program Dealer Contact Info
0140	All LED and Sound	0779	Program Dealer Contact Information
0141	Alternator 2 Field Test	0780	Program EIS_CGW VIN

0142	Alternator(s) Test	0781	Program Ignition
0143	Antenna Loop Test	0782	Program Ignition FOBIKs
0144	Anti-Theft Override Test	0783	Program Ignition FOBIKs Baseline System
0145	Anti-Tow Protection	0784	Program Ignition FOBIKs Keyless Go System
0146	Anti_Theft Information	0785	Program Ignition Keys
0147	Atmosphere Valve Actuator Test	0786	Program Ignition Keys OMRON SKIM only
0148	Audio Measure AC+DC	0787	Program Ignition Keys SKIM only
0149	Audio System Test	0788	Program Ignition Keys or Key FOBs
0150	Auto Door Lock	0789	Program Ignition Keys or Key FOBs:RKEONLY
0151	Auto Door Re-Lock	0790	Program Ignition Keys or Key FOBs:SKIM
0152	Auto Door Unlock	0791	Program Key FOBs
0153	Auto High Beam Aim Test	0792	Program Keys
0154	Auto Subsequent Locking Active	0793	Program Left Front Tire Sensor ID
0155	Auto Wipers	0794	Program Left Rear Tire Sensor ID
0156	Automatic Loudness	0795	Program Network Configuration
0157	Automatic Variant Coding (Restore ECU Config)	0796	Program New Ignition Key FOB
0158	Aux Heater Coolant Pump Temp Test	0797	Program RKE
0159	Auxiliary Fan	0798	Program RKE Only Keys
0160	Auxiliary Fuel Filter Enable	0799	Program Right Front Tire Sensor ID
0161	BCM Immobilizer Replace	0800	Program Right Rear Tire Sensor ID
0162	BCM Replaced	0801	Program Spare Tire Sensor ID
0163	BCM replacement	0802	Program Tire Sensor ID w/TPM Tool
0164	BCM transfer secret key to ESL ECM	0803	Program Tire Sensor ID with TPM Tool
0165	BPCM Battery Data Report	0804	Program Tire Sensor Identifications

0166	Battery Disconnect	0805	Program Tire Size
0167	Battery Pack Fan Test	0806	Program Tire Size for EATX
0168	Bleed Brakes	0807	Program Tire Size for EGS 52
0169	Bleed Brakes 2WD	0808	Program Tire Size/Pinion Factor
0170	Bleed Brakes 4WD	0809	Program Tire Size:CS
0171	Bleed Brakes ABS only	0810	Program Tire Size:DR
0172	Bleed Brakes Verification Test	0811	Program Tire Size:JC
0173	Bleed Brakes:LX	0812	Program Tire Size:KA
0174	Bleed Brakes:WK	0813	Program Tire Size:KK
0175	Bleed DHS	0814	Program Tire Size:LX
0176	Bleed Hydraulic Circuit	0815	Program Tire Size:ND
0177	Blinker System Activation	0816	Program Tire Size:PM or MK
0178	Blinking Lights Configuration	0817	Program Tire Size:PM or MK No TCM
0179	Block some areas of coding	0818	Program Tire Size:PT
0180	Blower	0819	Program Tire Size:PT No TCM
0181	Brake Pedal Calibration	0820	Program Variant Code
0182	Brake Sensor Zero Calibration	0821	Program Variant Coding
0183	Brake Switch Learn	0822	Program Variant Coding.
0184	CCN Display Dimmer Test	0823	Proxi Configuration
0185	CCN Gauge Test	0824	Proxi Configuration Alignment
0186	CCN LCD Display Test	0825	Pump Relay Replacement
0187	CCN Self Test	0826	Purge Vapor System Test
0188	CNG/Gasoline Forced Fuel Type	0827	Purge Vapors System Test
0189	CTM PROXI Configuration	0828	Pushbutton Test

0190	CVT Initialization	0829	Quick Learn
0191	CYLINDER PERFORMANCE TEST - Automatic Transmission	0830	Quick Learn:NOT_RFE
0192	CYLINDER PERFORMANCE TEST - Manual Transmission	0831	Quick Learn:Non RFE
0193	Calibrate AHLM	0832	Quick Learn:Non-RFE
0194	Calibrate Full Recline	833	Quick Learn:RFE
0195	Calibrate G-Sensor	0834	QuickLearn
0196	Calibrate HIDT Module	0835	QuickLearn (Non-RFE)
0197	Calibrate Lifetime Energy Value	0836	Quicklearn (62TE - PCM Var16)
0198	Calibrate Liftgate	0837	Quicklearn (62TE - PCM Var17)
0199	Calibrate Liftgate Full Close Position	0838	Quicklearn (62TE)
0200	Calibrate Liftgate Full Open Position	0839	Quicklearn (PCM RFE Transmission)
0201	Calibrate Stow	0840	Quicklearn (RFE)
0202	Cam Crank Relearn	0841	Quicklearn - 62TE
0203	Camshaft Reference Adaptation	0842	Quicklearn RFE
0204	Catalyst Efficiency Test	0843	RADIO PROXI Configuration
0205	Catalyst Replaced	0844	RBC Sensor Calibration
0206	Change Audio EQ Curve	0845	RDU Replacement
0207	Change Country Code	0846	RESET OIL CHANGE
0208	Change Cruise Control Mode	0847	RF Signal
0209	Change Language Preference	0848	RF-HUB Replace
0210	Change Measurement Units	0849	RFH immobilizer antenna test
0211	Change Status	0850	RFH locate learned keys
0212	Check APM VIN	0851	RFH replacement
0213	Check EVCU VIN	0852	RFH transfer secret key to BCM

0214	Check HCP VIN	0853	RFH_TPM Update FF_FR Axle Nom Tire Press Val
0215	Check PCM Odometer	0854	RFH_TPM program left front tire sensorId
0216	Check PCM VIN	0855	RFH_TPM program left rear tire sensorId
0217	Check Sensor Adaptives	0856	RFH_TPM program right front tire sensorId
0218	Check TCM VIN	0857	RFH_TPM program right rear tire sensorId
0219	Check Vin	0858	RFH_TPM sensor rolls tests
0220	Check/Write VIN	0859	RKE Unlock Sequence
0221	Circulating Pump	0860	ROW Map Configuration
0222	Clear All Learned Seat Parameters	0861	Radio Anti Theft Override Test
0223	Clear Battery Disconnect	0862	Radio Anti-Theft Override Test
0224	Clear DEF Pump Learned Offset Values	0863	Radio Clock Display
0225	Clear Engine Auto Restart Crank Counter	0864	Radio Dealership Mode
0226	Clear Last Successful Remote Start	0865	Radio Display Test
0227	Clear Learned Features	0866	Radio Enable/Disable Front Video
0228	Clear Learned Values	0867	Radio Hard-drive Back-up
0229	Clear Learned Variable Line Pressure (VLP) Counters	0868	Radio Initialization
0230	Clear Learned Variable Line Pressure Counters	0869	Radio Most Bus Connectivity
0231	Clear Misfire TLC	0870	Radio NCV3 Tone Test
0232	Clear Multi-Module VIN Handshake Immobilizer Failure	0871	Radio Tone Test
0233	Clear Remote Start Abort Reasons	0872	Radio Volume Balance Fade Test
0234	Clear Remote Start Inhibit Reasons	0873	Rail Pressure Control Switchover
0235	Clear Self Learning Data	0874	Rail Pressure Initialization
0236	Clear Steering Pull Compensation	0875	Rail pressure sensor replacement
0237	Clear Stored Accumulated Fuel Mass	0876	Rain and Automatic Lights Sensors check

0238	Clear TPM Sensor Audit	0877	Ramp Van Configuration
0239	Clear TPM Sensor Warnings	0878	Range selection electrovalve command (PPVS)
0240	Clear TPM Warnings	0879	Read Current Vehicle Configuration
0241	Clear VLP Counters	0880	Read Digital Encoder Channels
0242	Clear Variable Line Pressure (VLP)	0881	Read Ignition Module (IGNM) Software Information
0243	Clear Variable Line Pressure (VLP) Counters	0882	Read Original Vehicle Configuration
0244	Clock Display	0883	Read PCM Coding
0245	Close Failure Info	0884	Read TCM Coding
0246	Close Mode Info	0885	Read Vin
0247	Closed Couple Replacement	0886	Read second level micro safety reset event
0248	Cluster Auto Replacement	0887	Readiness Test
0249	Cluster Calibration Points	0888	Rear AC and Rear Wiper Wash Data Display
0250	Clutch Pedal Learn	0889	Rear Blower State
0251	Clutch Replacement	0890	Rear Differential Bleed
0252	Clutch group and/or clutch potentiometer replacement	0891	Rear Stop and Turn Lamp System Test
0253	Collect Immobilizer Data	0892	Rear View Camera Grid Lines
0254	Combined Rear Lighting	0893	Rear Window Movement
0255	Compass Calibration	0894	Record Curb Sensor Values
0256	Component Air Mass/Pressure/Ride Height Readings	0895	Regen Brake Control
0257	Compression Test	0896	Regulation of Low Voltage Control
0258	Compression Test (Engine NOT Running)	0897	Relearn TIPM VIN
0259	Compressor Circuit Test	0898	Remote Start Antenna Test
0260	Config Roof Pump Runtime Value	0899	Remote Start Override
0261	Config Roof Timeout Values	0900	Remote Start Temporary Disable

0262	Config Roof Tolerance Times	0901	Replace BPCM
0263	Configure Cluster	0902	Replace HCP
0264	Configure Door Locks	0903	Replace SCM
0265	Configure ITM	0904	Replace Steering Column Lock
0266	Configure License Plate Size	0905	Replace TCM
0267	Configure PTS	0906	Replacement instrument panel cluster
0268	Configure Suspension Type	0907	Replacement of EGR valve
0269	Configure for OCS	0908	Request Anti-Slugging For Air Condition Compressor
0270	Configure for Radio Clock	0909	Reset Accelerator Pedal Adaptives
0271	Configure for Side Airbags	0910	Reset Active Discharge Fault
0272	Constrain Battery Power Limits	0911	Reset Adaptive Memory
0273	Continuous Tone Test	0912	Reset Adaptive Values
0274	Control unit Replacement / Reprogramming	0913	Reset Adaptives
0275	Control unit replacement	0914	Reset Aftertreatment Trip Information
0276	Control unit reprogramming	0915	Reset All Learned Info
0277	Cool Down Test	0916	Reset Amplifier
0278	Coolant Three Way Valve Replaced	0917	Reset Cruise Control
0279	Coolant Three Way Valve Test	0918	Reset Customer Preferences
0280	Cooled EGR H-Bridge Valve System Test	0919	Reset ECU
0281	Cruise Control Data	0920	Reset Enhanced Automatic Oil Change Indicator
0282	Current VIN Read	0921	Reset Error Free Operation Time to 40 Hours
0283	Customer Programmable- Clock	0922	Reset High Voltage Impact Event
0284	Customer Programmable- Daytime Running Lamps	0923	Reset Inhibiting Timer
0285	Customer Programmable- Language	0924	Reset Learned Adaptives

0286	Customer Programmable- Speedometer/Odometer Units	0925	Reset Learned Features
0287	Customer Programmable- Temperature	0926	Reset Mass Airflow Values
0288	Cycle Stop Lamp Relay	0927	Reset Memory
0289	Cylinder 1 injector replacement	0928	Reset Module
0290	Cylinder 2 injector replacement	0929	Reset NOx Adsorber Counts
0291	Cylinder 3 injector replacement	0930	Reset ORC
0292	Cylinder 4 injector replacement	0931	Reset Odometer
0293	Cylinder Balance Test	0932	Reset Oil Change Indicator
0294	Cylinder Fuel Quantity Correction Test	0933	Reset Oil Change Light Service Information
0295	Cylinder Performance Test	0934	Reset PTU Shift Counter
0296	DAYS SINCE LAST OIL CHANGE	0935	Reset Parameters
0297	DEF (Reductant) Doser Prime Override Test	0936	Reset Pressure limiting Valve Accumulators
0298	DEF (Reductant) Doser Pump Override Test	0937	Reset RDM Shift Counter
0299	DEF (Reductant) Pressure Line Heater Test	0938	Reset Regen Filter Timers
0300	DEF (Reductant) Pressure Line Heater Tester	0939	Reset Regenerative Filter Timers
0301	DEF (Reductant) Return Line Heater Test	0940	Reset SKREEM
0302	DEF (Reductant) Suction Line Heater Test	0941	Reset Sensor Adaptives
0303	DEF (Reductant) Tank Heater Test	0942	Reset Service Information
0304	DEF Dosing Injection Quantity	0943	Reset To Default Parameters
0305	DEF Reductant Doser Prime Override Test	0944	Reset VCM Adaptives
0306	DEF Reductant Doser Pump Override Test	0945	Reset WIN Configuration
0307	DHS Verification Test	0946	Reset Weld Check Fault
0308	DIST.SINCE LAST OIL CHANGE	0947	Reset Wrench Light Service Information
0309	DPF Pressure Sensor Reset	0948	Reset Zero Fuel Quantity Calibration

0310	DPF Regeneration	0949	Reset adaptative parameter
0311	DPF Replacement	0950	Reset learn flag wheel tooth
0312	DPF Reset Option	0951	Reset of Data group
0313	DR WCM Replaced SCI	0952	Reset of Lambda values
0314	DVD Player/Video Settings	0953	Reset of 02 Values
0315	Daytime Running Lights	0954	Reset of SCR Long Term Adaptation Factor
0316	Deactivate/Activate Lamp Failure Recognition	0955	Reset phases front
0317	Deactivation of the Power Limitation function	0956	Reset vehicle configuration
0318	Dealer Contact Info Reset	0957	ResetMixtureAdaptives
0319	Denormalize Window	0958	Resetting distance travelled with Water in diesel warning lamp ON
0320	Diesel Particulate Filter (New) Initialization	0959	Resetting distance travelled with water temperature warning lamp ON
0321	Diesel Particulate Filter (Used) Learning	0960	Resolver Offset Learn Trigger Test
0322	Diesel Particulate Filter Replacement	0961	Restore BCM PROXI Configuration
0323	Differential Pressure Sensor Replacement	0962	Restore Vehicle Configuration
0324	Direct Gear Clutch Test 68RFE	0963	Restore Vehicle Configuration SRT10 and 16L
0325	Direct Gear Clutch Test:68RFE	0964	Restore Vehicle Configuration With Resets for FCM
0326	Disable Auto Relock	0965	Restore Vehicle Configuration With Resets for FCM 2004 and 2005
0327	Disable In Plant Mode	0966	Restore Vehicle Configuration Without Resets for FCM
0328	Disable KEYs/FOBIKs	0967	Restore Vehicle Configuration Without Resets for FCM 2004 and 2005
0329	Disable Key-Alike	0968	Restore Vehicle Configuration Without Resets for TIPM
0330	Disable Level Control	0969	Restore Vehicle Configuration- CS only
0331	Disable Radio Clock Display	0970	Reverse Gear Clutch Test
0332	Disable Seatbelt Minder Chime	0971	Reverse Gear Clutch Test (62TE)
0333	Disable seat belts reminder	0972	Reverse Gear Clutch Test (Non-RFE)

0334	Disable/Enable Seatbelt Minder Chime	0973	Reverse Gear Clutch Test (RFE)
0335	Display Critical ELV/EIS Data	0974	Reverse Gear Clutch Test - 62TE
0336	Display Diesel Particulate Filter Values	0975	Reverse Gear Clutch Test 68RFE
0337	Display LIN Part Numbers and Serial Numbers	0976	Reverse Gear Clutch Test FWD
0338	Door Handle Verification Test	0977	Reverse Gear Clutch Test RFE
0339	Double Door Locks	0978	Reverse Gear Clutch Test:62TE
0340	Downstream O2 Response Monitor	0979	Reverse Gear Clutch Test:FWD
0341	Drive All Motors	0980	Reverse Gear Clutch Test:Non RFE
0342	Drive Test	0981	Reverse Gear Clutch Test:NonRFE
0343	Dry Dual Clutch Transmission Report	0982	Reverse Gear Clutch Test:RFE
0344	Dual Alternator Enable / Disable	0983	Reverse Gear Clutch Test:RWD
0345	Dual Fuel Tank Enable / Disable	0984	Right Front Tire Pressure Signal Transmission Test
0346	EATX TCM Has Been Changed	0985	Right Rear Tire Pressure Signal Transmission Test
0347	ECM Gas Automatic Variant Coding (Restore ECU Config)	0986	Right Rear Window Movment
0348	ECM IGNITION COIL SHUTOFF	0987	Right Rotation Relay
0349	ECM Replacement	0988	RoadSetAdaptives
0350	ECU Auto Replacement	0989	Rolling Door Locks
0351	ECU Manual Replacement	0990	Rollover Detection
0352	ECU Replaced With Value Transfer	0991	Rollover Detection TRW Only
0353	ECU Replaced Without Value Transfer	0992	Rpm sensor and/or timing chain replacement
0354	ECU Replacement With Data Transfer	0993	S1 Solenoid
0355	ECU Replacement With Value Transfer	0994	S2 Solenoid
0356	ECU Replacement Without Value Transfer	0995	S3 Solenoid
0357	EDC16 Report	0996	S4 Solenoid

0358	EGR Coolant Regeneration	0997	SCOPE OF LAST SERVICE
0359	EGR System Test	0998	SCR DEF Dosing Injection Quantity
0360	EGR high pressure valve test	0999	SCR DEF Tank Fluid Level Reset
0361	EGR low pressure valve replacement	1000	SCR Extend Mileage W Active Fault
0362	EGR low pressure valve test	1001	SCR Reset Options
0363	EGR/ECU Self Test	1002	SCR System After ECU Replacement Procedure
0364	ELSD Quicklearn	1003	SCR System Catalyst Reset
0365	ELV Replace	1004	SCR System Dosing Module Replacement
0366	ELV Replaced	1005	SCR System Pressure Line Replacement
0367	ELV Stored Faults Read	1006	SCR System Procedure After ECU Replacement
0368	ENABLE JK HFM	1007	SCR System Tank Pump Replacement
0369	ENGINE VERSION	1008	SCR System Wiring Harness Replacement
0370	EOM Self Test	1009	SERVICE INTERVAL(DAYS)
0371	EPS Learn	1010	SERVICE INTERVAL(MILES)
0372	ESCL Replaced	1011	SET LOW ENGINE OIL WARNING
0373	ESIM Forced Monitor Test	1012	SRV Test
0374	ESL Replaced	1013	SUNR Initialization
0375	ESM Shift Lever Test	1014	Seatbelt Alert Minder
0376	ESP Brake Booster Test	1015	Seatbelt Alert System
0377	ETC System Test	1016	Seatbelt Alert System 2006
0378	ETC Throttle Follower Test	1017	Seatbelt Alert System 2007
0379	EVAP Temp Target Speed	1018	Seatbelt Minder Chime
0380	EVR Enable/Disable	1019	Secondary Air Service Test
0381	Easy Entry/Exit	1020	Selection and/or engagement clutch electrovalve replacement

0382	Easy Entry/Exit Feature	1021	Self Learning Motor Test
0383	Electric Cooling Fan	1022	Self Learning Working Mode
0384	Electric PRNDL Test	1023	Self Test
0385	Electric Park Brake management	1024	Self learning throttle body
0386	Electric Vacuum Pump Test	1025	Self-adaptive parameters reset
0387	Electric pump drive unit command	1026	Self-learnt functions reset
0388	Electrical VGT actuator test	1027	Sensor Connectivity and HMI Test
0389	Electropump drive unit replacement	1028	Sensor Functional Test
0390	Electropump replacement	1029	Sensor Rolls Test
0391	Emergency Unlock	1030	Sensor Versions
0392	Emission-Relevant Component Replacement	1031	Sensor Wiring Test
0393	Emissions Rolls Test Mode	1032	Sensors module replacement
0394	Enable / Disable Dealer Contact Info	1033	Sensors:Bussed Inputs:and Bussed Outputs
0395	Enable / Disable PTO Types	1034	Service Diesel Particulate Filter Regeneration
0396	Enable / Disable Vehicle Feature	1035	Service Interval - Diesel
0397	Enable / Disable Vehicle Features	1036	Service Interval - Gas
0398	Enable / Disable Vehicle Features:cc	1037	Service Module Replacement
0399	Enable / Disable Vehicle Features:pu	1038	Service Procedures
0400	Enable Auto Highbeam	1039	Service Replace
0401	Enable Cruise Control	1040	Service Single Pole Calibration
0402	Enable DRL	1041	Set Axle Type
0403	Enable DRL:LC	1042	Set Engine RPM
0404	Enable DRL:LX	1043	Set High Idle Allowed Speeds
0405	Enable Disable Premium TPM	1044	Set Max Cruise Speed

0406	Enable Disable TPM	1045	Set Max Vehicle Speed
0407	Enable Emissions Rolls Test Mode (FCM)	1046	Set Maximum Vehicle Speed
0408	Enable Emissions Rolls Test Mode (PowerNet)	1047	Set Oil Dilution Mass Value
0409	Enable Emissions Rolls Test Mode (TIPM)	1048	Set Oil Type
0410	Enable FCM/IPM Diagnostics	1049	Set PTCM To Defaults
0411	Enable Front Fog Lamp Dropout	1050	Set PTO Max Vehicle Speed
0412	Enable Front Fog Lamp Output	1051	Set RPM System Test
0413	Enable Heated Mirrors	1052	Set RPM System Test - Automatic Transmission
0414	Enable Jump Assist Mode	1053	Set RPM System Test - Manual Transmission
0415	Enable KEYs/FOBIKs	1054	Set RPM Test - ETC Equipped
0416	Enable Mopar VTSS Tamper Alert	1055	Set RPM Test - non - ETC Equipped
0417	Enable Trailer Tow Lamps	1056	Set Ride Height Level
0418	Enable VTSS	1057	Shift Lever Position Test
0419	Enable VTSS Mopar	1058	Shift Lever Position Test (62TE)
0420	Enable or Disable Mobile PTO	1059	Shift Lever Position Test (Non-RFE)
0421	Enable seat belts reminder	1060	Shift Lever Position Test (RFE)
0422	Enable the One Press All Unlock Feature	1061	Shift Lever Position Test - 62TE
0423	Enable/Disable Air Suspension for ITM	1062	Shift Lever Position Test:NON_RFE
0424	Enable/Disable DRL	1063	Shift Lever Position Test:RFE
0425	Enable/Disable Front Fog Lamp	1064	Shift PT Check Perform Test
0426	Enable/Disable Front Seat Video	1065	Shift Pressure Solenoid Test
0427	Enable/Disable HV Battery Contactors	1066	Siren Test
0428	Enable/Disable Seatbelt Minder	1067	Sliding Door Close Test
0429	Engagement electrovalve PPV1 command (3rd/2nd/Reverse)	1068	Sliding Door Latch Cinch Test

0430	Engagement electrovalve PPV2 command (1st/4th/5th/6th)	1069	Sliding Door Latch Release Test
0431	Engine CAN Baud-Rate Adjustment	1070	Sliding Door Open Test
0432	Engine Coolant System Air Purge	1071	Smart Bar Motor Self Test
0433	Engine ECU Replaced (Drive Authorization)	1072	Snorkel Output Test
0434	Engine ECU Replacement	1073	Software Reset Module
0435	Engine Idle Shutdown Feature Enable/Disable	1074	Solenoid Valve Test
0436	Engine Idle Shutdown Timer Adjustment	1075	Sound Horn On Lock
0437	Engine On Odometer	1076	Sound Horn on Lock
0438	Engine Warm Up	1077	Sound Horn on Remote Start
0439	Erase All Ignition Keys	1078	Speaker Test
0440	Erase All Keys and Program New Ignition Key FOB	1079	Speed Limiter
0441	Erase Ignition FOBIKs	1080	Spoiler Snapshot
0442	Erase Key FOBs Only	1081	Spring Deflate to Atmosphere
0443	Erase and Program Keys	1082	Spring Deflate to Reservoir
0444	Even gear clutch (K2) control solenoid valve command	1083	Standardization
0445	Even no. gear clutch pressure sensor replacement	1084	Standardization Routine
0446	Exhaust Phaser 1 Cleaning	1085	Startup with CODE CARD
0447	Exhaust Phaser 2 Cleaning	1086	Static Test
0448	Exhaust Throttle Plate Adaptive Learn	1087	Stationary Desoot
0449	Exhaust Throttle Plate Adaptive Learn Position	1088	Steering Angle Calibration
0450	Exit Logistic Mode	1089	Steering Angle Sensor Calibration
0451	Exit Production Mode	1090	Stop Failure Info
0452	Exit Shipping Mode	1091	Stop Mode Info
0453	Extend or Retract Spoiler	1092	Stop Start Confirmation

0454	FCM Enable Emissions Rolls Test Mode	1093	Stop Tire Training
0455	FFCM Calibration	1094	Store Learned Adaptives
0456	FUEL PRESSURE OVERRIDE - Automatic Transmission	1095	Sunroof Initialization
0457	FUEL PRESSURE OVERRIDE - Manual Transmission	1096	Supercharging system components replacement
0458	Fan cooling activation	1097	Swap Line Test
0459	Fill Spring From Reservoir	1098	Sway Bar Telltale Fast Blink Actuator
0460	Fire Protection System Activate	1099	Sway Bar Telltale Off Actuator
0461	First Pass Cool Down Test Results	1100	Sway Bar Telltale On Actuator
0462	First Passed Cool Down Test Results	1101	Sway Bar Telltale Slow Blink Actuator
0463	First Passed Cooldown Test Results	1102	Swirl Control Learn
0464	Flap actuators learning test	1103	Switch Test
0465	Flash Hazard Lamps On Lock	1104	System Functionality Test
0466	Flash Turn Signals with Door Lock	1105	System Pressure Measurement
0467	Fleet PIN Reset	1106	System Wiring Test
0468	Flexible Oil Change Indicator Reset	1107	TCC Break-In
0469	Front Blower State	1108	TCC Break-In (62TE)
0470	Fuel Injector Kill	1109	TCC Break-In (Non-RFE)
0471	Fuel Mean Value Adaptation Initialization	1110	TCC Break-In View Status
0472	Fuel Mean Value Adaption Initialization	1111	TCC BreakIn
0473	Fuel Pressure Override	1112	TCC Solenoid Test
0474	Fuel Pressure Override Test	1113	TCM Automatic Variant Coding (Restore ECU Config)
0475	Fuel Pump Activation	1114	TCM Initialization
0476	Fuel Rail Control Test	1115	TCM Module Service Replacement
0477	Fuel Rail Pressure Control Test	1116	TCM Reset Adaptive

0478	Fuel System Run Up Test	1117	TCM Reset Learned Adaptives
0479	Fuel supply system components replacement	1118	TCM Store Adaptive
0480	GENERATOR FULL FIELD TEST	1119	TCM VIN Verification
0481	Gauge Sweep Test	1120	TEMPERATURE DISPLAY
0482	Gear configuration reset	1121	TGW Tone Test
0483	Gearbox oil accumulator replacement	1122	TIME BATTERY DISCONNECTED
0484	Gearbox replacement	1123	TIPM Enable Emissions Rolls Test Mode
0485	Generate IUMPR Report	1124	TORQUE CONVERTER CLUTCH TEST
0486	Glow plug preheating circuit test	1125	TPIM Cooling Fan Actuation
0487	Gov 3 and 4 Shift Valve Test	1126	TPM FGA PROXI Configuration
0488	HB Disable Tilt Mirrors in Reverse	1127	TPM Sensor Position Parameter Update
0489	HB and HG:Enable DRL	1128	TPM Sensor Rolls Test
0490	HB and HG:Program Tire Size	1129	TPM Sensor Test
0491	HEV Telltale Actuators	1130	TPM Train Tires
0492	HFM Self Test	1131	TPM Trigger Module Test
0493	HIDT Calibration	1132	TPM Trigger Module Test DH
0494	HPV Electrical Circuit Test	1133	TRANSMISSION RANGE INDICATOR
0495	HV Battery Balance Test	1134	TVA AUTO ZERO TEST
0496	HV Battery Isolation Test	1135	TVA SPAN TEST
0497	HV Battery Open Cable Detected Fault Reset	1136	Take Out of In Plant Mode
0498	HVAC Cool Down Test	1137	Temporarily Block Keyfob
0499	HVAC Door Recalibration	1138	Temporary Remote Start Disable
0500	HVAC Proxi Configuration	1139	Temporary Tip Start Disable
0501	HVAC Self Test	1140	Thermistor Test
0502	HVIL Operating Status	1141	Thermistor Test (62TE)
0503	Hard Top / Soft Top Configuration	1142	Thermistor Test (Non-RFE)
0504	Hardware Reset Module	1143	Thermistor Test (RFE)
0505	HeadLamps On With Wipers	1144	Throttle Body Self Learning
0506	Headlamp Delay Time	1145	Throttle Body Self-Learning
0507	Headlamps Delay	1146	Throttle Follower Test
0508	Headlamps Delay Time	1147	Throttle Valve Initialization
0509	Headlamps On With Wipers	1148	Throttle Valve Learn
0510	Headlamps on with Wipers	1149	Throttle valve test
0511	Headphone Test	1150	Tilt Mirrors in Reverse
0512	Heated Steering Wheel Configuration	1151	Tilt Mirrors in Reverse Feature
0513	Height Sensor Check	1152	Time Controlled Spring Fill

0514	High Pressure Fuel Rail Test (Engine Running)	1153	Timing sensor and/or cam replacement
0515	High Pressure Fuel System Test	1154	Tip Start Override
0516	High Pressure Setpoint Test	1155	Tip Start Temporary Disable
0517	High Speed Fan Test	1156	Tire Pressure ECU Replacement with Manual Initialization
0518	High Voltage Battery Charge	1157	Tone Output Test
0519	High Voltage Battery Coolant Fill	1158	Tone Test
0520	High Voltage Battery Drain	1159	Torque Converter Clutch Test
0521	High Voltage Battery Negative Contactor Test	1160	Tow Hook Enable
0522	High Voltage Battery Pack Under Voltage Recovery	1161	Trailer Hook presence disabling
0523	High Voltage Battery Positive Contactor Test	1162	Trailer Hook presence enabling
0524	High Voltage Battery Precharge Contactor Test	1163	Trailer Module ECU Initialization
0525	High Voltage Contactor Circuit	1164	Trailer Tow Relay Outputs
0526	Horn Chirp	1165	Trans Adapt Reset Trigger
0527	Horn Chirp Duration	1166	Trans Adapts Reset Trigger
0528	Hybrid Battery Contactor Status	1167	Trans Aux Pump Speed
0529	Hybrid Battery Contactor Test	1168	Trans Cleaning Procedure
0530	Hybrid Trans Start/Stop	1169	Trans Fast Learn Trigger
0531	Hydraulic Circuit depressurization	1170	Trans Line Pressure
0532	Hydraulic Fan Solenoid Test	1171	Transmission Auxiliary Pump Test
0533	Hydraulic Kit replacement	1172	Transmission Cleaning Procedure
0534	IAC Wiggle Test	1173	Transmission Motor Control
0535	IC Set Clock	1174	Transmission Shift Solenoids Test
0536	IDLE UP FEATURE ENABLE	1175	Tunnel lever replacement
0537	IMA Quick Calibration	1176	Turbo Actuator Pre-Align / Self Calibrate
0538	IMA Rapid Calibration	1177	Turn off Gain Mode Override
0539	IMV Electrical Circuit Test	1178	Ultrasonic Motion Detection Test
0540	IPC Disable Seatbelt Minder Chime	1179	Ultrasonic Self Test
0541	IPC Enable Seatbelt Minder Chime	1180	Ultrasonic sensors check
0542	IPC Replacement	1181	UnLock With Valid Transponder
0543	IPC Self Test	1182	Unlock All Doors First Press
0544	IPC Service Mode	1183	Unlock All Doors on 1st Press
0545	IPM Enable Airbags	1184	Unlock Driver Door On 1st Press
0546	IR Sensor Data	1185	Update Front and Rear Axle Nominal Tire Pressure Values
0547	ITM Initialize	1186	Update Measurement Unit
0548	ITM Initialize KK Only	1187	Update Model Year to 2007
0549	ITM Initialize PT Only	1188	Update Pressure Thresholds
0550	ITM Initialize Siren	1189	Update Radio Market Select and DVD Region Code
0551	ITM Self Test	1190	Update Service Interval
0552	ITM Siren Replaced	1191	Uplift Pump Enable
0553	ITM Siren Test	1192	VG Turbo Cleaning Procedure
0554	ITM Ultrasonic Test	1193	VG Turbocharger Cleaning Procedure
0555	ITM and Siren Communication Test	1194	VGT Learn
0556	ITM_04_ITM_and_Siren_Communication_Test	1195	VIEW/RESET DUTY CYCLE ACCUMULATORS
0557	Identify EQ	1196	VIEW/RESET DUTY CYCLE ACCUMULATORS:03
0558	Idle Shutdown Timer Adjustment	1197	VIEW/RESET TRIP INFORMATION ACCUMULATORS
0559	Illuminated Approach Time	1198	VIN Locked
0560	Illuminated Entry Time	1199	VIN Verify Write
0561	Immobilizer Antenna Test	1200	VTM transport mode status
0562	Infared Temperature Sensor	1201	VVT System Test
0563	Initalize Learned Features	1202	Vacuum Pump Rezero
0564	Initalize Programed Features	1203	Valve Body Solenoid Learn
0565	Initalize VIN	1204	Variable geometry turbo and/or turbo position sensor replacement
0566	Initialize ABS	1205	Verify Front TPM Antenna
0567	Initialize ABS Module	1206	Verify Module Calibration

0568	Initialize ABS Non ESP	1207	Verify Rear TPM Antenna
0569	Initialize Air Flow Sensor Values	1208	View Adaptive Numerator Status
0570	Initialize EGS	1209	View Battery Monitoring Information
0571	Initialize EGS-52	1210	View Battery Pack Information
0572	Initialize EPPM	1211	View Battery Warranty Information
0573	Initialize EPS	1212	View ESMR Battery Usage History
0574	Initialize ESP Module:LX	1213	View Electronic TPM ID
0575	Initialize ESP Module:PT	1214	View HV Charge Mode Status and Amp Hours of Algorithm Charge
0576	Initialize ESP Module:WK	1215	View Hybrid Battery Reasons Contactor Not Closing When Commanded
0577	Initialize ESP Module:WK-Non ESP	1216	View Hybrid Commanded Engine Status
0578	Initialize ESP Sensor	1217	View Ignition (IGNM/KIN) Part Information
0579	Initialize ITM	1218	View Isolation Test Results
0580	Initialize Learned Features	1219	View Last Successful Remote Start Event Data
0581	Initialize ORC	1220	View Last VTA Trigger Cause
0582	Initialize Optical Paths	1221	View Last VTA Trigger Cause Data
0583	Initialize Power Top	1222	View Oil Dilution Mass Value
0584	Initialize Siren	1223	View Recent Multi-Module VIN Handshake Immobilizer Failures
0585	Initialize Steering Angle Sensor	1224	View Remote Start Abort Data
0586	Initialize VIN	1225	View Remote Start Enable Data
0587	Injector Accelerated Drift Learn	1226	View Remote Start Inhibit Data
0588	Injector Circuit Test	1227	View SKREEM Country Code
0589	Injector Kill System Test	1228	View SKREEM VIN
0590	Injector Kill Test	1229	View Satellite Sensor Information
0591	Injector Quantity Adjustment	1230	View Stored Hybrid Battery Reasons Contactors Opened
0592	Injector codes read	1231	View Stored Reasons Contactor Not Closing When Commanded
0593	Injector replacement (per bank)	1232	View Strong Hybrid Limp In Status
0594	Injector/s replacement	1233	View TPM Sensor IDs
0595	Input Test	1234	View Uconnect Log Data
0596	Intake Phaser 1 Cleaning	1235	View VTA Enable Data
0597	Intake Phaser 2 Cleaning	1236	View/Reset DEF (Reductant) Doser Purge Count Reset
0598	Intake manifold replacement	1237	View/Reset DOC After Treatment Over Temp Events
0599	Intelligent alternator (IAM) replacement	1238	View/Reset DPF After Treatment Over Temp Events
0600	Intrusion Sensor	1239	View/Reset Duty Cycle Maps
0601	Isolation Fault Reset	1240	View/Reset NAC After Treatment Over Temp Events
0602	JK Enable HFM	1241	WARNING THRESHOLD(DAYS)
0603	Key Fobs Linked to Memory	1242	WARNING THRESHOLD(MILES)
0604	Key Fobs Linked to Memory Feature	1243	WCM Gateway Replaced
0605	Key in test	1244	WCM Replaced
0606	LDP Forced Monitor Test	1245	WCM Replaced - Diesel
0607	LDP Monitor Test	1246	WCM Replaced - Gas
0608	LED Zebra Display	1247	WCM Replaced 1
0609	LF Antenna Verification Test	1248	WCM Replaced 2
0610	LIN Anti-tilt Sensor Check	1249	WCM Replaced DH
0611	LIN Line Request Check	1250	WCM Replaced ENG_SCI - Gas
0612	LIN Siren Check	1251	WCM Replaced Non TPM
0613	LRSM Re-Adaption	1252	WCM Replaced Not Var 5 non TPM
0614	LRSM Readaption	1253	WCM Replaced SK 3101DFF0 Non TPM
0615	Lambda Sensor 1 Initialization	1254	WCM Replaced SK 3101DFF0 TPM
0616	Lambda Sensor Replace	1255	WCM Replaced Var 5 non TPM
0617	Lambda sensor replacement	1256	WCM TPM Sensor Test
0618	Lamp Status	1257	WCM Trigger Module Test
0619	Language Preference	1258	WIN Replaced
0620	Last Inhibit Monitor	1259	WIN Replaced SK 3101DFF0
0621	Last service date	1260	WIN Replaced SK 3112
0622	Latch Cinch Test	1261	WIN Replaced SK 31A2

0623	Latch Home Sector Test	1262	WK and XK:Program Tire Size
0624	Latch Release Test	1263	WK:Enable DRL
0625	Leak Detection Pump (LDP) Forced Monitor	1264	Wheel Speed Sensor Recognition
0626	Leak detection pump test	1265	Wheel speed sensor type test
0627	Learn Clutches Contact Point	1266	Windows Down
0628	Learn ETC	1267	Windows Up
0629	Learn ETC (NGC4)	1268	Wiper Actuation Test
0630	Learn Latch Sector Home	1269	Write Left Rear Seat Position
0631	Learn Mis-Fire Adaptive Numerator	1270	Write PROXI
0632	Learn Motor	1271	Write Pinion Factor
0633	Learn Side Identifier	1272	Write Right Rear Seat Position
0634	Learn long acceleration Signal	1273	Write Suspension Height Values
0635	Led display test of gear lever position	1274	XK:Enable DRL
0636	Left Front Tire Pressure Signal Transmission Test	1275	self learning motors test
0637	Left Rear Tire Pressure Signal Transmission Test	1276	sensor and/or catalytic convertor replacement
0638	Left Rear Window Movment	1277	tone.output.test.stopCommand
0639	Left Rotation Relay	1278	tow hook exclusion
1279	TORQUE CONV CLUTCH TEST	1302	SET RPM SYSTEM TEST
1280	GOV 3 & 4 SHIFT VALVE TEST	1303	ReLearn Cam Crank
1281	Clear DTCs	1304	Program Tire Sensor ID
1282	Check VIN	1305	Program Ignition Key(s)
1283	Shift Lever	1306	Erase All Current Ign Keys
1284	Clutch Test	1307	Program New FOB
1285	LEAK DETECTION PUMP TEST	1308	Erase FOB Only Keys
1286	MINIMUM AIRFLOW Test	1309	SKREEM Replaced
1287	PURGE VAPORS TEST	1310	Manual SKREEM Functions
1288	IAC WIGGLE TEST	1311	Enable/Disable TPM
1289	LDP MONITOR TEST	1312	Display TPM Sensors IDs
1290	LINEAR IAC TEST	1313	Shift Lever
1291	EGR SYSTEM TEST	1314	Clutch Test
1292	INJECTOR KILL TEST	1315	Trans Overhauled/Replaced
1293	Clear PCM Batt Disconnect	1316	Quicklearn
1294	O2 HEATER TEST	1317	EATX DTC Event Data
1295	EGR SYSTEM TEST	1318	Program Tire Sensor ID
1296	ETC SYSTEM TEST	1319	Program Ignition Key(s)
1297	EGR SYSTEM TEST	1320	Manual SKIM Functions
1298	O2 HEATER TEST	1321	SKIM Replaced
1299	MISFIRE MONITOR TEST	1322	Program Tire Sensor ID
1300	ETC THROTTLE FOLLOWER TEST	1323	TPM Sensors Test
1301	ETC SYSTEM TEST		