

**Audi Diagnostics List**  
**(Note:For reference only)**

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S1	2013-2018	FS	01 Engine Electronics	Read Fault Codes	
Audi S1	2013-2018	FS	01 Engine Electronics	Clear Fault Codes	
Audi S1	2013-2018	FS	01 Engine Electronics	Measuring Blocks	
Audi S1	2013-2018	FS	01 Engine Electronics	Output Tests	
Audi S1	2013-2018	FS	01 Engine Electronics	Specia Functions	
Audi S1	2013-2018	FS	02 Transmission Electronics	Read Fault Codes	
Audi S1	2013-2018	FS	02 Transmission Electronics	Clear Fault Codes	
Audi S1	2013-2018	FS	02 Transmission Electronics	Measuring Blocks	
Audi S1	2013-2018	FS	02 Transmission Electronics	Output Tests	
Audi S1	2013-2018	FS	02 Transmission Electronics	Specia Functions	
Audi S1	2013-2018	FS	03 Brake Electronics	Read Fault Codes	
Audi S1	2013-2018	FS	03 Brake Electronics	Clear Fault Codes	
Audi S1	2013-2018	FS	03 Brake Electronics	Measuring Blocks	
Audi S1	2013-2018	FS	03 Brake Electronics	Output Tests	
Audi S1	2013-2018	FS	03 Brake Electronics	Specia Functions	
Audi S1	2013-2018	FS	05 Access & Permissi.	Read Fault Codes	
Audi S1	2013-2018	FS	05 Access & Permissi.	Clear Fault Codes	
Audi S1	2013-2018	FS	05 Access & Permissi.	Measuring Blocks	
Audi S1	2013-2018	FS	05 Access & Permissi.	Output Tests	
Audi S1	2013-2018	FS	05 Access & Permissi.	Specia Functions	
Audi S1	2013-2018	FS	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S1	2013-2018	FS	08 AC/Heating Electronics	Clear Fault Codes	
Audi S1	2013-2018	FS	08 AC/Heating Electronics	Measuring Blocks	
Audi S1	2013-2018	FS	08 AC/Heating Electronics	Output Tests	
Audi S1	2013-2018	FS	08 AC/Heating Electronics	Specia Functions	
Audi S1	2013-2018	FS	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S1	2013-2018	FS	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S1	2013-2018	FS	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S1	2013-2018	FS	09 Electronic Ctrl Electronics	Output Tests	
Audi S1	2013-2018	FS	09 Electronic Ctrl Electronics	Specia Functions	
Audi S1	2013-2018	FS	0E Media Player Position 1	Read Fault Codes	
Audi S1	2013-2018	FS	0E Media Player Position 1	Clear Fault Codes	
Audi S1	2013-2018	FS	0E Media Player Position 1	Measuring Blocks	
Audi S1	2013-2018	FS	0E Media Player Position 1	Output Tests	
Audi S1	2013-2018	FS	0E Media Player Position 1	Specia Functions	
Audi S1	2013-2018	FS	10 Parking Assist System 2	Read Fault Codes	
Audi S1	2013-2018	FS	10 Parking Assist System 2	Clear Fault Codes	
Audi S1	2013-2018	FS	10 Parking Assist System 2	Measuring Blocks	
Audi S1	2013-2018	FS	10 Parking Assist System 2	Output Tests	
Audi S1	2013-2018	FS	10 Parking Assist System 2	Specia Functions	
Audi S1	2013-2018	FS	14 Wheel Damping Electronics	Read Fault Codes	
Audi S1	2013-2018	FS	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S1	2013-2018	FS	14 Wheel Damping Electronics	Measuring Blocks	
Audi S1	2013-2018	FS	14 Wheel Damping Electronics	Output Tests	
Audi S1	2013-2018	FS	14 Wheel Damping Electronics	Specia Functions	
Audi S1	2013-2018	FS	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S1	2013-2018	FS	15 Airbags	Clear Fault Codes	
Audi S1	2013-2018	FS	15 Airbags	Measuring Blocks	
Audi S1	2013-2018	FS	15 Airbags	Output Tests	
Audi S1	2013-2018	FS	15 Airbags	Specia Functions	
Audi S1	2013-2018	FS	16 Steering Wheel Electronics	Read Fault Codes	
Audi S1	2013-2018	FS	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S1	2013-2018	FS	16 Steering Wheel Electronics	Measuring Blocks	
Audi S1	2013-2018	FS	16 Steering Wheel Electronics	Output Tests	
Audi S1	2013-2018	FS	16 Steering Wheel Electronics	Specia Functions	
Audi S1	2013-2018	FS	17 Instrument Cluster	Read Fault Codes	
Audi S1	2013-2018	FS	17 Instrument Cluster	Clear Fault Codes	
Audi S1	2013-2018	FS	17 Instrument Cluster	Measuring Blocks	
Audi S1	2013-2018	FS	17 Instrument Cluster	Output Tests	
Audi S1	2013-2018	FS	17 Instrument Cluster	Specia Functions	
Audi S1	2013-2018	FS	19 Gateway Data Bus	Read Fault Codes	
Audi S1	2013-2018	FS	19 Gateway Data Bus	Clear Fault Codes	
Audi S1	2013-2018	FS	19 Gateway Data Bus	Measuring Blocks	
Audi S1	2013-2018	FS	19 Gateway Data Bus	Output Tests	
Audi S1	2013-2018	FS	19 Gateway Data Bus	Specia Functions	
Audi S1	2013-2018	FS	20 High Beam Assistance Device	Read Fault Codes	
Audi S1	2013-2018	FS	20 High Beam Assistance Device	Clear Fault Codes	
Audi S1	2013-2018	FS	20 High Beam Assistance Device	Measuring Blocks	
Audi S1	2013-2018	FS	20 High Beam Assistance Device	Output Tests	
Audi S1	2013-2018	FS	20 High Beam Assistance Device	Specia Functions	
Audi S1	2013-2018	FS	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S1	2013-2018	FS	22 4WD Electronics	Clear Fault Codes	
Audi S1	2013-2018	FS	22 4WD Electronics	Measuring Blocks	
Audi S1	2013-2018	FS	22 4WD Electronics	Output Tests	
Audi S1	2013-2018	FS	22 4WD Electronics	Specia Functions	
Audi S1	2013-2018	FS	25 Immobilizer	Read Fault Codes	
Audi S1	2013-2018	FS	25 Immobilizer	Clear Fault Codes	
Audi S1	2013-2018	FS	25 Immobilizer	Measuring Blocks	
Audi S1	2013-2018	FS	25 Immobilizer	Output Tests	
Audi S1	2013-2018	FS	25 Immobilizer	Specia Functions	
Audi S1	2013-2018	FS	2B Steer Col Lock	Read Fault Codes	
Audi S1	2013-2018	FS	2B Steer Col Lock	Clear Fault Codes	
Audi S1	2013-2018	FS	2B Steer Col Lock	Measuring Blocks	
Audi S1	2013-2018	FS	2B Steer Col Lock	Output Tests	
Audi S1	2013-2018	FS	2B Steer Col Lock	Specia Functions	
Audi S1	2013-2018	FS	3C Lane Departure Assistance System	Read Fault Codes	
Audi S1	2013-2018	FS	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S1	2013-2018	FS	3C Lane Departure Assistance System	Measuring Blocks	
Audi S1	2013-2018	FS	3C Lane Departure Assistance System	Output Tests	
Audi S1	2013-2018	FS	3C Lane Departure Assistance System	Specia Functions	
Audi S1	2013-2018	FS	3D Special Function	Read Fault Codes	
Audi S1	2013-2018	FS	3D Special Function	Clear Fault Codes	
Audi S1	2013-2018	FS	3D Special Function	Measuring Blocks	
Audi S1	2013-2018	FS	3D Special Function	Output Tests	
Audi S1	2013-2018	FS	3D Special Function	Specia Functions	
Audi S1	2013-2018	FS	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S1	2013-2018	FS	42 Driver-Door Elect.	Clear Fault Codes	
Audi S1	2013-2018	FS	42 Driver-Door Elect.	Measuring Blocks	
Audi S1	2013-2018	FS	42 Driver-Door Elect.	Output Tests	
Audi S1	2013-2018	FS	42 Driver-Door Elect.	Specia Functions	
Audi S1	2013-2018	FS	44 Steering Assistance	Read Fault Codes	
Audi S1	2013-2018	FS	44 Steering Assistance	Clear Fault Codes	
Audi S1	2013-2018	FS	44 Steering Assistance	Measuring Blocks	
Audi S1	2013-2018	FS	44 Steering Assistance	Output Tests	
Audi S1	2013-2018	FS	44 Steering Assistance	Specia Functions	
Audi S1	2013-2018	FS	47 Soundsystem	Read Fault Codes	
Audi S1	2013-2018	FS	47 Soundsystem	Clear Fault Codes	
Audi S1	2013-2018	FS	47 Soundsystem	Measuring Blocks	
Audi S1	2013-2018	FS	47 Soundsystem	Output Tests	
Audi S1	2013-2018	FS	47 Soundsystem	Specia Functions	
Audi S1	2013-2018	FS	52 Passe.-Door Elect.	Read Fault Codes	
Audi S1	2013-2018	FS	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S1	2013-2018	FS	52 Passe.-Door Elect.	Measuring Blocks	
Audi S1	2013-2018	FS	52 Passe.-Door Elect.	Output Tests	
Audi S1	2013-2018	FS	52 Passe.-Door Elect.	Specia Functions	
Audi S1	2013-2018	FS	53 Parking Brake	Read Fault Codes	
Audi S1	2013-2018	FS	53 Parking Brake	Clear Fault Codes	
Audi S1	2013-2018	FS	53 Parking Brake	Measuring Blocks	
Audi S1	2013-2018	FS	53 Parking Brake	Output Tests	
Audi S1	2013-2018	FS	53 Parking Brake	Specia Functions	
Audi S1	2013-2018	FS	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S1	2013-2018	FS	55 Headlight Range Control	Clear Fault Codes	
Audi S1	2013-2018	FS	55 Headlight Range Control	Measuring Blocks	
Audi S1	2013-2018	FS	55 Headlight Range Control	Output Tests	
Audi S1	2013-2018	FS	55 Headlight Range Control	Specia Functions	
Audi S1	2013-2018	FS	56 Radio	Read Fault Codes	
Audi S1	2013-2018	FS	56 Radio	Clear Fault Codes	
Audi S1	2013-2018	FS	56 Radio	Measuring Blocks	
Audi S1	2013-2018	FS	56 Radio	Output Tests	
Audi S1	2013-2018	FS	56 Radio	Specia Functions	
Audi S1	2013-2018	FS	57 TV-Tuner	Read Fault Codes	
Audi S1	2013-2018	FS	57 TV-Tuner	Clear Fault Codes	
Audi S1	2013-2018	FS	57 TV-Tuner	Measuring Blocks	
Audi S1	2013-2018	FS	57 TV-Tuner	Output Tests	
Audi S1	2013-2018	FS	57 TV-Tuner	Specia Functions	
Audi S1	2013-2018	FS	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S1	2013-2018	FS	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S1	2013-2018	FS	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S1	2013-2018	FS	5F Information Electronic Equipment 1	Output Tests	
Audi S1	2013-2018	FS	5F Information Electronic Equipment 1	Specia Functions	
Audi S1	2013-2018	FS	62 LR-Door Electroni.	Read Fault Codes	
Audi S1	2013-2018	FS	62 LR-Door Electroni.	Clear Fault Codes	
Audi S1	2013-2018	FS	62 LR-Door Electroni.	Measuring Blocks	
Audi S1	2013-2018	FS	62 LR-Door Electroni.	Output Tests	
Audi S1	2013-2018	FS	62 LR-Door Electroni.	Specia Functions	
Audi S1	2013-2018	FS	69 Trailer Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S1	2013-2018	FS	69 Trailer Function	Clear Fault Codes	
Audi S1	2013-2018	FS	69 Trailer Function	Measuring Blocks	
Audi S1	2013-2018	FS	69 Trailer Function	Output Tests	
Audi S1	2013-2018	FS	69 Trailer Function	Specia Functions	
Audi S1	2013-2018	FS	6C Rear Camera	Read Fault Codes	
Audi S1	2013-2018	FS	6C Rear Camera	Clear Fault Codes	
Audi S1	2013-2018	FS	6C Rear Camera	Measuring Blocks	
Audi S1	2013-2018	FS	6C Rear Camera	Output Tests	
Audi S1	2013-2018	FS	6C Rear Camera	Specia Functions	
Audi S1	2013-2018	FS	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S1	2013-2018	FS	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S1	2013-2018	FS	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S1	2013-2018	FS	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S1	2013-2018	FS	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S1	2013-2018	FS	72 RR-Door Electroni.	Read Fault Codes	
Audi S1	2013-2018	FS	72 RR-Door Electroni.	Clear Fault Codes	
Audi S1	2013-2018	FS	72 RR-Door Electroni.	Measuring Blocks	
Audi S1	2013-2018	FS	72 RR-Door Electroni.	Output Tests	
Audi S1	2013-2018	FS	72 RR-Door Electroni.	Specia Functions	
Audi S1	2013-2018	FS	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi S1	2013-2018	FS	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi S1	2013-2018	FS	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi S1	2013-2018	FS	A5 Frt Sens.Drv.Assist	Output Tests	
Audi S1	2013-2018	FS	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi S1	2013-2018	FS	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S1	2013-2018	FS	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S1	2013-2018	FS	A9 Struct.Borne Sound	Measuring Blocks	
Audi S1	2013-2018	FS	A9 Struct.Borne Sound	Output Tests	
Audi S1	2013-2018	FS	A9 Struct.Borne Sound	Specia Functions	
Audi Q3	2012-2018	8U	01 Engine Electronics	Read Fault Codes	
Audi Q3	2012-2018	8U	01 Engine Electronics	Clear Fault Codes	
Audi Q3	2012-2018	8U	01 Engine Electronics	Measuring Blocks	
Audi Q3	2012-2018	8U	01 Engine Electronics	Output Tests	
Audi Q3	2012-2018	8U	01 Engine Electronics	Specia Functions	
Audi Q3	2012-2018	8U	02 Transmission Electronics	Read Fault Codes	
Audi Q3	2012-2018	8U	02 Transmission Electronics	Clear Fault Codes	
Audi Q3	2012-2018	8U	02 Transmission Electronics	Measuring Blocks	
Audi Q3	2012-2018	8U	02 Transmission Electronics	Output Tests	
Audi Q3	2012-2018	8U	02 Transmission Electronics	Specia Functions	
Audi Q3	2012-2018	8U	03 Brake Electronics	Read Fault Codes	
Audi Q3	2012-2018	8U	03 Brake Electronics	Clear Fault Codes	
Audi Q3	2012-2018	8U	03 Brake Electronics	Measuring Blocks	
Audi Q3	2012-2018	8U	03 Brake Electronics	Output Tests	
Audi Q3	2012-2018	8U	03 Brake Electronics	Specia Functions	
Audi Q3	2012-2018	8U	05 Access & Permissi.	Read Fault Codes	
Audi Q3	2012-2018	8U	05 Access & Permissi.	Clear Fault Codes	
Audi Q3	2012-2018	8U	05 Access & Permissi.	Measuring Blocks	
Audi Q3	2012-2018	8U	05 Access & Permissi.	Output Tests	
Audi Q3	2012-2018	8U	05 Access & Permissi.	Specia Functions	
Audi Q3	2012-2018	8U	08 AC/Heating Electronics	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi Q3	2012-2018	8U	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q3	2012-2018	8U	08 AC/Heating Electronics	Measuring Blocks	
Audi Q3	2012-2018	8U	08 AC/Heating Electronics	Output Tests	
Audi Q3	2012-2018	8U	08 AC/Heating Electronics	Specia Functions	
Audi Q3	2012-2018	8U	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Q3	2012-2018	8U	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q3	2012-2018	8U	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q3	2012-2018	8U	09 Electronic Ctrl Electronics	Output Tests	
Audi Q3	2012-2018	8U	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q3	2012-2018	8U	0E Media Player Position 1	Read Fault Codes	
Audi Q3	2012-2018	8U	0E Media Player Position 1	Clear Fault Codes	
Audi Q3	2012-2018	8U	0E Media Player Position 1	Measuring Blocks	
Audi Q3	2012-2018	8U	0E Media Player Position 1	Output Tests	
Audi Q3	2012-2018	8U	0E Media Player Position 1	Specia Functions	
Audi Q3	2012-2018	8U	10 Parking Assist System 2	Read Fault Codes	
Audi Q3	2012-2018	8U	10 Parking Assist System 2	Clear Fault Codes	
Audi Q3	2012-2018	8U	10 Parking Assist System 2	Measuring Blocks	
Audi Q3	2012-2018	8U	10 Parking Assist System 2	Output Tests	
Audi Q3	2012-2018	8U	10 Parking Assist System 2	Specia Functions	
Audi Q3	2012-2018	8U	14 Wheel Damping Electronics	Read Fault Codes	
Audi Q3	2012-2018	8U	14 Wheel Damping Electronics	Clear Fault Codes	
Audi Q3	2012-2018	8U	14 Wheel Damping Electronics	Measuring Blocks	
Audi Q3	2012-2018	8U	14 Wheel Damping Electronics	Output Tests	
Audi Q3	2012-2018	8U	14 Wheel Damping Electronics	Specia Functions	
Audi Q3	2012-2018	8U	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q3	2012-2018	8U	15 Airbags	Clear Fault Codes	
Audi Q3	2012-2018	8U	15 Airbags	Measuring Blocks	
Audi Q3	2012-2018	8U	15 Airbags	Output Tests	
Audi Q3	2012-2018	8U	15 Airbags	Specia Functions	
Audi Q3	2012-2018	8U	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q3	2012-2018	8U	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q3	2012-2018	8U	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q3	2012-2018	8U	16 Steering Wheel Electronics	Output Tests	
Audi Q3	2012-2018	8U	16 Steering Wheel Electronics	Specia Functions	
Audi Q3	2012-2018	8U	17 Instrument Cluster	Read Fault Codes	
Audi Q3	2012-2018	8U	17 Instrument Cluster	Clear Fault Codes	
Audi Q3	2012-2018	8U	17 Instrument Cluster	Measuring Blocks	
Audi Q3	2012-2018	8U	17 Instrument Cluster	Output Tests	
Audi Q3	2012-2018	8U	17 Instrument Cluster	Specia Functions	
Audi Q3	2012-2018	8U	19 Gateway Data Bus	Read Fault Codes	
Audi Q3	2012-2018	8U	19 Gateway Data Bus	Clear Fault Codes	
Audi Q3	2012-2018	8U	19 Gateway Data Bus	Measuring Blocks	
Audi Q3	2012-2018	8U	19 Gateway Data Bus	Output Tests	
Audi Q3	2012-2018	8U	19 Gateway Data Bus	Specia Functions	
Audi Q3	2012-2018	8U	20 High Beam Assistance Device	Read Fault Codes	
Audi Q3	2012-2018	8U	20 High Beam Assistance Device	Clear Fault Codes	
Audi Q3	2012-2018	8U	20 High Beam Assistance Device	Measuring Blocks	
Audi Q3	2012-2018	8U	20 High Beam Assistance Device	Output Tests	
Audi Q3	2012-2018	8U	20 High Beam Assistance Device	Specia Functions	
Audi Q3	2012-2018	8U	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q3	2012-2018	8U	22 4WD Electronics	Clear Fault Codes	
Audi Q3	2012-2018	8U	22 4WD Electronics	Measuring Blocks	
Audi Q3	2012-2018	8U	22 4WD Electronics	Output Tests	
Audi Q3	2012-2018	8U	22 4WD Electronics	Specia Functions	
Audi Q3	2012-2018	8U	25 Immobilizer	Read Fault Codes	
Audi Q3	2012-2018	8U	25 Immobilizer	Clear Fault Codes	
Audi Q3	2012-2018	8U	25 Immobilizer	Measuring Blocks	
Audi Q3	2012-2018	8U	25 Immobilizer	Output Tests	
Audi Q3	2012-2018	8U	25 Immobilizer	Specia Functions	
Audi Q3	2012-2018	8U	2B Steer Col Lock	Read Fault Codes	
Audi Q3	2012-2018	8U	2B Steer Col Lock	Clear Fault Codes	
Audi Q3	2012-2018	8U	2B Steer Col Lock	Measuring Blocks	
Audi Q3	2012-2018	8U	2B Steer Col Lock	Output Tests	
Audi Q3	2012-2018	8U	2B Steer Col Lock	Specia Functions	
Audi Q3	2012-2018	8U	3C Lane Departure Assistance System	Read Fault Codes	
Audi Q3	2012-2018	8U	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q3	2012-2018	8U	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q3	2012-2018	8U	3C Lane Departure Assistance System	Output Tests	
Audi Q3	2012-2018	8U	3C Lane Departure Assistance System	Specia Functions	
Audi Q3	2012-2018	8U	3D Special Function	Read Fault Codes	
Audi Q3	2012-2018	8U	3D Special Function	Clear Fault Codes	
Audi Q3	2012-2018	8U	3D Special Function	Measuring Blocks	
Audi Q3	2012-2018	8U	3D Special Function	Output Tests	
Audi Q3	2012-2018	8U	3D Special Function	Specia Functions	
Audi Q3	2012-2018	8U	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q3	2012-2018	8U	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q3	2012-2018	8U	42 Driver-Door Elect.	Measuring Blocks	
Audi Q3	2012-2018	8U	42 Driver-Door Elect.	Output Tests	
Audi Q3	2012-2018	8U	42 Driver-Door Elect.	Specia Functions	
Audi Q3	2012-2018	8U	44 Steering Assistance	Read Fault Codes	
Audi Q3	2012-2018	8U	44 Steering Assistance	Clear Fault Codes	
Audi Q3	2012-2018	8U	44 Steering Assistance	Measuring Blocks	
Audi Q3	2012-2018	8U	44 Steering Assistance	Output Tests	
Audi Q3	2012-2018	8U	44 Steering Assistance	Specia Functions	
Audi Q3	2012-2018	8U	47 Soundsystem	Read Fault Codes	
Audi Q3	2012-2018	8U	47 Soundsystem	Clear Fault Codes	
Audi Q3	2012-2018	8U	47 Soundsystem	Measuring Blocks	
Audi Q3	2012-2018	8U	47 Soundsystem	Output Tests	
Audi Q3	2012-2018	8U	47 Soundsystem	Specia Functions	
Audi Q3	2012-2018	8U	52 Passe.-Door Elect.	Read Fault Codes	
Audi Q3	2012-2018	8U	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q3	2012-2018	8U	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q3	2012-2018	8U	52 Passe.-Door Elect.	Output Tests	
Audi Q3	2012-2018	8U	52 Passe.-Door Elect.	Specia Functions	
Audi Q3	2012-2018	8U	53 Parking Brake	Read Fault Codes	
Audi Q3	2012-2018	8U	53 Parking Brake	Clear Fault Codes	
Audi Q3	2012-2018	8U	53 Parking Brake	Measuring Blocks	
Audi Q3	2012-2018	8U	53 Parking Brake	Output Tests	
Audi Q3	2012-2018	8U	53 Parking Brake	Specia Functions	
Audi Q3	2012-2018	8U	55 Headlight Range Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q3	2012-2018	8U	55 Headlight Range Control	Clear Fault Codes	
Audi Q3	2012-2018	8U	55 Headlight Range Control	Measuring Blocks	
Audi Q3	2012-2018	8U	55 Headlight Range Control	Output Tests	
Audi Q3	2012-2018	8U	55 Headlight Range Control	Specia Functions	
Audi Q3	2012-2018	8U	56 Radio	Read Fault Codes	
Audi Q3	2012-2018	8U	56 Radio	Clear Fault Codes	
Audi Q3	2012-2018	8U	56 Radio	Measuring Blocks	
Audi Q3	2012-2018	8U	56 Radio	Output Tests	
Audi Q3	2012-2018	8U	56 Radio	Specia Functions	
Audi Q3	2012-2018	8U	57 TV-Tuner	Read Fault Codes	
Audi Q3	2012-2018	8U	57 TV-Tuner	Clear Fault Codes	
Audi Q3	2012-2018	8U	57 TV-Tuner	Measuring Blocks	
Audi Q3	2012-2018	8U	57 TV-Tuner	Output Tests	
Audi Q3	2012-2018	8U	57 TV-Tuner	Specia Functions	
Audi Q3	2012-2018	8U	5F Information Electronic Equipment 1	Read Fault Codes	
Audi Q3	2012-2018	8U	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi Q3	2012-2018	8U	5F Information Electronic Equipment 1	Measuring Blocks	
Audi Q3	2012-2018	8U	5F Information Electronic Equipment 1	Output Tests	
Audi Q3	2012-2018	8U	5F Information Electronic Equipment 1	Specia Functions	
Audi Q3	2012-2018	8U	62 LR-Door Electroni.	Read Fault Codes	
Audi Q3	2012-2018	8U	62 LR-Door Electroni.	Clear Fault Codes	
Audi Q3	2012-2018	8U	62 LR-Door Electroni.	Measuring Blocks	
Audi Q3	2012-2018	8U	62 LR-Door Electroni.	Output Tests	
Audi Q3	2012-2018	8U	62 LR-Door Electroni.	Specia Functions	
Audi Q3	2012-2018	8U	69 Trailer Function	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q3	2012-2018	8U	69 Trailer Function	Clear Fault Codes	
Audi Q3	2012-2018	8U	69 Trailer Function	Measuring Blocks	
Audi Q3	2012-2018	8U	69 Trailer Function	Output Tests	
Audi Q3	2012-2018	8U	69 Trailer Function	Specia Functions	
Audi Q3	2012-2018	8U	6C Rear Camera	Read Fault Codes	
Audi Q3	2012-2018	8U	6C Rear Camera	Clear Fault Codes	
Audi Q3	2012-2018	8U	6C Rear Camera	Measuring Blocks	
Audi Q3	2012-2018	8U	6C Rear Camera	Output Tests	
Audi Q3	2012-2018	8U	6C Rear Camera	Specia Functions	
Audi Q3	2012-2018	8U	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi Q3	2012-2018	8U	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q3	2012-2018	8U	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q3	2012-2018	8U	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q3	2012-2018	8U	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q3	2012-2018	8U	72 RR-Door Electroni.	Read Fault Codes	
Audi Q3	2012-2018	8U	72 RR-Door Electroni.	Clear Fault Codes	
Audi Q3	2012-2018	8U	72 RR-Door Electroni.	Measuring Blocks	
Audi Q3	2012-2018	8U	72 RR-Door Electroni.	Output Tests	
Audi Q3	2012-2018	8U	72 RR-Door Electroni.	Specia Functions	
Audi Q3	2012-2018	8U	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi Q3	2012-2018	8U	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi Q3	2012-2018	8U	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi Q3	2012-2018	8U	A5 Frt Sens.Drv.Assist	Output Tests	
Audi Q3	2012-2018	8U	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi Q3	2012-2018	8U	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q3	2012-2018	8U	A9 Struct.Borne Sound	Clear Fault Codes	
Audi Q3	2012-2018	8U	A9 Struct.Borne Sound	Measuring Blocks	
Audi Q3	2012-2018	8U	A9 Struct.Borne Sound	Output Tests	
Audi Q3	2012-2018	8U	A9 Struct.Borne Sound	Specia Functions	
Audi A1	2011-2018	8X	01 Engine Electronics	Read Fault Codes	
Audi A1	2011-2018	8X	01 Engine Electronics	Clear Fault Codes	
Audi A1	2011-2018	8X	01 Engine Electronics	Measuring Blocks	
Audi A1	2011-2018	8X	01 Engine Electronics	Output Tests	
Audi A1	2011-2018	8X	01 Engine Electronics	Specia Functions	
Audi A1	2011-2018	8X	02 Transmission Electronics	Read Fault Codes	
Audi A1	2011-2018	8X	02 Transmission Electronics	Clear Fault Codes	
Audi A1	2011-2018	8X	02 Transmission Electronics	Measuring Blocks	
Audi A1	2011-2018	8X	02 Transmission Electronics	Output Tests	
Audi A1	2011-2018	8X	02 Transmission Electronics	Specia Functions	
Audi A1	2011-2018	8X	03 Brake Electronics	Read Fault Codes	
Audi A1	2011-2018	8X	03 Brake Electronics	Clear Fault Codes	
Audi A1	2011-2018	8X	03 Brake Electronics	Measuring Blocks	
Audi A1	2011-2018	8X	03 Brake Electronics	Output Tests	
Audi A1	2011-2018	8X	03 Brake Electronics	Specia Functions	
Audi A1	2011-2018	8X	05 Access & Permissi.	Read Fault Codes	
Audi A1	2011-2018	8X	05 Access & Permissi.	Clear Fault Codes	
Audi A1	2011-2018	8X	05 Access & Permissi.	Measuring Blocks	
Audi A1	2011-2018	8X	05 Access & Permissi.	Output Tests	
Audi A1	2011-2018	8X	05 Access & Permissi.	Specia Functions	
Audi A1	2011-2018	8X	08 AC/Heating Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A1	2011-2018	8X	08 AC/Heating Electronics	Clear Fault Codes	
Audi A1	2011-2018	8X	08 AC/Heating Electronics	Measuring Blocks	
Audi A1	2011-2018	8X	08 AC/Heating Electronics	Output Tests	
Audi A1	2011-2018	8X	08 AC/Heating Electronics	Specia Functions	
Audi A1	2011-2018	8X	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A1	2011-2018	8X	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A1	2011-2018	8X	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A1	2011-2018	8X	09 Electronic Ctrl Electronics	Output Tests	
Audi A1	2011-2018	8X	09 Electronic Ctrl Electronics	Specia Functions	
Audi A1	2011-2018	8X	0E Media Player Position 1	Read Fault Codes	
Audi A1	2011-2018	8X	0E Media Player Position 1	Clear Fault Codes	
Audi A1	2011-2018	8X	0E Media Player Position 1	Measuring Blocks	
Audi A1	2011-2018	8X	0E Media Player Position 1	Output Tests	
Audi A1	2011-2018	8X	0E Media Player Position 1	Specia Functions	
Audi A1	2011-2018	8X	10 Parking Assist System 2	Read Fault Codes	
Audi A1	2011-2018	8X	10 Parking Assist System 2	Clear Fault Codes	
Audi A1	2011-2018	8X	10 Parking Assist System 2	Measuring Blocks	
Audi A1	2011-2018	8X	10 Parking Assist System 2	Output Tests	
Audi A1	2011-2018	8X	10 Parking Assist System 2	Specia Functions	
Audi A1	2011-2018	8X	14 Wheel Damping Electronics	Read Fault Codes	
Audi A1	2011-2018	8X	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A1	2011-2018	8X	14 Wheel Damping Electronics	Measuring Blocks	
Audi A1	2011-2018	8X	14 Wheel Damping Electronics	Output Tests	
Audi A1	2011-2018	8X	14 Wheel Damping Electronics	Specia Functions	
Audi A1	2011-2018	8X	15 Airbags	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A1	2011-2018	8X	15 Airbags	Clear Fault Codes	
Audi A1	2011-2018	8X	15 Airbags	Measuring Blocks	
Audi A1	2011-2018	8X	15 Airbags	Output Tests	
Audi A1	2011-2018	8X	15 Airbags	Specia Functions	
Audi A1	2011-2018	8X	16 Steering Wheel Electronics	Read Fault Codes	
Audi A1	2011-2018	8X	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A1	2011-2018	8X	16 Steering Wheel Electronics	Measuring Blocks	
Audi A1	2011-2018	8X	16 Steering Wheel Electronics	Output Tests	
Audi A1	2011-2018	8X	16 Steering Wheel Electronics	Specia Functions	
Audi A1	2011-2018	8X	17 Instrument Cluster	Read Fault Codes	
Audi A1	2011-2018	8X	17 Instrument Cluster	Clear Fault Codes	
Audi A1	2011-2018	8X	17 Instrument Cluster	Measuring Blocks	
Audi A1	2011-2018	8X	17 Instrument Cluster	Output Tests	
Audi A1	2011-2018	8X	17 Instrument Cluster	Specia Functions	
Audi A1	2011-2018	8X	19 Gateway Data Bus	Read Fault Codes	
Audi A1	2011-2018	8X	19 Gateway Data Bus	Clear Fault Codes	
Audi A1	2011-2018	8X	19 Gateway Data Bus	Measuring Blocks	
Audi A1	2011-2018	8X	19 Gateway Data Bus	Output Tests	
Audi A1	2011-2018	8X	19 Gateway Data Bus	Specia Functions	
Audi A1	2011-2018	8X	20 High Beam Assistance Device	Read Fault Codes	
Audi A1	2011-2018	8X	20 High Beam Assistance Device	Clear Fault Codes	
Audi A1	2011-2018	8X	20 High Beam Assistance Device	Measuring Blocks	
Audi A1	2011-2018	8X	20 High Beam Assistance Device	Output Tests	
Audi A1	2011-2018	8X	20 High Beam Assistance Device	Specia Functions	
Audi A1	2011-2018	8X	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A1	2011-2018	8X	22 4WD Electronics	Clear Fault Codes	
Audi A1	2011-2018	8X	22 4WD Electronics	Measuring Blocks	
Audi A1	2011-2018	8X	22 4WD Electronics	Output Tests	
Audi A1	2011-2018	8X	22 4WD Electronics	Specia Functions	
Audi A1	2011-2018	8X	25 Immobilizer	Read Fault Codes	
Audi A1	2011-2018	8X	25 Immobilizer	Clear Fault Codes	
Audi A1	2011-2018	8X	25 Immobilizer	Measuring Blocks	
Audi A1	2011-2018	8X	25 Immobilizer	Output Tests	
Audi A1	2011-2018	8X	25 Immobilizer	Specia Functions	
Audi A1	2011-2018	8X	2B Steer Col Lock	Read Fault Codes	
Audi A1	2011-2018	8X	2B Steer Col Lock	Clear Fault Codes	
Audi A1	2011-2018	8X	2B Steer Col Lock	Measuring Blocks	
Audi A1	2011-2018	8X	2B Steer Col Lock	Output Tests	
Audi A1	2011-2018	8X	2B Steer Col Lock	Specia Functions	
Audi A1	2011-2018	8X	3C Lane Departure Assistance System	Read Fault Codes	
Audi A1	2011-2018	8X	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A1	2011-2018	8X	3C Lane Departure Assistance System	Measuring Blocks	
Audi A1	2011-2018	8X	3C Lane Departure Assistance System	Output Tests	
Audi A1	2011-2018	8X	3C Lane Departure Assistance System	Specia Functions	
Audi A1	2011-2018	8X	3D Special Function	Read Fault Codes	
Audi A1	2011-2018	8X	3D Special Function	Clear Fault Codes	
Audi A1	2011-2018	8X	3D Special Function	Measuring Blocks	
Audi A1	2011-2018	8X	3D Special Function	Output Tests	
Audi A1	2011-2018	8X	3D Special Function	Specia Functions	
Audi A1	2011-2018	8X	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A1	2011-2018	8X	42 Driver-Door Elect.	Clear Fault Codes	
Audi A1	2011-2018	8X	42 Driver-Door Elect.	Measuring Blocks	
Audi A1	2011-2018	8X	42 Driver-Door Elect.	Output Tests	
Audi A1	2011-2018	8X	42 Driver-Door Elect.	Specia Functions	
Audi A1	2011-2018	8X	44 Steering Assistance	Read Fault Codes	
Audi A1	2011-2018	8X	44 Steering Assistance	Clear Fault Codes	
Audi A1	2011-2018	8X	44 Steering Assistance	Measuring Blocks	
Audi A1	2011-2018	8X	44 Steering Assistance	Output Tests	
Audi A1	2011-2018	8X	44 Steering Assistance	Specia Functions	
Audi A1	2011-2018	8X	47 Soundsystem	Read Fault Codes	
Audi A1	2011-2018	8X	47 Soundsystem	Clear Fault Codes	
Audi A1	2011-2018	8X	47 Soundsystem	Measuring Blocks	
Audi A1	2011-2018	8X	47 Soundsystem	Output Tests	
Audi A1	2011-2018	8X	47 Soundsystem	Specia Functions	
Audi A1	2011-2018	8X	52 Passe.-Door Elect.	Read Fault Codes	
Audi A1	2011-2018	8X	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A1	2011-2018	8X	52 Passe.-Door Elect.	Measuring Blocks	
Audi A1	2011-2018	8X	52 Passe.-Door Elect.	Output Tests	
Audi A1	2011-2018	8X	52 Passe.-Door Elect.	Specia Functions	
Audi A1	2011-2018	8X	53 Parking Brake	Read Fault Codes	
Audi A1	2011-2018	8X	53 Parking Brake	Clear Fault Codes	
Audi A1	2011-2018	8X	53 Parking Brake	Measuring Blocks	
Audi A1	2011-2018	8X	53 Parking Brake	Output Tests	
Audi A1	2011-2018	8X	53 Parking Brake	Specia Functions	
Audi A1	2011-2018	8X	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A1	2011-2018	8X	55 Headlight Range Control	Clear Fault Codes	
Audi A1	2011-2018	8X	55 Headlight Range Control	Measuring Blocks	
Audi A1	2011-2018	8X	55 Headlight Range Control	Output Tests	
Audi A1	2011-2018	8X	55 Headlight Range Control	Specia Functions	
Audi A1	2011-2018	8X	56 Radio	Read Fault Codes	
Audi A1	2011-2018	8X	56 Radio	Clear Fault Codes	
Audi A1	2011-2018	8X	56 Radio	Measuring Blocks	
Audi A1	2011-2018	8X	56 Radio	Output Tests	
Audi A1	2011-2018	8X	56 Radio	Specia Functions	
Audi A1	2011-2018	8X	57 TV-Tuner	Read Fault Codes	
Audi A1	2011-2018	8X	57 TV-Tuner	Clear Fault Codes	
Audi A1	2011-2018	8X	57 TV-Tuner	Measuring Blocks	
Audi A1	2011-2018	8X	57 TV-Tuner	Output Tests	
Audi A1	2011-2018	8X	57 TV-Tuner	Specia Functions	
Audi A1	2011-2018	8X	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A1	2011-2018	8X	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A1	2011-2018	8X	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A1	2011-2018	8X	5F Information Electronic Equipment 1	Output Tests	
Audi A1	2011-2018	8X	5F Information Electronic Equipment 1	Specia Functions	
Audi A1	2011-2018	8X	62 LR-Door Electroni.	Read Fault Codes	
Audi A1	2011-2018	8X	62 LR-Door Electroni.	Clear Fault Codes	
Audi A1	2011-2018	8X	62 LR-Door Electroni.	Measuring Blocks	
Audi A1	2011-2018	8X	62 LR-Door Electroni.	Output Tests	
Audi A1	2011-2018	8X	62 LR-Door Electroni.	Specia Functions	
Audi A1	2011-2018	8X	69 Trailer Function	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A1	2011-2018	8X	69 Trailer Function	Clear Fault Codes	
Audi A1	2011-2018	8X	69 Trailer Function	Measuring Blocks	
Audi A1	2011-2018	8X	69 Trailer Function	Output Tests	
Audi A1	2011-2018	8X	69 Trailer Function	Specia Functions	
Audi A1	2011-2018	8X	6C Rear Camera	Read Fault Codes	
Audi A1	2011-2018	8X	6C Rear Camera	Clear Fault Codes	
Audi A1	2011-2018	8X	6C Rear Camera	Measuring Blocks	
Audi A1	2011-2018	8X	6C Rear Camera	Output Tests	
Audi A1	2011-2018	8X	6C Rear Camera	Specia Functions	
Audi A1	2011-2018	8X	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A1	2011-2018	8X	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A1	2011-2018	8X	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A1	2011-2018	8X	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A1	2011-2018	8X	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A1	2011-2018	8X	72 RR-Door Electroni.	Read Fault Codes	
Audi A1	2011-2018	8X	72 RR-Door Electroni.	Clear Fault Codes	
Audi A1	2011-2018	8X	72 RR-Door Electroni.	Measuring Blocks	
Audi A1	2011-2018	8X	72 RR-Door Electroni.	Output Tests	
Audi A1	2011-2018	8X	72 RR-Door Electroni.	Specia Functions	
Audi A1	2011-2018	8X	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A1	2011-2018	8X	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A1	2011-2018	8X	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A1	2011-2018	8X	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A1	2011-2018	8X	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A1	2011-2018	8X	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A1	2011-2018	8X	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A1	2011-2018	8X	A9 Struct.Borne Sound	Measuring Blocks	
Audi A1	2011-2018	8X	A9 Struct.Borne Sound	Output Tests	
Audi A1	2011-2018	8X	A9 Struct.Borne Sound	Specia Functions	
Audi A3	2008-2014	8J	01 Engine Electronics	Read Fault Codes	
Audi A3	2008-2014	8J	01 Engine Electronics	Clear Fault Codes	
Audi A3	2008-2014	8J	01 Engine Electronics	Measuring Blocks	
Audi A3	2008-2014	8J	01 Engine Electronics	Output Tests	
Audi A3	2008-2014	8J	01 Engine Electronics	Specia Functions	
Audi A3	2008-2014	8J	02 Transmission Electronics	Read Fault Codes	
Audi A3	2008-2014	8J	02 Transmission Electronics	Clear Fault Codes	
Audi A3	2008-2014	8J	02 Transmission Electronics	Measuring Blocks	
Audi A3	2008-2014	8J	02 Transmission Electronics	Output Tests	
Audi A3	2008-2014	8J	02 Transmission Electronics	Specia Functions	
Audi A3	2008-2014	8J	03 Brake Electronics	Read Fault Codes	
Audi A3	2008-2014	8J	03 Brake Electronics	Clear Fault Codes	
Audi A3	2008-2014	8J	03 Brake Electronics	Measuring Blocks	
Audi A3	2008-2014	8J	03 Brake Electronics	Output Tests	
Audi A3	2008-2014	8J	03 Brake Electronics	Specia Functions	
Audi A3	2008-2014	8J	08 AC/Heating Electronics	Read Fault Codes	
Audi A3	2008-2014	8J	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3	2008-2014	8J	08 AC/Heating Electronics	Measuring Blocks	
Audi A3	2008-2014	8J	08 AC/Heating Electronics	Output Tests	
Audi A3	2008-2014	8J	08 AC/Heating Electronics	Specia Functions	
Audi A3	2008-2014	8J	09 Electronic Ctrl Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3	2008-2014	8J	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3	2008-2014	8J	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3	2008-2014	8J	09 Electronic Ctrl Electronics	Output Tests	
Audi A3	2008-2014	8J	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3	2008-2014	8J	0E Media Player Position 1	Read Fault Codes	
Audi A3	2008-2014	8J	0E Media Player Position 1	Clear Fault Codes	
Audi A3	2008-2014	8J	0E Media Player Position 1	Measuring Blocks	
Audi A3	2008-2014	8J	0E Media Player Position 1	Output Tests	
Audi A3	2008-2014	8J	0E Media Player Position 1	Specia Functions	
Audi A3	2008-2014	8J	0F Radio Tuner-Digital	Read Fault Codes	
Audi A3	2008-2014	8J	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A3	2008-2014	8J	0F Radio Tuner-Digital	Measuring Blocks	
Audi A3	2008-2014	8J	0F Radio Tuner-Digital	Output Tests	
Audi A3	2008-2014	8J	0F Radio Tuner-Digital	Specia Functions	
Audi A3	2008-2014	8J	10 Parking Assist System 2	Read Fault Codes	
Audi A3	2008-2014	8J	10 Parking Assist System 2	Clear Fault Codes	
Audi A3	2008-2014	8J	10 Parking Assist System 2	Measuring Blocks	
Audi A3	2008-2014	8J	10 Parking Assist System 2	Output Tests	
Audi A3	2008-2014	8J	10 Parking Assist System 2	Specia Functions	
Audi A3	2008-2014	8J	11 Engine Electronics 2	Read Fault Codes	
Audi A3	2008-2014	8J	11 Engine Electronics 2	Clear Fault Codes	
Audi A3	2008-2014	8J	11 Engine Electronics 2	Measuring Blocks	
Audi A3	2008-2014	8J	11 Engine Electronics 2	Output Tests	
Audi A3	2008-2014	8J	11 Engine Electronics 2	Specia Functions	
Audi A3	2008-2014	8J	14 Wheel Damping Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008-2014	8J	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A3	2008-2014	8J	14 Wheel Damping Electronics	Measuring Blocks	
Audi A3	2008-2014	8J	14 Wheel Damping Electronics	Output Tests	
Audi A3	2008-2014	8J	14 Wheel Damping Electronics	Specia Functions	
Audi A3	2008-2014	8J	15 Airbags	Read Fault Codes	
Audi A3	2008-2014	8J	15 Airbags	Clear Fault Codes	
Audi A3	2008-2014	8J	15 Airbags	Measuring Blocks	
Audi A3	2008-2014	8J	15 Airbags	Output Tests	
Audi A3	2008-2014	8J	15 Airbags	Specia Functions	
Audi A3	2008-2014	8J	16 Steering Wheel Electronics	Read Fault Codes	
Audi A3	2008-2014	8J	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3	2008-2014	8J	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3	2008-2014	8J	16 Steering Wheel Electronics	Output Tests	
Audi A3	2008-2014	8J	16 Steering Wheel Electronics	Specia Functions	
Audi A3	2008-2014	8J	17 Instrument Cluster	Read Fault Codes	
Audi A3	2008-2014	8J	17 Instrument Cluster	Clear Fault Codes	
Audi A3	2008-2014	8J	17 Instrument Cluster	Measuring Blocks	
Audi A3	2008-2014	8J	17 Instrument Cluster	Output Tests	
Audi A3	2008-2014	8J	17 Instrument Cluster	Specia Functions	
Audi A3	2008-2014	8J	18 Aux Heating	Read Fault Codes	
Audi A3	2008-2014	8J	18 Aux Heating	Clear Fault Codes	
Audi A3	2008-2014	8J	18 Aux Heating	Measuring Blocks	
Audi A3	2008-2014	8J	18 Aux Heating	Output Tests	
Audi A3	2008-2014	8J	18 Aux Heating	Specia Functions	
Audi A3	2008-2014	8J	19 Gateway Data Bus	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008-2014	8J	19 Gateway Data Bus	Clear Fault Codes	
Audi A3	2008-2014	8J	19 Gateway Data Bus	Measuring Blocks	
Audi A3	2008-2014	8J	19 Gateway Data Bus	Output Tests	
Audi A3	2008-2014	8J	19 Gateway Data Bus	Specia Functions	
Audi A3	2008-2014	8J	20 High Beam Assistance Device	Read Fault Codes	
Audi A3	2008-2014	8J	20 High Beam Assistance Device	Clear Fault Codes	
Audi A3	2008-2014	8J	20 High Beam Assistance Device	Measuring Blocks	
Audi A3	2008-2014	8J	20 High Beam Assistance Device	Output Tests	
Audi A3	2008-2014	8J	20 High Beam Assistance Device	Specia Functions	
Audi A3	2008-2014	8J	22 4WD Electronics	Read Fault Codes	
Audi A3	2008-2014	8J	22 4WD Electronics	Clear Fault Codes	
Audi A3	2008-2014	8J	22 4WD Electronics	Measuring Blocks	
Audi A3	2008-2014	8J	22 4WD Electronics	Output Tests	
Audi A3	2008-2014	8J	22 4WD Electronics	Specia Functions	
Audi A3	2008-2014	8J	25 Immobilizer	Read Fault Codes	
Audi A3	2008-2014	8J	25 Immobilizer	Clear Fault Codes	
Audi A3	2008-2014	8J	25 Immobilizer	Measuring Blocks	
Audi A3	2008-2014	8J	25 Immobilizer	Output Tests	
Audi A3	2008-2014	8J	25 Immobilizer	Specia Functions	
Audi A3	2008-2014	8J	26 Electric Roof Control	Read Fault Codes	
Audi A3	2008-2014	8J	26 Electric Roof Control	Clear Fault Codes	
Audi A3	2008-2014	8J	26 Electric Roof Control	Measuring Blocks	
Audi A3	2008-2014	8J	26 Electric Roof Control	Output Tests	
Audi A3	2008-2014	8J	26 Electric Roof Control	Specia Functions	
Audi A3	2008-2014	8J	2E Media Player Position 3	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008-2014	8J	2E Media Player Position 3	Clear Fault Codes	
Audi A3	2008-2014	8J	2E Media Player Position 3	Measuring Blocks	
Audi A3	2008-2014	8J	2E Media Player Position 3	Output Tests	
Audi A3	2008-2014	8J	2E Media Player Position 3	Specia Functions	
Audi A3	2008-2014	8J	37 Navigation	Read Fault Codes	
Audi A3	2008-2014	8J	37 Navigation	Clear Fault Codes	
Audi A3	2008-2014	8J	37 Navigation	Measuring Blocks	
Audi A3	2008-2014	8J	37 Navigation	Output Tests	
Audi A3	2008-2014	8J	37 Navigation	Specia Functions	
Audi A3	2008-2014	8J	3D Special Function	Read Fault Codes	
Audi A3	2008-2014	8J	3D Special Function	Clear Fault Codes	
Audi A3	2008-2014	8J	3D Special Function	Measuring Blocks	
Audi A3	2008-2014	8J	3D Special Function	Output Tests	
Audi A3	2008-2014	8J	3D Special Function	Specia Functions	
Audi A3	2008-2014	8J	42 Driver-Door Elect.	Read Fault Codes	
Audi A3	2008-2014	8J	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3	2008-2014	8J	42 Driver-Door Elect.	Measuring Blocks	
Audi A3	2008-2014	8J	42 Driver-Door Elect.	Output Tests	
Audi A3	2008-2014	8J	42 Driver-Door Elect.	Specia Functions	
Audi A3	2008-2014	8J	44 Steering Assistance	Read Fault Codes	
Audi A3	2008-2014	8J	44 Steering Assistance	Clear Fault Codes	
Audi A3	2008-2014	8J	44 Steering Assistance	Measuring Blocks	
Audi A3	2008-2014	8J	44 Steering Assistance	Output Tests	
Audi A3	2008-2014	8J	44 Steering Assistance	Specia Functions	
Audi A3	2008-2014	8J	46 Central Control Module	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3	2008-2014	8J	46 Central Control Module	Clear Fault Codes	
Audi A3	2008-2014	8J	46 Central Control Module	Measuring Blocks	
Audi A3	2008-2014	8J	46 Central Control Module	Output Tests	
Audi A3	2008-2014	8J	46 Central Control Module	Specia Functions	
Audi A3	2008-2014	8J	47 Soundsystem	Read Fault Codes	
Audi A3	2008-2014	8J	47 Soundsystem	Clear Fault Codes	
Audi A3	2008-2014	8J	47 Soundsystem	Measuring Blocks	
Audi A3	2008-2014	8J	47 Soundsystem	Output Tests	
Audi A3	2008-2014	8J	47 Soundsystem	Specia Functions	
Audi A3	2008-2014	8J	4C Tyre Pressure Monitor II	Read Fault Codes	
Audi A3	2008-2014	8J	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi A3	2008-2014	8J	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi A3	2008-2014	8J	4C Tyre Pressure Monitor II	Output Tests	
Audi A3	2008-2014	8J	4C Tyre Pressure Monitor II	Specia Functions	
Audi A3	2008-2014	8J	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3	2008-2014	8J	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3	2008-2014	8J	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3	2008-2014	8J	52 Passe.-Door Elect.	Output Tests	
Audi A3	2008-2014	8J	52 Passe.-Door Elect.	Specia Functions	
Audi A3	2008-2014	8J	55 Headlight Range Control	Read Fault Codes	
Audi A3	2008-2014	8J	55 Headlight Range Control	Clear Fault Codes	
Audi A3	2008-2014	8J	55 Headlight Range Control	Measuring Blocks	
Audi A3	2008-2014	8J	55 Headlight Range Control	Output Tests	
Audi A3	2008-2014	8J	55 Headlight Range Control	Specia Functions	
Audi A3	2008-2014	8J	56 Radio	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008-2014	8J	56 Radio	Clear Fault Codes	
Audi A3	2008-2014	8J	56 Radio	Measuring Blocks	
Audi A3	2008-2014	8J	56 Radio	Output Tests	
Audi A3	2008-2014	8J	56 Radio	Specia Functions	
Audi A3	2008-2014	8J	57 TV-Tuner	Read Fault Codes	
Audi A3	2008-2014	8J	57 TV-Tuner	Clear Fault Codes	
Audi A3	2008-2014	8J	57 TV-Tuner	Measuring Blocks	
Audi A3	2008-2014	8J	57 TV-Tuner	Output Tests	
Audi A3	2008-2014	8J	57 TV-Tuner	Specia Functions	
Audi A3	2008-2014	8J	61 Battery Control	Read Fault Codes	
Audi A3	2008-2014	8J	61 Battery Control	Clear Fault Codes	
Audi A3	2008-2014	8J	61 Battery Control	Measuring Blocks	
Audi A3	2008-2014	8J	61 Battery Control	Output Tests	
Audi A3	2008-2014	8J	61 Battery Control	Specia Functions	
Audi A3	2008-2014	8J	62 LR-Door Electroni.	Read Fault Codes	
Audi A3	2008-2014	8J	62 LR-Door Electroni.	Clear Fault Codes	
Audi A3	2008-2014	8J	62 LR-Door Electroni.	Measuring Blocks	
Audi A3	2008-2014	8J	62 LR-Door Electroni.	Output Tests	
Audi A3	2008-2014	8J	62 LR-Door Electroni.	Specia Functions	
Audi A3	2008-2014	8J	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A3	2008-2014	8J	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A3	2008-2014	8J	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A3	2008-2014	8J	65 Tyre Pressure Monitoring	Output Tests	
Audi A3	2008-2014	8J	65 Tyre Pressure Monitoring	Specia Functions	
Audi A3	2008-2014	8J	69 Trailer Function	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3	2008-2014	8J	69 Trailer Function	Clear Fault Codes	
Audi A3	2008-2014	8J	69 Trailer Function	Measuring Blocks	
Audi A3	2008-2014	8J	69 Trailer Function	Output Tests	
Audi A3	2008-2014	8J	69 Trailer Function	Specia Functions	
Audi A3	2008-2014	8J	6C Rear Camera	Read Fault Codes	
Audi A3	2008-2014	8J	6C Rear Camera	Clear Fault Codes	
Audi A3	2008-2014	8J	6C Rear Camera	Measuring Blocks	
Audi A3	2008-2014	8J	6C Rear Camera	Output Tests	
Audi A3	2008-2014	8J	6C Rear Camera	Specia Functions	
Audi A3	2008-2014	8J	72 RR-Door Electroni.	Read Fault Codes	
Audi A3	2008-2014	8J	72 RR-Door Electroni.	Clear Fault Codes	
Audi A3	2008-2014	8J	72 RR-Door Electroni.	Measuring Blocks	
Audi A3	2008-2014	8J	72 RR-Door Electroni.	Output Tests	
Audi A3	2008-2014	8J	72 RR-Door Electroni.	Specia Functions	
Audi A3	2008-2014	8J	76 Parking Aid	Read Fault Codes	
Audi A3	2008-2014	8J	76 Parking Aid	Clear Fault Codes	
Audi A3	2008-2014	8J	76 Parking Aid	Measuring Blocks	
Audi A3	2008-2014	8J	76 Parking Aid	Output Tests	
Audi A3	2008-2014	8J	76 Parking Aid	Specia Functions	
Audi A3	2008-2014	8J	77 Telephone	Read Fault Codes	
Audi A3	2008-2014	8J	77 Telephone	Clear Fault Codes	
Audi A3	2008-2014	8J	77 Telephone	Measuring Blocks	
Audi A3	2008-2014	8J	77 Telephone	Output Tests	
Audi A3	2008-2014	8J	77 Telephone	Specia Functions	
Audi A3	2008-2014	8J	7D Auxiliary Heater	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008-2014	8J	7D Auxiliary Heater	Clear Fault Codes	
Audi A3	2008-2014	8J	7D Auxiliary Heater	Measuring Blocks	
Audi A3	2008-2014	8J	7D Auxiliary Heater	Output Tests	
Audi A3	2008-2014	8J	7D Auxiliary Heater	Specia Functions	
Audi A3	2008-2014	8J	A6 Microphone	Read Fault Codes	
Audi A3	2008-2014	8J	A6 Microphone	Clear Fault Codes	
Audi A3	2008-2014	8J	A6 Microphone	Measuring Blocks	
Audi A3	2008-2014	8J	A6 Microphone	Output Tests	
Audi A3	2008-2014	8J	A6 Microphone	Specia Functions	
Audi S3	2008-2014	8J	01 Engine Electronics	Read Fault Codes	
Audi S3	2008-2014	8J	01 Engine Electronics	Clear Fault Codes	
Audi S3	2008-2014	8J	01 Engine Electronics	Measuring Blocks	
Audi S3	2008-2014	8J	01 Engine Electronics	Output Tests	
Audi S3	2008-2014	8J	01 Engine Electronics	Specia Functions	
Audi S3	2008-2014	8J	02 Transmission Electronics	Read Fault Codes	
Audi S3	2008-2014	8J	02 Transmission Electronics	Clear Fault Codes	
Audi S3	2008-2014	8J	02 Transmission Electronics	Measuring Blocks	
Audi S3	2008-2014	8J	02 Transmission Electronics	Output Tests	
Audi S3	2008-2014	8J	02 Transmission Electronics	Specia Functions	
Audi S3	2008-2014	8J	03 Brake Electronics	Read Fault Codes	
Audi S3	2008-2014	8J	03 Brake Electronics	Clear Fault Codes	
Audi S3	2008-2014	8J	03 Brake Electronics	Measuring Blocks	
Audi S3	2008-2014	8J	03 Brake Electronics	Output Tests	
Audi S3	2008-2014	8J	03 Brake Electronics	Specia Functions	
Audi S3	2008-2014	8J	08 AC/Heating Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S3	2008-2014	8J	08 AC/Heating Electronics	Clear Fault Codes	
Audi S3	2008-2014	8J	08 AC/Heating Electronics	Measuring Blocks	
Audi S3	2008-2014	8J	08 AC/Heating Electronics	Output Tests	
Audi S3	2008-2014	8J	08 AC/Heating Electronics	Specia Functions	
Audi S3	2008-2014	8J	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S3	2008-2014	8J	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S3	2008-2014	8J	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S3	2008-2014	8J	09 Electronic Ctrl Electronics	Output Tests	
Audi S3	2008-2014	8J	09 Electronic Ctrl Electronics	Specia Functions	
Audi S3	2008-2014	8J	0E Media Player Position 1	Read Fault Codes	
Audi S3	2008-2014	8J	0E Media Player Position 1	Clear Fault Codes	
Audi S3	2008-2014	8J	0E Media Player Position 1	Measuring Blocks	
Audi S3	2008-2014	8J	0E Media Player Position 1	Output Tests	
Audi S3	2008-2014	8J	0E Media Player Position 1	Specia Functions	
Audi S3	2008-2014	8J	0F Radio Tuner-Digital	Read Fault Codes	
Audi S3	2008-2014	8J	0F Radio Tuner-Digital	Clear Fault Codes	
Audi S3	2008-2014	8J	0F Radio Tuner-Digital	Measuring Blocks	
Audi S3	2008-2014	8J	0F Radio Tuner-Digital	Output Tests	
Audi S3	2008-2014	8J	0F Radio Tuner-Digital	Specia Functions	
Audi S3	2008-2014	8J	10 Parking Assist System 2	Read Fault Codes	
Audi S3	2008-2014	8J	10 Parking Assist System 2	Clear Fault Codes	
Audi S3	2008-2014	8J	10 Parking Assist System 2	Measuring Blocks	
Audi S3	2008-2014	8J	10 Parking Assist System 2	Output Tests	
Audi S3	2008-2014	8J	10 Parking Assist System 2	Specia Functions	
Audi S3	2008-2014	8J	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2008-2014	8J	11 Engine Electronics 2	Clear Fault Codes	
Audi S3	2008-2014	8J	11 Engine Electronics 2	Measuring Blocks	
Audi S3	2008-2014	8J	11 Engine Electronics 2	Output Tests	
Audi S3	2008-2014	8J	11 Engine Electronics 2	Specia Functions	
Audi S3	2008-2014	8J	14 Wheel Damping Electronics	Read Fault Codes	
Audi S3	2008-2014	8J	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S3	2008-2014	8J	14 Wheel Damping Electronics	Measuring Blocks	
Audi S3	2008-2014	8J	14 Wheel Damping Electronics	Output Tests	
Audi S3	2008-2014	8J	14 Wheel Damping Electronics	Specia Functions	
Audi S3	2008-2014	8J	15 Airbags	Read Fault Codes	
Audi S3	2008-2014	8J	15 Airbags	Clear Fault Codes	
Audi S3	2008-2014	8J	15 Airbags	Measuring Blocks	
Audi S3	2008-2014	8J	15 Airbags	Output Tests	
Audi S3	2008-2014	8J	15 Airbags	Specia Functions	
Audi S3	2008-2014	8J	16 Steering Wheel Electronics	Read Fault Codes	
Audi S3	2008-2014	8J	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S3	2008-2014	8J	16 Steering Wheel Electronics	Measuring Blocks	
Audi S3	2008-2014	8J	16 Steering Wheel Electronics	Output Tests	
Audi S3	2008-2014	8J	16 Steering Wheel Electronics	Specia Functions	
Audi S3	2008-2014	8J	17 Instrument Cluster	Read Fault Codes	
Audi S3	2008-2014	8J	17 Instrument Cluster	Clear Fault Codes	
Audi S3	2008-2014	8J	17 Instrument Cluster	Measuring Blocks	
Audi S3	2008-2014	8J	17 Instrument Cluster	Output Tests	
Audi S3	2008-2014	8J	17 Instrument Cluster	Specia Functions	
Audi S3	2008-2014	8J	18 Aux Heating	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2008-2014	8J	18 Aux Heating	Clear Fault Codes	
Audi S3	2008-2014	8J	18 Aux Heating	Measuring Blocks	
Audi S3	2008-2014	8J	18 Aux Heating	Output Tests	
Audi S3	2008-2014	8J	18 Aux Heating	Specia Functions	
Audi S3	2008-2014	8J	19 Gateway Data Bus	Read Fault Codes	
Audi S3	2008-2014	8J	19 Gateway Data Bus	Clear Fault Codes	
Audi S3	2008-2014	8J	19 Gateway Data Bus	Measuring Blocks	
Audi S3	2008-2014	8J	19 Gateway Data Bus	Output Tests	
Audi S3	2008-2014	8J	19 Gateway Data Bus	Specia Functions	
Audi S3	2008-2014	8J	20 High Beam Assistance Device	Read Fault Codes	
Audi S3	2008-2014	8J	20 High Beam Assistance Device	Clear Fault Codes	
Audi S3	2008-2014	8J	20 High Beam Assistance Device	Measuring Blocks	
Audi S3	2008-2014	8J	20 High Beam Assistance Device	Output Tests	
Audi S3	2008-2014	8J	20 High Beam Assistance Device	Specia Functions	
Audi S3	2008-2014	8J	22 4WD Electronics	Read Fault Codes	
Audi S3	2008-2014	8J	22 4WD Electronics	Clear Fault Codes	
Audi S3	2008-2014	8J	22 4WD Electronics	Measuring Blocks	
Audi S3	2008-2014	8J	22 4WD Electronics	Output Tests	
Audi S3	2008-2014	8J	22 4WD Electronics	Specia Functions	
Audi S3	2008-2014	8J	25 Immobilizer	Read Fault Codes	
Audi S3	2008-2014	8J	25 Immobilizer	Clear Fault Codes	
Audi S3	2008-2014	8J	25 Immobilizer	Measuring Blocks	
Audi S3	2008-2014	8J	25 Immobilizer	Output Tests	
Audi S3	2008-2014	8J	25 Immobilizer	Specia Functions	
Audi S3	2008-2014	8J	26 Electric Roof Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2008-2014	8J	26 Electric Roof Control	Clear Fault Codes	
Audi S3	2008-2014	8J	26 Electric Roof Control	Measuring Blocks	
Audi S3	2008-2014	8J	26 Electric Roof Control	Output Tests	
Audi S3	2008-2014	8J	26 Electric Roof Control	Specia Functions	
Audi S3	2008-2014	8J	2E Media Player Position 3	Read Fault Codes	
Audi S3	2008-2014	8J	2E Media Player Position 3	Clear Fault Codes	
Audi S3	2008-2014	8J	2E Media Player Position 3	Measuring Blocks	
Audi S3	2008-2014	8J	2E Media Player Position 3	Output Tests	
Audi S3	2008-2014	8J	2E Media Player Position 3	Specia Functions	
Audi S3	2008-2014	8J	37 Navigation	Read Fault Codes	
Audi S3	2008-2014	8J	37 Navigation	Clear Fault Codes	
Audi S3	2008-2014	8J	37 Navigation	Measuring Blocks	
Audi S3	2008-2014	8J	37 Navigation	Output Tests	
Audi S3	2008-2014	8J	37 Navigation	Specia Functions	
Audi S3	2008-2014	8J	3D Special Function	Read Fault Codes	
Audi S3	2008-2014	8J	3D Special Function	Clear Fault Codes	
Audi S3	2008-2014	8J	3D Special Function	Measuring Blocks	
Audi S3	2008-2014	8J	3D Special Function	Output Tests	
Audi S3	2008-2014	8J	3D Special Function	Specia Functions	
Audi S3	2008-2014	8J	42 Driver-Door Elect.	Read Fault Codes	
Audi S3	2008-2014	8J	42 Driver-Door Elect.	Clear Fault Codes	
Audi S3	2008-2014	8J	42 Driver-Door Elect.	Measuring Blocks	
Audi S3	2008-2014	8J	42 Driver-Door Elect.	Output Tests	
Audi S3	2008-2014	8J	42 Driver-Door Elect.	Specia Functions	
Audi S3	2008-2014	8J	44 Steering Assistance	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2008-2014	8J	44 Steering Assistance	Clear Fault Codes	
Audi S3	2008-2014	8J	44 Steering Assistance	Measuring Blocks	
Audi S3	2008-2014	8J	44 Steering Assistance	Output Tests	
Audi S3	2008-2014	8J	44 Steering Assistance	Specia Functions	
Audi S3	2008-2014	8J	46 Central Control Module	Read Fault Codes	
Audi S3	2008-2014	8J	46 Central Control Module	Clear Fault Codes	
Audi S3	2008-2014	8J	46 Central Control Module	Measuring Blocks	
Audi S3	2008-2014	8J	46 Central Control Module	Output Tests	
Audi S3	2008-2014	8J	46 Central Control Module	Specia Functions	
Audi S3	2008-2014	8J	47 Soundsystem	Read Fault Codes	
Audi S3	2008-2014	8J	47 Soundsystem	Clear Fault Codes	
Audi S3	2008-2014	8J	47 Soundsystem	Measuring Blocks	
Audi S3	2008-2014	8J	47 Soundsystem	Output Tests	
Audi S3	2008-2014	8J	47 Soundsystem	Specia Functions	
Audi S3	2008-2014	8J	4C Tyre Pressure Monitor II	Read Fault Codes	
Audi S3	2008-2014	8J	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi S3	2008-2014	8J	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi S3	2008-2014	8J	4C Tyre Pressure Monitor II	Output Tests	
Audi S3	2008-2014	8J	4C Tyre Pressure Monitor II	Specia Functions	
Audi S3	2008-2014	8J	52 Passe.-Door Elect.	Read Fault Codes	
Audi S3	2008-2014	8J	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S3	2008-2014	8J	52 Passe.-Door Elect.	Measuring Blocks	
Audi S3	2008-2014	8J	52 Passe.-Door Elect.	Output Tests	
Audi S3	2008-2014	8J	52 Passe.-Door Elect.	Specia Functions	
Audi S3	2008-2014	8J	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2008-2014	8J	55 Headlight Range Control	Clear Fault Codes	
Audi S3	2008-2014	8J	55 Headlight Range Control	Measuring Blocks	
Audi S3	2008-2014	8J	55 Headlight Range Control	Output Tests	
Audi S3	2008-2014	8J	55 Headlight Range Control	Specia Functions	
Audi S3	2008-2014	8J	56 Radio	Read Fault Codes	
Audi S3	2008-2014	8J	56 Radio	Clear Fault Codes	
Audi S3	2008-2014	8J	56 Radio	Measuring Blocks	
Audi S3	2008-2014	8J	56 Radio	Output Tests	
Audi S3	2008-2014	8J	56 Radio	Specia Functions	
Audi S3	2008-2014	8J	57 TV-Tuner	Read Fault Codes	
Audi S3	2008-2014	8J	57 TV-Tuner	Clear Fault Codes	
Audi S3	2008-2014	8J	57 TV-Tuner	Measuring Blocks	
Audi S3	2008-2014	8J	57 TV-Tuner	Output Tests	
Audi S3	2008-2014	8J	57 TV-Tuner	Specia Functions	
Audi S3	2008-2014	8J	61 Battery Control	Read Fault Codes	
Audi S3	2008-2014	8J	61 Battery Control	Clear Fault Codes	
Audi S3	2008-2014	8J	61 Battery Control	Measuring Blocks	
Audi S3	2008-2014	8J	61 Battery Control	Output Tests	
Audi S3	2008-2014	8J	61 Battery Control	Specia Functions	
Audi S3	2008-2014	8J	62 LR-Door Electroni.	Read Fault Codes	
Audi S3	2008-2014	8J	62 LR-Door Electroni.	Clear Fault Codes	
Audi S3	2008-2014	8J	62 LR-Door Electroni.	Measuring Blocks	
Audi S3	2008-2014	8J	62 LR-Door Electroni.	Output Tests	
Audi S3	2008-2014	8J	62 LR-Door Electroni.	Specia Functions	
Audi S3	2008-2014	8J	65 Tyre Pressure Monitoring	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S3	2008-2014	8J	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S3	2008-2014	8J	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S3	2008-2014	8J	65 Tyre Pressure Monitoring	Output Tests	
Audi S3	2008-2014	8J	65 Tyre Pressure Monitoring	Specia Functions	
Audi S3	2008-2014	8J	69 Trailer Function	Read Fault Codes	
Audi S3	2008-2014	8J	69 Trailer Function	Clear Fault Codes	
Audi S3	2008-2014	8J	69 Trailer Function	Measuring Blocks	
Audi S3	2008-2014	8J	69 Trailer Function	Output Tests	
Audi S3	2008-2014	8J	69 Trailer Function	Specia Functions	
Audi S3	2008-2014	8J	6C Rear Camera	Read Fault Codes	
Audi S3	2008-2014	8J	6C Rear Camera	Clear Fault Codes	
Audi S3	2008-2014	8J	6C Rear Camera	Measuring Blocks	
Audi S3	2008-2014	8J	6C Rear Camera	Output Tests	
Audi S3	2008-2014	8J	6C Rear Camera	Specia Functions	
Audi S3	2008-2014	8J	72 RR-Door Electroni.	Read Fault Codes	
Audi S3	2008-2014	8J	72 RR-Door Electroni.	Clear Fault Codes	
Audi S3	2008-2014	8J	72 RR-Door Electroni.	Measuring Blocks	
Audi S3	2008-2014	8J	72 RR-Door Electroni.	Output Tests	
Audi S3	2008-2014	8J	72 RR-Door Electroni.	Specia Functions	
Audi S3	2008-2014	8J	76 Parking Aid	Read Fault Codes	
Audi S3	2008-2014	8J	76 Parking Aid	Clear Fault Codes	
Audi S3	2008-2014	8J	76 Parking Aid	Measuring Blocks	
Audi S3	2008-2014	8J	76 Parking Aid	Output Tests	
Audi S3	2008-2014	8J	76 Parking Aid	Specia Functions	
Audi S3	2008-2014	8J	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2008-2014	8J	77 Telephone	Clear Fault Codes	
Audi S3	2008-2014	8J	77 Telephone	Measuring Blocks	
Audi S3	2008-2014	8J	77 Telephone	Output Tests	
Audi S3	2008-2014	8J	77 Telephone	Specia Functions	
Audi S3	2008-2014	8J	7D Auxiliary Heater	Read Fault Codes	
Audi S3	2008-2014	8J	7D Auxiliary Heater	Clear Fault Codes	
Audi S3	2008-2014	8J	7D Auxiliary Heater	Measuring Blocks	
Audi S3	2008-2014	8J	7D Auxiliary Heater	Output Tests	
Audi S3	2008-2014	8J	7D Auxiliary Heater	Specia Functions	
Audi S3	2008-2014	8J	A6 Microphone	Read Fault Codes	
Audi S3	2008-2014	8J	A6 Microphone	Clear Fault Codes	
Audi S3	2008-2014	8J	A6 Microphone	Measuring Blocks	
Audi S3	2008-2014	8J	A6 Microphone	Output Tests	
Audi S3	2008-2014	8J	A6 Microphone	Specia Functions	
Audi RS3	2008-2014	8J	01 Engine Electronics	Read Fault Codes	
Audi RS3	2008-2014	8J	01 Engine Electronics	Clear Fault Codes	
Audi RS3	2008-2014	8J	01 Engine Electronics	Measuring Blocks	
Audi RS3	2008-2014	8J	01 Engine Electronics	Output Tests	
Audi RS3	2008-2014	8J	01 Engine Electronics	Specia Functions	
Audi RS3	2008-2014	8J	02 Transmission Electronics	Read Fault Codes	
Audi RS3	2008-2014	8J	02 Transmission Electronics	Clear Fault Codes	
Audi RS3	2008-2014	8J	02 Transmission Electronics	Measuring Blocks	
Audi RS3	2008-2014	8J	02 Transmission Electronics	Output Tests	
Audi RS3	2008-2014	8J	02 Transmission Electronics	Specia Functions	
Audi RS3	2008-2014	8J	03 Brake Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS3	2008-2014	8J	03 Brake Electronics	Clear Fault Codes	
Audi RS3	2008-2014	8J	03 Brake Electronics	Measuring Blocks	
Audi RS3	2008-2014	8J	03 Brake Electronics	Output Tests	
Audi RS3	2008-2014	8J	03 Brake Electronics	Specia Functions	
Audi RS3	2008-2014	8J	08 AC/Heating Electronics	Read Fault Codes	
Audi RS3	2008-2014	8J	08 AC/Heating Electronics	Clear Fault Codes	
Audi RS3	2008-2014	8J	08 AC/Heating Electronics	Measuring Blocks	
Audi RS3	2008-2014	8J	08 AC/Heating Electronics	Output Tests	
Audi RS3	2008-2014	8J	08 AC/Heating Electronics	Specia Functions	
Audi RS3	2008-2014	8J	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi RS3	2008-2014	8J	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi RS3	2008-2014	8J	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi RS3	2008-2014	8J	09 Electronic Ctrl Electronics	Output Tests	
Audi RS3	2008-2014	8J	09 Electronic Ctrl Electronics	Specia Functions	
Audi RS3	2008-2014	8J	0E Media Player Position 1	Read Fault Codes	
Audi RS3	2008-2014	8J	0E Media Player Position 1	Clear Fault Codes	
Audi RS3	2008-2014	8J	0E Media Player Position 1	Measuring Blocks	
Audi RS3	2008-2014	8J	0E Media Player Position 1	Output Tests	
Audi RS3	2008-2014	8J	0E Media Player Position 1	Specia Functions	
Audi RS3	2008-2014	8J	0F Radio Tuner-Digital	Read Fault Codes	
Audi RS3	2008-2014	8J	0F Radio Tuner-Digital	Clear Fault Codes	
Audi RS3	2008-2014	8J	0F Radio Tuner-Digital	Measuring Blocks	
Audi RS3	2008-2014	8J	0F Radio Tuner-Digital	Output Tests	
Audi RS3	2008-2014	8J	0F Radio Tuner-Digital	Specia Functions	
Audi RS3	2008-2014	8J	10 Parking Assist System 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS3	2008-2014	8J	10 Parking Assist System 2	Clear Fault Codes	
Audi RS3	2008-2014	8J	10 Parking Assist System 2	Measuring Blocks	
Audi RS3	2008-2014	8J	10 Parking Assist System 2	Output Tests	
Audi RS3	2008-2014	8J	10 Parking Assist System 2	Specia Functions	
Audi RS3	2008-2014	8J	11 Engine Electronics 2	Read Fault Codes	
Audi RS3	2008-2014	8J	11 Engine Electronics 2	Clear Fault Codes	
Audi RS3	2008-2014	8J	11 Engine Electronics 2	Measuring Blocks	
Audi RS3	2008-2014	8J	11 Engine Electronics 2	Output Tests	
Audi RS3	2008-2014	8J	11 Engine Electronics 2	Specia Functions	
Audi RS3	2008-2014	8J	14 Wheel Damping Electronics	Read Fault Codes	
Audi RS3	2008-2014	8J	14 Wheel Damping Electronics	Clear Fault Codes	
Audi RS3	2008-2014	8J	14 Wheel Damping Electronics	Measuring Blocks	
Audi RS3	2008-2014	8J	14 Wheel Damping Electronics	Output Tests	
Audi RS3	2008-2014	8J	14 Wheel Damping Electronics	Specia Functions	
Audi RS3	2008-2014	8J	15 Airbags	Read Fault Codes	
Audi RS3	2008-2014	8J	15 Airbags	Clear Fault Codes	
Audi RS3	2008-2014	8J	15 Airbags	Measuring Blocks	
Audi RS3	2008-2014	8J	15 Airbags	Output Tests	
Audi RS3	2008-2014	8J	15 Airbags	Specia Functions	
Audi RS3	2008-2014	8J	16 Steering Wheel Electronics	Read Fault Codes	
Audi RS3	2008-2014	8J	16 Steering Wheel Electronics	Clear Fault Codes	
Audi RS3	2008-2014	8J	16 Steering Wheel Electronics	Measuring Blocks	
Audi RS3	2008-2014	8J	16 Steering Wheel Electronics	Output Tests	
Audi RS3	2008-2014	8J	16 Steering Wheel Electronics	Specia Functions	
Audi RS3	2008-2014	8J	17 Instrument Cluster	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS3	2008-2014	8J	17 Instrument Cluster	Clear Fault Codes	
Audi RS3	2008-2014	8J	17 Instrument Cluster	Measuring Blocks	
Audi RS3	2008-2014	8J	17 Instrument Cluster	Output Tests	
Audi RS3	2008-2014	8J	17 Instrument Cluster	Specia Functions	
Audi RS3	2008-2014	8J	18 Aux Heating	Read Fault Codes	
Audi RS3	2008-2014	8J	18 Aux Heating	Clear Fault Codes	
Audi RS3	2008-2014	8J	18 Aux Heating	Measuring Blocks	
Audi RS3	2008-2014	8J	18 Aux Heating	Output Tests	
Audi RS3	2008-2014	8J	18 Aux Heating	Specia Functions	
Audi RS3	2008-2014	8J	19 Gateway Data Bus	Read Fault Codes	
Audi RS3	2008-2014	8J	19 Gateway Data Bus	Clear Fault Codes	
Audi RS3	2008-2014	8J	19 Gateway Data Bus	Measuring Blocks	
Audi RS3	2008-2014	8J	19 Gateway Data Bus	Output Tests	
Audi RS3	2008-2014	8J	19 Gateway Data Bus	Specia Functions	
Audi RS3	2008-2014	8J	20 High Beam Assistance Device	Read Fault Codes	
Audi RS3	2008-2014	8J	20 High Beam Assistance Device	Clear Fault Codes	
Audi RS3	2008-2014	8J	20 High Beam Assistance Device	Measuring Blocks	
Audi RS3	2008-2014	8J	20 High Beam Assistance Device	Output Tests	
Audi RS3	2008-2014	8J	20 High Beam Assistance Device	Specia Functions	
Audi RS3	2008-2014	8J	22 4WD Electronics	Read Fault Codes	
Audi RS3	2008-2014	8J	22 4WD Electronics	Clear Fault Codes	
Audi RS3	2008-2014	8J	22 4WD Electronics	Measuring Blocks	
Audi RS3	2008-2014	8J	22 4WD Electronics	Output Tests	
Audi RS3	2008-2014	8J	22 4WD Electronics	Specia Functions	
Audi RS3	2008-2014	8J	25 Immobilizer	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS3	2008-2014	8J	25 Immobilizer	Clear Fault Codes	
Audi RS3	2008-2014	8J	25 Immobilizer	Measuring Blocks	
Audi RS3	2008-2014	8J	25 Immobilizer	Output Tests	
Audi RS3	2008-2014	8J	25 Immobilizer	Specia Functions	
Audi RS3	2008-2014	8J	26 Electric Roof Control	Read Fault Codes	
Audi RS3	2008-2014	8J	26 Electric Roof Control	Clear Fault Codes	
Audi RS3	2008-2014	8J	26 Electric Roof Control	Measuring Blocks	
Audi RS3	2008-2014	8J	26 Electric Roof Control	Output Tests	
Audi RS3	2008-2014	8J	26 Electric Roof Control	Specia Functions	
Audi RS3	2008-2014	8J	2E Media Player Position 3	Read Fault Codes	
Audi RS3	2008-2014	8J	2E Media Player Position 3	Clear Fault Codes	
Audi RS3	2008-2014	8J	2E Media Player Position 3	Measuring Blocks	
Audi RS3	2008-2014	8J	2E Media Player Position 3	Output Tests	
Audi RS3	2008-2014	8J	2E Media Player Position 3	Specia Functions	
Audi RS3	2008-2014	8J	37 Navigation	Read Fault Codes	
Audi RS3	2008-2014	8J	37 Navigation	Clear Fault Codes	
Audi RS3	2008-2014	8J	37 Navigation	Measuring Blocks	
Audi RS3	2008-2014	8J	37 Navigation	Output Tests	
Audi RS3	2008-2014	8J	37 Navigation	Specia Functions	
Audi RS3	2008-2014	8J	3D Special Function	Read Fault Codes	
Audi RS3	2008-2014	8J	3D Special Function	Clear Fault Codes	
Audi RS3	2008-2014	8J	3D Special Function	Measuring Blocks	
Audi RS3	2008-2014	8J	3D Special Function	Output Tests	
Audi RS3	2008-2014	8J	3D Special Function	Specia Functions	
Audi RS3	2008-2014	8J	42 Driver-Door Elect.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS3	2008-2014	8J	42 Driver-Door Elect.	Clear Fault Codes	
Audi RS3	2008-2014	8J	42 Driver-Door Elect.	Measuring Blocks	
Audi RS3	2008-2014	8J	42 Driver-Door Elect.	Output Tests	
Audi RS3	2008-2014	8J	42 Driver-Door Elect.	Specia Functions	
Audi RS3	2008-2014	8J	44 Steering Assistance	Read Fault Codes	
Audi RS3	2008-2014	8J	44 Steering Assistance	Clear Fault Codes	
Audi RS3	2008-2014	8J	44 Steering Assistance	Measuring Blocks	
Audi RS3	2008-2014	8J	44 Steering Assistance	Output Tests	
Audi RS3	2008-2014	8J	44 Steering Assistance	Specia Functions	
Audi RS3	2008-2014	8J	46 Central Control Module	Read Fault Codes	
Audi RS3	2008-2014	8J	46 Central Control Module	Clear Fault Codes	
Audi RS3	2008-2014	8J	46 Central Control Module	Measuring Blocks	
Audi RS3	2008-2014	8J	46 Central Control Module	Output Tests	
Audi RS3	2008-2014	8J	46 Central Control Module	Specia Functions	
Audi RS3	2008-2014	8J	47 Soundsystem	Read Fault Codes	
Audi RS3	2008-2014	8J	47 Soundsystem	Clear Fault Codes	
Audi RS3	2008-2014	8J	47 Soundsystem	Measuring Blocks	
Audi RS3	2008-2014	8J	47 Soundsystem	Output Tests	
Audi RS3	2008-2014	8J	47 Soundsystem	Specia Functions	
Audi RS3	2008-2014	8J	4C Tyre Pressure Monitor II	Read Fault Codes	
Audi RS3	2008-2014	8J	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi RS3	2008-2014	8J	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi RS3	2008-2014	8J	4C Tyre Pressure Monitor II	Output Tests	
Audi RS3	2008-2014	8J	4C Tyre Pressure Monitor II	Specia Functions	
Audi RS3	2008-2014	8J	52 Passe.-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS3	2008-2014	8J	52 Passe.-Door Elect.	Clear Fault Codes	
Audi RS3	2008-2014	8J	52 Passe.-Door Elect.	Measuring Blocks	
Audi RS3	2008-2014	8J	52 Passe.-Door Elect.	Output Tests	
Audi RS3	2008-2014	8J	52 Passe.-Door Elect.	Specia Functions	
Audi RS3	2008-2014	8J	55 Headlight Range Control	Read Fault Codes	
Audi RS3	2008-2014	8J	55 Headlight Range Control	Clear Fault Codes	
Audi RS3	2008-2014	8J	55 Headlight Range Control	Measuring Blocks	
Audi RS3	2008-2014	8J	55 Headlight Range Control	Output Tests	
Audi RS3	2008-2014	8J	55 Headlight Range Control	Specia Functions	
Audi RS3	2008-2014	8J	56 Radio	Read Fault Codes	
Audi RS3	2008-2014	8J	56 Radio	Clear Fault Codes	
Audi RS3	2008-2014	8J	56 Radio	Measuring Blocks	
Audi RS3	2008-2014	8J	56 Radio	Output Tests	
Audi RS3	2008-2014	8J	56 Radio	Specia Functions	
Audi RS3	2008-2014	8J	57 TV-Tuner	Read Fault Codes	
Audi RS3	2008-2014	8J	57 TV-Tuner	Clear Fault Codes	
Audi RS3	2008-2014	8J	57 TV-Tuner	Measuring Blocks	
Audi RS3	2008-2014	8J	57 TV-Tuner	Output Tests	
Audi RS3	2008-2014	8J	57 TV-Tuner	Specia Functions	
Audi RS3	2008-2014	8J	61 Battery Control	Read Fault Codes	
Audi RS3	2008-2014	8J	61 Battery Control	Clear Fault Codes	
Audi RS3	2008-2014	8J	61 Battery Control	Measuring Blocks	
Audi RS3	2008-2014	8J	61 Battery Control	Output Tests	
Audi RS3	2008-2014	8J	61 Battery Control	Specia Functions	
Audi RS3	2008-2014	8J	62 LR-Door Electroni.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS3	2008-2014	8J	62 LR-Door Electroni.	Clear Fault Codes	
Audi RS3	2008-2014	8J	62 LR-Door Electroni.	Measuring Blocks	
Audi RS3	2008-2014	8J	62 LR-Door Electroni.	Output Tests	
Audi RS3	2008-2014	8J	62 LR-Door Electroni.	Specia Functions	
Audi RS3	2008-2014	8J	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi RS3	2008-2014	8J	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi RS3	2008-2014	8J	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi RS3	2008-2014	8J	65 Tyre Pressure Monitoring	Output Tests	
Audi RS3	2008-2014	8J	65 Tyre Pressure Monitoring	Specia Functions	
Audi RS3	2008-2014	8J	69 Trailer Function	Read Fault Codes	
Audi RS3	2008-2014	8J	69 Trailer Function	Clear Fault Codes	
Audi RS3	2008-2014	8J	69 Trailer Function	Measuring Blocks	
Audi RS3	2008-2014	8J	69 Trailer Function	Output Tests	
Audi RS3	2008-2014	8J	69 Trailer Function	Specia Functions	
Audi RS3	2008-2014	8J	6C Rear Camera	Read Fault Codes	
Audi RS3	2008-2014	8J	6C Rear Camera	Clear Fault Codes	
Audi RS3	2008-2014	8J	6C Rear Camera	Measuring Blocks	
Audi RS3	2008-2014	8J	6C Rear Camera	Output Tests	
Audi RS3	2008-2014	8J	6C Rear Camera	Specia Functions	
Audi RS3	2008-2014	8J	72 RR-Door Electroni.	Read Fault Codes	
Audi RS3	2008-2014	8J	72 RR-Door Electroni.	Clear Fault Codes	
Audi RS3	2008-2014	8J	72 RR-Door Electroni.	Measuring Blocks	
Audi RS3	2008-2014	8J	72 RR-Door Electroni.	Output Tests	
Audi RS3	2008-2014	8J	72 RR-Door Electroni.	Specia Functions	
Audi RS3	2008-2014	8J	76 Parking Aid	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS3	2008-2014	8J	76 Parking Aid	Clear Fault Codes	
Audi RS3	2008-2014	8J	76 Parking Aid	Measuring Blocks	
Audi RS3	2008-2014	8J	76 Parking Aid	Output Tests	
Audi RS3	2008-2014	8J	76 Parking Aid	Specia Functions	
Audi RS3	2008-2014	8J	77 Telephone	Read Fault Codes	
Audi RS3	2008-2014	8J	77 Telephone	Clear Fault Codes	
Audi RS3	2008-2014	8J	77 Telephone	Measuring Blocks	
Audi RS3	2008-2014	8J	77 Telephone	Output Tests	
Audi RS3	2008-2014	8J	77 Telephone	Specia Functions	
Audi RS3	2008-2014	8J	7D Auxiliary Heater	Read Fault Codes	
Audi RS3	2008-2014	8J	7D Auxiliary Heater	Clear Fault Codes	
Audi RS3	2008-2014	8J	7D Auxiliary Heater	Measuring Blocks	
Audi RS3	2008-2014	8J	7D Auxiliary Heater	Output Tests	
Audi RS3	2008-2014	8J	7D Auxiliary Heater	Specia Functions	
Audi RS3	2008-2014	8J	A6 Microphone	Read Fault Codes	
Audi RS3	2008-2014	8J	A6 Microphone	Clear Fault Codes	
Audi RS3	2008-2014	8J	A6 Microphone	Measuring Blocks	
Audi RS3	2008-2014	8J	A6 Microphone	Output Tests	
Audi RS3	2008-2014	8J	A6 Microphone	Specia Functions	
Audi TT	2009-2015	FK	01 Engine Electronics	Read Fault Codes	
Audi TT	2009-2015	FK	01 Engine Electronics	Clear Fault Codes	
Audi TT	2009-2015	FK	01 Engine Electronics	Measuring Blocks	
Audi TT	2009-2015	FK	01 Engine Electronics	Output Tests	
Audi TT	2009-2015	FK	01 Engine Electronics	Specia Functions	
Audi TT	2009-2015	FK	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2009-2015	FK	02 Transmission Electronics	Clear Fault Codes	
Audi TT	2009-2015	FK	02 Transmission Electronics	Measuring Blocks	
Audi TT	2009-2015	FK	02 Transmission Electronics	Output Tests	
Audi TT	2009-2015	FK	02 Transmission Electronics	Specia Functions	
Audi TT	2009-2015	FK	03 Brake Electronics	Read Fault Codes	
Audi TT	2009-2015	FK	03 Brake Electronics	Clear Fault Codes	
Audi TT	2009-2015	FK	03 Brake Electronics	Measuring Blocks	
Audi TT	2009-2015	FK	03 Brake Electronics	Output Tests	
Audi TT	2009-2015	FK	03 Brake Electronics	Specia Functions	
Audi TT	2009-2015	FK	08 AC/Heating Electronics	Read Fault Codes	
Audi TT	2009-2015	FK	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT	2009-2015	FK	08 AC/Heating Electronics	Measuring Blocks	
Audi TT	2009-2015	FK	08 AC/Heating Electronics	Output Tests	
Audi TT	2009-2015	FK	08 AC/Heating Electronics	Specia Functions	
Audi TT	2009-2015	FK	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi TT	2009-2015	FK	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi TT	2009-2015	FK	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi TT	2009-2015	FK	09 Electronic Ctrl Electronics	Output Tests	
Audi TT	2009-2015	FK	09 Electronic Ctrl Electronics	Specia Functions	
Audi TT	2009-2015	FK	0E Media Player Position 1	Read Fault Codes	
Audi TT	2009-2015	FK	0E Media Player Position 1	Clear Fault Codes	
Audi TT	2009-2015	FK	0E Media Player Position 1	Measuring Blocks	
Audi TT	2009-2015	FK	0E Media Player Position 1	Output Tests	
Audi TT	2009-2015	FK	0E Media Player Position 1	Specia Functions	
Audi TT	2009-2015	FK	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2009-2015	FK	0F Radio Tuner-Digital	Clear Fault Codes	
Audi TT	2009-2015	FK	0F Radio Tuner-Digital	Measuring Blocks	
Audi TT	2009-2015	FK	0F Radio Tuner-Digital	Output Tests	
Audi TT	2009-2015	FK	0F Radio Tuner-Digital	Specia Functions	
Audi TT	2009-2015	FK	10 Parking Assist System 2	Read Fault Codes	
Audi TT	2009-2015	FK	10 Parking Assist System 2	Clear Fault Codes	
Audi TT	2009-2015	FK	10 Parking Assist System 2	Measuring Blocks	
Audi TT	2009-2015	FK	10 Parking Assist System 2	Output Tests	
Audi TT	2009-2015	FK	10 Parking Assist System 2	Specia Functions	
Audi TT	2009-2015	FK	11 Engine Electronics 2	Read Fault Codes	
Audi TT	2009-2015	FK	11 Engine Electronics 2	Clear Fault Codes	
Audi TT	2009-2015	FK	11 Engine Electronics 2	Measuring Blocks	
Audi TT	2009-2015	FK	11 Engine Electronics 2	Output Tests	
Audi TT	2009-2015	FK	11 Engine Electronics 2	Specia Functions	
Audi TT	2009-2015	FK	14 Wheel Damping Electronics	Read Fault Codes	
Audi TT	2009-2015	FK	14 Wheel Damping Electronics	Clear Fault Codes	
Audi TT	2009-2015	FK	14 Wheel Damping Electronics	Measuring Blocks	
Audi TT	2009-2015	FK	14 Wheel Damping Electronics	Output Tests	
Audi TT	2009-2015	FK	14 Wheel Damping Electronics	Specia Functions	
Audi TT	2009-2015	FK	15 Airbags	Read Fault Codes	
Audi TT	2009-2015	FK	15 Airbags	Clear Fault Codes	
Audi TT	2009-2015	FK	15 Airbags	Measuring Blocks	
Audi TT	2009-2015	FK	15 Airbags	Output Tests	
Audi TT	2009-2015	FK	15 Airbags	Specia Functions	
Audi TT	2009-2015	FK	16 Steering Wheel Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2009-2015	FK	16 Steering Wheel Electronics	Clear Fault Codes	
Audi TT	2009-2015	FK	16 Steering Wheel Electronics	Measuring Blocks	
Audi TT	2009-2015	FK	16 Steering Wheel Electronics	Output Tests	
Audi TT	2009-2015	FK	16 Steering Wheel Electronics	Specia Functions	
Audi TT	2009-2015	FK	17 Instrument Cluster	Read Fault Codes	
Audi TT	2009-2015	FK	17 Instrument Cluster	Clear Fault Codes	
Audi TT	2009-2015	FK	17 Instrument Cluster	Measuring Blocks	
Audi TT	2009-2015	FK	17 Instrument Cluster	Output Tests	
Audi TT	2009-2015	FK	17 Instrument Cluster	Specia Functions	
Audi TT	2009-2015	FK	18 Aux Heating	Read Fault Codes	
Audi TT	2009-2015	FK	18 Aux Heating	Clear Fault Codes	
Audi TT	2009-2015	FK	18 Aux Heating	Measuring Blocks	
Audi TT	2009-2015	FK	18 Aux Heating	Output Tests	
Audi TT	2009-2015	FK	18 Aux Heating	Specia Functions	
Audi TT	2009-2015	FK	19 Gateway Data Bus	Read Fault Codes	
Audi TT	2009-2015	FK	19 Gateway Data Bus	Clear Fault Codes	
Audi TT	2009-2015	FK	19 Gateway Data Bus	Measuring Blocks	
Audi TT	2009-2015	FK	19 Gateway Data Bus	Output Tests	
Audi TT	2009-2015	FK	19 Gateway Data Bus	Specia Functions	
Audi TT	2009-2015	FK	20 High Beam Assistance Device	Read Fault Codes	
Audi TT	2009-2015	FK	20 High Beam Assistance Device	Clear Fault Codes	
Audi TT	2009-2015	FK	20 High Beam Assistance Device	Measuring Blocks	
Audi TT	2009-2015	FK	20 High Beam Assistance Device	Output Tests	
Audi TT	2009-2015	FK	20 High Beam Assistance Device	Specia Functions	
Audi TT	2009-2015	FK	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2009-2015	FK	22 4WD Electronics	Clear Fault Codes	
Audi TT	2009-2015	FK	22 4WD Electronics	Measuring Blocks	
Audi TT	2009-2015	FK	22 4WD Electronics	Output Tests	
Audi TT	2009-2015	FK	22 4WD Electronics	Specia Functions	
Audi TT	2009-2015	FK	25 Immobilizer	Read Fault Codes	
Audi TT	2009-2015	FK	25 Immobilizer	Clear Fault Codes	
Audi TT	2009-2015	FK	25 Immobilizer	Measuring Blocks	
Audi TT	2009-2015	FK	25 Immobilizer	Output Tests	
Audi TT	2009-2015	FK	25 Immobilizer	Specia Functions	
Audi TT	2009-2015	FK	26 Electric Roof Control	Read Fault Codes	
Audi TT	2009-2015	FK	26 Electric Roof Control	Clear Fault Codes	
Audi TT	2009-2015	FK	26 Electric Roof Control	Measuring Blocks	
Audi TT	2009-2015	FK	26 Electric Roof Control	Output Tests	
Audi TT	2009-2015	FK	26 Electric Roof Control	Specia Functions	
Audi TT	2009-2015	FK	2E Media Player Position 3	Read Fault Codes	
Audi TT	2009-2015	FK	2E Media Player Position 3	Clear Fault Codes	
Audi TT	2009-2015	FK	2E Media Player Position 3	Measuring Blocks	
Audi TT	2009-2015	FK	2E Media Player Position 3	Output Tests	
Audi TT	2009-2015	FK	2E Media Player Position 3	Specia Functions	
Audi TT	2009-2015	FK	37 Navigation	Read Fault Codes	
Audi TT	2009-2015	FK	37 Navigation	Clear Fault Codes	
Audi TT	2009-2015	FK	37 Navigation	Measuring Blocks	
Audi TT	2009-2015	FK	37 Navigation	Output Tests	
Audi TT	2009-2015	FK	37 Navigation	Specia Functions	
Audi TT	2009-2015	FK	3D Special Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2009-2015	FK	3D Special Function	Clear Fault Codes	
Audi TT	2009-2015	FK	3D Special Function	Measuring Blocks	
Audi TT	2009-2015	FK	3D Special Function	Output Tests	
Audi TT	2009-2015	FK	3D Special Function	Specia Functions	
Audi TT	2009-2015	FK	42 Driver-Door Elect.	Read Fault Codes	
Audi TT	2009-2015	FK	42 Driver-Door Elect.	Clear Fault Codes	
Audi TT	2009-2015	FK	42 Driver-Door Elect.	Measuring Blocks	
Audi TT	2009-2015	FK	42 Driver-Door Elect.	Output Tests	
Audi TT	2009-2015	FK	42 Driver-Door Elect.	Specia Functions	
Audi TT	2009-2015	FK	44 Steering Assistance	Read Fault Codes	
Audi TT	2009-2015	FK	44 Steering Assistance	Clear Fault Codes	
Audi TT	2009-2015	FK	44 Steering Assistance	Measuring Blocks	
Audi TT	2009-2015	FK	44 Steering Assistance	Output Tests	
Audi TT	2009-2015	FK	44 Steering Assistance	Specia Functions	
Audi TT	2009-2015	FK	46 Central Control Module	Read Fault Codes	
Audi TT	2009-2015	FK	46 Central Control Module	Clear Fault Codes	
Audi TT	2009-2015	FK	46 Central Control Module	Measuring Blocks	
Audi TT	2009-2015	FK	46 Central Control Module	Output Tests	
Audi TT	2009-2015	FK	46 Central Control Module	Specia Functions	
Audi TT	2009-2015	FK	47 Soundsystem	Read Fault Codes	
Audi TT	2009-2015	FK	47 Soundsystem	Clear Fault Codes	
Audi TT	2009-2015	FK	47 Soundsystem	Measuring Blocks	
Audi TT	2009-2015	FK	47 Soundsystem	Output Tests	
Audi TT	2009-2015	FK	47 Soundsystem	Specia Functions	
Audi TT	2009-2015	FK	4C Tyre Pressure Monitor II	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2009-2015	FK	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi TT	2009-2015	FK	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi TT	2009-2015	FK	4C Tyre Pressure Monitor II	Output Tests	
Audi TT	2009-2015	FK	4C Tyre Pressure Monitor II	Specia Functions	
Audi TT	2009-2015	FK	52 Passe.-Door Elect.	Read Fault Codes	
Audi TT	2009-2015	FK	52 Passe.-Door Elect.	Clear Fault Codes	
Audi TT	2009-2015	FK	52 Passe.-Door Elect.	Measuring Blocks	
Audi TT	2009-2015	FK	52 Passe.-Door Elect.	Output Tests	
Audi TT	2009-2015	FK	52 Passe.-Door Elect.	Specia Functions	
Audi TT	2009-2015	FK	55 Headlight Range Control	Read Fault Codes	
Audi TT	2009-2015	FK	55 Headlight Range Control	Clear Fault Codes	
Audi TT	2009-2015	FK	55 Headlight Range Control	Measuring Blocks	
Audi TT	2009-2015	FK	55 Headlight Range Control	Output Tests	
Audi TT	2009-2015	FK	55 Headlight Range Control	Specia Functions	
Audi TT	2009-2015	FK	56 Radio	Read Fault Codes	
Audi TT	2009-2015	FK	56 Radio	Clear Fault Codes	
Audi TT	2009-2015	FK	56 Radio	Measuring Blocks	
Audi TT	2009-2015	FK	56 Radio	Output Tests	
Audi TT	2009-2015	FK	56 Radio	Specia Functions	
Audi TT	2009-2015	FK	57 TV-Tuner	Read Fault Codes	
Audi TT	2009-2015	FK	57 TV-Tuner	Clear Fault Codes	
Audi TT	2009-2015	FK	57 TV-Tuner	Measuring Blocks	
Audi TT	2009-2015	FK	57 TV-Tuner	Output Tests	
Audi TT	2009-2015	FK	57 TV-Tuner	Specia Functions	
Audi TT	2009-2015	FK	61 Battery Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2009-2015	FK	61 Battery Control	Clear Fault Codes	
Audi TT	2009-2015	FK	61 Battery Control	Measuring Blocks	
Audi TT	2009-2015	FK	61 Battery Control	Output Tests	
Audi TT	2009-2015	FK	61 Battery Control	Specia Functions	
Audi TT	2009-2015	FK	62 LR-Door Electroni.	Read Fault Codes	
Audi TT	2009-2015	FK	62 LR-Door Electroni.	Clear Fault Codes	
Audi TT	2009-2015	FK	62 LR-Door Electroni.	Measuring Blocks	
Audi TT	2009-2015	FK	62 LR-Door Electroni.	Output Tests	
Audi TT	2009-2015	FK	62 LR-Door Electroni.	Specia Functions	
Audi TT	2009-2015	FK	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi TT	2009-2015	FK	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi TT	2009-2015	FK	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi TT	2009-2015	FK	65 Tyre Pressure Monitoring	Output Tests	
Audi TT	2009-2015	FK	65 Tyre Pressure Monitoring	Specia Functions	
Audi TT	2009-2015	FK	69 Trailer Function	Read Fault Codes	
Audi TT	2009-2015	FK	69 Trailer Function	Clear Fault Codes	
Audi TT	2009-2015	FK	69 Trailer Function	Measuring Blocks	
Audi TT	2009-2015	FK	69 Trailer Function	Output Tests	
Audi TT	2009-2015	FK	69 Trailer Function	Specia Functions	
Audi TT	2009-2015	FK	6C Rear Camera	Read Fault Codes	
Audi TT	2009-2015	FK	6C Rear Camera	Clear Fault Codes	
Audi TT	2009-2015	FK	6C Rear Camera	Measuring Blocks	
Audi TT	2009-2015	FK	6C Rear Camera	Output Tests	
Audi TT	2009-2015	FK	6C Rear Camera	Specia Functions	
Audi TT	2009-2015	FK	72 RR-Door Electroni.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2009-2015	FK	72 RR-Door Electroni.	Clear Fault Codes	
Audi TT	2009-2015	FK	72 RR-Door Electroni.	Measuring Blocks	
Audi TT	2009-2015	FK	72 RR-Door Electroni.	Output Tests	
Audi TT	2009-2015	FK	72 RR-Door Electroni.	Specia Functions	
Audi TT	2009-2015	FK	76 Parking Aid	Read Fault Codes	
Audi TT	2009-2015	FK	76 Parking Aid	Clear Fault Codes	
Audi TT	2009-2015	FK	76 Parking Aid	Measuring Blocks	
Audi TT	2009-2015	FK	76 Parking Aid	Output Tests	
Audi TT	2009-2015	FK	76 Parking Aid	Specia Functions	
Audi TT	2009-2015	FK	77 Telephone	Read Fault Codes	
Audi TT	2009-2015	FK	77 Telephone	Clear Fault Codes	
Audi TT	2009-2015	FK	77 Telephone	Measuring Blocks	
Audi TT	2009-2015	FK	77 Telephone	Output Tests	
Audi TT	2009-2015	FK	77 Telephone	Specia Functions	
Audi TT	2009-2015	FK	7D Auxiliary Heater	Read Fault Codes	
Audi TT	2009-2015	FK	7D Auxiliary Heater	Clear Fault Codes	
Audi TT	2009-2015	FK	7D Auxiliary Heater	Measuring Blocks	
Audi TT	2009-2015	FK	7D Auxiliary Heater	Output Tests	
Audi TT	2009-2015	FK	7D Auxiliary Heater	Specia Functions	
Audi TT	2009-2015	FK	A6 Microphone	Read Fault Codes	
Audi TT	2009-2015	FK	A6 Microphone	Clear Fault Codes	
Audi TT	2009-2015	FK	A6 Microphone	Measuring Blocks	
Audi TT	2009-2015	FK	A6 Microphone	Output Tests	
Audi TT	2009-2015	FK	A6 Microphone	Specia Functions	
Audi R8	2010-2016	FG	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2010-2016	FG	01 Engine Electronics	Clear Fault Codes	
Audi R8	2010-2016	FG	01 Engine Electronics	Measuring Blocks	
Audi R8	2010-2016	FG	01 Engine Electronics	Output Tests	
Audi R8	2010-2016	FG	01 Engine Electronics	Specia Functions	
Audi R8	2010-2016	FG	02 Transmission Electronics	Read Fault Codes	
Audi R8	2010-2016	FG	02 Transmission Electronics	Clear Fault Codes	
Audi R8	2010-2016	FG	02 Transmission Electronics	Measuring Blocks	
Audi R8	2010-2016	FG	02 Transmission Electronics	Output Tests	
Audi R8	2010-2016	FG	02 Transmission Electronics	Specia Functions	
Audi R8	2010-2016	FG	03 Brake Electronics	Read Fault Codes	
Audi R8	2010-2016	FG	03 Brake Electronics	Clear Fault Codes	
Audi R8	2010-2016	FG	03 Brake Electronics	Measuring Blocks	
Audi R8	2010-2016	FG	03 Brake Electronics	Output Tests	
Audi R8	2010-2016	FG	03 Brake Electronics	Specia Functions	
Audi R8	2010-2016	FG	08 AC/Heating Electronics	Read Fault Codes	
Audi R8	2010-2016	FG	08 AC/Heating Electronics	Clear Fault Codes	
Audi R8	2010-2016	FG	08 AC/Heating Electronics	Measuring Blocks	
Audi R8	2010-2016	FG	08 AC/Heating Electronics	Output Tests	
Audi R8	2010-2016	FG	08 AC/Heating Electronics	Specia Functions	
Audi R8	2010-2016	FG	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi R8	2010-2016	FG	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi R8	2010-2016	FG	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi R8	2010-2016	FG	09 Electronic Ctrl Electronics	Output Tests	
Audi R8	2010-2016	FG	09 Electronic Ctrl Electronics	Specia Functions	
Audi R8	2010-2016	FG	0E Media Player Position 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi R8	2010-2016	FG	0E Media Player Position 1	Clear Fault Codes	
Audi R8	2010-2016	FG	0E Media Player Position 1	Measuring Blocks	
Audi R8	2010-2016	FG	0E Media Player Position 1	Output Tests	
Audi R8	2010-2016	FG	0E Media Player Position 1	Specia Functions	
Audi R8	2010-2016	FG	0F Radio Tuner-Digital	Read Fault Codes	
Audi R8	2010-2016	FG	0F Radio Tuner-Digital	Clear Fault Codes	
Audi R8	2010-2016	FG	0F Radio Tuner-Digital	Measuring Blocks	
Audi R8	2010-2016	FG	0F Radio Tuner-Digital	Output Tests	
Audi R8	2010-2016	FG	0F Radio Tuner-Digital	Specia Functions	
Audi R8	2010-2016	FG	10 Parking Assist System 2	Read Fault Codes	
Audi R8	2010-2016	FG	10 Parking Assist System 2	Clear Fault Codes	
Audi R8	2010-2016	FG	10 Parking Assist System 2	Measuring Blocks	
Audi R8	2010-2016	FG	10 Parking Assist System 2	Output Tests	
Audi R8	2010-2016	FG	10 Parking Assist System 2	Specia Functions	
Audi R8	2010-2016	FG	11 Engine Electronics 2	Read Fault Codes	
Audi R8	2010-2016	FG	11 Engine Electronics 2	Clear Fault Codes	
Audi R8	2010-2016	FG	11 Engine Electronics 2	Measuring Blocks	
Audi R8	2010-2016	FG	11 Engine Electronics 2	Output Tests	
Audi R8	2010-2016	FG	11 Engine Electronics 2	Specia Functions	
Audi R8	2010-2016	FG	14 Wheel Damping Electronics	Read Fault Codes	
Audi R8	2010-2016	FG	14 Wheel Damping Electronics	Clear Fault Codes	
Audi R8	2010-2016	FG	14 Wheel Damping Electronics	Measuring Blocks	
Audi R8	2010-2016	FG	14 Wheel Damping Electronics	Output Tests	
Audi R8	2010-2016	FG	14 Wheel Damping Electronics	Specia Functions	
Audi R8	2010-2016	FG	15 Airbags	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2010-2016	FG	15 Airbags	Clear Fault Codes	
Audi R8	2010-2016	FG	15 Airbags	Measuring Blocks	
Audi R8	2010-2016	FG	15 Airbags	Output Tests	
Audi R8	2010-2016	FG	15 Airbags	Specia Functions	
Audi R8	2010-2016	FG	16 Steering Wheel Electronics	Read Fault Codes	
Audi R8	2010-2016	FG	16 Steering Wheel Electronics	Clear Fault Codes	
Audi R8	2010-2016	FG	16 Steering Wheel Electronics	Measuring Blocks	
Audi R8	2010-2016	FG	16 Steering Wheel Electronics	Output Tests	
Audi R8	2010-2016	FG	16 Steering Wheel Electronics	Specia Functions	
Audi R8	2010-2016	FG	17 Instrument Cluster	Read Fault Codes	
Audi R8	2010-2016	FG	17 Instrument Cluster	Clear Fault Codes	
Audi R8	2010-2016	FG	17 Instrument Cluster	Measuring Blocks	
Audi R8	2010-2016	FG	17 Instrument Cluster	Output Tests	
Audi R8	2010-2016	FG	17 Instrument Cluster	Specia Functions	
Audi R8	2010-2016	FG	18 Aux Heating	Read Fault Codes	
Audi R8	2010-2016	FG	18 Aux Heating	Clear Fault Codes	
Audi R8	2010-2016	FG	18 Aux Heating	Measuring Blocks	
Audi R8	2010-2016	FG	18 Aux Heating	Output Tests	
Audi R8	2010-2016	FG	18 Aux Heating	Specia Functions	
Audi R8	2010-2016	FG	19 Gateway Data Bus	Read Fault Codes	
Audi R8	2010-2016	FG	19 Gateway Data Bus	Clear Fault Codes	
Audi R8	2010-2016	FG	19 Gateway Data Bus	Measuring Blocks	
Audi R8	2010-2016	FG	19 Gateway Data Bus	Output Tests	
Audi R8	2010-2016	FG	19 Gateway Data Bus	Specia Functions	
Audi R8	2010-2016	FG	20 High Beam Assistance Device	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2010-2016	FG	20 High Beam Assistance Device	Clear Fault Codes	
Audi R8	2010-2016	FG	20 High Beam Assistance Device	Measuring Blocks	
Audi R8	2010-2016	FG	20 High Beam Assistance Device	Output Tests	
Audi R8	2010-2016	FG	20 High Beam Assistance Device	Specia Functions	
Audi R8	2010-2016	FG	22 4WD Electronics	Read Fault Codes	
Audi R8	2010-2016	FG	22 4WD Electronics	Clear Fault Codes	
Audi R8	2010-2016	FG	22 4WD Electronics	Measuring Blocks	
Audi R8	2010-2016	FG	22 4WD Electronics	Output Tests	
Audi R8	2010-2016	FG	22 4WD Electronics	Specia Functions	
Audi R8	2010-2016	FG	25 Immobilizer	Read Fault Codes	
Audi R8	2010-2016	FG	25 Immobilizer	Clear Fault Codes	
Audi R8	2010-2016	FG	25 Immobilizer	Measuring Blocks	
Audi R8	2010-2016	FG	25 Immobilizer	Output Tests	
Audi R8	2010-2016	FG	25 Immobilizer	Specia Functions	
Audi R8	2010-2016	FG	26 Electric Roof Control	Read Fault Codes	
Audi R8	2010-2016	FG	26 Electric Roof Control	Clear Fault Codes	
Audi R8	2010-2016	FG	26 Electric Roof Control	Measuring Blocks	
Audi R8	2010-2016	FG	26 Electric Roof Control	Output Tests	
Audi R8	2010-2016	FG	26 Electric Roof Control	Specia Functions	
Audi R8	2010-2016	FG	2E Media Player Position 3	Read Fault Codes	
Audi R8	2010-2016	FG	2E Media Player Position 3	Clear Fault Codes	
Audi R8	2010-2016	FG	2E Media Player Position 3	Measuring Blocks	
Audi R8	2010-2016	FG	2E Media Player Position 3	Output Tests	
Audi R8	2010-2016	FG	2E Media Player Position 3	Specia Functions	
Audi R8	2010-2016	FG	37 Navigation	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2010-2016	FG	37 Navigation	Clear Fault Codes	
Audi R8	2010-2016	FG	37 Navigation	Measuring Blocks	
Audi R8	2010-2016	FG	37 Navigation	Output Tests	
Audi R8	2010-2016	FG	37 Navigation	Specia Functions	
Audi R8	2010-2016	FG	3D Special Function	Read Fault Codes	
Audi R8	2010-2016	FG	3D Special Function	Clear Fault Codes	
Audi R8	2010-2016	FG	3D Special Function	Measuring Blocks	
Audi R8	2010-2016	FG	3D Special Function	Output Tests	
Audi R8	2010-2016	FG	3D Special Function	Specia Functions	
Audi R8	2010-2016	FG	42 Driver-Door Elect.	Read Fault Codes	
Audi R8	2010-2016	FG	42 Driver-Door Elect.	Clear Fault Codes	
Audi R8	2010-2016	FG	42 Driver-Door Elect.	Measuring Blocks	
Audi R8	2010-2016	FG	42 Driver-Door Elect.	Output Tests	
Audi R8	2010-2016	FG	42 Driver-Door Elect.	Specia Functions	
Audi R8	2010-2016	FG	44 Steering Assistance	Read Fault Codes	
Audi R8	2010-2016	FG	44 Steering Assistance	Clear Fault Codes	
Audi R8	2010-2016	FG	44 Steering Assistance	Measuring Blocks	
Audi R8	2010-2016	FG	44 Steering Assistance	Output Tests	
Audi R8	2010-2016	FG	44 Steering Assistance	Specia Functions	
Audi R8	2010-2016	FG	46 Central Control Module	Read Fault Codes	
Audi R8	2010-2016	FG	46 Central Control Module	Clear Fault Codes	
Audi R8	2010-2016	FG	46 Central Control Module	Measuring Blocks	
Audi R8	2010-2016	FG	46 Central Control Module	Output Tests	
Audi R8	2010-2016	FG	46 Central Control Module	Specia Functions	
Audi R8	2010-2016	FG	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2010-2016	FG	47 Soundsystem	Clear Fault Codes	
Audi R8	2010-2016	FG	47 Soundsystem	Measuring Blocks	
Audi R8	2010-2016	FG	47 Soundsystem	Output Tests	
Audi R8	2010-2016	FG	47 Soundsystem	Specia Functions	
Audi R8	2010-2016	FG	4C Tyre Pressure Monitor II	Read Fault Codes	
Audi R8	2010-2016	FG	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi R8	2010-2016	FG	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi R8	2010-2016	FG	4C Tyre Pressure Monitor II	Output Tests	
Audi R8	2010-2016	FG	4C Tyre Pressure Monitor II	Specia Functions	
Audi R8	2010-2016	FG	52 Passe.-Door Elect.	Read Fault Codes	
Audi R8	2010-2016	FG	52 Passe.-Door Elect.	Clear Fault Codes	
Audi R8	2010-2016	FG	52 Passe.-Door Elect.	Measuring Blocks	
Audi R8	2010-2016	FG	52 Passe.-Door Elect.	Output Tests	
Audi R8	2010-2016	FG	52 Passe.-Door Elect.	Specia Functions	
Audi R8	2010-2016	FG	55 Headlight Range Control	Read Fault Codes	
Audi R8	2010-2016	FG	55 Headlight Range Control	Clear Fault Codes	
Audi R8	2010-2016	FG	55 Headlight Range Control	Measuring Blocks	
Audi R8	2010-2016	FG	55 Headlight Range Control	Output Tests	
Audi R8	2010-2016	FG	55 Headlight Range Control	Specia Functions	
Audi R8	2010-2016	FG	56 Radio	Read Fault Codes	
Audi R8	2010-2016	FG	56 Radio	Clear Fault Codes	
Audi R8	2010-2016	FG	56 Radio	Measuring Blocks	
Audi R8	2010-2016	FG	56 Radio	Output Tests	
Audi R8	2010-2016	FG	56 Radio	Specia Functions	
Audi R8	2010-2016	FG	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2010-2016	FG	57 TV-Tuner	Clear Fault Codes	
Audi R8	2010-2016	FG	57 TV-Tuner	Measuring Blocks	
Audi R8	2010-2016	FG	57 TV-Tuner	Output Tests	
Audi R8	2010-2016	FG	57 TV-Tuner	Specia Functions	
Audi R8	2010-2016	FG	61 Battery Control	Read Fault Codes	
Audi R8	2010-2016	FG	61 Battery Control	Clear Fault Codes	
Audi R8	2010-2016	FG	61 Battery Control	Measuring Blocks	
Audi R8	2010-2016	FG	61 Battery Control	Output Tests	
Audi R8	2010-2016	FG	61 Battery Control	Specia Functions	
Audi R8	2010-2016	FG	62 LR-Door Electroni.	Read Fault Codes	
Audi R8	2010-2016	FG	62 LR-Door Electroni.	Clear Fault Codes	
Audi R8	2010-2016	FG	62 LR-Door Electroni.	Measuring Blocks	
Audi R8	2010-2016	FG	62 LR-Door Electroni.	Output Tests	
Audi R8	2010-2016	FG	62 LR-Door Electroni.	Specia Functions	
Audi R8	2010-2016	FG	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi R8	2010-2016	FG	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi R8	2010-2016	FG	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi R8	2010-2016	FG	65 Tyre Pressure Monitoring	Output Tests	
Audi R8	2010-2016	FG	65 Tyre Pressure Monitoring	Specia Functions	
Audi R8	2010-2016	FG	69 Trailer Function	Read Fault Codes	
Audi R8	2010-2016	FG	69 Trailer Function	Clear Fault Codes	
Audi R8	2010-2016	FG	69 Trailer Function	Measuring Blocks	
Audi R8	2010-2016	FG	69 Trailer Function	Output Tests	
Audi R8	2010-2016	FG	69 Trailer Function	Specia Functions	
Audi R8	2010-2016	FG	6C Rear Camera	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi R8	2010-2016	FG	6C Rear Camera	Clear Fault Codes	
Audi R8	2010-2016	FG	6C Rear Camera	Measuring Blocks	
Audi R8	2010-2016	FG	6C Rear Camera	Output Tests	
Audi R8	2010-2016	FG	6C Rear Camera	Specia Functions	
Audi R8	2010-2016	FG	72 RR-Door Electroni.	Read Fault Codes	
Audi R8	2010-2016	FG	72 RR-Door Electroni.	Clear Fault Codes	
Audi R8	2010-2016	FG	72 RR-Door Electroni.	Measuring Blocks	
Audi R8	2010-2016	FG	72 RR-Door Electroni.	Output Tests	
Audi R8	2010-2016	FG	72 RR-Door Electroni.	Specia Functions	
Audi R8	2010-2016	FG	76 Parking Aid	Read Fault Codes	
Audi R8	2010-2016	FG	76 Parking Aid	Clear Fault Codes	
Audi R8	2010-2016	FG	76 Parking Aid	Measuring Blocks	
Audi R8	2010-2016	FG	76 Parking Aid	Output Tests	
Audi R8	2010-2016	FG	76 Parking Aid	Specia Functions	
Audi R8	2010-2016	FG	77 Telephone	Read Fault Codes	
Audi R8	2010-2016	FG	77 Telephone	Clear Fault Codes	
Audi R8	2010-2016	FG	77 Telephone	Measuring Blocks	
Audi R8	2010-2016	FG	77 Telephone	Output Tests	
Audi R8	2010-2016	FG	77 Telephone	Specia Functions	
Audi R8	2010-2016	FG	7D Auxiliary Heater	Read Fault Codes	
Audi R8	2010-2016	FG	7D Auxiliary Heater	Clear Fault Codes	
Audi R8	2010-2016	FG	7D Auxiliary Heater	Measuring Blocks	
Audi R8	2010-2016	FG	7D Auxiliary Heater	Output Tests	
Audi R8	2010-2016	FG	7D Auxiliary Heater	Specia Functions	
Audi R8	2010-2016	FG	A6 Microphone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2010-2016	FG	A6 Microphone	Clear Fault Codes	
Audi R8	2010-2016	FG	A6 Microphone	Measuring Blocks	
Audi R8	2010-2016	FG	A6 Microphone	Output Tests	
Audi R8	2010-2016	FG	A6 Microphone	Specia Functions	
Audi A3	2013-2018	8V	01 Engine Electronics	Read Fault Codes	
Audi A3	2013-2018	8V	01 Engine Electronics	Clear Fault Codes	
Audi A3	2013-2018	8V	01 Engine Electronics	Measuring Blocks	
Audi A3	2013-2018	8V	01 Engine Electronics	Output Tests	
Audi A3	2013-2018	8V	01 Engine Electronics	Specia Functions	
Audi A3	2013-2018	8V	02 Transmission Electronics	Read Fault Codes	
Audi A3	2013-2018	8V	02 Transmission Electronics	Clear Fault Codes	
Audi A3	2013-2018	8V	02 Transmission Electronics	Measuring Blocks	
Audi A3	2013-2018	8V	02 Transmission Electronics	Output Tests	
Audi A3	2013-2018	8V	02 Transmission Electronics	Specia Functions	
Audi A3	2013-2018	8V	03 Brake Electronics	Read Fault Codes	
Audi A3	2013-2018	8V	03 Brake Electronics	Clear Fault Codes	
Audi A3	2013-2018	8V	03 Brake Electronics	Measuring Blocks	
Audi A3	2013-2018	8V	03 Brake Electronics	Output Tests	
Audi A3	2013-2018	8V	03 Brake Electronics	Specia Functions	
Audi A3	2013-2018	8V	06 Passene. Seat Adj.	Read Fault Codes	
Audi A3	2013-2018	8V	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A3	2013-2018	8V	06 Passene. Seat Adj.	Measuring Blocks	
Audi A3	2013-2018	8V	06 Passene. Seat Adj.	Output Tests	
Audi A3	2013-2018	8V	06 Passene. Seat Adj.	Specia Functions	
Audi A3	2013-2018	8V	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2013-2018	8V	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3	2013-2018	8V	08 AC/Heating Electronics	Measuring Blocks	
Audi A3	2013-2018	8V	08 AC/Heating Electronics	Output Tests	
Audi A3	2013-2018	8V	08 AC/Heating Electronics	Specia Functions	
Audi A3	2013-2018	8V	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3	2013-2018	8V	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3	2013-2018	8V	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3	2013-2018	8V	09 Electronic Ctrl Electronics	Output Tests	
Audi A3	2013-2018	8V	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3	2013-2018	8V	13 Distance Control	Read Fault Codes	
Audi A3	2013-2018	8V	13 Distance Control	Clear Fault Codes	
Audi A3	2013-2018	8V	13 Distance Control	Measuring Blocks	
Audi A3	2013-2018	8V	13 Distance Control	Output Tests	
Audi A3	2013-2018	8V	13 Distance Control	Specia Functions	
Audi A3	2013-2018	8V	14 Wheel Damping Electronics	Read Fault Codes	
Audi A3	2013-2018	8V	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A3	2013-2018	8V	14 Wheel Damping Electronics	Measuring Blocks	
Audi A3	2013-2018	8V	14 Wheel Damping Electronics	Output Tests	
Audi A3	2013-2018	8V	14 Wheel Damping Electronics	Specia Functions	
Audi A3	2013-2018	8V	15 Airbags	Read Fault Codes	
Audi A3	2013-2018	8V	15 Airbags	Clear Fault Codes	
Audi A3	2013-2018	8V	15 Airbags	Measuring Blocks	
Audi A3	2013-2018	8V	15 Airbags	Output Tests	
Audi A3	2013-2018	8V	15 Airbags	Specia Functions	
Audi A3	2013-2018	8V	16 Steering Wheel Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2013-2018	8V	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3	2013-2018	8V	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3	2013-2018	8V	16 Steering Wheel Electronics	Output Tests	
Audi A3	2013-2018	8V	16 Steering Wheel Electronics	Specia Functions	
Audi A3	2013-2018	8V	17 Instrument Cluster	Read Fault Codes	
Audi A3	2013-2018	8V	17 Instrument Cluster	Clear Fault Codes	
Audi A3	2013-2018	8V	17 Instrument Cluster	Measuring Blocks	
Audi A3	2013-2018	8V	17 Instrument Cluster	Output Tests	
Audi A3	2013-2018	8V	17 Instrument Cluster	Specia Functions	
Audi A3	2013-2018	8V	18 Aux Heating	Read Fault Codes	
Audi A3	2013-2018	8V	18 Aux Heating	Clear Fault Codes	
Audi A3	2013-2018	8V	18 Aux Heating	Measuring Blocks	
Audi A3	2013-2018	8V	18 Aux Heating	Output Tests	
Audi A3	2013-2018	8V	18 Aux Heating	Specia Functions	
Audi A3	2013-2018	8V	19 Gateway Data Bus	Read Fault Codes	
Audi A3	2013-2018	8V	19 Gateway Data Bus	Clear Fault Codes	
Audi A3	2013-2018	8V	19 Gateway Data Bus	Measuring Blocks	
Audi A3	2013-2018	8V	19 Gateway Data Bus	Output Tests	
Audi A3	2013-2018	8V	19 Gateway Data Bus	Specia Functions	
Audi A3	2013-2018	8V	20 High Beam Assistance Device	Read Fault Codes	
Audi A3	2013-2018	8V	20 High Beam Assistance Device	Clear Fault Codes	
Audi A3	2013-2018	8V	20 High Beam Assistance Device	Measuring Blocks	
Audi A3	2013-2018	8V	20 High Beam Assistance Device	Output Tests	
Audi A3	2013-2018	8V	20 High Beam Assistance Device	Specia Functions	
Audi A3	2013-2018	8V	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2013-2018	8V	22 4WD Electronics	Clear Fault Codes	
Audi A3	2013-2018	8V	22 4WD Electronics	Measuring Blocks	
Audi A3	2013-2018	8V	22 4WD Electronics	Output Tests	
Audi A3	2013-2018	8V	22 4WD Electronics	Specia Functions	
Audi A3	2013-2018	8V	23 Braker Booster	Read Fault Codes	
Audi A3	2013-2018	8V	23 Braker Booster	Clear Fault Codes	
Audi A3	2013-2018	8V	23 Braker Booster	Measuring Blocks	
Audi A3	2013-2018	8V	23 Braker Booster	Output Tests	
Audi A3	2013-2018	8V	23 Braker Booster	Specia Functions	
Audi A3	2013-2018	8V	26 Electric Roof Control	Read Fault Codes	
Audi A3	2013-2018	8V	26 Electric Roof Control	Clear Fault Codes	
Audi A3	2013-2018	8V	26 Electric Roof Control	Measuring Blocks	
Audi A3	2013-2018	8V	26 Electric Roof Control	Output Tests	
Audi A3	2013-2018	8V	26 Electric Roof Control	Specia Functions	
Audi A3	2013-2018	8V	29 Left Light Control	Read Fault Codes	
Audi A3	2013-2018	8V	29 Left Light Control	Clear Fault Codes	
Audi A3	2013-2018	8V	29 Left Light Control	Measuring Blocks	
Audi A3	2013-2018	8V	29 Left Light Control	Output Tests	
Audi A3	2013-2018	8V	29 Left Light Control	Specia Functions	
Audi A3	2013-2018	8V	2B Steer Col Lock	Read Fault Codes	
Audi A3	2013-2018	8V	2B Steer Col Lock	Clear Fault Codes	
Audi A3	2013-2018	8V	2B Steer Col Lock	Measuring Blocks	
Audi A3	2013-2018	8V	2B Steer Col Lock	Output Tests	
Audi A3	2013-2018	8V	2B Steer Col Lock	Specia Functions	
Audi A3	2013-2018	8V	30 Special Function 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2013-2018	8V	30 Special Function 2	Clear Fault Codes	
Audi A3	2013-2018	8V	30 Special Function 2	Measuring Blocks	
Audi A3	2013-2018	8V	30 Special Function 2	Output Tests	
Audi A3	2013-2018	8V	30 Special Function 2	Specia Functions	
Audi A3	2013-2018	8V	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A3	2013-2018	8V	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A3	2013-2018	8V	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A3	2013-2018	8V	36 Side of Driver Seat Adj.	Output Tests	
Audi A3	2013-2018	8V	36 Side of Driver Seat Adj.	Specia Functions	
Audi A3	2013-2018	8V	39 Right Light Control	Read Fault Codes	
Audi A3	2013-2018	8V	39 Right Light Control	Clear Fault Codes	
Audi A3	2013-2018	8V	39 Right Light Control	Measuring Blocks	
Audi A3	2013-2018	8V	39 Right Light Control	Output Tests	
Audi A3	2013-2018	8V	39 Right Light Control	Specia Functions	
Audi A3	2013-2018	8V	3C Lane Departure Assistance System	Read Fault Codes	
Audi A3	2013-2018	8V	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A3	2013-2018	8V	3C Lane Departure Assistance System	Measuring Blocks	
Audi A3	2013-2018	8V	3C Lane Departure Assistance System	Output Tests	
Audi A3	2013-2018	8V	3C Lane Departure Assistance System	Specia Functions	
Audi A3	2013-2018	8V	3D Special Function	Read Fault Codes	
Audi A3	2013-2018	8V	3D Special Function	Clear Fault Codes	
Audi A3	2013-2018	8V	3D Special Function	Measuring Blocks	
Audi A3	2013-2018	8V	3D Special Function	Output Tests	
Audi A3	2013-2018	8V	3D Special Function	Specia Functions	
Audi A3	2013-2018	8V	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2013-2018	8V	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3	2013-2018	8V	42 Driver-Door Elect.	Measuring Blocks	
Audi A3	2013-2018	8V	42 Driver-Door Elect.	Output Tests	
Audi A3	2013-2018	8V	42 Driver-Door Elect.	Specia Functions	
Audi A3	2013-2018	8V	44 Steering Assistance	Read Fault Codes	
Audi A3	2013-2018	8V	44 Steering Assistance	Clear Fault Codes	
Audi A3	2013-2018	8V	44 Steering Assistance	Measuring Blocks	
Audi A3	2013-2018	8V	44 Steering Assistance	Output Tests	
Audi A3	2013-2018	8V	44 Steering Assistance	Specia Functions	
Audi A3	2013-2018	8V	47 Soundsystem	Read Fault Codes	
Audi A3	2013-2018	8V	47 Soundsystem	Clear Fault Codes	
Audi A3	2013-2018	8V	47 Soundsystem	Measuring Blocks	
Audi A3	2013-2018	8V	47 Soundsystem	Output Tests	
Audi A3	2013-2018	8V	47 Soundsystem	Specia Functions	
Audi A3	2013-2018	8V	51 Electric Drive	Read Fault Codes	
Audi A3	2013-2018	8V	51 Electric Drive	Clear Fault Codes	
Audi A3	2013-2018	8V	51 Electric Drive	Measuring Blocks	
Audi A3	2013-2018	8V	51 Electric Drive	Output Tests	
Audi A3	2013-2018	8V	51 Electric Drive	Specia Functions	
Audi A3	2013-2018	8V	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3	2013-2018	8V	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3	2013-2018	8V	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3	2013-2018	8V	52 Passe.-Door Elect.	Output Tests	
Audi A3	2013-2018	8V	52 Passe.-Door Elect.	Specia Functions	
Audi A3	2013-2018	8V	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2013-2018	8V	55 Headlight Range Control	Clear Fault Codes	
Audi A3	2013-2018	8V	55 Headlight Range Control	Measuring Blocks	
Audi A3	2013-2018	8V	55 Headlight Range Control	Output Tests	
Audi A3	2013-2018	8V	55 Headlight Range Control	Specia Functions	
Audi A3	2013-2018	8V	57 TV-Tuner	Read Fault Codes	
Audi A3	2013-2018	8V	57 TV-Tuner	Clear Fault Codes	
Audi A3	2013-2018	8V	57 TV-Tuner	Measuring Blocks	
Audi A3	2013-2018	8V	57 TV-Tuner	Output Tests	
Audi A3	2013-2018	8V	57 TV-Tuner	Specia Functions	
Audi A3	2013-2018	8V	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A3	2013-2018	8V	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A3	2013-2018	8V	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A3	2013-2018	8V	5F Information Electronic Equipment 1	Output Tests	
Audi A3	2013-2018	8V	5F Information Electronic Equipment 1	Specia Functions	
Audi A3	2013-2018	8V	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A3	2013-2018	8V	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A3	2013-2018	8V	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A3	2013-2018	8V	65 Tyre Pressure Monitoring	Output Tests	
Audi A3	2013-2018	8V	65 Tyre Pressure Monitoring	Specia Functions	
Audi A3	2013-2018	8V	69 Trailer Function	Read Fault Codes	
Audi A3	2013-2018	8V	69 Trailer Function	Clear Fault Codes	
Audi A3	2013-2018	8V	69 Trailer Function	Measuring Blocks	
Audi A3	2013-2018	8V	69 Trailer Function	Output Tests	
Audi A3	2013-2018	8V	69 Trailer Function	Specia Functions	
Audi A3	2013-2018	8V	6C Rear Camera	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2013-2018	8V	6C Rear Camera	Clear Fault Codes	
Audi A3	2013-2018	8V	6C Rear Camera	Measuring Blocks	
Audi A3	2013-2018	8V	6C Rear Camera	Output Tests	
Audi A3	2013-2018	8V	6C Rear Camera	Specia Functions	
Audi A3	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A3	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A3	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A3	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A3	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A3	2013-2018	8V	75 Emergency Call Module	Read Fault Codes	
Audi A3	2013-2018	8V	75 Emergency Call Module	Clear Fault Codes	
Audi A3	2013-2018	8V	75 Emergency Call Module	Measuring Blocks	
Audi A3	2013-2018	8V	75 Emergency Call Module	Output Tests	
Audi A3	2013-2018	8V	75 Emergency Call Module	Specia Functions	
Audi A3	2013-2018	8V	76 Parking Aid	Read Fault Codes	
Audi A3	2013-2018	8V	76 Parking Aid	Clear Fault Codes	
Audi A3	2013-2018	8V	76 Parking Aid	Measuring Blocks	
Audi A3	2013-2018	8V	76 Parking Aid	Output Tests	
Audi A3	2013-2018	8V	76 Parking Aid	Specia Functions	
Audi A3	2013-2018	8V	82 Heads Up Display	Read Fault Codes	
Audi A3	2013-2018	8V	82 Heads Up Display	Clear Fault Codes	
Audi A3	2013-2018	8V	82 Heads Up Display	Measuring Blocks	
Audi A3	2013-2018	8V	82 Heads Up Display	Output Tests	
Audi A3	2013-2018	8V	82 Heads Up Display	Specia Functions	
Audi A3	2013-2018	8V	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2013-2018	8V	8C Hybrid Battery	Clear Fault Codes	
Audi A3	2013-2018	8V	8C Hybrid Battery	Measuring Blocks	
Audi A3	2013-2018	8V	8C Hybrid Battery	Output Tests	
Audi A3	2013-2018	8V	8C Hybrid Battery	Specia Functions	
Audi A3	2013-2018	8V	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A3	2013-2018	8V	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A3	2013-2018	8V	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A3	2013-2018	8V	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A3	2013-2018	8V	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A3	2013-2018	8V	A6 Microphone	Read Fault Codes	
Audi A3	2013-2018	8V	A6 Microphone	Clear Fault Codes	
Audi A3	2013-2018	8V	A6 Microphone	Measuring Blocks	
Audi A3	2013-2018	8V	A6 Microphone	Output Tests	
Audi A3	2013-2018	8V	A6 Microphone	Specia Functions	
Audi A3	2013-2018	8V	A9 Struct.Borne Sound	Read Fault Codes	
Audi A3	2013-2018	8V	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A3	2013-2018	8V	A9 Struct.Borne Sound	Measuring Blocks	
Audi A3	2013-2018	8V	A9 Struct.Borne Sound	Output Tests	
Audi A3	2013-2018	8V	A9 Struct.Borne Sound	Specia Functions	
Audi A3	2013-2018	8V	B7 Access Start Interf	Read Fault Codes	
Audi A3	2013-2018	8V	B7 Access Start Interf	Clear Fault Codes	
Audi A3	2013-2018	8V	B7 Access Start Interf	Measuring Blocks	
Audi A3	2013-2018	8V	B7 Access Start Interf	Output Tests	
Audi A3	2013-2018	8V	B7 Access Start Interf	Specia Functions	
Audi A3	2013-2018	8V	BB Door Rear Drv Side	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2013-2018	8V	BB Door Rear Drv Side	Clear Fault Codes	
Audi A3	2013-2018	8V	BB Door Rear Drv Side	Measuring Blocks	
Audi A3	2013-2018	8V	BB Door Rear Drv Side	Output Tests	
Audi A3	2013-2018	8V	BB Door Rear Drv Side	Specia Functions	
Audi A3	2013-2018	8V	BC Door Rear Pass Side	Read Fault Codes	
Audi A3	2013-2018	8V	BC Door Rear Pass Side	Clear Fault Codes	
Audi A3	2013-2018	8V	BC Door Rear Pass Side	Measuring Blocks	
Audi A3	2013-2018	8V	BC Door Rear Pass Side	Output Tests	
Audi A3	2013-2018	8V	BC Door Rear Pass Side	Specia Functions	
Audi A3	2013-2018	8V	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A3	2013-2018	8V	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A3	2013-2018	8V	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A3	2013-2018	8V	C0 Act. For Ext. Noise	Output Tests	
Audi A3	2013-2018	8V	C0 Act. For Ext. Noise	Specia Functions	
Audi A3	2013-2018	8V	C6 Batt. Chrg	Read Fault Codes	
Audi A3	2013-2018	8V	C6 Batt. Chrg	Clear Fault Codes	
Audi A3	2013-2018	8V	C6 Batt. Chrg	Measuring Blocks	
Audi A3	2013-2018	8V	C6 Batt. Chrg	Output Tests	
Audi A3	2013-2018	8V	C6 Batt. Chrg	Specia Functions	
Audi S3	2013-2018	8V	01 Engine Electronics	Read Fault Codes	
Audi S3	2013-2018	8V	01 Engine Electronics	Clear Fault Codes	
Audi S3	2013-2018	8V	01 Engine Electronics	Measuring Blocks	
Audi S3	2013-2018	8V	01 Engine Electronics	Output Tests	
Audi S3	2013-2018	8V	01 Engine Electronics	Specia Functions	
Audi S3	2013-2018	8V	02 Transmission Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2013-2018	8V	02 Transmission Electronics	Clear Fault Codes	
Audi S3	2013-2018	8V	02 Transmission Electronics	Measuring Blocks	
Audi S3	2013-2018	8V	02 Transmission Electronics	Output Tests	
Audi S3	2013-2018	8V	02 Transmission Electronics	Specia Functions	
Audi S3	2013-2018	8V	03 Brake Electronics	Read Fault Codes	
Audi S3	2013-2018	8V	03 Brake Electronics	Clear Fault Codes	
Audi S3	2013-2018	8V	03 Brake Electronics	Measuring Blocks	
Audi S3	2013-2018	8V	03 Brake Electronics	Output Tests	
Audi S3	2013-2018	8V	03 Brake Electronics	Specia Functions	
Audi S3	2013-2018	8V	06 Passene. Seat Adj.	Read Fault Codes	
Audi S3	2013-2018	8V	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S3	2013-2018	8V	06 Passene. Seat Adj.	Measuring Blocks	
Audi S3	2013-2018	8V	06 Passene. Seat Adj.	Output Tests	
Audi S3	2013-2018	8V	06 Passene. Seat Adj.	Specia Functions	
Audi S3	2013-2018	8V	08 AC/Heating Electronics	Read Fault Codes	
Audi S3	2013-2018	8V	08 AC/Heating Electronics	Clear Fault Codes	
Audi S3	2013-2018	8V	08 AC/Heating Electronics	Measuring Blocks	
Audi S3	2013-2018	8V	08 AC/Heating Electronics	Output Tests	
Audi S3	2013-2018	8V	08 AC/Heating Electronics	Specia Functions	
Audi S3	2013-2018	8V	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S3	2013-2018	8V	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S3	2013-2018	8V	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S3	2013-2018	8V	09 Electronic Ctrl Electronics	Output Tests	
Audi S3	2013-2018	8V	09 Electronic Ctrl Electronics	Specia Functions	
Audi S3	2013-2018	8V	13 Distance Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2013-2018	8V	13 Distance Control	Clear Fault Codes	
Audi S3	2013-2018	8V	13 Distance Control	Measuring Blocks	
Audi S3	2013-2018	8V	13 Distance Control	Output Tests	
Audi S3	2013-2018	8V	13 Distance Control	Specia Functions	
Audi S3	2013-2018	8V	14 Wheel Damping Electronics	Read Fault Codes	
Audi S3	2013-2018	8V	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S3	2013-2018	8V	14 Wheel Damping Electronics	Measuring Blocks	
Audi S3	2013-2018	8V	14 Wheel Damping Electronics	Output Tests	
Audi S3	2013-2018	8V	14 Wheel Damping Electronics	Specia Functions	
Audi S3	2013-2018	8V	15 Airbags	Read Fault Codes	
Audi S3	2013-2018	8V	15 Airbags	Clear Fault Codes	
Audi S3	2013-2018	8V	15 Airbags	Measuring Blocks	
Audi S3	2013-2018	8V	15 Airbags	Output Tests	
Audi S3	2013-2018	8V	15 Airbags	Specia Functions	
Audi S3	2013-2018	8V	16 Steering Wheel Electronics	Read Fault Codes	
Audi S3	2013-2018	8V	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S3	2013-2018	8V	16 Steering Wheel Electronics	Measuring Blocks	
Audi S3	2013-2018	8V	16 Steering Wheel Electronics	Output Tests	
Audi S3	2013-2018	8V	16 Steering Wheel Electronics	Specia Functions	
Audi S3	2013-2018	8V	17 Instrument Cluster	Read Fault Codes	
Audi S3	2013-2018	8V	17 Instrument Cluster	Clear Fault Codes	
Audi S3	2013-2018	8V	17 Instrument Cluster	Measuring Blocks	
Audi S3	2013-2018	8V	17 Instrument Cluster	Output Tests	
Audi S3	2013-2018	8V	17 Instrument Cluster	Specia Functions	
Audi S3	2013-2018	8V	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2013-2018	8V	18 Aux Heating	Clear Fault Codes	
Audi S3	2013-2018	8V	18 Aux Heating	Measuring Blocks	
Audi S3	2013-2018	8V	18 Aux Heating	Output Tests	
Audi S3	2013-2018	8V	18 Aux Heating	Specia Functions	
Audi S3	2013-2018	8V	19 Gateway Data Bus	Read Fault Codes	
Audi S3	2013-2018	8V	19 Gateway Data Bus	Clear Fault Codes	
Audi S3	2013-2018	8V	19 Gateway Data Bus	Measuring Blocks	
Audi S3	2013-2018	8V	19 Gateway Data Bus	Output Tests	
Audi S3	2013-2018	8V	19 Gateway Data Bus	Specia Functions	
Audi S3	2013-2018	8V	20 High Beam Assistance Device	Read Fault Codes	
Audi S3	2013-2018	8V	20 High Beam Assistance Device	Clear Fault Codes	
Audi S3	2013-2018	8V	20 High Beam Assistance Device	Measuring Blocks	
Audi S3	2013-2018	8V	20 High Beam Assistance Device	Output Tests	
Audi S3	2013-2018	8V	20 High Beam Assistance Device	Specia Functions	
Audi S3	2013-2018	8V	22 4WD Electronics	Read Fault Codes	
Audi S3	2013-2018	8V	22 4WD Electronics	Clear Fault Codes	
Audi S3	2013-2018	8V	22 4WD Electronics	Measuring Blocks	
Audi S3	2013-2018	8V	22 4WD Electronics	Output Tests	
Audi S3	2013-2018	8V	22 4WD Electronics	Specia Functions	
Audi S3	2013-2018	8V	23 Braker Booster	Read Fault Codes	
Audi S3	2013-2018	8V	23 Braker Booster	Clear Fault Codes	
Audi S3	2013-2018	8V	23 Braker Booster	Measuring Blocks	
Audi S3	2013-2018	8V	23 Braker Booster	Output Tests	
Audi S3	2013-2018	8V	23 Braker Booster	Specia Functions	
Audi S3	2013-2018	8V	26 Electric Roof Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2013-2018	8V	26 Electric Roof Control	Clear Fault Codes	
Audi S3	2013-2018	8V	26 Electric Roof Control	Measuring Blocks	
Audi S3	2013-2018	8V	26 Electric Roof Control	Output Tests	
Audi S3	2013-2018	8V	26 Electric Roof Control	Specia Functions	
Audi S3	2013-2018	8V	29 Left Light Control	Read Fault Codes	
Audi S3	2013-2018	8V	29 Left Light Control	Clear Fault Codes	
Audi S3	2013-2018	8V	29 Left Light Control	Measuring Blocks	
Audi S3	2013-2018	8V	29 Left Light Control	Output Tests	
Audi S3	2013-2018	8V	29 Left Light Control	Specia Functions	
Audi S3	2013-2018	8V	2B Steer Col Lock	Read Fault Codes	
Audi S3	2013-2018	8V	2B Steer Col Lock	Clear Fault Codes	
Audi S3	2013-2018	8V	2B Steer Col Lock	Measuring Blocks	
Audi S3	2013-2018	8V	2B Steer Col Lock	Output Tests	
Audi S3	2013-2018	8V	2B Steer Col Lock	Specia Functions	
Audi S3	2013-2018	8V	30 Special Function 2	Read Fault Codes	
Audi S3	2013-2018	8V	30 Special Function 2	Clear Fault Codes	
Audi S3	2013-2018	8V	30 Special Function 2	Measuring Blocks	
Audi S3	2013-2018	8V	30 Special Function 2	Output Tests	
Audi S3	2013-2018	8V	30 Special Function 2	Specia Functions	
Audi S3	2013-2018	8V	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi S3	2013-2018	8V	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S3	2013-2018	8V	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S3	2013-2018	8V	36 Side of Driver Seat Adj.	Output Tests	
Audi S3	2013-2018	8V	36 Side of Driver Seat Adj.	Specia Functions	
Audi S3	2013-2018	8V	39 Right Light Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2013-2018	8V	39 Right Light Control	Clear Fault Codes	
Audi S3	2013-2018	8V	39 Right Light Control	Measuring Blocks	
Audi S3	2013-2018	8V	39 Right Light Control	Output Tests	
Audi S3	2013-2018	8V	39 Right Light Control	Specia Functions	
Audi S3	2013-2018	8V	3C Lane Departure Assistance System	Read Fault Codes	
Audi S3	2013-2018	8V	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S3	2013-2018	8V	3C Lane Departure Assistance System	Measuring Blocks	
Audi S3	2013-2018	8V	3C Lane Departure Assistance System	Output Tests	
Audi S3	2013-2018	8V	3C Lane Departure Assistance System	Specia Functions	
Audi S3	2013-2018	8V	3D Special Function	Read Fault Codes	
Audi S3	2013-2018	8V	3D Special Function	Clear Fault Codes	
Audi S3	2013-2018	8V	3D Special Function	Measuring Blocks	
Audi S3	2013-2018	8V	3D Special Function	Output Tests	
Audi S3	2013-2018	8V	3D Special Function	Specia Functions	
Audi S3	2013-2018	8V	42 Driver-Door Elect.	Read Fault Codes	
Audi S3	2013-2018	8V	42 Driver-Door Elect.	Clear Fault Codes	
Audi S3	2013-2018	8V	42 Driver-Door Elect.	Measuring Blocks	
Audi S3	2013-2018	8V	42 Driver-Door Elect.	Output Tests	
Audi S3	2013-2018	8V	42 Driver-Door Elect.	Specia Functions	
Audi S3	2013-2018	8V	44 Steering Assistance	Read Fault Codes	
Audi S3	2013-2018	8V	44 Steering Assistance	Clear Fault Codes	
Audi S3	2013-2018	8V	44 Steering Assistance	Measuring Blocks	
Audi S3	2013-2018	8V	44 Steering Assistance	Output Tests	
Audi S3	2013-2018	8V	44 Steering Assistance	Specia Functions	
Audi S3	2013-2018	8V	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2013-2018	8V	47 Soundsystem	Clear Fault Codes	
Audi S3	2013-2018	8V	47 Soundsystem	Measuring Blocks	
Audi S3	2013-2018	8V	47 Soundsystem	Output Tests	
Audi S3	2013-2018	8V	47 Soundsystem	Specia Functions	
Audi S3	2013-2018	8V	51 Electric Drive	Read Fault Codes	
Audi S3	2013-2018	8V	51 Electric Drive	Clear Fault Codes	
Audi S3	2013-2018	8V	51 Electric Drive	Measuring Blocks	
Audi S3	2013-2018	8V	51 Electric Drive	Output Tests	
Audi S3	2013-2018	8V	51 Electric Drive	Specia Functions	
Audi S3	2013-2018	8V	52 Passe.-Door Elect.	Read Fault Codes	
Audi S3	2013-2018	8V	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S3	2013-2018	8V	52 Passe.-Door Elect.	Measuring Blocks	
Audi S3	2013-2018	8V	52 Passe.-Door Elect.	Output Tests	
Audi S3	2013-2018	8V	52 Passe.-Door Elect.	Specia Functions	
Audi S3	2013-2018	8V	55 Headlight Range Control	Read Fault Codes	
Audi S3	2013-2018	8V	55 Headlight Range Control	Clear Fault Codes	
Audi S3	2013-2018	8V	55 Headlight Range Control	Measuring Blocks	
Audi S3	2013-2018	8V	55 Headlight Range Control	Output Tests	
Audi S3	2013-2018	8V	55 Headlight Range Control	Specia Functions	
Audi S3	2013-2018	8V	57 TV-Tuner	Read Fault Codes	
Audi S3	2013-2018	8V	57 TV-Tuner	Clear Fault Codes	
Audi S3	2013-2018	8V	57 TV-Tuner	Measuring Blocks	
Audi S3	2013-2018	8V	57 TV-Tuner	Output Tests	
Audi S3	2013-2018	8V	57 TV-Tuner	Specia Functions	
Audi S3	2013-2018	8V	5F Information Electronic Equipment 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2013-2018	8V	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S3	2013-2018	8V	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S3	2013-2018	8V	5F Information Electronic Equipment 1	Output Tests	
Audi S3	2013-2018	8V	5F Information Electronic Equipment 1	Specia Functions	
Audi S3	2013-2018	8V	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi S3	2013-2018	8V	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S3	2013-2018	8V	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S3	2013-2018	8V	65 Tyre Pressure Monitoring	Output Tests	
Audi S3	2013-2018	8V	65 Tyre Pressure Monitoring	Specia Functions	
Audi S3	2013-2018	8V	69 Trailer Function	Read Fault Codes	
Audi S3	2013-2018	8V	69 Trailer Function	Clear Fault Codes	
Audi S3	2013-2018	8V	69 Trailer Function	Measuring Blocks	
Audi S3	2013-2018	8V	69 Trailer Function	Output Tests	
Audi S3	2013-2018	8V	69 Trailer Function	Specia Functions	
Audi S3	2013-2018	8V	6C Rear Camera	Read Fault Codes	
Audi S3	2013-2018	8V	6C Rear Camera	Clear Fault Codes	
Audi S3	2013-2018	8V	6C Rear Camera	Measuring Blocks	
Audi S3	2013-2018	8V	6C Rear Camera	Output Tests	
Audi S3	2013-2018	8V	6C Rear Camera	Specia Functions	
Audi S3	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S3	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S3	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S3	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S3	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S3	2013-2018	8V	75 Emergency Call Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2013-2018	8V	75 Emergency Call Module	Clear Fault Codes	
Audi S3	2013-2018	8V	75 Emergency Call Module	Measuring Blocks	
Audi S3	2013-2018	8V	75 Emergency Call Module	Output Tests	
Audi S3	2013-2018	8V	75 Emergency Call Module	Specia Functions	
Audi S3	2013-2018	8V	76 Parking Aid	Read Fault Codes	
Audi S3	2013-2018	8V	76 Parking Aid	Clear Fault Codes	
Audi S3	2013-2018	8V	76 Parking Aid	Measuring Blocks	
Audi S3	2013-2018	8V	76 Parking Aid	Output Tests	
Audi S3	2013-2018	8V	76 Parking Aid	Specia Functions	
Audi S3	2013-2018	8V	82 Heads Up Display	Read Fault Codes	
Audi S3	2013-2018	8V	82 Heads Up Display	Clear Fault Codes	
Audi S3	2013-2018	8V	82 Heads Up Display	Measuring Blocks	
Audi S3	2013-2018	8V	82 Heads Up Display	Output Tests	
Audi S3	2013-2018	8V	82 Heads Up Display	Specia Functions	
Audi S3	2013-2018	8V	8C Hybrid Battery	Read Fault Codes	
Audi S3	2013-2018	8V	8C Hybrid Battery	Clear Fault Codes	
Audi S3	2013-2018	8V	8C Hybrid Battery	Measuring Blocks	
Audi S3	2013-2018	8V	8C Hybrid Battery	Output Tests	
Audi S3	2013-2018	8V	8C Hybrid Battery	Specia Functions	
Audi S3	2013-2018	8V	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi S3	2013-2018	8V	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi S3	2013-2018	8V	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi S3	2013-2018	8V	A5 Frt Sens.Drv.Assist	Output Tests	
Audi S3	2013-2018	8V	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi S3	2013-2018	8V	A6 Microphone	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2013-2018	8V	A6 Microphone	Clear Fault Codes	
Audi S3	2013-2018	8V	A6 Microphone	Measuring Blocks	
Audi S3	2013-2018	8V	A6 Microphone	Output Tests	
Audi S3	2013-2018	8V	A6 Microphone	Specia Functions	
Audi S3	2013-2018	8V	A9 Struct.Borne Sound	Read Fault Codes	
Audi S3	2013-2018	8V	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S3	2013-2018	8V	A9 Struct.Borne Sound	Measuring Blocks	
Audi S3	2013-2018	8V	A9 Struct.Borne Sound	Output Tests	
Audi S3	2013-2018	8V	A9 Struct.Borne Sound	Specia Functions	
Audi S3	2013-2018	8V	B7 Access Start Interf	Read Fault Codes	
Audi S3	2013-2018	8V	B7 Access Start Interf	Clear Fault Codes	
Audi S3	2013-2018	8V	B7 Access Start Interf	Measuring Blocks	
Audi S3	2013-2018	8V	B7 Access Start Interf	Output Tests	
Audi S3	2013-2018	8V	B7 Access Start Interf	Specia Functions	
Audi S3	2013-2018	8V	BB Door Rear Drv Side	Read Fault Codes	
Audi S3	2013-2018	8V	BB Door Rear Drv Side	Clear Fault Codes	
Audi S3	2013-2018	8V	BB Door Rear Drv Side	Measuring Blocks	
Audi S3	2013-2018	8V	BB Door Rear Drv Side	Output Tests	
Audi S3	2013-2018	8V	BB Door Rear Drv Side	Specia Functions	
Audi S3	2013-2018	8V	BC Door Rear Pass Side	Read Fault Codes	
Audi S3	2013-2018	8V	BC Door Rear Pass Side	Clear Fault Codes	
Audi S3	2013-2018	8V	BC Door Rear Pass Side	Measuring Blocks	
Audi S3	2013-2018	8V	BC Door Rear Pass Side	Output Tests	
Audi S3	2013-2018	8V	BC Door Rear Pass Side	Specia Functions	
Audi S3	2013-2018	8V	C0 Act. For Ext. Noise	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3	2013-2018	8V	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi S3	2013-2018	8V	C0 Act. For Ext. Noise	Measuring Blocks	
Audi S3	2013-2018	8V	C0 Act. For Ext. Noise	Output Tests	
Audi S3	2013-2018	8V	C0 Act. For Ext. Noise	Specia Functions	
Audi S3	2013-2018	8V	C6 Batt. Chrg	Read Fault Codes	
Audi S3	2013-2018	8V	C6 Batt. Chrg	Clear Fault Codes	
Audi S3	2013-2018	8V	C6 Batt. Chrg	Measuring Blocks	
Audi S3	2013-2018	8V	C6 Batt. Chrg	Output Tests	
Audi S3	2013-2018	8V	C6 Batt. Chrg	Specia Functions	
Audi A3 Sportback	2015-2018	FF	01 Engine Electronics	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	01 Engine Electronics	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	01 Engine Electronics	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	01 Engine Electronics	Output Tests	
Audi A3 Sportback	2015-2018	FF	01 Engine Electronics	Specia Functions	
Audi A3 Sportback	2015-2018	FF	02 Transmission Electronics	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	02 Transmission Electronics	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	02 Transmission Electronics	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	02 Transmission Electronics	Output Tests	
Audi A3 Sportback	2015-2018	FF	02 Transmission Electronics	Specia Functions	
Audi A3 Sportback	2015-2018	FF	03 Brake Electronics	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	03 Brake Electronics	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	03 Brake Electronics	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	03 Brake Electronics	Output Tests	
Audi A3 Sportback	2015-2018	FF	03 Brake Electronics	Specia Functions	
Audi A3 Sportback	2015-2018	FF	06 Passene. Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportback	2015-2018	FF	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	06 Passene. Seat Adj.	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	06 Passene. Seat Adj.	Output Tests	
Audi A3 Sportback	2015-2018	FF	06 Passene. Seat Adj.	Specia Functions	
Audi A3 Sportback	2015-2018	FF	08 AC/Heating Electronics	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	08 AC/Heating Electronics	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	08 AC/Heating Electronics	Output Tests	
Audi A3 Sportback	2015-2018	FF	08 AC/Heating Electronics	Specia Functions	
Audi A3 Sportback	2015-2018	FF	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	09 Electronic Ctrl Electronics	Output Tests	
Audi A3 Sportback	2015-2018	FF	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3 Sportback	2015-2018	FF	13 Distance Control	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	13 Distance Control	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	13 Distance Control	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	13 Distance Control	Output Tests	
Audi A3 Sportback	2015-2018	FF	13 Distance Control	Specia Functions	
Audi A3 Sportback	2015-2018	FF	14 Wheel Damping Electronics	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	14 Wheel Damping Electronics	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	14 Wheel Damping Electronics	Output Tests	
Audi A3 Sportback	2015-2018	FF	14 Wheel Damping Electronics	Specia Functions	
Audi A3 Sportback	2015-2018	FF	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportback	2015-2018	FF	15 Airbags	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	15 Airbags	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	15 Airbags	Output Tests	
Audi A3 Sportback	2015-2018	FF	15 Airbags	Specia Functions	
Audi A3 Sportback	2015-2018	FF	16 Steering Wheel Electronics	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	16 Steering Wheel Electronics	Output Tests	
Audi A3 Sportback	2015-2018	FF	16 Steering Wheel Electronics	Specia Functions	
Audi A3 Sportback	2015-2018	FF	17 Instrument Cluster	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	17 Instrument Cluster	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	17 Instrument Cluster	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	17 Instrument Cluster	Output Tests	
Audi A3 Sportback	2015-2018	FF	17 Instrument Cluster	Specia Functions	
Audi A3 Sportback	2015-2018	FF	18 Aux Heating	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	18 Aux Heating	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	18 Aux Heating	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	18 Aux Heating	Output Tests	
Audi A3 Sportback	2015-2018	FF	18 Aux Heating	Specia Functions	
Audi A3 Sportback	2015-2018	FF	19 Gateway Data Bus	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	19 Gateway Data Bus	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	19 Gateway Data Bus	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	19 Gateway Data Bus	Output Tests	
Audi A3 Sportback	2015-2018	FF	19 Gateway Data Bus	Specia Functions	
Audi A3 Sportback	2015-2018	FF	20 High Beam Assistance Device	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportback	2015-2018	FF	20 High Beam Assistance Device	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	20 High Beam Assistance Device	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	20 High Beam Assistance Device	Output Tests	
Audi A3 Sportback	2015-2018	FF	20 High Beam Assistance Device	Specia Functions	
Audi A3 Sportback	2015-2018	FF	22 4WD Electronics	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	22 4WD Electronics	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	22 4WD Electronics	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	22 4WD Electronics	Output Tests	
Audi A3 Sportback	2015-2018	FF	22 4WD Electronics	Specia Functions	
Audi A3 Sportback	2015-2018	FF	23 Braker Booster	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	23 Braker Booster	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	23 Braker Booster	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	23 Braker Booster	Output Tests	
Audi A3 Sportback	2015-2018	FF	23 Braker Booster	Specia Functions	
Audi A3 Sportback	2015-2018	FF	26 Electric Roof Control	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	26 Electric Roof Control	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	26 Electric Roof Control	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	26 Electric Roof Control	Output Tests	
Audi A3 Sportback	2015-2018	FF	26 Electric Roof Control	Specia Functions	
Audi A3 Sportback	2015-2018	FF	29 Left Light Control	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	29 Left Light Control	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	29 Left Light Control	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	29 Left Light Control	Output Tests	
Audi A3 Sportback	2015-2018	FF	29 Left Light Control	Specia Functions	
Audi A3 Sportback	2015-2018	FF	2B Steer Col Lock	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportback	2015-2018	FF	2B Steer Col Lock	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	2B Steer Col Lock	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	2B Steer Col Lock	Output Tests	
Audi A3 Sportback	2015-2018	FF	2B Steer Col Lock	Specia Functions	
Audi A3 Sportback	2015-2018	FF	30 Special Function 2	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	30 Special Function 2	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	30 Special Function 2	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	30 Special Function 2	Output Tests	
Audi A3 Sportback	2015-2018	FF	30 Special Function 2	Specia Functions	
Audi A3 Sportback	2015-2018	FF	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	36 Side of Driver Seat Adj.	Output Tests	
Audi A3 Sportback	2015-2018	FF	36 Side of Driver Seat Adj.	Specia Functions	
Audi A3 Sportback	2015-2018	FF	39 Right Light Control	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	39 Right Light Control	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	39 Right Light Control	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	39 Right Light Control	Output Tests	
Audi A3 Sportback	2015-2018	FF	39 Right Light Control	Specia Functions	
Audi A3 Sportback	2015-2018	FF	3C Lane Departure Assistance System	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	3C Lane Departure Assistance System	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	3C Lane Departure Assistance System	Output Tests	
Audi A3 Sportback	2015-2018	FF	3C Lane Departure Assistance System	Specia Functions	
Audi A3 Sportback	2015-2018	FF	3D Special Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportback	2015-2018	FF	3D Special Function	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	3D Special Function	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	3D Special Function	Output Tests	
Audi A3 Sportback	2015-2018	FF	3D Special Function	Specia Functions	
Audi A3 Sportback	2015-2018	FF	42 Driver-Door Elect.	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	42 Driver-Door Elect.	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	42 Driver-Door Elect.	Output Tests	
Audi A3 Sportback	2015-2018	FF	42 Driver-Door Elect.	Specia Functions	
Audi A3 Sportback	2015-2018	FF	44 Steering Assistance	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	44 Steering Assistance	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	44 Steering Assistance	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	44 Steering Assistance	Output Tests	
Audi A3 Sportback	2015-2018	FF	44 Steering Assistance	Specia Functions	
Audi A3 Sportback	2015-2018	FF	47 Soundsystem	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	47 Soundsystem	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	47 Soundsystem	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	47 Soundsystem	Output Tests	
Audi A3 Sportback	2015-2018	FF	47 Soundsystem	Specia Functions	
Audi A3 Sportback	2015-2018	FF	51 Electric Drive	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	51 Electric Drive	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	51 Electric Drive	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	51 Electric Drive	Output Tests	
Audi A3 Sportback	2015-2018	FF	51 Electric Drive	Specia Functions	
Audi A3 Sportback	2015-2018	FF	52 Passe.-Door Elect.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3 Sportback	2015-2018	FF	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	52 Passe.-Door Elect.	Output Tests	
Audi A3 Sportback	2015-2018	FF	52 Passe.-Door Elect.	Specia Functions	
Audi A3 Sportback	2015-2018	FF	55 Headlight Range Control	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	55 Headlight Range Control	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	55 Headlight Range Control	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	55 Headlight Range Control	Output Tests	
Audi A3 Sportback	2015-2018	FF	55 Headlight Range Control	Specia Functions	
Audi A3 Sportback	2015-2018	FF	57 TV-Tuner	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	57 TV-Tuner	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	57 TV-Tuner	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	57 TV-Tuner	Output Tests	
Audi A3 Sportback	2015-2018	FF	57 TV-Tuner	Specia Functions	
Audi A3 Sportback	2015-2018	FF	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	5F Information Electronic Equipment 1	Output Tests	
Audi A3 Sportback	2015-2018	FF	5F Information Electronic Equipment 1	Specia Functions	
Audi A3 Sportback	2015-2018	FF	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	65 Tyre Pressure Monitoring	Output Tests	
Audi A3 Sportback	2015-2018	FF	65 Tyre Pressure Monitoring	Specia Functions	
Audi A3 Sportback	2015-2018	FF	69 Trailer Function	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportback	2015-2018	FF	69 Trailer Function	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	69 Trailer Function	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	69 Trailer Function	Output Tests	
Audi A3 Sportback	2015-2018	FF	69 Trailer Function	Specia Functions	
Audi A3 Sportback	2015-2018	FF	6C Rear Camera	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	6C Rear Camera	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	6C Rear Camera	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	6C Rear Camera	Output Tests	
Audi A3 Sportback	2015-2018	FF	6C Rear Camera	Specia Functions	
Audi A3 Sportback	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A3 Sportback	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A3 Sportback	2015-2018	FF	75 Emergency Call Module	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	75 Emergency Call Module	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	75 Emergency Call Module	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	75 Emergency Call Module	Output Tests	
Audi A3 Sportback	2015-2018	FF	75 Emergency Call Module	Specia Functions	
Audi A3 Sportback	2015-2018	FF	76 Parking Aid	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	76 Parking Aid	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	76 Parking Aid	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	76 Parking Aid	Output Tests	
Audi A3 Sportback	2015-2018	FF	76 Parking Aid	Specia Functions	
Audi A3 Sportback	2015-2018	FF	82 Heads Up Display	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportback	2015-2018	FF	82 Heads Up Display	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	82 Heads Up Display	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	82 Heads Up Display	Output Tests	
Audi A3 Sportback	2015-2018	FF	82 Heads Up Display	Specia Functions	
Audi A3 Sportback	2015-2018	FF	8C Hybrid Battery	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	8C Hybrid Battery	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	8C Hybrid Battery	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	8C Hybrid Battery	Output Tests	
Audi A3 Sportback	2015-2018	FF	8C Hybrid Battery	Specia Functions	
Audi A3 Sportback	2015-2018	FF	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A3 Sportback	2015-2018	FF	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A3 Sportback	2015-2018	FF	A6 Microphone	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	A6 Microphone	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	A6 Microphone	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	A6 Microphone	Output Tests	
Audi A3 Sportback	2015-2018	FF	A6 Microphone	Specia Functions	
Audi A3 Sportback	2015-2018	FF	A9 Struct.Borne Sound	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	A9 Struct.Borne Sound	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	A9 Struct.Borne Sound	Output Tests	
Audi A3 Sportback	2015-2018	FF	A9 Struct.Borne Sound	Specia Functions	
Audi A3 Sportback	2015-2018	FF	B7 Access Start Interf	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3 Sportback	2015-2018	FF	B7 Access Start Interf	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	B7 Access Start Interf	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	B7 Access Start Interf	Output Tests	
Audi A3 Sportback	2015-2018	FF	B7 Access Start Interf	Specia Functions	
Audi A3 Sportback	2015-2018	FF	BB Door Rear Drv Side	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	BB Door Rear Drv Side	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	BB Door Rear Drv Side	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	BB Door Rear Drv Side	Output Tests	
Audi A3 Sportback	2015-2018	FF	BB Door Rear Drv Side	Specia Functions	
Audi A3 Sportback	2015-2018	FF	BC Door Rear Pass Side	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	BC Door Rear Pass Side	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	BC Door Rear Pass Side	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	BC Door Rear Pass Side	Output Tests	
Audi A3 Sportback	2015-2018	FF	BC Door Rear Pass Side	Specia Functions	
Audi A3 Sportback	2015-2018	FF	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	C0 Act. For Ext. Noise	Output Tests	
Audi A3 Sportback	2015-2018	FF	C0 Act. For Ext. Noise	Specia Functions	
Audi A3 Sportback	2015-2018	FF	C6 Batt. Chrg	Read Fault Codes	
Audi A3 Sportback	2015-2018	FF	C6 Batt. Chrg	Clear Fault Codes	
Audi A3 Sportback	2015-2018	FF	C6 Batt. Chrg	Measuring Blocks	
Audi A3 Sportback	2015-2018	FF	C6 Batt. Chrg	Output Tests	
Audi A3 Sportback	2015-2018	FF	C6 Batt. Chrg	Specia Functions	
Audi S3 Sportback	2015-2018	FF	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportback	2015-2018	FF	01 Engine Electronics	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	01 Engine Electronics	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	01 Engine Electronics	Output Tests	
Audi S3 Sportback	2015-2018	FF	01 Engine Electronics	Specia Functions	
Audi S3 Sportback	2015-2018	FF	02 Transmission Electronics	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	02 Transmission Electronics	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	02 Transmission Electronics	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	02 Transmission Electronics	Output Tests	
Audi S3 Sportback	2015-2018	FF	02 Transmission Electronics	Specia Functions	
Audi S3 Sportback	2015-2018	FF	03 Brake Electronics	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	03 Brake Electronics	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	03 Brake Electronics	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	03 Brake Electronics	Output Tests	
Audi S3 Sportback	2015-2018	FF	03 Brake Electronics	Specia Functions	
Audi S3 Sportback	2015-2018	FF	06 Passene. Seat Adj.	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	06 Passene. Seat Adj.	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	06 Passene. Seat Adj.	Output Tests	
Audi S3 Sportback	2015-2018	FF	06 Passene. Seat Adj.	Specia Functions	
Audi S3 Sportback	2015-2018	FF	08 AC/Heating Electronics	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	08 AC/Heating Electronics	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	08 AC/Heating Electronics	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	08 AC/Heating Electronics	Output Tests	
Audi S3 Sportback	2015-2018	FF	08 AC/Heating Electronics	Specia Functions	
Audi S3 Sportback	2015-2018	FF	09 Electronic Ctrl Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportback	2015-2018	FF	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	09 Electronic Ctrl Electronics	Output Tests	
Audi S3 Sportback	2015-2018	FF	09 Electronic Ctrl Electronics	Specia Functions	
Audi S3 Sportback	2015-2018	FF	13 Distance Control	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	13 Distance Control	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	13 Distance Control	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	13 Distance Control	Output Tests	
Audi S3 Sportback	2015-2018	FF	13 Distance Control	Specia Functions	
Audi S3 Sportback	2015-2018	FF	14 Wheel Damping Electronics	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	14 Wheel Damping Electronics	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	14 Wheel Damping Electronics	Output Tests	
Audi S3 Sportback	2015-2018	FF	14 Wheel Damping Electronics	Specia Functions	
Audi S3 Sportback	2015-2018	FF	15 Airbags	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	15 Airbags	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	15 Airbags	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	15 Airbags	Output Tests	
Audi S3 Sportback	2015-2018	FF	15 Airbags	Specia Functions	
Audi S3 Sportback	2015-2018	FF	16 Steering Wheel Electronics	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	16 Steering Wheel Electronics	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	16 Steering Wheel Electronics	Output Tests	
Audi S3 Sportback	2015-2018	FF	16 Steering Wheel Electronics	Specia Functions	
Audi S3 Sportback	2015-2018	FF	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportback	2015-2018	FF	17 Instrument Cluster	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	17 Instrument Cluster	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	17 Instrument Cluster	Output Tests	
Audi S3 Sportback	2015-2018	FF	17 Instrument Cluster	Specia Functions	
Audi S3 Sportback	2015-2018	FF	18 Aux Heating	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	18 Aux Heating	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	18 Aux Heating	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	18 Aux Heating	Output Tests	
Audi S3 Sportback	2015-2018	FF	18 Aux Heating	Specia Functions	
Audi S3 Sportback	2015-2018	FF	19 Gateway Data Bus	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	19 Gateway Data Bus	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	19 Gateway Data Bus	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	19 Gateway Data Bus	Output Tests	
Audi S3 Sportback	2015-2018	FF	19 Gateway Data Bus	Specia Functions	
Audi S3 Sportback	2015-2018	FF	20 High Beam Assistance Device	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	20 High Beam Assistance Device	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	20 High Beam Assistance Device	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	20 High Beam Assistance Device	Output Tests	
Audi S3 Sportback	2015-2018	FF	20 High Beam Assistance Device	Specia Functions	
Audi S3 Sportback	2015-2018	FF	22 4WD Electronics	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	22 4WD Electronics	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	22 4WD Electronics	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	22 4WD Electronics	Output Tests	
Audi S3 Sportback	2015-2018	FF	22 4WD Electronics	Specia Functions	
Audi S3 Sportback	2015-2018	FF	23 Braker Booster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportback	2015-2018	FF	23 Braker Booster	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	23 Braker Booster	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	23 Braker Booster	Output Tests	
Audi S3 Sportback	2015-2018	FF	23 Braker Booster	Specia Functions	
Audi S3 Sportback	2015-2018	FF	26 Electric Roof Control	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	26 Electric Roof Control	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	26 Electric Roof Control	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	26 Electric Roof Control	Output Tests	
Audi S3 Sportback	2015-2018	FF	26 Electric Roof Control	Specia Functions	
Audi S3 Sportback	2015-2018	FF	29 Left Light Control	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	29 Left Light Control	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	29 Left Light Control	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	29 Left Light Control	Output Tests	
Audi S3 Sportback	2015-2018	FF	29 Left Light Control	Specia Functions	
Audi S3 Sportback	2015-2018	FF	2B Steer Col Lock	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	2B Steer Col Lock	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	2B Steer Col Lock	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	2B Steer Col Lock	Output Tests	
Audi S3 Sportback	2015-2018	FF	2B Steer Col Lock	Specia Functions	
Audi S3 Sportback	2015-2018	FF	30 Special Function 2	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	30 Special Function 2	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	30 Special Function 2	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	30 Special Function 2	Output Tests	
Audi S3 Sportback	2015-2018	FF	30 Special Function 2	Specia Functions	
Audi S3 Sportback	2015-2018	FF	36 Side of Driver Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S3 Sportback	2015-2018	FF	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	36 Side of Driver Seat Adj.	Output Tests	
Audi S3 Sportback	2015-2018	FF	36 Side of Driver Seat Adj.	Specia Functions	
Audi S3 Sportback	2015-2018	FF	39 Right Light Control	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	39 Right Light Control	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	39 Right Light Control	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	39 Right Light Control	Output Tests	
Audi S3 Sportback	2015-2018	FF	39 Right Light Control	Specia Functions	
Audi S3 Sportback	2015-2018	FF	3C Lane Departure Assistance System	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	3C Lane Departure Assistance System	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	3C Lane Departure Assistance System	Output Tests	
Audi S3 Sportback	2015-2018	FF	3C Lane Departure Assistance System	Specia Functions	
Audi S3 Sportback	2015-2018	FF	3D Special Function	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	3D Special Function	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	3D Special Function	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	3D Special Function	Output Tests	
Audi S3 Sportback	2015-2018	FF	3D Special Function	Specia Functions	
Audi S3 Sportback	2015-2018	FF	42 Driver-Door Elect.	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	42 Driver-Door Elect.	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	42 Driver-Door Elect.	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	42 Driver-Door Elect.	Output Tests	
Audi S3 Sportback	2015-2018	FF	42 Driver-Door Elect.	Specia Functions	
Audi S3 Sportback	2015-2018	FF	44 Steering Assistance	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportback	2015-2018	FF	44 Steering Assistance	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	44 Steering Assistance	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	44 Steering Assistance	Output Tests	
Audi S3 Sportback	2015-2018	FF	44 Steering Assistance	Specia Functions	
Audi S3 Sportback	2015-2018	FF	47 Soundsystem	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	47 Soundsystem	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	47 Soundsystem	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	47 Soundsystem	Output Tests	
Audi S3 Sportback	2015-2018	FF	47 Soundsystem	Specia Functions	
Audi S3 Sportback	2015-2018	FF	51 Electric Drive	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	51 Electric Drive	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	51 Electric Drive	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	51 Electric Drive	Output Tests	
Audi S3 Sportback	2015-2018	FF	51 Electric Drive	Specia Functions	
Audi S3 Sportback	2015-2018	FF	52 Passe.-Door Elect.	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	52 Passe.-Door Elect.	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	52 Passe.-Door Elect.	Output Tests	
Audi S3 Sportback	2015-2018	FF	52 Passe.-Door Elect.	Specia Functions	
Audi S3 Sportback	2015-2018	FF	55 Headlight Range Control	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	55 Headlight Range Control	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	55 Headlight Range Control	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	55 Headlight Range Control	Output Tests	
Audi S3 Sportback	2015-2018	FF	55 Headlight Range Control	Specia Functions	
Audi S3 Sportback	2015-2018	FF	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportback	2015-2018	FF	57 TV-Tuner	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	57 TV-Tuner	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	57 TV-Tuner	Output Tests	
Audi S3 Sportback	2015-2018	FF	57 TV-Tuner	Specia Functions	
Audi S3 Sportback	2015-2018	FF	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	5F Information Electronic Equipment 1	Output Tests	
Audi S3 Sportback	2015-2018	FF	5F Information Electronic Equipment 1	Specia Functions	
Audi S3 Sportback	2015-2018	FF	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	65 Tyre Pressure Monitoring	Output Tests	
Audi S3 Sportback	2015-2018	FF	65 Tyre Pressure Monitoring	Specia Functions	
Audi S3 Sportback	2015-2018	FF	69 Trailer Function	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	69 Trailer Function	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	69 Trailer Function	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	69 Trailer Function	Output Tests	
Audi S3 Sportback	2015-2018	FF	69 Trailer Function	Specia Functions	
Audi S3 Sportback	2015-2018	FF	6C Rear Camera	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	6C Rear Camera	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	6C Rear Camera	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	6C Rear Camera	Output Tests	
Audi S3 Sportback	2015-2018	FF	6C Rear Camera	Specia Functions	
Audi S3 Sportback	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportback	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S3 Sportback	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S3 Sportback	2015-2018	FF	75 Emergency Call Module	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	75 Emergency Call Module	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	75 Emergency Call Module	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	75 Emergency Call Module	Output Tests	
Audi S3 Sportback	2015-2018	FF	75 Emergency Call Module	Specia Functions	
Audi S3 Sportback	2015-2018	FF	76 Parking Aid	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	76 Parking Aid	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	76 Parking Aid	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	76 Parking Aid	Output Tests	
Audi S3 Sportback	2015-2018	FF	76 Parking Aid	Specia Functions	
Audi S3 Sportback	2015-2018	FF	82 Heads Up Display	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	82 Heads Up Display	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	82 Heads Up Display	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	82 Heads Up Display	Output Tests	
Audi S3 Sportback	2015-2018	FF	82 Heads Up Display	Specia Functions	
Audi S3 Sportback	2015-2018	FF	8C Hybrid Battery	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	8C Hybrid Battery	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	8C Hybrid Battery	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	8C Hybrid Battery	Output Tests	
Audi S3 Sportback	2015-2018	FF	8C Hybrid Battery	Specia Functions	
Audi S3 Sportback	2015-2018	FF	A5 Frt Sens.Drv.Assist	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportback	2015-2018	FF	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	A5 Frt Sens.Drv.Assist	Output Tests	
Audi S3 Sportback	2015-2018	FF	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi S3 Sportback	2015-2018	FF	A6 Microphone	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	A6 Microphone	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	A6 Microphone	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	A6 Microphone	Output Tests	
Audi S3 Sportback	2015-2018	FF	A6 Microphone	Specia Functions	
Audi S3 Sportback	2015-2018	FF	A9 Struct.Borne Sound	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	A9 Struct.Borne Sound	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	A9 Struct.Borne Sound	Output Tests	
Audi S3 Sportback	2015-2018	FF	A9 Struct.Borne Sound	Specia Functions	
Audi S3 Sportback	2015-2018	FF	B7 Access Start Interf	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	B7 Access Start Interf	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	B7 Access Start Interf	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	B7 Access Start Interf	Output Tests	
Audi S3 Sportback	2015-2018	FF	B7 Access Start Interf	Specia Functions	
Audi S3 Sportback	2015-2018	FF	BB Door Rear Drv Side	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	BB Door Rear Drv Side	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	BB Door Rear Drv Side	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	BB Door Rear Drv Side	Output Tests	
Audi S3 Sportback	2015-2018	FF	BB Door Rear Drv Side	Specia Functions	
Audi S3 Sportback	2015-2018	FF	BC Door Rear Pass Side	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportback	2015-2018	FF	BC Door Rear Pass Side	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	BC Door Rear Pass Side	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	BC Door Rear Pass Side	Output Tests	
Audi S3 Sportback	2015-2018	FF	BC Door Rear Pass Side	Specia Functions	
Audi S3 Sportback	2015-2018	FF	C0 Act. For Ext. Noise	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	C0 Act. For Ext. Noise	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	C0 Act. For Ext. Noise	Output Tests	
Audi S3 Sportback	2015-2018	FF	C0 Act. For Ext. Noise	Specia Functions	
Audi S3 Sportback	2015-2018	FF	C6 Batt. Chrg	Read Fault Codes	
Audi S3 Sportback	2015-2018	FF	C6 Batt. Chrg	Clear Fault Codes	
Audi S3 Sportback	2015-2018	FF	C6 Batt. Chrg	Measuring Blocks	
Audi S3 Sportback	2015-2018	FF	C6 Batt. Chrg	Output Tests	
Audi S3 Sportback	2015-2018	FF	C6 Batt. Chrg	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	01 Engine Electronics	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	01 Engine Electronics	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	01 Engine Electronics	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	01 Engine Electronics	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	01 Engine Electronics	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	02 Transmission Electronics	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	02 Transmission Electronics	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	02 Transmission Electronics	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	02 Transmission Electronics	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	02 Transmission Electronics	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	03 Brake Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3 Sportlimousine	2015-2018	FF	03 Brake Electronics	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	03 Brake Electronics	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	03 Brake Electronics	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	03 Brake Electronics	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	06 Passene. Seat Adj.	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	06 Passene. Seat Adj.	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	06 Passene. Seat Adj.	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	06 Passene. Seat Adj.	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	08 AC/Heating Electronics	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	08 AC/Heating Electronics	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	08 AC/Heating Electronics	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	08 AC/Heating Electronics	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	09 Electronic Ctrl Electronics	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	13 Distance Control	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	13 Distance Control	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	13 Distance Control	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	13 Distance Control	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	13 Distance Control	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	14 Wheel Damping Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportlimousine	2015-2018	FF	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	14 Wheel Damping Electronics	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	14 Wheel Damping Electronics	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	14 Wheel Damping Electronics	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	15 Airbags	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	15 Airbags	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	15 Airbags	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	15 Airbags	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	15 Airbags	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	16 Steering Wheel Electronics	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	16 Steering Wheel Electronics	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	16 Steering Wheel Electronics	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	17 Instrument Cluster	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	17 Instrument Cluster	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	17 Instrument Cluster	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	17 Instrument Cluster	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	17 Instrument Cluster	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	18 Aux Heating	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	18 Aux Heating	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	18 Aux Heating	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	18 Aux Heating	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	18 Aux Heating	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportlimousine	2015-2018	FF	19 Gateway Data Bus	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	19 Gateway Data Bus	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	19 Gateway Data Bus	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	19 Gateway Data Bus	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	20 High Beam Assistance Device	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	20 High Beam Assistance Device	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	20 High Beam Assistance Device	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	20 High Beam Assistance Device	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	20 High Beam Assistance Device	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	22 4WD Electronics	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	22 4WD Electronics	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	22 4WD Electronics	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	22 4WD Electronics	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	22 4WD Electronics	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	23 Braker Booster	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	23 Braker Booster	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	23 Braker Booster	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	23 Braker Booster	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	23 Braker Booster	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	26 Electric Roof Control	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	26 Electric Roof Control	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	26 Electric Roof Control	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	26 Electric Roof Control	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	26 Electric Roof Control	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	29 Left Light Control	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportlimousine	2015-2018	FF	29 Left Light Control	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	29 Left Light Control	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	29 Left Light Control	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	29 Left Light Control	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	2B Steer Col Lock	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	2B Steer Col Lock	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	2B Steer Col Lock	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	2B Steer Col Lock	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	2B Steer Col Lock	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	30 Special Function 2	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	30 Special Function 2	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	30 Special Function 2	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	30 Special Function 2	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	30 Special Function 2	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	36 Side of Driver Seat Adj.	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	36 Side of Driver Seat Adj.	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	39 Right Light Control	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	39 Right Light Control	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	39 Right Light Control	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	39 Right Light Control	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	39 Right Light Control	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportlimousine	2015-2018	FF	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	3C Lane Departure Assistance System	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	3C Lane Departure Assistance System	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	3C Lane Departure Assistance System	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	3D Special Function	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	3D Special Function	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	3D Special Function	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	3D Special Function	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	3D Special Function	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	42 Driver-Door Elect.	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	42 Driver-Door Elect.	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	42 Driver-Door Elect.	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	42 Driver-Door Elect.	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	44 Steering Assistance	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	44 Steering Assistance	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	44 Steering Assistance	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	44 Steering Assistance	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	44 Steering Assistance	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	47 Soundsystem	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	47 Soundsystem	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	47 Soundsystem	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	47 Soundsystem	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	47 Soundsystem	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	51 Electric Drive	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3 Sportlimousine	2015-2018	FF	51 Electric Drive	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	51 Electric Drive	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	51 Electric Drive	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	51 Electric Drive	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	52 Passe.-Door Elect.	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	52 Passe.-Door Elect.	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	55 Headlight Range Control	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	55 Headlight Range Control	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	55 Headlight Range Control	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	55 Headlight Range Control	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	55 Headlight Range Control	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	57 TV-Tuner	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	57 TV-Tuner	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	57 TV-Tuner	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	57 TV-Tuner	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	57 TV-Tuner	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	5F Information Electronic Equipment 1	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	5F Information Electronic Equipment 1	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	65 Tyre Pressure Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportlimousine	2015-2018	FF	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	65 Tyre Pressure Monitoring	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	65 Tyre Pressure Monitoring	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	69 Trailer Function	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	69 Trailer Function	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	69 Trailer Function	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	69 Trailer Function	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	69 Trailer Function	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	6C Rear Camera	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	6C Rear Camera	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	6C Rear Camera	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	6C Rear Camera	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	6C Rear Camera	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	75 Emergency Call Module	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	75 Emergency Call Module	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	75 Emergency Call Module	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	75 Emergency Call Module	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	75 Emergency Call Module	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	76 Parking Aid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportlimousine	2015-2018	FF	76 Parking Aid	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	76 Parking Aid	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	76 Parking Aid	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	76 Parking Aid	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	82 Heads Up Display	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	82 Heads Up Display	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	82 Heads Up Display	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	82 Heads Up Display	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	82 Heads Up Display	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	8C Hybrid Battery	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	8C Hybrid Battery	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	8C Hybrid Battery	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	8C Hybrid Battery	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	8C Hybrid Battery	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	A6 Microphone	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	A6 Microphone	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	A6 Microphone	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	A6 Microphone	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	A6 Microphone	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportlimousine	2015-2018	FF	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	A9 Struct.Borne Sound	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	A9 Struct.Borne Sound	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	A9 Struct.Borne Sound	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	B7 Access Start Interf	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	B7 Access Start Interf	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	B7 Access Start Interf	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	B7 Access Start Interf	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	B7 Access Start Interf	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	BB Door Rear Drv Side	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	BB Door Rear Drv Side	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	BB Door Rear Drv Side	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	BB Door Rear Drv Side	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	BB Door Rear Drv Side	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	BC Door Rear Pass Side	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	BC Door Rear Pass Side	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	BC Door Rear Pass Side	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	BC Door Rear Pass Side	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	BC Door Rear Pass Side	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	C0 Act. For Ext. Noise	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	C0 Act. For Ext. Noise	Specia Functions	
Audi A3 Sportlimousine	2015-2018	FF	C6 Batt. Chrg	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Sportlimousine	2015-2018	FF	C6 Batt. Chrg	Clear Fault Codes	
Audi A3 Sportlimousine	2015-2018	FF	C6 Batt. Chrg	Measuring Blocks	
Audi A3 Sportlimousine	2015-2018	FF	C6 Batt. Chrg	Output Tests	
Audi A3 Sportlimousine	2015-2018	FF	C6 Batt. Chrg	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	01 Engine Electronics	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	01 Engine Electronics	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	01 Engine Electronics	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	01 Engine Electronics	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	01 Engine Electronics	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	02 Transmission Electronics	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	02 Transmission Electronics	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	02 Transmission Electronics	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	02 Transmission Electronics	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	02 Transmission Electronics	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	03 Brake Electronics	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	03 Brake Electronics	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	03 Brake Electronics	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	03 Brake Electronics	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	03 Brake Electronics	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	06 Passene. Seat Adj.	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	06 Passene. Seat Adj.	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	06 Passene. Seat Adj.	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	06 Passene. Seat Adj.	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportlimousine	2015-2018	FF	08 AC/Heating Electronics	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	08 AC/Heating Electronics	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	08 AC/Heating Electronics	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	08 AC/Heating Electronics	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	09 Electronic Ctrl Electronics	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	09 Electronic Ctrl Electronics	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	13 Distance Control	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	13 Distance Control	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	13 Distance Control	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	13 Distance Control	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	13 Distance Control	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	14 Wheel Damping Electronics	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	14 Wheel Damping Electronics	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	14 Wheel Damping Electronics	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	14 Wheel Damping Electronics	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	15 Airbags	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	15 Airbags	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	15 Airbags	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	15 Airbags	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	15 Airbags	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	16 Steering Wheel Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportlimousine	2015-2018	FF	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	16 Steering Wheel Electronics	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	16 Steering Wheel Electronics	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	16 Steering Wheel Electronics	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	17 Instrument Cluster	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	17 Instrument Cluster	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	17 Instrument Cluster	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	17 Instrument Cluster	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	17 Instrument Cluster	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	18 Aux Heating	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	18 Aux Heating	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	18 Aux Heating	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	18 Aux Heating	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	18 Aux Heating	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	19 Gateway Data Bus	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	19 Gateway Data Bus	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	19 Gateway Data Bus	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	19 Gateway Data Bus	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	19 Gateway Data Bus	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	20 High Beam Assistance Device	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	20 High Beam Assistance Device	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	20 High Beam Assistance Device	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	20 High Beam Assistance Device	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	20 High Beam Assistance Device	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportlimousine	2015-2018	FF	22 4WD Electronics	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	22 4WD Electronics	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	22 4WD Electronics	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	22 4WD Electronics	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	23 Braker Booster	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	23 Braker Booster	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	23 Braker Booster	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	23 Braker Booster	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	23 Braker Booster	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	26 Electric Roof Control	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	26 Electric Roof Control	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	26 Electric Roof Control	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	26 Electric Roof Control	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	26 Electric Roof Control	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	29 Left Light Control	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	29 Left Light Control	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	29 Left Light Control	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	29 Left Light Control	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	29 Left Light Control	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	2B Steer Col Lock	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	2B Steer Col Lock	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	2B Steer Col Lock	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	2B Steer Col Lock	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	2B Steer Col Lock	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	30 Special Function 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportlimousine	2015-2018	FF	30 Special Function 2	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	30 Special Function 2	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	30 Special Function 2	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	30 Special Function 2	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	36 Side of Driver Seat Adj.	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	36 Side of Driver Seat Adj.	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	39 Right Light Control	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	39 Right Light Control	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	39 Right Light Control	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	39 Right Light Control	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	39 Right Light Control	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	3C Lane Departure Assistance System	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	3C Lane Departure Assistance System	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	3C Lane Departure Assistance System	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	3C Lane Departure Assistance System	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	3D Special Function	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	3D Special Function	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	3D Special Function	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	3D Special Function	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	3D Special Function	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportlimousine	2015-2018	FF	42 Driver-Door Elect.	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	42 Driver-Door Elect.	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	42 Driver-Door Elect.	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	42 Driver-Door Elect.	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	44 Steering Assistance	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	44 Steering Assistance	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	44 Steering Assistance	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	44 Steering Assistance	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	44 Steering Assistance	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	47 Soundsystem	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	47 Soundsystem	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	47 Soundsystem	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	47 Soundsystem	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	47 Soundsystem	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	51 Electric Drive	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	51 Electric Drive	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	51 Electric Drive	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	51 Electric Drive	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	51 Electric Drive	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	52 Passe.-Door Elect.	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	52 Passe.-Door Elect.	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	52 Passe.-Door Elect.	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	52 Passe.-Door Elect.	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	55 Headlight Range Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S3 Sportlimousine	2015-2018	FF	55 Headlight Range Control	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	55 Headlight Range Control	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	55 Headlight Range Control	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	55 Headlight Range Control	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	57 TV-Tuner	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	57 TV-Tuner	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	57 TV-Tuner	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	57 TV-Tuner	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	57 TV-Tuner	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	5F Information Electronic Equipment 1	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	5F Information Electronic Equipment 1	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	65 Tyre Pressure Monitoring	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	65 Tyre Pressure Monitoring	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	69 Trailer Function	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	69 Trailer Function	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	69 Trailer Function	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	69 Trailer Function	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	69 Trailer Function	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	6C Rear Camera	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportlimousine	2015-2018	FF	6C Rear Camera	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	6C Rear Camera	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	6C Rear Camera	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	6C Rear Camera	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	75 Emergency Call Module	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	75 Emergency Call Module	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	75 Emergency Call Module	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	75 Emergency Call Module	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	75 Emergency Call Module	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	76 Parking Aid	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	76 Parking Aid	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	76 Parking Aid	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	76 Parking Aid	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	76 Parking Aid	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	82 Heads Up Display	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	82 Heads Up Display	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	82 Heads Up Display	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	82 Heads Up Display	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	82 Heads Up Display	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportlimousine	2015-2018	FF	8C Hybrid Battery	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	8C Hybrid Battery	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	8C Hybrid Battery	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	8C Hybrid Battery	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	A5 Frt Sens.Drv.Assist	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	A6 Microphone	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	A6 Microphone	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	A6 Microphone	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	A6 Microphone	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	A6 Microphone	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	A9 Struct.Borne Sound	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	A9 Struct.Borne Sound	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	A9 Struct.Borne Sound	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	A9 Struct.Borne Sound	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	B7 Access Start Interf	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	B7 Access Start Interf	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	B7 Access Start Interf	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	B7 Access Start Interf	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	B7 Access Start Interf	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	BB Door Rear Drv Side	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Sportlimousine	2015-2018	FF	BB Door Rear Drv Side	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	BB Door Rear Drv Side	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	BB Door Rear Drv Side	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	BB Door Rear Drv Side	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	BC Door Rear Pass Side	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	BC Door Rear Pass Side	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	BC Door Rear Pass Side	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	BC Door Rear Pass Side	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	BC Door Rear Pass Side	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	C0 Act. For Ext. Noise	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	C0 Act. For Ext. Noise	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	C0 Act. For Ext. Noise	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	C0 Act. For Ext. Noise	Specia Functions	
Audi S3 Sportlimousine	2015-2018	FF	C6 Batt. Chrg	Read Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	C6 Batt. Chrg	Clear Fault Codes	
Audi S3 Sportlimousine	2015-2018	FF	C6 Batt. Chrg	Measuring Blocks	
Audi S3 Sportlimousine	2015-2018	FF	C6 Batt. Chrg	Output Tests	
Audi S3 Sportlimousine	2015-2018	FF	C6 Batt. Chrg	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	01 Engine Electronics	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	01 Engine Electronics	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	01 Engine Electronics	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	01 Engine Electronics	Output Tests	
Audi A3 Cabrio	2015-2018	FF	01 Engine Electronics	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	02 Transmission Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Cabrio	2015-2018	FF	02 Transmission Electronics	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	02 Transmission Electronics	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	02 Transmission Electronics	Output Tests	
Audi A3 Cabrio	2015-2018	FF	02 Transmission Electronics	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	03 Brake Electronics	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	03 Brake Electronics	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	03 Brake Electronics	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	03 Brake Electronics	Output Tests	
Audi A3 Cabrio	2015-2018	FF	03 Brake Electronics	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	06 Passene. Seat Adj.	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	06 Passene. Seat Adj.	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	06 Passene. Seat Adj.	Output Tests	
Audi A3 Cabrio	2015-2018	FF	06 Passene. Seat Adj.	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	08 AC/Heating Electronics	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	08 AC/Heating Electronics	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	08 AC/Heating Electronics	Output Tests	
Audi A3 Cabrio	2015-2018	FF	08 AC/Heating Electronics	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	09 Electronic Ctrl Electronics	Output Tests	
Audi A3 Cabrio	2015-2018	FF	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	13 Distance Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Cabrio	2015-2018	FF	13 Distance Control	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	13 Distance Control	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	13 Distance Control	Output Tests	
Audi A3 Cabrio	2015-2018	FF	13 Distance Control	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	14 Wheel Damping Electronics	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	14 Wheel Damping Electronics	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	14 Wheel Damping Electronics	Output Tests	
Audi A3 Cabrio	2015-2018	FF	14 Wheel Damping Electronics	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	15 Airbags	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	15 Airbags	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	15 Airbags	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	15 Airbags	Output Tests	
Audi A3 Cabrio	2015-2018	FF	15 Airbags	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	16 Steering Wheel Electronics	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	16 Steering Wheel Electronics	Output Tests	
Audi A3 Cabrio	2015-2018	FF	16 Steering Wheel Electronics	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	17 Instrument Cluster	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	17 Instrument Cluster	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	17 Instrument Cluster	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	17 Instrument Cluster	Output Tests	
Audi A3 Cabrio	2015-2018	FF	17 Instrument Cluster	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Cabrio	2015-2018	FF	18 Aux Heating	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	18 Aux Heating	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	18 Aux Heating	Output Tests	
Audi A3 Cabrio	2015-2018	FF	18 Aux Heating	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	19 Gateway Data Bus	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	19 Gateway Data Bus	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	19 Gateway Data Bus	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	19 Gateway Data Bus	Output Tests	
Audi A3 Cabrio	2015-2018	FF	19 Gateway Data Bus	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	20 High Beam Assistance Device	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	20 High Beam Assistance Device	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	20 High Beam Assistance Device	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	20 High Beam Assistance Device	Output Tests	
Audi A3 Cabrio	2015-2018	FF	20 High Beam Assistance Device	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	22 4WD Electronics	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	22 4WD Electronics	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	22 4WD Electronics	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	22 4WD Electronics	Output Tests	
Audi A3 Cabrio	2015-2018	FF	22 4WD Electronics	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	23 Braker Booster	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	23 Braker Booster	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	23 Braker Booster	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	23 Braker Booster	Output Tests	
Audi A3 Cabrio	2015-2018	FF	23 Braker Booster	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	26 Electric Roof Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Cabrio	2015-2018	FF	26 Electric Roof Control	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	26 Electric Roof Control	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	26 Electric Roof Control	Output Tests	
Audi A3 Cabrio	2015-2018	FF	26 Electric Roof Control	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	29 Left Light Control	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	29 Left Light Control	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	29 Left Light Control	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	29 Left Light Control	Output Tests	
Audi A3 Cabrio	2015-2018	FF	29 Left Light Control	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	2B Steer Col Lock	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	2B Steer Col Lock	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	2B Steer Col Lock	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	2B Steer Col Lock	Output Tests	
Audi A3 Cabrio	2015-2018	FF	2B Steer Col Lock	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	30 Special Function 2	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	30 Special Function 2	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	30 Special Function 2	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	30 Special Function 2	Output Tests	
Audi A3 Cabrio	2015-2018	FF	30 Special Function 2	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	36 Side of Driver Seat Adj.	Output Tests	
Audi A3 Cabrio	2015-2018	FF	36 Side of Driver Seat Adj.	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	39 Right Light Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Cabrio	2015-2018	FF	39 Right Light Control	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	39 Right Light Control	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	39 Right Light Control	Output Tests	
Audi A3 Cabrio	2015-2018	FF	39 Right Light Control	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	3C Lane Departure Assistance System	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	3C Lane Departure Assistance System	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	3C Lane Departure Assistance System	Output Tests	
Audi A3 Cabrio	2015-2018	FF	3C Lane Departure Assistance System	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	3D Special Function	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	3D Special Function	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	3D Special Function	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	3D Special Function	Output Tests	
Audi A3 Cabrio	2015-2018	FF	3D Special Function	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	42 Driver-Door Elect.	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	42 Driver-Door Elect.	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	42 Driver-Door Elect.	Output Tests	
Audi A3 Cabrio	2015-2018	FF	42 Driver-Door Elect.	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	44 Steering Assistance	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	44 Steering Assistance	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	44 Steering Assistance	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	44 Steering Assistance	Output Tests	
Audi A3 Cabrio	2015-2018	FF	44 Steering Assistance	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Cabrio	2015-2018	FF	47 Soundsystem	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	47 Soundsystem	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	47 Soundsystem	Output Tests	
Audi A3 Cabrio	2015-2018	FF	47 Soundsystem	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	51 Electric Drive	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	51 Electric Drive	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	51 Electric Drive	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	51 Electric Drive	Output Tests	
Audi A3 Cabrio	2015-2018	FF	51 Electric Drive	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	52 Passe.-Door Elect.	Output Tests	
Audi A3 Cabrio	2015-2018	FF	52 Passe.-Door Elect.	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	55 Headlight Range Control	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	55 Headlight Range Control	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	55 Headlight Range Control	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	55 Headlight Range Control	Output Tests	
Audi A3 Cabrio	2015-2018	FF	55 Headlight Range Control	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	57 TV-Tuner	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	57 TV-Tuner	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	57 TV-Tuner	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	57 TV-Tuner	Output Tests	
Audi A3 Cabrio	2015-2018	FF	57 TV-Tuner	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	5F Information Electronic Equipment 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Cabrio	2015-2018	FF	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	5F Information Electronic Equipment 1	Output Tests	
Audi A3 Cabrio	2015-2018	FF	5F Information Electronic Equipment 1	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	65 Tyre Pressure Monitoring	Output Tests	
Audi A3 Cabrio	2015-2018	FF	65 Tyre Pressure Monitoring	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	69 Trailer Function	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	69 Trailer Function	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	69 Trailer Function	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	69 Trailer Function	Output Tests	
Audi A3 Cabrio	2015-2018	FF	69 Trailer Function	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	6C Rear Camera	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	6C Rear Camera	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	6C Rear Camera	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	6C Rear Camera	Output Tests	
Audi A3 Cabrio	2015-2018	FF	6C Rear Camera	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A3 Cabrio	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	75 Emergency Call Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Cabrio	2015-2018	FF	75 Emergency Call Module	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	75 Emergency Call Module	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	75 Emergency Call Module	Output Tests	
Audi A3 Cabrio	2015-2018	FF	75 Emergency Call Module	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	76 Parking Aid	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	76 Parking Aid	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	76 Parking Aid	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	76 Parking Aid	Output Tests	
Audi A3 Cabrio	2015-2018	FF	76 Parking Aid	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	82 Heads Up Display	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	82 Heads Up Display	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	82 Heads Up Display	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	82 Heads Up Display	Output Tests	
Audi A3 Cabrio	2015-2018	FF	82 Heads Up Display	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	8C Hybrid Battery	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	8C Hybrid Battery	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	8C Hybrid Battery	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	8C Hybrid Battery	Output Tests	
Audi A3 Cabrio	2015-2018	FF	8C Hybrid Battery	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A3 Cabrio	2015-2018	FF	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	A6 Microphone	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Cabrio	2015-2018	FF	A6 Microphone	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	A6 Microphone	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	A6 Microphone	Output Tests	
Audi A3 Cabrio	2015-2018	FF	A6 Microphone	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	A9 Struct.Borne Sound	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	A9 Struct.Borne Sound	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	A9 Struct.Borne Sound	Output Tests	
Audi A3 Cabrio	2015-2018	FF	A9 Struct.Borne Sound	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	B7 Access Start Interf	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	B7 Access Start Interf	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	B7 Access Start Interf	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	B7 Access Start Interf	Output Tests	
Audi A3 Cabrio	2015-2018	FF	B7 Access Start Interf	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	BB Door Rear Drv Side	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	BB Door Rear Drv Side	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	BB Door Rear Drv Side	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	BB Door Rear Drv Side	Output Tests	
Audi A3 Cabrio	2015-2018	FF	BB Door Rear Drv Side	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	BC Door Rear Pass Side	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	BC Door Rear Pass Side	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	BC Door Rear Pass Side	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	BC Door Rear Pass Side	Output Tests	
Audi A3 Cabrio	2015-2018	FF	BC Door Rear Pass Side	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	C0 Act. For Ext. Noise	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 Cabrio	2015-2018	FF	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	C0 Act. For Ext. Noise	Output Tests	
Audi A3 Cabrio	2015-2018	FF	C0 Act. For Ext. Noise	Specia Functions	
Audi A3 Cabrio	2015-2018	FF	C6 Batt. Chrg	Read Fault Codes	
Audi A3 Cabrio	2015-2018	FF	C6 Batt. Chrg	Clear Fault Codes	
Audi A3 Cabrio	2015-2018	FF	C6 Batt. Chrg	Measuring Blocks	
Audi A3 Cabrio	2015-2018	FF	C6 Batt. Chrg	Output Tests	
Audi A3 Cabrio	2015-2018	FF	C6 Batt. Chrg	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	01 Engine Electronics	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	01 Engine Electronics	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	01 Engine Electronics	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	01 Engine Electronics	Output Tests	
Audi S3 Cabrio	2015-2018	FF	01 Engine Electronics	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	02 Transmission Electronics	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	02 Transmission Electronics	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	02 Transmission Electronics	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	02 Transmission Electronics	Output Tests	
Audi S3 Cabrio	2015-2018	FF	02 Transmission Electronics	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	03 Brake Electronics	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	03 Brake Electronics	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	03 Brake Electronics	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	03 Brake Electronics	Output Tests	
Audi S3 Cabrio	2015-2018	FF	03 Brake Electronics	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	06 Passene. Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Cabrio	2015-2018	FF	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	06 Passene. Seat Adj.	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	06 Passene. Seat Adj.	Output Tests	
Audi S3 Cabrio	2015-2018	FF	06 Passene. Seat Adj.	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	08 AC/Heating Electronics	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	08 AC/Heating Electronics	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	08 AC/Heating Electronics	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	08 AC/Heating Electronics	Output Tests	
Audi S3 Cabrio	2015-2018	FF	08 AC/Heating Electronics	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	09 Electronic Ctrl Electronics	Output Tests	
Audi S3 Cabrio	2015-2018	FF	09 Electronic Ctrl Electronics	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	13 Distance Control	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	13 Distance Control	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	13 Distance Control	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	13 Distance Control	Output Tests	
Audi S3 Cabrio	2015-2018	FF	13 Distance Control	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	14 Wheel Damping Electronics	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	14 Wheel Damping Electronics	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	14 Wheel Damping Electronics	Output Tests	
Audi S3 Cabrio	2015-2018	FF	14 Wheel Damping Electronics	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Cabrio	2015-2018	FF	15 Airbags	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	15 Airbags	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	15 Airbags	Output Tests	
Audi S3 Cabrio	2015-2018	FF	15 Airbags	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	16 Steering Wheel Electronics	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	16 Steering Wheel Electronics	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	16 Steering Wheel Electronics	Output Tests	
Audi S3 Cabrio	2015-2018	FF	16 Steering Wheel Electronics	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	17 Instrument Cluster	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	17 Instrument Cluster	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	17 Instrument Cluster	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	17 Instrument Cluster	Output Tests	
Audi S3 Cabrio	2015-2018	FF	17 Instrument Cluster	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	18 Aux Heating	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	18 Aux Heating	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	18 Aux Heating	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	18 Aux Heating	Output Tests	
Audi S3 Cabrio	2015-2018	FF	18 Aux Heating	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	19 Gateway Data Bus	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	19 Gateway Data Bus	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	19 Gateway Data Bus	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	19 Gateway Data Bus	Output Tests	
Audi S3 Cabrio	2015-2018	FF	19 Gateway Data Bus	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	20 High Beam Assistance Device	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Cabrio	2015-2018	FF	20 High Beam Assistance Device	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	20 High Beam Assistance Device	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	20 High Beam Assistance Device	Output Tests	
Audi S3 Cabrio	2015-2018	FF	20 High Beam Assistance Device	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	22 4WD Electronics	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	22 4WD Electronics	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	22 4WD Electronics	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	22 4WD Electronics	Output Tests	
Audi S3 Cabrio	2015-2018	FF	22 4WD Electronics	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	23 Braker Booster	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	23 Braker Booster	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	23 Braker Booster	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	23 Braker Booster	Output Tests	
Audi S3 Cabrio	2015-2018	FF	23 Braker Booster	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	26 Electric Roof Control	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	26 Electric Roof Control	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	26 Electric Roof Control	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	26 Electric Roof Control	Output Tests	
Audi S3 Cabrio	2015-2018	FF	26 Electric Roof Control	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	29 Left Light Control	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	29 Left Light Control	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	29 Left Light Control	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	29 Left Light Control	Output Tests	
Audi S3 Cabrio	2015-2018	FF	29 Left Light Control	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	2B Steer Col Lock	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Cabrio	2015-2018	FF	2B Steer Col Lock	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	2B Steer Col Lock	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	2B Steer Col Lock	Output Tests	
Audi S3 Cabrio	2015-2018	FF	2B Steer Col Lock	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	30 Special Function 2	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	30 Special Function 2	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	30 Special Function 2	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	30 Special Function 2	Output Tests	
Audi S3 Cabrio	2015-2018	FF	30 Special Function 2	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	36 Side of Driver Seat Adj.	Output Tests	
Audi S3 Cabrio	2015-2018	FF	36 Side of Driver Seat Adj.	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	39 Right Light Control	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	39 Right Light Control	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	39 Right Light Control	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	39 Right Light Control	Output Tests	
Audi S3 Cabrio	2015-2018	FF	39 Right Light Control	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	3C Lane Departure Assistance System	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	3C Lane Departure Assistance System	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	3C Lane Departure Assistance System	Output Tests	
Audi S3 Cabrio	2015-2018	FF	3C Lane Departure Assistance System	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	3D Special Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Cabrio	2015-2018	FF	3D Special Function	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	3D Special Function	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	3D Special Function	Output Tests	
Audi S3 Cabrio	2015-2018	FF	3D Special Function	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	42 Driver-Door Elect.	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	42 Driver-Door Elect.	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	42 Driver-Door Elect.	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	42 Driver-Door Elect.	Output Tests	
Audi S3 Cabrio	2015-2018	FF	42 Driver-Door Elect.	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	44 Steering Assistance	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	44 Steering Assistance	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	44 Steering Assistance	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	44 Steering Assistance	Output Tests	
Audi S3 Cabrio	2015-2018	FF	44 Steering Assistance	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	47 Soundsystem	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	47 Soundsystem	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	47 Soundsystem	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	47 Soundsystem	Output Tests	
Audi S3 Cabrio	2015-2018	FF	47 Soundsystem	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	51 Electric Drive	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	51 Electric Drive	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	51 Electric Drive	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	51 Electric Drive	Output Tests	
Audi S3 Cabrio	2015-2018	FF	51 Electric Drive	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	52 Passe.-Door Elect.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S3 Cabrio	2015-2018	FF	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	52 Passe.-Door Elect.	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	52 Passe.-Door Elect.	Output Tests	
Audi S3 Cabrio	2015-2018	FF	52 Passe.-Door Elect.	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	55 Headlight Range Control	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	55 Headlight Range Control	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	55 Headlight Range Control	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	55 Headlight Range Control	Output Tests	
Audi S3 Cabrio	2015-2018	FF	55 Headlight Range Control	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	57 TV-Tuner	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	57 TV-Tuner	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	57 TV-Tuner	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	57 TV-Tuner	Output Tests	
Audi S3 Cabrio	2015-2018	FF	57 TV-Tuner	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	5F Information Electronic Equipment 1	Output Tests	
Audi S3 Cabrio	2015-2018	FF	5F Information Electronic Equipment 1	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	65 Tyre Pressure Monitoring	Output Tests	
Audi S3 Cabrio	2015-2018	FF	65 Tyre Pressure Monitoring	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	69 Trailer Function	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Cabrio	2015-2018	FF	69 Trailer Function	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	69 Trailer Function	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	69 Trailer Function	Output Tests	
Audi S3 Cabrio	2015-2018	FF	69 Trailer Function	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	6C Rear Camera	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	6C Rear Camera	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	6C Rear Camera	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	6C Rear Camera	Output Tests	
Audi S3 Cabrio	2015-2018	FF	6C Rear Camera	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S3 Cabrio	2015-2018	FF	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	75 Emergency Call Module	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	75 Emergency Call Module	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	75 Emergency Call Module	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	75 Emergency Call Module	Output Tests	
Audi S3 Cabrio	2015-2018	FF	75 Emergency Call Module	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	76 Parking Aid	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	76 Parking Aid	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	76 Parking Aid	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	76 Parking Aid	Output Tests	
Audi S3 Cabrio	2015-2018	FF	76 Parking Aid	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	82 Heads Up Display	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Cabrio	2015-2018	FF	82 Heads Up Display	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	82 Heads Up Display	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	82 Heads Up Display	Output Tests	
Audi S3 Cabrio	2015-2018	FF	82 Heads Up Display	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	8C Hybrid Battery	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	8C Hybrid Battery	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	8C Hybrid Battery	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	8C Hybrid Battery	Output Tests	
Audi S3 Cabrio	2015-2018	FF	8C Hybrid Battery	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	A5 Frt Sens.Drv.Assist	Output Tests	
Audi S3 Cabrio	2015-2018	FF	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	A6 Microphone	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	A6 Microphone	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	A6 Microphone	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	A6 Microphone	Output Tests	
Audi S3 Cabrio	2015-2018	FF	A6 Microphone	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	A9 Struct.Borne Sound	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	A9 Struct.Borne Sound	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	A9 Struct.Borne Sound	Output Tests	
Audi S3 Cabrio	2015-2018	FF	A9 Struct.Borne Sound	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	B7 Access Start Interf	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S3 Cabrio	2015-2018	FF	B7 Access Start Interf	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	B7 Access Start Interf	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	B7 Access Start Interf	Output Tests	
Audi S3 Cabrio	2015-2018	FF	B7 Access Start Interf	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	BB Door Rear Drv Side	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	BB Door Rear Drv Side	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	BB Door Rear Drv Side	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	BB Door Rear Drv Side	Output Tests	
Audi S3 Cabrio	2015-2018	FF	BB Door Rear Drv Side	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	BC Door Rear Pass Side	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	BC Door Rear Pass Side	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	BC Door Rear Pass Side	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	BC Door Rear Pass Side	Output Tests	
Audi S3 Cabrio	2015-2018	FF	BC Door Rear Pass Side	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	C0 Act. For Ext. Noise	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	C0 Act. For Ext. Noise	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	C0 Act. For Ext. Noise	Output Tests	
Audi S3 Cabrio	2015-2018	FF	C0 Act. For Ext. Noise	Specia Functions	
Audi S3 Cabrio	2015-2018	FF	C6 Batt. Chrg	Read Fault Codes	
Audi S3 Cabrio	2015-2018	FF	C6 Batt. Chrg	Clear Fault Codes	
Audi S3 Cabrio	2015-2018	FF	C6 Batt. Chrg	Measuring Blocks	
Audi S3 Cabrio	2015-2018	FF	C6 Batt. Chrg	Output Tests	
Audi S3 Cabrio	2015-2018	FF	C6 Batt. Chrg	Specia Functions	
Audi TT	2013-2018	8V	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2013-2018	8V	01 Engine Electronics	Clear Fault Codes	
Audi TT	2013-2018	8V	01 Engine Electronics	Measuring Blocks	
Audi TT	2013-2018	8V	01 Engine Electronics	Output Tests	
Audi TT	2013-2018	8V	01 Engine Electronics	Specia Functions	
Audi TT	2013-2018	8V	02 Transmission Electronics	Read Fault Codes	
Audi TT	2013-2018	8V	02 Transmission Electronics	Clear Fault Codes	
Audi TT	2013-2018	8V	02 Transmission Electronics	Measuring Blocks	
Audi TT	2013-2018	8V	02 Transmission Electronics	Output Tests	
Audi TT	2013-2018	8V	02 Transmission Electronics	Specia Functions	
Audi TT	2013-2018	8V	03 Brake Electronics	Read Fault Codes	
Audi TT	2013-2018	8V	03 Brake Electronics	Clear Fault Codes	
Audi TT	2013-2018	8V	03 Brake Electronics	Measuring Blocks	
Audi TT	2013-2018	8V	03 Brake Electronics	Output Tests	
Audi TT	2013-2018	8V	03 Brake Electronics	Specia Functions	
Audi TT	2013-2018	8V	06 Passene. Seat Adj.	Read Fault Codes	
Audi TT	2013-2018	8V	06 Passene. Seat Adj.	Clear Fault Codes	
Audi TT	2013-2018	8V	06 Passene. Seat Adj.	Measuring Blocks	
Audi TT	2013-2018	8V	06 Passene. Seat Adj.	Output Tests	
Audi TT	2013-2018	8V	06 Passene. Seat Adj.	Specia Functions	
Audi TT	2013-2018	8V	08 AC/Heating Electronics	Read Fault Codes	
Audi TT	2013-2018	8V	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT	2013-2018	8V	08 AC/Heating Electronics	Measuring Blocks	
Audi TT	2013-2018	8V	08 AC/Heating Electronics	Output Tests	
Audi TT	2013-2018	8V	08 AC/Heating Electronics	Specia Functions	
Audi TT	2013-2018	8V	09 Electronic Ctrl Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2013-2018	8V	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi TT	2013-2018	8V	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi TT	2013-2018	8V	09 Electronic Ctrl Electronics	Output Tests	
Audi TT	2013-2018	8V	09 Electronic Ctrl Electronics	Specia Functions	
Audi TT	2013-2018	8V	13 Distance Control	Read Fault Codes	
Audi TT	2013-2018	8V	13 Distance Control	Clear Fault Codes	
Audi TT	2013-2018	8V	13 Distance Control	Measuring Blocks	
Audi TT	2013-2018	8V	13 Distance Control	Output Tests	
Audi TT	2013-2018	8V	13 Distance Control	Specia Functions	
Audi TT	2013-2018	8V	14 Wheel Damping Electronics	Read Fault Codes	
Audi TT	2013-2018	8V	14 Wheel Damping Electronics	Clear Fault Codes	
Audi TT	2013-2018	8V	14 Wheel Damping Electronics	Measuring Blocks	
Audi TT	2013-2018	8V	14 Wheel Damping Electronics	Output Tests	
Audi TT	2013-2018	8V	14 Wheel Damping Electronics	Specia Functions	
Audi TT	2013-2018	8V	15 Airbags	Read Fault Codes	
Audi TT	2013-2018	8V	15 Airbags	Clear Fault Codes	
Audi TT	2013-2018	8V	15 Airbags	Measuring Blocks	
Audi TT	2013-2018	8V	15 Airbags	Output Tests	
Audi TT	2013-2018	8V	15 Airbags	Specia Functions	
Audi TT	2013-2018	8V	16 Steering Wheel Electronics	Read Fault Codes	
Audi TT	2013-2018	8V	16 Steering Wheel Electronics	Clear Fault Codes	
Audi TT	2013-2018	8V	16 Steering Wheel Electronics	Measuring Blocks	
Audi TT	2013-2018	8V	16 Steering Wheel Electronics	Output Tests	
Audi TT	2013-2018	8V	16 Steering Wheel Electronics	Specia Functions	
Audi TT	2013-2018	8V	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2013-2018	8V	17 Instrument Cluster	Clear Fault Codes	
Audi TT	2013-2018	8V	17 Instrument Cluster	Measuring Blocks	
Audi TT	2013-2018	8V	17 Instrument Cluster	Output Tests	
Audi TT	2013-2018	8V	17 Instrument Cluster	Specia Functions	
Audi TT	2013-2018	8V	18 Aux Heating	Read Fault Codes	
Audi TT	2013-2018	8V	18 Aux Heating	Clear Fault Codes	
Audi TT	2013-2018	8V	18 Aux Heating	Measuring Blocks	
Audi TT	2013-2018	8V	18 Aux Heating	Output Tests	
Audi TT	2013-2018	8V	18 Aux Heating	Specia Functions	
Audi TT	2013-2018	8V	19 Gateway Data Bus	Read Fault Codes	
Audi TT	2013-2018	8V	19 Gateway Data Bus	Clear Fault Codes	
Audi TT	2013-2018	8V	19 Gateway Data Bus	Measuring Blocks	
Audi TT	2013-2018	8V	19 Gateway Data Bus	Output Tests	
Audi TT	2013-2018	8V	19 Gateway Data Bus	Specia Functions	
Audi TT	2013-2018	8V	20 High Beam Assistance Device	Read Fault Codes	
Audi TT	2013-2018	8V	20 High Beam Assistance Device	Clear Fault Codes	
Audi TT	2013-2018	8V	20 High Beam Assistance Device	Measuring Blocks	
Audi TT	2013-2018	8V	20 High Beam Assistance Device	Output Tests	
Audi TT	2013-2018	8V	20 High Beam Assistance Device	Specia Functions	
Audi TT	2013-2018	8V	22 4WD Electronics	Read Fault Codes	
Audi TT	2013-2018	8V	22 4WD Electronics	Clear Fault Codes	
Audi TT	2013-2018	8V	22 4WD Electronics	Measuring Blocks	
Audi TT	2013-2018	8V	22 4WD Electronics	Output Tests	
Audi TT	2013-2018	8V	22 4WD Electronics	Specia Functions	
Audi TT	2013-2018	8V	23 Braker Booster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2013-2018	8V	23 Braker Booster	Clear Fault Codes	
Audi TT	2013-2018	8V	23 Braker Booster	Measuring Blocks	
Audi TT	2013-2018	8V	23 Braker Booster	Output Tests	
Audi TT	2013-2018	8V	23 Braker Booster	Specia Functions	
Audi TT	2013-2018	8V	26 Electric Roof Control	Read Fault Codes	
Audi TT	2013-2018	8V	26 Electric Roof Control	Clear Fault Codes	
Audi TT	2013-2018	8V	26 Electric Roof Control	Measuring Blocks	
Audi TT	2013-2018	8V	26 Electric Roof Control	Output Tests	
Audi TT	2013-2018	8V	26 Electric Roof Control	Specia Functions	
Audi TT	2013-2018	8V	29 Left Light Control	Read Fault Codes	
Audi TT	2013-2018	8V	29 Left Light Control	Clear Fault Codes	
Audi TT	2013-2018	8V	29 Left Light Control	Measuring Blocks	
Audi TT	2013-2018	8V	29 Left Light Control	Output Tests	
Audi TT	2013-2018	8V	29 Left Light Control	Specia Functions	
Audi TT	2013-2018	8V	2B Steer Col Lock	Read Fault Codes	
Audi TT	2013-2018	8V	2B Steer Col Lock	Clear Fault Codes	
Audi TT	2013-2018	8V	2B Steer Col Lock	Measuring Blocks	
Audi TT	2013-2018	8V	2B Steer Col Lock	Output Tests	
Audi TT	2013-2018	8V	2B Steer Col Lock	Specia Functions	
Audi TT	2013-2018	8V	30 Special Function 2	Read Fault Codes	
Audi TT	2013-2018	8V	30 Special Function 2	Clear Fault Codes	
Audi TT	2013-2018	8V	30 Special Function 2	Measuring Blocks	
Audi TT	2013-2018	8V	30 Special Function 2	Output Tests	
Audi TT	2013-2018	8V	30 Special Function 2	Specia Functions	
Audi TT	2013-2018	8V	36 Side of Driver Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi TT	2013-2018	8V	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi TT	2013-2018	8V	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi TT	2013-2018	8V	36 Side of Driver Seat Adj.	Output Tests	
Audi TT	2013-2018	8V	36 Side of Driver Seat Adj.	Specia Functions	
Audi TT	2013-2018	8V	39 Right Light Control	Read Fault Codes	
Audi TT	2013-2018	8V	39 Right Light Control	Clear Fault Codes	
Audi TT	2013-2018	8V	39 Right Light Control	Measuring Blocks	
Audi TT	2013-2018	8V	39 Right Light Control	Output Tests	
Audi TT	2013-2018	8V	39 Right Light Control	Specia Functions	
Audi TT	2013-2018	8V	3C Lane Departure Assistance System	Read Fault Codes	
Audi TT	2013-2018	8V	3C Lane Departure Assistance System	Clear Fault Codes	
Audi TT	2013-2018	8V	3C Lane Departure Assistance System	Measuring Blocks	
Audi TT	2013-2018	8V	3C Lane Departure Assistance System	Output Tests	
Audi TT	2013-2018	8V	3C Lane Departure Assistance System	Specia Functions	
Audi TT	2013-2018	8V	3D Special Function	Read Fault Codes	
Audi TT	2013-2018	8V	3D Special Function	Clear Fault Codes	
Audi TT	2013-2018	8V	3D Special Function	Measuring Blocks	
Audi TT	2013-2018	8V	3D Special Function	Output Tests	
Audi TT	2013-2018	8V	3D Special Function	Specia Functions	
Audi TT	2013-2018	8V	42 Driver-Door Elect.	Read Fault Codes	
Audi TT	2013-2018	8V	42 Driver-Door Elect.	Clear Fault Codes	
Audi TT	2013-2018	8V	42 Driver-Door Elect.	Measuring Blocks	
Audi TT	2013-2018	8V	42 Driver-Door Elect.	Output Tests	
Audi TT	2013-2018	8V	42 Driver-Door Elect.	Specia Functions	
Audi TT	2013-2018	8V	44 Steering Assistance	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2013-2018	8V	44 Steering Assistance	Clear Fault Codes	
Audi TT	2013-2018	8V	44 Steering Assistance	Measuring Blocks	
Audi TT	2013-2018	8V	44 Steering Assistance	Output Tests	
Audi TT	2013-2018	8V	44 Steering Assistance	Specia Functions	
Audi TT	2013-2018	8V	47 Soundsystem	Read Fault Codes	
Audi TT	2013-2018	8V	47 Soundsystem	Clear Fault Codes	
Audi TT	2013-2018	8V	47 Soundsystem	Measuring Blocks	
Audi TT	2013-2018	8V	47 Soundsystem	Output Tests	
Audi TT	2013-2018	8V	47 Soundsystem	Specia Functions	
Audi TT	2013-2018	8V	51 Electric Drive	Read Fault Codes	
Audi TT	2013-2018	8V	51 Electric Drive	Clear Fault Codes	
Audi TT	2013-2018	8V	51 Electric Drive	Measuring Blocks	
Audi TT	2013-2018	8V	51 Electric Drive	Output Tests	
Audi TT	2013-2018	8V	51 Electric Drive	Specia Functions	
Audi TT	2013-2018	8V	52 Passe.-Door Elect.	Read Fault Codes	
Audi TT	2013-2018	8V	52 Passe.-Door Elect.	Clear Fault Codes	
Audi TT	2013-2018	8V	52 Passe.-Door Elect.	Measuring Blocks	
Audi TT	2013-2018	8V	52 Passe.-Door Elect.	Output Tests	
Audi TT	2013-2018	8V	52 Passe.-Door Elect.	Specia Functions	
Audi TT	2013-2018	8V	55 Headlight Range Control	Read Fault Codes	
Audi TT	2013-2018	8V	55 Headlight Range Control	Clear Fault Codes	
Audi TT	2013-2018	8V	55 Headlight Range Control	Measuring Blocks	
Audi TT	2013-2018	8V	55 Headlight Range Control	Output Tests	
Audi TT	2013-2018	8V	55 Headlight Range Control	Specia Functions	
Audi TT	2013-2018	8V	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2013-2018	8V	57 TV-Tuner	Clear Fault Codes	
Audi TT	2013-2018	8V	57 TV-Tuner	Measuring Blocks	
Audi TT	2013-2018	8V	57 TV-Tuner	Output Tests	
Audi TT	2013-2018	8V	57 TV-Tuner	Specia Functions	
Audi TT	2013-2018	8V	5F Information Electronic Equipment 1	Read Fault Codes	
Audi TT	2013-2018	8V	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi TT	2013-2018	8V	5F Information Electronic Equipment 1	Measuring Blocks	
Audi TT	2013-2018	8V	5F Information Electronic Equipment 1	Output Tests	
Audi TT	2013-2018	8V	5F Information Electronic Equipment 1	Specia Functions	
Audi TT	2013-2018	8V	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi TT	2013-2018	8V	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi TT	2013-2018	8V	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi TT	2013-2018	8V	65 Tyre Pressure Monitoring	Output Tests	
Audi TT	2013-2018	8V	65 Tyre Pressure Monitoring	Specia Functions	
Audi TT	2013-2018	8V	69 Trailer Function	Read Fault Codes	
Audi TT	2013-2018	8V	69 Trailer Function	Clear Fault Codes	
Audi TT	2013-2018	8V	69 Trailer Function	Measuring Blocks	
Audi TT	2013-2018	8V	69 Trailer Function	Output Tests	
Audi TT	2013-2018	8V	69 Trailer Function	Specia Functions	
Audi TT	2013-2018	8V	6C Rear Camera	Read Fault Codes	
Audi TT	2013-2018	8V	6C Rear Camera	Clear Fault Codes	
Audi TT	2013-2018	8V	6C Rear Camera	Measuring Blocks	
Audi TT	2013-2018	8V	6C Rear Camera	Output Tests	
Audi TT	2013-2018	8V	6C Rear Camera	Specia Functions	
Audi TT	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi TT	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi TT	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi TT	2013-2018	8V	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi TT	2013-2018	8V	75 Emergency Call Module	Read Fault Codes	
Audi TT	2013-2018	8V	75 Emergency Call Module	Clear Fault Codes	
Audi TT	2013-2018	8V	75 Emergency Call Module	Measuring Blocks	
Audi TT	2013-2018	8V	75 Emergency Call Module	Output Tests	
Audi TT	2013-2018	8V	75 Emergency Call Module	Specia Functions	
Audi TT	2013-2018	8V	76 Parking Aid	Read Fault Codes	
Audi TT	2013-2018	8V	76 Parking Aid	Clear Fault Codes	
Audi TT	2013-2018	8V	76 Parking Aid	Measuring Blocks	
Audi TT	2013-2018	8V	76 Parking Aid	Output Tests	
Audi TT	2013-2018	8V	76 Parking Aid	Specia Functions	
Audi TT	2013-2018	8V	82 Heads Up Display	Read Fault Codes	
Audi TT	2013-2018	8V	82 Heads Up Display	Clear Fault Codes	
Audi TT	2013-2018	8V	82 Heads Up Display	Measuring Blocks	
Audi TT	2013-2018	8V	82 Heads Up Display	Output Tests	
Audi TT	2013-2018	8V	82 Heads Up Display	Specia Functions	
Audi TT	2013-2018	8V	8C Hybrid Battery	Read Fault Codes	
Audi TT	2013-2018	8V	8C Hybrid Battery	Clear Fault Codes	
Audi TT	2013-2018	8V	8C Hybrid Battery	Measuring Blocks	
Audi TT	2013-2018	8V	8C Hybrid Battery	Output Tests	
Audi TT	2013-2018	8V	8C Hybrid Battery	Specia Functions	
Audi TT	2013-2018	8V	A5 Frt Sens.Drv.Assist	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2013-2018	8V	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi TT	2013-2018	8V	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi TT	2013-2018	8V	A5 Frt Sens.Drv.Assist	Output Tests	
Audi TT	2013-2018	8V	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi TT	2013-2018	8V	A6 Microphone	Read Fault Codes	
Audi TT	2013-2018	8V	A6 Microphone	Clear Fault Codes	
Audi TT	2013-2018	8V	A6 Microphone	Measuring Blocks	
Audi TT	2013-2018	8V	A6 Microphone	Output Tests	
Audi TT	2013-2018	8V	A6 Microphone	Specia Functions	
Audi TT	2013-2018	8V	A9 Struct.Borne Sound	Read Fault Codes	
Audi TT	2013-2018	8V	A9 Struct.Borne Sound	Clear Fault Codes	
Audi TT	2013-2018	8V	A9 Struct.Borne Sound	Measuring Blocks	
Audi TT	2013-2018	8V	A9 Struct.Borne Sound	Output Tests	
Audi TT	2013-2018	8V	A9 Struct.Borne Sound	Specia Functions	
Audi TT	2013-2018	8V	B7 Access Start Interf	Read Fault Codes	
Audi TT	2013-2018	8V	B7 Access Start Interf	Clear Fault Codes	
Audi TT	2013-2018	8V	B7 Access Start Interf	Measuring Blocks	
Audi TT	2013-2018	8V	B7 Access Start Interf	Output Tests	
Audi TT	2013-2018	8V	B7 Access Start Interf	Specia Functions	
Audi TT	2013-2018	8V	BB Door Rear Drv Side	Read Fault Codes	
Audi TT	2013-2018	8V	BB Door Rear Drv Side	Clear Fault Codes	
Audi TT	2013-2018	8V	BB Door Rear Drv Side	Measuring Blocks	
Audi TT	2013-2018	8V	BB Door Rear Drv Side	Output Tests	
Audi TT	2013-2018	8V	BB Door Rear Drv Side	Specia Functions	
Audi TT	2013-2018	8V	BC Door Rear Pass Side	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2013-2018	8V	BC Door Rear Pass Side	Clear Fault Codes	
Audi TT	2013-2018	8V	BC Door Rear Pass Side	Measuring Blocks	
Audi TT	2013-2018	8V	BC Door Rear Pass Side	Output Tests	
Audi TT	2013-2018	8V	BC Door Rear Pass Side	Specia Functions	
Audi TT	2013-2018	8V	C0 Act. For Ext. Noise	Read Fault Codes	
Audi TT	2013-2018	8V	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi TT	2013-2018	8V	C0 Act. For Ext. Noise	Measuring Blocks	
Audi TT	2013-2018	8V	C0 Act. For Ext. Noise	Output Tests	
Audi TT	2013-2018	8V	C0 Act. For Ext. Noise	Specia Functions	
Audi TT	2013-2018	8V	C6 Batt. Chrg	Read Fault Codes	
Audi TT	2013-2018	8V	C6 Batt. Chrg	Clear Fault Codes	
Audi TT	2013-2018	8V	C6 Batt. Chrg	Measuring Blocks	
Audi TT	2013-2018	8V	C6 Batt. Chrg	Output Tests	
Audi TT	2013-2018	8V	C6 Batt. Chrg	Specia Functions	
Audi Q1	2017	GA	01 Engine Electronics	Read Fault Codes	
Audi Q1	2017	GA	01 Engine Electronics	Clear Fault Codes	
Audi Q1	2017	GA	01 Engine Electronics	Measuring Blocks	
Audi Q1	2017	GA	01 Engine Electronics	Output Tests	
Audi Q1	2017	GA	01 Engine Electronics	Specia Functions	
Audi Q1	2017	GA	02 Transmission Electronics	Read Fault Codes	
Audi Q1	2017	GA	02 Transmission Electronics	Clear Fault Codes	
Audi Q1	2017	GA	02 Transmission Electronics	Measuring Blocks	
Audi Q1	2017	GA	02 Transmission Electronics	Output Tests	
Audi Q1	2017	GA	02 Transmission Electronics	Specia Functions	
Audi Q1	2017	GA	03 Brake Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q1	2017	GA	03 Brake Electronics	Clear Fault Codes	
Audi Q1	2017	GA	03 Brake Electronics	Measuring Blocks	
Audi Q1	2017	GA	03 Brake Electronics	Output Tests	
Audi Q1	2017	GA	03 Brake Electronics	Specia Functions	
Audi Q1	2017	GA	06 Passene. Seat Adj.	Read Fault Codes	
Audi Q1	2017	GA	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q1	2017	GA	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q1	2017	GA	06 Passene. Seat Adj.	Output Tests	
Audi Q1	2017	GA	06 Passene. Seat Adj.	Specia Functions	
Audi Q1	2017	GA	08 AC/Heating Electronics	Read Fault Codes	
Audi Q1	2017	GA	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q1	2017	GA	08 AC/Heating Electronics	Measuring Blocks	
Audi Q1	2017	GA	08 AC/Heating Electronics	Output Tests	
Audi Q1	2017	GA	08 AC/Heating Electronics	Specia Functions	
Audi Q1	2017	GA	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Q1	2017	GA	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q1	2017	GA	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q1	2017	GA	09 Electronic Ctrl Electronics	Output Tests	
Audi Q1	2017	GA	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q1	2017	GA	13 Distance Control	Read Fault Codes	
Audi Q1	2017	GA	13 Distance Control	Clear Fault Codes	
Audi Q1	2017	GA	13 Distance Control	Measuring Blocks	
Audi Q1	2017	GA	13 Distance Control	Output Tests	
Audi Q1	2017	GA	13 Distance Control	Specia Functions	
Audi Q1	2017	GA	14 Wheel Damping Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q1	2017	GA	14 Wheel Damping Electronics	Clear Fault Codes	
Audi Q1	2017	GA	14 Wheel Damping Electronics	Measuring Blocks	
Audi Q1	2017	GA	14 Wheel Damping Electronics	Output Tests	
Audi Q1	2017	GA	14 Wheel Damping Electronics	Specia Functions	
Audi Q1	2017	GA	15 Airbags	Read Fault Codes	
Audi Q1	2017	GA	15 Airbags	Clear Fault Codes	
Audi Q1	2017	GA	15 Airbags	Measuring Blocks	
Audi Q1	2017	GA	15 Airbags	Output Tests	
Audi Q1	2017	GA	15 Airbags	Specia Functions	
Audi Q1	2017	GA	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q1	2017	GA	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q1	2017	GA	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q1	2017	GA	16 Steering Wheel Electronics	Output Tests	
Audi Q1	2017	GA	16 Steering Wheel Electronics	Specia Functions	
Audi Q1	2017	GA	17 Instrument Cluster	Read Fault Codes	
Audi Q1	2017	GA	17 Instrument Cluster	Clear Fault Codes	
Audi Q1	2017	GA	17 Instrument Cluster	Measuring Blocks	
Audi Q1	2017	GA	17 Instrument Cluster	Output Tests	
Audi Q1	2017	GA	17 Instrument Cluster	Specia Functions	
Audi Q1	2017	GA	18 Aux Heating	Read Fault Codes	
Audi Q1	2017	GA	18 Aux Heating	Clear Fault Codes	
Audi Q1	2017	GA	18 Aux Heating	Measuring Blocks	
Audi Q1	2017	GA	18 Aux Heating	Output Tests	
Audi Q1	2017	GA	18 Aux Heating	Specia Functions	
Audi Q1	2017	GA	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q1	2017	GA	19 Gateway Data Bus	Clear Fault Codes	
Audi Q1	2017	GA	19 Gateway Data Bus	Measuring Blocks	
Audi Q1	2017	GA	19 Gateway Data Bus	Output Tests	
Audi Q1	2017	GA	19 Gateway Data Bus	Specia Functions	
Audi Q1	2017	GA	20 High Beam Assistance Device	Read Fault Codes	
Audi Q1	2017	GA	20 High Beam Assistance Device	Clear Fault Codes	
Audi Q1	2017	GA	20 High Beam Assistance Device	Measuring Blocks	
Audi Q1	2017	GA	20 High Beam Assistance Device	Output Tests	
Audi Q1	2017	GA	20 High Beam Assistance Device	Specia Functions	
Audi Q1	2017	GA	22 4WD Electronics	Read Fault Codes	
Audi Q1	2017	GA	22 4WD Electronics	Clear Fault Codes	
Audi Q1	2017	GA	22 4WD Electronics	Measuring Blocks	
Audi Q1	2017	GA	22 4WD Electronics	Output Tests	
Audi Q1	2017	GA	22 4WD Electronics	Specia Functions	
Audi Q1	2017	GA	23 Braker Booster	Read Fault Codes	
Audi Q1	2017	GA	23 Braker Booster	Clear Fault Codes	
Audi Q1	2017	GA	23 Braker Booster	Measuring Blocks	
Audi Q1	2017	GA	23 Braker Booster	Output Tests	
Audi Q1	2017	GA	23 Braker Booster	Specia Functions	
Audi Q1	2017	GA	26 Electric Roof Control	Read Fault Codes	
Audi Q1	2017	GA	26 Electric Roof Control	Clear Fault Codes	
Audi Q1	2017	GA	26 Electric Roof Control	Measuring Blocks	
Audi Q1	2017	GA	26 Electric Roof Control	Output Tests	
Audi Q1	2017	GA	26 Electric Roof Control	Specia Functions	
Audi Q1	2017	GA	29 Left Light Control	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q1	2017	GA	29 Left Light Control	Clear Fault Codes	
Audi Q1	2017	GA	29 Left Light Control	Measuring Blocks	
Audi Q1	2017	GA	29 Left Light Control	Output Tests	
Audi Q1	2017	GA	29 Left Light Control	Specia Functions	
Audi Q1	2017	GA	2B Steer Col Lock	Read Fault Codes	
Audi Q1	2017	GA	2B Steer Col Lock	Clear Fault Codes	
Audi Q1	2017	GA	2B Steer Col Lock	Measuring Blocks	
Audi Q1	2017	GA	2B Steer Col Lock	Output Tests	
Audi Q1	2017	GA	2B Steer Col Lock	Specia Functions	
Audi Q1	2017	GA	30 Special Function 2	Read Fault Codes	
Audi Q1	2017	GA	30 Special Function 2	Clear Fault Codes	
Audi Q1	2017	GA	30 Special Function 2	Measuring Blocks	
Audi Q1	2017	GA	30 Special Function 2	Output Tests	
Audi Q1	2017	GA	30 Special Function 2	Specia Functions	
Audi Q1	2017	GA	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi Q1	2017	GA	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Q1	2017	GA	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Q1	2017	GA	36 Side of Driver Seat Adj.	Output Tests	
Audi Q1	2017	GA	36 Side of Driver Seat Adj.	Specia Functions	
Audi Q1	2017	GA	39 Right Light Control	Read Fault Codes	
Audi Q1	2017	GA	39 Right Light Control	Clear Fault Codes	
Audi Q1	2017	GA	39 Right Light Control	Measuring Blocks	
Audi Q1	2017	GA	39 Right Light Control	Output Tests	
Audi Q1	2017	GA	39 Right Light Control	Specia Functions	
Audi Q1	2017	GA	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q1	2017	GA	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q1	2017	GA	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q1	2017	GA	3C Lane Departure Assistance System	Output Tests	
Audi Q1	2017	GA	3C Lane Departure Assistance System	Specia Functions	
Audi Q1	2017	GA	3D Special Function	Read Fault Codes	
Audi Q1	2017	GA	3D Special Function	Clear Fault Codes	
Audi Q1	2017	GA	3D Special Function	Measuring Blocks	
Audi Q1	2017	GA	3D Special Function	Output Tests	
Audi Q1	2017	GA	3D Special Function	Specia Functions	
Audi Q1	2017	GA	42 Driver-Door Elect.	Read Fault Codes	
Audi Q1	2017	GA	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q1	2017	GA	42 Driver-Door Elect.	Measuring Blocks	
Audi Q1	2017	GA	42 Driver-Door Elect.	Output Tests	
Audi Q1	2017	GA	42 Driver-Door Elect.	Specia Functions	
Audi Q1	2017	GA	44 Steering Assistance	Read Fault Codes	
Audi Q1	2017	GA	44 Steering Assistance	Clear Fault Codes	
Audi Q1	2017	GA	44 Steering Assistance	Measuring Blocks	
Audi Q1	2017	GA	44 Steering Assistance	Output Tests	
Audi Q1	2017	GA	44 Steering Assistance	Specia Functions	
Audi Q1	2017	GA	47 Soundsystem	Read Fault Codes	
Audi Q1	2017	GA	47 Soundsystem	Clear Fault Codes	
Audi Q1	2017	GA	47 Soundsystem	Measuring Blocks	
Audi Q1	2017	GA	47 Soundsystem	Output Tests	
Audi Q1	2017	GA	47 Soundsystem	Specia Functions	
Audi Q1	2017	GA	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q1	2017	GA	51 Electric Drive	Clear Fault Codes	
Audi Q1	2017	GA	51 Electric Drive	Measuring Blocks	
Audi Q1	2017	GA	51 Electric Drive	Output Tests	
Audi Q1	2017	GA	51 Electric Drive	Specia Functions	
Audi Q1	2017	GA	52 Passe.-Door Elect.	Read Fault Codes	
Audi Q1	2017	GA	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q1	2017	GA	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q1	2017	GA	52 Passe.-Door Elect.	Output Tests	
Audi Q1	2017	GA	52 Passe.-Door Elect.	Specia Functions	
Audi Q1	2017	GA	55 Headlight Range Control	Read Fault Codes	
Audi Q1	2017	GA	55 Headlight Range Control	Clear Fault Codes	
Audi Q1	2017	GA	55 Headlight Range Control	Measuring Blocks	
Audi Q1	2017	GA	55 Headlight Range Control	Output Tests	
Audi Q1	2017	GA	55 Headlight Range Control	Specia Functions	
Audi Q1	2017	GA	57 TV-Tuner	Read Fault Codes	
Audi Q1	2017	GA	57 TV-Tuner	Clear Fault Codes	
Audi Q1	2017	GA	57 TV-Tuner	Measuring Blocks	
Audi Q1	2017	GA	57 TV-Tuner	Output Tests	
Audi Q1	2017	GA	57 TV-Tuner	Specia Functions	
Audi Q1	2017	GA	5F Information Electronic Equipment 1	Read Fault Codes	
Audi Q1	2017	GA	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi Q1	2017	GA	5F Information Electronic Equipment 1	Measuring Blocks	
Audi Q1	2017	GA	5F Information Electronic Equipment 1	Output Tests	
Audi Q1	2017	GA	5F Information Electronic Equipment 1	Specia Functions	
Audi Q1	2017	GA	65 Tyre Pressure Monitoring	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q1	2017	GA	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Q1	2017	GA	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Q1	2017	GA	65 Tyre Pressure Monitoring	Output Tests	
Audi Q1	2017	GA	65 Tyre Pressure Monitoring	Specia Functions	
Audi Q1	2017	GA	69 Trailer Function	Read Fault Codes	
Audi Q1	2017	GA	69 Trailer Function	Clear Fault Codes	
Audi Q1	2017	GA	69 Trailer Function	Measuring Blocks	
Audi Q1	2017	GA	69 Trailer Function	Output Tests	
Audi Q1	2017	GA	69 Trailer Function	Specia Functions	
Audi Q1	2017	GA	6C Rear Camera	Read Fault Codes	
Audi Q1	2017	GA	6C Rear Camera	Clear Fault Codes	
Audi Q1	2017	GA	6C Rear Camera	Measuring Blocks	
Audi Q1	2017	GA	6C Rear Camera	Output Tests	
Audi Q1	2017	GA	6C Rear Camera	Specia Functions	
Audi Q1	2017	GA	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi Q1	2017	GA	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q1	2017	GA	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q1	2017	GA	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q1	2017	GA	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q1	2017	GA	75 Emergency Call Module	Read Fault Codes	
Audi Q1	2017	GA	75 Emergency Call Module	Clear Fault Codes	
Audi Q1	2017	GA	75 Emergency Call Module	Measuring Blocks	
Audi Q1	2017	GA	75 Emergency Call Module	Output Tests	
Audi Q1	2017	GA	75 Emergency Call Module	Specia Functions	
Audi Q1	2017	GA	76 Parking Aid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q1	2017	GA	76 Parking Aid	Clear Fault Codes	
Audi Q1	2017	GA	76 Parking Aid	Measuring Blocks	
Audi Q1	2017	GA	76 Parking Aid	Output Tests	
Audi Q1	2017	GA	76 Parking Aid	Specia Functions	
Audi Q1	2017	GA	82 Heads Up Display	Read Fault Codes	
Audi Q1	2017	GA	82 Heads Up Display	Clear Fault Codes	
Audi Q1	2017	GA	82 Heads Up Display	Measuring Blocks	
Audi Q1	2017	GA	82 Heads Up Display	Output Tests	
Audi Q1	2017	GA	82 Heads Up Display	Specia Functions	
Audi Q1	2017	GA	8C Hybrid Battery	Read Fault Codes	
Audi Q1	2017	GA	8C Hybrid Battery	Clear Fault Codes	
Audi Q1	2017	GA	8C Hybrid Battery	Measuring Blocks	
Audi Q1	2017	GA	8C Hybrid Battery	Output Tests	
Audi Q1	2017	GA	8C Hybrid Battery	Specia Functions	
Audi Q1	2017	GA	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi Q1	2017	GA	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi Q1	2017	GA	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi Q1	2017	GA	A5 Frt Sens.Drv.Assist	Output Tests	
Audi Q1	2017	GA	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi Q1	2017	GA	A6 Microphone	Read Fault Codes	
Audi Q1	2017	GA	A6 Microphone	Clear Fault Codes	
Audi Q1	2017	GA	A6 Microphone	Measuring Blocks	
Audi Q1	2017	GA	A6 Microphone	Output Tests	
Audi Q1	2017	GA	A6 Microphone	Specia Functions	
Audi Q1	2017	GA	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q1	2017	GA	A9 Struct.Borne Sound	Clear Fault Codes	
Audi Q1	2017	GA	A9 Struct.Borne Sound	Measuring Blocks	
Audi Q1	2017	GA	A9 Struct.Borne Sound	Output Tests	
Audi Q1	2017	GA	A9 Struct.Borne Sound	Specia Functions	
Audi Q1	2017	GA	B7 Access Start Interf	Read Fault Codes	
Audi Q1	2017	GA	B7 Access Start Interf	Clear Fault Codes	
Audi Q1	2017	GA	B7 Access Start Interf	Measuring Blocks	
Audi Q1	2017	GA	B7 Access Start Interf	Output Tests	
Audi Q1	2017	GA	B7 Access Start Interf	Specia Functions	
Audi Q1	2017	GA	BB Door Rear Drv Side	Read Fault Codes	
Audi Q1	2017	GA	BB Door Rear Drv Side	Clear Fault Codes	
Audi Q1	2017	GA	BB Door Rear Drv Side	Measuring Blocks	
Audi Q1	2017	GA	BB Door Rear Drv Side	Output Tests	
Audi Q1	2017	GA	BB Door Rear Drv Side	Specia Functions	
Audi Q1	2017	GA	BC Door Rear Pass Side	Read Fault Codes	
Audi Q1	2017	GA	BC Door Rear Pass Side	Clear Fault Codes	
Audi Q1	2017	GA	BC Door Rear Pass Side	Measuring Blocks	
Audi Q1	2017	GA	BC Door Rear Pass Side	Output Tests	
Audi Q1	2017	GA	BC Door Rear Pass Side	Specia Functions	
Audi Q1	2017	GA	C0 Act. For Ext. Noise	Read Fault Codes	
Audi Q1	2017	GA	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi Q1	2017	GA	C0 Act. For Ext. Noise	Measuring Blocks	
Audi Q1	2017	GA	C0 Act. For Ext. Noise	Output Tests	
Audi Q1	2017	GA	C0 Act. For Ext. Noise	Specia Functions	
Audi Q1	2017	GA	C6 Batt. Chrg	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q1	2017	GA	C6 Batt. Chrg	Clear Fault Codes	
Audi Q1	2017	GA	C6 Batt. Chrg	Measuring Blocks	
Audi Q1	2017	GA	C6 Batt. Chrg	Output Tests	
Audi Q1	2017	GA	C6 Batt. Chrg	Specia Functions	
Audi A4 (USA)	2008-2018	8R	01 Engine Electronics	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi A4 (USA)	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi A4 (USA)	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi A4 (USA)	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi A4 (USA)	2008-2018	8R	03 Brake Electronics	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi A4 (USA)	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi A4 (USA)	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi A4 (USA)	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi A4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi A4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi A4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi A4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi A4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi A4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi A4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi A4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi A4 (USA)	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi A4 (USA)	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi A4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi A4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi A4 (USA)	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi A4 (USA)	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi A4 (USA)	2008-2018	8R	13 Distance Control	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	13 Distance Control	Output Tests	
Audi A4 (USA)	2008-2018	8R	13 Distance Control	Specia Functions	
Audi A4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi A4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi A4 (USA)	2008-2018	8R	15 Airbags	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	15 Airbags	Output Tests	
Audi A4 (USA)	2008-2018	8R	15 Airbags	Specia Functions	
Audi A4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi A4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi A4 (USA)	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi A4 (USA)	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi A4 (USA)	2008-2018	8R	18 Aux Heating	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	18 Aux Heating	Output Tests	
Audi A4 (USA)	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi A4 (USA)	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi A4 (USA)	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi A4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi A4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi A4 (USA)	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4 (USA)	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi A4 (USA)	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi A4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi A4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi A4 (USA)	2008-2018	8R	22 4WD Electronics	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi A4 (USA)	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi A4 (USA)	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi A4 (USA)	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi A4 (USA)	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi A4 (USA)	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi A4 (USA)	2008-2018	8R	30 Special Function 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4 (USA)	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	30 Special Function 2	Output Tests	
Audi A4 (USA)	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi A4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi A4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi A4 (USA)	2008-2018	8R	37 Navigation	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	37 Navigation	Output Tests	
Audi A4 (USA)	2008-2018	8R	37 Navigation	Specia Functions	
Audi A4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi A4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi A4 (USA)	2008-2018	8R	3D Special Function	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	3D Special Function	Output Tests	
Audi A4 (USA)	2008-2018	8R	3D Special Function	Specia Functions	
Audi A4 (USA)	2008-2018	8R	40 Air Compressor	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4 (USA)	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	40 Air Compressor	Output Tests	
Audi A4 (USA)	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi A4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi A4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi A4 (USA)	2008-2018	8R	44 Steering Assistance	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi A4 (USA)	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi A4 (USA)	2008-2018	8R	46 Central Control Module	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	46 Central Control Module	Output Tests	
Audi A4 (USA)	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi A4 (USA)	2008-2018	8R	47 Soundsystem	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	47 Soundsystem	Output Tests	
Audi A4 (USA)	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi A4 (USA)	2008-2018	8R	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4 (USA)	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	51 Electric Drive	Output Tests	
Audi A4 (USA)	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi A4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi A4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi A4 (USA)	2008-2018	8R	53 Parking Brake	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	53 Parking Brake	Output Tests	
Audi A4 (USA)	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi A4 (USA)	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi A4 (USA)	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi A4 (USA)	2008-2018	8R	56 Radio	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	56 Radio	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	56 Radio	Output Tests	
Audi A4 (USA)	2008-2018	8R	56 Radio	Specia Functions	
Audi A4 (USA)	2008-2018	8R	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4 (USA)	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi A4 (USA)	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi A4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi A4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi A4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi A4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi A4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi A4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi A4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi A4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi A4 (USA)	2008-2018	8R	67 Voice Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4 (USA)	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	67 Voice Control	Output Tests	
Audi A4 (USA)	2008-2018	8R	67 Voice Control	Specia Functions	
Audi A4 (USA)	2008-2018	8R	69 Trailer Function	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	69 Trailer Function	Output Tests	
Audi A4 (USA)	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi A4 (USA)	2008-2018	8R	6C Rear Camera	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	6C Rear Camera	Output Tests	
Audi A4 (USA)	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi A4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi A4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi A4 (USA)	2008-2018	8R	77 Telephone	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi A4 (USA)	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	77 Telephone	Output Tests	
Audi A4 (USA)	2008-2018	8R	77 Telephone	Specia Functions	
Audi A4 (USA)	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi A4 (USA)	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi A4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi A4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi A4 (USA)	2008-2018	8R	AC Reductant Control	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	AC Reductant Control	Output Tests	
Audi A4 (USA)	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi A4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi A4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi S4 (USA)	2008-2018	8R	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4 (USA)	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi S4 (USA)	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi S4 (USA)	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi S4 (USA)	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi S4 (USA)	2008-2018	8R	03 Brake Electronics	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi S4 (USA)	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi S4 (USA)	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi S4 (USA)	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi S4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi S4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi S4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi S4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi S4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi S4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi S4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi S4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi S4 (USA)	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi S4 (USA)	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi S4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi S4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi S4 (USA)	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4 (USA)	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi S4 (USA)	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi S4 (USA)	2008-2018	8R	13 Distance Control	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	13 Distance Control	Output Tests	
Audi S4 (USA)	2008-2018	8R	13 Distance Control	Specia Functions	
Audi S4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi S4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi S4 (USA)	2008-2018	8R	15 Airbags	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	15 Airbags	Output Tests	
Audi S4 (USA)	2008-2018	8R	15 Airbags	Specia Functions	
Audi S4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi S4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi S4 (USA)	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4 (USA)	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi S4 (USA)	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi S4 (USA)	2008-2018	8R	18 Aux Heating	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	18 Aux Heating	Output Tests	
Audi S4 (USA)	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi S4 (USA)	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi S4 (USA)	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi S4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi S4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi S4 (USA)	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi S4 (USA)	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi S4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi S4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi S4 (USA)	2008-2018	8R	22 4WD Electronics	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi S4 (USA)	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi S4 (USA)	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi S4 (USA)	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi S4 (USA)	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi S4 (USA)	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi S4 (USA)	2008-2018	8R	30 Special Function 2	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	30 Special Function 2	Output Tests	
Audi S4 (USA)	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi S4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi S4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi S4 (USA)	2008-2018	8R	37 Navigation	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	37 Navigation	Output Tests	
Audi S4 (USA)	2008-2018	8R	37 Navigation	Specia Functions	
Audi S4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi S4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi S4 (USA)	2008-2018	8R	3D Special Function	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	3D Special Function	Output Tests	
Audi S4 (USA)	2008-2018	8R	3D Special Function	Specia Functions	
Audi S4 (USA)	2008-2018	8R	40 Air Compressor	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	40 Air Compressor	Output Tests	
Audi S4 (USA)	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi S4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi S4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi S4 (USA)	2008-2018	8R	44 Steering Assistance	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi S4 (USA)	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi S4 (USA)	2008-2018	8R	46 Central Control Module	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	46 Central Control Module	Output Tests	
Audi S4 (USA)	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi S4 (USA)	2008-2018	8R	47 Soundsystem	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	47 Soundsystem	Output Tests	
Audi S4 (USA)	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi S4 (USA)	2008-2018	8R	51 Electric Drive	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	51 Electric Drive	Output Tests	
Audi S4 (USA)	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi S4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi S4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi S4 (USA)	2008-2018	8R	53 Parking Brake	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	53 Parking Brake	Output Tests	
Audi S4 (USA)	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi S4 (USA)	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi S4 (USA)	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi S4 (USA)	2008-2018	8R	56 Radio	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	56 Radio	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	56 Radio	Output Tests	
Audi S4 (USA)	2008-2018	8R	56 Radio	Specia Functions	
Audi S4 (USA)	2008-2018	8R	57 TV-Tuner	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi S4 (USA)	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi S4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi S4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi S4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi S4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi S4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi S4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi S4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi S4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi S4 (USA)	2008-2018	8R	67 Voice Control	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	67 Voice Control	Output Tests	
Audi S4 (USA)	2008-2018	8R	67 Voice Control	Specia Functions	
Audi S4 (USA)	2008-2018	8R	69 Trailer Function	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S4 (USA)	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	69 Trailer Function	Output Tests	
Audi S4 (USA)	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi S4 (USA)	2008-2018	8R	6C Rear Camera	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	6C Rear Camera	Output Tests	
Audi S4 (USA)	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi S4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi S4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi S4 (USA)	2008-2018	8R	77 Telephone	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	77 Telephone	Output Tests	
Audi S4 (USA)	2008-2018	8R	77 Telephone	Specia Functions	
Audi S4 (USA)	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S4 (USA)	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi S4 (USA)	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi S4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi S4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi S4 (USA)	2008-2018	8R	AC Reductant Control	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	AC Reductant Control	Output Tests	
Audi S4 (USA)	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi S4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	
Audi S4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi S4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi S4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi S4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	01 Engine Electronics	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi RS4 (USA)	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4 (USA)	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi RS4 (USA)	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	03 Brake Electronics	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi RS4 (USA)	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi RS4 (USA)	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi RS4 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi RS4 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi RS4 (USA)	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi RS4 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi RS4 (USA)	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi RS4 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi RS4 (USA)	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	13 Distance Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4 (USA)	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	13 Distance Control	Output Tests	
Audi RS4 (USA)	2008-2018	8R	13 Distance Control	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi RS4 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	15 Airbags	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	15 Airbags	Output Tests	
Audi RS4 (USA)	2008-2018	8R	15 Airbags	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi RS4 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi RS4 (USA)	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4 (USA)	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	18 Aux Heating	Output Tests	
Audi RS4 (USA)	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi RS4 (USA)	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi RS4 (USA)	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi RS4 (USA)	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi RS4 (USA)	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	22 4WD Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4 (USA)	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi RS4 (USA)	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi RS4 (USA)	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi RS4 (USA)	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	30 Special Function 2	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	30 Special Function 2	Output Tests	
Audi RS4 (USA)	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi RS4 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	37 Navigation	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4 (USA)	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	37 Navigation	Output Tests	
Audi RS4 (USA)	2008-2018	8R	37 Navigation	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi RS4 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	3D Special Function	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	3D Special Function	Output Tests	
Audi RS4 (USA)	2008-2018	8R	3D Special Function	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	40 Air Compressor	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	40 Air Compressor	Output Tests	
Audi RS4 (USA)	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi RS4 (USA)	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	44 Steering Assistance	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4 (USA)	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi RS4 (USA)	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	46 Central Control Module	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	46 Central Control Module	Output Tests	
Audi RS4 (USA)	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	47 Soundsystem	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	47 Soundsystem	Output Tests	
Audi RS4 (USA)	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	51 Electric Drive	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	51 Electric Drive	Output Tests	
Audi RS4 (USA)	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi RS4 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	53 Parking Brake	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS4 (USA)	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	53 Parking Brake	Output Tests	
Audi RS4 (USA)	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi RS4 (USA)	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	56 Radio	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	56 Radio	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	56 Radio	Output Tests	
Audi RS4 (USA)	2008-2018	8R	56 Radio	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	57 TV-Tuner	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi RS4 (USA)	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi RS4 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi RS4 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi RS4 (USA)	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi RS4 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	67 Voice Control	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	67 Voice Control	Output Tests	
Audi RS4 (USA)	2008-2018	8R	67 Voice Control	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	69 Trailer Function	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	69 Trailer Function	Output Tests	
Audi RS4 (USA)	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	6C Rear Camera	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS4 (USA)	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	6C Rear Camera	Output Tests	
Audi RS4 (USA)	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi RS4 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi RS4 (USA)	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	77 Telephone	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	77 Telephone	Output Tests	
Audi RS4 (USA)	2008-2018	8R	77 Telephone	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi RS4 (USA)	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi RS4 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	AC Reductant Control	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	AC Reductant Control	Output Tests	
Audi RS4 (USA)	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi RS4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	
Audi RS4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi RS4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi RS4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi RS4 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi A5 (USA)	2008-2018	8R	01 Engine Electronics	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi A5 (USA)	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi A5 (USA)	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi A5 (USA)	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi A5 (USA)	2008-2018	8R	03 Brake Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A5 (USA)	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi A5 (USA)	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi A5 (USA)	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi A5 (USA)	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi A5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi A5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi A5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi A5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi A5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi A5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi A5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi A5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi A5 (USA)	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi A5 (USA)	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi A5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi A5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi A5 (USA)	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi A5 (USA)	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi A5 (USA)	2008-2018	8R	13 Distance Control	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	13 Distance Control	Output Tests	
Audi A5 (USA)	2008-2018	8R	13 Distance Control	Specia Functions	
Audi A5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi A5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi A5 (USA)	2008-2018	8R	15 Airbags	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	15 Airbags	Output Tests	
Audi A5 (USA)	2008-2018	8R	15 Airbags	Specia Functions	
Audi A5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi A5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi A5 (USA)	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi A5 (USA)	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi A5 (USA)	2008-2018	8R	18 Aux Heating	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	18 Aux Heating	Output Tests	
Audi A5 (USA)	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi A5 (USA)	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi A5 (USA)	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi A5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi A5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi A5 (USA)	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi A5 (USA)	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi A5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi A5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi A5 (USA)	2008-2018	8R	22 4WD Electronics	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi A5 (USA)	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi A5 (USA)	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi A5 (USA)	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi A5 (USA)	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi A5 (USA)	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi A5 (USA)	2008-2018	8R	30 Special Function 2	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	30 Special Function 2	Output Tests	
Audi A5 (USA)	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi A5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi A5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi A5 (USA)	2008-2018	8R	37 Navigation	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	37 Navigation	Output Tests	
Audi A5 (USA)	2008-2018	8R	37 Navigation	Specia Functions	
Audi A5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi A5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi A5 (USA)	2008-2018	8R	3D Special Function	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	3D Special Function	Output Tests	
Audi A5 (USA)	2008-2018	8R	3D Special Function	Specia Functions	
Audi A5 (USA)	2008-2018	8R	40 Air Compressor	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	40 Air Compressor	Output Tests	
Audi A5 (USA)	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi A5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi A5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi A5 (USA)	2008-2018	8R	44 Steering Assistance	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi A5 (USA)	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi A5 (USA)	2008-2018	8R	46 Central Control Module	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A5 (USA)	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	46 Central Control Module	Output Tests	
Audi A5 (USA)	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi A5 (USA)	2008-2018	8R	47 Soundsystem	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	47 Soundsystem	Output Tests	
Audi A5 (USA)	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi A5 (USA)	2008-2018	8R	51 Electric Drive	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	51 Electric Drive	Output Tests	
Audi A5 (USA)	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi A5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi A5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi A5 (USA)	2008-2018	8R	53 Parking Brake	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	53 Parking Brake	Output Tests	
Audi A5 (USA)	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi A5 (USA)	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A5 (USA)	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi A5 (USA)	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi A5 (USA)	2008-2018	8R	56 Radio	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	56 Radio	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	56 Radio	Output Tests	
Audi A5 (USA)	2008-2018	8R	56 Radio	Specia Functions	
Audi A5 (USA)	2008-2018	8R	57 TV-Tuner	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi A5 (USA)	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi A5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi A5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi A5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi A5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi A5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi A5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi A5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi A5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi A5 (USA)	2008-2018	8R	67 Voice Control	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	67 Voice Control	Output Tests	
Audi A5 (USA)	2008-2018	8R	67 Voice Control	Specia Functions	
Audi A5 (USA)	2008-2018	8R	69 Trailer Function	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	69 Trailer Function	Output Tests	
Audi A5 (USA)	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi A5 (USA)	2008-2018	8R	6C Rear Camera	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	6C Rear Camera	Output Tests	
Audi A5 (USA)	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi A5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi A5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi A5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi A5 (USA)	2008-2018	8R	77 Telephone	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	77 Telephone	Output Tests	
Audi A5 (USA)	2008-2018	8R	77 Telephone	Specia Functions	
Audi A5 (USA)	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi A5 (USA)	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi A5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi A5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi A5 (USA)	2008-2018	8R	AC Reductant Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	AC Reductant Control	Output Tests	
Audi A5 (USA)	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi A5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi A5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi S5 (USA)	2008-2018	8R	01 Engine Electronics	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi S5 (USA)	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi S5 (USA)	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi S5 (USA)	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi S5 (USA)	2008-2018	8R	03 Brake Electronics	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi S5 (USA)	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi S5 (USA)	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S5 (USA)	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi S5 (USA)	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi S5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi S5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi S5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi S5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi S5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi S5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi S5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi S5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi S5 (USA)	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S5 (USA)	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi S5 (USA)	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi S5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi S5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi S5 (USA)	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi S5 (USA)	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi S5 (USA)	2008-2018	8R	13 Distance Control	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	13 Distance Control	Output Tests	
Audi S5 (USA)	2008-2018	8R	13 Distance Control	Specia Functions	
Audi S5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi S5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi S5 (USA)	2008-2018	8R	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5 (USA)	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	15 Airbags	Output Tests	
Audi S5 (USA)	2008-2018	8R	15 Airbags	Specia Functions	
Audi S5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi S5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi S5 (USA)	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi S5 (USA)	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi S5 (USA)	2008-2018	8R	18 Aux Heating	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	18 Aux Heating	Output Tests	
Audi S5 (USA)	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi S5 (USA)	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi S5 (USA)	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi S5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi S5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi S5 (USA)	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi S5 (USA)	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi S5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi S5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi S5 (USA)	2008-2018	8R	22 4WD Electronics	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi S5 (USA)	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi S5 (USA)	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi S5 (USA)	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi S5 (USA)	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S5 (USA)	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi S5 (USA)	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi S5 (USA)	2008-2018	8R	30 Special Function 2	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	30 Special Function 2	Output Tests	
Audi S5 (USA)	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi S5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi S5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi S5 (USA)	2008-2018	8R	37 Navigation	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	37 Navigation	Output Tests	
Audi S5 (USA)	2008-2018	8R	37 Navigation	Specia Functions	
Audi S5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi S5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi S5 (USA)	2008-2018	8R	3D Special Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5 (USA)	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	3D Special Function	Output Tests	
Audi S5 (USA)	2008-2018	8R	3D Special Function	Specia Functions	
Audi S5 (USA)	2008-2018	8R	40 Air Compressor	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	40 Air Compressor	Output Tests	
Audi S5 (USA)	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi S5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi S5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi S5 (USA)	2008-2018	8R	44 Steering Assistance	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi S5 (USA)	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi S5 (USA)	2008-2018	8R	46 Central Control Module	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	46 Central Control Module	Output Tests	
Audi S5 (USA)	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi S5 (USA)	2008-2018	8R	47 Soundsystem	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5 (USA)	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	47 Soundsystem	Output Tests	
Audi S5 (USA)	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi S5 (USA)	2008-2018	8R	51 Electric Drive	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	51 Electric Drive	Output Tests	
Audi S5 (USA)	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi S5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi S5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi S5 (USA)	2008-2018	8R	53 Parking Brake	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	53 Parking Brake	Output Tests	
Audi S5 (USA)	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi S5 (USA)	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi S5 (USA)	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi S5 (USA)	2008-2018	8R	56 Radio	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S5 (USA)	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	56 Radio	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	56 Radio	Output Tests	
Audi S5 (USA)	2008-2018	8R	56 Radio	Specia Functions	
Audi S5 (USA)	2008-2018	8R	57 TV-Tuner	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi S5 (USA)	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi S5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi S5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi S5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi S5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi S5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi S5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi S5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi S5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi S5 (USA)	2008-2018	8R	67 Voice Control	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	67 Voice Control	Output Tests	
Audi S5 (USA)	2008-2018	8R	67 Voice Control	Specia Functions	
Audi S5 (USA)	2008-2018	8R	69 Trailer Function	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	69 Trailer Function	Output Tests	
Audi S5 (USA)	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi S5 (USA)	2008-2018	8R	6C Rear Camera	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	6C Rear Camera	Output Tests	
Audi S5 (USA)	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi S5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi S5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi S5 (USA)	2008-2018	8R	77 Telephone	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	77 Telephone	Output Tests	
Audi S5 (USA)	2008-2018	8R	77 Telephone	Specia Functions	
Audi S5 (USA)	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi S5 (USA)	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi S5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi S5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi S5 (USA)	2008-2018	8R	AC Reductant Control	Read Fault Codes	
Audi S5 (USA)	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	AC Reductant Control	Output Tests	
Audi S5 (USA)	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi S5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi S5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi S5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi S5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	01 Engine Electronics	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi RS5 (USA)	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi RS5 (USA)	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	03 Brake Electronics	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi RS5 (USA)	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi RS5 (USA)	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi RS5 (USA)	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi RS5 (USA)	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi RS5 (USA)	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi RS5 (USA)	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi RS5 (USA)	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi RS5 (USA)	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi RS5 (USA)	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	13 Distance Control	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	13 Distance Control	Output Tests	
Audi RS5 (USA)	2008-2018	8R	13 Distance Control	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi RS5 (USA)	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	15 Airbags	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	15 Airbags	Output Tests	
Audi RS5 (USA)	2008-2018	8R	15 Airbags	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi RS5 (USA)	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi RS5 (USA)	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	18 Aux Heating	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	18 Aux Heating	Output Tests	
Audi RS5 (USA)	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi RS5 (USA)	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi RS5 (USA)	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5 (USA)	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi RS5 (USA)	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi RS5 (USA)	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	22 4WD Electronics	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi RS5 (USA)	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi RS5 (USA)	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi RS5 (USA)	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	30 Special Function 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5 (USA)	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	30 Special Function 2	Output Tests	
Audi RS5 (USA)	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi RS5 (USA)	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	37 Navigation	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	37 Navigation	Output Tests	
Audi RS5 (USA)	2008-2018	8R	37 Navigation	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi RS5 (USA)	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	3D Special Function	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	3D Special Function	Output Tests	
Audi RS5 (USA)	2008-2018	8R	3D Special Function	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	40 Air Compressor	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5 (USA)	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	40 Air Compressor	Output Tests	
Audi RS5 (USA)	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi RS5 (USA)	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	44 Steering Assistance	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi RS5 (USA)	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	46 Central Control Module	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	46 Central Control Module	Output Tests	
Audi RS5 (USA)	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	47 Soundsystem	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	47 Soundsystem	Output Tests	
Audi RS5 (USA)	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5 (USA)	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	51 Electric Drive	Output Tests	
Audi RS5 (USA)	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi RS5 (USA)	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	53 Parking Brake	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	53 Parking Brake	Output Tests	
Audi RS5 (USA)	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi RS5 (USA)	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	56 Radio	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	56 Radio	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	56 Radio	Output Tests	
Audi RS5 (USA)	2008-2018	8R	56 Radio	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	57 TV-Tuner	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS5 (USA)	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi RS5 (USA)	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi RS5 (USA)	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi RS5 (USA)	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi RS5 (USA)	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi RS5 (USA)	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	67 Voice Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5 (USA)	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	67 Voice Control	Output Tests	
Audi RS5 (USA)	2008-2018	8R	67 Voice Control	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	69 Trailer Function	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	69 Trailer Function	Output Tests	
Audi RS5 (USA)	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	6C Rear Camera	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	6C Rear Camera	Output Tests	
Audi RS5 (USA)	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi RS5 (USA)	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi RS5 (USA)	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	77 Telephone	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS5 (USA)	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	77 Telephone	Output Tests	
Audi RS5 (USA)	2008-2018	8R	77 Telephone	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi RS5 (USA)	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi RS5 (USA)	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	AC Reductant Control	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	AC Reductant Control	Output Tests	
Audi RS5 (USA)	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi RS5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	
Audi RS5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi RS5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi RS5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi RS5 (USA)	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2009-2018	FP	01 Engine Electronics	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	01 Engine Electronics	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	01 Engine Electronics	Output Tests	
Audi Q5 (USA)	2009-2018	FP	01 Engine Electronics	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	02 Transmission Electronics	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	02 Transmission Electronics	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	02 Transmission Electronics	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	02 Transmission Electronics	Output Tests	
Audi Q5 (USA)	2009-2018	FP	02 Transmission Electronics	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	03 Brake Electronics	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	03 Brake Electronics	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	03 Brake Electronics	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	03 Brake Electronics	Output Tests	
Audi Q5 (USA)	2009-2018	FP	03 Brake Electronics	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	05 Access & Permissi.	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	05 Access & Permissi.	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	05 Access & Permissi.	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	05 Access & Permissi.	Output Tests	
Audi Q5 (USA)	2009-2018	FP	05 Access & Permissi.	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	06 Passene. Seat Adj.	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	06 Passene. Seat Adj.	Output Tests	
Audi Q5 (USA)	2009-2018	FP	06 Passene. Seat Adj.	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	07 Display-/Cntl Unit	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2009-2018	FP	07 Display-/Cntl Unit	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	07 Display-/Cntl Unit	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	07 Display-/Cntl Unit	Output Tests	
Audi Q5 (USA)	2009-2018	FP	07 Display-/Cntl Unit	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	08 AC/Heating Electronics	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	08 AC/Heating Electronics	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	08 AC/Heating Electronics	Output Tests	
Audi Q5 (USA)	2009-2018	FP	08 AC/Heating Electronics	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	09 Electronic Ctrl Electronics	Output Tests	
Audi Q5 (USA)	2009-2018	FP	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	0E Media Player Position 1	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	0E Media Player Position 1	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	0E Media Player Position 1	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	0E Media Player Position 1	Output Tests	
Audi Q5 (USA)	2009-2018	FP	0E Media Player Position 1	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	0F Radio Tuner-Digital	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	0F Radio Tuner-Digital	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	0F Radio Tuner-Digital	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	0F Radio Tuner-Digital	Output Tests	
Audi Q5 (USA)	2009-2018	FP	0F Radio Tuner-Digital	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	10 Parking Assist System 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2009-2018	FP	10 Parking Assist System 2	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	10 Parking Assist System 2	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	10 Parking Assist System 2	Output Tests	
Audi Q5 (USA)	2009-2018	FP	10 Parking Assist System 2	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	13 Distance Control	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	13 Distance Control	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	13 Distance Control	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	13 Distance Control	Output Tests	
Audi Q5 (USA)	2009-2018	FP	13 Distance Control	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	14 Wheel Damping Electronics	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	14 Wheel Damping Electronics	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	14 Wheel Damping Electronics	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	14 Wheel Damping Electronics	Output Tests	
Audi Q5 (USA)	2009-2018	FP	14 Wheel Damping Electronics	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	15 Airbags	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	15 Airbags	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	15 Airbags	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	15 Airbags	Output Tests	
Audi Q5 (USA)	2009-2018	FP	15 Airbags	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	16 Steering Wheel Electronics	Output Tests	
Audi Q5 (USA)	2009-2018	FP	16 Steering Wheel Electronics	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2009-2018	FP	17 Instrument Cluster	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	17 Instrument Cluster	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	17 Instrument Cluster	Output Tests	
Audi Q5 (USA)	2009-2018	FP	17 Instrument Cluster	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	18 Aux Heating	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	18 Aux Heating	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	18 Aux Heating	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	18 Aux Heating	Output Tests	
Audi Q5 (USA)	2009-2018	FP	18 Aux Heating	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	19 Gateway Data Bus	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	19 Gateway Data Bus	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	19 Gateway Data Bus	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	19 Gateway Data Bus	Output Tests	
Audi Q5 (USA)	2009-2018	FP	19 Gateway Data Bus	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	1B Power-Assisted Steering	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	1B Power-Assisted Steering	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	1B Power-Assisted Steering	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	1B Power-Assisted Steering	Output Tests	
Audi Q5 (USA)	2009-2018	FP	1B Power-Assisted Steering	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	1E Media Player Position 2	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	1E Media Player Position 2	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	1E Media Player Position 2	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	1E Media Player Position 2	Output Tests	
Audi Q5 (USA)	2009-2018	FP	1E Media Player Position 2	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	20 High Beam Assistance Device	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2009-2018	FP	20 High Beam Assistance Device	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	20 High Beam Assistance Device	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	20 High Beam Assistance Device	Output Tests	
Audi Q5 (USA)	2009-2018	FP	20 High Beam Assistance Device	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	22 4WD Electronics	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	22 4WD Electronics	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	22 4WD Electronics	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	22 4WD Electronics	Output Tests	
Audi Q5 (USA)	2009-2018	FP	22 4WD Electronics	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	26 Electric Roof Control	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	26 Electric Roof Control	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	26 Electric Roof Control	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	26 Electric Roof Control	Output Tests	
Audi Q5 (USA)	2009-2018	FP	26 Electric Roof Control	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	2E Media Player Position 3	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	2E Media Player Position 3	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	2E Media Player Position 3	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	2E Media Player Position 3	Output Tests	
Audi Q5 (USA)	2009-2018	FP	2E Media Player Position 3	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	30 Special Function 2	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	30 Special Function 2	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	30 Special Function 2	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	30 Special Function 2	Output Tests	
Audi Q5 (USA)	2009-2018	FP	30 Special Function 2	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	36 Side of Driver Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q5 (USA)	2009-2018	FP	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	36 Side of Driver Seat Adj.	Output Tests	
Audi Q5 (USA)	2009-2018	FP	36 Side of Driver Seat Adj.	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	37 Navigation	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	37 Navigation	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	37 Navigation	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	37 Navigation	Output Tests	
Audi Q5 (USA)	2009-2018	FP	37 Navigation	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	3C Lane Departure Assistance System	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	3C Lane Departure Assistance System	Output Tests	
Audi Q5 (USA)	2009-2018	FP	3C Lane Departure Assistance System	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	3D Special Function	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	3D Special Function	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	3D Special Function	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	3D Special Function	Output Tests	
Audi Q5 (USA)	2009-2018	FP	3D Special Function	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	40 Air Compressor	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	40 Air Compressor	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	40 Air Compressor	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	40 Air Compressor	Output Tests	
Audi Q5 (USA)	2009-2018	FP	40 Air Compressor	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2009-2018	FP	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	42 Driver-Door Elect.	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	42 Driver-Door Elect.	Output Tests	
Audi Q5 (USA)	2009-2018	FP	42 Driver-Door Elect.	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	44 Steering Assistance	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	44 Steering Assistance	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	44 Steering Assistance	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	44 Steering Assistance	Output Tests	
Audi Q5 (USA)	2009-2018	FP	44 Steering Assistance	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	46 Central Control Module	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	46 Central Control Module	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	46 Central Control Module	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	46 Central Control Module	Output Tests	
Audi Q5 (USA)	2009-2018	FP	46 Central Control Module	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	47 Soundsystem	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	47 Soundsystem	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	47 Soundsystem	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	47 Soundsystem	Output Tests	
Audi Q5 (USA)	2009-2018	FP	47 Soundsystem	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	51 Electric Drive	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	51 Electric Drive	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	51 Electric Drive	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	51 Electric Drive	Output Tests	
Audi Q5 (USA)	2009-2018	FP	51 Electric Drive	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	52 Passe.-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2009-2018	FP	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	52 Passe.-Door Elect.	Output Tests	
Audi Q5 (USA)	2009-2018	FP	52 Passe.-Door Elect.	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	53 Parking Brake	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	53 Parking Brake	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	53 Parking Brake	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	53 Parking Brake	Output Tests	
Audi Q5 (USA)	2009-2018	FP	53 Parking Brake	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	55 Headlight Range Control	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	55 Headlight Range Control	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	55 Headlight Range Control	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	55 Headlight Range Control	Output Tests	
Audi Q5 (USA)	2009-2018	FP	55 Headlight Range Control	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	56 Radio	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	56 Radio	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	56 Radio	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	56 Radio	Output Tests	
Audi Q5 (USA)	2009-2018	FP	56 Radio	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	57 TV-Tuner	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	57 TV-Tuner	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	57 TV-Tuner	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	57 TV-Tuner	Output Tests	
Audi Q5 (USA)	2009-2018	FP	57 TV-Tuner	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	5C Lane Keeping Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2009-2018	FP	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	5C Lane Keeping Assistance System	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	5C Lane Keeping Assistance System	Output Tests	
Audi Q5 (USA)	2009-2018	FP	5C Lane Keeping Assistance System	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	5F Information Electronic Equipment 1	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	5F Information Electronic Equipment 1	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	5F Information Electronic Equipment 1	Output Tests	
Audi Q5 (USA)	2009-2018	FP	5F Information Electronic Equipment 1	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	62 LR-Door Electroni.	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	62 LR-Door Electroni.	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	62 LR-Door Electroni.	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	62 LR-Door Electroni.	Output Tests	
Audi Q5 (USA)	2009-2018	FP	62 LR-Door Electroni.	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	65 Tyre Pressure Monitoring	Output Tests	
Audi Q5 (USA)	2009-2018	FP	65 Tyre Pressure Monitoring	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	67 Voice Control	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	67 Voice Control	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	67 Voice Control	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	67 Voice Control	Output Tests	
Audi Q5 (USA)	2009-2018	FP	67 Voice Control	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	69 Trailer Function	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi Q5 (USA)	2009-2018	FP	69 Trailer Function	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	69 Trailer Function	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	69 Trailer Function	Output Tests	
Audi Q5 (USA)	2009-2018	FP	69 Trailer Function	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	6C Rear Camera	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	6C Rear Camera	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	6C Rear Camera	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	6C Rear Camera	Output Tests	
Audi Q5 (USA)	2009-2018	FP	6C Rear Camera	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q5 (USA)	2009-2018	FP	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	72 RR-Door Electroni.	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	72 RR-Door Electroni.	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	72 RR-Door Electroni.	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	72 RR-Door Electroni.	Output Tests	
Audi Q5 (USA)	2009-2018	FP	72 RR-Door Electroni.	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	77 Telephone	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	77 Telephone	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	77 Telephone	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	77 Telephone	Output Tests	
Audi Q5 (USA)	2009-2018	FP	77 Telephone	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	8C Hybrid Battery	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q5 (USA)	2009-2018	FP	8C Hybrid Battery	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	8C Hybrid Battery	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	8C Hybrid Battery	Output Tests	
Audi Q5 (USA)	2009-2018	FP	8C Hybrid Battery	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	A9 Struct.Borne Sound	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	A9 Struct.Borne Sound	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	A9 Struct.Borne Sound	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	A9 Struct.Borne Sound	Output Tests	
Audi Q5 (USA)	2009-2018	FP	A9 Struct.Borne Sound	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	AC Reductant Control	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	AC Reductant Control	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	AC Reductant Control	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	AC Reductant Control	Output Tests	
Audi Q5 (USA)	2009-2018	FP	AC Reductant Control	Specia Functions	
Audi Q5 (USA)	2009-2018	FP	C0 Act. For Ext. Noise	Read Fault Codes	
Audi Q5 (USA)	2009-2018	FP	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi Q5 (USA)	2009-2018	FP	C0 Act. For Ext. Noise	Measuring Blocks	
Audi Q5 (USA)	2009-2018	FP	C0 Act. For Ext. Noise	Output Tests	
Audi Q5 (USA)	2009-2018	FP	C0 Act. For Ext. Noise	Specia Functions	
Audi A6	2008-2013	4F	01 Engine Electronics	Read Fault Codes	
Audi A6	2008-2013	4F	01 Engine Electronics	Clear Fault Codes	
Audi A6	2008-2013	4F	01 Engine Electronics	Measuring Blocks	
Audi A6	2008-2013	4F	01 Engine Electronics	Output Tests	
Audi A6	2008-2013	4F	01 Engine Electronics	Specia Functions	
Audi A6	2008-2013	4F	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2008-2013	4F	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2008-2013	4F	02 Transmission Electronics	Measuring Blocks	
Audi A6	2008-2013	4F	02 Transmission Electronics	Output Tests	
Audi A6	2008-2013	4F	02 Transmission Electronics	Specia Functions	
Audi A6	2008-2013	4F	03 Brake Electronics	Read Fault Codes	
Audi A6	2008-2013	4F	03 Brake Electronics	Clear Fault Codes	
Audi A6	2008-2013	4F	03 Brake Electronics	Measuring Blocks	
Audi A6	2008-2013	4F	03 Brake Electronics	Output Tests	
Audi A6	2008-2013	4F	03 Brake Electronics	Specia Functions	
Audi A6	2008-2013	4F	05 Access & Permissi.	Read Fault Codes	
Audi A6	2008-2013	4F	05 Access & Permissi.	Clear Fault Codes	
Audi A6	2008-2013	4F	05 Access & Permissi.	Measuring Blocks	
Audi A6	2008-2013	4F	05 Access & Permissi.	Output Tests	
Audi A6	2008-2013	4F	05 Access & Permissi.	Specia Functions	
Audi A6	2008-2013	4F	06 Passene. Seat Adj.	Read Fault Codes	
Audi A6	2008-2013	4F	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6	2008-2013	4F	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6	2008-2013	4F	06 Passene. Seat Adj.	Output Tests	
Audi A6	2008-2013	4F	06 Passene. Seat Adj.	Specia Functions	
Audi A6	2008-2013	4F	07 Display-/Cntl Unit	Read Fault Codes	
Audi A6	2008-2013	4F	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A6	2008-2013	4F	07 Display-/Cntl Unit	Measuring Blocks	
Audi A6	2008-2013	4F	07 Display-/Cntl Unit	Output Tests	
Audi A6	2008-2013	4F	07 Display-/Cntl Unit	Specia Functions	
Audi A6	2008-2013	4F	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2008-2013	4F	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	2008-2013	4F	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	2008-2013	4F	08 AC/Heating Electronics	Output Tests	
Audi A6	2008-2013	4F	08 AC/Heating Electronics	Specia Functions	
Audi A6	2008-2013	4F	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A6	2008-2013	4F	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A6	2008-2013	4F	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A6	2008-2013	4F	09 Electronic Ctrl Electronics	Output Tests	
Audi A6	2008-2013	4F	09 Electronic Ctrl Electronics	Specia Functions	
Audi A6	2008-2013	4F	0E Media Player Position 1	Read Fault Codes	
Audi A6	2008-2013	4F	0E Media Player Position 1	Clear Fault Codes	
Audi A6	2008-2013	4F	0E Media Player Position 1	Measuring Blocks	
Audi A6	2008-2013	4F	0E Media Player Position 1	Output Tests	
Audi A6	2008-2013	4F	0E Media Player Position 1	Specia Functions	
Audi A6	2008-2013	4F	0F Radio Tuner-Digital	Read Fault Codes	
Audi A6	2008-2013	4F	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A6	2008-2013	4F	0F Radio Tuner-Digital	Measuring Blocks	
Audi A6	2008-2013	4F	0F Radio Tuner-Digital	Output Tests	
Audi A6	2008-2013	4F	0F Radio Tuner-Digital	Specia Functions	
Audi A6	2008-2013	4F	10 Parking Assist System 2	Read Fault Codes	
Audi A6	2008-2013	4F	10 Parking Assist System 2	Clear Fault Codes	
Audi A6	2008-2013	4F	10 Parking Assist System 2	Measuring Blocks	
Audi A6	2008-2013	4F	10 Parking Assist System 2	Output Tests	
Audi A6	2008-2013	4F	10 Parking Assist System 2	Specia Functions	
Audi A6	2008-2013	4F	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2008-2013	4F	11 Engine Electronics 2	Clear Fault Codes	
Audi A6	2008-2013	4F	11 Engine Electronics 2	Measuring Blocks	
Audi A6	2008-2013	4F	11 Engine Electronics 2	Output Tests	
Audi A6	2008-2013	4F	11 Engine Electronics 2	Specia Functions	
Audi A6	2008-2013	4F	13 Distance Control	Read Fault Codes	
Audi A6	2008-2013	4F	13 Distance Control	Clear Fault Codes	
Audi A6	2008-2013	4F	13 Distance Control	Measuring Blocks	
Audi A6	2008-2013	4F	13 Distance Control	Output Tests	
Audi A6	2008-2013	4F	13 Distance Control	Specia Functions	
Audi A6	2008-2013	4F	14 Wheel Damping Electronics	Read Fault Codes	
Audi A6	2008-2013	4F	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A6	2008-2013	4F	14 Wheel Damping Electronics	Measuring Blocks	
Audi A6	2008-2013	4F	14 Wheel Damping Electronics	Output Tests	
Audi A6	2008-2013	4F	14 Wheel Damping Electronics	Specia Functions	
Audi A6	2008-2013	4F	15 Airbags	Read Fault Codes	
Audi A6	2008-2013	4F	15 Airbags	Clear Fault Codes	
Audi A6	2008-2013	4F	15 Airbags	Measuring Blocks	
Audi A6	2008-2013	4F	15 Airbags	Output Tests	
Audi A6	2008-2013	4F	15 Airbags	Specia Functions	
Audi A6	2008-2013	4F	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2008-2013	4F	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2008-2013	4F	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2008-2013	4F	16 Steering Wheel Electronics	Output Tests	
Audi A6	2008-2013	4F	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2008-2013	4F	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2008-2013	4F	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2008-2013	4F	17 Instrument Cluster	Measuring Blocks	
Audi A6	2008-2013	4F	17 Instrument Cluster	Output Tests	
Audi A6	2008-2013	4F	17 Instrument Cluster	Specia Functions	
Audi A6	2008-2013	4F	18 Aux Heating	Read Fault Codes	
Audi A6	2008-2013	4F	18 Aux Heating	Clear Fault Codes	
Audi A6	2008-2013	4F	18 Aux Heating	Measuring Blocks	
Audi A6	2008-2013	4F	18 Aux Heating	Output Tests	
Audi A6	2008-2013	4F	18 Aux Heating	Specia Functions	
Audi A6	2008-2013	4F	19 Gateway Data Bus	Read Fault Codes	
Audi A6	2008-2013	4F	19 Gateway Data Bus	Clear Fault Codes	
Audi A6	2008-2013	4F	19 Gateway Data Bus	Measuring Blocks	
Audi A6	2008-2013	4F	19 Gateway Data Bus	Output Tests	
Audi A6	2008-2013	4F	19 Gateway Data Bus	Specia Functions	
Audi A6	2008-2013	4F	1E Media Player Position 2	Read Fault Codes	
Audi A6	2008-2013	4F	1E Media Player Position 2	Clear Fault Codes	
Audi A6	2008-2013	4F	1E Media Player Position 2	Measuring Blocks	
Audi A6	2008-2013	4F	1E Media Player Position 2	Output Tests	
Audi A6	2008-2013	4F	1E Media Player Position 2	Specia Functions	
Audi A6	2008-2013	4F	20 High Beam Assistance Device	Read Fault Codes	
Audi A6	2008-2013	4F	20 High Beam Assistance Device	Clear Fault Codes	
Audi A6	2008-2013	4F	20 High Beam Assistance Device	Measuring Blocks	
Audi A6	2008-2013	4F	20 High Beam Assistance Device	Output Tests	
Audi A6	2008-2013	4F	20 High Beam Assistance Device	Specia Functions	
Audi A6	2008-2013	4F	28 Climate Control Unit Rear	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2008-2013	4F	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A6	2008-2013	4F	28 Climate Control Unit Rear	Measuring Blocks	
Audi A6	2008-2013	4F	28 Climate Control Unit Rear	Output Tests	
Audi A6	2008-2013	4F	28 Climate Control Unit Rear	Specia Functions	
Audi A6	2008-2013	4F	2E Media Player Position 3	Read Fault Codes	
Audi A6	2008-2013	4F	2E Media Player Position 3	Clear Fault Codes	
Audi A6	2008-2013	4F	2E Media Player Position 3	Measuring Blocks	
Audi A6	2008-2013	4F	2E Media Player Position 3	Output Tests	
Audi A6	2008-2013	4F	2E Media Player Position 3	Specia Functions	
Audi A6	2008-2013	4F	34 Self Leveling Suspension	Read Fault Codes	
Audi A6	2008-2013	4F	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	2008-2013	4F	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	2008-2013	4F	34 Self Leveling Suspension	Output Tests	
Audi A6	2008-2013	4F	34 Self Leveling Suspension	Specia Functions	
Audi A6	2008-2013	4F	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A6	2008-2013	4F	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	2008-2013	4F	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	2008-2013	4F	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	2008-2013	4F	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	2008-2013	4F	37 Navigation	Read Fault Codes	
Audi A6	2008-2013	4F	37 Navigation	Clear Fault Codes	
Audi A6	2008-2013	4F	37 Navigation	Measuring Blocks	
Audi A6	2008-2013	4F	37 Navigation	Output Tests	
Audi A6	2008-2013	4F	37 Navigation	Specia Functions	
Audi A6	2008-2013	4F	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2008-2013	4F	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A6	2008-2013	4F	3C Lane Departure Assistance System	Measuring Blocks	
Audi A6	2008-2013	4F	3C Lane Departure Assistance System	Output Tests	
Audi A6	2008-2013	4F	3C Lane Departure Assistance System	Specia Functions	
Audi A6	2008-2013	4F	3D Special Function	Read Fault Codes	
Audi A6	2008-2013	4F	3D Special Function	Clear Fault Codes	
Audi A6	2008-2013	4F	3D Special Function	Measuring Blocks	
Audi A6	2008-2013	4F	3D Special Function	Output Tests	
Audi A6	2008-2013	4F	3D Special Function	Specia Functions	
Audi A6	2008-2013	4F	42 Driver-Door Elect.	Read Fault Codes	
Audi A6	2008-2013	4F	42 Driver-Door Elect.	Clear Fault Codes	
Audi A6	2008-2013	4F	42 Driver-Door Elect.	Measuring Blocks	
Audi A6	2008-2013	4F	42 Driver-Door Elect.	Output Tests	
Audi A6	2008-2013	4F	42 Driver-Door Elect.	Specia Functions	
Audi A6	2008-2013	4F	46 Central Control Module	Read Fault Codes	
Audi A6	2008-2013	4F	46 Central Control Module	Clear Fault Codes	
Audi A6	2008-2013	4F	46 Central Control Module	Measuring Blocks	
Audi A6	2008-2013	4F	46 Central Control Module	Output Tests	
Audi A6	2008-2013	4F	46 Central Control Module	Specia Functions	
Audi A6	2008-2013	4F	47 Soundsystem	Read Fault Codes	
Audi A6	2008-2013	4F	47 Soundsystem	Clear Fault Codes	
Audi A6	2008-2013	4F	47 Soundsystem	Measuring Blocks	
Audi A6	2008-2013	4F	47 Soundsystem	Output Tests	
Audi A6	2008-2013	4F	47 Soundsystem	Specia Functions	
Audi A6	2008-2013	4F	4C Tyre Pressure Monitor II	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2008-2013	4F	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi A6	2008-2013	4F	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi A6	2008-2013	4F	4C Tyre Pressure Monitor II	Output Tests	
Audi A6	2008-2013	4F	4C Tyre Pressure Monitor II	Specia Functions	
Audi A6	2008-2013	4F	4F Electronic Central Electric II	Read Fault Codes	
Audi A6	2008-2013	4F	4F Electronic Central Electric II	Clear Fault Codes	
Audi A6	2008-2013	4F	4F Electronic Central Electric II	Measuring Blocks	
Audi A6	2008-2013	4F	4F Electronic Central Electric II	Output Tests	
Audi A6	2008-2013	4F	4F Electronic Central Electric II	Specia Functions	
Audi A6	2008-2013	4F	52 Passe.-Door Elect.	Read Fault Codes	
Audi A6	2008-2013	4F	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A6	2008-2013	4F	52 Passe.-Door Elect.	Measuring Blocks	
Audi A6	2008-2013	4F	52 Passe.-Door Elect.	Output Tests	
Audi A6	2008-2013	4F	52 Passe.-Door Elect.	Specia Functions	
Audi A6	2008-2013	4F	53 Parking Brake	Read Fault Codes	
Audi A6	2008-2013	4F	53 Parking Brake	Clear Fault Codes	
Audi A6	2008-2013	4F	53 Parking Brake	Measuring Blocks	
Audi A6	2008-2013	4F	53 Parking Brake	Output Tests	
Audi A6	2008-2013	4F	53 Parking Brake	Specia Functions	
Audi A6	2008-2013	4F	55 Headlight Range Control	Read Fault Codes	
Audi A6	2008-2013	4F	55 Headlight Range Control	Clear Fault Codes	
Audi A6	2008-2013	4F	55 Headlight Range Control	Measuring Blocks	
Audi A6	2008-2013	4F	55 Headlight Range Control	Output Tests	
Audi A6	2008-2013	4F	55 Headlight Range Control	Specia Functions	
Audi A6	2008-2013	4F	56 Radio	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2008-2013	4F	56 Radio	Clear Fault Codes	
Audi A6	2008-2013	4F	56 Radio	Measuring Blocks	
Audi A6	2008-2013	4F	56 Radio	Output Tests	
Audi A6	2008-2013	4F	56 Radio	Specia Functions	
Audi A6	2008-2013	4F	57 TV-Tuner	Read Fault Codes	
Audi A6	2008-2013	4F	57 TV-Tuner	Clear Fault Codes	
Audi A6	2008-2013	4F	57 TV-Tuner	Measuring Blocks	
Audi A6	2008-2013	4F	57 TV-Tuner	Output Tests	
Audi A6	2008-2013	4F	57 TV-Tuner	Specia Functions	
Audi A6	2008-2013	4F	5C Lane Keeping Assistance System	Read Fault Codes	
Audi A6	2008-2013	4F	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi A6	2008-2013	4F	5C Lane Keeping Assistance System	Measuring Blocks	
Audi A6	2008-2013	4F	5C Lane Keeping Assistance System	Output Tests	
Audi A6	2008-2013	4F	5C Lane Keeping Assistance System	Specia Functions	
Audi A6	2008-2013	4F	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A6	2008-2013	4F	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A6	2008-2013	4F	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A6	2008-2013	4F	5F Information Electronic Equipment 1	Output Tests	
Audi A6	2008-2013	4F	5F Information Electronic Equipment 1	Specia Functions	
Audi A6	2008-2013	4F	61 Battery Control	Read Fault Codes	
Audi A6	2008-2013	4F	61 Battery Control	Clear Fault Codes	
Audi A6	2008-2013	4F	61 Battery Control	Measuring Blocks	
Audi A6	2008-2013	4F	61 Battery Control	Output Tests	
Audi A6	2008-2013	4F	61 Battery Control	Specia Functions	
Audi A6	2008-2013	4F	62 LR-Door Electroni.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6	2008-2013	4F	62 LR-Door Electroni.	Clear Fault Codes	
Audi A6	2008-2013	4F	62 LR-Door Electroni.	Measuring Blocks	
Audi A6	2008-2013	4F	62 LR-Door Electroni.	Output Tests	
Audi A6	2008-2013	4F	62 LR-Door Electroni.	Specia Functions	
Audi A6	2008-2013	4F	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6	2008-2013	4F	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6	2008-2013	4F	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6	2008-2013	4F	65 Tyre Pressure Monitoring	Output Tests	
Audi A6	2008-2013	4F	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6	2008-2013	4F	67 Voice Control	Read Fault Codes	
Audi A6	2008-2013	4F	67 Voice Control	Clear Fault Codes	
Audi A6	2008-2013	4F	67 Voice Control	Measuring Blocks	
Audi A6	2008-2013	4F	67 Voice Control	Output Tests	
Audi A6	2008-2013	4F	67 Voice Control	Specia Functions	
Audi A6	2008-2013	4F	69 Trailer Function	Read Fault Codes	
Audi A6	2008-2013	4F	69 Trailer Function	Clear Fault Codes	
Audi A6	2008-2013	4F	69 Trailer Function	Measuring Blocks	
Audi A6	2008-2013	4F	69 Trailer Function	Output Tests	
Audi A6	2008-2013	4F	69 Trailer Function	Specia Functions	
Audi A6	2008-2013	4F	6C Rear Camera	Read Fault Codes	
Audi A6	2008-2013	4F	6C Rear Camera	Clear Fault Codes	
Audi A6	2008-2013	4F	6C Rear Camera	Measuring Blocks	
Audi A6	2008-2013	4F	6C Rear Camera	Output Tests	
Audi A6	2008-2013	4F	6C Rear Camera	Specia Functions	
Audi A6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A6	2008-2013	4F	6F Confort Central Control Unit II	Read Fault Codes	
Audi A6	2008-2013	4F	6F Confort Central Control Unit II	Clear Fault Codes	
Audi A6	2008-2013	4F	6F Confort Central Control Unit II	Measuring Blocks	
Audi A6	2008-2013	4F	6F Confort Central Control Unit II	Output Tests	
Audi A6	2008-2013	4F	6F Confort Central Control Unit II	Specia Functions	
Audi A6	2008-2013	4F	72 RR-Door Electroni.	Read Fault Codes	
Audi A6	2008-2013	4F	72 RR-Door Electroni.	Clear Fault Codes	
Audi A6	2008-2013	4F	72 RR-Door Electroni.	Measuring Blocks	
Audi A6	2008-2013	4F	72 RR-Door Electroni.	Output Tests	
Audi A6	2008-2013	4F	72 RR-Door Electroni.	Specia Functions	
Audi A6	2008-2013	4F	76 Parking Aid	Read Fault Codes	
Audi A6	2008-2013	4F	76 Parking Aid	Clear Fault Codes	
Audi A6	2008-2013	4F	76 Parking Aid	Measuring Blocks	
Audi A6	2008-2013	4F	76 Parking Aid	Output Tests	
Audi A6	2008-2013	4F	76 Parking Aid	Specia Functions	
Audi A6	2008-2013	4F	77 Telephone	Read Fault Codes	
Audi A6	2008-2013	4F	77 Telephone	Clear Fault Codes	
Audi A6	2008-2013	4F	77 Telephone	Measuring Blocks	
Audi A6	2008-2013	4F	77 Telephone	Output Tests	
Audi A6	2008-2013	4F	77 Telephone	Specia Functions	
Audi S6	2008-2013	4F	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2008-2013	4F	01 Engine Electronics	Clear Fault Codes	
Audi S6	2008-2013	4F	01 Engine Electronics	Measuring Blocks	
Audi S6	2008-2013	4F	01 Engine Electronics	Output Tests	
Audi S6	2008-2013	4F	01 Engine Electronics	Specia Functions	
Audi S6	2008-2013	4F	02 Transmission Electronics	Read Fault Codes	
Audi S6	2008-2013	4F	02 Transmission Electronics	Clear Fault Codes	
Audi S6	2008-2013	4F	02 Transmission Electronics	Measuring Blocks	
Audi S6	2008-2013	4F	02 Transmission Electronics	Output Tests	
Audi S6	2008-2013	4F	02 Transmission Electronics	Specia Functions	
Audi S6	2008-2013	4F	03 Brake Electronics	Read Fault Codes	
Audi S6	2008-2013	4F	03 Brake Electronics	Clear Fault Codes	
Audi S6	2008-2013	4F	03 Brake Electronics	Measuring Blocks	
Audi S6	2008-2013	4F	03 Brake Electronics	Output Tests	
Audi S6	2008-2013	4F	03 Brake Electronics	Specia Functions	
Audi S6	2008-2013	4F	05 Access & Permissi.	Read Fault Codes	
Audi S6	2008-2013	4F	05 Access & Permissi.	Clear Fault Codes	
Audi S6	2008-2013	4F	05 Access & Permissi.	Measuring Blocks	
Audi S6	2008-2013	4F	05 Access & Permissi.	Output Tests	
Audi S6	2008-2013	4F	05 Access & Permissi.	Specia Functions	
Audi S6	2008-2013	4F	06 Passene. Seat Adj.	Read Fault Codes	
Audi S6	2008-2013	4F	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S6	2008-2013	4F	06 Passene. Seat Adj.	Measuring Blocks	
Audi S6	2008-2013	4F	06 Passene. Seat Adj.	Output Tests	
Audi S6	2008-2013	4F	06 Passene. Seat Adj.	Specia Functions	
Audi S6	2008-2013	4F	07 Display-/Cntl Unit	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2008-2013	4F	07 Display-/Cntl Unit	Clear Fault Codes	
Audi S6	2008-2013	4F	07 Display-/Cntl Unit	Measuring Blocks	
Audi S6	2008-2013	4F	07 Display-/Cntl Unit	Output Tests	
Audi S6	2008-2013	4F	07 Display-/Cntl Unit	Specia Functions	
Audi S6	2008-2013	4F	08 AC/Heating Electronics	Read Fault Codes	
Audi S6	2008-2013	4F	08 AC/Heating Electronics	Clear Fault Codes	
Audi S6	2008-2013	4F	08 AC/Heating Electronics	Measuring Blocks	
Audi S6	2008-2013	4F	08 AC/Heating Electronics	Output Tests	
Audi S6	2008-2013	4F	08 AC/Heating Electronics	Specia Functions	
Audi S6	2008-2013	4F	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S6	2008-2013	4F	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S6	2008-2013	4F	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S6	2008-2013	4F	09 Electronic Ctrl Electronics	Output Tests	
Audi S6	2008-2013	4F	09 Electronic Ctrl Electronics	Specia Functions	
Audi S6	2008-2013	4F	0E Media Player Position 1	Read Fault Codes	
Audi S6	2008-2013	4F	0E Media Player Position 1	Clear Fault Codes	
Audi S6	2008-2013	4F	0E Media Player Position 1	Measuring Blocks	
Audi S6	2008-2013	4F	0E Media Player Position 1	Output Tests	
Audi S6	2008-2013	4F	0E Media Player Position 1	Specia Functions	
Audi S6	2008-2013	4F	0F Radio Tuner-Digital	Read Fault Codes	
Audi S6	2008-2013	4F	0F Radio Tuner-Digital	Clear Fault Codes	
Audi S6	2008-2013	4F	0F Radio Tuner-Digital	Measuring Blocks	
Audi S6	2008-2013	4F	0F Radio Tuner-Digital	Output Tests	
Audi S6	2008-2013	4F	0F Radio Tuner-Digital	Specia Functions	
Audi S6	2008-2013	4F	10 Parking Assist System 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S6	2008-2013	4F	10 Parking Assist System 2	Clear Fault Codes	
Audi S6	2008-2013	4F	10 Parking Assist System 2	Measuring Blocks	
Audi S6	2008-2013	4F	10 Parking Assist System 2	Output Tests	
Audi S6	2008-2013	4F	10 Parking Assist System 2	Specia Functions	
Audi S6	2008-2013	4F	11 Engine Electronics 2	Read Fault Codes	
Audi S6	2008-2013	4F	11 Engine Electronics 2	Clear Fault Codes	
Audi S6	2008-2013	4F	11 Engine Electronics 2	Measuring Blocks	
Audi S6	2008-2013	4F	11 Engine Electronics 2	Output Tests	
Audi S6	2008-2013	4F	11 Engine Electronics 2	Specia Functions	
Audi S6	2008-2013	4F	13 Distance Control	Read Fault Codes	
Audi S6	2008-2013	4F	13 Distance Control	Clear Fault Codes	
Audi S6	2008-2013	4F	13 Distance Control	Measuring Blocks	
Audi S6	2008-2013	4F	13 Distance Control	Output Tests	
Audi S6	2008-2013	4F	13 Distance Control	Specia Functions	
Audi S6	2008-2013	4F	14 Wheel Damping Electronics	Read Fault Codes	
Audi S6	2008-2013	4F	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S6	2008-2013	4F	14 Wheel Damping Electronics	Measuring Blocks	
Audi S6	2008-2013	4F	14 Wheel Damping Electronics	Output Tests	
Audi S6	2008-2013	4F	14 Wheel Damping Electronics	Specia Functions	
Audi S6	2008-2013	4F	15 Airbags	Read Fault Codes	
Audi S6	2008-2013	4F	15 Airbags	Clear Fault Codes	
Audi S6	2008-2013	4F	15 Airbags	Measuring Blocks	
Audi S6	2008-2013	4F	15 Airbags	Output Tests	
Audi S6	2008-2013	4F	15 Airbags	Specia Functions	
Audi S6	2008-2013	4F	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2008-2013	4F	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S6	2008-2013	4F	16 Steering Wheel Electronics	Measuring Blocks	
Audi S6	2008-2013	4F	16 Steering Wheel Electronics	Output Tests	
Audi S6	2008-2013	4F	16 Steering Wheel Electronics	Specia Functions	
Audi S6	2008-2013	4F	17 Instrument Cluster	Read Fault Codes	
Audi S6	2008-2013	4F	17 Instrument Cluster	Clear Fault Codes	
Audi S6	2008-2013	4F	17 Instrument Cluster	Measuring Blocks	
Audi S6	2008-2013	4F	17 Instrument Cluster	Output Tests	
Audi S6	2008-2013	4F	17 Instrument Cluster	Specia Functions	
Audi S6	2008-2013	4F	18 Aux Heating	Read Fault Codes	
Audi S6	2008-2013	4F	18 Aux Heating	Clear Fault Codes	
Audi S6	2008-2013	4F	18 Aux Heating	Measuring Blocks	
Audi S6	2008-2013	4F	18 Aux Heating	Output Tests	
Audi S6	2008-2013	4F	18 Aux Heating	Specia Functions	
Audi S6	2008-2013	4F	19 Gateway Data Bus	Read Fault Codes	
Audi S6	2008-2013	4F	19 Gateway Data Bus	Clear Fault Codes	
Audi S6	2008-2013	4F	19 Gateway Data Bus	Measuring Blocks	
Audi S6	2008-2013	4F	19 Gateway Data Bus	Output Tests	
Audi S6	2008-2013	4F	19 Gateway Data Bus	Specia Functions	
Audi S6	2008-2013	4F	1E Media Player Position 2	Read Fault Codes	
Audi S6	2008-2013	4F	1E Media Player Position 2	Clear Fault Codes	
Audi S6	2008-2013	4F	1E Media Player Position 2	Measuring Blocks	
Audi S6	2008-2013	4F	1E Media Player Position 2	Output Tests	
Audi S6	2008-2013	4F	1E Media Player Position 2	Specia Functions	
Audi S6	2008-2013	4F	20 High Beam Assistance Device	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2008-2013	4F	20 High Beam Assistance Device	Clear Fault Codes	
Audi S6	2008-2013	4F	20 High Beam Assistance Device	Measuring Blocks	
Audi S6	2008-2013	4F	20 High Beam Assistance Device	Output Tests	
Audi S6	2008-2013	4F	20 High Beam Assistance Device	Specia Functions	
Audi S6	2008-2013	4F	28 Climate Control Unit Rear	Read Fault Codes	
Audi S6	2008-2013	4F	28 Climate Control Unit Rear	Clear Fault Codes	
Audi S6	2008-2013	4F	28 Climate Control Unit Rear	Measuring Blocks	
Audi S6	2008-2013	4F	28 Climate Control Unit Rear	Output Tests	
Audi S6	2008-2013	4F	28 Climate Control Unit Rear	Specia Functions	
Audi S6	2008-2013	4F	2E Media Player Position 3	Read Fault Codes	
Audi S6	2008-2013	4F	2E Media Player Position 3	Clear Fault Codes	
Audi S6	2008-2013	4F	2E Media Player Position 3	Measuring Blocks	
Audi S6	2008-2013	4F	2E Media Player Position 3	Output Tests	
Audi S6	2008-2013	4F	2E Media Player Position 3	Specia Functions	
Audi S6	2008-2013	4F	34 Self Leveling Suspension	Read Fault Codes	
Audi S6	2008-2013	4F	34 Self Leveling Suspension	Clear Fault Codes	
Audi S6	2008-2013	4F	34 Self Leveling Suspension	Measuring Blocks	
Audi S6	2008-2013	4F	34 Self Leveling Suspension	Output Tests	
Audi S6	2008-2013	4F	34 Self Leveling Suspension	Specia Functions	
Audi S6	2008-2013	4F	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi S6	2008-2013	4F	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S6	2008-2013	4F	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S6	2008-2013	4F	36 Side of Driver Seat Adj.	Output Tests	
Audi S6	2008-2013	4F	36 Side of Driver Seat Adj.	Specia Functions	
Audi S6	2008-2013	4F	37 Navigation	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2008-2013	4F	37 Navigation	Clear Fault Codes	
Audi S6	2008-2013	4F	37 Navigation	Measuring Blocks	
Audi S6	2008-2013	4F	37 Navigation	Output Tests	
Audi S6	2008-2013	4F	37 Navigation	Specia Functions	
Audi S6	2008-2013	4F	3C Lane Departure Assistance System	Read Fault Codes	
Audi S6	2008-2013	4F	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S6	2008-2013	4F	3C Lane Departure Assistance System	Measuring Blocks	
Audi S6	2008-2013	4F	3C Lane Departure Assistance System	Output Tests	
Audi S6	2008-2013	4F	3C Lane Departure Assistance System	Specia Functions	
Audi S6	2008-2013	4F	3D Special Function	Read Fault Codes	
Audi S6	2008-2013	4F	3D Special Function	Clear Fault Codes	
Audi S6	2008-2013	4F	3D Special Function	Measuring Blocks	
Audi S6	2008-2013	4F	3D Special Function	Output Tests	
Audi S6	2008-2013	4F	3D Special Function	Specia Functions	
Audi S6	2008-2013	4F	42 Driver-Door Elect.	Read Fault Codes	
Audi S6	2008-2013	4F	42 Driver-Door Elect.	Clear Fault Codes	
Audi S6	2008-2013	4F	42 Driver-Door Elect.	Measuring Blocks	
Audi S6	2008-2013	4F	42 Driver-Door Elect.	Output Tests	
Audi S6	2008-2013	4F	42 Driver-Door Elect.	Specia Functions	
Audi S6	2008-2013	4F	46 Central Control Module	Read Fault Codes	
Audi S6	2008-2013	4F	46 Central Control Module	Clear Fault Codes	
Audi S6	2008-2013	4F	46 Central Control Module	Measuring Blocks	
Audi S6	2008-2013	4F	46 Central Control Module	Output Tests	
Audi S6	2008-2013	4F	46 Central Control Module	Specia Functions	
Audi S6	2008-2013	4F	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2008-2013	4F	47 Soundsystem	Clear Fault Codes	
Audi S6	2008-2013	4F	47 Soundsystem	Measuring Blocks	
Audi S6	2008-2013	4F	47 Soundsystem	Output Tests	
Audi S6	2008-2013	4F	47 Soundsystem	Specia Functions	
Audi S6	2008-2013	4F	4C Tyre Pressure Monitor II	Read Fault Codes	
Audi S6	2008-2013	4F	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi S6	2008-2013	4F	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi S6	2008-2013	4F	4C Tyre Pressure Monitor II	Output Tests	
Audi S6	2008-2013	4F	4C Tyre Pressure Monitor II	Specia Functions	
Audi S6	2008-2013	4F	4F Electronic Central Electric II	Read Fault Codes	
Audi S6	2008-2013	4F	4F Electronic Central Electric II	Clear Fault Codes	
Audi S6	2008-2013	4F	4F Electronic Central Electric II	Measuring Blocks	
Audi S6	2008-2013	4F	4F Electronic Central Electric II	Output Tests	
Audi S6	2008-2013	4F	4F Electronic Central Electric II	Specia Functions	
Audi S6	2008-2013	4F	52 Passe.-Door Elect.	Read Fault Codes	
Audi S6	2008-2013	4F	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S6	2008-2013	4F	52 Passe.-Door Elect.	Measuring Blocks	
Audi S6	2008-2013	4F	52 Passe.-Door Elect.	Output Tests	
Audi S6	2008-2013	4F	52 Passe.-Door Elect.	Specia Functions	
Audi S6	2008-2013	4F	53 Parking Brake	Read Fault Codes	
Audi S6	2008-2013	4F	53 Parking Brake	Clear Fault Codes	
Audi S6	2008-2013	4F	53 Parking Brake	Measuring Blocks	
Audi S6	2008-2013	4F	53 Parking Brake	Output Tests	
Audi S6	2008-2013	4F	53 Parking Brake	Specia Functions	
Audi S6	2008-2013	4F	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2008-2013	4F	55 Headlight Range Control	Clear Fault Codes	
Audi S6	2008-2013	4F	55 Headlight Range Control	Measuring Blocks	
Audi S6	2008-2013	4F	55 Headlight Range Control	Output Tests	
Audi S6	2008-2013	4F	55 Headlight Range Control	Specia Functions	
Audi S6	2008-2013	4F	56 Radio	Read Fault Codes	
Audi S6	2008-2013	4F	56 Radio	Clear Fault Codes	
Audi S6	2008-2013	4F	56 Radio	Measuring Blocks	
Audi S6	2008-2013	4F	56 Radio	Output Tests	
Audi S6	2008-2013	4F	56 Radio	Specia Functions	
Audi S6	2008-2013	4F	57 TV-Tuner	Read Fault Codes	
Audi S6	2008-2013	4F	57 TV-Tuner	Clear Fault Codes	
Audi S6	2008-2013	4F	57 TV-Tuner	Measuring Blocks	
Audi S6	2008-2013	4F	57 TV-Tuner	Output Tests	
Audi S6	2008-2013	4F	57 TV-Tuner	Specia Functions	
Audi S6	2008-2013	4F	5C Lane Keeping Assistance System	Read Fault Codes	
Audi S6	2008-2013	4F	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi S6	2008-2013	4F	5C Lane Keeping Assistance System	Measuring Blocks	
Audi S6	2008-2013	4F	5C Lane Keeping Assistance System	Output Tests	
Audi S6	2008-2013	4F	5C Lane Keeping Assistance System	Specia Functions	
Audi S6	2008-2013	4F	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S6	2008-2013	4F	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S6	2008-2013	4F	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S6	2008-2013	4F	5F Information Electronic Equipment 1	Output Tests	
Audi S6	2008-2013	4F	5F Information Electronic Equipment 1	Specia Functions	
Audi S6	2008-2013	4F	61 Battery Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2008-2013	4F	61 Battery Control	Clear Fault Codes	
Audi S6	2008-2013	4F	61 Battery Control	Measuring Blocks	
Audi S6	2008-2013	4F	61 Battery Control	Output Tests	
Audi S6	2008-2013	4F	61 Battery Control	Specia Functions	
Audi S6	2008-2013	4F	62 LR-Door Electroni.	Read Fault Codes	
Audi S6	2008-2013	4F	62 LR-Door Electroni.	Clear Fault Codes	
Audi S6	2008-2013	4F	62 LR-Door Electroni.	Measuring Blocks	
Audi S6	2008-2013	4F	62 LR-Door Electroni.	Output Tests	
Audi S6	2008-2013	4F	62 LR-Door Electroni.	Specia Functions	
Audi S6	2008-2013	4F	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi S6	2008-2013	4F	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S6	2008-2013	4F	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S6	2008-2013	4F	65 Tyre Pressure Monitoring	Output Tests	
Audi S6	2008-2013	4F	65 Tyre Pressure Monitoring	Specia Functions	
Audi S6	2008-2013	4F	67 Voice Control	Read Fault Codes	
Audi S6	2008-2013	4F	67 Voice Control	Clear Fault Codes	
Audi S6	2008-2013	4F	67 Voice Control	Measuring Blocks	
Audi S6	2008-2013	4F	67 Voice Control	Output Tests	
Audi S6	2008-2013	4F	67 Voice Control	Specia Functions	
Audi S6	2008-2013	4F	69 Trailer Function	Read Fault Codes	
Audi S6	2008-2013	4F	69 Trailer Function	Clear Fault Codes	
Audi S6	2008-2013	4F	69 Trailer Function	Measuring Blocks	
Audi S6	2008-2013	4F	69 Trailer Function	Output Tests	
Audi S6	2008-2013	4F	69 Trailer Function	Specia Functions	
Audi S6	2008-2013	4F	6C Rear Camera	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2008-2013	4F	6C Rear Camera	Clear Fault Codes	
Audi S6	2008-2013	4F	6C Rear Camera	Measuring Blocks	
Audi S6	2008-2013	4F	6C Rear Camera	Output Tests	
Audi S6	2008-2013	4F	6C Rear Camera	Specia Functions	
Audi S6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S6	2008-2013	4F	6F Confort Central Control Unit II	Read Fault Codes	
Audi S6	2008-2013	4F	6F Confort Central Control Unit II	Clear Fault Codes	
Audi S6	2008-2013	4F	6F Confort Central Control Unit II	Measuring Blocks	
Audi S6	2008-2013	4F	6F Confort Central Control Unit II	Output Tests	
Audi S6	2008-2013	4F	6F Confort Central Control Unit II	Specia Functions	
Audi S6	2008-2013	4F	72 RR-Door Electroni.	Read Fault Codes	
Audi S6	2008-2013	4F	72 RR-Door Electroni.	Clear Fault Codes	
Audi S6	2008-2013	4F	72 RR-Door Electroni.	Measuring Blocks	
Audi S6	2008-2013	4F	72 RR-Door Electroni.	Output Tests	
Audi S6	2008-2013	4F	72 RR-Door Electroni.	Specia Functions	
Audi S6	2008-2013	4F	76 Parking Aid	Read Fault Codes	
Audi S6	2008-2013	4F	76 Parking Aid	Clear Fault Codes	
Audi S6	2008-2013	4F	76 Parking Aid	Measuring Blocks	
Audi S6	2008-2013	4F	76 Parking Aid	Output Tests	
Audi S6	2008-2013	4F	76 Parking Aid	Specia Functions	
Audi S6	2008-2013	4F	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2008-2013	4F	77 Telephone	Clear Fault Codes	
Audi S6	2008-2013	4F	77 Telephone	Measuring Blocks	
Audi S6	2008-2013	4F	77 Telephone	Output Tests	
Audi S6	2008-2013	4F	77 Telephone	Specia Functions	
Audi RS6	2008-2013	4F	01 Engine Electronics	Read Fault Codes	
Audi RS6	2008-2013	4F	01 Engine Electronics	Clear Fault Codes	
Audi RS6	2008-2013	4F	01 Engine Electronics	Measuring Blocks	
Audi RS6	2008-2013	4F	01 Engine Electronics	Output Tests	
Audi RS6	2008-2013	4F	01 Engine Electronics	Specia Functions	
Audi RS6	2008-2013	4F	02 Transmission Electronics	Read Fault Codes	
Audi RS6	2008-2013	4F	02 Transmission Electronics	Clear Fault Codes	
Audi RS6	2008-2013	4F	02 Transmission Electronics	Measuring Blocks	
Audi RS6	2008-2013	4F	02 Transmission Electronics	Output Tests	
Audi RS6	2008-2013	4F	02 Transmission Electronics	Specia Functions	
Audi RS6	2008-2013	4F	03 Brake Electronics	Read Fault Codes	
Audi RS6	2008-2013	4F	03 Brake Electronics	Clear Fault Codes	
Audi RS6	2008-2013	4F	03 Brake Electronics	Measuring Blocks	
Audi RS6	2008-2013	4F	03 Brake Electronics	Output Tests	
Audi RS6	2008-2013	4F	03 Brake Electronics	Specia Functions	
Audi RS6	2008-2013	4F	05 Access & Permissi.	Read Fault Codes	
Audi RS6	2008-2013	4F	05 Access & Permissi.	Clear Fault Codes	
Audi RS6	2008-2013	4F	05 Access & Permissi.	Measuring Blocks	
Audi RS6	2008-2013	4F	05 Access & Permissi.	Output Tests	
Audi RS6	2008-2013	4F	05 Access & Permissi.	Specia Functions	
Audi RS6	2008-2013	4F	06 Passene. Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS6	2008-2013	4F	06 Passene. Seat Adj.	Clear Fault Codes	
Audi RS6	2008-2013	4F	06 Passene. Seat Adj.	Measuring Blocks	
Audi RS6	2008-2013	4F	06 Passene. Seat Adj.	Output Tests	
Audi RS6	2008-2013	4F	06 Passene. Seat Adj.	Specia Functions	
Audi RS6	2008-2013	4F	07 Display-/Cntl Unit	Read Fault Codes	
Audi RS6	2008-2013	4F	07 Display-/Cntl Unit	Clear Fault Codes	
Audi RS6	2008-2013	4F	07 Display-/Cntl Unit	Measuring Blocks	
Audi RS6	2008-2013	4F	07 Display-/Cntl Unit	Output Tests	
Audi RS6	2008-2013	4F	07 Display-/Cntl Unit	Specia Functions	
Audi RS6	2008-2013	4F	08 AC/Heating Electronics	Read Fault Codes	
Audi RS6	2008-2013	4F	08 AC/Heating Electronics	Clear Fault Codes	
Audi RS6	2008-2013	4F	08 AC/Heating Electronics	Measuring Blocks	
Audi RS6	2008-2013	4F	08 AC/Heating Electronics	Output Tests	
Audi RS6	2008-2013	4F	08 AC/Heating Electronics	Specia Functions	
Audi RS6	2008-2013	4F	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi RS6	2008-2013	4F	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi RS6	2008-2013	4F	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi RS6	2008-2013	4F	09 Electronic Ctrl Electronics	Output Tests	
Audi RS6	2008-2013	4F	09 Electronic Ctrl Electronics	Specia Functions	
Audi RS6	2008-2013	4F	0E Media Player Position 1	Read Fault Codes	
Audi RS6	2008-2013	4F	0E Media Player Position 1	Clear Fault Codes	
Audi RS6	2008-2013	4F	0E Media Player Position 1	Measuring Blocks	
Audi RS6	2008-2013	4F	0E Media Player Position 1	Output Tests	
Audi RS6	2008-2013	4F	0E Media Player Position 1	Specia Functions	
Audi RS6	2008-2013	4F	0F Radio Tuner-Digital	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2008-2013	4F	0F Radio Tuner-Digital	Clear Fault Codes	
Audi RS6	2008-2013	4F	0F Radio Tuner-Digital	Measuring Blocks	
Audi RS6	2008-2013	4F	0F Radio Tuner-Digital	Output Tests	
Audi RS6	2008-2013	4F	0F Radio Tuner-Digital	Specia Functions	
Audi RS6	2008-2013	4F	10 Parking Assist System 2	Read Fault Codes	
Audi RS6	2008-2013	4F	10 Parking Assist System 2	Clear Fault Codes	
Audi RS6	2008-2013	4F	10 Parking Assist System 2	Measuring Blocks	
Audi RS6	2008-2013	4F	10 Parking Assist System 2	Output Tests	
Audi RS6	2008-2013	4F	10 Parking Assist System 2	Specia Functions	
Audi RS6	2008-2013	4F	11 Engine Electronics 2	Read Fault Codes	
Audi RS6	2008-2013	4F	11 Engine Electronics 2	Clear Fault Codes	
Audi RS6	2008-2013	4F	11 Engine Electronics 2	Measuring Blocks	
Audi RS6	2008-2013	4F	11 Engine Electronics 2	Output Tests	
Audi RS6	2008-2013	4F	11 Engine Electronics 2	Specia Functions	
Audi RS6	2008-2013	4F	13 Distance Control	Read Fault Codes	
Audi RS6	2008-2013	4F	13 Distance Control	Clear Fault Codes	
Audi RS6	2008-2013	4F	13 Distance Control	Measuring Blocks	
Audi RS6	2008-2013	4F	13 Distance Control	Output Tests	
Audi RS6	2008-2013	4F	13 Distance Control	Specia Functions	
Audi RS6	2008-2013	4F	14 Wheel Damping Electronics	Read Fault Codes	
Audi RS6	2008-2013	4F	14 Wheel Damping Electronics	Clear Fault Codes	
Audi RS6	2008-2013	4F	14 Wheel Damping Electronics	Measuring Blocks	
Audi RS6	2008-2013	4F	14 Wheel Damping Electronics	Output Tests	
Audi RS6	2008-2013	4F	14 Wheel Damping Electronics	Specia Functions	
Audi RS6	2008-2013	4F	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2008-2013	4F	15 Airbags	Clear Fault Codes	
Audi RS6	2008-2013	4F	15 Airbags	Measuring Blocks	
Audi RS6	2008-2013	4F	15 Airbags	Output Tests	
Audi RS6	2008-2013	4F	15 Airbags	Specia Functions	
Audi RS6	2008-2013	4F	16 Steering Wheel Electronics	Read Fault Codes	
Audi RS6	2008-2013	4F	16 Steering Wheel Electronics	Clear Fault Codes	
Audi RS6	2008-2013	4F	16 Steering Wheel Electronics	Measuring Blocks	
Audi RS6	2008-2013	4F	16 Steering Wheel Electronics	Output Tests	
Audi RS6	2008-2013	4F	16 Steering Wheel Electronics	Specia Functions	
Audi RS6	2008-2013	4F	17 Instrument Cluster	Read Fault Codes	
Audi RS6	2008-2013	4F	17 Instrument Cluster	Clear Fault Codes	
Audi RS6	2008-2013	4F	17 Instrument Cluster	Measuring Blocks	
Audi RS6	2008-2013	4F	17 Instrument Cluster	Output Tests	
Audi RS6	2008-2013	4F	17 Instrument Cluster	Specia Functions	
Audi RS6	2008-2013	4F	18 Aux Heating	Read Fault Codes	
Audi RS6	2008-2013	4F	18 Aux Heating	Clear Fault Codes	
Audi RS6	2008-2013	4F	18 Aux Heating	Measuring Blocks	
Audi RS6	2008-2013	4F	18 Aux Heating	Output Tests	
Audi RS6	2008-2013	4F	18 Aux Heating	Specia Functions	
Audi RS6	2008-2013	4F	19 Gateway Data Bus	Read Fault Codes	
Audi RS6	2008-2013	4F	19 Gateway Data Bus	Clear Fault Codes	
Audi RS6	2008-2013	4F	19 Gateway Data Bus	Measuring Blocks	
Audi RS6	2008-2013	4F	19 Gateway Data Bus	Output Tests	
Audi RS6	2008-2013	4F	19 Gateway Data Bus	Specia Functions	
Audi RS6	2008-2013	4F	1E Media Player Position 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS6	2008-2013	4F	1E Media Player Position 2	Clear Fault Codes	
Audi RS6	2008-2013	4F	1E Media Player Position 2	Measuring Blocks	
Audi RS6	2008-2013	4F	1E Media Player Position 2	Output Tests	
Audi RS6	2008-2013	4F	1E Media Player Position 2	Specia Functions	
Audi RS6	2008-2013	4F	20 High Beam Assistance Device	Read Fault Codes	
Audi RS6	2008-2013	4F	20 High Beam Assistance Device	Clear Fault Codes	
Audi RS6	2008-2013	4F	20 High Beam Assistance Device	Measuring Blocks	
Audi RS6	2008-2013	4F	20 High Beam Assistance Device	Output Tests	
Audi RS6	2008-2013	4F	20 High Beam Assistance Device	Specia Functions	
Audi RS6	2008-2013	4F	28 Climate Control Unit Rear	Read Fault Codes	
Audi RS6	2008-2013	4F	28 Climate Control Unit Rear	Clear Fault Codes	
Audi RS6	2008-2013	4F	28 Climate Control Unit Rear	Measuring Blocks	
Audi RS6	2008-2013	4F	28 Climate Control Unit Rear	Output Tests	
Audi RS6	2008-2013	4F	28 Climate Control Unit Rear	Specia Functions	
Audi RS6	2008-2013	4F	2E Media Player Position 3	Read Fault Codes	
Audi RS6	2008-2013	4F	2E Media Player Position 3	Clear Fault Codes	
Audi RS6	2008-2013	4F	2E Media Player Position 3	Measuring Blocks	
Audi RS6	2008-2013	4F	2E Media Player Position 3	Output Tests	
Audi RS6	2008-2013	4F	2E Media Player Position 3	Specia Functions	
Audi RS6	2008-2013	4F	34 Self Leveling Suspension	Read Fault Codes	
Audi RS6	2008-2013	4F	34 Self Leveling Suspension	Clear Fault Codes	
Audi RS6	2008-2013	4F	34 Self Leveling Suspension	Measuring Blocks	
Audi RS6	2008-2013	4F	34 Self Leveling Suspension	Output Tests	
Audi RS6	2008-2013	4F	34 Self Leveling Suspension	Specia Functions	
Audi RS6	2008-2013	4F	36 Side of Driver Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2008-2013	4F	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi RS6	2008-2013	4F	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi RS6	2008-2013	4F	36 Side of Driver Seat Adj.	Output Tests	
Audi RS6	2008-2013	4F	36 Side of Driver Seat Adj.	Specia Functions	
Audi RS6	2008-2013	4F	37 Navigation	Read Fault Codes	
Audi RS6	2008-2013	4F	37 Navigation	Clear Fault Codes	
Audi RS6	2008-2013	4F	37 Navigation	Measuring Blocks	
Audi RS6	2008-2013	4F	37 Navigation	Output Tests	
Audi RS6	2008-2013	4F	37 Navigation	Specia Functions	
Audi RS6	2008-2013	4F	3C Lane Departure Assistance System	Read Fault Codes	
Audi RS6	2008-2013	4F	3C Lane Departure Assistance System	Clear Fault Codes	
Audi RS6	2008-2013	4F	3C Lane Departure Assistance System	Measuring Blocks	
Audi RS6	2008-2013	4F	3C Lane Departure Assistance System	Output Tests	
Audi RS6	2008-2013	4F	3C Lane Departure Assistance System	Specia Functions	
Audi RS6	2008-2013	4F	3D Special Function	Read Fault Codes	
Audi RS6	2008-2013	4F	3D Special Function	Clear Fault Codes	
Audi RS6	2008-2013	4F	3D Special Function	Measuring Blocks	
Audi RS6	2008-2013	4F	3D Special Function	Output Tests	
Audi RS6	2008-2013	4F	3D Special Function	Specia Functions	
Audi RS6	2008-2013	4F	42 Driver-Door Elect.	Read Fault Codes	
Audi RS6	2008-2013	4F	42 Driver-Door Elect.	Clear Fault Codes	
Audi RS6	2008-2013	4F	42 Driver-Door Elect.	Measuring Blocks	
Audi RS6	2008-2013	4F	42 Driver-Door Elect.	Output Tests	
Audi RS6	2008-2013	4F	42 Driver-Door Elect.	Specia Functions	
Audi RS6	2008-2013	4F	46 Central Control Module	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS6	2008-2013	4F	46 Central Control Module	Clear Fault Codes	
Audi RS6	2008-2013	4F	46 Central Control Module	Measuring Blocks	
Audi RS6	2008-2013	4F	46 Central Control Module	Output Tests	
Audi RS6	2008-2013	4F	46 Central Control Module	Specia Functions	
Audi RS6	2008-2013	4F	47 Soundsystem	Read Fault Codes	
Audi RS6	2008-2013	4F	47 Soundsystem	Clear Fault Codes	
Audi RS6	2008-2013	4F	47 Soundsystem	Measuring Blocks	
Audi RS6	2008-2013	4F	47 Soundsystem	Output Tests	
Audi RS6	2008-2013	4F	47 Soundsystem	Specia Functions	
Audi RS6	2008-2013	4F	4C Tyre Pressure Monitor II	Read Fault Codes	
Audi RS6	2008-2013	4F	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi RS6	2008-2013	4F	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi RS6	2008-2013	4F	4C Tyre Pressure Monitor II	Output Tests	
Audi RS6	2008-2013	4F	4C Tyre Pressure Monitor II	Specia Functions	
Audi RS6	2008-2013	4F	4F Electronic Central Electric II	Read Fault Codes	
Audi RS6	2008-2013	4F	4F Electronic Central Electric II	Clear Fault Codes	
Audi RS6	2008-2013	4F	4F Electronic Central Electric II	Measuring Blocks	
Audi RS6	2008-2013	4F	4F Electronic Central Electric II	Output Tests	
Audi RS6	2008-2013	4F	4F Electronic Central Electric II	Specia Functions	
Audi RS6	2008-2013	4F	52 Passe.-Door Elect.	Read Fault Codes	
Audi RS6	2008-2013	4F	52 Passe.-Door Elect.	Clear Fault Codes	
Audi RS6	2008-2013	4F	52 Passe.-Door Elect.	Measuring Blocks	
Audi RS6	2008-2013	4F	52 Passe.-Door Elect.	Output Tests	
Audi RS6	2008-2013	4F	52 Passe.-Door Elect.	Specia Functions	
Audi RS6	2008-2013	4F	53 Parking Brake	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2008-2013	4F	53 Parking Brake	Clear Fault Codes	
Audi RS6	2008-2013	4F	53 Parking Brake	Measuring Blocks	
Audi RS6	2008-2013	4F	53 Parking Brake	Output Tests	
Audi RS6	2008-2013	4F	53 Parking Brake	Specia Functions	
Audi RS6	2008-2013	4F	55 Headlight Range Control	Read Fault Codes	
Audi RS6	2008-2013	4F	55 Headlight Range Control	Clear Fault Codes	
Audi RS6	2008-2013	4F	55 Headlight Range Control	Measuring Blocks	
Audi RS6	2008-2013	4F	55 Headlight Range Control	Output Tests	
Audi RS6	2008-2013	4F	55 Headlight Range Control	Specia Functions	
Audi RS6	2008-2013	4F	56 Radio	Read Fault Codes	
Audi RS6	2008-2013	4F	56 Radio	Clear Fault Codes	
Audi RS6	2008-2013	4F	56 Radio	Measuring Blocks	
Audi RS6	2008-2013	4F	56 Radio	Output Tests	
Audi RS6	2008-2013	4F	56 Radio	Specia Functions	
Audi RS6	2008-2013	4F	57 TV-Tuner	Read Fault Codes	
Audi RS6	2008-2013	4F	57 TV-Tuner	Clear Fault Codes	
Audi RS6	2008-2013	4F	57 TV-Tuner	Measuring Blocks	
Audi RS6	2008-2013	4F	57 TV-Tuner	Output Tests	
Audi RS6	2008-2013	4F	57 TV-Tuner	Specia Functions	
Audi RS6	2008-2013	4F	5C Lane Keeping Assistance System	Read Fault Codes	
Audi RS6	2008-2013	4F	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi RS6	2008-2013	4F	5C Lane Keeping Assistance System	Measuring Blocks	
Audi RS6	2008-2013	4F	5C Lane Keeping Assistance System	Output Tests	
Audi RS6	2008-2013	4F	5C Lane Keeping Assistance System	Specia Functions	
Audi RS6	2008-2013	4F	5F Information Electronic Equipment 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2008-2013	4F	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi RS6	2008-2013	4F	5F Information Electronic Equipment 1	Measuring Blocks	
Audi RS6	2008-2013	4F	5F Information Electronic Equipment 1	Output Tests	
Audi RS6	2008-2013	4F	5F Information Electronic Equipment 1	Specia Functions	
Audi RS6	2008-2013	4F	61 Battery Control	Read Fault Codes	
Audi RS6	2008-2013	4F	61 Battery Control	Clear Fault Codes	
Audi RS6	2008-2013	4F	61 Battery Control	Measuring Blocks	
Audi RS6	2008-2013	4F	61 Battery Control	Output Tests	
Audi RS6	2008-2013	4F	61 Battery Control	Specia Functions	
Audi RS6	2008-2013	4F	62 LR-Door Electroni.	Read Fault Codes	
Audi RS6	2008-2013	4F	62 LR-Door Electroni.	Clear Fault Codes	
Audi RS6	2008-2013	4F	62 LR-Door Electroni.	Measuring Blocks	
Audi RS6	2008-2013	4F	62 LR-Door Electroni.	Output Tests	
Audi RS6	2008-2013	4F	62 LR-Door Electroni.	Specia Functions	
Audi RS6	2008-2013	4F	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi RS6	2008-2013	4F	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi RS6	2008-2013	4F	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi RS6	2008-2013	4F	65 Tyre Pressure Monitoring	Output Tests	
Audi RS6	2008-2013	4F	65 Tyre Pressure Monitoring	Specia Functions	
Audi RS6	2008-2013	4F	67 Voice Control	Read Fault Codes	
Audi RS6	2008-2013	4F	67 Voice Control	Clear Fault Codes	
Audi RS6	2008-2013	4F	67 Voice Control	Measuring Blocks	
Audi RS6	2008-2013	4F	67 Voice Control	Output Tests	
Audi RS6	2008-2013	4F	67 Voice Control	Specia Functions	
Audi RS6	2008-2013	4F	69 Trailer Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2008-2013	4F	69 Trailer Function	Clear Fault Codes	
Audi RS6	2008-2013	4F	69 Trailer Function	Measuring Blocks	
Audi RS6	2008-2013	4F	69 Trailer Function	Output Tests	
Audi RS6	2008-2013	4F	69 Trailer Function	Specia Functions	
Audi RS6	2008-2013	4F	6C Rear Camera	Read Fault Codes	
Audi RS6	2008-2013	4F	6C Rear Camera	Clear Fault Codes	
Audi RS6	2008-2013	4F	6C Rear Camera	Measuring Blocks	
Audi RS6	2008-2013	4F	6C Rear Camera	Output Tests	
Audi RS6	2008-2013	4F	6C Rear Camera	Specia Functions	
Audi RS6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi RS6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi RS6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi RS6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi RS6	2008-2013	4F	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi RS6	2008-2013	4F	6F Confort Central Control Unit II	Read Fault Codes	
Audi RS6	2008-2013	4F	6F Confort Central Control Unit II	Clear Fault Codes	
Audi RS6	2008-2013	4F	6F Confort Central Control Unit II	Measuring Blocks	
Audi RS6	2008-2013	4F	6F Confort Central Control Unit II	Output Tests	
Audi RS6	2008-2013	4F	6F Confort Central Control Unit II	Specia Functions	
Audi RS6	2008-2013	4F	72 RR-Door Electroni.	Read Fault Codes	
Audi RS6	2008-2013	4F	72 RR-Door Electroni.	Clear Fault Codes	
Audi RS6	2008-2013	4F	72 RR-Door Electroni.	Measuring Blocks	
Audi RS6	2008-2013	4F	72 RR-Door Electroni.	Output Tests	
Audi RS6	2008-2013	4F	72 RR-Door Electroni.	Specia Functions	
Audi RS6	2008-2013	4F	76 Parking Aid	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2008-2013	4F	76 Parking Aid	Clear Fault Codes	
Audi RS6	2008-2013	4F	76 Parking Aid	Measuring Blocks	
Audi RS6	2008-2013	4F	76 Parking Aid	Output Tests	
Audi RS6	2008-2013	4F	76 Parking Aid	Specia Functions	
Audi RS6	2008-2013	4F	77 Telephone	Read Fault Codes	
Audi RS6	2008-2013	4F	77 Telephone	Clear Fault Codes	
Audi RS6	2008-2013	4F	77 Telephone	Measuring Blocks	
Audi RS6	2008-2013	4F	77 Telephone	Output Tests	
Audi RS6	2008-2013	4F	77 Telephone	Specia Functions	
Audi Q7	2009-2016	4L	01 Engine Electronics	Read Fault Codes	
Audi Q7	2009-2016	4L	01 Engine Electronics	Clear Fault Codes	
Audi Q7	2009-2016	4L	01 Engine Electronics	Measuring Blocks	
Audi Q7	2009-2016	4L	01 Engine Electronics	Output Tests	
Audi Q7	2009-2016	4L	01 Engine Electronics	Specia Functions	
Audi Q7	2009-2016	4L	02 Transmission Electronics	Read Fault Codes	
Audi Q7	2009-2016	4L	02 Transmission Electronics	Clear Fault Codes	
Audi Q7	2009-2016	4L	02 Transmission Electronics	Measuring Blocks	
Audi Q7	2009-2016	4L	02 Transmission Electronics	Output Tests	
Audi Q7	2009-2016	4L	02 Transmission Electronics	Specia Functions	
Audi Q7	2009-2016	4L	03 Brake Electronics	Read Fault Codes	
Audi Q7	2009-2016	4L	03 Brake Electronics	Clear Fault Codes	
Audi Q7	2009-2016	4L	03 Brake Electronics	Measuring Blocks	
Audi Q7	2009-2016	4L	03 Brake Electronics	Output Tests	
Audi Q7	2009-2016	4L	03 Brake Electronics	Specia Functions	
Audi Q7	2009-2016	4L	05 Access & Permissi.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7	2009-2016	4L	05 Access & Permissi.	Clear Fault Codes	
Audi Q7	2009-2016	4L	05 Access & Permissi.	Measuring Blocks	
Audi Q7	2009-2016	4L	05 Access & Permissi.	Output Tests	
Audi Q7	2009-2016	4L	05 Access & Permissi.	Specia Functions	
Audi Q7	2009-2016	4L	06 Passene. Seat Adj.	Read Fault Codes	
Audi Q7	2009-2016	4L	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q7	2009-2016	4L	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q7	2009-2016	4L	06 Passene. Seat Adj.	Output Tests	
Audi Q7	2009-2016	4L	06 Passene. Seat Adj.	Specia Functions	
Audi Q7	2009-2016	4L	07 Display-/Cntl Unit	Read Fault Codes	
Audi Q7	2009-2016	4L	07 Display-/Cntl Unit	Clear Fault Codes	
Audi Q7	2009-2016	4L	07 Display-/Cntl Unit	Measuring Blocks	
Audi Q7	2009-2016	4L	07 Display-/Cntl Unit	Output Tests	
Audi Q7	2009-2016	4L	07 Display-/Cntl Unit	Specia Functions	
Audi Q7	2009-2016	4L	08 AC/Heating Electronics	Read Fault Codes	
Audi Q7	2009-2016	4L	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q7	2009-2016	4L	08 AC/Heating Electronics	Measuring Blocks	
Audi Q7	2009-2016	4L	08 AC/Heating Electronics	Output Tests	
Audi Q7	2009-2016	4L	08 AC/Heating Electronics	Specia Functions	
Audi Q7	2009-2016	4L	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Q7	2009-2016	4L	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q7	2009-2016	4L	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q7	2009-2016	4L	09 Electronic Ctrl Electronics	Output Tests	
Audi Q7	2009-2016	4L	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q7	2009-2016	4L	0E Media Player Position 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2009-2016	4L	0E Media Player Position 1	Clear Fault Codes	
Audi Q7	2009-2016	4L	0E Media Player Position 1	Measuring Blocks	
Audi Q7	2009-2016	4L	0E Media Player Position 1	Output Tests	
Audi Q7	2009-2016	4L	0E Media Player Position 1	Specia Functions	
Audi Q7	2009-2016	4L	0F Radio Tuner-Digital	Read Fault Codes	
Audi Q7	2009-2016	4L	0F Radio Tuner-Digital	Clear Fault Codes	
Audi Q7	2009-2016	4L	0F Radio Tuner-Digital	Measuring Blocks	
Audi Q7	2009-2016	4L	0F Radio Tuner-Digital	Output Tests	
Audi Q7	2009-2016	4L	0F Radio Tuner-Digital	Specia Functions	
Audi Q7	2009-2016	4L	10 Parking Assist System 2	Read Fault Codes	
Audi Q7	2009-2016	4L	10 Parking Assist System 2	Clear Fault Codes	
Audi Q7	2009-2016	4L	10 Parking Assist System 2	Measuring Blocks	
Audi Q7	2009-2016	4L	10 Parking Assist System 2	Output Tests	
Audi Q7	2009-2016	4L	10 Parking Assist System 2	Specia Functions	
Audi Q7	2009-2016	4L	11 Engine Electronics 2	Read Fault Codes	
Audi Q7	2009-2016	4L	11 Engine Electronics 2	Clear Fault Codes	
Audi Q7	2009-2016	4L	11 Engine Electronics 2	Measuring Blocks	
Audi Q7	2009-2016	4L	11 Engine Electronics 2	Output Tests	
Audi Q7	2009-2016	4L	11 Engine Electronics 2	Specia Functions	
Audi Q7	2009-2016	4L	13 Distance Control	Read Fault Codes	
Audi Q7	2009-2016	4L	13 Distance Control	Clear Fault Codes	
Audi Q7	2009-2016	4L	13 Distance Control	Measuring Blocks	
Audi Q7	2009-2016	4L	13 Distance Control	Output Tests	
Audi Q7	2009-2016	4L	13 Distance Control	Specia Functions	
Audi Q7	2009-2016	4L	14 Wheel Damping Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2009-2016	4L	14 Wheel Damping Electronics	Clear Fault Codes	
Audi Q7	2009-2016	4L	14 Wheel Damping Electronics	Measuring Blocks	
Audi Q7	2009-2016	4L	14 Wheel Damping Electronics	Output Tests	
Audi Q7	2009-2016	4L	14 Wheel Damping Electronics	Specia Functions	
Audi Q7	2009-2016	4L	15 Airbags	Read Fault Codes	
Audi Q7	2009-2016	4L	15 Airbags	Clear Fault Codes	
Audi Q7	2009-2016	4L	15 Airbags	Measuring Blocks	
Audi Q7	2009-2016	4L	15 Airbags	Output Tests	
Audi Q7	2009-2016	4L	15 Airbags	Specia Functions	
Audi Q7	2009-2016	4L	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q7	2009-2016	4L	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q7	2009-2016	4L	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q7	2009-2016	4L	16 Steering Wheel Electronics	Output Tests	
Audi Q7	2009-2016	4L	16 Steering Wheel Electronics	Specia Functions	
Audi Q7	2009-2016	4L	17 Instrument Cluster	Read Fault Codes	
Audi Q7	2009-2016	4L	17 Instrument Cluster	Clear Fault Codes	
Audi Q7	2009-2016	4L	17 Instrument Cluster	Measuring Blocks	
Audi Q7	2009-2016	4L	17 Instrument Cluster	Output Tests	
Audi Q7	2009-2016	4L	17 Instrument Cluster	Specia Functions	
Audi Q7	2009-2016	4L	18 Aux Heating	Read Fault Codes	
Audi Q7	2009-2016	4L	18 Aux Heating	Clear Fault Codes	
Audi Q7	2009-2016	4L	18 Aux Heating	Measuring Blocks	
Audi Q7	2009-2016	4L	18 Aux Heating	Output Tests	
Audi Q7	2009-2016	4L	18 Aux Heating	Specia Functions	
Audi Q7	2009-2016	4L	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2009-2016	4L	19 Gateway Data Bus	Clear Fault Codes	
Audi Q7	2009-2016	4L	19 Gateway Data Bus	Measuring Blocks	
Audi Q7	2009-2016	4L	19 Gateway Data Bus	Output Tests	
Audi Q7	2009-2016	4L	19 Gateway Data Bus	Specia Functions	
Audi Q7	2009-2016	4L	1E Media Player Position 2	Read Fault Codes	
Audi Q7	2009-2016	4L	1E Media Player Position 2	Clear Fault Codes	
Audi Q7	2009-2016	4L	1E Media Player Position 2	Measuring Blocks	
Audi Q7	2009-2016	4L	1E Media Player Position 2	Output Tests	
Audi Q7	2009-2016	4L	1E Media Player Position 2	Specia Functions	
Audi Q7	2009-2016	4L	20 High Beam Assistance Device	Read Fault Codes	
Audi Q7	2009-2016	4L	20 High Beam Assistance Device	Clear Fault Codes	
Audi Q7	2009-2016	4L	20 High Beam Assistance Device	Measuring Blocks	
Audi Q7	2009-2016	4L	20 High Beam Assistance Device	Output Tests	
Audi Q7	2009-2016	4L	20 High Beam Assistance Device	Specia Functions	
Audi Q7	2009-2016	4L	28 Climate Control Unit Rear	Read Fault Codes	
Audi Q7	2009-2016	4L	28 Climate Control Unit Rear	Clear Fault Codes	
Audi Q7	2009-2016	4L	28 Climate Control Unit Rear	Measuring Blocks	
Audi Q7	2009-2016	4L	28 Climate Control Unit Rear	Output Tests	
Audi Q7	2009-2016	4L	28 Climate Control Unit Rear	Specia Functions	
Audi Q7	2009-2016	4L	2E Media Player Position 3	Read Fault Codes	
Audi Q7	2009-2016	4L	2E Media Player Position 3	Clear Fault Codes	
Audi Q7	2009-2016	4L	2E Media Player Position 3	Measuring Blocks	
Audi Q7	2009-2016	4L	2E Media Player Position 3	Output Tests	
Audi Q7	2009-2016	4L	2E Media Player Position 3	Specia Functions	
Audi Q7	2009-2016	4L	34 Self Leveling Suspension	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7	2009-2016	4L	34 Self Leveling Suspension	Clear Fault Codes	
Audi Q7	2009-2016	4L	34 Self Leveling Suspension	Measuring Blocks	
Audi Q7	2009-2016	4L	34 Self Leveling Suspension	Output Tests	
Audi Q7	2009-2016	4L	34 Self Leveling Suspension	Specia Functions	
Audi Q7	2009-2016	4L	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi Q7	2009-2016	4L	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Q7	2009-2016	4L	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Q7	2009-2016	4L	36 Side of Driver Seat Adj.	Output Tests	
Audi Q7	2009-2016	4L	36 Side of Driver Seat Adj.	Specia Functions	
Audi Q7	2009-2016	4L	37 Navigation	Read Fault Codes	
Audi Q7	2009-2016	4L	37 Navigation	Clear Fault Codes	
Audi Q7	2009-2016	4L	37 Navigation	Measuring Blocks	
Audi Q7	2009-2016	4L	37 Navigation	Output Tests	
Audi Q7	2009-2016	4L	37 Navigation	Specia Functions	
Audi Q7	2009-2016	4L	3C Lane Departure Assistance System	Read Fault Codes	
Audi Q7	2009-2016	4L	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q7	2009-2016	4L	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q7	2009-2016	4L	3C Lane Departure Assistance System	Output Tests	
Audi Q7	2009-2016	4L	3C Lane Departure Assistance System	Specia Functions	
Audi Q7	2009-2016	4L	3D Special Function	Read Fault Codes	
Audi Q7	2009-2016	4L	3D Special Function	Clear Fault Codes	
Audi Q7	2009-2016	4L	3D Special Function	Measuring Blocks	
Audi Q7	2009-2016	4L	3D Special Function	Output Tests	
Audi Q7	2009-2016	4L	3D Special Function	Specia Functions	
Audi Q7	2009-2016	4L	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2009-2016	4L	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q7	2009-2016	4L	42 Driver-Door Elect.	Measuring Blocks	
Audi Q7	2009-2016	4L	42 Driver-Door Elect.	Output Tests	
Audi Q7	2009-2016	4L	42 Driver-Door Elect.	Specia Functions	
Audi Q7	2009-2016	4L	46 Central Control Module	Read Fault Codes	
Audi Q7	2009-2016	4L	46 Central Control Module	Clear Fault Codes	
Audi Q7	2009-2016	4L	46 Central Control Module	Measuring Blocks	
Audi Q7	2009-2016	4L	46 Central Control Module	Output Tests	
Audi Q7	2009-2016	4L	46 Central Control Module	Specia Functions	
Audi Q7	2009-2016	4L	47 Soundsystem	Read Fault Codes	
Audi Q7	2009-2016	4L	47 Soundsystem	Clear Fault Codes	
Audi Q7	2009-2016	4L	47 Soundsystem	Measuring Blocks	
Audi Q7	2009-2016	4L	47 Soundsystem	Output Tests	
Audi Q7	2009-2016	4L	47 Soundsystem	Specia Functions	
Audi Q7	2009-2016	4L	4C Tyre Pressure Monitor II	Read Fault Codes	
Audi Q7	2009-2016	4L	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi Q7	2009-2016	4L	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi Q7	2009-2016	4L	4C Tyre Pressure Monitor II	Output Tests	
Audi Q7	2009-2016	4L	4C Tyre Pressure Monitor II	Specia Functions	
Audi Q7	2009-2016	4L	4F Electronic Central Electric II	Read Fault Codes	
Audi Q7	2009-2016	4L	4F Electronic Central Electric II	Clear Fault Codes	
Audi Q7	2009-2016	4L	4F Electronic Central Electric II	Measuring Blocks	
Audi Q7	2009-2016	4L	4F Electronic Central Electric II	Output Tests	
Audi Q7	2009-2016	4L	4F Electronic Central Electric II	Specia Functions	
Audi Q7	2009-2016	4L	52 Passe.-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2009-2016	4L	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q7	2009-2016	4L	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q7	2009-2016	4L	52 Passe.-Door Elect.	Output Tests	
Audi Q7	2009-2016	4L	52 Passe.-Door Elect.	Specia Functions	
Audi Q7	2009-2016	4L	53 Parking Brake	Read Fault Codes	
Audi Q7	2009-2016	4L	53 Parking Brake	Clear Fault Codes	
Audi Q7	2009-2016	4L	53 Parking Brake	Measuring Blocks	
Audi Q7	2009-2016	4L	53 Parking Brake	Output Tests	
Audi Q7	2009-2016	4L	53 Parking Brake	Specia Functions	
Audi Q7	2009-2016	4L	55 Headlight Range Control	Read Fault Codes	
Audi Q7	2009-2016	4L	55 Headlight Range Control	Clear Fault Codes	
Audi Q7	2009-2016	4L	55 Headlight Range Control	Measuring Blocks	
Audi Q7	2009-2016	4L	55 Headlight Range Control	Output Tests	
Audi Q7	2009-2016	4L	55 Headlight Range Control	Specia Functions	
Audi Q7	2009-2016	4L	56 Radio	Read Fault Codes	
Audi Q7	2009-2016	4L	56 Radio	Clear Fault Codes	
Audi Q7	2009-2016	4L	56 Radio	Measuring Blocks	
Audi Q7	2009-2016	4L	56 Radio	Output Tests	
Audi Q7	2009-2016	4L	56 Radio	Specia Functions	
Audi Q7	2009-2016	4L	57 TV-Tuner	Read Fault Codes	
Audi Q7	2009-2016	4L	57 TV-Tuner	Clear Fault Codes	
Audi Q7	2009-2016	4L	57 TV-Tuner	Measuring Blocks	
Audi Q7	2009-2016	4L	57 TV-Tuner	Output Tests	
Audi Q7	2009-2016	4L	57 TV-Tuner	Specia Functions	
Audi Q7	2009-2016	4L	5C Lane Keeping Assistance System	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2009-2016	4L	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi Q7	2009-2016	4L	5C Lane Keeping Assistance System	Measuring Blocks	
Audi Q7	2009-2016	4L	5C Lane Keeping Assistance System	Output Tests	
Audi Q7	2009-2016	4L	5C Lane Keeping Assistance System	Specia Functions	
Audi Q7	2009-2016	4L	5F Information Electronic Equipment 1	Read Fault Codes	
Audi Q7	2009-2016	4L	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi Q7	2009-2016	4L	5F Information Electronic Equipment 1	Measuring Blocks	
Audi Q7	2009-2016	4L	5F Information Electronic Equipment 1	Output Tests	
Audi Q7	2009-2016	4L	5F Information Electronic Equipment 1	Specia Functions	
Audi Q7	2009-2016	4L	61 Battery Control	Read Fault Codes	
Audi Q7	2009-2016	4L	61 Battery Control	Clear Fault Codes	
Audi Q7	2009-2016	4L	61 Battery Control	Measuring Blocks	
Audi Q7	2009-2016	4L	61 Battery Control	Output Tests	
Audi Q7	2009-2016	4L	61 Battery Control	Specia Functions	
Audi Q7	2009-2016	4L	62 LR-Door Electroni.	Read Fault Codes	
Audi Q7	2009-2016	4L	62 LR-Door Electroni.	Clear Fault Codes	
Audi Q7	2009-2016	4L	62 LR-Door Electroni.	Measuring Blocks	
Audi Q7	2009-2016	4L	62 LR-Door Electroni.	Output Tests	
Audi Q7	2009-2016	4L	62 LR-Door Electroni.	Specia Functions	
Audi Q7	2009-2016	4L	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Q7	2009-2016	4L	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Q7	2009-2016	4L	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Q7	2009-2016	4L	65 Tyre Pressure Monitoring	Output Tests	
Audi Q7	2009-2016	4L	65 Tyre Pressure Monitoring	Specia Functions	
Audi Q7	2009-2016	4L	67 Voice Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2009-2016	4L	67 Voice Control	Clear Fault Codes	
Audi Q7	2009-2016	4L	67 Voice Control	Measuring Blocks	
Audi Q7	2009-2016	4L	67 Voice Control	Output Tests	
Audi Q7	2009-2016	4L	67 Voice Control	Specia Functions	
Audi Q7	2009-2016	4L	69 Trailer Function	Read Fault Codes	
Audi Q7	2009-2016	4L	69 Trailer Function	Clear Fault Codes	
Audi Q7	2009-2016	4L	69 Trailer Function	Measuring Blocks	
Audi Q7	2009-2016	4L	69 Trailer Function	Output Tests	
Audi Q7	2009-2016	4L	69 Trailer Function	Specia Functions	
Audi Q7	2009-2016	4L	6C Rear Camera	Read Fault Codes	
Audi Q7	2009-2016	4L	6C Rear Camera	Clear Fault Codes	
Audi Q7	2009-2016	4L	6C Rear Camera	Measuring Blocks	
Audi Q7	2009-2016	4L	6C Rear Camera	Output Tests	
Audi Q7	2009-2016	4L	6C Rear Camera	Specia Functions	
Audi Q7	2009-2016	4L	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi Q7	2009-2016	4L	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q7	2009-2016	4L	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q7	2009-2016	4L	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q7	2009-2016	4L	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q7	2009-2016	4L	6F Confort Central Control Unit II	Read Fault Codes	
Audi Q7	2009-2016	4L	6F Confort Central Control Unit II	Clear Fault Codes	
Audi Q7	2009-2016	4L	6F Confort Central Control Unit II	Measuring Blocks	
Audi Q7	2009-2016	4L	6F Confort Central Control Unit II	Output Tests	
Audi Q7	2009-2016	4L	6F Confort Central Control Unit II	Specia Functions	
Audi Q7	2009-2016	4L	72 RR-Door Electroni.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2009-2016	4L	72 RR-Door Electroni.	Clear Fault Codes	
Audi Q7	2009-2016	4L	72 RR-Door Electroni.	Measuring Blocks	
Audi Q7	2009-2016	4L	72 RR-Door Electroni.	Output Tests	
Audi Q7	2009-2016	4L	72 RR-Door Electroni.	Specia Functions	
Audi Q7	2009-2016	4L	76 Parking Aid	Read Fault Codes	
Audi Q7	2009-2016	4L	76 Parking Aid	Clear Fault Codes	
Audi Q7	2009-2016	4L	76 Parking Aid	Measuring Blocks	
Audi Q7	2009-2016	4L	76 Parking Aid	Output Tests	
Audi Q7	2009-2016	4L	76 Parking Aid	Specia Functions	
Audi Q7	2009-2016	4L	77 Telephone	Read Fault Codes	
Audi Q7	2009-2016	4L	77 Telephone	Clear Fault Codes	
Audi Q7	2009-2016	4L	77 Telephone	Measuring Blocks	
Audi Q7	2009-2016	4L	77 Telephone	Output Tests	
Audi Q7	2009-2016	4L	77 Telephone	Specia Functions	
Audi A6 (USA)	2011-2018	4G	01 Engine Electronics	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	01 Engine Electronics	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	01 Engine Electronics	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	01 Engine Electronics	Output Tests	
Audi A6 (USA)	2011-2018	4G	01 Engine Electronics	Specia Functions	
Audi A6 (USA)	2011-2018	4G	02 Transmission Electronics	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	02 Transmission Electronics	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	02 Transmission Electronics	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	02 Transmission Electronics	Output Tests	
Audi A6 (USA)	2011-2018	4G	02 Transmission Electronics	Specia Functions	
Audi A6 (USA)	2011-2018	4G	03 Brake Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 (USA)	2011-2018	4G	03 Brake Electronics	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	03 Brake Electronics	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	03 Brake Electronics	Output Tests	
Audi A6 (USA)	2011-2018	4G	03 Brake Electronics	Specia Functions	
Audi A6 (USA)	2011-2018	4G	05 Access & Permissi.	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	05 Access & Permissi.	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	05 Access & Permissi.	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	05 Access & Permissi.	Output Tests	
Audi A6 (USA)	2011-2018	4G	05 Access & Permissi.	Specia Functions	
Audi A6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Output Tests	
Audi A6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Specia Functions	
Audi A6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Output Tests	
Audi A6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Specia Functions	
Audi A6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Output Tests	
Audi A6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Specia Functions	
Audi A6 (USA)	2011-2018	4G	0E Media Player Position 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 (USA)	2011-2018	4G	0E Media Player Position 1	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	0E Media Player Position 1	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	0E Media Player Position 1	Output Tests	
Audi A6 (USA)	2011-2018	4G	0E Media Player Position 1	Specia Functions	
Audi A6 (USA)	2011-2018	4G	10 Parking Assist System 2	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	10 Parking Assist System 2	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	10 Parking Assist System 2	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	10 Parking Assist System 2	Output Tests	
Audi A6 (USA)	2011-2018	4G	10 Parking Assist System 2	Specia Functions	
Audi A6 (USA)	2011-2018	4G	13 Distance Control	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	13 Distance Control	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	13 Distance Control	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	13 Distance Control	Output Tests	
Audi A6 (USA)	2011-2018	4G	13 Distance Control	Specia Functions	
Audi A6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Output Tests	
Audi A6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Specia Functions	
Audi A6 (USA)	2011-2018	4G	15 Airbags	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	15 Airbags	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	15 Airbags	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	15 Airbags	Output Tests	
Audi A6 (USA)	2011-2018	4G	15 Airbags	Specia Functions	
Audi A6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Output Tests	
Audi A6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Specia Functions	
Audi A6 (USA)	2011-2018	4G	17 Instrument Cluster	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	17 Instrument Cluster	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	17 Instrument Cluster	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	17 Instrument Cluster	Output Tests	
Audi A6 (USA)	2011-2018	4G	17 Instrument Cluster	Specia Functions	
Audi A6 (USA)	2011-2018	4G	18 Aux Heating	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	18 Aux Heating	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	18 Aux Heating	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	18 Aux Heating	Output Tests	
Audi A6 (USA)	2011-2018	4G	18 Aux Heating	Specia Functions	
Audi A6 (USA)	2011-2018	4G	19 Gateway Data Bus	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	19 Gateway Data Bus	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	19 Gateway Data Bus	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	19 Gateway Data Bus	Output Tests	
Audi A6 (USA)	2011-2018	4G	19 Gateway Data Bus	Specia Functions	
Audi A6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Output Tests	
Audi A6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Specia Functions	
Audi A6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Output Tests	
Audi A6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Specia Functions	
Audi A6 (USA)	2011-2018	4G	22 4WD Electronics	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	22 4WD Electronics	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	22 4WD Electronics	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	22 4WD Electronics	Output Tests	
Audi A6 (USA)	2011-2018	4G	22 4WD Electronics	Specia Functions	
Audi A6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Output Tests	
Audi A6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Specia Functions	
Audi A6 (USA)	2011-2018	4G	30 Special Function 2	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	30 Special Function 2	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	30 Special Function 2	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	30 Special Function 2	Output Tests	
Audi A6 (USA)	2011-2018	4G	30 Special Function 2	Specia Functions	
Audi A6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Output Tests	
Audi A6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Specia Functions	
Audi A6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Output Tests	
Audi A6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6 (USA)	2011-2018	4G	3B Sensor Elect.	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	3B Sensor Elect.	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	3B Sensor Elect.	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	3B Sensor Elect.	Output Tests	
Audi A6 (USA)	2011-2018	4G	3B Sensor Elect.	Specia Functions	
Audi A6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Output Tests	
Audi A6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Specia Functions	
Audi A6 (USA)	2011-2018	4G	3D Special Function	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	3D Special Function	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	3D Special Function	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	3D Special Function	Output Tests	
Audi A6 (USA)	2011-2018	4G	3D Special Function	Specia Functions	
Audi A6 (USA)	2011-2018	4G	40 Air Compressor	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	40 Air Compressor	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	40 Air Compressor	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	40 Air Compressor	Output Tests	
Audi A6 (USA)	2011-2018	4G	40 Air Compressor	Specia Functions	
Audi A6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Output Tests	
Audi A6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Specia Functions	
Audi A6 (USA)	2011-2018	4G	44 Steering Assistance	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	44 Steering Assistance	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	44 Steering Assistance	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	44 Steering Assistance	Output Tests	
Audi A6 (USA)	2011-2018	4G	44 Steering Assistance	Specia Functions	
Audi A6 (USA)	2011-2018	4G	46 Central Control Module	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	46 Central Control Module	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	46 Central Control Module	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	46 Central Control Module	Output Tests	
Audi A6 (USA)	2011-2018	4G	46 Central Control Module	Specia Functions	
Audi A6 (USA)	2011-2018	4G	47 Soundsystem	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	47 Soundsystem	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	47 Soundsystem	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	47 Soundsystem	Output Tests	
Audi A6 (USA)	2011-2018	4G	47 Soundsystem	Specia Functions	
Audi A6 (USA)	2011-2018	4G	4E Control Head RR	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	4E Control Head RR	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	4E Control Head RR	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	4E Control Head RR	Output Tests	
Audi A6 (USA)	2011-2018	4G	4E Control Head RR	Specia Functions	
Audi A6 (USA)	2011-2018	4G	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 (USA)	2011-2018	4G	51 Electric Drive	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	51 Electric Drive	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	51 Electric Drive	Output Tests	
Audi A6 (USA)	2011-2018	4G	51 Electric Drive	Specia Functions	
Audi A6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Output Tests	
Audi A6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Specia Functions	
Audi A6 (USA)	2011-2018	4G	53 Parking Brake	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	53 Parking Brake	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	53 Parking Brake	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	53 Parking Brake	Output Tests	
Audi A6 (USA)	2011-2018	4G	53 Parking Brake	Specia Functions	
Audi A6 (USA)	2011-2018	4G	55 Headlight Range Control	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	55 Headlight Range Control	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	55 Headlight Range Control	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	55 Headlight Range Control	Output Tests	
Audi A6 (USA)	2011-2018	4G	55 Headlight Range Control	Specia Functions	
Audi A6 (USA)	2011-2018	4G	56 Radio	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	56 Radio	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	56 Radio	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	56 Radio	Output Tests	
Audi A6 (USA)	2011-2018	4G	56 Radio	Specia Functions	
Audi A6 (USA)	2011-2018	4G	57 TV-Tuner	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 (USA)	2011-2018	4G	57 TV-Tuner	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	57 TV-Tuner	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	57 TV-Tuner	Output Tests	
Audi A6 (USA)	2011-2018	4G	57 TV-Tuner	Specia Functions	
Audi A6 (USA)	2011-2018	4G	5E Control Head LR	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	5E Control Head LR	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	5E Control Head LR	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	5E Control Head LR	Output Tests	
Audi A6 (USA)	2011-2018	4G	5E Control Head LR	Specia Functions	
Audi A6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Output Tests	
Audi A6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Specia Functions	
Audi A6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Output Tests	
Audi A6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Specia Functions	
Audi A6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Output Tests	
Audi A6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6 (USA)	2011-2018	4G	69 Trailer Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 (USA)	2011-2018	4G	69 Trailer Function	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	69 Trailer Function	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	69 Trailer Function	Output Tests	
Audi A6 (USA)	2011-2018	4G	69 Trailer Function	Specia Functions	
Audi A6 (USA)	2011-2018	4G	6C Rear Camera	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	6C Rear Camera	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	6C Rear Camera	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	6C Rear Camera	Output Tests	
Audi A6 (USA)	2011-2018	4G	6C Rear Camera	Specia Functions	
Audi A6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Output Tests	
Audi A6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Specia Functions	
Audi A6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Output Tests	
Audi A6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Specia Functions	
Audi A6 (USA)	2011-2018	4G	82 Heads Up Display	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 (USA)	2011-2018	4G	82 Heads Up Display	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	82 Heads Up Display	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	82 Heads Up Display	Output Tests	
Audi A6 (USA)	2011-2018	4G	82 Heads Up Display	Specia Functions	
Audi A6 (USA)	2011-2018	4G	84 Night Vision	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	84 Night Vision	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	84 Night Vision	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	84 Night Vision	Output Tests	
Audi A6 (USA)	2011-2018	4G	84 Night Vision	Specia Functions	
Audi A6 (USA)	2011-2018	4G	85 On Board Cam.	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	85 On Board Cam.	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	85 On Board Cam.	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	85 On Board Cam.	Output Tests	
Audi A6 (USA)	2011-2018	4G	85 On Board Cam.	Specia Functions	
Audi A6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Output Tests	
Audi A6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Specia Functions	
Audi A6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Output Tests	
Audi A6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Specia Functions	
Audi A6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Output Tests	
Audi A6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Specia Functions	
Audi A6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Output Tests	
Audi A6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Specia Functions	
Audi A6 (USA)	2011-2018	4G	8C Hybrid Battery	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	8C Hybrid Battery	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	8C Hybrid Battery	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	8C Hybrid Battery	Output Tests	
Audi A6 (USA)	2011-2018	4G	8C Hybrid Battery	Specia Functions	
Audi A6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Output Tests	
Audi A6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Specia Functions	
Audi A6 (USA)	2011-2018	4G	8E Image Processing	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	8E Image Processing	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	8E Image Processing	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	8E Image Processing	Output Tests	
Audi A6 (USA)	2011-2018	4G	8E Image Processing	Specia Functions	
Audi A6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Output Tests	
Audi A6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Specia Functions	
Audi A6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Output Tests	
Audi A6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Specia Functions	
Audi A6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Output Tests	
Audi A6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Specia Functions	
Audi A6 (USA)	2011-2018	4G	AC Reductant Control	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	AC Reductant Control	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	AC Reductant Control	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	AC Reductant Control	Output Tests	
Audi A6 (USA)	2011-2018	4G	AC Reductant Control	Specia Functions	
Audi A6 (USA)	2011-2018	4G	BA Motor Mounts	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	BA Motor Mounts	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	BA Motor Mounts	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	BA Motor Mounts	Output Tests	
Audi A6 (USA)	2011-2018	4G	BA Motor Mounts	Specia Functions	
Audi A6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Output Tests	
Audi A6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Specia Functions	
Audi A6 (USA)	2011-2018	4G	C6 Batt. Chrg	Read Fault Codes	
Audi A6 (USA)	2011-2018	4G	C6 Batt. Chrg	Clear Fault Codes	
Audi A6 (USA)	2011-2018	4G	C6 Batt. Chrg	Measuring Blocks	
Audi A6 (USA)	2011-2018	4G	C6 Batt. Chrg	Output Tests	
Audi A6 (USA)	2011-2018	4G	C6 Batt. Chrg	Specia Functions	
Audi S6 (USA)	2011-2018	4G	01 Engine Electronics	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	01 Engine Electronics	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	01 Engine Electronics	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	01 Engine Electronics	Output Tests	
Audi S6 (USA)	2011-2018	4G	01 Engine Electronics	Specia Functions	
Audi S6 (USA)	2011-2018	4G	02 Transmission Electronics	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	02 Transmission Electronics	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	02 Transmission Electronics	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	02 Transmission Electronics	Output Tests	
Audi S6 (USA)	2011-2018	4G	02 Transmission Electronics	Specia Functions	
Audi S6 (USA)	2011-2018	4G	03 Brake Electronics	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	03 Brake Electronics	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	03 Brake Electronics	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	03 Brake Electronics	Output Tests	
Audi S6 (USA)	2011-2018	4G	03 Brake Electronics	Specia Functions	
Audi S6 (USA)	2011-2018	4G	05 Access & Permissi.	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi S6 (USA)	2011-2018	4G	05 Access & Permissi.	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	05 Access & Permissi.	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	05 Access & Permissi.	Output Tests	
Audi S6 (USA)	2011-2018	4G	05 Access & Permissi.	Specia Functions	
Audi S6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Output Tests	
Audi S6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Specia Functions	
Audi S6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Output Tests	
Audi S6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Specia Functions	
Audi S6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Output Tests	
Audi S6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Specia Functions	
Audi S6 (USA)	2011-2018	4G	0E Media Player Position 1	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	0E Media Player Position 1	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	0E Media Player Position 1	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	0E Media Player Position 1	Output Tests	
Audi S6 (USA)	2011-2018	4G	0E Media Player Position 1	Specia Functions	
Audi S6 (USA)	2011-2018	4G	10 Parking Assist System 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	10 Parking Assist System 2	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	10 Parking Assist System 2	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	10 Parking Assist System 2	Output Tests	
Audi S6 (USA)	2011-2018	4G	10 Parking Assist System 2	Specia Functions	
Audi S6 (USA)	2011-2018	4G	13 Distance Control	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	13 Distance Control	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	13 Distance Control	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	13 Distance Control	Output Tests	
Audi S6 (USA)	2011-2018	4G	13 Distance Control	Specia Functions	
Audi S6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Output Tests	
Audi S6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Specia Functions	
Audi S6 (USA)	2011-2018	4G	15 Airbags	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	15 Airbags	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	15 Airbags	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	15 Airbags	Output Tests	
Audi S6 (USA)	2011-2018	4G	15 Airbags	Specia Functions	
Audi S6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Output Tests	
Audi S6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Specia Functions	
Audi S6 (USA)	2011-2018	4G	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	17 Instrument Cluster	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	17 Instrument Cluster	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	17 Instrument Cluster	Output Tests	
Audi S6 (USA)	2011-2018	4G	17 Instrument Cluster	Specia Functions	
Audi S6 (USA)	2011-2018	4G	18 Aux Heating	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	18 Aux Heating	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	18 Aux Heating	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	18 Aux Heating	Output Tests	
Audi S6 (USA)	2011-2018	4G	18 Aux Heating	Specia Functions	
Audi S6 (USA)	2011-2018	4G	19 Gateway Data Bus	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	19 Gateway Data Bus	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	19 Gateway Data Bus	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	19 Gateway Data Bus	Output Tests	
Audi S6 (USA)	2011-2018	4G	19 Gateway Data Bus	Specia Functions	
Audi S6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Output Tests	
Audi S6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Specia Functions	
Audi S6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Output Tests	
Audi S6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Specia Functions	
Audi S6 (USA)	2011-2018	4G	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	22 4WD Electronics	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	22 4WD Electronics	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	22 4WD Electronics	Output Tests	
Audi S6 (USA)	2011-2018	4G	22 4WD Electronics	Specia Functions	
Audi S6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Output Tests	
Audi S6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Specia Functions	
Audi S6 (USA)	2011-2018	4G	30 Special Function 2	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	30 Special Function 2	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	30 Special Function 2	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	30 Special Function 2	Output Tests	
Audi S6 (USA)	2011-2018	4G	30 Special Function 2	Specia Functions	
Audi S6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Output Tests	
Audi S6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Specia Functions	
Audi S6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Output Tests	
Audi S6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Specia Functions	
Audi S6 (USA)	2011-2018	4G	3B Sensor Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	3B Sensor Elect.	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	3B Sensor Elect.	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	3B Sensor Elect.	Output Tests	
Audi S6 (USA)	2011-2018	4G	3B Sensor Elect.	Specia Functions	
Audi S6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Output Tests	
Audi S6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Specia Functions	
Audi S6 (USA)	2011-2018	4G	3D Special Function	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	3D Special Function	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	3D Special Function	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	3D Special Function	Output Tests	
Audi S6 (USA)	2011-2018	4G	3D Special Function	Specia Functions	
Audi S6 (USA)	2011-2018	4G	40 Air Compressor	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	40 Air Compressor	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	40 Air Compressor	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	40 Air Compressor	Output Tests	
Audi S6 (USA)	2011-2018	4G	40 Air Compressor	Specia Functions	
Audi S6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Output Tests	
Audi S6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Specia Functions	
Audi S6 (USA)	2011-2018	4G	44 Steering Assistance	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	44 Steering Assistance	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	44 Steering Assistance	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	44 Steering Assistance	Output Tests	
Audi S6 (USA)	2011-2018	4G	44 Steering Assistance	Specia Functions	
Audi S6 (USA)	2011-2018	4G	46 Central Control Module	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	46 Central Control Module	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	46 Central Control Module	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	46 Central Control Module	Output Tests	
Audi S6 (USA)	2011-2018	4G	46 Central Control Module	Specia Functions	
Audi S6 (USA)	2011-2018	4G	47 Soundsystem	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	47 Soundsystem	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	47 Soundsystem	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	47 Soundsystem	Output Tests	
Audi S6 (USA)	2011-2018	4G	47 Soundsystem	Specia Functions	
Audi S6 (USA)	2011-2018	4G	4E Control Head RR	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	4E Control Head RR	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	4E Control Head RR	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	4E Control Head RR	Output Tests	
Audi S6 (USA)	2011-2018	4G	4E Control Head RR	Specia Functions	
Audi S6 (USA)	2011-2018	4G	51 Electric Drive	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	51 Electric Drive	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	51 Electric Drive	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	51 Electric Drive	Output Tests	
Audi S6 (USA)	2011-2018	4G	51 Electric Drive	Specia Functions	
Audi S6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Output Tests	
Audi S6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Specia Functions	
Audi S6 (USA)	2011-2018	4G	53 Parking Brake	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	53 Parking Brake	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	53 Parking Brake	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	53 Parking Brake	Output Tests	
Audi S6 (USA)	2011-2018	4G	53 Parking Brake	Specia Functions	
Audi S6 (USA)	2011-2018	4G	55 Headlight Range Control	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	55 Headlight Range Control	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	55 Headlight Range Control	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	55 Headlight Range Control	Output Tests	
Audi S6 (USA)	2011-2018	4G	55 Headlight Range Control	Specia Functions	
Audi S6 (USA)	2011-2018	4G	56 Radio	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	56 Radio	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	56 Radio	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	56 Radio	Output Tests	
Audi S6 (USA)	2011-2018	4G	56 Radio	Specia Functions	
Audi S6 (USA)	2011-2018	4G	57 TV-Tuner	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	57 TV-Tuner	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	57 TV-Tuner	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	57 TV-Tuner	Output Tests	
Audi S6 (USA)	2011-2018	4G	57 TV-Tuner	Specia Functions	
Audi S6 (USA)	2011-2018	4G	5E Control Head LR	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	5E Control Head LR	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	5E Control Head LR	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	5E Control Head LR	Output Tests	
Audi S6 (USA)	2011-2018	4G	5E Control Head LR	Specia Functions	
Audi S6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Output Tests	
Audi S6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Specia Functions	
Audi S6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Output Tests	
Audi S6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Specia Functions	
Audi S6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Output Tests	
Audi S6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Specia Functions	
Audi S6 (USA)	2011-2018	4G	69 Trailer Function	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	69 Trailer Function	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	69 Trailer Function	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	69 Trailer Function	Output Tests	
Audi S6 (USA)	2011-2018	4G	69 Trailer Function	Specia Functions	
Audi S6 (USA)	2011-2018	4G	6C Rear Camera	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	6C Rear Camera	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	6C Rear Camera	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	6C Rear Camera	Output Tests	
Audi S6 (USA)	2011-2018	4G	6C Rear Camera	Specia Functions	
Audi S6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Output Tests	
Audi S6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Specia Functions	
Audi S6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Output Tests	
Audi S6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Specia Functions	
Audi S6 (USA)	2011-2018	4G	82 Heads Up Display	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	82 Heads Up Display	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	82 Heads Up Display	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	82 Heads Up Display	Output Tests	
Audi S6 (USA)	2011-2018	4G	82 Heads Up Display	Specia Functions	
Audi S6 (USA)	2011-2018	4G	84 Night Vision	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	84 Night Vision	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	84 Night Vision	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	84 Night Vision	Output Tests	
Audi S6 (USA)	2011-2018	4G	84 Night Vision	Specia Functions	
Audi S6 (USA)	2011-2018	4G	85 On Board Cam.	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	85 On Board Cam.	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	85 On Board Cam.	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	85 On Board Cam.	Output Tests	
Audi S6 (USA)	2011-2018	4G	85 On Board Cam.	Specia Functions	
Audi S6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Output Tests	
Audi S6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Specia Functions	
Audi S6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Output Tests	
Audi S6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Specia Functions	
Audi S6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Output Tests	
Audi S6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Specia Functions	
Audi S6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Output Tests	
Audi S6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Specia Functions	
Audi S6 (USA)	2011-2018	4G	8C Hybrid Battery	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	8C Hybrid Battery	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	8C Hybrid Battery	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	8C Hybrid Battery	Output Tests	
Audi S6 (USA)	2011-2018	4G	8C Hybrid Battery	Specia Functions	
Audi S6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Output Tests	
Audi S6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Specia Functions	
Audi S6 (USA)	2011-2018	4G	8E Image Processing	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	8E Image Processing	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	8E Image Processing	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	8E Image Processing	Output Tests	
Audi S6 (USA)	2011-2018	4G	8E Image Processing	Specia Functions	
Audi S6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Output Tests	
Audi S6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Specia Functions	
Audi S6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Output Tests	
Audi S6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Specia Functions	
Audi S6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Output Tests	
Audi S6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Specia Functions	
Audi S6 (USA)	2011-2018	4G	AC Reductant Control	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	AC Reductant Control	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	AC Reductant Control	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	AC Reductant Control	Output Tests	
Audi S6 (USA)	2011-2018	4G	AC Reductant Control	Specia Functions	
Audi S6 (USA)	2011-2018	4G	BA Motor Mounts	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	BA Motor Mounts	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	BA Motor Mounts	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	BA Motor Mounts	Output Tests	
Audi S6 (USA)	2011-2018	4G	BA Motor Mounts	Specia Functions	
Audi S6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Read Fault Codes	
Audi S6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Output Tests	
Audi S6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Specia Functions	
Audi S6 (USA)	2011-2018	4G	C6 Batt. Chrg	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S6 (USA)	2011-2018	4G	C6 Batt. Chrg	Clear Fault Codes	
Audi S6 (USA)	2011-2018	4G	C6 Batt. Chrg	Measuring Blocks	
Audi S6 (USA)	2011-2018	4G	C6 Batt. Chrg	Output Tests	
Audi S6 (USA)	2011-2018	4G	C6 Batt. Chrg	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	01 Engine Electronics	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	01 Engine Electronics	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	01 Engine Electronics	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	01 Engine Electronics	Output Tests	
Audi RS6 (USA)	2011-2018	4G	01 Engine Electronics	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	02 Transmission Electronics	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	02 Transmission Electronics	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	02 Transmission Electronics	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	02 Transmission Electronics	Output Tests	
Audi RS6 (USA)	2011-2018	4G	02 Transmission Electronics	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	03 Brake Electronics	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	03 Brake Electronics	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	03 Brake Electronics	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	03 Brake Electronics	Output Tests	
Audi RS6 (USA)	2011-2018	4G	03 Brake Electronics	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	05 Access & Permissi.	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	05 Access & Permissi.	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	05 Access & Permissi.	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	05 Access & Permissi.	Output Tests	
Audi RS6 (USA)	2011-2018	4G	05 Access & Permissi.	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Output Tests	
Audi RS6 (USA)	2011-2018	4G	06 Passene. Seat Adj.	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Output Tests	
Audi RS6 (USA)	2011-2018	4G	08 AC/Heating Electronics	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Output Tests	
Audi RS6 (USA)	2011-2018	4G	09 Electronic Ctrl Electronics	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	0E Media Player Position 1	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	0E Media Player Position 1	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	0E Media Player Position 1	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	0E Media Player Position 1	Output Tests	
Audi RS6 (USA)	2011-2018	4G	0E Media Player Position 1	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	10 Parking Assist System 2	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	10 Parking Assist System 2	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	10 Parking Assist System 2	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	10 Parking Assist System 2	Output Tests	
Audi RS6 (USA)	2011-2018	4G	10 Parking Assist System 2	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	13 Distance Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6 (USA)	2011-2018	4G	13 Distance Control	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	13 Distance Control	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	13 Distance Control	Output Tests	
Audi RS6 (USA)	2011-2018	4G	13 Distance Control	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Output Tests	
Audi RS6 (USA)	2011-2018	4G	14 Wheel Damping Electronics	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	15 Airbags	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	15 Airbags	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	15 Airbags	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	15 Airbags	Output Tests	
Audi RS6 (USA)	2011-2018	4G	15 Airbags	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Output Tests	
Audi RS6 (USA)	2011-2018	4G	16 Steering Wheel Electronics	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	17 Instrument Cluster	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	17 Instrument Cluster	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	17 Instrument Cluster	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	17 Instrument Cluster	Output Tests	
Audi RS6 (USA)	2011-2018	4G	17 Instrument Cluster	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6 (USA)	2011-2018	4G	18 Aux Heating	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	18 Aux Heating	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	18 Aux Heating	Output Tests	
Audi RS6 (USA)	2011-2018	4G	18 Aux Heating	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	19 Gateway Data Bus	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	19 Gateway Data Bus	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	19 Gateway Data Bus	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	19 Gateway Data Bus	Output Tests	
Audi RS6 (USA)	2011-2018	4G	19 Gateway Data Bus	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Output Tests	
Audi RS6 (USA)	2011-2018	4G	1B Power-Assisted Steering	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Output Tests	
Audi RS6 (USA)	2011-2018	4G	20 High Beam Assistance Device	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	22 4WD Electronics	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	22 4WD Electronics	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	22 4WD Electronics	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	22 4WD Electronics	Output Tests	
Audi RS6 (USA)	2011-2018	4G	22 4WD Electronics	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Output Tests	
Audi RS6 (USA)	2011-2018	4G	28 Climate Control Unit Rear	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	30 Special Function 2	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	30 Special Function 2	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	30 Special Function 2	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	30 Special Function 2	Output Tests	
Audi RS6 (USA)	2011-2018	4G	30 Special Function 2	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Output Tests	
Audi RS6 (USA)	2011-2018	4G	34 Self Leveling Suspension	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Output Tests	
Audi RS6 (USA)	2011-2018	4G	36 Side of Driver Seat Adj.	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	3B Sensor Elect.	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	3B Sensor Elect.	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	3B Sensor Elect.	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	3B Sensor Elect.	Output Tests	
Audi RS6 (USA)	2011-2018	4G	3B Sensor Elect.	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Output Tests	
Audi RS6 (USA)	2011-2018	4G	3C Lane Departure Assistance System	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	3D Special Function	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	3D Special Function	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	3D Special Function	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	3D Special Function	Output Tests	
Audi RS6 (USA)	2011-2018	4G	3D Special Function	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	40 Air Compressor	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	40 Air Compressor	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	40 Air Compressor	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	40 Air Compressor	Output Tests	
Audi RS6 (USA)	2011-2018	4G	40 Air Compressor	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Output Tests	
Audi RS6 (USA)	2011-2018	4G	42 Driver-Door Elect.	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	44 Steering Assistance	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	44 Steering Assistance	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	44 Steering Assistance	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	44 Steering Assistance	Output Tests	
Audi RS6 (USA)	2011-2018	4G	44 Steering Assistance	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	46 Central Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6 (USA)	2011-2018	4G	46 Central Control Module	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	46 Central Control Module	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	46 Central Control Module	Output Tests	
Audi RS6 (USA)	2011-2018	4G	46 Central Control Module	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	47 Soundsystem	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	47 Soundsystem	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	47 Soundsystem	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	47 Soundsystem	Output Tests	
Audi RS6 (USA)	2011-2018	4G	47 Soundsystem	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	4E Control Head RR	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	4E Control Head RR	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	4E Control Head RR	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	4E Control Head RR	Output Tests	
Audi RS6 (USA)	2011-2018	4G	4E Control Head RR	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	51 Electric Drive	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	51 Electric Drive	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	51 Electric Drive	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	51 Electric Drive	Output Tests	
Audi RS6 (USA)	2011-2018	4G	51 Electric Drive	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Output Tests	
Audi RS6 (USA)	2011-2018	4G	52 Passe.-Door Elect.	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	53 Parking Brake	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6 (USA)	2011-2018	4G	53 Parking Brake	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	53 Parking Brake	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	53 Parking Brake	Output Tests	
Audi RS6 (USA)	2011-2018	4G	53 Parking Brake	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	55 Headlight Range Control	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	55 Headlight Range Control	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	55 Headlight Range Control	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	55 Headlight Range Control	Output Tests	
Audi RS6 (USA)	2011-2018	4G	55 Headlight Range Control	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	56 Radio	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	56 Radio	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	56 Radio	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	56 Radio	Output Tests	
Audi RS6 (USA)	2011-2018	4G	56 Radio	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	57 TV-Tuner	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	57 TV-Tuner	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	57 TV-Tuner	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	57 TV-Tuner	Output Tests	
Audi RS6 (USA)	2011-2018	4G	57 TV-Tuner	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	5E Control Head LR	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	5E Control Head LR	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	5E Control Head LR	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	5E Control Head LR	Output Tests	
Audi RS6 (USA)	2011-2018	4G	5E Control Head LR	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Output Tests	
Audi RS6 (USA)	2011-2018	4G	5F Information Electronic Equipment 1	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Output Tests	
Audi RS6 (USA)	2011-2018	4G	62 LR-Door Electroni.	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Output Tests	
Audi RS6 (USA)	2011-2018	4G	65 Tyre Pressure Monitoring	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	69 Trailer Function	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	69 Trailer Function	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	69 Trailer Function	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	69 Trailer Function	Output Tests	
Audi RS6 (USA)	2011-2018	4G	69 Trailer Function	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	6C Rear Camera	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	6C Rear Camera	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	6C Rear Camera	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	6C Rear Camera	Output Tests	
Audi RS6 (USA)	2011-2018	4G	6C Rear Camera	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi RS6 (USA)	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Output Tests	
Audi RS6 (USA)	2011-2018	4G	72 RR-Door Electroni.	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Output Tests	
Audi RS6 (USA)	2011-2018	4G	7F Information Electronic Equipment 2	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	82 Heads Up Display	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	82 Heads Up Display	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	82 Heads Up Display	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	82 Heads Up Display	Output Tests	
Audi RS6 (USA)	2011-2018	4G	82 Heads Up Display	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	84 Night Vision	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	84 Night Vision	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	84 Night Vision	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	84 Night Vision	Output Tests	
Audi RS6 (USA)	2011-2018	4G	84 Night Vision	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	85 On Board Cam.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6 (USA)	2011-2018	4G	85 On Board Cam.	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	85 On Board Cam.	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	85 On Board Cam.	Output Tests	
Audi RS6 (USA)	2011-2018	4G	85 On Board Cam.	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Output Tests	
Audi RS6 (USA)	2011-2018	4G	88 Multicont. Seat Driver	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Output Tests	
Audi RS6 (USA)	2011-2018	4G	89 Multicont. Seat Driver	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Output Tests	
Audi RS6 (USA)	2011-2018	4G	8A Multicont. Seat Rear, DS	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Output Tests	
Audi RS6 (USA)	2011-2018	4G	8B Adaptive Cruise 2	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	8C Hybrid Battery	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS6 (USA)	2011-2018	4G	8C Hybrid Battery	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8C Hybrid Battery	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	8C Hybrid Battery	Output Tests	
Audi RS6 (USA)	2011-2018	4G	8C Hybrid Battery	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Output Tests	
Audi RS6 (USA)	2011-2018	4G	8D Multicont.Seat Rear,PS	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	8E Image Processing	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8E Image Processing	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8E Image Processing	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	8E Image Processing	Output Tests	
Audi RS6 (USA)	2011-2018	4G	8E Image Processing	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Output Tests	
Audi RS6 (USA)	2011-2018	4G	8F Pretens. Frt Left	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Output Tests	
Audi RS6 (USA)	2011-2018	4G	90 Pretens. Frt Right	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Output Tests	
Audi RS6 (USA)	2011-2018	4G	A9 Struct.Borne Sound	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	AC Reductant Control	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	AC Reductant Control	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	AC Reductant Control	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	AC Reductant Control	Output Tests	
Audi RS6 (USA)	2011-2018	4G	AC Reductant Control	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	BA Motor Mounts	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	BA Motor Mounts	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	BA Motor Mounts	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	BA Motor Mounts	Output Tests	
Audi RS6 (USA)	2011-2018	4G	BA Motor Mounts	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Output Tests	
Audi RS6 (USA)	2011-2018	4G	C0 Act. For Ext. Noise	Specia Functions	
Audi RS6 (USA)	2011-2018	4G	C6 Batt. Chrg	Read Fault Codes	
Audi RS6 (USA)	2011-2018	4G	C6 Batt. Chrg	Clear Fault Codes	
Audi RS6 (USA)	2011-2018	4G	C6 Batt. Chrg	Measuring Blocks	
Audi RS6 (USA)	2011-2018	4G	C6 Batt. Chrg	Output Tests	
Audi RS6 (USA)	2011-2018	4G	C6 Batt. Chrg	Specia Functions	
Audi A7 (USA)	2011-2018	FC	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 (USA)	2011-2018	FC	01 Engine Electronics	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	01 Engine Electronics	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	01 Engine Electronics	Output Tests	
Audi A7 (USA)	2011-2018	FC	01 Engine Electronics	Specia Functions	
Audi A7 (USA)	2011-2018	FC	02 Transmission Electronics	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	02 Transmission Electronics	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	02 Transmission Electronics	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	02 Transmission Electronics	Output Tests	
Audi A7 (USA)	2011-2018	FC	02 Transmission Electronics	Specia Functions	
Audi A7 (USA)	2011-2018	FC	03 Brake Electronics	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	03 Brake Electronics	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	03 Brake Electronics	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	03 Brake Electronics	Output Tests	
Audi A7 (USA)	2011-2018	FC	03 Brake Electronics	Specia Functions	
Audi A7 (USA)	2011-2018	FC	05 Access & Permissi.	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	05 Access & Permissi.	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	05 Access & Permissi.	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	05 Access & Permissi.	Output Tests	
Audi A7 (USA)	2011-2018	FC	05 Access & Permissi.	Specia Functions	
Audi A7 (USA)	2011-2018	FC	06 Passene. Seat Adj.	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	06 Passene. Seat Adj.	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	06 Passene. Seat Adj.	Output Tests	
Audi A7 (USA)	2011-2018	FC	06 Passene. Seat Adj.	Specia Functions	
Audi A7 (USA)	2011-2018	FC	08 AC/Heating Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7 (USA)	2011-2018	FC	08 AC/Heating Electronics	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	08 AC/Heating Electronics	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	08 AC/Heating Electronics	Output Tests	
Audi A7 (USA)	2011-2018	FC	08 AC/Heating Electronics	Specia Functions	
Audi A7 (USA)	2011-2018	FC	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	09 Electronic Ctrl Electronics	Output Tests	
Audi A7 (USA)	2011-2018	FC	09 Electronic Ctrl Electronics	Specia Functions	
Audi A7 (USA)	2011-2018	FC	0E Media Player Position 1	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	0E Media Player Position 1	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	0E Media Player Position 1	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	0E Media Player Position 1	Output Tests	
Audi A7 (USA)	2011-2018	FC	0E Media Player Position 1	Specia Functions	
Audi A7 (USA)	2011-2018	FC	10 Parking Assist System 2	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	10 Parking Assist System 2	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	10 Parking Assist System 2	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	10 Parking Assist System 2	Output Tests	
Audi A7 (USA)	2011-2018	FC	10 Parking Assist System 2	Specia Functions	
Audi A7 (USA)	2011-2018	FC	13 Distance Control	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	13 Distance Control	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	13 Distance Control	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	13 Distance Control	Output Tests	
Audi A7 (USA)	2011-2018	FC	13 Distance Control	Specia Functions	
Audi A7 (USA)	2011-2018	FC	14 Wheel Damping Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 (USA)	2011-2018	FC	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	14 Wheel Damping Electronics	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	14 Wheel Damping Electronics	Output Tests	
Audi A7 (USA)	2011-2018	FC	14 Wheel Damping Electronics	Specia Functions	
Audi A7 (USA)	2011-2018	FC	15 Airbags	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	15 Airbags	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	15 Airbags	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	15 Airbags	Output Tests	
Audi A7 (USA)	2011-2018	FC	15 Airbags	Specia Functions	
Audi A7 (USA)	2011-2018	FC	16 Steering Wheel Electronics	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	16 Steering Wheel Electronics	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	16 Steering Wheel Electronics	Output Tests	
Audi A7 (USA)	2011-2018	FC	16 Steering Wheel Electronics	Specia Functions	
Audi A7 (USA)	2011-2018	FC	17 Instrument Cluster	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	17 Instrument Cluster	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	17 Instrument Cluster	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	17 Instrument Cluster	Output Tests	
Audi A7 (USA)	2011-2018	FC	17 Instrument Cluster	Specia Functions	
Audi A7 (USA)	2011-2018	FC	18 Aux Heating	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	18 Aux Heating	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	18 Aux Heating	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	18 Aux Heating	Output Tests	
Audi A7 (USA)	2011-2018	FC	18 Aux Heating	Specia Functions	
Audi A7 (USA)	2011-2018	FC	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 (USA)	2011-2018	FC	19 Gateway Data Bus	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	19 Gateway Data Bus	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	19 Gateway Data Bus	Output Tests	
Audi A7 (USA)	2011-2018	FC	19 Gateway Data Bus	Specia Functions	
Audi A7 (USA)	2011-2018	FC	1B Power-Assisted Steering	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	1B Power-Assisted Steering	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	1B Power-Assisted Steering	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	1B Power-Assisted Steering	Output Tests	
Audi A7 (USA)	2011-2018	FC	1B Power-Assisted Steering	Specia Functions	
Audi A7 (USA)	2011-2018	FC	20 High Beam Assistance Device	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	20 High Beam Assistance Device	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	20 High Beam Assistance Device	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	20 High Beam Assistance Device	Output Tests	
Audi A7 (USA)	2011-2018	FC	20 High Beam Assistance Device	Specia Functions	
Audi A7 (USA)	2011-2018	FC	22 4WD Electronics	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	22 4WD Electronics	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	22 4WD Electronics	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	22 4WD Electronics	Output Tests	
Audi A7 (USA)	2011-2018	FC	22 4WD Electronics	Specia Functions	
Audi A7 (USA)	2011-2018	FC	28 Climate Control Unit Rear	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	28 Climate Control Unit Rear	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	28 Climate Control Unit Rear	Output Tests	
Audi A7 (USA)	2011-2018	FC	28 Climate Control Unit Rear	Specia Functions	
Audi A7 (USA)	2011-2018	FC	30 Special Function 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7 (USA)	2011-2018	FC	30 Special Function 2	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	30 Special Function 2	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	30 Special Function 2	Output Tests	
Audi A7 (USA)	2011-2018	FC	30 Special Function 2	Specia Functions	
Audi A7 (USA)	2011-2018	FC	34 Self Leveling Suspension	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	34 Self Leveling Suspension	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	34 Self Leveling Suspension	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	34 Self Leveling Suspension	Output Tests	
Audi A7 (USA)	2011-2018	FC	34 Self Leveling Suspension	Specia Functions	
Audi A7 (USA)	2011-2018	FC	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	36 Side of Driver Seat Adj.	Output Tests	
Audi A7 (USA)	2011-2018	FC	36 Side of Driver Seat Adj.	Specia Functions	
Audi A7 (USA)	2011-2018	FC	3B Sensor Elect.	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	3B Sensor Elect.	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	3B Sensor Elect.	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	3B Sensor Elect.	Output Tests	
Audi A7 (USA)	2011-2018	FC	3B Sensor Elect.	Specia Functions	
Audi A7 (USA)	2011-2018	FC	3C Lane Departure Assistance System	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	3C Lane Departure Assistance System	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	3C Lane Departure Assistance System	Output Tests	
Audi A7 (USA)	2011-2018	FC	3C Lane Departure Assistance System	Specia Functions	
Audi A7 (USA)	2011-2018	FC	3D Special Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 (USA)	2011-2018	FC	3D Special Function	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	3D Special Function	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	3D Special Function	Output Tests	
Audi A7 (USA)	2011-2018	FC	3D Special Function	Specia Functions	
Audi A7 (USA)	2011-2018	FC	40 Air Compressor	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	40 Air Compressor	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	40 Air Compressor	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	40 Air Compressor	Output Tests	
Audi A7 (USA)	2011-2018	FC	40 Air Compressor	Specia Functions	
Audi A7 (USA)	2011-2018	FC	42 Driver-Door Elect.	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	42 Driver-Door Elect.	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	42 Driver-Door Elect.	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	42 Driver-Door Elect.	Output Tests	
Audi A7 (USA)	2011-2018	FC	42 Driver-Door Elect.	Specia Functions	
Audi A7 (USA)	2011-2018	FC	44 Steering Assistance	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	44 Steering Assistance	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	44 Steering Assistance	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	44 Steering Assistance	Output Tests	
Audi A7 (USA)	2011-2018	FC	44 Steering Assistance	Specia Functions	
Audi A7 (USA)	2011-2018	FC	46 Central Control Module	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	46 Central Control Module	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	46 Central Control Module	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	46 Central Control Module	Output Tests	
Audi A7 (USA)	2011-2018	FC	46 Central Control Module	Specia Functions	
Audi A7 (USA)	2011-2018	FC	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 (USA)	2011-2018	FC	47 Soundsystem	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	47 Soundsystem	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	47 Soundsystem	Output Tests	
Audi A7 (USA)	2011-2018	FC	47 Soundsystem	Specia Functions	
Audi A7 (USA)	2011-2018	FC	4E Control Head RR	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	4E Control Head RR	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	4E Control Head RR	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	4E Control Head RR	Output Tests	
Audi A7 (USA)	2011-2018	FC	4E Control Head RR	Specia Functions	
Audi A7 (USA)	2011-2018	FC	51 Electric Drive	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	51 Electric Drive	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	51 Electric Drive	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	51 Electric Drive	Output Tests	
Audi A7 (USA)	2011-2018	FC	51 Electric Drive	Specia Functions	
Audi A7 (USA)	2011-2018	FC	52 Passe.-Door Elect.	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	52 Passe.-Door Elect.	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	52 Passe.-Door Elect.	Output Tests	
Audi A7 (USA)	2011-2018	FC	52 Passe.-Door Elect.	Specia Functions	
Audi A7 (USA)	2011-2018	FC	53 Parking Brake	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	53 Parking Brake	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	53 Parking Brake	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	53 Parking Brake	Output Tests	
Audi A7 (USA)	2011-2018	FC	53 Parking Brake	Specia Functions	
Audi A7 (USA)	2011-2018	FC	55 Headlight Range Control	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi A7 (USA)	2011-2018	FC	55 Headlight Range Control	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	55 Headlight Range Control	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	55 Headlight Range Control	Output Tests	
Audi A7 (USA)	2011-2018	FC	55 Headlight Range Control	Specia Functions	
Audi A7 (USA)	2011-2018	FC	56 Radio	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	56 Radio	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	56 Radio	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	56 Radio	Output Tests	
Audi A7 (USA)	2011-2018	FC	56 Radio	Specia Functions	
Audi A7 (USA)	2011-2018	FC	57 TV-Tuner	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	57 TV-Tuner	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	57 TV-Tuner	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	57 TV-Tuner	Output Tests	
Audi A7 (USA)	2011-2018	FC	57 TV-Tuner	Specia Functions	
Audi A7 (USA)	2011-2018	FC	5E Control Head LR	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	5E Control Head LR	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	5E Control Head LR	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	5E Control Head LR	Output Tests	
Audi A7 (USA)	2011-2018	FC	5E Control Head LR	Specia Functions	
Audi A7 (USA)	2011-2018	FC	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	5F Information Electronic Equipment 1	Output Tests	
Audi A7 (USA)	2011-2018	FC	5F Information Electronic Equipment 1	Specia Functions	
Audi A7 (USA)	2011-2018	FC	62 LR-Door Electroni.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7 (USA)	2011-2018	FC	62 LR-Door Electroni.	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	62 LR-Door Electroni.	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	62 LR-Door Electroni.	Output Tests	
Audi A7 (USA)	2011-2018	FC	62 LR-Door Electroni.	Specia Functions	
Audi A7 (USA)	2011-2018	FC	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	65 Tyre Pressure Monitoring	Output Tests	
Audi A7 (USA)	2011-2018	FC	65 Tyre Pressure Monitoring	Specia Functions	
Audi A7 (USA)	2011-2018	FC	69 Trailer Function	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	69 Trailer Function	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	69 Trailer Function	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	69 Trailer Function	Output Tests	
Audi A7 (USA)	2011-2018	FC	69 Trailer Function	Specia Functions	
Audi A7 (USA)	2011-2018	FC	6C Rear Camera	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	6C Rear Camera	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	6C Rear Camera	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	6C Rear Camera	Output Tests	
Audi A7 (USA)	2011-2018	FC	6C Rear Camera	Specia Functions	
Audi A7 (USA)	2011-2018	FC	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A7 (USA)	2011-2018	FC	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A7 (USA)	2011-2018	FC	72 RR-Door Electroni.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7 (USA)	2011-2018	FC	72 RR-Door Electroni.	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	72 RR-Door Electroni.	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	72 RR-Door Electroni.	Output Tests	
Audi A7 (USA)	2011-2018	FC	72 RR-Door Electroni.	Specia Functions	
Audi A7 (USA)	2011-2018	FC	7F Information Electronic Equipment 2	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	7F Information Electronic Equipment 2	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	7F Information Electronic Equipment 2	Output Tests	
Audi A7 (USA)	2011-2018	FC	7F Information Electronic Equipment 2	Specia Functions	
Audi A7 (USA)	2011-2018	FC	82 Heads Up Display	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	82 Heads Up Display	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	82 Heads Up Display	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	82 Heads Up Display	Output Tests	
Audi A7 (USA)	2011-2018	FC	82 Heads Up Display	Specia Functions	
Audi A7 (USA)	2011-2018	FC	84 Night Vision	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	84 Night Vision	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	84 Night Vision	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	84 Night Vision	Output Tests	
Audi A7 (USA)	2011-2018	FC	84 Night Vision	Specia Functions	
Audi A7 (USA)	2011-2018	FC	85 On Board Cam.	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	85 On Board Cam.	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	85 On Board Cam.	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	85 On Board Cam.	Output Tests	
Audi A7 (USA)	2011-2018	FC	85 On Board Cam.	Specia Functions	
Audi A7 (USA)	2011-2018	FC	88 Multicont. Seat Driver	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7 (USA)	2011-2018	FC	88 Multicont. Seat Driver	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	88 Multicont. Seat Driver	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	88 Multicont. Seat Driver	Output Tests	
Audi A7 (USA)	2011-2018	FC	88 Multicont. Seat Driver	Specia Functions	
Audi A7 (USA)	2011-2018	FC	89 Multicont. Seat Driver	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	89 Multicont. Seat Driver	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	89 Multicont. Seat Driver	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	89 Multicont. Seat Driver	Output Tests	
Audi A7 (USA)	2011-2018	FC	89 Multicont. Seat Driver	Specia Functions	
Audi A7 (USA)	2011-2018	FC	8A Multicont. Seat Rear, DS	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	8A Multicont. Seat Rear, DS	Output Tests	
Audi A7 (USA)	2011-2018	FC	8A Multicont. Seat Rear, DS	Specia Functions	
Audi A7 (USA)	2011-2018	FC	8B Adaptive Cruise 2	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	8B Adaptive Cruise 2	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	8B Adaptive Cruise 2	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	8B Adaptive Cruise 2	Output Tests	
Audi A7 (USA)	2011-2018	FC	8B Adaptive Cruise 2	Specia Functions	
Audi A7 (USA)	2011-2018	FC	8C Hybrid Battery	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	8C Hybrid Battery	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	8C Hybrid Battery	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	8C Hybrid Battery	Output Tests	
Audi A7 (USA)	2011-2018	FC	8C Hybrid Battery	Specia Functions	
Audi A7 (USA)	2011-2018	FC	8D Multicont.Seat Rear,PS	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7 (USA)	2011-2018	FC	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	8D Multicont.Seat Rear,PS	Output Tests	
Audi A7 (USA)	2011-2018	FC	8D Multicont.Seat Rear,PS	Specia Functions	
Audi A7 (USA)	2011-2018	FC	8E Image Processing	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	8E Image Processing	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	8E Image Processing	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	8E Image Processing	Output Tests	
Audi A7 (USA)	2011-2018	FC	8E Image Processing	Specia Functions	
Audi A7 (USA)	2011-2018	FC	8F Pretens. Frt Left	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	8F Pretens. Frt Left	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	8F Pretens. Frt Left	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	8F Pretens. Frt Left	Output Tests	
Audi A7 (USA)	2011-2018	FC	8F Pretens. Frt Left	Specia Functions	
Audi A7 (USA)	2011-2018	FC	90 Pretens. Frt Right	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	90 Pretens. Frt Right	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	90 Pretens. Frt Right	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	90 Pretens. Frt Right	Output Tests	
Audi A7 (USA)	2011-2018	FC	90 Pretens. Frt Right	Specia Functions	
Audi A7 (USA)	2011-2018	FC	A9 Struct.Borne Sound	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	A9 Struct.Borne Sound	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	A9 Struct.Borne Sound	Output Tests	
Audi A7 (USA)	2011-2018	FC	A9 Struct.Borne Sound	Specia Functions	
Audi A7 (USA)	2011-2018	FC	AC Reductant Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 (USA)	2011-2018	FC	AC Reductant Control	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	AC Reductant Control	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	AC Reductant Control	Output Tests	
Audi A7 (USA)	2011-2018	FC	AC Reductant Control	Specia Functions	
Audi A7 (USA)	2011-2018	FC	BA Motor Mounts	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	BA Motor Mounts	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	BA Motor Mounts	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	BA Motor Mounts	Output Tests	
Audi A7 (USA)	2011-2018	FC	BA Motor Mounts	Specia Functions	
Audi A7 (USA)	2011-2018	FC	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	C0 Act. For Ext. Noise	Output Tests	
Audi A7 (USA)	2011-2018	FC	C0 Act. For Ext. Noise	Specia Functions	
Audi A7 (USA)	2011-2018	FC	C6 Batt. Chrg	Read Fault Codes	
Audi A7 (USA)	2011-2018	FC	C6 Batt. Chrg	Clear Fault Codes	
Audi A7 (USA)	2011-2018	FC	C6 Batt. Chrg	Measuring Blocks	
Audi A7 (USA)	2011-2018	FC	C6 Batt. Chrg	Output Tests	
Audi A7 (USA)	2011-2018	FC	C6 Batt. Chrg	Specia Functions	
Audi A8 (USA)	2010-2018	4H	01 Engine Electronics	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	01 Engine Electronics	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	01 Engine Electronics	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	01 Engine Electronics	Output Tests	
Audi A8 (USA)	2010-2018	4H	01 Engine Electronics	Specia Functions	
Audi A8 (USA)	2010-2018	4H	02 Transmission Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2010-2018	4H	02 Transmission Electronics	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	02 Transmission Electronics	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	02 Transmission Electronics	Output Tests	
Audi A8 (USA)	2010-2018	4H	02 Transmission Electronics	Specia Functions	
Audi A8 (USA)	2010-2018	4H	03 Brake Electronics	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	03 Brake Electronics	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	03 Brake Electronics	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	03 Brake Electronics	Output Tests	
Audi A8 (USA)	2010-2018	4H	03 Brake Electronics	Specia Functions	
Audi A8 (USA)	2010-2018	4H	05 Access & Permissi.	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	05 Access & Permissi.	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	05 Access & Permissi.	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	05 Access & Permissi.	Output Tests	
Audi A8 (USA)	2010-2018	4H	05 Access & Permissi.	Specia Functions	
Audi A8 (USA)	2010-2018	4H	06 Passene. Seat Adj.	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	06 Passene. Seat Adj.	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	06 Passene. Seat Adj.	Output Tests	
Audi A8 (USA)	2010-2018	4H	06 Passene. Seat Adj.	Specia Functions	
Audi A8 (USA)	2010-2018	4H	08 AC/Heating Electronics	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	08 AC/Heating Electronics	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	08 AC/Heating Electronics	Output Tests	
Audi A8 (USA)	2010-2018	4H	08 AC/Heating Electronics	Specia Functions	
Audi A8 (USA)	2010-2018	4H	09 Electronic Ctrl Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2010-2018	4H	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	09 Electronic Ctrl Electronics	Output Tests	
Audi A8 (USA)	2010-2018	4H	09 Electronic Ctrl Electronics	Specia Functions	
Audi A8 (USA)	2010-2018	4H	0E Media Player Position 1	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	0E Media Player Position 1	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	0E Media Player Position 1	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	0E Media Player Position 1	Output Tests	
Audi A8 (USA)	2010-2018	4H	0E Media Player Position 1	Specia Functions	
Audi A8 (USA)	2010-2018	4H	10 Parking Assist System 2	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	10 Parking Assist System 2	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	10 Parking Assist System 2	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	10 Parking Assist System 2	Output Tests	
Audi A8 (USA)	2010-2018	4H	10 Parking Assist System 2	Specia Functions	
Audi A8 (USA)	2010-2018	4H	11 Engine Electronics 2	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	11 Engine Electronics 2	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	11 Engine Electronics 2	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	11 Engine Electronics 2	Output Tests	
Audi A8 (USA)	2010-2018	4H	11 Engine Electronics 2	Specia Functions	
Audi A8 (USA)	2010-2018	4H	13 Distance Control	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	13 Distance Control	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	13 Distance Control	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	13 Distance Control	Output Tests	
Audi A8 (USA)	2010-2018	4H	13 Distance Control	Specia Functions	
Audi A8 (USA)	2010-2018	4H	15 Airbags	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi A8 (USA)	2010-2018	4H	15 Airbags	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	15 Airbags	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	15 Airbags	Output Tests	
Audi A8 (USA)	2010-2018	4H	15 Airbags	Specia Functions	
Audi A8 (USA)	2010-2018	4H	16 Steering Wheel Electronics	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	16 Steering Wheel Electronics	Output Tests	
Audi A8 (USA)	2010-2018	4H	16 Steering Wheel Electronics	Specia Functions	
Audi A8 (USA)	2010-2018	4H	17 Instrument Cluster	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	17 Instrument Cluster	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	17 Instrument Cluster	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	17 Instrument Cluster	Output Tests	
Audi A8 (USA)	2010-2018	4H	17 Instrument Cluster	Specia Functions	
Audi A8 (USA)	2010-2018	4H	18 Aux Heating	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	18 Aux Heating	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	18 Aux Heating	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	18 Aux Heating	Output Tests	
Audi A8 (USA)	2010-2018	4H	18 Aux Heating	Specia Functions	
Audi A8 (USA)	2010-2018	4H	19 Gateway Data Bus	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	19 Gateway Data Bus	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	19 Gateway Data Bus	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	19 Gateway Data Bus	Output Tests	
Audi A8 (USA)	2010-2018	4H	19 Gateway Data Bus	Specia Functions	
Audi A8 (USA)	2010-2018	4H	1B Power-Assisted Steering	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2010-2018	4H	1B Power-Assisted Steering	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	1B Power-Assisted Steering	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	1B Power-Assisted Steering	Output Tests	
Audi A8 (USA)	2010-2018	4H	1B Power-Assisted Steering	Specia Functions	
Audi A8 (USA)	2010-2018	4H	20 High Beam Assistance Device	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	20 High Beam Assistance Device	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	20 High Beam Assistance Device	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	20 High Beam Assistance Device	Output Tests	
Audi A8 (USA)	2010-2018	4H	20 High Beam Assistance Device	Specia Functions	
Audi A8 (USA)	2010-2018	4H	22 4WD Electronics	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	22 4WD Electronics	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	22 4WD Electronics	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	22 4WD Electronics	Output Tests	
Audi A8 (USA)	2010-2018	4H	22 4WD Electronics	Specia Functions	
Audi A8 (USA)	2010-2018	4H	28 Climate Control Unit Rear	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	28 Climate Control Unit Rear	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	28 Climate Control Unit Rear	Output Tests	
Audi A8 (USA)	2010-2018	4H	28 Climate Control Unit Rear	Specia Functions	
Audi A8 (USA)	2010-2018	4H	30 Special Function 2	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	30 Special Function 2	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	30 Special Function 2	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	30 Special Function 2	Output Tests	
Audi A8 (USA)	2010-2018	4H	30 Special Function 2	Specia Functions	
Audi A8 (USA)	2010-2018	4H	34 Self Leveling Suspension	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2010-2018	4H	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	34 Self Leveling Suspension	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	34 Self Leveling Suspension	Output Tests	
Audi A8 (USA)	2010-2018	4H	34 Self Leveling Suspension	Specia Functions	
Audi A8 (USA)	2010-2018	4H	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	36 Side of Driver Seat Adj.	Output Tests	
Audi A8 (USA)	2010-2018	4H	36 Side of Driver Seat Adj.	Specia Functions	
Audi A8 (USA)	2010-2018	4H	3B Sensor Elect.	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	3B Sensor Elect.	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	3B Sensor Elect.	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	3B Sensor Elect.	Output Tests	
Audi A8 (USA)	2010-2018	4H	3B Sensor Elect.	Specia Functions	
Audi A8 (USA)	2010-2018	4H	3C Lane Departure Assistance System	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	3C Lane Departure Assistance System	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	3C Lane Departure Assistance System	Output Tests	
Audi A8 (USA)	2010-2018	4H	3C Lane Departure Assistance System	Specia Functions	
Audi A8 (USA)	2010-2018	4H	3D Special Function	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	3D Special Function	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	3D Special Function	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	3D Special Function	Output Tests	
Audi A8 (USA)	2010-2018	4H	3D Special Function	Specia Functions	
Audi A8 (USA)	2010-2018	4H	40 Air Compressor	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2010-2018	4H	40 Air Compressor	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	40 Air Compressor	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	40 Air Compressor	Output Tests	
Audi A8 (USA)	2010-2018	4H	40 Air Compressor	Specia Functions	
Audi A8 (USA)	2010-2018	4H	42 Driver-Door Elect.	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	42 Driver-Door Elect.	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	42 Driver-Door Elect.	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	42 Driver-Door Elect.	Output Tests	
Audi A8 (USA)	2010-2018	4H	42 Driver-Door Elect.	Specia Functions	
Audi A8 (USA)	2010-2018	4H	44 Steering Assistance	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	44 Steering Assistance	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	44 Steering Assistance	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	44 Steering Assistance	Output Tests	
Audi A8 (USA)	2010-2018	4H	44 Steering Assistance	Specia Functions	
Audi A8 (USA)	2010-2018	4H	46 Central Control Module	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	46 Central Control Module	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	46 Central Control Module	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	46 Central Control Module	Output Tests	
Audi A8 (USA)	2010-2018	4H	46 Central Control Module	Specia Functions	
Audi A8 (USA)	2010-2018	4H	47 Soundsystem	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	47 Soundsystem	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	47 Soundsystem	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	47 Soundsystem	Output Tests	
Audi A8 (USA)	2010-2018	4H	47 Soundsystem	Specia Functions	
Audi A8 (USA)	2010-2018	4H	48 Drvs Seat Adj.Rear	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8 (USA)	2010-2018	4H	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	48 Drvs Seat Adj.Rear	Output Tests	
Audi A8 (USA)	2010-2018	4H	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A8 (USA)	2010-2018	4H	51 Electric Drive	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	51 Electric Drive	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	51 Electric Drive	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	51 Electric Drive	Output Tests	
Audi A8 (USA)	2010-2018	4H	51 Electric Drive	Specia Functions	
Audi A8 (USA)	2010-2018	4H	52 Passe.-Door Elect.	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	52 Passe.-Door Elect.	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	52 Passe.-Door Elect.	Output Tests	
Audi A8 (USA)	2010-2018	4H	52 Passe.-Door Elect.	Specia Functions	
Audi A8 (USA)	2010-2018	4H	53 Parking Brake	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	53 Parking Brake	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	53 Parking Brake	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	53 Parking Brake	Output Tests	
Audi A8 (USA)	2010-2018	4H	53 Parking Brake	Specia Functions	
Audi A8 (USA)	2010-2018	4H	55 Headlight Range Control	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	55 Headlight Range Control	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	55 Headlight Range Control	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	55 Headlight Range Control	Output Tests	
Audi A8 (USA)	2010-2018	4H	55 Headlight Range Control	Specia Functions	
Audi A8 (USA)	2010-2018	4H	56 Radio	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2010-2018	4H	56 Radio	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	56 Radio	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	56 Radio	Output Tests	
Audi A8 (USA)	2010-2018	4H	56 Radio	Specia Functions	
Audi A8 (USA)	2010-2018	4H	57 TV-Tuner	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	57 TV-Tuner	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	57 TV-Tuner	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	57 TV-Tuner	Output Tests	
Audi A8 (USA)	2010-2018	4H	57 TV-Tuner	Specia Functions	
Audi A8 (USA)	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Output Tests	
Audi A8 (USA)	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Specia Functions	
Audi A8 (USA)	2010-2018	4H	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	5F Information Electronic Equipment 1	Output Tests	
Audi A8 (USA)	2010-2018	4H	5F Information Electronic Equipment 1	Specia Functions	
Audi A8 (USA)	2010-2018	4H	62 LR-Door Electroni.	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	62 LR-Door Electroni.	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	62 LR-Door Electroni.	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	62 LR-Door Electroni.	Output Tests	
Audi A8 (USA)	2010-2018	4H	62 LR-Door Electroni.	Specia Functions	
Audi A8 (USA)	2010-2018	4H	65 Tyre Pressure Monitoring	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2010-2018	4H	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	65 Tyre Pressure Monitoring	Output Tests	
Audi A8 (USA)	2010-2018	4H	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8 (USA)	2010-2018	4H	69 Trailer Function	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	69 Trailer Function	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	69 Trailer Function	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	69 Trailer Function	Output Tests	
Audi A8 (USA)	2010-2018	4H	69 Trailer Function	Specia Functions	
Audi A8 (USA)	2010-2018	4H	6C Rear Camera	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	6C Rear Camera	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	6C Rear Camera	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	6C Rear Camera	Output Tests	
Audi A8 (USA)	2010-2018	4H	6C Rear Camera	Specia Functions	
Audi A8 (USA)	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A8 (USA)	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A8 (USA)	2010-2018	4H	6F Confort Central Control Unit II	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	6F Confort Central Control Unit II	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	6F Confort Central Control Unit II	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	6F Confort Central Control Unit II	Output Tests	
Audi A8 (USA)	2010-2018	4H	6F Confort Central Control Unit II	Specia Functions	
Audi A8 (USA)	2010-2018	4H	72 RR-Door Electroni.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2010-2018	4H	72 RR-Door Electroni.	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	72 RR-Door Electroni.	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	72 RR-Door Electroni.	Output Tests	
Audi A8 (USA)	2010-2018	4H	72 RR-Door Electroni.	Specia Functions	
Audi A8 (USA)	2010-2018	4H	7F Information Electronic Equipment 2	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	7F Information Electronic Equipment 2	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	7F Information Electronic Equipment 2	Output Tests	
Audi A8 (USA)	2010-2018	4H	7F Information Electronic Equipment 2	Specia Functions	
Audi A8 (USA)	2010-2018	4H	81 Gear Shift	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	81 Gear Shift	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	81 Gear Shift	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	81 Gear Shift	Output Tests	
Audi A8 (USA)	2010-2018	4H	81 Gear Shift	Specia Functions	
Audi A8 (USA)	2010-2018	4H	82 Heads Up Display	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	82 Heads Up Display	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	82 Heads Up Display	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	82 Heads Up Display	Output Tests	
Audi A8 (USA)	2010-2018	4H	82 Heads Up Display	Specia Functions	
Audi A8 (USA)	2010-2018	4H	84 Night Vision	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	84 Night Vision	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	84 Night Vision	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	84 Night Vision	Output Tests	
Audi A8 (USA)	2010-2018	4H	84 Night Vision	Specia Functions	
Audi A8 (USA)	2010-2018	4H	85 On Board Cam.	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8 (USA)	2010-2018	4H	85 On Board Cam.	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	85 On Board Cam.	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	85 On Board Cam.	Output Tests	
Audi A8 (USA)	2010-2018	4H	85 On Board Cam.	Specia Functions	
Audi A8 (USA)	2010-2018	4H	88 Multicont. Seat Driver	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	88 Multicont. Seat Driver	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	88 Multicont. Seat Driver	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	88 Multicont. Seat Driver	Output Tests	
Audi A8 (USA)	2010-2018	4H	88 Multicont. Seat Driver	Specia Functions	
Audi A8 (USA)	2010-2018	4H	89 Multicont. Seat Driver	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	89 Multicont. Seat Driver	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	89 Multicont. Seat Driver	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	89 Multicont. Seat Driver	Output Tests	
Audi A8 (USA)	2010-2018	4H	89 Multicont. Seat Driver	Specia Functions	
Audi A8 (USA)	2010-2018	4H	8A Multicont. Seat Rear, DS	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	8A Multicont. Seat Rear, DS	Output Tests	
Audi A8 (USA)	2010-2018	4H	8A Multicont. Seat Rear, DS	Specia Functions	
Audi A8 (USA)	2010-2018	4H	8B Adaptive Cruise 2	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	8B Adaptive Cruise 2	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	8B Adaptive Cruise 2	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	8B Adaptive Cruise 2	Output Tests	
Audi A8 (USA)	2010-2018	4H	8B Adaptive Cruise 2	Specia Functions	
Audi A8 (USA)	2010-2018	4H	8C Hybrid Battery	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2010-2018	4H	8C Hybrid Battery	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	8C Hybrid Battery	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	8C Hybrid Battery	Output Tests	
Audi A8 (USA)	2010-2018	4H	8C Hybrid Battery	Specia Functions	
Audi A8 (USA)	2010-2018	4H	8D Multicont.Seat Rear,PS	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	8D Multicont.Seat Rear,PS	Output Tests	
Audi A8 (USA)	2010-2018	4H	8D Multicont.Seat Rear,PS	Specia Functions	
Audi A8 (USA)	2010-2018	4H	8E Image Processing	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	8E Image Processing	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	8E Image Processing	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	8E Image Processing	Output Tests	
Audi A8 (USA)	2010-2018	4H	8E Image Processing	Specia Functions	
Audi A8 (USA)	2010-2018	4H	8F Pretens. Frt Left	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	8F Pretens. Frt Left	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	8F Pretens. Frt Left	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	8F Pretens. Frt Left	Output Tests	
Audi A8 (USA)	2010-2018	4H	8F Pretens. Frt Left	Specia Functions	
Audi A8 (USA)	2010-2018	4H	90 Pretens. Frt Right	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	90 Pretens. Frt Right	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	90 Pretens. Frt Right	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	90 Pretens. Frt Right	Output Tests	
Audi A8 (USA)	2010-2018	4H	90 Pretens. Frt Right	Specia Functions	
Audi A8 (USA)	2010-2018	4H	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8 (USA)	2010-2018	4H	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	A9 Struct.Borne Sound	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	A9 Struct.Borne Sound	Output Tests	
Audi A8 (USA)	2010-2018	4H	A9 Struct.Borne Sound	Specia Functions	
Audi A8 (USA)	2010-2018	4H	AC Reductant Control	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	AC Reductant Control	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	AC Reductant Control	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	AC Reductant Control	Output Tests	
Audi A8 (USA)	2010-2018	4H	AC Reductant Control	Specia Functions	
Audi A8 (USA)	2010-2018	4H	BA Motor Mounts	Read Fault Codes	
Audi A8 (USA)	2010-2018	4H	BA Motor Mounts	Clear Fault Codes	
Audi A8 (USA)	2010-2018	4H	BA Motor Mounts	Measuring Blocks	
Audi A8 (USA)	2010-2018	4H	BA Motor Mounts	Output Tests	
Audi A8 (USA)	2010-2018	4H	BA Motor Mounts	Specia Functions	
Audi S8 (USA)	2010-2018	4H	01 Engine Electronics	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	01 Engine Electronics	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	01 Engine Electronics	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	01 Engine Electronics	Output Tests	
Audi S8 (USA)	2010-2018	4H	01 Engine Electronics	Specia Functions	
Audi S8 (USA)	2010-2018	4H	02 Transmission Electronics	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	02 Transmission Electronics	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	02 Transmission Electronics	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	02 Transmission Electronics	Output Tests	
Audi S8 (USA)	2010-2018	4H	02 Transmission Electronics	Specia Functions	
Audi S8 (USA)	2010-2018	4H	03 Brake Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S8 (USA)	2010-2018	4H	03 Brake Electronics	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	03 Brake Electronics	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	03 Brake Electronics	Output Tests	
Audi S8 (USA)	2010-2018	4H	03 Brake Electronics	Specia Functions	
Audi S8 (USA)	2010-2018	4H	05 Access & Permissi.	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	05 Access & Permissi.	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	05 Access & Permissi.	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	05 Access & Permissi.	Output Tests	
Audi S8 (USA)	2010-2018	4H	05 Access & Permissi.	Specia Functions	
Audi S8 (USA)	2010-2018	4H	06 Passene. Seat Adj.	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	06 Passene. Seat Adj.	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	06 Passene. Seat Adj.	Output Tests	
Audi S8 (USA)	2010-2018	4H	06 Passene. Seat Adj.	Specia Functions	
Audi S8 (USA)	2010-2018	4H	08 AC/Heating Electronics	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	08 AC/Heating Electronics	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	08 AC/Heating Electronics	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	08 AC/Heating Electronics	Output Tests	
Audi S8 (USA)	2010-2018	4H	08 AC/Heating Electronics	Specia Functions	
Audi S8 (USA)	2010-2018	4H	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	09 Electronic Ctrl Electronics	Output Tests	
Audi S8 (USA)	2010-2018	4H	09 Electronic Ctrl Electronics	Specia Functions	
Audi S8 (USA)	2010-2018	4H	0E Media Player Position 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S8 (USA)	2010-2018	4H	0E Media Player Position 1	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	0E Media Player Position 1	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	0E Media Player Position 1	Output Tests	
Audi S8 (USA)	2010-2018	4H	0E Media Player Position 1	Specia Functions	
Audi S8 (USA)	2010-2018	4H	10 Parking Assist System 2	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	10 Parking Assist System 2	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	10 Parking Assist System 2	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	10 Parking Assist System 2	Output Tests	
Audi S8 (USA)	2010-2018	4H	10 Parking Assist System 2	Specia Functions	
Audi S8 (USA)	2010-2018	4H	11 Engine Electronics 2	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	11 Engine Electronics 2	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	11 Engine Electronics 2	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	11 Engine Electronics 2	Output Tests	
Audi S8 (USA)	2010-2018	4H	11 Engine Electronics 2	Specia Functions	
Audi S8 (USA)	2010-2018	4H	13 Distance Control	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	13 Distance Control	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	13 Distance Control	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	13 Distance Control	Output Tests	
Audi S8 (USA)	2010-2018	4H	13 Distance Control	Specia Functions	
Audi S8 (USA)	2010-2018	4H	15 Airbags	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	15 Airbags	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	15 Airbags	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	15 Airbags	Output Tests	
Audi S8 (USA)	2010-2018	4H	15 Airbags	Specia Functions	
Audi S8 (USA)	2010-2018	4H	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8 (USA)	2010-2018	4H	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	16 Steering Wheel Electronics	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	16 Steering Wheel Electronics	Output Tests	
Audi S8 (USA)	2010-2018	4H	16 Steering Wheel Electronics	Specia Functions	
Audi S8 (USA)	2010-2018	4H	17 Instrument Cluster	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	17 Instrument Cluster	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	17 Instrument Cluster	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	17 Instrument Cluster	Output Tests	
Audi S8 (USA)	2010-2018	4H	17 Instrument Cluster	Specia Functions	
Audi S8 (USA)	2010-2018	4H	18 Aux Heating	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	18 Aux Heating	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	18 Aux Heating	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	18 Aux Heating	Output Tests	
Audi S8 (USA)	2010-2018	4H	18 Aux Heating	Specia Functions	
Audi S8 (USA)	2010-2018	4H	19 Gateway Data Bus	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	19 Gateway Data Bus	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	19 Gateway Data Bus	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	19 Gateway Data Bus	Output Tests	
Audi S8 (USA)	2010-2018	4H	19 Gateway Data Bus	Specia Functions	
Audi S8 (USA)	2010-2018	4H	1B Power-Assisted Steering	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	1B Power-Assisted Steering	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	1B Power-Assisted Steering	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	1B Power-Assisted Steering	Output Tests	
Audi S8 (USA)	2010-2018	4H	1B Power-Assisted Steering	Specia Functions	
Audi S8 (USA)	2010-2018	4H	20 High Beam Assistance Device	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8 (USA)	2010-2018	4H	20 High Beam Assistance Device	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	20 High Beam Assistance Device	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	20 High Beam Assistance Device	Output Tests	
Audi S8 (USA)	2010-2018	4H	20 High Beam Assistance Device	Specia Functions	
Audi S8 (USA)	2010-2018	4H	22 4WD Electronics	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	22 4WD Electronics	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	22 4WD Electronics	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	22 4WD Electronics	Output Tests	
Audi S8 (USA)	2010-2018	4H	22 4WD Electronics	Specia Functions	
Audi S8 (USA)	2010-2018	4H	28 Climate Control Unit Rear	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	28 Climate Control Unit Rear	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	28 Climate Control Unit Rear	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	28 Climate Control Unit Rear	Output Tests	
Audi S8 (USA)	2010-2018	4H	28 Climate Control Unit Rear	Specia Functions	
Audi S8 (USA)	2010-2018	4H	30 Special Function 2	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	30 Special Function 2	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	30 Special Function 2	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	30 Special Function 2	Output Tests	
Audi S8 (USA)	2010-2018	4H	30 Special Function 2	Specia Functions	
Audi S8 (USA)	2010-2018	4H	34 Self Leveling Suspension	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	34 Self Leveling Suspension	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	34 Self Leveling Suspension	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	34 Self Leveling Suspension	Output Tests	
Audi S8 (USA)	2010-2018	4H	34 Self Leveling Suspension	Specia Functions	
Audi S8 (USA)	2010-2018	4H	36 Side of Driver Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S8 (USA)	2010-2018	4H	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	36 Side of Driver Seat Adj.	Output Tests	
Audi S8 (USA)	2010-2018	4H	36 Side of Driver Seat Adj.	Specia Functions	
Audi S8 (USA)	2010-2018	4H	3B Sensor Elect.	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	3B Sensor Elect.	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	3B Sensor Elect.	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	3B Sensor Elect.	Output Tests	
Audi S8 (USA)	2010-2018	4H	3B Sensor Elect.	Specia Functions	
Audi S8 (USA)	2010-2018	4H	3C Lane Departure Assistance System	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	3C Lane Departure Assistance System	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	3C Lane Departure Assistance System	Output Tests	
Audi S8 (USA)	2010-2018	4H	3C Lane Departure Assistance System	Specia Functions	
Audi S8 (USA)	2010-2018	4H	3D Special Function	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	3D Special Function	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	3D Special Function	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	3D Special Function	Output Tests	
Audi S8 (USA)	2010-2018	4H	3D Special Function	Specia Functions	
Audi S8 (USA)	2010-2018	4H	40 Air Compressor	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	40 Air Compressor	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	40 Air Compressor	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	40 Air Compressor	Output Tests	
Audi S8 (USA)	2010-2018	4H	40 Air Compressor	Specia Functions	
Audi S8 (USA)	2010-2018	4H	42 Driver-Door Elect.	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8 (USA)	2010-2018	4H	42 Driver-Door Elect.	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	42 Driver-Door Elect.	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	42 Driver-Door Elect.	Output Tests	
Audi S8 (USA)	2010-2018	4H	42 Driver-Door Elect.	Specia Functions	
Audi S8 (USA)	2010-2018	4H	44 Steering Assistance	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	44 Steering Assistance	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	44 Steering Assistance	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	44 Steering Assistance	Output Tests	
Audi S8 (USA)	2010-2018	4H	44 Steering Assistance	Specia Functions	
Audi S8 (USA)	2010-2018	4H	46 Central Control Module	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	46 Central Control Module	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	46 Central Control Module	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	46 Central Control Module	Output Tests	
Audi S8 (USA)	2010-2018	4H	46 Central Control Module	Specia Functions	
Audi S8 (USA)	2010-2018	4H	47 Soundsystem	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	47 Soundsystem	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	47 Soundsystem	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	47 Soundsystem	Output Tests	
Audi S8 (USA)	2010-2018	4H	47 Soundsystem	Specia Functions	
Audi S8 (USA)	2010-2018	4H	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	48 Drvs Seat Adj.Rear	Output Tests	
Audi S8 (USA)	2010-2018	4H	48 Drvs Seat Adj.Rear	Specia Functions	
Audi S8 (USA)	2010-2018	4H	51 Electric Drive	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S8 (USA)	2010-2018	4H	51 Electric Drive	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	51 Electric Drive	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	51 Electric Drive	Output Tests	
Audi S8 (USA)	2010-2018	4H	51 Electric Drive	Specia Functions	
Audi S8 (USA)	2010-2018	4H	52 Passe.-Door Elect.	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	52 Passe.-Door Elect.	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	52 Passe.-Door Elect.	Output Tests	
Audi S8 (USA)	2010-2018	4H	52 Passe.-Door Elect.	Specia Functions	
Audi S8 (USA)	2010-2018	4H	53 Parking Brake	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	53 Parking Brake	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	53 Parking Brake	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	53 Parking Brake	Output Tests	
Audi S8 (USA)	2010-2018	4H	53 Parking Brake	Specia Functions	
Audi S8 (USA)	2010-2018	4H	55 Headlight Range Control	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	55 Headlight Range Control	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	55 Headlight Range Control	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	55 Headlight Range Control	Output Tests	
Audi S8 (USA)	2010-2018	4H	55 Headlight Range Control	Specia Functions	
Audi S8 (USA)	2010-2018	4H	56 Radio	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	56 Radio	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	56 Radio	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	56 Radio	Output Tests	
Audi S8 (USA)	2010-2018	4H	56 Radio	Specia Functions	
Audi S8 (USA)	2010-2018	4H	57 TV-Tuner	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S8 (USA)	2010-2018	4H	57 TV-Tuner	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	57 TV-Tuner	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	57 TV-Tuner	Output Tests	
Audi S8 (USA)	2010-2018	4H	57 TV-Tuner	Specia Functions	
Audi S8 (USA)	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Output Tests	
Audi S8 (USA)	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Specia Functions	
Audi S8 (USA)	2010-2018	4H	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	5F Information Electronic Equipment 1	Output Tests	
Audi S8 (USA)	2010-2018	4H	5F Information Electronic Equipment 1	Specia Functions	
Audi S8 (USA)	2010-2018	4H	62 LR-Door Electroni.	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	62 LR-Door Electroni.	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	62 LR-Door Electroni.	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	62 LR-Door Electroni.	Output Tests	
Audi S8 (USA)	2010-2018	4H	62 LR-Door Electroni.	Specia Functions	
Audi S8 (USA)	2010-2018	4H	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	65 Tyre Pressure Monitoring	Output Tests	
Audi S8 (USA)	2010-2018	4H	65 Tyre Pressure Monitoring	Specia Functions	
Audi S8 (USA)	2010-2018	4H	69 Trailer Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8 (USA)	2010-2018	4H	69 Trailer Function	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	69 Trailer Function	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	69 Trailer Function	Output Tests	
Audi S8 (USA)	2010-2018	4H	69 Trailer Function	Specia Functions	
Audi S8 (USA)	2010-2018	4H	6C Rear Camera	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	6C Rear Camera	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	6C Rear Camera	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	6C Rear Camera	Output Tests	
Audi S8 (USA)	2010-2018	4H	6C Rear Camera	Specia Functions	
Audi S8 (USA)	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S8 (USA)	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S8 (USA)	2010-2018	4H	6F Confort Central Control Unit II	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	6F Confort Central Control Unit II	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	6F Confort Central Control Unit II	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	6F Confort Central Control Unit II	Output Tests	
Audi S8 (USA)	2010-2018	4H	6F Confort Central Control Unit II	Specia Functions	
Audi S8 (USA)	2010-2018	4H	72 RR-Door Electroni.	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	72 RR-Door Electroni.	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	72 RR-Door Electroni.	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	72 RR-Door Electroni.	Output Tests	
Audi S8 (USA)	2010-2018	4H	72 RR-Door Electroni.	Specia Functions	
Audi S8 (USA)	2010-2018	4H	7F Information Electronic Equipment 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S8 (USA)	2010-2018	4H	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	7F Information Electronic Equipment 2	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	7F Information Electronic Equipment 2	Output Tests	
Audi S8 (USA)	2010-2018	4H	7F Information Electronic Equipment 2	Specia Functions	
Audi S8 (USA)	2010-2018	4H	81 Gear Shift	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	81 Gear Shift	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	81 Gear Shift	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	81 Gear Shift	Output Tests	
Audi S8 (USA)	2010-2018	4H	81 Gear Shift	Specia Functions	
Audi S8 (USA)	2010-2018	4H	82 Heads Up Display	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	82 Heads Up Display	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	82 Heads Up Display	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	82 Heads Up Display	Output Tests	
Audi S8 (USA)	2010-2018	4H	82 Heads Up Display	Specia Functions	
Audi S8 (USA)	2010-2018	4H	84 Night Vision	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	84 Night Vision	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	84 Night Vision	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	84 Night Vision	Output Tests	
Audi S8 (USA)	2010-2018	4H	84 Night Vision	Specia Functions	
Audi S8 (USA)	2010-2018	4H	85 On Board Cam.	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	85 On Board Cam.	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	85 On Board Cam.	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	85 On Board Cam.	Output Tests	
Audi S8 (USA)	2010-2018	4H	85 On Board Cam.	Specia Functions	
Audi S8 (USA)	2010-2018	4H	88 Multicont. Seat Driver	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8 (USA)	2010-2018	4H	88 Multicont. Seat Driver	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	88 Multicont. Seat Driver	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	88 Multicont. Seat Driver	Output Tests	
Audi S8 (USA)	2010-2018	4H	88 Multicont. Seat Driver	Specia Functions	
Audi S8 (USA)	2010-2018	4H	89 Multicont. Seat Driver	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	89 Multicont. Seat Driver	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	89 Multicont. Seat Driver	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	89 Multicont. Seat Driver	Output Tests	
Audi S8 (USA)	2010-2018	4H	89 Multicont. Seat Driver	Specia Functions	
Audi S8 (USA)	2010-2018	4H	8A Multicont. Seat Rear, DS	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	8A Multicont. Seat Rear, DS	Output Tests	
Audi S8 (USA)	2010-2018	4H	8A Multicont. Seat Rear, DS	Specia Functions	
Audi S8 (USA)	2010-2018	4H	8B Adaptive Cruise 2	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	8B Adaptive Cruise 2	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	8B Adaptive Cruise 2	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	8B Adaptive Cruise 2	Output Tests	
Audi S8 (USA)	2010-2018	4H	8B Adaptive Cruise 2	Specia Functions	
Audi S8 (USA)	2010-2018	4H	8C Hybrid Battery	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	8C Hybrid Battery	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	8C Hybrid Battery	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	8C Hybrid Battery	Output Tests	
Audi S8 (USA)	2010-2018	4H	8C Hybrid Battery	Specia Functions	
Audi S8 (USA)	2010-2018	4H	8D Multicont.Seat Rear,PS	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S8 (USA)	2010-2018	4H	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	8D Multicont.Seat Rear,PS	Output Tests	
Audi S8 (USA)	2010-2018	4H	8D Multicont.Seat Rear,PS	Specia Functions	
Audi S8 (USA)	2010-2018	4H	8E Image Processing	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	8E Image Processing	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	8E Image Processing	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	8E Image Processing	Output Tests	
Audi S8 (USA)	2010-2018	4H	8E Image Processing	Specia Functions	
Audi S8 (USA)	2010-2018	4H	8F Pretens. Frt Left	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	8F Pretens. Frt Left	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	8F Pretens. Frt Left	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	8F Pretens. Frt Left	Output Tests	
Audi S8 (USA)	2010-2018	4H	8F Pretens. Frt Left	Specia Functions	
Audi S8 (USA)	2010-2018	4H	90 Pretens. Frt Right	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	90 Pretens. Frt Right	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	90 Pretens. Frt Right	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	90 Pretens. Frt Right	Output Tests	
Audi S8 (USA)	2010-2018	4H	90 Pretens. Frt Right	Specia Functions	
Audi S8 (USA)	2010-2018	4H	A9 Struct.Borne Sound	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	A9 Struct.Borne Sound	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	A9 Struct.Borne Sound	Output Tests	
Audi S8 (USA)	2010-2018	4H	A9 Struct.Borne Sound	Specia Functions	
Audi S8 (USA)	2010-2018	4H	AC Reductant Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8 (USA)	2010-2018	4H	AC Reductant Control	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	AC Reductant Control	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	AC Reductant Control	Output Tests	
Audi S8 (USA)	2010-2018	4H	AC Reductant Control	Specia Functions	
Audi S8 (USA)	2010-2018	4H	BA Motor Mounts	Read Fault Codes	
Audi S8 (USA)	2010-2018	4H	BA Motor Mounts	Clear Fault Codes	
Audi S8 (USA)	2010-2018	4H	BA Motor Mounts	Measuring Blocks	
Audi S8 (USA)	2010-2018	4H	BA Motor Mounts	Output Tests	
Audi S8 (USA)	2010-2018	4H	BA Motor Mounts	Specia Functions	
Audi A4 (USA)	2016-2018	F4	01 Engine Electronics	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	01 Engine Electronics	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	01 Engine Electronics	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	01 Engine Electronics	Output Tests	
Audi A4 (USA)	2016-2018	F4	01 Engine Electronics	Specia Functions	
Audi A4 (USA)	2016-2018	F4	02 Transmission Electronics	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	02 Transmission Electronics	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	02 Transmission Electronics	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	02 Transmission Electronics	Output Tests	
Audi A4 (USA)	2016-2018	F4	02 Transmission Electronics	Specia Functions	
Audi A4 (USA)	2016-2018	F4	03 Brake Electronics	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	03 Brake Electronics	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	03 Brake Electronics	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	03 Brake Electronics	Output Tests	
Audi A4 (USA)	2016-2018	F4	03 Brake Electronics	Specia Functions	
Audi A4 (USA)	2016-2018	F4	06 Passene. Seat Adj.	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4 (USA)	2016-2018	F4	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	06 Passene. Seat Adj.	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	06 Passene. Seat Adj.	Output Tests	
Audi A4 (USA)	2016-2018	F4	06 Passene. Seat Adj.	Specia Functions	
Audi A4 (USA)	2016-2018	F4	08 AC/Heating Electronics	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	08 AC/Heating Electronics	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	08 AC/Heating Electronics	Output Tests	
Audi A4 (USA)	2016-2018	F4	08 AC/Heating Electronics	Specia Functions	
Audi A4 (USA)	2016-2018	F4	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	09 Electronic Ctrl Electronics	Output Tests	
Audi A4 (USA)	2016-2018	F4	09 Electronic Ctrl Electronics	Specia Functions	
Audi A4 (USA)	2016-2018	F4	13 Distance Control	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	13 Distance Control	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	13 Distance Control	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	13 Distance Control	Output Tests	
Audi A4 (USA)	2016-2018	F4	13 Distance Control	Specia Functions	
Audi A4 (USA)	2016-2018	F4	15 Airbags	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	15 Airbags	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	15 Airbags	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	15 Airbags	Output Tests	
Audi A4 (USA)	2016-2018	F4	15 Airbags	Specia Functions	
Audi A4 (USA)	2016-2018	F4	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4 (USA)	2016-2018	F4	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	16 Steering Wheel Electronics	Output Tests	
Audi A4 (USA)	2016-2018	F4	16 Steering Wheel Electronics	Specia Functions	
Audi A4 (USA)	2016-2018	F4	17 Instrument Cluster	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	17 Instrument Cluster	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	17 Instrument Cluster	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	17 Instrument Cluster	Output Tests	
Audi A4 (USA)	2016-2018	F4	17 Instrument Cluster	Specia Functions	
Audi A4 (USA)	2016-2018	F4	18 Aux Heating	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	18 Aux Heating	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	18 Aux Heating	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	18 Aux Heating	Output Tests	
Audi A4 (USA)	2016-2018	F4	18 Aux Heating	Specia Functions	
Audi A4 (USA)	2016-2018	F4	19 Gateway Data Bus	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	19 Gateway Data Bus	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	19 Gateway Data Bus	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	19 Gateway Data Bus	Output Tests	
Audi A4 (USA)	2016-2018	F4	19 Gateway Data Bus	Specia Functions	
Audi A4 (USA)	2016-2018	F4	1B Power-Assisted Steering	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	1B Power-Assisted Steering	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	1B Power-Assisted Steering	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	1B Power-Assisted Steering	Output Tests	
Audi A4 (USA)	2016-2018	F4	1B Power-Assisted Steering	Specia Functions	
Audi A4 (USA)	2016-2018	F4	20 High Beam Assistance Device	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4 (USA)	2016-2018	F4	20 High Beam Assistance Device	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	20 High Beam Assistance Device	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	20 High Beam Assistance Device	Output Tests	
Audi A4 (USA)	2016-2018	F4	20 High Beam Assistance Device	Specia Functions	
Audi A4 (USA)	2016-2018	F4	21 Engine Electronics 3	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	21 Engine Electronics 3	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	21 Engine Electronics 3	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	21 Engine Electronics 3	Output Tests	
Audi A4 (USA)	2016-2018	F4	21 Engine Electronics 3	Specia Functions	
Audi A4 (USA)	2016-2018	F4	22 4WD Electronics	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	22 4WD Electronics	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	22 4WD Electronics	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	22 4WD Electronics	Output Tests	
Audi A4 (USA)	2016-2018	F4	22 4WD Electronics	Specia Functions	
Audi A4 (USA)	2016-2018	F4	29 Left Light Control	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	29 Left Light Control	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	29 Left Light Control	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	29 Left Light Control	Output Tests	
Audi A4 (USA)	2016-2018	F4	29 Left Light Control	Specia Functions	
Audi A4 (USA)	2016-2018	F4	2B Steer Col Lock	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	2B Steer Col Lock	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	2B Steer Col Lock	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	2B Steer Col Lock	Output Tests	
Audi A4 (USA)	2016-2018	F4	2B Steer Col Lock	Specia Functions	
Audi A4 (USA)	2016-2018	F4	32 Locking Electronisc	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4 (USA)	2016-2018	F4	32 Locking Electronisc	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	32 Locking Electronisc	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	32 Locking Electronisc	Output Tests	
Audi A4 (USA)	2016-2018	F4	32 Locking Electronisc	Specia Functions	
Audi A4 (USA)	2016-2018	F4	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	36 Side of Driver Seat Adj.	Output Tests	
Audi A4 (USA)	2016-2018	F4	36 Side of Driver Seat Adj.	Specia Functions	
Audi A4 (USA)	2016-2018	F4	39 Right Light Control	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	39 Right Light Control	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	39 Right Light Control	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	39 Right Light Control	Output Tests	
Audi A4 (USA)	2016-2018	F4	39 Right Light Control	Specia Functions	
Audi A4 (USA)	2016-2018	F4	3C Lane Departure Assistance System	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	3C Lane Departure Assistance System	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	3C Lane Departure Assistance System	Output Tests	
Audi A4 (USA)	2016-2018	F4	3C Lane Departure Assistance System	Specia Functions	
Audi A4 (USA)	2016-2018	F4	3D Special Function	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	3D Special Function	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	3D Special Function	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	3D Special Function	Output Tests	
Audi A4 (USA)	2016-2018	F4	3D Special Function	Specia Functions	
Audi A4 (USA)	2016-2018	F4	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4 (USA)	2016-2018	F4	42 Driver-Door Elect.	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	42 Driver-Door Elect.	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	42 Driver-Door Elect.	Output Tests	
Audi A4 (USA)	2016-2018	F4	42 Driver-Door Elect.	Specia Functions	
Audi A4 (USA)	2016-2018	F4	44 Steering Assistance	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	44 Steering Assistance	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	44 Steering Assistance	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	44 Steering Assistance	Output Tests	
Audi A4 (USA)	2016-2018	F4	44 Steering Assistance	Specia Functions	
Audi A4 (USA)	2016-2018	F4	46 Central Control Module	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	46 Central Control Module	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	46 Central Control Module	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	46 Central Control Module	Output Tests	
Audi A4 (USA)	2016-2018	F4	46 Central Control Module	Specia Functions	
Audi A4 (USA)	2016-2018	F4	47 Soundsystem	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	47 Soundsystem	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	47 Soundsystem	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	47 Soundsystem	Output Tests	
Audi A4 (USA)	2016-2018	F4	47 Soundsystem	Specia Functions	
Audi A4 (USA)	2016-2018	F4	4E Control Head RR	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	4E Control Head RR	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	4E Control Head RR	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	4E Control Head RR	Output Tests	
Audi A4 (USA)	2016-2018	F4	4E Control Head RR	Specia Functions	
Audi A4 (USA)	2016-2018	F4	52 Passe.-Door Elect.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4 (USA)	2016-2018	F4	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	52 Passe.-Door Elect.	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	52 Passe.-Door Elect.	Output Tests	
Audi A4 (USA)	2016-2018	F4	52 Passe.-Door Elect.	Specia Functions	
Audi A4 (USA)	2016-2018	F4	57 TV-Tuner	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	57 TV-Tuner	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	57 TV-Tuner	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	57 TV-Tuner	Output Tests	
Audi A4 (USA)	2016-2018	F4	57 TV-Tuner	Specia Functions	
Audi A4 (USA)	2016-2018	F4	5E Control Head LR	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	5E Control Head LR	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	5E Control Head LR	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	5E Control Head LR	Output Tests	
Audi A4 (USA)	2016-2018	F4	5E Control Head LR	Specia Functions	
Audi A4 (USA)	2016-2018	F4	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	5F Information Electronic Equipment 1	Output Tests	
Audi A4 (USA)	2016-2018	F4	5F Information Electronic Equipment 1	Specia Functions	
Audi A4 (USA)	2016-2018	F4	69 Trailer Function	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	69 Trailer Function	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	69 Trailer Function	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	69 Trailer Function	Output Tests	
Audi A4 (USA)	2016-2018	F4	69 Trailer Function	Specia Functions	
Audi A4 (USA)	2016-2018	F4	6C Rear Camera	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4 (USA)	2016-2018	F4	6C Rear Camera	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	6C Rear Camera	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	6C Rear Camera	Output Tests	
Audi A4 (USA)	2016-2018	F4	6C Rear Camera	Specia Functions	
Audi A4 (USA)	2016-2018	F4	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A4 (USA)	2016-2018	F4	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A4 (USA)	2016-2018	F4	74 Vehicle Control System	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	74 Vehicle Control System	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	74 Vehicle Control System	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	74 Vehicle Control System	Output Tests	
Audi A4 (USA)	2016-2018	F4	74 Vehicle Control System	Specia Functions	
Audi A4 (USA)	2016-2018	F4	81 Gear Shift	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	81 Gear Shift	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	81 Gear Shift	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	81 Gear Shift	Output Tests	
Audi A4 (USA)	2016-2018	F4	81 Gear Shift	Specia Functions	
Audi A4 (USA)	2016-2018	F4	82 Heads Up Display	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	82 Heads Up Display	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	82 Heads Up Display	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	82 Heads Up Display	Output Tests	
Audi A4 (USA)	2016-2018	F4	82 Heads Up Display	Specia Functions	
Audi A4 (USA)	2016-2018	F4	8B Adaptive Cruise 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4 (USA)	2016-2018	F4	8B Adaptive Cruise 2	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	8B Adaptive Cruise 2	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	8B Adaptive Cruise 2	Output Tests	
Audi A4 (USA)	2016-2018	F4	8B Adaptive Cruise 2	Specia Functions	
Audi A4 (USA)	2016-2018	F4	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A4 (USA)	2016-2018	F4	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A4 (USA)	2016-2018	F4	A9 Struct.Borne Sound	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	A9 Struct.Borne Sound	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	A9 Struct.Borne Sound	Output Tests	
Audi A4 (USA)	2016-2018	F4	A9 Struct.Borne Sound	Specia Functions	
Audi A4 (USA)	2016-2018	F4	AC Reductant Control	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	AC Reductant Control	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	AC Reductant Control	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	AC Reductant Control	Output Tests	
Audi A4 (USA)	2016-2018	F4	AC Reductant Control	Specia Functions	
Audi A4 (USA)	2016-2018	F4	BB Door Rear Drv Side	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	BB Door Rear Drv Side	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	BB Door Rear Drv Side	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	BB Door Rear Drv Side	Output Tests	
Audi A4 (USA)	2016-2018	F4	BB Door Rear Drv Side	Specia Functions	
Audi A4 (USA)	2016-2018	F4	BC Door Rear Pass Side	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4 (USA)	2016-2018	F4	BC Door Rear Pass Side	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	BC Door Rear Pass Side	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	BC Door Rear Pass Side	Output Tests	
Audi A4 (USA)	2016-2018	F4	BC Door Rear Pass Side	Specia Functions	
Audi A4 (USA)	2016-2018	F4	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A4 (USA)	2016-2018	F4	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A4 (USA)	2016-2018	F4	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A4 (USA)	2016-2018	F4	C0 Act. For Ext. Noise	Output Tests	
Audi A4 (USA)	2016-2018	F4	C0 Act. For Ext. Noise	Specia Functions	
Audi A5 (USA)	2016-2018	8W	01 Engine Electronics	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	01 Engine Electronics	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	01 Engine Electronics	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	01 Engine Electronics	Output Tests	
Audi A5 (USA)	2016-2018	8W	01 Engine Electronics	Specia Functions	
Audi A5 (USA)	2016-2018	8W	02 Transmission Electronics	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	02 Transmission Electronics	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	02 Transmission Electronics	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	02 Transmission Electronics	Output Tests	
Audi A5 (USA)	2016-2018	8W	02 Transmission Electronics	Specia Functions	
Audi A5 (USA)	2016-2018	8W	03 Brake Electronics	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	03 Brake Electronics	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	03 Brake Electronics	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	03 Brake Electronics	Output Tests	
Audi A5 (USA)	2016-2018	8W	03 Brake Electronics	Specia Functions	
Audi A5 (USA)	2016-2018	8W	06 Passene. Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A5 (USA)	2016-2018	8W	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	06 Passene. Seat Adj.	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	06 Passene. Seat Adj.	Output Tests	
Audi A5 (USA)	2016-2018	8W	06 Passene. Seat Adj.	Specia Functions	
Audi A5 (USA)	2016-2018	8W	08 AC/Heating Electronics	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	08 AC/Heating Electronics	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	08 AC/Heating Electronics	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	08 AC/Heating Electronics	Output Tests	
Audi A5 (USA)	2016-2018	8W	08 AC/Heating Electronics	Specia Functions	
Audi A5 (USA)	2016-2018	8W	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	09 Electronic Ctrl Electronics	Output Tests	
Audi A5 (USA)	2016-2018	8W	09 Electronic Ctrl Electronics	Specia Functions	
Audi A5 (USA)	2016-2018	8W	13 Distance Control	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	13 Distance Control	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	13 Distance Control	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	13 Distance Control	Output Tests	
Audi A5 (USA)	2016-2018	8W	13 Distance Control	Specia Functions	
Audi A5 (USA)	2016-2018	8W	15 Airbags	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	15 Airbags	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	15 Airbags	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	15 Airbags	Output Tests	
Audi A5 (USA)	2016-2018	8W	15 Airbags	Specia Functions	
Audi A5 (USA)	2016-2018	8W	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2016-2018	8W	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	16 Steering Wheel Electronics	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	16 Steering Wheel Electronics	Output Tests	
Audi A5 (USA)	2016-2018	8W	16 Steering Wheel Electronics	Specia Functions	
Audi A5 (USA)	2016-2018	8W	17 Instrument Cluster	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	17 Instrument Cluster	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	17 Instrument Cluster	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	17 Instrument Cluster	Output Tests	
Audi A5 (USA)	2016-2018	8W	17 Instrument Cluster	Specia Functions	
Audi A5 (USA)	2016-2018	8W	18 Aux Heating	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	18 Aux Heating	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	18 Aux Heating	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	18 Aux Heating	Output Tests	
Audi A5 (USA)	2016-2018	8W	18 Aux Heating	Specia Functions	
Audi A5 (USA)	2016-2018	8W	19 Gateway Data Bus	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	19 Gateway Data Bus	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	19 Gateway Data Bus	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	19 Gateway Data Bus	Output Tests	
Audi A5 (USA)	2016-2018	8W	19 Gateway Data Bus	Specia Functions	
Audi A5 (USA)	2016-2018	8W	1B Power-Assisted Steering	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	1B Power-Assisted Steering	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	1B Power-Assisted Steering	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	1B Power-Assisted Steering	Output Tests	
Audi A5 (USA)	2016-2018	8W	1B Power-Assisted Steering	Specia Functions	
Audi A5 (USA)	2016-2018	8W	20 High Beam Assistance Device	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2016-2018	8W	20 High Beam Assistance Device	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	20 High Beam Assistance Device	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	20 High Beam Assistance Device	Output Tests	
Audi A5 (USA)	2016-2018	8W	20 High Beam Assistance Device	Specia Functions	
Audi A5 (USA)	2016-2018	8W	21 Engine Electronics 3	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	21 Engine Electronics 3	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	21 Engine Electronics 3	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	21 Engine Electronics 3	Output Tests	
Audi A5 (USA)	2016-2018	8W	21 Engine Electronics 3	Specia Functions	
Audi A5 (USA)	2016-2018	8W	22 4WD Electronics	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	22 4WD Electronics	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	22 4WD Electronics	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	22 4WD Electronics	Output Tests	
Audi A5 (USA)	2016-2018	8W	22 4WD Electronics	Specia Functions	
Audi A5 (USA)	2016-2018	8W	29 Left Light Control	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	29 Left Light Control	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	29 Left Light Control	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	29 Left Light Control	Output Tests	
Audi A5 (USA)	2016-2018	8W	29 Left Light Control	Specia Functions	
Audi A5 (USA)	2016-2018	8W	2B Steer Col Lock	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	2B Steer Col Lock	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	2B Steer Col Lock	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	2B Steer Col Lock	Output Tests	
Audi A5 (USA)	2016-2018	8W	2B Steer Col Lock	Specia Functions	
Audi A5 (USA)	2016-2018	8W	32 Locking Electronisc	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A5 (USA)	2016-2018	8W	32 Locking Electronisc	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	32 Locking Electronisc	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	32 Locking Electronisc	Output Tests	
Audi A5 (USA)	2016-2018	8W	32 Locking Electronisc	Specia Functions	
Audi A5 (USA)	2016-2018	8W	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	36 Side of Driver Seat Adj.	Output Tests	
Audi A5 (USA)	2016-2018	8W	36 Side of Driver Seat Adj.	Specia Functions	
Audi A5 (USA)	2016-2018	8W	39 Right Light Control	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	39 Right Light Control	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	39 Right Light Control	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	39 Right Light Control	Output Tests	
Audi A5 (USA)	2016-2018	8W	39 Right Light Control	Specia Functions	
Audi A5 (USA)	2016-2018	8W	3C Lane Departure Assistance System	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	3C Lane Departure Assistance System	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	3C Lane Departure Assistance System	Output Tests	
Audi A5 (USA)	2016-2018	8W	3C Lane Departure Assistance System	Specia Functions	
Audi A5 (USA)	2016-2018	8W	3D Special Function	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	3D Special Function	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	3D Special Function	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	3D Special Function	Output Tests	
Audi A5 (USA)	2016-2018	8W	3D Special Function	Specia Functions	
Audi A5 (USA)	2016-2018	8W	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2016-2018	8W	42 Driver-Door Elect.	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	42 Driver-Door Elect.	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	42 Driver-Door Elect.	Output Tests	
Audi A5 (USA)	2016-2018	8W	42 Driver-Door Elect.	Specia Functions	
Audi A5 (USA)	2016-2018	8W	44 Steering Assistance	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	44 Steering Assistance	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	44 Steering Assistance	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	44 Steering Assistance	Output Tests	
Audi A5 (USA)	2016-2018	8W	44 Steering Assistance	Specia Functions	
Audi A5 (USA)	2016-2018	8W	46 Central Control Module	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	46 Central Control Module	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	46 Central Control Module	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	46 Central Control Module	Output Tests	
Audi A5 (USA)	2016-2018	8W	46 Central Control Module	Specia Functions	
Audi A5 (USA)	2016-2018	8W	47 Soundsystem	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	47 Soundsystem	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	47 Soundsystem	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	47 Soundsystem	Output Tests	
Audi A5 (USA)	2016-2018	8W	47 Soundsystem	Specia Functions	
Audi A5 (USA)	2016-2018	8W	4E Control Head RR	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	4E Control Head RR	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	4E Control Head RR	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	4E Control Head RR	Output Tests	
Audi A5 (USA)	2016-2018	8W	4E Control Head RR	Specia Functions	
Audi A5 (USA)	2016-2018	8W	52 Passe.-Door Elect.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A5 (USA)	2016-2018	8W	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	52 Passe.-Door Elect.	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	52 Passe.-Door Elect.	Output Tests	
Audi A5 (USA)	2016-2018	8W	52 Passe.-Door Elect.	Specia Functions	
Audi A5 (USA)	2016-2018	8W	57 TV-Tuner	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	57 TV-Tuner	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	57 TV-Tuner	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	57 TV-Tuner	Output Tests	
Audi A5 (USA)	2016-2018	8W	57 TV-Tuner	Specia Functions	
Audi A5 (USA)	2016-2018	8W	5E Control Head LR	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	5E Control Head LR	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	5E Control Head LR	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	5E Control Head LR	Output Tests	
Audi A5 (USA)	2016-2018	8W	5E Control Head LR	Specia Functions	
Audi A5 (USA)	2016-2018	8W	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	5F Information Electronic Equipment 1	Output Tests	
Audi A5 (USA)	2016-2018	8W	5F Information Electronic Equipment 1	Specia Functions	
Audi A5 (USA)	2016-2018	8W	69 Trailer Function	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	69 Trailer Function	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	69 Trailer Function	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	69 Trailer Function	Output Tests	
Audi A5 (USA)	2016-2018	8W	69 Trailer Function	Specia Functions	
Audi A5 (USA)	2016-2018	8W	6C Rear Camera	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2016-2018	8W	6C Rear Camera	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	6C Rear Camera	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	6C Rear Camera	Output Tests	
Audi A5 (USA)	2016-2018	8W	6C Rear Camera	Specia Functions	
Audi A5 (USA)	2016-2018	8W	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A5 (USA)	2016-2018	8W	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A5 (USA)	2016-2018	8W	74 Vehicle Control System	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	74 Vehicle Control System	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	74 Vehicle Control System	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	74 Vehicle Control System	Output Tests	
Audi A5 (USA)	2016-2018	8W	74 Vehicle Control System	Specia Functions	
Audi A5 (USA)	2016-2018	8W	81 Gear Shift	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	81 Gear Shift	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	81 Gear Shift	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	81 Gear Shift	Output Tests	
Audi A5 (USA)	2016-2018	8W	81 Gear Shift	Specia Functions	
Audi A5 (USA)	2016-2018	8W	82 Heads Up Display	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	82 Heads Up Display	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	82 Heads Up Display	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	82 Heads Up Display	Output Tests	
Audi A5 (USA)	2016-2018	8W	82 Heads Up Display	Specia Functions	
Audi A5 (USA)	2016-2018	8W	8B Adaptive Cruise 2	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi A5 (USA)	2016-2018	8W	8B Adaptive Cruise 2	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	8B Adaptive Cruise 2	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	8B Adaptive Cruise 2	Output Tests	
Audi A5 (USA)	2016-2018	8W	8B Adaptive Cruise 2	Specia Functions	
Audi A5 (USA)	2016-2018	8W	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A5 (USA)	2016-2018	8W	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A5 (USA)	2016-2018	8W	A9 Struct.Borne Sound	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	A9 Struct.Borne Sound	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	A9 Struct.Borne Sound	Output Tests	
Audi A5 (USA)	2016-2018	8W	A9 Struct.Borne Sound	Specia Functions	
Audi A5 (USA)	2016-2018	8W	AC Reductant Control	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	AC Reductant Control	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	AC Reductant Control	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	AC Reductant Control	Output Tests	
Audi A5 (USA)	2016-2018	8W	AC Reductant Control	Specia Functions	
Audi A5 (USA)	2016-2018	8W	BB Door Rear Drv Side	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	BB Door Rear Drv Side	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	BB Door Rear Drv Side	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	BB Door Rear Drv Side	Output Tests	
Audi A5 (USA)	2016-2018	8W	BB Door Rear Drv Side	Specia Functions	
Audi A5 (USA)	2016-2018	8W	BC Door Rear Pass Side	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5 (USA)	2016-2018	8W	BC Door Rear Pass Side	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	BC Door Rear Pass Side	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	BC Door Rear Pass Side	Output Tests	
Audi A5 (USA)	2016-2018	8W	BC Door Rear Pass Side	Specia Functions	
Audi A5 (USA)	2016-2018	8W	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A5 (USA)	2016-2018	8W	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A5 (USA)	2016-2018	8W	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A5 (USA)	2016-2018	8W	C0 Act. For Ext. Noise	Output Tests	
Audi A5 (USA)	2016-2018	8W	C0 Act. For Ext. Noise	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	01 Engine Electronics	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	01 Engine Electronics	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	01 Engine Electronics	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	01 Engine Electronics	Output Tests	
Audi Q7 (USA)	2015-2018	4M	01 Engine Electronics	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	02 Transmission Electronics	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	02 Transmission Electronics	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	02 Transmission Electronics	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	02 Transmission Electronics	Output Tests	
Audi Q7 (USA)	2015-2018	4M	02 Transmission Electronics	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	03 Brake Electronics	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	03 Brake Electronics	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	03 Brake Electronics	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	03 Brake Electronics	Output Tests	
Audi Q7 (USA)	2015-2018	4M	03 Brake Electronics	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	06 Passene. Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 (USA)	2015-2018	4M	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	06 Passene. Seat Adj.	Output Tests	
Audi Q7 (USA)	2015-2018	4M	06 Passene. Seat Adj.	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	08 AC/Heating Electronics	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	08 AC/Heating Electronics	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	08 AC/Heating Electronics	Output Tests	
Audi Q7 (USA)	2015-2018	4M	08 AC/Heating Electronics	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	09 Electronic Ctrl Electronics	Output Tests	
Audi Q7 (USA)	2015-2018	4M	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	0E Media Player Position 1	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	0E Media Player Position 1	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	0E Media Player Position 1	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	0E Media Player Position 1	Output Tests	
Audi Q7 (USA)	2015-2018	4M	0E Media Player Position 1	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	13 Distance Control	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	13 Distance Control	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	13 Distance Control	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	13 Distance Control	Output Tests	
Audi Q7 (USA)	2015-2018	4M	13 Distance Control	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	15 Airbags	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 (USA)	2015-2018	4M	15 Airbags	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	15 Airbags	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	15 Airbags	Output Tests	
Audi Q7 (USA)	2015-2018	4M	15 Airbags	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	16 Steering Wheel Electronics	Output Tests	
Audi Q7 (USA)	2015-2018	4M	16 Steering Wheel Electronics	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	17 Instrument Cluster	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	17 Instrument Cluster	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	17 Instrument Cluster	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	17 Instrument Cluster	Output Tests	
Audi Q7 (USA)	2015-2018	4M	17 Instrument Cluster	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	18 Aux Heating	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	18 Aux Heating	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	18 Aux Heating	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	18 Aux Heating	Output Tests	
Audi Q7 (USA)	2015-2018	4M	18 Aux Heating	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	19 Gateway Data Bus	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	19 Gateway Data Bus	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	19 Gateway Data Bus	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	19 Gateway Data Bus	Output Tests	
Audi Q7 (USA)	2015-2018	4M	19 Gateway Data Bus	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	20 High Beam Assistance Device	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 (USA)	2015-2018	4M	20 High Beam Assistance Device	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	20 High Beam Assistance Device	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	20 High Beam Assistance Device	Output Tests	
Audi Q7 (USA)	2015-2018	4M	20 High Beam Assistance Device	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	21 Engine Electronics 3	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	21 Engine Electronics 3	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	21 Engine Electronics 3	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	21 Engine Electronics 3	Output Tests	
Audi Q7 (USA)	2015-2018	4M	21 Engine Electronics 3	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	23 Braker Booster	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	23 Braker Booster	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	23 Braker Booster	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	23 Braker Booster	Output Tests	
Audi Q7 (USA)	2015-2018	4M	23 Braker Booster	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	28 Climate Control Unit Rear	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	28 Climate Control Unit Rear	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	28 Climate Control Unit Rear	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	28 Climate Control Unit Rear	Output Tests	
Audi Q7 (USA)	2015-2018	4M	28 Climate Control Unit Rear	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	29 Left Light Control	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	29 Left Light Control	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	29 Left Light Control	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	29 Left Light Control	Output Tests	
Audi Q7 (USA)	2015-2018	4M	29 Left Light Control	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	2B Steer Col Lock	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 (USA)	2015-2018	4M	2B Steer Col Lock	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	2B Steer Col Lock	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	2B Steer Col Lock	Output Tests	
Audi Q7 (USA)	2015-2018	4M	2B Steer Col Lock	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	32 Locking Electronisc	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	32 Locking Electronisc	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	32 Locking Electronisc	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	32 Locking Electronisc	Output Tests	
Audi Q7 (USA)	2015-2018	4M	32 Locking Electronisc	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	36 Side of Driver Seat Adj.	Output Tests	
Audi Q7 (USA)	2015-2018	4M	36 Side of Driver Seat Adj.	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	39 Right Light Control	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	39 Right Light Control	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	39 Right Light Control	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	39 Right Light Control	Output Tests	
Audi Q7 (USA)	2015-2018	4M	39 Right Light Control	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	3C Lane Departure Assistance System	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	3C Lane Departure Assistance System	Output Tests	
Audi Q7 (USA)	2015-2018	4M	3C Lane Departure Assistance System	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 (USA)	2015-2018	4M	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	42 Driver-Door Elect.	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	42 Driver-Door Elect.	Output Tests	
Audi Q7 (USA)	2015-2018	4M	42 Driver-Door Elect.	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	44 Steering Assistance	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	44 Steering Assistance	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	44 Steering Assistance	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	44 Steering Assistance	Output Tests	
Audi Q7 (USA)	2015-2018	4M	44 Steering Assistance	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	46 Central Control Module	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	46 Central Control Module	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	46 Central Control Module	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	46 Central Control Module	Output Tests	
Audi Q7 (USA)	2015-2018	4M	46 Central Control Module	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	47 Soundsystem	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	47 Soundsystem	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	47 Soundsystem	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	47 Soundsystem	Output Tests	
Audi Q7 (USA)	2015-2018	4M	47 Soundsystem	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	48 Drvs Seat Adj.Rear	Output Tests	
Audi Q7 (USA)	2015-2018	4M	48 Drvs Seat Adj.Rear	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	4E Control Head RR	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 (USA)	2015-2018	4M	4E Control Head RR	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	4E Control Head RR	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	4E Control Head RR	Output Tests	
Audi Q7 (USA)	2015-2018	4M	4E Control Head RR	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	51 Electric Drive	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	51 Electric Drive	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	51 Electric Drive	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	51 Electric Drive	Output Tests	
Audi Q7 (USA)	2015-2018	4M	51 Electric Drive	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	52 Passe.-Door Elect.	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	52 Passe.-Door Elect.	Output Tests	
Audi Q7 (USA)	2015-2018	4M	52 Passe.-Door Elect.	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	57 TV-Tuner	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	57 TV-Tuner	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	57 TV-Tuner	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	57 TV-Tuner	Output Tests	
Audi Q7 (USA)	2015-2018	4M	57 TV-Tuner	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	5B Seat Adjustment Rear Passenger Side	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	5B Seat Adjustment Rear Passenger Side	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	5B Seat Adjustment Rear Passenger Side	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	5B Seat Adjustment Rear Passenger Side	Output Tests	
Audi Q7 (USA)	2015-2018	4M	5B Seat Adjustment Rear Passenger Side	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	5E Control Head LR	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi Q7 (USA)	2015-2018	4M	5E Control Head LR	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	5E Control Head LR	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	5E Control Head LR	Output Tests	
Audi Q7 (USA)	2015-2018	4M	5E Control Head LR	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	5F Information Electronic Equipment 1	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	5F Information Electronic Equipment 1	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	5F Information Electronic Equipment 1	Output Tests	
Audi Q7 (USA)	2015-2018	4M	5F Information Electronic Equipment 1	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	65 Tyre Pressure Monitoring	Output Tests	
Audi Q7 (USA)	2015-2018	4M	65 Tyre Pressure Monitoring	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	69 Trailer Function	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	69 Trailer Function	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	69 Trailer Function	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	69 Trailer Function	Output Tests	
Audi Q7 (USA)	2015-2018	4M	69 Trailer Function	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	6C Rear Camera	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	6C Rear Camera	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	6C Rear Camera	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	6C Rear Camera	Output Tests	
Audi Q7 (USA)	2015-2018	4M	6C Rear Camera	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 (USA)	2015-2018	4M	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q7 (USA)	2015-2018	4M	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	74 Vehicle Control System	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	74 Vehicle Control System	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	74 Vehicle Control System	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	74 Vehicle Control System	Output Tests	
Audi Q7 (USA)	2015-2018	4M	74 Vehicle Control System	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	81 Gear Shift	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	81 Gear Shift	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	81 Gear Shift	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	81 Gear Shift	Output Tests	
Audi Q7 (USA)	2015-2018	4M	81 Gear Shift	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	82 Heads Up Display	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	82 Heads Up Display	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	82 Heads Up Display	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	82 Heads Up Display	Output Tests	
Audi Q7 (USA)	2015-2018	4M	82 Heads Up Display	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	84 Night Vision	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	84 Night Vision	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	84 Night Vision	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	84 Night Vision	Output Tests	
Audi Q7 (USA)	2015-2018	4M	84 Night Vision	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	8B Adaptive Cruise 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 (USA)	2015-2018	4M	8B Adaptive Cruise 2	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	8B Adaptive Cruise 2	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	8B Adaptive Cruise 2	Output Tests	
Audi Q7 (USA)	2015-2018	4M	8B Adaptive Cruise 2	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	8C Hybrid Battery	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	8C Hybrid Battery	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	8C Hybrid Battery	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	8C Hybrid Battery	Output Tests	
Audi Q7 (USA)	2015-2018	4M	8C Hybrid Battery	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	A5 Frt Sens.Drv.Assist	Output Tests	
Audi Q7 (USA)	2015-2018	4M	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	A9 Struct.Borne Sound	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	A9 Struct.Borne Sound	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	A9 Struct.Borne Sound	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	A9 Struct.Borne Sound	Output Tests	
Audi Q7 (USA)	2015-2018	4M	A9 Struct.Borne Sound	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	AC Reductant Control	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	AC Reductant Control	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	AC Reductant Control	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	AC Reductant Control	Output Tests	
Audi Q7 (USA)	2015-2018	4M	AC Reductant Control	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	BA Motor Mounts	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 (USA)	2015-2018	4M	BA Motor Mounts	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	BA Motor Mounts	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	BA Motor Mounts	Output Tests	
Audi Q7 (USA)	2015-2018	4M	BA Motor Mounts	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	BB Door Rear Drv Side	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	BB Door Rear Drv Side	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	BB Door Rear Drv Side	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	BB Door Rear Drv Side	Output Tests	
Audi Q7 (USA)	2015-2018	4M	BB Door Rear Drv Side	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	BC Door Rear Pass Side	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	BC Door Rear Pass Side	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	BC Door Rear Pass Side	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	BC Door Rear Pass Side	Output Tests	
Audi Q7 (USA)	2015-2018	4M	BC Door Rear Pass Side	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	C0 Act. For Ext. Noise	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	C0 Act. For Ext. Noise	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	C0 Act. For Ext. Noise	Output Tests	
Audi Q7 (USA)	2015-2018	4M	C0 Act. For Ext. Noise	Specia Functions	
Audi Q7 (USA)	2015-2018	4M	C6 Batt. Chrg	Read Fault Codes	
Audi Q7 (USA)	2015-2018	4M	C6 Batt. Chrg	Clear Fault Codes	
Audi Q7 (USA)	2015-2018	4M	C6 Batt. Chrg	Measuring Blocks	
Audi Q7 (USA)	2015-2018	4M	C6 Batt. Chrg	Output Tests	
Audi Q7 (USA)	2015-2018	4M	C6 Batt. Chrg	Specia Functions	
Audi R8 (USA)	2015-2018	FX	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 (USA)	2015-2018	FX	01 Engine Electronics	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	01 Engine Electronics	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	01 Engine Electronics	Output Tests	
Audi R8 (USA)	2015-2018	FX	01 Engine Electronics	Specia Functions	
Audi R8 (USA)	2015-2018	FX	02 Transmission Electronics	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	02 Transmission Electronics	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	02 Transmission Electronics	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	02 Transmission Electronics	Output Tests	
Audi R8 (USA)	2015-2018	FX	02 Transmission Electronics	Specia Functions	
Audi R8 (USA)	2015-2018	FX	03 Brake Electronics	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	03 Brake Electronics	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	03 Brake Electronics	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	03 Brake Electronics	Output Tests	
Audi R8 (USA)	2015-2018	FX	03 Brake Electronics	Specia Functions	
Audi R8 (USA)	2015-2018	FX	05 Access & Permissi.	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	05 Access & Permissi.	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	05 Access & Permissi.	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	05 Access & Permissi.	Output Tests	
Audi R8 (USA)	2015-2018	FX	05 Access & Permissi.	Specia Functions	
Audi R8 (USA)	2015-2018	FX	06 Passene. Seat Adj.	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	06 Passene. Seat Adj.	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	06 Passene. Seat Adj.	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	06 Passene. Seat Adj.	Output Tests	
Audi R8 (USA)	2015-2018	FX	06 Passene. Seat Adj.	Specia Functions	
Audi R8 (USA)	2015-2018	FX	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 (USA)	2015-2018	FX	08 AC/Heating Electronics	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	08 AC/Heating Electronics	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	08 AC/Heating Electronics	Output Tests	
Audi R8 (USA)	2015-2018	FX	08 AC/Heating Electronics	Specia Functions	
Audi R8 (USA)	2015-2018	FX	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	09 Electronic Ctrl Electronics	Output Tests	
Audi R8 (USA)	2015-2018	FX	09 Electronic Ctrl Electronics	Specia Functions	
Audi R8 (USA)	2015-2018	FX	11 Engine Electronics 2	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	11 Engine Electronics 2	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	11 Engine Electronics 2	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	11 Engine Electronics 2	Output Tests	
Audi R8 (USA)	2015-2018	FX	11 Engine Electronics 2	Specia Functions	
Audi R8 (USA)	2015-2018	FX	14 Wheel Damping Electronics	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	14 Wheel Damping Electronics	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	14 Wheel Damping Electronics	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	14 Wheel Damping Electronics	Output Tests	
Audi R8 (USA)	2015-2018	FX	14 Wheel Damping Electronics	Specia Functions	
Audi R8 (USA)	2015-2018	FX	15 Airbags	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	15 Airbags	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	15 Airbags	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	15 Airbags	Output Tests	
Audi R8 (USA)	2015-2018	FX	15 Airbags	Specia Functions	
Audi R8 (USA)	2015-2018	FX	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 (USA)	2015-2018	FX	16 Steering Wheel Electronics	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	16 Steering Wheel Electronics	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	16 Steering Wheel Electronics	Output Tests	
Audi R8 (USA)	2015-2018	FX	16 Steering Wheel Electronics	Specia Functions	
Audi R8 (USA)	2015-2018	FX	17 Instrument Cluster	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	17 Instrument Cluster	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	17 Instrument Cluster	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	17 Instrument Cluster	Output Tests	
Audi R8 (USA)	2015-2018	FX	17 Instrument Cluster	Specia Functions	
Audi R8 (USA)	2015-2018	FX	19 Gateway Data Bus	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	19 Gateway Data Bus	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	19 Gateway Data Bus	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	19 Gateway Data Bus	Output Tests	
Audi R8 (USA)	2015-2018	FX	19 Gateway Data Bus	Specia Functions	
Audi R8 (USA)	2015-2018	FX	1B Power-Assisted Steering	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	1B Power-Assisted Steering	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	1B Power-Assisted Steering	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	1B Power-Assisted Steering	Output Tests	
Audi R8 (USA)	2015-2018	FX	1B Power-Assisted Steering	Specia Functions	
Audi R8 (USA)	2015-2018	FX	20 High Beam Assistance Device	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	20 High Beam Assistance Device	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	20 High Beam Assistance Device	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	20 High Beam Assistance Device	Output Tests	
Audi R8 (USA)	2015-2018	FX	20 High Beam Assistance Device	Specia Functions	
Audi R8 (USA)	2015-2018	FX	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 (USA)	2015-2018	FX	22 4WD Electronics	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	22 4WD Electronics	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	22 4WD Electronics	Output Tests	
Audi R8 (USA)	2015-2018	FX	22 4WD Electronics	Specia Functions	
Audi R8 (USA)	2015-2018	FX	26 Electric Roof Control	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	26 Electric Roof Control	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	26 Electric Roof Control	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	26 Electric Roof Control	Output Tests	
Audi R8 (USA)	2015-2018	FX	26 Electric Roof Control	Specia Functions	
Audi R8 (USA)	2015-2018	FX	30 Special Function 2	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	30 Special Function 2	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	30 Special Function 2	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	30 Special Function 2	Output Tests	
Audi R8 (USA)	2015-2018	FX	30 Special Function 2	Specia Functions	
Audi R8 (USA)	2015-2018	FX	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	36 Side of Driver Seat Adj.	Output Tests	
Audi R8 (USA)	2015-2018	FX	36 Side of Driver Seat Adj.	Specia Functions	
Audi R8 (USA)	2015-2018	FX	3B Sensor Elect.	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	3B Sensor Elect.	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	3B Sensor Elect.	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	3B Sensor Elect.	Output Tests	
Audi R8 (USA)	2015-2018	FX	3B Sensor Elect.	Specia Functions	
Audi R8 (USA)	2015-2018	FX	42 Driver-Door Elect.	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 (USA)	2015-2018	FX	42 Driver-Door Elect.	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	42 Driver-Door Elect.	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	42 Driver-Door Elect.	Output Tests	
Audi R8 (USA)	2015-2018	FX	42 Driver-Door Elect.	Specia Functions	
Audi R8 (USA)	2015-2018	FX	44 Steering Assistance	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	44 Steering Assistance	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	44 Steering Assistance	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	44 Steering Assistance	Output Tests	
Audi R8 (USA)	2015-2018	FX	44 Steering Assistance	Specia Functions	
Audi R8 (USA)	2015-2018	FX	46 Central Control Module	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	46 Central Control Module	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	46 Central Control Module	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	46 Central Control Module	Output Tests	
Audi R8 (USA)	2015-2018	FX	46 Central Control Module	Specia Functions	
Audi R8 (USA)	2015-2018	FX	47 Soundsystem	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	47 Soundsystem	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	47 Soundsystem	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	47 Soundsystem	Output Tests	
Audi R8 (USA)	2015-2018	FX	47 Soundsystem	Specia Functions	
Audi R8 (USA)	2015-2018	FX	52 Passe.-Door Elect.	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	52 Passe.-Door Elect.	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	52 Passe.-Door Elect.	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	52 Passe.-Door Elect.	Output Tests	
Audi R8 (USA)	2015-2018	FX	52 Passe.-Door Elect.	Specia Functions	
Audi R8 (USA)	2015-2018	FX	53 Parking Brake	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 (USA)	2015-2018	FX	53 Parking Brake	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	53 Parking Brake	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	53 Parking Brake	Output Tests	
Audi R8 (USA)	2015-2018	FX	53 Parking Brake	Specia Functions	
Audi R8 (USA)	2015-2018	FX	55 Headlight Range Control	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	55 Headlight Range Control	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	55 Headlight Range Control	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	55 Headlight Range Control	Output Tests	
Audi R8 (USA)	2015-2018	FX	55 Headlight Range Control	Specia Functions	
Audi R8 (USA)	2015-2018	FX	57 TV-Tuner	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	57 TV-Tuner	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	57 TV-Tuner	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	57 TV-Tuner	Output Tests	
Audi R8 (USA)	2015-2018	FX	57 TV-Tuner	Specia Functions	
Audi R8 (USA)	2015-2018	FX	5F Information Electronic Equipment 1	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	5F Information Electronic Equipment 1	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	5F Information Electronic Equipment 1	Output Tests	
Audi R8 (USA)	2015-2018	FX	5F Information Electronic Equipment 1	Specia Functions	
Audi R8 (USA)	2015-2018	FX	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	65 Tyre Pressure Monitoring	Output Tests	
Audi R8 (USA)	2015-2018	FX	65 Tyre Pressure Monitoring	Specia Functions	
Audi R8 (USA)	2015-2018	FX	6C Rear Camera	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 (USA)	2015-2018	FX	6C Rear Camera	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	6C Rear Camera	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	6C Rear Camera	Output Tests	
Audi R8 (USA)	2015-2018	FX	6C Rear Camera	Specia Functions	
Audi R8 (USA)	2015-2018	FX	81 Gear Shift	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	81 Gear Shift	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	81 Gear Shift	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	81 Gear Shift	Output Tests	
Audi R8 (USA)	2015-2018	FX	81 Gear Shift	Specia Functions	
Audi R8 (USA)	2015-2018	FX	A6 Microphone	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	A6 Microphone	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	A6 Microphone	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	A6 Microphone	Output Tests	
Audi R8 (USA)	2015-2018	FX	A6 Microphone	Specia Functions	
Audi R8 (USA)	2015-2018	FX	A9 Struct.Borne Sound	Read Fault Codes	
Audi R8 (USA)	2015-2018	FX	A9 Struct.Borne Sound	Clear Fault Codes	
Audi R8 (USA)	2015-2018	FX	A9 Struct.Borne Sound	Measuring Blocks	
Audi R8 (USA)	2015-2018	FX	A9 Struct.Borne Sound	Output Tests	
Audi R8 (USA)	2015-2018	FX	A9 Struct.Borne Sound	Specia Functions	
Audi A3	2002-2004	8P	01 Engine Electronics	Read Fault Codes	
Audi A3	2002-2004	8P	01 Engine Electronics	Clear Fault Codes	
Audi A3	2002-2004	8P	01 Engine Electronics	Measuring Blocks	
Audi A3	2002-2004	8P	01 Engine Electronics	Output Tests	
Audi A3	2002-2004	8P	01 Engine Electronics	Specia Functions	
Audi A3	2002-2004	8P	02 Transmission Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3	2002-2004	8P	02 Transmission Electronics	Clear Fault Codes	
Audi A3	2002-2004	8P	02 Transmission Electronics	Measuring Blocks	
Audi A3	2002-2004	8P	02 Transmission Electronics	Output Tests	
Audi A3	2002-2004	8P	02 Transmission Electronics	Specia Functions	
Audi A3	2002-2004	8P	03 Brake Electronics	Read Fault Codes	
Audi A3	2002-2004	8P	03 Brake Electronics	Clear Fault Codes	
Audi A3	2002-2004	8P	03 Brake Electronics	Measuring Blocks	
Audi A3	2002-2004	8P	03 Brake Electronics	Output Tests	
Audi A3	2002-2004	8P	03 Brake Electronics	Specia Functions	
Audi A3	2002-2004	8P	08 AC/Heating Electronics	Read Fault Codes	
Audi A3	2002-2004	8P	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3	2002-2004	8P	08 AC/Heating Electronics	Measuring Blocks	
Audi A3	2002-2004	8P	08 AC/Heating Electronics	Output Tests	
Audi A3	2002-2004	8P	08 AC/Heating Electronics	Specia Functions	
Audi A3	2002-2004	8P	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3	2002-2004	8P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3	2002-2004	8P	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3	2002-2004	8P	09 Electronic Ctrl Electronics	Output Tests	
Audi A3	2002-2004	8P	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3	2002-2004	8P	11 Engine Electronics 2	Read Fault Codes	
Audi A3	2002-2004	8P	11 Engine Electronics 2	Clear Fault Codes	
Audi A3	2002-2004	8P	11 Engine Electronics 2	Measuring Blocks	
Audi A3	2002-2004	8P	11 Engine Electronics 2	Output Tests	
Audi A3	2002-2004	8P	11 Engine Electronics 2	Specia Functions	
Audi A3	2002-2004	8P	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2002-2004	8P	15 Airbags	Clear Fault Codes	
Audi A3	2002-2004	8P	15 Airbags	Measuring Blocks	
Audi A3	2002-2004	8P	15 Airbags	Output Tests	
Audi A3	2002-2004	8P	15 Airbags	Specia Functions	
Audi A3	2002-2004	8P	16 Steering Wheel Electronics	Read Fault Codes	
Audi A3	2002-2004	8P	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3	2002-2004	8P	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3	2002-2004	8P	16 Steering Wheel Electronics	Output Tests	
Audi A3	2002-2004	8P	16 Steering Wheel Electronics	Specia Functions	
Audi A3	2002-2004	8P	17 Instrument Cluster	Read Fault Codes	
Audi A3	2002-2004	8P	17 Instrument Cluster	Clear Fault Codes	
Audi A3	2002-2004	8P	17 Instrument Cluster	Measuring Blocks	
Audi A3	2002-2004	8P	17 Instrument Cluster	Output Tests	
Audi A3	2002-2004	8P	17 Instrument Cluster	Specia Functions	
Audi A3	2002-2004	8P	18 Aux Heating	Read Fault Codes	
Audi A3	2002-2004	8P	18 Aux Heating	Clear Fault Codes	
Audi A3	2002-2004	8P	18 Aux Heating	Measuring Blocks	
Audi A3	2002-2004	8P	18 Aux Heating	Output Tests	
Audi A3	2002-2004	8P	18 Aux Heating	Specia Functions	
Audi A3	2002-2004	8P	19 Gateway Data Bus	Read Fault Codes	
Audi A3	2002-2004	8P	19 Gateway Data Bus	Clear Fault Codes	
Audi A3	2002-2004	8P	19 Gateway Data Bus	Measuring Blocks	
Audi A3	2002-2004	8P	19 Gateway Data Bus	Output Tests	
Audi A3	2002-2004	8P	19 Gateway Data Bus	Specia Functions	
Audi A3	2002-2004	8P	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2002-2004	8P	22 4WD Electronics	Clear Fault Codes	
Audi A3	2002-2004	8P	22 4WD Electronics	Measuring Blocks	
Audi A3	2002-2004	8P	22 4WD Electronics	Output Tests	
Audi A3	2002-2004	8P	22 4WD Electronics	Specia Functions	
Audi A3	2002-2004	8P	25 Immobilizer	Read Fault Codes	
Audi A3	2002-2004	8P	25 Immobilizer	Clear Fault Codes	
Audi A3	2002-2004	8P	25 Immobilizer	Measuring Blocks	
Audi A3	2002-2004	8P	25 Immobilizer	Output Tests	
Audi A3	2002-2004	8P	25 Immobilizer	Specia Functions	
Audi A3	2002-2004	8P	37 Navigation	Read Fault Codes	
Audi A3	2002-2004	8P	37 Navigation	Clear Fault Codes	
Audi A3	2002-2004	8P	37 Navigation	Measuring Blocks	
Audi A3	2002-2004	8P	37 Navigation	Output Tests	
Audi A3	2002-2004	8P	37 Navigation	Specia Functions	
Audi A3	2002-2004	8P	42 Driver-Door Elect.	Read Fault Codes	
Audi A3	2002-2004	8P	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3	2002-2004	8P	42 Driver-Door Elect.	Measuring Blocks	
Audi A3	2002-2004	8P	42 Driver-Door Elect.	Output Tests	
Audi A3	2002-2004	8P	42 Driver-Door Elect.	Specia Functions	
Audi A3	2002-2004	8P	44 Steering Assistance	Read Fault Codes	
Audi A3	2002-2004	8P	44 Steering Assistance	Clear Fault Codes	
Audi A3	2002-2004	8P	44 Steering Assistance	Measuring Blocks	
Audi A3	2002-2004	8P	44 Steering Assistance	Output Tests	
Audi A3	2002-2004	8P	44 Steering Assistance	Specia Functions	
Audi A3	2002-2004	8P	45 Interior Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2002-2004	8P	45 Interior Monitoring	Clear Fault Codes	
Audi A3	2002-2004	8P	45 Interior Monitoring	Measuring Blocks	
Audi A3	2002-2004	8P	45 Interior Monitoring	Output Tests	
Audi A3	2002-2004	8P	45 Interior Monitoring	Specia Functions	
Audi A3	2002-2004	8P	46 Central Control Module	Read Fault Codes	
Audi A3	2002-2004	8P	46 Central Control Module	Clear Fault Codes	
Audi A3	2002-2004	8P	46 Central Control Module	Measuring Blocks	
Audi A3	2002-2004	8P	46 Central Control Module	Output Tests	
Audi A3	2002-2004	8P	46 Central Control Module	Specia Functions	
Audi A3	2002-2004	8P	47 Soundsystem	Read Fault Codes	
Audi A3	2002-2004	8P	47 Soundsystem	Clear Fault Codes	
Audi A3	2002-2004	8P	47 Soundsystem	Measuring Blocks	
Audi A3	2002-2004	8P	47 Soundsystem	Output Tests	
Audi A3	2002-2004	8P	47 Soundsystem	Specia Functions	
Audi A3	2002-2004	8P	51 Electric Drive	Read Fault Codes	
Audi A3	2002-2004	8P	51 Electric Drive	Clear Fault Codes	
Audi A3	2002-2004	8P	51 Electric Drive	Measuring Blocks	
Audi A3	2002-2004	8P	51 Electric Drive	Output Tests	
Audi A3	2002-2004	8P	51 Electric Drive	Specia Functions	
Audi A3	2002-2004	8P	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3	2002-2004	8P	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3	2002-2004	8P	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3	2002-2004	8P	52 Passe.-Door Elect.	Output Tests	
Audi A3	2002-2004	8P	52 Passe.-Door Elect.	Specia Functions	
Audi A3	2002-2004	8P	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2002-2004	8P	55 Headlight Range Control	Clear Fault Codes	
Audi A3	2002-2004	8P	55 Headlight Range Control	Measuring Blocks	
Audi A3	2002-2004	8P	55 Headlight Range Control	Output Tests	
Audi A3	2002-2004	8P	55 Headlight Range Control	Specia Functions	
Audi A3	2002-2004	8P	56 Radio	Read Fault Codes	
Audi A3	2002-2004	8P	56 Radio	Clear Fault Codes	
Audi A3	2002-2004	8P	56 Radio	Measuring Blocks	
Audi A3	2002-2004	8P	56 Radio	Output Tests	
Audi A3	2002-2004	8P	56 Radio	Specia Functions	
Audi A3	2002-2004	8P	57 TV-Tuner	Read Fault Codes	
Audi A3	2002-2004	8P	57 TV-Tuner	Clear Fault Codes	
Audi A3	2002-2004	8P	57 TV-Tuner	Measuring Blocks	
Audi A3	2002-2004	8P	57 TV-Tuner	Output Tests	
Audi A3	2002-2004	8P	57 TV-Tuner	Specia Functions	
Audi A3	2002-2004	8P	69 Trailer Function	Read Fault Codes	
Audi A3	2002-2004	8P	69 Trailer Function	Clear Fault Codes	
Audi A3	2002-2004	8P	69 Trailer Function	Measuring Blocks	
Audi A3	2002-2004	8P	69 Trailer Function	Output Tests	
Audi A3	2002-2004	8P	69 Trailer Function	Specia Functions	
Audi A3	2002-2004	8P	76 Parking Aid	Read Fault Codes	
Audi A3	2002-2004	8P	76 Parking Aid	Clear Fault Codes	
Audi A3	2002-2004	8P	76 Parking Aid	Measuring Blocks	
Audi A3	2002-2004	8P	76 Parking Aid	Output Tests	
Audi A3	2002-2004	8P	76 Parking Aid	Specia Functions	
Audi A3	2002-2004	8P	77 Telephone	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2002-2004	8P	77 Telephone	Clear Fault Codes	
Audi A3	2002-2004	8P	77 Telephone	Measuring Blocks	
Audi A3	2002-2004	8P	77 Telephone	Output Tests	
Audi A3	2002-2004	8P	77 Telephone	Specia Functions	
Audi A3	2002-2004	8P	7D Auxiliary Heater	Read Fault Codes	
Audi A3	2002-2004	8P	7D Auxiliary Heater	Clear Fault Codes	
Audi A3	2002-2004	8P	7D Auxiliary Heater	Measuring Blocks	
Audi A3	2002-2004	8P	7D Auxiliary Heater	Output Tests	
Audi A3	2002-2004	8P	7D Auxiliary Heater	Specia Functions	
Audi A3	2002-2004	8P	8C Hybrid Battery	Read Fault Codes	
Audi A3	2002-2004	8P	8C Hybrid Battery	Clear Fault Codes	
Audi A3	2002-2004	8P	8C Hybrid Battery	Measuring Blocks	
Audi A3	2002-2004	8P	8C Hybrid Battery	Output Tests	
Audi A3	2002-2004	8P	8C Hybrid Battery	Specia Functions	
Audi A3	2005	8P	01 Engine Electronics	Read Fault Codes	
Audi A3	2005	8P	01 Engine Electronics	Clear Fault Codes	
Audi A3	2005	8P	01 Engine Electronics	Measuring Blocks	
Audi A3	2005	8P	01 Engine Electronics	Output Tests	
Audi A3	2005	8P	01 Engine Electronics	Specia Functions	
Audi A3	2005	8P	02 Transmission Electronics	Read Fault Codes	
Audi A3	2005	8P	02 Transmission Electronics	Clear Fault Codes	
Audi A3	2005	8P	02 Transmission Electronics	Measuring Blocks	
Audi A3	2005	8P	02 Transmission Electronics	Output Tests	
Audi A3	2005	8P	02 Transmission Electronics	Specia Functions	
Audi A3	2005	8P	03 Brake Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2005	8P	03 Brake Electronics	Clear Fault Codes	
Audi A3	2005	8P	03 Brake Electronics	Measuring Blocks	
Audi A3	2005	8P	03 Brake Electronics	Output Tests	
Audi A3	2005	8P	03 Brake Electronics	Specia Functions	
Audi A3	2005	8P	08 AC/Heating Electronics	Read Fault Codes	
Audi A3	2005	8P	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3	2005	8P	08 AC/Heating Electronics	Measuring Blocks	
Audi A3	2005	8P	08 AC/Heating Electronics	Output Tests	
Audi A3	2005	8P	08 AC/Heating Electronics	Specia Functions	
Audi A3	2005	8P	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3	2005	8P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3	2005	8P	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3	2005	8P	09 Electronic Ctrl Electronics	Output Tests	
Audi A3	2005	8P	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3	2005	8P	11 Engine Electronics 2	Read Fault Codes	
Audi A3	2005	8P	11 Engine Electronics 2	Clear Fault Codes	
Audi A3	2005	8P	11 Engine Electronics 2	Measuring Blocks	
Audi A3	2005	8P	11 Engine Electronics 2	Output Tests	
Audi A3	2005	8P	11 Engine Electronics 2	Specia Functions	
Audi A3	2005	8P	15 Airbags	Read Fault Codes	
Audi A3	2005	8P	15 Airbags	Clear Fault Codes	
Audi A3	2005	8P	15 Airbags	Measuring Blocks	
Audi A3	2005	8P	15 Airbags	Output Tests	
Audi A3	2005	8P	15 Airbags	Specia Functions	
Audi A3	2005	8P	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2005	8P	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3	2005	8P	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3	2005	8P	16 Steering Wheel Electronics	Output Tests	
Audi A3	2005	8P	16 Steering Wheel Electronics	Specia Functions	
Audi A3	2005	8P	17 Instrument Cluster	Read Fault Codes	
Audi A3	2005	8P	17 Instrument Cluster	Clear Fault Codes	
Audi A3	2005	8P	17 Instrument Cluster	Measuring Blocks	
Audi A3	2005	8P	17 Instrument Cluster	Output Tests	
Audi A3	2005	8P	17 Instrument Cluster	Specia Functions	
Audi A3	2005	8P	18 Aux Heating	Read Fault Codes	
Audi A3	2005	8P	18 Aux Heating	Clear Fault Codes	
Audi A3	2005	8P	18 Aux Heating	Measuring Blocks	
Audi A3	2005	8P	18 Aux Heating	Output Tests	
Audi A3	2005	8P	18 Aux Heating	Specia Functions	
Audi A3	2005	8P	19 Gateway Data Bus	Read Fault Codes	
Audi A3	2005	8P	19 Gateway Data Bus	Clear Fault Codes	
Audi A3	2005	8P	19 Gateway Data Bus	Measuring Blocks	
Audi A3	2005	8P	19 Gateway Data Bus	Output Tests	
Audi A3	2005	8P	19 Gateway Data Bus	Specia Functions	
Audi A3	2005	8P	22 4WD Electronics	Read Fault Codes	
Audi A3	2005	8P	22 4WD Electronics	Clear Fault Codes	
Audi A3	2005	8P	22 4WD Electronics	Measuring Blocks	
Audi A3	2005	8P	22 4WD Electronics	Output Tests	
Audi A3	2005	8P	22 4WD Electronics	Specia Functions	
Audi A3	2005	8P	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2005	8P	25 Immobilizer	Clear Fault Codes	
Audi A3	2005	8P	25 Immobilizer	Measuring Blocks	
Audi A3	2005	8P	25 Immobilizer	Output Tests	
Audi A3	2005	8P	25 Immobilizer	Specia Functions	
Audi A3	2005	8P	37 Navigation	Read Fault Codes	
Audi A3	2005	8P	37 Navigation	Clear Fault Codes	
Audi A3	2005	8P	37 Navigation	Measuring Blocks	
Audi A3	2005	8P	37 Navigation	Output Tests	
Audi A3	2005	8P	37 Navigation	Specia Functions	
Audi A3	2005	8P	42 Driver-Door Elect.	Read Fault Codes	
Audi A3	2005	8P	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3	2005	8P	42 Driver-Door Elect.	Measuring Blocks	
Audi A3	2005	8P	42 Driver-Door Elect.	Output Tests	
Audi A3	2005	8P	42 Driver-Door Elect.	Specia Functions	
Audi A3	2005	8P	44 Steering Assistance	Read Fault Codes	
Audi A3	2005	8P	44 Steering Assistance	Clear Fault Codes	
Audi A3	2005	8P	44 Steering Assistance	Measuring Blocks	
Audi A3	2005	8P	44 Steering Assistance	Output Tests	
Audi A3	2005	8P	44 Steering Assistance	Specia Functions	
Audi A3	2005	8P	46 Central Control Module	Read Fault Codes	
Audi A3	2005	8P	46 Central Control Module	Clear Fault Codes	
Audi A3	2005	8P	46 Central Control Module	Measuring Blocks	
Audi A3	2005	8P	46 Central Control Module	Output Tests	
Audi A3	2005	8P	46 Central Control Module	Specia Functions	
Audi A3	2005	8P	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2005	8P	47 Soundsystem	Clear Fault Codes	
Audi A3	2005	8P	47 Soundsystem	Measuring Blocks	
Audi A3	2005	8P	47 Soundsystem	Output Tests	
Audi A3	2005	8P	47 Soundsystem	Specia Functions	
Audi A3	2005	8P	51 Electric Drive	Read Fault Codes	
Audi A3	2005	8P	51 Electric Drive	Clear Fault Codes	
Audi A3	2005	8P	51 Electric Drive	Measuring Blocks	
Audi A3	2005	8P	51 Electric Drive	Output Tests	
Audi A3	2005	8P	51 Electric Drive	Specia Functions	
Audi A3	2005	8P	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3	2005	8P	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3	2005	8P	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3	2005	8P	52 Passe.-Door Elect.	Output Tests	
Audi A3	2005	8P	52 Passe.-Door Elect.	Specia Functions	
Audi A3	2005	8P	55 Headlight Range Control	Read Fault Codes	
Audi A3	2005	8P	55 Headlight Range Control	Clear Fault Codes	
Audi A3	2005	8P	55 Headlight Range Control	Measuring Blocks	
Audi A3	2005	8P	55 Headlight Range Control	Output Tests	
Audi A3	2005	8P	55 Headlight Range Control	Specia Functions	
Audi A3	2005	8P	56 Radio	Read Fault Codes	
Audi A3	2005	8P	56 Radio	Clear Fault Codes	
Audi A3	2005	8P	56 Radio	Measuring Blocks	
Audi A3	2005	8P	56 Radio	Output Tests	
Audi A3	2005	8P	56 Radio	Specia Functions	
Audi A3	2005	8P	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2005	8P	57 TV-Tuner	Clear Fault Codes	
Audi A3	2005	8P	57 TV-Tuner	Measuring Blocks	
Audi A3	2005	8P	57 TV-Tuner	Output Tests	
Audi A3	2005	8P	57 TV-Tuner	Specia Functions	
Audi A3	2005	8P	62 LR-Door Electroni.	Read Fault Codes	
Audi A3	2005	8P	62 LR-Door Electroni.	Clear Fault Codes	
Audi A3	2005	8P	62 LR-Door Electroni.	Measuring Blocks	
Audi A3	2005	8P	62 LR-Door Electroni.	Output Tests	
Audi A3	2005	8P	62 LR-Door Electroni.	Specia Functions	
Audi A3	2005	8P	69 Trailer Function	Read Fault Codes	
Audi A3	2005	8P	69 Trailer Function	Clear Fault Codes	
Audi A3	2005	8P	69 Trailer Function	Measuring Blocks	
Audi A3	2005	8P	69 Trailer Function	Output Tests	
Audi A3	2005	8P	69 Trailer Function	Specia Functions	
Audi A3	2005	8P	72 RR-Door Electroni.	Read Fault Codes	
Audi A3	2005	8P	72 RR-Door Electroni.	Clear Fault Codes	
Audi A3	2005	8P	72 RR-Door Electroni.	Measuring Blocks	
Audi A3	2005	8P	72 RR-Door Electroni.	Output Tests	
Audi A3	2005	8P	72 RR-Door Electroni.	Specia Functions	
Audi A3	2005	8P	76 Parking Aid	Read Fault Codes	
Audi A3	2005	8P	76 Parking Aid	Clear Fault Codes	
Audi A3	2005	8P	76 Parking Aid	Measuring Blocks	
Audi A3	2005	8P	76 Parking Aid	Output Tests	
Audi A3	2005	8P	76 Parking Aid	Specia Functions	
Audi A3	2005	8P	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2005	8P	77 Telephone	Clear Fault Codes	
Audi A3	2005	8P	77 Telephone	Measuring Blocks	
Audi A3	2005	8P	77 Telephone	Output Tests	
Audi A3	2005	8P	77 Telephone	Specia Functions	
Audi A3	2005	8P	7D Auxiliary Heater	Read Fault Codes	
Audi A3	2005	8P	7D Auxiliary Heater	Clear Fault Codes	
Audi A3	2005	8P	7D Auxiliary Heater	Measuring Blocks	
Audi A3	2005	8P	7D Auxiliary Heater	Output Tests	
Audi A3	2005	8P	7D Auxiliary Heater	Specia Functions	
Audi A3	2005	8P	8C Hybrid Battery	Read Fault Codes	
Audi A3	2005	8P	8C Hybrid Battery	Clear Fault Codes	
Audi A3	2005	8P	8C Hybrid Battery	Measuring Blocks	
Audi A3	2005	8P	8C Hybrid Battery	Output Tests	
Audi A3	2005	8P	8C Hybrid Battery	Specia Functions	
Audi A3	2006	8P	01 Engine Electronics	Read Fault Codes	
Audi A3	2006	8P	01 Engine Electronics	Clear Fault Codes	
Audi A3	2006	8P	01 Engine Electronics	Measuring Blocks	
Audi A3	2006	8P	01 Engine Electronics	Output Tests	
Audi A3	2006	8P	01 Engine Electronics	Specia Functions	
Audi A3	2006	8P	02 Transmission Electronics	Read Fault Codes	
Audi A3	2006	8P	02 Transmission Electronics	Clear Fault Codes	
Audi A3	2006	8P	02 Transmission Electronics	Measuring Blocks	
Audi A3	2006	8P	02 Transmission Electronics	Output Tests	
Audi A3	2006	8P	02 Transmission Electronics	Specia Functions	
Audi A3	2006	8P	03 Brake Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3	2006	8P	03 Brake Electronics	Clear Fault Codes	
Audi A3	2006	8P	03 Brake Electronics	Measuring Blocks	
Audi A3	2006	8P	03 Brake Electronics	Output Tests	
Audi A3	2006	8P	03 Brake Electronics	Specia Functions	
Audi A3	2006	8P	08 AC/Heating Electronics	Read Fault Codes	
Audi A3	2006	8P	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3	2006	8P	08 AC/Heating Electronics	Measuring Blocks	
Audi A3	2006	8P	08 AC/Heating Electronics	Output Tests	
Audi A3	2006	8P	08 AC/Heating Electronics	Specia Functions	
Audi A3	2006	8P	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3	2006	8P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3	2006	8P	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3	2006	8P	09 Electronic Ctrl Electronics	Output Tests	
Audi A3	2006	8P	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3	2006	8P	0F Radio Tuner-Digital	Read Fault Codes	
Audi A3	2006	8P	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A3	2006	8P	0F Radio Tuner-Digital	Measuring Blocks	
Audi A3	2006	8P	0F Radio Tuner-Digital	Output Tests	
Audi A3	2006	8P	0F Radio Tuner-Digital	Specia Functions	
Audi A3	2006	8P	11 Engine Electronics 2	Read Fault Codes	
Audi A3	2006	8P	11 Engine Electronics 2	Clear Fault Codes	
Audi A3	2006	8P	11 Engine Electronics 2	Measuring Blocks	
Audi A3	2006	8P	11 Engine Electronics 2	Output Tests	
Audi A3	2006	8P	11 Engine Electronics 2	Specia Functions	
Audi A3	2006	8P	15 Airbags	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2006	8P	15 Airbags	Clear Fault Codes	
Audi A3	2006	8P	15 Airbags	Measuring Blocks	
Audi A3	2006	8P	15 Airbags	Output Tests	
Audi A3	2006	8P	15 Airbags	Specia Functions	
Audi A3	2006	8P	16 Steering Wheel Electronics	Read Fault Codes	
Audi A3	2006	8P	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3	2006	8P	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3	2006	8P	16 Steering Wheel Electronics	Output Tests	
Audi A3	2006	8P	16 Steering Wheel Electronics	Specia Functions	
Audi A3	2006	8P	17 Instrument Cluster	Read Fault Codes	
Audi A3	2006	8P	17 Instrument Cluster	Clear Fault Codes	
Audi A3	2006	8P	17 Instrument Cluster	Measuring Blocks	
Audi A3	2006	8P	17 Instrument Cluster	Output Tests	
Audi A3	2006	8P	17 Instrument Cluster	Specia Functions	
Audi A3	2006	8P	18 Aux Heating	Read Fault Codes	
Audi A3	2006	8P	18 Aux Heating	Clear Fault Codes	
Audi A3	2006	8P	18 Aux Heating	Measuring Blocks	
Audi A3	2006	8P	18 Aux Heating	Output Tests	
Audi A3	2006	8P	18 Aux Heating	Specia Functions	
Audi A3	2006	8P	19 Gateway Data Bus	Read Fault Codes	
Audi A3	2006	8P	19 Gateway Data Bus	Clear Fault Codes	
Audi A3	2006	8P	19 Gateway Data Bus	Measuring Blocks	
Audi A3	2006	8P	19 Gateway Data Bus	Output Tests	
Audi A3	2006	8P	19 Gateway Data Bus	Specia Functions	
Audi A3	2006	8P	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2006	8P	22 4WD Electronics	Clear Fault Codes	
Audi A3	2006	8P	22 4WD Electronics	Measuring Blocks	
Audi A3	2006	8P	22 4WD Electronics	Output Tests	
Audi A3	2006	8P	22 4WD Electronics	Specia Functions	
Audi A3	2006	8P	25 Immobilizer	Read Fault Codes	
Audi A3	2006	8P	25 Immobilizer	Clear Fault Codes	
Audi A3	2006	8P	25 Immobilizer	Measuring Blocks	
Audi A3	2006	8P	25 Immobilizer	Output Tests	
Audi A3	2006	8P	25 Immobilizer	Specia Functions	
Audi A3	2006	8P	37 Navigation	Read Fault Codes	
Audi A3	2006	8P	37 Navigation	Clear Fault Codes	
Audi A3	2006	8P	37 Navigation	Measuring Blocks	
Audi A3	2006	8P	37 Navigation	Output Tests	
Audi A3	2006	8P	37 Navigation	Specia Functions	
Audi A3	2006	8P	42 Driver-Door Elect.	Read Fault Codes	
Audi A3	2006	8P	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3	2006	8P	42 Driver-Door Elect.	Measuring Blocks	
Audi A3	2006	8P	42 Driver-Door Elect.	Output Tests	
Audi A3	2006	8P	42 Driver-Door Elect.	Specia Functions	
Audi A3	2006	8P	44 Steering Assistance	Read Fault Codes	
Audi A3	2006	8P	44 Steering Assistance	Clear Fault Codes	
Audi A3	2006	8P	44 Steering Assistance	Measuring Blocks	
Audi A3	2006	8P	44 Steering Assistance	Output Tests	
Audi A3	2006	8P	44 Steering Assistance	Specia Functions	
Audi A3	2006	8P	46 Central Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2006	8P	46 Central Control Module	Clear Fault Codes	
Audi A3	2006	8P	46 Central Control Module	Measuring Blocks	
Audi A3	2006	8P	46 Central Control Module	Output Tests	
Audi A3	2006	8P	46 Central Control Module	Specia Functions	
Audi A3	2006	8P	47 Soundsystem	Read Fault Codes	
Audi A3	2006	8P	47 Soundsystem	Clear Fault Codes	
Audi A3	2006	8P	47 Soundsystem	Measuring Blocks	
Audi A3	2006	8P	47 Soundsystem	Output Tests	
Audi A3	2006	8P	47 Soundsystem	Specia Functions	
Audi A3	2006	8P	51 Electric Drive	Read Fault Codes	
Audi A3	2006	8P	51 Electric Drive	Clear Fault Codes	
Audi A3	2006	8P	51 Electric Drive	Measuring Blocks	
Audi A3	2006	8P	51 Electric Drive	Output Tests	
Audi A3	2006	8P	51 Electric Drive	Specia Functions	
Audi A3	2006	8P	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3	2006	8P	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3	2006	8P	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3	2006	8P	52 Passe.-Door Elect.	Output Tests	
Audi A3	2006	8P	52 Passe.-Door Elect.	Specia Functions	
Audi A3	2006	8P	55 Headlight Range Control	Read Fault Codes	
Audi A3	2006	8P	55 Headlight Range Control	Clear Fault Codes	
Audi A3	2006	8P	55 Headlight Range Control	Measuring Blocks	
Audi A3	2006	8P	55 Headlight Range Control	Output Tests	
Audi A3	2006	8P	55 Headlight Range Control	Specia Functions	
Audi A3	2006	8P	56 Radio	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2006	8P	56 Radio	Clear Fault Codes	
Audi A3	2006	8P	56 Radio	Measuring Blocks	
Audi A3	2006	8P	56 Radio	Output Tests	
Audi A3	2006	8P	56 Radio	Specia Functions	
Audi A3	2006	8P	57 TV-Tuner	Read Fault Codes	
Audi A3	2006	8P	57 TV-Tuner	Clear Fault Codes	
Audi A3	2006	8P	57 TV-Tuner	Measuring Blocks	
Audi A3	2006	8P	57 TV-Tuner	Output Tests	
Audi A3	2006	8P	57 TV-Tuner	Specia Functions	
Audi A3	2006	8P	62 LR-Door Electroni.	Read Fault Codes	
Audi A3	2006	8P	62 LR-Door Electroni.	Clear Fault Codes	
Audi A3	2006	8P	62 LR-Door Electroni.	Measuring Blocks	
Audi A3	2006	8P	62 LR-Door Electroni.	Output Tests	
Audi A3	2006	8P	62 LR-Door Electroni.	Specia Functions	
Audi A3	2006	8P	69 Trailer Function	Read Fault Codes	
Audi A3	2006	8P	69 Trailer Function	Clear Fault Codes	
Audi A3	2006	8P	69 Trailer Function	Measuring Blocks	
Audi A3	2006	8P	69 Trailer Function	Output Tests	
Audi A3	2006	8P	69 Trailer Function	Specia Functions	
Audi A3	2006	8P	72 RR-Door Electroni.	Read Fault Codes	
Audi A3	2006	8P	72 RR-Door Electroni.	Clear Fault Codes	
Audi A3	2006	8P	72 RR-Door Electroni.	Measuring Blocks	
Audi A3	2006	8P	72 RR-Door Electroni.	Output Tests	
Audi A3	2006	8P	72 RR-Door Electroni.	Specia Functions	
Audi A3	2006	8P	76 Parking Aid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2006	8P	76 Parking Aid	Clear Fault Codes	
Audi A3	2006	8P	76 Parking Aid	Measuring Blocks	
Audi A3	2006	8P	76 Parking Aid	Output Tests	
Audi A3	2006	8P	76 Parking Aid	Specia Functions	
Audi A3	2006	8P	77 Telephone	Read Fault Codes	
Audi A3	2006	8P	77 Telephone	Clear Fault Codes	
Audi A3	2006	8P	77 Telephone	Measuring Blocks	
Audi A3	2006	8P	77 Telephone	Output Tests	
Audi A3	2006	8P	77 Telephone	Specia Functions	
Audi A3	2006	8P	7D Auxiliary Heater	Read Fault Codes	
Audi A3	2006	8P	7D Auxiliary Heater	Clear Fault Codes	
Audi A3	2006	8P	7D Auxiliary Heater	Measuring Blocks	
Audi A3	2006	8P	7D Auxiliary Heater	Output Tests	
Audi A3	2006	8P	7D Auxiliary Heater	Specia Functions	
Audi A3	2006	8P	8C Hybrid Battery	Read Fault Codes	
Audi A3	2006	8P	8C Hybrid Battery	Clear Fault Codes	
Audi A3	2006	8P	8C Hybrid Battery	Measuring Blocks	
Audi A3	2006	8P	8C Hybrid Battery	Output Tests	
Audi A3	2006	8P	8C Hybrid Battery	Specia Functions	
Audi A3	2007	8P	01 Engine Electronics	Read Fault Codes	
Audi A3	2007	8P	01 Engine Electronics	Clear Fault Codes	
Audi A3	2007	8P	01 Engine Electronics	Measuring Blocks	
Audi A3	2007	8P	01 Engine Electronics	Output Tests	
Audi A3	2007	8P	01 Engine Electronics	Specia Functions	
Audi A3	2007	8P	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2007	8P	02 Transmission Electronics	Clear Fault Codes	
Audi A3	2007	8P	02 Transmission Electronics	Measuring Blocks	
Audi A3	2007	8P	02 Transmission Electronics	Output Tests	
Audi A3	2007	8P	02 Transmission Electronics	Specia Functions	
Audi A3	2007	8P	03 Brake Electronics	Read Fault Codes	
Audi A3	2007	8P	03 Brake Electronics	Clear Fault Codes	
Audi A3	2007	8P	03 Brake Electronics	Measuring Blocks	
Audi A3	2007	8P	03 Brake Electronics	Output Tests	
Audi A3	2007	8P	03 Brake Electronics	Specia Functions	
Audi A3	2007	8P	08 AC/Heating Electronics	Read Fault Codes	
Audi A3	2007	8P	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3	2007	8P	08 AC/Heating Electronics	Measuring Blocks	
Audi A3	2007	8P	08 AC/Heating Electronics	Output Tests	
Audi A3	2007	8P	08 AC/Heating Electronics	Specia Functions	
Audi A3	2007	8P	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3	2007	8P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3	2007	8P	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3	2007	8P	09 Electronic Ctrl Electronics	Output Tests	
Audi A3	2007	8P	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3	2007	8P	0F Radio Tuner-Digital	Read Fault Codes	
Audi A3	2007	8P	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A3	2007	8P	0F Radio Tuner-Digital	Measuring Blocks	
Audi A3	2007	8P	0F Radio Tuner-Digital	Output Tests	
Audi A3	2007	8P	0F Radio Tuner-Digital	Specia Functions	
Audi A3	2007	8P	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2007	8P	11 Engine Electronics 2	Clear Fault Codes	
Audi A3	2007	8P	11 Engine Electronics 2	Measuring Blocks	
Audi A3	2007	8P	11 Engine Electronics 2	Output Tests	
Audi A3	2007	8P	11 Engine Electronics 2	Specia Functions	
Audi A3	2007	8P	15 Airbags	Read Fault Codes	
Audi A3	2007	8P	15 Airbags	Clear Fault Codes	
Audi A3	2007	8P	15 Airbags	Measuring Blocks	
Audi A3	2007	8P	15 Airbags	Output Tests	
Audi A3	2007	8P	15 Airbags	Specia Functions	
Audi A3	2007	8P	16 Steering Wheel Electronics	Read Fault Codes	
Audi A3	2007	8P	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3	2007	8P	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3	2007	8P	16 Steering Wheel Electronics	Output Tests	
Audi A3	2007	8P	16 Steering Wheel Electronics	Specia Functions	
Audi A3	2007	8P	17 Instrument Cluster	Read Fault Codes	
Audi A3	2007	8P	17 Instrument Cluster	Clear Fault Codes	
Audi A3	2007	8P	17 Instrument Cluster	Measuring Blocks	
Audi A3	2007	8P	17 Instrument Cluster	Output Tests	
Audi A3	2007	8P	17 Instrument Cluster	Specia Functions	
Audi A3	2007	8P	18 Aux Heating	Read Fault Codes	
Audi A3	2007	8P	18 Aux Heating	Clear Fault Codes	
Audi A3	2007	8P	18 Aux Heating	Measuring Blocks	
Audi A3	2007	8P	18 Aux Heating	Output Tests	
Audi A3	2007	8P	18 Aux Heating	Specia Functions	
Audi A3	2007	8P	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2007	8P	19 Gateway Data Bus	Clear Fault Codes	
Audi A3	2007	8P	19 Gateway Data Bus	Measuring Blocks	
Audi A3	2007	8P	19 Gateway Data Bus	Output Tests	
Audi A3	2007	8P	19 Gateway Data Bus	Specia Functions	
Audi A3	2007	8P	22 4WD Electronics	Read Fault Codes	
Audi A3	2007	8P	22 4WD Electronics	Clear Fault Codes	
Audi A3	2007	8P	22 4WD Electronics	Measuring Blocks	
Audi A3	2007	8P	22 4WD Electronics	Output Tests	
Audi A3	2007	8P	22 4WD Electronics	Specia Functions	
Audi A3	2007	8P	25 Immobilizer	Read Fault Codes	
Audi A3	2007	8P	25 Immobilizer	Clear Fault Codes	
Audi A3	2007	8P	25 Immobilizer	Measuring Blocks	
Audi A3	2007	8P	25 Immobilizer	Output Tests	
Audi A3	2007	8P	25 Immobilizer	Specia Functions	
Audi A3	2007	8P	37 Navigation	Read Fault Codes	
Audi A3	2007	8P	37 Navigation	Clear Fault Codes	
Audi A3	2007	8P	37 Navigation	Measuring Blocks	
Audi A3	2007	8P	37 Navigation	Output Tests	
Audi A3	2007	8P	37 Navigation	Specia Functions	
Audi A3	2007	8P	42 Driver-Door Elect.	Read Fault Codes	
Audi A3	2007	8P	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3	2007	8P	42 Driver-Door Elect.	Measuring Blocks	
Audi A3	2007	8P	42 Driver-Door Elect.	Output Tests	
Audi A3	2007	8P	42 Driver-Door Elect.	Specia Functions	
Audi A3	2007	8P	44 Steering Assistance	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2007	8P	44 Steering Assistance	Clear Fault Codes	
Audi A3	2007	8P	44 Steering Assistance	Measuring Blocks	
Audi A3	2007	8P	44 Steering Assistance	Output Tests	
Audi A3	2007	8P	44 Steering Assistance	Specia Functions	
Audi A3	2007	8P	46 Central Control Module	Read Fault Codes	
Audi A3	2007	8P	46 Central Control Module	Clear Fault Codes	
Audi A3	2007	8P	46 Central Control Module	Measuring Blocks	
Audi A3	2007	8P	46 Central Control Module	Output Tests	
Audi A3	2007	8P	46 Central Control Module	Specia Functions	
Audi A3	2007	8P	47 Soundsystem	Read Fault Codes	
Audi A3	2007	8P	47 Soundsystem	Clear Fault Codes	
Audi A3	2007	8P	47 Soundsystem	Measuring Blocks	
Audi A3	2007	8P	47 Soundsystem	Output Tests	
Audi A3	2007	8P	47 Soundsystem	Specia Functions	
Audi A3	2007	8P	51 Electric Drive	Read Fault Codes	
Audi A3	2007	8P	51 Electric Drive	Clear Fault Codes	
Audi A3	2007	8P	51 Electric Drive	Measuring Blocks	
Audi A3	2007	8P	51 Electric Drive	Output Tests	
Audi A3	2007	8P	51 Electric Drive	Specia Functions	
Audi A3	2007	8P	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3	2007	8P	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3	2007	8P	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3	2007	8P	52 Passe.-Door Elect.	Output Tests	
Audi A3	2007	8P	52 Passe.-Door Elect.	Specia Functions	
Audi A3	2007	8P	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2007	8P	55 Headlight Range Control	Clear Fault Codes	
Audi A3	2007	8P	55 Headlight Range Control	Measuring Blocks	
Audi A3	2007	8P	55 Headlight Range Control	Output Tests	
Audi A3	2007	8P	55 Headlight Range Control	Specia Functions	
Audi A3	2007	8P	56 Radio	Read Fault Codes	
Audi A3	2007	8P	56 Radio	Clear Fault Codes	
Audi A3	2007	8P	56 Radio	Measuring Blocks	
Audi A3	2007	8P	56 Radio	Output Tests	
Audi A3	2007	8P	56 Radio	Specia Functions	
Audi A3	2007	8P	57 TV-Tuner	Read Fault Codes	
Audi A3	2007	8P	57 TV-Tuner	Clear Fault Codes	
Audi A3	2007	8P	57 TV-Tuner	Measuring Blocks	
Audi A3	2007	8P	57 TV-Tuner	Output Tests	
Audi A3	2007	8P	57 TV-Tuner	Specia Functions	
Audi A3	2007	8P	62 LR-Door Electroni.	Read Fault Codes	
Audi A3	2007	8P	62 LR-Door Electroni.	Clear Fault Codes	
Audi A3	2007	8P	62 LR-Door Electroni.	Measuring Blocks	
Audi A3	2007	8P	62 LR-Door Electroni.	Output Tests	
Audi A3	2007	8P	62 LR-Door Electroni.	Specia Functions	
Audi A3	2007	8P	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A3	2007	8P	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A3	2007	8P	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A3	2007	8P	65 Tyre Pressure Monitoring	Output Tests	
Audi A3	2007	8P	65 Tyre Pressure Monitoring	Specia Functions	
Audi A3	2007	8P	69 Trailer Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2007	8P	69 Trailer Function	Clear Fault Codes	
Audi A3	2007	8P	69 Trailer Function	Measuring Blocks	
Audi A3	2007	8P	69 Trailer Function	Output Tests	
Audi A3	2007	8P	69 Trailer Function	Specia Functions	
Audi A3	2007	8P	72 RR-Door Electroni.	Read Fault Codes	
Audi A3	2007	8P	72 RR-Door Electroni.	Clear Fault Codes	
Audi A3	2007	8P	72 RR-Door Electroni.	Measuring Blocks	
Audi A3	2007	8P	72 RR-Door Electroni.	Output Tests	
Audi A3	2007	8P	72 RR-Door Electroni.	Specia Functions	
Audi A3	2007	8P	76 Parking Aid	Read Fault Codes	
Audi A3	2007	8P	76 Parking Aid	Clear Fault Codes	
Audi A3	2007	8P	76 Parking Aid	Measuring Blocks	
Audi A3	2007	8P	76 Parking Aid	Output Tests	
Audi A3	2007	8P	76 Parking Aid	Specia Functions	
Audi A3	2007	8P	77 Telephone	Read Fault Codes	
Audi A3	2007	8P	77 Telephone	Clear Fault Codes	
Audi A3	2007	8P	77 Telephone	Measuring Blocks	
Audi A3	2007	8P	77 Telephone	Output Tests	
Audi A3	2007	8P	77 Telephone	Specia Functions	
Audi A3	2007	8P	7D Auxiliary Heater	Read Fault Codes	
Audi A3	2007	8P	7D Auxiliary Heater	Clear Fault Codes	
Audi A3	2007	8P	7D Auxiliary Heater	Measuring Blocks	
Audi A3	2007	8P	7D Auxiliary Heater	Output Tests	
Audi A3	2007	8P	7D Auxiliary Heater	Specia Functions	
Audi A3	2007	8P	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2007	8P	8C Hybrid Battery	Clear Fault Codes	
Audi A3	2007	8P	8C Hybrid Battery	Measuring Blocks	
Audi A3	2007	8P	8C Hybrid Battery	Output Tests	
Audi A3	2007	8P	8C Hybrid Battery	Specia Functions	
Audi A3	2008	8P	01 Engine Electronics	Read Fault Codes	
Audi A3	2008	8P	01 Engine Electronics	Clear Fault Codes	
Audi A3	2008	8P	01 Engine Electronics	Measuring Blocks	
Audi A3	2008	8P	01 Engine Electronics	Output Tests	
Audi A3	2008	8P	01 Engine Electronics	Specia Functions	
Audi A3	2008	8P	02 Transmission Electronics	Read Fault Codes	
Audi A3	2008	8P	02 Transmission Electronics	Clear Fault Codes	
Audi A3	2008	8P	02 Transmission Electronics	Measuring Blocks	
Audi A3	2008	8P	02 Transmission Electronics	Output Tests	
Audi A3	2008	8P	02 Transmission Electronics	Specia Functions	
Audi A3	2008	8P	03 Brake Electronics	Read Fault Codes	
Audi A3	2008	8P	03 Brake Electronics	Clear Fault Codes	
Audi A3	2008	8P	03 Brake Electronics	Measuring Blocks	
Audi A3	2008	8P	03 Brake Electronics	Output Tests	
Audi A3	2008	8P	03 Brake Electronics	Specia Functions	
Audi A3	2008	8P	08 AC/Heating Electronics	Read Fault Codes	
Audi A3	2008	8P	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3	2008	8P	08 AC/Heating Electronics	Measuring Blocks	
Audi A3	2008	8P	08 AC/Heating Electronics	Output Tests	
Audi A3	2008	8P	08 AC/Heating Electronics	Specia Functions	
Audi A3	2008	8P	09 Electronic Ctrl Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008	8P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3	2008	8P	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3	2008	8P	09 Electronic Ctrl Electronics	Output Tests	
Audi A3	2008	8P	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3	2008	8P	0F Radio Tuner-Digital	Read Fault Codes	
Audi A3	2008	8P	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A3	2008	8P	0F Radio Tuner-Digital	Measuring Blocks	
Audi A3	2008	8P	0F Radio Tuner-Digital	Output Tests	
Audi A3	2008	8P	0F Radio Tuner-Digital	Specia Functions	
Audi A3	2008	8P	10 Parking Assist System 2	Read Fault Codes	
Audi A3	2008	8P	10 Parking Assist System 2	Clear Fault Codes	
Audi A3	2008	8P	10 Parking Assist System 2	Measuring Blocks	
Audi A3	2008	8P	10 Parking Assist System 2	Output Tests	
Audi A3	2008	8P	10 Parking Assist System 2	Specia Functions	
Audi A3	2008	8P	11 Engine Electronics 2	Read Fault Codes	
Audi A3	2008	8P	11 Engine Electronics 2	Clear Fault Codes	
Audi A3	2008	8P	11 Engine Electronics 2	Measuring Blocks	
Audi A3	2008	8P	11 Engine Electronics 2	Output Tests	
Audi A3	2008	8P	11 Engine Electronics 2	Specia Functions	
Audi A3	2008	8P	15 Airbags	Read Fault Codes	
Audi A3	2008	8P	15 Airbags	Clear Fault Codes	
Audi A3	2008	8P	15 Airbags	Measuring Blocks	
Audi A3	2008	8P	15 Airbags	Output Tests	
Audi A3	2008	8P	15 Airbags	Specia Functions	
Audi A3	2008	8P	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008	8P	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3	2008	8P	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3	2008	8P	16 Steering Wheel Electronics	Output Tests	
Audi A3	2008	8P	16 Steering Wheel Electronics	Specia Functions	
Audi A3	2008	8P	17 Instrument Cluster	Read Fault Codes	
Audi A3	2008	8P	17 Instrument Cluster	Clear Fault Codes	
Audi A3	2008	8P	17 Instrument Cluster	Measuring Blocks	
Audi A3	2008	8P	17 Instrument Cluster	Output Tests	
Audi A3	2008	8P	17 Instrument Cluster	Specia Functions	
Audi A3	2008	8P	18 Aux Heating	Read Fault Codes	
Audi A3	2008	8P	18 Aux Heating	Clear Fault Codes	
Audi A3	2008	8P	18 Aux Heating	Measuring Blocks	
Audi A3	2008	8P	18 Aux Heating	Output Tests	
Audi A3	2008	8P	18 Aux Heating	Specia Functions	
Audi A3	2008	8P	19 Gateway Data Bus	Read Fault Codes	
Audi A3	2008	8P	19 Gateway Data Bus	Clear Fault Codes	
Audi A3	2008	8P	19 Gateway Data Bus	Measuring Blocks	
Audi A3	2008	8P	19 Gateway Data Bus	Output Tests	
Audi A3	2008	8P	19 Gateway Data Bus	Specia Functions	
Audi A3	2008	8P	22 4WD Electronics	Read Fault Codes	
Audi A3	2008	8P	22 4WD Electronics	Clear Fault Codes	
Audi A3	2008	8P	22 4WD Electronics	Measuring Blocks	
Audi A3	2008	8P	22 4WD Electronics	Output Tests	
Audi A3	2008	8P	22 4WD Electronics	Specia Functions	
Audi A3	2008	8P	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008	8P	25 Immobilizer	Clear Fault Codes	
Audi A3	2008	8P	25 Immobilizer	Measuring Blocks	
Audi A3	2008	8P	25 Immobilizer	Output Tests	
Audi A3	2008	8P	25 Immobilizer	Specia Functions	
Audi A3	2008	8P	26 Electric Roof Control	Read Fault Codes	
Audi A3	2008	8P	26 Electric Roof Control	Clear Fault Codes	
Audi A3	2008	8P	26 Electric Roof Control	Measuring Blocks	
Audi A3	2008	8P	26 Electric Roof Control	Output Tests	
Audi A3	2008	8P	26 Electric Roof Control	Specia Functions	
Audi A3	2008	8P	37 Navigation	Read Fault Codes	
Audi A3	2008	8P	37 Navigation	Clear Fault Codes	
Audi A3	2008	8P	37 Navigation	Measuring Blocks	
Audi A3	2008	8P	37 Navigation	Output Tests	
Audi A3	2008	8P	37 Navigation	Specia Functions	
Audi A3	2008	8P	42 Driver-Door Elect.	Read Fault Codes	
Audi A3	2008	8P	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3	2008	8P	42 Driver-Door Elect.	Measuring Blocks	
Audi A3	2008	8P	42 Driver-Door Elect.	Output Tests	
Audi A3	2008	8P	42 Driver-Door Elect.	Specia Functions	
Audi A3	2008	8P	44 Steering Assistance	Read Fault Codes	
Audi A3	2008	8P	44 Steering Assistance	Clear Fault Codes	
Audi A3	2008	8P	44 Steering Assistance	Measuring Blocks	
Audi A3	2008	8P	44 Steering Assistance	Output Tests	
Audi A3	2008	8P	44 Steering Assistance	Specia Functions	
Audi A3	2008	8P	46 Central Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008	8P	46 Central Control Module	Clear Fault Codes	
Audi A3	2008	8P	46 Central Control Module	Measuring Blocks	
Audi A3	2008	8P	46 Central Control Module	Output Tests	
Audi A3	2008	8P	46 Central Control Module	Specia Functions	
Audi A3	2008	8P	47 Soundsystem	Read Fault Codes	
Audi A3	2008	8P	47 Soundsystem	Clear Fault Codes	
Audi A3	2008	8P	47 Soundsystem	Measuring Blocks	
Audi A3	2008	8P	47 Soundsystem	Output Tests	
Audi A3	2008	8P	47 Soundsystem	Specia Functions	
Audi A3	2008	8P	51 Electric Drive	Read Fault Codes	
Audi A3	2008	8P	51 Electric Drive	Clear Fault Codes	
Audi A3	2008	8P	51 Electric Drive	Measuring Blocks	
Audi A3	2008	8P	51 Electric Drive	Output Tests	
Audi A3	2008	8P	51 Electric Drive	Specia Functions	
Audi A3	2008	8P	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3	2008	8P	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3	2008	8P	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3	2008	8P	52 Passe.-Door Elect.	Output Tests	
Audi A3	2008	8P	52 Passe.-Door Elect.	Specia Functions	
Audi A3	2008	8P	55 Headlight Range Control	Read Fault Codes	
Audi A3	2008	8P	55 Headlight Range Control	Clear Fault Codes	
Audi A3	2008	8P	55 Headlight Range Control	Measuring Blocks	
Audi A3	2008	8P	55 Headlight Range Control	Output Tests	
Audi A3	2008	8P	55 Headlight Range Control	Specia Functions	
Audi A3	2008	8P	56 Radio	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008	8P	56 Radio	Clear Fault Codes	
Audi A3	2008	8P	56 Radio	Measuring Blocks	
Audi A3	2008	8P	56 Radio	Output Tests	
Audi A3	2008	8P	56 Radio	Specia Functions	
Audi A3	2008	8P	57 TV-Tuner	Read Fault Codes	
Audi A3	2008	8P	57 TV-Tuner	Clear Fault Codes	
Audi A3	2008	8P	57 TV-Tuner	Measuring Blocks	
Audi A3	2008	8P	57 TV-Tuner	Output Tests	
Audi A3	2008	8P	57 TV-Tuner	Specia Functions	
Audi A3	2008	8P	62 LR-Door Electroni.	Read Fault Codes	
Audi A3	2008	8P	62 LR-Door Electroni.	Clear Fault Codes	
Audi A3	2008	8P	62 LR-Door Electroni.	Measuring Blocks	
Audi A3	2008	8P	62 LR-Door Electroni.	Output Tests	
Audi A3	2008	8P	62 LR-Door Electroni.	Specia Functions	
Audi A3	2008	8P	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A3	2008	8P	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A3	2008	8P	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A3	2008	8P	65 Tyre Pressure Monitoring	Output Tests	
Audi A3	2008	8P	65 Tyre Pressure Monitoring	Specia Functions	
Audi A3	2008	8P	69 Trailer Function	Read Fault Codes	
Audi A3	2008	8P	69 Trailer Function	Clear Fault Codes	
Audi A3	2008	8P	69 Trailer Function	Measuring Blocks	
Audi A3	2008	8P	69 Trailer Function	Output Tests	
Audi A3	2008	8P	69 Trailer Function	Specia Functions	
Audi A3	2008	8P	72 RR-Door Electroni.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2008	8P	72 RR-Door Electroni.	Clear Fault Codes	
Audi A3	2008	8P	72 RR-Door Electroni.	Measuring Blocks	
Audi A3	2008	8P	72 RR-Door Electroni.	Output Tests	
Audi A3	2008	8P	72 RR-Door Electroni.	Specia Functions	
Audi A3	2008	8P	76 Parking Aid	Read Fault Codes	
Audi A3	2008	8P	76 Parking Aid	Clear Fault Codes	
Audi A3	2008	8P	76 Parking Aid	Measuring Blocks	
Audi A3	2008	8P	76 Parking Aid	Output Tests	
Audi A3	2008	8P	76 Parking Aid	Specia Functions	
Audi A3	2008	8P	77 Telephone	Read Fault Codes	
Audi A3	2008	8P	77 Telephone	Clear Fault Codes	
Audi A3	2008	8P	77 Telephone	Measuring Blocks	
Audi A3	2008	8P	77 Telephone	Output Tests	
Audi A3	2008	8P	77 Telephone	Specia Functions	
Audi A3	2008	8P	7D Auxiliary Heater	Read Fault Codes	
Audi A3	2008	8P	7D Auxiliary Heater	Clear Fault Codes	
Audi A3	2008	8P	7D Auxiliary Heater	Measuring Blocks	
Audi A3	2008	8P	7D Auxiliary Heater	Output Tests	
Audi A3	2008	8P	7D Auxiliary Heater	Specia Functions	
Audi A3	2008	8P	8C Hybrid Battery	Read Fault Codes	
Audi A3	2008	8P	8C Hybrid Battery	Clear Fault Codes	
Audi A3	2008	8P	8C Hybrid Battery	Measuring Blocks	
Audi A3	2008	8P	8C Hybrid Battery	Output Tests	
Audi A3	2008	8P	8C Hybrid Battery	Specia Functions	
Audi A3 USA	2006	FM	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 USA	2006	FM	01 Engine Electronics	Clear Fault Codes	
Audi A3 USA	2006	FM	01 Engine Electronics	Measuring Blocks	
Audi A3 USA	2006	FM	01 Engine Electronics	Output Tests	
Audi A3 USA	2006	FM	01 Engine Electronics	Specia Functions	
Audi A3 USA	2006	FM	02 Transmission Electronics	Read Fault Codes	
Audi A3 USA	2006	FM	02 Transmission Electronics	Clear Fault Codes	
Audi A3 USA	2006	FM	02 Transmission Electronics	Measuring Blocks	
Audi A3 USA	2006	FM	02 Transmission Electronics	Output Tests	
Audi A3 USA	2006	FM	02 Transmission Electronics	Specia Functions	
Audi A3 USA	2006	FM	03 Brake Electronics	Read Fault Codes	
Audi A3 USA	2006	FM	03 Brake Electronics	Clear Fault Codes	
Audi A3 USA	2006	FM	03 Brake Electronics	Measuring Blocks	
Audi A3 USA	2006	FM	03 Brake Electronics	Output Tests	
Audi A3 USA	2006	FM	03 Brake Electronics	Specia Functions	
Audi A3 USA	2006	FM	08 AC/Heating Electronics	Read Fault Codes	
Audi A3 USA	2006	FM	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3 USA	2006	FM	08 AC/Heating Electronics	Measuring Blocks	
Audi A3 USA	2006	FM	08 AC/Heating Electronics	Output Tests	
Audi A3 USA	2006	FM	08 AC/Heating Electronics	Specia Functions	
Audi A3 USA	2006	FM	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3 USA	2006	FM	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3 USA	2006	FM	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3 USA	2006	FM	09 Electronic Ctrl Electronics	Output Tests	
Audi A3 USA	2006	FM	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3 USA	2006	FM	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 USA	2006	FM	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A3 USA	2006	FM	0F Radio Tuner-Digital	Measuring Blocks	
Audi A3 USA	2006	FM	0F Radio Tuner-Digital	Output Tests	
Audi A3 USA	2006	FM	0F Radio Tuner-Digital	Specia Functions	
Audi A3 USA	2006	FM	15 Airbags	Read Fault Codes	
Audi A3 USA	2006	FM	15 Airbags	Clear Fault Codes	
Audi A3 USA	2006	FM	15 Airbags	Measuring Blocks	
Audi A3 USA	2006	FM	15 Airbags	Output Tests	
Audi A3 USA	2006	FM	15 Airbags	Specia Functions	
Audi A3 USA	2006	FM	16 Steering Wheel Electronics	Read Fault Codes	
Audi A3 USA	2006	FM	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3 USA	2006	FM	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3 USA	2006	FM	16 Steering Wheel Electronics	Output Tests	
Audi A3 USA	2006	FM	16 Steering Wheel Electronics	Specia Functions	
Audi A3 USA	2006	FM	17 Instrument Cluster	Read Fault Codes	
Audi A3 USA	2006	FM	17 Instrument Cluster	Clear Fault Codes	
Audi A3 USA	2006	FM	17 Instrument Cluster	Measuring Blocks	
Audi A3 USA	2006	FM	17 Instrument Cluster	Output Tests	
Audi A3 USA	2006	FM	17 Instrument Cluster	Specia Functions	
Audi A3 USA	2006	FM	18 Aux Heating	Read Fault Codes	
Audi A3 USA	2006	FM	18 Aux Heating	Clear Fault Codes	
Audi A3 USA	2006	FM	18 Aux Heating	Measuring Blocks	
Audi A3 USA	2006	FM	18 Aux Heating	Output Tests	
Audi A3 USA	2006	FM	18 Aux Heating	Specia Functions	
Audi A3 USA	2006	FM	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 USA	2006	FM	19 Gateway Data Bus	Clear Fault Codes	
Audi A3 USA	2006	FM	19 Gateway Data Bus	Measuring Blocks	
Audi A3 USA	2006	FM	19 Gateway Data Bus	Output Tests	
Audi A3 USA	2006	FM	19 Gateway Data Bus	Specia Functions	
Audi A3 USA	2006	FM	22 4WD Electronics	Read Fault Codes	
Audi A3 USA	2006	FM	22 4WD Electronics	Clear Fault Codes	
Audi A3 USA	2006	FM	22 4WD Electronics	Measuring Blocks	
Audi A3 USA	2006	FM	22 4WD Electronics	Output Tests	
Audi A3 USA	2006	FM	22 4WD Electronics	Specia Functions	
Audi A3 USA	2006	FM	25 Immobilizer	Read Fault Codes	
Audi A3 USA	2006	FM	25 Immobilizer	Clear Fault Codes	
Audi A3 USA	2006	FM	25 Immobilizer	Measuring Blocks	
Audi A3 USA	2006	FM	25 Immobilizer	Output Tests	
Audi A3 USA	2006	FM	25 Immobilizer	Specia Functions	
Audi A3 USA	2006	FM	37 Navigation	Read Fault Codes	
Audi A3 USA	2006	FM	37 Navigation	Clear Fault Codes	
Audi A3 USA	2006	FM	37 Navigation	Measuring Blocks	
Audi A3 USA	2006	FM	37 Navigation	Output Tests	
Audi A3 USA	2006	FM	37 Navigation	Specia Functions	
Audi A3 USA	2006	FM	42 Driver-Door Elect.	Read Fault Codes	
Audi A3 USA	2006	FM	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3 USA	2006	FM	42 Driver-Door Elect.	Measuring Blocks	
Audi A3 USA	2006	FM	42 Driver-Door Elect.	Output Tests	
Audi A3 USA	2006	FM	42 Driver-Door Elect.	Specia Functions	
Audi A3 USA	2006	FM	44 Steering Assistance	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 USA	2006	FM	44 Steering Assistance	Clear Fault Codes	
Audi A3 USA	2006	FM	44 Steering Assistance	Measuring Blocks	
Audi A3 USA	2006	FM	44 Steering Assistance	Output Tests	
Audi A3 USA	2006	FM	44 Steering Assistance	Specia Functions	
Audi A3 USA	2006	FM	46 Central Control Module	Read Fault Codes	
Audi A3 USA	2006	FM	46 Central Control Module	Clear Fault Codes	
Audi A3 USA	2006	FM	46 Central Control Module	Measuring Blocks	
Audi A3 USA	2006	FM	46 Central Control Module	Output Tests	
Audi A3 USA	2006	FM	46 Central Control Module	Specia Functions	
Audi A3 USA	2006	FM	47 Soundsystem	Read Fault Codes	
Audi A3 USA	2006	FM	47 Soundsystem	Clear Fault Codes	
Audi A3 USA	2006	FM	47 Soundsystem	Measuring Blocks	
Audi A3 USA	2006	FM	47 Soundsystem	Output Tests	
Audi A3 USA	2006	FM	47 Soundsystem	Specia Functions	
Audi A3 USA	2006	FM	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3 USA	2006	FM	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3 USA	2006	FM	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3 USA	2006	FM	52 Passe.-Door Elect.	Output Tests	
Audi A3 USA	2006	FM	52 Passe.-Door Elect.	Specia Functions	
Audi A3 USA	2006	FM	55 Headlight Range Control	Read Fault Codes	
Audi A3 USA	2006	FM	55 Headlight Range Control	Clear Fault Codes	
Audi A3 USA	2006	FM	55 Headlight Range Control	Measuring Blocks	
Audi A3 USA	2006	FM	55 Headlight Range Control	Output Tests	
Audi A3 USA	2006	FM	55 Headlight Range Control	Specia Functions	
Audi A3 USA	2006	FM	56 Radio	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 USA	2006	FM	56 Radio	Clear Fault Codes	
Audi A3 USA	2006	FM	56 Radio	Measuring Blocks	
Audi A3 USA	2006	FM	56 Radio	Output Tests	
Audi A3 USA	2006	FM	56 Radio	Specia Functions	
Audi A3 USA	2006	FM	57 TV-Tuner	Read Fault Codes	
Audi A3 USA	2006	FM	57 TV-Tuner	Clear Fault Codes	
Audi A3 USA	2006	FM	57 TV-Tuner	Measuring Blocks	
Audi A3 USA	2006	FM	57 TV-Tuner	Output Tests	
Audi A3 USA	2006	FM	57 TV-Tuner	Specia Functions	
Audi A3 USA	2006	FM	62 LR-Door Electroni.	Read Fault Codes	
Audi A3 USA	2006	FM	62 LR-Door Electroni.	Clear Fault Codes	
Audi A3 USA	2006	FM	62 LR-Door Electroni.	Measuring Blocks	
Audi A3 USA	2006	FM	62 LR-Door Electroni.	Output Tests	
Audi A3 USA	2006	FM	62 LR-Door Electroni.	Specia Functions	
Audi A3 USA	2006	FM	69 Trailer Function	Read Fault Codes	
Audi A3 USA	2006	FM	69 Trailer Function	Clear Fault Codes	
Audi A3 USA	2006	FM	69 Trailer Function	Measuring Blocks	
Audi A3 USA	2006	FM	69 Trailer Function	Output Tests	
Audi A3 USA	2006	FM	69 Trailer Function	Specia Functions	
Audi A3 USA	2006	FM	72 RR-Door Electroni.	Read Fault Codes	
Audi A3 USA	2006	FM	72 RR-Door Electroni.	Clear Fault Codes	
Audi A3 USA	2006	FM	72 RR-Door Electroni.	Measuring Blocks	
Audi A3 USA	2006	FM	72 RR-Door Electroni.	Output Tests	
Audi A3 USA	2006	FM	72 RR-Door Electroni.	Specia Functions	
Audi A3 USA	2006	FM	76 Parking Aid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 USA	2006	FM	76 Parking Aid	Clear Fault Codes	
Audi A3 USA	2006	FM	76 Parking Aid	Measuring Blocks	
Audi A3 USA	2006	FM	76 Parking Aid	Output Tests	
Audi A3 USA	2006	FM	76 Parking Aid	Specia Functions	
Audi A3 USA	2006	FM	77 Telephone	Read Fault Codes	
Audi A3 USA	2006	FM	77 Telephone	Clear Fault Codes	
Audi A3 USA	2006	FM	77 Telephone	Measuring Blocks	
Audi A3 USA	2006	FM	77 Telephone	Output Tests	
Audi A3 USA	2006	FM	77 Telephone	Specia Functions	
Audi A3 USA	2006	FM	7D Auxiliary Heater	Read Fault Codes	
Audi A3 USA	2006	FM	7D Auxiliary Heater	Clear Fault Codes	
Audi A3 USA	2006	FM	7D Auxiliary Heater	Measuring Blocks	
Audi A3 USA	2006	FM	7D Auxiliary Heater	Output Tests	
Audi A3 USA	2006	FM	7D Auxiliary Heater	Specia Functions	
Audi A3 USA	2007-2008	FM	01 Engine Electronics	Read Fault Codes	
Audi A3 USA	2007-2008	FM	01 Engine Electronics	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	01 Engine Electronics	Measuring Blocks	
Audi A3 USA	2007-2008	FM	01 Engine Electronics	Output Tests	
Audi A3 USA	2007-2008	FM	01 Engine Electronics	Specia Functions	
Audi A3 USA	2007-2008	FM	02 Transmission Electronics	Read Fault Codes	
Audi A3 USA	2007-2008	FM	02 Transmission Electronics	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	02 Transmission Electronics	Measuring Blocks	
Audi A3 USA	2007-2008	FM	02 Transmission Electronics	Output Tests	
Audi A3 USA	2007-2008	FM	02 Transmission Electronics	Specia Functions	
Audi A3 USA	2007-2008	FM	03 Brake Electronics	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi A3 USA	2007-2008	FM	03 Brake Electronics	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	03 Brake Electronics	Measuring Blocks	
Audi A3 USA	2007-2008	FM	03 Brake Electronics	Output Tests	
Audi A3 USA	2007-2008	FM	03 Brake Electronics	Specia Functions	
Audi A3 USA	2007-2008	FM	08 AC/Heating Electronics	Read Fault Codes	
Audi A3 USA	2007-2008	FM	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	08 AC/Heating Electronics	Measuring Blocks	
Audi A3 USA	2007-2008	FM	08 AC/Heating Electronics	Output Tests	
Audi A3 USA	2007-2008	FM	08 AC/Heating Electronics	Specia Functions	
Audi A3 USA	2007-2008	FM	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3 USA	2007-2008	FM	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3 USA	2007-2008	FM	09 Electronic Ctrl Electronics	Output Tests	
Audi A3 USA	2007-2008	FM	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3 USA	2007-2008	FM	0F Radio Tuner-Digital	Read Fault Codes	
Audi A3 USA	2007-2008	FM	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	0F Radio Tuner-Digital	Measuring Blocks	
Audi A3 USA	2007-2008	FM	0F Radio Tuner-Digital	Output Tests	
Audi A3 USA	2007-2008	FM	0F Radio Tuner-Digital	Specia Functions	
Audi A3 USA	2007-2008	FM	15 Airbags	Read Fault Codes	
Audi A3 USA	2007-2008	FM	15 Airbags	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	15 Airbags	Measuring Blocks	
Audi A3 USA	2007-2008	FM	15 Airbags	Output Tests	
Audi A3 USA	2007-2008	FM	15 Airbags	Specia Functions	
Audi A3 USA	2007-2008	FM	16 Steering Wheel Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3 USA	2007-2008	FM	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3 USA	2007-2008	FM	16 Steering Wheel Electronics	Output Tests	
Audi A3 USA	2007-2008	FM	16 Steering Wheel Electronics	Specia Functions	
Audi A3 USA	2007-2008	FM	17 Instrument Cluster	Read Fault Codes	
Audi A3 USA	2007-2008	FM	17 Instrument Cluster	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	17 Instrument Cluster	Measuring Blocks	
Audi A3 USA	2007-2008	FM	17 Instrument Cluster	Output Tests	
Audi A3 USA	2007-2008	FM	17 Instrument Cluster	Specia Functions	
Audi A3 USA	2007-2008	FM	18 Aux Heating	Read Fault Codes	
Audi A3 USA	2007-2008	FM	18 Aux Heating	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	18 Aux Heating	Measuring Blocks	
Audi A3 USA	2007-2008	FM	18 Aux Heating	Output Tests	
Audi A3 USA	2007-2008	FM	18 Aux Heating	Specia Functions	
Audi A3 USA	2007-2008	FM	19 Gateway Data Bus	Read Fault Codes	
Audi A3 USA	2007-2008	FM	19 Gateway Data Bus	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	19 Gateway Data Bus	Measuring Blocks	
Audi A3 USA	2007-2008	FM	19 Gateway Data Bus	Output Tests	
Audi A3 USA	2007-2008	FM	19 Gateway Data Bus	Specia Functions	
Audi A3 USA	2007-2008	FM	22 4WD Electronics	Read Fault Codes	
Audi A3 USA	2007-2008	FM	22 4WD Electronics	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	22 4WD Electronics	Measuring Blocks	
Audi A3 USA	2007-2008	FM	22 4WD Electronics	Output Tests	
Audi A3 USA	2007-2008	FM	22 4WD Electronics	Specia Functions	
Audi A3 USA	2007-2008	FM	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 USA	2007-2008	FM	25 Immobilizer	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	25 Immobilizer	Measuring Blocks	
Audi A3 USA	2007-2008	FM	25 Immobilizer	Output Tests	
Audi A3 USA	2007-2008	FM	25 Immobilizer	Specia Functions	
Audi A3 USA	2007-2008	FM	37 Navigation	Read Fault Codes	
Audi A3 USA	2007-2008	FM	37 Navigation	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	37 Navigation	Measuring Blocks	
Audi A3 USA	2007-2008	FM	37 Navigation	Output Tests	
Audi A3 USA	2007-2008	FM	37 Navigation	Specia Functions	
Audi A3 USA	2007-2008	FM	42 Driver-Door Elect.	Read Fault Codes	
Audi A3 USA	2007-2008	FM	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	42 Driver-Door Elect.	Measuring Blocks	
Audi A3 USA	2007-2008	FM	42 Driver-Door Elect.	Output Tests	
Audi A3 USA	2007-2008	FM	42 Driver-Door Elect.	Specia Functions	
Audi A3 USA	2007-2008	FM	44 Steering Assistance	Read Fault Codes	
Audi A3 USA	2007-2008	FM	44 Steering Assistance	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	44 Steering Assistance	Measuring Blocks	
Audi A3 USA	2007-2008	FM	44 Steering Assistance	Output Tests	
Audi A3 USA	2007-2008	FM	44 Steering Assistance	Specia Functions	
Audi A3 USA	2007-2008	FM	46 Central Control Module	Read Fault Codes	
Audi A3 USA	2007-2008	FM	46 Central Control Module	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	46 Central Control Module	Measuring Blocks	
Audi A3 USA	2007-2008	FM	46 Central Control Module	Output Tests	
Audi A3 USA	2007-2008	FM	46 Central Control Module	Specia Functions	
Audi A3 USA	2007-2008	FM	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 USA	2007-2008	FM	47 Soundsystem	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	47 Soundsystem	Measuring Blocks	
Audi A3 USA	2007-2008	FM	47 Soundsystem	Output Tests	
Audi A3 USA	2007-2008	FM	47 Soundsystem	Specia Functions	
Audi A3 USA	2007-2008	FM	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3 USA	2007-2008	FM	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3 USA	2007-2008	FM	52 Passe.-Door Elect.	Output Tests	
Audi A3 USA	2007-2008	FM	52 Passe.-Door Elect.	Specia Functions	
Audi A3 USA	2007-2008	FM	55 Headlight Range Control	Read Fault Codes	
Audi A3 USA	2007-2008	FM	55 Headlight Range Control	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	55 Headlight Range Control	Measuring Blocks	
Audi A3 USA	2007-2008	FM	55 Headlight Range Control	Output Tests	
Audi A3 USA	2007-2008	FM	55 Headlight Range Control	Specia Functions	
Audi A3 USA	2007-2008	FM	56 Radio	Read Fault Codes	
Audi A3 USA	2007-2008	FM	56 Radio	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	56 Radio	Measuring Blocks	
Audi A3 USA	2007-2008	FM	56 Radio	Output Tests	
Audi A3 USA	2007-2008	FM	56 Radio	Specia Functions	
Audi A3 USA	2007-2008	FM	57 TV-Tuner	Read Fault Codes	
Audi A3 USA	2007-2008	FM	57 TV-Tuner	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	57 TV-Tuner	Measuring Blocks	
Audi A3 USA	2007-2008	FM	57 TV-Tuner	Output Tests	
Audi A3 USA	2007-2008	FM	57 TV-Tuner	Specia Functions	
Audi A3 USA	2007-2008	FM	62 LR-Door Electroni.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3 USA	2007-2008	FM	62 LR-Door Electroni.	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	62 LR-Door Electroni.	Measuring Blocks	
Audi A3 USA	2007-2008	FM	62 LR-Door Electroni.	Output Tests	
Audi A3 USA	2007-2008	FM	62 LR-Door Electroni.	Specia Functions	
Audi A3 USA	2007-2008	FM	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A3 USA	2007-2008	FM	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A3 USA	2007-2008	FM	65 Tyre Pressure Monitoring	Output Tests	
Audi A3 USA	2007-2008	FM	65 Tyre Pressure Monitoring	Specia Functions	
Audi A3 USA	2007-2008	FM	69 Trailer Function	Read Fault Codes	
Audi A3 USA	2007-2008	FM	69 Trailer Function	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	69 Trailer Function	Measuring Blocks	
Audi A3 USA	2007-2008	FM	69 Trailer Function	Output Tests	
Audi A3 USA	2007-2008	FM	69 Trailer Function	Specia Functions	
Audi A3 USA	2007-2008	FM	72 RR-Door Electroni.	Read Fault Codes	
Audi A3 USA	2007-2008	FM	72 RR-Door Electroni.	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	72 RR-Door Electroni.	Measuring Blocks	
Audi A3 USA	2007-2008	FM	72 RR-Door Electroni.	Output Tests	
Audi A3 USA	2007-2008	FM	72 RR-Door Electroni.	Specia Functions	
Audi A3 USA	2007-2008	FM	76 Parking Aid	Read Fault Codes	
Audi A3 USA	2007-2008	FM	76 Parking Aid	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	76 Parking Aid	Measuring Blocks	
Audi A3 USA	2007-2008	FM	76 Parking Aid	Output Tests	
Audi A3 USA	2007-2008	FM	76 Parking Aid	Specia Functions	
Audi A3 USA	2007-2008	FM	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 USA	2007-2008	FM	77 Telephone	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	77 Telephone	Measuring Blocks	
Audi A3 USA	2007-2008	FM	77 Telephone	Output Tests	
Audi A3 USA	2007-2008	FM	77 Telephone	Specia Functions	
Audi A3 USA	2007-2008	FM	7D Auxiliary Heater	Read Fault Codes	
Audi A3 USA	2007-2008	FM	7D Auxiliary Heater	Clear Fault Codes	
Audi A3 USA	2007-2008	FM	7D Auxiliary Heater	Measuring Blocks	
Audi A3 USA	2007-2008	FM	7D Auxiliary Heater	Output Tests	
Audi A3 USA	2007-2008	FM	7D Auxiliary Heater	Specia Functions	
Audi A4	2000-2001	8E	01 Engine Electronics	Read Fault Codes	
Audi A4	2000-2001	8E	01 Engine Electronics	Clear Fault Codes	
Audi A4	2000-2001	8E	01 Engine Electronics	Measuring Blocks	
Audi A4	2000-2001	8E	01 Engine Electronics	Output Tests	
Audi A4	2000-2001	8E	01 Engine Electronics	Specia Functions	
Audi A4	2000-2001	8E	02 Transmission Electronics	Read Fault Codes	
Audi A4	2000-2001	8E	02 Transmission Electronics	Clear Fault Codes	
Audi A4	2000-2001	8E	02 Transmission Electronics	Measuring Blocks	
Audi A4	2000-2001	8E	02 Transmission Electronics	Output Tests	
Audi A4	2000-2001	8E	02 Transmission Electronics	Specia Functions	
Audi A4	2000-2001	8E	03 Brake Electronics	Read Fault Codes	
Audi A4	2000-2001	8E	03 Brake Electronics	Clear Fault Codes	
Audi A4	2000-2001	8E	03 Brake Electronics	Measuring Blocks	
Audi A4	2000-2001	8E	03 Brake Electronics	Output Tests	
Audi A4	2000-2001	8E	03 Brake Electronics	Specia Functions	
Audi A4	2000-2001	8E	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2000-2001	8E	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4	2000-2001	8E	08 AC/Heating Electronics	Measuring Blocks	
Audi A4	2000-2001	8E	08 AC/Heating Electronics	Output Tests	
Audi A4	2000-2001	8E	08 AC/Heating Electronics	Specia Functions	
Audi A4	2000-2001	8E	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A4	2000-2001	8E	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A4	2000-2001	8E	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A4	2000-2001	8E	09 Electronic Ctrl Electronics	Output Tests	
Audi A4	2000-2001	8E	09 Electronic Ctrl Electronics	Specia Functions	
Audi A4	2000-2001	8E	11 Engine Electronics 2	Read Fault Codes	
Audi A4	2000-2001	8E	11 Engine Electronics 2	Clear Fault Codes	
Audi A4	2000-2001	8E	11 Engine Electronics 2	Measuring Blocks	
Audi A4	2000-2001	8E	11 Engine Electronics 2	Output Tests	
Audi A4	2000-2001	8E	11 Engine Electronics 2	Specia Functions	
Audi A4	2000-2001	8E	15 Airbags	Read Fault Codes	
Audi A4	2000-2001	8E	15 Airbags	Clear Fault Codes	
Audi A4	2000-2001	8E	15 Airbags	Measuring Blocks	
Audi A4	2000-2001	8E	15 Airbags	Output Tests	
Audi A4	2000-2001	8E	15 Airbags	Specia Functions	
Audi A4	2000-2001	8E	16 Steering Wheel Electronics	Read Fault Codes	
Audi A4	2000-2001	8E	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4	2000-2001	8E	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4	2000-2001	8E	16 Steering Wheel Electronics	Output Tests	
Audi A4	2000-2001	8E	16 Steering Wheel Electronics	Specia Functions	
Audi A4	2000-2001	8E	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2000-2001	8E	17 Instrument Cluster	Clear Fault Codes	
Audi A4	2000-2001	8E	17 Instrument Cluster	Measuring Blocks	
Audi A4	2000-2001	8E	17 Instrument Cluster	Output Tests	
Audi A4	2000-2001	8E	17 Instrument Cluster	Specia Functions	
Audi A4	2000-2001	8E	18 Aux Heating	Read Fault Codes	
Audi A4	2000-2001	8E	18 Aux Heating	Clear Fault Codes	
Audi A4	2000-2001	8E	18 Aux Heating	Measuring Blocks	
Audi A4	2000-2001	8E	18 Aux Heating	Output Tests	
Audi A4	2000-2001	8E	18 Aux Heating	Specia Functions	
Audi A4	2000-2001	8E	25 Immobilizer	Read Fault Codes	
Audi A4	2000-2001	8E	25 Immobilizer	Clear Fault Codes	
Audi A4	2000-2001	8E	25 Immobilizer	Measuring Blocks	
Audi A4	2000-2001	8E	25 Immobilizer	Output Tests	
Audi A4	2000-2001	8E	25 Immobilizer	Specia Functions	
Audi A4	2000-2001	8E	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A4	2000-2001	8E	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A4	2000-2001	8E	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A4	2000-2001	8E	36 Side of Driver Seat Adj.	Output Tests	
Audi A4	2000-2001	8E	36 Side of Driver Seat Adj.	Specia Functions	
Audi A4	2000-2001	8E	37 Navigation	Read Fault Codes	
Audi A4	2000-2001	8E	37 Navigation	Clear Fault Codes	
Audi A4	2000-2001	8E	37 Navigation	Measuring Blocks	
Audi A4	2000-2001	8E	37 Navigation	Output Tests	
Audi A4	2000-2001	8E	37 Navigation	Specia Functions	
Audi A4	2000-2001	8E	45 Interior Monitoring	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2000-2001	8E	45 Interior Monitoring	Clear Fault Codes	
Audi A4	2000-2001	8E	45 Interior Monitoring	Measuring Blocks	
Audi A4	2000-2001	8E	45 Interior Monitoring	Output Tests	
Audi A4	2000-2001	8E	45 Interior Monitoring	Specia Functions	
Audi A4	2000-2001	8E	46 Central Control Module	Read Fault Codes	
Audi A4	2000-2001	8E	46 Central Control Module	Clear Fault Codes	
Audi A4	2000-2001	8E	46 Central Control Module	Measuring Blocks	
Audi A4	2000-2001	8E	46 Central Control Module	Output Tests	
Audi A4	2000-2001	8E	46 Central Control Module	Specia Functions	
Audi A4	2000-2001	8E	51 Electric Drive	Read Fault Codes	
Audi A4	2000-2001	8E	51 Electric Drive	Clear Fault Codes	
Audi A4	2000-2001	8E	51 Electric Drive	Measuring Blocks	
Audi A4	2000-2001	8E	51 Electric Drive	Output Tests	
Audi A4	2000-2001	8E	51 Electric Drive	Specia Functions	
Audi A4	2000-2001	8E	55 Headlight Range Control	Read Fault Codes	
Audi A4	2000-2001	8E	55 Headlight Range Control	Clear Fault Codes	
Audi A4	2000-2001	8E	55 Headlight Range Control	Measuring Blocks	
Audi A4	2000-2001	8E	55 Headlight Range Control	Output Tests	
Audi A4	2000-2001	8E	55 Headlight Range Control	Specia Functions	
Audi A4	2000-2001	8E	56 Radio	Read Fault Codes	
Audi A4	2000-2001	8E	56 Radio	Clear Fault Codes	
Audi A4	2000-2001	8E	56 Radio	Measuring Blocks	
Audi A4	2000-2001	8E	56 Radio	Output Tests	
Audi A4	2000-2001	8E	56 Radio	Specia Functions	
Audi A4	2000-2001	8E	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2000-2001	8E	57 TV-Tuner	Clear Fault Codes	
Audi A4	2000-2001	8E	57 TV-Tuner	Measuring Blocks	
Audi A4	2000-2001	8E	57 TV-Tuner	Output Tests	
Audi A4	2000-2001	8E	57 TV-Tuner	Specia Functions	
Audi A4	2000-2001	8E	67 Voice Control	Read Fault Codes	
Audi A4	2000-2001	8E	67 Voice Control	Clear Fault Codes	
Audi A4	2000-2001	8E	67 Voice Control	Measuring Blocks	
Audi A4	2000-2001	8E	67 Voice Control	Output Tests	
Audi A4	2000-2001	8E	67 Voice Control	Specia Functions	
Audi A4	2000-2001	8E	75 Emergency Call Module	Read Fault Codes	
Audi A4	2000-2001	8E	75 Emergency Call Module	Clear Fault Codes	
Audi A4	2000-2001	8E	75 Emergency Call Module	Measuring Blocks	
Audi A4	2000-2001	8E	75 Emergency Call Module	Output Tests	
Audi A4	2000-2001	8E	75 Emergency Call Module	Specia Functions	
Audi A4	2000-2001	8E	76 Parking Aid	Read Fault Codes	
Audi A4	2000-2001	8E	76 Parking Aid	Clear Fault Codes	
Audi A4	2000-2001	8E	76 Parking Aid	Measuring Blocks	
Audi A4	2000-2001	8E	76 Parking Aid	Output Tests	
Audi A4	2000-2001	8E	76 Parking Aid	Specia Functions	
Audi A4	2000-2001	8E	77 Telephone	Read Fault Codes	
Audi A4	2000-2001	8E	77 Telephone	Clear Fault Codes	
Audi A4	2000-2001	8E	77 Telephone	Measuring Blocks	
Audi A4	2000-2001	8E	77 Telephone	Output Tests	
Audi A4	2000-2001	8E	77 Telephone	Specia Functions	
Audi A4	2000-2001	8E	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2000-2001	8E	8C Hybrid Battery	Clear Fault Codes	
Audi A4	2000-2001	8E	8C Hybrid Battery	Measuring Blocks	
Audi A4	2000-2001	8E	8C Hybrid Battery	Output Tests	
Audi A4	2000-2001	8E	8C Hybrid Battery	Specia Functions	
Audi A4	2002	8E	01 Engine Electronics	Read Fault Codes	
Audi A4	2002	8E	01 Engine Electronics	Clear Fault Codes	
Audi A4	2002	8E	01 Engine Electronics	Measuring Blocks	
Audi A4	2002	8E	01 Engine Electronics	Output Tests	
Audi A4	2002	8E	01 Engine Electronics	Specia Functions	
Audi A4	2002	8E	02 Transmission Electronics	Read Fault Codes	
Audi A4	2002	8E	02 Transmission Electronics	Clear Fault Codes	
Audi A4	2002	8E	02 Transmission Electronics	Measuring Blocks	
Audi A4	2002	8E	02 Transmission Electronics	Output Tests	
Audi A4	2002	8E	02 Transmission Electronics	Specia Functions	
Audi A4	2002	8E	03 Brake Electronics	Read Fault Codes	
Audi A4	2002	8E	03 Brake Electronics	Clear Fault Codes	
Audi A4	2002	8E	03 Brake Electronics	Measuring Blocks	
Audi A4	2002	8E	03 Brake Electronics	Output Tests	
Audi A4	2002	8E	03 Brake Electronics	Specia Functions	
Audi A4	2002	8E	08 AC/Heating Electronics	Read Fault Codes	
Audi A4	2002	8E	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4	2002	8E	08 AC/Heating Electronics	Measuring Blocks	
Audi A4	2002	8E	08 AC/Heating Electronics	Output Tests	
Audi A4	2002	8E	08 AC/Heating Electronics	Specia Functions	
Audi A4	2002	8E	09 Electronic Ctrl Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2002	8E	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A4	2002	8E	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A4	2002	8E	09 Electronic Ctrl Electronics	Output Tests	
Audi A4	2002	8E	09 Electronic Ctrl Electronics	Specia Functions	
Audi A4	2002	8E	11 Engine Electronics 2	Read Fault Codes	
Audi A4	2002	8E	11 Engine Electronics 2	Clear Fault Codes	
Audi A4	2002	8E	11 Engine Electronics 2	Measuring Blocks	
Audi A4	2002	8E	11 Engine Electronics 2	Output Tests	
Audi A4	2002	8E	11 Engine Electronics 2	Specia Functions	
Audi A4	2002	8E	15 Airbags	Read Fault Codes	
Audi A4	2002	8E	15 Airbags	Clear Fault Codes	
Audi A4	2002	8E	15 Airbags	Measuring Blocks	
Audi A4	2002	8E	15 Airbags	Output Tests	
Audi A4	2002	8E	15 Airbags	Specia Functions	
Audi A4	2002	8E	16 Steering Wheel Electronics	Read Fault Codes	
Audi A4	2002	8E	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4	2002	8E	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4	2002	8E	16 Steering Wheel Electronics	Output Tests	
Audi A4	2002	8E	16 Steering Wheel Electronics	Specia Functions	
Audi A4	2002	8E	17 Instrument Cluster	Read Fault Codes	
Audi A4	2002	8E	17 Instrument Cluster	Clear Fault Codes	
Audi A4	2002	8E	17 Instrument Cluster	Measuring Blocks	
Audi A4	2002	8E	17 Instrument Cluster	Output Tests	
Audi A4	2002	8E	17 Instrument Cluster	Specia Functions	
Audi A4	2002	8E	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2002	8E	18 Aux Heating	Clear Fault Codes	
Audi A4	2002	8E	18 Aux Heating	Measuring Blocks	
Audi A4	2002	8E	18 Aux Heating	Output Tests	
Audi A4	2002	8E	18 Aux Heating	Specia Functions	
Audi A4	2002	8E	25 Immobilizer	Read Fault Codes	
Audi A4	2002	8E	25 Immobilizer	Clear Fault Codes	
Audi A4	2002	8E	25 Immobilizer	Measuring Blocks	
Audi A4	2002	8E	25 Immobilizer	Output Tests	
Audi A4	2002	8E	25 Immobilizer	Specia Functions	
Audi A4	2002	8E	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A4	2002	8E	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A4	2002	8E	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A4	2002	8E	36 Side of Driver Seat Adj.	Output Tests	
Audi A4	2002	8E	36 Side of Driver Seat Adj.	Specia Functions	
Audi A4	2002	8E	37 Navigation	Read Fault Codes	
Audi A4	2002	8E	37 Navigation	Clear Fault Codes	
Audi A4	2002	8E	37 Navigation	Measuring Blocks	
Audi A4	2002	8E	37 Navigation	Output Tests	
Audi A4	2002	8E	37 Navigation	Specia Functions	
Audi A4	2002	8E	45 Interior Monitoring	Read Fault Codes	
Audi A4	2002	8E	45 Interior Monitoring	Clear Fault Codes	
Audi A4	2002	8E	45 Interior Monitoring	Measuring Blocks	
Audi A4	2002	8E	45 Interior Monitoring	Output Tests	
Audi A4	2002	8E	45 Interior Monitoring	Specia Functions	
Audi A4	2002	8E	46 Central Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2002	8E	46 Central Control Module	Clear Fault Codes	
Audi A4	2002	8E	46 Central Control Module	Measuring Blocks	
Audi A4	2002	8E	46 Central Control Module	Output Tests	
Audi A4	2002	8E	46 Central Control Module	Specia Functions	
Audi A4	2002	8E	51 Electric Drive	Read Fault Codes	
Audi A4	2002	8E	51 Electric Drive	Clear Fault Codes	
Audi A4	2002	8E	51 Electric Drive	Measuring Blocks	
Audi A4	2002	8E	51 Electric Drive	Output Tests	
Audi A4	2002	8E	51 Electric Drive	Specia Functions	
Audi A4	2002	8E	55 Headlight Range Control	Read Fault Codes	
Audi A4	2002	8E	55 Headlight Range Control	Clear Fault Codes	
Audi A4	2002	8E	55 Headlight Range Control	Measuring Blocks	
Audi A4	2002	8E	55 Headlight Range Control	Output Tests	
Audi A4	2002	8E	55 Headlight Range Control	Specia Functions	
Audi A4	2002	8E	56 Radio	Read Fault Codes	
Audi A4	2002	8E	56 Radio	Clear Fault Codes	
Audi A4	2002	8E	56 Radio	Measuring Blocks	
Audi A4	2002	8E	56 Radio	Output Tests	
Audi A4	2002	8E	56 Radio	Specia Functions	
Audi A4	2002	8E	57 TV-Tuner	Read Fault Codes	
Audi A4	2002	8E	57 TV-Tuner	Clear Fault Codes	
Audi A4	2002	8E	57 TV-Tuner	Measuring Blocks	
Audi A4	2002	8E	57 TV-Tuner	Output Tests	
Audi A4	2002	8E	57 TV-Tuner	Specia Functions	
Audi A4	2002	8E	67 Voice Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2002	8E	67 Voice Control	Clear Fault Codes	
Audi A4	2002	8E	67 Voice Control	Measuring Blocks	
Audi A4	2002	8E	67 Voice Control	Output Tests	
Audi A4	2002	8E	67 Voice Control	Specia Functions	
Audi A4	2002	8E	75 Emergency Call Module	Read Fault Codes	
Audi A4	2002	8E	75 Emergency Call Module	Clear Fault Codes	
Audi A4	2002	8E	75 Emergency Call Module	Measuring Blocks	
Audi A4	2002	8E	75 Emergency Call Module	Output Tests	
Audi A4	2002	8E	75 Emergency Call Module	Specia Functions	
Audi A4	2002	8E	76 Parking Aid	Read Fault Codes	
Audi A4	2002	8E	76 Parking Aid	Clear Fault Codes	
Audi A4	2002	8E	76 Parking Aid	Measuring Blocks	
Audi A4	2002	8E	76 Parking Aid	Output Tests	
Audi A4	2002	8E	76 Parking Aid	Specia Functions	
Audi A4	2002	8E	77 Telephone	Read Fault Codes	
Audi A4	2002	8E	77 Telephone	Clear Fault Codes	
Audi A4	2002	8E	77 Telephone	Measuring Blocks	
Audi A4	2002	8E	77 Telephone	Output Tests	
Audi A4	2002	8E	77 Telephone	Specia Functions	
Audi A4	2002	8E	8C Hybrid Battery	Read Fault Codes	
Audi A4	2002	8E	8C Hybrid Battery	Clear Fault Codes	
Audi A4	2002	8E	8C Hybrid Battery	Measuring Blocks	
Audi A4	2002	8E	8C Hybrid Battery	Output Tests	
Audi A4	2002	8E	8C Hybrid Battery	Specia Functions	
Audi A4	2003	8E	01 Engine Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4	2003	8E	01 Engine Electronics	Clear Fault Codes	
Audi A4	2003	8E	01 Engine Electronics	Measuring Blocks	
Audi A4	2003	8E	01 Engine Electronics	Output Tests	
Audi A4	2003	8E	01 Engine Electronics	Specia Functions	
Audi A4	2003	8E	02 Transmission Electronics	Read Fault Codes	
Audi A4	2003	8E	02 Transmission Electronics	Clear Fault Codes	
Audi A4	2003	8E	02 Transmission Electronics	Measuring Blocks	
Audi A4	2003	8E	02 Transmission Electronics	Output Tests	
Audi A4	2003	8E	02 Transmission Electronics	Specia Functions	
Audi A4	2003	8E	03 Brake Electronics	Read Fault Codes	
Audi A4	2003	8E	03 Brake Electronics	Clear Fault Codes	
Audi A4	2003	8E	03 Brake Electronics	Measuring Blocks	
Audi A4	2003	8E	03 Brake Electronics	Output Tests	
Audi A4	2003	8E	03 Brake Electronics	Specia Functions	
Audi A4	2003	8E	08 AC/Heating Electronics	Read Fault Codes	
Audi A4	2003	8E	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4	2003	8E	08 AC/Heating Electronics	Measuring Blocks	
Audi A4	2003	8E	08 AC/Heating Electronics	Output Tests	
Audi A4	2003	8E	08 AC/Heating Electronics	Specia Functions	
Audi A4	2003	8E	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A4	2003	8E	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A4	2003	8E	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A4	2003	8E	09 Electronic Ctrl Electronics	Output Tests	
Audi A4	2003	8E	09 Electronic Ctrl Electronics	Specia Functions	
Audi A4	2003	8E	11 Engine Electronics 2	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2003	8E	11 Engine Electronics 2	Clear Fault Codes	
Audi A4	2003	8E	11 Engine Electronics 2	Measuring Blocks	
Audi A4	2003	8E	11 Engine Electronics 2	Output Tests	
Audi A4	2003	8E	11 Engine Electronics 2	Specia Functions	
Audi A4	2003	8E	15 Airbags	Read Fault Codes	
Audi A4	2003	8E	15 Airbags	Clear Fault Codes	
Audi A4	2003	8E	15 Airbags	Measuring Blocks	
Audi A4	2003	8E	15 Airbags	Output Tests	
Audi A4	2003	8E	15 Airbags	Specia Functions	
Audi A4	2003	8E	16 Steering Wheel Electronics	Read Fault Codes	
Audi A4	2003	8E	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4	2003	8E	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4	2003	8E	16 Steering Wheel Electronics	Output Tests	
Audi A4	2003	8E	16 Steering Wheel Electronics	Specia Functions	
Audi A4	2003	8E	17 Instrument Cluster	Read Fault Codes	
Audi A4	2003	8E	17 Instrument Cluster	Clear Fault Codes	
Audi A4	2003	8E	17 Instrument Cluster	Measuring Blocks	
Audi A4	2003	8E	17 Instrument Cluster	Output Tests	
Audi A4	2003	8E	17 Instrument Cluster	Specia Functions	
Audi A4	2003	8E	18 Aux Heating	Read Fault Codes	
Audi A4	2003	8E	18 Aux Heating	Clear Fault Codes	
Audi A4	2003	8E	18 Aux Heating	Measuring Blocks	
Audi A4	2003	8E	18 Aux Heating	Output Tests	
Audi A4	2003	8E	18 Aux Heating	Specia Functions	
Audi A4	2003	8E	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2003	8E	25 Immobilizer	Clear Fault Codes	
Audi A4	2003	8E	25 Immobilizer	Measuring Blocks	
Audi A4	2003	8E	25 Immobilizer	Output Tests	
Audi A4	2003	8E	25 Immobilizer	Specia Functions	
Audi A4	2003	8E	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A4	2003	8E	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A4	2003	8E	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A4	2003	8E	36 Side of Driver Seat Adj.	Output Tests	
Audi A4	2003	8E	36 Side of Driver Seat Adj.	Specia Functions	
Audi A4	2003	8E	37 Navigation	Read Fault Codes	
Audi A4	2003	8E	37 Navigation	Clear Fault Codes	
Audi A4	2003	8E	37 Navigation	Measuring Blocks	
Audi A4	2003	8E	37 Navigation	Output Tests	
Audi A4	2003	8E	37 Navigation	Specia Functions	
Audi A4	2003	8E	45 Interior Monitoring	Read Fault Codes	
Audi A4	2003	8E	45 Interior Monitoring	Clear Fault Codes	
Audi A4	2003	8E	45 Interior Monitoring	Measuring Blocks	
Audi A4	2003	8E	45 Interior Monitoring	Output Tests	
Audi A4	2003	8E	45 Interior Monitoring	Specia Functions	
Audi A4	2003	8E	46 Central Control Module	Read Fault Codes	
Audi A4	2003	8E	46 Central Control Module	Clear Fault Codes	
Audi A4	2003	8E	46 Central Control Module	Measuring Blocks	
Audi A4	2003	8E	46 Central Control Module	Output Tests	
Audi A4	2003	8E	46 Central Control Module	Specia Functions	
Audi A4	2003	8E	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2003	8E	51 Electric Drive	Clear Fault Codes	
Audi A4	2003	8E	51 Electric Drive	Measuring Blocks	
Audi A4	2003	8E	51 Electric Drive	Output Tests	
Audi A4	2003	8E	51 Electric Drive	Specia Functions	
Audi A4	2003	8E	55 Headlight Range Control	Read Fault Codes	
Audi A4	2003	8E	55 Headlight Range Control	Clear Fault Codes	
Audi A4	2003	8E	55 Headlight Range Control	Measuring Blocks	
Audi A4	2003	8E	55 Headlight Range Control	Output Tests	
Audi A4	2003	8E	55 Headlight Range Control	Specia Functions	
Audi A4	2003	8E	56 Radio	Read Fault Codes	
Audi A4	2003	8E	56 Radio	Clear Fault Codes	
Audi A4	2003	8E	56 Radio	Measuring Blocks	
Audi A4	2003	8E	56 Radio	Output Tests	
Audi A4	2003	8E	56 Radio	Specia Functions	
Audi A4	2003	8E	57 TV-Tuner	Read Fault Codes	
Audi A4	2003	8E	57 TV-Tuner	Clear Fault Codes	
Audi A4	2003	8E	57 TV-Tuner	Measuring Blocks	
Audi A4	2003	8E	57 TV-Tuner	Output Tests	
Audi A4	2003	8E	57 TV-Tuner	Specia Functions	
Audi A4	2003	8E	67 Voice Control	Read Fault Codes	
Audi A4	2003	8E	67 Voice Control	Clear Fault Codes	
Audi A4	2003	8E	67 Voice Control	Measuring Blocks	
Audi A4	2003	8E	67 Voice Control	Output Tests	
Audi A4	2003	8E	67 Voice Control	Specia Functions	
Audi A4	2003	8E	75 Emergency Call Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2003	8E	75 Emergency Call Module	Clear Fault Codes	
Audi A4	2003	8E	75 Emergency Call Module	Measuring Blocks	
Audi A4	2003	8E	75 Emergency Call Module	Output Tests	
Audi A4	2003	8E	75 Emergency Call Module	Specia Functions	
Audi A4	2003	8E	76 Parking Aid	Read Fault Codes	
Audi A4	2003	8E	76 Parking Aid	Clear Fault Codes	
Audi A4	2003	8E	76 Parking Aid	Measuring Blocks	
Audi A4	2003	8E	76 Parking Aid	Output Tests	
Audi A4	2003	8E	76 Parking Aid	Specia Functions	
Audi A4	2003	8E	77 Telephone	Read Fault Codes	
Audi A4	2003	8E	77 Telephone	Clear Fault Codes	
Audi A4	2003	8E	77 Telephone	Measuring Blocks	
Audi A4	2003	8E	77 Telephone	Output Tests	
Audi A4	2003	8E	77 Telephone	Specia Functions	
Audi A4	2003	8E	8C Hybrid Battery	Read Fault Codes	
Audi A4	2003	8E	8C Hybrid Battery	Clear Fault Codes	
Audi A4	2003	8E	8C Hybrid Battery	Measuring Blocks	
Audi A4	2003	8E	8C Hybrid Battery	Output Tests	
Audi A4	2003	8E	8C Hybrid Battery	Specia Functions	
Audi A4	2004-2005	8E	01 Engine Electronics	Read Fault Codes	
Audi A4	2004-2005	8E	01 Engine Electronics	Clear Fault Codes	
Audi A4	2004-2005	8E	01 Engine Electronics	Measuring Blocks	
Audi A4	2004-2005	8E	01 Engine Electronics	Output Tests	
Audi A4	2004-2005	8E	01 Engine Electronics	Specia Functions	
Audi A4	2004-2005	8E	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2004-2005	8E	02 Transmission Electronics	Clear Fault Codes	
Audi A4	2004-2005	8E	02 Transmission Electronics	Measuring Blocks	
Audi A4	2004-2005	8E	02 Transmission Electronics	Output Tests	
Audi A4	2004-2005	8E	02 Transmission Electronics	Specia Functions	
Audi A4	2004-2005	8E	03 Brake Electronics	Read Fault Codes	
Audi A4	2004-2005	8E	03 Brake Electronics	Clear Fault Codes	
Audi A4	2004-2005	8E	03 Brake Electronics	Measuring Blocks	
Audi A4	2004-2005	8E	03 Brake Electronics	Output Tests	
Audi A4	2004-2005	8E	03 Brake Electronics	Specia Functions	
Audi A4	2004-2005	8E	08 AC/Heating Electronics	Read Fault Codes	
Audi A4	2004-2005	8E	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4	2004-2005	8E	08 AC/Heating Electronics	Measuring Blocks	
Audi A4	2004-2005	8E	08 AC/Heating Electronics	Output Tests	
Audi A4	2004-2005	8E	08 AC/Heating Electronics	Specia Functions	
Audi A4	2004-2005	8E	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A4	2004-2005	8E	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A4	2004-2005	8E	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A4	2004-2005	8E	09 Electronic Ctrl Electronics	Output Tests	
Audi A4	2004-2005	8E	09 Electronic Ctrl Electronics	Specia Functions	
Audi A4	2004-2005	8E	0F Radio Tuner-Digital	Read Fault Codes	
Audi A4	2004-2005	8E	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A4	2004-2005	8E	0F Radio Tuner-Digital	Measuring Blocks	
Audi A4	2004-2005	8E	0F Radio Tuner-Digital	Output Tests	
Audi A4	2004-2005	8E	0F Radio Tuner-Digital	Specia Functions	
Audi A4	2004-2005	8E	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2004-2005	8E	11 Engine Electronics 2	Clear Fault Codes	
Audi A4	2004-2005	8E	11 Engine Electronics 2	Measuring Blocks	
Audi A4	2004-2005	8E	11 Engine Electronics 2	Output Tests	
Audi A4	2004-2005	8E	11 Engine Electronics 2	Specia Functions	
Audi A4	2004-2005	8E	15 Airbags	Read Fault Codes	
Audi A4	2004-2005	8E	15 Airbags	Clear Fault Codes	
Audi A4	2004-2005	8E	15 Airbags	Measuring Blocks	
Audi A4	2004-2005	8E	15 Airbags	Output Tests	
Audi A4	2004-2005	8E	15 Airbags	Specia Functions	
Audi A4	2004-2005	8E	16 Steering Wheel Electronics	Read Fault Codes	
Audi A4	2004-2005	8E	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4	2004-2005	8E	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4	2004-2005	8E	16 Steering Wheel Electronics	Output Tests	
Audi A4	2004-2005	8E	16 Steering Wheel Electronics	Specia Functions	
Audi A4	2004-2005	8E	17 Instrument Cluster	Read Fault Codes	
Audi A4	2004-2005	8E	17 Instrument Cluster	Clear Fault Codes	
Audi A4	2004-2005	8E	17 Instrument Cluster	Measuring Blocks	
Audi A4	2004-2005	8E	17 Instrument Cluster	Output Tests	
Audi A4	2004-2005	8E	17 Instrument Cluster	Specia Functions	
Audi A4	2004-2005	8E	18 Aux Heating	Read Fault Codes	
Audi A4	2004-2005	8E	18 Aux Heating	Clear Fault Codes	
Audi A4	2004-2005	8E	18 Aux Heating	Measuring Blocks	
Audi A4	2004-2005	8E	18 Aux Heating	Output Tests	
Audi A4	2004-2005	8E	18 Aux Heating	Specia Functions	
Audi A4	2004-2005	8E	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2004-2005	8E	25 Immobilizer	Clear Fault Codes	
Audi A4	2004-2005	8E	25 Immobilizer	Measuring Blocks	
Audi A4	2004-2005	8E	25 Immobilizer	Output Tests	
Audi A4	2004-2005	8E	25 Immobilizer	Specia Functions	
Audi A4	2004-2005	8E	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A4	2004-2005	8E	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A4	2004-2005	8E	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A4	2004-2005	8E	36 Side of Driver Seat Adj.	Output Tests	
Audi A4	2004-2005	8E	36 Side of Driver Seat Adj.	Specia Functions	
Audi A4	2004-2005	8E	37 Navigation	Read Fault Codes	
Audi A4	2004-2005	8E	37 Navigation	Clear Fault Codes	
Audi A4	2004-2005	8E	37 Navigation	Measuring Blocks	
Audi A4	2004-2005	8E	37 Navigation	Output Tests	
Audi A4	2004-2005	8E	37 Navigation	Specia Functions	
Audi A4	2004-2005	8E	45 Interior Monitoring	Read Fault Codes	
Audi A4	2004-2005	8E	45 Interior Monitoring	Clear Fault Codes	
Audi A4	2004-2005	8E	45 Interior Monitoring	Measuring Blocks	
Audi A4	2004-2005	8E	45 Interior Monitoring	Output Tests	
Audi A4	2004-2005	8E	45 Interior Monitoring	Specia Functions	
Audi A4	2004-2005	8E	46 Central Control Module	Read Fault Codes	
Audi A4	2004-2005	8E	46 Central Control Module	Clear Fault Codes	
Audi A4	2004-2005	8E	46 Central Control Module	Measuring Blocks	
Audi A4	2004-2005	8E	46 Central Control Module	Output Tests	
Audi A4	2004-2005	8E	46 Central Control Module	Specia Functions	
Audi A4	2004-2005	8E	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2004-2005	8E	51 Electric Drive	Clear Fault Codes	
Audi A4	2004-2005	8E	51 Electric Drive	Measuring Blocks	
Audi A4	2004-2005	8E	51 Electric Drive	Output Tests	
Audi A4	2004-2005	8E	51 Electric Drive	Specia Functions	
Audi A4	2004-2005	8E	55 Headlight Range Control	Read Fault Codes	
Audi A4	2004-2005	8E	55 Headlight Range Control	Clear Fault Codes	
Audi A4	2004-2005	8E	55 Headlight Range Control	Measuring Blocks	
Audi A4	2004-2005	8E	55 Headlight Range Control	Output Tests	
Audi A4	2004-2005	8E	55 Headlight Range Control	Specia Functions	
Audi A4	2004-2005	8E	56 Radio	Read Fault Codes	
Audi A4	2004-2005	8E	56 Radio	Clear Fault Codes	
Audi A4	2004-2005	8E	56 Radio	Measuring Blocks	
Audi A4	2004-2005	8E	56 Radio	Output Tests	
Audi A4	2004-2005	8E	56 Radio	Specia Functions	
Audi A4	2004-2005	8E	57 TV-Tuner	Read Fault Codes	
Audi A4	2004-2005	8E	57 TV-Tuner	Clear Fault Codes	
Audi A4	2004-2005	8E	57 TV-Tuner	Measuring Blocks	
Audi A4	2004-2005	8E	57 TV-Tuner	Output Tests	
Audi A4	2004-2005	8E	57 TV-Tuner	Specia Functions	
Audi A4	2004-2005	8E	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A4	2004-2005	8E	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A4	2004-2005	8E	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A4	2004-2005	8E	65 Tyre Pressure Monitoring	Output Tests	
Audi A4	2004-2005	8E	65 Tyre Pressure Monitoring	Specia Functions	
Audi A4	2004-2005	8E	67 Voice Control	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2004-2005	8E	67 Voice Control	Clear Fault Codes	
Audi A4	2004-2005	8E	67 Voice Control	Measuring Blocks	
Audi A4	2004-2005	8E	67 Voice Control	Output Tests	
Audi A4	2004-2005	8E	67 Voice Control	Specia Functions	
Audi A4	2004-2005	8E	75 Emergency Call Module	Read Fault Codes	
Audi A4	2004-2005	8E	75 Emergency Call Module	Clear Fault Codes	
Audi A4	2004-2005	8E	75 Emergency Call Module	Measuring Blocks	
Audi A4	2004-2005	8E	75 Emergency Call Module	Output Tests	
Audi A4	2004-2005	8E	75 Emergency Call Module	Specia Functions	
Audi A4	2004-2005	8E	76 Parking Aid	Read Fault Codes	
Audi A4	2004-2005	8E	76 Parking Aid	Clear Fault Codes	
Audi A4	2004-2005	8E	76 Parking Aid	Measuring Blocks	
Audi A4	2004-2005	8E	76 Parking Aid	Output Tests	
Audi A4	2004-2005	8E	76 Parking Aid	Specia Functions	
Audi A4	2004-2005	8E	77 Telephone	Read Fault Codes	
Audi A4	2004-2005	8E	77 Telephone	Clear Fault Codes	
Audi A4	2004-2005	8E	77 Telephone	Measuring Blocks	
Audi A4	2004-2005	8E	77 Telephone	Output Tests	
Audi A4	2004-2005	8E	77 Telephone	Specia Functions	
Audi A4	2004-2005	8E	8C Hybrid Battery	Read Fault Codes	
Audi A4	2004-2005	8E	8C Hybrid Battery	Clear Fault Codes	
Audi A4	2004-2005	8E	8C Hybrid Battery	Measuring Blocks	
Audi A4	2004-2005	8E	8C Hybrid Battery	Output Tests	
Audi A4	2004-2005	8E	8C Hybrid Battery	Specia Functions	
Audi A4	2006-2008	8E	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2006-2008	8E	01 Engine Electronics	Clear Fault Codes	
Audi A4	2006-2008	8E	01 Engine Electronics	Measuring Blocks	
Audi A4	2006-2008	8E	01 Engine Electronics	Output Tests	
Audi A4	2006-2008	8E	01 Engine Electronics	Specia Functions	
Audi A4	2006-2008	8E	02 Transmission Electronics	Read Fault Codes	
Audi A4	2006-2008	8E	02 Transmission Electronics	Clear Fault Codes	
Audi A4	2006-2008	8E	02 Transmission Electronics	Measuring Blocks	
Audi A4	2006-2008	8E	02 Transmission Electronics	Output Tests	
Audi A4	2006-2008	8E	02 Transmission Electronics	Specia Functions	
Audi A4	2006-2008	8E	03 Brake Electronics	Read Fault Codes	
Audi A4	2006-2008	8E	03 Brake Electronics	Clear Fault Codes	
Audi A4	2006-2008	8E	03 Brake Electronics	Measuring Blocks	
Audi A4	2006-2008	8E	03 Brake Electronics	Output Tests	
Audi A4	2006-2008	8E	03 Brake Electronics	Specia Functions	
Audi A4	2006-2008	8E	08 AC/Heating Electronics	Read Fault Codes	
Audi A4	2006-2008	8E	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4	2006-2008	8E	08 AC/Heating Electronics	Measuring Blocks	
Audi A4	2006-2008	8E	08 AC/Heating Electronics	Output Tests	
Audi A4	2006-2008	8E	08 AC/Heating Electronics	Specia Functions	
Audi A4	2006-2008	8E	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A4	2006-2008	8E	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A4	2006-2008	8E	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A4	2006-2008	8E	09 Electronic Ctrl Electronics	Output Tests	
Audi A4	2006-2008	8E	09 Electronic Ctrl Electronics	Specia Functions	
Audi A4	2006-2008	8E	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2006-2008	8E	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A4	2006-2008	8E	0F Radio Tuner-Digital	Measuring Blocks	
Audi A4	2006-2008	8E	0F Radio Tuner-Digital	Output Tests	
Audi A4	2006-2008	8E	0F Radio Tuner-Digital	Specia Functions	
Audi A4	2006-2008	8E	11 Engine Electronics 2	Read Fault Codes	
Audi A4	2006-2008	8E	11 Engine Electronics 2	Clear Fault Codes	
Audi A4	2006-2008	8E	11 Engine Electronics 2	Measuring Blocks	
Audi A4	2006-2008	8E	11 Engine Electronics 2	Output Tests	
Audi A4	2006-2008	8E	11 Engine Electronics 2	Specia Functions	
Audi A4	2006-2008	8E	15 Airbags	Read Fault Codes	
Audi A4	2006-2008	8E	15 Airbags	Clear Fault Codes	
Audi A4	2006-2008	8E	15 Airbags	Measuring Blocks	
Audi A4	2006-2008	8E	15 Airbags	Output Tests	
Audi A4	2006-2008	8E	15 Airbags	Specia Functions	
Audi A4	2006-2008	8E	16 Steering Wheel Electronics	Read Fault Codes	
Audi A4	2006-2008	8E	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4	2006-2008	8E	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4	2006-2008	8E	16 Steering Wheel Electronics	Output Tests	
Audi A4	2006-2008	8E	16 Steering Wheel Electronics	Specia Functions	
Audi A4	2006-2008	8E	17 Instrument Cluster	Read Fault Codes	
Audi A4	2006-2008	8E	17 Instrument Cluster	Clear Fault Codes	
Audi A4	2006-2008	8E	17 Instrument Cluster	Measuring Blocks	
Audi A4	2006-2008	8E	17 Instrument Cluster	Output Tests	
Audi A4	2006-2008	8E	17 Instrument Cluster	Specia Functions	
Audi A4	2006-2008	8E	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2006-2008	8E	18 Aux Heating	Clear Fault Codes	
Audi A4	2006-2008	8E	18 Aux Heating	Measuring Blocks	
Audi A4	2006-2008	8E	18 Aux Heating	Output Tests	
Audi A4	2006-2008	8E	18 Aux Heating	Specia Functions	
Audi A4	2006-2008	8E	25 Immobilizer	Read Fault Codes	
Audi A4	2006-2008	8E	25 Immobilizer	Clear Fault Codes	
Audi A4	2006-2008	8E	25 Immobilizer	Measuring Blocks	
Audi A4	2006-2008	8E	25 Immobilizer	Output Tests	
Audi A4	2006-2008	8E	25 Immobilizer	Specia Functions	
Audi A4	2006-2008	8E	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A4	2006-2008	8E	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A4	2006-2008	8E	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A4	2006-2008	8E	36 Side of Driver Seat Adj.	Output Tests	
Audi A4	2006-2008	8E	36 Side of Driver Seat Adj.	Specia Functions	
Audi A4	2006-2008	8E	37 Navigation	Read Fault Codes	
Audi A4	2006-2008	8E	37 Navigation	Clear Fault Codes	
Audi A4	2006-2008	8E	37 Navigation	Measuring Blocks	
Audi A4	2006-2008	8E	37 Navigation	Output Tests	
Audi A4	2006-2008	8E	37 Navigation	Specia Functions	
Audi A4	2006-2008	8E	45 Interior Monitoring	Read Fault Codes	
Audi A4	2006-2008	8E	45 Interior Monitoring	Clear Fault Codes	
Audi A4	2006-2008	8E	45 Interior Monitoring	Measuring Blocks	
Audi A4	2006-2008	8E	45 Interior Monitoring	Output Tests	
Audi A4	2006-2008	8E	45 Interior Monitoring	Specia Functions	
Audi A4	2006-2008	8E	46 Central Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2006-2008	8E	46 Central Control Module	Clear Fault Codes	
Audi A4	2006-2008	8E	46 Central Control Module	Measuring Blocks	
Audi A4	2006-2008	8E	46 Central Control Module	Output Tests	
Audi A4	2006-2008	8E	46 Central Control Module	Specia Functions	
Audi A4	2006-2008	8E	51 Electric Drive	Read Fault Codes	
Audi A4	2006-2008	8E	51 Electric Drive	Clear Fault Codes	
Audi A4	2006-2008	8E	51 Electric Drive	Measuring Blocks	
Audi A4	2006-2008	8E	51 Electric Drive	Output Tests	
Audi A4	2006-2008	8E	51 Electric Drive	Specia Functions	
Audi A4	2006-2008	8E	55 Headlight Range Control	Read Fault Codes	
Audi A4	2006-2008	8E	55 Headlight Range Control	Clear Fault Codes	
Audi A4	2006-2008	8E	55 Headlight Range Control	Measuring Blocks	
Audi A4	2006-2008	8E	55 Headlight Range Control	Output Tests	
Audi A4	2006-2008	8E	55 Headlight Range Control	Specia Functions	
Audi A4	2006-2008	8E	56 Radio	Read Fault Codes	
Audi A4	2006-2008	8E	56 Radio	Clear Fault Codes	
Audi A4	2006-2008	8E	56 Radio	Measuring Blocks	
Audi A4	2006-2008	8E	56 Radio	Output Tests	
Audi A4	2006-2008	8E	56 Radio	Specia Functions	
Audi A4	2006-2008	8E	57 TV-Tuner	Read Fault Codes	
Audi A4	2006-2008	8E	57 TV-Tuner	Clear Fault Codes	
Audi A4	2006-2008	8E	57 TV-Tuner	Measuring Blocks	
Audi A4	2006-2008	8E	57 TV-Tuner	Output Tests	
Audi A4	2006-2008	8E	57 TV-Tuner	Specia Functions	
Audi A4	2006-2008	8E	65 Tyre Pressure Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2006-2008	8E	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A4	2006-2008	8E	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A4	2006-2008	8E	65 Tyre Pressure Monitoring	Output Tests	
Audi A4	2006-2008	8E	65 Tyre Pressure Monitoring	Specia Functions	
Audi A4	2006-2008	8E	67 Voice Control	Read Fault Codes	
Audi A4	2006-2008	8E	67 Voice Control	Clear Fault Codes	
Audi A4	2006-2008	8E	67 Voice Control	Measuring Blocks	
Audi A4	2006-2008	8E	67 Voice Control	Output Tests	
Audi A4	2006-2008	8E	67 Voice Control	Specia Functions	
Audi A4	2006-2008	8E	75 Emergency Call Module	Read Fault Codes	
Audi A4	2006-2008	8E	75 Emergency Call Module	Clear Fault Codes	
Audi A4	2006-2008	8E	75 Emergency Call Module	Measuring Blocks	
Audi A4	2006-2008	8E	75 Emergency Call Module	Output Tests	
Audi A4	2006-2008	8E	75 Emergency Call Module	Specia Functions	
Audi A4	2006-2008	8E	76 Parking Aid	Read Fault Codes	
Audi A4	2006-2008	8E	76 Parking Aid	Clear Fault Codes	
Audi A4	2006-2008	8E	76 Parking Aid	Measuring Blocks	
Audi A4	2006-2008	8E	76 Parking Aid	Output Tests	
Audi A4	2006-2008	8E	76 Parking Aid	Specia Functions	
Audi A4	2006-2008	8E	77 Telephone	Read Fault Codes	
Audi A4	2006-2008	8E	77 Telephone	Clear Fault Codes	
Audi A4	2006-2008	8E	77 Telephone	Measuring Blocks	
Audi A4	2006-2008	8E	77 Telephone	Output Tests	
Audi A4	2006-2008	8E	77 Telephone	Specia Functions	
Audi A4	2006-2008	8E	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2006-2008	8E	8C Hybrid Battery	Clear Fault Codes	
Audi A4	2006-2008	8E	8C Hybrid Battery	Measuring Blocks	
Audi A4	2006-2008	8E	8C Hybrid Battery	Output Tests	
Audi A4	2006-2008	8E	8C Hybrid Battery	Specia Functions	
Audi A6	2004-2005	4F	01 Engine Electronics	Read Fault Codes	
Audi A6	2004-2005	4F	01 Engine Electronics	Clear Fault Codes	
Audi A6	2004-2005	4F	01 Engine Electronics	Measuring Blocks	
Audi A6	2004-2005	4F	01 Engine Electronics	Output Tests	
Audi A6	2004-2005	4F	01 Engine Electronics	Specia Functions	
Audi A6	2004-2005	4F	02 Transmission Electronics	Read Fault Codes	
Audi A6	2004-2005	4F	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2004-2005	4F	02 Transmission Electronics	Measuring Blocks	
Audi A6	2004-2005	4F	02 Transmission Electronics	Output Tests	
Audi A6	2004-2005	4F	02 Transmission Electronics	Specia Functions	
Audi A6	2004-2005	4F	03 Brake Electronics	Read Fault Codes	
Audi A6	2004-2005	4F	03 Brake Electronics	Clear Fault Codes	
Audi A6	2004-2005	4F	03 Brake Electronics	Measuring Blocks	
Audi A6	2004-2005	4F	03 Brake Electronics	Output Tests	
Audi A6	2004-2005	4F	03 Brake Electronics	Specia Functions	
Audi A6	2004-2005	4F	05 Access & Permissi.	Read Fault Codes	
Audi A6	2004-2005	4F	05 Access & Permissi.	Clear Fault Codes	
Audi A6	2004-2005	4F	05 Access & Permissi.	Measuring Blocks	
Audi A6	2004-2005	4F	05 Access & Permissi.	Output Tests	
Audi A6	2004-2005	4F	05 Access & Permissi.	Specia Functions	
Audi A6	2004-2005	4F	06 Passene. Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2005	4F	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6	2004-2005	4F	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6	2004-2005	4F	06 Passene. Seat Adj.	Output Tests	
Audi A6	2004-2005	4F	06 Passene. Seat Adj.	Specia Functions	
Audi A6	2004-2005	4F	07 Display-/Cntl Unit	Read Fault Codes	
Audi A6	2004-2005	4F	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A6	2004-2005	4F	07 Display-/Cntl Unit	Measuring Blocks	
Audi A6	2004-2005	4F	07 Display-/Cntl Unit	Output Tests	
Audi A6	2004-2005	4F	07 Display-/Cntl Unit	Specia Functions	
Audi A6	2004-2005	4F	08 AC/Heating Electronics	Read Fault Codes	
Audi A6	2004-2005	4F	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	2004-2005	4F	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	2004-2005	4F	08 AC/Heating Electronics	Output Tests	
Audi A6	2004-2005	4F	08 AC/Heating Electronics	Specia Functions	
Audi A6	2004-2005	4F	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A6	2004-2005	4F	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A6	2004-2005	4F	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A6	2004-2005	4F	09 Electronic Ctrl Electronics	Output Tests	
Audi A6	2004-2005	4F	09 Electronic Ctrl Electronics	Specia Functions	
Audi A6	2004-2005	4F	0E Media Player Position 1	Read Fault Codes	
Audi A6	2004-2005	4F	0E Media Player Position 1	Clear Fault Codes	
Audi A6	2004-2005	4F	0E Media Player Position 1	Measuring Blocks	
Audi A6	2004-2005	4F	0E Media Player Position 1	Output Tests	
Audi A6	2004-2005	4F	0E Media Player Position 1	Specia Functions	
Audi A6	2004-2005	4F	0F Radio Tuner-Digital	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2005	4F	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A6	2004-2005	4F	0F Radio Tuner-Digital	Measuring Blocks	
Audi A6	2004-2005	4F	0F Radio Tuner-Digital	Output Tests	
Audi A6	2004-2005	4F	0F Radio Tuner-Digital	Specia Functions	
Audi A6	2004-2005	4F	11 Engine Electronics 2	Read Fault Codes	
Audi A6	2004-2005	4F	11 Engine Electronics 2	Clear Fault Codes	
Audi A6	2004-2005	4F	11 Engine Electronics 2	Measuring Blocks	
Audi A6	2004-2005	4F	11 Engine Electronics 2	Output Tests	
Audi A6	2004-2005	4F	11 Engine Electronics 2	Specia Functions	
Audi A6	2004-2005	4F	13 Distance Control	Read Fault Codes	
Audi A6	2004-2005	4F	13 Distance Control	Clear Fault Codes	
Audi A6	2004-2005	4F	13 Distance Control	Measuring Blocks	
Audi A6	2004-2005	4F	13 Distance Control	Output Tests	
Audi A6	2004-2005	4F	13 Distance Control	Specia Functions	
Audi A6	2004-2005	4F	15 Airbags	Read Fault Codes	
Audi A6	2004-2005	4F	15 Airbags	Clear Fault Codes	
Audi A6	2004-2005	4F	15 Airbags	Measuring Blocks	
Audi A6	2004-2005	4F	15 Airbags	Output Tests	
Audi A6	2004-2005	4F	15 Airbags	Specia Functions	
Audi A6	2004-2005	4F	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2004-2005	4F	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2004-2005	4F	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2004-2005	4F	16 Steering Wheel Electronics	Output Tests	
Audi A6	2004-2005	4F	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2004-2005	4F	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2005	4F	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2004-2005	4F	17 Instrument Cluster	Measuring Blocks	
Audi A6	2004-2005	4F	17 Instrument Cluster	Output Tests	
Audi A6	2004-2005	4F	17 Instrument Cluster	Specia Functions	
Audi A6	2004-2005	4F	18 Aux Heating	Read Fault Codes	
Audi A6	2004-2005	4F	18 Aux Heating	Clear Fault Codes	
Audi A6	2004-2005	4F	18 Aux Heating	Measuring Blocks	
Audi A6	2004-2005	4F	18 Aux Heating	Output Tests	
Audi A6	2004-2005	4F	18 Aux Heating	Specia Functions	
Audi A6	2004-2005	4F	19 Gateway Data Bus	Read Fault Codes	
Audi A6	2004-2005	4F	19 Gateway Data Bus	Clear Fault Codes	
Audi A6	2004-2005	4F	19 Gateway Data Bus	Measuring Blocks	
Audi A6	2004-2005	4F	19 Gateway Data Bus	Output Tests	
Audi A6	2004-2005	4F	19 Gateway Data Bus	Specia Functions	
Audi A6	2004-2005	4F	1E Media Player Position 2	Read Fault Codes	
Audi A6	2004-2005	4F	1E Media Player Position 2	Clear Fault Codes	
Audi A6	2004-2005	4F	1E Media Player Position 2	Measuring Blocks	
Audi A6	2004-2005	4F	1E Media Player Position 2	Output Tests	
Audi A6	2004-2005	4F	1E Media Player Position 2	Specia Functions	
Audi A6	2004-2005	4F	25 Immobilizer	Read Fault Codes	
Audi A6	2004-2005	4F	25 Immobilizer	Clear Fault Codes	
Audi A6	2004-2005	4F	25 Immobilizer	Measuring Blocks	
Audi A6	2004-2005	4F	25 Immobilizer	Output Tests	
Audi A6	2004-2005	4F	25 Immobilizer	Specia Functions	
Audi A6	2004-2005	4F	28 Climate Control Unit Rear	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2005	4F	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A6	2004-2005	4F	28 Climate Control Unit Rear	Measuring Blocks	
Audi A6	2004-2005	4F	28 Climate Control Unit Rear	Output Tests	
Audi A6	2004-2005	4F	28 Climate Control Unit Rear	Specia Functions	
Audi A6	2004-2005	4F	34 Self Leveling Suspension	Read Fault Codes	
Audi A6	2004-2005	4F	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	2004-2005	4F	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	2004-2005	4F	34 Self Leveling Suspension	Output Tests	
Audi A6	2004-2005	4F	34 Self Leveling Suspension	Specia Functions	
Audi A6	2004-2005	4F	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A6	2004-2005	4F	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	2004-2005	4F	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	2004-2005	4F	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	2004-2005	4F	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	2004-2005	4F	37 Navigation	Read Fault Codes	
Audi A6	2004-2005	4F	37 Navigation	Clear Fault Codes	
Audi A6	2004-2005	4F	37 Navigation	Measuring Blocks	
Audi A6	2004-2005	4F	37 Navigation	Output Tests	
Audi A6	2004-2005	4F	37 Navigation	Specia Functions	
Audi A6	2004-2005	4F	3D Special Function	Read Fault Codes	
Audi A6	2004-2005	4F	3D Special Function	Clear Fault Codes	
Audi A6	2004-2005	4F	3D Special Function	Measuring Blocks	
Audi A6	2004-2005	4F	3D Special Function	Output Tests	
Audi A6	2004-2005	4F	3D Special Function	Specia Functions	
Audi A6	2004-2005	4F	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2005	4F	42 Driver-Door Elect.	Clear Fault Codes	
Audi A6	2004-2005	4F	42 Driver-Door Elect.	Measuring Blocks	
Audi A6	2004-2005	4F	42 Driver-Door Elect.	Output Tests	
Audi A6	2004-2005	4F	42 Driver-Door Elect.	Specia Functions	
Audi A6	2004-2005	4F	46 Central Control Module	Read Fault Codes	
Audi A6	2004-2005	4F	46 Central Control Module	Clear Fault Codes	
Audi A6	2004-2005	4F	46 Central Control Module	Measuring Blocks	
Audi A6	2004-2005	4F	46 Central Control Module	Output Tests	
Audi A6	2004-2005	4F	46 Central Control Module	Specia Functions	
Audi A6	2004-2005	4F	47 Soundsystem	Read Fault Codes	
Audi A6	2004-2005	4F	47 Soundsystem	Clear Fault Codes	
Audi A6	2004-2005	4F	47 Soundsystem	Measuring Blocks	
Audi A6	2004-2005	4F	47 Soundsystem	Output Tests	
Audi A6	2004-2005	4F	47 Soundsystem	Specia Functions	
Audi A6	2004-2005	4F	4F Electronic Central Electric II	Read Fault Codes	
Audi A6	2004-2005	4F	4F Electronic Central Electric II	Clear Fault Codes	
Audi A6	2004-2005	4F	4F Electronic Central Electric II	Measuring Blocks	
Audi A6	2004-2005	4F	4F Electronic Central Electric II	Output Tests	
Audi A6	2004-2005	4F	4F Electronic Central Electric II	Specia Functions	
Audi A6	2004-2005	4F	51 Electric Drive	Read Fault Codes	
Audi A6	2004-2005	4F	51 Electric Drive	Clear Fault Codes	
Audi A6	2004-2005	4F	51 Electric Drive	Measuring Blocks	
Audi A6	2004-2005	4F	51 Electric Drive	Output Tests	
Audi A6	2004-2005	4F	51 Electric Drive	Specia Functions	
Audi A6	2004-2005	4F	52 Passe.-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2005	4F	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A6	2004-2005	4F	52 Passe.-Door Elect.	Measuring Blocks	
Audi A6	2004-2005	4F	52 Passe.-Door Elect.	Output Tests	
Audi A6	2004-2005	4F	52 Passe.-Door Elect.	Specia Functions	
Audi A6	2004-2005	4F	53 Parking Brake	Read Fault Codes	
Audi A6	2004-2005	4F	53 Parking Brake	Clear Fault Codes	
Audi A6	2004-2005	4F	53 Parking Brake	Measuring Blocks	
Audi A6	2004-2005	4F	53 Parking Brake	Output Tests	
Audi A6	2004-2005	4F	53 Parking Brake	Specia Functions	
Audi A6	2004-2005	4F	55 Headlight Range Control	Read Fault Codes	
Audi A6	2004-2005	4F	55 Headlight Range Control	Clear Fault Codes	
Audi A6	2004-2005	4F	55 Headlight Range Control	Measuring Blocks	
Audi A6	2004-2005	4F	55 Headlight Range Control	Output Tests	
Audi A6	2004-2005	4F	55 Headlight Range Control	Specia Functions	
Audi A6	2004-2005	4F	56 Radio	Read Fault Codes	
Audi A6	2004-2005	4F	56 Radio	Clear Fault Codes	
Audi A6	2004-2005	4F	56 Radio	Measuring Blocks	
Audi A6	2004-2005	4F	56 Radio	Output Tests	
Audi A6	2004-2005	4F	56 Radio	Specia Functions	
Audi A6	2004-2005	4F	57 TV-Tuner	Read Fault Codes	
Audi A6	2004-2005	4F	57 TV-Tuner	Clear Fault Codes	
Audi A6	2004-2005	4F	57 TV-Tuner	Measuring Blocks	
Audi A6	2004-2005	4F	57 TV-Tuner	Output Tests	
Audi A6	2004-2005	4F	57 TV-Tuner	Specia Functions	
Audi A6	2004-2005	4F	61 Battery Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2005	4F	61 Battery Control	Clear Fault Codes	
Audi A6	2004-2005	4F	61 Battery Control	Measuring Blocks	
Audi A6	2004-2005	4F	61 Battery Control	Output Tests	
Audi A6	2004-2005	4F	61 Battery Control	Specia Functions	
Audi A6	2004-2005	4F	62 LR-Door Electroni.	Read Fault Codes	
Audi A6	2004-2005	4F	62 LR-Door Electroni.	Clear Fault Codes	
Audi A6	2004-2005	4F	62 LR-Door Electroni.	Measuring Blocks	
Audi A6	2004-2005	4F	62 LR-Door Electroni.	Output Tests	
Audi A6	2004-2005	4F	62 LR-Door Electroni.	Specia Functions	
Audi A6	2004-2005	4F	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6	2004-2005	4F	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6	2004-2005	4F	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6	2004-2005	4F	65 Tyre Pressure Monitoring	Output Tests	
Audi A6	2004-2005	4F	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6	2004-2005	4F	67 Voice Control	Read Fault Codes	
Audi A6	2004-2005	4F	67 Voice Control	Clear Fault Codes	
Audi A6	2004-2005	4F	67 Voice Control	Measuring Blocks	
Audi A6	2004-2005	4F	67 Voice Control	Output Tests	
Audi A6	2004-2005	4F	67 Voice Control	Specia Functions	
Audi A6	2004-2005	4F	69 Trailer Function	Read Fault Codes	
Audi A6	2004-2005	4F	69 Trailer Function	Clear Fault Codes	
Audi A6	2004-2005	4F	69 Trailer Function	Measuring Blocks	
Audi A6	2004-2005	4F	69 Trailer Function	Output Tests	
Audi A6	2004-2005	4F	69 Trailer Function	Specia Functions	
Audi A6	2004-2005	4F	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2005	4F	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A6	2004-2005	4F	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A6	2004-2005	4F	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A6	2004-2005	4F	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A6	2004-2005	4F	72 RR-Door Electroni.	Read Fault Codes	
Audi A6	2004-2005	4F	72 RR-Door Electroni.	Clear Fault Codes	
Audi A6	2004-2005	4F	72 RR-Door Electroni.	Measuring Blocks	
Audi A6	2004-2005	4F	72 RR-Door Electroni.	Output Tests	
Audi A6	2004-2005	4F	72 RR-Door Electroni.	Specia Functions	
Audi A6	2004-2005	4F	76 Parking Aid	Read Fault Codes	
Audi A6	2004-2005	4F	76 Parking Aid	Clear Fault Codes	
Audi A6	2004-2005	4F	76 Parking Aid	Measuring Blocks	
Audi A6	2004-2005	4F	76 Parking Aid	Output Tests	
Audi A6	2004-2005	4F	76 Parking Aid	Specia Functions	
Audi A6	2004-2005	4F	77 Telephone	Read Fault Codes	
Audi A6	2004-2005	4F	77 Telephone	Clear Fault Codes	
Audi A6	2004-2005	4F	77 Telephone	Measuring Blocks	
Audi A6	2004-2005	4F	77 Telephone	Output Tests	
Audi A6	2004-2005	4F	77 Telephone	Specia Functions	
Audi A6	2004-2005	4F	8C Hybrid Battery	Read Fault Codes	
Audi A6	2004-2005	4F	8C Hybrid Battery	Clear Fault Codes	
Audi A6	2004-2005	4F	8C Hybrid Battery	Measuring Blocks	
Audi A6	2004-2005	4F	8C Hybrid Battery	Output Tests	
Audi A6	2004-2005	4F	8C Hybrid Battery	Specia Functions	
Audi A6	2006	4F	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2006	4F	01 Engine Electronics	Clear Fault Codes	
Audi A6	2006	4F	01 Engine Electronics	Measuring Blocks	
Audi A6	2006	4F	01 Engine Electronics	Output Tests	
Audi A6	2006	4F	01 Engine Electronics	Specia Functions	
Audi A6	2006	4F	02 Transmission Electronics	Read Fault Codes	
Audi A6	2006	4F	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2006	4F	02 Transmission Electronics	Measuring Blocks	
Audi A6	2006	4F	02 Transmission Electronics	Output Tests	
Audi A6	2006	4F	02 Transmission Electronics	Specia Functions	
Audi A6	2006	4F	03 Brake Electronics	Read Fault Codes	
Audi A6	2006	4F	03 Brake Electronics	Clear Fault Codes	
Audi A6	2006	4F	03 Brake Electronics	Measuring Blocks	
Audi A6	2006	4F	03 Brake Electronics	Output Tests	
Audi A6	2006	4F	03 Brake Electronics	Specia Functions	
Audi A6	2006	4F	05 Access & Permissi.	Read Fault Codes	
Audi A6	2006	4F	05 Access & Permissi.	Clear Fault Codes	
Audi A6	2006	4F	05 Access & Permissi.	Measuring Blocks	
Audi A6	2006	4F	05 Access & Permissi.	Output Tests	
Audi A6	2006	4F	05 Access & Permissi.	Specia Functions	
Audi A6	2006	4F	06 Passene. Seat Adj.	Read Fault Codes	
Audi A6	2006	4F	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6	2006	4F	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6	2006	4F	06 Passene. Seat Adj.	Output Tests	
Audi A6	2006	4F	06 Passene. Seat Adj.	Specia Functions	
Audi A6	2006	4F	07 Display-/Cntl Unit	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2006	4F	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A6	2006	4F	07 Display-/Cntl Unit	Measuring Blocks	
Audi A6	2006	4F	07 Display-/Cntl Unit	Output Tests	
Audi A6	2006	4F	07 Display-/Cntl Unit	Specia Functions	
Audi A6	2006	4F	08 AC/Heating Electronics	Read Fault Codes	
Audi A6	2006	4F	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	2006	4F	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	2006	4F	08 AC/Heating Electronics	Output Tests	
Audi A6	2006	4F	08 AC/Heating Electronics	Specia Functions	
Audi A6	2006	4F	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A6	2006	4F	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A6	2006	4F	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A6	2006	4F	09 Electronic Ctrl Electronics	Output Tests	
Audi A6	2006	4F	09 Electronic Ctrl Electronics	Specia Functions	
Audi A6	2006	4F	0E Media Player Position 1	Read Fault Codes	
Audi A6	2006	4F	0E Media Player Position 1	Clear Fault Codes	
Audi A6	2006	4F	0E Media Player Position 1	Measuring Blocks	
Audi A6	2006	4F	0E Media Player Position 1	Output Tests	
Audi A6	2006	4F	0E Media Player Position 1	Specia Functions	
Audi A6	2006	4F	0F Radio Tuner-Digital	Read Fault Codes	
Audi A6	2006	4F	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A6	2006	4F	0F Radio Tuner-Digital	Measuring Blocks	
Audi A6	2006	4F	0F Radio Tuner-Digital	Output Tests	
Audi A6	2006	4F	0F Radio Tuner-Digital	Specia Functions	
Audi A6	2006	4F	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2006	4F	11 Engine Electronics 2	Clear Fault Codes	
Audi A6	2006	4F	11 Engine Electronics 2	Measuring Blocks	
Audi A6	2006	4F	11 Engine Electronics 2	Output Tests	
Audi A6	2006	4F	11 Engine Electronics 2	Specia Functions	
Audi A6	2006	4F	13 Distance Control	Read Fault Codes	
Audi A6	2006	4F	13 Distance Control	Clear Fault Codes	
Audi A6	2006	4F	13 Distance Control	Measuring Blocks	
Audi A6	2006	4F	13 Distance Control	Output Tests	
Audi A6	2006	4F	13 Distance Control	Specia Functions	
Audi A6	2006	4F	15 Airbags	Read Fault Codes	
Audi A6	2006	4F	15 Airbags	Clear Fault Codes	
Audi A6	2006	4F	15 Airbags	Measuring Blocks	
Audi A6	2006	4F	15 Airbags	Output Tests	
Audi A6	2006	4F	15 Airbags	Specia Functions	
Audi A6	2006	4F	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2006	4F	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2006	4F	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2006	4F	16 Steering Wheel Electronics	Output Tests	
Audi A6	2006	4F	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2006	4F	17 Instrument Cluster	Read Fault Codes	
Audi A6	2006	4F	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2006	4F	17 Instrument Cluster	Measuring Blocks	
Audi A6	2006	4F	17 Instrument Cluster	Output Tests	
Audi A6	2006	4F	17 Instrument Cluster	Specia Functions	
Audi A6	2006	4F	18 Aux Heating	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6	2006	4F	18 Aux Heating	Clear Fault Codes	
Audi A6	2006	4F	18 Aux Heating	Measuring Blocks	
Audi A6	2006	4F	18 Aux Heating	Output Tests	
Audi A6	2006	4F	18 Aux Heating	Specia Functions	
Audi A6	2006	4F	19 Gateway Data Bus	Read Fault Codes	
Audi A6	2006	4F	19 Gateway Data Bus	Clear Fault Codes	
Audi A6	2006	4F	19 Gateway Data Bus	Measuring Blocks	
Audi A6	2006	4F	19 Gateway Data Bus	Output Tests	
Audi A6	2006	4F	19 Gateway Data Bus	Specia Functions	
Audi A6	2006	4F	1E Media Player Position 2	Read Fault Codes	
Audi A6	2006	4F	1E Media Player Position 2	Clear Fault Codes	
Audi A6	2006	4F	1E Media Player Position 2	Measuring Blocks	
Audi A6	2006	4F	1E Media Player Position 2	Output Tests	
Audi A6	2006	4F	1E Media Player Position 2	Specia Functions	
Audi A6	2006	4F	25 Immobilizer	Read Fault Codes	
Audi A6	2006	4F	25 Immobilizer	Clear Fault Codes	
Audi A6	2006	4F	25 Immobilizer	Measuring Blocks	
Audi A6	2006	4F	25 Immobilizer	Output Tests	
Audi A6	2006	4F	25 Immobilizer	Specia Functions	
Audi A6	2006	4F	28 Climate Control Unit Rear	Read Fault Codes	
Audi A6	2006	4F	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A6	2006	4F	28 Climate Control Unit Rear	Measuring Blocks	
Audi A6	2006	4F	28 Climate Control Unit Rear	Output Tests	
Audi A6	2006	4F	28 Climate Control Unit Rear	Specia Functions	
Audi A6	2006	4F	34 Self Leveling Suspension	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2006	4F	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	2006	4F	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	2006	4F	34 Self Leveling Suspension	Output Tests	
Audi A6	2006	4F	34 Self Leveling Suspension	Specia Functions	
Audi A6	2006	4F	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A6	2006	4F	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	2006	4F	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	2006	4F	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	2006	4F	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	2006	4F	37 Navigation	Read Fault Codes	
Audi A6	2006	4F	37 Navigation	Clear Fault Codes	
Audi A6	2006	4F	37 Navigation	Measuring Blocks	
Audi A6	2006	4F	37 Navigation	Output Tests	
Audi A6	2006	4F	37 Navigation	Specia Functions	
Audi A6	2006	4F	3D Special Function	Read Fault Codes	
Audi A6	2006	4F	3D Special Function	Clear Fault Codes	
Audi A6	2006	4F	3D Special Function	Measuring Blocks	
Audi A6	2006	4F	3D Special Function	Output Tests	
Audi A6	2006	4F	3D Special Function	Specia Functions	
Audi A6	2006	4F	42 Driver-Door Elect.	Read Fault Codes	
Audi A6	2006	4F	42 Driver-Door Elect.	Clear Fault Codes	
Audi A6	2006	4F	42 Driver-Door Elect.	Measuring Blocks	
Audi A6	2006	4F	42 Driver-Door Elect.	Output Tests	
Audi A6	2006	4F	42 Driver-Door Elect.	Specia Functions	
Audi A6	2006	4F	46 Central Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2006	4F	46 Central Control Module	Clear Fault Codes	
Audi A6	2006	4F	46 Central Control Module	Measuring Blocks	
Audi A6	2006	4F	46 Central Control Module	Output Tests	
Audi A6	2006	4F	46 Central Control Module	Specia Functions	
Audi A6	2006	4F	47 Soundsystem	Read Fault Codes	
Audi A6	2006	4F	47 Soundsystem	Clear Fault Codes	
Audi A6	2006	4F	47 Soundsystem	Measuring Blocks	
Audi A6	2006	4F	47 Soundsystem	Output Tests	
Audi A6	2006	4F	47 Soundsystem	Specia Functions	
Audi A6	2006	4F	4F Electronic Central Electric II	Read Fault Codes	
Audi A6	2006	4F	4F Electronic Central Electric II	Clear Fault Codes	
Audi A6	2006	4F	4F Electronic Central Electric II	Measuring Blocks	
Audi A6	2006	4F	4F Electronic Central Electric II	Output Tests	
Audi A6	2006	4F	4F Electronic Central Electric II	Specia Functions	
Audi A6	2006	4F	51 Electric Drive	Read Fault Codes	
Audi A6	2006	4F	51 Electric Drive	Clear Fault Codes	
Audi A6	2006	4F	51 Electric Drive	Measuring Blocks	
Audi A6	2006	4F	51 Electric Drive	Output Tests	
Audi A6	2006	4F	51 Electric Drive	Specia Functions	
Audi A6	2006	4F	52 Passe.-Door Elect.	Read Fault Codes	
Audi A6	2006	4F	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A6	2006	4F	52 Passe.-Door Elect.	Measuring Blocks	
Audi A6	2006	4F	52 Passe.-Door Elect.	Output Tests	
Audi A6	2006	4F	52 Passe.-Door Elect.	Specia Functions	
Audi A6	2006	4F	53 Parking Brake	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2006	4F	53 Parking Brake	Clear Fault Codes	
Audi A6	2006	4F	53 Parking Brake	Measuring Blocks	
Audi A6	2006	4F	53 Parking Brake	Output Tests	
Audi A6	2006	4F	53 Parking Brake	Specia Functions	
Audi A6	2006	4F	55 Headlight Range Control	Read Fault Codes	
Audi A6	2006	4F	55 Headlight Range Control	Clear Fault Codes	
Audi A6	2006	4F	55 Headlight Range Control	Measuring Blocks	
Audi A6	2006	4F	55 Headlight Range Control	Output Tests	
Audi A6	2006	4F	55 Headlight Range Control	Specia Functions	
Audi A6	2006	4F	56 Radio	Read Fault Codes	
Audi A6	2006	4F	56 Radio	Clear Fault Codes	
Audi A6	2006	4F	56 Radio	Measuring Blocks	
Audi A6	2006	4F	56 Radio	Output Tests	
Audi A6	2006	4F	56 Radio	Specia Functions	
Audi A6	2006	4F	57 TV-Tuner	Read Fault Codes	
Audi A6	2006	4F	57 TV-Tuner	Clear Fault Codes	
Audi A6	2006	4F	57 TV-Tuner	Measuring Blocks	
Audi A6	2006	4F	57 TV-Tuner	Output Tests	
Audi A6	2006	4F	57 TV-Tuner	Specia Functions	
Audi A6	2006	4F	61 Battery Control	Read Fault Codes	
Audi A6	2006	4F	61 Battery Control	Clear Fault Codes	
Audi A6	2006	4F	61 Battery Control	Measuring Blocks	
Audi A6	2006	4F	61 Battery Control	Output Tests	
Audi A6	2006	4F	61 Battery Control	Specia Functions	
Audi A6	2006	4F	62 LR-Door Electroni.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2006	4F	62 LR-Door Electroni.	Clear Fault Codes	
Audi A6	2006	4F	62 LR-Door Electroni.	Measuring Blocks	
Audi A6	2006	4F	62 LR-Door Electroni.	Output Tests	
Audi A6	2006	4F	62 LR-Door Electroni.	Specia Functions	
Audi A6	2006	4F	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6	2006	4F	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6	2006	4F	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6	2006	4F	65 Tyre Pressure Monitoring	Output Tests	
Audi A6	2006	4F	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6	2006	4F	67 Voice Control	Read Fault Codes	
Audi A6	2006	4F	67 Voice Control	Clear Fault Codes	
Audi A6	2006	4F	67 Voice Control	Measuring Blocks	
Audi A6	2006	4F	67 Voice Control	Output Tests	
Audi A6	2006	4F	67 Voice Control	Specia Functions	
Audi A6	2006	4F	69 Trailer Function	Read Fault Codes	
Audi A6	2006	4F	69 Trailer Function	Clear Fault Codes	
Audi A6	2006	4F	69 Trailer Function	Measuring Blocks	
Audi A6	2006	4F	69 Trailer Function	Output Tests	
Audi A6	2006	4F	69 Trailer Function	Specia Functions	
Audi A6	2006	4F	6C Rear Camera	Read Fault Codes	
Audi A6	2006	4F	6C Rear Camera	Clear Fault Codes	
Audi A6	2006	4F	6C Rear Camera	Measuring Blocks	
Audi A6	2006	4F	6C Rear Camera	Output Tests	
Audi A6	2006	4F	6C Rear Camera	Specia Functions	
Audi A6	2006	4F	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2006	4F	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A6	2006	4F	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A6	2006	4F	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A6	2006	4F	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A6	2006	4F	72 RR-Door Electroni.	Read Fault Codes	
Audi A6	2006	4F	72 RR-Door Electroni.	Clear Fault Codes	
Audi A6	2006	4F	72 RR-Door Electroni.	Measuring Blocks	
Audi A6	2006	4F	72 RR-Door Electroni.	Output Tests	
Audi A6	2006	4F	72 RR-Door Electroni.	Specia Functions	
Audi A6	2006	4F	76 Parking Aid	Read Fault Codes	
Audi A6	2006	4F	76 Parking Aid	Clear Fault Codes	
Audi A6	2006	4F	76 Parking Aid	Measuring Blocks	
Audi A6	2006	4F	76 Parking Aid	Output Tests	
Audi A6	2006	4F	76 Parking Aid	Specia Functions	
Audi A6	2006	4F	77 Telephone	Read Fault Codes	
Audi A6	2006	4F	77 Telephone	Clear Fault Codes	
Audi A6	2006	4F	77 Telephone	Measuring Blocks	
Audi A6	2006	4F	77 Telephone	Output Tests	
Audi A6	2006	4F	77 Telephone	Specia Functions	
Audi A6	2006	4F	8C Hybrid Battery	Read Fault Codes	
Audi A6	2006	4F	8C Hybrid Battery	Clear Fault Codes	
Audi A6	2006	4F	8C Hybrid Battery	Measuring Blocks	
Audi A6	2006	4F	8C Hybrid Battery	Output Tests	
Audi A6	2006	4F	8C Hybrid Battery	Specia Functions	
Audi A6	2007	4F	01 Engine Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2007	4F	01 Engine Electronics	Clear Fault Codes	
Audi A6	2007	4F	01 Engine Electronics	Measuring Blocks	
Audi A6	2007	4F	01 Engine Electronics	Output Tests	
Audi A6	2007	4F	01 Engine Electronics	Specia Functions	
Audi A6	2007	4F	02 Transmission Electronics	Read Fault Codes	
Audi A6	2007	4F	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2007	4F	02 Transmission Electronics	Measuring Blocks	
Audi A6	2007	4F	02 Transmission Electronics	Output Tests	
Audi A6	2007	4F	02 Transmission Electronics	Specia Functions	
Audi A6	2007	4F	03 Brake Electronics	Read Fault Codes	
Audi A6	2007	4F	03 Brake Electronics	Clear Fault Codes	
Audi A6	2007	4F	03 Brake Electronics	Measuring Blocks	
Audi A6	2007	4F	03 Brake Electronics	Output Tests	
Audi A6	2007	4F	03 Brake Electronics	Specia Functions	
Audi A6	2007	4F	05 Access & Permissi.	Read Fault Codes	
Audi A6	2007	4F	05 Access & Permissi.	Clear Fault Codes	
Audi A6	2007	4F	05 Access & Permissi.	Measuring Blocks	
Audi A6	2007	4F	05 Access & Permissi.	Output Tests	
Audi A6	2007	4F	05 Access & Permissi.	Specia Functions	
Audi A6	2007	4F	06 Passene. Seat Adj.	Read Fault Codes	
Audi A6	2007	4F	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6	2007	4F	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6	2007	4F	06 Passene. Seat Adj.	Output Tests	
Audi A6	2007	4F	06 Passene. Seat Adj.	Specia Functions	
Audi A6	2007	4F	07 Display-/Cntl Unit	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2007	4F	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A6	2007	4F	07 Display-/Cntl Unit	Measuring Blocks	
Audi A6	2007	4F	07 Display-/Cntl Unit	Output Tests	
Audi A6	2007	4F	07 Display-/Cntl Unit	Specia Functions	
Audi A6	2007	4F	08 AC/Heating Electronics	Read Fault Codes	
Audi A6	2007	4F	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	2007	4F	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	2007	4F	08 AC/Heating Electronics	Output Tests	
Audi A6	2007	4F	08 AC/Heating Electronics	Specia Functions	
Audi A6	2007	4F	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A6	2007	4F	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A6	2007	4F	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A6	2007	4F	09 Electronic Ctrl Electronics	Output Tests	
Audi A6	2007	4F	09 Electronic Ctrl Electronics	Specia Functions	
Audi A6	2007	4F	0E Media Player Position 1	Read Fault Codes	
Audi A6	2007	4F	0E Media Player Position 1	Clear Fault Codes	
Audi A6	2007	4F	0E Media Player Position 1	Measuring Blocks	
Audi A6	2007	4F	0E Media Player Position 1	Output Tests	
Audi A6	2007	4F	0E Media Player Position 1	Specia Functions	
Audi A6	2007	4F	0F Radio Tuner-Digital	Read Fault Codes	
Audi A6	2007	4F	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A6	2007	4F	0F Radio Tuner-Digital	Measuring Blocks	
Audi A6	2007	4F	0F Radio Tuner-Digital	Output Tests	
Audi A6	2007	4F	0F Radio Tuner-Digital	Specia Functions	
Audi A6	2007	4F	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2007	4F	11 Engine Electronics 2	Clear Fault Codes	
Audi A6	2007	4F	11 Engine Electronics 2	Measuring Blocks	
Audi A6	2007	4F	11 Engine Electronics 2	Output Tests	
Audi A6	2007	4F	11 Engine Electronics 2	Specia Functions	
Audi A6	2007	4F	13 Distance Control	Read Fault Codes	
Audi A6	2007	4F	13 Distance Control	Clear Fault Codes	
Audi A6	2007	4F	13 Distance Control	Measuring Blocks	
Audi A6	2007	4F	13 Distance Control	Output Tests	
Audi A6	2007	4F	13 Distance Control	Specia Functions	
Audi A6	2007	4F	15 Airbags	Read Fault Codes	
Audi A6	2007	4F	15 Airbags	Clear Fault Codes	
Audi A6	2007	4F	15 Airbags	Measuring Blocks	
Audi A6	2007	4F	15 Airbags	Output Tests	
Audi A6	2007	4F	15 Airbags	Specia Functions	
Audi A6	2007	4F	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2007	4F	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2007	4F	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2007	4F	16 Steering Wheel Electronics	Output Tests	
Audi A6	2007	4F	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2007	4F	17 Instrument Cluster	Read Fault Codes	
Audi A6	2007	4F	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2007	4F	17 Instrument Cluster	Measuring Blocks	
Audi A6	2007	4F	17 Instrument Cluster	Output Tests	
Audi A6	2007	4F	17 Instrument Cluster	Specia Functions	
Audi A6	2007	4F	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2007	4F	18 Aux Heating	Clear Fault Codes	
Audi A6	2007	4F	18 Aux Heating	Measuring Blocks	
Audi A6	2007	4F	18 Aux Heating	Output Tests	
Audi A6	2007	4F	18 Aux Heating	Specia Functions	
Audi A6	2007	4F	19 Gateway Data Bus	Read Fault Codes	
Audi A6	2007	4F	19 Gateway Data Bus	Clear Fault Codes	
Audi A6	2007	4F	19 Gateway Data Bus	Measuring Blocks	
Audi A6	2007	4F	19 Gateway Data Bus	Output Tests	
Audi A6	2007	4F	19 Gateway Data Bus	Specia Functions	
Audi A6	2007	4F	1E Media Player Position 2	Read Fault Codes	
Audi A6	2007	4F	1E Media Player Position 2	Clear Fault Codes	
Audi A6	2007	4F	1E Media Player Position 2	Measuring Blocks	
Audi A6	2007	4F	1E Media Player Position 2	Output Tests	
Audi A6	2007	4F	1E Media Player Position 2	Specia Functions	
Audi A6	2007	4F	25 Immobilizer	Read Fault Codes	
Audi A6	2007	4F	25 Immobilizer	Clear Fault Codes	
Audi A6	2007	4F	25 Immobilizer	Measuring Blocks	
Audi A6	2007	4F	25 Immobilizer	Output Tests	
Audi A6	2007	4F	25 Immobilizer	Specia Functions	
Audi A6	2007	4F	28 Climate Control Unit Rear	Read Fault Codes	
Audi A6	2007	4F	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A6	2007	4F	28 Climate Control Unit Rear	Measuring Blocks	
Audi A6	2007	4F	28 Climate Control Unit Rear	Output Tests	
Audi A6	2007	4F	28 Climate Control Unit Rear	Specia Functions	
Audi A6	2007	4F	34 Self Leveling Suspension	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2007	4F	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	2007	4F	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	2007	4F	34 Self Leveling Suspension	Output Tests	
Audi A6	2007	4F	34 Self Leveling Suspension	Specia Functions	
Audi A6	2007	4F	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A6	2007	4F	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	2007	4F	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	2007	4F	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	2007	4F	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	2007	4F	37 Navigation	Read Fault Codes	
Audi A6	2007	4F	37 Navigation	Clear Fault Codes	
Audi A6	2007	4F	37 Navigation	Measuring Blocks	
Audi A6	2007	4F	37 Navigation	Output Tests	
Audi A6	2007	4F	37 Navigation	Specia Functions	
Audi A6	2007	4F	3C Lane Departure Assistance System	Read Fault Codes	
Audi A6	2007	4F	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A6	2007	4F	3C Lane Departure Assistance System	Measuring Blocks	
Audi A6	2007	4F	3C Lane Departure Assistance System	Output Tests	
Audi A6	2007	4F	3C Lane Departure Assistance System	Specia Functions	
Audi A6	2007	4F	3D Special Function	Read Fault Codes	
Audi A6	2007	4F	3D Special Function	Clear Fault Codes	
Audi A6	2007	4F	3D Special Function	Measuring Blocks	
Audi A6	2007	4F	3D Special Function	Output Tests	
Audi A6	2007	4F	3D Special Function	Specia Functions	
Audi A6	2007	4F	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2007	4F	42 Driver-Door Elect.	Clear Fault Codes	
Audi A6	2007	4F	42 Driver-Door Elect.	Measuring Blocks	
Audi A6	2007	4F	42 Driver-Door Elect.	Output Tests	
Audi A6	2007	4F	42 Driver-Door Elect.	Specia Functions	
Audi A6	2007	4F	46 Central Control Module	Read Fault Codes	
Audi A6	2007	4F	46 Central Control Module	Clear Fault Codes	
Audi A6	2007	4F	46 Central Control Module	Measuring Blocks	
Audi A6	2007	4F	46 Central Control Module	Output Tests	
Audi A6	2007	4F	46 Central Control Module	Specia Functions	
Audi A6	2007	4F	47 Soundsystem	Read Fault Codes	
Audi A6	2007	4F	47 Soundsystem	Clear Fault Codes	
Audi A6	2007	4F	47 Soundsystem	Measuring Blocks	
Audi A6	2007	4F	47 Soundsystem	Output Tests	
Audi A6	2007	4F	47 Soundsystem	Specia Functions	
Audi A6	2007	4F	4F Electronic Central Electric II	Read Fault Codes	
Audi A6	2007	4F	4F Electronic Central Electric II	Clear Fault Codes	
Audi A6	2007	4F	4F Electronic Central Electric II	Measuring Blocks	
Audi A6	2007	4F	4F Electronic Central Electric II	Output Tests	
Audi A6	2007	4F	4F Electronic Central Electric II	Specia Functions	
Audi A6	2007	4F	51 Electric Drive	Read Fault Codes	
Audi A6	2007	4F	51 Electric Drive	Clear Fault Codes	
Audi A6	2007	4F	51 Electric Drive	Measuring Blocks	
Audi A6	2007	4F	51 Electric Drive	Output Tests	
Audi A6	2007	4F	51 Electric Drive	Specia Functions	
Audi A6	2007	4F	52 Passe.-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2007	4F	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A6	2007	4F	52 Passe.-Door Elect.	Measuring Blocks	
Audi A6	2007	4F	52 Passe.-Door Elect.	Output Tests	
Audi A6	2007	4F	52 Passe.-Door Elect.	Specia Functions	
Audi A6	2007	4F	53 Parking Brake	Read Fault Codes	
Audi A6	2007	4F	53 Parking Brake	Clear Fault Codes	
Audi A6	2007	4F	53 Parking Brake	Measuring Blocks	
Audi A6	2007	4F	53 Parking Brake	Output Tests	
Audi A6	2007	4F	53 Parking Brake	Specia Functions	
Audi A6	2007	4F	55 Headlight Range Control	Read Fault Codes	
Audi A6	2007	4F	55 Headlight Range Control	Clear Fault Codes	
Audi A6	2007	4F	55 Headlight Range Control	Measuring Blocks	
Audi A6	2007	4F	55 Headlight Range Control	Output Tests	
Audi A6	2007	4F	55 Headlight Range Control	Specia Functions	
Audi A6	2007	4F	56 Radio	Read Fault Codes	
Audi A6	2007	4F	56 Radio	Clear Fault Codes	
Audi A6	2007	4F	56 Radio	Measuring Blocks	
Audi A6	2007	4F	56 Radio	Output Tests	
Audi A6	2007	4F	56 Radio	Specia Functions	
Audi A6	2007	4F	57 TV-Tuner	Read Fault Codes	
Audi A6	2007	4F	57 TV-Tuner	Clear Fault Codes	
Audi A6	2007	4F	57 TV-Tuner	Measuring Blocks	
Audi A6	2007	4F	57 TV-Tuner	Output Tests	
Audi A6	2007	4F	57 TV-Tuner	Specia Functions	
Audi A6	2007	4F	61 Battery Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2007	4F	61 Battery Control	Clear Fault Codes	
Audi A6	2007	4F	61 Battery Control	Measuring Blocks	
Audi A6	2007	4F	61 Battery Control	Output Tests	
Audi A6	2007	4F	61 Battery Control	Specia Functions	
Audi A6	2007	4F	62 LR-Door Electroni.	Read Fault Codes	
Audi A6	2007	4F	62 LR-Door Electroni.	Clear Fault Codes	
Audi A6	2007	4F	62 LR-Door Electroni.	Measuring Blocks	
Audi A6	2007	4F	62 LR-Door Electroni.	Output Tests	
Audi A6	2007	4F	62 LR-Door Electroni.	Specia Functions	
Audi A6	2007	4F	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6	2007	4F	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6	2007	4F	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6	2007	4F	65 Tyre Pressure Monitoring	Output Tests	
Audi A6	2007	4F	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6	2007	4F	67 Voice Control	Read Fault Codes	
Audi A6	2007	4F	67 Voice Control	Clear Fault Codes	
Audi A6	2007	4F	67 Voice Control	Measuring Blocks	
Audi A6	2007	4F	67 Voice Control	Output Tests	
Audi A6	2007	4F	67 Voice Control	Specia Functions	
Audi A6	2007	4F	69 Trailer Function	Read Fault Codes	
Audi A6	2007	4F	69 Trailer Function	Clear Fault Codes	
Audi A6	2007	4F	69 Trailer Function	Measuring Blocks	
Audi A6	2007	4F	69 Trailer Function	Output Tests	
Audi A6	2007	4F	69 Trailer Function	Specia Functions	
Audi A6	2007	4F	6C Rear Camera	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2007	4F	6C Rear Camera	Clear Fault Codes	
Audi A6	2007	4F	6C Rear Camera	Measuring Blocks	
Audi A6	2007	4F	6C Rear Camera	Output Tests	
Audi A6	2007	4F	6C Rear Camera	Specia Functions	
Audi A6	2007	4F	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A6	2007	4F	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A6	2007	4F	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A6	2007	4F	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A6	2007	4F	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A6	2007	4F	72 RR-Door Electroni.	Read Fault Codes	
Audi A6	2007	4F	72 RR-Door Electroni.	Clear Fault Codes	
Audi A6	2007	4F	72 RR-Door Electroni.	Measuring Blocks	
Audi A6	2007	4F	72 RR-Door Electroni.	Output Tests	
Audi A6	2007	4F	72 RR-Door Electroni.	Specia Functions	
Audi A6	2007	4F	76 Parking Aid	Read Fault Codes	
Audi A6	2007	4F	76 Parking Aid	Clear Fault Codes	
Audi A6	2007	4F	76 Parking Aid	Measuring Blocks	
Audi A6	2007	4F	76 Parking Aid	Output Tests	
Audi A6	2007	4F	76 Parking Aid	Specia Functions	
Audi A6	2007	4F	77 Telephone	Read Fault Codes	
Audi A6	2007	4F	77 Telephone	Clear Fault Codes	
Audi A6	2007	4F	77 Telephone	Measuring Blocks	
Audi A6	2007	4F	77 Telephone	Output Tests	
Audi A6	2007	4F	77 Telephone	Specia Functions	
Audi A6	2007	4F	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2007	4F	8C Hybrid Battery	Clear Fault Codes	
Audi A6	2007	4F	8C Hybrid Battery	Measuring Blocks	
Audi A6	2007	4F	8C Hybrid Battery	Output Tests	
Audi A6	2007	4F	8C Hybrid Battery	Specia Functions	
Audi A8	2002-2003	4E	01 Engine Electronics	Read Fault Codes	
Audi A8	2002-2003	4E	01 Engine Electronics	Clear Fault Codes	
Audi A8	2002-2003	4E	01 Engine Electronics	Measuring Blocks	
Audi A8	2002-2003	4E	01 Engine Electronics	Output Tests	
Audi A8	2002-2003	4E	01 Engine Electronics	Specia Functions	
Audi A8	2002-2003	4E	02 Transmission Electronics	Read Fault Codes	
Audi A8	2002-2003	4E	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2002-2003	4E	02 Transmission Electronics	Measuring Blocks	
Audi A8	2002-2003	4E	02 Transmission Electronics	Output Tests	
Audi A8	2002-2003	4E	02 Transmission Electronics	Specia Functions	
Audi A8	2002-2003	4E	03 Brake Electronics	Read Fault Codes	
Audi A8	2002-2003	4E	03 Brake Electronics	Clear Fault Codes	
Audi A8	2002-2003	4E	03 Brake Electronics	Measuring Blocks	
Audi A8	2002-2003	4E	03 Brake Electronics	Output Tests	
Audi A8	2002-2003	4E	03 Brake Electronics	Specia Functions	
Audi A8	2002-2003	4E	05 Access & Permissi.	Read Fault Codes	
Audi A8	2002-2003	4E	05 Access & Permissi.	Clear Fault Codes	
Audi A8	2002-2003	4E	05 Access & Permissi.	Measuring Blocks	
Audi A8	2002-2003	4E	05 Access & Permissi.	Output Tests	
Audi A8	2002-2003	4E	05 Access & Permissi.	Specia Functions	
Audi A8	2002-2003	4E	06 Passene. Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002-2003	4E	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A8	2002-2003	4E	06 Passene. Seat Adj.	Measuring Blocks	
Audi A8	2002-2003	4E	06 Passene. Seat Adj.	Output Tests	
Audi A8	2002-2003	4E	06 Passene. Seat Adj.	Specia Functions	
Audi A8	2002-2003	4E	07 Display-/Cntl Unit	Read Fault Codes	
Audi A8	2002-2003	4E	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A8	2002-2003	4E	07 Display-/Cntl Unit	Measuring Blocks	
Audi A8	2002-2003	4E	07 Display-/Cntl Unit	Output Tests	
Audi A8	2002-2003	4E	07 Display-/Cntl Unit	Specia Functions	
Audi A8	2002-2003	4E	08 AC/Heating Electronics	Read Fault Codes	
Audi A8	2002-2003	4E	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	2002-2003	4E	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	2002-2003	4E	08 AC/Heating Electronics	Output Tests	
Audi A8	2002-2003	4E	08 AC/Heating Electronics	Specia Functions	
Audi A8	2002-2003	4E	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A8	2002-2003	4E	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A8	2002-2003	4E	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A8	2002-2003	4E	09 Electronic Ctrl Electronics	Output Tests	
Audi A8	2002-2003	4E	09 Electronic Ctrl Electronics	Specia Functions	
Audi A8	2002-2003	4E	0E Media Player Position 1	Read Fault Codes	
Audi A8	2002-2003	4E	0E Media Player Position 1	Clear Fault Codes	
Audi A8	2002-2003	4E	0E Media Player Position 1	Measuring Blocks	
Audi A8	2002-2003	4E	0E Media Player Position 1	Output Tests	
Audi A8	2002-2003	4E	0E Media Player Position 1	Specia Functions	
Audi A8	2002-2003	4E	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002-2003	4E	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	2002-2003	4E	11 Engine Electronics 2	Measuring Blocks	
Audi A8	2002-2003	4E	11 Engine Electronics 2	Output Tests	
Audi A8	2002-2003	4E	11 Engine Electronics 2	Specia Functions	
Audi A8	2002-2003	4E	13 Distance Control	Read Fault Codes	
Audi A8	2002-2003	4E	13 Distance Control	Clear Fault Codes	
Audi A8	2002-2003	4E	13 Distance Control	Measuring Blocks	
Audi A8	2002-2003	4E	13 Distance Control	Output Tests	
Audi A8	2002-2003	4E	13 Distance Control	Specia Functions	
Audi A8	2002-2003	4E	15 Airbags	Read Fault Codes	
Audi A8	2002-2003	4E	15 Airbags	Clear Fault Codes	
Audi A8	2002-2003	4E	15 Airbags	Measuring Blocks	
Audi A8	2002-2003	4E	15 Airbags	Output Tests	
Audi A8	2002-2003	4E	15 Airbags	Specia Functions	
Audi A8	2002-2003	4E	16 Steering Wheel Electronics	Read Fault Codes	
Audi A8	2002-2003	4E	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2002-2003	4E	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2002-2003	4E	16 Steering Wheel Electronics	Output Tests	
Audi A8	2002-2003	4E	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2002-2003	4E	17 Instrument Cluster	Read Fault Codes	
Audi A8	2002-2003	4E	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2002-2003	4E	17 Instrument Cluster	Measuring Blocks	
Audi A8	2002-2003	4E	17 Instrument Cluster	Output Tests	
Audi A8	2002-2003	4E	17 Instrument Cluster	Specia Functions	
Audi A8	2002-2003	4E	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002-2003	4E	18 Aux Heating	Clear Fault Codes	
Audi A8	2002-2003	4E	18 Aux Heating	Measuring Blocks	
Audi A8	2002-2003	4E	18 Aux Heating	Output Tests	
Audi A8	2002-2003	4E	18 Aux Heating	Specia Functions	
Audi A8	2002-2003	4E	19 Gateway Data Bus	Read Fault Codes	
Audi A8	2002-2003	4E	19 Gateway Data Bus	Clear Fault Codes	
Audi A8	2002-2003	4E	19 Gateway Data Bus	Measuring Blocks	
Audi A8	2002-2003	4E	19 Gateway Data Bus	Output Tests	
Audi A8	2002-2003	4E	19 Gateway Data Bus	Specia Functions	
Audi A8	2002-2003	4E	1D Driver Identification	Read Fault Codes	
Audi A8	2002-2003	4E	1D Driver Identification	Clear Fault Codes	
Audi A8	2002-2003	4E	1D Driver Identification	Measuring Blocks	
Audi A8	2002-2003	4E	1D Driver Identification	Output Tests	
Audi A8	2002-2003	4E	1D Driver Identification	Specia Functions	
Audi A8	2002-2003	4E	1E Media Player Position 2	Read Fault Codes	
Audi A8	2002-2003	4E	1E Media Player Position 2	Clear Fault Codes	
Audi A8	2002-2003	4E	1E Media Player Position 2	Measuring Blocks	
Audi A8	2002-2003	4E	1E Media Player Position 2	Output Tests	
Audi A8	2002-2003	4E	1E Media Player Position 2	Specia Functions	
Audi A8	2002-2003	4E	25 Immobilizer	Read Fault Codes	
Audi A8	2002-2003	4E	25 Immobilizer	Clear Fault Codes	
Audi A8	2002-2003	4E	25 Immobilizer	Measuring Blocks	
Audi A8	2002-2003	4E	25 Immobilizer	Output Tests	
Audi A8	2002-2003	4E	25 Immobilizer	Specia Functions	
Audi A8	2002-2003	4E	28 Climate Control Unit Rear	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002-2003	4E	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A8	2002-2003	4E	28 Climate Control Unit Rear	Measuring Blocks	
Audi A8	2002-2003	4E	28 Climate Control Unit Rear	Output Tests	
Audi A8	2002-2003	4E	28 Climate Control Unit Rear	Specia Functions	
Audi A8	2002-2003	4E	34 Self Leveling Suspension	Read Fault Codes	
Audi A8	2002-2003	4E	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8	2002-2003	4E	34 Self Leveling Suspension	Measuring Blocks	
Audi A8	2002-2003	4E	34 Self Leveling Suspension	Output Tests	
Audi A8	2002-2003	4E	34 Self Leveling Suspension	Specia Functions	
Audi A8	2002-2003	4E	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A8	2002-2003	4E	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A8	2002-2003	4E	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A8	2002-2003	4E	36 Side of Driver Seat Adj.	Output Tests	
Audi A8	2002-2003	4E	36 Side of Driver Seat Adj.	Specia Functions	
Audi A8	2002-2003	4E	37 Navigation	Read Fault Codes	
Audi A8	2002-2003	4E	37 Navigation	Clear Fault Codes	
Audi A8	2002-2003	4E	37 Navigation	Measuring Blocks	
Audi A8	2002-2003	4E	37 Navigation	Output Tests	
Audi A8	2002-2003	4E	37 Navigation	Specia Functions	
Audi A8	2002-2003	4E	38 Roof Electronics	Read Fault Codes	
Audi A8	2002-2003	4E	38 Roof Electronics	Clear Fault Codes	
Audi A8	2002-2003	4E	38 Roof Electronics	Measuring Blocks	
Audi A8	2002-2003	4E	38 Roof Electronics	Output Tests	
Audi A8	2002-2003	4E	38 Roof Electronics	Specia Functions	
Audi A8	2002-2003	4E	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002-2003	4E	42 Driver-Door Elect.	Clear Fault Codes	
Audi A8	2002-2003	4E	42 Driver-Door Elect.	Measuring Blocks	
Audi A8	2002-2003	4E	42 Driver-Door Elect.	Output Tests	
Audi A8	2002-2003	4E	42 Driver-Door Elect.	Specia Functions	
Audi A8	2002-2003	4E	46 Central Control Module	Read Fault Codes	
Audi A8	2002-2003	4E	46 Central Control Module	Clear Fault Codes	
Audi A8	2002-2003	4E	46 Central Control Module	Measuring Blocks	
Audi A8	2002-2003	4E	46 Central Control Module	Output Tests	
Audi A8	2002-2003	4E	46 Central Control Module	Specia Functions	
Audi A8	2002-2003	4E	47 Soundsystem	Read Fault Codes	
Audi A8	2002-2003	4E	47 Soundsystem	Clear Fault Codes	
Audi A8	2002-2003	4E	47 Soundsystem	Measuring Blocks	
Audi A8	2002-2003	4E	47 Soundsystem	Output Tests	
Audi A8	2002-2003	4E	47 Soundsystem	Specia Functions	
Audi A8	2002-2003	4E	4E Control Head RR	Read Fault Codes	
Audi A8	2002-2003	4E	4E Control Head RR	Clear Fault Codes	
Audi A8	2002-2003	4E	4E Control Head RR	Measuring Blocks	
Audi A8	2002-2003	4E	4E Control Head RR	Output Tests	
Audi A8	2002-2003	4E	4E Control Head RR	Specia Functions	
Audi A8	2002-2003	4E	4F Electronic Central Electric II	Read Fault Codes	
Audi A8	2002-2003	4E	4F Electronic Central Electric II	Clear Fault Codes	
Audi A8	2002-2003	4E	4F Electronic Central Electric II	Measuring Blocks	
Audi A8	2002-2003	4E	4F Electronic Central Electric II	Output Tests	
Audi A8	2002-2003	4E	4F Electronic Central Electric II	Specia Functions	
Audi A8	2002-2003	4E	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002-2003	4E	51 Electric Drive	Clear Fault Codes	
Audi A8	2002-2003	4E	51 Electric Drive	Measuring Blocks	
Audi A8	2002-2003	4E	51 Electric Drive	Output Tests	
Audi A8	2002-2003	4E	51 Electric Drive	Specia Functions	
Audi A8	2002-2003	4E	52 Passe.-Door Elect.	Read Fault Codes	
Audi A8	2002-2003	4E	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A8	2002-2003	4E	52 Passe.-Door Elect.	Measuring Blocks	
Audi A8	2002-2003	4E	52 Passe.-Door Elect.	Output Tests	
Audi A8	2002-2003	4E	52 Passe.-Door Elect.	Specia Functions	
Audi A8	2002-2003	4E	53 Parking Brake	Read Fault Codes	
Audi A8	2002-2003	4E	53 Parking Brake	Clear Fault Codes	
Audi A8	2002-2003	4E	53 Parking Brake	Measuring Blocks	
Audi A8	2002-2003	4E	53 Parking Brake	Output Tests	
Audi A8	2002-2003	4E	53 Parking Brake	Specia Functions	
Audi A8	2002-2003	4E	55 Headlight Range Control	Read Fault Codes	
Audi A8	2002-2003	4E	55 Headlight Range Control	Clear Fault Codes	
Audi A8	2002-2003	4E	55 Headlight Range Control	Measuring Blocks	
Audi A8	2002-2003	4E	55 Headlight Range Control	Output Tests	
Audi A8	2002-2003	4E	55 Headlight Range Control	Specia Functions	
Audi A8	2002-2003	4E	56 Radio	Read Fault Codes	
Audi A8	2002-2003	4E	56 Radio	Clear Fault Codes	
Audi A8	2002-2003	4E	56 Radio	Measuring Blocks	
Audi A8	2002-2003	4E	56 Radio	Output Tests	
Audi A8	2002-2003	4E	56 Radio	Specia Functions	
Audi A8	2002-2003	4E	57 TV-Tuner	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002-2003	4E	57 TV-Tuner	Clear Fault Codes	
Audi A8	2002-2003	4E	57 TV-Tuner	Measuring Blocks	
Audi A8	2002-2003	4E	57 TV-Tuner	Output Tests	
Audi A8	2002-2003	4E	57 TV-Tuner	Specia Functions	
Audi A8	2002-2003	4E	5E Control Head LR	Read Fault Codes	
Audi A8	2002-2003	4E	5E Control Head LR	Clear Fault Codes	
Audi A8	2002-2003	4E	5E Control Head LR	Measuring Blocks	
Audi A8	2002-2003	4E	5E Control Head LR	Output Tests	
Audi A8	2002-2003	4E	5E Control Head LR	Specia Functions	
Audi A8	2002-2003	4E	61 Battery Control	Read Fault Codes	
Audi A8	2002-2003	4E	61 Battery Control	Clear Fault Codes	
Audi A8	2002-2003	4E	61 Battery Control	Measuring Blocks	
Audi A8	2002-2003	4E	61 Battery Control	Output Tests	
Audi A8	2002-2003	4E	61 Battery Control	Specia Functions	
Audi A8	2002-2003	4E	62 LR-Door Electroni.	Read Fault Codes	
Audi A8	2002-2003	4E	62 LR-Door Electroni.	Clear Fault Codes	
Audi A8	2002-2003	4E	62 LR-Door Electroni.	Measuring Blocks	
Audi A8	2002-2003	4E	62 LR-Door Electroni.	Output Tests	
Audi A8	2002-2003	4E	62 LR-Door Electroni.	Specia Functions	
Audi A8	2002-2003	4E	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8	2002-2003	4E	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8	2002-2003	4E	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8	2002-2003	4E	65 Tyre Pressure Monitoring	Output Tests	
Audi A8	2002-2003	4E	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8	2002-2003	4E	66 Seat-/Mirror Adjust.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002-2003	4E	66 Seat-/Mirror Adjust.	Clear Fault Codes	
Audi A8	2002-2003	4E	66 Seat-/Mirror Adjust.	Measuring Blocks	
Audi A8	2002-2003	4E	66 Seat-/Mirror Adjust.	Output Tests	
Audi A8	2002-2003	4E	66 Seat-/Mirror Adjust.	Specia Functions	
Audi A8	2002-2003	4E	67 Voice Control	Read Fault Codes	
Audi A8	2002-2003	4E	67 Voice Control	Clear Fault Codes	
Audi A8	2002-2003	4E	67 Voice Control	Measuring Blocks	
Audi A8	2002-2003	4E	67 Voice Control	Output Tests	
Audi A8	2002-2003	4E	67 Voice Control	Specia Functions	
Audi A8	2002-2003	4E	69 Trailer Function	Read Fault Codes	
Audi A8	2002-2003	4E	69 Trailer Function	Clear Fault Codes	
Audi A8	2002-2003	4E	69 Trailer Function	Measuring Blocks	
Audi A8	2002-2003	4E	69 Trailer Function	Output Tests	
Audi A8	2002-2003	4E	69 Trailer Function	Specia Functions	
Audi A8	2002-2003	4E	72 RR-Door Electroni.	Read Fault Codes	
Audi A8	2002-2003	4E	72 RR-Door Electroni.	Clear Fault Codes	
Audi A8	2002-2003	4E	72 RR-Door Electroni.	Measuring Blocks	
Audi A8	2002-2003	4E	72 RR-Door Electroni.	Output Tests	
Audi A8	2002-2003	4E	72 RR-Door Electroni.	Specia Functions	
Audi A8	2002-2003	4E	76 Parking Aid	Read Fault Codes	
Audi A8	2002-2003	4E	76 Parking Aid	Clear Fault Codes	
Audi A8	2002-2003	4E	76 Parking Aid	Measuring Blocks	
Audi A8	2002-2003	4E	76 Parking Aid	Output Tests	
Audi A8	2002-2003	4E	76 Parking Aid	Specia Functions	
Audi A8	2002-2003	4E	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002-2003	4E	77 Telephone	Clear Fault Codes	
Audi A8	2002-2003	4E	77 Telephone	Measuring Blocks	
Audi A8	2002-2003	4E	77 Telephone	Output Tests	
Audi A8	2002-2003	4E	77 Telephone	Specia Functions	
Audi A8	2002-2003	4E	8C Hybrid Battery	Read Fault Codes	
Audi A8	2002-2003	4E	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2002-2003	4E	8C Hybrid Battery	Measuring Blocks	
Audi A8	2002-2003	4E	8C Hybrid Battery	Output Tests	
Audi A8	2002-2003	4E	8C Hybrid Battery	Specia Functions	
Audi A8	2004-2006	4E	01 Engine Electronics	Read Fault Codes	
Audi A8	2004-2006	4E	01 Engine Electronics	Clear Fault Codes	
Audi A8	2004-2006	4E	01 Engine Electronics	Measuring Blocks	
Audi A8	2004-2006	4E	01 Engine Electronics	Output Tests	
Audi A8	2004-2006	4E	01 Engine Electronics	Specia Functions	
Audi A8	2004-2006	4E	02 Transmission Electronics	Read Fault Codes	
Audi A8	2004-2006	4E	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2004-2006	4E	02 Transmission Electronics	Measuring Blocks	
Audi A8	2004-2006	4E	02 Transmission Electronics	Output Tests	
Audi A8	2004-2006	4E	02 Transmission Electronics	Specia Functions	
Audi A8	2004-2006	4E	03 Brake Electronics	Read Fault Codes	
Audi A8	2004-2006	4E	03 Brake Electronics	Clear Fault Codes	
Audi A8	2004-2006	4E	03 Brake Electronics	Measuring Blocks	
Audi A8	2004-2006	4E	03 Brake Electronics	Output Tests	
Audi A8	2004-2006	4E	03 Brake Electronics	Specia Functions	
Audi A8	2004-2006	4E	05 Access & Permissi.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2004-2006	4E	05 Access & Permissi.	Clear Fault Codes	
Audi A8	2004-2006	4E	05 Access & Permissi.	Measuring Blocks	
Audi A8	2004-2006	4E	05 Access & Permissi.	Output Tests	
Audi A8	2004-2006	4E	05 Access & Permissi.	Specia Functions	
Audi A8	2004-2006	4E	06 Passene. Seat Adj.	Read Fault Codes	
Audi A8	2004-2006	4E	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A8	2004-2006	4E	06 Passene. Seat Adj.	Measuring Blocks	
Audi A8	2004-2006	4E	06 Passene. Seat Adj.	Output Tests	
Audi A8	2004-2006	4E	06 Passene. Seat Adj.	Specia Functions	
Audi A8	2004-2006	4E	07 Display-/Cntl Unit	Read Fault Codes	
Audi A8	2004-2006	4E	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A8	2004-2006	4E	07 Display-/Cntl Unit	Measuring Blocks	
Audi A8	2004-2006	4E	07 Display-/Cntl Unit	Output Tests	
Audi A8	2004-2006	4E	07 Display-/Cntl Unit	Specia Functions	
Audi A8	2004-2006	4E	08 AC/Heating Electronics	Read Fault Codes	
Audi A8	2004-2006	4E	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	2004-2006	4E	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	2004-2006	4E	08 AC/Heating Electronics	Output Tests	
Audi A8	2004-2006	4E	08 AC/Heating Electronics	Specia Functions	
Audi A8	2004-2006	4E	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A8	2004-2006	4E	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A8	2004-2006	4E	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A8	2004-2006	4E	09 Electronic Ctrl Electronics	Output Tests	
Audi A8	2004-2006	4E	09 Electronic Ctrl Electronics	Specia Functions	
Audi A8	2004-2006	4E	0E Media Player Position 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2004-2006	4E	0E Media Player Position 1	Clear Fault Codes	
Audi A8	2004-2006	4E	0E Media Player Position 1	Measuring Blocks	
Audi A8	2004-2006	4E	0E Media Player Position 1	Output Tests	
Audi A8	2004-2006	4E	0E Media Player Position 1	Specia Functions	
Audi A8	2004-2006	4E	0F Radio Tuner-Digital	Read Fault Codes	
Audi A8	2004-2006	4E	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A8	2004-2006	4E	0F Radio Tuner-Digital	Measuring Blocks	
Audi A8	2004-2006	4E	0F Radio Tuner-Digital	Output Tests	
Audi A8	2004-2006	4E	0F Radio Tuner-Digital	Specia Functions	
Audi A8	2004-2006	4E	11 Engine Electronics 2	Read Fault Codes	
Audi A8	2004-2006	4E	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	2004-2006	4E	11 Engine Electronics 2	Measuring Blocks	
Audi A8	2004-2006	4E	11 Engine Electronics 2	Output Tests	
Audi A8	2004-2006	4E	11 Engine Electronics 2	Specia Functions	
Audi A8	2004-2006	4E	13 Distance Control	Read Fault Codes	
Audi A8	2004-2006	4E	13 Distance Control	Clear Fault Codes	
Audi A8	2004-2006	4E	13 Distance Control	Measuring Blocks	
Audi A8	2004-2006	4E	13 Distance Control	Output Tests	
Audi A8	2004-2006	4E	13 Distance Control	Specia Functions	
Audi A8	2004-2006	4E	15 Airbags	Read Fault Codes	
Audi A8	2004-2006	4E	15 Airbags	Clear Fault Codes	
Audi A8	2004-2006	4E	15 Airbags	Measuring Blocks	
Audi A8	2004-2006	4E	15 Airbags	Output Tests	
Audi A8	2004-2006	4E	15 Airbags	Specia Functions	
Audi A8	2004-2006	4E	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2004-2006	4E	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2004-2006	4E	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2004-2006	4E	16 Steering Wheel Electronics	Output Tests	
Audi A8	2004-2006	4E	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2004-2006	4E	17 Instrument Cluster	Read Fault Codes	
Audi A8	2004-2006	4E	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2004-2006	4E	17 Instrument Cluster	Measuring Blocks	
Audi A8	2004-2006	4E	17 Instrument Cluster	Output Tests	
Audi A8	2004-2006	4E	17 Instrument Cluster	Specia Functions	
Audi A8	2004-2006	4E	18 Aux Heating	Read Fault Codes	
Audi A8	2004-2006	4E	18 Aux Heating	Clear Fault Codes	
Audi A8	2004-2006	4E	18 Aux Heating	Measuring Blocks	
Audi A8	2004-2006	4E	18 Aux Heating	Output Tests	
Audi A8	2004-2006	4E	18 Aux Heating	Specia Functions	
Audi A8	2004-2006	4E	19 Gateway Data Bus	Read Fault Codes	
Audi A8	2004-2006	4E	19 Gateway Data Bus	Clear Fault Codes	
Audi A8	2004-2006	4E	19 Gateway Data Bus	Measuring Blocks	
Audi A8	2004-2006	4E	19 Gateway Data Bus	Output Tests	
Audi A8	2004-2006	4E	19 Gateway Data Bus	Specia Functions	
Audi A8	2004-2006	4E	1D Driver Identification	Read Fault Codes	
Audi A8	2004-2006	4E	1D Driver Identification	Clear Fault Codes	
Audi A8	2004-2006	4E	1D Driver Identification	Measuring Blocks	
Audi A8	2004-2006	4E	1D Driver Identification	Output Tests	
Audi A8	2004-2006	4E	1D Driver Identification	Specia Functions	
Audi A8	2004-2006	4E	1E Media Player Position 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2004-2006	4E	1E Media Player Position 2	Clear Fault Codes	
Audi A8	2004-2006	4E	1E Media Player Position 2	Measuring Blocks	
Audi A8	2004-2006	4E	1E Media Player Position 2	Output Tests	
Audi A8	2004-2006	4E	1E Media Player Position 2	Specia Functions	
Audi A8	2004-2006	4E	25 Immobilizer	Read Fault Codes	
Audi A8	2004-2006	4E	25 Immobilizer	Clear Fault Codes	
Audi A8	2004-2006	4E	25 Immobilizer	Measuring Blocks	
Audi A8	2004-2006	4E	25 Immobilizer	Output Tests	
Audi A8	2004-2006	4E	25 Immobilizer	Specia Functions	
Audi A8	2004-2006	4E	28 Climate Control Unit Rear	Read Fault Codes	
Audi A8	2004-2006	4E	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A8	2004-2006	4E	28 Climate Control Unit Rear	Measuring Blocks	
Audi A8	2004-2006	4E	28 Climate Control Unit Rear	Output Tests	
Audi A8	2004-2006	4E	28 Climate Control Unit Rear	Specia Functions	
Audi A8	2004-2006	4E	2E Media Player Position 3	Read Fault Codes	
Audi A8	2004-2006	4E	2E Media Player Position 3	Clear Fault Codes	
Audi A8	2004-2006	4E	2E Media Player Position 3	Measuring Blocks	
Audi A8	2004-2006	4E	2E Media Player Position 3	Output Tests	
Audi A8	2004-2006	4E	2E Media Player Position 3	Specia Functions	
Audi A8	2004-2006	4E	34 Self Leveling Suspension	Read Fault Codes	
Audi A8	2004-2006	4E	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8	2004-2006	4E	34 Self Leveling Suspension	Measuring Blocks	
Audi A8	2004-2006	4E	34 Self Leveling Suspension	Output Tests	
Audi A8	2004-2006	4E	34 Self Leveling Suspension	Specia Functions	
Audi A8	2004-2006	4E	36 Side of Driver Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2004-2006	4E	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A8	2004-2006	4E	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A8	2004-2006	4E	36 Side of Driver Seat Adj.	Output Tests	
Audi A8	2004-2006	4E	36 Side of Driver Seat Adj.	Specia Functions	
Audi A8	2004-2006	4E	37 Navigation	Read Fault Codes	
Audi A8	2004-2006	4E	37 Navigation	Clear Fault Codes	
Audi A8	2004-2006	4E	37 Navigation	Measuring Blocks	
Audi A8	2004-2006	4E	37 Navigation	Output Tests	
Audi A8	2004-2006	4E	37 Navigation	Specia Functions	
Audi A8	2004-2006	4E	38 Roof Electronics	Read Fault Codes	
Audi A8	2004-2006	4E	38 Roof Electronics	Clear Fault Codes	
Audi A8	2004-2006	4E	38 Roof Electronics	Measuring Blocks	
Audi A8	2004-2006	4E	38 Roof Electronics	Output Tests	
Audi A8	2004-2006	4E	38 Roof Electronics	Specia Functions	
Audi A8	2004-2006	4E	3E Media Player Position 4	Read Fault Codes	
Audi A8	2004-2006	4E	3E Media Player Position 4	Clear Fault Codes	
Audi A8	2004-2006	4E	3E Media Player Position 4	Measuring Blocks	
Audi A8	2004-2006	4E	3E Media Player Position 4	Output Tests	
Audi A8	2004-2006	4E	3E Media Player Position 4	Specia Functions	
Audi A8	2004-2006	4E	42 Driver-Door Elect.	Read Fault Codes	
Audi A8	2004-2006	4E	42 Driver-Door Elect.	Clear Fault Codes	
Audi A8	2004-2006	4E	42 Driver-Door Elect.	Measuring Blocks	
Audi A8	2004-2006	4E	42 Driver-Door Elect.	Output Tests	
Audi A8	2004-2006	4E	42 Driver-Door Elect.	Specia Functions	
Audi A8	2004-2006	4E	46 Central Control Module	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2004-2006	4E	46 Central Control Module	Clear Fault Codes	
Audi A8	2004-2006	4E	46 Central Control Module	Measuring Blocks	
Audi A8	2004-2006	4E	46 Central Control Module	Output Tests	
Audi A8	2004-2006	4E	46 Central Control Module	Specia Functions	
Audi A8	2004-2006	4E	47 Soundsystem	Read Fault Codes	
Audi A8	2004-2006	4E	47 Soundsystem	Clear Fault Codes	
Audi A8	2004-2006	4E	47 Soundsystem	Measuring Blocks	
Audi A8	2004-2006	4E	47 Soundsystem	Output Tests	
Audi A8	2004-2006	4E	47 Soundsystem	Specia Functions	
Audi A8	2004-2006	4E	4E Control Head RR	Read Fault Codes	
Audi A8	2004-2006	4E	4E Control Head RR	Clear Fault Codes	
Audi A8	2004-2006	4E	4E Control Head RR	Measuring Blocks	
Audi A8	2004-2006	4E	4E Control Head RR	Output Tests	
Audi A8	2004-2006	4E	4E Control Head RR	Specia Functions	
Audi A8	2004-2006	4E	4F Electronic Central Electric II	Read Fault Codes	
Audi A8	2004-2006	4E	4F Electronic Central Electric II	Clear Fault Codes	
Audi A8	2004-2006	4E	4F Electronic Central Electric II	Measuring Blocks	
Audi A8	2004-2006	4E	4F Electronic Central Electric II	Output Tests	
Audi A8	2004-2006	4E	4F Electronic Central Electric II	Specia Functions	
Audi A8	2004-2006	4E	51 Electric Drive	Read Fault Codes	
Audi A8	2004-2006	4E	51 Electric Drive	Clear Fault Codes	
Audi A8	2004-2006	4E	51 Electric Drive	Measuring Blocks	
Audi A8	2004-2006	4E	51 Electric Drive	Output Tests	
Audi A8	2004-2006	4E	51 Electric Drive	Specia Functions	
Audi A8	2004-2006	4E	52 Passe.-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2004-2006	4E	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A8	2004-2006	4E	52 Passe.-Door Elect.	Measuring Blocks	
Audi A8	2004-2006	4E	52 Passe.-Door Elect.	Output Tests	
Audi A8	2004-2006	4E	52 Passe.-Door Elect.	Specia Functions	
Audi A8	2004-2006	4E	53 Parking Brake	Read Fault Codes	
Audi A8	2004-2006	4E	53 Parking Brake	Clear Fault Codes	
Audi A8	2004-2006	4E	53 Parking Brake	Measuring Blocks	
Audi A8	2004-2006	4E	53 Parking Brake	Output Tests	
Audi A8	2004-2006	4E	53 Parking Brake	Specia Functions	
Audi A8	2004-2006	4E	55 Headlight Range Control	Read Fault Codes	
Audi A8	2004-2006	4E	55 Headlight Range Control	Clear Fault Codes	
Audi A8	2004-2006	4E	55 Headlight Range Control	Measuring Blocks	
Audi A8	2004-2006	4E	55 Headlight Range Control	Output Tests	
Audi A8	2004-2006	4E	55 Headlight Range Control	Specia Functions	
Audi A8	2004-2006	4E	56 Radio	Read Fault Codes	
Audi A8	2004-2006	4E	56 Radio	Clear Fault Codes	
Audi A8	2004-2006	4E	56 Radio	Measuring Blocks	
Audi A8	2004-2006	4E	56 Radio	Output Tests	
Audi A8	2004-2006	4E	56 Radio	Specia Functions	
Audi A8	2004-2006	4E	57 TV-Tuner	Read Fault Codes	
Audi A8	2004-2006	4E	57 TV-Tuner	Clear Fault Codes	
Audi A8	2004-2006	4E	57 TV-Tuner	Measuring Blocks	
Audi A8	2004-2006	4E	57 TV-Tuner	Output Tests	
Audi A8	2004-2006	4E	57 TV-Tuner	Specia Functions	
Audi A8	2004-2006	4E	5E Control Head LR	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2004-2006	4E	5E Control Head LR	Clear Fault Codes	
Audi A8	2004-2006	4E	5E Control Head LR	Measuring Blocks	
Audi A8	2004-2006	4E	5E Control Head LR	Output Tests	
Audi A8	2004-2006	4E	5E Control Head LR	Specia Functions	
Audi A8	2004-2006	4E	61 Battery Control	Read Fault Codes	
Audi A8	2004-2006	4E	61 Battery Control	Clear Fault Codes	
Audi A8	2004-2006	4E	61 Battery Control	Measuring Blocks	
Audi A8	2004-2006	4E	61 Battery Control	Output Tests	
Audi A8	2004-2006	4E	61 Battery Control	Specia Functions	
Audi A8	2004-2006	4E	62 LR-Door Electroni.	Read Fault Codes	
Audi A8	2004-2006	4E	62 LR-Door Electroni.	Clear Fault Codes	
Audi A8	2004-2006	4E	62 LR-Door Electroni.	Measuring Blocks	
Audi A8	2004-2006	4E	62 LR-Door Electroni.	Output Tests	
Audi A8	2004-2006	4E	62 LR-Door Electroni.	Specia Functions	
Audi A8	2004-2006	4E	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8	2004-2006	4E	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8	2004-2006	4E	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8	2004-2006	4E	65 Tyre Pressure Monitoring	Output Tests	
Audi A8	2004-2006	4E	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8	2004-2006	4E	66 Seat-/Mirror Adjust.	Read Fault Codes	
Audi A8	2004-2006	4E	66 Seat-/Mirror Adjust.	Clear Fault Codes	
Audi A8	2004-2006	4E	66 Seat-/Mirror Adjust.	Measuring Blocks	
Audi A8	2004-2006	4E	66 Seat-/Mirror Adjust.	Output Tests	
Audi A8	2004-2006	4E	66 Seat-/Mirror Adjust.	Specia Functions	
Audi A8	2004-2006	4E	67 Voice Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2004-2006	4E	67 Voice Control	Clear Fault Codes	
Audi A8	2004-2006	4E	67 Voice Control	Measuring Blocks	
Audi A8	2004-2006	4E	67 Voice Control	Output Tests	
Audi A8	2004-2006	4E	67 Voice Control	Specia Functions	
Audi A8	2004-2006	4E	69 Trailer Function	Read Fault Codes	
Audi A8	2004-2006	4E	69 Trailer Function	Clear Fault Codes	
Audi A8	2004-2006	4E	69 Trailer Function	Measuring Blocks	
Audi A8	2004-2006	4E	69 Trailer Function	Output Tests	
Audi A8	2004-2006	4E	69 Trailer Function	Specia Functions	
Audi A8	2004-2006	4E	72 RR-Door Electroni.	Read Fault Codes	
Audi A8	2004-2006	4E	72 RR-Door Electroni.	Clear Fault Codes	
Audi A8	2004-2006	4E	72 RR-Door Electroni.	Measuring Blocks	
Audi A8	2004-2006	4E	72 RR-Door Electroni.	Output Tests	
Audi A8	2004-2006	4E	72 RR-Door Electroni.	Specia Functions	
Audi A8	2004-2006	4E	75 Emergency Call Module	Read Fault Codes	
Audi A8	2004-2006	4E	75 Emergency Call Module	Clear Fault Codes	
Audi A8	2004-2006	4E	75 Emergency Call Module	Measuring Blocks	
Audi A8	2004-2006	4E	75 Emergency Call Module	Output Tests	
Audi A8	2004-2006	4E	75 Emergency Call Module	Specia Functions	
Audi A8	2004-2006	4E	76 Parking Aid	Read Fault Codes	
Audi A8	2004-2006	4E	76 Parking Aid	Clear Fault Codes	
Audi A8	2004-2006	4E	76 Parking Aid	Measuring Blocks	
Audi A8	2004-2006	4E	76 Parking Aid	Output Tests	
Audi A8	2004-2006	4E	76 Parking Aid	Specia Functions	
Audi A8	2004-2006	4E	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2004-2006	4E	77 Telephone	Clear Fault Codes	
Audi A8	2004-2006	4E	77 Telephone	Measuring Blocks	
Audi A8	2004-2006	4E	77 Telephone	Output Tests	
Audi A8	2004-2006	4E	77 Telephone	Specia Functions	
Audi A8	2004-2006	4E	8C Hybrid Battery	Read Fault Codes	
Audi A8	2004-2006	4E	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2004-2006	4E	8C Hybrid Battery	Measuring Blocks	
Audi A8	2004-2006	4E	8C Hybrid Battery	Output Tests	
Audi A8	2004-2006	4E	8C Hybrid Battery	Specia Functions	
Audi A8	2007	4E	01 Engine Electronics	Read Fault Codes	
Audi A8	2007	4E	01 Engine Electronics	Clear Fault Codes	
Audi A8	2007	4E	01 Engine Electronics	Measuring Blocks	
Audi A8	2007	4E	01 Engine Electronics	Output Tests	
Audi A8	2007	4E	01 Engine Electronics	Specia Functions	
Audi A8	2007	4E	02 Transmission Electronics	Read Fault Codes	
Audi A8	2007	4E	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2007	4E	02 Transmission Electronics	Measuring Blocks	
Audi A8	2007	4E	02 Transmission Electronics	Output Tests	
Audi A8	2007	4E	02 Transmission Electronics	Specia Functions	
Audi A8	2007	4E	03 Brake Electronics	Read Fault Codes	
Audi A8	2007	4E	03 Brake Electronics	Clear Fault Codes	
Audi A8	2007	4E	03 Brake Electronics	Measuring Blocks	
Audi A8	2007	4E	03 Brake Electronics	Output Tests	
Audi A8	2007	4E	03 Brake Electronics	Specia Functions	
Audi A8	2007	4E	05 Access & Permissi.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2007	4E	05 Access & Permissi.	Clear Fault Codes	
Audi A8	2007	4E	05 Access & Permissi.	Measuring Blocks	
Audi A8	2007	4E	05 Access & Permissi.	Output Tests	
Audi A8	2007	4E	05 Access & Permissi.	Specia Functions	
Audi A8	2007	4E	06 Passene. Seat Adj.	Read Fault Codes	
Audi A8	2007	4E	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A8	2007	4E	06 Passene. Seat Adj.	Measuring Blocks	
Audi A8	2007	4E	06 Passene. Seat Adj.	Output Tests	
Audi A8	2007	4E	06 Passene. Seat Adj.	Specia Functions	
Audi A8	2007	4E	07 Display-/Cntl Unit	Read Fault Codes	
Audi A8	2007	4E	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A8	2007	4E	07 Display-/Cntl Unit	Measuring Blocks	
Audi A8	2007	4E	07 Display-/Cntl Unit	Output Tests	
Audi A8	2007	4E	07 Display-/Cntl Unit	Specia Functions	
Audi A8	2007	4E	08 AC/Heating Electronics	Read Fault Codes	
Audi A8	2007	4E	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	2007	4E	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	2007	4E	08 AC/Heating Electronics	Output Tests	
Audi A8	2007	4E	08 AC/Heating Electronics	Specia Functions	
Audi A8	2007	4E	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A8	2007	4E	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A8	2007	4E	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A8	2007	4E	09 Electronic Ctrl Electronics	Output Tests	
Audi A8	2007	4E	09 Electronic Ctrl Electronics	Specia Functions	
Audi A8	2007	4E	0E Media Player Position 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2007	4E	0E Media Player Position 1	Clear Fault Codes	
Audi A8	2007	4E	0E Media Player Position 1	Measuring Blocks	
Audi A8	2007	4E	0E Media Player Position 1	Output Tests	
Audi A8	2007	4E	0E Media Player Position 1	Specia Functions	
Audi A8	2007	4E	0F Radio Tuner-Digital	Read Fault Codes	
Audi A8	2007	4E	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A8	2007	4E	0F Radio Tuner-Digital	Measuring Blocks	
Audi A8	2007	4E	0F Radio Tuner-Digital	Output Tests	
Audi A8	2007	4E	0F Radio Tuner-Digital	Specia Functions	
Audi A8	2007	4E	11 Engine Electronics 2	Read Fault Codes	
Audi A8	2007	4E	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	2007	4E	11 Engine Electronics 2	Measuring Blocks	
Audi A8	2007	4E	11 Engine Electronics 2	Output Tests	
Audi A8	2007	4E	11 Engine Electronics 2	Specia Functions	
Audi A8	2007	4E	13 Distance Control	Read Fault Codes	
Audi A8	2007	4E	13 Distance Control	Clear Fault Codes	
Audi A8	2007	4E	13 Distance Control	Measuring Blocks	
Audi A8	2007	4E	13 Distance Control	Output Tests	
Audi A8	2007	4E	13 Distance Control	Specia Functions	
Audi A8	2007	4E	15 Airbags	Read Fault Codes	
Audi A8	2007	4E	15 Airbags	Clear Fault Codes	
Audi A8	2007	4E	15 Airbags	Measuring Blocks	
Audi A8	2007	4E	15 Airbags	Output Tests	
Audi A8	2007	4E	15 Airbags	Specia Functions	
Audi A8	2007	4E	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2007	4E	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2007	4E	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2007	4E	16 Steering Wheel Electronics	Output Tests	
Audi A8	2007	4E	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2007	4E	17 Instrument Cluster	Read Fault Codes	
Audi A8	2007	4E	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2007	4E	17 Instrument Cluster	Measuring Blocks	
Audi A8	2007	4E	17 Instrument Cluster	Output Tests	
Audi A8	2007	4E	17 Instrument Cluster	Specia Functions	
Audi A8	2007	4E	18 Aux Heating	Read Fault Codes	
Audi A8	2007	4E	18 Aux Heating	Clear Fault Codes	
Audi A8	2007	4E	18 Aux Heating	Measuring Blocks	
Audi A8	2007	4E	18 Aux Heating	Output Tests	
Audi A8	2007	4E	18 Aux Heating	Specia Functions	
Audi A8	2007	4E	19 Gateway Data Bus	Read Fault Codes	
Audi A8	2007	4E	19 Gateway Data Bus	Clear Fault Codes	
Audi A8	2007	4E	19 Gateway Data Bus	Measuring Blocks	
Audi A8	2007	4E	19 Gateway Data Bus	Output Tests	
Audi A8	2007	4E	19 Gateway Data Bus	Specia Functions	
Audi A8	2007	4E	1D Driver Identification	Read Fault Codes	
Audi A8	2007	4E	1D Driver Identification	Clear Fault Codes	
Audi A8	2007	4E	1D Driver Identification	Measuring Blocks	
Audi A8	2007	4E	1D Driver Identification	Output Tests	
Audi A8	2007	4E	1D Driver Identification	Specia Functions	
Audi A8	2007	4E	1E Media Player Position 2	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2007	4E	1E Media Player Position 2	Clear Fault Codes	
Audi A8	2007	4E	1E Media Player Position 2	Measuring Blocks	
Audi A8	2007	4E	1E Media Player Position 2	Output Tests	
Audi A8	2007	4E	1E Media Player Position 2	Specia Functions	
Audi A8	2007	4E	25 Immobilizer	Read Fault Codes	
Audi A8	2007	4E	25 Immobilizer	Clear Fault Codes	
Audi A8	2007	4E	25 Immobilizer	Measuring Blocks	
Audi A8	2007	4E	25 Immobilizer	Output Tests	
Audi A8	2007	4E	25 Immobilizer	Specia Functions	
Audi A8	2007	4E	28 Climate Control Unit Rear	Read Fault Codes	
Audi A8	2007	4E	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A8	2007	4E	28 Climate Control Unit Rear	Measuring Blocks	
Audi A8	2007	4E	28 Climate Control Unit Rear	Output Tests	
Audi A8	2007	4E	28 Climate Control Unit Rear	Specia Functions	
Audi A8	2007	4E	2E Media Player Position 3	Read Fault Codes	
Audi A8	2007	4E	2E Media Player Position 3	Clear Fault Codes	
Audi A8	2007	4E	2E Media Player Position 3	Measuring Blocks	
Audi A8	2007	4E	2E Media Player Position 3	Output Tests	
Audi A8	2007	4E	2E Media Player Position 3	Specia Functions	
Audi A8	2007	4E	34 Self Leveling Suspension	Read Fault Codes	
Audi A8	2007	4E	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8	2007	4E	34 Self Leveling Suspension	Measuring Blocks	
Audi A8	2007	4E	34 Self Leveling Suspension	Output Tests	
Audi A8	2007	4E	34 Self Leveling Suspension	Specia Functions	
Audi A8	2007	4E	36 Side of Driver Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2007	4E	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A8	2007	4E	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A8	2007	4E	36 Side of Driver Seat Adj.	Output Tests	
Audi A8	2007	4E	36 Side of Driver Seat Adj.	Specia Functions	
Audi A8	2007	4E	37 Navigation	Read Fault Codes	
Audi A8	2007	4E	37 Navigation	Clear Fault Codes	
Audi A8	2007	4E	37 Navigation	Measuring Blocks	
Audi A8	2007	4E	37 Navigation	Output Tests	
Audi A8	2007	4E	37 Navigation	Specia Functions	
Audi A8	2007	4E	38 Roof Electronics	Read Fault Codes	
Audi A8	2007	4E	38 Roof Electronics	Clear Fault Codes	
Audi A8	2007	4E	38 Roof Electronics	Measuring Blocks	
Audi A8	2007	4E	38 Roof Electronics	Output Tests	
Audi A8	2007	4E	38 Roof Electronics	Specia Functions	
Audi A8	2007	4E	3C Lane Departure Assistance System	Read Fault Codes	
Audi A8	2007	4E	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A8	2007	4E	3C Lane Departure Assistance System	Measuring Blocks	
Audi A8	2007	4E	3C Lane Departure Assistance System	Output Tests	
Audi A8	2007	4E	3C Lane Departure Assistance System	Specia Functions	
Audi A8	2007	4E	3E Media Player Position 4	Read Fault Codes	
Audi A8	2007	4E	3E Media Player Position 4	Clear Fault Codes	
Audi A8	2007	4E	3E Media Player Position 4	Measuring Blocks	
Audi A8	2007	4E	3E Media Player Position 4	Output Tests	
Audi A8	2007	4E	3E Media Player Position 4	Specia Functions	
Audi A8	2007	4E	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2007	4E	42 Driver-Door Elect.	Clear Fault Codes	
Audi A8	2007	4E	42 Driver-Door Elect.	Measuring Blocks	
Audi A8	2007	4E	42 Driver-Door Elect.	Output Tests	
Audi A8	2007	4E	42 Driver-Door Elect.	Specia Functions	
Audi A8	2007	4E	46 Central Control Module	Read Fault Codes	
Audi A8	2007	4E	46 Central Control Module	Clear Fault Codes	
Audi A8	2007	4E	46 Central Control Module	Measuring Blocks	
Audi A8	2007	4E	46 Central Control Module	Output Tests	
Audi A8	2007	4E	46 Central Control Module	Specia Functions	
Audi A8	2007	4E	47 Soundsystem	Read Fault Codes	
Audi A8	2007	4E	47 Soundsystem	Clear Fault Codes	
Audi A8	2007	4E	47 Soundsystem	Measuring Blocks	
Audi A8	2007	4E	47 Soundsystem	Output Tests	
Audi A8	2007	4E	47 Soundsystem	Specia Functions	
Audi A8	2007	4E	4E Control Head RR	Read Fault Codes	
Audi A8	2007	4E	4E Control Head RR	Clear Fault Codes	
Audi A8	2007	4E	4E Control Head RR	Measuring Blocks	
Audi A8	2007	4E	4E Control Head RR	Output Tests	
Audi A8	2007	4E	4E Control Head RR	Specia Functions	
Audi A8	2007	4E	4F Electronic Central Electric II	Read Fault Codes	
Audi A8	2007	4E	4F Electronic Central Electric II	Clear Fault Codes	
Audi A8	2007	4E	4F Electronic Central Electric II	Measuring Blocks	
Audi A8	2007	4E	4F Electronic Central Electric II	Output Tests	
Audi A8	2007	4E	4F Electronic Central Electric II	Specia Functions	
Audi A8	2007	4E	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2007	4E	51 Electric Drive	Clear Fault Codes	
Audi A8	2007	4E	51 Electric Drive	Measuring Blocks	
Audi A8	2007	4E	51 Electric Drive	Output Tests	
Audi A8	2007	4E	51 Electric Drive	Specia Functions	
Audi A8	2007	4E	52 Passe.-Door Elect.	Read Fault Codes	
Audi A8	2007	4E	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A8	2007	4E	52 Passe.-Door Elect.	Measuring Blocks	
Audi A8	2007	4E	52 Passe.-Door Elect.	Output Tests	
Audi A8	2007	4E	52 Passe.-Door Elect.	Specia Functions	
Audi A8	2007	4E	53 Parking Brake	Read Fault Codes	
Audi A8	2007	4E	53 Parking Brake	Clear Fault Codes	
Audi A8	2007	4E	53 Parking Brake	Measuring Blocks	
Audi A8	2007	4E	53 Parking Brake	Output Tests	
Audi A8	2007	4E	53 Parking Brake	Specia Functions	
Audi A8	2007	4E	55 Headlight Range Control	Read Fault Codes	
Audi A8	2007	4E	55 Headlight Range Control	Clear Fault Codes	
Audi A8	2007	4E	55 Headlight Range Control	Measuring Blocks	
Audi A8	2007	4E	55 Headlight Range Control	Output Tests	
Audi A8	2007	4E	55 Headlight Range Control	Specia Functions	
Audi A8	2007	4E	56 Radio	Read Fault Codes	
Audi A8	2007	4E	56 Radio	Clear Fault Codes	
Audi A8	2007	4E	56 Radio	Measuring Blocks	
Audi A8	2007	4E	56 Radio	Output Tests	
Audi A8	2007	4E	56 Radio	Specia Functions	
Audi A8	2007	4E	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2007	4E	57 TV-Tuner	Clear Fault Codes	
Audi A8	2007	4E	57 TV-Tuner	Measuring Blocks	
Audi A8	2007	4E	57 TV-Tuner	Output Tests	
Audi A8	2007	4E	57 TV-Tuner	Specia Functions	
Audi A8	2007	4E	5E Control Head LR	Read Fault Codes	
Audi A8	2007	4E	5E Control Head LR	Clear Fault Codes	
Audi A8	2007	4E	5E Control Head LR	Measuring Blocks	
Audi A8	2007	4E	5E Control Head LR	Output Tests	
Audi A8	2007	4E	5E Control Head LR	Specia Functions	
Audi A8	2007	4E	61 Battery Control	Read Fault Codes	
Audi A8	2007	4E	61 Battery Control	Clear Fault Codes	
Audi A8	2007	4E	61 Battery Control	Measuring Blocks	
Audi A8	2007	4E	61 Battery Control	Output Tests	
Audi A8	2007	4E	61 Battery Control	Specia Functions	
Audi A8	2007	4E	62 LR-Door Electroni.	Read Fault Codes	
Audi A8	2007	4E	62 LR-Door Electroni.	Clear Fault Codes	
Audi A8	2007	4E	62 LR-Door Electroni.	Measuring Blocks	
Audi A8	2007	4E	62 LR-Door Electroni.	Output Tests	
Audi A8	2007	4E	62 LR-Door Electroni.	Specia Functions	
Audi A8	2007	4E	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8	2007	4E	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8	2007	4E	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8	2007	4E	65 Tyre Pressure Monitoring	Output Tests	
Audi A8	2007	4E	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8	2007	4E	66 Seat-/Mirror Adjust.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2007	4E	66 Seat-/Mirror Adjust.	Clear Fault Codes	
Audi A8	2007	4E	66 Seat-/Mirror Adjust.	Measuring Blocks	
Audi A8	2007	4E	66 Seat-/Mirror Adjust.	Output Tests	
Audi A8	2007	4E	66 Seat-/Mirror Adjust.	Specia Functions	
Audi A8	2007	4E	67 Voice Control	Read Fault Codes	
Audi A8	2007	4E	67 Voice Control	Clear Fault Codes	
Audi A8	2007	4E	67 Voice Control	Measuring Blocks	
Audi A8	2007	4E	67 Voice Control	Output Tests	
Audi A8	2007	4E	67 Voice Control	Specia Functions	
Audi A8	2007	4E	69 Trailer Function	Read Fault Codes	
Audi A8	2007	4E	69 Trailer Function	Clear Fault Codes	
Audi A8	2007	4E	69 Trailer Function	Measuring Blocks	
Audi A8	2007	4E	69 Trailer Function	Output Tests	
Audi A8	2007	4E	69 Trailer Function	Specia Functions	
Audi A8	2007	4E	6C Rear Camera	Read Fault Codes	
Audi A8	2007	4E	6C Rear Camera	Clear Fault Codes	
Audi A8	2007	4E	6C Rear Camera	Measuring Blocks	
Audi A8	2007	4E	6C Rear Camera	Output Tests	
Audi A8	2007	4E	6C Rear Camera	Specia Functions	
Audi A8	2007	4E	72 RR-Door Electroni.	Read Fault Codes	
Audi A8	2007	4E	72 RR-Door Electroni.	Clear Fault Codes	
Audi A8	2007	4E	72 RR-Door Electroni.	Measuring Blocks	
Audi A8	2007	4E	72 RR-Door Electroni.	Output Tests	
Audi A8	2007	4E	72 RR-Door Electroni.	Specia Functions	
Audi A8	2007	4E	75 Emergency Call Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2007	4E	75 Emergency Call Module	Clear Fault Codes	
Audi A8	2007	4E	75 Emergency Call Module	Measuring Blocks	
Audi A8	2007	4E	75 Emergency Call Module	Output Tests	
Audi A8	2007	4E	75 Emergency Call Module	Specia Functions	
Audi A8	2007	4E	76 Parking Aid	Read Fault Codes	
Audi A8	2007	4E	76 Parking Aid	Clear Fault Codes	
Audi A8	2007	4E	76 Parking Aid	Measuring Blocks	
Audi A8	2007	4E	76 Parking Aid	Output Tests	
Audi A8	2007	4E	76 Parking Aid	Specia Functions	
Audi A8	2007	4E	77 Telephone	Read Fault Codes	
Audi A8	2007	4E	77 Telephone	Clear Fault Codes	
Audi A8	2007	4E	77 Telephone	Measuring Blocks	
Audi A8	2007	4E	77 Telephone	Output Tests	
Audi A8	2007	4E	77 Telephone	Specia Functions	
Audi A8	2007	4E	8C Hybrid Battery	Read Fault Codes	
Audi A8	2007	4E	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2007	4E	8C Hybrid Battery	Measuring Blocks	
Audi A8	2007	4E	8C Hybrid Battery	Output Tests	
Audi A8	2007	4E	8C Hybrid Battery	Specia Functions	
Audi A8	2008	4E	01 Engine Electronics	Read Fault Codes	
Audi A8	2008	4E	01 Engine Electronics	Clear Fault Codes	
Audi A8	2008	4E	01 Engine Electronics	Measuring Blocks	
Audi A8	2008	4E	01 Engine Electronics	Output Tests	
Audi A8	2008	4E	01 Engine Electronics	Specia Functions	
Audi A8	2008	4E	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2008	4E	02 Transmission Electronics	Measuring Blocks	
Audi A8	2008	4E	02 Transmission Electronics	Output Tests	
Audi A8	2008	4E	02 Transmission Electronics	Specia Functions	
Audi A8	2008	4E	03 Brake Electronics	Read Fault Codes	
Audi A8	2008	4E	03 Brake Electronics	Clear Fault Codes	
Audi A8	2008	4E	03 Brake Electronics	Measuring Blocks	
Audi A8	2008	4E	03 Brake Electronics	Output Tests	
Audi A8	2008	4E	03 Brake Electronics	Specia Functions	
Audi A8	2008	4E	05 Access & Permissi.	Read Fault Codes	
Audi A8	2008	4E	05 Access & Permissi.	Clear Fault Codes	
Audi A8	2008	4E	05 Access & Permissi.	Measuring Blocks	
Audi A8	2008	4E	05 Access & Permissi.	Output Tests	
Audi A8	2008	4E	05 Access & Permissi.	Specia Functions	
Audi A8	2008	4E	06 Passene. Seat Adj.	Read Fault Codes	
Audi A8	2008	4E	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A8	2008	4E	06 Passene. Seat Adj.	Measuring Blocks	
Audi A8	2008	4E	06 Passene. Seat Adj.	Output Tests	
Audi A8	2008	4E	06 Passene. Seat Adj.	Specia Functions	
Audi A8	2008	4E	07 Display-/Cntl Unit	Read Fault Codes	
Audi A8	2008	4E	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A8	2008	4E	07 Display-/Cntl Unit	Measuring Blocks	
Audi A8	2008	4E	07 Display-/Cntl Unit	Output Tests	
Audi A8	2008	4E	07 Display-/Cntl Unit	Specia Functions	
Audi A8	2008	4E	08 AC/Heating Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	2008	4E	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	2008	4E	08 AC/Heating Electronics	Output Tests	
Audi A8	2008	4E	08 AC/Heating Electronics	Specia Functions	
Audi A8	2008	4E	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A8	2008	4E	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A8	2008	4E	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A8	2008	4E	09 Electronic Ctrl Electronics	Output Tests	
Audi A8	2008	4E	09 Electronic Ctrl Electronics	Specia Functions	
Audi A8	2008	4E	0E Media Player Position 1	Read Fault Codes	
Audi A8	2008	4E	0E Media Player Position 1	Clear Fault Codes	
Audi A8	2008	4E	0E Media Player Position 1	Measuring Blocks	
Audi A8	2008	4E	0E Media Player Position 1	Output Tests	
Audi A8	2008	4E	0E Media Player Position 1	Specia Functions	
Audi A8	2008	4E	0F Radio Tuner-Digital	Read Fault Codes	
Audi A8	2008	4E	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A8	2008	4E	0F Radio Tuner-Digital	Measuring Blocks	
Audi A8	2008	4E	0F Radio Tuner-Digital	Output Tests	
Audi A8	2008	4E	0F Radio Tuner-Digital	Specia Functions	
Audi A8	2008	4E	11 Engine Electronics 2	Read Fault Codes	
Audi A8	2008	4E	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	2008	4E	11 Engine Electronics 2	Measuring Blocks	
Audi A8	2008	4E	11 Engine Electronics 2	Output Tests	
Audi A8	2008	4E	11 Engine Electronics 2	Specia Functions	
Audi A8	2008	4E	13 Distance Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	13 Distance Control	Clear Fault Codes	
Audi A8	2008	4E	13 Distance Control	Measuring Blocks	
Audi A8	2008	4E	13 Distance Control	Output Tests	
Audi A8	2008	4E	13 Distance Control	Specia Functions	
Audi A8	2008	4E	15 Airbags	Read Fault Codes	
Audi A8	2008	4E	15 Airbags	Clear Fault Codes	
Audi A8	2008	4E	15 Airbags	Measuring Blocks	
Audi A8	2008	4E	15 Airbags	Output Tests	
Audi A8	2008	4E	15 Airbags	Specia Functions	
Audi A8	2008	4E	16 Steering Wheel Electronics	Read Fault Codes	
Audi A8	2008	4E	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2008	4E	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2008	4E	16 Steering Wheel Electronics	Output Tests	
Audi A8	2008	4E	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2008	4E	17 Instrument Cluster	Read Fault Codes	
Audi A8	2008	4E	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2008	4E	17 Instrument Cluster	Measuring Blocks	
Audi A8	2008	4E	17 Instrument Cluster	Output Tests	
Audi A8	2008	4E	17 Instrument Cluster	Specia Functions	
Audi A8	2008	4E	18 Aux Heating	Read Fault Codes	
Audi A8	2008	4E	18 Aux Heating	Clear Fault Codes	
Audi A8	2008	4E	18 Aux Heating	Measuring Blocks	
Audi A8	2008	4E	18 Aux Heating	Output Tests	
Audi A8	2008	4E	18 Aux Heating	Specia Functions	
Audi A8	2008	4E	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	19 Gateway Data Bus	Clear Fault Codes	
Audi A8	2008	4E	19 Gateway Data Bus	Measuring Blocks	
Audi A8	2008	4E	19 Gateway Data Bus	Output Tests	
Audi A8	2008	4E	19 Gateway Data Bus	Specia Functions	
Audi A8	2008	4E	1D Driver Identification	Read Fault Codes	
Audi A8	2008	4E	1D Driver Identification	Clear Fault Codes	
Audi A8	2008	4E	1D Driver Identification	Measuring Blocks	
Audi A8	2008	4E	1D Driver Identification	Output Tests	
Audi A8	2008	4E	1D Driver Identification	Specia Functions	
Audi A8	2008	4E	1E Media Player Position 2	Read Fault Codes	
Audi A8	2008	4E	1E Media Player Position 2	Clear Fault Codes	
Audi A8	2008	4E	1E Media Player Position 2	Measuring Blocks	
Audi A8	2008	4E	1E Media Player Position 2	Output Tests	
Audi A8	2008	4E	1E Media Player Position 2	Specia Functions	
Audi A8	2008	4E	25 Immobilizer	Read Fault Codes	
Audi A8	2008	4E	25 Immobilizer	Clear Fault Codes	
Audi A8	2008	4E	25 Immobilizer	Measuring Blocks	
Audi A8	2008	4E	25 Immobilizer	Output Tests	
Audi A8	2008	4E	25 Immobilizer	Specia Functions	
Audi A8	2008	4E	28 Climate Control Unit Rear	Read Fault Codes	
Audi A8	2008	4E	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A8	2008	4E	28 Climate Control Unit Rear	Measuring Blocks	
Audi A8	2008	4E	28 Climate Control Unit Rear	Output Tests	
Audi A8	2008	4E	28 Climate Control Unit Rear	Specia Functions	
Audi A8	2008	4E	2E Media Player Position 3	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	2E Media Player Position 3	Clear Fault Codes	
Audi A8	2008	4E	2E Media Player Position 3	Measuring Blocks	
Audi A8	2008	4E	2E Media Player Position 3	Output Tests	
Audi A8	2008	4E	2E Media Player Position 3	Specia Functions	
Audi A8	2008	4E	34 Self Leveling Suspension	Read Fault Codes	
Audi A8	2008	4E	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8	2008	4E	34 Self Leveling Suspension	Measuring Blocks	
Audi A8	2008	4E	34 Self Leveling Suspension	Output Tests	
Audi A8	2008	4E	34 Self Leveling Suspension	Specia Functions	
Audi A8	2008	4E	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A8	2008	4E	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A8	2008	4E	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A8	2008	4E	36 Side of Driver Seat Adj.	Output Tests	
Audi A8	2008	4E	36 Side of Driver Seat Adj.	Specia Functions	
Audi A8	2008	4E	37 Navigation	Read Fault Codes	
Audi A8	2008	4E	37 Navigation	Clear Fault Codes	
Audi A8	2008	4E	37 Navigation	Measuring Blocks	
Audi A8	2008	4E	37 Navigation	Output Tests	
Audi A8	2008	4E	37 Navigation	Specia Functions	
Audi A8	2008	4E	38 Roof Electronics	Read Fault Codes	
Audi A8	2008	4E	38 Roof Electronics	Clear Fault Codes	
Audi A8	2008	4E	38 Roof Electronics	Measuring Blocks	
Audi A8	2008	4E	38 Roof Electronics	Output Tests	
Audi A8	2008	4E	38 Roof Electronics	Specia Functions	
Audi A8	2008	4E	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A8	2008	4E	3C Lane Departure Assistance System	Measuring Blocks	
Audi A8	2008	4E	3C Lane Departure Assistance System	Output Tests	
Audi A8	2008	4E	3C Lane Departure Assistance System	Specia Functions	
Audi A8	2008	4E	3E Media Player Position 4	Read Fault Codes	
Audi A8	2008	4E	3E Media Player Position 4	Clear Fault Codes	
Audi A8	2008	4E	3E Media Player Position 4	Measuring Blocks	
Audi A8	2008	4E	3E Media Player Position 4	Output Tests	
Audi A8	2008	4E	3E Media Player Position 4	Specia Functions	
Audi A8	2008	4E	42 Driver-Door Elect.	Read Fault Codes	
Audi A8	2008	4E	42 Driver-Door Elect.	Clear Fault Codes	
Audi A8	2008	4E	42 Driver-Door Elect.	Measuring Blocks	
Audi A8	2008	4E	42 Driver-Door Elect.	Output Tests	
Audi A8	2008	4E	42 Driver-Door Elect.	Specia Functions	
Audi A8	2008	4E	46 Central Control Module	Read Fault Codes	
Audi A8	2008	4E	46 Central Control Module	Clear Fault Codes	
Audi A8	2008	4E	46 Central Control Module	Measuring Blocks	
Audi A8	2008	4E	46 Central Control Module	Output Tests	
Audi A8	2008	4E	46 Central Control Module	Specia Functions	
Audi A8	2008	4E	47 Soundsystem	Read Fault Codes	
Audi A8	2008	4E	47 Soundsystem	Clear Fault Codes	
Audi A8	2008	4E	47 Soundsystem	Measuring Blocks	
Audi A8	2008	4E	47 Soundsystem	Output Tests	
Audi A8	2008	4E	47 Soundsystem	Specia Functions	
Audi A8	2008	4E	4E Control Head RR	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	4E Control Head RR	Clear Fault Codes	
Audi A8	2008	4E	4E Control Head RR	Measuring Blocks	
Audi A8	2008	4E	4E Control Head RR	Output Tests	
Audi A8	2008	4E	4E Control Head RR	Specia Functions	
Audi A8	2008	4E	4F Electronic Central Electric II	Read Fault Codes	
Audi A8	2008	4E	4F Electronic Central Electric II	Clear Fault Codes	
Audi A8	2008	4E	4F Electronic Central Electric II	Measuring Blocks	
Audi A8	2008	4E	4F Electronic Central Electric II	Output Tests	
Audi A8	2008	4E	4F Electronic Central Electric II	Specia Functions	
Audi A8	2008	4E	51 Electric Drive	Read Fault Codes	
Audi A8	2008	4E	51 Electric Drive	Clear Fault Codes	
Audi A8	2008	4E	51 Electric Drive	Measuring Blocks	
Audi A8	2008	4E	51 Electric Drive	Output Tests	
Audi A8	2008	4E	51 Electric Drive	Specia Functions	
Audi A8	2008	4E	52 Passe.-Door Elect.	Read Fault Codes	
Audi A8	2008	4E	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A8	2008	4E	52 Passe.-Door Elect.	Measuring Blocks	
Audi A8	2008	4E	52 Passe.-Door Elect.	Output Tests	
Audi A8	2008	4E	52 Passe.-Door Elect.	Specia Functions	
Audi A8	2008	4E	53 Parking Brake	Read Fault Codes	
Audi A8	2008	4E	53 Parking Brake	Clear Fault Codes	
Audi A8	2008	4E	53 Parking Brake	Measuring Blocks	
Audi A8	2008	4E	53 Parking Brake	Output Tests	
Audi A8	2008	4E	53 Parking Brake	Specia Functions	
Audi A8	2008	4E	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	55 Headlight Range Control	Clear Fault Codes	
Audi A8	2008	4E	55 Headlight Range Control	Measuring Blocks	
Audi A8	2008	4E	55 Headlight Range Control	Output Tests	
Audi A8	2008	4E	55 Headlight Range Control	Specia Functions	
Audi A8	2008	4E	56 Radio	Read Fault Codes	
Audi A8	2008	4E	56 Radio	Clear Fault Codes	
Audi A8	2008	4E	56 Radio	Measuring Blocks	
Audi A8	2008	4E	56 Radio	Output Tests	
Audi A8	2008	4E	56 Radio	Specia Functions	
Audi A8	2008	4E	57 TV-Tuner	Read Fault Codes	
Audi A8	2008	4E	57 TV-Tuner	Clear Fault Codes	
Audi A8	2008	4E	57 TV-Tuner	Measuring Blocks	
Audi A8	2008	4E	57 TV-Tuner	Output Tests	
Audi A8	2008	4E	57 TV-Tuner	Specia Functions	
Audi A8	2008	4E	5C Lane Keeping Assistance System	Read Fault Codes	
Audi A8	2008	4E	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi A8	2008	4E	5C Lane Keeping Assistance System	Measuring Blocks	
Audi A8	2008	4E	5C Lane Keeping Assistance System	Output Tests	
Audi A8	2008	4E	5C Lane Keeping Assistance System	Specia Functions	
Audi A8	2008	4E	5E Control Head LR	Read Fault Codes	
Audi A8	2008	4E	5E Control Head LR	Clear Fault Codes	
Audi A8	2008	4E	5E Control Head LR	Measuring Blocks	
Audi A8	2008	4E	5E Control Head LR	Output Tests	
Audi A8	2008	4E	5E Control Head LR	Specia Functions	
Audi A8	2008	4E	61 Battery Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	61 Battery Control	Clear Fault Codes	
Audi A8	2008	4E	61 Battery Control	Measuring Blocks	
Audi A8	2008	4E	61 Battery Control	Output Tests	
Audi A8	2008	4E	61 Battery Control	Specia Functions	
Audi A8	2008	4E	62 LR-Door Electroni.	Read Fault Codes	
Audi A8	2008	4E	62 LR-Door Electroni.	Clear Fault Codes	
Audi A8	2008	4E	62 LR-Door Electroni.	Measuring Blocks	
Audi A8	2008	4E	62 LR-Door Electroni.	Output Tests	
Audi A8	2008	4E	62 LR-Door Electroni.	Specia Functions	
Audi A8	2008	4E	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8	2008	4E	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8	2008	4E	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8	2008	4E	65 Tyre Pressure Monitoring	Output Tests	
Audi A8	2008	4E	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8	2008	4E	66 Seat-/Mirror Adjust.	Read Fault Codes	
Audi A8	2008	4E	66 Seat-/Mirror Adjust.	Clear Fault Codes	
Audi A8	2008	4E	66 Seat-/Mirror Adjust.	Measuring Blocks	
Audi A8	2008	4E	66 Seat-/Mirror Adjust.	Output Tests	
Audi A8	2008	4E	66 Seat-/Mirror Adjust.	Specia Functions	
Audi A8	2008	4E	67 Voice Control	Read Fault Codes	
Audi A8	2008	4E	67 Voice Control	Clear Fault Codes	
Audi A8	2008	4E	67 Voice Control	Measuring Blocks	
Audi A8	2008	4E	67 Voice Control	Output Tests	
Audi A8	2008	4E	67 Voice Control	Specia Functions	
Audi A8	2008	4E	69 Trailer Function	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	69 Trailer Function	Clear Fault Codes	
Audi A8	2008	4E	69 Trailer Function	Measuring Blocks	
Audi A8	2008	4E	69 Trailer Function	Output Tests	
Audi A8	2008	4E	69 Trailer Function	Specia Functions	
Audi A8	2008	4E	6C Rear Camera	Read Fault Codes	
Audi A8	2008	4E	6C Rear Camera	Clear Fault Codes	
Audi A8	2008	4E	6C Rear Camera	Measuring Blocks	
Audi A8	2008	4E	6C Rear Camera	Output Tests	
Audi A8	2008	4E	6C Rear Camera	Specia Functions	
Audi A8	2008	4E	72 RR-Door Electroni.	Read Fault Codes	
Audi A8	2008	4E	72 RR-Door Electroni.	Clear Fault Codes	
Audi A8	2008	4E	72 RR-Door Electroni.	Measuring Blocks	
Audi A8	2008	4E	72 RR-Door Electroni.	Output Tests	
Audi A8	2008	4E	72 RR-Door Electroni.	Specia Functions	
Audi A8	2008	4E	75 Emergency Call Module	Read Fault Codes	
Audi A8	2008	4E	75 Emergency Call Module	Clear Fault Codes	
Audi A8	2008	4E	75 Emergency Call Module	Measuring Blocks	
Audi A8	2008	4E	75 Emergency Call Module	Output Tests	
Audi A8	2008	4E	75 Emergency Call Module	Specia Functions	
Audi A8	2008	4E	76 Parking Aid	Read Fault Codes	
Audi A8	2008	4E	76 Parking Aid	Clear Fault Codes	
Audi A8	2008	4E	76 Parking Aid	Measuring Blocks	
Audi A8	2008	4E	76 Parking Aid	Output Tests	
Audi A8	2008	4E	76 Parking Aid	Specia Functions	
Audi A8	2008	4E	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2008	4E	77 Telephone	Clear Fault Codes	
Audi A8	2008	4E	77 Telephone	Measuring Blocks	
Audi A8	2008	4E	77 Telephone	Output Tests	
Audi A8	2008	4E	77 Telephone	Specia Functions	
Audi A8	2008	4E	8C Hybrid Battery	Read Fault Codes	
Audi A8	2008	4E	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2008	4E	8C Hybrid Battery	Measuring Blocks	
Audi A8	2008	4E	8C Hybrid Battery	Output Tests	
Audi A8	2008	4E	8C Hybrid Battery	Specia Functions	
Audi A8	2009-2010	4E	01 Engine Electronics	Read Fault Codes	
Audi A8	2009-2010	4E	01 Engine Electronics	Clear Fault Codes	
Audi A8	2009-2010	4E	01 Engine Electronics	Measuring Blocks	
Audi A8	2009-2010	4E	01 Engine Electronics	Output Tests	
Audi A8	2009-2010	4E	01 Engine Electronics	Specia Functions	
Audi A8	2009-2010	4E	02 Transmission Electronics	Read Fault Codes	
Audi A8	2009-2010	4E	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2009-2010	4E	02 Transmission Electronics	Measuring Blocks	
Audi A8	2009-2010	4E	02 Transmission Electronics	Output Tests	
Audi A8	2009-2010	4E	02 Transmission Electronics	Specia Functions	
Audi A8	2009-2010	4E	03 Brake Electronics	Read Fault Codes	
Audi A8	2009-2010	4E	03 Brake Electronics	Clear Fault Codes	
Audi A8	2009-2010	4E	03 Brake Electronics	Measuring Blocks	
Audi A8	2009-2010	4E	03 Brake Electronics	Output Tests	
Audi A8	2009-2010	4E	03 Brake Electronics	Specia Functions	
Audi A8	2009-2010	4E	05 Access & Permissi.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2009-2010	4E	05 Access & Permissi.	Clear Fault Codes	
Audi A8	2009-2010	4E	05 Access & Permissi.	Measuring Blocks	
Audi A8	2009-2010	4E	05 Access & Permissi.	Output Tests	
Audi A8	2009-2010	4E	05 Access & Permissi.	Specia Functions	
Audi A8	2009-2010	4E	06 Passene. Seat Adj.	Read Fault Codes	
Audi A8	2009-2010	4E	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A8	2009-2010	4E	06 Passene. Seat Adj.	Measuring Blocks	
Audi A8	2009-2010	4E	06 Passene. Seat Adj.	Output Tests	
Audi A8	2009-2010	4E	06 Passene. Seat Adj.	Specia Functions	
Audi A8	2009-2010	4E	07 Display-/Cntl Unit	Read Fault Codes	
Audi A8	2009-2010	4E	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A8	2009-2010	4E	07 Display-/Cntl Unit	Measuring Blocks	
Audi A8	2009-2010	4E	07 Display-/Cntl Unit	Output Tests	
Audi A8	2009-2010	4E	07 Display-/Cntl Unit	Specia Functions	
Audi A8	2009-2010	4E	08 AC/Heating Electronics	Read Fault Codes	
Audi A8	2009-2010	4E	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	2009-2010	4E	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	2009-2010	4E	08 AC/Heating Electronics	Output Tests	
Audi A8	2009-2010	4E	08 AC/Heating Electronics	Specia Functions	
Audi A8	2009-2010	4E	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A8	2009-2010	4E	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A8	2009-2010	4E	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A8	2009-2010	4E	09 Electronic Ctrl Electronics	Output Tests	
Audi A8	2009-2010	4E	09 Electronic Ctrl Electronics	Specia Functions	
Audi A8	2009-2010	4E	0E Media Player Position 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2009-2010	4E	0E Media Player Position 1	Clear Fault Codes	
Audi A8	2009-2010	4E	0E Media Player Position 1	Measuring Blocks	
Audi A8	2009-2010	4E	0E Media Player Position 1	Output Tests	
Audi A8	2009-2010	4E	0E Media Player Position 1	Specia Functions	
Audi A8	2009-2010	4E	0F Radio Tuner-Digital	Read Fault Codes	
Audi A8	2009-2010	4E	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A8	2009-2010	4E	0F Radio Tuner-Digital	Measuring Blocks	
Audi A8	2009-2010	4E	0F Radio Tuner-Digital	Output Tests	
Audi A8	2009-2010	4E	0F Radio Tuner-Digital	Specia Functions	
Audi A8	2009-2010	4E	11 Engine Electronics 2	Read Fault Codes	
Audi A8	2009-2010	4E	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	2009-2010	4E	11 Engine Electronics 2	Measuring Blocks	
Audi A8	2009-2010	4E	11 Engine Electronics 2	Output Tests	
Audi A8	2009-2010	4E	11 Engine Electronics 2	Specia Functions	
Audi A8	2009-2010	4E	13 Distance Control	Read Fault Codes	
Audi A8	2009-2010	4E	13 Distance Control	Clear Fault Codes	
Audi A8	2009-2010	4E	13 Distance Control	Measuring Blocks	
Audi A8	2009-2010	4E	13 Distance Control	Output Tests	
Audi A8	2009-2010	4E	13 Distance Control	Specia Functions	
Audi A8	2009-2010	4E	15 Airbags	Read Fault Codes	
Audi A8	2009-2010	4E	15 Airbags	Clear Fault Codes	
Audi A8	2009-2010	4E	15 Airbags	Measuring Blocks	
Audi A8	2009-2010	4E	15 Airbags	Output Tests	
Audi A8	2009-2010	4E	15 Airbags	Specia Functions	
Audi A8	2009-2010	4E	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2009-2010	4E	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2009-2010	4E	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2009-2010	4E	16 Steering Wheel Electronics	Output Tests	
Audi A8	2009-2010	4E	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2009-2010	4E	17 Instrument Cluster	Read Fault Codes	
Audi A8	2009-2010	4E	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2009-2010	4E	17 Instrument Cluster	Measuring Blocks	
Audi A8	2009-2010	4E	17 Instrument Cluster	Output Tests	
Audi A8	2009-2010	4E	17 Instrument Cluster	Specia Functions	
Audi A8	2009-2010	4E	18 Aux Heating	Read Fault Codes	
Audi A8	2009-2010	4E	18 Aux Heating	Clear Fault Codes	
Audi A8	2009-2010	4E	18 Aux Heating	Measuring Blocks	
Audi A8	2009-2010	4E	18 Aux Heating	Output Tests	
Audi A8	2009-2010	4E	18 Aux Heating	Specia Functions	
Audi A8	2009-2010	4E	19 Gateway Data Bus	Read Fault Codes	
Audi A8	2009-2010	4E	19 Gateway Data Bus	Clear Fault Codes	
Audi A8	2009-2010	4E	19 Gateway Data Bus	Measuring Blocks	
Audi A8	2009-2010	4E	19 Gateway Data Bus	Output Tests	
Audi A8	2009-2010	4E	19 Gateway Data Bus	Specia Functions	
Audi A8	2009-2010	4E	1D Driver Identification	Read Fault Codes	
Audi A8	2009-2010	4E	1D Driver Identification	Clear Fault Codes	
Audi A8	2009-2010	4E	1D Driver Identification	Measuring Blocks	
Audi A8	2009-2010	4E	1D Driver Identification	Output Tests	
Audi A8	2009-2010	4E	1D Driver Identification	Specia Functions	
Audi A8	2009-2010	4E	1E Media Player Position 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2009-2010	4E	1E Media Player Position 2	Clear Fault Codes	
Audi A8	2009-2010	4E	1E Media Player Position 2	Measuring Blocks	
Audi A8	2009-2010	4E	1E Media Player Position 2	Output Tests	
Audi A8	2009-2010	4E	1E Media Player Position 2	Specia Functions	
Audi A8	2009-2010	4E	25 Immobilizer	Read Fault Codes	
Audi A8	2009-2010	4E	25 Immobilizer	Clear Fault Codes	
Audi A8	2009-2010	4E	25 Immobilizer	Measuring Blocks	
Audi A8	2009-2010	4E	25 Immobilizer	Output Tests	
Audi A8	2009-2010	4E	25 Immobilizer	Specia Functions	
Audi A8	2009-2010	4E	28 Climate Control Unit Rear	Read Fault Codes	
Audi A8	2009-2010	4E	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A8	2009-2010	4E	28 Climate Control Unit Rear	Measuring Blocks	
Audi A8	2009-2010	4E	28 Climate Control Unit Rear	Output Tests	
Audi A8	2009-2010	4E	28 Climate Control Unit Rear	Specia Functions	
Audi A8	2009-2010	4E	2E Media Player Position 3	Read Fault Codes	
Audi A8	2009-2010	4E	2E Media Player Position 3	Clear Fault Codes	
Audi A8	2009-2010	4E	2E Media Player Position 3	Measuring Blocks	
Audi A8	2009-2010	4E	2E Media Player Position 3	Output Tests	
Audi A8	2009-2010	4E	2E Media Player Position 3	Specia Functions	
Audi A8	2009-2010	4E	34 Self Leveling Suspension	Read Fault Codes	
Audi A8	2009-2010	4E	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8	2009-2010	4E	34 Self Leveling Suspension	Measuring Blocks	
Audi A8	2009-2010	4E	34 Self Leveling Suspension	Output Tests	
Audi A8	2009-2010	4E	34 Self Leveling Suspension	Specia Functions	
Audi A8	2009-2010	4E	36 Side of Driver Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2009-2010	4E	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A8	2009-2010	4E	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A8	2009-2010	4E	36 Side of Driver Seat Adj.	Output Tests	
Audi A8	2009-2010	4E	36 Side of Driver Seat Adj.	Specia Functions	
Audi A8	2009-2010	4E	37 Navigation	Read Fault Codes	
Audi A8	2009-2010	4E	37 Navigation	Clear Fault Codes	
Audi A8	2009-2010	4E	37 Navigation	Measuring Blocks	
Audi A8	2009-2010	4E	37 Navigation	Output Tests	
Audi A8	2009-2010	4E	37 Navigation	Specia Functions	
Audi A8	2009-2010	4E	38 Roof Electronics	Read Fault Codes	
Audi A8	2009-2010	4E	38 Roof Electronics	Clear Fault Codes	
Audi A8	2009-2010	4E	38 Roof Electronics	Measuring Blocks	
Audi A8	2009-2010	4E	38 Roof Electronics	Output Tests	
Audi A8	2009-2010	4E	38 Roof Electronics	Specia Functions	
Audi A8	2009-2010	4E	3C Lane Departure Assistance System	Read Fault Codes	
Audi A8	2009-2010	4E	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A8	2009-2010	4E	3C Lane Departure Assistance System	Measuring Blocks	
Audi A8	2009-2010	4E	3C Lane Departure Assistance System	Output Tests	
Audi A8	2009-2010	4E	3C Lane Departure Assistance System	Specia Functions	
Audi A8	2009-2010	4E	3D Special Function	Read Fault Codes	
Audi A8	2009-2010	4E	3D Special Function	Clear Fault Codes	
Audi A8	2009-2010	4E	3D Special Function	Measuring Blocks	
Audi A8	2009-2010	4E	3D Special Function	Output Tests	
Audi A8	2009-2010	4E	3D Special Function	Specia Functions	
Audi A8	2009-2010	4E	3E Media Player Position 4	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2009-2010	4E	3E Media Player Position 4	Clear Fault Codes	
Audi A8	2009-2010	4E	3E Media Player Position 4	Measuring Blocks	
Audi A8	2009-2010	4E	3E Media Player Position 4	Output Tests	
Audi A8	2009-2010	4E	3E Media Player Position 4	Specia Functions	
Audi A8	2009-2010	4E	42 Driver-Door Elect.	Read Fault Codes	
Audi A8	2009-2010	4E	42 Driver-Door Elect.	Clear Fault Codes	
Audi A8	2009-2010	4E	42 Driver-Door Elect.	Measuring Blocks	
Audi A8	2009-2010	4E	42 Driver-Door Elect.	Output Tests	
Audi A8	2009-2010	4E	42 Driver-Door Elect.	Specia Functions	
Audi A8	2009-2010	4E	46 Central Control Module	Read Fault Codes	
Audi A8	2009-2010	4E	46 Central Control Module	Clear Fault Codes	
Audi A8	2009-2010	4E	46 Central Control Module	Measuring Blocks	
Audi A8	2009-2010	4E	46 Central Control Module	Output Tests	
Audi A8	2009-2010	4E	46 Central Control Module	Specia Functions	
Audi A8	2009-2010	4E	47 Soundsystem	Read Fault Codes	
Audi A8	2009-2010	4E	47 Soundsystem	Clear Fault Codes	
Audi A8	2009-2010	4E	47 Soundsystem	Measuring Blocks	
Audi A8	2009-2010	4E	47 Soundsystem	Output Tests	
Audi A8	2009-2010	4E	47 Soundsystem	Specia Functions	
Audi A8	2009-2010	4E	4E Control Head RR	Read Fault Codes	
Audi A8	2009-2010	4E	4E Control Head RR	Clear Fault Codes	
Audi A8	2009-2010	4E	4E Control Head RR	Measuring Blocks	
Audi A8	2009-2010	4E	4E Control Head RR	Output Tests	
Audi A8	2009-2010	4E	4E Control Head RR	Specia Functions	
Audi A8	2009-2010	4E	4F Electronic Central Electric II	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2009-2010	4E	4F Electronic Central Electric II	Clear Fault Codes	
Audi A8	2009-2010	4E	4F Electronic Central Electric II	Measuring Blocks	
Audi A8	2009-2010	4E	4F Electronic Central Electric II	Output Tests	
Audi A8	2009-2010	4E	4F Electronic Central Electric II	Specia Functions	
Audi A8	2009-2010	4E	51 Electric Drive	Read Fault Codes	
Audi A8	2009-2010	4E	51 Electric Drive	Clear Fault Codes	
Audi A8	2009-2010	4E	51 Electric Drive	Measuring Blocks	
Audi A8	2009-2010	4E	51 Electric Drive	Output Tests	
Audi A8	2009-2010	4E	51 Electric Drive	Specia Functions	
Audi A8	2009-2010	4E	52 Passe.-Door Elect.	Read Fault Codes	
Audi A8	2009-2010	4E	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A8	2009-2010	4E	52 Passe.-Door Elect.	Measuring Blocks	
Audi A8	2009-2010	4E	52 Passe.-Door Elect.	Output Tests	
Audi A8	2009-2010	4E	52 Passe.-Door Elect.	Specia Functions	
Audi A8	2009-2010	4E	53 Parking Brake	Read Fault Codes	
Audi A8	2009-2010	4E	53 Parking Brake	Clear Fault Codes	
Audi A8	2009-2010	4E	53 Parking Brake	Measuring Blocks	
Audi A8	2009-2010	4E	53 Parking Brake	Output Tests	
Audi A8	2009-2010	4E	53 Parking Brake	Specia Functions	
Audi A8	2009-2010	4E	55 Headlight Range Control	Read Fault Codes	
Audi A8	2009-2010	4E	55 Headlight Range Control	Clear Fault Codes	
Audi A8	2009-2010	4E	55 Headlight Range Control	Measuring Blocks	
Audi A8	2009-2010	4E	55 Headlight Range Control	Output Tests	
Audi A8	2009-2010	4E	55 Headlight Range Control	Specia Functions	
Audi A8	2009-2010	4E	56 Radio	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2009-2010	4E	56 Radio	Clear Fault Codes	
Audi A8	2009-2010	4E	56 Radio	Measuring Blocks	
Audi A8	2009-2010	4E	56 Radio	Output Tests	
Audi A8	2009-2010	4E	56 Radio	Specia Functions	
Audi A8	2009-2010	4E	57 TV-Tuner	Read Fault Codes	
Audi A8	2009-2010	4E	57 TV-Tuner	Clear Fault Codes	
Audi A8	2009-2010	4E	57 TV-Tuner	Measuring Blocks	
Audi A8	2009-2010	4E	57 TV-Tuner	Output Tests	
Audi A8	2009-2010	4E	57 TV-Tuner	Specia Functions	
Audi A8	2009-2010	4E	5C Lane Keeping Assistance System	Read Fault Codes	
Audi A8	2009-2010	4E	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi A8	2009-2010	4E	5C Lane Keeping Assistance System	Measuring Blocks	
Audi A8	2009-2010	4E	5C Lane Keeping Assistance System	Output Tests	
Audi A8	2009-2010	4E	5C Lane Keeping Assistance System	Specia Functions	
Audi A8	2009-2010	4E	5E Control Head LR	Read Fault Codes	
Audi A8	2009-2010	4E	5E Control Head LR	Clear Fault Codes	
Audi A8	2009-2010	4E	5E Control Head LR	Measuring Blocks	
Audi A8	2009-2010	4E	5E Control Head LR	Output Tests	
Audi A8	2009-2010	4E	5E Control Head LR	Specia Functions	
Audi A8	2009-2010	4E	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A8	2009-2010	4E	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A8	2009-2010	4E	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A8	2009-2010	4E	5F Information Electronic Equipment 1	Output Tests	
Audi A8	2009-2010	4E	5F Information Electronic Equipment 1	Specia Functions	
Audi A8	2009-2010	4E	61 Battery Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2009-2010	4E	61 Battery Control	Clear Fault Codes	
Audi A8	2009-2010	4E	61 Battery Control	Measuring Blocks	
Audi A8	2009-2010	4E	61 Battery Control	Output Tests	
Audi A8	2009-2010	4E	61 Battery Control	Specia Functions	
Audi A8	2009-2010	4E	62 LR-Door Electroni.	Read Fault Codes	
Audi A8	2009-2010	4E	62 LR-Door Electroni.	Clear Fault Codes	
Audi A8	2009-2010	4E	62 LR-Door Electroni.	Measuring Blocks	
Audi A8	2009-2010	4E	62 LR-Door Electroni.	Output Tests	
Audi A8	2009-2010	4E	62 LR-Door Electroni.	Specia Functions	
Audi A8	2009-2010	4E	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8	2009-2010	4E	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8	2009-2010	4E	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8	2009-2010	4E	65 Tyre Pressure Monitoring	Output Tests	
Audi A8	2009-2010	4E	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8	2009-2010	4E	66 Seat-/Mirror Adjust.	Read Fault Codes	
Audi A8	2009-2010	4E	66 Seat-/Mirror Adjust.	Clear Fault Codes	
Audi A8	2009-2010	4E	66 Seat-/Mirror Adjust.	Measuring Blocks	
Audi A8	2009-2010	4E	66 Seat-/Mirror Adjust.	Output Tests	
Audi A8	2009-2010	4E	66 Seat-/Mirror Adjust.	Specia Functions	
Audi A8	2009-2010	4E	67 Voice Control	Read Fault Codes	
Audi A8	2009-2010	4E	67 Voice Control	Clear Fault Codes	
Audi A8	2009-2010	4E	67 Voice Control	Measuring Blocks	
Audi A8	2009-2010	4E	67 Voice Control	Output Tests	
Audi A8	2009-2010	4E	67 Voice Control	Specia Functions	
Audi A8	2009-2010	4E	69 Trailer Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2009-2010	4E	69 Trailer Function	Clear Fault Codes	
Audi A8	2009-2010	4E	69 Trailer Function	Measuring Blocks	
Audi A8	2009-2010	4E	69 Trailer Function	Output Tests	
Audi A8	2009-2010	4E	69 Trailer Function	Specia Functions	
Audi A8	2009-2010	4E	6C Rear Camera	Read Fault Codes	
Audi A8	2009-2010	4E	6C Rear Camera	Clear Fault Codes	
Audi A8	2009-2010	4E	6C Rear Camera	Measuring Blocks	
Audi A8	2009-2010	4E	6C Rear Camera	Output Tests	
Audi A8	2009-2010	4E	6C Rear Camera	Specia Functions	
Audi A8	2009-2010	4E	72 RR-Door Electroni.	Read Fault Codes	
Audi A8	2009-2010	4E	72 RR-Door Electroni.	Clear Fault Codes	
Audi A8	2009-2010	4E	72 RR-Door Electroni.	Measuring Blocks	
Audi A8	2009-2010	4E	72 RR-Door Electroni.	Output Tests	
Audi A8	2009-2010	4E	72 RR-Door Electroni.	Specia Functions	
Audi A8	2009-2010	4E	75 Emergency Call Module	Read Fault Codes	
Audi A8	2009-2010	4E	75 Emergency Call Module	Clear Fault Codes	
Audi A8	2009-2010	4E	75 Emergency Call Module	Measuring Blocks	
Audi A8	2009-2010	4E	75 Emergency Call Module	Output Tests	
Audi A8	2009-2010	4E	75 Emergency Call Module	Specia Functions	
Audi A8	2009-2010	4E	76 Parking Aid	Read Fault Codes	
Audi A8	2009-2010	4E	76 Parking Aid	Clear Fault Codes	
Audi A8	2009-2010	4E	76 Parking Aid	Measuring Blocks	
Audi A8	2009-2010	4E	76 Parking Aid	Output Tests	
Audi A8	2009-2010	4E	76 Parking Aid	Specia Functions	
Audi A8	2009-2010	4E	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2009-2010	4E	77 Telephone	Clear Fault Codes	
Audi A8	2009-2010	4E	77 Telephone	Measuring Blocks	
Audi A8	2009-2010	4E	77 Telephone	Output Tests	
Audi A8	2009-2010	4E	77 Telephone	Specia Functions	
Audi A8	2009-2010	4E	8C Hybrid Battery	Read Fault Codes	
Audi A8	2009-2010	4E	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2009-2010	4E	8C Hybrid Battery	Measuring Blocks	
Audi A8	2009-2010	4E	8C Hybrid Battery	Output Tests	
Audi A8	2009-2010	4E	8C Hybrid Battery	Specia Functions	
Audi TT	1998-1999	8N	01 Engine Electronics	Read Fault Codes	
Audi TT	1998-1999	8N	01 Engine Electronics	Clear Fault Codes	
Audi TT	1998-1999	8N	01 Engine Electronics	Measuring Blocks	
Audi TT	1998-1999	8N	01 Engine Electronics	Output Tests	
Audi TT	1998-1999	8N	01 Engine Electronics	Specia Functions	
Audi TT	1998-1999	8N	02 Transmission Electronics	Read Fault Codes	
Audi TT	1998-1999	8N	02 Transmission Electronics	Clear Fault Codes	
Audi TT	1998-1999	8N	02 Transmission Electronics	Measuring Blocks	
Audi TT	1998-1999	8N	02 Transmission Electronics	Output Tests	
Audi TT	1998-1999	8N	02 Transmission Electronics	Specia Functions	
Audi TT	1998-1999	8N	03 Brake Electronics	Read Fault Codes	
Audi TT	1998-1999	8N	03 Brake Electronics	Clear Fault Codes	
Audi TT	1998-1999	8N	03 Brake Electronics	Measuring Blocks	
Audi TT	1998-1999	8N	03 Brake Electronics	Output Tests	
Audi TT	1998-1999	8N	03 Brake Electronics	Specia Functions	
Audi TT	1998-1999	8N	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	1998-1999	8N	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT	1998-1999	8N	08 AC/Heating Electronics	Measuring Blocks	
Audi TT	1998-1999	8N	08 AC/Heating Electronics	Output Tests	
Audi TT	1998-1999	8N	08 AC/Heating Electronics	Specia Functions	
Audi TT	1998-1999	8N	11 Engine Electronics 2	Read Fault Codes	
Audi TT	1998-1999	8N	11 Engine Electronics 2	Clear Fault Codes	
Audi TT	1998-1999	8N	11 Engine Electronics 2	Measuring Blocks	
Audi TT	1998-1999	8N	11 Engine Electronics 2	Output Tests	
Audi TT	1998-1999	8N	11 Engine Electronics 2	Specia Functions	
Audi TT	1998-1999	8N	15 Airbags	Read Fault Codes	
Audi TT	1998-1999	8N	15 Airbags	Clear Fault Codes	
Audi TT	1998-1999	8N	15 Airbags	Measuring Blocks	
Audi TT	1998-1999	8N	15 Airbags	Output Tests	
Audi TT	1998-1999	8N	15 Airbags	Specia Functions	
Audi TT	1998-1999	8N	17 Instrument Cluster	Read Fault Codes	
Audi TT	1998-1999	8N	17 Instrument Cluster	Clear Fault Codes	
Audi TT	1998-1999	8N	17 Instrument Cluster	Measuring Blocks	
Audi TT	1998-1999	8N	17 Instrument Cluster	Output Tests	
Audi TT	1998-1999	8N	17 Instrument Cluster	Specia Functions	
Audi TT	1998-1999	8N	22 4WD Electronics	Read Fault Codes	
Audi TT	1998-1999	8N	22 4WD Electronics	Clear Fault Codes	
Audi TT	1998-1999	8N	22 4WD Electronics	Measuring Blocks	
Audi TT	1998-1999	8N	22 4WD Electronics	Output Tests	
Audi TT	1998-1999	8N	22 4WD Electronics	Specia Functions	
Audi TT	1998-1999	8N	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	1998-1999	8N	25 Immobilizer	Clear Fault Codes	
Audi TT	1998-1999	8N	25 Immobilizer	Measuring Blocks	
Audi TT	1998-1999	8N	25 Immobilizer	Output Tests	
Audi TT	1998-1999	8N	25 Immobilizer	Specia Functions	
Audi TT	1998-1999	8N	35 Central Locking	Read Fault Codes	
Audi TT	1998-1999	8N	35 Central Locking	Clear Fault Codes	
Audi TT	1998-1999	8N	35 Central Locking	Measuring Blocks	
Audi TT	1998-1999	8N	35 Central Locking	Output Tests	
Audi TT	1998-1999	8N	35 Central Locking	Specia Functions	
Audi TT	1998-1999	8N	45 Interior Monitoring	Read Fault Codes	
Audi TT	1998-1999	8N	45 Interior Monitoring	Clear Fault Codes	
Audi TT	1998-1999	8N	45 Interior Monitoring	Measuring Blocks	
Audi TT	1998-1999	8N	45 Interior Monitoring	Output Tests	
Audi TT	1998-1999	8N	45 Interior Monitoring	Specia Functions	
Audi TT	1998-1999	8N	51 Electric Drive	Read Fault Codes	
Audi TT	1998-1999	8N	51 Electric Drive	Clear Fault Codes	
Audi TT	1998-1999	8N	51 Electric Drive	Measuring Blocks	
Audi TT	1998-1999	8N	51 Electric Drive	Output Tests	
Audi TT	1998-1999	8N	51 Electric Drive	Specia Functions	
Audi TT	1998-1999	8N	55 Headlight Range Control	Read Fault Codes	
Audi TT	1998-1999	8N	55 Headlight Range Control	Clear Fault Codes	
Audi TT	1998-1999	8N	55 Headlight Range Control	Measuring Blocks	
Audi TT	1998-1999	8N	55 Headlight Range Control	Output Tests	
Audi TT	1998-1999	8N	55 Headlight Range Control	Specia Functions	
Audi TT	1998-1999	8N	56 Radio	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	1998-1999	8N	56 Radio	Clear Fault Codes	
Audi TT	1998-1999	8N	56 Radio	Measuring Blocks	
Audi TT	1998-1999	8N	56 Radio	Output Tests	
Audi TT	1998-1999	8N	56 Radio	Specia Functions	
Audi TT	1998-1999	8N	8C Hybrid Battery	Read Fault Codes	
Audi TT	1998-1999	8N	8C Hybrid Battery	Clear Fault Codes	
Audi TT	1998-1999	8N	8C Hybrid Battery	Measuring Blocks	
Audi TT	1998-1999	8N	8C Hybrid Battery	Output Tests	
Audi TT	1998-1999	8N	8C Hybrid Battery	Specia Functions	
Audi TT	2000	8N	01 Engine Electronics	Read Fault Codes	
Audi TT	2000	8N	01 Engine Electronics	Clear Fault Codes	
Audi TT	2000	8N	01 Engine Electronics	Measuring Blocks	
Audi TT	2000	8N	01 Engine Electronics	Output Tests	
Audi TT	2000	8N	01 Engine Electronics	Specia Functions	
Audi TT	2000	8N	02 Transmission Electronics	Read Fault Codes	
Audi TT	2000	8N	02 Transmission Electronics	Clear Fault Codes	
Audi TT	2000	8N	02 Transmission Electronics	Measuring Blocks	
Audi TT	2000	8N	02 Transmission Electronics	Output Tests	
Audi TT	2000	8N	02 Transmission Electronics	Specia Functions	
Audi TT	2000	8N	03 Brake Electronics	Read Fault Codes	
Audi TT	2000	8N	03 Brake Electronics	Clear Fault Codes	
Audi TT	2000	8N	03 Brake Electronics	Measuring Blocks	
Audi TT	2000	8N	03 Brake Electronics	Output Tests	
Audi TT	2000	8N	03 Brake Electronics	Specia Functions	
Audi TT	2000	8N	08 AC/Heating Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2000	8N	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT	2000	8N	08 AC/Heating Electronics	Measuring Blocks	
Audi TT	2000	8N	08 AC/Heating Electronics	Output Tests	
Audi TT	2000	8N	08 AC/Heating Electronics	Specia Functions	
Audi TT	2000	8N	11 Engine Electronics 2	Read Fault Codes	
Audi TT	2000	8N	11 Engine Electronics 2	Clear Fault Codes	
Audi TT	2000	8N	11 Engine Electronics 2	Measuring Blocks	
Audi TT	2000	8N	11 Engine Electronics 2	Output Tests	
Audi TT	2000	8N	11 Engine Electronics 2	Specia Functions	
Audi TT	2000	8N	15 Airbags	Read Fault Codes	
Audi TT	2000	8N	15 Airbags	Clear Fault Codes	
Audi TT	2000	8N	15 Airbags	Measuring Blocks	
Audi TT	2000	8N	15 Airbags	Output Tests	
Audi TT	2000	8N	15 Airbags	Specia Functions	
Audi TT	2000	8N	17 Instrument Cluster	Read Fault Codes	
Audi TT	2000	8N	17 Instrument Cluster	Clear Fault Codes	
Audi TT	2000	8N	17 Instrument Cluster	Measuring Blocks	
Audi TT	2000	8N	17 Instrument Cluster	Output Tests	
Audi TT	2000	8N	17 Instrument Cluster	Specia Functions	
Audi TT	2000	8N	22 4WD Electronics	Read Fault Codes	
Audi TT	2000	8N	22 4WD Electronics	Clear Fault Codes	
Audi TT	2000	8N	22 4WD Electronics	Measuring Blocks	
Audi TT	2000	8N	22 4WD Electronics	Output Tests	
Audi TT	2000	8N	22 4WD Electronics	Specia Functions	
Audi TT	2000	8N	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2000	8N	25 Immobilizer	Clear Fault Codes	
Audi TT	2000	8N	25 Immobilizer	Measuring Blocks	
Audi TT	2000	8N	25 Immobilizer	Output Tests	
Audi TT	2000	8N	25 Immobilizer	Specia Functions	
Audi TT	2000	8N	35 Central Locking	Read Fault Codes	
Audi TT	2000	8N	35 Central Locking	Clear Fault Codes	
Audi TT	2000	8N	35 Central Locking	Measuring Blocks	
Audi TT	2000	8N	35 Central Locking	Output Tests	
Audi TT	2000	8N	35 Central Locking	Specia Functions	
Audi TT	2000	8N	37 Navigation	Read Fault Codes	
Audi TT	2000	8N	37 Navigation	Clear Fault Codes	
Audi TT	2000	8N	37 Navigation	Measuring Blocks	
Audi TT	2000	8N	37 Navigation	Output Tests	
Audi TT	2000	8N	37 Navigation	Specia Functions	
Audi TT	2000	8N	45 Interior Monitoring	Read Fault Codes	
Audi TT	2000	8N	45 Interior Monitoring	Clear Fault Codes	
Audi TT	2000	8N	45 Interior Monitoring	Measuring Blocks	
Audi TT	2000	8N	45 Interior Monitoring	Output Tests	
Audi TT	2000	8N	45 Interior Monitoring	Specia Functions	
Audi TT	2000	8N	51 Electric Drive	Read Fault Codes	
Audi TT	2000	8N	51 Electric Drive	Clear Fault Codes	
Audi TT	2000	8N	51 Electric Drive	Measuring Blocks	
Audi TT	2000	8N	51 Electric Drive	Output Tests	
Audi TT	2000	8N	51 Electric Drive	Specia Functions	
Audi TT	2000	8N	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2000	8N	55 Headlight Range Control	Clear Fault Codes	
Audi TT	2000	8N	55 Headlight Range Control	Measuring Blocks	
Audi TT	2000	8N	55 Headlight Range Control	Output Tests	
Audi TT	2000	8N	55 Headlight Range Control	Specia Functions	
Audi TT	2000	8N	56 Radio	Read Fault Codes	
Audi TT	2000	8N	56 Radio	Clear Fault Codes	
Audi TT	2000	8N	56 Radio	Measuring Blocks	
Audi TT	2000	8N	56 Radio	Output Tests	
Audi TT	2000	8N	56 Radio	Specia Functions	
Audi TT	2000	8N	8C Hybrid Battery	Read Fault Codes	
Audi TT	2000	8N	8C Hybrid Battery	Clear Fault Codes	
Audi TT	2000	8N	8C Hybrid Battery	Measuring Blocks	
Audi TT	2000	8N	8C Hybrid Battery	Output Tests	
Audi TT	2000	8N	8C Hybrid Battery	Specia Functions	
Audi TT	2001	8N	01 Engine Electronics	Read Fault Codes	
Audi TT	2001	8N	01 Engine Electronics	Clear Fault Codes	
Audi TT	2001	8N	01 Engine Electronics	Measuring Blocks	
Audi TT	2001	8N	01 Engine Electronics	Output Tests	
Audi TT	2001	8N	01 Engine Electronics	Specia Functions	
Audi TT	2001	8N	02 Transmission Electronics	Read Fault Codes	
Audi TT	2001	8N	02 Transmission Electronics	Clear Fault Codes	
Audi TT	2001	8N	02 Transmission Electronics	Measuring Blocks	
Audi TT	2001	8N	02 Transmission Electronics	Output Tests	
Audi TT	2001	8N	02 Transmission Electronics	Specia Functions	
Audi TT	2001	8N	03 Brake Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2001	8N	03 Brake Electronics	Clear Fault Codes	
Audi TT	2001	8N	03 Brake Electronics	Measuring Blocks	
Audi TT	2001	8N	03 Brake Electronics	Output Tests	
Audi TT	2001	8N	03 Brake Electronics	Specia Functions	
Audi TT	2001	8N	08 AC/Heating Electronics	Read Fault Codes	
Audi TT	2001	8N	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT	2001	8N	08 AC/Heating Electronics	Measuring Blocks	
Audi TT	2001	8N	08 AC/Heating Electronics	Output Tests	
Audi TT	2001	8N	08 AC/Heating Electronics	Specia Functions	
Audi TT	2001	8N	11 Engine Electronics 2	Read Fault Codes	
Audi TT	2001	8N	11 Engine Electronics 2	Clear Fault Codes	
Audi TT	2001	8N	11 Engine Electronics 2	Measuring Blocks	
Audi TT	2001	8N	11 Engine Electronics 2	Output Tests	
Audi TT	2001	8N	11 Engine Electronics 2	Specia Functions	
Audi TT	2001	8N	15 Airbags	Read Fault Codes	
Audi TT	2001	8N	15 Airbags	Clear Fault Codes	
Audi TT	2001	8N	15 Airbags	Measuring Blocks	
Audi TT	2001	8N	15 Airbags	Output Tests	
Audi TT	2001	8N	15 Airbags	Specia Functions	
Audi TT	2001	8N	17 Instrument Cluster	Read Fault Codes	
Audi TT	2001	8N	17 Instrument Cluster	Clear Fault Codes	
Audi TT	2001	8N	17 Instrument Cluster	Measuring Blocks	
Audi TT	2001	8N	17 Instrument Cluster	Output Tests	
Audi TT	2001	8N	17 Instrument Cluster	Specia Functions	
Audi TT	2001	8N	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2001	8N	22 4WD Electronics	Clear Fault Codes	
Audi TT	2001	8N	22 4WD Electronics	Measuring Blocks	
Audi TT	2001	8N	22 4WD Electronics	Output Tests	
Audi TT	2001	8N	22 4WD Electronics	Specia Functions	
Audi TT	2001	8N	25 Immobilizer	Read Fault Codes	
Audi TT	2001	8N	25 Immobilizer	Clear Fault Codes	
Audi TT	2001	8N	25 Immobilizer	Measuring Blocks	
Audi TT	2001	8N	25 Immobilizer	Output Tests	
Audi TT	2001	8N	25 Immobilizer	Specia Functions	
Audi TT	2001	8N	35 Central Locking	Read Fault Codes	
Audi TT	2001	8N	35 Central Locking	Clear Fault Codes	
Audi TT	2001	8N	35 Central Locking	Measuring Blocks	
Audi TT	2001	8N	35 Central Locking	Output Tests	
Audi TT	2001	8N	35 Central Locking	Specia Functions	
Audi TT	2001	8N	37 Navigation	Read Fault Codes	
Audi TT	2001	8N	37 Navigation	Clear Fault Codes	
Audi TT	2001	8N	37 Navigation	Measuring Blocks	
Audi TT	2001	8N	37 Navigation	Output Tests	
Audi TT	2001	8N	37 Navigation	Specia Functions	
Audi TT	2001	8N	51 Electric Drive	Read Fault Codes	
Audi TT	2001	8N	51 Electric Drive	Clear Fault Codes	
Audi TT	2001	8N	51 Electric Drive	Measuring Blocks	
Audi TT	2001	8N	51 Electric Drive	Output Tests	
Audi TT	2001	8N	51 Electric Drive	Specia Functions	
Audi TT	2001	8N	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2001	8N	55 Headlight Range Control	Clear Fault Codes	
Audi TT	2001	8N	55 Headlight Range Control	Measuring Blocks	
Audi TT	2001	8N	55 Headlight Range Control	Output Tests	
Audi TT	2001	8N	55 Headlight Range Control	Specia Functions	
Audi TT	2001	8N	56 Radio	Read Fault Codes	
Audi TT	2001	8N	56 Radio	Clear Fault Codes	
Audi TT	2001	8N	56 Radio	Measuring Blocks	
Audi TT	2001	8N	56 Radio	Output Tests	
Audi TT	2001	8N	56 Radio	Specia Functions	
Audi TT	2001	8N	76 Parking Aid	Read Fault Codes	
Audi TT	2001	8N	76 Parking Aid	Clear Fault Codes	
Audi TT	2001	8N	76 Parking Aid	Measuring Blocks	
Audi TT	2001	8N	76 Parking Aid	Output Tests	
Audi TT	2001	8N	76 Parking Aid	Specia Functions	
Audi TT	2001	8N	8C Hybrid Battery	Read Fault Codes	
Audi TT	2001	8N	8C Hybrid Battery	Clear Fault Codes	
Audi TT	2001	8N	8C Hybrid Battery	Measuring Blocks	
Audi TT	2001	8N	8C Hybrid Battery	Output Tests	
Audi TT	2001	8N	8C Hybrid Battery	Specia Functions	
Audi TT	2002	8N	01 Engine Electronics	Read Fault Codes	
Audi TT	2002	8N	01 Engine Electronics	Clear Fault Codes	
Audi TT	2002	8N	01 Engine Electronics	Measuring Blocks	
Audi TT	2002	8N	01 Engine Electronics	Output Tests	
Audi TT	2002	8N	01 Engine Electronics	Specia Functions	
Audi TT	2002	8N	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2002	8N	02 Transmission Electronics	Clear Fault Codes	
Audi TT	2002	8N	02 Transmission Electronics	Measuring Blocks	
Audi TT	2002	8N	02 Transmission Electronics	Output Tests	
Audi TT	2002	8N	02 Transmission Electronics	Specia Functions	
Audi TT	2002	8N	03 Brake Electronics	Read Fault Codes	
Audi TT	2002	8N	03 Brake Electronics	Clear Fault Codes	
Audi TT	2002	8N	03 Brake Electronics	Measuring Blocks	
Audi TT	2002	8N	03 Brake Electronics	Output Tests	
Audi TT	2002	8N	03 Brake Electronics	Specia Functions	
Audi TT	2002	8N	08 AC/Heating Electronics	Read Fault Codes	
Audi TT	2002	8N	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT	2002	8N	08 AC/Heating Electronics	Measuring Blocks	
Audi TT	2002	8N	08 AC/Heating Electronics	Output Tests	
Audi TT	2002	8N	08 AC/Heating Electronics	Specia Functions	
Audi TT	2002	8N	11 Engine Electronics 2	Read Fault Codes	
Audi TT	2002	8N	11 Engine Electronics 2	Clear Fault Codes	
Audi TT	2002	8N	11 Engine Electronics 2	Measuring Blocks	
Audi TT	2002	8N	11 Engine Electronics 2	Output Tests	
Audi TT	2002	8N	11 Engine Electronics 2	Specia Functions	
Audi TT	2002	8N	15 Airbags	Read Fault Codes	
Audi TT	2002	8N	15 Airbags	Clear Fault Codes	
Audi TT	2002	8N	15 Airbags	Measuring Blocks	
Audi TT	2002	8N	15 Airbags	Output Tests	
Audi TT	2002	8N	15 Airbags	Specia Functions	
Audi TT	2002	8N	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2002	8N	17 Instrument Cluster	Clear Fault Codes	
Audi TT	2002	8N	17 Instrument Cluster	Measuring Blocks	
Audi TT	2002	8N	17 Instrument Cluster	Output Tests	
Audi TT	2002	8N	17 Instrument Cluster	Specia Functions	
Audi TT	2002	8N	22 4WD Electronics	Read Fault Codes	
Audi TT	2002	8N	22 4WD Electronics	Clear Fault Codes	
Audi TT	2002	8N	22 4WD Electronics	Measuring Blocks	
Audi TT	2002	8N	22 4WD Electronics	Output Tests	
Audi TT	2002	8N	22 4WD Electronics	Specia Functions	
Audi TT	2002	8N	25 Immobilizer	Read Fault Codes	
Audi TT	2002	8N	25 Immobilizer	Clear Fault Codes	
Audi TT	2002	8N	25 Immobilizer	Measuring Blocks	
Audi TT	2002	8N	25 Immobilizer	Output Tests	
Audi TT	2002	8N	25 Immobilizer	Specia Functions	
Audi TT	2002	8N	35 Central Locking	Read Fault Codes	
Audi TT	2002	8N	35 Central Locking	Clear Fault Codes	
Audi TT	2002	8N	35 Central Locking	Measuring Blocks	
Audi TT	2002	8N	35 Central Locking	Output Tests	
Audi TT	2002	8N	35 Central Locking	Specia Functions	
Audi TT	2002	8N	37 Navigation	Read Fault Codes	
Audi TT	2002	8N	37 Navigation	Clear Fault Codes	
Audi TT	2002	8N	37 Navigation	Measuring Blocks	
Audi TT	2002	8N	37 Navigation	Output Tests	
Audi TT	2002	8N	37 Navigation	Specia Functions	
Audi TT	2002	8N	51 Electric Drive	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2002	8N	51 Electric Drive	Clear Fault Codes	
Audi TT	2002	8N	51 Electric Drive	Measuring Blocks	
Audi TT	2002	8N	51 Electric Drive	Output Tests	
Audi TT	2002	8N	51 Electric Drive	Specia Functions	
Audi TT	2002	8N	55 Headlight Range Control	Read Fault Codes	
Audi TT	2002	8N	55 Headlight Range Control	Clear Fault Codes	
Audi TT	2002	8N	55 Headlight Range Control	Measuring Blocks	
Audi TT	2002	8N	55 Headlight Range Control	Output Tests	
Audi TT	2002	8N	55 Headlight Range Control	Specia Functions	
Audi TT	2002	8N	56 Radio	Read Fault Codes	
Audi TT	2002	8N	56 Radio	Clear Fault Codes	
Audi TT	2002	8N	56 Radio	Measuring Blocks	
Audi TT	2002	8N	56 Radio	Output Tests	
Audi TT	2002	8N	56 Radio	Specia Functions	
Audi TT	2002	8N	76 Parking Aid	Read Fault Codes	
Audi TT	2002	8N	76 Parking Aid	Clear Fault Codes	
Audi TT	2002	8N	76 Parking Aid	Measuring Blocks	
Audi TT	2002	8N	76 Parking Aid	Output Tests	
Audi TT	2002	8N	76 Parking Aid	Specia Functions	
Audi TT	2002	8N	8C Hybrid Battery	Read Fault Codes	
Audi TT	2002	8N	8C Hybrid Battery	Clear Fault Codes	
Audi TT	2002	8N	8C Hybrid Battery	Measuring Blocks	
Audi TT	2002	8N	8C Hybrid Battery	Output Tests	
Audi TT	2002	8N	8C Hybrid Battery	Specia Functions	
Audi TT	2003	8N	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2003	8N	01 Engine Electronics	Clear Fault Codes	
Audi TT	2003	8N	01 Engine Electronics	Measuring Blocks	
Audi TT	2003	8N	01 Engine Electronics	Output Tests	
Audi TT	2003	8N	01 Engine Electronics	Specia Functions	
Audi TT	2003	8N	02 Transmission Electronics	Read Fault Codes	
Audi TT	2003	8N	02 Transmission Electronics	Clear Fault Codes	
Audi TT	2003	8N	02 Transmission Electronics	Measuring Blocks	
Audi TT	2003	8N	02 Transmission Electronics	Output Tests	
Audi TT	2003	8N	02 Transmission Electronics	Specia Functions	
Audi TT	2003	8N	03 Brake Electronics	Read Fault Codes	
Audi TT	2003	8N	03 Brake Electronics	Clear Fault Codes	
Audi TT	2003	8N	03 Brake Electronics	Measuring Blocks	
Audi TT	2003	8N	03 Brake Electronics	Output Tests	
Audi TT	2003	8N	03 Brake Electronics	Specia Functions	
Audi TT	2003	8N	08 AC/Heating Electronics	Read Fault Codes	
Audi TT	2003	8N	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT	2003	8N	08 AC/Heating Electronics	Measuring Blocks	
Audi TT	2003	8N	08 AC/Heating Electronics	Output Tests	
Audi TT	2003	8N	08 AC/Heating Electronics	Specia Functions	
Audi TT	2003	8N	11 Engine Electronics 2	Read Fault Codes	
Audi TT	2003	8N	11 Engine Electronics 2	Clear Fault Codes	
Audi TT	2003	8N	11 Engine Electronics 2	Measuring Blocks	
Audi TT	2003	8N	11 Engine Electronics 2	Output Tests	
Audi TT	2003	8N	11 Engine Electronics 2	Specia Functions	
Audi TT	2003	8N	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2003	8N	15 Airbags	Clear Fault Codes	
Audi TT	2003	8N	15 Airbags	Measuring Blocks	
Audi TT	2003	8N	15 Airbags	Output Tests	
Audi TT	2003	8N	15 Airbags	Specia Functions	
Audi TT	2003	8N	17 Instrument Cluster	Read Fault Codes	
Audi TT	2003	8N	17 Instrument Cluster	Clear Fault Codes	
Audi TT	2003	8N	17 Instrument Cluster	Measuring Blocks	
Audi TT	2003	8N	17 Instrument Cluster	Output Tests	
Audi TT	2003	8N	17 Instrument Cluster	Specia Functions	
Audi TT	2003	8N	22 4WD Electronics	Read Fault Codes	
Audi TT	2003	8N	22 4WD Electronics	Clear Fault Codes	
Audi TT	2003	8N	22 4WD Electronics	Measuring Blocks	
Audi TT	2003	8N	22 4WD Electronics	Output Tests	
Audi TT	2003	8N	22 4WD Electronics	Specia Functions	
Audi TT	2003	8N	25 Immobilizer	Read Fault Codes	
Audi TT	2003	8N	25 Immobilizer	Clear Fault Codes	
Audi TT	2003	8N	25 Immobilizer	Measuring Blocks	
Audi TT	2003	8N	25 Immobilizer	Output Tests	
Audi TT	2003	8N	25 Immobilizer	Specia Functions	
Audi TT	2003	8N	35 Central Locking	Read Fault Codes	
Audi TT	2003	8N	35 Central Locking	Clear Fault Codes	
Audi TT	2003	8N	35 Central Locking	Measuring Blocks	
Audi TT	2003	8N	35 Central Locking	Output Tests	
Audi TT	2003	8N	35 Central Locking	Specia Functions	
Audi TT	2003	8N	37 Navigation	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2003	8N	37 Navigation	Clear Fault Codes	
Audi TT	2003	8N	37 Navigation	Measuring Blocks	
Audi TT	2003	8N	37 Navigation	Output Tests	
Audi TT	2003	8N	37 Navigation	Specia Functions	
Audi TT	2003	8N	51 Electric Drive	Read Fault Codes	
Audi TT	2003	8N	51 Electric Drive	Clear Fault Codes	
Audi TT	2003	8N	51 Electric Drive	Measuring Blocks	
Audi TT	2003	8N	51 Electric Drive	Output Tests	
Audi TT	2003	8N	51 Electric Drive	Specia Functions	
Audi TT	2003	8N	55 Headlight Range Control	Read Fault Codes	
Audi TT	2003	8N	55 Headlight Range Control	Clear Fault Codes	
Audi TT	2003	8N	55 Headlight Range Control	Measuring Blocks	
Audi TT	2003	8N	55 Headlight Range Control	Output Tests	
Audi TT	2003	8N	55 Headlight Range Control	Specia Functions	
Audi TT	2003	8N	56 Radio	Read Fault Codes	
Audi TT	2003	8N	56 Radio	Clear Fault Codes	
Audi TT	2003	8N	56 Radio	Measuring Blocks	
Audi TT	2003	8N	56 Radio	Output Tests	
Audi TT	2003	8N	56 Radio	Specia Functions	
Audi TT	2003	8N	76 Parking Aid	Read Fault Codes	
Audi TT	2003	8N	76 Parking Aid	Clear Fault Codes	
Audi TT	2003	8N	76 Parking Aid	Measuring Blocks	
Audi TT	2003	8N	76 Parking Aid	Output Tests	
Audi TT	2003	8N	76 Parking Aid	Specia Functions	
Audi TT	2003	8N	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2003	8N	8C Hybrid Battery	Clear Fault Codes	
Audi TT	2003	8N	8C Hybrid Battery	Measuring Blocks	
Audi TT	2003	8N	8C Hybrid Battery	Output Tests	
Audi TT	2003	8N	8C Hybrid Battery	Specia Functions	
Audi TT	2004-2006	8N	01 Engine Electronics	Read Fault Codes	
Audi TT	2004-2006	8N	01 Engine Electronics	Clear Fault Codes	
Audi TT	2004-2006	8N	01 Engine Electronics	Measuring Blocks	
Audi TT	2004-2006	8N	01 Engine Electronics	Output Tests	
Audi TT	2004-2006	8N	01 Engine Electronics	Specia Functions	
Audi TT	2004-2006	8N	02 Transmission Electronics	Read Fault Codes	
Audi TT	2004-2006	8N	02 Transmission Electronics	Clear Fault Codes	
Audi TT	2004-2006	8N	02 Transmission Electronics	Measuring Blocks	
Audi TT	2004-2006	8N	02 Transmission Electronics	Output Tests	
Audi TT	2004-2006	8N	02 Transmission Electronics	Specia Functions	
Audi TT	2004-2006	8N	03 Brake Electronics	Read Fault Codes	
Audi TT	2004-2006	8N	03 Brake Electronics	Clear Fault Codes	
Audi TT	2004-2006	8N	03 Brake Electronics	Measuring Blocks	
Audi TT	2004-2006	8N	03 Brake Electronics	Output Tests	
Audi TT	2004-2006	8N	03 Brake Electronics	Specia Functions	
Audi TT	2004-2006	8N	08 AC/Heating Electronics	Read Fault Codes	
Audi TT	2004-2006	8N	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT	2004-2006	8N	08 AC/Heating Electronics	Measuring Blocks	
Audi TT	2004-2006	8N	08 AC/Heating Electronics	Output Tests	
Audi TT	2004-2006	8N	08 AC/Heating Electronics	Specia Functions	
Audi TT	2004-2006	8N	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2004-2006	8N	11 Engine Electronics 2	Clear Fault Codes	
Audi TT	2004-2006	8N	11 Engine Electronics 2	Measuring Blocks	
Audi TT	2004-2006	8N	11 Engine Electronics 2	Output Tests	
Audi TT	2004-2006	8N	11 Engine Electronics 2	Specia Functions	
Audi TT	2004-2006	8N	15 Airbags	Read Fault Codes	
Audi TT	2004-2006	8N	15 Airbags	Clear Fault Codes	
Audi TT	2004-2006	8N	15 Airbags	Measuring Blocks	
Audi TT	2004-2006	8N	15 Airbags	Output Tests	
Audi TT	2004-2006	8N	15 Airbags	Specia Functions	
Audi TT	2004-2006	8N	17 Instrument Cluster	Read Fault Codes	
Audi TT	2004-2006	8N	17 Instrument Cluster	Clear Fault Codes	
Audi TT	2004-2006	8N	17 Instrument Cluster	Measuring Blocks	
Audi TT	2004-2006	8N	17 Instrument Cluster	Output Tests	
Audi TT	2004-2006	8N	17 Instrument Cluster	Specia Functions	
Audi TT	2004-2006	8N	22 4WD Electronics	Read Fault Codes	
Audi TT	2004-2006	8N	22 4WD Electronics	Clear Fault Codes	
Audi TT	2004-2006	8N	22 4WD Electronics	Measuring Blocks	
Audi TT	2004-2006	8N	22 4WD Electronics	Output Tests	
Audi TT	2004-2006	8N	22 4WD Electronics	Specia Functions	
Audi TT	2004-2006	8N	25 Immobilizer	Read Fault Codes	
Audi TT	2004-2006	8N	25 Immobilizer	Clear Fault Codes	
Audi TT	2004-2006	8N	25 Immobilizer	Measuring Blocks	
Audi TT	2004-2006	8N	25 Immobilizer	Output Tests	
Audi TT	2004-2006	8N	25 Immobilizer	Specia Functions	
Audi TT	2004-2006	8N	35 Central Locking	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2004-2006	8N	35 Central Locking	Clear Fault Codes	
Audi TT	2004-2006	8N	35 Central Locking	Measuring Blocks	
Audi TT	2004-2006	8N	35 Central Locking	Output Tests	
Audi TT	2004-2006	8N	35 Central Locking	Specia Functions	
Audi TT	2004-2006	8N	37 Navigation	Read Fault Codes	
Audi TT	2004-2006	8N	37 Navigation	Clear Fault Codes	
Audi TT	2004-2006	8N	37 Navigation	Measuring Blocks	
Audi TT	2004-2006	8N	37 Navigation	Output Tests	
Audi TT	2004-2006	8N	37 Navigation	Specia Functions	
Audi TT	2004-2006	8N	51 Electric Drive	Read Fault Codes	
Audi TT	2004-2006	8N	51 Electric Drive	Clear Fault Codes	
Audi TT	2004-2006	8N	51 Electric Drive	Measuring Blocks	
Audi TT	2004-2006	8N	51 Electric Drive	Output Tests	
Audi TT	2004-2006	8N	51 Electric Drive	Specia Functions	
Audi TT	2004-2006	8N	55 Headlight Range Control	Read Fault Codes	
Audi TT	2004-2006	8N	55 Headlight Range Control	Clear Fault Codes	
Audi TT	2004-2006	8N	55 Headlight Range Control	Measuring Blocks	
Audi TT	2004-2006	8N	55 Headlight Range Control	Output Tests	
Audi TT	2004-2006	8N	55 Headlight Range Control	Specia Functions	
Audi TT	2004-2006	8N	56 Radio	Read Fault Codes	
Audi TT	2004-2006	8N	56 Radio	Clear Fault Codes	
Audi TT	2004-2006	8N	56 Radio	Measuring Blocks	
Audi TT	2004-2006	8N	56 Radio	Output Tests	
Audi TT	2004-2006	8N	56 Radio	Specia Functions	
Audi TT	2004-2006	8N	76 Parking Aid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2004-2006	8N	76 Parking Aid	Clear Fault Codes	
Audi TT	2004-2006	8N	76 Parking Aid	Measuring Blocks	
Audi TT	2004-2006	8N	76 Parking Aid	Output Tests	
Audi TT	2004-2006	8N	76 Parking Aid	Specia Functions	
Audi TT	2004-2006	8N	77 Telephone	Read Fault Codes	
Audi TT	2004-2006	8N	77 Telephone	Clear Fault Codes	
Audi TT	2004-2006	8N	77 Telephone	Measuring Blocks	
Audi TT	2004-2006	8N	77 Telephone	Output Tests	
Audi TT	2004-2006	8N	77 Telephone	Specia Functions	
Audi TT	2004-2006	8N	8C Hybrid Battery	Read Fault Codes	
Audi TT	2004-2006	8N	8C Hybrid Battery	Clear Fault Codes	
Audi TT	2004-2006	8N	8C Hybrid Battery	Measuring Blocks	
Audi TT	2004-2006	8N	8C Hybrid Battery	Output Tests	
Audi TT	2004-2006	8N	8C Hybrid Battery	Specia Functions	
Audi TT	2007	8N	01 Engine Electronics	Read Fault Codes	
Audi TT	2007	8N	01 Engine Electronics	Clear Fault Codes	
Audi TT	2007	8N	01 Engine Electronics	Measuring Blocks	
Audi TT	2007	8N	01 Engine Electronics	Output Tests	
Audi TT	2007	8N	01 Engine Electronics	Specia Functions	
Audi TT	2007	8N	02 Transmission Electronics	Read Fault Codes	
Audi TT	2007	8N	02 Transmission Electronics	Clear Fault Codes	
Audi TT	2007	8N	02 Transmission Electronics	Measuring Blocks	
Audi TT	2007	8N	02 Transmission Electronics	Output Tests	
Audi TT	2007	8N	02 Transmission Electronics	Specia Functions	
Audi TT	2007	8N	03 Brake Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2007	8N	03 Brake Electronics	Clear Fault Codes	
Audi TT	2007	8N	03 Brake Electronics	Measuring Blocks	
Audi TT	2007	8N	03 Brake Electronics	Output Tests	
Audi TT	2007	8N	03 Brake Electronics	Specia Functions	
Audi TT	2007	8N	08 AC/Heating Electronics	Read Fault Codes	
Audi TT	2007	8N	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT	2007	8N	08 AC/Heating Electronics	Measuring Blocks	
Audi TT	2007	8N	08 AC/Heating Electronics	Output Tests	
Audi TT	2007	8N	08 AC/Heating Electronics	Specia Functions	
Audi TT	2007	8N	11 Engine Electronics 2	Read Fault Codes	
Audi TT	2007	8N	11 Engine Electronics 2	Clear Fault Codes	
Audi TT	2007	8N	11 Engine Electronics 2	Measuring Blocks	
Audi TT	2007	8N	11 Engine Electronics 2	Output Tests	
Audi TT	2007	8N	11 Engine Electronics 2	Specia Functions	
Audi TT	2007	8N	15 Airbags	Read Fault Codes	
Audi TT	2007	8N	15 Airbags	Clear Fault Codes	
Audi TT	2007	8N	15 Airbags	Measuring Blocks	
Audi TT	2007	8N	15 Airbags	Output Tests	
Audi TT	2007	8N	15 Airbags	Specia Functions	
Audi TT	2007	8N	17 Instrument Cluster	Read Fault Codes	
Audi TT	2007	8N	17 Instrument Cluster	Clear Fault Codes	
Audi TT	2007	8N	17 Instrument Cluster	Measuring Blocks	
Audi TT	2007	8N	17 Instrument Cluster	Output Tests	
Audi TT	2007	8N	17 Instrument Cluster	Specia Functions	
Audi TT	2007	8N	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2007	8N	22 4WD Electronics	Clear Fault Codes	
Audi TT	2007	8N	22 4WD Electronics	Measuring Blocks	
Audi TT	2007	8N	22 4WD Electronics	Output Tests	
Audi TT	2007	8N	22 4WD Electronics	Specia Functions	
Audi TT	2007	8N	25 Immobilizer	Read Fault Codes	
Audi TT	2007	8N	25 Immobilizer	Clear Fault Codes	
Audi TT	2007	8N	25 Immobilizer	Measuring Blocks	
Audi TT	2007	8N	25 Immobilizer	Output Tests	
Audi TT	2007	8N	25 Immobilizer	Specia Functions	
Audi TT	2007	8N	35 Central Locking	Read Fault Codes	
Audi TT	2007	8N	35 Central Locking	Clear Fault Codes	
Audi TT	2007	8N	35 Central Locking	Measuring Blocks	
Audi TT	2007	8N	35 Central Locking	Output Tests	
Audi TT	2007	8N	35 Central Locking	Specia Functions	
Audi TT	2007	8N	37 Navigation	Read Fault Codes	
Audi TT	2007	8N	37 Navigation	Clear Fault Codes	
Audi TT	2007	8N	37 Navigation	Measuring Blocks	
Audi TT	2007	8N	37 Navigation	Output Tests	
Audi TT	2007	8N	37 Navigation	Specia Functions	
Audi TT	2007	8N	51 Electric Drive	Read Fault Codes	
Audi TT	2007	8N	51 Electric Drive	Clear Fault Codes	
Audi TT	2007	8N	51 Electric Drive	Measuring Blocks	
Audi TT	2007	8N	51 Electric Drive	Output Tests	
Audi TT	2007	8N	51 Electric Drive	Specia Functions	
Audi TT	2007	8N	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2007	8N	55 Headlight Range Control	Clear Fault Codes	
Audi TT	2007	8N	55 Headlight Range Control	Measuring Blocks	
Audi TT	2007	8N	55 Headlight Range Control	Output Tests	
Audi TT	2007	8N	55 Headlight Range Control	Specia Functions	
Audi TT	2007	8N	56 Radio	Read Fault Codes	
Audi TT	2007	8N	56 Radio	Clear Fault Codes	
Audi TT	2007	8N	56 Radio	Measuring Blocks	
Audi TT	2007	8N	56 Radio	Output Tests	
Audi TT	2007	8N	56 Radio	Specia Functions	
Audi TT	2007	8N	76 Parking Aid	Read Fault Codes	
Audi TT	2007	8N	76 Parking Aid	Clear Fault Codes	
Audi TT	2007	8N	76 Parking Aid	Measuring Blocks	
Audi TT	2007	8N	76 Parking Aid	Output Tests	
Audi TT	2007	8N	76 Parking Aid	Specia Functions	
Audi TT	2007	8N	8C Hybrid Battery	Read Fault Codes	
Audi TT	2007	8N	8C Hybrid Battery	Clear Fault Codes	
Audi TT	2007	8N	8C Hybrid Battery	Measuring Blocks	
Audi TT	2007	8N	8C Hybrid Battery	Output Tests	
Audi TT	2007	8N	8C Hybrid Battery	Specia Functions	
Audi TT USA	2008	FK	01 Engine Electronics	Read Fault Codes	
Audi TT USA	2008	FK	01 Engine Electronics	Clear Fault Codes	
Audi TT USA	2008	FK	01 Engine Electronics	Measuring Blocks	
Audi TT USA	2008	FK	01 Engine Electronics	Output Tests	
Audi TT USA	2008	FK	01 Engine Electronics	Specia Functions	
Audi TT USA	2008	FK	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT USA	2008	FK	02 Transmission Electronics	Clear Fault Codes	
Audi TT USA	2008	FK	02 Transmission Electronics	Measuring Blocks	
Audi TT USA	2008	FK	02 Transmission Electronics	Output Tests	
Audi TT USA	2008	FK	02 Transmission Electronics	Specia Functions	
Audi TT USA	2008	FK	03 Brake Electronics	Read Fault Codes	
Audi TT USA	2008	FK	03 Brake Electronics	Clear Fault Codes	
Audi TT USA	2008	FK	03 Brake Electronics	Measuring Blocks	
Audi TT USA	2008	FK	03 Brake Electronics	Output Tests	
Audi TT USA	2008	FK	03 Brake Electronics	Specia Functions	
Audi TT USA	2008	FK	08 AC/Heating Electronics	Read Fault Codes	
Audi TT USA	2008	FK	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT USA	2008	FK	08 AC/Heating Electronics	Measuring Blocks	
Audi TT USA	2008	FK	08 AC/Heating Electronics	Output Tests	
Audi TT USA	2008	FK	08 AC/Heating Electronics	Specia Functions	
Audi TT USA	2008	FK	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi TT USA	2008	FK	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi TT USA	2008	FK	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi TT USA	2008	FK	09 Electronic Ctrl Electronics	Output Tests	
Audi TT USA	2008	FK	09 Electronic Ctrl Electronics	Specia Functions	
Audi TT USA	2008	FK	0F Radio Tuner-Digital	Read Fault Codes	
Audi TT USA	2008	FK	0F Radio Tuner-Digital	Clear Fault Codes	
Audi TT USA	2008	FK	0F Radio Tuner-Digital	Measuring Blocks	
Audi TT USA	2008	FK	0F Radio Tuner-Digital	Output Tests	
Audi TT USA	2008	FK	0F Radio Tuner-Digital	Specia Functions	
Audi TT USA	2008	FK	14 Wheel Damping Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT USA	2008	FK	14 Wheel Damping Electronics	Clear Fault Codes	
Audi TT USA	2008	FK	14 Wheel Damping Electronics	Measuring Blocks	
Audi TT USA	2008	FK	14 Wheel Damping Electronics	Output Tests	
Audi TT USA	2008	FK	14 Wheel Damping Electronics	Specia Functions	
Audi TT USA	2008	FK	15 Airbags	Read Fault Codes	
Audi TT USA	2008	FK	15 Airbags	Clear Fault Codes	
Audi TT USA	2008	FK	15 Airbags	Measuring Blocks	
Audi TT USA	2008	FK	15 Airbags	Output Tests	
Audi TT USA	2008	FK	15 Airbags	Specia Functions	
Audi TT USA	2008	FK	16 Steering Wheel Electronics	Read Fault Codes	
Audi TT USA	2008	FK	16 Steering Wheel Electronics	Clear Fault Codes	
Audi TT USA	2008	FK	16 Steering Wheel Electronics	Measuring Blocks	
Audi TT USA	2008	FK	16 Steering Wheel Electronics	Output Tests	
Audi TT USA	2008	FK	16 Steering Wheel Electronics	Specia Functions	
Audi TT USA	2008	FK	17 Instrument Cluster	Read Fault Codes	
Audi TT USA	2008	FK	17 Instrument Cluster	Clear Fault Codes	
Audi TT USA	2008	FK	17 Instrument Cluster	Measuring Blocks	
Audi TT USA	2008	FK	17 Instrument Cluster	Output Tests	
Audi TT USA	2008	FK	17 Instrument Cluster	Specia Functions	
Audi TT USA	2008	FK	19 Gateway Data Bus	Read Fault Codes	
Audi TT USA	2008	FK	19 Gateway Data Bus	Clear Fault Codes	
Audi TT USA	2008	FK	19 Gateway Data Bus	Measuring Blocks	
Audi TT USA	2008	FK	19 Gateway Data Bus	Output Tests	
Audi TT USA	2008	FK	19 Gateway Data Bus	Specia Functions	
Audi TT USA	2008	FK	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT USA	2008	FK	22 4WD Electronics	Clear Fault Codes	
Audi TT USA	2008	FK	22 4WD Electronics	Measuring Blocks	
Audi TT USA	2008	FK	22 4WD Electronics	Output Tests	
Audi TT USA	2008	FK	22 4WD Electronics	Specia Functions	
Audi TT USA	2008	FK	25 Immobilizer	Read Fault Codes	
Audi TT USA	2008	FK	25 Immobilizer	Clear Fault Codes	
Audi TT USA	2008	FK	25 Immobilizer	Measuring Blocks	
Audi TT USA	2008	FK	25 Immobilizer	Output Tests	
Audi TT USA	2008	FK	25 Immobilizer	Specia Functions	
Audi TT USA	2008	FK	26 Electric Roof Control	Read Fault Codes	
Audi TT USA	2008	FK	26 Electric Roof Control	Clear Fault Codes	
Audi TT USA	2008	FK	26 Electric Roof Control	Measuring Blocks	
Audi TT USA	2008	FK	26 Electric Roof Control	Output Tests	
Audi TT USA	2008	FK	26 Electric Roof Control	Specia Functions	
Audi TT USA	2008	FK	37 Navigation	Read Fault Codes	
Audi TT USA	2008	FK	37 Navigation	Clear Fault Codes	
Audi TT USA	2008	FK	37 Navigation	Measuring Blocks	
Audi TT USA	2008	FK	37 Navigation	Output Tests	
Audi TT USA	2008	FK	37 Navigation	Specia Functions	
Audi TT USA	2008	FK	42 Driver-Door Elect.	Read Fault Codes	
Audi TT USA	2008	FK	42 Driver-Door Elect.	Clear Fault Codes	
Audi TT USA	2008	FK	42 Driver-Door Elect.	Measuring Blocks	
Audi TT USA	2008	FK	42 Driver-Door Elect.	Output Tests	
Audi TT USA	2008	FK	42 Driver-Door Elect.	Specia Functions	
Audi TT USA	2008	FK	44 Steering Assistance	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT USA	2008	FK	44 Steering Assistance	Clear Fault Codes	
Audi TT USA	2008	FK	44 Steering Assistance	Measuring Blocks	
Audi TT USA	2008	FK	44 Steering Assistance	Output Tests	
Audi TT USA	2008	FK	44 Steering Assistance	Specia Functions	
Audi TT USA	2008	FK	46 Central Control Module	Read Fault Codes	
Audi TT USA	2008	FK	46 Central Control Module	Clear Fault Codes	
Audi TT USA	2008	FK	46 Central Control Module	Measuring Blocks	
Audi TT USA	2008	FK	46 Central Control Module	Output Tests	
Audi TT USA	2008	FK	46 Central Control Module	Specia Functions	
Audi TT USA	2008	FK	47 Soundsystem	Read Fault Codes	
Audi TT USA	2008	FK	47 Soundsystem	Clear Fault Codes	
Audi TT USA	2008	FK	47 Soundsystem	Measuring Blocks	
Audi TT USA	2008	FK	47 Soundsystem	Output Tests	
Audi TT USA	2008	FK	47 Soundsystem	Specia Functions	
Audi TT USA	2008	FK	4C Tyre Pressure Monitor II	Read Fault Codes	
Audi TT USA	2008	FK	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi TT USA	2008	FK	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi TT USA	2008	FK	4C Tyre Pressure Monitor II	Output Tests	
Audi TT USA	2008	FK	4C Tyre Pressure Monitor II	Specia Functions	
Audi TT USA	2008	FK	52 Passe.-Door Elect.	Read Fault Codes	
Audi TT USA	2008	FK	52 Passe.-Door Elect.	Clear Fault Codes	
Audi TT USA	2008	FK	52 Passe.-Door Elect.	Measuring Blocks	
Audi TT USA	2008	FK	52 Passe.-Door Elect.	Output Tests	
Audi TT USA	2008	FK	52 Passe.-Door Elect.	Specia Functions	
Audi TT USA	2008	FK	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT USA	2008	FK	55 Headlight Range Control	Clear Fault Codes	
Audi TT USA	2008	FK	55 Headlight Range Control	Measuring Blocks	
Audi TT USA	2008	FK	55 Headlight Range Control	Output Tests	
Audi TT USA	2008	FK	55 Headlight Range Control	Specia Functions	
Audi TT USA	2008	FK	56 Radio	Read Fault Codes	
Audi TT USA	2008	FK	56 Radio	Clear Fault Codes	
Audi TT USA	2008	FK	56 Radio	Measuring Blocks	
Audi TT USA	2008	FK	56 Radio	Output Tests	
Audi TT USA	2008	FK	56 Radio	Specia Functions	
Audi TT USA	2008	FK	57 TV-Tuner	Read Fault Codes	
Audi TT USA	2008	FK	57 TV-Tuner	Clear Fault Codes	
Audi TT USA	2008	FK	57 TV-Tuner	Measuring Blocks	
Audi TT USA	2008	FK	57 TV-Tuner	Output Tests	
Audi TT USA	2008	FK	57 TV-Tuner	Specia Functions	
Audi TT USA	2008	FK	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi TT USA	2008	FK	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi TT USA	2008	FK	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi TT USA	2008	FK	65 Tyre Pressure Monitoring	Output Tests	
Audi TT USA	2008	FK	65 Tyre Pressure Monitoring	Specia Functions	
Audi TT USA	2008	FK	76 Parking Aid	Read Fault Codes	
Audi TT USA	2008	FK	76 Parking Aid	Clear Fault Codes	
Audi TT USA	2008	FK	76 Parking Aid	Measuring Blocks	
Audi TT USA	2008	FK	76 Parking Aid	Output Tests	
Audi TT USA	2008	FK	76 Parking Aid	Specia Functions	
Audi TT USA	2008	FK	77 Telephone	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT USA	2008	FK	77 Telephone	Clear Fault Codes	
Audi TT USA	2008	FK	77 Telephone	Measuring Blocks	
Audi TT USA	2008	FK	77 Telephone	Output Tests	
Audi TT USA	2008	FK	77 Telephone	Specia Functions	
Audi A2	1999-2001	8Z	01 Engine Electronics	Read Fault Codes	
Audi A2	1999-2001	8Z	01 Engine Electronics	Clear Fault Codes	
Audi A2	1999-2001	8Z	01 Engine Electronics	Measuring Blocks	
Audi A2	1999-2001	8Z	01 Engine Electronics	Output Tests	
Audi A2	1999-2001	8Z	01 Engine Electronics	Specia Functions	
Audi A2	1999-2001	8Z	02 Transmission Electronics	Read Fault Codes	
Audi A2	1999-2001	8Z	02 Transmission Electronics	Clear Fault Codes	
Audi A2	1999-2001	8Z	02 Transmission Electronics	Measuring Blocks	
Audi A2	1999-2001	8Z	02 Transmission Electronics	Output Tests	
Audi A2	1999-2001	8Z	02 Transmission Electronics	Specia Functions	
Audi A2	1999-2001	8Z	03 Brake Electronics	Read Fault Codes	
Audi A2	1999-2001	8Z	03 Brake Electronics	Clear Fault Codes	
Audi A2	1999-2001	8Z	03 Brake Electronics	Measuring Blocks	
Audi A2	1999-2001	8Z	03 Brake Electronics	Output Tests	
Audi A2	1999-2001	8Z	03 Brake Electronics	Specia Functions	
Audi A2	1999-2001	8Z	08 AC/Heating Electronics	Read Fault Codes	
Audi A2	1999-2001	8Z	08 AC/Heating Electronics	Clear Fault Codes	
Audi A2	1999-2001	8Z	08 AC/Heating Electronics	Measuring Blocks	
Audi A2	1999-2001	8Z	08 AC/Heating Electronics	Output Tests	
Audi A2	1999-2001	8Z	08 AC/Heating Electronics	Specia Functions	
Audi A2	1999-2001	8Z	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	1999-2001	8Z	11 Engine Electronics 2	Clear Fault Codes	
Audi A2	1999-2001	8Z	11 Engine Electronics 2	Measuring Blocks	
Audi A2	1999-2001	8Z	11 Engine Electronics 2	Output Tests	
Audi A2	1999-2001	8Z	11 Engine Electronics 2	Specia Functions	
Audi A2	1999-2001	8Z	15 Airbags	Read Fault Codes	
Audi A2	1999-2001	8Z	15 Airbags	Clear Fault Codes	
Audi A2	1999-2001	8Z	15 Airbags	Measuring Blocks	
Audi A2	1999-2001	8Z	15 Airbags	Output Tests	
Audi A2	1999-2001	8Z	15 Airbags	Specia Functions	
Audi A2	1999-2001	8Z	16 Steering Wheel Electronics	Read Fault Codes	
Audi A2	1999-2001	8Z	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A2	1999-2001	8Z	16 Steering Wheel Electronics	Measuring Blocks	
Audi A2	1999-2001	8Z	16 Steering Wheel Electronics	Output Tests	
Audi A2	1999-2001	8Z	16 Steering Wheel Electronics	Specia Functions	
Audi A2	1999-2001	8Z	17 Instrument Cluster	Read Fault Codes	
Audi A2	1999-2001	8Z	17 Instrument Cluster	Clear Fault Codes	
Audi A2	1999-2001	8Z	17 Instrument Cluster	Measuring Blocks	
Audi A2	1999-2001	8Z	17 Instrument Cluster	Output Tests	
Audi A2	1999-2001	8Z	17 Instrument Cluster	Specia Functions	
Audi A2	1999-2001	8Z	37 Navigation	Read Fault Codes	
Audi A2	1999-2001	8Z	37 Navigation	Clear Fault Codes	
Audi A2	1999-2001	8Z	37 Navigation	Measuring Blocks	
Audi A2	1999-2001	8Z	37 Navigation	Output Tests	
Audi A2	1999-2001	8Z	37 Navigation	Specia Functions	
Audi A2	1999-2001	8Z	45 Interior Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	1999-2001	8Z	45 Interior Monitoring	Clear Fault Codes	
Audi A2	1999-2001	8Z	45 Interior Monitoring	Measuring Blocks	
Audi A2	1999-2001	8Z	45 Interior Monitoring	Output Tests	
Audi A2	1999-2001	8Z	45 Interior Monitoring	Specia Functions	
Audi A2	1999-2001	8Z	46 Central Control Module	Read Fault Codes	
Audi A2	1999-2001	8Z	46 Central Control Module	Clear Fault Codes	
Audi A2	1999-2001	8Z	46 Central Control Module	Measuring Blocks	
Audi A2	1999-2001	8Z	46 Central Control Module	Output Tests	
Audi A2	1999-2001	8Z	46 Central Control Module	Specia Functions	
Audi A2	1999-2001	8Z	51 Electric Drive	Read Fault Codes	
Audi A2	1999-2001	8Z	51 Electric Drive	Clear Fault Codes	
Audi A2	1999-2001	8Z	51 Electric Drive	Measuring Blocks	
Audi A2	1999-2001	8Z	51 Electric Drive	Output Tests	
Audi A2	1999-2001	8Z	51 Electric Drive	Specia Functions	
Audi A2	1999-2001	8Z	56 Radio	Read Fault Codes	
Audi A2	1999-2001	8Z	56 Radio	Clear Fault Codes	
Audi A2	1999-2001	8Z	56 Radio	Measuring Blocks	
Audi A2	1999-2001	8Z	56 Radio	Output Tests	
Audi A2	1999-2001	8Z	56 Radio	Specia Functions	
Audi A2	1999-2001	8Z	75 Emergency Call Module	Read Fault Codes	
Audi A2	1999-2001	8Z	75 Emergency Call Module	Clear Fault Codes	
Audi A2	1999-2001	8Z	75 Emergency Call Module	Measuring Blocks	
Audi A2	1999-2001	8Z	75 Emergency Call Module	Output Tests	
Audi A2	1999-2001	8Z	75 Emergency Call Module	Specia Functions	
Audi A2	1999-2001	8Z	76 Parking Aid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	1999-2001	8Z	76 Parking Aid	Clear Fault Codes	
Audi A2	1999-2001	8Z	76 Parking Aid	Measuring Blocks	
Audi A2	1999-2001	8Z	76 Parking Aid	Output Tests	
Audi A2	1999-2001	8Z	76 Parking Aid	Specia Functions	
Audi A2	1999-2001	8Z	8C Hybrid Battery	Read Fault Codes	
Audi A2	1999-2001	8Z	8C Hybrid Battery	Clear Fault Codes	
Audi A2	1999-2001	8Z	8C Hybrid Battery	Measuring Blocks	
Audi A2	1999-2001	8Z	8C Hybrid Battery	Output Tests	
Audi A2	1999-2001	8Z	8C Hybrid Battery	Specia Functions	
Audi A2	2002	8Z	01 Engine Electronics	Read Fault Codes	
Audi A2	2002	8Z	01 Engine Electronics	Clear Fault Codes	
Audi A2	2002	8Z	01 Engine Electronics	Measuring Blocks	
Audi A2	2002	8Z	01 Engine Electronics	Output Tests	
Audi A2	2002	8Z	01 Engine Electronics	Specia Functions	
Audi A2	2002	8Z	02 Transmission Electronics	Read Fault Codes	
Audi A2	2002	8Z	02 Transmission Electronics	Clear Fault Codes	
Audi A2	2002	8Z	02 Transmission Electronics	Measuring Blocks	
Audi A2	2002	8Z	02 Transmission Electronics	Output Tests	
Audi A2	2002	8Z	02 Transmission Electronics	Specia Functions	
Audi A2	2002	8Z	03 Brake Electronics	Read Fault Codes	
Audi A2	2002	8Z	03 Brake Electronics	Clear Fault Codes	
Audi A2	2002	8Z	03 Brake Electronics	Measuring Blocks	
Audi A2	2002	8Z	03 Brake Electronics	Output Tests	
Audi A2	2002	8Z	03 Brake Electronics	Specia Functions	
Audi A2	2002	8Z	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	2002	8Z	08 AC/Heating Electronics	Clear Fault Codes	
Audi A2	2002	8Z	08 AC/Heating Electronics	Measuring Blocks	
Audi A2	2002	8Z	08 AC/Heating Electronics	Output Tests	
Audi A2	2002	8Z	08 AC/Heating Electronics	Specia Functions	
Audi A2	2002	8Z	11 Engine Electronics 2	Read Fault Codes	
Audi A2	2002	8Z	11 Engine Electronics 2	Clear Fault Codes	
Audi A2	2002	8Z	11 Engine Electronics 2	Measuring Blocks	
Audi A2	2002	8Z	11 Engine Electronics 2	Output Tests	
Audi A2	2002	8Z	11 Engine Electronics 2	Specia Functions	
Audi A2	2002	8Z	15 Airbags	Read Fault Codes	
Audi A2	2002	8Z	15 Airbags	Clear Fault Codes	
Audi A2	2002	8Z	15 Airbags	Measuring Blocks	
Audi A2	2002	8Z	15 Airbags	Output Tests	
Audi A2	2002	8Z	15 Airbags	Specia Functions	
Audi A2	2002	8Z	16 Steering Wheel Electronics	Read Fault Codes	
Audi A2	2002	8Z	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A2	2002	8Z	16 Steering Wheel Electronics	Measuring Blocks	
Audi A2	2002	8Z	16 Steering Wheel Electronics	Output Tests	
Audi A2	2002	8Z	16 Steering Wheel Electronics	Specia Functions	
Audi A2	2002	8Z	17 Instrument Cluster	Read Fault Codes	
Audi A2	2002	8Z	17 Instrument Cluster	Clear Fault Codes	
Audi A2	2002	8Z	17 Instrument Cluster	Measuring Blocks	
Audi A2	2002	8Z	17 Instrument Cluster	Output Tests	
Audi A2	2002	8Z	17 Instrument Cluster	Specia Functions	
Audi A2	2002	8Z	37 Navigation	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	2002	8Z	37 Navigation	Clear Fault Codes	
Audi A2	2002	8Z	37 Navigation	Measuring Blocks	
Audi A2	2002	8Z	37 Navigation	Output Tests	
Audi A2	2002	8Z	37 Navigation	Specia Functions	
Audi A2	2002	8Z	45 Interior Monitoring	Read Fault Codes	
Audi A2	2002	8Z	45 Interior Monitoring	Clear Fault Codes	
Audi A2	2002	8Z	45 Interior Monitoring	Measuring Blocks	
Audi A2	2002	8Z	45 Interior Monitoring	Output Tests	
Audi A2	2002	8Z	45 Interior Monitoring	Specia Functions	
Audi A2	2002	8Z	46 Central Control Module	Read Fault Codes	
Audi A2	2002	8Z	46 Central Control Module	Clear Fault Codes	
Audi A2	2002	8Z	46 Central Control Module	Measuring Blocks	
Audi A2	2002	8Z	46 Central Control Module	Output Tests	
Audi A2	2002	8Z	46 Central Control Module	Specia Functions	
Audi A2	2002	8Z	51 Electric Drive	Read Fault Codes	
Audi A2	2002	8Z	51 Electric Drive	Clear Fault Codes	
Audi A2	2002	8Z	51 Electric Drive	Measuring Blocks	
Audi A2	2002	8Z	51 Electric Drive	Output Tests	
Audi A2	2002	8Z	51 Electric Drive	Specia Functions	
Audi A2	2002	8Z	56 Radio	Read Fault Codes	
Audi A2	2002	8Z	56 Radio	Clear Fault Codes	
Audi A2	2002	8Z	56 Radio	Measuring Blocks	
Audi A2	2002	8Z	56 Radio	Output Tests	
Audi A2	2002	8Z	56 Radio	Specia Functions	
Audi A2	2002	8Z	75 Emergency Call Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	2002	8Z	75 Emergency Call Module	Clear Fault Codes	
Audi A2	2002	8Z	75 Emergency Call Module	Measuring Blocks	
Audi A2	2002	8Z	75 Emergency Call Module	Output Tests	
Audi A2	2002	8Z	75 Emergency Call Module	Specia Functions	
Audi A2	2002	8Z	76 Parking Aid	Read Fault Codes	
Audi A2	2002	8Z	76 Parking Aid	Clear Fault Codes	
Audi A2	2002	8Z	76 Parking Aid	Measuring Blocks	
Audi A2	2002	8Z	76 Parking Aid	Output Tests	
Audi A2	2002	8Z	76 Parking Aid	Specia Functions	
Audi A2	2002	8Z	77 Telephone	Read Fault Codes	
Audi A2	2002	8Z	77 Telephone	Clear Fault Codes	
Audi A2	2002	8Z	77 Telephone	Measuring Blocks	
Audi A2	2002	8Z	77 Telephone	Output Tests	
Audi A2	2002	8Z	77 Telephone	Specia Functions	
Audi A2	2002	8Z	8C Hybrid Battery	Read Fault Codes	
Audi A2	2002	8Z	8C Hybrid Battery	Clear Fault Codes	
Audi A2	2002	8Z	8C Hybrid Battery	Measuring Blocks	
Audi A2	2002	8Z	8C Hybrid Battery	Output Tests	
Audi A2	2002	8Z	8C Hybrid Battery	Specia Functions	
Audi A2	2003-2004	8Z	01 Engine Electronics	Read Fault Codes	
Audi A2	2003-2004	8Z	01 Engine Electronics	Clear Fault Codes	
Audi A2	2003-2004	8Z	01 Engine Electronics	Measuring Blocks	
Audi A2	2003-2004	8Z	01 Engine Electronics	Output Tests	
Audi A2	2003-2004	8Z	01 Engine Electronics	Specia Functions	
Audi A2	2003-2004	8Z	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	2003-2004	8Z	02 Transmission Electronics	Clear Fault Codes	
Audi A2	2003-2004	8Z	02 Transmission Electronics	Measuring Blocks	
Audi A2	2003-2004	8Z	02 Transmission Electronics	Output Tests	
Audi A2	2003-2004	8Z	02 Transmission Electronics	Specia Functions	
Audi A2	2003-2004	8Z	03 Brake Electronics	Read Fault Codes	
Audi A2	2003-2004	8Z	03 Brake Electronics	Clear Fault Codes	
Audi A2	2003-2004	8Z	03 Brake Electronics	Measuring Blocks	
Audi A2	2003-2004	8Z	03 Brake Electronics	Output Tests	
Audi A2	2003-2004	8Z	03 Brake Electronics	Specia Functions	
Audi A2	2003-2004	8Z	08 AC/Heating Electronics	Read Fault Codes	
Audi A2	2003-2004	8Z	08 AC/Heating Electronics	Clear Fault Codes	
Audi A2	2003-2004	8Z	08 AC/Heating Electronics	Measuring Blocks	
Audi A2	2003-2004	8Z	08 AC/Heating Electronics	Output Tests	
Audi A2	2003-2004	8Z	08 AC/Heating Electronics	Specia Functions	
Audi A2	2003-2004	8Z	11 Engine Electronics 2	Read Fault Codes	
Audi A2	2003-2004	8Z	11 Engine Electronics 2	Clear Fault Codes	
Audi A2	2003-2004	8Z	11 Engine Electronics 2	Measuring Blocks	
Audi A2	2003-2004	8Z	11 Engine Electronics 2	Output Tests	
Audi A2	2003-2004	8Z	11 Engine Electronics 2	Specia Functions	
Audi A2	2003-2004	8Z	15 Airbags	Read Fault Codes	
Audi A2	2003-2004	8Z	15 Airbags	Clear Fault Codes	
Audi A2	2003-2004	8Z	15 Airbags	Measuring Blocks	
Audi A2	2003-2004	8Z	15 Airbags	Output Tests	
Audi A2	2003-2004	8Z	15 Airbags	Specia Functions	
Audi A2	2003-2004	8Z	16 Steering Wheel Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	2003-2004	8Z	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A2	2003-2004	8Z	16 Steering Wheel Electronics	Measuring Blocks	
Audi A2	2003-2004	8Z	16 Steering Wheel Electronics	Output Tests	
Audi A2	2003-2004	8Z	16 Steering Wheel Electronics	Specia Functions	
Audi A2	2003-2004	8Z	17 Instrument Cluster	Read Fault Codes	
Audi A2	2003-2004	8Z	17 Instrument Cluster	Clear Fault Codes	
Audi A2	2003-2004	8Z	17 Instrument Cluster	Measuring Blocks	
Audi A2	2003-2004	8Z	17 Instrument Cluster	Output Tests	
Audi A2	2003-2004	8Z	17 Instrument Cluster	Specia Functions	
Audi A2	2003-2004	8Z	37 Navigation	Read Fault Codes	
Audi A2	2003-2004	8Z	37 Navigation	Clear Fault Codes	
Audi A2	2003-2004	8Z	37 Navigation	Measuring Blocks	
Audi A2	2003-2004	8Z	37 Navigation	Output Tests	
Audi A2	2003-2004	8Z	37 Navigation	Specia Functions	
Audi A2	2003-2004	8Z	45 Interior Monitoring	Read Fault Codes	
Audi A2	2003-2004	8Z	45 Interior Monitoring	Clear Fault Codes	
Audi A2	2003-2004	8Z	45 Interior Monitoring	Measuring Blocks	
Audi A2	2003-2004	8Z	45 Interior Monitoring	Output Tests	
Audi A2	2003-2004	8Z	45 Interior Monitoring	Specia Functions	
Audi A2	2003-2004	8Z	46 Central Control Module	Read Fault Codes	
Audi A2	2003-2004	8Z	46 Central Control Module	Clear Fault Codes	
Audi A2	2003-2004	8Z	46 Central Control Module	Measuring Blocks	
Audi A2	2003-2004	8Z	46 Central Control Module	Output Tests	
Audi A2	2003-2004	8Z	46 Central Control Module	Specia Functions	
Audi A2	2003-2004	8Z	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	2003-2004	8Z	51 Electric Drive	Clear Fault Codes	
Audi A2	2003-2004	8Z	51 Electric Drive	Measuring Blocks	
Audi A2	2003-2004	8Z	51 Electric Drive	Output Tests	
Audi A2	2003-2004	8Z	51 Electric Drive	Specia Functions	
Audi A2	2003-2004	8Z	56 Radio	Read Fault Codes	
Audi A2	2003-2004	8Z	56 Radio	Clear Fault Codes	
Audi A2	2003-2004	8Z	56 Radio	Measuring Blocks	
Audi A2	2003-2004	8Z	56 Radio	Output Tests	
Audi A2	2003-2004	8Z	56 Radio	Specia Functions	
Audi A2	2003-2004	8Z	75 Emergency Call Module	Read Fault Codes	
Audi A2	2003-2004	8Z	75 Emergency Call Module	Clear Fault Codes	
Audi A2	2003-2004	8Z	75 Emergency Call Module	Measuring Blocks	
Audi A2	2003-2004	8Z	75 Emergency Call Module	Output Tests	
Audi A2	2003-2004	8Z	75 Emergency Call Module	Specia Functions	
Audi A2	2003-2004	8Z	76 Parking Aid	Read Fault Codes	
Audi A2	2003-2004	8Z	76 Parking Aid	Clear Fault Codes	
Audi A2	2003-2004	8Z	76 Parking Aid	Measuring Blocks	
Audi A2	2003-2004	8Z	76 Parking Aid	Output Tests	
Audi A2	2003-2004	8Z	76 Parking Aid	Specia Functions	
Audi A2	2003-2004	8Z	77 Telephone	Read Fault Codes	
Audi A2	2003-2004	8Z	77 Telephone	Clear Fault Codes	
Audi A2	2003-2004	8Z	77 Telephone	Measuring Blocks	
Audi A2	2003-2004	8Z	77 Telephone	Output Tests	
Audi A2	2003-2004	8Z	77 Telephone	Specia Functions	
Audi A2	2003-2004	8Z	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	2003-2004	8Z	8C Hybrid Battery	Clear Fault Codes	
Audi A2	2003-2004	8Z	8C Hybrid Battery	Measuring Blocks	
Audi A2	2003-2004	8Z	8C Hybrid Battery	Output Tests	
Audi A2	2003-2004	8Z	8C Hybrid Battery	Specia Functions	
Audi A2	2005-2006	8Z	01 Engine Electronics	Read Fault Codes	
Audi A2	2005-2006	8Z	01 Engine Electronics	Clear Fault Codes	
Audi A2	2005-2006	8Z	01 Engine Electronics	Measuring Blocks	
Audi A2	2005-2006	8Z	01 Engine Electronics	Output Tests	
Audi A2	2005-2006	8Z	01 Engine Electronics	Specia Functions	
Audi A2	2005-2006	8Z	02 Transmission Electronics	Read Fault Codes	
Audi A2	2005-2006	8Z	02 Transmission Electronics	Clear Fault Codes	
Audi A2	2005-2006	8Z	02 Transmission Electronics	Measuring Blocks	
Audi A2	2005-2006	8Z	02 Transmission Electronics	Output Tests	
Audi A2	2005-2006	8Z	02 Transmission Electronics	Specia Functions	
Audi A2	2005-2006	8Z	03 Brake Electronics	Read Fault Codes	
Audi A2	2005-2006	8Z	03 Brake Electronics	Clear Fault Codes	
Audi A2	2005-2006	8Z	03 Brake Electronics	Measuring Blocks	
Audi A2	2005-2006	8Z	03 Brake Electronics	Output Tests	
Audi A2	2005-2006	8Z	03 Brake Electronics	Specia Functions	
Audi A2	2005-2006	8Z	08 AC/Heating Electronics	Read Fault Codes	
Audi A2	2005-2006	8Z	08 AC/Heating Electronics	Clear Fault Codes	
Audi A2	2005-2006	8Z	08 AC/Heating Electronics	Measuring Blocks	
Audi A2	2005-2006	8Z	08 AC/Heating Electronics	Output Tests	
Audi A2	2005-2006	8Z	08 AC/Heating Electronics	Specia Functions	
Audi A2	2005-2006	8Z	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	2005-2006	8Z	11 Engine Electronics 2	Clear Fault Codes	
Audi A2	2005-2006	8Z	11 Engine Electronics 2	Measuring Blocks	
Audi A2	2005-2006	8Z	11 Engine Electronics 2	Output Tests	
Audi A2	2005-2006	8Z	11 Engine Electronics 2	Specia Functions	
Audi A2	2005-2006	8Z	15 Airbags	Read Fault Codes	
Audi A2	2005-2006	8Z	15 Airbags	Clear Fault Codes	
Audi A2	2005-2006	8Z	15 Airbags	Measuring Blocks	
Audi A2	2005-2006	8Z	15 Airbags	Output Tests	
Audi A2	2005-2006	8Z	15 Airbags	Specia Functions	
Audi A2	2005-2006	8Z	16 Steering Wheel Electronics	Read Fault Codes	
Audi A2	2005-2006	8Z	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A2	2005-2006	8Z	16 Steering Wheel Electronics	Measuring Blocks	
Audi A2	2005-2006	8Z	16 Steering Wheel Electronics	Output Tests	
Audi A2	2005-2006	8Z	16 Steering Wheel Electronics	Specia Functions	
Audi A2	2005-2006	8Z	17 Instrument Cluster	Read Fault Codes	
Audi A2	2005-2006	8Z	17 Instrument Cluster	Clear Fault Codes	
Audi A2	2005-2006	8Z	17 Instrument Cluster	Measuring Blocks	
Audi A2	2005-2006	8Z	17 Instrument Cluster	Output Tests	
Audi A2	2005-2006	8Z	17 Instrument Cluster	Specia Functions	
Audi A2	2005-2006	8Z	37 Navigation	Read Fault Codes	
Audi A2	2005-2006	8Z	37 Navigation	Clear Fault Codes	
Audi A2	2005-2006	8Z	37 Navigation	Measuring Blocks	
Audi A2	2005-2006	8Z	37 Navigation	Output Tests	
Audi A2	2005-2006	8Z	37 Navigation	Specia Functions	
Audi A2	2005-2006	8Z	45 Interior Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	2005-2006	8Z	45 Interior Monitoring	Clear Fault Codes	
Audi A2	2005-2006	8Z	45 Interior Monitoring	Measuring Blocks	
Audi A2	2005-2006	8Z	45 Interior Monitoring	Output Tests	
Audi A2	2005-2006	8Z	45 Interior Monitoring	Specia Functions	
Audi A2	2005-2006	8Z	46 Central Control Module	Read Fault Codes	
Audi A2	2005-2006	8Z	46 Central Control Module	Clear Fault Codes	
Audi A2	2005-2006	8Z	46 Central Control Module	Measuring Blocks	
Audi A2	2005-2006	8Z	46 Central Control Module	Output Tests	
Audi A2	2005-2006	8Z	46 Central Control Module	Specia Functions	
Audi A2	2005-2006	8Z	51 Electric Drive	Read Fault Codes	
Audi A2	2005-2006	8Z	51 Electric Drive	Clear Fault Codes	
Audi A2	2005-2006	8Z	51 Electric Drive	Measuring Blocks	
Audi A2	2005-2006	8Z	51 Electric Drive	Output Tests	
Audi A2	2005-2006	8Z	51 Electric Drive	Specia Functions	
Audi A2	2005-2006	8Z	56 Radio	Read Fault Codes	
Audi A2	2005-2006	8Z	56 Radio	Clear Fault Codes	
Audi A2	2005-2006	8Z	56 Radio	Measuring Blocks	
Audi A2	2005-2006	8Z	56 Radio	Output Tests	
Audi A2	2005-2006	8Z	56 Radio	Specia Functions	
Audi A2	2005-2006	8Z	76 Parking Aid	Read Fault Codes	
Audi A2	2005-2006	8Z	76 Parking Aid	Clear Fault Codes	
Audi A2	2005-2006	8Z	76 Parking Aid	Measuring Blocks	
Audi A2	2005-2006	8Z	76 Parking Aid	Output Tests	
Audi A2	2005-2006	8Z	76 Parking Aid	Specia Functions	
Audi A2	2005-2006	8Z	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A2	2005-2006	8Z	77 Telephone	Clear Fault Codes	
Audi A2	2005-2006	8Z	77 Telephone	Measuring Blocks	
Audi A2	2005-2006	8Z	77 Telephone	Output Tests	
Audi A2	2005-2006	8Z	77 Telephone	Specia Functions	
Audi A2	2005-2006	8Z	8C Hybrid Battery	Read Fault Codes	
Audi A2	2005-2006	8Z	8C Hybrid Battery	Clear Fault Codes	
Audi A2	2005-2006	8Z	8C Hybrid Battery	Measuring Blocks	
Audi A2	2005-2006	8Z	8C Hybrid Battery	Output Tests	
Audi A2	2005-2006	8Z	8C Hybrid Battery	Specia Functions	
Audi Cabriolet	2002-2003	8H	01 Engine Electronics	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	01 Engine Electronics	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	01 Engine Electronics	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	01 Engine Electronics	Output Tests	
Audi Cabriolet	2002-2003	8H	01 Engine Electronics	Specia Functions	
Audi Cabriolet	2002-2003	8H	02 Transmission Electronics	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	02 Transmission Electronics	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	02 Transmission Electronics	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	02 Transmission Electronics	Output Tests	
Audi Cabriolet	2002-2003	8H	02 Transmission Electronics	Specia Functions	
Audi Cabriolet	2002-2003	8H	03 Brake Electronics	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	03 Brake Electronics	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	03 Brake Electronics	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	03 Brake Electronics	Output Tests	
Audi Cabriolet	2002-2003	8H	03 Brake Electronics	Specia Functions	
Audi Cabriolet	2002-2003	8H	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2002-2003	8H	08 AC/Heating Electronics	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	08 AC/Heating Electronics	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	08 AC/Heating Electronics	Output Tests	
Audi Cabriolet	2002-2003	8H	08 AC/Heating Electronics	Specia Functions	
Audi Cabriolet	2002-2003	8H	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	09 Electronic Ctrl Electronics	Output Tests	
Audi Cabriolet	2002-2003	8H	09 Electronic Ctrl Electronics	Specia Functions	
Audi Cabriolet	2002-2003	8H	0F Radio Tuner-Digital	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	0F Radio Tuner-Digital	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	0F Radio Tuner-Digital	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	0F Radio Tuner-Digital	Output Tests	
Audi Cabriolet	2002-2003	8H	0F Radio Tuner-Digital	Specia Functions	
Audi Cabriolet	2002-2003	8H	11 Engine Electronics 2	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	11 Engine Electronics 2	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	11 Engine Electronics 2	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	11 Engine Electronics 2	Output Tests	
Audi Cabriolet	2002-2003	8H	11 Engine Electronics 2	Specia Functions	
Audi Cabriolet	2002-2003	8H	15 Airbags	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	15 Airbags	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	15 Airbags	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	15 Airbags	Output Tests	
Audi Cabriolet	2002-2003	8H	15 Airbags	Specia Functions	
Audi Cabriolet	2002-2003	8H	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2002-2003	8H	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	16 Steering Wheel Electronics	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	16 Steering Wheel Electronics	Output Tests	
Audi Cabriolet	2002-2003	8H	16 Steering Wheel Electronics	Specia Functions	
Audi Cabriolet	2002-2003	8H	17 Instrument Cluster	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	17 Instrument Cluster	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	17 Instrument Cluster	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	17 Instrument Cluster	Output Tests	
Audi Cabriolet	2002-2003	8H	17 Instrument Cluster	Specia Functions	
Audi Cabriolet	2002-2003	8H	18 Aux Heating	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	18 Aux Heating	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	18 Aux Heating	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	18 Aux Heating	Output Tests	
Audi Cabriolet	2002-2003	8H	18 Aux Heating	Specia Functions	
Audi Cabriolet	2002-2003	8H	25 Immobilizer	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	25 Immobilizer	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	25 Immobilizer	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	25 Immobilizer	Output Tests	
Audi Cabriolet	2002-2003	8H	25 Immobilizer	Specia Functions	
Audi Cabriolet	2002-2003	8H	26 Electric Roof Control	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	26 Electric Roof Control	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	26 Electric Roof Control	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	26 Electric Roof Control	Output Tests	
Audi Cabriolet	2002-2003	8H	26 Electric Roof Control	Specia Functions	
Audi Cabriolet	2002-2003	8H	36 Side of Driver Seat Adj.	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2002-2003	8H	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	36 Side of Driver Seat Adj.	Output Tests	
Audi Cabriolet	2002-2003	8H	36 Side of Driver Seat Adj.	Specia Functions	
Audi Cabriolet	2002-2003	8H	37 Navigation	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	37 Navigation	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	37 Navigation	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	37 Navigation	Output Tests	
Audi Cabriolet	2002-2003	8H	37 Navigation	Specia Functions	
Audi Cabriolet	2002-2003	8H	45 Interior Monitoring	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	45 Interior Monitoring	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	45 Interior Monitoring	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	45 Interior Monitoring	Output Tests	
Audi Cabriolet	2002-2003	8H	45 Interior Monitoring	Specia Functions	
Audi Cabriolet	2002-2003	8H	46 Central Control Module	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	46 Central Control Module	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	46 Central Control Module	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	46 Central Control Module	Output Tests	
Audi Cabriolet	2002-2003	8H	46 Central Control Module	Specia Functions	
Audi Cabriolet	2002-2003	8H	51 Electric Drive	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	51 Electric Drive	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	51 Electric Drive	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	51 Electric Drive	Output Tests	
Audi Cabriolet	2002-2003	8H	51 Electric Drive	Specia Functions	
Audi Cabriolet	2002-2003	8H	55 Headlight Range Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Cabriolet	2002-2003	8H	55 Headlight Range Control	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	55 Headlight Range Control	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	55 Headlight Range Control	Output Tests	
Audi Cabriolet	2002-2003	8H	55 Headlight Range Control	Specia Functions	
Audi Cabriolet	2002-2003	8H	56 Radio	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	56 Radio	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	56 Radio	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	56 Radio	Output Tests	
Audi Cabriolet	2002-2003	8H	56 Radio	Specia Functions	
Audi Cabriolet	2002-2003	8H	57 TV-Tuner	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	57 TV-Tuner	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	57 TV-Tuner	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	57 TV-Tuner	Output Tests	
Audi Cabriolet	2002-2003	8H	57 TV-Tuner	Specia Functions	
Audi Cabriolet	2002-2003	8H	63 Drvs Boarding Ass1	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	63 Drvs Boarding Ass1	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	63 Drvs Boarding Ass1	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	63 Drvs Boarding Ass1	Output Tests	
Audi Cabriolet	2002-2003	8H	63 Drvs Boarding Ass1	Specia Functions	
Audi Cabriolet	2002-2003	8H	67 Voice Control	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	67 Voice Control	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	67 Voice Control	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	67 Voice Control	Output Tests	
Audi Cabriolet	2002-2003	8H	67 Voice Control	Specia Functions	
Audi Cabriolet	2002-2003	8H	73 Drvs Boarding Ass2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2002-2003	8H	73 Drvs Boarding Ass2	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	73 Drvs Boarding Ass2	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	73 Drvs Boarding Ass2	Output Tests	
Audi Cabriolet	2002-2003	8H	73 Drvs Boarding Ass2	Specia Functions	
Audi Cabriolet	2002-2003	8H	75 Emergency Call Module	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	75 Emergency Call Module	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	75 Emergency Call Module	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	75 Emergency Call Module	Output Tests	
Audi Cabriolet	2002-2003	8H	75 Emergency Call Module	Specia Functions	
Audi Cabriolet	2002-2003	8H	76 Parking Aid	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	76 Parking Aid	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	76 Parking Aid	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	76 Parking Aid	Output Tests	
Audi Cabriolet	2002-2003	8H	76 Parking Aid	Specia Functions	
Audi Cabriolet	2002-2003	8H	77 Telephone	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	77 Telephone	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	77 Telephone	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	77 Telephone	Output Tests	
Audi Cabriolet	2002-2003	8H	77 Telephone	Specia Functions	
Audi Cabriolet	2002-2003	8H	8C Hybrid Battery	Read Fault Codes	
Audi Cabriolet	2002-2003	8H	8C Hybrid Battery	Clear Fault Codes	
Audi Cabriolet	2002-2003	8H	8C Hybrid Battery	Measuring Blocks	
Audi Cabriolet	2002-2003	8H	8C Hybrid Battery	Output Tests	
Audi Cabriolet	2002-2003	8H	8C Hybrid Battery	Specia Functions	
Audi Cabriolet	2004	8H	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2004	8H	01 Engine Electronics	Clear Fault Codes	
Audi Cabriolet	2004	8H	01 Engine Electronics	Measuring Blocks	
Audi Cabriolet	2004	8H	01 Engine Electronics	Output Tests	
Audi Cabriolet	2004	8H	01 Engine Electronics	Specia Functions	
Audi Cabriolet	2004	8H	02 Transmission Electronics	Read Fault Codes	
Audi Cabriolet	2004	8H	02 Transmission Electronics	Clear Fault Codes	
Audi Cabriolet	2004	8H	02 Transmission Electronics	Measuring Blocks	
Audi Cabriolet	2004	8H	02 Transmission Electronics	Output Tests	
Audi Cabriolet	2004	8H	02 Transmission Electronics	Specia Functions	
Audi Cabriolet	2004	8H	03 Brake Electronics	Read Fault Codes	
Audi Cabriolet	2004	8H	03 Brake Electronics	Clear Fault Codes	
Audi Cabriolet	2004	8H	03 Brake Electronics	Measuring Blocks	
Audi Cabriolet	2004	8H	03 Brake Electronics	Output Tests	
Audi Cabriolet	2004	8H	03 Brake Electronics	Specia Functions	
Audi Cabriolet	2004	8H	08 AC/Heating Electronics	Read Fault Codes	
Audi Cabriolet	2004	8H	08 AC/Heating Electronics	Clear Fault Codes	
Audi Cabriolet	2004	8H	08 AC/Heating Electronics	Measuring Blocks	
Audi Cabriolet	2004	8H	08 AC/Heating Electronics	Output Tests	
Audi Cabriolet	2004	8H	08 AC/Heating Electronics	Specia Functions	
Audi Cabriolet	2004	8H	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Cabriolet	2004	8H	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Cabriolet	2004	8H	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Cabriolet	2004	8H	09 Electronic Ctrl Electronics	Output Tests	
Audi Cabriolet	2004	8H	09 Electronic Ctrl Electronics	Specia Functions	
Audi Cabriolet	2004	8H	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2004	8H	0F Radio Tuner-Digital	Clear Fault Codes	
Audi Cabriolet	2004	8H	0F Radio Tuner-Digital	Measuring Blocks	
Audi Cabriolet	2004	8H	0F Radio Tuner-Digital	Output Tests	
Audi Cabriolet	2004	8H	0F Radio Tuner-Digital	Specia Functions	
Audi Cabriolet	2004	8H	11 Engine Electronics 2	Read Fault Codes	
Audi Cabriolet	2004	8H	11 Engine Electronics 2	Clear Fault Codes	
Audi Cabriolet	2004	8H	11 Engine Electronics 2	Measuring Blocks	
Audi Cabriolet	2004	8H	11 Engine Electronics 2	Output Tests	
Audi Cabriolet	2004	8H	11 Engine Electronics 2	Specia Functions	
Audi Cabriolet	2004	8H	15 Airbags	Read Fault Codes	
Audi Cabriolet	2004	8H	15 Airbags	Clear Fault Codes	
Audi Cabriolet	2004	8H	15 Airbags	Measuring Blocks	
Audi Cabriolet	2004	8H	15 Airbags	Output Tests	
Audi Cabriolet	2004	8H	15 Airbags	Specia Functions	
Audi Cabriolet	2004	8H	16 Steering Wheel Electronics	Read Fault Codes	
Audi Cabriolet	2004	8H	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Cabriolet	2004	8H	16 Steering Wheel Electronics	Measuring Blocks	
Audi Cabriolet	2004	8H	16 Steering Wheel Electronics	Output Tests	
Audi Cabriolet	2004	8H	16 Steering Wheel Electronics	Specia Functions	
Audi Cabriolet	2004	8H	17 Instrument Cluster	Read Fault Codes	
Audi Cabriolet	2004	8H	17 Instrument Cluster	Clear Fault Codes	
Audi Cabriolet	2004	8H	17 Instrument Cluster	Measuring Blocks	
Audi Cabriolet	2004	8H	17 Instrument Cluster	Output Tests	
Audi Cabriolet	2004	8H	17 Instrument Cluster	Specia Functions	
Audi Cabriolet	2004	8H	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2004	8H	18 Aux Heating	Clear Fault Codes	
Audi Cabriolet	2004	8H	18 Aux Heating	Measuring Blocks	
Audi Cabriolet	2004	8H	18 Aux Heating	Output Tests	
Audi Cabriolet	2004	8H	18 Aux Heating	Specia Functions	
Audi Cabriolet	2004	8H	25 Immobilizer	Read Fault Codes	
Audi Cabriolet	2004	8H	25 Immobilizer	Clear Fault Codes	
Audi Cabriolet	2004	8H	25 Immobilizer	Measuring Blocks	
Audi Cabriolet	2004	8H	25 Immobilizer	Output Tests	
Audi Cabriolet	2004	8H	25 Immobilizer	Specia Functions	
Audi Cabriolet	2004	8H	26 Electric Roof Control	Read Fault Codes	
Audi Cabriolet	2004	8H	26 Electric Roof Control	Clear Fault Codes	
Audi Cabriolet	2004	8H	26 Electric Roof Control	Measuring Blocks	
Audi Cabriolet	2004	8H	26 Electric Roof Control	Output Tests	
Audi Cabriolet	2004	8H	26 Electric Roof Control	Specia Functions	
Audi Cabriolet	2004	8H	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi Cabriolet	2004	8H	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Cabriolet	2004	8H	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Cabriolet	2004	8H	36 Side of Driver Seat Adj.	Output Tests	
Audi Cabriolet	2004	8H	36 Side of Driver Seat Adj.	Specia Functions	
Audi Cabriolet	2004	8H	37 Navigation	Read Fault Codes	
Audi Cabriolet	2004	8H	37 Navigation	Clear Fault Codes	
Audi Cabriolet	2004	8H	37 Navigation	Measuring Blocks	
Audi Cabriolet	2004	8H	37 Navigation	Output Tests	
Audi Cabriolet	2004	8H	37 Navigation	Specia Functions	
Audi Cabriolet	2004	8H	45 Interior Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2004	8H	45 Interior Monitoring	Clear Fault Codes	
Audi Cabriolet	2004	8H	45 Interior Monitoring	Measuring Blocks	
Audi Cabriolet	2004	8H	45 Interior Monitoring	Output Tests	
Audi Cabriolet	2004	8H	45 Interior Monitoring	Specia Functions	
Audi Cabriolet	2004	8H	46 Central Control Module	Read Fault Codes	
Audi Cabriolet	2004	8H	46 Central Control Module	Clear Fault Codes	
Audi Cabriolet	2004	8H	46 Central Control Module	Measuring Blocks	
Audi Cabriolet	2004	8H	46 Central Control Module	Output Tests	
Audi Cabriolet	2004	8H	46 Central Control Module	Specia Functions	
Audi Cabriolet	2004	8H	51 Electric Drive	Read Fault Codes	
Audi Cabriolet	2004	8H	51 Electric Drive	Clear Fault Codes	
Audi Cabriolet	2004	8H	51 Electric Drive	Measuring Blocks	
Audi Cabriolet	2004	8H	51 Electric Drive	Output Tests	
Audi Cabriolet	2004	8H	51 Electric Drive	Specia Functions	
Audi Cabriolet	2004	8H	55 Headlight Range Control	Read Fault Codes	
Audi Cabriolet	2004	8H	55 Headlight Range Control	Clear Fault Codes	
Audi Cabriolet	2004	8H	55 Headlight Range Control	Measuring Blocks	
Audi Cabriolet	2004	8H	55 Headlight Range Control	Output Tests	
Audi Cabriolet	2004	8H	55 Headlight Range Control	Specia Functions	
Audi Cabriolet	2004	8H	56 Radio	Read Fault Codes	
Audi Cabriolet	2004	8H	56 Radio	Clear Fault Codes	
Audi Cabriolet	2004	8H	56 Radio	Measuring Blocks	
Audi Cabriolet	2004	8H	56 Radio	Output Tests	
Audi Cabriolet	2004	8H	56 Radio	Specia Functions	
Audi Cabriolet	2004	8H	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2004	8H	57 TV-Tuner	Clear Fault Codes	
Audi Cabriolet	2004	8H	57 TV-Tuner	Measuring Blocks	
Audi Cabriolet	2004	8H	57 TV-Tuner	Output Tests	
Audi Cabriolet	2004	8H	57 TV-Tuner	Specia Functions	
Audi Cabriolet	2004	8H	63 Drvs Boarding Ass1	Read Fault Codes	
Audi Cabriolet	2004	8H	63 Drvs Boarding Ass1	Clear Fault Codes	
Audi Cabriolet	2004	8H	63 Drvs Boarding Ass1	Measuring Blocks	
Audi Cabriolet	2004	8H	63 Drvs Boarding Ass1	Output Tests	
Audi Cabriolet	2004	8H	63 Drvs Boarding Ass1	Specia Functions	
Audi Cabriolet	2004	8H	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Cabriolet	2004	8H	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Cabriolet	2004	8H	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Cabriolet	2004	8H	65 Tyre Pressure Monitoring	Output Tests	
Audi Cabriolet	2004	8H	65 Tyre Pressure Monitoring	Specia Functions	
Audi Cabriolet	2004	8H	67 Voice Control	Read Fault Codes	
Audi Cabriolet	2004	8H	67 Voice Control	Clear Fault Codes	
Audi Cabriolet	2004	8H	67 Voice Control	Measuring Blocks	
Audi Cabriolet	2004	8H	67 Voice Control	Output Tests	
Audi Cabriolet	2004	8H	67 Voice Control	Specia Functions	
Audi Cabriolet	2004	8H	73 Drvs Boarding Ass2	Read Fault Codes	
Audi Cabriolet	2004	8H	73 Drvs Boarding Ass2	Clear Fault Codes	
Audi Cabriolet	2004	8H	73 Drvs Boarding Ass2	Measuring Blocks	
Audi Cabriolet	2004	8H	73 Drvs Boarding Ass2	Output Tests	
Audi Cabriolet	2004	8H	73 Drvs Boarding Ass2	Specia Functions	
Audi Cabriolet	2004	8H	75 Emergency Call Module	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2004	8H	75 Emergency Call Module	Clear Fault Codes	
Audi Cabriolet	2004	8H	75 Emergency Call Module	Measuring Blocks	
Audi Cabriolet	2004	8H	75 Emergency Call Module	Output Tests	
Audi Cabriolet	2004	8H	75 Emergency Call Module	Specia Functions	
Audi Cabriolet	2004	8H	76 Parking Aid	Read Fault Codes	
Audi Cabriolet	2004	8H	76 Parking Aid	Clear Fault Codes	
Audi Cabriolet	2004	8H	76 Parking Aid	Measuring Blocks	
Audi Cabriolet	2004	8H	76 Parking Aid	Output Tests	
Audi Cabriolet	2004	8H	76 Parking Aid	Specia Functions	
Audi Cabriolet	2004	8H	77 Telephone	Read Fault Codes	
Audi Cabriolet	2004	8H	77 Telephone	Clear Fault Codes	
Audi Cabriolet	2004	8H	77 Telephone	Measuring Blocks	
Audi Cabriolet	2004	8H	77 Telephone	Output Tests	
Audi Cabriolet	2004	8H	77 Telephone	Specia Functions	
Audi Cabriolet	2004	8H	8C Hybrid Battery	Read Fault Codes	
Audi Cabriolet	2004	8H	8C Hybrid Battery	Clear Fault Codes	
Audi Cabriolet	2004	8H	8C Hybrid Battery	Measuring Blocks	
Audi Cabriolet	2004	8H	8C Hybrid Battery	Output Tests	
Audi Cabriolet	2004	8H	8C Hybrid Battery	Specia Functions	
Audi Cabriolet	2005	8H	01 Engine Electronics	Read Fault Codes	
Audi Cabriolet	2005	8H	01 Engine Electronics	Clear Fault Codes	
Audi Cabriolet	2005	8H	01 Engine Electronics	Measuring Blocks	
Audi Cabriolet	2005	8H	01 Engine Electronics	Output Tests	
Audi Cabriolet	2005	8H	01 Engine Electronics	Specia Functions	
Audi Cabriolet	2005	8H	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2005	8H	02 Transmission Electronics	Clear Fault Codes	
Audi Cabriolet	2005	8H	02 Transmission Electronics	Measuring Blocks	
Audi Cabriolet	2005	8H	02 Transmission Electronics	Output Tests	
Audi Cabriolet	2005	8H	02 Transmission Electronics	Specia Functions	
Audi Cabriolet	2005	8H	03 Brake Electronics	Read Fault Codes	
Audi Cabriolet	2005	8H	03 Brake Electronics	Clear Fault Codes	
Audi Cabriolet	2005	8H	03 Brake Electronics	Measuring Blocks	
Audi Cabriolet	2005	8H	03 Brake Electronics	Output Tests	
Audi Cabriolet	2005	8H	03 Brake Electronics	Specia Functions	
Audi Cabriolet	2005	8H	08 AC/Heating Electronics	Read Fault Codes	
Audi Cabriolet	2005	8H	08 AC/Heating Electronics	Clear Fault Codes	
Audi Cabriolet	2005	8H	08 AC/Heating Electronics	Measuring Blocks	
Audi Cabriolet	2005	8H	08 AC/Heating Electronics	Output Tests	
Audi Cabriolet	2005	8H	08 AC/Heating Electronics	Specia Functions	
Audi Cabriolet	2005	8H	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Cabriolet	2005	8H	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Cabriolet	2005	8H	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Cabriolet	2005	8H	09 Electronic Ctrl Electronics	Output Tests	
Audi Cabriolet	2005	8H	09 Electronic Ctrl Electronics	Specia Functions	
Audi Cabriolet	2005	8H	0F Radio Tuner-Digital	Read Fault Codes	
Audi Cabriolet	2005	8H	0F Radio Tuner-Digital	Clear Fault Codes	
Audi Cabriolet	2005	8H	0F Radio Tuner-Digital	Measuring Blocks	
Audi Cabriolet	2005	8H	0F Radio Tuner-Digital	Output Tests	
Audi Cabriolet	2005	8H	0F Radio Tuner-Digital	Specia Functions	
Audi Cabriolet	2005	8H	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2005	8H	11 Engine Electronics 2	Clear Fault Codes	
Audi Cabriolet	2005	8H	11 Engine Electronics 2	Measuring Blocks	
Audi Cabriolet	2005	8H	11 Engine Electronics 2	Output Tests	
Audi Cabriolet	2005	8H	11 Engine Electronics 2	Specia Functions	
Audi Cabriolet	2005	8H	15 Airbags	Read Fault Codes	
Audi Cabriolet	2005	8H	15 Airbags	Clear Fault Codes	
Audi Cabriolet	2005	8H	15 Airbags	Measuring Blocks	
Audi Cabriolet	2005	8H	15 Airbags	Output Tests	
Audi Cabriolet	2005	8H	15 Airbags	Specia Functions	
Audi Cabriolet	2005	8H	16 Steering Wheel Electronics	Read Fault Codes	
Audi Cabriolet	2005	8H	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Cabriolet	2005	8H	16 Steering Wheel Electronics	Measuring Blocks	
Audi Cabriolet	2005	8H	16 Steering Wheel Electronics	Output Tests	
Audi Cabriolet	2005	8H	16 Steering Wheel Electronics	Specia Functions	
Audi Cabriolet	2005	8H	17 Instrument Cluster	Read Fault Codes	
Audi Cabriolet	2005	8H	17 Instrument Cluster	Clear Fault Codes	
Audi Cabriolet	2005	8H	17 Instrument Cluster	Measuring Blocks	
Audi Cabriolet	2005	8H	17 Instrument Cluster	Output Tests	
Audi Cabriolet	2005	8H	17 Instrument Cluster	Specia Functions	
Audi Cabriolet	2005	8H	18 Aux Heating	Read Fault Codes	
Audi Cabriolet	2005	8H	18 Aux Heating	Clear Fault Codes	
Audi Cabriolet	2005	8H	18 Aux Heating	Measuring Blocks	
Audi Cabriolet	2005	8H	18 Aux Heating	Output Tests	
Audi Cabriolet	2005	8H	18 Aux Heating	Specia Functions	
Audi Cabriolet	2005	8H	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2005	8H	25 Immobilizer	Clear Fault Codes	
Audi Cabriolet	2005	8H	25 Immobilizer	Measuring Blocks	
Audi Cabriolet	2005	8H	25 Immobilizer	Output Tests	
Audi Cabriolet	2005	8H	25 Immobilizer	Specia Functions	
Audi Cabriolet	2005	8H	26 Electric Roof Control	Read Fault Codes	
Audi Cabriolet	2005	8H	26 Electric Roof Control	Clear Fault Codes	
Audi Cabriolet	2005	8H	26 Electric Roof Control	Measuring Blocks	
Audi Cabriolet	2005	8H	26 Electric Roof Control	Output Tests	
Audi Cabriolet	2005	8H	26 Electric Roof Control	Specia Functions	
Audi Cabriolet	2005	8H	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi Cabriolet	2005	8H	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Cabriolet	2005	8H	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Cabriolet	2005	8H	36 Side of Driver Seat Adj.	Output Tests	
Audi Cabriolet	2005	8H	36 Side of Driver Seat Adj.	Specia Functions	
Audi Cabriolet	2005	8H	37 Navigation	Read Fault Codes	
Audi Cabriolet	2005	8H	37 Navigation	Clear Fault Codes	
Audi Cabriolet	2005	8H	37 Navigation	Measuring Blocks	
Audi Cabriolet	2005	8H	37 Navigation	Output Tests	
Audi Cabriolet	2005	8H	37 Navigation	Specia Functions	
Audi Cabriolet	2005	8H	45 Interior Monitoring	Read Fault Codes	
Audi Cabriolet	2005	8H	45 Interior Monitoring	Clear Fault Codes	
Audi Cabriolet	2005	8H	45 Interior Monitoring	Measuring Blocks	
Audi Cabriolet	2005	8H	45 Interior Monitoring	Output Tests	
Audi Cabriolet	2005	8H	45 Interior Monitoring	Specia Functions	
Audi Cabriolet	2005	8H	46 Central Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2005	8H	46 Central Control Module	Clear Fault Codes	
Audi Cabriolet	2005	8H	46 Central Control Module	Measuring Blocks	
Audi Cabriolet	2005	8H	46 Central Control Module	Output Tests	
Audi Cabriolet	2005	8H	46 Central Control Module	Specia Functions	
Audi Cabriolet	2005	8H	51 Electric Drive	Read Fault Codes	
Audi Cabriolet	2005	8H	51 Electric Drive	Clear Fault Codes	
Audi Cabriolet	2005	8H	51 Electric Drive	Measuring Blocks	
Audi Cabriolet	2005	8H	51 Electric Drive	Output Tests	
Audi Cabriolet	2005	8H	51 Electric Drive	Specia Functions	
Audi Cabriolet	2005	8H	55 Headlight Range Control	Read Fault Codes	
Audi Cabriolet	2005	8H	55 Headlight Range Control	Clear Fault Codes	
Audi Cabriolet	2005	8H	55 Headlight Range Control	Measuring Blocks	
Audi Cabriolet	2005	8H	55 Headlight Range Control	Output Tests	
Audi Cabriolet	2005	8H	55 Headlight Range Control	Specia Functions	
Audi Cabriolet	2005	8H	56 Radio	Read Fault Codes	
Audi Cabriolet	2005	8H	56 Radio	Clear Fault Codes	
Audi Cabriolet	2005	8H	56 Radio	Measuring Blocks	
Audi Cabriolet	2005	8H	56 Radio	Output Tests	
Audi Cabriolet	2005	8H	56 Radio	Specia Functions	
Audi Cabriolet	2005	8H	57 TV-Tuner	Read Fault Codes	
Audi Cabriolet	2005	8H	57 TV-Tuner	Clear Fault Codes	
Audi Cabriolet	2005	8H	57 TV-Tuner	Measuring Blocks	
Audi Cabriolet	2005	8H	57 TV-Tuner	Output Tests	
Audi Cabriolet	2005	8H	57 TV-Tuner	Specia Functions	
Audi Cabriolet	2005	8H	63 Drvs Boarding Ass1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2005	8H	63 Drvs Boarding Ass1	Clear Fault Codes	
Audi Cabriolet	2005	8H	63 Drvs Boarding Ass1	Measuring Blocks	
Audi Cabriolet	2005	8H	63 Drvs Boarding Ass1	Output Tests	
Audi Cabriolet	2005	8H	63 Drvs Boarding Ass1	Specia Functions	
Audi Cabriolet	2005	8H	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Cabriolet	2005	8H	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Cabriolet	2005	8H	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Cabriolet	2005	8H	65 Tyre Pressure Monitoring	Output Tests	
Audi Cabriolet	2005	8H	65 Tyre Pressure Monitoring	Specia Functions	
Audi Cabriolet	2005	8H	67 Voice Control	Read Fault Codes	
Audi Cabriolet	2005	8H	67 Voice Control	Clear Fault Codes	
Audi Cabriolet	2005	8H	67 Voice Control	Measuring Blocks	
Audi Cabriolet	2005	8H	67 Voice Control	Output Tests	
Audi Cabriolet	2005	8H	67 Voice Control	Specia Functions	
Audi Cabriolet	2005	8H	73 Drvs Boarding Ass2	Read Fault Codes	
Audi Cabriolet	2005	8H	73 Drvs Boarding Ass2	Clear Fault Codes	
Audi Cabriolet	2005	8H	73 Drvs Boarding Ass2	Measuring Blocks	
Audi Cabriolet	2005	8H	73 Drvs Boarding Ass2	Output Tests	
Audi Cabriolet	2005	8H	73 Drvs Boarding Ass2	Specia Functions	
Audi Cabriolet	2005	8H	75 Emergency Call Module	Read Fault Codes	
Audi Cabriolet	2005	8H	75 Emergency Call Module	Clear Fault Codes	
Audi Cabriolet	2005	8H	75 Emergency Call Module	Measuring Blocks	
Audi Cabriolet	2005	8H	75 Emergency Call Module	Output Tests	
Audi Cabriolet	2005	8H	75 Emergency Call Module	Specia Functions	
Audi Cabriolet	2005	8H	76 Parking Aid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2005	8H	76 Parking Aid	Clear Fault Codes	
Audi Cabriolet	2005	8H	76 Parking Aid	Measuring Blocks	
Audi Cabriolet	2005	8H	76 Parking Aid	Output Tests	
Audi Cabriolet	2005	8H	76 Parking Aid	Specia Functions	
Audi Cabriolet	2005	8H	77 Telephone	Read Fault Codes	
Audi Cabriolet	2005	8H	77 Telephone	Clear Fault Codes	
Audi Cabriolet	2005	8H	77 Telephone	Measuring Blocks	
Audi Cabriolet	2005	8H	77 Telephone	Output Tests	
Audi Cabriolet	2005	8H	77 Telephone	Specia Functions	
Audi Cabriolet	2005	8H	8C Hybrid Battery	Read Fault Codes	
Audi Cabriolet	2005	8H	8C Hybrid Battery	Clear Fault Codes	
Audi Cabriolet	2005	8H	8C Hybrid Battery	Measuring Blocks	
Audi Cabriolet	2005	8H	8C Hybrid Battery	Output Tests	
Audi Cabriolet	2005	8H	8C Hybrid Battery	Specia Functions	
Audi Cabriolet	2006	8H	01 Engine Electronics	Read Fault Codes	
Audi Cabriolet	2006	8H	01 Engine Electronics	Clear Fault Codes	
Audi Cabriolet	2006	8H	01 Engine Electronics	Measuring Blocks	
Audi Cabriolet	2006	8H	01 Engine Electronics	Output Tests	
Audi Cabriolet	2006	8H	01 Engine Electronics	Specia Functions	
Audi Cabriolet	2006	8H	02 Transmission Electronics	Read Fault Codes	
Audi Cabriolet	2006	8H	02 Transmission Electronics	Clear Fault Codes	
Audi Cabriolet	2006	8H	02 Transmission Electronics	Measuring Blocks	
Audi Cabriolet	2006	8H	02 Transmission Electronics	Output Tests	
Audi Cabriolet	2006	8H	02 Transmission Electronics	Specia Functions	
Audi Cabriolet	2006	8H	03 Brake Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Cabriolet	2006	8H	03 Brake Electronics	Clear Fault Codes	
Audi Cabriolet	2006	8H	03 Brake Electronics	Measuring Blocks	
Audi Cabriolet	2006	8H	03 Brake Electronics	Output Tests	
Audi Cabriolet	2006	8H	03 Brake Electronics	Specia Functions	
Audi Cabriolet	2006	8H	08 AC/Heating Electronics	Read Fault Codes	
Audi Cabriolet	2006	8H	08 AC/Heating Electronics	Clear Fault Codes	
Audi Cabriolet	2006	8H	08 AC/Heating Electronics	Measuring Blocks	
Audi Cabriolet	2006	8H	08 AC/Heating Electronics	Output Tests	
Audi Cabriolet	2006	8H	08 AC/Heating Electronics	Specia Functions	
Audi Cabriolet	2006	8H	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Cabriolet	2006	8H	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Cabriolet	2006	8H	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Cabriolet	2006	8H	09 Electronic Ctrl Electronics	Output Tests	
Audi Cabriolet	2006	8H	09 Electronic Ctrl Electronics	Specia Functions	
Audi Cabriolet	2006	8H	0F Radio Tuner-Digital	Read Fault Codes	
Audi Cabriolet	2006	8H	0F Radio Tuner-Digital	Clear Fault Codes	
Audi Cabriolet	2006	8H	0F Radio Tuner-Digital	Measuring Blocks	
Audi Cabriolet	2006	8H	0F Radio Tuner-Digital	Output Tests	
Audi Cabriolet	2006	8H	0F Radio Tuner-Digital	Specia Functions	
Audi Cabriolet	2006	8H	11 Engine Electronics 2	Read Fault Codes	
Audi Cabriolet	2006	8H	11 Engine Electronics 2	Clear Fault Codes	
Audi Cabriolet	2006	8H	11 Engine Electronics 2	Measuring Blocks	
Audi Cabriolet	2006	8H	11 Engine Electronics 2	Output Tests	
Audi Cabriolet	2006	8H	11 Engine Electronics 2	Specia Functions	
Audi Cabriolet	2006	8H	15 Airbags	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2006	8H	15 Airbags	Clear Fault Codes	
Audi Cabriolet	2006	8H	15 Airbags	Measuring Blocks	
Audi Cabriolet	2006	8H	15 Airbags	Output Tests	
Audi Cabriolet	2006	8H	15 Airbags	Specia Functions	
Audi Cabriolet	2006	8H	16 Steering Wheel Electronics	Read Fault Codes	
Audi Cabriolet	2006	8H	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Cabriolet	2006	8H	16 Steering Wheel Electronics	Measuring Blocks	
Audi Cabriolet	2006	8H	16 Steering Wheel Electronics	Output Tests	
Audi Cabriolet	2006	8H	16 Steering Wheel Electronics	Specia Functions	
Audi Cabriolet	2006	8H	17 Instrument Cluster	Read Fault Codes	
Audi Cabriolet	2006	8H	17 Instrument Cluster	Clear Fault Codes	
Audi Cabriolet	2006	8H	17 Instrument Cluster	Measuring Blocks	
Audi Cabriolet	2006	8H	17 Instrument Cluster	Output Tests	
Audi Cabriolet	2006	8H	17 Instrument Cluster	Specia Functions	
Audi Cabriolet	2006	8H	18 Aux Heating	Read Fault Codes	
Audi Cabriolet	2006	8H	18 Aux Heating	Clear Fault Codes	
Audi Cabriolet	2006	8H	18 Aux Heating	Measuring Blocks	
Audi Cabriolet	2006	8H	18 Aux Heating	Output Tests	
Audi Cabriolet	2006	8H	18 Aux Heating	Specia Functions	
Audi Cabriolet	2006	8H	25 Immobilizer	Read Fault Codes	
Audi Cabriolet	2006	8H	25 Immobilizer	Clear Fault Codes	
Audi Cabriolet	2006	8H	25 Immobilizer	Measuring Blocks	
Audi Cabriolet	2006	8H	25 Immobilizer	Output Tests	
Audi Cabriolet	2006	8H	25 Immobilizer	Specia Functions	
Audi Cabriolet	2006	8H	26 Electric Roof Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2006	8H	26 Electric Roof Control	Clear Fault Codes	
Audi Cabriolet	2006	8H	26 Electric Roof Control	Measuring Blocks	
Audi Cabriolet	2006	8H	26 Electric Roof Control	Output Tests	
Audi Cabriolet	2006	8H	26 Electric Roof Control	Specia Functions	
Audi Cabriolet	2006	8H	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi Cabriolet	2006	8H	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Cabriolet	2006	8H	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Cabriolet	2006	8H	36 Side of Driver Seat Adj.	Output Tests	
Audi Cabriolet	2006	8H	36 Side of Driver Seat Adj.	Specia Functions	
Audi Cabriolet	2006	8H	37 Navigation	Read Fault Codes	
Audi Cabriolet	2006	8H	37 Navigation	Clear Fault Codes	
Audi Cabriolet	2006	8H	37 Navigation	Measuring Blocks	
Audi Cabriolet	2006	8H	37 Navigation	Output Tests	
Audi Cabriolet	2006	8H	37 Navigation	Specia Functions	
Audi Cabriolet	2006	8H	45 Interior Monitoring	Read Fault Codes	
Audi Cabriolet	2006	8H	45 Interior Monitoring	Clear Fault Codes	
Audi Cabriolet	2006	8H	45 Interior Monitoring	Measuring Blocks	
Audi Cabriolet	2006	8H	45 Interior Monitoring	Output Tests	
Audi Cabriolet	2006	8H	45 Interior Monitoring	Specia Functions	
Audi Cabriolet	2006	8H	46 Central Control Module	Read Fault Codes	
Audi Cabriolet	2006	8H	46 Central Control Module	Clear Fault Codes	
Audi Cabriolet	2006	8H	46 Central Control Module	Measuring Blocks	
Audi Cabriolet	2006	8H	46 Central Control Module	Output Tests	
Audi Cabriolet	2006	8H	46 Central Control Module	Specia Functions	
Audi Cabriolet	2006	8H	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2006	8H	51 Electric Drive	Clear Fault Codes	
Audi Cabriolet	2006	8H	51 Electric Drive	Measuring Blocks	
Audi Cabriolet	2006	8H	51 Electric Drive	Output Tests	
Audi Cabriolet	2006	8H	51 Electric Drive	Specia Functions	
Audi Cabriolet	2006	8H	55 Headlight Range Control	Read Fault Codes	
Audi Cabriolet	2006	8H	55 Headlight Range Control	Clear Fault Codes	
Audi Cabriolet	2006	8H	55 Headlight Range Control	Measuring Blocks	
Audi Cabriolet	2006	8H	55 Headlight Range Control	Output Tests	
Audi Cabriolet	2006	8H	55 Headlight Range Control	Specia Functions	
Audi Cabriolet	2006	8H	56 Radio	Read Fault Codes	
Audi Cabriolet	2006	8H	56 Radio	Clear Fault Codes	
Audi Cabriolet	2006	8H	56 Radio	Measuring Blocks	
Audi Cabriolet	2006	8H	56 Radio	Output Tests	
Audi Cabriolet	2006	8H	56 Radio	Specia Functions	
Audi Cabriolet	2006	8H	57 TV-Tuner	Read Fault Codes	
Audi Cabriolet	2006	8H	57 TV-Tuner	Clear Fault Codes	
Audi Cabriolet	2006	8H	57 TV-Tuner	Measuring Blocks	
Audi Cabriolet	2006	8H	57 TV-Tuner	Output Tests	
Audi Cabriolet	2006	8H	57 TV-Tuner	Specia Functions	
Audi Cabriolet	2006	8H	63 Drvs Boarding Ass1	Read Fault Codes	
Audi Cabriolet	2006	8H	63 Drvs Boarding Ass1	Clear Fault Codes	
Audi Cabriolet	2006	8H	63 Drvs Boarding Ass1	Measuring Blocks	
Audi Cabriolet	2006	8H	63 Drvs Boarding Ass1	Output Tests	
Audi Cabriolet	2006	8H	63 Drvs Boarding Ass1	Specia Functions	
Audi Cabriolet	2006	8H	65 Tyre Pressure Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2006	8H	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Cabriolet	2006	8H	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Cabriolet	2006	8H	65 Tyre Pressure Monitoring	Output Tests	
Audi Cabriolet	2006	8H	65 Tyre Pressure Monitoring	Specia Functions	
Audi Cabriolet	2006	8H	67 Voice Control	Read Fault Codes	
Audi Cabriolet	2006	8H	67 Voice Control	Clear Fault Codes	
Audi Cabriolet	2006	8H	67 Voice Control	Measuring Blocks	
Audi Cabriolet	2006	8H	67 Voice Control	Output Tests	
Audi Cabriolet	2006	8H	67 Voice Control	Specia Functions	
Audi Cabriolet	2006	8H	73 Drvs Boarding Ass2	Read Fault Codes	
Audi Cabriolet	2006	8H	73 Drvs Boarding Ass2	Clear Fault Codes	
Audi Cabriolet	2006	8H	73 Drvs Boarding Ass2	Measuring Blocks	
Audi Cabriolet	2006	8H	73 Drvs Boarding Ass2	Output Tests	
Audi Cabriolet	2006	8H	73 Drvs Boarding Ass2	Specia Functions	
Audi Cabriolet	2006	8H	75 Emergency Call Module	Read Fault Codes	
Audi Cabriolet	2006	8H	75 Emergency Call Module	Clear Fault Codes	
Audi Cabriolet	2006	8H	75 Emergency Call Module	Measuring Blocks	
Audi Cabriolet	2006	8H	75 Emergency Call Module	Output Tests	
Audi Cabriolet	2006	8H	75 Emergency Call Module	Specia Functions	
Audi Cabriolet	2006	8H	76 Parking Aid	Read Fault Codes	
Audi Cabriolet	2006	8H	76 Parking Aid	Clear Fault Codes	
Audi Cabriolet	2006	8H	76 Parking Aid	Measuring Blocks	
Audi Cabriolet	2006	8H	76 Parking Aid	Output Tests	
Audi Cabriolet	2006	8H	76 Parking Aid	Specia Functions	
Audi Cabriolet	2006	8H	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2006	8H	77 Telephone	Clear Fault Codes	
Audi Cabriolet	2006	8H	77 Telephone	Measuring Blocks	
Audi Cabriolet	2006	8H	77 Telephone	Output Tests	
Audi Cabriolet	2006	8H	77 Telephone	Specia Functions	
Audi Cabriolet	2006	8H	8C Hybrid Battery	Read Fault Codes	
Audi Cabriolet	2006	8H	8C Hybrid Battery	Clear Fault Codes	
Audi Cabriolet	2006	8H	8C Hybrid Battery	Measuring Blocks	
Audi Cabriolet	2006	8H	8C Hybrid Battery	Output Tests	
Audi Cabriolet	2006	8H	8C Hybrid Battery	Specia Functions	
Audi Cabriolet	2007-2009	8H	01 Engine Electronics	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	01 Engine Electronics	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	01 Engine Electronics	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	01 Engine Electronics	Output Tests	
Audi Cabriolet	2007-2009	8H	01 Engine Electronics	Specia Functions	
Audi Cabriolet	2007-2009	8H	02 Transmission Electronics	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	02 Transmission Electronics	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	02 Transmission Electronics	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	02 Transmission Electronics	Output Tests	
Audi Cabriolet	2007-2009	8H	02 Transmission Electronics	Specia Functions	
Audi Cabriolet	2007-2009	8H	03 Brake Electronics	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	03 Brake Electronics	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	03 Brake Electronics	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	03 Brake Electronics	Output Tests	
Audi Cabriolet	2007-2009	8H	03 Brake Electronics	Specia Functions	
Audi Cabriolet	2007-2009	8H	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2007-2009	8H	08 AC/Heating Electronics	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	08 AC/Heating Electronics	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	08 AC/Heating Electronics	Output Tests	
Audi Cabriolet	2007-2009	8H	08 AC/Heating Electronics	Specia Functions	
Audi Cabriolet	2007-2009	8H	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	09 Electronic Ctrl Electronics	Output Tests	
Audi Cabriolet	2007-2009	8H	09 Electronic Ctrl Electronics	Specia Functions	
Audi Cabriolet	2007-2009	8H	0F Radio Tuner-Digital	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	0F Radio Tuner-Digital	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	0F Radio Tuner-Digital	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	0F Radio Tuner-Digital	Output Tests	
Audi Cabriolet	2007-2009	8H	0F Radio Tuner-Digital	Specia Functions	
Audi Cabriolet	2007-2009	8H	11 Engine Electronics 2	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	11 Engine Electronics 2	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	11 Engine Electronics 2	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	11 Engine Electronics 2	Output Tests	
Audi Cabriolet	2007-2009	8H	11 Engine Electronics 2	Specia Functions	
Audi Cabriolet	2007-2009	8H	15 Airbags	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	15 Airbags	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	15 Airbags	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	15 Airbags	Output Tests	
Audi Cabriolet	2007-2009	8H	15 Airbags	Specia Functions	
Audi Cabriolet	2007-2009	8H	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2007-2009	8H	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	16 Steering Wheel Electronics	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	16 Steering Wheel Electronics	Output Tests	
Audi Cabriolet	2007-2009	8H	16 Steering Wheel Electronics	Specia Functions	
Audi Cabriolet	2007-2009	8H	17 Instrument Cluster	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	17 Instrument Cluster	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	17 Instrument Cluster	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	17 Instrument Cluster	Output Tests	
Audi Cabriolet	2007-2009	8H	17 Instrument Cluster	Specia Functions	
Audi Cabriolet	2007-2009	8H	18 Aux Heating	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	18 Aux Heating	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	18 Aux Heating	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	18 Aux Heating	Output Tests	
Audi Cabriolet	2007-2009	8H	18 Aux Heating	Specia Functions	
Audi Cabriolet	2007-2009	8H	25 Immobilizer	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	25 Immobilizer	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	25 Immobilizer	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	25 Immobilizer	Output Tests	
Audi Cabriolet	2007-2009	8H	25 Immobilizer	Specia Functions	
Audi Cabriolet	2007-2009	8H	26 Electric Roof Control	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	26 Electric Roof Control	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	26 Electric Roof Control	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	26 Electric Roof Control	Output Tests	
Audi Cabriolet	2007-2009	8H	26 Electric Roof Control	Specia Functions	
Audi Cabriolet	2007-2009	8H	36 Side of Driver Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2007-2009	8H	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	36 Side of Driver Seat Adj.	Output Tests	
Audi Cabriolet	2007-2009	8H	36 Side of Driver Seat Adj.	Specia Functions	
Audi Cabriolet	2007-2009	8H	37 Navigation	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	37 Navigation	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	37 Navigation	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	37 Navigation	Output Tests	
Audi Cabriolet	2007-2009	8H	37 Navigation	Specia Functions	
Audi Cabriolet	2007-2009	8H	45 Interior Monitoring	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	45 Interior Monitoring	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	45 Interior Monitoring	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	45 Interior Monitoring	Output Tests	
Audi Cabriolet	2007-2009	8H	45 Interior Monitoring	Specia Functions	
Audi Cabriolet	2007-2009	8H	46 Central Control Module	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	46 Central Control Module	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	46 Central Control Module	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	46 Central Control Module	Output Tests	
Audi Cabriolet	2007-2009	8H	46 Central Control Module	Specia Functions	
Audi Cabriolet	2007-2009	8H	51 Electric Drive	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	51 Electric Drive	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	51 Electric Drive	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	51 Electric Drive	Output Tests	
Audi Cabriolet	2007-2009	8H	51 Electric Drive	Specia Functions	
Audi Cabriolet	2007-2009	8H	55 Headlight Range Control	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi Cabriolet	2007-2009	8H	55 Headlight Range Control	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	55 Headlight Range Control	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	55 Headlight Range Control	Output Tests	
Audi Cabriolet	2007-2009	8H	55 Headlight Range Control	Specia Functions	
Audi Cabriolet	2007-2009	8H	56 Radio	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	56 Radio	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	56 Radio	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	56 Radio	Output Tests	
Audi Cabriolet	2007-2009	8H	56 Radio	Specia Functions	
Audi Cabriolet	2007-2009	8H	57 TV-Tuner	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	57 TV-Tuner	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	57 TV-Tuner	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	57 TV-Tuner	Output Tests	
Audi Cabriolet	2007-2009	8H	57 TV-Tuner	Specia Functions	
Audi Cabriolet	2007-2009	8H	63 Drvs Boarding Ass1	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	63 Drvs Boarding Ass1	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	63 Drvs Boarding Ass1	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	63 Drvs Boarding Ass1	Output Tests	
Audi Cabriolet	2007-2009	8H	63 Drvs Boarding Ass1	Specia Functions	
Audi Cabriolet	2007-2009	8H	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	65 Tyre Pressure Monitoring	Output Tests	
Audi Cabriolet	2007-2009	8H	65 Tyre Pressure Monitoring	Specia Functions	
Audi Cabriolet	2007-2009	8H	67 Voice Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2007-2009	8H	67 Voice Control	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	67 Voice Control	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	67 Voice Control	Output Tests	
Audi Cabriolet	2007-2009	8H	67 Voice Control	Specia Functions	
Audi Cabriolet	2007-2009	8H	73 Drvs Boarding Ass2	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	73 Drvs Boarding Ass2	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	73 Drvs Boarding Ass2	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	73 Drvs Boarding Ass2	Output Tests	
Audi Cabriolet	2007-2009	8H	73 Drvs Boarding Ass2	Specia Functions	
Audi Cabriolet	2007-2009	8H	75 Emergency Call Module	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	75 Emergency Call Module	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	75 Emergency Call Module	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	75 Emergency Call Module	Output Tests	
Audi Cabriolet	2007-2009	8H	75 Emergency Call Module	Specia Functions	
Audi Cabriolet	2007-2009	8H	76 Parking Aid	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	76 Parking Aid	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	76 Parking Aid	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	76 Parking Aid	Output Tests	
Audi Cabriolet	2007-2009	8H	76 Parking Aid	Specia Functions	
Audi Cabriolet	2007-2009	8H	77 Telephone	Read Fault Codes	
Audi Cabriolet	2007-2009	8H	77 Telephone	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	77 Telephone	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	77 Telephone	Output Tests	
Audi Cabriolet	2007-2009	8H	77 Telephone	Specia Functions	
Audi Cabriolet	2007-2009	8H	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Cabriolet	2007-2009	8H	8C Hybrid Battery	Clear Fault Codes	
Audi Cabriolet	2007-2009	8H	8C Hybrid Battery	Measuring Blocks	
Audi Cabriolet	2007-2009	8H	8C Hybrid Battery	Output Tests	
Audi Cabriolet	2007-2009	8H	8C Hybrid Battery	Specia Functions	
Audi A3	1996-1999	8L	01 Engine Electronics	Read Fault Codes	
Audi A3	1996-1999	8L	01 Engine Electronics	Clear Fault Codes	
Audi A3	1996-1999	8L	01 Engine Electronics	Measuring Blocks	
Audi A3	1996-1999	8L	01 Engine Electronics	Output Tests	
Audi A3	1996-1999	8L	01 Engine Electronics	Specia Functions	
Audi A3	1996-1999	8L	02 Transmission Electronics	Read Fault Codes	
Audi A3	1996-1999	8L	02 Transmission Electronics	Clear Fault Codes	
Audi A3	1996-1999	8L	02 Transmission Electronics	Measuring Blocks	
Audi A3	1996-1999	8L	02 Transmission Electronics	Output Tests	
Audi A3	1996-1999	8L	02 Transmission Electronics	Specia Functions	
Audi A3	1996-1999	8L	03 Brake Electronics	Read Fault Codes	
Audi A3	1996-1999	8L	03 Brake Electronics	Clear Fault Codes	
Audi A3	1996-1999	8L	03 Brake Electronics	Measuring Blocks	
Audi A3	1996-1999	8L	03 Brake Electronics	Output Tests	
Audi A3	1996-1999	8L	03 Brake Electronics	Specia Functions	
Audi A3	1996-1999	8L	08 AC/Heating Electronics	Read Fault Codes	
Audi A3	1996-1999	8L	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3	1996-1999	8L	08 AC/Heating Electronics	Measuring Blocks	
Audi A3	1996-1999	8L	08 AC/Heating Electronics	Output Tests	
Audi A3	1996-1999	8L	08 AC/Heating Electronics	Specia Functions	
Audi A3	1996-1999	8L	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	1996-1999	8L	11 Engine Electronics 2	Clear Fault Codes	
Audi A3	1996-1999	8L	11 Engine Electronics 2	Measuring Blocks	
Audi A3	1996-1999	8L	11 Engine Electronics 2	Output Tests	
Audi A3	1996-1999	8L	11 Engine Electronics 2	Specia Functions	
Audi A3	1996-1999	8L	15 Airbags	Read Fault Codes	
Audi A3	1996-1999	8L	15 Airbags	Clear Fault Codes	
Audi A3	1996-1999	8L	15 Airbags	Measuring Blocks	
Audi A3	1996-1999	8L	15 Airbags	Output Tests	
Audi A3	1996-1999	8L	15 Airbags	Specia Functions	
Audi A3	1996-1999	8L	17 Instrument Cluster	Read Fault Codes	
Audi A3	1996-1999	8L	17 Instrument Cluster	Clear Fault Codes	
Audi A3	1996-1999	8L	17 Instrument Cluster	Measuring Blocks	
Audi A3	1996-1999	8L	17 Instrument Cluster	Output Tests	
Audi A3	1996-1999	8L	17 Instrument Cluster	Specia Functions	
Audi A3	1996-1999	8L	22 4WD Electronics	Read Fault Codes	
Audi A3	1996-1999	8L	22 4WD Electronics	Clear Fault Codes	
Audi A3	1996-1999	8L	22 4WD Electronics	Measuring Blocks	
Audi A3	1996-1999	8L	22 4WD Electronics	Output Tests	
Audi A3	1996-1999	8L	22 4WD Electronics	Specia Functions	
Audi A3	1996-1999	8L	25 Immobilizer	Read Fault Codes	
Audi A3	1996-1999	8L	25 Immobilizer	Clear Fault Codes	
Audi A3	1996-1999	8L	25 Immobilizer	Measuring Blocks	
Audi A3	1996-1999	8L	25 Immobilizer	Output Tests	
Audi A3	1996-1999	8L	25 Immobilizer	Specia Functions	
Audi A3	1996-1999	8L	35 Central Locking	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	1996-1999	8L	35 Central Locking	Clear Fault Codes	
Audi A3	1996-1999	8L	35 Central Locking	Measuring Blocks	
Audi A3	1996-1999	8L	35 Central Locking	Output Tests	
Audi A3	1996-1999	8L	35 Central Locking	Specia Functions	
Audi A3	1996-1999	8L	37 Navigation	Read Fault Codes	
Audi A3	1996-1999	8L	37 Navigation	Clear Fault Codes	
Audi A3	1996-1999	8L	37 Navigation	Measuring Blocks	
Audi A3	1996-1999	8L	37 Navigation	Output Tests	
Audi A3	1996-1999	8L	37 Navigation	Specia Functions	
Audi A3	1996-1999	8L	45 Interior Monitoring	Read Fault Codes	
Audi A3	1996-1999	8L	45 Interior Monitoring	Clear Fault Codes	
Audi A3	1996-1999	8L	45 Interior Monitoring	Measuring Blocks	
Audi A3	1996-1999	8L	45 Interior Monitoring	Output Tests	
Audi A3	1996-1999	8L	45 Interior Monitoring	Specia Functions	
Audi A3	1996-1999	8L	51 Electric Drive	Read Fault Codes	
Audi A3	1996-1999	8L	51 Electric Drive	Clear Fault Codes	
Audi A3	1996-1999	8L	51 Electric Drive	Measuring Blocks	
Audi A3	1996-1999	8L	51 Electric Drive	Output Tests	
Audi A3	1996-1999	8L	51 Electric Drive	Specia Functions	
Audi A3	1996-1999	8L	56 Radio	Read Fault Codes	
Audi A3	1996-1999	8L	56 Radio	Clear Fault Codes	
Audi A3	1996-1999	8L	56 Radio	Measuring Blocks	
Audi A3	1996-1999	8L	56 Radio	Output Tests	
Audi A3	1996-1999	8L	56 Radio	Specia Functions	
Audi A3	1996-1999	8L	76 Parking Aid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	1996-1999	8L	76 Parking Aid	Clear Fault Codes	
Audi A3	1996-1999	8L	76 Parking Aid	Measuring Blocks	
Audi A3	1996-1999	8L	76 Parking Aid	Output Tests	
Audi A3	1996-1999	8L	76 Parking Aid	Specia Functions	
Audi A3	1996-1999	8L	8C Hybrid Battery	Read Fault Codes	
Audi A3	1996-1999	8L	8C Hybrid Battery	Clear Fault Codes	
Audi A3	1996-1999	8L	8C Hybrid Battery	Measuring Blocks	
Audi A3	1996-1999	8L	8C Hybrid Battery	Output Tests	
Audi A3	1996-1999	8L	8C Hybrid Battery	Specia Functions	
Audi A3	2000-2001	8L	01 Engine Electronics	Read Fault Codes	
Audi A3	2000-2001	8L	01 Engine Electronics	Clear Fault Codes	
Audi A3	2000-2001	8L	01 Engine Electronics	Measuring Blocks	
Audi A3	2000-2001	8L	01 Engine Electronics	Output Tests	
Audi A3	2000-2001	8L	01 Engine Electronics	Specia Functions	
Audi A3	2000-2001	8L	02 Transmission Electronics	Read Fault Codes	
Audi A3	2000-2001	8L	02 Transmission Electronics	Clear Fault Codes	
Audi A3	2000-2001	8L	02 Transmission Electronics	Measuring Blocks	
Audi A3	2000-2001	8L	02 Transmission Electronics	Output Tests	
Audi A3	2000-2001	8L	02 Transmission Electronics	Specia Functions	
Audi A3	2000-2001	8L	03 Brake Electronics	Read Fault Codes	
Audi A3	2000-2001	8L	03 Brake Electronics	Clear Fault Codes	
Audi A3	2000-2001	8L	03 Brake Electronics	Measuring Blocks	
Audi A3	2000-2001	8L	03 Brake Electronics	Output Tests	
Audi A3	2000-2001	8L	03 Brake Electronics	Specia Functions	
Audi A3	2000-2001	8L	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2000-2001	8L	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3	2000-2001	8L	08 AC/Heating Electronics	Measuring Blocks	
Audi A3	2000-2001	8L	08 AC/Heating Electronics	Output Tests	
Audi A3	2000-2001	8L	08 AC/Heating Electronics	Specia Functions	
Audi A3	2000-2001	8L	11 Engine Electronics 2	Read Fault Codes	
Audi A3	2000-2001	8L	11 Engine Electronics 2	Clear Fault Codes	
Audi A3	2000-2001	8L	11 Engine Electronics 2	Measuring Blocks	
Audi A3	2000-2001	8L	11 Engine Electronics 2	Output Tests	
Audi A3	2000-2001	8L	11 Engine Electronics 2	Specia Functions	
Audi A3	2000-2001	8L	15 Airbags	Read Fault Codes	
Audi A3	2000-2001	8L	15 Airbags	Clear Fault Codes	
Audi A3	2000-2001	8L	15 Airbags	Measuring Blocks	
Audi A3	2000-2001	8L	15 Airbags	Output Tests	
Audi A3	2000-2001	8L	15 Airbags	Specia Functions	
Audi A3	2000-2001	8L	17 Instrument Cluster	Read Fault Codes	
Audi A3	2000-2001	8L	17 Instrument Cluster	Clear Fault Codes	
Audi A3	2000-2001	8L	17 Instrument Cluster	Measuring Blocks	
Audi A3	2000-2001	8L	17 Instrument Cluster	Output Tests	
Audi A3	2000-2001	8L	17 Instrument Cluster	Specia Functions	
Audi A3	2000-2001	8L	22 4WD Electronics	Read Fault Codes	
Audi A3	2000-2001	8L	22 4WD Electronics	Clear Fault Codes	
Audi A3	2000-2001	8L	22 4WD Electronics	Measuring Blocks	
Audi A3	2000-2001	8L	22 4WD Electronics	Output Tests	
Audi A3	2000-2001	8L	22 4WD Electronics	Specia Functions	
Audi A3	2000-2001	8L	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2000-2001	8L	25 Immobilizer	Clear Fault Codes	
Audi A3	2000-2001	8L	25 Immobilizer	Measuring Blocks	
Audi A3	2000-2001	8L	25 Immobilizer	Output Tests	
Audi A3	2000-2001	8L	25 Immobilizer	Specia Functions	
Audi A3	2000-2001	8L	35 Central Locking	Read Fault Codes	
Audi A3	2000-2001	8L	35 Central Locking	Clear Fault Codes	
Audi A3	2000-2001	8L	35 Central Locking	Measuring Blocks	
Audi A3	2000-2001	8L	35 Central Locking	Output Tests	
Audi A3	2000-2001	8L	35 Central Locking	Specia Functions	
Audi A3	2000-2001	8L	37 Navigation	Read Fault Codes	
Audi A3	2000-2001	8L	37 Navigation	Clear Fault Codes	
Audi A3	2000-2001	8L	37 Navigation	Measuring Blocks	
Audi A3	2000-2001	8L	37 Navigation	Output Tests	
Audi A3	2000-2001	8L	37 Navigation	Specia Functions	
Audi A3	2000-2001	8L	45 Interior Monitoring	Read Fault Codes	
Audi A3	2000-2001	8L	45 Interior Monitoring	Clear Fault Codes	
Audi A3	2000-2001	8L	45 Interior Monitoring	Measuring Blocks	
Audi A3	2000-2001	8L	45 Interior Monitoring	Output Tests	
Audi A3	2000-2001	8L	45 Interior Monitoring	Specia Functions	
Audi A3	2000-2001	8L	51 Electric Drive	Read Fault Codes	
Audi A3	2000-2001	8L	51 Electric Drive	Clear Fault Codes	
Audi A3	2000-2001	8L	51 Electric Drive	Measuring Blocks	
Audi A3	2000-2001	8L	51 Electric Drive	Output Tests	
Audi A3	2000-2001	8L	51 Electric Drive	Specia Functions	
Audi A3	2000-2001	8L	55 Headlight Range Control	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2000-2001	8L	55 Headlight Range Control	Clear Fault Codes	
Audi A3	2000-2001	8L	55 Headlight Range Control	Measuring Blocks	
Audi A3	2000-2001	8L	55 Headlight Range Control	Output Tests	
Audi A3	2000-2001	8L	55 Headlight Range Control	Specia Functions	
Audi A3	2000-2001	8L	56 Radio	Read Fault Codes	
Audi A3	2000-2001	8L	56 Radio	Clear Fault Codes	
Audi A3	2000-2001	8L	56 Radio	Measuring Blocks	
Audi A3	2000-2001	8L	56 Radio	Output Tests	
Audi A3	2000-2001	8L	56 Radio	Specia Functions	
Audi A3	2000-2001	8L	75 Emergency Call Module	Read Fault Codes	
Audi A3	2000-2001	8L	75 Emergency Call Module	Clear Fault Codes	
Audi A3	2000-2001	8L	75 Emergency Call Module	Measuring Blocks	
Audi A3	2000-2001	8L	75 Emergency Call Module	Output Tests	
Audi A3	2000-2001	8L	75 Emergency Call Module	Specia Functions	
Audi A3	2000-2001	8L	76 Parking Aid	Read Fault Codes	
Audi A3	2000-2001	8L	76 Parking Aid	Clear Fault Codes	
Audi A3	2000-2001	8L	76 Parking Aid	Measuring Blocks	
Audi A3	2000-2001	8L	76 Parking Aid	Output Tests	
Audi A3	2000-2001	8L	76 Parking Aid	Specia Functions	
Audi A3	2000-2001	8L	8C Hybrid Battery	Read Fault Codes	
Audi A3	2000-2001	8L	8C Hybrid Battery	Clear Fault Codes	
Audi A3	2000-2001	8L	8C Hybrid Battery	Measuring Blocks	
Audi A3	2000-2001	8L	8C Hybrid Battery	Output Tests	
Audi A3	2000-2001	8L	8C Hybrid Battery	Specia Functions	
Audi A3	2002-2007	8L	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2002-2007	8L	01 Engine Electronics	Clear Fault Codes	
Audi A3	2002-2007	8L	01 Engine Electronics	Measuring Blocks	
Audi A3	2002-2007	8L	01 Engine Electronics	Output Tests	
Audi A3	2002-2007	8L	01 Engine Electronics	Specia Functions	
Audi A3	2002-2007	8L	02 Transmission Electronics	Read Fault Codes	
Audi A3	2002-2007	8L	02 Transmission Electronics	Clear Fault Codes	
Audi A3	2002-2007	8L	02 Transmission Electronics	Measuring Blocks	
Audi A3	2002-2007	8L	02 Transmission Electronics	Output Tests	
Audi A3	2002-2007	8L	02 Transmission Electronics	Specia Functions	
Audi A3	2002-2007	8L	03 Brake Electronics	Read Fault Codes	
Audi A3	2002-2007	8L	03 Brake Electronics	Clear Fault Codes	
Audi A3	2002-2007	8L	03 Brake Electronics	Measuring Blocks	
Audi A3	2002-2007	8L	03 Brake Electronics	Output Tests	
Audi A3	2002-2007	8L	03 Brake Electronics	Specia Functions	
Audi A3	2002-2007	8L	08 AC/Heating Electronics	Read Fault Codes	
Audi A3	2002-2007	8L	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3	2002-2007	8L	08 AC/Heating Electronics	Measuring Blocks	
Audi A3	2002-2007	8L	08 AC/Heating Electronics	Output Tests	
Audi A3	2002-2007	8L	08 AC/Heating Electronics	Specia Functions	
Audi A3	2002-2007	8L	11 Engine Electronics 2	Read Fault Codes	
Audi A3	2002-2007	8L	11 Engine Electronics 2	Clear Fault Codes	
Audi A3	2002-2007	8L	11 Engine Electronics 2	Measuring Blocks	
Audi A3	2002-2007	8L	11 Engine Electronics 2	Output Tests	
Audi A3	2002-2007	8L	11 Engine Electronics 2	Specia Functions	
Audi A3	2002-2007	8L	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2002-2007	8L	15 Airbags	Clear Fault Codes	
Audi A3	2002-2007	8L	15 Airbags	Measuring Blocks	
Audi A3	2002-2007	8L	15 Airbags	Output Tests	
Audi A3	2002-2007	8L	15 Airbags	Specia Functions	
Audi A3	2002-2007	8L	17 Instrument Cluster	Read Fault Codes	
Audi A3	2002-2007	8L	17 Instrument Cluster	Clear Fault Codes	
Audi A3	2002-2007	8L	17 Instrument Cluster	Measuring Blocks	
Audi A3	2002-2007	8L	17 Instrument Cluster	Output Tests	
Audi A3	2002-2007	8L	17 Instrument Cluster	Specia Functions	
Audi A3	2002-2007	8L	22 4WD Electronics	Read Fault Codes	
Audi A3	2002-2007	8L	22 4WD Electronics	Clear Fault Codes	
Audi A3	2002-2007	8L	22 4WD Electronics	Measuring Blocks	
Audi A3	2002-2007	8L	22 4WD Electronics	Output Tests	
Audi A3	2002-2007	8L	22 4WD Electronics	Specia Functions	
Audi A3	2002-2007	8L	25 Immobilizer	Read Fault Codes	
Audi A3	2002-2007	8L	25 Immobilizer	Clear Fault Codes	
Audi A3	2002-2007	8L	25 Immobilizer	Measuring Blocks	
Audi A3	2002-2007	8L	25 Immobilizer	Output Tests	
Audi A3	2002-2007	8L	25 Immobilizer	Specia Functions	
Audi A3	2002-2007	8L	35 Central Locking	Read Fault Codes	
Audi A3	2002-2007	8L	35 Central Locking	Clear Fault Codes	
Audi A3	2002-2007	8L	35 Central Locking	Measuring Blocks	
Audi A3	2002-2007	8L	35 Central Locking	Output Tests	
Audi A3	2002-2007	8L	35 Central Locking	Specia Functions	
Audi A3	2002-2007	8L	37 Navigation	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2002-2007	8L	37 Navigation	Clear Fault Codes	
Audi A3	2002-2007	8L	37 Navigation	Measuring Blocks	
Audi A3	2002-2007	8L	37 Navigation	Output Tests	
Audi A3	2002-2007	8L	37 Navigation	Specia Functions	
Audi A3	2002-2007	8L	45 Interior Monitoring	Read Fault Codes	
Audi A3	2002-2007	8L	45 Interior Monitoring	Clear Fault Codes	
Audi A3	2002-2007	8L	45 Interior Monitoring	Measuring Blocks	
Audi A3	2002-2007	8L	45 Interior Monitoring	Output Tests	
Audi A3	2002-2007	8L	45 Interior Monitoring	Specia Functions	
Audi A3	2002-2007	8L	51 Electric Drive	Read Fault Codes	
Audi A3	2002-2007	8L	51 Electric Drive	Clear Fault Codes	
Audi A3	2002-2007	8L	51 Electric Drive	Measuring Blocks	
Audi A3	2002-2007	8L	51 Electric Drive	Output Tests	
Audi A3	2002-2007	8L	51 Electric Drive	Specia Functions	
Audi A3	2002-2007	8L	55 Headlight Range Control	Read Fault Codes	
Audi A3	2002-2007	8L	55 Headlight Range Control	Clear Fault Codes	
Audi A3	2002-2007	8L	55 Headlight Range Control	Measuring Blocks	
Audi A3	2002-2007	8L	55 Headlight Range Control	Output Tests	
Audi A3	2002-2007	8L	55 Headlight Range Control	Specia Functions	
Audi A3	2002-2007	8L	56 Radio	Read Fault Codes	
Audi A3	2002-2007	8L	56 Radio	Clear Fault Codes	
Audi A3	2002-2007	8L	56 Radio	Measuring Blocks	
Audi A3	2002-2007	8L	56 Radio	Output Tests	
Audi A3	2002-2007	8L	56 Radio	Specia Functions	
Audi A3	2002-2007	8L	75 Emergency Call Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3	2002-2007	8L	75 Emergency Call Module	Clear Fault Codes	
Audi A3	2002-2007	8L	75 Emergency Call Module	Measuring Blocks	
Audi A3	2002-2007	8L	75 Emergency Call Module	Output Tests	
Audi A3	2002-2007	8L	75 Emergency Call Module	Specia Functions	
Audi A3	2002-2007	8L	76 Parking Aid	Read Fault Codes	
Audi A3	2002-2007	8L	76 Parking Aid	Clear Fault Codes	
Audi A3	2002-2007	8L	76 Parking Aid	Measuring Blocks	
Audi A3	2002-2007	8L	76 Parking Aid	Output Tests	
Audi A3	2002-2007	8L	76 Parking Aid	Specia Functions	
Audi A3	2002-2007	8L	77 Telephone	Read Fault Codes	
Audi A3	2002-2007	8L	77 Telephone	Clear Fault Codes	
Audi A3	2002-2007	8L	77 Telephone	Measuring Blocks	
Audi A3	2002-2007	8L	77 Telephone	Output Tests	
Audi A3	2002-2007	8L	77 Telephone	Specia Functions	
Audi A3	2002-2007	8L	8C Hybrid Battery	Read Fault Codes	
Audi A3	2002-2007	8L	8C Hybrid Battery	Clear Fault Codes	
Audi A3	2002-2007	8L	8C Hybrid Battery	Measuring Blocks	
Audi A3	2002-2007	8L	8C Hybrid Battery	Output Tests	
Audi A3	2002-2007	8L	8C Hybrid Battery	Specia Functions	
Audi A4	1994-1999	8D	01 Engine Electronics	Read Fault Codes	
Audi A4	1994-1999	8D	01 Engine Electronics	Clear Fault Codes	
Audi A4	1994-1999	8D	01 Engine Electronics	Measuring Blocks	
Audi A4	1994-1999	8D	01 Engine Electronics	Output Tests	
Audi A4	1994-1999	8D	01 Engine Electronics	Specia Functions	
Audi A4	1994-1999	8D	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	1994-1999	8D	02 Transmission Electronics	Clear Fault Codes	
Audi A4	1994-1999	8D	02 Transmission Electronics	Measuring Blocks	
Audi A4	1994-1999	8D	02 Transmission Electronics	Output Tests	
Audi A4	1994-1999	8D	02 Transmission Electronics	Specia Functions	
Audi A4	1994-1999	8D	03 Brake Electronics	Read Fault Codes	
Audi A4	1994-1999	8D	03 Brake Electronics	Clear Fault Codes	
Audi A4	1994-1999	8D	03 Brake Electronics	Measuring Blocks	
Audi A4	1994-1999	8D	03 Brake Electronics	Output Tests	
Audi A4	1994-1999	8D	03 Brake Electronics	Specia Functions	
Audi A4	1994-1999	8D	08 AC/Heating Electronics	Read Fault Codes	
Audi A4	1994-1999	8D	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4	1994-1999	8D	08 AC/Heating Electronics	Measuring Blocks	
Audi A4	1994-1999	8D	08 AC/Heating Electronics	Output Tests	
Audi A4	1994-1999	8D	08 AC/Heating Electronics	Specia Functions	
Audi A4	1994-1999	8D	11 Engine Electronics 2	Read Fault Codes	
Audi A4	1994-1999	8D	11 Engine Electronics 2	Clear Fault Codes	
Audi A4	1994-1999	8D	11 Engine Electronics 2	Measuring Blocks	
Audi A4	1994-1999	8D	11 Engine Electronics 2	Output Tests	
Audi A4	1994-1999	8D	11 Engine Electronics 2	Specia Functions	
Audi A4	1994-1999	8D	15 Airbags	Read Fault Codes	
Audi A4	1994-1999	8D	15 Airbags	Clear Fault Codes	
Audi A4	1994-1999	8D	15 Airbags	Measuring Blocks	
Audi A4	1994-1999	8D	15 Airbags	Output Tests	
Audi A4	1994-1999	8D	15 Airbags	Specia Functions	
Audi A4	1994-1999	8D	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	1994-1999	8D	17 Instrument Cluster	Clear Fault Codes	
Audi A4	1994-1999	8D	17 Instrument Cluster	Measuring Blocks	
Audi A4	1994-1999	8D	17 Instrument Cluster	Output Tests	
Audi A4	1994-1999	8D	17 Instrument Cluster	Specia Functions	
Audi A4	1994-1999	8D	25 Immobilizer	Read Fault Codes	
Audi A4	1994-1999	8D	25 Immobilizer	Clear Fault Codes	
Audi A4	1994-1999	8D	25 Immobilizer	Measuring Blocks	
Audi A4	1994-1999	8D	25 Immobilizer	Output Tests	
Audi A4	1994-1999	8D	25 Immobilizer	Specia Functions	
Audi A4	1994-1999	8D	35 Central Locking	Read Fault Codes	
Audi A4	1994-1999	8D	35 Central Locking	Clear Fault Codes	
Audi A4	1994-1999	8D	35 Central Locking	Measuring Blocks	
Audi A4	1994-1999	8D	35 Central Locking	Output Tests	
Audi A4	1994-1999	8D	35 Central Locking	Specia Functions	
Audi A4	1994-1999	8D	37 Navigation	Read Fault Codes	
Audi A4	1994-1999	8D	37 Navigation	Clear Fault Codes	
Audi A4	1994-1999	8D	37 Navigation	Measuring Blocks	
Audi A4	1994-1999	8D	37 Navigation	Output Tests	
Audi A4	1994-1999	8D	37 Navigation	Specia Functions	
Audi A4	1994-1999	8D	45 Interior Monitoring	Read Fault Codes	
Audi A4	1994-1999	8D	45 Interior Monitoring	Clear Fault Codes	
Audi A4	1994-1999	8D	45 Interior Monitoring	Measuring Blocks	
Audi A4	1994-1999	8D	45 Interior Monitoring	Output Tests	
Audi A4	1994-1999	8D	45 Interior Monitoring	Specia Functions	
Audi A4	1994-1999	8D	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	1994-1999	8D	51 Electric Drive	Clear Fault Codes	
Audi A4	1994-1999	8D	51 Electric Drive	Measuring Blocks	
Audi A4	1994-1999	8D	51 Electric Drive	Output Tests	
Audi A4	1994-1999	8D	51 Electric Drive	Specia Functions	
Audi A4	1994-1999	8D	55 Headlight Range Control	Read Fault Codes	
Audi A4	1994-1999	8D	55 Headlight Range Control	Clear Fault Codes	
Audi A4	1994-1999	8D	55 Headlight Range Control	Measuring Blocks	
Audi A4	1994-1999	8D	55 Headlight Range Control	Output Tests	
Audi A4	1994-1999	8D	55 Headlight Range Control	Specia Functions	
Audi A4	1994-1999	8D	56 Radio	Read Fault Codes	
Audi A4	1994-1999	8D	56 Radio	Clear Fault Codes	
Audi A4	1994-1999	8D	56 Radio	Measuring Blocks	
Audi A4	1994-1999	8D	56 Radio	Output Tests	
Audi A4	1994-1999	8D	56 Radio	Specia Functions	
Audi A4	1994-1999	8D	76 Parking Aid	Read Fault Codes	
Audi A4	1994-1999	8D	76 Parking Aid	Clear Fault Codes	
Audi A4	1994-1999	8D	76 Parking Aid	Measuring Blocks	
Audi A4	1994-1999	8D	76 Parking Aid	Output Tests	
Audi A4	1994-1999	8D	76 Parking Aid	Specia Functions	
Audi A4	1994-1999	8D	8C Hybrid Battery	Read Fault Codes	
Audi A4	1994-1999	8D	8C Hybrid Battery	Clear Fault Codes	
Audi A4	1994-1999	8D	8C Hybrid Battery	Measuring Blocks	
Audi A4	1994-1999	8D	8C Hybrid Battery	Output Tests	
Audi A4	1994-1999	8D	8C Hybrid Battery	Specia Functions	
Audi A4	2000	8D	01 Engine Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2000	8D	01 Engine Electronics	Clear Fault Codes	
Audi A4	2000	8D	01 Engine Electronics	Measuring Blocks	
Audi A4	2000	8D	01 Engine Electronics	Output Tests	
Audi A4	2000	8D	01 Engine Electronics	Specia Functions	
Audi A4	2000	8D	02 Transmission Electronics	Read Fault Codes	
Audi A4	2000	8D	02 Transmission Electronics	Clear Fault Codes	
Audi A4	2000	8D	02 Transmission Electronics	Measuring Blocks	
Audi A4	2000	8D	02 Transmission Electronics	Output Tests	
Audi A4	2000	8D	02 Transmission Electronics	Specia Functions	
Audi A4	2000	8D	03 Brake Electronics	Read Fault Codes	
Audi A4	2000	8D	03 Brake Electronics	Clear Fault Codes	
Audi A4	2000	8D	03 Brake Electronics	Measuring Blocks	
Audi A4	2000	8D	03 Brake Electronics	Output Tests	
Audi A4	2000	8D	03 Brake Electronics	Specia Functions	
Audi A4	2000	8D	08 AC/Heating Electronics	Read Fault Codes	
Audi A4	2000	8D	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4	2000	8D	08 AC/Heating Electronics	Measuring Blocks	
Audi A4	2000	8D	08 AC/Heating Electronics	Output Tests	
Audi A4	2000	8D	08 AC/Heating Electronics	Specia Functions	
Audi A4	2000	8D	11 Engine Electronics 2	Read Fault Codes	
Audi A4	2000	8D	11 Engine Electronics 2	Clear Fault Codes	
Audi A4	2000	8D	11 Engine Electronics 2	Measuring Blocks	
Audi A4	2000	8D	11 Engine Electronics 2	Output Tests	
Audi A4	2000	8D	11 Engine Electronics 2	Specia Functions	
Audi A4	2000	8D	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2000	8D	15 Airbags	Clear Fault Codes	
Audi A4	2000	8D	15 Airbags	Measuring Blocks	
Audi A4	2000	8D	15 Airbags	Output Tests	
Audi A4	2000	8D	15 Airbags	Specia Functions	
Audi A4	2000	8D	16 Steering Wheel Electronics	Read Fault Codes	
Audi A4	2000	8D	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4	2000	8D	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4	2000	8D	16 Steering Wheel Electronics	Output Tests	
Audi A4	2000	8D	16 Steering Wheel Electronics	Specia Functions	
Audi A4	2000	8D	17 Instrument Cluster	Read Fault Codes	
Audi A4	2000	8D	17 Instrument Cluster	Clear Fault Codes	
Audi A4	2000	8D	17 Instrument Cluster	Measuring Blocks	
Audi A4	2000	8D	17 Instrument Cluster	Output Tests	
Audi A4	2000	8D	17 Instrument Cluster	Specia Functions	
Audi A4	2000	8D	25 Immobilizer	Read Fault Codes	
Audi A4	2000	8D	25 Immobilizer	Clear Fault Codes	
Audi A4	2000	8D	25 Immobilizer	Measuring Blocks	
Audi A4	2000	8D	25 Immobilizer	Output Tests	
Audi A4	2000	8D	25 Immobilizer	Specia Functions	
Audi A4	2000	8D	35 Central Locking	Read Fault Codes	
Audi A4	2000	8D	35 Central Locking	Clear Fault Codes	
Audi A4	2000	8D	35 Central Locking	Measuring Blocks	
Audi A4	2000	8D	35 Central Locking	Output Tests	
Audi A4	2000	8D	35 Central Locking	Specia Functions	
Audi A4	2000	8D	37 Navigation	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2000	8D	37 Navigation	Clear Fault Codes	
Audi A4	2000	8D	37 Navigation	Measuring Blocks	
Audi A4	2000	8D	37 Navigation	Output Tests	
Audi A4	2000	8D	37 Navigation	Specia Functions	
Audi A4	2000	8D	45 Interior Monitoring	Read Fault Codes	
Audi A4	2000	8D	45 Interior Monitoring	Clear Fault Codes	
Audi A4	2000	8D	45 Interior Monitoring	Measuring Blocks	
Audi A4	2000	8D	45 Interior Monitoring	Output Tests	
Audi A4	2000	8D	45 Interior Monitoring	Specia Functions	
Audi A4	2000	8D	51 Electric Drive	Read Fault Codes	
Audi A4	2000	8D	51 Electric Drive	Clear Fault Codes	
Audi A4	2000	8D	51 Electric Drive	Measuring Blocks	
Audi A4	2000	8D	51 Electric Drive	Output Tests	
Audi A4	2000	8D	51 Electric Drive	Specia Functions	
Audi A4	2000	8D	55 Headlight Range Control	Read Fault Codes	
Audi A4	2000	8D	55 Headlight Range Control	Clear Fault Codes	
Audi A4	2000	8D	55 Headlight Range Control	Measuring Blocks	
Audi A4	2000	8D	55 Headlight Range Control	Output Tests	
Audi A4	2000	8D	55 Headlight Range Control	Specia Functions	
Audi A4	2000	8D	56 Radio	Read Fault Codes	
Audi A4	2000	8D	56 Radio	Clear Fault Codes	
Audi A4	2000	8D	56 Radio	Measuring Blocks	
Audi A4	2000	8D	56 Radio	Output Tests	
Audi A4	2000	8D	56 Radio	Specia Functions	
Audi A4	2000	8D	75 Emergency Call Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2000	8D	75 Emergency Call Module	Clear Fault Codes	
Audi A4	2000	8D	75 Emergency Call Module	Measuring Blocks	
Audi A4	2000	8D	75 Emergency Call Module	Output Tests	
Audi A4	2000	8D	75 Emergency Call Module	Specia Functions	
Audi A4	2000	8D	76 Parking Aid	Read Fault Codes	
Audi A4	2000	8D	76 Parking Aid	Clear Fault Codes	
Audi A4	2000	8D	76 Parking Aid	Measuring Blocks	
Audi A4	2000	8D	76 Parking Aid	Output Tests	
Audi A4	2000	8D	76 Parking Aid	Specia Functions	
Audi A4	2000	8D	8C Hybrid Battery	Read Fault Codes	
Audi A4	2000	8D	8C Hybrid Battery	Clear Fault Codes	
Audi A4	2000	8D	8C Hybrid Battery	Measuring Blocks	
Audi A4	2000	8D	8C Hybrid Battery	Output Tests	
Audi A4	2000	8D	8C Hybrid Battery	Specia Functions	
Audi A4	2001	8D	01 Engine Electronics	Read Fault Codes	
Audi A4	2001	8D	01 Engine Electronics	Clear Fault Codes	
Audi A4	2001	8D	01 Engine Electronics	Measuring Blocks	
Audi A4	2001	8D	01 Engine Electronics	Output Tests	
Audi A4	2001	8D	01 Engine Electronics	Specia Functions	
Audi A4	2001	8D	02 Transmission Electronics	Read Fault Codes	
Audi A4	2001	8D	02 Transmission Electronics	Clear Fault Codes	
Audi A4	2001	8D	02 Transmission Electronics	Measuring Blocks	
Audi A4	2001	8D	02 Transmission Electronics	Output Tests	
Audi A4	2001	8D	02 Transmission Electronics	Specia Functions	
Audi A4	2001	8D	03 Brake Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2001	8D	03 Brake Electronics	Clear Fault Codes	
Audi A4	2001	8D	03 Brake Electronics	Measuring Blocks	
Audi A4	2001	8D	03 Brake Electronics	Output Tests	
Audi A4	2001	8D	03 Brake Electronics	Specia Functions	
Audi A4	2001	8D	08 AC/Heating Electronics	Read Fault Codes	
Audi A4	2001	8D	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4	2001	8D	08 AC/Heating Electronics	Measuring Blocks	
Audi A4	2001	8D	08 AC/Heating Electronics	Output Tests	
Audi A4	2001	8D	08 AC/Heating Electronics	Specia Functions	
Audi A4	2001	8D	11 Engine Electronics 2	Read Fault Codes	
Audi A4	2001	8D	11 Engine Electronics 2	Clear Fault Codes	
Audi A4	2001	8D	11 Engine Electronics 2	Measuring Blocks	
Audi A4	2001	8D	11 Engine Electronics 2	Output Tests	
Audi A4	2001	8D	11 Engine Electronics 2	Specia Functions	
Audi A4	2001	8D	15 Airbags	Read Fault Codes	
Audi A4	2001	8D	15 Airbags	Clear Fault Codes	
Audi A4	2001	8D	15 Airbags	Measuring Blocks	
Audi A4	2001	8D	15 Airbags	Output Tests	
Audi A4	2001	8D	15 Airbags	Specia Functions	
Audi A4	2001	8D	16 Steering Wheel Electronics	Read Fault Codes	
Audi A4	2001	8D	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4	2001	8D	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4	2001	8D	16 Steering Wheel Electronics	Output Tests	
Audi A4	2001	8D	16 Steering Wheel Electronics	Specia Functions	
Audi A4	2001	8D	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2001	8D	17 Instrument Cluster	Clear Fault Codes	
Audi A4	2001	8D	17 Instrument Cluster	Measuring Blocks	
Audi A4	2001	8D	17 Instrument Cluster	Output Tests	
Audi A4	2001	8D	17 Instrument Cluster	Specia Functions	
Audi A4	2001	8D	25 Immobilizer	Read Fault Codes	
Audi A4	2001	8D	25 Immobilizer	Clear Fault Codes	
Audi A4	2001	8D	25 Immobilizer	Measuring Blocks	
Audi A4	2001	8D	25 Immobilizer	Output Tests	
Audi A4	2001	8D	25 Immobilizer	Specia Functions	
Audi A4	2001	8D	35 Central Locking	Read Fault Codes	
Audi A4	2001	8D	35 Central Locking	Clear Fault Codes	
Audi A4	2001	8D	35 Central Locking	Measuring Blocks	
Audi A4	2001	8D	35 Central Locking	Output Tests	
Audi A4	2001	8D	35 Central Locking	Specia Functions	
Audi A4	2001	8D	37 Navigation	Read Fault Codes	
Audi A4	2001	8D	37 Navigation	Clear Fault Codes	
Audi A4	2001	8D	37 Navigation	Measuring Blocks	
Audi A4	2001	8D	37 Navigation	Output Tests	
Audi A4	2001	8D	37 Navigation	Specia Functions	
Audi A4	2001	8D	45 Interior Monitoring	Read Fault Codes	
Audi A4	2001	8D	45 Interior Monitoring	Clear Fault Codes	
Audi A4	2001	8D	45 Interior Monitoring	Measuring Blocks	
Audi A4	2001	8D	45 Interior Monitoring	Output Tests	
Audi A4	2001	8D	45 Interior Monitoring	Specia Functions	
Audi A4	2001	8D	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2001	8D	51 Electric Drive	Clear Fault Codes	
Audi A4	2001	8D	51 Electric Drive	Measuring Blocks	
Audi A4	2001	8D	51 Electric Drive	Output Tests	
Audi A4	2001	8D	51 Electric Drive	Specia Functions	
Audi A4	2001	8D	55 Headlight Range Control	Read Fault Codes	
Audi A4	2001	8D	55 Headlight Range Control	Clear Fault Codes	
Audi A4	2001	8D	55 Headlight Range Control	Measuring Blocks	
Audi A4	2001	8D	55 Headlight Range Control	Output Tests	
Audi A4	2001	8D	55 Headlight Range Control	Specia Functions	
Audi A4	2001	8D	56 Radio	Read Fault Codes	
Audi A4	2001	8D	56 Radio	Clear Fault Codes	
Audi A4	2001	8D	56 Radio	Measuring Blocks	
Audi A4	2001	8D	56 Radio	Output Tests	
Audi A4	2001	8D	56 Radio	Specia Functions	
Audi A4	2001	8D	67 Voice Control	Read Fault Codes	
Audi A4	2001	8D	67 Voice Control	Clear Fault Codes	
Audi A4	2001	8D	67 Voice Control	Measuring Blocks	
Audi A4	2001	8D	67 Voice Control	Output Tests	
Audi A4	2001	8D	67 Voice Control	Specia Functions	
Audi A4	2001	8D	75 Emergency Call Module	Read Fault Codes	
Audi A4	2001	8D	75 Emergency Call Module	Clear Fault Codes	
Audi A4	2001	8D	75 Emergency Call Module	Measuring Blocks	
Audi A4	2001	8D	75 Emergency Call Module	Output Tests	
Audi A4	2001	8D	75 Emergency Call Module	Specia Functions	
Audi A4	2001	8D	76 Parking Aid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2001	8D	76 Parking Aid	Clear Fault Codes	
Audi A4	2001	8D	76 Parking Aid	Measuring Blocks	
Audi A4	2001	8D	76 Parking Aid	Output Tests	
Audi A4	2001	8D	76 Parking Aid	Specia Functions	
Audi A4	2001	8D	8C Hybrid Battery	Read Fault Codes	
Audi A4	2001	8D	8C Hybrid Battery	Clear Fault Codes	
Audi A4	2001	8D	8C Hybrid Battery	Measuring Blocks	
Audi A4	2001	8D	8C Hybrid Battery	Output Tests	
Audi A4	2001	8D	8C Hybrid Battery	Specia Functions	
Audi A4	2002	8D	01 Engine Electronics	Read Fault Codes	
Audi A4	2002	8D	01 Engine Electronics	Clear Fault Codes	
Audi A4	2002	8D	01 Engine Electronics	Measuring Blocks	
Audi A4	2002	8D	01 Engine Electronics	Output Tests	
Audi A4	2002	8D	01 Engine Electronics	Specia Functions	
Audi A4	2002	8D	02 Transmission Electronics	Read Fault Codes	
Audi A4	2002	8D	02 Transmission Electronics	Clear Fault Codes	
Audi A4	2002	8D	02 Transmission Electronics	Measuring Blocks	
Audi A4	2002	8D	02 Transmission Electronics	Output Tests	
Audi A4	2002	8D	02 Transmission Electronics	Specia Functions	
Audi A4	2002	8D	03 Brake Electronics	Read Fault Codes	
Audi A4	2002	8D	03 Brake Electronics	Clear Fault Codes	
Audi A4	2002	8D	03 Brake Electronics	Measuring Blocks	
Audi A4	2002	8D	03 Brake Electronics	Output Tests	
Audi A4	2002	8D	03 Brake Electronics	Specia Functions	
Audi A4	2002	8D	08 AC/Heating Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2002	8D	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4	2002	8D	08 AC/Heating Electronics	Measuring Blocks	
Audi A4	2002	8D	08 AC/Heating Electronics	Output Tests	
Audi A4	2002	8D	08 AC/Heating Electronics	Specia Functions	
Audi A4	2002	8D	11 Engine Electronics 2	Read Fault Codes	
Audi A4	2002	8D	11 Engine Electronics 2	Clear Fault Codes	
Audi A4	2002	8D	11 Engine Electronics 2	Measuring Blocks	
Audi A4	2002	8D	11 Engine Electronics 2	Output Tests	
Audi A4	2002	8D	11 Engine Electronics 2	Specia Functions	
Audi A4	2002	8D	15 Airbags	Read Fault Codes	
Audi A4	2002	8D	15 Airbags	Clear Fault Codes	
Audi A4	2002	8D	15 Airbags	Measuring Blocks	
Audi A4	2002	8D	15 Airbags	Output Tests	
Audi A4	2002	8D	15 Airbags	Specia Functions	
Audi A4	2002	8D	16 Steering Wheel Electronics	Read Fault Codes	
Audi A4	2002	8D	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4	2002	8D	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4	2002	8D	16 Steering Wheel Electronics	Output Tests	
Audi A4	2002	8D	16 Steering Wheel Electronics	Specia Functions	
Audi A4	2002	8D	17 Instrument Cluster	Read Fault Codes	
Audi A4	2002	8D	17 Instrument Cluster	Clear Fault Codes	
Audi A4	2002	8D	17 Instrument Cluster	Measuring Blocks	
Audi A4	2002	8D	17 Instrument Cluster	Output Tests	
Audi A4	2002	8D	17 Instrument Cluster	Specia Functions	
Audi A4	2002	8D	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2002	8D	25 Immobilizer	Clear Fault Codes	
Audi A4	2002	8D	25 Immobilizer	Measuring Blocks	
Audi A4	2002	8D	25 Immobilizer	Output Tests	
Audi A4	2002	8D	25 Immobilizer	Specia Functions	
Audi A4	2002	8D	35 Central Locking	Read Fault Codes	
Audi A4	2002	8D	35 Central Locking	Clear Fault Codes	
Audi A4	2002	8D	35 Central Locking	Measuring Blocks	
Audi A4	2002	8D	35 Central Locking	Output Tests	
Audi A4	2002	8D	35 Central Locking	Specia Functions	
Audi A4	2002	8D	37 Navigation	Read Fault Codes	
Audi A4	2002	8D	37 Navigation	Clear Fault Codes	
Audi A4	2002	8D	37 Navigation	Measuring Blocks	
Audi A4	2002	8D	37 Navigation	Output Tests	
Audi A4	2002	8D	37 Navigation	Specia Functions	
Audi A4	2002	8D	45 Interior Monitoring	Read Fault Codes	
Audi A4	2002	8D	45 Interior Monitoring	Clear Fault Codes	
Audi A4	2002	8D	45 Interior Monitoring	Measuring Blocks	
Audi A4	2002	8D	45 Interior Monitoring	Output Tests	
Audi A4	2002	8D	45 Interior Monitoring	Specia Functions	
Audi A4	2002	8D	51 Electric Drive	Read Fault Codes	
Audi A4	2002	8D	51 Electric Drive	Clear Fault Codes	
Audi A4	2002	8D	51 Electric Drive	Measuring Blocks	
Audi A4	2002	8D	51 Electric Drive	Output Tests	
Audi A4	2002	8D	51 Electric Drive	Specia Functions	
Audi A4	2002	8D	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2002	8D	55 Headlight Range Control	Clear Fault Codes	
Audi A4	2002	8D	55 Headlight Range Control	Measuring Blocks	
Audi A4	2002	8D	55 Headlight Range Control	Output Tests	
Audi A4	2002	8D	55 Headlight Range Control	Specia Functions	
Audi A4	2002	8D	56 Radio	Read Fault Codes	
Audi A4	2002	8D	56 Radio	Clear Fault Codes	
Audi A4	2002	8D	56 Radio	Measuring Blocks	
Audi A4	2002	8D	56 Radio	Output Tests	
Audi A4	2002	8D	56 Radio	Specia Functions	
Audi A4	2002	8D	67 Voice Control	Read Fault Codes	
Audi A4	2002	8D	67 Voice Control	Clear Fault Codes	
Audi A4	2002	8D	67 Voice Control	Measuring Blocks	
Audi A4	2002	8D	67 Voice Control	Output Tests	
Audi A4	2002	8D	67 Voice Control	Specia Functions	
Audi A4	2002	8D	75 Emergency Call Module	Read Fault Codes	
Audi A4	2002	8D	75 Emergency Call Module	Clear Fault Codes	
Audi A4	2002	8D	75 Emergency Call Module	Measuring Blocks	
Audi A4	2002	8D	75 Emergency Call Module	Output Tests	
Audi A4	2002	8D	75 Emergency Call Module	Specia Functions	
Audi A4	2002	8D	76 Parking Aid	Read Fault Codes	
Audi A4	2002	8D	76 Parking Aid	Clear Fault Codes	
Audi A4	2002	8D	76 Parking Aid	Measuring Blocks	
Audi A4	2002	8D	76 Parking Aid	Output Tests	
Audi A4	2002	8D	76 Parking Aid	Specia Functions	
Audi A4	2002	8D	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2002	8D	8C Hybrid Battery	Clear Fault Codes	
Audi A4	2002	8D	8C Hybrid Battery	Measuring Blocks	
Audi A4	2002	8D	8C Hybrid Battery	Output Tests	
Audi A4	2002	8D	8C Hybrid Battery	Specia Functions	
Audi A6	1996-1999	4B	01 Engine Electronics	Read Fault Codes	
Audi A6	1996-1999	4B	01 Engine Electronics	Clear Fault Codes	
Audi A6	1996-1999	4B	01 Engine Electronics	Measuring Blocks	
Audi A6	1996-1999	4B	01 Engine Electronics	Output Tests	
Audi A6	1996-1999	4B	01 Engine Electronics	Specia Functions	
Audi A6	1996-1999	4B	02 Transmission Electronics	Read Fault Codes	
Audi A6	1996-1999	4B	02 Transmission Electronics	Clear Fault Codes	
Audi A6	1996-1999	4B	02 Transmission Electronics	Measuring Blocks	
Audi A6	1996-1999	4B	02 Transmission Electronics	Output Tests	
Audi A6	1996-1999	4B	02 Transmission Electronics	Specia Functions	
Audi A6	1996-1999	4B	03 Brake Electronics	Read Fault Codes	
Audi A6	1996-1999	4B	03 Brake Electronics	Clear Fault Codes	
Audi A6	1996-1999	4B	03 Brake Electronics	Measuring Blocks	
Audi A6	1996-1999	4B	03 Brake Electronics	Output Tests	
Audi A6	1996-1999	4B	03 Brake Electronics	Specia Functions	
Audi A6	1996-1999	4B	08 AC/Heating Electronics	Read Fault Codes	
Audi A6	1996-1999	4B	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	1996-1999	4B	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	1996-1999	4B	08 AC/Heating Electronics	Output Tests	
Audi A6	1996-1999	4B	08 AC/Heating Electronics	Specia Functions	
Audi A6	1996-1999	4B	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	1996-1999	4B	11 Engine Electronics 2	Clear Fault Codes	
Audi A6	1996-1999	4B	11 Engine Electronics 2	Measuring Blocks	
Audi A6	1996-1999	4B	11 Engine Electronics 2	Output Tests	
Audi A6	1996-1999	4B	11 Engine Electronics 2	Specia Functions	
Audi A6	1996-1999	4B	15 Airbags	Read Fault Codes	
Audi A6	1996-1999	4B	15 Airbags	Clear Fault Codes	
Audi A6	1996-1999	4B	15 Airbags	Measuring Blocks	
Audi A6	1996-1999	4B	15 Airbags	Output Tests	
Audi A6	1996-1999	4B	15 Airbags	Specia Functions	
Audi A6	1996-1999	4B	17 Instrument Cluster	Read Fault Codes	
Audi A6	1996-1999	4B	17 Instrument Cluster	Clear Fault Codes	
Audi A6	1996-1999	4B	17 Instrument Cluster	Measuring Blocks	
Audi A6	1996-1999	4B	17 Instrument Cluster	Output Tests	
Audi A6	1996-1999	4B	17 Instrument Cluster	Specia Functions	
Audi A6	1996-1999	4B	18 Aux Heating	Read Fault Codes	
Audi A6	1996-1999	4B	18 Aux Heating	Clear Fault Codes	
Audi A6	1996-1999	4B	18 Aux Heating	Measuring Blocks	
Audi A6	1996-1999	4B	18 Aux Heating	Output Tests	
Audi A6	1996-1999	4B	18 Aux Heating	Specia Functions	
Audi A6	1996-1999	4B	25 Immobilizer	Read Fault Codes	
Audi A6	1996-1999	4B	25 Immobilizer	Clear Fault Codes	
Audi A6	1996-1999	4B	25 Immobilizer	Measuring Blocks	
Audi A6	1996-1999	4B	25 Immobilizer	Output Tests	
Audi A6	1996-1999	4B	25 Immobilizer	Specia Functions	
Audi A6	1996-1999	4B	34 Self Leveling Suspension	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	1996-1999	4B	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	1996-1999	4B	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	1996-1999	4B	34 Self Leveling Suspension	Output Tests	
Audi A6	1996-1999	4B	34 Self Leveling Suspension	Specia Functions	
Audi A6	1996-1999	4B	35 Central Locking	Read Fault Codes	
Audi A6	1996-1999	4B	35 Central Locking	Clear Fault Codes	
Audi A6	1996-1999	4B	35 Central Locking	Measuring Blocks	
Audi A6	1996-1999	4B	35 Central Locking	Output Tests	
Audi A6	1996-1999	4B	35 Central Locking	Specia Functions	
Audi A6	1996-1999	4B	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A6	1996-1999	4B	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	1996-1999	4B	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	1996-1999	4B	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	1996-1999	4B	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	1996-1999	4B	37 Navigation	Read Fault Codes	
Audi A6	1996-1999	4B	37 Navigation	Clear Fault Codes	
Audi A6	1996-1999	4B	37 Navigation	Measuring Blocks	
Audi A6	1996-1999	4B	37 Navigation	Output Tests	
Audi A6	1996-1999	4B	37 Navigation	Specia Functions	
Audi A6	1996-1999	4B	45 Interior Monitoring	Read Fault Codes	
Audi A6	1996-1999	4B	45 Interior Monitoring	Clear Fault Codes	
Audi A6	1996-1999	4B	45 Interior Monitoring	Measuring Blocks	
Audi A6	1996-1999	4B	45 Interior Monitoring	Output Tests	
Audi A6	1996-1999	4B	45 Interior Monitoring	Specia Functions	
Audi A6	1996-1999	4B	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	1996-1999	4B	51 Electric Drive	Clear Fault Codes	
Audi A6	1996-1999	4B	51 Electric Drive	Measuring Blocks	
Audi A6	1996-1999	4B	51 Electric Drive	Output Tests	
Audi A6	1996-1999	4B	51 Electric Drive	Specia Functions	
Audi A6	1996-1999	4B	55 Headlight Range Control	Read Fault Codes	
Audi A6	1996-1999	4B	55 Headlight Range Control	Clear Fault Codes	
Audi A6	1996-1999	4B	55 Headlight Range Control	Measuring Blocks	
Audi A6	1996-1999	4B	55 Headlight Range Control	Output Tests	
Audi A6	1996-1999	4B	55 Headlight Range Control	Specia Functions	
Audi A6	1996-1999	4B	56 Radio	Read Fault Codes	
Audi A6	1996-1999	4B	56 Radio	Clear Fault Codes	
Audi A6	1996-1999	4B	56 Radio	Measuring Blocks	
Audi A6	1996-1999	4B	56 Radio	Output Tests	
Audi A6	1996-1999	4B	56 Radio	Specia Functions	
Audi A6	1996-1999	4B	76 Parking Aid	Read Fault Codes	
Audi A6	1996-1999	4B	76 Parking Aid	Clear Fault Codes	
Audi A6	1996-1999	4B	76 Parking Aid	Measuring Blocks	
Audi A6	1996-1999	4B	76 Parking Aid	Output Tests	
Audi A6	1996-1999	4B	76 Parking Aid	Specia Functions	
Audi A6	1996-1999	4B	8C Hybrid Battery	Read Fault Codes	
Audi A6	1996-1999	4B	8C Hybrid Battery	Clear Fault Codes	
Audi A6	1996-1999	4B	8C Hybrid Battery	Measuring Blocks	
Audi A6	1996-1999	4B	8C Hybrid Battery	Output Tests	
Audi A6	1996-1999	4B	8C Hybrid Battery	Specia Functions	
Audi A6	2000	4B	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2000	4B	01 Engine Electronics	Clear Fault Codes	
Audi A6	2000	4B	01 Engine Electronics	Measuring Blocks	
Audi A6	2000	4B	01 Engine Electronics	Output Tests	
Audi A6	2000	4B	01 Engine Electronics	Specia Functions	
Audi A6	2000	4B	02 Transmission Electronics	Read Fault Codes	
Audi A6	2000	4B	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2000	4B	02 Transmission Electronics	Measuring Blocks	
Audi A6	2000	4B	02 Transmission Electronics	Output Tests	
Audi A6	2000	4B	02 Transmission Electronics	Specia Functions	
Audi A6	2000	4B	03 Brake Electronics	Read Fault Codes	
Audi A6	2000	4B	03 Brake Electronics	Clear Fault Codes	
Audi A6	2000	4B	03 Brake Electronics	Measuring Blocks	
Audi A6	2000	4B	03 Brake Electronics	Output Tests	
Audi A6	2000	4B	03 Brake Electronics	Specia Functions	
Audi A6	2000	4B	08 AC/Heating Electronics	Read Fault Codes	
Audi A6	2000	4B	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	2000	4B	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	2000	4B	08 AC/Heating Electronics	Output Tests	
Audi A6	2000	4B	08 AC/Heating Electronics	Specia Functions	
Audi A6	2000	4B	11 Engine Electronics 2	Read Fault Codes	
Audi A6	2000	4B	11 Engine Electronics 2	Clear Fault Codes	
Audi A6	2000	4B	11 Engine Electronics 2	Measuring Blocks	
Audi A6	2000	4B	11 Engine Electronics 2	Output Tests	
Audi A6	2000	4B	11 Engine Electronics 2	Specia Functions	
Audi A6	2000	4B	15 Airbags	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2000	4B	15 Airbags	Clear Fault Codes	
Audi A6	2000	4B	15 Airbags	Measuring Blocks	
Audi A6	2000	4B	15 Airbags	Output Tests	
Audi A6	2000	4B	15 Airbags	Specia Functions	
Audi A6	2000	4B	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2000	4B	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2000	4B	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2000	4B	16 Steering Wheel Electronics	Output Tests	
Audi A6	2000	4B	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2000	4B	17 Instrument Cluster	Read Fault Codes	
Audi A6	2000	4B	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2000	4B	17 Instrument Cluster	Measuring Blocks	
Audi A6	2000	4B	17 Instrument Cluster	Output Tests	
Audi A6	2000	4B	17 Instrument Cluster	Specia Functions	
Audi A6	2000	4B	18 Aux Heating	Read Fault Codes	
Audi A6	2000	4B	18 Aux Heating	Clear Fault Codes	
Audi A6	2000	4B	18 Aux Heating	Measuring Blocks	
Audi A6	2000	4B	18 Aux Heating	Output Tests	
Audi A6	2000	4B	18 Aux Heating	Specia Functions	
Audi A6	2000	4B	22 4WD Electronics	Read Fault Codes	
Audi A6	2000	4B	22 4WD Electronics	Clear Fault Codes	
Audi A6	2000	4B	22 4WD Electronics	Measuring Blocks	
Audi A6	2000	4B	22 4WD Electronics	Output Tests	
Audi A6	2000	4B	22 4WD Electronics	Specia Functions	
Audi A6	2000	4B	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2000	4B	25 Immobilizer	Clear Fault Codes	
Audi A6	2000	4B	25 Immobilizer	Measuring Blocks	
Audi A6	2000	4B	25 Immobilizer	Output Tests	
Audi A6	2000	4B	25 Immobilizer	Specia Functions	
Audi A6	2000	4B	34 Self Leveling Suspension	Read Fault Codes	
Audi A6	2000	4B	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	2000	4B	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	2000	4B	34 Self Leveling Suspension	Output Tests	
Audi A6	2000	4B	34 Self Leveling Suspension	Specia Functions	
Audi A6	2000	4B	35 Central Locking	Read Fault Codes	
Audi A6	2000	4B	35 Central Locking	Clear Fault Codes	
Audi A6	2000	4B	35 Central Locking	Measuring Blocks	
Audi A6	2000	4B	35 Central Locking	Output Tests	
Audi A6	2000	4B	35 Central Locking	Specia Functions	
Audi A6	2000	4B	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A6	2000	4B	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	2000	4B	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	2000	4B	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	2000	4B	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	2000	4B	37 Navigation	Read Fault Codes	
Audi A6	2000	4B	37 Navigation	Clear Fault Codes	
Audi A6	2000	4B	37 Navigation	Measuring Blocks	
Audi A6	2000	4B	37 Navigation	Output Tests	
Audi A6	2000	4B	37 Navigation	Specia Functions	
Audi A6	2000	4B	45 Interior Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2000	4B	45 Interior Monitoring	Clear Fault Codes	
Audi A6	2000	4B	45 Interior Monitoring	Measuring Blocks	
Audi A6	2000	4B	45 Interior Monitoring	Output Tests	
Audi A6	2000	4B	45 Interior Monitoring	Specia Functions	
Audi A6	2000	4B	51 Electric Drive	Read Fault Codes	
Audi A6	2000	4B	51 Electric Drive	Clear Fault Codes	
Audi A6	2000	4B	51 Electric Drive	Measuring Blocks	
Audi A6	2000	4B	51 Electric Drive	Output Tests	
Audi A6	2000	4B	51 Electric Drive	Specia Functions	
Audi A6	2000	4B	55 Headlight Range Control	Read Fault Codes	
Audi A6	2000	4B	55 Headlight Range Control	Clear Fault Codes	
Audi A6	2000	4B	55 Headlight Range Control	Measuring Blocks	
Audi A6	2000	4B	55 Headlight Range Control	Output Tests	
Audi A6	2000	4B	55 Headlight Range Control	Specia Functions	
Audi A6	2000	4B	56 Radio	Read Fault Codes	
Audi A6	2000	4B	56 Radio	Clear Fault Codes	
Audi A6	2000	4B	56 Radio	Measuring Blocks	
Audi A6	2000	4B	56 Radio	Output Tests	
Audi A6	2000	4B	56 Radio	Specia Functions	
Audi A6	2000	4B	75 Emergency Call Module	Read Fault Codes	
Audi A6	2000	4B	75 Emergency Call Module	Clear Fault Codes	
Audi A6	2000	4B	75 Emergency Call Module	Measuring Blocks	
Audi A6	2000	4B	75 Emergency Call Module	Output Tests	
Audi A6	2000	4B	75 Emergency Call Module	Specia Functions	
Audi A6	2000	4B	76 Parking Aid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2000	4B	76 Parking Aid	Clear Fault Codes	
Audi A6	2000	4B	76 Parking Aid	Measuring Blocks	
Audi A6	2000	4B	76 Parking Aid	Output Tests	
Audi A6	2000	4B	76 Parking Aid	Specia Functions	
Audi A6	2000	4B	8C Hybrid Battery	Read Fault Codes	
Audi A6	2000	4B	8C Hybrid Battery	Clear Fault Codes	
Audi A6	2000	4B	8C Hybrid Battery	Measuring Blocks	
Audi A6	2000	4B	8C Hybrid Battery	Output Tests	
Audi A6	2000	4B	8C Hybrid Battery	Specia Functions	
Audi A6	2001	4B	01 Engine Electronics	Read Fault Codes	
Audi A6	2001	4B	01 Engine Electronics	Clear Fault Codes	
Audi A6	2001	4B	01 Engine Electronics	Measuring Blocks	
Audi A6	2001	4B	01 Engine Electronics	Output Tests	
Audi A6	2001	4B	01 Engine Electronics	Specia Functions	
Audi A6	2001	4B	02 Transmission Electronics	Read Fault Codes	
Audi A6	2001	4B	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2001	4B	02 Transmission Electronics	Measuring Blocks	
Audi A6	2001	4B	02 Transmission Electronics	Output Tests	
Audi A6	2001	4B	02 Transmission Electronics	Specia Functions	
Audi A6	2001	4B	03 Brake Electronics	Read Fault Codes	
Audi A6	2001	4B	03 Brake Electronics	Clear Fault Codes	
Audi A6	2001	4B	03 Brake Electronics	Measuring Blocks	
Audi A6	2001	4B	03 Brake Electronics	Output Tests	
Audi A6	2001	4B	03 Brake Electronics	Specia Functions	
Audi A6	2001	4B	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2001	4B	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	2001	4B	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	2001	4B	08 AC/Heating Electronics	Output Tests	
Audi A6	2001	4B	08 AC/Heating Electronics	Specia Functions	
Audi A6	2001	4B	11 Engine Electronics 2	Read Fault Codes	
Audi A6	2001	4B	11 Engine Electronics 2	Clear Fault Codes	
Audi A6	2001	4B	11 Engine Electronics 2	Measuring Blocks	
Audi A6	2001	4B	11 Engine Electronics 2	Output Tests	
Audi A6	2001	4B	11 Engine Electronics 2	Specia Functions	
Audi A6	2001	4B	15 Airbags	Read Fault Codes	
Audi A6	2001	4B	15 Airbags	Clear Fault Codes	
Audi A6	2001	4B	15 Airbags	Measuring Blocks	
Audi A6	2001	4B	15 Airbags	Output Tests	
Audi A6	2001	4B	15 Airbags	Specia Functions	
Audi A6	2001	4B	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2001	4B	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2001	4B	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2001	4B	16 Steering Wheel Electronics	Output Tests	
Audi A6	2001	4B	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2001	4B	17 Instrument Cluster	Read Fault Codes	
Audi A6	2001	4B	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2001	4B	17 Instrument Cluster	Measuring Blocks	
Audi A6	2001	4B	17 Instrument Cluster	Output Tests	
Audi A6	2001	4B	17 Instrument Cluster	Specia Functions	
Audi A6	2001	4B	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2001	4B	18 Aux Heating	Clear Fault Codes	
Audi A6	2001	4B	18 Aux Heating	Measuring Blocks	
Audi A6	2001	4B	18 Aux Heating	Output Tests	
Audi A6	2001	4B	18 Aux Heating	Specia Functions	
Audi A6	2001	4B	22 4WD Electronics	Read Fault Codes	
Audi A6	2001	4B	22 4WD Electronics	Clear Fault Codes	
Audi A6	2001	4B	22 4WD Electronics	Measuring Blocks	
Audi A6	2001	4B	22 4WD Electronics	Output Tests	
Audi A6	2001	4B	22 4WD Electronics	Specia Functions	
Audi A6	2001	4B	25 Immobilizer	Read Fault Codes	
Audi A6	2001	4B	25 Immobilizer	Clear Fault Codes	
Audi A6	2001	4B	25 Immobilizer	Measuring Blocks	
Audi A6	2001	4B	25 Immobilizer	Output Tests	
Audi A6	2001	4B	25 Immobilizer	Specia Functions	
Audi A6	2001	4B	34 Self Leveling Suspension	Read Fault Codes	
Audi A6	2001	4B	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	2001	4B	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	2001	4B	34 Self Leveling Suspension	Output Tests	
Audi A6	2001	4B	34 Self Leveling Suspension	Specia Functions	
Audi A6	2001	4B	35 Central Locking	Read Fault Codes	
Audi A6	2001	4B	35 Central Locking	Clear Fault Codes	
Audi A6	2001	4B	35 Central Locking	Measuring Blocks	
Audi A6	2001	4B	35 Central Locking	Output Tests	
Audi A6	2001	4B	35 Central Locking	Specia Functions	
Audi A6	2001	4B	36 Side of Driver Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2001	4B	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	2001	4B	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	2001	4B	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	2001	4B	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	2001	4B	37 Navigation	Read Fault Codes	
Audi A6	2001	4B	37 Navigation	Clear Fault Codes	
Audi A6	2001	4B	37 Navigation	Measuring Blocks	
Audi A6	2001	4B	37 Navigation	Output Tests	
Audi A6	2001	4B	37 Navigation	Specia Functions	
Audi A6	2001	4B	45 Interior Monitoring	Read Fault Codes	
Audi A6	2001	4B	45 Interior Monitoring	Clear Fault Codes	
Audi A6	2001	4B	45 Interior Monitoring	Measuring Blocks	
Audi A6	2001	4B	45 Interior Monitoring	Output Tests	
Audi A6	2001	4B	45 Interior Monitoring	Specia Functions	
Audi A6	2001	4B	51 Electric Drive	Read Fault Codes	
Audi A6	2001	4B	51 Electric Drive	Clear Fault Codes	
Audi A6	2001	4B	51 Electric Drive	Measuring Blocks	
Audi A6	2001	4B	51 Electric Drive	Output Tests	
Audi A6	2001	4B	51 Electric Drive	Specia Functions	
Audi A6	2001	4B	55 Headlight Range Control	Read Fault Codes	
Audi A6	2001	4B	55 Headlight Range Control	Clear Fault Codes	
Audi A6	2001	4B	55 Headlight Range Control	Measuring Blocks	
Audi A6	2001	4B	55 Headlight Range Control	Output Tests	
Audi A6	2001	4B	55 Headlight Range Control	Specia Functions	
Audi A6	2001	4B	56 Radio	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2001	4B	56 Radio	Clear Fault Codes	
Audi A6	2001	4B	56 Radio	Measuring Blocks	
Audi A6	2001	4B	56 Radio	Output Tests	
Audi A6	2001	4B	56 Radio	Specia Functions	
Audi A6	2001	4B	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6	2001	4B	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6	2001	4B	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6	2001	4B	65 Tyre Pressure Monitoring	Output Tests	
Audi A6	2001	4B	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6	2001	4B	67 Voice Control	Read Fault Codes	
Audi A6	2001	4B	67 Voice Control	Clear Fault Codes	
Audi A6	2001	4B	67 Voice Control	Measuring Blocks	
Audi A6	2001	4B	67 Voice Control	Output Tests	
Audi A6	2001	4B	67 Voice Control	Specia Functions	
Audi A6	2001	4B	75 Emergency Call Module	Read Fault Codes	
Audi A6	2001	4B	75 Emergency Call Module	Clear Fault Codes	
Audi A6	2001	4B	75 Emergency Call Module	Measuring Blocks	
Audi A6	2001	4B	75 Emergency Call Module	Output Tests	
Audi A6	2001	4B	75 Emergency Call Module	Specia Functions	
Audi A6	2001	4B	76 Parking Aid	Read Fault Codes	
Audi A6	2001	4B	76 Parking Aid	Clear Fault Codes	
Audi A6	2001	4B	76 Parking Aid	Measuring Blocks	
Audi A6	2001	4B	76 Parking Aid	Output Tests	
Audi A6	2001	4B	76 Parking Aid	Specia Functions	
Audi A6	2001	4B	8C Hybrid Battery	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2001	4B	8C Hybrid Battery	Clear Fault Codes	
Audi A6	2001	4B	8C Hybrid Battery	Measuring Blocks	
Audi A6	2001	4B	8C Hybrid Battery	Output Tests	
Audi A6	2001	4B	8C Hybrid Battery	Specia Functions	
Audi A6	2002	4B	01 Engine Electronics	Read Fault Codes	
Audi A6	2002	4B	01 Engine Electronics	Clear Fault Codes	
Audi A6	2002	4B	01 Engine Electronics	Measuring Blocks	
Audi A6	2002	4B	01 Engine Electronics	Output Tests	
Audi A6	2002	4B	01 Engine Electronics	Specia Functions	
Audi A6	2002	4B	02 Transmission Electronics	Read Fault Codes	
Audi A6	2002	4B	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2002	4B	02 Transmission Electronics	Measuring Blocks	
Audi A6	2002	4B	02 Transmission Electronics	Output Tests	
Audi A6	2002	4B	02 Transmission Electronics	Specia Functions	
Audi A6	2002	4B	03 Brake Electronics	Read Fault Codes	
Audi A6	2002	4B	03 Brake Electronics	Clear Fault Codes	
Audi A6	2002	4B	03 Brake Electronics	Measuring Blocks	
Audi A6	2002	4B	03 Brake Electronics	Output Tests	
Audi A6	2002	4B	03 Brake Electronics	Specia Functions	
Audi A6	2002	4B	06 Passene. Seat Adj.	Read Fault Codes	
Audi A6	2002	4B	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6	2002	4B	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6	2002	4B	06 Passene. Seat Adj.	Output Tests	
Audi A6	2002	4B	06 Passene. Seat Adj.	Specia Functions	
Audi A6	2002	4B	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2002	4B	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	2002	4B	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	2002	4B	08 AC/Heating Electronics	Output Tests	
Audi A6	2002	4B	08 AC/Heating Electronics	Specia Functions	
Audi A6	2002	4B	11 Engine Electronics 2	Read Fault Codes	
Audi A6	2002	4B	11 Engine Electronics 2	Clear Fault Codes	
Audi A6	2002	4B	11 Engine Electronics 2	Measuring Blocks	
Audi A6	2002	4B	11 Engine Electronics 2	Output Tests	
Audi A6	2002	4B	11 Engine Electronics 2	Specia Functions	
Audi A6	2002	4B	15 Airbags	Read Fault Codes	
Audi A6	2002	4B	15 Airbags	Clear Fault Codes	
Audi A6	2002	4B	15 Airbags	Measuring Blocks	
Audi A6	2002	4B	15 Airbags	Output Tests	
Audi A6	2002	4B	15 Airbags	Specia Functions	
Audi A6	2002	4B	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2002	4B	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2002	4B	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2002	4B	16 Steering Wheel Electronics	Output Tests	
Audi A6	2002	4B	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2002	4B	17 Instrument Cluster	Read Fault Codes	
Audi A6	2002	4B	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2002	4B	17 Instrument Cluster	Measuring Blocks	
Audi A6	2002	4B	17 Instrument Cluster	Output Tests	
Audi A6	2002	4B	17 Instrument Cluster	Specia Functions	
Audi A6	2002	4B	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2002	4B	18 Aux Heating	Clear Fault Codes	
Audi A6	2002	4B	18 Aux Heating	Measuring Blocks	
Audi A6	2002	4B	18 Aux Heating	Output Tests	
Audi A6	2002	4B	18 Aux Heating	Specia Functions	
Audi A6	2002	4B	22 4WD Electronics	Read Fault Codes	
Audi A6	2002	4B	22 4WD Electronics	Clear Fault Codes	
Audi A6	2002	4B	22 4WD Electronics	Measuring Blocks	
Audi A6	2002	4B	22 4WD Electronics	Output Tests	
Audi A6	2002	4B	22 4WD Electronics	Specia Functions	
Audi A6	2002	4B	25 Immobilizer	Read Fault Codes	
Audi A6	2002	4B	25 Immobilizer	Clear Fault Codes	
Audi A6	2002	4B	25 Immobilizer	Measuring Blocks	
Audi A6	2002	4B	25 Immobilizer	Output Tests	
Audi A6	2002	4B	25 Immobilizer	Specia Functions	
Audi A6	2002	4B	34 Self Leveling Suspension	Read Fault Codes	
Audi A6	2002	4B	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	2002	4B	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	2002	4B	34 Self Leveling Suspension	Output Tests	
Audi A6	2002	4B	34 Self Leveling Suspension	Specia Functions	
Audi A6	2002	4B	35 Central Locking	Read Fault Codes	
Audi A6	2002	4B	35 Central Locking	Clear Fault Codes	
Audi A6	2002	4B	35 Central Locking	Measuring Blocks	
Audi A6	2002	4B	35 Central Locking	Output Tests	
Audi A6	2002	4B	35 Central Locking	Specia Functions	
Audi A6	2002	4B	36 Side of Driver Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2002	4B	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	2002	4B	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	2002	4B	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	2002	4B	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	2002	4B	37 Navigation	Read Fault Codes	
Audi A6	2002	4B	37 Navigation	Clear Fault Codes	
Audi A6	2002	4B	37 Navigation	Measuring Blocks	
Audi A6	2002	4B	37 Navigation	Output Tests	
Audi A6	2002	4B	37 Navigation	Specia Functions	
Audi A6	2002	4B	45 Interior Monitoring	Read Fault Codes	
Audi A6	2002	4B	45 Interior Monitoring	Clear Fault Codes	
Audi A6	2002	4B	45 Interior Monitoring	Measuring Blocks	
Audi A6	2002	4B	45 Interior Monitoring	Output Tests	
Audi A6	2002	4B	45 Interior Monitoring	Specia Functions	
Audi A6	2002	4B	51 Electric Drive	Read Fault Codes	
Audi A6	2002	4B	51 Electric Drive	Clear Fault Codes	
Audi A6	2002	4B	51 Electric Drive	Measuring Blocks	
Audi A6	2002	4B	51 Electric Drive	Output Tests	
Audi A6	2002	4B	51 Electric Drive	Specia Functions	
Audi A6	2002	4B	55 Headlight Range Control	Read Fault Codes	
Audi A6	2002	4B	55 Headlight Range Control	Clear Fault Codes	
Audi A6	2002	4B	55 Headlight Range Control	Measuring Blocks	
Audi A6	2002	4B	55 Headlight Range Control	Output Tests	
Audi A6	2002	4B	55 Headlight Range Control	Specia Functions	
Audi A6	2002	4B	56 Radio	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2002	4B	56 Radio	Clear Fault Codes	
Audi A6	2002	4B	56 Radio	Measuring Blocks	
Audi A6	2002	4B	56 Radio	Output Tests	
Audi A6	2002	4B	56 Radio	Specia Functions	
Audi A6	2002	4B	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6	2002	4B	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6	2002	4B	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6	2002	4B	65 Tyre Pressure Monitoring	Output Tests	
Audi A6	2002	4B	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6	2002	4B	67 Voice Control	Read Fault Codes	
Audi A6	2002	4B	67 Voice Control	Clear Fault Codes	
Audi A6	2002	4B	67 Voice Control	Measuring Blocks	
Audi A6	2002	4B	67 Voice Control	Output Tests	
Audi A6	2002	4B	67 Voice Control	Specia Functions	
Audi A6	2002	4B	75 Emergency Call Module	Read Fault Codes	
Audi A6	2002	4B	75 Emergency Call Module	Clear Fault Codes	
Audi A6	2002	4B	75 Emergency Call Module	Measuring Blocks	
Audi A6	2002	4B	75 Emergency Call Module	Output Tests	
Audi A6	2002	4B	75 Emergency Call Module	Specia Functions	
Audi A6	2002	4B	76 Parking Aid	Read Fault Codes	
Audi A6	2002	4B	76 Parking Aid	Clear Fault Codes	
Audi A6	2002	4B	76 Parking Aid	Measuring Blocks	
Audi A6	2002	4B	76 Parking Aid	Output Tests	
Audi A6	2002	4B	76 Parking Aid	Specia Functions	
Audi A6	2002	4B	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2002	4B	77 Telephone	Clear Fault Codes	
Audi A6	2002	4B	77 Telephone	Measuring Blocks	
Audi A6	2002	4B	77 Telephone	Output Tests	
Audi A6	2002	4B	77 Telephone	Specia Functions	
Audi A6	2002	4B	8C Hybrid Battery	Read Fault Codes	
Audi A6	2002	4B	8C Hybrid Battery	Clear Fault Codes	
Audi A6	2002	4B	8C Hybrid Battery	Measuring Blocks	
Audi A6	2002	4B	8C Hybrid Battery	Output Tests	
Audi A6	2002	4B	8C Hybrid Battery	Specia Functions	
Audi A6	2003	4B	01 Engine Electronics	Read Fault Codes	
Audi A6	2003	4B	01 Engine Electronics	Clear Fault Codes	
Audi A6	2003	4B	01 Engine Electronics	Measuring Blocks	
Audi A6	2003	4B	01 Engine Electronics	Output Tests	
Audi A6	2003	4B	01 Engine Electronics	Specia Functions	
Audi A6	2003	4B	02 Transmission Electronics	Read Fault Codes	
Audi A6	2003	4B	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2003	4B	02 Transmission Electronics	Measuring Blocks	
Audi A6	2003	4B	02 Transmission Electronics	Output Tests	
Audi A6	2003	4B	02 Transmission Electronics	Specia Functions	
Audi A6	2003	4B	03 Brake Electronics	Read Fault Codes	
Audi A6	2003	4B	03 Brake Electronics	Clear Fault Codes	
Audi A6	2003	4B	03 Brake Electronics	Measuring Blocks	
Audi A6	2003	4B	03 Brake Electronics	Output Tests	
Audi A6	2003	4B	03 Brake Electronics	Specia Functions	
Audi A6	2003	4B	06 Passene. Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2003	4B	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6	2003	4B	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6	2003	4B	06 Passene. Seat Adj.	Output Tests	
Audi A6	2003	4B	06 Passene. Seat Adj.	Specia Functions	
Audi A6	2003	4B	08 AC/Heating Electronics	Read Fault Codes	
Audi A6	2003	4B	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	2003	4B	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	2003	4B	08 AC/Heating Electronics	Output Tests	
Audi A6	2003	4B	08 AC/Heating Electronics	Specia Functions	
Audi A6	2003	4B	11 Engine Electronics 2	Read Fault Codes	
Audi A6	2003	4B	11 Engine Electronics 2	Clear Fault Codes	
Audi A6	2003	4B	11 Engine Electronics 2	Measuring Blocks	
Audi A6	2003	4B	11 Engine Electronics 2	Output Tests	
Audi A6	2003	4B	11 Engine Electronics 2	Specia Functions	
Audi A6	2003	4B	15 Airbags	Read Fault Codes	
Audi A6	2003	4B	15 Airbags	Clear Fault Codes	
Audi A6	2003	4B	15 Airbags	Measuring Blocks	
Audi A6	2003	4B	15 Airbags	Output Tests	
Audi A6	2003	4B	15 Airbags	Specia Functions	
Audi A6	2003	4B	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2003	4B	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2003	4B	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2003	4B	16 Steering Wheel Electronics	Output Tests	
Audi A6	2003	4B	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2003	4B	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2003	4B	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2003	4B	17 Instrument Cluster	Measuring Blocks	
Audi A6	2003	4B	17 Instrument Cluster	Output Tests	
Audi A6	2003	4B	17 Instrument Cluster	Specia Functions	
Audi A6	2003	4B	18 Aux Heating	Read Fault Codes	
Audi A6	2003	4B	18 Aux Heating	Clear Fault Codes	
Audi A6	2003	4B	18 Aux Heating	Measuring Blocks	
Audi A6	2003	4B	18 Aux Heating	Output Tests	
Audi A6	2003	4B	18 Aux Heating	Specia Functions	
Audi A6	2003	4B	22 4WD Electronics	Read Fault Codes	
Audi A6	2003	4B	22 4WD Electronics	Clear Fault Codes	
Audi A6	2003	4B	22 4WD Electronics	Measuring Blocks	
Audi A6	2003	4B	22 4WD Electronics	Output Tests	
Audi A6	2003	4B	22 4WD Electronics	Specia Functions	
Audi A6	2003	4B	25 Immobilizer	Read Fault Codes	
Audi A6	2003	4B	25 Immobilizer	Clear Fault Codes	
Audi A6	2003	4B	25 Immobilizer	Measuring Blocks	
Audi A6	2003	4B	25 Immobilizer	Output Tests	
Audi A6	2003	4B	25 Immobilizer	Specia Functions	
Audi A6	2003	4B	34 Self Leveling Suspension	Read Fault Codes	
Audi A6	2003	4B	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	2003	4B	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	2003	4B	34 Self Leveling Suspension	Output Tests	
Audi A6	2003	4B	34 Self Leveling Suspension	Specia Functions	
Audi A6	2003	4B	35 Central Locking	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2003	4B	35 Central Locking	Clear Fault Codes	
Audi A6	2003	4B	35 Central Locking	Measuring Blocks	
Audi A6	2003	4B	35 Central Locking	Output Tests	
Audi A6	2003	4B	35 Central Locking	Specia Functions	
Audi A6	2003	4B	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A6	2003	4B	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	2003	4B	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	2003	4B	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	2003	4B	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	2003	4B	37 Navigation	Read Fault Codes	
Audi A6	2003	4B	37 Navigation	Clear Fault Codes	
Audi A6	2003	4B	37 Navigation	Measuring Blocks	
Audi A6	2003	4B	37 Navigation	Output Tests	
Audi A6	2003	4B	37 Navigation	Specia Functions	
Audi A6	2003	4B	45 Interior Monitoring	Read Fault Codes	
Audi A6	2003	4B	45 Interior Monitoring	Clear Fault Codes	
Audi A6	2003	4B	45 Interior Monitoring	Measuring Blocks	
Audi A6	2003	4B	45 Interior Monitoring	Output Tests	
Audi A6	2003	4B	45 Interior Monitoring	Specia Functions	
Audi A6	2003	4B	51 Electric Drive	Read Fault Codes	
Audi A6	2003	4B	51 Electric Drive	Clear Fault Codes	
Audi A6	2003	4B	51 Electric Drive	Measuring Blocks	
Audi A6	2003	4B	51 Electric Drive	Output Tests	
Audi A6	2003	4B	51 Electric Drive	Specia Functions	
Audi A6	2003	4B	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2003	4B	55 Headlight Range Control	Clear Fault Codes	
Audi A6	2003	4B	55 Headlight Range Control	Measuring Blocks	
Audi A6	2003	4B	55 Headlight Range Control	Output Tests	
Audi A6	2003	4B	55 Headlight Range Control	Specia Functions	
Audi A6	2003	4B	56 Radio	Read Fault Codes	
Audi A6	2003	4B	56 Radio	Clear Fault Codes	
Audi A6	2003	4B	56 Radio	Measuring Blocks	
Audi A6	2003	4B	56 Radio	Output Tests	
Audi A6	2003	4B	56 Radio	Specia Functions	
Audi A6	2003	4B	57 TV-Tuner	Read Fault Codes	
Audi A6	2003	4B	57 TV-Tuner	Clear Fault Codes	
Audi A6	2003	4B	57 TV-Tuner	Measuring Blocks	
Audi A6	2003	4B	57 TV-Tuner	Output Tests	
Audi A6	2003	4B	57 TV-Tuner	Specia Functions	
Audi A6	2003	4B	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6	2003	4B	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6	2003	4B	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6	2003	4B	65 Tyre Pressure Monitoring	Output Tests	
Audi A6	2003	4B	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6	2003	4B	67 Voice Control	Read Fault Codes	
Audi A6	2003	4B	67 Voice Control	Clear Fault Codes	
Audi A6	2003	4B	67 Voice Control	Measuring Blocks	
Audi A6	2003	4B	67 Voice Control	Output Tests	
Audi A6	2003	4B	67 Voice Control	Specia Functions	
Audi A6	2003	4B	75 Emergency Call Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2003	4B	75 Emergency Call Module	Clear Fault Codes	
Audi A6	2003	4B	75 Emergency Call Module	Measuring Blocks	
Audi A6	2003	4B	75 Emergency Call Module	Output Tests	
Audi A6	2003	4B	75 Emergency Call Module	Specia Functions	
Audi A6	2003	4B	76 Parking Aid	Read Fault Codes	
Audi A6	2003	4B	76 Parking Aid	Clear Fault Codes	
Audi A6	2003	4B	76 Parking Aid	Measuring Blocks	
Audi A6	2003	4B	76 Parking Aid	Output Tests	
Audi A6	2003	4B	76 Parking Aid	Specia Functions	
Audi A6	2003	4B	77 Telephone	Read Fault Codes	
Audi A6	2003	4B	77 Telephone	Clear Fault Codes	
Audi A6	2003	4B	77 Telephone	Measuring Blocks	
Audi A6	2003	4B	77 Telephone	Output Tests	
Audi A6	2003	4B	77 Telephone	Specia Functions	
Audi A6	2003	4B	8C Hybrid Battery	Read Fault Codes	
Audi A6	2003	4B	8C Hybrid Battery	Clear Fault Codes	
Audi A6	2003	4B	8C Hybrid Battery	Measuring Blocks	
Audi A6	2003	4B	8C Hybrid Battery	Output Tests	
Audi A6	2003	4B	8C Hybrid Battery	Specia Functions	
Audi A6	2004-2007	4B	01 Engine Electronics	Read Fault Codes	
Audi A6	2004-2007	4B	01 Engine Electronics	Clear Fault Codes	
Audi A6	2004-2007	4B	01 Engine Electronics	Measuring Blocks	
Audi A6	2004-2007	4B	01 Engine Electronics	Output Tests	
Audi A6	2004-2007	4B	01 Engine Electronics	Specia Functions	
Audi A6	2004-2007	4B	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2007	4B	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2004-2007	4B	02 Transmission Electronics	Measuring Blocks	
Audi A6	2004-2007	4B	02 Transmission Electronics	Output Tests	
Audi A6	2004-2007	4B	02 Transmission Electronics	Specia Functions	
Audi A6	2004-2007	4B	03 Brake Electronics	Read Fault Codes	
Audi A6	2004-2007	4B	03 Brake Electronics	Clear Fault Codes	
Audi A6	2004-2007	4B	03 Brake Electronics	Measuring Blocks	
Audi A6	2004-2007	4B	03 Brake Electronics	Output Tests	
Audi A6	2004-2007	4B	03 Brake Electronics	Specia Functions	
Audi A6	2004-2007	4B	06 Passene. Seat Adj.	Read Fault Codes	
Audi A6	2004-2007	4B	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6	2004-2007	4B	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6	2004-2007	4B	06 Passene. Seat Adj.	Output Tests	
Audi A6	2004-2007	4B	06 Passene. Seat Adj.	Specia Functions	
Audi A6	2004-2007	4B	08 AC/Heating Electronics	Read Fault Codes	
Audi A6	2004-2007	4B	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	2004-2007	4B	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	2004-2007	4B	08 AC/Heating Electronics	Output Tests	
Audi A6	2004-2007	4B	08 AC/Heating Electronics	Specia Functions	
Audi A6	2004-2007	4B	0F Radio Tuner-Digital	Read Fault Codes	
Audi A6	2004-2007	4B	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A6	2004-2007	4B	0F Radio Tuner-Digital	Measuring Blocks	
Audi A6	2004-2007	4B	0F Radio Tuner-Digital	Output Tests	
Audi A6	2004-2007	4B	0F Radio Tuner-Digital	Specia Functions	
Audi A6	2004-2007	4B	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2007	4B	11 Engine Electronics 2	Clear Fault Codes	
Audi A6	2004-2007	4B	11 Engine Electronics 2	Measuring Blocks	
Audi A6	2004-2007	4B	11 Engine Electronics 2	Output Tests	
Audi A6	2004-2007	4B	11 Engine Electronics 2	Specia Functions	
Audi A6	2004-2007	4B	15 Airbags	Read Fault Codes	
Audi A6	2004-2007	4B	15 Airbags	Clear Fault Codes	
Audi A6	2004-2007	4B	15 Airbags	Measuring Blocks	
Audi A6	2004-2007	4B	15 Airbags	Output Tests	
Audi A6	2004-2007	4B	15 Airbags	Specia Functions	
Audi A6	2004-2007	4B	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2004-2007	4B	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2004-2007	4B	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2004-2007	4B	16 Steering Wheel Electronics	Output Tests	
Audi A6	2004-2007	4B	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2004-2007	4B	17 Instrument Cluster	Read Fault Codes	
Audi A6	2004-2007	4B	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2004-2007	4B	17 Instrument Cluster	Measuring Blocks	
Audi A6	2004-2007	4B	17 Instrument Cluster	Output Tests	
Audi A6	2004-2007	4B	17 Instrument Cluster	Specia Functions	
Audi A6	2004-2007	4B	18 Aux Heating	Read Fault Codes	
Audi A6	2004-2007	4B	18 Aux Heating	Clear Fault Codes	
Audi A6	2004-2007	4B	18 Aux Heating	Measuring Blocks	
Audi A6	2004-2007	4B	18 Aux Heating	Output Tests	
Audi A6	2004-2007	4B	18 Aux Heating	Specia Functions	
Audi A6	2004-2007	4B	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2007	4B	22 4WD Electronics	Clear Fault Codes	
Audi A6	2004-2007	4B	22 4WD Electronics	Measuring Blocks	
Audi A6	2004-2007	4B	22 4WD Electronics	Output Tests	
Audi A6	2004-2007	4B	22 4WD Electronics	Specia Functions	
Audi A6	2004-2007	4B	25 Immobilizer	Read Fault Codes	
Audi A6	2004-2007	4B	25 Immobilizer	Clear Fault Codes	
Audi A6	2004-2007	4B	25 Immobilizer	Measuring Blocks	
Audi A6	2004-2007	4B	25 Immobilizer	Output Tests	
Audi A6	2004-2007	4B	25 Immobilizer	Specia Functions	
Audi A6	2004-2007	4B	34 Self Leveling Suspension	Read Fault Codes	
Audi A6	2004-2007	4B	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	2004-2007	4B	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	2004-2007	4B	34 Self Leveling Suspension	Output Tests	
Audi A6	2004-2007	4B	34 Self Leveling Suspension	Specia Functions	
Audi A6	2004-2007	4B	35 Central Locking	Read Fault Codes	
Audi A6	2004-2007	4B	35 Central Locking	Clear Fault Codes	
Audi A6	2004-2007	4B	35 Central Locking	Measuring Blocks	
Audi A6	2004-2007	4B	35 Central Locking	Output Tests	
Audi A6	2004-2007	4B	35 Central Locking	Specia Functions	
Audi A6	2004-2007	4B	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A6	2004-2007	4B	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	2004-2007	4B	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	2004-2007	4B	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	2004-2007	4B	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	2004-2007	4B	37 Navigation	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2007	4B	37 Navigation	Clear Fault Codes	
Audi A6	2004-2007	4B	37 Navigation	Measuring Blocks	
Audi A6	2004-2007	4B	37 Navigation	Output Tests	
Audi A6	2004-2007	4B	37 Navigation	Specia Functions	
Audi A6	2004-2007	4B	45 Interior Monitoring	Read Fault Codes	
Audi A6	2004-2007	4B	45 Interior Monitoring	Clear Fault Codes	
Audi A6	2004-2007	4B	45 Interior Monitoring	Measuring Blocks	
Audi A6	2004-2007	4B	45 Interior Monitoring	Output Tests	
Audi A6	2004-2007	4B	45 Interior Monitoring	Specia Functions	
Audi A6	2004-2007	4B	51 Electric Drive	Read Fault Codes	
Audi A6	2004-2007	4B	51 Electric Drive	Clear Fault Codes	
Audi A6	2004-2007	4B	51 Electric Drive	Measuring Blocks	
Audi A6	2004-2007	4B	51 Electric Drive	Output Tests	
Audi A6	2004-2007	4B	51 Electric Drive	Specia Functions	
Audi A6	2004-2007	4B	55 Headlight Range Control	Read Fault Codes	
Audi A6	2004-2007	4B	55 Headlight Range Control	Clear Fault Codes	
Audi A6	2004-2007	4B	55 Headlight Range Control	Measuring Blocks	
Audi A6	2004-2007	4B	55 Headlight Range Control	Output Tests	
Audi A6	2004-2007	4B	55 Headlight Range Control	Specia Functions	
Audi A6	2004-2007	4B	56 Radio	Read Fault Codes	
Audi A6	2004-2007	4B	56 Radio	Clear Fault Codes	
Audi A6	2004-2007	4B	56 Radio	Measuring Blocks	
Audi A6	2004-2007	4B	56 Radio	Output Tests	
Audi A6	2004-2007	4B	56 Radio	Specia Functions	
Audi A6	2004-2007	4B	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2007	4B	57 TV-Tuner	Clear Fault Codes	
Audi A6	2004-2007	4B	57 TV-Tuner	Measuring Blocks	
Audi A6	2004-2007	4B	57 TV-Tuner	Output Tests	
Audi A6	2004-2007	4B	57 TV-Tuner	Specia Functions	
Audi A6	2004-2007	4B	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6	2004-2007	4B	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6	2004-2007	4B	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6	2004-2007	4B	65 Tyre Pressure Monitoring	Output Tests	
Audi A6	2004-2007	4B	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6	2004-2007	4B	67 Voice Control	Read Fault Codes	
Audi A6	2004-2007	4B	67 Voice Control	Clear Fault Codes	
Audi A6	2004-2007	4B	67 Voice Control	Measuring Blocks	
Audi A6	2004-2007	4B	67 Voice Control	Output Tests	
Audi A6	2004-2007	4B	67 Voice Control	Specia Functions	
Audi A6	2004-2007	4B	75 Emergency Call Module	Read Fault Codes	
Audi A6	2004-2007	4B	75 Emergency Call Module	Clear Fault Codes	
Audi A6	2004-2007	4B	75 Emergency Call Module	Measuring Blocks	
Audi A6	2004-2007	4B	75 Emergency Call Module	Output Tests	
Audi A6	2004-2007	4B	75 Emergency Call Module	Specia Functions	
Audi A6	2004-2007	4B	76 Parking Aid	Read Fault Codes	
Audi A6	2004-2007	4B	76 Parking Aid	Clear Fault Codes	
Audi A6	2004-2007	4B	76 Parking Aid	Measuring Blocks	
Audi A6	2004-2007	4B	76 Parking Aid	Output Tests	
Audi A6	2004-2007	4B	76 Parking Aid	Specia Functions	
Audi A6	2004-2007	4B	77 Telephone	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2004-2007	4B	77 Telephone	Clear Fault Codes	
Audi A6	2004-2007	4B	77 Telephone	Measuring Blocks	
Audi A6	2004-2007	4B	77 Telephone	Output Tests	
Audi A6	2004-2007	4B	77 Telephone	Specia Functions	
Audi A6	2004-2007	4B	8C Hybrid Battery	Read Fault Codes	
Audi A6	2004-2007	4B	8C Hybrid Battery	Clear Fault Codes	
Audi A6	2004-2007	4B	8C Hybrid Battery	Measuring Blocks	
Audi A6	2004-2007	4B	8C Hybrid Battery	Output Tests	
Audi A6	2004-2007	4B	8C Hybrid Battery	Specia Functions	
Audi A8	1994-1999	4D	01 Engine Electronics	Read Fault Codes	
Audi A8	1994-1999	4D	01 Engine Electronics	Clear Fault Codes	
Audi A8	1994-1999	4D	01 Engine Electronics	Measuring Blocks	
Audi A8	1994-1999	4D	01 Engine Electronics	Output Tests	
Audi A8	1994-1999	4D	01 Engine Electronics	Specia Functions	
Audi A8	1994-1999	4D	02 Transmission Electronics	Read Fault Codes	
Audi A8	1994-1999	4D	02 Transmission Electronics	Clear Fault Codes	
Audi A8	1994-1999	4D	02 Transmission Electronics	Measuring Blocks	
Audi A8	1994-1999	4D	02 Transmission Electronics	Output Tests	
Audi A8	1994-1999	4D	02 Transmission Electronics	Specia Functions	
Audi A8	1994-1999	4D	03 Brake Electronics	Read Fault Codes	
Audi A8	1994-1999	4D	03 Brake Electronics	Clear Fault Codes	
Audi A8	1994-1999	4D	03 Brake Electronics	Measuring Blocks	
Audi A8	1994-1999	4D	03 Brake Electronics	Output Tests	
Audi A8	1994-1999	4D	03 Brake Electronics	Specia Functions	
Audi A8	1994-1999	4D	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	1994-1999	4D	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	1994-1999	4D	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	1994-1999	4D	08 AC/Heating Electronics	Output Tests	
Audi A8	1994-1999	4D	08 AC/Heating Electronics	Specia Functions	
Audi A8	1994-1999	4D	11 Engine Electronics 2	Read Fault Codes	
Audi A8	1994-1999	4D	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	1994-1999	4D	11 Engine Electronics 2	Measuring Blocks	
Audi A8	1994-1999	4D	11 Engine Electronics 2	Output Tests	
Audi A8	1994-1999	4D	11 Engine Electronics 2	Specia Functions	
Audi A8	1994-1999	4D	15 Airbags	Read Fault Codes	
Audi A8	1994-1999	4D	15 Airbags	Clear Fault Codes	
Audi A8	1994-1999	4D	15 Airbags	Measuring Blocks	
Audi A8	1994-1999	4D	15 Airbags	Output Tests	
Audi A8	1994-1999	4D	15 Airbags	Specia Functions	
Audi A8	1994-1999	4D	16 Steering Wheel Electronics	Read Fault Codes	
Audi A8	1994-1999	4D	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	1994-1999	4D	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	1994-1999	4D	16 Steering Wheel Electronics	Output Tests	
Audi A8	1994-1999	4D	16 Steering Wheel Electronics	Specia Functions	
Audi A8	1994-1999	4D	17 Instrument Cluster	Read Fault Codes	
Audi A8	1994-1999	4D	17 Instrument Cluster	Clear Fault Codes	
Audi A8	1994-1999	4D	17 Instrument Cluster	Measuring Blocks	
Audi A8	1994-1999	4D	17 Instrument Cluster	Output Tests	
Audi A8	1994-1999	4D	17 Instrument Cluster	Specia Functions	
Audi A8	1994-1999	4D	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	1994-1999	4D	18 Aux Heating	Clear Fault Codes	
Audi A8	1994-1999	4D	18 Aux Heating	Measuring Blocks	
Audi A8	1994-1999	4D	18 Aux Heating	Output Tests	
Audi A8	1994-1999	4D	18 Aux Heating	Specia Functions	
Audi A8	1994-1999	4D	25 Immobilizer	Read Fault Codes	
Audi A8	1994-1999	4D	25 Immobilizer	Clear Fault Codes	
Audi A8	1994-1999	4D	25 Immobilizer	Measuring Blocks	
Audi A8	1994-1999	4D	25 Immobilizer	Output Tests	
Audi A8	1994-1999	4D	25 Immobilizer	Specia Functions	
Audi A8	1994-1999	4D	34 Self Leveling Suspension	Read Fault Codes	
Audi A8	1994-1999	4D	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8	1994-1999	4D	34 Self Leveling Suspension	Measuring Blocks	
Audi A8	1994-1999	4D	34 Self Leveling Suspension	Output Tests	
Audi A8	1994-1999	4D	34 Self Leveling Suspension	Specia Functions	
Audi A8	1994-1999	4D	35 Central Locking	Read Fault Codes	
Audi A8	1994-1999	4D	35 Central Locking	Clear Fault Codes	
Audi A8	1994-1999	4D	35 Central Locking	Measuring Blocks	
Audi A8	1994-1999	4D	35 Central Locking	Output Tests	
Audi A8	1994-1999	4D	35 Central Locking	Specia Functions	
Audi A8	1994-1999	4D	37 Navigation	Read Fault Codes	
Audi A8	1994-1999	4D	37 Navigation	Clear Fault Codes	
Audi A8	1994-1999	4D	37 Navigation	Measuring Blocks	
Audi A8	1994-1999	4D	37 Navigation	Output Tests	
Audi A8	1994-1999	4D	37 Navigation	Specia Functions	
Audi A8	1994-1999	4D	45 Interior Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	1994-1999	4D	45 Interior Monitoring	Clear Fault Codes	
Audi A8	1994-1999	4D	45 Interior Monitoring	Measuring Blocks	
Audi A8	1994-1999	4D	45 Interior Monitoring	Output Tests	
Audi A8	1994-1999	4D	45 Interior Monitoring	Specia Functions	
Audi A8	1994-1999	4D	51 Electric Drive	Read Fault Codes	
Audi A8	1994-1999	4D	51 Electric Drive	Clear Fault Codes	
Audi A8	1994-1999	4D	51 Electric Drive	Measuring Blocks	
Audi A8	1994-1999	4D	51 Electric Drive	Output Tests	
Audi A8	1994-1999	4D	51 Electric Drive	Specia Functions	
Audi A8	1994-1999	4D	55 Headlight Range Control	Read Fault Codes	
Audi A8	1994-1999	4D	55 Headlight Range Control	Clear Fault Codes	
Audi A8	1994-1999	4D	55 Headlight Range Control	Measuring Blocks	
Audi A8	1994-1999	4D	55 Headlight Range Control	Output Tests	
Audi A8	1994-1999	4D	55 Headlight Range Control	Specia Functions	
Audi A8	1994-1999	4D	56 Radio	Read Fault Codes	
Audi A8	1994-1999	4D	56 Radio	Clear Fault Codes	
Audi A8	1994-1999	4D	56 Radio	Measuring Blocks	
Audi A8	1994-1999	4D	56 Radio	Output Tests	
Audi A8	1994-1999	4D	56 Radio	Specia Functions	
Audi A8	1994-1999	4D	76 Parking Aid	Read Fault Codes	
Audi A8	1994-1999	4D	76 Parking Aid	Clear Fault Codes	
Audi A8	1994-1999	4D	76 Parking Aid	Measuring Blocks	
Audi A8	1994-1999	4D	76 Parking Aid	Output Tests	
Audi A8	1994-1999	4D	76 Parking Aid	Specia Functions	
Audi A8	1994-1999	4D	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	1994-1999	4D	8C Hybrid Battery	Clear Fault Codes	
Audi A8	1994-1999	4D	8C Hybrid Battery	Measuring Blocks	
Audi A8	1994-1999	4D	8C Hybrid Battery	Output Tests	
Audi A8	1994-1999	4D	8C Hybrid Battery	Specia Functions	
Audi A8	2000	4D	01 Engine Electronics	Read Fault Codes	
Audi A8	2000	4D	01 Engine Electronics	Clear Fault Codes	
Audi A8	2000	4D	01 Engine Electronics	Measuring Blocks	
Audi A8	2000	4D	01 Engine Electronics	Output Tests	
Audi A8	2000	4D	01 Engine Electronics	Specia Functions	
Audi A8	2000	4D	02 Transmission Electronics	Read Fault Codes	
Audi A8	2000	4D	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2000	4D	02 Transmission Electronics	Measuring Blocks	
Audi A8	2000	4D	02 Transmission Electronics	Output Tests	
Audi A8	2000	4D	02 Transmission Electronics	Specia Functions	
Audi A8	2000	4D	03 Brake Electronics	Read Fault Codes	
Audi A8	2000	4D	03 Brake Electronics	Clear Fault Codes	
Audi A8	2000	4D	03 Brake Electronics	Measuring Blocks	
Audi A8	2000	4D	03 Brake Electronics	Output Tests	
Audi A8	2000	4D	03 Brake Electronics	Specia Functions	
Audi A8	2000	4D	08 AC/Heating Electronics	Read Fault Codes	
Audi A8	2000	4D	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	2000	4D	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	2000	4D	08 AC/Heating Electronics	Output Tests	
Audi A8	2000	4D	08 AC/Heating Electronics	Specia Functions	
Audi A8	2000	4D	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2000	4D	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	2000	4D	11 Engine Electronics 2	Measuring Blocks	
Audi A8	2000	4D	11 Engine Electronics 2	Output Tests	
Audi A8	2000	4D	11 Engine Electronics 2	Specia Functions	
Audi A8	2000	4D	15 Airbags	Read Fault Codes	
Audi A8	2000	4D	15 Airbags	Clear Fault Codes	
Audi A8	2000	4D	15 Airbags	Measuring Blocks	
Audi A8	2000	4D	15 Airbags	Output Tests	
Audi A8	2000	4D	15 Airbags	Specia Functions	
Audi A8	2000	4D	16 Steering Wheel Electronics	Read Fault Codes	
Audi A8	2000	4D	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2000	4D	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2000	4D	16 Steering Wheel Electronics	Output Tests	
Audi A8	2000	4D	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2000	4D	17 Instrument Cluster	Read Fault Codes	
Audi A8	2000	4D	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2000	4D	17 Instrument Cluster	Measuring Blocks	
Audi A8	2000	4D	17 Instrument Cluster	Output Tests	
Audi A8	2000	4D	17 Instrument Cluster	Specia Functions	
Audi A8	2000	4D	18 Aux Heating	Read Fault Codes	
Audi A8	2000	4D	18 Aux Heating	Clear Fault Codes	
Audi A8	2000	4D	18 Aux Heating	Measuring Blocks	
Audi A8	2000	4D	18 Aux Heating	Output Tests	
Audi A8	2000	4D	18 Aux Heating	Specia Functions	
Audi A8	2000	4D	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2000	4D	25 Immobilizer	Clear Fault Codes	
Audi A8	2000	4D	25 Immobilizer	Measuring Blocks	
Audi A8	2000	4D	25 Immobilizer	Output Tests	
Audi A8	2000	4D	25 Immobilizer	Specia Functions	
Audi A8	2000	4D	34 Self Leveling Suspension	Read Fault Codes	
Audi A8	2000	4D	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8	2000	4D	34 Self Leveling Suspension	Measuring Blocks	
Audi A8	2000	4D	34 Self Leveling Suspension	Output Tests	
Audi A8	2000	4D	34 Self Leveling Suspension	Specia Functions	
Audi A8	2000	4D	35 Central Locking	Read Fault Codes	
Audi A8	2000	4D	35 Central Locking	Clear Fault Codes	
Audi A8	2000	4D	35 Central Locking	Measuring Blocks	
Audi A8	2000	4D	35 Central Locking	Output Tests	
Audi A8	2000	4D	35 Central Locking	Specia Functions	
Audi A8	2000	4D	37 Navigation	Read Fault Codes	
Audi A8	2000	4D	37 Navigation	Clear Fault Codes	
Audi A8	2000	4D	37 Navigation	Measuring Blocks	
Audi A8	2000	4D	37 Navigation	Output Tests	
Audi A8	2000	4D	37 Navigation	Specia Functions	
Audi A8	2000	4D	45 Interior Monitoring	Read Fault Codes	
Audi A8	2000	4D	45 Interior Monitoring	Clear Fault Codes	
Audi A8	2000	4D	45 Interior Monitoring	Measuring Blocks	
Audi A8	2000	4D	45 Interior Monitoring	Output Tests	
Audi A8	2000	4D	45 Interior Monitoring	Specia Functions	
Audi A8	2000	4D	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2000	4D	51 Electric Drive	Clear Fault Codes	
Audi A8	2000	4D	51 Electric Drive	Measuring Blocks	
Audi A8	2000	4D	51 Electric Drive	Output Tests	
Audi A8	2000	4D	51 Electric Drive	Specia Functions	
Audi A8	2000	4D	55 Headlight Range Control	Read Fault Codes	
Audi A8	2000	4D	55 Headlight Range Control	Clear Fault Codes	
Audi A8	2000	4D	55 Headlight Range Control	Measuring Blocks	
Audi A8	2000	4D	55 Headlight Range Control	Output Tests	
Audi A8	2000	4D	55 Headlight Range Control	Specia Functions	
Audi A8	2000	4D	56 Radio	Read Fault Codes	
Audi A8	2000	4D	56 Radio	Clear Fault Codes	
Audi A8	2000	4D	56 Radio	Measuring Blocks	
Audi A8	2000	4D	56 Radio	Output Tests	
Audi A8	2000	4D	56 Radio	Specia Functions	
Audi A8	2000	4D	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8	2000	4D	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8	2000	4D	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8	2000	4D	65 Tyre Pressure Monitoring	Output Tests	
Audi A8	2000	4D	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8	2000	4D	75 Emergency Call Module	Read Fault Codes	
Audi A8	2000	4D	75 Emergency Call Module	Clear Fault Codes	
Audi A8	2000	4D	75 Emergency Call Module	Measuring Blocks	
Audi A8	2000	4D	75 Emergency Call Module	Output Tests	
Audi A8	2000	4D	75 Emergency Call Module	Specia Functions	
Audi A8	2000	4D	76 Parking Aid	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2000	4D	76 Parking Aid	Clear Fault Codes	
Audi A8	2000	4D	76 Parking Aid	Measuring Blocks	
Audi A8	2000	4D	76 Parking Aid	Output Tests	
Audi A8	2000	4D	76 Parking Aid	Specia Functions	
Audi A8	2000	4D	8C Hybrid Battery	Read Fault Codes	
Audi A8	2000	4D	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2000	4D	8C Hybrid Battery	Measuring Blocks	
Audi A8	2000	4D	8C Hybrid Battery	Output Tests	
Audi A8	2000	4D	8C Hybrid Battery	Specia Functions	
Audi A8	2001	4D	01 Engine Electronics	Read Fault Codes	
Audi A8	2001	4D	01 Engine Electronics	Clear Fault Codes	
Audi A8	2001	4D	01 Engine Electronics	Measuring Blocks	
Audi A8	2001	4D	01 Engine Electronics	Output Tests	
Audi A8	2001	4D	01 Engine Electronics	Specia Functions	
Audi A8	2001	4D	02 Transmission Electronics	Read Fault Codes	
Audi A8	2001	4D	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2001	4D	02 Transmission Electronics	Measuring Blocks	
Audi A8	2001	4D	02 Transmission Electronics	Output Tests	
Audi A8	2001	4D	02 Transmission Electronics	Specia Functions	
Audi A8	2001	4D	03 Brake Electronics	Read Fault Codes	
Audi A8	2001	4D	03 Brake Electronics	Clear Fault Codes	
Audi A8	2001	4D	03 Brake Electronics	Measuring Blocks	
Audi A8	2001	4D	03 Brake Electronics	Output Tests	
Audi A8	2001	4D	03 Brake Electronics	Specia Functions	
Audi A8	2001	4D	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2001	4D	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	2001	4D	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	2001	4D	08 AC/Heating Electronics	Output Tests	
Audi A8	2001	4D	08 AC/Heating Electronics	Specia Functions	
Audi A8	2001	4D	11 Engine Electronics 2	Read Fault Codes	
Audi A8	2001	4D	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	2001	4D	11 Engine Electronics 2	Measuring Blocks	
Audi A8	2001	4D	11 Engine Electronics 2	Output Tests	
Audi A8	2001	4D	11 Engine Electronics 2	Specia Functions	
Audi A8	2001	4D	15 Airbags	Read Fault Codes	
Audi A8	2001	4D	15 Airbags	Clear Fault Codes	
Audi A8	2001	4D	15 Airbags	Measuring Blocks	
Audi A8	2001	4D	15 Airbags	Output Tests	
Audi A8	2001	4D	15 Airbags	Specia Functions	
Audi A8	2001	4D	16 Steering Wheel Electronics	Read Fault Codes	
Audi A8	2001	4D	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2001	4D	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2001	4D	16 Steering Wheel Electronics	Output Tests	
Audi A8	2001	4D	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2001	4D	17 Instrument Cluster	Read Fault Codes	
Audi A8	2001	4D	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2001	4D	17 Instrument Cluster	Measuring Blocks	
Audi A8	2001	4D	17 Instrument Cluster	Output Tests	
Audi A8	2001	4D	17 Instrument Cluster	Specia Functions	
Audi A8	2001	4D	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2001	4D	18 Aux Heating	Clear Fault Codes	
Audi A8	2001	4D	18 Aux Heating	Measuring Blocks	
Audi A8	2001	4D	18 Aux Heating	Output Tests	
Audi A8	2001	4D	18 Aux Heating	Specia Functions	
Audi A8	2001	4D	25 Immobilizer	Read Fault Codes	
Audi A8	2001	4D	25 Immobilizer	Clear Fault Codes	
Audi A8	2001	4D	25 Immobilizer	Measuring Blocks	
Audi A8	2001	4D	25 Immobilizer	Output Tests	
Audi A8	2001	4D	25 Immobilizer	Specia Functions	
Audi A8	2001	4D	34 Self Leveling Suspension	Read Fault Codes	
Audi A8	2001	4D	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8	2001	4D	34 Self Leveling Suspension	Measuring Blocks	
Audi A8	2001	4D	34 Self Leveling Suspension	Output Tests	
Audi A8	2001	4D	34 Self Leveling Suspension	Specia Functions	
Audi A8	2001	4D	35 Central Locking	Read Fault Codes	
Audi A8	2001	4D	35 Central Locking	Clear Fault Codes	
Audi A8	2001	4D	35 Central Locking	Measuring Blocks	
Audi A8	2001	4D	35 Central Locking	Output Tests	
Audi A8	2001	4D	35 Central Locking	Specia Functions	
Audi A8	2001	4D	37 Navigation	Read Fault Codes	
Audi A8	2001	4D	37 Navigation	Clear Fault Codes	
Audi A8	2001	4D	37 Navigation	Measuring Blocks	
Audi A8	2001	4D	37 Navigation	Output Tests	
Audi A8	2001	4D	37 Navigation	Specia Functions	
Audi A8	2001	4D	45 Interior Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2001	4D	45 Interior Monitoring	Clear Fault Codes	
Audi A8	2001	4D	45 Interior Monitoring	Measuring Blocks	
Audi A8	2001	4D	45 Interior Monitoring	Output Tests	
Audi A8	2001	4D	45 Interior Monitoring	Specia Functions	
Audi A8	2001	4D	51 Electric Drive	Read Fault Codes	
Audi A8	2001	4D	51 Electric Drive	Clear Fault Codes	
Audi A8	2001	4D	51 Electric Drive	Measuring Blocks	
Audi A8	2001	4D	51 Electric Drive	Output Tests	
Audi A8	2001	4D	51 Electric Drive	Specia Functions	
Audi A8	2001	4D	55 Headlight Range Control	Read Fault Codes	
Audi A8	2001	4D	55 Headlight Range Control	Clear Fault Codes	
Audi A8	2001	4D	55 Headlight Range Control	Measuring Blocks	
Audi A8	2001	4D	55 Headlight Range Control	Output Tests	
Audi A8	2001	4D	55 Headlight Range Control	Specia Functions	
Audi A8	2001	4D	56 Radio	Read Fault Codes	
Audi A8	2001	4D	56 Radio	Clear Fault Codes	
Audi A8	2001	4D	56 Radio	Measuring Blocks	
Audi A8	2001	4D	56 Radio	Output Tests	
Audi A8	2001	4D	56 Radio	Specia Functions	
Audi A8	2001	4D	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8	2001	4D	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8	2001	4D	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8	2001	4D	65 Tyre Pressure Monitoring	Output Tests	
Audi A8	2001	4D	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8	2001	4D	67 Voice Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2001	4D	67 Voice Control	Clear Fault Codes	
Audi A8	2001	4D	67 Voice Control	Measuring Blocks	
Audi A8	2001	4D	67 Voice Control	Output Tests	
Audi A8	2001	4D	67 Voice Control	Specia Functions	
Audi A8	2001	4D	75 Emergency Call Module	Read Fault Codes	
Audi A8	2001	4D	75 Emergency Call Module	Clear Fault Codes	
Audi A8	2001	4D	75 Emergency Call Module	Measuring Blocks	
Audi A8	2001	4D	75 Emergency Call Module	Output Tests	
Audi A8	2001	4D	75 Emergency Call Module	Specia Functions	
Audi A8	2001	4D	76 Parking Aid	Read Fault Codes	
Audi A8	2001	4D	76 Parking Aid	Clear Fault Codes	
Audi A8	2001	4D	76 Parking Aid	Measuring Blocks	
Audi A8	2001	4D	76 Parking Aid	Output Tests	
Audi A8	2001	4D	76 Parking Aid	Specia Functions	
Audi A8	2001	4D	8C Hybrid Battery	Read Fault Codes	
Audi A8	2001	4D	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2001	4D	8C Hybrid Battery	Measuring Blocks	
Audi A8	2001	4D	8C Hybrid Battery	Output Tests	
Audi A8	2001	4D	8C Hybrid Battery	Specia Functions	
Audi A8	2002	4D	01 Engine Electronics	Read Fault Codes	
Audi A8	2002	4D	01 Engine Electronics	Clear Fault Codes	
Audi A8	2002	4D	01 Engine Electronics	Measuring Blocks	
Audi A8	2002	4D	01 Engine Electronics	Output Tests	
Audi A8	2002	4D	01 Engine Electronics	Specia Functions	
Audi A8	2002	4D	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002	4D	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2002	4D	02 Transmission Electronics	Measuring Blocks	
Audi A8	2002	4D	02 Transmission Electronics	Output Tests	
Audi A8	2002	4D	02 Transmission Electronics	Specia Functions	
Audi A8	2002	4D	03 Brake Electronics	Read Fault Codes	
Audi A8	2002	4D	03 Brake Electronics	Clear Fault Codes	
Audi A8	2002	4D	03 Brake Electronics	Measuring Blocks	
Audi A8	2002	4D	03 Brake Electronics	Output Tests	
Audi A8	2002	4D	03 Brake Electronics	Specia Functions	
Audi A8	2002	4D	08 AC/Heating Electronics	Read Fault Codes	
Audi A8	2002	4D	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	2002	4D	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	2002	4D	08 AC/Heating Electronics	Output Tests	
Audi A8	2002	4D	08 AC/Heating Electronics	Specia Functions	
Audi A8	2002	4D	11 Engine Electronics 2	Read Fault Codes	
Audi A8	2002	4D	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	2002	4D	11 Engine Electronics 2	Measuring Blocks	
Audi A8	2002	4D	11 Engine Electronics 2	Output Tests	
Audi A8	2002	4D	11 Engine Electronics 2	Specia Functions	
Audi A8	2002	4D	15 Airbags	Read Fault Codes	
Audi A8	2002	4D	15 Airbags	Clear Fault Codes	
Audi A8	2002	4D	15 Airbags	Measuring Blocks	
Audi A8	2002	4D	15 Airbags	Output Tests	
Audi A8	2002	4D	15 Airbags	Specia Functions	
Audi A8	2002	4D	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002	4D	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2002	4D	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2002	4D	16 Steering Wheel Electronics	Output Tests	
Audi A8	2002	4D	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2002	4D	17 Instrument Cluster	Read Fault Codes	
Audi A8	2002	4D	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2002	4D	17 Instrument Cluster	Measuring Blocks	
Audi A8	2002	4D	17 Instrument Cluster	Output Tests	
Audi A8	2002	4D	17 Instrument Cluster	Specia Functions	
Audi A8	2002	4D	18 Aux Heating	Read Fault Codes	
Audi A8	2002	4D	18 Aux Heating	Clear Fault Codes	
Audi A8	2002	4D	18 Aux Heating	Measuring Blocks	
Audi A8	2002	4D	18 Aux Heating	Output Tests	
Audi A8	2002	4D	18 Aux Heating	Specia Functions	
Audi A8	2002	4D	25 Immobilizer	Read Fault Codes	
Audi A8	2002	4D	25 Immobilizer	Clear Fault Codes	
Audi A8	2002	4D	25 Immobilizer	Measuring Blocks	
Audi A8	2002	4D	25 Immobilizer	Output Tests	
Audi A8	2002	4D	25 Immobilizer	Specia Functions	
Audi A8	2002	4D	34 Self Leveling Suspension	Read Fault Codes	
Audi A8	2002	4D	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8	2002	4D	34 Self Leveling Suspension	Measuring Blocks	
Audi A8	2002	4D	34 Self Leveling Suspension	Output Tests	
Audi A8	2002	4D	34 Self Leveling Suspension	Specia Functions	
Audi A8	2002	4D	35 Central Locking	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002	4D	35 Central Locking	Clear Fault Codes	
Audi A8	2002	4D	35 Central Locking	Measuring Blocks	
Audi A8	2002	4D	35 Central Locking	Output Tests	
Audi A8	2002	4D	35 Central Locking	Specia Functions	
Audi A8	2002	4D	37 Navigation	Read Fault Codes	
Audi A8	2002	4D	37 Navigation	Clear Fault Codes	
Audi A8	2002	4D	37 Navigation	Measuring Blocks	
Audi A8	2002	4D	37 Navigation	Output Tests	
Audi A8	2002	4D	37 Navigation	Specia Functions	
Audi A8	2002	4D	45 Interior Monitoring	Read Fault Codes	
Audi A8	2002	4D	45 Interior Monitoring	Clear Fault Codes	
Audi A8	2002	4D	45 Interior Monitoring	Measuring Blocks	
Audi A8	2002	4D	45 Interior Monitoring	Output Tests	
Audi A8	2002	4D	45 Interior Monitoring	Specia Functions	
Audi A8	2002	4D	51 Electric Drive	Read Fault Codes	
Audi A8	2002	4D	51 Electric Drive	Clear Fault Codes	
Audi A8	2002	4D	51 Electric Drive	Measuring Blocks	
Audi A8	2002	4D	51 Electric Drive	Output Tests	
Audi A8	2002	4D	51 Electric Drive	Specia Functions	
Audi A8	2002	4D	55 Headlight Range Control	Read Fault Codes	
Audi A8	2002	4D	55 Headlight Range Control	Clear Fault Codes	
Audi A8	2002	4D	55 Headlight Range Control	Measuring Blocks	
Audi A8	2002	4D	55 Headlight Range Control	Output Tests	
Audi A8	2002	4D	55 Headlight Range Control	Specia Functions	
Audi A8	2002	4D	56 Radio	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002	4D	56 Radio	Clear Fault Codes	
Audi A8	2002	4D	56 Radio	Measuring Blocks	
Audi A8	2002	4D	56 Radio	Output Tests	
Audi A8	2002	4D	56 Radio	Specia Functions	
Audi A8	2002	4D	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8	2002	4D	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8	2002	4D	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8	2002	4D	65 Tyre Pressure Monitoring	Output Tests	
Audi A8	2002	4D	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8	2002	4D	67 Voice Control	Read Fault Codes	
Audi A8	2002	4D	67 Voice Control	Clear Fault Codes	
Audi A8	2002	4D	67 Voice Control	Measuring Blocks	
Audi A8	2002	4D	67 Voice Control	Output Tests	
Audi A8	2002	4D	67 Voice Control	Specia Functions	
Audi A8	2002	4D	75 Emergency Call Module	Read Fault Codes	
Audi A8	2002	4D	75 Emergency Call Module	Clear Fault Codes	
Audi A8	2002	4D	75 Emergency Call Module	Measuring Blocks	
Audi A8	2002	4D	75 Emergency Call Module	Output Tests	
Audi A8	2002	4D	75 Emergency Call Module	Specia Functions	
Audi A8	2002	4D	76 Parking Aid	Read Fault Codes	
Audi A8	2002	4D	76 Parking Aid	Clear Fault Codes	
Audi A8	2002	4D	76 Parking Aid	Measuring Blocks	
Audi A8	2002	4D	76 Parking Aid	Output Tests	
Audi A8	2002	4D	76 Parking Aid	Specia Functions	
Audi A8	2002	4D	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2002	4D	77 Telephone	Clear Fault Codes	
Audi A8	2002	4D	77 Telephone	Measuring Blocks	
Audi A8	2002	4D	77 Telephone	Output Tests	
Audi A8	2002	4D	77 Telephone	Specia Functions	
Audi A8	2002	4D	8C Hybrid Battery	Read Fault Codes	
Audi A8	2002	4D	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2002	4D	8C Hybrid Battery	Measuring Blocks	
Audi A8	2002	4D	8C Hybrid Battery	Output Tests	
Audi A8	2002	4D	8C Hybrid Battery	Specia Functions	
Audi A8	2003	4D	01 Engine Electronics	Read Fault Codes	
Audi A8	2003	4D	01 Engine Electronics	Clear Fault Codes	
Audi A8	2003	4D	01 Engine Electronics	Measuring Blocks	
Audi A8	2003	4D	01 Engine Electronics	Output Tests	
Audi A8	2003	4D	01 Engine Electronics	Specia Functions	
Audi A8	2003	4D	02 Transmission Electronics	Read Fault Codes	
Audi A8	2003	4D	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2003	4D	02 Transmission Electronics	Measuring Blocks	
Audi A8	2003	4D	02 Transmission Electronics	Output Tests	
Audi A8	2003	4D	02 Transmission Electronics	Specia Functions	
Audi A8	2003	4D	03 Brake Electronics	Read Fault Codes	
Audi A8	2003	4D	03 Brake Electronics	Clear Fault Codes	
Audi A8	2003	4D	03 Brake Electronics	Measuring Blocks	
Audi A8	2003	4D	03 Brake Electronics	Output Tests	
Audi A8	2003	4D	03 Brake Electronics	Specia Functions	
Audi A8	2003	4D	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2003	4D	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	2003	4D	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	2003	4D	08 AC/Heating Electronics	Output Tests	
Audi A8	2003	4D	08 AC/Heating Electronics	Specia Functions	
Audi A8	2003	4D	11 Engine Electronics 2	Read Fault Codes	
Audi A8	2003	4D	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	2003	4D	11 Engine Electronics 2	Measuring Blocks	
Audi A8	2003	4D	11 Engine Electronics 2	Output Tests	
Audi A8	2003	4D	11 Engine Electronics 2	Specia Functions	
Audi A8	2003	4D	15 Airbags	Read Fault Codes	
Audi A8	2003	4D	15 Airbags	Clear Fault Codes	
Audi A8	2003	4D	15 Airbags	Measuring Blocks	
Audi A8	2003	4D	15 Airbags	Output Tests	
Audi A8	2003	4D	15 Airbags	Specia Functions	
Audi A8	2003	4D	16 Steering Wheel Electronics	Read Fault Codes	
Audi A8	2003	4D	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2003	4D	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2003	4D	16 Steering Wheel Electronics	Output Tests	
Audi A8	2003	4D	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2003	4D	17 Instrument Cluster	Read Fault Codes	
Audi A8	2003	4D	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2003	4D	17 Instrument Cluster	Measuring Blocks	
Audi A8	2003	4D	17 Instrument Cluster	Output Tests	
Audi A8	2003	4D	17 Instrument Cluster	Specia Functions	
Audi A8	2003	4D	25 Immobilizer	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2003	4D	25 Immobilizer	Clear Fault Codes	
Audi A8	2003	4D	25 Immobilizer	Measuring Blocks	
Audi A8	2003	4D	25 Immobilizer	Output Tests	
Audi A8	2003	4D	25 Immobilizer	Specia Functions	
Audi A8	2003	4D	35 Central Locking	Read Fault Codes	
Audi A8	2003	4D	35 Central Locking	Clear Fault Codes	
Audi A8	2003	4D	35 Central Locking	Measuring Blocks	
Audi A8	2003	4D	35 Central Locking	Output Tests	
Audi A8	2003	4D	35 Central Locking	Specia Functions	
Audi A8	2003	4D	37 Navigation	Read Fault Codes	
Audi A8	2003	4D	37 Navigation	Clear Fault Codes	
Audi A8	2003	4D	37 Navigation	Measuring Blocks	
Audi A8	2003	4D	37 Navigation	Output Tests	
Audi A8	2003	4D	37 Navigation	Specia Functions	
Audi A8	2003	4D	45 Interior Monitoring	Read Fault Codes	
Audi A8	2003	4D	45 Interior Monitoring	Clear Fault Codes	
Audi A8	2003	4D	45 Interior Monitoring	Measuring Blocks	
Audi A8	2003	4D	45 Interior Monitoring	Output Tests	
Audi A8	2003	4D	45 Interior Monitoring	Specia Functions	
Audi A8	2003	4D	51 Electric Drive	Read Fault Codes	
Audi A8	2003	4D	51 Electric Drive	Clear Fault Codes	
Audi A8	2003	4D	51 Electric Drive	Measuring Blocks	
Audi A8	2003	4D	51 Electric Drive	Output Tests	
Audi A8	2003	4D	51 Electric Drive	Specia Functions	
Audi A8	2003	4D	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2003	4D	55 Headlight Range Control	Clear Fault Codes	
Audi A8	2003	4D	55 Headlight Range Control	Measuring Blocks	
Audi A8	2003	4D	55 Headlight Range Control	Output Tests	
Audi A8	2003	4D	55 Headlight Range Control	Specia Functions	
Audi A8	2003	4D	56 Radio	Read Fault Codes	
Audi A8	2003	4D	56 Radio	Clear Fault Codes	
Audi A8	2003	4D	56 Radio	Measuring Blocks	
Audi A8	2003	4D	56 Radio	Output Tests	
Audi A8	2003	4D	56 Radio	Specia Functions	
Audi A8	2003	4D	75 Emergency Call Module	Read Fault Codes	
Audi A8	2003	4D	75 Emergency Call Module	Clear Fault Codes	
Audi A8	2003	4D	75 Emergency Call Module	Measuring Blocks	
Audi A8	2003	4D	75 Emergency Call Module	Output Tests	
Audi A8	2003	4D	75 Emergency Call Module	Specia Functions	
Audi A8	2003	4D	76 Parking Aid	Read Fault Codes	
Audi A8	2003	4D	76 Parking Aid	Clear Fault Codes	
Audi A8	2003	4D	76 Parking Aid	Measuring Blocks	
Audi A8	2003	4D	76 Parking Aid	Output Tests	
Audi A8	2003	4D	76 Parking Aid	Specia Functions	
Audi A8	2003	4D	8C Hybrid Battery	Read Fault Codes	
Audi A8	2003	4D	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2003	4D	8C Hybrid Battery	Measuring Blocks	
Audi A8	2003	4D	8C Hybrid Battery	Output Tests	
Audi A8	2003	4D	8C Hybrid Battery	Specia Functions	
Audi TT	2007-2008	8J	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2007-2008	8J	01 Engine Electronics	Clear Fault Codes	
Audi TT	2007-2008	8J	01 Engine Electronics	Measuring Blocks	
Audi TT	2007-2008	8J	01 Engine Electronics	Output Tests	
Audi TT	2007-2008	8J	01 Engine Electronics	Specia Functions	
Audi TT	2007-2008	8J	02 Transmission Electronics	Read Fault Codes	
Audi TT	2007-2008	8J	02 Transmission Electronics	Clear Fault Codes	
Audi TT	2007-2008	8J	02 Transmission Electronics	Measuring Blocks	
Audi TT	2007-2008	8J	02 Transmission Electronics	Output Tests	
Audi TT	2007-2008	8J	02 Transmission Electronics	Specia Functions	
Audi TT	2007-2008	8J	03 Brake Electronics	Read Fault Codes	
Audi TT	2007-2008	8J	03 Brake Electronics	Clear Fault Codes	
Audi TT	2007-2008	8J	03 Brake Electronics	Measuring Blocks	
Audi TT	2007-2008	8J	03 Brake Electronics	Output Tests	
Audi TT	2007-2008	8J	03 Brake Electronics	Specia Functions	
Audi TT	2007-2008	8J	08 AC/Heating Electronics	Read Fault Codes	
Audi TT	2007-2008	8J	08 AC/Heating Electronics	Clear Fault Codes	
Audi TT	2007-2008	8J	08 AC/Heating Electronics	Measuring Blocks	
Audi TT	2007-2008	8J	08 AC/Heating Electronics	Output Tests	
Audi TT	2007-2008	8J	08 AC/Heating Electronics	Specia Functions	
Audi TT	2007-2008	8J	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi TT	2007-2008	8J	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi TT	2007-2008	8J	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi TT	2007-2008	8J	09 Electronic Ctrl Electronics	Output Tests	
Audi TT	2007-2008	8J	09 Electronic Ctrl Electronics	Specia Functions	
Audi TT	2007-2008	8J	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2007-2008	8J	0F Radio Tuner-Digital	Clear Fault Codes	
Audi TT	2007-2008	8J	0F Radio Tuner-Digital	Measuring Blocks	
Audi TT	2007-2008	8J	0F Radio Tuner-Digital	Output Tests	
Audi TT	2007-2008	8J	0F Radio Tuner-Digital	Specia Functions	
Audi TT	2007-2008	8J	11 Engine Electronics 2	Read Fault Codes	
Audi TT	2007-2008	8J	11 Engine Electronics 2	Clear Fault Codes	
Audi TT	2007-2008	8J	11 Engine Electronics 2	Measuring Blocks	
Audi TT	2007-2008	8J	11 Engine Electronics 2	Output Tests	
Audi TT	2007-2008	8J	11 Engine Electronics 2	Specia Functions	
Audi TT	2007-2008	8J	14 Wheel Damping Electronics	Read Fault Codes	
Audi TT	2007-2008	8J	14 Wheel Damping Electronics	Clear Fault Codes	
Audi TT	2007-2008	8J	14 Wheel Damping Electronics	Measuring Blocks	
Audi TT	2007-2008	8J	14 Wheel Damping Electronics	Output Tests	
Audi TT	2007-2008	8J	14 Wheel Damping Electronics	Specia Functions	
Audi TT	2007-2008	8J	15 Airbags	Read Fault Codes	
Audi TT	2007-2008	8J	15 Airbags	Clear Fault Codes	
Audi TT	2007-2008	8J	15 Airbags	Measuring Blocks	
Audi TT	2007-2008	8J	15 Airbags	Output Tests	
Audi TT	2007-2008	8J	15 Airbags	Specia Functions	
Audi TT	2007-2008	8J	16 Steering Wheel Electronics	Read Fault Codes	
Audi TT	2007-2008	8J	16 Steering Wheel Electronics	Clear Fault Codes	
Audi TT	2007-2008	8J	16 Steering Wheel Electronics	Measuring Blocks	
Audi TT	2007-2008	8J	16 Steering Wheel Electronics	Output Tests	
Audi TT	2007-2008	8J	16 Steering Wheel Electronics	Specia Functions	
Audi TT	2007-2008	8J	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2007-2008	8J	17 Instrument Cluster	Clear Fault Codes	
Audi TT	2007-2008	8J	17 Instrument Cluster	Measuring Blocks	
Audi TT	2007-2008	8J	17 Instrument Cluster	Output Tests	
Audi TT	2007-2008	8J	17 Instrument Cluster	Specia Functions	
Audi TT	2007-2008	8J	18 Aux Heating	Read Fault Codes	
Audi TT	2007-2008	8J	18 Aux Heating	Clear Fault Codes	
Audi TT	2007-2008	8J	18 Aux Heating	Measuring Blocks	
Audi TT	2007-2008	8J	18 Aux Heating	Output Tests	
Audi TT	2007-2008	8J	18 Aux Heating	Specia Functions	
Audi TT	2007-2008	8J	19 Gateway Data Bus	Read Fault Codes	
Audi TT	2007-2008	8J	19 Gateway Data Bus	Clear Fault Codes	
Audi TT	2007-2008	8J	19 Gateway Data Bus	Measuring Blocks	
Audi TT	2007-2008	8J	19 Gateway Data Bus	Output Tests	
Audi TT	2007-2008	8J	19 Gateway Data Bus	Specia Functions	
Audi TT	2007-2008	8J	22 4WD Electronics	Read Fault Codes	
Audi TT	2007-2008	8J	22 4WD Electronics	Clear Fault Codes	
Audi TT	2007-2008	8J	22 4WD Electronics	Measuring Blocks	
Audi TT	2007-2008	8J	22 4WD Electronics	Output Tests	
Audi TT	2007-2008	8J	22 4WD Electronics	Specia Functions	
Audi TT	2007-2008	8J	25 Immobilizer	Read Fault Codes	
Audi TT	2007-2008	8J	25 Immobilizer	Clear Fault Codes	
Audi TT	2007-2008	8J	25 Immobilizer	Measuring Blocks	
Audi TT	2007-2008	8J	25 Immobilizer	Output Tests	
Audi TT	2007-2008	8J	25 Immobilizer	Specia Functions	
Audi TT	2007-2008	8J	26 Electric Roof Control	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2007-2008	8J	26 Electric Roof Control	Clear Fault Codes	
Audi TT	2007-2008	8J	26 Electric Roof Control	Measuring Blocks	
Audi TT	2007-2008	8J	26 Electric Roof Control	Output Tests	
Audi TT	2007-2008	8J	26 Electric Roof Control	Specia Functions	
Audi TT	2007-2008	8J	37 Navigation	Read Fault Codes	
Audi TT	2007-2008	8J	37 Navigation	Clear Fault Codes	
Audi TT	2007-2008	8J	37 Navigation	Measuring Blocks	
Audi TT	2007-2008	8J	37 Navigation	Output Tests	
Audi TT	2007-2008	8J	37 Navigation	Specia Functions	
Audi TT	2007-2008	8J	42 Driver-Door Elect.	Read Fault Codes	
Audi TT	2007-2008	8J	42 Driver-Door Elect.	Clear Fault Codes	
Audi TT	2007-2008	8J	42 Driver-Door Elect.	Measuring Blocks	
Audi TT	2007-2008	8J	42 Driver-Door Elect.	Output Tests	
Audi TT	2007-2008	8J	42 Driver-Door Elect.	Specia Functions	
Audi TT	2007-2008	8J	44 Steering Assistance	Read Fault Codes	
Audi TT	2007-2008	8J	44 Steering Assistance	Clear Fault Codes	
Audi TT	2007-2008	8J	44 Steering Assistance	Measuring Blocks	
Audi TT	2007-2008	8J	44 Steering Assistance	Output Tests	
Audi TT	2007-2008	8J	44 Steering Assistance	Specia Functions	
Audi TT	2007-2008	8J	46 Central Control Module	Read Fault Codes	
Audi TT	2007-2008	8J	46 Central Control Module	Clear Fault Codes	
Audi TT	2007-2008	8J	46 Central Control Module	Measuring Blocks	
Audi TT	2007-2008	8J	46 Central Control Module	Output Tests	
Audi TT	2007-2008	8J	46 Central Control Module	Specia Functions	
Audi TT	2007-2008	8J	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2007-2008	8J	47 Soundsystem	Clear Fault Codes	
Audi TT	2007-2008	8J	47 Soundsystem	Measuring Blocks	
Audi TT	2007-2008	8J	47 Soundsystem	Output Tests	
Audi TT	2007-2008	8J	47 Soundsystem	Specia Functions	
Audi TT	2007-2008	8J	4C Tyre Pressure Monitor II	Read Fault Codes	
Audi TT	2007-2008	8J	4C Tyre Pressure Monitor II	Clear Fault Codes	
Audi TT	2007-2008	8J	4C Tyre Pressure Monitor II	Measuring Blocks	
Audi TT	2007-2008	8J	4C Tyre Pressure Monitor II	Output Tests	
Audi TT	2007-2008	8J	4C Tyre Pressure Monitor II	Specia Functions	
Audi TT	2007-2008	8J	51 Electric Drive	Read Fault Codes	
Audi TT	2007-2008	8J	51 Electric Drive	Clear Fault Codes	
Audi TT	2007-2008	8J	51 Electric Drive	Measuring Blocks	
Audi TT	2007-2008	8J	51 Electric Drive	Output Tests	
Audi TT	2007-2008	8J	51 Electric Drive	Specia Functions	
Audi TT	2007-2008	8J	52 Passe.-Door Elect.	Read Fault Codes	
Audi TT	2007-2008	8J	52 Passe.-Door Elect.	Clear Fault Codes	
Audi TT	2007-2008	8J	52 Passe.-Door Elect.	Measuring Blocks	
Audi TT	2007-2008	8J	52 Passe.-Door Elect.	Output Tests	
Audi TT	2007-2008	8J	52 Passe.-Door Elect.	Specia Functions	
Audi TT	2007-2008	8J	55 Headlight Range Control	Read Fault Codes	
Audi TT	2007-2008	8J	55 Headlight Range Control	Clear Fault Codes	
Audi TT	2007-2008	8J	55 Headlight Range Control	Measuring Blocks	
Audi TT	2007-2008	8J	55 Headlight Range Control	Output Tests	
Audi TT	2007-2008	8J	55 Headlight Range Control	Specia Functions	
Audi TT	2007-2008	8J	56 Radio	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2007-2008	8J	56 Radio	Clear Fault Codes	
Audi TT	2007-2008	8J	56 Radio	Measuring Blocks	
Audi TT	2007-2008	8J	56 Radio	Output Tests	
Audi TT	2007-2008	8J	56 Radio	Specia Functions	
Audi TT	2007-2008	8J	57 TV-Tuner	Read Fault Codes	
Audi TT	2007-2008	8J	57 TV-Tuner	Clear Fault Codes	
Audi TT	2007-2008	8J	57 TV-Tuner	Measuring Blocks	
Audi TT	2007-2008	8J	57 TV-Tuner	Output Tests	
Audi TT	2007-2008	8J	57 TV-Tuner	Specia Functions	
Audi TT	2007-2008	8J	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi TT	2007-2008	8J	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi TT	2007-2008	8J	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi TT	2007-2008	8J	65 Tyre Pressure Monitoring	Output Tests	
Audi TT	2007-2008	8J	65 Tyre Pressure Monitoring	Specia Functions	
Audi TT	2007-2008	8J	76 Parking Aid	Read Fault Codes	
Audi TT	2007-2008	8J	76 Parking Aid	Clear Fault Codes	
Audi TT	2007-2008	8J	76 Parking Aid	Measuring Blocks	
Audi TT	2007-2008	8J	76 Parking Aid	Output Tests	
Audi TT	2007-2008	8J	76 Parking Aid	Specia Functions	
Audi TT	2007-2008	8J	77 Telephone	Read Fault Codes	
Audi TT	2007-2008	8J	77 Telephone	Clear Fault Codes	
Audi TT	2007-2008	8J	77 Telephone	Measuring Blocks	
Audi TT	2007-2008	8J	77 Telephone	Output Tests	
Audi TT	2007-2008	8J	77 Telephone	Specia Functions	
Audi TT	2007-2008	8J	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi TT	2007-2008	8J	8C Hybrid Battery	Clear Fault Codes	
Audi TT	2007-2008	8J	8C Hybrid Battery	Measuring Blocks	
Audi TT	2007-2008	8J	8C Hybrid Battery	Output Tests	
Audi TT	2007-2008	8J	8C Hybrid Battery	Specia Functions	
Audi Q7	2005-2008	4L	01 Engine Electronics	Read Fault Codes	
Audi Q7	2005-2008	4L	01 Engine Electronics	Clear Fault Codes	
Audi Q7	2005-2008	4L	01 Engine Electronics	Measuring Blocks	
Audi Q7	2005-2008	4L	01 Engine Electronics	Output Tests	
Audi Q7	2005-2008	4L	01 Engine Electronics	Specia Functions	
Audi Q7	2005-2008	4L	02 Transmission Electronics	Read Fault Codes	
Audi Q7	2005-2008	4L	02 Transmission Electronics	Clear Fault Codes	
Audi Q7	2005-2008	4L	02 Transmission Electronics	Measuring Blocks	
Audi Q7	2005-2008	4L	02 Transmission Electronics	Output Tests	
Audi Q7	2005-2008	4L	02 Transmission Electronics	Specia Functions	
Audi Q7	2005-2008	4L	03 Brake Electronics	Read Fault Codes	
Audi Q7	2005-2008	4L	03 Brake Electronics	Clear Fault Codes	
Audi Q7	2005-2008	4L	03 Brake Electronics	Measuring Blocks	
Audi Q7	2005-2008	4L	03 Brake Electronics	Output Tests	
Audi Q7	2005-2008	4L	03 Brake Electronics	Specia Functions	
Audi Q7	2005-2008	4L	05 Access & Permissi.	Read Fault Codes	
Audi Q7	2005-2008	4L	05 Access & Permissi.	Clear Fault Codes	
Audi Q7	2005-2008	4L	05 Access & Permissi.	Measuring Blocks	
Audi Q7	2005-2008	4L	05 Access & Permissi.	Output Tests	
Audi Q7	2005-2008	4L	05 Access & Permissi.	Specia Functions	
Audi Q7	2005-2008	4L	06 Passene. Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2005-2008	4L	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q7	2005-2008	4L	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q7	2005-2008	4L	06 Passene. Seat Adj.	Output Tests	
Audi Q7	2005-2008	4L	06 Passene. Seat Adj.	Specia Functions	
Audi Q7	2005-2008	4L	07 Display-/Cntl Unit	Read Fault Codes	
Audi Q7	2005-2008	4L	07 Display-/Cntl Unit	Clear Fault Codes	
Audi Q7	2005-2008	4L	07 Display-/Cntl Unit	Measuring Blocks	
Audi Q7	2005-2008	4L	07 Display-/Cntl Unit	Output Tests	
Audi Q7	2005-2008	4L	07 Display-/Cntl Unit	Specia Functions	
Audi Q7	2005-2008	4L	08 AC/Heating Electronics	Read Fault Codes	
Audi Q7	2005-2008	4L	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q7	2005-2008	4L	08 AC/Heating Electronics	Measuring Blocks	
Audi Q7	2005-2008	4L	08 AC/Heating Electronics	Output Tests	
Audi Q7	2005-2008	4L	08 AC/Heating Electronics	Specia Functions	
Audi Q7	2005-2008	4L	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Q7	2005-2008	4L	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q7	2005-2008	4L	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q7	2005-2008	4L	09 Electronic Ctrl Electronics	Output Tests	
Audi Q7	2005-2008	4L	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q7	2005-2008	4L	0E Media Player Position 1	Read Fault Codes	
Audi Q7	2005-2008	4L	0E Media Player Position 1	Clear Fault Codes	
Audi Q7	2005-2008	4L	0E Media Player Position 1	Measuring Blocks	
Audi Q7	2005-2008	4L	0E Media Player Position 1	Output Tests	
Audi Q7	2005-2008	4L	0E Media Player Position 1	Specia Functions	
Audi Q7	2005-2008	4L	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2005-2008	4L	0F Radio Tuner-Digital	Clear Fault Codes	
Audi Q7	2005-2008	4L	0F Radio Tuner-Digital	Measuring Blocks	
Audi Q7	2005-2008	4L	0F Radio Tuner-Digital	Output Tests	
Audi Q7	2005-2008	4L	0F Radio Tuner-Digital	Specia Functions	
Audi Q7	2005-2008	4L	11 Engine Electronics 2	Read Fault Codes	
Audi Q7	2005-2008	4L	11 Engine Electronics 2	Clear Fault Codes	
Audi Q7	2005-2008	4L	11 Engine Electronics 2	Measuring Blocks	
Audi Q7	2005-2008	4L	11 Engine Electronics 2	Output Tests	
Audi Q7	2005-2008	4L	11 Engine Electronics 2	Specia Functions	
Audi Q7	2005-2008	4L	13 Distance Control	Read Fault Codes	
Audi Q7	2005-2008	4L	13 Distance Control	Clear Fault Codes	
Audi Q7	2005-2008	4L	13 Distance Control	Measuring Blocks	
Audi Q7	2005-2008	4L	13 Distance Control	Output Tests	
Audi Q7	2005-2008	4L	13 Distance Control	Specia Functions	
Audi Q7	2005-2008	4L	15 Airbags	Read Fault Codes	
Audi Q7	2005-2008	4L	15 Airbags	Clear Fault Codes	
Audi Q7	2005-2008	4L	15 Airbags	Measuring Blocks	
Audi Q7	2005-2008	4L	15 Airbags	Output Tests	
Audi Q7	2005-2008	4L	15 Airbags	Specia Functions	
Audi Q7	2005-2008	4L	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q7	2005-2008	4L	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q7	2005-2008	4L	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q7	2005-2008	4L	16 Steering Wheel Electronics	Output Tests	
Audi Q7	2005-2008	4L	16 Steering Wheel Electronics	Specia Functions	
Audi Q7	2005-2008	4L	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2005-2008	4L	17 Instrument Cluster	Clear Fault Codes	
Audi Q7	2005-2008	4L	17 Instrument Cluster	Measuring Blocks	
Audi Q7	2005-2008	4L	17 Instrument Cluster	Output Tests	
Audi Q7	2005-2008	4L	17 Instrument Cluster	Specia Functions	
Audi Q7	2005-2008	4L	18 Aux Heating	Read Fault Codes	
Audi Q7	2005-2008	4L	18 Aux Heating	Clear Fault Codes	
Audi Q7	2005-2008	4L	18 Aux Heating	Measuring Blocks	
Audi Q7	2005-2008	4L	18 Aux Heating	Output Tests	
Audi Q7	2005-2008	4L	18 Aux Heating	Specia Functions	
Audi Q7	2005-2008	4L	19 Gateway Data Bus	Read Fault Codes	
Audi Q7	2005-2008	4L	19 Gateway Data Bus	Clear Fault Codes	
Audi Q7	2005-2008	4L	19 Gateway Data Bus	Measuring Blocks	
Audi Q7	2005-2008	4L	19 Gateway Data Bus	Output Tests	
Audi Q7	2005-2008	4L	19 Gateway Data Bus	Specia Functions	
Audi Q7	2005-2008	4L	1E Media Player Position 2	Read Fault Codes	
Audi Q7	2005-2008	4L	1E Media Player Position 2	Clear Fault Codes	
Audi Q7	2005-2008	4L	1E Media Player Position 2	Measuring Blocks	
Audi Q7	2005-2008	4L	1E Media Player Position 2	Output Tests	
Audi Q7	2005-2008	4L	1E Media Player Position 2	Specia Functions	
Audi Q7	2005-2008	4L	28 Climate Control Unit Rear	Read Fault Codes	
Audi Q7	2005-2008	4L	28 Climate Control Unit Rear	Clear Fault Codes	
Audi Q7	2005-2008	4L	28 Climate Control Unit Rear	Measuring Blocks	
Audi Q7	2005-2008	4L	28 Climate Control Unit Rear	Output Tests	
Audi Q7	2005-2008	4L	28 Climate Control Unit Rear	Specia Functions	
Audi Q7	2005-2008	4L	34 Self Leveling Suspension	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2005-2008	4L	34 Self Leveling Suspension	Clear Fault Codes	
Audi Q7	2005-2008	4L	34 Self Leveling Suspension	Measuring Blocks	
Audi Q7	2005-2008	4L	34 Self Leveling Suspension	Output Tests	
Audi Q7	2005-2008	4L	34 Self Leveling Suspension	Specia Functions	
Audi Q7	2005-2008	4L	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi Q7	2005-2008	4L	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Q7	2005-2008	4L	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Q7	2005-2008	4L	36 Side of Driver Seat Adj.	Output Tests	
Audi Q7	2005-2008	4L	36 Side of Driver Seat Adj.	Specia Functions	
Audi Q7	2005-2008	4L	37 Navigation	Read Fault Codes	
Audi Q7	2005-2008	4L	37 Navigation	Clear Fault Codes	
Audi Q7	2005-2008	4L	37 Navigation	Measuring Blocks	
Audi Q7	2005-2008	4L	37 Navigation	Output Tests	
Audi Q7	2005-2008	4L	37 Navigation	Specia Functions	
Audi Q7	2005-2008	4L	3C Lane Departure Assistance System	Read Fault Codes	
Audi Q7	2005-2008	4L	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q7	2005-2008	4L	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q7	2005-2008	4L	3C Lane Departure Assistance System	Output Tests	
Audi Q7	2005-2008	4L	3C Lane Departure Assistance System	Specia Functions	
Audi Q7	2005-2008	4L	42 Driver-Door Elect.	Read Fault Codes	
Audi Q7	2005-2008	4L	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q7	2005-2008	4L	42 Driver-Door Elect.	Measuring Blocks	
Audi Q7	2005-2008	4L	42 Driver-Door Elect.	Output Tests	
Audi Q7	2005-2008	4L	42 Driver-Door Elect.	Specia Functions	
Audi Q7	2005-2008	4L	46 Central Control Module	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2005-2008	4L	46 Central Control Module	Clear Fault Codes	
Audi Q7	2005-2008	4L	46 Central Control Module	Measuring Blocks	
Audi Q7	2005-2008	4L	46 Central Control Module	Output Tests	
Audi Q7	2005-2008	4L	46 Central Control Module	Specia Functions	
Audi Q7	2005-2008	4L	47 Soundsystem	Read Fault Codes	
Audi Q7	2005-2008	4L	47 Soundsystem	Clear Fault Codes	
Audi Q7	2005-2008	4L	47 Soundsystem	Measuring Blocks	
Audi Q7	2005-2008	4L	47 Soundsystem	Output Tests	
Audi Q7	2005-2008	4L	47 Soundsystem	Specia Functions	
Audi Q7	2005-2008	4L	4F Electronic Central Electric II	Read Fault Codes	
Audi Q7	2005-2008	4L	4F Electronic Central Electric II	Clear Fault Codes	
Audi Q7	2005-2008	4L	4F Electronic Central Electric II	Measuring Blocks	
Audi Q7	2005-2008	4L	4F Electronic Central Electric II	Output Tests	
Audi Q7	2005-2008	4L	4F Electronic Central Electric II	Specia Functions	
Audi Q7	2005-2008	4L	51 Electric Drive	Read Fault Codes	
Audi Q7	2005-2008	4L	51 Electric Drive	Clear Fault Codes	
Audi Q7	2005-2008	4L	51 Electric Drive	Measuring Blocks	
Audi Q7	2005-2008	4L	51 Electric Drive	Output Tests	
Audi Q7	2005-2008	4L	51 Electric Drive	Specia Functions	
Audi Q7	2005-2008	4L	52 Passe.-Door Elect.	Read Fault Codes	
Audi Q7	2005-2008	4L	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q7	2005-2008	4L	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q7	2005-2008	4L	52 Passe.-Door Elect.	Output Tests	
Audi Q7	2005-2008	4L	52 Passe.-Door Elect.	Specia Functions	
Audi Q7	2005-2008	4L	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2005-2008	4L	55 Headlight Range Control	Clear Fault Codes	
Audi Q7	2005-2008	4L	55 Headlight Range Control	Measuring Blocks	
Audi Q7	2005-2008	4L	55 Headlight Range Control	Output Tests	
Audi Q7	2005-2008	4L	55 Headlight Range Control	Specia Functions	
Audi Q7	2005-2008	4L	56 Radio	Read Fault Codes	
Audi Q7	2005-2008	4L	56 Radio	Clear Fault Codes	
Audi Q7	2005-2008	4L	56 Radio	Measuring Blocks	
Audi Q7	2005-2008	4L	56 Radio	Output Tests	
Audi Q7	2005-2008	4L	56 Radio	Specia Functions	
Audi Q7	2005-2008	4L	57 TV-Tuner	Read Fault Codes	
Audi Q7	2005-2008	4L	57 TV-Tuner	Clear Fault Codes	
Audi Q7	2005-2008	4L	57 TV-Tuner	Measuring Blocks	
Audi Q7	2005-2008	4L	57 TV-Tuner	Output Tests	
Audi Q7	2005-2008	4L	57 TV-Tuner	Specia Functions	
Audi Q7	2005-2008	4L	5C Lane Keeping Assistance System	Read Fault Codes	
Audi Q7	2005-2008	4L	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi Q7	2005-2008	4L	5C Lane Keeping Assistance System	Measuring Blocks	
Audi Q7	2005-2008	4L	5C Lane Keeping Assistance System	Output Tests	
Audi Q7	2005-2008	4L	5C Lane Keeping Assistance System	Specia Functions	
Audi Q7	2005-2008	4L	61 Battery Control	Read Fault Codes	
Audi Q7	2005-2008	4L	61 Battery Control	Clear Fault Codes	
Audi Q7	2005-2008	4L	61 Battery Control	Measuring Blocks	
Audi Q7	2005-2008	4L	61 Battery Control	Output Tests	
Audi Q7	2005-2008	4L	61 Battery Control	Specia Functions	
Audi Q7	2005-2008	4L	62 LR-Door Electroni.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2005-2008	4L	62 LR-Door Electroni.	Clear Fault Codes	
Audi Q7	2005-2008	4L	62 LR-Door Electroni.	Measuring Blocks	
Audi Q7	2005-2008	4L	62 LR-Door Electroni.	Output Tests	
Audi Q7	2005-2008	4L	62 LR-Door Electroni.	Specia Functions	
Audi Q7	2005-2008	4L	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Q7	2005-2008	4L	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Q7	2005-2008	4L	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Q7	2005-2008	4L	65 Tyre Pressure Monitoring	Output Tests	
Audi Q7	2005-2008	4L	65 Tyre Pressure Monitoring	Specia Functions	
Audi Q7	2005-2008	4L	67 Voice Control	Read Fault Codes	
Audi Q7	2005-2008	4L	67 Voice Control	Clear Fault Codes	
Audi Q7	2005-2008	4L	67 Voice Control	Measuring Blocks	
Audi Q7	2005-2008	4L	67 Voice Control	Output Tests	
Audi Q7	2005-2008	4L	67 Voice Control	Specia Functions	
Audi Q7	2005-2008	4L	69 Trailer Function	Read Fault Codes	
Audi Q7	2005-2008	4L	69 Trailer Function	Clear Fault Codes	
Audi Q7	2005-2008	4L	69 Trailer Function	Measuring Blocks	
Audi Q7	2005-2008	4L	69 Trailer Function	Output Tests	
Audi Q7	2005-2008	4L	69 Trailer Function	Specia Functions	
Audi Q7	2005-2008	4L	6C Rear Camera	Read Fault Codes	
Audi Q7	2005-2008	4L	6C Rear Camera	Clear Fault Codes	
Audi Q7	2005-2008	4L	6C Rear Camera	Measuring Blocks	
Audi Q7	2005-2008	4L	6C Rear Camera	Output Tests	
Audi Q7	2005-2008	4L	6C Rear Camera	Specia Functions	
Audi Q7	2005-2008	4L	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2005-2008	4L	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q7	2005-2008	4L	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q7	2005-2008	4L	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q7	2005-2008	4L	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q7	2005-2008	4L	6F Confort Central Control Unit II	Read Fault Codes	
Audi Q7	2005-2008	4L	6F Confort Central Control Unit II	Clear Fault Codes	
Audi Q7	2005-2008	4L	6F Confort Central Control Unit II	Measuring Blocks	
Audi Q7	2005-2008	4L	6F Confort Central Control Unit II	Output Tests	
Audi Q7	2005-2008	4L	6F Confort Central Control Unit II	Specia Functions	
Audi Q7	2005-2008	4L	72 RR-Door Electroni.	Read Fault Codes	
Audi Q7	2005-2008	4L	72 RR-Door Electroni.	Clear Fault Codes	
Audi Q7	2005-2008	4L	72 RR-Door Electroni.	Measuring Blocks	
Audi Q7	2005-2008	4L	72 RR-Door Electroni.	Output Tests	
Audi Q7	2005-2008	4L	72 RR-Door Electroni.	Specia Functions	
Audi Q7	2005-2008	4L	76 Parking Aid	Read Fault Codes	
Audi Q7	2005-2008	4L	76 Parking Aid	Clear Fault Codes	
Audi Q7	2005-2008	4L	76 Parking Aid	Measuring Blocks	
Audi Q7	2005-2008	4L	76 Parking Aid	Output Tests	
Audi Q7	2005-2008	4L	76 Parking Aid	Specia Functions	
Audi Q7	2005-2008	4L	77 Telephone	Read Fault Codes	
Audi Q7	2005-2008	4L	77 Telephone	Clear Fault Codes	
Audi Q7	2005-2008	4L	77 Telephone	Measuring Blocks	
Audi Q7	2005-2008	4L	77 Telephone	Output Tests	
Audi Q7	2005-2008	4L	77 Telephone	Specia Functions	
Audi Q7	2005-2008	4L	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7	2005-2008	4L	8C Hybrid Battery	Clear Fault Codes	
Audi Q7	2005-2008	4L	8C Hybrid Battery	Measuring Blocks	
Audi Q7	2005-2008	4L	8C Hybrid Battery	Output Tests	
Audi Q7	2005-2008	4L	8C Hybrid Battery	Specia Functions	
Audi Q7 USA	2007-2008	FE	01 Engine Electronics	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	01 Engine Electronics	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	01 Engine Electronics	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	01 Engine Electronics	Output Tests	
Audi Q7 USA	2007-2008	FE	01 Engine Electronics	Specia Functions	
Audi Q7 USA	2007-2008	FE	02 Transmission Electronics	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	02 Transmission Electronics	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	02 Transmission Electronics	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	02 Transmission Electronics	Output Tests	
Audi Q7 USA	2007-2008	FE	02 Transmission Electronics	Specia Functions	
Audi Q7 USA	2007-2008	FE	03 Brake Electronics	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	03 Brake Electronics	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	03 Brake Electronics	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	03 Brake Electronics	Output Tests	
Audi Q7 USA	2007-2008	FE	03 Brake Electronics	Specia Functions	
Audi Q7 USA	2007-2008	FE	05 Access & Permissi.	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	05 Access & Permissi.	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	05 Access & Permissi.	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	05 Access & Permissi.	Output Tests	
Audi Q7 USA	2007-2008	FE	05 Access & Permissi.	Specia Functions	
Audi Q7 USA	2007-2008	FE	06 Passene. Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 USA	2007-2008	FE	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	06 Passene. Seat Adj.	Output Tests	
Audi Q7 USA	2007-2008	FE	06 Passene. Seat Adj.	Specia Functions	
Audi Q7 USA	2007-2008	FE	07 Display-/Cntl Unit	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	07 Display-/Cntl Unit	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	07 Display-/Cntl Unit	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	07 Display-/Cntl Unit	Output Tests	
Audi Q7 USA	2007-2008	FE	07 Display-/Cntl Unit	Specia Functions	
Audi Q7 USA	2007-2008	FE	08 AC/Heating Electronics	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	08 AC/Heating Electronics	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	08 AC/Heating Electronics	Output Tests	
Audi Q7 USA	2007-2008	FE	08 AC/Heating Electronics	Specia Functions	
Audi Q7 USA	2007-2008	FE	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	09 Electronic Ctrl Electronics	Output Tests	
Audi Q7 USA	2007-2008	FE	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q7 USA	2007-2008	FE	0E Media Player Position 1	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	0E Media Player Position 1	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	0E Media Player Position 1	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	0E Media Player Position 1	Output Tests	
Audi Q7 USA	2007-2008	FE	0E Media Player Position 1	Specia Functions	
Audi Q7 USA	2007-2008	FE	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 USA	2007-2008	FE	0F Radio Tuner-Digital	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	0F Radio Tuner-Digital	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	0F Radio Tuner-Digital	Output Tests	
Audi Q7 USA	2007-2008	FE	0F Radio Tuner-Digital	Specia Functions	
Audi Q7 USA	2007-2008	FE	13 Distance Control	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	13 Distance Control	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	13 Distance Control	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	13 Distance Control	Output Tests	
Audi Q7 USA	2007-2008	FE	13 Distance Control	Specia Functions	
Audi Q7 USA	2007-2008	FE	15 Airbags	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	15 Airbags	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	15 Airbags	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	15 Airbags	Output Tests	
Audi Q7 USA	2007-2008	FE	15 Airbags	Specia Functions	
Audi Q7 USA	2007-2008	FE	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	16 Steering Wheel Electronics	Output Tests	
Audi Q7 USA	2007-2008	FE	16 Steering Wheel Electronics	Specia Functions	
Audi Q7 USA	2007-2008	FE	17 Instrument Cluster	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	17 Instrument Cluster	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	17 Instrument Cluster	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	17 Instrument Cluster	Output Tests	
Audi Q7 USA	2007-2008	FE	17 Instrument Cluster	Specia Functions	
Audi Q7 USA	2007-2008	FE	18 Aux Heating	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 USA	2007-2008	FE	18 Aux Heating	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	18 Aux Heating	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	18 Aux Heating	Output Tests	
Audi Q7 USA	2007-2008	FE	18 Aux Heating	Specia Functions	
Audi Q7 USA	2007-2008	FE	19 Gateway Data Bus	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	19 Gateway Data Bus	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	19 Gateway Data Bus	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	19 Gateway Data Bus	Output Tests	
Audi Q7 USA	2007-2008	FE	19 Gateway Data Bus	Specia Functions	
Audi Q7 USA	2007-2008	FE	1E Media Player Position 2	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	1E Media Player Position 2	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	1E Media Player Position 2	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	1E Media Player Position 2	Output Tests	
Audi Q7 USA	2007-2008	FE	1E Media Player Position 2	Specia Functions	
Audi Q7 USA	2007-2008	FE	28 Climate Control Unit Rear	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	28 Climate Control Unit Rear	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	28 Climate Control Unit Rear	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	28 Climate Control Unit Rear	Output Tests	
Audi Q7 USA	2007-2008	FE	28 Climate Control Unit Rear	Specia Functions	
Audi Q7 USA	2007-2008	FE	34 Self Leveling Suspension	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	34 Self Leveling Suspension	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	34 Self Leveling Suspension	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	34 Self Leveling Suspension	Output Tests	
Audi Q7 USA	2007-2008	FE	34 Self Leveling Suspension	Specia Functions	
Audi Q7 USA	2007-2008	FE	36 Side of Driver Seat Adj.	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi Q7 USA	2007-2008	FE	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	36 Side of Driver Seat Adj.	Output Tests	
Audi Q7 USA	2007-2008	FE	36 Side of Driver Seat Adj.	Specia Functions	
Audi Q7 USA	2007-2008	FE	37 Navigation	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	37 Navigation	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	37 Navigation	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	37 Navigation	Output Tests	
Audi Q7 USA	2007-2008	FE	37 Navigation	Specia Functions	
Audi Q7 USA	2007-2008	FE	3C Lane Departure Assistance System	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	3C Lane Departure Assistance System	Output Tests	
Audi Q7 USA	2007-2008	FE	3C Lane Departure Assistance System	Specia Functions	
Audi Q7 USA	2007-2008	FE	42 Driver-Door Elect.	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	42 Driver-Door Elect.	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	42 Driver-Door Elect.	Output Tests	
Audi Q7 USA	2007-2008	FE	42 Driver-Door Elect.	Specia Functions	
Audi Q7 USA	2007-2008	FE	46 Central Control Module	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	46 Central Control Module	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	46 Central Control Module	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	46 Central Control Module	Output Tests	
Audi Q7 USA	2007-2008	FE	46 Central Control Module	Specia Functions	
Audi Q7 USA	2007-2008	FE	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 USA	2007-2008	FE	47 Soundsystem	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	47 Soundsystem	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	47 Soundsystem	Output Tests	
Audi Q7 USA	2007-2008	FE	47 Soundsystem	Specia Functions	
Audi Q7 USA	2007-2008	FE	4F Electronic Central Electric II	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	4F Electronic Central Electric II	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	4F Electronic Central Electric II	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	4F Electronic Central Electric II	Output Tests	
Audi Q7 USA	2007-2008	FE	4F Electronic Central Electric II	Specia Functions	
Audi Q7 USA	2007-2008	FE	52 Passe.-Door Elect.	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	52 Passe.-Door Elect.	Output Tests	
Audi Q7 USA	2007-2008	FE	52 Passe.-Door Elect.	Specia Functions	
Audi Q7 USA	2007-2008	FE	55 Headlight Range Control	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	55 Headlight Range Control	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	55 Headlight Range Control	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	55 Headlight Range Control	Output Tests	
Audi Q7 USA	2007-2008	FE	55 Headlight Range Control	Specia Functions	
Audi Q7 USA	2007-2008	FE	56 Radio	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	56 Radio	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	56 Radio	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	56 Radio	Output Tests	
Audi Q7 USA	2007-2008	FE	56 Radio	Specia Functions	
Audi Q7 USA	2007-2008	FE	57 TV-Tuner	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 USA	2007-2008	FE	57 TV-Tuner	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	57 TV-Tuner	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	57 TV-Tuner	Output Tests	
Audi Q7 USA	2007-2008	FE	57 TV-Tuner	Specia Functions	
Audi Q7 USA	2007-2008	FE	5C Lane Keeping Assistance System	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	5C Lane Keeping Assistance System	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	5C Lane Keeping Assistance System	Output Tests	
Audi Q7 USA	2007-2008	FE	5C Lane Keeping Assistance System	Specia Functions	
Audi Q7 USA	2007-2008	FE	61 Battery Control	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	61 Battery Control	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	61 Battery Control	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	61 Battery Control	Output Tests	
Audi Q7 USA	2007-2008	FE	61 Battery Control	Specia Functions	
Audi Q7 USA	2007-2008	FE	62 LR-Door Electroni.	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	62 LR-Door Electroni.	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	62 LR-Door Electroni.	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	62 LR-Door Electroni.	Output Tests	
Audi Q7 USA	2007-2008	FE	62 LR-Door Electroni.	Specia Functions	
Audi Q7 USA	2007-2008	FE	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	65 Tyre Pressure Monitoring	Output Tests	
Audi Q7 USA	2007-2008	FE	65 Tyre Pressure Monitoring	Specia Functions	
Audi Q7 USA	2007-2008	FE	67 Voice Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 USA	2007-2008	FE	67 Voice Control	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	67 Voice Control	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	67 Voice Control	Output Tests	
Audi Q7 USA	2007-2008	FE	67 Voice Control	Specia Functions	
Audi Q7 USA	2007-2008	FE	69 Trailer Function	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	69 Trailer Function	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	69 Trailer Function	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	69 Trailer Function	Output Tests	
Audi Q7 USA	2007-2008	FE	69 Trailer Function	Specia Functions	
Audi Q7 USA	2007-2008	FE	6C Rear Camera	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	6C Rear Camera	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	6C Rear Camera	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	6C Rear Camera	Output Tests	
Audi Q7 USA	2007-2008	FE	6C Rear Camera	Specia Functions	
Audi Q7 USA	2007-2008	FE	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q7 USA	2007-2008	FE	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q7 USA	2007-2008	FE	6F Confort Central Control Unit II	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	6F Confort Central Control Unit II	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	6F Confort Central Control Unit II	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	6F Confort Central Control Unit II	Output Tests	
Audi Q7 USA	2007-2008	FE	6F Confort Central Control Unit II	Specia Functions	
Audi Q7 USA	2007-2008	FE	72 RR-Door Electroni.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 USA	2007-2008	FE	72 RR-Door Electroni.	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	72 RR-Door Electroni.	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	72 RR-Door Electroni.	Output Tests	
Audi Q7 USA	2007-2008	FE	72 RR-Door Electroni.	Specia Functions	
Audi Q7 USA	2007-2008	FE	76 Parking Aid	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	76 Parking Aid	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	76 Parking Aid	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	76 Parking Aid	Output Tests	
Audi Q7 USA	2007-2008	FE	76 Parking Aid	Specia Functions	
Audi Q7 USA	2007-2008	FE	77 Telephone	Read Fault Codes	
Audi Q7 USA	2007-2008	FE	77 Telephone	Clear Fault Codes	
Audi Q7 USA	2007-2008	FE	77 Telephone	Measuring Blocks	
Audi Q7 USA	2007-2008	FE	77 Telephone	Output Tests	
Audi Q7 USA	2007-2008	FE	77 Telephone	Specia Functions	
Audi Q7 USA	2009	FE	01 Engine Electronics	Read Fault Codes	
Audi Q7 USA	2009	FE	01 Engine Electronics	Clear Fault Codes	
Audi Q7 USA	2009	FE	01 Engine Electronics	Measuring Blocks	
Audi Q7 USA	2009	FE	01 Engine Electronics	Output Tests	
Audi Q7 USA	2009	FE	01 Engine Electronics	Specia Functions	
Audi Q7 USA	2009	FE	02 Transmission Electronics	Read Fault Codes	
Audi Q7 USA	2009	FE	02 Transmission Electronics	Clear Fault Codes	
Audi Q7 USA	2009	FE	02 Transmission Electronics	Measuring Blocks	
Audi Q7 USA	2009	FE	02 Transmission Electronics	Output Tests	
Audi Q7 USA	2009	FE	02 Transmission Electronics	Specia Functions	
Audi Q7 USA	2009	FE	03 Brake Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 USA	2009	FE	03 Brake Electronics	Clear Fault Codes	
Audi Q7 USA	2009	FE	03 Brake Electronics	Measuring Blocks	
Audi Q7 USA	2009	FE	03 Brake Electronics	Output Tests	
Audi Q7 USA	2009	FE	03 Brake Electronics	Specia Functions	
Audi Q7 USA	2009	FE	05 Access & Permissi.	Read Fault Codes	
Audi Q7 USA	2009	FE	05 Access & Permissi.	Clear Fault Codes	
Audi Q7 USA	2009	FE	05 Access & Permissi.	Measuring Blocks	
Audi Q7 USA	2009	FE	05 Access & Permissi.	Output Tests	
Audi Q7 USA	2009	FE	05 Access & Permissi.	Specia Functions	
Audi Q7 USA	2009	FE	06 Passene. Seat Adj.	Read Fault Codes	
Audi Q7 USA	2009	FE	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q7 USA	2009	FE	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q7 USA	2009	FE	06 Passene. Seat Adj.	Output Tests	
Audi Q7 USA	2009	FE	06 Passene. Seat Adj.	Specia Functions	
Audi Q7 USA	2009	FE	07 Display-/Cntl Unit	Read Fault Codes	
Audi Q7 USA	2009	FE	07 Display-/Cntl Unit	Clear Fault Codes	
Audi Q7 USA	2009	FE	07 Display-/Cntl Unit	Measuring Blocks	
Audi Q7 USA	2009	FE	07 Display-/Cntl Unit	Output Tests	
Audi Q7 USA	2009	FE	07 Display-/Cntl Unit	Specia Functions	
Audi Q7 USA	2009	FE	08 AC/Heating Electronics	Read Fault Codes	
Audi Q7 USA	2009	FE	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q7 USA	2009	FE	08 AC/Heating Electronics	Measuring Blocks	
Audi Q7 USA	2009	FE	08 AC/Heating Electronics	Output Tests	
Audi Q7 USA	2009	FE	08 AC/Heating Electronics	Specia Functions	
Audi Q7 USA	2009	FE	09 Electronic Ctrl Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 USA	2009	FE	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q7 USA	2009	FE	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q7 USA	2009	FE	09 Electronic Ctrl Electronics	Output Tests	
Audi Q7 USA	2009	FE	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q7 USA	2009	FE	0E Media Player Position 1	Read Fault Codes	
Audi Q7 USA	2009	FE	0E Media Player Position 1	Clear Fault Codes	
Audi Q7 USA	2009	FE	0E Media Player Position 1	Measuring Blocks	
Audi Q7 USA	2009	FE	0E Media Player Position 1	Output Tests	
Audi Q7 USA	2009	FE	0E Media Player Position 1	Specia Functions	
Audi Q7 USA	2009	FE	0F Radio Tuner-Digital	Read Fault Codes	
Audi Q7 USA	2009	FE	0F Radio Tuner-Digital	Clear Fault Codes	
Audi Q7 USA	2009	FE	0F Radio Tuner-Digital	Measuring Blocks	
Audi Q7 USA	2009	FE	0F Radio Tuner-Digital	Output Tests	
Audi Q7 USA	2009	FE	0F Radio Tuner-Digital	Specia Functions	
Audi Q7 USA	2009	FE	13 Distance Control	Read Fault Codes	
Audi Q7 USA	2009	FE	13 Distance Control	Clear Fault Codes	
Audi Q7 USA	2009	FE	13 Distance Control	Measuring Blocks	
Audi Q7 USA	2009	FE	13 Distance Control	Output Tests	
Audi Q7 USA	2009	FE	13 Distance Control	Specia Functions	
Audi Q7 USA	2009	FE	15 Airbags	Read Fault Codes	
Audi Q7 USA	2009	FE	15 Airbags	Clear Fault Codes	
Audi Q7 USA	2009	FE	15 Airbags	Measuring Blocks	
Audi Q7 USA	2009	FE	15 Airbags	Output Tests	
Audi Q7 USA	2009	FE	15 Airbags	Specia Functions	
Audi Q7 USA	2009	FE	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 USA	2009	FE	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q7 USA	2009	FE	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q7 USA	2009	FE	16 Steering Wheel Electronics	Output Tests	
Audi Q7 USA	2009	FE	16 Steering Wheel Electronics	Specia Functions	
Audi Q7 USA	2009	FE	17 Instrument Cluster	Read Fault Codes	
Audi Q7 USA	2009	FE	17 Instrument Cluster	Clear Fault Codes	
Audi Q7 USA	2009	FE	17 Instrument Cluster	Measuring Blocks	
Audi Q7 USA	2009	FE	17 Instrument Cluster	Output Tests	
Audi Q7 USA	2009	FE	17 Instrument Cluster	Specia Functions	
Audi Q7 USA	2009	FE	18 Aux Heating	Read Fault Codes	
Audi Q7 USA	2009	FE	18 Aux Heating	Clear Fault Codes	
Audi Q7 USA	2009	FE	18 Aux Heating	Measuring Blocks	
Audi Q7 USA	2009	FE	18 Aux Heating	Output Tests	
Audi Q7 USA	2009	FE	18 Aux Heating	Specia Functions	
Audi Q7 USA	2009	FE	19 Gateway Data Bus	Read Fault Codes	
Audi Q7 USA	2009	FE	19 Gateway Data Bus	Clear Fault Codes	
Audi Q7 USA	2009	FE	19 Gateway Data Bus	Measuring Blocks	
Audi Q7 USA	2009	FE	19 Gateway Data Bus	Output Tests	
Audi Q7 USA	2009	FE	19 Gateway Data Bus	Specia Functions	
Audi Q7 USA	2009	FE	1E Media Player Position 2	Read Fault Codes	
Audi Q7 USA	2009	FE	1E Media Player Position 2	Clear Fault Codes	
Audi Q7 USA	2009	FE	1E Media Player Position 2	Measuring Blocks	
Audi Q7 USA	2009	FE	1E Media Player Position 2	Output Tests	
Audi Q7 USA	2009	FE	1E Media Player Position 2	Specia Functions	
Audi Q7 USA	2009	FE	20 High Beam Assistance Device	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 USA	2009	FE	20 High Beam Assistance Device	Clear Fault Codes	
Audi Q7 USA	2009	FE	20 High Beam Assistance Device	Measuring Blocks	
Audi Q7 USA	2009	FE	20 High Beam Assistance Device	Output Tests	
Audi Q7 USA	2009	FE	20 High Beam Assistance Device	Specia Functions	
Audi Q7 USA	2009	FE	28 Climate Control Unit Rear	Read Fault Codes	
Audi Q7 USA	2009	FE	28 Climate Control Unit Rear	Clear Fault Codes	
Audi Q7 USA	2009	FE	28 Climate Control Unit Rear	Measuring Blocks	
Audi Q7 USA	2009	FE	28 Climate Control Unit Rear	Output Tests	
Audi Q7 USA	2009	FE	28 Climate Control Unit Rear	Specia Functions	
Audi Q7 USA	2009	FE	34 Self Leveling Suspension	Read Fault Codes	
Audi Q7 USA	2009	FE	34 Self Leveling Suspension	Clear Fault Codes	
Audi Q7 USA	2009	FE	34 Self Leveling Suspension	Measuring Blocks	
Audi Q7 USA	2009	FE	34 Self Leveling Suspension	Output Tests	
Audi Q7 USA	2009	FE	34 Self Leveling Suspension	Specia Functions	
Audi Q7 USA	2009	FE	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi Q7 USA	2009	FE	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Q7 USA	2009	FE	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Q7 USA	2009	FE	36 Side of Driver Seat Adj.	Output Tests	
Audi Q7 USA	2009	FE	36 Side of Driver Seat Adj.	Specia Functions	
Audi Q7 USA	2009	FE	37 Navigation	Read Fault Codes	
Audi Q7 USA	2009	FE	37 Navigation	Clear Fault Codes	
Audi Q7 USA	2009	FE	37 Navigation	Measuring Blocks	
Audi Q7 USA	2009	FE	37 Navigation	Output Tests	
Audi Q7 USA	2009	FE	37 Navigation	Specia Functions	
Audi Q7 USA	2009	FE	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 USA	2009	FE	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q7 USA	2009	FE	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q7 USA	2009	FE	3C Lane Departure Assistance System	Output Tests	
Audi Q7 USA	2009	FE	3C Lane Departure Assistance System	Specia Functions	
Audi Q7 USA	2009	FE	3D Special Function	Read Fault Codes	
Audi Q7 USA	2009	FE	3D Special Function	Clear Fault Codes	
Audi Q7 USA	2009	FE	3D Special Function	Measuring Blocks	
Audi Q7 USA	2009	FE	3D Special Function	Output Tests	
Audi Q7 USA	2009	FE	3D Special Function	Specia Functions	
Audi Q7 USA	2009	FE	42 Driver-Door Elect.	Read Fault Codes	
Audi Q7 USA	2009	FE	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q7 USA	2009	FE	42 Driver-Door Elect.	Measuring Blocks	
Audi Q7 USA	2009	FE	42 Driver-Door Elect.	Output Tests	
Audi Q7 USA	2009	FE	42 Driver-Door Elect.	Specia Functions	
Audi Q7 USA	2009	FE	46 Central Control Module	Read Fault Codes	
Audi Q7 USA	2009	FE	46 Central Control Module	Clear Fault Codes	
Audi Q7 USA	2009	FE	46 Central Control Module	Measuring Blocks	
Audi Q7 USA	2009	FE	46 Central Control Module	Output Tests	
Audi Q7 USA	2009	FE	46 Central Control Module	Specia Functions	
Audi Q7 USA	2009	FE	47 Soundsystem	Read Fault Codes	
Audi Q7 USA	2009	FE	47 Soundsystem	Clear Fault Codes	
Audi Q7 USA	2009	FE	47 Soundsystem	Measuring Blocks	
Audi Q7 USA	2009	FE	47 Soundsystem	Output Tests	
Audi Q7 USA	2009	FE	47 Soundsystem	Specia Functions	
Audi Q7 USA	2009	FE	4F Electronic Central Electric II	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 USA	2009	FE	4F Electronic Central Electric II	Clear Fault Codes	
Audi Q7 USA	2009	FE	4F Electronic Central Electric II	Measuring Blocks	
Audi Q7 USA	2009	FE	4F Electronic Central Electric II	Output Tests	
Audi Q7 USA	2009	FE	4F Electronic Central Electric II	Specia Functions	
Audi Q7 USA	2009	FE	52 Passe.-Door Elect.	Read Fault Codes	
Audi Q7 USA	2009	FE	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q7 USA	2009	FE	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q7 USA	2009	FE	52 Passe.-Door Elect.	Output Tests	
Audi Q7 USA	2009	FE	52 Passe.-Door Elect.	Specia Functions	
Audi Q7 USA	2009	FE	55 Headlight Range Control	Read Fault Codes	
Audi Q7 USA	2009	FE	55 Headlight Range Control	Clear Fault Codes	
Audi Q7 USA	2009	FE	55 Headlight Range Control	Measuring Blocks	
Audi Q7 USA	2009	FE	55 Headlight Range Control	Output Tests	
Audi Q7 USA	2009	FE	55 Headlight Range Control	Specia Functions	
Audi Q7 USA	2009	FE	56 Radio	Read Fault Codes	
Audi Q7 USA	2009	FE	56 Radio	Clear Fault Codes	
Audi Q7 USA	2009	FE	56 Radio	Measuring Blocks	
Audi Q7 USA	2009	FE	56 Radio	Output Tests	
Audi Q7 USA	2009	FE	56 Radio	Specia Functions	
Audi Q7 USA	2009	FE	57 TV-Tuner	Read Fault Codes	
Audi Q7 USA	2009	FE	57 TV-Tuner	Clear Fault Codes	
Audi Q7 USA	2009	FE	57 TV-Tuner	Measuring Blocks	
Audi Q7 USA	2009	FE	57 TV-Tuner	Output Tests	
Audi Q7 USA	2009	FE	57 TV-Tuner	Specia Functions	
Audi Q7 USA	2009	FE	5C Lane Keeping Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 USA	2009	FE	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi Q7 USA	2009	FE	5C Lane Keeping Assistance System	Measuring Blocks	
Audi Q7 USA	2009	FE	5C Lane Keeping Assistance System	Output Tests	
Audi Q7 USA	2009	FE	5C Lane Keeping Assistance System	Specia Functions	
Audi Q7 USA	2009	FE	62 LR-Door Electroni.	Read Fault Codes	
Audi Q7 USA	2009	FE	62 LR-Door Electroni.	Clear Fault Codes	
Audi Q7 USA	2009	FE	62 LR-Door Electroni.	Measuring Blocks	
Audi Q7 USA	2009	FE	62 LR-Door Electroni.	Output Tests	
Audi Q7 USA	2009	FE	62 LR-Door Electroni.	Specia Functions	
Audi Q7 USA	2009	FE	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Q7 USA	2009	FE	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Q7 USA	2009	FE	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Q7 USA	2009	FE	65 Tyre Pressure Monitoring	Output Tests	
Audi Q7 USA	2009	FE	65 Tyre Pressure Monitoring	Specia Functions	
Audi Q7 USA	2009	FE	67 Voice Control	Read Fault Codes	
Audi Q7 USA	2009	FE	67 Voice Control	Clear Fault Codes	
Audi Q7 USA	2009	FE	67 Voice Control	Measuring Blocks	
Audi Q7 USA	2009	FE	67 Voice Control	Output Tests	
Audi Q7 USA	2009	FE	67 Voice Control	Specia Functions	
Audi Q7 USA	2009	FE	69 Trailer Function	Read Fault Codes	
Audi Q7 USA	2009	FE	69 Trailer Function	Clear Fault Codes	
Audi Q7 USA	2009	FE	69 Trailer Function	Measuring Blocks	
Audi Q7 USA	2009	FE	69 Trailer Function	Output Tests	
Audi Q7 USA	2009	FE	69 Trailer Function	Specia Functions	
Audi Q7 USA	2009	FE	6C Rear Camera	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q7 USA	2009	FE	6C Rear Camera	Clear Fault Codes	
Audi Q7 USA	2009	FE	6C Rear Camera	Measuring Blocks	
Audi Q7 USA	2009	FE	6C Rear Camera	Output Tests	
Audi Q7 USA	2009	FE	6C Rear Camera	Specia Functions	
Audi Q7 USA	2009	FE	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi Q7 USA	2009	FE	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q7 USA	2009	FE	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q7 USA	2009	FE	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q7 USA	2009	FE	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q7 USA	2009	FE	6F Confort Central Control Unit II	Read Fault Codes	
Audi Q7 USA	2009	FE	6F Confort Central Control Unit II	Clear Fault Codes	
Audi Q7 USA	2009	FE	6F Confort Central Control Unit II	Measuring Blocks	
Audi Q7 USA	2009	FE	6F Confort Central Control Unit II	Output Tests	
Audi Q7 USA	2009	FE	6F Confort Central Control Unit II	Specia Functions	
Audi Q7 USA	2009	FE	72 RR-Door Electroni.	Read Fault Codes	
Audi Q7 USA	2009	FE	72 RR-Door Electroni.	Clear Fault Codes	
Audi Q7 USA	2009	FE	72 RR-Door Electroni.	Measuring Blocks	
Audi Q7 USA	2009	FE	72 RR-Door Electroni.	Output Tests	
Audi Q7 USA	2009	FE	72 RR-Door Electroni.	Specia Functions	
Audi Q7 USA	2009	FE	76 Parking Aid	Read Fault Codes	
Audi Q7 USA	2009	FE	76 Parking Aid	Clear Fault Codes	
Audi Q7 USA	2009	FE	76 Parking Aid	Measuring Blocks	
Audi Q7 USA	2009	FE	76 Parking Aid	Output Tests	
Audi Q7 USA	2009	FE	76 Parking Aid	Specia Functions	
Audi Q7 USA	2009	FE	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q7 USA	2009	FE	77 Telephone	Clear Fault Codes	
Audi Q7 USA	2009	FE	77 Telephone	Measuring Blocks	
Audi Q7 USA	2009	FE	77 Telephone	Output Tests	
Audi Q7 USA	2009	FE	77 Telephone	Specia Functions	
Audi R8	2006-2007	42	01 Engine Electronics	Read Fault Codes	
Audi R8	2006-2007	42	01 Engine Electronics	Clear Fault Codes	
Audi R8	2006-2007	42	01 Engine Electronics	Measuring Blocks	
Audi R8	2006-2007	42	01 Engine Electronics	Output Tests	
Audi R8	2006-2007	42	01 Engine Electronics	Specia Functions	
Audi R8	2006-2007	42	02 Transmission Electronics	Read Fault Codes	
Audi R8	2006-2007	42	02 Transmission Electronics	Clear Fault Codes	
Audi R8	2006-2007	42	02 Transmission Electronics	Measuring Blocks	
Audi R8	2006-2007	42	02 Transmission Electronics	Output Tests	
Audi R8	2006-2007	42	02 Transmission Electronics	Specia Functions	
Audi R8	2006-2007	42	03 Brake Electronics	Read Fault Codes	
Audi R8	2006-2007	42	03 Brake Electronics	Clear Fault Codes	
Audi R8	2006-2007	42	03 Brake Electronics	Measuring Blocks	
Audi R8	2006-2007	42	03 Brake Electronics	Output Tests	
Audi R8	2006-2007	42	03 Brake Electronics	Specia Functions	
Audi R8	2006-2007	42	08 AC/Heating Electronics	Read Fault Codes	
Audi R8	2006-2007	42	08 AC/Heating Electronics	Clear Fault Codes	
Audi R8	2006-2007	42	08 AC/Heating Electronics	Measuring Blocks	
Audi R8	2006-2007	42	08 AC/Heating Electronics	Output Tests	
Audi R8	2006-2007	42	08 AC/Heating Electronics	Specia Functions	
Audi R8	2006-2007	42	09 Electronic Ctrl Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2006-2007	42	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi R8	2006-2007	42	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi R8	2006-2007	42	09 Electronic Ctrl Electronics	Output Tests	
Audi R8	2006-2007	42	09 Electronic Ctrl Electronics	Specia Functions	
Audi R8	2006-2007	42	11 Engine Electronics 2	Read Fault Codes	
Audi R8	2006-2007	42	11 Engine Electronics 2	Clear Fault Codes	
Audi R8	2006-2007	42	11 Engine Electronics 2	Measuring Blocks	
Audi R8	2006-2007	42	11 Engine Electronics 2	Output Tests	
Audi R8	2006-2007	42	11 Engine Electronics 2	Specia Functions	
Audi R8	2006-2007	42	14 Wheel Damping Electronics	Read Fault Codes	
Audi R8	2006-2007	42	14 Wheel Damping Electronics	Clear Fault Codes	
Audi R8	2006-2007	42	14 Wheel Damping Electronics	Measuring Blocks	
Audi R8	2006-2007	42	14 Wheel Damping Electronics	Output Tests	
Audi R8	2006-2007	42	14 Wheel Damping Electronics	Specia Functions	
Audi R8	2006-2007	42	15 Airbags	Read Fault Codes	
Audi R8	2006-2007	42	15 Airbags	Clear Fault Codes	
Audi R8	2006-2007	42	15 Airbags	Measuring Blocks	
Audi R8	2006-2007	42	15 Airbags	Output Tests	
Audi R8	2006-2007	42	15 Airbags	Specia Functions	
Audi R8	2006-2007	42	16 Steering Wheel Electronics	Read Fault Codes	
Audi R8	2006-2007	42	16 Steering Wheel Electronics	Clear Fault Codes	
Audi R8	2006-2007	42	16 Steering Wheel Electronics	Measuring Blocks	
Audi R8	2006-2007	42	16 Steering Wheel Electronics	Output Tests	
Audi R8	2006-2007	42	16 Steering Wheel Electronics	Specia Functions	
Audi R8	2006-2007	42	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2006-2007	42	17 Instrument Cluster	Clear Fault Codes	
Audi R8	2006-2007	42	17 Instrument Cluster	Measuring Blocks	
Audi R8	2006-2007	42	17 Instrument Cluster	Output Tests	
Audi R8	2006-2007	42	17 Instrument Cluster	Specia Functions	
Audi R8	2006-2007	42	19 Gateway Data Bus	Read Fault Codes	
Audi R8	2006-2007	42	19 Gateway Data Bus	Clear Fault Codes	
Audi R8	2006-2007	42	19 Gateway Data Bus	Measuring Blocks	
Audi R8	2006-2007	42	19 Gateway Data Bus	Output Tests	
Audi R8	2006-2007	42	19 Gateway Data Bus	Specia Functions	
Audi R8	2006-2007	42	25 Immobilizer	Read Fault Codes	
Audi R8	2006-2007	42	25 Immobilizer	Clear Fault Codes	
Audi R8	2006-2007	42	25 Immobilizer	Measuring Blocks	
Audi R8	2006-2007	42	25 Immobilizer	Output Tests	
Audi R8	2006-2007	42	25 Immobilizer	Specia Functions	
Audi R8	2006-2007	42	37 Navigation	Read Fault Codes	
Audi R8	2006-2007	42	37 Navigation	Clear Fault Codes	
Audi R8	2006-2007	42	37 Navigation	Measuring Blocks	
Audi R8	2006-2007	42	37 Navigation	Output Tests	
Audi R8	2006-2007	42	37 Navigation	Specia Functions	
Audi R8	2006-2007	42	42 Driver-Door Elect.	Read Fault Codes	
Audi R8	2006-2007	42	42 Driver-Door Elect.	Clear Fault Codes	
Audi R8	2006-2007	42	42 Driver-Door Elect.	Measuring Blocks	
Audi R8	2006-2007	42	42 Driver-Door Elect.	Output Tests	
Audi R8	2006-2007	42	42 Driver-Door Elect.	Specia Functions	
Audi R8	2006-2007	42	46 Central Control Module	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2006-2007	42	46 Central Control Module	Clear Fault Codes	
Audi R8	2006-2007	42	46 Central Control Module	Measuring Blocks	
Audi R8	2006-2007	42	46 Central Control Module	Output Tests	
Audi R8	2006-2007	42	46 Central Control Module	Specia Functions	
Audi R8	2006-2007	42	47 Soundsystem	Read Fault Codes	
Audi R8	2006-2007	42	47 Soundsystem	Clear Fault Codes	
Audi R8	2006-2007	42	47 Soundsystem	Measuring Blocks	
Audi R8	2006-2007	42	47 Soundsystem	Output Tests	
Audi R8	2006-2007	42	47 Soundsystem	Specia Functions	
Audi R8	2006-2007	42	51 Electric Drive	Read Fault Codes	
Audi R8	2006-2007	42	51 Electric Drive	Clear Fault Codes	
Audi R8	2006-2007	42	51 Electric Drive	Measuring Blocks	
Audi R8	2006-2007	42	51 Electric Drive	Output Tests	
Audi R8	2006-2007	42	51 Electric Drive	Specia Functions	
Audi R8	2006-2007	42	52 Passe.-Door Elect.	Read Fault Codes	
Audi R8	2006-2007	42	52 Passe.-Door Elect.	Clear Fault Codes	
Audi R8	2006-2007	42	52 Passe.-Door Elect.	Measuring Blocks	
Audi R8	2006-2007	42	52 Passe.-Door Elect.	Output Tests	
Audi R8	2006-2007	42	52 Passe.-Door Elect.	Specia Functions	
Audi R8	2006-2007	42	56 Radio	Read Fault Codes	
Audi R8	2006-2007	42	56 Radio	Clear Fault Codes	
Audi R8	2006-2007	42	56 Radio	Measuring Blocks	
Audi R8	2006-2007	42	56 Radio	Output Tests	
Audi R8	2006-2007	42	56 Radio	Specia Functions	
Audi R8	2006-2007	42	65 Tyre Pressure Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2006-2007	42	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi R8	2006-2007	42	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi R8	2006-2007	42	65 Tyre Pressure Monitoring	Output Tests	
Audi R8	2006-2007	42	65 Tyre Pressure Monitoring	Specia Functions	
Audi R8	2006-2007	42	6C Rear Camera	Read Fault Codes	
Audi R8	2006-2007	42	6C Rear Camera	Clear Fault Codes	
Audi R8	2006-2007	42	6C Rear Camera	Measuring Blocks	
Audi R8	2006-2007	42	6C Rear Camera	Output Tests	
Audi R8	2006-2007	42	6C Rear Camera	Specia Functions	
Audi R8	2006-2007	42	76 Parking Aid	Read Fault Codes	
Audi R8	2006-2007	42	76 Parking Aid	Clear Fault Codes	
Audi R8	2006-2007	42	76 Parking Aid	Measuring Blocks	
Audi R8	2006-2007	42	76 Parking Aid	Output Tests	
Audi R8	2006-2007	42	76 Parking Aid	Specia Functions	
Audi R8	2006-2007	42	77 Telephone	Read Fault Codes	
Audi R8	2006-2007	42	77 Telephone	Clear Fault Codes	
Audi R8	2006-2007	42	77 Telephone	Measuring Blocks	
Audi R8	2006-2007	42	77 Telephone	Output Tests	
Audi R8	2006-2007	42	77 Telephone	Specia Functions	
Audi R8	2006-2007	42	8C Hybrid Battery	Read Fault Codes	
Audi R8	2006-2007	42	8C Hybrid Battery	Clear Fault Codes	
Audi R8	2006-2007	42	8C Hybrid Battery	Measuring Blocks	
Audi R8	2006-2007	42	8C Hybrid Battery	Output Tests	
Audi R8	2006-2007	42	8C Hybrid Battery	Specia Functions	
Audi R8	2008	42	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2008	42	01 Engine Electronics	Clear Fault Codes	
Audi R8	2008	42	01 Engine Electronics	Measuring Blocks	
Audi R8	2008	42	01 Engine Electronics	Output Tests	
Audi R8	2008	42	01 Engine Electronics	Specia Functions	
Audi R8	2008	42	02 Transmission Electronics	Read Fault Codes	
Audi R8	2008	42	02 Transmission Electronics	Clear Fault Codes	
Audi R8	2008	42	02 Transmission Electronics	Measuring Blocks	
Audi R8	2008	42	02 Transmission Electronics	Output Tests	
Audi R8	2008	42	02 Transmission Electronics	Specia Functions	
Audi R8	2008	42	03 Brake Electronics	Read Fault Codes	
Audi R8	2008	42	03 Brake Electronics	Clear Fault Codes	
Audi R8	2008	42	03 Brake Electronics	Measuring Blocks	
Audi R8	2008	42	03 Brake Electronics	Output Tests	
Audi R8	2008	42	03 Brake Electronics	Specia Functions	
Audi R8	2008	42	08 AC/Heating Electronics	Read Fault Codes	
Audi R8	2008	42	08 AC/Heating Electronics	Clear Fault Codes	
Audi R8	2008	42	08 AC/Heating Electronics	Measuring Blocks	
Audi R8	2008	42	08 AC/Heating Electronics	Output Tests	
Audi R8	2008	42	08 AC/Heating Electronics	Specia Functions	
Audi R8	2008	42	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi R8	2008	42	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi R8	2008	42	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi R8	2008	42	09 Electronic Ctrl Electronics	Output Tests	
Audi R8	2008	42	09 Electronic Ctrl Electronics	Specia Functions	
Audi R8	2008	42	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2008	42	0F Radio Tuner-Digital	Clear Fault Codes	
Audi R8	2008	42	0F Radio Tuner-Digital	Measuring Blocks	
Audi R8	2008	42	0F Radio Tuner-Digital	Output Tests	
Audi R8	2008	42	0F Radio Tuner-Digital	Specia Functions	
Audi R8	2008	42	11 Engine Electronics 2	Read Fault Codes	
Audi R8	2008	42	11 Engine Electronics 2	Clear Fault Codes	
Audi R8	2008	42	11 Engine Electronics 2	Measuring Blocks	
Audi R8	2008	42	11 Engine Electronics 2	Output Tests	
Audi R8	2008	42	11 Engine Electronics 2	Specia Functions	
Audi R8	2008	42	14 Wheel Damping Electronics	Read Fault Codes	
Audi R8	2008	42	14 Wheel Damping Electronics	Clear Fault Codes	
Audi R8	2008	42	14 Wheel Damping Electronics	Measuring Blocks	
Audi R8	2008	42	14 Wheel Damping Electronics	Output Tests	
Audi R8	2008	42	14 Wheel Damping Electronics	Specia Functions	
Audi R8	2008	42	15 Airbags	Read Fault Codes	
Audi R8	2008	42	15 Airbags	Clear Fault Codes	
Audi R8	2008	42	15 Airbags	Measuring Blocks	
Audi R8	2008	42	15 Airbags	Output Tests	
Audi R8	2008	42	15 Airbags	Specia Functions	
Audi R8	2008	42	16 Steering Wheel Electronics	Read Fault Codes	
Audi R8	2008	42	16 Steering Wheel Electronics	Clear Fault Codes	
Audi R8	2008	42	16 Steering Wheel Electronics	Measuring Blocks	
Audi R8	2008	42	16 Steering Wheel Electronics	Output Tests	
Audi R8	2008	42	16 Steering Wheel Electronics	Specia Functions	
Audi R8	2008	42	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2008	42	17 Instrument Cluster	Clear Fault Codes	
Audi R8	2008	42	17 Instrument Cluster	Measuring Blocks	
Audi R8	2008	42	17 Instrument Cluster	Output Tests	
Audi R8	2008	42	17 Instrument Cluster	Specia Functions	
Audi R8	2008	42	19 Gateway Data Bus	Read Fault Codes	
Audi R8	2008	42	19 Gateway Data Bus	Clear Fault Codes	
Audi R8	2008	42	19 Gateway Data Bus	Measuring Blocks	
Audi R8	2008	42	19 Gateway Data Bus	Output Tests	
Audi R8	2008	42	19 Gateway Data Bus	Specia Functions	
Audi R8	2008	42	25 Immobilizer	Read Fault Codes	
Audi R8	2008	42	25 Immobilizer	Clear Fault Codes	
Audi R8	2008	42	25 Immobilizer	Measuring Blocks	
Audi R8	2008	42	25 Immobilizer	Output Tests	
Audi R8	2008	42	25 Immobilizer	Specia Functions	
Audi R8	2008	42	37 Navigation	Read Fault Codes	
Audi R8	2008	42	37 Navigation	Clear Fault Codes	
Audi R8	2008	42	37 Navigation	Measuring Blocks	
Audi R8	2008	42	37 Navigation	Output Tests	
Audi R8	2008	42	37 Navigation	Specia Functions	
Audi R8	2008	42	42 Driver-Door Elect.	Read Fault Codes	
Audi R8	2008	42	42 Driver-Door Elect.	Clear Fault Codes	
Audi R8	2008	42	42 Driver-Door Elect.	Measuring Blocks	
Audi R8	2008	42	42 Driver-Door Elect.	Output Tests	
Audi R8	2008	42	42 Driver-Door Elect.	Specia Functions	
Audi R8	2008	42	46 Central Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2008	42	46 Central Control Module	Clear Fault Codes	
Audi R8	2008	42	46 Central Control Module	Measuring Blocks	
Audi R8	2008	42	46 Central Control Module	Output Tests	
Audi R8	2008	42	46 Central Control Module	Specia Functions	
Audi R8	2008	42	47 Soundsystem	Read Fault Codes	
Audi R8	2008	42	47 Soundsystem	Clear Fault Codes	
Audi R8	2008	42	47 Soundsystem	Measuring Blocks	
Audi R8	2008	42	47 Soundsystem	Output Tests	
Audi R8	2008	42	47 Soundsystem	Specia Functions	
Audi R8	2008	42	51 Electric Drive	Read Fault Codes	
Audi R8	2008	42	51 Electric Drive	Clear Fault Codes	
Audi R8	2008	42	51 Electric Drive	Measuring Blocks	
Audi R8	2008	42	51 Electric Drive	Output Tests	
Audi R8	2008	42	51 Electric Drive	Specia Functions	
Audi R8	2008	42	52 Passe.-Door Elect.	Read Fault Codes	
Audi R8	2008	42	52 Passe.-Door Elect.	Clear Fault Codes	
Audi R8	2008	42	52 Passe.-Door Elect.	Measuring Blocks	
Audi R8	2008	42	52 Passe.-Door Elect.	Output Tests	
Audi R8	2008	42	52 Passe.-Door Elect.	Specia Functions	
Audi R8	2008	42	56 Radio	Read Fault Codes	
Audi R8	2008	42	56 Radio	Clear Fault Codes	
Audi R8	2008	42	56 Radio	Measuring Blocks	
Audi R8	2008	42	56 Radio	Output Tests	
Audi R8	2008	42	56 Radio	Specia Functions	
Audi R8	2008	42	65 Tyre Pressure Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2008	42	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi R8	2008	42	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi R8	2008	42	65 Tyre Pressure Monitoring	Output Tests	
Audi R8	2008	42	65 Tyre Pressure Monitoring	Specia Functions	
Audi R8	2008	42	6C Rear Camera	Read Fault Codes	
Audi R8	2008	42	6C Rear Camera	Clear Fault Codes	
Audi R8	2008	42	6C Rear Camera	Measuring Blocks	
Audi R8	2008	42	6C Rear Camera	Output Tests	
Audi R8	2008	42	6C Rear Camera	Specia Functions	
Audi R8	2008	42	76 Parking Aid	Read Fault Codes	
Audi R8	2008	42	76 Parking Aid	Clear Fault Codes	
Audi R8	2008	42	76 Parking Aid	Measuring Blocks	
Audi R8	2008	42	76 Parking Aid	Output Tests	
Audi R8	2008	42	76 Parking Aid	Specia Functions	
Audi R8	2008	42	77 Telephone	Read Fault Codes	
Audi R8	2008	42	77 Telephone	Clear Fault Codes	
Audi R8	2008	42	77 Telephone	Measuring Blocks	
Audi R8	2008	42	77 Telephone	Output Tests	
Audi R8	2008	42	77 Telephone	Specia Functions	
Audi R8	2008	42	8C Hybrid Battery	Read Fault Codes	
Audi R8	2008	42	8C Hybrid Battery	Clear Fault Codes	
Audi R8	2008	42	8C Hybrid Battery	Measuring Blocks	
Audi R8	2008	42	8C Hybrid Battery	Output Tests	
Audi R8	2008	42	8C Hybrid Battery	Specia Functions	
Audi R8	2009	42	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2009	42	01 Engine Electronics	Clear Fault Codes	
Audi R8	2009	42	01 Engine Electronics	Measuring Blocks	
Audi R8	2009	42	01 Engine Electronics	Output Tests	
Audi R8	2009	42	01 Engine Electronics	Specia Functions	
Audi R8	2009	42	02 Transmission Electronics	Read Fault Codes	
Audi R8	2009	42	02 Transmission Electronics	Clear Fault Codes	
Audi R8	2009	42	02 Transmission Electronics	Measuring Blocks	
Audi R8	2009	42	02 Transmission Electronics	Output Tests	
Audi R8	2009	42	02 Transmission Electronics	Specia Functions	
Audi R8	2009	42	03 Brake Electronics	Read Fault Codes	
Audi R8	2009	42	03 Brake Electronics	Clear Fault Codes	
Audi R8	2009	42	03 Brake Electronics	Measuring Blocks	
Audi R8	2009	42	03 Brake Electronics	Output Tests	
Audi R8	2009	42	03 Brake Electronics	Specia Functions	
Audi R8	2009	42	08 AC/Heating Electronics	Read Fault Codes	
Audi R8	2009	42	08 AC/Heating Electronics	Clear Fault Codes	
Audi R8	2009	42	08 AC/Heating Electronics	Measuring Blocks	
Audi R8	2009	42	08 AC/Heating Electronics	Output Tests	
Audi R8	2009	42	08 AC/Heating Electronics	Specia Functions	
Audi R8	2009	42	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi R8	2009	42	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi R8	2009	42	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi R8	2009	42	09 Electronic Ctrl Electronics	Output Tests	
Audi R8	2009	42	09 Electronic Ctrl Electronics	Specia Functions	
Audi R8	2009	42	0F Radio Tuner-Digital	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2009	42	0F Radio Tuner-Digital	Clear Fault Codes	
Audi R8	2009	42	0F Radio Tuner-Digital	Measuring Blocks	
Audi R8	2009	42	0F Radio Tuner-Digital	Output Tests	
Audi R8	2009	42	0F Radio Tuner-Digital	Specia Functions	
Audi R8	2009	42	10 Parking Assist System 2	Read Fault Codes	
Audi R8	2009	42	10 Parking Assist System 2	Clear Fault Codes	
Audi R8	2009	42	10 Parking Assist System 2	Measuring Blocks	
Audi R8	2009	42	10 Parking Assist System 2	Output Tests	
Audi R8	2009	42	10 Parking Assist System 2	Specia Functions	
Audi R8	2009	42	11 Engine Electronics 2	Read Fault Codes	
Audi R8	2009	42	11 Engine Electronics 2	Clear Fault Codes	
Audi R8	2009	42	11 Engine Electronics 2	Measuring Blocks	
Audi R8	2009	42	11 Engine Electronics 2	Output Tests	
Audi R8	2009	42	11 Engine Electronics 2	Specia Functions	
Audi R8	2009	42	14 Wheel Damping Electronics	Read Fault Codes	
Audi R8	2009	42	14 Wheel Damping Electronics	Clear Fault Codes	
Audi R8	2009	42	14 Wheel Damping Electronics	Measuring Blocks	
Audi R8	2009	42	14 Wheel Damping Electronics	Output Tests	
Audi R8	2009	42	14 Wheel Damping Electronics	Specia Functions	
Audi R8	2009	42	15 Airbags	Read Fault Codes	
Audi R8	2009	42	15 Airbags	Clear Fault Codes	
Audi R8	2009	42	15 Airbags	Measuring Blocks	
Audi R8	2009	42	15 Airbags	Output Tests	
Audi R8	2009	42	15 Airbags	Specia Functions	
Audi R8	2009	42	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2009	42	16 Steering Wheel Electronics	Clear Fault Codes	
Audi R8	2009	42	16 Steering Wheel Electronics	Measuring Blocks	
Audi R8	2009	42	16 Steering Wheel Electronics	Output Tests	
Audi R8	2009	42	16 Steering Wheel Electronics	Specia Functions	
Audi R8	2009	42	17 Instrument Cluster	Read Fault Codes	
Audi R8	2009	42	17 Instrument Cluster	Clear Fault Codes	
Audi R8	2009	42	17 Instrument Cluster	Measuring Blocks	
Audi R8	2009	42	17 Instrument Cluster	Output Tests	
Audi R8	2009	42	17 Instrument Cluster	Specia Functions	
Audi R8	2009	42	19 Gateway Data Bus	Read Fault Codes	
Audi R8	2009	42	19 Gateway Data Bus	Clear Fault Codes	
Audi R8	2009	42	19 Gateway Data Bus	Measuring Blocks	
Audi R8	2009	42	19 Gateway Data Bus	Output Tests	
Audi R8	2009	42	19 Gateway Data Bus	Specia Functions	
Audi R8	2009	42	25 Immobilizer	Read Fault Codes	
Audi R8	2009	42	25 Immobilizer	Clear Fault Codes	
Audi R8	2009	42	25 Immobilizer	Measuring Blocks	
Audi R8	2009	42	25 Immobilizer	Output Tests	
Audi R8	2009	42	25 Immobilizer	Specia Functions	
Audi R8	2009	42	37 Navigation	Read Fault Codes	
Audi R8	2009	42	37 Navigation	Clear Fault Codes	
Audi R8	2009	42	37 Navigation	Measuring Blocks	
Audi R8	2009	42	37 Navigation	Output Tests	
Audi R8	2009	42	37 Navigation	Specia Functions	
Audi R8	2009	42	3D Special Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2009	42	3D Special Function	Clear Fault Codes	
Audi R8	2009	42	3D Special Function	Measuring Blocks	
Audi R8	2009	42	3D Special Function	Output Tests	
Audi R8	2009	42	3D Special Function	Specia Functions	
Audi R8	2009	42	42 Driver-Door Elect.	Read Fault Codes	
Audi R8	2009	42	42 Driver-Door Elect.	Clear Fault Codes	
Audi R8	2009	42	42 Driver-Door Elect.	Measuring Blocks	
Audi R8	2009	42	42 Driver-Door Elect.	Output Tests	
Audi R8	2009	42	42 Driver-Door Elect.	Specia Functions	
Audi R8	2009	42	46 Central Control Module	Read Fault Codes	
Audi R8	2009	42	46 Central Control Module	Clear Fault Codes	
Audi R8	2009	42	46 Central Control Module	Measuring Blocks	
Audi R8	2009	42	46 Central Control Module	Output Tests	
Audi R8	2009	42	46 Central Control Module	Specia Functions	
Audi R8	2009	42	47 Soundsystem	Read Fault Codes	
Audi R8	2009	42	47 Soundsystem	Clear Fault Codes	
Audi R8	2009	42	47 Soundsystem	Measuring Blocks	
Audi R8	2009	42	47 Soundsystem	Output Tests	
Audi R8	2009	42	47 Soundsystem	Specia Functions	
Audi R8	2009	42	51 Electric Drive	Read Fault Codes	
Audi R8	2009	42	51 Electric Drive	Clear Fault Codes	
Audi R8	2009	42	51 Electric Drive	Measuring Blocks	
Audi R8	2009	42	51 Electric Drive	Output Tests	
Audi R8	2009	42	51 Electric Drive	Specia Functions	
Audi R8	2009	42	52 Passe.-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2009	42	52 Passe.-Door Elect.	Clear Fault Codes	
Audi R8	2009	42	52 Passe.-Door Elect.	Measuring Blocks	
Audi R8	2009	42	52 Passe.-Door Elect.	Output Tests	
Audi R8	2009	42	52 Passe.-Door Elect.	Specia Functions	
Audi R8	2009	42	56 Radio	Read Fault Codes	
Audi R8	2009	42	56 Radio	Clear Fault Codes	
Audi R8	2009	42	56 Radio	Measuring Blocks	
Audi R8	2009	42	56 Radio	Output Tests	
Audi R8	2009	42	56 Radio	Specia Functions	
Audi R8	2009	42	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi R8	2009	42	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi R8	2009	42	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi R8	2009	42	65 Tyre Pressure Monitoring	Output Tests	
Audi R8	2009	42	65 Tyre Pressure Monitoring	Specia Functions	
Audi R8	2009	42	6C Rear Camera	Read Fault Codes	
Audi R8	2009	42	6C Rear Camera	Clear Fault Codes	
Audi R8	2009	42	6C Rear Camera	Measuring Blocks	
Audi R8	2009	42	6C Rear Camera	Output Tests	
Audi R8	2009	42	6C Rear Camera	Specia Functions	
Audi R8	2009	42	76 Parking Aid	Read Fault Codes	
Audi R8	2009	42	76 Parking Aid	Clear Fault Codes	
Audi R8	2009	42	76 Parking Aid	Measuring Blocks	
Audi R8	2009	42	76 Parking Aid	Output Tests	
Audi R8	2009	42	76 Parking Aid	Specia Functions	
Audi R8	2009	42	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8	2009	42	77 Telephone	Clear Fault Codes	
Audi R8	2009	42	77 Telephone	Measuring Blocks	
Audi R8	2009	42	77 Telephone	Output Tests	
Audi R8	2009	42	77 Telephone	Specia Functions	
Audi R8	2009	42	8C Hybrid Battery	Read Fault Codes	
Audi R8	2009	42	8C Hybrid Battery	Clear Fault Codes	
Audi R8	2009	42	8C Hybrid Battery	Measuring Blocks	
Audi R8	2009	42	8C Hybrid Battery	Output Tests	
Audi R8	2009	42	8C Hybrid Battery	Specia Functions	
Audi R8 USA	2008	FG	01 Engine Electronics	Read Fault Codes	
Audi R8 USA	2008	FG	01 Engine Electronics	Clear Fault Codes	
Audi R8 USA	2008	FG	01 Engine Electronics	Measuring Blocks	
Audi R8 USA	2008	FG	01 Engine Electronics	Output Tests	
Audi R8 USA	2008	FG	01 Engine Electronics	Specia Functions	
Audi R8 USA	2008	FG	02 Transmission Electronics	Read Fault Codes	
Audi R8 USA	2008	FG	02 Transmission Electronics	Clear Fault Codes	
Audi R8 USA	2008	FG	02 Transmission Electronics	Measuring Blocks	
Audi R8 USA	2008	FG	02 Transmission Electronics	Output Tests	
Audi R8 USA	2008	FG	02 Transmission Electronics	Specia Functions	
Audi R8 USA	2008	FG	03 Brake Electronics	Read Fault Codes	
Audi R8 USA	2008	FG	03 Brake Electronics	Clear Fault Codes	
Audi R8 USA	2008	FG	03 Brake Electronics	Measuring Blocks	
Audi R8 USA	2008	FG	03 Brake Electronics	Output Tests	
Audi R8 USA	2008	FG	03 Brake Electronics	Specia Functions	
Audi R8 USA	2008	FG	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 USA	2008	FG	08 AC/Heating Electronics	Clear Fault Codes	
Audi R8 USA	2008	FG	08 AC/Heating Electronics	Measuring Blocks	
Audi R8 USA	2008	FG	08 AC/Heating Electronics	Output Tests	
Audi R8 USA	2008	FG	08 AC/Heating Electronics	Specia Functions	
Audi R8 USA	2008	FG	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi R8 USA	2008	FG	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi R8 USA	2008	FG	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi R8 USA	2008	FG	09 Electronic Ctrl Electronics	Output Tests	
Audi R8 USA	2008	FG	09 Electronic Ctrl Electronics	Specia Functions	
Audi R8 USA	2008	FG	0F Radio Tuner-Digital	Read Fault Codes	
Audi R8 USA	2008	FG	0F Radio Tuner-Digital	Clear Fault Codes	
Audi R8 USA	2008	FG	0F Radio Tuner-Digital	Measuring Blocks	
Audi R8 USA	2008	FG	0F Radio Tuner-Digital	Output Tests	
Audi R8 USA	2008	FG	0F Radio Tuner-Digital	Specia Functions	
Audi R8 USA	2008	FG	11 Engine Electronics 2	Read Fault Codes	
Audi R8 USA	2008	FG	11 Engine Electronics 2	Clear Fault Codes	
Audi R8 USA	2008	FG	11 Engine Electronics 2	Measuring Blocks	
Audi R8 USA	2008	FG	11 Engine Electronics 2	Output Tests	
Audi R8 USA	2008	FG	11 Engine Electronics 2	Specia Functions	
Audi R8 USA	2008	FG	14 Wheel Damping Electronics	Read Fault Codes	
Audi R8 USA	2008	FG	14 Wheel Damping Electronics	Clear Fault Codes	
Audi R8 USA	2008	FG	14 Wheel Damping Electronics	Measuring Blocks	
Audi R8 USA	2008	FG	14 Wheel Damping Electronics	Output Tests	
Audi R8 USA	2008	FG	14 Wheel Damping Electronics	Specia Functions	
Audi R8 USA	2008	FG	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 USA	2008	FG	15 Airbags	Clear Fault Codes	
Audi R8 USA	2008	FG	15 Airbags	Measuring Blocks	
Audi R8 USA	2008	FG	15 Airbags	Output Tests	
Audi R8 USA	2008	FG	15 Airbags	Specia Functions	
Audi R8 USA	2008	FG	16 Steering Wheel Electronics	Read Fault Codes	
Audi R8 USA	2008	FG	16 Steering Wheel Electronics	Clear Fault Codes	
Audi R8 USA	2008	FG	16 Steering Wheel Electronics	Measuring Blocks	
Audi R8 USA	2008	FG	16 Steering Wheel Electronics	Output Tests	
Audi R8 USA	2008	FG	16 Steering Wheel Electronics	Specia Functions	
Audi R8 USA	2008	FG	17 Instrument Cluster	Read Fault Codes	
Audi R8 USA	2008	FG	17 Instrument Cluster	Clear Fault Codes	
Audi R8 USA	2008	FG	17 Instrument Cluster	Measuring Blocks	
Audi R8 USA	2008	FG	17 Instrument Cluster	Output Tests	
Audi R8 USA	2008	FG	17 Instrument Cluster	Specia Functions	
Audi R8 USA	2008	FG	19 Gateway Data Bus	Read Fault Codes	
Audi R8 USA	2008	FG	19 Gateway Data Bus	Clear Fault Codes	
Audi R8 USA	2008	FG	19 Gateway Data Bus	Measuring Blocks	
Audi R8 USA	2008	FG	19 Gateway Data Bus	Output Tests	
Audi R8 USA	2008	FG	19 Gateway Data Bus	Specia Functions	
Audi R8 USA	2008	FG	25 Immobilizer	Read Fault Codes	
Audi R8 USA	2008	FG	25 Immobilizer	Clear Fault Codes	
Audi R8 USA	2008	FG	25 Immobilizer	Measuring Blocks	
Audi R8 USA	2008	FG	25 Immobilizer	Output Tests	
Audi R8 USA	2008	FG	25 Immobilizer	Specia Functions	
Audi R8 USA	2008	FG	37 Navigation	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 USA	2008	FG	37 Navigation	Clear Fault Codes	
Audi R8 USA	2008	FG	37 Navigation	Measuring Blocks	
Audi R8 USA	2008	FG	37 Navigation	Output Tests	
Audi R8 USA	2008	FG	37 Navigation	Specia Functions	
Audi R8 USA	2008	FG	42 Driver-Door Elect.	Read Fault Codes	
Audi R8 USA	2008	FG	42 Driver-Door Elect.	Clear Fault Codes	
Audi R8 USA	2008	FG	42 Driver-Door Elect.	Measuring Blocks	
Audi R8 USA	2008	FG	42 Driver-Door Elect.	Output Tests	
Audi R8 USA	2008	FG	42 Driver-Door Elect.	Specia Functions	
Audi R8 USA	2008	FG	46 Central Control Module	Read Fault Codes	
Audi R8 USA	2008	FG	46 Central Control Module	Clear Fault Codes	
Audi R8 USA	2008	FG	46 Central Control Module	Measuring Blocks	
Audi R8 USA	2008	FG	46 Central Control Module	Output Tests	
Audi R8 USA	2008	FG	46 Central Control Module	Specia Functions	
Audi R8 USA	2008	FG	47 Soundsystem	Read Fault Codes	
Audi R8 USA	2008	FG	47 Soundsystem	Clear Fault Codes	
Audi R8 USA	2008	FG	47 Soundsystem	Measuring Blocks	
Audi R8 USA	2008	FG	47 Soundsystem	Output Tests	
Audi R8 USA	2008	FG	47 Soundsystem	Specia Functions	
Audi R8 USA	2008	FG	52 Passe.-Door Elect.	Read Fault Codes	
Audi R8 USA	2008	FG	52 Passe.-Door Elect.	Clear Fault Codes	
Audi R8 USA	2008	FG	52 Passe.-Door Elect.	Measuring Blocks	
Audi R8 USA	2008	FG	52 Passe.-Door Elect.	Output Tests	
Audi R8 USA	2008	FG	52 Passe.-Door Elect.	Specia Functions	
Audi R8 USA	2008	FG	56 Radio	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 USA	2008	FG	56 Radio	Clear Fault Codes	
Audi R8 USA	2008	FG	56 Radio	Measuring Blocks	
Audi R8 USA	2008	FG	56 Radio	Output Tests	
Audi R8 USA	2008	FG	56 Radio	Specia Functions	
Audi R8 USA	2008	FG	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi R8 USA	2008	FG	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi R8 USA	2008	FG	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi R8 USA	2008	FG	65 Tyre Pressure Monitoring	Output Tests	
Audi R8 USA	2008	FG	65 Tyre Pressure Monitoring	Specia Functions	
Audi R8 USA	2008	FG	6C Rear Camera	Read Fault Codes	
Audi R8 USA	2008	FG	6C Rear Camera	Clear Fault Codes	
Audi R8 USA	2008	FG	6C Rear Camera	Measuring Blocks	
Audi R8 USA	2008	FG	6C Rear Camera	Output Tests	
Audi R8 USA	2008	FG	6C Rear Camera	Specia Functions	
Audi R8 USA	2008	FG	76 Parking Aid	Read Fault Codes	
Audi R8 USA	2008	FG	76 Parking Aid	Clear Fault Codes	
Audi R8 USA	2008	FG	76 Parking Aid	Measuring Blocks	
Audi R8 USA	2008	FG	76 Parking Aid	Output Tests	
Audi R8 USA	2008	FG	76 Parking Aid	Specia Functions	
Audi R8 USA	2008	FG	77 Telephone	Read Fault Codes	
Audi R8 USA	2008	FG	77 Telephone	Clear Fault Codes	
Audi R8 USA	2008	FG	77 Telephone	Measuring Blocks	
Audi R8 USA	2008	FG	77 Telephone	Output Tests	
Audi R8 USA	2008	FG	77 Telephone	Specia Functions	
Audi R8 USA	2009	FG	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 USA	2009	FG	01 Engine Electronics	Clear Fault Codes	
Audi R8 USA	2009	FG	01 Engine Electronics	Measuring Blocks	
Audi R8 USA	2009	FG	01 Engine Electronics	Output Tests	
Audi R8 USA	2009	FG	01 Engine Electronics	Specia Functions	
Audi R8 USA	2009	FG	02 Transmission Electronics	Read Fault Codes	
Audi R8 USA	2009	FG	02 Transmission Electronics	Clear Fault Codes	
Audi R8 USA	2009	FG	02 Transmission Electronics	Measuring Blocks	
Audi R8 USA	2009	FG	02 Transmission Electronics	Output Tests	
Audi R8 USA	2009	FG	02 Transmission Electronics	Specia Functions	
Audi R8 USA	2009	FG	03 Brake Electronics	Read Fault Codes	
Audi R8 USA	2009	FG	03 Brake Electronics	Clear Fault Codes	
Audi R8 USA	2009	FG	03 Brake Electronics	Measuring Blocks	
Audi R8 USA	2009	FG	03 Brake Electronics	Output Tests	
Audi R8 USA	2009	FG	03 Brake Electronics	Specia Functions	
Audi R8 USA	2009	FG	08 AC/Heating Electronics	Read Fault Codes	
Audi R8 USA	2009	FG	08 AC/Heating Electronics	Clear Fault Codes	
Audi R8 USA	2009	FG	08 AC/Heating Electronics	Measuring Blocks	
Audi R8 USA	2009	FG	08 AC/Heating Electronics	Output Tests	
Audi R8 USA	2009	FG	08 AC/Heating Electronics	Specia Functions	
Audi R8 USA	2009	FG	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi R8 USA	2009	FG	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi R8 USA	2009	FG	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi R8 USA	2009	FG	09 Electronic Ctrl Electronics	Output Tests	
Audi R8 USA	2009	FG	09 Electronic Ctrl Electronics	Specia Functions	
Audi R8 USA	2009	FG	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 USA	2009	FG	0F Radio Tuner-Digital	Clear Fault Codes	
Audi R8 USA	2009	FG	0F Radio Tuner-Digital	Measuring Blocks	
Audi R8 USA	2009	FG	0F Radio Tuner-Digital	Output Tests	
Audi R8 USA	2009	FG	0F Radio Tuner-Digital	Specia Functions	
Audi R8 USA	2009	FG	10 Parking Assist System 2	Read Fault Codes	
Audi R8 USA	2009	FG	10 Parking Assist System 2	Clear Fault Codes	
Audi R8 USA	2009	FG	10 Parking Assist System 2	Measuring Blocks	
Audi R8 USA	2009	FG	10 Parking Assist System 2	Output Tests	
Audi R8 USA	2009	FG	10 Parking Assist System 2	Specia Functions	
Audi R8 USA	2009	FG	11 Engine Electronics 2	Read Fault Codes	
Audi R8 USA	2009	FG	11 Engine Electronics 2	Clear Fault Codes	
Audi R8 USA	2009	FG	11 Engine Electronics 2	Measuring Blocks	
Audi R8 USA	2009	FG	11 Engine Electronics 2	Output Tests	
Audi R8 USA	2009	FG	11 Engine Electronics 2	Specia Functions	
Audi R8 USA	2009	FG	14 Wheel Damping Electronics	Read Fault Codes	
Audi R8 USA	2009	FG	14 Wheel Damping Electronics	Clear Fault Codes	
Audi R8 USA	2009	FG	14 Wheel Damping Electronics	Measuring Blocks	
Audi R8 USA	2009	FG	14 Wheel Damping Electronics	Output Tests	
Audi R8 USA	2009	FG	14 Wheel Damping Electronics	Specia Functions	
Audi R8 USA	2009	FG	15 Airbags	Read Fault Codes	
Audi R8 USA	2009	FG	15 Airbags	Clear Fault Codes	
Audi R8 USA	2009	FG	15 Airbags	Measuring Blocks	
Audi R8 USA	2009	FG	15 Airbags	Output Tests	
Audi R8 USA	2009	FG	15 Airbags	Specia Functions	
Audi R8 USA	2009	FG	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 USA	2009	FG	16 Steering Wheel Electronics	Clear Fault Codes	
Audi R8 USA	2009	FG	16 Steering Wheel Electronics	Measuring Blocks	
Audi R8 USA	2009	FG	16 Steering Wheel Electronics	Output Tests	
Audi R8 USA	2009	FG	16 Steering Wheel Electronics	Specia Functions	
Audi R8 USA	2009	FG	17 Instrument Cluster	Read Fault Codes	
Audi R8 USA	2009	FG	17 Instrument Cluster	Clear Fault Codes	
Audi R8 USA	2009	FG	17 Instrument Cluster	Measuring Blocks	
Audi R8 USA	2009	FG	17 Instrument Cluster	Output Tests	
Audi R8 USA	2009	FG	17 Instrument Cluster	Specia Functions	
Audi R8 USA	2009	FG	19 Gateway Data Bus	Read Fault Codes	
Audi R8 USA	2009	FG	19 Gateway Data Bus	Clear Fault Codes	
Audi R8 USA	2009	FG	19 Gateway Data Bus	Measuring Blocks	
Audi R8 USA	2009	FG	19 Gateway Data Bus	Output Tests	
Audi R8 USA	2009	FG	19 Gateway Data Bus	Specia Functions	
Audi R8 USA	2009	FG	25 Immobilizer	Read Fault Codes	
Audi R8 USA	2009	FG	25 Immobilizer	Clear Fault Codes	
Audi R8 USA	2009	FG	25 Immobilizer	Measuring Blocks	
Audi R8 USA	2009	FG	25 Immobilizer	Output Tests	
Audi R8 USA	2009	FG	25 Immobilizer	Specia Functions	
Audi R8 USA	2009	FG	37 Navigation	Read Fault Codes	
Audi R8 USA	2009	FG	37 Navigation	Clear Fault Codes	
Audi R8 USA	2009	FG	37 Navigation	Measuring Blocks	
Audi R8 USA	2009	FG	37 Navigation	Output Tests	
Audi R8 USA	2009	FG	37 Navigation	Specia Functions	
Audi R8 USA	2009	FG	3D Special Function	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi R8 USA	2009	FG	3D Special Function	Clear Fault Codes	
Audi R8 USA	2009	FG	3D Special Function	Measuring Blocks	
Audi R8 USA	2009	FG	3D Special Function	Output Tests	
Audi R8 USA	2009	FG	3D Special Function	Specia Functions	
Audi R8 USA	2009	FG	42 Driver-Door Elect.	Read Fault Codes	
Audi R8 USA	2009	FG	42 Driver-Door Elect.	Clear Fault Codes	
Audi R8 USA	2009	FG	42 Driver-Door Elect.	Measuring Blocks	
Audi R8 USA	2009	FG	42 Driver-Door Elect.	Output Tests	
Audi R8 USA	2009	FG	42 Driver-Door Elect.	Specia Functions	
Audi R8 USA	2009	FG	46 Central Control Module	Read Fault Codes	
Audi R8 USA	2009	FG	46 Central Control Module	Clear Fault Codes	
Audi R8 USA	2009	FG	46 Central Control Module	Measuring Blocks	
Audi R8 USA	2009	FG	46 Central Control Module	Output Tests	
Audi R8 USA	2009	FG	46 Central Control Module	Specia Functions	
Audi R8 USA	2009	FG	47 Soundsystem	Read Fault Codes	
Audi R8 USA	2009	FG	47 Soundsystem	Clear Fault Codes	
Audi R8 USA	2009	FG	47 Soundsystem	Measuring Blocks	
Audi R8 USA	2009	FG	47 Soundsystem	Output Tests	
Audi R8 USA	2009	FG	47 Soundsystem	Specia Functions	
Audi R8 USA	2009	FG	52 Passe.-Door Elect.	Read Fault Codes	
Audi R8 USA	2009	FG	52 Passe.-Door Elect.	Clear Fault Codes	
Audi R8 USA	2009	FG	52 Passe.-Door Elect.	Measuring Blocks	
Audi R8 USA	2009	FG	52 Passe.-Door Elect.	Output Tests	
Audi R8 USA	2009	FG	52 Passe.-Door Elect.	Specia Functions	
Audi R8 USA	2009	FG	56 Radio	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi R8 USA	2009	FG	56 Radio	Clear Fault Codes	
Audi R8 USA	2009	FG	56 Radio	Measuring Blocks	
Audi R8 USA	2009	FG	56 Radio	Output Tests	
Audi R8 USA	2009	FG	56 Radio	Specia Functions	
Audi R8 USA	2009	FG	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi R8 USA	2009	FG	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi R8 USA	2009	FG	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi R8 USA	2009	FG	65 Tyre Pressure Monitoring	Output Tests	
Audi R8 USA	2009	FG	65 Tyre Pressure Monitoring	Specia Functions	
Audi R8 USA	2009	FG	6C Rear Camera	Read Fault Codes	
Audi R8 USA	2009	FG	6C Rear Camera	Clear Fault Codes	
Audi R8 USA	2009	FG	6C Rear Camera	Measuring Blocks	
Audi R8 USA	2009	FG	6C Rear Camera	Output Tests	
Audi R8 USA	2009	FG	6C Rear Camera	Specia Functions	
Audi R8 USA	2009	FG	76 Parking Aid	Read Fault Codes	
Audi R8 USA	2009	FG	76 Parking Aid	Clear Fault Codes	
Audi R8 USA	2009	FG	76 Parking Aid	Measuring Blocks	
Audi R8 USA	2009	FG	76 Parking Aid	Output Tests	
Audi R8 USA	2009	FG	76 Parking Aid	Specia Functions	
Audi R8 USA	2009	FG	77 Telephone	Read Fault Codes	
Audi R8 USA	2009	FG	77 Telephone	Clear Fault Codes	
Audi R8 USA	2009	FG	77 Telephone	Measuring Blocks	
Audi R8 USA	2009	FG	77 Telephone	Output Tests	
Audi R8 USA	2009	FG	77 Telephone	Specia Functions	
Audi Q2	2017-2018	GA	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q2	2017-2018	GA	01 Engine Electronics	Clear Fault Codes	
Audi Q2	2017-2018	GA	01 Engine Electronics	Measuring Blocks	
Audi Q2	2017-2018	GA	01 Engine Electronics	Output Tests	
Audi Q2	2017-2018	GA	01 Engine Electronics	Specia Functions	
Audi Q2	2017-2018	GA	02 Transmission Electronics	Read Fault Codes	
Audi Q2	2017-2018	GA	02 Transmission Electronics	Clear Fault Codes	
Audi Q2	2017-2018	GA	02 Transmission Electronics	Measuring Blocks	
Audi Q2	2017-2018	GA	02 Transmission Electronics	Output Tests	
Audi Q2	2017-2018	GA	02 Transmission Electronics	Specia Functions	
Audi Q2	2017-2018	GA	03 Brake Electronics	Read Fault Codes	
Audi Q2	2017-2018	GA	03 Brake Electronics	Clear Fault Codes	
Audi Q2	2017-2018	GA	03 Brake Electronics	Measuring Blocks	
Audi Q2	2017-2018	GA	03 Brake Electronics	Output Tests	
Audi Q2	2017-2018	GA	03 Brake Electronics	Specia Functions	
Audi Q2	2017-2018	GA	06 Passene. Seat Adj.	Read Fault Codes	
Audi Q2	2017-2018	GA	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q2	2017-2018	GA	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q2	2017-2018	GA	06 Passene. Seat Adj.	Output Tests	
Audi Q2	2017-2018	GA	06 Passene. Seat Adj.	Specia Functions	
Audi Q2	2017-2018	GA	08 AC/Heating Electronics	Read Fault Codes	
Audi Q2	2017-2018	GA	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q2	2017-2018	GA	08 AC/Heating Electronics	Measuring Blocks	
Audi Q2	2017-2018	GA	08 AC/Heating Electronics	Output Tests	
Audi Q2	2017-2018	GA	08 AC/Heating Electronics	Specia Functions	
Audi Q2	2017-2018	GA	09 Electronic Ctrl Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q2	2017-2018	GA	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q2	2017-2018	GA	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q2	2017-2018	GA	09 Electronic Ctrl Electronics	Output Tests	
Audi Q2	2017-2018	GA	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q2	2017-2018	GA	13 Distance Control	Read Fault Codes	
Audi Q2	2017-2018	GA	13 Distance Control	Clear Fault Codes	
Audi Q2	2017-2018	GA	13 Distance Control	Measuring Blocks	
Audi Q2	2017-2018	GA	13 Distance Control	Output Tests	
Audi Q2	2017-2018	GA	13 Distance Control	Specia Functions	
Audi Q2	2017-2018	GA	14 Wheel Damping Electronics	Read Fault Codes	
Audi Q2	2017-2018	GA	14 Wheel Damping Electronics	Clear Fault Codes	
Audi Q2	2017-2018	GA	14 Wheel Damping Electronics	Measuring Blocks	
Audi Q2	2017-2018	GA	14 Wheel Damping Electronics	Output Tests	
Audi Q2	2017-2018	GA	14 Wheel Damping Electronics	Specia Functions	
Audi Q2	2017-2018	GA	15 Airbags	Read Fault Codes	
Audi Q2	2017-2018	GA	15 Airbags	Clear Fault Codes	
Audi Q2	2017-2018	GA	15 Airbags	Measuring Blocks	
Audi Q2	2017-2018	GA	15 Airbags	Output Tests	
Audi Q2	2017-2018	GA	15 Airbags	Specia Functions	
Audi Q2	2017-2018	GA	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q2	2017-2018	GA	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q2	2017-2018	GA	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q2	2017-2018	GA	16 Steering Wheel Electronics	Output Tests	
Audi Q2	2017-2018	GA	16 Steering Wheel Electronics	Specia Functions	
Audi Q2	2017-2018	GA	17 Instrument Cluster	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q2	2017-2018	GA	17 Instrument Cluster	Clear Fault Codes	
Audi Q2	2017-2018	GA	17 Instrument Cluster	Measuring Blocks	
Audi Q2	2017-2018	GA	17 Instrument Cluster	Output Tests	
Audi Q2	2017-2018	GA	17 Instrument Cluster	Specia Functions	
Audi Q2	2017-2018	GA	18 Aux Heating	Read Fault Codes	
Audi Q2	2017-2018	GA	18 Aux Heating	Clear Fault Codes	
Audi Q2	2017-2018	GA	18 Aux Heating	Measuring Blocks	
Audi Q2	2017-2018	GA	18 Aux Heating	Output Tests	
Audi Q2	2017-2018	GA	18 Aux Heating	Specia Functions	
Audi Q2	2017-2018	GA	19 Gateway Data Bus	Read Fault Codes	
Audi Q2	2017-2018	GA	19 Gateway Data Bus	Clear Fault Codes	
Audi Q2	2017-2018	GA	19 Gateway Data Bus	Measuring Blocks	
Audi Q2	2017-2018	GA	19 Gateway Data Bus	Output Tests	
Audi Q2	2017-2018	GA	19 Gateway Data Bus	Specia Functions	
Audi Q2	2017-2018	GA	20 High Beam Assistance Device	Read Fault Codes	
Audi Q2	2017-2018	GA	20 High Beam Assistance Device	Clear Fault Codes	
Audi Q2	2017-2018	GA	20 High Beam Assistance Device	Measuring Blocks	
Audi Q2	2017-2018	GA	20 High Beam Assistance Device	Output Tests	
Audi Q2	2017-2018	GA	20 High Beam Assistance Device	Specia Functions	
Audi Q2	2017-2018	GA	22 4WD Electronics	Read Fault Codes	
Audi Q2	2017-2018	GA	22 4WD Electronics	Clear Fault Codes	
Audi Q2	2017-2018	GA	22 4WD Electronics	Measuring Blocks	
Audi Q2	2017-2018	GA	22 4WD Electronics	Output Tests	
Audi Q2	2017-2018	GA	22 4WD Electronics	Specia Functions	
Audi Q2	2017-2018	GA	23 Braker Booster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q2	2017-2018	GA	23 Braker Booster	Clear Fault Codes	
Audi Q2	2017-2018	GA	23 Braker Booster	Measuring Blocks	
Audi Q2	2017-2018	GA	23 Braker Booster	Output Tests	
Audi Q2	2017-2018	GA	23 Braker Booster	Specia Functions	
Audi Q2	2017-2018	GA	26 Electric Roof Control	Read Fault Codes	
Audi Q2	2017-2018	GA	26 Electric Roof Control	Clear Fault Codes	
Audi Q2	2017-2018	GA	26 Electric Roof Control	Measuring Blocks	
Audi Q2	2017-2018	GA	26 Electric Roof Control	Output Tests	
Audi Q2	2017-2018	GA	26 Electric Roof Control	Specia Functions	
Audi Q2	2017-2018	GA	29 Left Light Control	Read Fault Codes	
Audi Q2	2017-2018	GA	29 Left Light Control	Clear Fault Codes	
Audi Q2	2017-2018	GA	29 Left Light Control	Measuring Blocks	
Audi Q2	2017-2018	GA	29 Left Light Control	Output Tests	
Audi Q2	2017-2018	GA	29 Left Light Control	Specia Functions	
Audi Q2	2017-2018	GA	2B Steer Col Lock	Read Fault Codes	
Audi Q2	2017-2018	GA	2B Steer Col Lock	Clear Fault Codes	
Audi Q2	2017-2018	GA	2B Steer Col Lock	Measuring Blocks	
Audi Q2	2017-2018	GA	2B Steer Col Lock	Output Tests	
Audi Q2	2017-2018	GA	2B Steer Col Lock	Specia Functions	
Audi Q2	2017-2018	GA	30 Special Function 2	Read Fault Codes	
Audi Q2	2017-2018	GA	30 Special Function 2	Clear Fault Codes	
Audi Q2	2017-2018	GA	30 Special Function 2	Measuring Blocks	
Audi Q2	2017-2018	GA	30 Special Function 2	Output Tests	
Audi Q2	2017-2018	GA	30 Special Function 2	Specia Functions	
Audi Q2	2017-2018	GA	36 Driver`s Side Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q2	2017-2018	GA	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Audi Q2	2017-2018	GA	36 Driver`s Side Seat Adj.	Measuring Blocks	
Audi Q2	2017-2018	GA	36 Driver`s Side Seat Adj.	Output Tests	
Audi Q2	2017-2018	GA	36 Driver`s Side Seat Adj.	Specia Functions	
Audi Q2	2017-2018	GA	39 Right Light Control	Read Fault Codes	
Audi Q2	2017-2018	GA	39 Right Light Control	Clear Fault Codes	
Audi Q2	2017-2018	GA	39 Right Light Control	Measuring Blocks	
Audi Q2	2017-2018	GA	39 Right Light Control	Output Tests	
Audi Q2	2017-2018	GA	39 Right Light Control	Specia Functions	
Audi Q2	2017-2018	GA	3C Lane Departure Assistance System	Read Fault Codes	
Audi Q2	2017-2018	GA	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q2	2017-2018	GA	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q2	2017-2018	GA	3C Lane Departure Assistance System	Output Tests	
Audi Q2	2017-2018	GA	3C Lane Departure Assistance System	Specia Functions	
Audi Q2	2017-2018	GA	3D Special Function	Read Fault Codes	
Audi Q2	2017-2018	GA	3D Special Function	Clear Fault Codes	
Audi Q2	2017-2018	GA	3D Special Function	Measuring Blocks	
Audi Q2	2017-2018	GA	3D Special Function	Output Tests	
Audi Q2	2017-2018	GA	3D Special Function	Specia Functions	
Audi Q2	2017-2018	GA	42 Driver-Door Elect.	Read Fault Codes	
Audi Q2	2017-2018	GA	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q2	2017-2018	GA	42 Driver-Door Elect.	Measuring Blocks	
Audi Q2	2017-2018	GA	42 Driver-Door Elect.	Output Tests	
Audi Q2	2017-2018	GA	42 Driver-Door Elect.	Specia Functions	
Audi Q2	2017-2018	GA	44 Steering Assistance	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q2	2017-2018	GA	44 Steering Assistance	Clear Fault Codes	
Audi Q2	2017-2018	GA	44 Steering Assistance	Measuring Blocks	
Audi Q2	2017-2018	GA	44 Steering Assistance	Output Tests	
Audi Q2	2017-2018	GA	44 Steering Assistance	Specia Functions	
Audi Q2	2017-2018	GA	47 Soundsystem	Read Fault Codes	
Audi Q2	2017-2018	GA	47 Soundsystem	Clear Fault Codes	
Audi Q2	2017-2018	GA	47 Soundsystem	Measuring Blocks	
Audi Q2	2017-2018	GA	47 Soundsystem	Output Tests	
Audi Q2	2017-2018	GA	47 Soundsystem	Specia Functions	
Audi Q2	2017-2018	GA	51 Electric Drive	Read Fault Codes	
Audi Q2	2017-2018	GA	51 Electric Drive	Clear Fault Codes	
Audi Q2	2017-2018	GA	51 Electric Drive	Measuring Blocks	
Audi Q2	2017-2018	GA	51 Electric Drive	Output Tests	
Audi Q2	2017-2018	GA	51 Electric Drive	Specia Functions	
Audi Q2	2017-2018	GA	52 Passe.-Door Elect.	Read Fault Codes	
Audi Q2	2017-2018	GA	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q2	2017-2018	GA	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q2	2017-2018	GA	52 Passe.-Door Elect.	Output Tests	
Audi Q2	2017-2018	GA	52 Passe.-Door Elect.	Specia Functions	
Audi Q2	2017-2018	GA	55 Headlight Range Control	Read Fault Codes	
Audi Q2	2017-2018	GA	55 Headlight Range Control	Clear Fault Codes	
Audi Q2	2017-2018	GA	55 Headlight Range Control	Measuring Blocks	
Audi Q2	2017-2018	GA	55 Headlight Range Control	Output Tests	
Audi Q2	2017-2018	GA	55 Headlight Range Control	Specia Functions	
Audi Q2	2017-2018	GA	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q2	2017-2018	GA	57 TV-Tuner	Clear Fault Codes	
Audi Q2	2017-2018	GA	57 TV-Tuner	Measuring Blocks	
Audi Q2	2017-2018	GA	57 TV-Tuner	Output Tests	
Audi Q2	2017-2018	GA	57 TV-Tuner	Specia Functions	
Audi Q2	2017-2018	GA	5F Information Electronic Equipment 1	Read Fault Codes	
Audi Q2	2017-2018	GA	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi Q2	2017-2018	GA	5F Information Electronic Equipment 1	Measuring Blocks	
Audi Q2	2017-2018	GA	5F Information Electronic Equipment 1	Output Tests	
Audi Q2	2017-2018	GA	5F Information Electronic Equipment 1	Specia Functions	
Audi Q2	2017-2018	GA	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Q2	2017-2018	GA	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Q2	2017-2018	GA	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Q2	2017-2018	GA	65 Tyre Pressure Monitoring	Output Tests	
Audi Q2	2017-2018	GA	65 Tyre Pressure Monitoring	Specia Functions	
Audi Q2	2017-2018	GA	69 Trailer Function	Read Fault Codes	
Audi Q2	2017-2018	GA	69 Trailer Function	Clear Fault Codes	
Audi Q2	2017-2018	GA	69 Trailer Function	Measuring Blocks	
Audi Q2	2017-2018	GA	69 Trailer Function	Output Tests	
Audi Q2	2017-2018	GA	69 Trailer Function	Specia Functions	
Audi Q2	2017-2018	GA	6C Rear Camera	Read Fault Codes	
Audi Q2	2017-2018	GA	6C Rear Camera	Clear Fault Codes	
Audi Q2	2017-2018	GA	6C Rear Camera	Measuring Blocks	
Audi Q2	2017-2018	GA	6C Rear Camera	Output Tests	
Audi Q2	2017-2018	GA	6C Rear Camera	Specia Functions	
Audi Q2	2017-2018	GA	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q2	2017-2018	GA	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q2	2017-2018	GA	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q2	2017-2018	GA	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q2	2017-2018	GA	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q2	2017-2018	GA	75 Emergency Call Module	Read Fault Codes	
Audi Q2	2017-2018	GA	75 Emergency Call Module	Clear Fault Codes	
Audi Q2	2017-2018	GA	75 Emergency Call Module	Measuring Blocks	
Audi Q2	2017-2018	GA	75 Emergency Call Module	Output Tests	
Audi Q2	2017-2018	GA	75 Emergency Call Module	Specia Functions	
Audi Q2	2017-2018	GA	76 Parking Aid	Read Fault Codes	
Audi Q2	2017-2018	GA	76 Parking Aid	Clear Fault Codes	
Audi Q2	2017-2018	GA	76 Parking Aid	Measuring Blocks	
Audi Q2	2017-2018	GA	76 Parking Aid	Output Tests	
Audi Q2	2017-2018	GA	76 Parking Aid	Specia Functions	
Audi Q2	2017-2018	GA	82 Heads Up Display	Read Fault Codes	
Audi Q2	2017-2018	GA	82 Heads Up Display	Clear Fault Codes	
Audi Q2	2017-2018	GA	82 Heads Up Display	Measuring Blocks	
Audi Q2	2017-2018	GA	82 Heads Up Display	Output Tests	
Audi Q2	2017-2018	GA	82 Heads Up Display	Specia Functions	
Audi Q2	2017-2018	GA	8C Hybrid Battery	Read Fault Codes	
Audi Q2	2017-2018	GA	8C Hybrid Battery	Clear Fault Codes	
Audi Q2	2017-2018	GA	8C Hybrid Battery	Measuring Blocks	
Audi Q2	2017-2018	GA	8C Hybrid Battery	Output Tests	
Audi Q2	2017-2018	GA	8C Hybrid Battery	Specia Functions	
Audi Q2	2017-2018	GA	A5 Frt Sens.Drv.Assist	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q2	2017-2018	GA	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi Q2	2017-2018	GA	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi Q2	2017-2018	GA	A5 Frt Sens.Drv.Assist	Output Tests	
Audi Q2	2017-2018	GA	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi Q2	2017-2018	GA	A6 Microphone	Read Fault Codes	
Audi Q2	2017-2018	GA	A6 Microphone	Clear Fault Codes	
Audi Q2	2017-2018	GA	A6 Microphone	Measuring Blocks	
Audi Q2	2017-2018	GA	A6 Microphone	Output Tests	
Audi Q2	2017-2018	GA	A6 Microphone	Specia Functions	
Audi Q2	2017-2018	GA	A9 Struct.Borne Sound	Read Fault Codes	
Audi Q2	2017-2018	GA	A9 Struct.Borne Sound	Clear Fault Codes	
Audi Q2	2017-2018	GA	A9 Struct.Borne Sound	Measuring Blocks	
Audi Q2	2017-2018	GA	A9 Struct.Borne Sound	Output Tests	
Audi Q2	2017-2018	GA	A9 Struct.Borne Sound	Specia Functions	
Audi Q2	2017-2018	GA	B7 Access Start Interf	Read Fault Codes	
Audi Q2	2017-2018	GA	B7 Access Start Interf	Clear Fault Codes	
Audi Q2	2017-2018	GA	B7 Access Start Interf	Measuring Blocks	
Audi Q2	2017-2018	GA	B7 Access Start Interf	Output Tests	
Audi Q2	2017-2018	GA	B7 Access Start Interf	Specia Functions	
Audi Q2	2017-2018	GA	BB Door Rear Drv Side	Read Fault Codes	
Audi Q2	2017-2018	GA	BB Door Rear Drv Side	Clear Fault Codes	
Audi Q2	2017-2018	GA	BB Door Rear Drv Side	Measuring Blocks	
Audi Q2	2017-2018	GA	BB Door Rear Drv Side	Output Tests	
Audi Q2	2017-2018	GA	BB Door Rear Drv Side	Specia Functions	
Audi Q2	2017-2018	GA	BC Door Rear Pass Side	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q2	2017-2018	GA	BC Door Rear Pass Side	Clear Fault Codes	
Audi Q2	2017-2018	GA	BC Door Rear Pass Side	Measuring Blocks	
Audi Q2	2017-2018	GA	BC Door Rear Pass Side	Output Tests	
Audi Q2	2017-2018	GA	BC Door Rear Pass Side	Specia Functions	
Audi Q2	2017-2018	GA	C0 Act. For Ext. Noise	Read Fault Codes	
Audi Q2	2017-2018	GA	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi Q2	2017-2018	GA	C0 Act. For Ext. Noise	Measuring Blocks	
Audi Q2	2017-2018	GA	C0 Act. For Ext. Noise	Output Tests	
Audi Q2	2017-2018	GA	C0 Act. For Ext. Noise	Specia Functions	
Audi Q2	2017-2018	GA	C6 Batt. Chrg	Read Fault Codes	
Audi Q2	2017-2018	GA	C6 Batt. Chrg	Clear Fault Codes	
Audi Q2	2017-2018	GA	C6 Batt. Chrg	Measuring Blocks	
Audi Q2	2017-2018	GA	C6 Batt. Chrg	Output Tests	
Audi Q2	2017-2018	GA	C6 Batt. Chrg	Specia Functions	
Audi Q2	2017-2018	GA	4B Multifunction Module	Read Fault Codes	
Audi Q2	2017-2018	GA	4B Multifunction Module	Clear Fault Codes	
Audi Q2	2017-2018	GA	4B Multifunction Module	Measuring Blocks	
Audi Q2	2017-2018	GA	4B Multifunction Module	Output Tests	
Audi Q2	2017-2018	GA	4B Multifunction Module	Specia Functions	
Audi Q2	2017-2018	GA	CF Control Unit Lane Change Assistant 2	Read Fault Codes	
Audi Q2	2017-2018	GA	CF Control Unit Lane Change Assistant 2	Clear Fault Codes	
Audi Q2	2017-2018	GA	CF Control Unit Lane Change Assistant 2	Measuring Blocks	
Audi Q2	2017-2018	GA	CF Control Unit Lane Change Assistant 2	Output Tests	
Audi Q2	2017-2018	GA	CF Control Unit Lane Change Assistant 2	Specia Functions	
Audi Q2	2017-2018	GA	D6 Light Control Left 2	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi Q2	2017-2018	GA	D6 Light Control Left 2	Clear Fault Codes	
Audi Q2	2017-2018	GA	D6 Light Control Left 2	Measuring Blocks	
Audi Q2	2017-2018	GA	D6 Light Control Left 2	Output Tests	
Audi Q2	2017-2018	GA	D6 Light Control Left 2	Specia Functions	
Audi Q2	2017-2018	GA	D7 Light Control Right 2	Read Fault Codes	
Audi Q2	2017-2018	GA	D7 Light Control Right 2	Clear Fault Codes	
Audi Q2	2017-2018	GA	D7 Light Control Right 2	Measuring Blocks	
Audi Q2	2017-2018	GA	D7 Light Control Right 2	Output Tests	
Audi Q2	2017-2018	GA	D7 Light Control Right 2	Specia Functions	
Audi Q2	2017-2018	GA	DE Charger 1 Mobile Devices	Read Fault Codes	
Audi Q2	2017-2018	GA	DE Charger 1 Mobile Devices	Clear Fault Codes	
Audi Q2	2017-2018	GA	DE Charger 1 Mobile Devices	Measuring Blocks	
Audi Q2	2017-2018	GA	DE Charger 1 Mobile Devices	Output Tests	
Audi Q2	2017-2018	GA	DE Charger 1 Mobile Devices	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	01 Engine Electronics	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	01 Engine Electronics	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	01 Engine Electronics	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	01 Engine Electronics	Output Tests	
Audi A3 (Bra)	2013-2018	FV	01 Engine Electronics	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	02 Transmission Electronics	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	02 Transmission Electronics	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	02 Transmission Electronics	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	02 Transmission Electronics	Output Tests	
Audi A3 (Bra)	2013-2018	FV	02 Transmission Electronics	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	03 Brake Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 (Bra)	2013-2018	FV	03 Brake Electronics	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	03 Brake Electronics	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	03 Brake Electronics	Output Tests	
Audi A3 (Bra)	2013-2018	FV	03 Brake Electronics	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	06 Passene. Seat Adj.	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	06 Passene. Seat Adj.	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	06 Passene. Seat Adj.	Output Tests	
Audi A3 (Bra)	2013-2018	FV	06 Passene. Seat Adj.	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	08 AC/Heating Electronics	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	08 AC/Heating Electronics	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	08 AC/Heating Electronics	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	08 AC/Heating Electronics	Output Tests	
Audi A3 (Bra)	2013-2018	FV	08 AC/Heating Electronics	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	09 Electronic Ctrl Electronics	Output Tests	
Audi A3 (Bra)	2013-2018	FV	09 Electronic Ctrl Electronics	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	13 Distance Control	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	13 Distance Control	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	13 Distance Control	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	13 Distance Control	Output Tests	
Audi A3 (Bra)	2013-2018	FV	13 Distance Control	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	14 Wheel Damping Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 (Bra)	2013-2018	FV	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	14 Wheel Damping Electronics	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	14 Wheel Damping Electronics	Output Tests	
Audi A3 (Bra)	2013-2018	FV	14 Wheel Damping Electronics	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	15 Airbags	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	15 Airbags	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	15 Airbags	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	15 Airbags	Output Tests	
Audi A3 (Bra)	2013-2018	FV	15 Airbags	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	16 Steering Wheel Electronics	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	16 Steering Wheel Electronics	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	16 Steering Wheel Electronics	Output Tests	
Audi A3 (Bra)	2013-2018	FV	16 Steering Wheel Electronics	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	17 Instrument Cluster	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	17 Instrument Cluster	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	17 Instrument Cluster	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	17 Instrument Cluster	Output Tests	
Audi A3 (Bra)	2013-2018	FV	17 Instrument Cluster	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	18 Aux Heating	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	18 Aux Heating	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	18 Aux Heating	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	18 Aux Heating	Output Tests	
Audi A3 (Bra)	2013-2018	FV	18 Aux Heating	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 (Bra)	2013-2018	FV	19 Gateway Data Bus	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	19 Gateway Data Bus	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	19 Gateway Data Bus	Output Tests	
Audi A3 (Bra)	2013-2018	FV	19 Gateway Data Bus	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	20 High Beam Assistance Device	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	20 High Beam Assistance Device	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	20 High Beam Assistance Device	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	20 High Beam Assistance Device	Output Tests	
Audi A3 (Bra)	2013-2018	FV	20 High Beam Assistance Device	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	22 4WD Electronics	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	22 4WD Electronics	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	22 4WD Electronics	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	22 4WD Electronics	Output Tests	
Audi A3 (Bra)	2013-2018	FV	22 4WD Electronics	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	23 Braker Booster	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	23 Braker Booster	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	23 Braker Booster	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	23 Braker Booster	Output Tests	
Audi A3 (Bra)	2013-2018	FV	23 Braker Booster	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	26 Electric Roof Control	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	26 Electric Roof Control	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	26 Electric Roof Control	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	26 Electric Roof Control	Output Tests	
Audi A3 (Bra)	2013-2018	FV	26 Electric Roof Control	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	29 Left Light Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3 (Bra)	2013-2018	FV	29 Left Light Control	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	29 Left Light Control	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	29 Left Light Control	Output Tests	
Audi A3 (Bra)	2013-2018	FV	29 Left Light Control	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	2B Steer Col Lock	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	2B Steer Col Lock	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	2B Steer Col Lock	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	2B Steer Col Lock	Output Tests	
Audi A3 (Bra)	2013-2018	FV	2B Steer Col Lock	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	30 Special Function 2	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	30 Special Function 2	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	30 Special Function 2	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	30 Special Function 2	Output Tests	
Audi A3 (Bra)	2013-2018	FV	30 Special Function 2	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	36 Driver`s Side Seat Adj.	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	36 Driver`s Side Seat Adj.	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	36 Driver`s Side Seat Adj.	Output Tests	
Audi A3 (Bra)	2013-2018	FV	36 Driver`s Side Seat Adj.	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	39 Right Light Control	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	39 Right Light Control	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	39 Right Light Control	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	39 Right Light Control	Output Tests	
Audi A3 (Bra)	2013-2018	FV	39 Right Light Control	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 (Bra)	2013-2018	FV	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	3C Lane Departure Assistance System	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	3C Lane Departure Assistance System	Output Tests	
Audi A3 (Bra)	2013-2018	FV	3C Lane Departure Assistance System	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	3D Special Function	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	3D Special Function	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	3D Special Function	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	3D Special Function	Output Tests	
Audi A3 (Bra)	2013-2018	FV	3D Special Function	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	42 Driver-Door Elect.	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	42 Driver-Door Elect.	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	42 Driver-Door Elect.	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	42 Driver-Door Elect.	Output Tests	
Audi A3 (Bra)	2013-2018	FV	42 Driver-Door Elect.	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	44 Steering Assistance	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	44 Steering Assistance	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	44 Steering Assistance	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	44 Steering Assistance	Output Tests	
Audi A3 (Bra)	2013-2018	FV	44 Steering Assistance	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	47 Soundsystem	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	47 Soundsystem	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	47 Soundsystem	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	47 Soundsystem	Output Tests	
Audi A3 (Bra)	2013-2018	FV	47 Soundsystem	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	51 Electric Drive	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3 (Bra)	2013-2018	FV	51 Electric Drive	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	51 Electric Drive	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	51 Electric Drive	Output Tests	
Audi A3 (Bra)	2013-2018	FV	51 Electric Drive	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	52 Passe.-Door Elect.	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	52 Passe.-Door Elect.	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	52 Passe.-Door Elect.	Output Tests	
Audi A3 (Bra)	2013-2018	FV	52 Passe.-Door Elect.	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	55 Headlight Range Control	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	55 Headlight Range Control	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	55 Headlight Range Control	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	55 Headlight Range Control	Output Tests	
Audi A3 (Bra)	2013-2018	FV	55 Headlight Range Control	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	57 TV-Tuner	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	57 TV-Tuner	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	57 TV-Tuner	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	57 TV-Tuner	Output Tests	
Audi A3 (Bra)	2013-2018	FV	57 TV-Tuner	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	5F Information Electronic Equipment 1	Output Tests	
Audi A3 (Bra)	2013-2018	FV	5F Information Electronic Equipment 1	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	65 Tyre Pressure Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 (Bra)	2013-2018	FV	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	65 Tyre Pressure Monitoring	Output Tests	
Audi A3 (Bra)	2013-2018	FV	65 Tyre Pressure Monitoring	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	69 Trailer Function	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	69 Trailer Function	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	69 Trailer Function	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	69 Trailer Function	Output Tests	
Audi A3 (Bra)	2013-2018	FV	69 Trailer Function	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	6C Rear Camera	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	6C Rear Camera	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	6C Rear Camera	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	6C Rear Camera	Output Tests	
Audi A3 (Bra)	2013-2018	FV	6C Rear Camera	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A3 (Bra)	2013-2018	FV	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	75 Emergency Call Module	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	75 Emergency Call Module	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	75 Emergency Call Module	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	75 Emergency Call Module	Output Tests	
Audi A3 (Bra)	2013-2018	FV	75 Emergency Call Module	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	76 Parking Aid	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 (Bra)	2013-2018	FV	76 Parking Aid	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	76 Parking Aid	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	76 Parking Aid	Output Tests	
Audi A3 (Bra)	2013-2018	FV	76 Parking Aid	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	82 Heads Up Display	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	82 Heads Up Display	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	82 Heads Up Display	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	82 Heads Up Display	Output Tests	
Audi A3 (Bra)	2013-2018	FV	82 Heads Up Display	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	8C Hybrid Battery	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	8C Hybrid Battery	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	8C Hybrid Battery	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	8C Hybrid Battery	Output Tests	
Audi A3 (Bra)	2013-2018	FV	8C Hybrid Battery	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A3 (Bra)	2013-2018	FV	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	A6 Microphone	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	A6 Microphone	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	A6 Microphone	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	A6 Microphone	Output Tests	
Audi A3 (Bra)	2013-2018	FV	A6 Microphone	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 (Bra)	2013-2018	FV	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	A9 Struct.Borne Sound	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	A9 Struct.Borne Sound	Output Tests	
Audi A3 (Bra)	2013-2018	FV	A9 Struct.Borne Sound	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	B7 Access Start Interf	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	B7 Access Start Interf	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	B7 Access Start Interf	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	B7 Access Start Interf	Output Tests	
Audi A3 (Bra)	2013-2018	FV	B7 Access Start Interf	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	BB Door Rear Drv Side	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	BB Door Rear Drv Side	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	BB Door Rear Drv Side	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	BB Door Rear Drv Side	Output Tests	
Audi A3 (Bra)	2013-2018	FV	BB Door Rear Drv Side	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	BC Door Rear Pass Side	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	BC Door Rear Pass Side	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	BC Door Rear Pass Side	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	BC Door Rear Pass Side	Output Tests	
Audi A3 (Bra)	2013-2018	FV	BC Door Rear Pass Side	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	C0 Act. For Ext. Noise	Output Tests	
Audi A3 (Bra)	2013-2018	FV	C0 Act. For Ext. Noise	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	C6 Batt. Chrg	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A3 (Bra)	2013-2018	FV	C6 Batt. Chrg	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	C6 Batt. Chrg	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	C6 Batt. Chrg	Output Tests	
Audi A3 (Bra)	2013-2018	FV	C6 Batt. Chrg	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	4B Multifunction Module	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	4B Multifunction Module	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	4B Multifunction Module	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	4B Multifunction Module	Output Tests	
Audi A3 (Bra)	2013-2018	FV	4B Multifunction Module	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	CF Control Unit Lane Change Assistant 2	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	CF Control Unit Lane Change Assistant 2	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	CF Control Unit Lane Change Assistant 2	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	CF Control Unit Lane Change Assistant 2	Output Tests	
Audi A3 (Bra)	2013-2018	FV	CF Control Unit Lane Change Assistant 2	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	D6 Light Control Left 2	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	D6 Light Control Left 2	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	D6 Light Control Left 2	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	D6 Light Control Left 2	Output Tests	
Audi A3 (Bra)	2013-2018	FV	D6 Light Control Left 2	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	D7 Light Control Right 2	Read Fault Codes	
Audi A3 (Bra)	2013-2018	FV	D7 Light Control Right 2	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	D7 Light Control Right 2	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	D7 Light Control Right 2	Output Tests	
Audi A3 (Bra)	2013-2018	FV	D7 Light Control Right 2	Specia Functions	
Audi A3 (Bra)	2013-2018	FV	DE Charger 1 Mobile Devices	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A3 (Bra)	2013-2018	FV	DE Charger 1 Mobile Devices	Clear Fault Codes	
Audi A3 (Bra)	2013-2018	FV	DE Charger 1 Mobile Devices	Measuring Blocks	
Audi A3 (Bra)	2013-2018	FV	DE Charger 1 Mobile Devices	Output Tests	
Audi A3 (Bra)	2013-2018	FV	DE Charger 1 Mobile Devices	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	01 Engine Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	01 Engine Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	01 Engine Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	01 Engine Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	FY	01 Engine Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	02 Transmission Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	02 Transmission Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	02 Transmission Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	02 Transmission Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	FY	02 Transmission Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	03 Brake Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	03 Brake Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	03 Brake Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	03 Brake Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	FY	03 Brake Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	06 Passene. Seat Adj.	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	06 Passene. Seat Adj.	Output Tests	
Audi Q5 (USA)	2017-2018	FY	06 Passene. Seat Adj.	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	FY	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	08 AC/Heating Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	08 AC/Heating Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	FY	08 AC/Heating Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	09 Electronic Ctrl Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	FY	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	13 Distance Control	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	13 Distance Control	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	13 Distance Control	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	13 Distance Control	Output Tests	
Audi Q5 (USA)	2017-2018	FY	13 Distance Control	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	15 Airbags	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	15 Airbags	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	15 Airbags	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	15 Airbags	Output Tests	
Audi Q5 (USA)	2017-2018	FY	15 Airbags	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	16 Steering Wheel Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	FY	16 Steering Wheel Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	FY	17 Instrument Cluster	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	17 Instrument Cluster	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	17 Instrument Cluster	Output Tests	
Audi Q5 (USA)	2017-2018	FY	17 Instrument Cluster	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	18 Aux Heating	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	18 Aux Heating	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	18 Aux Heating	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	18 Aux Heating	Output Tests	
Audi Q5 (USA)	2017-2018	FY	18 Aux Heating	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	19 Gateway Data Bus	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	19 Gateway Data Bus	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	19 Gateway Data Bus	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	19 Gateway Data Bus	Output Tests	
Audi Q5 (USA)	2017-2018	FY	19 Gateway Data Bus	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	1B Active Steering	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	1B Active Steering	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	1B Active Steering	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	1B Active Steering	Output Tests	
Audi Q5 (USA)	2017-2018	FY	1B Active Steering	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	20 High Beam Assistance Device	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	20 High Beam Assistance Device	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	20 High Beam Assistance Device	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	20 High Beam Assistance Device	Output Tests	
Audi Q5 (USA)	2017-2018	FY	20 High Beam Assistance Device	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	21 Battery Energy Control Module 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	FY	21 Battery Energy Control Module 2	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	21 Battery Energy Control Module 2	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	21 Battery Energy Control Module 2	Output Tests	
Audi Q5 (USA)	2017-2018	FY	21 Battery Energy Control Module 2	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	22 4WD Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	22 4WD Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	22 4WD Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	22 4WD Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	FY	22 4WD Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	29 Left Light Control	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	29 Left Light Control	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	29 Left Light Control	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	29 Left Light Control	Output Tests	
Audi Q5 (USA)	2017-2018	FY	29 Left Light Control	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	2B Steer Col Lock	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	2B Steer Col Lock	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	2B Steer Col Lock	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	2B Steer Col Lock	Output Tests	
Audi Q5 (USA)	2017-2018	FY	2B Steer Col Lock	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	32 Lock Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	32 Lock Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	32 Lock Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	32 Lock Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	FY	32 Lock Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	36 Driver`s Side Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q5 (USA)	2017-2018	FY	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	36 Driver`s Side Seat Adj.	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	36 Driver`s Side Seat Adj.	Output Tests	
Audi Q5 (USA)	2017-2018	FY	36 Driver`s Side Seat Adj.	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	39 Right Light Control	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	39 Right Light Control	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	39 Right Light Control	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	39 Right Light Control	Output Tests	
Audi Q5 (USA)	2017-2018	FY	39 Right Light Control	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	3C Lane Departure Assistance System	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	3C Lane Departure Assistance System	Output Tests	
Audi Q5 (USA)	2017-2018	FY	3C Lane Departure Assistance System	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	3D Special Function	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	3D Special Function	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	3D Special Function	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	3D Special Function	Output Tests	
Audi Q5 (USA)	2017-2018	FY	3D Special Function	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	42 Driver-Door Elect.	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	42 Driver-Door Elect.	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	42 Driver-Door Elect.	Output Tests	
Audi Q5 (USA)	2017-2018	FY	42 Driver-Door Elect.	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	44 Steering Assistance	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	FY	44 Steering Assistance	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	44 Steering Assistance	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	44 Steering Assistance	Output Tests	
Audi Q5 (USA)	2017-2018	FY	44 Steering Assistance	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	46 Central Module Comfort System	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	46 Central Module Comfort System	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	46 Central Module Comfort System	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	46 Central Module Comfort System	Output Tests	
Audi Q5 (USA)	2017-2018	FY	46 Central Module Comfort System	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	47 Soundsystem	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	47 Soundsystem	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	47 Soundsystem	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	47 Soundsystem	Output Tests	
Audi Q5 (USA)	2017-2018	FY	47 Soundsystem	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	4E Control Head Rear Right	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	4E Control Head Rear Right	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	4E Control Head Rear Right	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	4E Control Head Rear Right	Output Tests	
Audi Q5 (USA)	2017-2018	FY	4E Control Head Rear Right	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	52 Passe.-Door Elect.	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	52 Passe.-Door Elect.	Output Tests	
Audi Q5 (USA)	2017-2018	FY	52 Passe.-Door Elect.	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	57 TV-Tuner	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q5 (USA)	2017-2018	FY	57 TV-Tuner	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	57 TV-Tuner	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	57 TV-Tuner	Output Tests	
Audi Q5 (USA)	2017-2018	FY	57 TV-Tuner	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	5E Control Head Rear Left	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	5E Control Head Rear Left	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	5E Control Head Rear Left	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	5E Control Head Rear Left	Output Tests	
Audi Q5 (USA)	2017-2018	FY	5E Control Head Rear Left	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	5F Information Electronic Equipment 1	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	5F Information Electronic Equipment 1	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	5F Information Electronic Equipment 1	Output Tests	
Audi Q5 (USA)	2017-2018	FY	5F Information Electronic Equipment 1	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	69 Trailer Function	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	69 Trailer Function	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	69 Trailer Function	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	69 Trailer Function	Output Tests	
Audi Q5 (USA)	2017-2018	FY	69 Trailer Function	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	6C Rear Camera	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	6C Rear Camera	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	6C Rear Camera	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	6C Rear Camera	Output Tests	
Audi Q5 (USA)	2017-2018	FY	6C Rear Camera	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	FY	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q5 (USA)	2017-2018	FY	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	74 Chassis Control	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	74 Chassis Control	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	74 Chassis Control	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	74 Chassis Control	Output Tests	
Audi Q5 (USA)	2017-2018	FY	74 Chassis Control	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	81 Gear Shift Control Module	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	81 Gear Shift Control Module	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	81 Gear Shift Control Module	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	81 Gear Shift Control Module	Output Tests	
Audi Q5 (USA)	2017-2018	FY	81 Gear Shift Control Module	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	82 Heads Up Display	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	82 Heads Up Display	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	82 Heads Up Display	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	82 Heads Up Display	Output Tests	
Audi Q5 (USA)	2017-2018	FY	82 Heads Up Display	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	8B Adaptive Cruise Control 2	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	8B Adaptive Cruise Control 2	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	8B Adaptive Cruise Control 2	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	8B Adaptive Cruise Control 2	Output Tests	
Audi Q5 (USA)	2017-2018	FY	8B Adaptive Cruise Control 2	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	A5 Frt Sens.Drv.Assist	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	FY	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	A5 Frt Sens.Drv.Assist	Output Tests	
Audi Q5 (USA)	2017-2018	FY	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	A9 Struct.Borne Sound	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	A9 Struct.Borne Sound	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	A9 Struct.Borne Sound	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	A9 Struct.Borne Sound	Output Tests	
Audi Q5 (USA)	2017-2018	FY	A9 Struct.Borne Sound	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	AC Reductant Control Module	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	AC Reductant Control Module	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	AC Reductant Control Module	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	AC Reductant Control Module	Output Tests	
Audi Q5 (USA)	2017-2018	FY	AC Reductant Control Module	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	BB Door Rear Drv Side	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	BB Door Rear Drv Side	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	BB Door Rear Drv Side	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	BB Door Rear Drv Side	Output Tests	
Audi Q5 (USA)	2017-2018	FY	BB Door Rear Drv Side	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	BC Door Rear Pass Side	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	BC Door Rear Pass Side	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	BC Door Rear Pass Side	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	BC Door Rear Pass Side	Output Tests	
Audi Q5 (USA)	2017-2018	FY	BC Door Rear Pass Side	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	C0 Act. For Ext. Noise	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	FY	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	C0 Act. For Ext. Noise	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	C0 Act. For Ext. Noise	Output Tests	
Audi Q5 (USA)	2017-2018	FY	C0 Act. For Ext. Noise	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	23 Brake Boost	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	23 Brake Boost	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	23 Brake Boost	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	23 Brake Boost	Output Tests	
Audi Q5 (USA)	2017-2018	FY	23 Brake Boost	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	26 Electronic Roof Control	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	26 Electronic Roof Control	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	26 Electronic Roof Control	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	26 Electronic Roof Control	Output Tests	
Audi Q5 (USA)	2017-2018	FY	26 Electronic Roof Control	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	51 Drive Motor Control Module	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	51 Drive Motor Control Module	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	51 Drive Motor Control Module	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	51 Drive Motor Control Module	Output Tests	
Audi Q5 (USA)	2017-2018	FY	51 Drive Motor Control Module	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	5D Operation	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	5D Operation	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	5D Operation	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	5D Operation	Output Tests	
Audi Q5 (USA)	2017-2018	FY	5D Operation	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	65 Tyre Pressure Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	FY	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	65 Tyre Pressure Monitoring	Output Tests	
Audi Q5 (USA)	2017-2018	FY	65 Tyre Pressure Monitoring	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	80 Battery Regulation Auxiliary Accumulator 1	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	80 Battery Regulation Auxiliary Accumulator 1	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	80 Battery Regulation Auxiliary Accumulator 1	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	80 Battery Regulation Auxiliary Accumulator 1	Output Tests	
Audi Q5 (USA)	2017-2018	FY	80 Battery Regulation Auxiliary Accumulator 1	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	8C Battery Energy Control Module	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	8C Battery Energy Control Module	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	8C Battery Energy Control Module	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	8C Battery Energy Control Module	Output Tests	
Audi Q5 (USA)	2017-2018	FY	8C Battery Energy Control Module	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	A6 Microphone Control Unit	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	A6 Microphone Control Unit	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	A6 Microphone Control Unit	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	A6 Microphone Control Unit	Output Tests	
Audi Q5 (USA)	2017-2018	FY	A6 Microphone Control Unit	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	C4 DC/DC Converter Control Module	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	C4 DC/DC Converter Control Module	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	C4 DC/DC Converter Control Module	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	C4 DC/DC Converter Control Module	Output Tests	
Audi Q5 (USA)	2017-2018	FY	C4 DC/DC Converter Control Module	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	C5 Thermal Management	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	FY	C5 Thermal Management	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	C5 Thermal Management	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	C5 Thermal Management	Output Tests	
Audi Q5 (USA)	2017-2018	FY	C5 Thermal Management	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	C6 Battery Charger Control Module	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	C6 Battery Charger Control Module	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	C6 Battery Charger Control Module	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	C6 Battery Charger Control Module	Output Tests	
Audi Q5 (USA)	2017-2018	FY	C6 Battery Charger Control Module	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	CA Control Module For Sunroof	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	CA Control Module For Sunroof	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	CA Control Module For Sunroof	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	CA Control Module For Sunroof	Output Tests	
Audi Q5 (USA)	2017-2018	FY	CA Control Module For Sunroof	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	CC Starter / Generator Control Module	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	CC Starter / Generator Control Module	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	CC Starter / Generator Control Module	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	CC Starter / Generator Control Module	Output Tests	
Audi Q5 (USA)	2017-2018	FY	CC Starter / Generator Control Module	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	CF Control Unit Lane Change Assistant 2	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	CF Control Unit Lane Change Assistant 2	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	CF Control Unit Lane Change Assistant 2	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	CF Control Unit Lane Change Assistant 2	Output Tests	
Audi Q5 (USA)	2017-2018	FY	CF Control Unit Lane Change Assistant 2	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	D6 Light Control Left 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	FY	D6 Light Control Left 2	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	D6 Light Control Left 2	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	D6 Light Control Left 2	Output Tests	
Audi Q5 (USA)	2017-2018	FY	D6 Light Control Left 2	Specia Functions	
Audi Q5 (USA)	2017-2018	FY	D7 Light Control Right 2	Read Fault Codes	
Audi Q5 (USA)	2017-2018	FY	D7 Light Control Right 2	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	FY	D7 Light Control Right 2	Measuring Blocks	
Audi Q5 (USA)	2017-2018	FY	D7 Light Control Right 2	Output Tests	
Audi Q5 (USA)	2017-2018	FY	D7 Light Control Right 2	Specia Functions	
Audi A8 (USA)	2017-2018	F8	01 Engine Electronics	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	01 Engine Electronics	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	01 Engine Electronics	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	01 Engine Electronics	Output Tests	
Audi A8 (USA)	2017-2018	F8	01 Engine Electronics	Specia Functions	
Audi A8 (USA)	2017-2018	F8	02 Transmission Electronics	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	02 Transmission Electronics	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	02 Transmission Electronics	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	02 Transmission Electronics	Output Tests	
Audi A8 (USA)	2017-2018	F8	02 Transmission Electronics	Specia Functions	
Audi A8 (USA)	2017-2018	F8	03 Brake Electronics	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	03 Brake Electronics	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	03 Brake Electronics	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	03 Brake Electronics	Output Tests	
Audi A8 (USA)	2017-2018	F8	03 Brake Electronics	Specia Functions	
Audi A8 (USA)	2017-2018	F8	06 Passene. Seat Adj.	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	06 Passene. Seat Adj.	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	06 Passene. Seat Adj.	Output Tests	
Audi A8 (USA)	2017-2018	F8	06 Passene. Seat Adj.	Specia Functions	
Audi A8 (USA)	2017-2018	F8	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	09 Electronic Ctrl Electronics	Output Tests	
Audi A8 (USA)	2017-2018	F8	09 Electronic Ctrl Electronics	Specia Functions	
Audi A8 (USA)	2017-2018	F8	0E Media Player Position 1	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	0E Media Player Position 1	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	0E Media Player Position 1	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	0E Media Player Position 1	Output Tests	
Audi A8 (USA)	2017-2018	F8	0E Media Player Position 1	Specia Functions	
Audi A8 (USA)	2017-2018	F8	11 Engine Control Module 2	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	11 Engine Control Module 2	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	11 Engine Control Module 2	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	11 Engine Control Module 2	Output Tests	
Audi A8 (USA)	2017-2018	F8	11 Engine Control Module 2	Specia Functions	
Audi A8 (USA)	2017-2018	F8	13 Distance Control	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	13 Distance Control	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	13 Distance Control	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	13 Distance Control	Output Tests	
Audi A8 (USA)	2017-2018	F8	13 Distance Control	Specia Functions	
Audi A8 (USA)	2017-2018	F8	15 Airbags	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	15 Airbags	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	15 Airbags	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	15 Airbags	Output Tests	
Audi A8 (USA)	2017-2018	F8	15 Airbags	Specia Functions	
Audi A8 (USA)	2017-2018	F8	16 Steering Wheel Electronics	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	16 Steering Wheel Electronics	Output Tests	
Audi A8 (USA)	2017-2018	F8	16 Steering Wheel Electronics	Specia Functions	
Audi A8 (USA)	2017-2018	F8	17 Instrument Cluster	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	17 Instrument Cluster	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	17 Instrument Cluster	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	17 Instrument Cluster	Output Tests	
Audi A8 (USA)	2017-2018	F8	17 Instrument Cluster	Specia Functions	
Audi A8 (USA)	2017-2018	F8	18 Aux Heating	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	18 Aux Heating	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	18 Aux Heating	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	18 Aux Heating	Output Tests	
Audi A8 (USA)	2017-2018	F8	18 Aux Heating	Specia Functions	
Audi A8 (USA)	2017-2018	F8	19 Gateway Data Bus	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	19 Gateway Data Bus	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	19 Gateway Data Bus	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	19 Gateway Data Bus	Output Tests	
Audi A8 (USA)	2017-2018	F8	19 Gateway Data Bus	Specia Functions	
Audi A8 (USA)	2017-2018	F8	1B Active Steering	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	1B Active Steering	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	1B Active Steering	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	1B Active Steering	Output Tests	
Audi A8 (USA)	2017-2018	F8	1B Active Steering	Specia Functions	
Audi A8 (USA)	2017-2018	F8	21 Battery Energy Control Module 2	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	21 Battery Energy Control Module 2	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	21 Battery Energy Control Module 2	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	21 Battery Energy Control Module 2	Output Tests	
Audi A8 (USA)	2017-2018	F8	21 Battery Energy Control Module 2	Specia Functions	
Audi A8 (USA)	2017-2018	F8	23 Braker Booster	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	23 Braker Booster	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	23 Braker Booster	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	23 Braker Booster	Output Tests	
Audi A8 (USA)	2017-2018	F8	23 Braker Booster	Specia Functions	
Audi A8 (USA)	2017-2018	F8	29 Left Light Control	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	29 Left Light Control	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	29 Left Light Control	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	29 Left Light Control	Output Tests	
Audi A8 (USA)	2017-2018	F8	29 Left Light Control	Specia Functions	
Audi A8 (USA)	2017-2018	F8	2A Control Unit Wireless Charging	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	2A Control Unit Wireless Charging	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	2A Control Unit Wireless Charging	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	2A Control Unit Wireless Charging	Output Tests	
Audi A8 (USA)	2017-2018	F8	2A Control Unit Wireless Charging	Specia Functions	
Audi A8 (USA)	2017-2018	F8	2B Steer Col Lock	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	2B Steer Col Lock	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	2B Steer Col Lock	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	2B Steer Col Lock	Output Tests	
Audi A8 (USA)	2017-2018	F8	2B Steer Col Lock	Specia Functions	
Audi A8 (USA)	2017-2018	F8	32 Lock Electronics	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	32 Lock Electronics	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	32 Lock Electronics	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	32 Lock Electronics	Output Tests	
Audi A8 (USA)	2017-2018	F8	32 Lock Electronics	Specia Functions	
Audi A8 (USA)	2017-2018	F8	36 Driver`s Side Seat Adj.	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	36 Driver`s Side Seat Adj.	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	36 Driver`s Side Seat Adj.	Output Tests	
Audi A8 (USA)	2017-2018	F8	36 Driver`s Side Seat Adj.	Specia Functions	
Audi A8 (USA)	2017-2018	F8	39 Right Light Control	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	39 Right Light Control	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	39 Right Light Control	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	39 Right Light Control	Output Tests	
Audi A8 (USA)	2017-2018	F8	39 Right Light Control	Specia Functions	
Audi A8 (USA)	2017-2018	F8	3C Lane Departure Assistance System	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	3C Lane Departure Assistance System	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	3C Lane Departure Assistance System	Output Tests	
Audi A8 (USA)	2017-2018	F8	3C Lane Departure Assistance System	Specia Functions	
Audi A8 (USA)	2017-2018	F8	42 Driver-Door Elect.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	42 Driver-Door Elect.	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	42 Driver-Door Elect.	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	42 Driver-Door Elect.	Output Tests	
Audi A8 (USA)	2017-2018	F8	42 Driver-Door Elect.	Specia Functions	
Audi A8 (USA)	2017-2018	F8	44 Steering Assistance	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	44 Steering Assistance	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	44 Steering Assistance	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	44 Steering Assistance	Output Tests	
Audi A8 (USA)	2017-2018	F8	44 Steering Assistance	Specia Functions	
Audi A8 (USA)	2017-2018	F8	46 Central Module Comfort System	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	46 Central Module Comfort System	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	46 Central Module Comfort System	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	46 Central Module Comfort System	Output Tests	
Audi A8 (USA)	2017-2018	F8	46 Central Module Comfort System	Specia Functions	
Audi A8 (USA)	2017-2018	F8	47 Soundsystem	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	47 Soundsystem	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	47 Soundsystem	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	47 Soundsystem	Output Tests	
Audi A8 (USA)	2017-2018	F8	47 Soundsystem	Specia Functions	
Audi A8 (USA)	2017-2018	F8	48 Seat Adjustment Rear Driver Side	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	48 Seat Adjustment Rear Driver Side	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	48 Seat Adjustment Rear Driver Side	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	48 Seat Adjustment Rear Driver Side	Output Tests	
Audi A8 (USA)	2017-2018	F8	48 Seat Adjustment Rear Driver Side	Specia Functions	
Audi A8 (USA)	2017-2018	F8	4E Control Head Rear Right	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	4E Control Head Rear Right	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	4E Control Head Rear Right	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	4E Control Head Rear Right	Output Tests	
Audi A8 (USA)	2017-2018	F8	4E Control Head Rear Right	Specia Functions	
Audi A8 (USA)	2017-2018	F8	51 Electric Drive	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	51 Electric Drive	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	51 Electric Drive	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	51 Electric Drive	Output Tests	
Audi A8 (USA)	2017-2018	F8	51 Electric Drive	Specia Functions	
Audi A8 (USA)	2017-2018	F8	52 Passe.-Door Elect.	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	52 Passe.-Door Elect.	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	52 Passe.-Door Elect.	Output Tests	
Audi A8 (USA)	2017-2018	F8	52 Passe.-Door Elect.	Specia Functions	
Audi A8 (USA)	2017-2018	F8	57 TV-Tuner	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	57 TV-Tuner	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	57 TV-Tuner	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	57 TV-Tuner	Output Tests	
Audi A8 (USA)	2017-2018	F8	57 TV-Tuner	Specia Functions	
Audi A8 (USA)	2017-2018	F8	5B Seat Adjustment Rear Passenger Side	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	5B Seat Adjustment Rear Passenger Side	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	5B Seat Adjustment Rear Passenger Side	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	5B Seat Adjustment Rear Passenger Side	Output Tests	
Audi A8 (USA)	2017-2018	F8	5B Seat Adjustment Rear Passenger Side	Specia Functions	
Audi A8 (USA)	2017-2018	F8	5E Control Head Rear Left	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	5E Control Head Rear Left	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	5E Control Head Rear Left	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	5E Control Head Rear Left	Output Tests	
Audi A8 (USA)	2017-2018	F8	5E Control Head Rear Left	Specia Functions	
Audi A8 (USA)	2017-2018	F8	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	5F Information Electronic Equipment 1	Output Tests	
Audi A8 (USA)	2017-2018	F8	5F Information Electronic Equipment 1	Specia Functions	
Audi A8 (USA)	2017-2018	F8	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	65 Tyre Pressure Monitoring	Output Tests	
Audi A8 (USA)	2017-2018	F8	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8 (USA)	2017-2018	F8	69 Trailer Function	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	69 Trailer Function	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	69 Trailer Function	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	69 Trailer Function	Output Tests	
Audi A8 (USA)	2017-2018	F8	69 Trailer Function	Specia Functions	
Audi A8 (USA)	2017-2018	F8	6C Rear Camera	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	6C Rear Camera	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	6C Rear Camera	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	6C Rear Camera	Output Tests	
Audi A8 (USA)	2017-2018	F8	6C Rear Camera	Specia Functions	
Audi A8 (USA)	2017-2018	F8	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8 (USA)	2017-2018	F8	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A8 (USA)	2017-2018	F8	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A8 (USA)	2017-2018	F8	74 Chassis Control	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	74 Chassis Control	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	74 Chassis Control	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	74 Chassis Control	Output Tests	
Audi A8 (USA)	2017-2018	F8	74 Chassis Control	Specia Functions	
Audi A8 (USA)	2017-2018	F8	81 Gear Shift Control Module	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	81 Gear Shift Control Module	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	81 Gear Shift Control Module	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	81 Gear Shift Control Module	Output Tests	
Audi A8 (USA)	2017-2018	F8	81 Gear Shift Control Module	Specia Functions	
Audi A8 (USA)	2017-2018	F8	82 Heads Up Display	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	82 Heads Up Display	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	82 Heads Up Display	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	82 Heads Up Display	Output Tests	
Audi A8 (USA)	2017-2018	F8	82 Heads Up Display	Specia Functions	
Audi A8 (USA)	2017-2018	F8	84 Night Vision	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	84 Night Vision	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	84 Night Vision	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	84 Night Vision	Output Tests	
Audi A8 (USA)	2017-2018	F8	84 Night Vision	Specia Functions	
Audi A8 (USA)	2017-2018	F8	8C Hybrid Battery	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	8C Hybrid Battery	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	8C Hybrid Battery	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	8C Hybrid Battery	Output Tests	
Audi A8 (USA)	2017-2018	F8	8C Hybrid Battery	Specia Functions	
Audi A8 (USA)	2017-2018	F8	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A8 (USA)	2017-2018	F8	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A8 (USA)	2017-2018	F8	A9 Struct.Borne Sound	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	A9 Struct.Borne Sound	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	A9 Struct.Borne Sound	Output Tests	
Audi A8 (USA)	2017-2018	F8	A9 Struct.Borne Sound	Specia Functions	
Audi A8 (USA)	2017-2018	F8	AC Reductant Control Module	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	AC Reductant Control Module	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	AC Reductant Control Module	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	AC Reductant Control Module	Output Tests	
Audi A8 (USA)	2017-2018	F8	AC Reductant Control Module	Specia Functions	
Audi A8 (USA)	2017-2018	F8	BA Assembly Mounting	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	BA Assembly Mounting	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	BA Assembly Mounting	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	BA Assembly Mounting	Output Tests	
Audi A8 (USA)	2017-2018	F8	BA Assembly Mounting	Specia Functions	
Audi A8 (USA)	2017-2018	F8	BB Door Rear Drv Side	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	BB Door Rear Drv Side	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	BB Door Rear Drv Side	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	BB Door Rear Drv Side	Output Tests	
Audi A8 (USA)	2017-2018	F8	BB Door Rear Drv Side	Specia Functions	
Audi A8 (USA)	2017-2018	F8	BC Door Rear Pass Side	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	BC Door Rear Pass Side	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	BC Door Rear Pass Side	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	BC Door Rear Pass Side	Output Tests	
Audi A8 (USA)	2017-2018	F8	BC Door Rear Pass Side	Specia Functions	
Audi A8 (USA)	2017-2018	F8	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	C0 Act. For Ext. Noise	Output Tests	
Audi A8 (USA)	2017-2018	F8	C0 Act. For Ext. Noise	Specia Functions	
Audi A8 (USA)	2017-2018	F8	C4 DC/DC Converter Control Module	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	C4 DC/DC Converter Control Module	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	C4 DC/DC Converter Control Module	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	C4 DC/DC Converter Control Module	Output Tests	
Audi A8 (USA)	2017-2018	F8	C4 DC/DC Converter Control Module	Specia Functions	
Audi A8 (USA)	2017-2018	F8	C5 Thermal Management	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	C5 Thermal Management	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	C5 Thermal Management	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	C5 Thermal Management	Output Tests	
Audi A8 (USA)	2017-2018	F8	C5 Thermal Management	Specia Functions	
Audi A8 (USA)	2017-2018	F8	C6 Batt. Chrg	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8 (USA)	2017-2018	F8	C6 Batt. Chrg	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	C6 Batt. Chrg	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	C6 Batt. Chrg	Output Tests	
Audi A8 (USA)	2017-2018	F8	C6 Batt. Chrg	Specia Functions	
Audi A8 (USA)	2017-2018	F8	CA Control Module For Sunroof	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	CA Control Module For Sunroof	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	CA Control Module For Sunroof	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	CA Control Module For Sunroof	Output Tests	
Audi A8 (USA)	2017-2018	F8	CA Control Module For Sunroof	Specia Functions	
Audi A8 (USA)	2017-2018	F8	CB Rear Axle Steering	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	CB Rear Axle Steering	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	CB Rear Axle Steering	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	CB Rear Axle Steering	Output Tests	
Audi A8 (USA)	2017-2018	F8	CB Rear Axle Steering	Specia Functions	
Audi A8 (USA)	2017-2018	F8	CC Starter / Generator Control Module	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	CC Starter / Generator Control Module	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	CC Starter / Generator Control Module	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	CC Starter / Generator Control Module	Output Tests	
Audi A8 (USA)	2017-2018	F8	CC Starter / Generator Control Module	Specia Functions	
Audi A8 (USA)	2017-2018	F8	CD Laser Scanner	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	CD Laser Scanner	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	CD Laser Scanner	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	CD Laser Scanner	Output Tests	
Audi A8 (USA)	2017-2018	F8	CD Laser Scanner	Specia Functions	
Audi A8 (USA)	2017-2018	F8	CF Control Unit Lane Change Assistant 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	CF Control Unit Lane Change Assistant 2	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	CF Control Unit Lane Change Assistant 2	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	CF Control Unit Lane Change Assistant 2	Output Tests	
Audi A8 (USA)	2017-2018	F8	CF Control Unit Lane Change Assistant 2	Specia Functions	
Audi A8 (USA)	2017-2018	F8	D4 Roll Control System 1	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	D4 Roll Control System 1	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	D4 Roll Control System 1	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	D4 Roll Control System 1	Output Tests	
Audi A8 (USA)	2017-2018	F8	D4 Roll Control System 1	Specia Functions	
Audi A8 (USA)	2017-2018	F8	D5 Roll Control System 2	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	D5 Roll Control System 2	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	D5 Roll Control System 2	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	D5 Roll Control System 2	Output Tests	
Audi A8 (USA)	2017-2018	F8	D5 Roll Control System 2	Specia Functions	
Audi A8 (USA)	2017-2018	F8	D6 Light Control Left 2	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	D6 Light Control Left 2	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	D6 Light Control Left 2	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	D6 Light Control Left 2	Output Tests	
Audi A8 (USA)	2017-2018	F8	D6 Light Control Left 2	Specia Functions	
Audi A8 (USA)	2017-2018	F8	D7 Light Control Right 2	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	D7 Light Control Right 2	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	D7 Light Control Right 2	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	D7 Light Control Right 2	Output Tests	
Audi A8 (USA)	2017-2018	F8	D7 Light Control Right 2	Specia Functions	
Audi A8 (USA)	2017-2018	F8	DB Front Corner Radar 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	DB Front Corner Radar 1	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	DB Front Corner Radar 1	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	DB Front Corner Radar 1	Output Tests	
Audi A8 (USA)	2017-2018	F8	DB Front Corner Radar 1	Specia Functions	
Audi A8 (USA)	2017-2018	F8	DC Front Corner Radar 2	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	DC Front Corner Radar 2	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	DC Front Corner Radar 2	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	DC Front Corner Radar 2	Output Tests	
Audi A8 (USA)	2017-2018	F8	DC Front Corner Radar 2	Specia Functions	
Audi A8 (USA)	2017-2018	F8	DD Control Module 2 For Sunroof	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	DD Control Module 2 For Sunroof	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	DD Control Module 2 For Sunroof	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	DD Control Module 2 For Sunroof	Output Tests	
Audi A8 (USA)	2017-2018	F8	DD Control Module 2 For Sunroof	Specia Functions	
Audi A8 (USA)	2017-2018	F8	DE Charger 1 Mobile Devices	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	DE Charger 1 Mobile Devices	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	DE Charger 1 Mobile Devices	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	DE Charger 1 Mobile Devices	Output Tests	
Audi A8 (USA)	2017-2018	F8	DE Charger 1 Mobile Devices	Specia Functions	
Audi A8 (USA)	2017-2018	F8	DF Charger 2 Mobile Devices	Read Fault Codes	
Audi A8 (USA)	2017-2018	F8	DF Charger 2 Mobile Devices	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	DF Charger 2 Mobile Devices	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	DF Charger 2 Mobile Devices	Output Tests	
Audi A8 (USA)	2017-2018	F8	DF Charger 2 Mobile Devices	Specia Functions	
Audi A8 (USA)	2017-2018	F8	E0 Auxiliary Display Control Unit 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8 (USA)	2017-2018	F8	E0 Auxiliary Display Control Unit 1	Clear Fault Codes	
Audi A8 (USA)	2017-2018	F8	E0 Auxiliary Display Control Unit 1	Measuring Blocks	
Audi A8 (USA)	2017-2018	F8	E0 Auxiliary Display Control Unit 1	Output Tests	
Audi A8 (USA)	2017-2018	F8	E0 Auxiliary Display Control Unit 1	Specia Functions	
Audi A4	2008-2018	8R	01 Engine Electronics	Read Fault Codes	
Audi A4	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi A4	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi A4	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi A4	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi A4	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	
Audi A4	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi A4	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi A4	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi A4	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi A4	2008-2018	8R	03 Brake Electronics	Read Fault Codes	
Audi A4	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi A4	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi A4	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi A4	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi A4	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	
Audi A4	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi A4	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi A4	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi A4	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi A4	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A4	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi A4	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi A4	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi A4	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	
Audi A4	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A4	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi A4	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi A4	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi A4	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	
Audi A4	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi A4	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi A4	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi A4	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi A4	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A4	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A4	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A4	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi A4	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi A4	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	
Audi A4	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi A4	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi A4	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi A4	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi A4	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A4	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi A4	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi A4	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi A4	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	
Audi A4	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi A4	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi A4	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi A4	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi A4	2008-2018	8R	13 Distance Control	Read Fault Codes	
Audi A4	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi A4	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi A4	2008-2018	8R	13 Distance Control	Output Tests	
Audi A4	2008-2018	8R	13 Distance Control	Specia Functions	
Audi A4	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	
Audi A4	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A4	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi A4	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi A4	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi A4	2008-2018	8R	15 Airbags	Read Fault Codes	
Audi A4	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi A4	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi A4	2008-2018	8R	15 Airbags	Output Tests	
Audi A4	2008-2018	8R	15 Airbags	Specia Functions	
Audi A4	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A4	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi A4	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi A4	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi A4	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	
Audi A4	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi A4	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi A4	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi A4	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi A4	2008-2018	8R	18 Aux Heating	Read Fault Codes	
Audi A4	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi A4	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi A4	2008-2018	8R	18 Aux Heating	Output Tests	
Audi A4	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi A4	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	
Audi A4	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi A4	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi A4	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi A4	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi A4	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	
Audi A4	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi A4	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi A4	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi A4	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi A4	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi A4	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi A4	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi A4	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi A4	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	
Audi A4	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi A4	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi A4	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi A4	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi A4	2008-2018	8R	22 4WD Electronics	Read Fault Codes	
Audi A4	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi A4	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi A4	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi A4	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi A4	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	
Audi A4	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi A4	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi A4	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi A4	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi A4	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	
Audi A4	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi A4	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi A4	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi A4	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi A4	2008-2018	8R	30 Special Function 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi A4	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi A4	2008-2018	8R	30 Special Function 2	Output Tests	
Audi A4	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi A4	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A4	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A4	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A4	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi A4	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi A4	2008-2018	8R	37 Navigation	Read Fault Codes	
Audi A4	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi A4	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi A4	2008-2018	8R	37 Navigation	Output Tests	
Audi A4	2008-2018	8R	37 Navigation	Specia Functions	
Audi A4	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	
Audi A4	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A4	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi A4	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi A4	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi A4	2008-2018	8R	3D Special Function	Read Fault Codes	
Audi A4	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi A4	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi A4	2008-2018	8R	3D Special Function	Output Tests	
Audi A4	2008-2018	8R	3D Special Function	Specia Functions	
Audi A4	2008-2018	8R	40 Air Compressor	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi A4	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi A4	2008-2018	8R	40 Air Compressor	Output Tests	
Audi A4	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi A4	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	
Audi A4	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi A4	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi A4	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi A4	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi A4	2008-2018	8R	44 Steering Assistance	Read Fault Codes	
Audi A4	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi A4	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi A4	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi A4	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi A4	2008-2018	8R	46 Central Control Module	Read Fault Codes	
Audi A4	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi A4	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi A4	2008-2018	8R	46 Central Control Module	Output Tests	
Audi A4	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi A4	2008-2018	8R	47 Soundsystem	Read Fault Codes	
Audi A4	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi A4	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi A4	2008-2018	8R	47 Soundsystem	Output Tests	
Audi A4	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi A4	2008-2018	8R	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi A4	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi A4	2008-2018	8R	51 Electric Drive	Output Tests	
Audi A4	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi A4	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	
Audi A4	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A4	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi A4	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi A4	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi A4	2008-2018	8R	53 Parking Brake	Read Fault Codes	
Audi A4	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi A4	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi A4	2008-2018	8R	53 Parking Brake	Output Tests	
Audi A4	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi A4	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	
Audi A4	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi A4	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi A4	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi A4	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi A4	2008-2018	8R	56 Radio	Read Fault Codes	
Audi A4	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi A4	2008-2018	8R	56 Radio	Measuring Blocks	
Audi A4	2008-2018	8R	56 Radio	Output Tests	
Audi A4	2008-2018	8R	56 Radio	Specia Functions	
Audi A4	2008-2018	8R	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi A4	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi A4	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi A4	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi A4	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	
Audi A4	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi A4	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi A4	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi A4	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi A4	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A4	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A4	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A4	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi A4	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi A4	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	
Audi A4	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi A4	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi A4	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi A4	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi A4	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A4	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A4	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A4	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi A4	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi A4	2008-2018	8R	67 Voice Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A4	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi A4	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi A4	2008-2018	8R	67 Voice Control	Output Tests	
Audi A4	2008-2018	8R	67 Voice Control	Specia Functions	
Audi A4	2008-2018	8R	69 Trailer Function	Read Fault Codes	
Audi A4	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi A4	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi A4	2008-2018	8R	69 Trailer Function	Output Tests	
Audi A4	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi A4	2008-2018	8R	6C Rear Camera	Read Fault Codes	
Audi A4	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi A4	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi A4	2008-2018	8R	6C Rear Camera	Output Tests	
Audi A4	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi A4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A4	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	
Audi A4	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi A4	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi A4	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi A4	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi A4	2008-2018	8R	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A4	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi A4	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi A4	2008-2018	8R	77 Telephone	Output Tests	
Audi A4	2008-2018	8R	77 Telephone	Specia Functions	
Audi A4	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	
Audi A4	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi A4	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi A4	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi A4	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi A4	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	
Audi A4	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A4	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi A4	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi A4	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi A4	2008-2018	8R	AC Reductant Control	Read Fault Codes	
Audi A4	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi A4	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi A4	2008-2018	8R	AC Reductant Control	Output Tests	
Audi A4	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi A4	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A4	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A4	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A4	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi A4	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi S4	2008-2018	8R	01 Engine Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi S4	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi S4	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi S4	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi S4	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	
Audi S4	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi S4	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi S4	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi S4	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi S4	2008-2018	8R	03 Brake Electronics	Read Fault Codes	
Audi S4	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi S4	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi S4	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi S4	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi S4	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	
Audi S4	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi S4	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi S4	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi S4	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi S4	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	
Audi S4	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S4	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi S4	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi S4	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi S4	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi S4	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi S4	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi S4	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi S4	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	
Audi S4	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi S4	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi S4	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi S4	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi S4	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S4	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S4	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S4	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi S4	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi S4	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	
Audi S4	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi S4	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi S4	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi S4	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi S4	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	
Audi S4	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi S4	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi S4	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi S4	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi S4	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi S4	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi S4	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi S4	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi S4	2008-2018	8R	13 Distance Control	Read Fault Codes	
Audi S4	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi S4	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi S4	2008-2018	8R	13 Distance Control	Output Tests	
Audi S4	2008-2018	8R	13 Distance Control	Specia Functions	
Audi S4	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	
Audi S4	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S4	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi S4	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi S4	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi S4	2008-2018	8R	15 Airbags	Read Fault Codes	
Audi S4	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi S4	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi S4	2008-2018	8R	15 Airbags	Output Tests	
Audi S4	2008-2018	8R	15 Airbags	Specia Functions	
Audi S4	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	
Audi S4	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S4	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi S4	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi S4	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi S4	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi S4	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi S4	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi S4	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi S4	2008-2018	8R	18 Aux Heating	Read Fault Codes	
Audi S4	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi S4	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi S4	2008-2018	8R	18 Aux Heating	Output Tests	
Audi S4	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi S4	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	
Audi S4	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi S4	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi S4	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi S4	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi S4	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	
Audi S4	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi S4	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi S4	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi S4	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi S4	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	
Audi S4	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi S4	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi S4	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi S4	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi S4	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi S4	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi S4	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi S4	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi S4	2008-2018	8R	22 4WD Electronics	Read Fault Codes	
Audi S4	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi S4	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi S4	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi S4	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi S4	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	
Audi S4	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi S4	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi S4	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi S4	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi S4	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	
Audi S4	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi S4	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi S4	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi S4	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi S4	2008-2018	8R	30 Special Function 2	Read Fault Codes	
Audi S4	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi S4	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi S4	2008-2018	8R	30 Special Function 2	Output Tests	
Audi S4	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi S4	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S4	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S4	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi S4	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi S4	2008-2018	8R	37 Navigation	Read Fault Codes	
Audi S4	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi S4	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi S4	2008-2018	8R	37 Navigation	Output Tests	
Audi S4	2008-2018	8R	37 Navigation	Specia Functions	
Audi S4	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	
Audi S4	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S4	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi S4	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi S4	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi S4	2008-2018	8R	3D Special Function	Read Fault Codes	
Audi S4	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi S4	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi S4	2008-2018	8R	3D Special Function	Output Tests	
Audi S4	2008-2018	8R	3D Special Function	Specia Functions	
Audi S4	2008-2018	8R	40 Air Compressor	Read Fault Codes	
Audi S4	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi S4	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi S4	2008-2018	8R	40 Air Compressor	Output Tests	
Audi S4	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi S4	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi S4	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi S4	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi S4	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi S4	2008-2018	8R	44 Steering Assistance	Read Fault Codes	
Audi S4	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi S4	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi S4	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi S4	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi S4	2008-2018	8R	46 Central Control Module	Read Fault Codes	
Audi S4	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi S4	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi S4	2008-2018	8R	46 Central Control Module	Output Tests	
Audi S4	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi S4	2008-2018	8R	47 Soundsystem	Read Fault Codes	
Audi S4	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi S4	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi S4	2008-2018	8R	47 Soundsystem	Output Tests	
Audi S4	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi S4	2008-2018	8R	51 Electric Drive	Read Fault Codes	
Audi S4	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi S4	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi S4	2008-2018	8R	51 Electric Drive	Output Tests	
Audi S4	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi S4	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S4	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi S4	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi S4	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi S4	2008-2018	8R	53 Parking Brake	Read Fault Codes	
Audi S4	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi S4	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi S4	2008-2018	8R	53 Parking Brake	Output Tests	
Audi S4	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi S4	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	
Audi S4	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi S4	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi S4	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi S4	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi S4	2008-2018	8R	56 Radio	Read Fault Codes	
Audi S4	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi S4	2008-2018	8R	56 Radio	Measuring Blocks	
Audi S4	2008-2018	8R	56 Radio	Output Tests	
Audi S4	2008-2018	8R	56 Radio	Specia Functions	
Audi S4	2008-2018	8R	57 TV-Tuner	Read Fault Codes	
Audi S4	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi S4	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi S4	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi S4	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi S4	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi S4	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi S4	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi S4	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi S4	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S4	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S4	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S4	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi S4	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi S4	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	
Audi S4	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi S4	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi S4	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi S4	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi S4	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi S4	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S4	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S4	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi S4	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi S4	2008-2018	8R	67 Voice Control	Read Fault Codes	
Audi S4	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi S4	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi S4	2008-2018	8R	67 Voice Control	Output Tests	
Audi S4	2008-2018	8R	67 Voice Control	Specia Functions	
Audi S4	2008-2018	8R	69 Trailer Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi S4	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi S4	2008-2018	8R	69 Trailer Function	Output Tests	
Audi S4	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi S4	2008-2018	8R	6C Rear Camera	Read Fault Codes	
Audi S4	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi S4	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi S4	2008-2018	8R	6C Rear Camera	Output Tests	
Audi S4	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi S4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S4	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	
Audi S4	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi S4	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi S4	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi S4	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi S4	2008-2018	8R	77 Telephone	Read Fault Codes	
Audi S4	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi S4	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi S4	2008-2018	8R	77 Telephone	Output Tests	
Audi S4	2008-2018	8R	77 Telephone	Specia Functions	
Audi S4	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S4	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi S4	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi S4	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi S4	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi S4	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	
Audi S4	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S4	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi S4	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi S4	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi S4	2008-2018	8R	AC Reductant Control	Read Fault Codes	
Audi S4	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi S4	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi S4	2008-2018	8R	AC Reductant Control	Output Tests	
Audi S4	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi S4	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	
Audi S4	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi S4	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi S4	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi S4	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi RS4	2008-2018	8R	01 Engine Electronics	Read Fault Codes	
Audi RS4	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi RS4	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi RS4	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi RS4	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi RS4	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi RS4	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi RS4	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi RS4	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi RS4	2008-2018	8R	03 Brake Electronics	Read Fault Codes	
Audi RS4	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi RS4	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi RS4	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi RS4	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi RS4	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	
Audi RS4	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi RS4	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi RS4	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi RS4	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi RS4	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	
Audi RS4	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi RS4	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi RS4	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi RS4	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi RS4	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	
Audi RS4	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi RS4	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi RS4	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi RS4	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi RS4	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS4	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi RS4	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi RS4	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi RS4	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi RS4	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi RS4	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi RS4	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi RS4	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi RS4	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi RS4	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	
Audi RS4	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi RS4	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi RS4	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi RS4	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi RS4	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	
Audi RS4	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi RS4	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi RS4	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi RS4	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi RS4	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	
Audi RS4	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi RS4	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi RS4	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi RS4	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi RS4	2008-2018	8R	13 Distance Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi RS4	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi RS4	2008-2018	8R	13 Distance Control	Output Tests	
Audi RS4	2008-2018	8R	13 Distance Control	Specia Functions	
Audi RS4	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	
Audi RS4	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi RS4	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi RS4	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi RS4	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi RS4	2008-2018	8R	15 Airbags	Read Fault Codes	
Audi RS4	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi RS4	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi RS4	2008-2018	8R	15 Airbags	Output Tests	
Audi RS4	2008-2018	8R	15 Airbags	Specia Functions	
Audi RS4	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	
Audi RS4	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi RS4	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi RS4	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi RS4	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi RS4	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	
Audi RS4	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi RS4	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi RS4	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi RS4	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi RS4	2008-2018	8R	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi RS4	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi RS4	2008-2018	8R	18 Aux Heating	Output Tests	
Audi RS4	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi RS4	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	
Audi RS4	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi RS4	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi RS4	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi RS4	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi RS4	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	
Audi RS4	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi RS4	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi RS4	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi RS4	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi RS4	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	
Audi RS4	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi RS4	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi RS4	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi RS4	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi RS4	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	
Audi RS4	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi RS4	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi RS4	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi RS4	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi RS4	2008-2018	8R	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi RS4	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi RS4	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi RS4	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi RS4	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	
Audi RS4	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi RS4	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi RS4	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi RS4	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi RS4	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	
Audi RS4	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi RS4	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi RS4	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi RS4	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi RS4	2008-2018	8R	30 Special Function 2	Read Fault Codes	
Audi RS4	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi RS4	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi RS4	2008-2018	8R	30 Special Function 2	Output Tests	
Audi RS4	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi RS4	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi RS4	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi RS4	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi RS4	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi RS4	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi RS4	2008-2018	8R	37 Navigation	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi RS4	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi RS4	2008-2018	8R	37 Navigation	Output Tests	
Audi RS4	2008-2018	8R	37 Navigation	Specia Functions	
Audi RS4	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	
Audi RS4	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi RS4	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi RS4	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi RS4	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi RS4	2008-2018	8R	3D Special Function	Read Fault Codes	
Audi RS4	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi RS4	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi RS4	2008-2018	8R	3D Special Function	Output Tests	
Audi RS4	2008-2018	8R	3D Special Function	Specia Functions	
Audi RS4	2008-2018	8R	40 Air Compressor	Read Fault Codes	
Audi RS4	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi RS4	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi RS4	2008-2018	8R	40 Air Compressor	Output Tests	
Audi RS4	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi RS4	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	
Audi RS4	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi RS4	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi RS4	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi RS4	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi RS4	2008-2018	8R	44 Steering Assistance	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi RS4	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi RS4	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi RS4	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi RS4	2008-2018	8R	46 Central Control Module	Read Fault Codes	
Audi RS4	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi RS4	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi RS4	2008-2018	8R	46 Central Control Module	Output Tests	
Audi RS4	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi RS4	2008-2018	8R	47 Soundsystem	Read Fault Codes	
Audi RS4	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi RS4	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi RS4	2008-2018	8R	47 Soundsystem	Output Tests	
Audi RS4	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi RS4	2008-2018	8R	51 Electric Drive	Read Fault Codes	
Audi RS4	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi RS4	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi RS4	2008-2018	8R	51 Electric Drive	Output Tests	
Audi RS4	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi RS4	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	
Audi RS4	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi RS4	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi RS4	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi RS4	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi RS4	2008-2018	8R	53 Parking Brake	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi RS4	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi RS4	2008-2018	8R	53 Parking Brake	Output Tests	
Audi RS4	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi RS4	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	
Audi RS4	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi RS4	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi RS4	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi RS4	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi RS4	2008-2018	8R	56 Radio	Read Fault Codes	
Audi RS4	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi RS4	2008-2018	8R	56 Radio	Measuring Blocks	
Audi RS4	2008-2018	8R	56 Radio	Output Tests	
Audi RS4	2008-2018	8R	56 Radio	Specia Functions	
Audi RS4	2008-2018	8R	57 TV-Tuner	Read Fault Codes	
Audi RS4	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi RS4	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi RS4	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi RS4	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi RS4	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	
Audi RS4	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi RS4	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi RS4	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi RS4	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi RS4	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS4	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi RS4	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi RS4	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi RS4	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi RS4	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	
Audi RS4	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi RS4	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi RS4	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi RS4	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi RS4	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi RS4	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi RS4	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi RS4	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi RS4	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi RS4	2008-2018	8R	67 Voice Control	Read Fault Codes	
Audi RS4	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi RS4	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi RS4	2008-2018	8R	67 Voice Control	Output Tests	
Audi RS4	2008-2018	8R	67 Voice Control	Specia Functions	
Audi RS4	2008-2018	8R	69 Trailer Function	Read Fault Codes	
Audi RS4	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi RS4	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi RS4	2008-2018	8R	69 Trailer Function	Output Tests	
Audi RS4	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi RS4	2008-2018	8R	6C Rear Camera	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS4	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi RS4	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi RS4	2008-2018	8R	6C Rear Camera	Output Tests	
Audi RS4	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi RS4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi RS4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi RS4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi RS4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi RS4	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi RS4	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	
Audi RS4	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi RS4	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi RS4	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi RS4	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi RS4	2008-2018	8R	77 Telephone	Read Fault Codes	
Audi RS4	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi RS4	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi RS4	2008-2018	8R	77 Telephone	Output Tests	
Audi RS4	2008-2018	8R	77 Telephone	Specia Functions	
Audi RS4	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	
Audi RS4	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi RS4	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi RS4	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi RS4	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi RS4	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS4	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi RS4	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi RS4	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi RS4	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi RS4	2008-2018	8R	AC Reductant Control	Read Fault Codes	
Audi RS4	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi RS4	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi RS4	2008-2018	8R	AC Reductant Control	Output Tests	
Audi RS4	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi RS4	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	
Audi RS4	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi RS4	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi RS4	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi RS4	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi A5	2008-2018	8R	01 Engine Electronics	Read Fault Codes	
Audi A5	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi A5	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi A5	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi A5	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi A5	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	
Audi A5	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi A5	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi A5	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi A5	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi A5	2008-2018	8R	03 Brake Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi A5	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi A5	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi A5	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi A5	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	
Audi A5	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi A5	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi A5	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi A5	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi A5	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	
Audi A5	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A5	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi A5	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi A5	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi A5	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	
Audi A5	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi A5	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi A5	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi A5	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi A5	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	
Audi A5	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi A5	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi A5	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi A5	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi A5	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A5	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A5	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi A5	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi A5	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	
Audi A5	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi A5	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi A5	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi A5	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi A5	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	
Audi A5	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi A5	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi A5	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi A5	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi A5	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	
Audi A5	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi A5	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi A5	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi A5	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi A5	2008-2018	8R	13 Distance Control	Read Fault Codes	
Audi A5	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi A5	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi A5	2008-2018	8R	13 Distance Control	Output Tests	
Audi A5	2008-2018	8R	13 Distance Control	Specia Functions	
Audi A5	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A5	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi A5	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi A5	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi A5	2008-2018	8R	15 Airbags	Read Fault Codes	
Audi A5	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi A5	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi A5	2008-2018	8R	15 Airbags	Output Tests	
Audi A5	2008-2018	8R	15 Airbags	Specia Functions	
Audi A5	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	
Audi A5	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A5	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi A5	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi A5	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi A5	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	
Audi A5	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi A5	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi A5	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi A5	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi A5	2008-2018	8R	18 Aux Heating	Read Fault Codes	
Audi A5	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi A5	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi A5	2008-2018	8R	18 Aux Heating	Output Tests	
Audi A5	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi A5	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi A5	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi A5	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi A5	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi A5	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	
Audi A5	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi A5	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi A5	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi A5	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi A5	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	
Audi A5	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi A5	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi A5	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi A5	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi A5	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	
Audi A5	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi A5	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi A5	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi A5	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi A5	2008-2018	8R	22 4WD Electronics	Read Fault Codes	
Audi A5	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi A5	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi A5	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi A5	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi A5	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi A5	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi A5	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi A5	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi A5	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	
Audi A5	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi A5	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi A5	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi A5	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi A5	2008-2018	8R	30 Special Function 2	Read Fault Codes	
Audi A5	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi A5	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi A5	2008-2018	8R	30 Special Function 2	Output Tests	
Audi A5	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi A5	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A5	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A5	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A5	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi A5	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi A5	2008-2018	8R	37 Navigation	Read Fault Codes	
Audi A5	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi A5	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi A5	2008-2018	8R	37 Navigation	Output Tests	
Audi A5	2008-2018	8R	37 Navigation	Specia Functions	
Audi A5	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A5	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi A5	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi A5	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi A5	2008-2018	8R	3D Special Function	Read Fault Codes	
Audi A5	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi A5	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi A5	2008-2018	8R	3D Special Function	Output Tests	
Audi A5	2008-2018	8R	3D Special Function	Specia Functions	
Audi A5	2008-2018	8R	40 Air Compressor	Read Fault Codes	
Audi A5	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi A5	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi A5	2008-2018	8R	40 Air Compressor	Output Tests	
Audi A5	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi A5	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	
Audi A5	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi A5	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi A5	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi A5	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi A5	2008-2018	8R	44 Steering Assistance	Read Fault Codes	
Audi A5	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi A5	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi A5	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi A5	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi A5	2008-2018	8R	46 Central Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi A5	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi A5	2008-2018	8R	46 Central Control Module	Output Tests	
Audi A5	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi A5	2008-2018	8R	47 Soundsystem	Read Fault Codes	
Audi A5	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi A5	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi A5	2008-2018	8R	47 Soundsystem	Output Tests	
Audi A5	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi A5	2008-2018	8R	51 Electric Drive	Read Fault Codes	
Audi A5	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi A5	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi A5	2008-2018	8R	51 Electric Drive	Output Tests	
Audi A5	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi A5	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	
Audi A5	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A5	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi A5	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi A5	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi A5	2008-2018	8R	53 Parking Brake	Read Fault Codes	
Audi A5	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi A5	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi A5	2008-2018	8R	53 Parking Brake	Output Tests	
Audi A5	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi A5	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi A5	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi A5	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi A5	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi A5	2008-2018	8R	56 Radio	Read Fault Codes	
Audi A5	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi A5	2008-2018	8R	56 Radio	Measuring Blocks	
Audi A5	2008-2018	8R	56 Radio	Output Tests	
Audi A5	2008-2018	8R	56 Radio	Specia Functions	
Audi A5	2008-2018	8R	57 TV-Tuner	Read Fault Codes	
Audi A5	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi A5	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi A5	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi A5	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi A5	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	
Audi A5	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi A5	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi A5	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi A5	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi A5	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A5	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A5	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A5	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi A5	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi A5	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi A5	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi A5	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi A5	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi A5	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A5	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A5	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A5	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi A5	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi A5	2008-2018	8R	67 Voice Control	Read Fault Codes	
Audi A5	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi A5	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi A5	2008-2018	8R	67 Voice Control	Output Tests	
Audi A5	2008-2018	8R	67 Voice Control	Specia Functions	
Audi A5	2008-2018	8R	69 Trailer Function	Read Fault Codes	
Audi A5	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi A5	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi A5	2008-2018	8R	69 Trailer Function	Output Tests	
Audi A5	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi A5	2008-2018	8R	6C Rear Camera	Read Fault Codes	
Audi A5	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi A5	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi A5	2008-2018	8R	6C Rear Camera	Output Tests	
Audi A5	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi A5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A5	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	
Audi A5	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi A5	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi A5	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi A5	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi A5	2008-2018	8R	77 Telephone	Read Fault Codes	
Audi A5	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi A5	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi A5	2008-2018	8R	77 Telephone	Output Tests	
Audi A5	2008-2018	8R	77 Telephone	Specia Functions	
Audi A5	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	
Audi A5	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi A5	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi A5	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi A5	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi A5	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	
Audi A5	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A5	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi A5	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi A5	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi A5	2008-2018	8R	AC Reductant Control	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A5	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi A5	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi A5	2008-2018	8R	AC Reductant Control	Output Tests	
Audi A5	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi A5	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A5	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A5	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A5	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi A5	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi S5	2008-2018	8R	01 Engine Electronics	Read Fault Codes	
Audi S5	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi S5	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi S5	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi S5	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi S5	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	
Audi S5	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi S5	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi S5	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi S5	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi S5	2008-2018	8R	03 Brake Electronics	Read Fault Codes	
Audi S5	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi S5	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi S5	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi S5	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi S5	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi S5	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi S5	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi S5	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi S5	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	
Audi S5	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S5	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi S5	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi S5	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi S5	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	
Audi S5	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi S5	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi S5	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi S5	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi S5	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	
Audi S5	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi S5	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi S5	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi S5	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi S5	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S5	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S5	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S5	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi S5	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi S5	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S5	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi S5	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi S5	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi S5	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi S5	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	
Audi S5	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi S5	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi S5	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi S5	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi S5	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	
Audi S5	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi S5	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi S5	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi S5	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi S5	2008-2018	8R	13 Distance Control	Read Fault Codes	
Audi S5	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi S5	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi S5	2008-2018	8R	13 Distance Control	Output Tests	
Audi S5	2008-2018	8R	13 Distance Control	Specia Functions	
Audi S5	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	
Audi S5	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S5	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi S5	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi S5	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi S5	2008-2018	8R	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi S5	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi S5	2008-2018	8R	15 Airbags	Output Tests	
Audi S5	2008-2018	8R	15 Airbags	Specia Functions	
Audi S5	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	
Audi S5	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S5	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi S5	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi S5	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi S5	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	
Audi S5	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi S5	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi S5	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi S5	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi S5	2008-2018	8R	18 Aux Heating	Read Fault Codes	
Audi S5	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi S5	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi S5	2008-2018	8R	18 Aux Heating	Output Tests	
Audi S5	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi S5	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	
Audi S5	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi S5	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi S5	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi S5	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi S5	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S5	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi S5	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi S5	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi S5	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi S5	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	
Audi S5	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi S5	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi S5	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi S5	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi S5	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	
Audi S5	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi S5	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi S5	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi S5	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi S5	2008-2018	8R	22 4WD Electronics	Read Fault Codes	
Audi S5	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi S5	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi S5	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi S5	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi S5	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	
Audi S5	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi S5	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi S5	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi S5	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi S5	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi S5	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi S5	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi S5	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi S5	2008-2018	8R	30 Special Function 2	Read Fault Codes	
Audi S5	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi S5	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi S5	2008-2018	8R	30 Special Function 2	Output Tests	
Audi S5	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi S5	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi S5	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S5	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S5	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi S5	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi S5	2008-2018	8R	37 Navigation	Read Fault Codes	
Audi S5	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi S5	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi S5	2008-2018	8R	37 Navigation	Output Tests	
Audi S5	2008-2018	8R	37 Navigation	Specia Functions	
Audi S5	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	
Audi S5	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S5	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi S5	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi S5	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi S5	2008-2018	8R	3D Special Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi S5	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi S5	2008-2018	8R	3D Special Function	Output Tests	
Audi S5	2008-2018	8R	3D Special Function	Specia Functions	
Audi S5	2008-2018	8R	40 Air Compressor	Read Fault Codes	
Audi S5	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi S5	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi S5	2008-2018	8R	40 Air Compressor	Output Tests	
Audi S5	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi S5	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	
Audi S5	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi S5	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi S5	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi S5	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi S5	2008-2018	8R	44 Steering Assistance	Read Fault Codes	
Audi S5	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi S5	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi S5	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi S5	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi S5	2008-2018	8R	46 Central Control Module	Read Fault Codes	
Audi S5	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi S5	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi S5	2008-2018	8R	46 Central Control Module	Output Tests	
Audi S5	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi S5	2008-2018	8R	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi S5	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi S5	2008-2018	8R	47 Soundsystem	Output Tests	
Audi S5	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi S5	2008-2018	8R	51 Electric Drive	Read Fault Codes	
Audi S5	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi S5	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi S5	2008-2018	8R	51 Electric Drive	Output Tests	
Audi S5	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi S5	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	
Audi S5	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S5	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi S5	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi S5	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi S5	2008-2018	8R	53 Parking Brake	Read Fault Codes	
Audi S5	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi S5	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi S5	2008-2018	8R	53 Parking Brake	Output Tests	
Audi S5	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi S5	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	
Audi S5	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi S5	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi S5	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi S5	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi S5	2008-2018	8R	56 Radio	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi S5	2008-2018	8R	56 Radio	Measuring Blocks	
Audi S5	2008-2018	8R	56 Radio	Output Tests	
Audi S5	2008-2018	8R	56 Radio	Specia Functions	
Audi S5	2008-2018	8R	57 TV-Tuner	Read Fault Codes	
Audi S5	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi S5	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi S5	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi S5	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi S5	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	
Audi S5	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi S5	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi S5	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi S5	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi S5	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S5	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S5	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S5	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi S5	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi S5	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	
Audi S5	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi S5	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi S5	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi S5	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi S5	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S5	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S5	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi S5	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi S5	2008-2018	8R	67 Voice Control	Read Fault Codes	
Audi S5	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi S5	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi S5	2008-2018	8R	67 Voice Control	Output Tests	
Audi S5	2008-2018	8R	67 Voice Control	Specia Functions	
Audi S5	2008-2018	8R	69 Trailer Function	Read Fault Codes	
Audi S5	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi S5	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi S5	2008-2018	8R	69 Trailer Function	Output Tests	
Audi S5	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi S5	2008-2018	8R	6C Rear Camera	Read Fault Codes	
Audi S5	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi S5	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi S5	2008-2018	8R	6C Rear Camera	Output Tests	
Audi S5	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi S5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S5	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi S5	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi S5	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi S5	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi S5	2008-2018	8R	77 Telephone	Read Fault Codes	
Audi S5	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi S5	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi S5	2008-2018	8R	77 Telephone	Output Tests	
Audi S5	2008-2018	8R	77 Telephone	Specia Functions	
Audi S5	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	
Audi S5	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi S5	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi S5	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi S5	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi S5	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	
Audi S5	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S5	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi S5	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi S5	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi S5	2008-2018	8R	AC Reductant Control	Read Fault Codes	
Audi S5	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi S5	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi S5	2008-2018	8R	AC Reductant Control	Output Tests	
Audi S5	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi S5	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S5	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi S5	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi S5	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi S5	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi RS5	2008-2018	8R	01 Engine Electronics	Read Fault Codes	
Audi RS5	2008-2018	8R	01 Engine Electronics	Clear Fault Codes	
Audi RS5	2008-2018	8R	01 Engine Electronics	Measuring Blocks	
Audi RS5	2008-2018	8R	01 Engine Electronics	Output Tests	
Audi RS5	2008-2018	8R	01 Engine Electronics	Specia Functions	
Audi RS5	2008-2018	8R	02 Transmission Electronics	Read Fault Codes	
Audi RS5	2008-2018	8R	02 Transmission Electronics	Clear Fault Codes	
Audi RS5	2008-2018	8R	02 Transmission Electronics	Measuring Blocks	
Audi RS5	2008-2018	8R	02 Transmission Electronics	Output Tests	
Audi RS5	2008-2018	8R	02 Transmission Electronics	Specia Functions	
Audi RS5	2008-2018	8R	03 Brake Electronics	Read Fault Codes	
Audi RS5	2008-2018	8R	03 Brake Electronics	Clear Fault Codes	
Audi RS5	2008-2018	8R	03 Brake Electronics	Measuring Blocks	
Audi RS5	2008-2018	8R	03 Brake Electronics	Output Tests	
Audi RS5	2008-2018	8R	03 Brake Electronics	Specia Functions	
Audi RS5	2008-2018	8R	05 Access & Permissi.	Read Fault Codes	
Audi RS5	2008-2018	8R	05 Access & Permissi.	Clear Fault Codes	
Audi RS5	2008-2018	8R	05 Access & Permissi.	Measuring Blocks	
Audi RS5	2008-2018	8R	05 Access & Permissi.	Output Tests	
Audi RS5	2008-2018	8R	05 Access & Permissi.	Specia Functions	
Audi RS5	2008-2018	8R	06 Passene. Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS5	2008-2018	8R	06 Passene. Seat Adj.	Clear Fault Codes	
Audi RS5	2008-2018	8R	06 Passene. Seat Adj.	Measuring Blocks	
Audi RS5	2008-2018	8R	06 Passene. Seat Adj.	Output Tests	
Audi RS5	2008-2018	8R	06 Passene. Seat Adj.	Specia Functions	
Audi RS5	2008-2018	8R	07 Display-/Cntl Unit	Read Fault Codes	
Audi RS5	2008-2018	8R	07 Display-/Cntl Unit	Clear Fault Codes	
Audi RS5	2008-2018	8R	07 Display-/Cntl Unit	Measuring Blocks	
Audi RS5	2008-2018	8R	07 Display-/Cntl Unit	Output Tests	
Audi RS5	2008-2018	8R	07 Display-/Cntl Unit	Specia Functions	
Audi RS5	2008-2018	8R	08 AC/Heating Electronics	Read Fault Codes	
Audi RS5	2008-2018	8R	08 AC/Heating Electronics	Clear Fault Codes	
Audi RS5	2008-2018	8R	08 AC/Heating Electronics	Measuring Blocks	
Audi RS5	2008-2018	8R	08 AC/Heating Electronics	Output Tests	
Audi RS5	2008-2018	8R	08 AC/Heating Electronics	Specia Functions	
Audi RS5	2008-2018	8R	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi RS5	2008-2018	8R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi RS5	2008-2018	8R	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi RS5	2008-2018	8R	09 Electronic Ctrl Electronics	Output Tests	
Audi RS5	2008-2018	8R	09 Electronic Ctrl Electronics	Specia Functions	
Audi RS5	2008-2018	8R	0E Media Player Position 1	Read Fault Codes	
Audi RS5	2008-2018	8R	0E Media Player Position 1	Clear Fault Codes	
Audi RS5	2008-2018	8R	0E Media Player Position 1	Measuring Blocks	
Audi RS5	2008-2018	8R	0E Media Player Position 1	Output Tests	
Audi RS5	2008-2018	8R	0E Media Player Position 1	Specia Functions	
Audi RS5	2008-2018	8R	0F Radio Tuner-Digital	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5	2008-2018	8R	0F Radio Tuner-Digital	Clear Fault Codes	
Audi RS5	2008-2018	8R	0F Radio Tuner-Digital	Measuring Blocks	
Audi RS5	2008-2018	8R	0F Radio Tuner-Digital	Output Tests	
Audi RS5	2008-2018	8R	0F Radio Tuner-Digital	Specia Functions	
Audi RS5	2008-2018	8R	10 Parking Assist System 2	Read Fault Codes	
Audi RS5	2008-2018	8R	10 Parking Assist System 2	Clear Fault Codes	
Audi RS5	2008-2018	8R	10 Parking Assist System 2	Measuring Blocks	
Audi RS5	2008-2018	8R	10 Parking Assist System 2	Output Tests	
Audi RS5	2008-2018	8R	10 Parking Assist System 2	Specia Functions	
Audi RS5	2008-2018	8R	13 Distance Control	Read Fault Codes	
Audi RS5	2008-2018	8R	13 Distance Control	Clear Fault Codes	
Audi RS5	2008-2018	8R	13 Distance Control	Measuring Blocks	
Audi RS5	2008-2018	8R	13 Distance Control	Output Tests	
Audi RS5	2008-2018	8R	13 Distance Control	Specia Functions	
Audi RS5	2008-2018	8R	14 Wheel Damping Electronics	Read Fault Codes	
Audi RS5	2008-2018	8R	14 Wheel Damping Electronics	Clear Fault Codes	
Audi RS5	2008-2018	8R	14 Wheel Damping Electronics	Measuring Blocks	
Audi RS5	2008-2018	8R	14 Wheel Damping Electronics	Output Tests	
Audi RS5	2008-2018	8R	14 Wheel Damping Electronics	Specia Functions	
Audi RS5	2008-2018	8R	15 Airbags	Read Fault Codes	
Audi RS5	2008-2018	8R	15 Airbags	Clear Fault Codes	
Audi RS5	2008-2018	8R	15 Airbags	Measuring Blocks	
Audi RS5	2008-2018	8R	15 Airbags	Output Tests	
Audi RS5	2008-2018	8R	15 Airbags	Specia Functions	
Audi RS5	2008-2018	8R	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5	2008-2018	8R	16 Steering Wheel Electronics	Clear Fault Codes	
Audi RS5	2008-2018	8R	16 Steering Wheel Electronics	Measuring Blocks	
Audi RS5	2008-2018	8R	16 Steering Wheel Electronics	Output Tests	
Audi RS5	2008-2018	8R	16 Steering Wheel Electronics	Specia Functions	
Audi RS5	2008-2018	8R	17 Instrument Cluster	Read Fault Codes	
Audi RS5	2008-2018	8R	17 Instrument Cluster	Clear Fault Codes	
Audi RS5	2008-2018	8R	17 Instrument Cluster	Measuring Blocks	
Audi RS5	2008-2018	8R	17 Instrument Cluster	Output Tests	
Audi RS5	2008-2018	8R	17 Instrument Cluster	Specia Functions	
Audi RS5	2008-2018	8R	18 Aux Heating	Read Fault Codes	
Audi RS5	2008-2018	8R	18 Aux Heating	Clear Fault Codes	
Audi RS5	2008-2018	8R	18 Aux Heating	Measuring Blocks	
Audi RS5	2008-2018	8R	18 Aux Heating	Output Tests	
Audi RS5	2008-2018	8R	18 Aux Heating	Specia Functions	
Audi RS5	2008-2018	8R	19 Gateway Data Bus	Read Fault Codes	
Audi RS5	2008-2018	8R	19 Gateway Data Bus	Clear Fault Codes	
Audi RS5	2008-2018	8R	19 Gateway Data Bus	Measuring Blocks	
Audi RS5	2008-2018	8R	19 Gateway Data Bus	Output Tests	
Audi RS5	2008-2018	8R	19 Gateway Data Bus	Specia Functions	
Audi RS5	2008-2018	8R	1B Power-Assisted Steering	Read Fault Codes	
Audi RS5	2008-2018	8R	1B Power-Assisted Steering	Clear Fault Codes	
Audi RS5	2008-2018	8R	1B Power-Assisted Steering	Measuring Blocks	
Audi RS5	2008-2018	8R	1B Power-Assisted Steering	Output Tests	
Audi RS5	2008-2018	8R	1B Power-Assisted Steering	Specia Functions	
Audi RS5	2008-2018	8R	1E Media Player Position 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS5	2008-2018	8R	1E Media Player Position 2	Clear Fault Codes	
Audi RS5	2008-2018	8R	1E Media Player Position 2	Measuring Blocks	
Audi RS5	2008-2018	8R	1E Media Player Position 2	Output Tests	
Audi RS5	2008-2018	8R	1E Media Player Position 2	Specia Functions	
Audi RS5	2008-2018	8R	20 High Beam Assistance Device	Read Fault Codes	
Audi RS5	2008-2018	8R	20 High Beam Assistance Device	Clear Fault Codes	
Audi RS5	2008-2018	8R	20 High Beam Assistance Device	Measuring Blocks	
Audi RS5	2008-2018	8R	20 High Beam Assistance Device	Output Tests	
Audi RS5	2008-2018	8R	20 High Beam Assistance Device	Specia Functions	
Audi RS5	2008-2018	8R	22 4WD Electronics	Read Fault Codes	
Audi RS5	2008-2018	8R	22 4WD Electronics	Clear Fault Codes	
Audi RS5	2008-2018	8R	22 4WD Electronics	Measuring Blocks	
Audi RS5	2008-2018	8R	22 4WD Electronics	Output Tests	
Audi RS5	2008-2018	8R	22 4WD Electronics	Specia Functions	
Audi RS5	2008-2018	8R	26 Electric Roof Control	Read Fault Codes	
Audi RS5	2008-2018	8R	26 Electric Roof Control	Clear Fault Codes	
Audi RS5	2008-2018	8R	26 Electric Roof Control	Measuring Blocks	
Audi RS5	2008-2018	8R	26 Electric Roof Control	Output Tests	
Audi RS5	2008-2018	8R	26 Electric Roof Control	Specia Functions	
Audi RS5	2008-2018	8R	2E Media Player Position 3	Read Fault Codes	
Audi RS5	2008-2018	8R	2E Media Player Position 3	Clear Fault Codes	
Audi RS5	2008-2018	8R	2E Media Player Position 3	Measuring Blocks	
Audi RS5	2008-2018	8R	2E Media Player Position 3	Output Tests	
Audi RS5	2008-2018	8R	2E Media Player Position 3	Specia Functions	
Audi RS5	2008-2018	8R	30 Special Function 2	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5	2008-2018	8R	30 Special Function 2	Clear Fault Codes	
Audi RS5	2008-2018	8R	30 Special Function 2	Measuring Blocks	
Audi RS5	2008-2018	8R	30 Special Function 2	Output Tests	
Audi RS5	2008-2018	8R	30 Special Function 2	Specia Functions	
Audi RS5	2008-2018	8R	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi RS5	2008-2018	8R	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi RS5	2008-2018	8R	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi RS5	2008-2018	8R	36 Side of Driver Seat Adj.	Output Tests	
Audi RS5	2008-2018	8R	36 Side of Driver Seat Adj.	Specia Functions	
Audi RS5	2008-2018	8R	37 Navigation	Read Fault Codes	
Audi RS5	2008-2018	8R	37 Navigation	Clear Fault Codes	
Audi RS5	2008-2018	8R	37 Navigation	Measuring Blocks	
Audi RS5	2008-2018	8R	37 Navigation	Output Tests	
Audi RS5	2008-2018	8R	37 Navigation	Specia Functions	
Audi RS5	2008-2018	8R	3C Lane Departure Assistance System	Read Fault Codes	
Audi RS5	2008-2018	8R	3C Lane Departure Assistance System	Clear Fault Codes	
Audi RS5	2008-2018	8R	3C Lane Departure Assistance System	Measuring Blocks	
Audi RS5	2008-2018	8R	3C Lane Departure Assistance System	Output Tests	
Audi RS5	2008-2018	8R	3C Lane Departure Assistance System	Specia Functions	
Audi RS5	2008-2018	8R	3D Special Function	Read Fault Codes	
Audi RS5	2008-2018	8R	3D Special Function	Clear Fault Codes	
Audi RS5	2008-2018	8R	3D Special Function	Measuring Blocks	
Audi RS5	2008-2018	8R	3D Special Function	Output Tests	
Audi RS5	2008-2018	8R	3D Special Function	Specia Functions	
Audi RS5	2008-2018	8R	40 Air Compressor	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5	2008-2018	8R	40 Air Compressor	Clear Fault Codes	
Audi RS5	2008-2018	8R	40 Air Compressor	Measuring Blocks	
Audi RS5	2008-2018	8R	40 Air Compressor	Output Tests	
Audi RS5	2008-2018	8R	40 Air Compressor	Specia Functions	
Audi RS5	2008-2018	8R	42 Driver-Door Elect.	Read Fault Codes	
Audi RS5	2008-2018	8R	42 Driver-Door Elect.	Clear Fault Codes	
Audi RS5	2008-2018	8R	42 Driver-Door Elect.	Measuring Blocks	
Audi RS5	2008-2018	8R	42 Driver-Door Elect.	Output Tests	
Audi RS5	2008-2018	8R	42 Driver-Door Elect.	Specia Functions	
Audi RS5	2008-2018	8R	44 Steering Assistance	Read Fault Codes	
Audi RS5	2008-2018	8R	44 Steering Assistance	Clear Fault Codes	
Audi RS5	2008-2018	8R	44 Steering Assistance	Measuring Blocks	
Audi RS5	2008-2018	8R	44 Steering Assistance	Output Tests	
Audi RS5	2008-2018	8R	44 Steering Assistance	Specia Functions	
Audi RS5	2008-2018	8R	46 Central Control Module	Read Fault Codes	
Audi RS5	2008-2018	8R	46 Central Control Module	Clear Fault Codes	
Audi RS5	2008-2018	8R	46 Central Control Module	Measuring Blocks	
Audi RS5	2008-2018	8R	46 Central Control Module	Output Tests	
Audi RS5	2008-2018	8R	46 Central Control Module	Specia Functions	
Audi RS5	2008-2018	8R	47 Soundsystem	Read Fault Codes	
Audi RS5	2008-2018	8R	47 Soundsystem	Clear Fault Codes	
Audi RS5	2008-2018	8R	47 Soundsystem	Measuring Blocks	
Audi RS5	2008-2018	8R	47 Soundsystem	Output Tests	
Audi RS5	2008-2018	8R	47 Soundsystem	Specia Functions	
Audi RS5	2008-2018	8R	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5	2008-2018	8R	51 Electric Drive	Clear Fault Codes	
Audi RS5	2008-2018	8R	51 Electric Drive	Measuring Blocks	
Audi RS5	2008-2018	8R	51 Electric Drive	Output Tests	
Audi RS5	2008-2018	8R	51 Electric Drive	Specia Functions	
Audi RS5	2008-2018	8R	52 Passe.-Door Elect.	Read Fault Codes	
Audi RS5	2008-2018	8R	52 Passe.-Door Elect.	Clear Fault Codes	
Audi RS5	2008-2018	8R	52 Passe.-Door Elect.	Measuring Blocks	
Audi RS5	2008-2018	8R	52 Passe.-Door Elect.	Output Tests	
Audi RS5	2008-2018	8R	52 Passe.-Door Elect.	Specia Functions	
Audi RS5	2008-2018	8R	53 Parking Brake	Read Fault Codes	
Audi RS5	2008-2018	8R	53 Parking Brake	Clear Fault Codes	
Audi RS5	2008-2018	8R	53 Parking Brake	Measuring Blocks	
Audi RS5	2008-2018	8R	53 Parking Brake	Output Tests	
Audi RS5	2008-2018	8R	53 Parking Brake	Specia Functions	
Audi RS5	2008-2018	8R	55 Headlight Range Control	Read Fault Codes	
Audi RS5	2008-2018	8R	55 Headlight Range Control	Clear Fault Codes	
Audi RS5	2008-2018	8R	55 Headlight Range Control	Measuring Blocks	
Audi RS5	2008-2018	8R	55 Headlight Range Control	Output Tests	
Audi RS5	2008-2018	8R	55 Headlight Range Control	Specia Functions	
Audi RS5	2008-2018	8R	56 Radio	Read Fault Codes	
Audi RS5	2008-2018	8R	56 Radio	Clear Fault Codes	
Audi RS5	2008-2018	8R	56 Radio	Measuring Blocks	
Audi RS5	2008-2018	8R	56 Radio	Output Tests	
Audi RS5	2008-2018	8R	56 Radio	Specia Functions	
Audi RS5	2008-2018	8R	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5	2008-2018	8R	57 TV-Tuner	Clear Fault Codes	
Audi RS5	2008-2018	8R	57 TV-Tuner	Measuring Blocks	
Audi RS5	2008-2018	8R	57 TV-Tuner	Output Tests	
Audi RS5	2008-2018	8R	57 TV-Tuner	Specia Functions	
Audi RS5	2008-2018	8R	5C Lane Keeping Assistance System	Read Fault Codes	
Audi RS5	2008-2018	8R	5C Lane Keeping Assistance System	Clear Fault Codes	
Audi RS5	2008-2018	8R	5C Lane Keeping Assistance System	Measuring Blocks	
Audi RS5	2008-2018	8R	5C Lane Keeping Assistance System	Output Tests	
Audi RS5	2008-2018	8R	5C Lane Keeping Assistance System	Specia Functions	
Audi RS5	2008-2018	8R	5F Information Electronic Equipment 1	Read Fault Codes	
Audi RS5	2008-2018	8R	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi RS5	2008-2018	8R	5F Information Electronic Equipment 1	Measuring Blocks	
Audi RS5	2008-2018	8R	5F Information Electronic Equipment 1	Output Tests	
Audi RS5	2008-2018	8R	5F Information Electronic Equipment 1	Specia Functions	
Audi RS5	2008-2018	8R	62 LR-Door Electroni.	Read Fault Codes	
Audi RS5	2008-2018	8R	62 LR-Door Electroni.	Clear Fault Codes	
Audi RS5	2008-2018	8R	62 LR-Door Electroni.	Measuring Blocks	
Audi RS5	2008-2018	8R	62 LR-Door Electroni.	Output Tests	
Audi RS5	2008-2018	8R	62 LR-Door Electroni.	Specia Functions	
Audi RS5	2008-2018	8R	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi RS5	2008-2018	8R	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi RS5	2008-2018	8R	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi RS5	2008-2018	8R	65 Tyre Pressure Monitoring	Output Tests	
Audi RS5	2008-2018	8R	65 Tyre Pressure Monitoring	Specia Functions	
Audi RS5	2008-2018	8R	67 Voice Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5	2008-2018	8R	67 Voice Control	Clear Fault Codes	
Audi RS5	2008-2018	8R	67 Voice Control	Measuring Blocks	
Audi RS5	2008-2018	8R	67 Voice Control	Output Tests	
Audi RS5	2008-2018	8R	67 Voice Control	Specia Functions	
Audi RS5	2008-2018	8R	69 Trailer Function	Read Fault Codes	
Audi RS5	2008-2018	8R	69 Trailer Function	Clear Fault Codes	
Audi RS5	2008-2018	8R	69 Trailer Function	Measuring Blocks	
Audi RS5	2008-2018	8R	69 Trailer Function	Output Tests	
Audi RS5	2008-2018	8R	69 Trailer Function	Specia Functions	
Audi RS5	2008-2018	8R	6C Rear Camera	Read Fault Codes	
Audi RS5	2008-2018	8R	6C Rear Camera	Clear Fault Codes	
Audi RS5	2008-2018	8R	6C Rear Camera	Measuring Blocks	
Audi RS5	2008-2018	8R	6C Rear Camera	Output Tests	
Audi RS5	2008-2018	8R	6C Rear Camera	Specia Functions	
Audi RS5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi RS5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi RS5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi RS5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi RS5	2008-2018	8R	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi RS5	2008-2018	8R	72 RR-Door Electroni.	Read Fault Codes	
Audi RS5	2008-2018	8R	72 RR-Door Electroni.	Clear Fault Codes	
Audi RS5	2008-2018	8R	72 RR-Door Electroni.	Measuring Blocks	
Audi RS5	2008-2018	8R	72 RR-Door Electroni.	Output Tests	
Audi RS5	2008-2018	8R	72 RR-Door Electroni.	Specia Functions	
Audi RS5	2008-2018	8R	77 Telephone	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS5	2008-2018	8R	77 Telephone	Clear Fault Codes	
Audi RS5	2008-2018	8R	77 Telephone	Measuring Blocks	
Audi RS5	2008-2018	8R	77 Telephone	Output Tests	
Audi RS5	2008-2018	8R	77 Telephone	Specia Functions	
Audi RS5	2008-2018	8R	8C Hybrid Battery	Read Fault Codes	
Audi RS5	2008-2018	8R	8C Hybrid Battery	Clear Fault Codes	
Audi RS5	2008-2018	8R	8C Hybrid Battery	Measuring Blocks	
Audi RS5	2008-2018	8R	8C Hybrid Battery	Output Tests	
Audi RS5	2008-2018	8R	8C Hybrid Battery	Specia Functions	
Audi RS5	2008-2018	8R	A9 Struct.Borne Sound	Read Fault Codes	
Audi RS5	2008-2018	8R	A9 Struct.Borne Sound	Clear Fault Codes	
Audi RS5	2008-2018	8R	A9 Struct.Borne Sound	Measuring Blocks	
Audi RS5	2008-2018	8R	A9 Struct.Borne Sound	Output Tests	
Audi RS5	2008-2018	8R	A9 Struct.Borne Sound	Specia Functions	
Audi RS5	2008-2018	8R	AC Reductant Control	Read Fault Codes	
Audi RS5	2008-2018	8R	AC Reductant Control	Clear Fault Codes	
Audi RS5	2008-2018	8R	AC Reductant Control	Measuring Blocks	
Audi RS5	2008-2018	8R	AC Reductant Control	Output Tests	
Audi RS5	2008-2018	8R	AC Reductant Control	Specia Functions	
Audi RS5	2008-2018	8R	C0 Act. For Ext. Noise	Read Fault Codes	
Audi RS5	2008-2018	8R	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi RS5	2008-2018	8R	C0 Act. For Ext. Noise	Measuring Blocks	
Audi RS5	2008-2018	8R	C0 Act. For Ext. Noise	Output Tests	
Audi RS5	2008-2018	8R	C0 Act. For Ext. Noise	Specia Functions	
Audi A6	2011-2018	4G	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	01 Engine Electronics	Clear Fault Codes	
Audi A6	2011-2018	4G	01 Engine Electronics	Measuring Blocks	
Audi A6	2011-2018	4G	01 Engine Electronics	Output Tests	
Audi A6	2011-2018	4G	01 Engine Electronics	Specia Functions	
Audi A6	2011-2018	4G	02 Transmission Electronics	Read Fault Codes	
Audi A6	2011-2018	4G	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2011-2018	4G	02 Transmission Electronics	Measuring Blocks	
Audi A6	2011-2018	4G	02 Transmission Electronics	Output Tests	
Audi A6	2011-2018	4G	02 Transmission Electronics	Specia Functions	
Audi A6	2011-2018	4G	03 Brake Electronics	Read Fault Codes	
Audi A6	2011-2018	4G	03 Brake Electronics	Clear Fault Codes	
Audi A6	2011-2018	4G	03 Brake Electronics	Measuring Blocks	
Audi A6	2011-2018	4G	03 Brake Electronics	Output Tests	
Audi A6	2011-2018	4G	03 Brake Electronics	Specia Functions	
Audi A6	2011-2018	4G	05 Access & Permissi.	Read Fault Codes	
Audi A6	2011-2018	4G	05 Access & Permissi.	Clear Fault Codes	
Audi A6	2011-2018	4G	05 Access & Permissi.	Measuring Blocks	
Audi A6	2011-2018	4G	05 Access & Permissi.	Output Tests	
Audi A6	2011-2018	4G	05 Access & Permissi.	Specia Functions	
Audi A6	2011-2018	4G	06 Passene. Seat Adj.	Read Fault Codes	
Audi A6	2011-2018	4G	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6	2011-2018	4G	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6	2011-2018	4G	06 Passene. Seat Adj.	Output Tests	
Audi A6	2011-2018	4G	06 Passene. Seat Adj.	Specia Functions	
Audi A6	2011-2018	4G	08 AC/Heating Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	08 AC/Heating Electronics	Clear Fault Codes	
Audi A6	2011-2018	4G	08 AC/Heating Electronics	Measuring Blocks	
Audi A6	2011-2018	4G	08 AC/Heating Electronics	Output Tests	
Audi A6	2011-2018	4G	08 AC/Heating Electronics	Specia Functions	
Audi A6	2011-2018	4G	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A6	2011-2018	4G	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A6	2011-2018	4G	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A6	2011-2018	4G	09 Electronic Ctrl Electronics	Output Tests	
Audi A6	2011-2018	4G	09 Electronic Ctrl Electronics	Specia Functions	
Audi A6	2011-2018	4G	0E Media Player Position 1	Read Fault Codes	
Audi A6	2011-2018	4G	0E Media Player Position 1	Clear Fault Codes	
Audi A6	2011-2018	4G	0E Media Player Position 1	Measuring Blocks	
Audi A6	2011-2018	4G	0E Media Player Position 1	Output Tests	
Audi A6	2011-2018	4G	0E Media Player Position 1	Specia Functions	
Audi A6	2011-2018	4G	10 Parking Assist System 2	Read Fault Codes	
Audi A6	2011-2018	4G	10 Parking Assist System 2	Clear Fault Codes	
Audi A6	2011-2018	4G	10 Parking Assist System 2	Measuring Blocks	
Audi A6	2011-2018	4G	10 Parking Assist System 2	Output Tests	
Audi A6	2011-2018	4G	10 Parking Assist System 2	Specia Functions	
Audi A6	2011-2018	4G	13 Distance Control	Read Fault Codes	
Audi A6	2011-2018	4G	13 Distance Control	Clear Fault Codes	
Audi A6	2011-2018	4G	13 Distance Control	Measuring Blocks	
Audi A6	2011-2018	4G	13 Distance Control	Output Tests	
Audi A6	2011-2018	4G	13 Distance Control	Specia Functions	
Audi A6	2011-2018	4G	14 Wheel Damping Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	14 Wheel Damping Electronics	Clear Fault Codes	
Audi A6	2011-2018	4G	14 Wheel Damping Electronics	Measuring Blocks	
Audi A6	2011-2018	4G	14 Wheel Damping Electronics	Output Tests	
Audi A6	2011-2018	4G	14 Wheel Damping Electronics	Specia Functions	
Audi A6	2011-2018	4G	15 Airbags	Read Fault Codes	
Audi A6	2011-2018	4G	15 Airbags	Clear Fault Codes	
Audi A6	2011-2018	4G	15 Airbags	Measuring Blocks	
Audi A6	2011-2018	4G	15 Airbags	Output Tests	
Audi A6	2011-2018	4G	15 Airbags	Specia Functions	
Audi A6	2011-2018	4G	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2011-2018	4G	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2011-2018	4G	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2011-2018	4G	16 Steering Wheel Electronics	Output Tests	
Audi A6	2011-2018	4G	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2011-2018	4G	17 Instrument Cluster	Read Fault Codes	
Audi A6	2011-2018	4G	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2011-2018	4G	17 Instrument Cluster	Measuring Blocks	
Audi A6	2011-2018	4G	17 Instrument Cluster	Output Tests	
Audi A6	2011-2018	4G	17 Instrument Cluster	Specia Functions	
Audi A6	2011-2018	4G	18 Aux Heating	Read Fault Codes	
Audi A6	2011-2018	4G	18 Aux Heating	Clear Fault Codes	
Audi A6	2011-2018	4G	18 Aux Heating	Measuring Blocks	
Audi A6	2011-2018	4G	18 Aux Heating	Output Tests	
Audi A6	2011-2018	4G	18 Aux Heating	Specia Functions	
Audi A6	2011-2018	4G	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	19 Gateway Data Bus	Clear Fault Codes	
Audi A6	2011-2018	4G	19 Gateway Data Bus	Measuring Blocks	
Audi A6	2011-2018	4G	19 Gateway Data Bus	Output Tests	
Audi A6	2011-2018	4G	19 Gateway Data Bus	Specia Functions	
Audi A6	2011-2018	4G	1B Power-Assisted Steering	Read Fault Codes	
Audi A6	2011-2018	4G	1B Power-Assisted Steering	Clear Fault Codes	
Audi A6	2011-2018	4G	1B Power-Assisted Steering	Measuring Blocks	
Audi A6	2011-2018	4G	1B Power-Assisted Steering	Output Tests	
Audi A6	2011-2018	4G	1B Power-Assisted Steering	Specia Functions	
Audi A6	2011-2018	4G	20 High Beam Assistance Device	Read Fault Codes	
Audi A6	2011-2018	4G	20 High Beam Assistance Device	Clear Fault Codes	
Audi A6	2011-2018	4G	20 High Beam Assistance Device	Measuring Blocks	
Audi A6	2011-2018	4G	20 High Beam Assistance Device	Output Tests	
Audi A6	2011-2018	4G	20 High Beam Assistance Device	Specia Functions	
Audi A6	2011-2018	4G	22 4WD Electronics	Read Fault Codes	
Audi A6	2011-2018	4G	22 4WD Electronics	Clear Fault Codes	
Audi A6	2011-2018	4G	22 4WD Electronics	Measuring Blocks	
Audi A6	2011-2018	4G	22 4WD Electronics	Output Tests	
Audi A6	2011-2018	4G	22 4WD Electronics	Specia Functions	
Audi A6	2011-2018	4G	28 Climate Control Unit Rear	Read Fault Codes	
Audi A6	2011-2018	4G	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A6	2011-2018	4G	28 Climate Control Unit Rear	Measuring Blocks	
Audi A6	2011-2018	4G	28 Climate Control Unit Rear	Output Tests	
Audi A6	2011-2018	4G	28 Climate Control Unit Rear	Specia Functions	
Audi A6	2011-2018	4G	30 Special Function 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	30 Special Function 2	Clear Fault Codes	
Audi A6	2011-2018	4G	30 Special Function 2	Measuring Blocks	
Audi A6	2011-2018	4G	30 Special Function 2	Output Tests	
Audi A6	2011-2018	4G	30 Special Function 2	Specia Functions	
Audi A6	2011-2018	4G	34 Self Leveling Suspension	Read Fault Codes	
Audi A6	2011-2018	4G	34 Self Leveling Suspension	Clear Fault Codes	
Audi A6	2011-2018	4G	34 Self Leveling Suspension	Measuring Blocks	
Audi A6	2011-2018	4G	34 Self Leveling Suspension	Output Tests	
Audi A6	2011-2018	4G	34 Self Leveling Suspension	Specia Functions	
Audi A6	2011-2018	4G	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A6	2011-2018	4G	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A6	2011-2018	4G	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A6	2011-2018	4G	36 Side of Driver Seat Adj.	Output Tests	
Audi A6	2011-2018	4G	36 Side of Driver Seat Adj.	Specia Functions	
Audi A6	2011-2018	4G	3B Sensor Elect.	Read Fault Codes	
Audi A6	2011-2018	4G	3B Sensor Elect.	Clear Fault Codes	
Audi A6	2011-2018	4G	3B Sensor Elect.	Measuring Blocks	
Audi A6	2011-2018	4G	3B Sensor Elect.	Output Tests	
Audi A6	2011-2018	4G	3B Sensor Elect.	Specia Functions	
Audi A6	2011-2018	4G	3C Lane Departure Assistance System	Read Fault Codes	
Audi A6	2011-2018	4G	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A6	2011-2018	4G	3C Lane Departure Assistance System	Measuring Blocks	
Audi A6	2011-2018	4G	3C Lane Departure Assistance System	Output Tests	
Audi A6	2011-2018	4G	3C Lane Departure Assistance System	Specia Functions	
Audi A6	2011-2018	4G	3D Special Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	3D Special Function	Clear Fault Codes	
Audi A6	2011-2018	4G	3D Special Function	Measuring Blocks	
Audi A6	2011-2018	4G	3D Special Function	Output Tests	
Audi A6	2011-2018	4G	3D Special Function	Specia Functions	
Audi A6	2011-2018	4G	40 Air Compressor	Read Fault Codes	
Audi A6	2011-2018	4G	40 Air Compressor	Clear Fault Codes	
Audi A6	2011-2018	4G	40 Air Compressor	Measuring Blocks	
Audi A6	2011-2018	4G	40 Air Compressor	Output Tests	
Audi A6	2011-2018	4G	40 Air Compressor	Specia Functions	
Audi A6	2011-2018	4G	42 Driver-Door Elect.	Read Fault Codes	
Audi A6	2011-2018	4G	42 Driver-Door Elect.	Clear Fault Codes	
Audi A6	2011-2018	4G	42 Driver-Door Elect.	Measuring Blocks	
Audi A6	2011-2018	4G	42 Driver-Door Elect.	Output Tests	
Audi A6	2011-2018	4G	42 Driver-Door Elect.	Specia Functions	
Audi A6	2011-2018	4G	44 Steering Assistance	Read Fault Codes	
Audi A6	2011-2018	4G	44 Steering Assistance	Clear Fault Codes	
Audi A6	2011-2018	4G	44 Steering Assistance	Measuring Blocks	
Audi A6	2011-2018	4G	44 Steering Assistance	Output Tests	
Audi A6	2011-2018	4G	44 Steering Assistance	Specia Functions	
Audi A6	2011-2018	4G	46 Central Control Module	Read Fault Codes	
Audi A6	2011-2018	4G	46 Central Control Module	Clear Fault Codes	
Audi A6	2011-2018	4G	46 Central Control Module	Measuring Blocks	
Audi A6	2011-2018	4G	46 Central Control Module	Output Tests	
Audi A6	2011-2018	4G	46 Central Control Module	Specia Functions	
Audi A6	2011-2018	4G	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	47 Soundsystem	Clear Fault Codes	
Audi A6	2011-2018	4G	47 Soundsystem	Measuring Blocks	
Audi A6	2011-2018	4G	47 Soundsystem	Output Tests	
Audi A6	2011-2018	4G	47 Soundsystem	Specia Functions	
Audi A6	2011-2018	4G	4E Control Head RR	Read Fault Codes	
Audi A6	2011-2018	4G	4E Control Head RR	Clear Fault Codes	
Audi A6	2011-2018	4G	4E Control Head RR	Measuring Blocks	
Audi A6	2011-2018	4G	4E Control Head RR	Output Tests	
Audi A6	2011-2018	4G	4E Control Head RR	Specia Functions	
Audi A6	2011-2018	4G	51 Electric Drive	Read Fault Codes	
Audi A6	2011-2018	4G	51 Electric Drive	Clear Fault Codes	
Audi A6	2011-2018	4G	51 Electric Drive	Measuring Blocks	
Audi A6	2011-2018	4G	51 Electric Drive	Output Tests	
Audi A6	2011-2018	4G	51 Electric Drive	Specia Functions	
Audi A6	2011-2018	4G	52 Passe.-Door Elect.	Read Fault Codes	
Audi A6	2011-2018	4G	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A6	2011-2018	4G	52 Passe.-Door Elect.	Measuring Blocks	
Audi A6	2011-2018	4G	52 Passe.-Door Elect.	Output Tests	
Audi A6	2011-2018	4G	52 Passe.-Door Elect.	Specia Functions	
Audi A6	2011-2018	4G	53 Parking Brake	Read Fault Codes	
Audi A6	2011-2018	4G	53 Parking Brake	Clear Fault Codes	
Audi A6	2011-2018	4G	53 Parking Brake	Measuring Blocks	
Audi A6	2011-2018	4G	53 Parking Brake	Output Tests	
Audi A6	2011-2018	4G	53 Parking Brake	Specia Functions	
Audi A6	2011-2018	4G	55 Headlight Range Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6	2011-2018	4G	55 Headlight Range Control	Clear Fault Codes	
Audi A6	2011-2018	4G	55 Headlight Range Control	Measuring Blocks	
Audi A6	2011-2018	4G	55 Headlight Range Control	Output Tests	
Audi A6	2011-2018	4G	55 Headlight Range Control	Specia Functions	
Audi A6	2011-2018	4G	56 Radio	Read Fault Codes	
Audi A6	2011-2018	4G	56 Radio	Clear Fault Codes	
Audi A6	2011-2018	4G	56 Radio	Measuring Blocks	
Audi A6	2011-2018	4G	56 Radio	Output Tests	
Audi A6	2011-2018	4G	56 Radio	Specia Functions	
Audi A6	2011-2018	4G	57 TV-Tuner	Read Fault Codes	
Audi A6	2011-2018	4G	57 TV-Tuner	Clear Fault Codes	
Audi A6	2011-2018	4G	57 TV-Tuner	Measuring Blocks	
Audi A6	2011-2018	4G	57 TV-Tuner	Output Tests	
Audi A6	2011-2018	4G	57 TV-Tuner	Specia Functions	
Audi A6	2011-2018	4G	5E Control Head LR	Read Fault Codes	
Audi A6	2011-2018	4G	5E Control Head LR	Clear Fault Codes	
Audi A6	2011-2018	4G	5E Control Head LR	Measuring Blocks	
Audi A6	2011-2018	4G	5E Control Head LR	Output Tests	
Audi A6	2011-2018	4G	5E Control Head LR	Specia Functions	
Audi A6	2011-2018	4G	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A6	2011-2018	4G	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A6	2011-2018	4G	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A6	2011-2018	4G	5F Information Electronic Equipment 1	Output Tests	
Audi A6	2011-2018	4G	5F Information Electronic Equipment 1	Specia Functions	
Audi A6	2011-2018	4G	62 LR-Door Electroni.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	62 LR-Door Electroni.	Clear Fault Codes	
Audi A6	2011-2018	4G	62 LR-Door Electroni.	Measuring Blocks	
Audi A6	2011-2018	4G	62 LR-Door Electroni.	Output Tests	
Audi A6	2011-2018	4G	62 LR-Door Electroni.	Specia Functions	
Audi A6	2011-2018	4G	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6	2011-2018	4G	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6	2011-2018	4G	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6	2011-2018	4G	65 Tyre Pressure Monitoring	Output Tests	
Audi A6	2011-2018	4G	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6	2011-2018	4G	69 Trailer Function	Read Fault Codes	
Audi A6	2011-2018	4G	69 Trailer Function	Clear Fault Codes	
Audi A6	2011-2018	4G	69 Trailer Function	Measuring Blocks	
Audi A6	2011-2018	4G	69 Trailer Function	Output Tests	
Audi A6	2011-2018	4G	69 Trailer Function	Specia Functions	
Audi A6	2011-2018	4G	6C Rear Camera	Read Fault Codes	
Audi A6	2011-2018	4G	6C Rear Camera	Clear Fault Codes	
Audi A6	2011-2018	4G	6C Rear Camera	Measuring Blocks	
Audi A6	2011-2018	4G	6C Rear Camera	Output Tests	
Audi A6	2011-2018	4G	6C Rear Camera	Specia Functions	
Audi A6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A6	2011-2018	4G	72 RR-Door Electroni.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	72 RR-Door Electroni.	Clear Fault Codes	
Audi A6	2011-2018	4G	72 RR-Door Electroni.	Measuring Blocks	
Audi A6	2011-2018	4G	72 RR-Door Electroni.	Output Tests	
Audi A6	2011-2018	4G	72 RR-Door Electroni.	Specia Functions	
Audi A6	2011-2018	4G	7F Information Electronic Equipment 2	Read Fault Codes	
Audi A6	2011-2018	4G	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi A6	2011-2018	4G	7F Information Electronic Equipment 2	Measuring Blocks	
Audi A6	2011-2018	4G	7F Information Electronic Equipment 2	Output Tests	
Audi A6	2011-2018	4G	7F Information Electronic Equipment 2	Specia Functions	
Audi A6	2011-2018	4G	82 Heads Up Display	Read Fault Codes	
Audi A6	2011-2018	4G	82 Heads Up Display	Clear Fault Codes	
Audi A6	2011-2018	4G	82 Heads Up Display	Measuring Blocks	
Audi A6	2011-2018	4G	82 Heads Up Display	Output Tests	
Audi A6	2011-2018	4G	82 Heads Up Display	Specia Functions	
Audi A6	2011-2018	4G	84 Night Vision	Read Fault Codes	
Audi A6	2011-2018	4G	84 Night Vision	Clear Fault Codes	
Audi A6	2011-2018	4G	84 Night Vision	Measuring Blocks	
Audi A6	2011-2018	4G	84 Night Vision	Output Tests	
Audi A6	2011-2018	4G	84 Night Vision	Specia Functions	
Audi A6	2011-2018	4G	85 On Board Cam.	Read Fault Codes	
Audi A6	2011-2018	4G	85 On Board Cam.	Clear Fault Codes	
Audi A6	2011-2018	4G	85 On Board Cam.	Measuring Blocks	
Audi A6	2011-2018	4G	85 On Board Cam.	Output Tests	
Audi A6	2011-2018	4G	85 On Board Cam.	Specia Functions	
Audi A6	2011-2018	4G	88 Multicont. Seat Driver	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	88 Multicont. Seat Driver	Clear Fault Codes	
Audi A6	2011-2018	4G	88 Multicont. Seat Driver	Measuring Blocks	
Audi A6	2011-2018	4G	88 Multicont. Seat Driver	Output Tests	
Audi A6	2011-2018	4G	88 Multicont. Seat Driver	Specia Functions	
Audi A6	2011-2018	4G	89 Multicont. Seat Driver	Read Fault Codes	
Audi A6	2011-2018	4G	89 Multicont. Seat Driver	Clear Fault Codes	
Audi A6	2011-2018	4G	89 Multicont. Seat Driver	Measuring Blocks	
Audi A6	2011-2018	4G	89 Multicont. Seat Driver	Output Tests	
Audi A6	2011-2018	4G	89 Multicont. Seat Driver	Specia Functions	
Audi A6	2011-2018	4G	8A Multicont. Seat Rear, DS	Read Fault Codes	
Audi A6	2011-2018	4G	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi A6	2011-2018	4G	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi A6	2011-2018	4G	8A Multicont. Seat Rear, DS	Output Tests	
Audi A6	2011-2018	4G	8A Multicont. Seat Rear, DS	Specia Functions	
Audi A6	2011-2018	4G	8B Adaptive Cruise 2	Read Fault Codes	
Audi A6	2011-2018	4G	8B Adaptive Cruise 2	Clear Fault Codes	
Audi A6	2011-2018	4G	8B Adaptive Cruise 2	Measuring Blocks	
Audi A6	2011-2018	4G	8B Adaptive Cruise 2	Output Tests	
Audi A6	2011-2018	4G	8B Adaptive Cruise 2	Specia Functions	
Audi A6	2011-2018	4G	8C Hybrid Battery	Read Fault Codes	
Audi A6	2011-2018	4G	8C Hybrid Battery	Clear Fault Codes	
Audi A6	2011-2018	4G	8C Hybrid Battery	Measuring Blocks	
Audi A6	2011-2018	4G	8C Hybrid Battery	Output Tests	
Audi A6	2011-2018	4G	8C Hybrid Battery	Specia Functions	
Audi A6	2011-2018	4G	8D Multicont.Seat Rear,PS	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2011-2018	4G	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi A6	2011-2018	4G	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi A6	2011-2018	4G	8D Multicont.Seat Rear,PS	Output Tests	
Audi A6	2011-2018	4G	8D Multicont.Seat Rear,PS	Specia Functions	
Audi A6	2011-2018	4G	8E Image Processing	Read Fault Codes	
Audi A6	2011-2018	4G	8E Image Processing	Clear Fault Codes	
Audi A6	2011-2018	4G	8E Image Processing	Measuring Blocks	
Audi A6	2011-2018	4G	8E Image Processing	Output Tests	
Audi A6	2011-2018	4G	8E Image Processing	Specia Functions	
Audi A6	2011-2018	4G	8F Pretens. Frt Left	Read Fault Codes	
Audi A6	2011-2018	4G	8F Pretens. Frt Left	Clear Fault Codes	
Audi A6	2011-2018	4G	8F Pretens. Frt Left	Measuring Blocks	
Audi A6	2011-2018	4G	8F Pretens. Frt Left	Output Tests	
Audi A6	2011-2018	4G	8F Pretens. Frt Left	Specia Functions	
Audi A6	2011-2018	4G	90 Pretens. Frt Right	Read Fault Codes	
Audi A6	2011-2018	4G	90 Pretens. Frt Right	Clear Fault Codes	
Audi A6	2011-2018	4G	90 Pretens. Frt Right	Measuring Blocks	
Audi A6	2011-2018	4G	90 Pretens. Frt Right	Output Tests	
Audi A6	2011-2018	4G	90 Pretens. Frt Right	Specia Functions	
Audi A6	2011-2018	4G	A9 Struct.Borne Sound	Read Fault Codes	
Audi A6	2011-2018	4G	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A6	2011-2018	4G	A9 Struct.Borne Sound	Measuring Blocks	
Audi A6	2011-2018	4G	A9 Struct.Borne Sound	Output Tests	
Audi A6	2011-2018	4G	A9 Struct.Borne Sound	Specia Functions	
Audi A6	2011-2018	4G	AC Reductant Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6	2011-2018	4G	AC Reductant Control	Clear Fault Codes	
Audi A6	2011-2018	4G	AC Reductant Control	Measuring Blocks	
Audi A6	2011-2018	4G	AC Reductant Control	Output Tests	
Audi A6	2011-2018	4G	AC Reductant Control	Specia Functions	
Audi A6	2011-2018	4G	BA Motor Mounts	Read Fault Codes	
Audi A6	2011-2018	4G	BA Motor Mounts	Clear Fault Codes	
Audi A6	2011-2018	4G	BA Motor Mounts	Measuring Blocks	
Audi A6	2011-2018	4G	BA Motor Mounts	Output Tests	
Audi A6	2011-2018	4G	BA Motor Mounts	Specia Functions	
Audi A6	2011-2018	4G	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A6	2011-2018	4G	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A6	2011-2018	4G	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A6	2011-2018	4G	C0 Act. For Ext. Noise	Output Tests	
Audi A6	2011-2018	4G	C0 Act. For Ext. Noise	Specia Functions	
Audi A6	2011-2018	4G	C6 Batt. Chrg	Read Fault Codes	
Audi A6	2011-2018	4G	C6 Batt. Chrg	Clear Fault Codes	
Audi A6	2011-2018	4G	C6 Batt. Chrg	Measuring Blocks	
Audi A6	2011-2018	4G	C6 Batt. Chrg	Output Tests	
Audi A6	2011-2018	4G	C6 Batt. Chrg	Specia Functions	
Audi S6	2011-2018	4G	01 Engine Electronics	Read Fault Codes	
Audi S6	2011-2018	4G	01 Engine Electronics	Clear Fault Codes	
Audi S6	2011-2018	4G	01 Engine Electronics	Measuring Blocks	
Audi S6	2011-2018	4G	01 Engine Electronics	Output Tests	
Audi S6	2011-2018	4G	01 Engine Electronics	Specia Functions	
Audi S6	2011-2018	4G	02 Transmission Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	02 Transmission Electronics	Clear Fault Codes	
Audi S6	2011-2018	4G	02 Transmission Electronics	Measuring Blocks	
Audi S6	2011-2018	4G	02 Transmission Electronics	Output Tests	
Audi S6	2011-2018	4G	02 Transmission Electronics	Specia Functions	
Audi S6	2011-2018	4G	03 Brake Electronics	Read Fault Codes	
Audi S6	2011-2018	4G	03 Brake Electronics	Clear Fault Codes	
Audi S6	2011-2018	4G	03 Brake Electronics	Measuring Blocks	
Audi S6	2011-2018	4G	03 Brake Electronics	Output Tests	
Audi S6	2011-2018	4G	03 Brake Electronics	Specia Functions	
Audi S6	2011-2018	4G	05 Access & Permissi.	Read Fault Codes	
Audi S6	2011-2018	4G	05 Access & Permissi.	Clear Fault Codes	
Audi S6	2011-2018	4G	05 Access & Permissi.	Measuring Blocks	
Audi S6	2011-2018	4G	05 Access & Permissi.	Output Tests	
Audi S6	2011-2018	4G	05 Access & Permissi.	Specia Functions	
Audi S6	2011-2018	4G	06 Passene. Seat Adj.	Read Fault Codes	
Audi S6	2011-2018	4G	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S6	2011-2018	4G	06 Passene. Seat Adj.	Measuring Blocks	
Audi S6	2011-2018	4G	06 Passene. Seat Adj.	Output Tests	
Audi S6	2011-2018	4G	06 Passene. Seat Adj.	Specia Functions	
Audi S6	2011-2018	4G	08 AC/Heating Electronics	Read Fault Codes	
Audi S6	2011-2018	4G	08 AC/Heating Electronics	Clear Fault Codes	
Audi S6	2011-2018	4G	08 AC/Heating Electronics	Measuring Blocks	
Audi S6	2011-2018	4G	08 AC/Heating Electronics	Output Tests	
Audi S6	2011-2018	4G	08 AC/Heating Electronics	Specia Functions	
Audi S6	2011-2018	4G	09 Electronic Ctrl Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S6	2011-2018	4G	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S6	2011-2018	4G	09 Electronic Ctrl Electronics	Output Tests	
Audi S6	2011-2018	4G	09 Electronic Ctrl Electronics	Specia Functions	
Audi S6	2011-2018	4G	0E Media Player Position 1	Read Fault Codes	
Audi S6	2011-2018	4G	0E Media Player Position 1	Clear Fault Codes	
Audi S6	2011-2018	4G	0E Media Player Position 1	Measuring Blocks	
Audi S6	2011-2018	4G	0E Media Player Position 1	Output Tests	
Audi S6	2011-2018	4G	0E Media Player Position 1	Specia Functions	
Audi S6	2011-2018	4G	10 Parking Assist System 2	Read Fault Codes	
Audi S6	2011-2018	4G	10 Parking Assist System 2	Clear Fault Codes	
Audi S6	2011-2018	4G	10 Parking Assist System 2	Measuring Blocks	
Audi S6	2011-2018	4G	10 Parking Assist System 2	Output Tests	
Audi S6	2011-2018	4G	10 Parking Assist System 2	Specia Functions	
Audi S6	2011-2018	4G	13 Distance Control	Read Fault Codes	
Audi S6	2011-2018	4G	13 Distance Control	Clear Fault Codes	
Audi S6	2011-2018	4G	13 Distance Control	Measuring Blocks	
Audi S6	2011-2018	4G	13 Distance Control	Output Tests	
Audi S6	2011-2018	4G	13 Distance Control	Specia Functions	
Audi S6	2011-2018	4G	14 Wheel Damping Electronics	Read Fault Codes	
Audi S6	2011-2018	4G	14 Wheel Damping Electronics	Clear Fault Codes	
Audi S6	2011-2018	4G	14 Wheel Damping Electronics	Measuring Blocks	
Audi S6	2011-2018	4G	14 Wheel Damping Electronics	Output Tests	
Audi S6	2011-2018	4G	14 Wheel Damping Electronics	Specia Functions	
Audi S6	2011-2018	4G	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	15 Airbags	Clear Fault Codes	
Audi S6	2011-2018	4G	15 Airbags	Measuring Blocks	
Audi S6	2011-2018	4G	15 Airbags	Output Tests	
Audi S6	2011-2018	4G	15 Airbags	Specia Functions	
Audi S6	2011-2018	4G	16 Steering Wheel Electronics	Read Fault Codes	
Audi S6	2011-2018	4G	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S6	2011-2018	4G	16 Steering Wheel Electronics	Measuring Blocks	
Audi S6	2011-2018	4G	16 Steering Wheel Electronics	Output Tests	
Audi S6	2011-2018	4G	16 Steering Wheel Electronics	Specia Functions	
Audi S6	2011-2018	4G	17 Instrument Cluster	Read Fault Codes	
Audi S6	2011-2018	4G	17 Instrument Cluster	Clear Fault Codes	
Audi S6	2011-2018	4G	17 Instrument Cluster	Measuring Blocks	
Audi S6	2011-2018	4G	17 Instrument Cluster	Output Tests	
Audi S6	2011-2018	4G	17 Instrument Cluster	Specia Functions	
Audi S6	2011-2018	4G	18 Aux Heating	Read Fault Codes	
Audi S6	2011-2018	4G	18 Aux Heating	Clear Fault Codes	
Audi S6	2011-2018	4G	18 Aux Heating	Measuring Blocks	
Audi S6	2011-2018	4G	18 Aux Heating	Output Tests	
Audi S6	2011-2018	4G	18 Aux Heating	Specia Functions	
Audi S6	2011-2018	4G	19 Gateway Data Bus	Read Fault Codes	
Audi S6	2011-2018	4G	19 Gateway Data Bus	Clear Fault Codes	
Audi S6	2011-2018	4G	19 Gateway Data Bus	Measuring Blocks	
Audi S6	2011-2018	4G	19 Gateway Data Bus	Output Tests	
Audi S6	2011-2018	4G	19 Gateway Data Bus	Specia Functions	
Audi S6	2011-2018	4G	1B Power-Assisted Steering	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	1B Power-Assisted Steering	Clear Fault Codes	
Audi S6	2011-2018	4G	1B Power-Assisted Steering	Measuring Blocks	
Audi S6	2011-2018	4G	1B Power-Assisted Steering	Output Tests	
Audi S6	2011-2018	4G	1B Power-Assisted Steering	Specia Functions	
Audi S6	2011-2018	4G	20 High Beam Assistance Device	Read Fault Codes	
Audi S6	2011-2018	4G	20 High Beam Assistance Device	Clear Fault Codes	
Audi S6	2011-2018	4G	20 High Beam Assistance Device	Measuring Blocks	
Audi S6	2011-2018	4G	20 High Beam Assistance Device	Output Tests	
Audi S6	2011-2018	4G	20 High Beam Assistance Device	Specia Functions	
Audi S6	2011-2018	4G	22 4WD Electronics	Read Fault Codes	
Audi S6	2011-2018	4G	22 4WD Electronics	Clear Fault Codes	
Audi S6	2011-2018	4G	22 4WD Electronics	Measuring Blocks	
Audi S6	2011-2018	4G	22 4WD Electronics	Output Tests	
Audi S6	2011-2018	4G	22 4WD Electronics	Specia Functions	
Audi S6	2011-2018	4G	28 Climate Control Unit Rear	Read Fault Codes	
Audi S6	2011-2018	4G	28 Climate Control Unit Rear	Clear Fault Codes	
Audi S6	2011-2018	4G	28 Climate Control Unit Rear	Measuring Blocks	
Audi S6	2011-2018	4G	28 Climate Control Unit Rear	Output Tests	
Audi S6	2011-2018	4G	28 Climate Control Unit Rear	Specia Functions	
Audi S6	2011-2018	4G	30 Special Function 2	Read Fault Codes	
Audi S6	2011-2018	4G	30 Special Function 2	Clear Fault Codes	
Audi S6	2011-2018	4G	30 Special Function 2	Measuring Blocks	
Audi S6	2011-2018	4G	30 Special Function 2	Output Tests	
Audi S6	2011-2018	4G	30 Special Function 2	Specia Functions	
Audi S6	2011-2018	4G	34 Self Leveling Suspension	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	34 Self Leveling Suspension	Clear Fault Codes	
Audi S6	2011-2018	4G	34 Self Leveling Suspension	Measuring Blocks	
Audi S6	2011-2018	4G	34 Self Leveling Suspension	Output Tests	
Audi S6	2011-2018	4G	34 Self Leveling Suspension	Specia Functions	
Audi S6	2011-2018	4G	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi S6	2011-2018	4G	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S6	2011-2018	4G	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S6	2011-2018	4G	36 Side of Driver Seat Adj.	Output Tests	
Audi S6	2011-2018	4G	36 Side of Driver Seat Adj.	Specia Functions	
Audi S6	2011-2018	4G	3B Sensor Elect.	Read Fault Codes	
Audi S6	2011-2018	4G	3B Sensor Elect.	Clear Fault Codes	
Audi S6	2011-2018	4G	3B Sensor Elect.	Measuring Blocks	
Audi S6	2011-2018	4G	3B Sensor Elect.	Output Tests	
Audi S6	2011-2018	4G	3B Sensor Elect.	Specia Functions	
Audi S6	2011-2018	4G	3C Lane Departure Assistance System	Read Fault Codes	
Audi S6	2011-2018	4G	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S6	2011-2018	4G	3C Lane Departure Assistance System	Measuring Blocks	
Audi S6	2011-2018	4G	3C Lane Departure Assistance System	Output Tests	
Audi S6	2011-2018	4G	3C Lane Departure Assistance System	Specia Functions	
Audi S6	2011-2018	4G	3D Special Function	Read Fault Codes	
Audi S6	2011-2018	4G	3D Special Function	Clear Fault Codes	
Audi S6	2011-2018	4G	3D Special Function	Measuring Blocks	
Audi S6	2011-2018	4G	3D Special Function	Output Tests	
Audi S6	2011-2018	4G	3D Special Function	Specia Functions	
Audi S6	2011-2018	4G	40 Air Compressor	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	40 Air Compressor	Clear Fault Codes	
Audi S6	2011-2018	4G	40 Air Compressor	Measuring Blocks	
Audi S6	2011-2018	4G	40 Air Compressor	Output Tests	
Audi S6	2011-2018	4G	40 Air Compressor	Specia Functions	
Audi S6	2011-2018	4G	42 Driver-Door Elect.	Read Fault Codes	
Audi S6	2011-2018	4G	42 Driver-Door Elect.	Clear Fault Codes	
Audi S6	2011-2018	4G	42 Driver-Door Elect.	Measuring Blocks	
Audi S6	2011-2018	4G	42 Driver-Door Elect.	Output Tests	
Audi S6	2011-2018	4G	42 Driver-Door Elect.	Specia Functions	
Audi S6	2011-2018	4G	44 Steering Assistance	Read Fault Codes	
Audi S6	2011-2018	4G	44 Steering Assistance	Clear Fault Codes	
Audi S6	2011-2018	4G	44 Steering Assistance	Measuring Blocks	
Audi S6	2011-2018	4G	44 Steering Assistance	Output Tests	
Audi S6	2011-2018	4G	44 Steering Assistance	Specia Functions	
Audi S6	2011-2018	4G	46 Central Control Module	Read Fault Codes	
Audi S6	2011-2018	4G	46 Central Control Module	Clear Fault Codes	
Audi S6	2011-2018	4G	46 Central Control Module	Measuring Blocks	
Audi S6	2011-2018	4G	46 Central Control Module	Output Tests	
Audi S6	2011-2018	4G	46 Central Control Module	Specia Functions	
Audi S6	2011-2018	4G	47 Soundsystem	Read Fault Codes	
Audi S6	2011-2018	4G	47 Soundsystem	Clear Fault Codes	
Audi S6	2011-2018	4G	47 Soundsystem	Measuring Blocks	
Audi S6	2011-2018	4G	47 Soundsystem	Output Tests	
Audi S6	2011-2018	4G	47 Soundsystem	Specia Functions	
Audi S6	2011-2018	4G	4E Control Head RR	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	4E Control Head RR	Clear Fault Codes	
Audi S6	2011-2018	4G	4E Control Head RR	Measuring Blocks	
Audi S6	2011-2018	4G	4E Control Head RR	Output Tests	
Audi S6	2011-2018	4G	4E Control Head RR	Specia Functions	
Audi S6	2011-2018	4G	51 Electric Drive	Read Fault Codes	
Audi S6	2011-2018	4G	51 Electric Drive	Clear Fault Codes	
Audi S6	2011-2018	4G	51 Electric Drive	Measuring Blocks	
Audi S6	2011-2018	4G	51 Electric Drive	Output Tests	
Audi S6	2011-2018	4G	51 Electric Drive	Specia Functions	
Audi S6	2011-2018	4G	52 Passe.-Door Elect.	Read Fault Codes	
Audi S6	2011-2018	4G	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S6	2011-2018	4G	52 Passe.-Door Elect.	Measuring Blocks	
Audi S6	2011-2018	4G	52 Passe.-Door Elect.	Output Tests	
Audi S6	2011-2018	4G	52 Passe.-Door Elect.	Specia Functions	
Audi S6	2011-2018	4G	53 Parking Brake	Read Fault Codes	
Audi S6	2011-2018	4G	53 Parking Brake	Clear Fault Codes	
Audi S6	2011-2018	4G	53 Parking Brake	Measuring Blocks	
Audi S6	2011-2018	4G	53 Parking Brake	Output Tests	
Audi S6	2011-2018	4G	53 Parking Brake	Specia Functions	
Audi S6	2011-2018	4G	55 Headlight Range Control	Read Fault Codes	
Audi S6	2011-2018	4G	55 Headlight Range Control	Clear Fault Codes	
Audi S6	2011-2018	4G	55 Headlight Range Control	Measuring Blocks	
Audi S6	2011-2018	4G	55 Headlight Range Control	Output Tests	
Audi S6	2011-2018	4G	55 Headlight Range Control	Specia Functions	
Audi S6	2011-2018	4G	56 Radio	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	56 Radio	Clear Fault Codes	
Audi S6	2011-2018	4G	56 Radio	Measuring Blocks	
Audi S6	2011-2018	4G	56 Radio	Output Tests	
Audi S6	2011-2018	4G	56 Radio	Specia Functions	
Audi S6	2011-2018	4G	57 TV-Tuner	Read Fault Codes	
Audi S6	2011-2018	4G	57 TV-Tuner	Clear Fault Codes	
Audi S6	2011-2018	4G	57 TV-Tuner	Measuring Blocks	
Audi S6	2011-2018	4G	57 TV-Tuner	Output Tests	
Audi S6	2011-2018	4G	57 TV-Tuner	Specia Functions	
Audi S6	2011-2018	4G	5E Control Head LR	Read Fault Codes	
Audi S6	2011-2018	4G	5E Control Head LR	Clear Fault Codes	
Audi S6	2011-2018	4G	5E Control Head LR	Measuring Blocks	
Audi S6	2011-2018	4G	5E Control Head LR	Output Tests	
Audi S6	2011-2018	4G	5E Control Head LR	Specia Functions	
Audi S6	2011-2018	4G	5F Information Electronic Equipment 1	Read Fault Codes	
Audi S6	2011-2018	4G	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S6	2011-2018	4G	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S6	2011-2018	4G	5F Information Electronic Equipment 1	Output Tests	
Audi S6	2011-2018	4G	5F Information Electronic Equipment 1	Specia Functions	
Audi S6	2011-2018	4G	62 LR-Door Electroni.	Read Fault Codes	
Audi S6	2011-2018	4G	62 LR-Door Electroni.	Clear Fault Codes	
Audi S6	2011-2018	4G	62 LR-Door Electroni.	Measuring Blocks	
Audi S6	2011-2018	4G	62 LR-Door Electroni.	Output Tests	
Audi S6	2011-2018	4G	62 LR-Door Electroni.	Specia Functions	
Audi S6	2011-2018	4G	65 Tyre Pressure Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S6	2011-2018	4G	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S6	2011-2018	4G	65 Tyre Pressure Monitoring	Output Tests	
Audi S6	2011-2018	4G	65 Tyre Pressure Monitoring	Specia Functions	
Audi S6	2011-2018	4G	69 Trailer Function	Read Fault Codes	
Audi S6	2011-2018	4G	69 Trailer Function	Clear Fault Codes	
Audi S6	2011-2018	4G	69 Trailer Function	Measuring Blocks	
Audi S6	2011-2018	4G	69 Trailer Function	Output Tests	
Audi S6	2011-2018	4G	69 Trailer Function	Specia Functions	
Audi S6	2011-2018	4G	6C Rear Camera	Read Fault Codes	
Audi S6	2011-2018	4G	6C Rear Camera	Clear Fault Codes	
Audi S6	2011-2018	4G	6C Rear Camera	Measuring Blocks	
Audi S6	2011-2018	4G	6C Rear Camera	Output Tests	
Audi S6	2011-2018	4G	6C Rear Camera	Specia Functions	
Audi S6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi S6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S6	2011-2018	4G	72 RR-Door Electroni.	Read Fault Codes	
Audi S6	2011-2018	4G	72 RR-Door Electroni.	Clear Fault Codes	
Audi S6	2011-2018	4G	72 RR-Door Electroni.	Measuring Blocks	
Audi S6	2011-2018	4G	72 RR-Door Electroni.	Output Tests	
Audi S6	2011-2018	4G	72 RR-Door Electroni.	Specia Functions	
Audi S6	2011-2018	4G	7F Information Electronic Equipment 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi S6	2011-2018	4G	7F Information Electronic Equipment 2	Measuring Blocks	
Audi S6	2011-2018	4G	7F Information Electronic Equipment 2	Output Tests	
Audi S6	2011-2018	4G	7F Information Electronic Equipment 2	Specia Functions	
Audi S6	2011-2018	4G	82 Heads Up Display	Read Fault Codes	
Audi S6	2011-2018	4G	82 Heads Up Display	Clear Fault Codes	
Audi S6	2011-2018	4G	82 Heads Up Display	Measuring Blocks	
Audi S6	2011-2018	4G	82 Heads Up Display	Output Tests	
Audi S6	2011-2018	4G	82 Heads Up Display	Specia Functions	
Audi S6	2011-2018	4G	84 Night Vision	Read Fault Codes	
Audi S6	2011-2018	4G	84 Night Vision	Clear Fault Codes	
Audi S6	2011-2018	4G	84 Night Vision	Measuring Blocks	
Audi S6	2011-2018	4G	84 Night Vision	Output Tests	
Audi S6	2011-2018	4G	84 Night Vision	Specia Functions	
Audi S6	2011-2018	4G	85 On Board Cam.	Read Fault Codes	
Audi S6	2011-2018	4G	85 On Board Cam.	Clear Fault Codes	
Audi S6	2011-2018	4G	85 On Board Cam.	Measuring Blocks	
Audi S6	2011-2018	4G	85 On Board Cam.	Output Tests	
Audi S6	2011-2018	4G	85 On Board Cam.	Specia Functions	
Audi S6	2011-2018	4G	88 Multicont. Seat Driver	Read Fault Codes	
Audi S6	2011-2018	4G	88 Multicont. Seat Driver	Clear Fault Codes	
Audi S6	2011-2018	4G	88 Multicont. Seat Driver	Measuring Blocks	
Audi S6	2011-2018	4G	88 Multicont. Seat Driver	Output Tests	
Audi S6	2011-2018	4G	88 Multicont. Seat Driver	Specia Functions	
Audi S6	2011-2018	4G	89 Multicont. Seat Driver	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	89 Multicont. Seat Driver	Clear Fault Codes	
Audi S6	2011-2018	4G	89 Multicont. Seat Driver	Measuring Blocks	
Audi S6	2011-2018	4G	89 Multicont. Seat Driver	Output Tests	
Audi S6	2011-2018	4G	89 Multicont. Seat Driver	Specia Functions	
Audi S6	2011-2018	4G	8A Multicont. Seat Rear, DS	Read Fault Codes	
Audi S6	2011-2018	4G	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi S6	2011-2018	4G	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi S6	2011-2018	4G	8A Multicont. Seat Rear, DS	Output Tests	
Audi S6	2011-2018	4G	8A Multicont. Seat Rear, DS	Specia Functions	
Audi S6	2011-2018	4G	8B Adaptive Cruise 2	Read Fault Codes	
Audi S6	2011-2018	4G	8B Adaptive Cruise 2	Clear Fault Codes	
Audi S6	2011-2018	4G	8B Adaptive Cruise 2	Measuring Blocks	
Audi S6	2011-2018	4G	8B Adaptive Cruise 2	Output Tests	
Audi S6	2011-2018	4G	8B Adaptive Cruise 2	Specia Functions	
Audi S6	2011-2018	4G	8C Hybrid Battery	Read Fault Codes	
Audi S6	2011-2018	4G	8C Hybrid Battery	Clear Fault Codes	
Audi S6	2011-2018	4G	8C Hybrid Battery	Measuring Blocks	
Audi S6	2011-2018	4G	8C Hybrid Battery	Output Tests	
Audi S6	2011-2018	4G	8C Hybrid Battery	Specia Functions	
Audi S6	2011-2018	4G	8D Multicont.Seat Rear,PS	Read Fault Codes	
Audi S6	2011-2018	4G	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi S6	2011-2018	4G	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi S6	2011-2018	4G	8D Multicont.Seat Rear,PS	Output Tests	
Audi S6	2011-2018	4G	8D Multicont.Seat Rear,PS	Specia Functions	
Audi S6	2011-2018	4G	8E Image Processing	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	8E Image Processing	Clear Fault Codes	
Audi S6	2011-2018	4G	8E Image Processing	Measuring Blocks	
Audi S6	2011-2018	4G	8E Image Processing	Output Tests	
Audi S6	2011-2018	4G	8E Image Processing	Specia Functions	
Audi S6	2011-2018	4G	8F Pretens. Frt Left	Read Fault Codes	
Audi S6	2011-2018	4G	8F Pretens. Frt Left	Clear Fault Codes	
Audi S6	2011-2018	4G	8F Pretens. Frt Left	Measuring Blocks	
Audi S6	2011-2018	4G	8F Pretens. Frt Left	Output Tests	
Audi S6	2011-2018	4G	8F Pretens. Frt Left	Specia Functions	
Audi S6	2011-2018	4G	90 Pretens. Frt Right	Read Fault Codes	
Audi S6	2011-2018	4G	90 Pretens. Frt Right	Clear Fault Codes	
Audi S6	2011-2018	4G	90 Pretens. Frt Right	Measuring Blocks	
Audi S6	2011-2018	4G	90 Pretens. Frt Right	Output Tests	
Audi S6	2011-2018	4G	90 Pretens. Frt Right	Specia Functions	
Audi S6	2011-2018	4G	A9 Struct.Borne Sound	Read Fault Codes	
Audi S6	2011-2018	4G	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S6	2011-2018	4G	A9 Struct.Borne Sound	Measuring Blocks	
Audi S6	2011-2018	4G	A9 Struct.Borne Sound	Output Tests	
Audi S6	2011-2018	4G	A9 Struct.Borne Sound	Specia Functions	
Audi S6	2011-2018	4G	AC Reductant Control	Read Fault Codes	
Audi S6	2011-2018	4G	AC Reductant Control	Clear Fault Codes	
Audi S6	2011-2018	4G	AC Reductant Control	Measuring Blocks	
Audi S6	2011-2018	4G	AC Reductant Control	Output Tests	
Audi S6	2011-2018	4G	AC Reductant Control	Specia Functions	
Audi S6	2011-2018	4G	BA Motor Mounts	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S6	2011-2018	4G	BA Motor Mounts	Clear Fault Codes	
Audi S6	2011-2018	4G	BA Motor Mounts	Measuring Blocks	
Audi S6	2011-2018	4G	BA Motor Mounts	Output Tests	
Audi S6	2011-2018	4G	BA Motor Mounts	Specia Functions	
Audi S6	2011-2018	4G	C0 Act. For Ext. Noise	Read Fault Codes	
Audi S6	2011-2018	4G	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi S6	2011-2018	4G	C0 Act. For Ext. Noise	Measuring Blocks	
Audi S6	2011-2018	4G	C0 Act. For Ext. Noise	Output Tests	
Audi S6	2011-2018	4G	C0 Act. For Ext. Noise	Specia Functions	
Audi S6	2011-2018	4G	C6 Batt. Chrg	Read Fault Codes	
Audi S6	2011-2018	4G	C6 Batt. Chrg	Clear Fault Codes	
Audi S6	2011-2018	4G	C6 Batt. Chrg	Measuring Blocks	
Audi S6	2011-2018	4G	C6 Batt. Chrg	Output Tests	
Audi S6	2011-2018	4G	C6 Batt. Chrg	Specia Functions	
Audi RS6	2011-2018	4G	01 Engine Electronics	Read Fault Codes	
Audi RS6	2011-2018	4G	01 Engine Electronics	Clear Fault Codes	
Audi RS6	2011-2018	4G	01 Engine Electronics	Measuring Blocks	
Audi RS6	2011-2018	4G	01 Engine Electronics	Output Tests	
Audi RS6	2011-2018	4G	01 Engine Electronics	Specia Functions	
Audi RS6	2011-2018	4G	02 Transmission Electronics	Read Fault Codes	
Audi RS6	2011-2018	4G	02 Transmission Electronics	Clear Fault Codes	
Audi RS6	2011-2018	4G	02 Transmission Electronics	Measuring Blocks	
Audi RS6	2011-2018	4G	02 Transmission Electronics	Output Tests	
Audi RS6	2011-2018	4G	02 Transmission Electronics	Specia Functions	
Audi RS6	2011-2018	4G	03 Brake Electronics	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi RS6	2011-2018	4G	03 Brake Electronics	Clear Fault Codes	
Audi RS6	2011-2018	4G	03 Brake Electronics	Measuring Blocks	
Audi RS6	2011-2018	4G	03 Brake Electronics	Output Tests	
Audi RS6	2011-2018	4G	03 Brake Electronics	Specia Functions	
Audi RS6	2011-2018	4G	05 Access & Permissi.	Read Fault Codes	
Audi RS6	2011-2018	4G	05 Access & Permissi.	Clear Fault Codes	
Audi RS6	2011-2018	4G	05 Access & Permissi.	Measuring Blocks	
Audi RS6	2011-2018	4G	05 Access & Permissi.	Output Tests	
Audi RS6	2011-2018	4G	05 Access & Permissi.	Specia Functions	
Audi RS6	2011-2018	4G	06 Passene. Seat Adj.	Read Fault Codes	
Audi RS6	2011-2018	4G	06 Passene. Seat Adj.	Clear Fault Codes	
Audi RS6	2011-2018	4G	06 Passene. Seat Adj.	Measuring Blocks	
Audi RS6	2011-2018	4G	06 Passene. Seat Adj.	Output Tests	
Audi RS6	2011-2018	4G	06 Passene. Seat Adj.	Specia Functions	
Audi RS6	2011-2018	4G	08 AC/Heating Electronics	Read Fault Codes	
Audi RS6	2011-2018	4G	08 AC/Heating Electronics	Clear Fault Codes	
Audi RS6	2011-2018	4G	08 AC/Heating Electronics	Measuring Blocks	
Audi RS6	2011-2018	4G	08 AC/Heating Electronics	Output Tests	
Audi RS6	2011-2018	4G	08 AC/Heating Electronics	Specia Functions	
Audi RS6	2011-2018	4G	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi RS6	2011-2018	4G	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi RS6	2011-2018	4G	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi RS6	2011-2018	4G	09 Electronic Ctrl Electronics	Output Tests	
Audi RS6	2011-2018	4G	09 Electronic Ctrl Electronics	Specia Functions	
Audi RS6	2011-2018	4G	0E Media Player Position 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS6	2011-2018	4G	0E Media Player Position 1	Clear Fault Codes	
Audi RS6	2011-2018	4G	0E Media Player Position 1	Measuring Blocks	
Audi RS6	2011-2018	4G	0E Media Player Position 1	Output Tests	
Audi RS6	2011-2018	4G	0E Media Player Position 1	Specia Functions	
Audi RS6	2011-2018	4G	10 Parking Assist System 2	Read Fault Codes	
Audi RS6	2011-2018	4G	10 Parking Assist System 2	Clear Fault Codes	
Audi RS6	2011-2018	4G	10 Parking Assist System 2	Measuring Blocks	
Audi RS6	2011-2018	4G	10 Parking Assist System 2	Output Tests	
Audi RS6	2011-2018	4G	10 Parking Assist System 2	Specia Functions	
Audi RS6	2011-2018	4G	13 Distance Control	Read Fault Codes	
Audi RS6	2011-2018	4G	13 Distance Control	Clear Fault Codes	
Audi RS6	2011-2018	4G	13 Distance Control	Measuring Blocks	
Audi RS6	2011-2018	4G	13 Distance Control	Output Tests	
Audi RS6	2011-2018	4G	13 Distance Control	Specia Functions	
Audi RS6	2011-2018	4G	14 Wheel Damping Electronics	Read Fault Codes	
Audi RS6	2011-2018	4G	14 Wheel Damping Electronics	Clear Fault Codes	
Audi RS6	2011-2018	4G	14 Wheel Damping Electronics	Measuring Blocks	
Audi RS6	2011-2018	4G	14 Wheel Damping Electronics	Output Tests	
Audi RS6	2011-2018	4G	14 Wheel Damping Electronics	Specia Functions	
Audi RS6	2011-2018	4G	15 Airbags	Read Fault Codes	
Audi RS6	2011-2018	4G	15 Airbags	Clear Fault Codes	
Audi RS6	2011-2018	4G	15 Airbags	Measuring Blocks	
Audi RS6	2011-2018	4G	15 Airbags	Output Tests	
Audi RS6	2011-2018	4G	15 Airbags	Specia Functions	
Audi RS6	2011-2018	4G	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2011-2018	4G	16 Steering Wheel Electronics	Clear Fault Codes	
Audi RS6	2011-2018	4G	16 Steering Wheel Electronics	Measuring Blocks	
Audi RS6	2011-2018	4G	16 Steering Wheel Electronics	Output Tests	
Audi RS6	2011-2018	4G	16 Steering Wheel Electronics	Specia Functions	
Audi RS6	2011-2018	4G	17 Instrument Cluster	Read Fault Codes	
Audi RS6	2011-2018	4G	17 Instrument Cluster	Clear Fault Codes	
Audi RS6	2011-2018	4G	17 Instrument Cluster	Measuring Blocks	
Audi RS6	2011-2018	4G	17 Instrument Cluster	Output Tests	
Audi RS6	2011-2018	4G	17 Instrument Cluster	Specia Functions	
Audi RS6	2011-2018	4G	18 Aux Heating	Read Fault Codes	
Audi RS6	2011-2018	4G	18 Aux Heating	Clear Fault Codes	
Audi RS6	2011-2018	4G	18 Aux Heating	Measuring Blocks	
Audi RS6	2011-2018	4G	18 Aux Heating	Output Tests	
Audi RS6	2011-2018	4G	18 Aux Heating	Specia Functions	
Audi RS6	2011-2018	4G	19 Gateway Data Bus	Read Fault Codes	
Audi RS6	2011-2018	4G	19 Gateway Data Bus	Clear Fault Codes	
Audi RS6	2011-2018	4G	19 Gateway Data Bus	Measuring Blocks	
Audi RS6	2011-2018	4G	19 Gateway Data Bus	Output Tests	
Audi RS6	2011-2018	4G	19 Gateway Data Bus	Specia Functions	
Audi RS6	2011-2018	4G	1B Power-Assisted Steering	Read Fault Codes	
Audi RS6	2011-2018	4G	1B Power-Assisted Steering	Clear Fault Codes	
Audi RS6	2011-2018	4G	1B Power-Assisted Steering	Measuring Blocks	
Audi RS6	2011-2018	4G	1B Power-Assisted Steering	Output Tests	
Audi RS6	2011-2018	4G	1B Power-Assisted Steering	Specia Functions	
Audi RS6	2011-2018	4G	20 High Beam Assistance Device	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS6	2011-2018	4G	20 High Beam Assistance Device	Clear Fault Codes	
Audi RS6	2011-2018	4G	20 High Beam Assistance Device	Measuring Blocks	
Audi RS6	2011-2018	4G	20 High Beam Assistance Device	Output Tests	
Audi RS6	2011-2018	4G	20 High Beam Assistance Device	Specia Functions	
Audi RS6	2011-2018	4G	22 4WD Electronics	Read Fault Codes	
Audi RS6	2011-2018	4G	22 4WD Electronics	Clear Fault Codes	
Audi RS6	2011-2018	4G	22 4WD Electronics	Measuring Blocks	
Audi RS6	2011-2018	4G	22 4WD Electronics	Output Tests	
Audi RS6	2011-2018	4G	22 4WD Electronics	Specia Functions	
Audi RS6	2011-2018	4G	28 Climate Control Unit Rear	Read Fault Codes	
Audi RS6	2011-2018	4G	28 Climate Control Unit Rear	Clear Fault Codes	
Audi RS6	2011-2018	4G	28 Climate Control Unit Rear	Measuring Blocks	
Audi RS6	2011-2018	4G	28 Climate Control Unit Rear	Output Tests	
Audi RS6	2011-2018	4G	28 Climate Control Unit Rear	Specia Functions	
Audi RS6	2011-2018	4G	30 Special Function 2	Read Fault Codes	
Audi RS6	2011-2018	4G	30 Special Function 2	Clear Fault Codes	
Audi RS6	2011-2018	4G	30 Special Function 2	Measuring Blocks	
Audi RS6	2011-2018	4G	30 Special Function 2	Output Tests	
Audi RS6	2011-2018	4G	30 Special Function 2	Specia Functions	
Audi RS6	2011-2018	4G	34 Self Leveling Suspension	Read Fault Codes	
Audi RS6	2011-2018	4G	34 Self Leveling Suspension	Clear Fault Codes	
Audi RS6	2011-2018	4G	34 Self Leveling Suspension	Measuring Blocks	
Audi RS6	2011-2018	4G	34 Self Leveling Suspension	Output Tests	
Audi RS6	2011-2018	4G	34 Self Leveling Suspension	Specia Functions	
Audi RS6	2011-2018	4G	36 Side of Driver Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi RS6	2011-2018	4G	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi RS6	2011-2018	4G	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi RS6	2011-2018	4G	36 Side of Driver Seat Adj.	Output Tests	
Audi RS6	2011-2018	4G	36 Side of Driver Seat Adj.	Specia Functions	
Audi RS6	2011-2018	4G	3B Sensor Elect.	Read Fault Codes	
Audi RS6	2011-2018	4G	3B Sensor Elect.	Clear Fault Codes	
Audi RS6	2011-2018	4G	3B Sensor Elect.	Measuring Blocks	
Audi RS6	2011-2018	4G	3B Sensor Elect.	Output Tests	
Audi RS6	2011-2018	4G	3B Sensor Elect.	Specia Functions	
Audi RS6	2011-2018	4G	3C Lane Departure Assistance System	Read Fault Codes	
Audi RS6	2011-2018	4G	3C Lane Departure Assistance System	Clear Fault Codes	
Audi RS6	2011-2018	4G	3C Lane Departure Assistance System	Measuring Blocks	
Audi RS6	2011-2018	4G	3C Lane Departure Assistance System	Output Tests	
Audi RS6	2011-2018	4G	3C Lane Departure Assistance System	Specia Functions	
Audi RS6	2011-2018	4G	3D Special Function	Read Fault Codes	
Audi RS6	2011-2018	4G	3D Special Function	Clear Fault Codes	
Audi RS6	2011-2018	4G	3D Special Function	Measuring Blocks	
Audi RS6	2011-2018	4G	3D Special Function	Output Tests	
Audi RS6	2011-2018	4G	3D Special Function	Specia Functions	
Audi RS6	2011-2018	4G	40 Air Compressor	Read Fault Codes	
Audi RS6	2011-2018	4G	40 Air Compressor	Clear Fault Codes	
Audi RS6	2011-2018	4G	40 Air Compressor	Measuring Blocks	
Audi RS6	2011-2018	4G	40 Air Compressor	Output Tests	
Audi RS6	2011-2018	4G	40 Air Compressor	Specia Functions	
Audi RS6	2011-2018	4G	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2011-2018	4G	42 Driver-Door Elect.	Clear Fault Codes	
Audi RS6	2011-2018	4G	42 Driver-Door Elect.	Measuring Blocks	
Audi RS6	2011-2018	4G	42 Driver-Door Elect.	Output Tests	
Audi RS6	2011-2018	4G	42 Driver-Door Elect.	Specia Functions	
Audi RS6	2011-2018	4G	44 Steering Assistance	Read Fault Codes	
Audi RS6	2011-2018	4G	44 Steering Assistance	Clear Fault Codes	
Audi RS6	2011-2018	4G	44 Steering Assistance	Measuring Blocks	
Audi RS6	2011-2018	4G	44 Steering Assistance	Output Tests	
Audi RS6	2011-2018	4G	44 Steering Assistance	Specia Functions	
Audi RS6	2011-2018	4G	46 Central Control Module	Read Fault Codes	
Audi RS6	2011-2018	4G	46 Central Control Module	Clear Fault Codes	
Audi RS6	2011-2018	4G	46 Central Control Module	Measuring Blocks	
Audi RS6	2011-2018	4G	46 Central Control Module	Output Tests	
Audi RS6	2011-2018	4G	46 Central Control Module	Specia Functions	
Audi RS6	2011-2018	4G	47 Soundsystem	Read Fault Codes	
Audi RS6	2011-2018	4G	47 Soundsystem	Clear Fault Codes	
Audi RS6	2011-2018	4G	47 Soundsystem	Measuring Blocks	
Audi RS6	2011-2018	4G	47 Soundsystem	Output Tests	
Audi RS6	2011-2018	4G	47 Soundsystem	Specia Functions	
Audi RS6	2011-2018	4G	4E Control Head RR	Read Fault Codes	
Audi RS6	2011-2018	4G	4E Control Head RR	Clear Fault Codes	
Audi RS6	2011-2018	4G	4E Control Head RR	Measuring Blocks	
Audi RS6	2011-2018	4G	4E Control Head RR	Output Tests	
Audi RS6	2011-2018	4G	4E Control Head RR	Specia Functions	
Audi RS6	2011-2018	4G	51 Electric Drive	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2011-2018	4G	51 Electric Drive	Clear Fault Codes	
Audi RS6	2011-2018	4G	51 Electric Drive	Measuring Blocks	
Audi RS6	2011-2018	4G	51 Electric Drive	Output Tests	
Audi RS6	2011-2018	4G	51 Electric Drive	Specia Functions	
Audi RS6	2011-2018	4G	52 Passe.-Door Elect.	Read Fault Codes	
Audi RS6	2011-2018	4G	52 Passe.-Door Elect.	Clear Fault Codes	
Audi RS6	2011-2018	4G	52 Passe.-Door Elect.	Measuring Blocks	
Audi RS6	2011-2018	4G	52 Passe.-Door Elect.	Output Tests	
Audi RS6	2011-2018	4G	52 Passe.-Door Elect.	Specia Functions	
Audi RS6	2011-2018	4G	53 Parking Brake	Read Fault Codes	
Audi RS6	2011-2018	4G	53 Parking Brake	Clear Fault Codes	
Audi RS6	2011-2018	4G	53 Parking Brake	Measuring Blocks	
Audi RS6	2011-2018	4G	53 Parking Brake	Output Tests	
Audi RS6	2011-2018	4G	53 Parking Brake	Specia Functions	
Audi RS6	2011-2018	4G	55 Headlight Range Control	Read Fault Codes	
Audi RS6	2011-2018	4G	55 Headlight Range Control	Clear Fault Codes	
Audi RS6	2011-2018	4G	55 Headlight Range Control	Measuring Blocks	
Audi RS6	2011-2018	4G	55 Headlight Range Control	Output Tests	
Audi RS6	2011-2018	4G	55 Headlight Range Control	Specia Functions	
Audi RS6	2011-2018	4G	56 Radio	Read Fault Codes	
Audi RS6	2011-2018	4G	56 Radio	Clear Fault Codes	
Audi RS6	2011-2018	4G	56 Radio	Measuring Blocks	
Audi RS6	2011-2018	4G	56 Radio	Output Tests	
Audi RS6	2011-2018	4G	56 Radio	Specia Functions	
Audi RS6	2011-2018	4G	57 TV-Tuner	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2011-2018	4G	57 TV-Tuner	Clear Fault Codes	
Audi RS6	2011-2018	4G	57 TV-Tuner	Measuring Blocks	
Audi RS6	2011-2018	4G	57 TV-Tuner	Output Tests	
Audi RS6	2011-2018	4G	57 TV-Tuner	Specia Functions	
Audi RS6	2011-2018	4G	5E Control Head LR	Read Fault Codes	
Audi RS6	2011-2018	4G	5E Control Head LR	Clear Fault Codes	
Audi RS6	2011-2018	4G	5E Control Head LR	Measuring Blocks	
Audi RS6	2011-2018	4G	5E Control Head LR	Output Tests	
Audi RS6	2011-2018	4G	5E Control Head LR	Specia Functions	
Audi RS6	2011-2018	4G	5F Information Electronic Equipment 1	Read Fault Codes	
Audi RS6	2011-2018	4G	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi RS6	2011-2018	4G	5F Information Electronic Equipment 1	Measuring Blocks	
Audi RS6	2011-2018	4G	5F Information Electronic Equipment 1	Output Tests	
Audi RS6	2011-2018	4G	5F Information Electronic Equipment 1	Specia Functions	
Audi RS6	2011-2018	4G	62 LR-Door Electroni.	Read Fault Codes	
Audi RS6	2011-2018	4G	62 LR-Door Electroni.	Clear Fault Codes	
Audi RS6	2011-2018	4G	62 LR-Door Electroni.	Measuring Blocks	
Audi RS6	2011-2018	4G	62 LR-Door Electroni.	Output Tests	
Audi RS6	2011-2018	4G	62 LR-Door Electroni.	Specia Functions	
Audi RS6	2011-2018	4G	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi RS6	2011-2018	4G	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi RS6	2011-2018	4G	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi RS6	2011-2018	4G	65 Tyre Pressure Monitoring	Output Tests	
Audi RS6	2011-2018	4G	65 Tyre Pressure Monitoring	Specia Functions	
Audi RS6	2011-2018	4G	69 Trailer Function	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi RS6	2011-2018	4G	69 Trailer Function	Clear Fault Codes	
Audi RS6	2011-2018	4G	69 Trailer Function	Measuring Blocks	
Audi RS6	2011-2018	4G	69 Trailer Function	Output Tests	
Audi RS6	2011-2018	4G	69 Trailer Function	Specia Functions	
Audi RS6	2011-2018	4G	6C Rear Camera	Read Fault Codes	
Audi RS6	2011-2018	4G	6C Rear Camera	Clear Fault Codes	
Audi RS6	2011-2018	4G	6C Rear Camera	Measuring Blocks	
Audi RS6	2011-2018	4G	6C Rear Camera	Output Tests	
Audi RS6	2011-2018	4G	6C Rear Camera	Specia Functions	
Audi RS6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi RS6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi RS6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi RS6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi RS6	2011-2018	4G	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi RS6	2011-2018	4G	72 RR-Door Electroni.	Read Fault Codes	
Audi RS6	2011-2018	4G	72 RR-Door Electroni.	Clear Fault Codes	
Audi RS6	2011-2018	4G	72 RR-Door Electroni.	Measuring Blocks	
Audi RS6	2011-2018	4G	72 RR-Door Electroni.	Output Tests	
Audi RS6	2011-2018	4G	72 RR-Door Electroni.	Specia Functions	
Audi RS6	2011-2018	4G	7F Information Electronic Equipment 2	Read Fault Codes	
Audi RS6	2011-2018	4G	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi RS6	2011-2018	4G	7F Information Electronic Equipment 2	Measuring Blocks	
Audi RS6	2011-2018	4G	7F Information Electronic Equipment 2	Output Tests	
Audi RS6	2011-2018	4G	7F Information Electronic Equipment 2	Specia Functions	
Audi RS6	2011-2018	4G	82 Heads Up Display	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2011-2018	4G	82 Heads Up Display	Clear Fault Codes	
Audi RS6	2011-2018	4G	82 Heads Up Display	Measuring Blocks	
Audi RS6	2011-2018	4G	82 Heads Up Display	Output Tests	
Audi RS6	2011-2018	4G	82 Heads Up Display	Specia Functions	
Audi RS6	2011-2018	4G	84 Night Vision	Read Fault Codes	
Audi RS6	2011-2018	4G	84 Night Vision	Clear Fault Codes	
Audi RS6	2011-2018	4G	84 Night Vision	Measuring Blocks	
Audi RS6	2011-2018	4G	84 Night Vision	Output Tests	
Audi RS6	2011-2018	4G	84 Night Vision	Specia Functions	
Audi RS6	2011-2018	4G	85 On Board Cam.	Read Fault Codes	
Audi RS6	2011-2018	4G	85 On Board Cam.	Clear Fault Codes	
Audi RS6	2011-2018	4G	85 On Board Cam.	Measuring Blocks	
Audi RS6	2011-2018	4G	85 On Board Cam.	Output Tests	
Audi RS6	2011-2018	4G	85 On Board Cam.	Specia Functions	
Audi RS6	2011-2018	4G	88 Multicont. Seat Driver	Read Fault Codes	
Audi RS6	2011-2018	4G	88 Multicont. Seat Driver	Clear Fault Codes	
Audi RS6	2011-2018	4G	88 Multicont. Seat Driver	Measuring Blocks	
Audi RS6	2011-2018	4G	88 Multicont. Seat Driver	Output Tests	
Audi RS6	2011-2018	4G	88 Multicont. Seat Driver	Specia Functions	
Audi RS6	2011-2018	4G	89 Multicont. Seat Driver	Read Fault Codes	
Audi RS6	2011-2018	4G	89 Multicont. Seat Driver	Clear Fault Codes	
Audi RS6	2011-2018	4G	89 Multicont. Seat Driver	Measuring Blocks	
Audi RS6	2011-2018	4G	89 Multicont. Seat Driver	Output Tests	
Audi RS6	2011-2018	4G	89 Multicont. Seat Driver	Specia Functions	
Audi RS6	2011-2018	4G	8A Multicont. Seat Rear, DS	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2011-2018	4G	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi RS6	2011-2018	4G	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi RS6	2011-2018	4G	8A Multicont. Seat Rear, DS	Output Tests	
Audi RS6	2011-2018	4G	8A Multicont. Seat Rear, DS	Specia Functions	
Audi RS6	2011-2018	4G	8B Adaptive Cruise 2	Read Fault Codes	
Audi RS6	2011-2018	4G	8B Adaptive Cruise 2	Clear Fault Codes	
Audi RS6	2011-2018	4G	8B Adaptive Cruise 2	Measuring Blocks	
Audi RS6	2011-2018	4G	8B Adaptive Cruise 2	Output Tests	
Audi RS6	2011-2018	4G	8B Adaptive Cruise 2	Specia Functions	
Audi RS6	2011-2018	4G	8C Hybrid Battery	Read Fault Codes	
Audi RS6	2011-2018	4G	8C Hybrid Battery	Clear Fault Codes	
Audi RS6	2011-2018	4G	8C Hybrid Battery	Measuring Blocks	
Audi RS6	2011-2018	4G	8C Hybrid Battery	Output Tests	
Audi RS6	2011-2018	4G	8C Hybrid Battery	Specia Functions	
Audi RS6	2011-2018	4G	8D Multicont.Seat Rear,PS	Read Fault Codes	
Audi RS6	2011-2018	4G	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi RS6	2011-2018	4G	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi RS6	2011-2018	4G	8D Multicont.Seat Rear,PS	Output Tests	
Audi RS6	2011-2018	4G	8D Multicont.Seat Rear,PS	Specia Functions	
Audi RS6	2011-2018	4G	8E Image Processing	Read Fault Codes	
Audi RS6	2011-2018	4G	8E Image Processing	Clear Fault Codes	
Audi RS6	2011-2018	4G	8E Image Processing	Measuring Blocks	
Audi RS6	2011-2018	4G	8E Image Processing	Output Tests	
Audi RS6	2011-2018	4G	8E Image Processing	Specia Functions	
Audi RS6	2011-2018	4G	8F Pretens. Frt Left	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2011-2018	4G	8F Pretens. Frt Left	Clear Fault Codes	
Audi RS6	2011-2018	4G	8F Pretens. Frt Left	Measuring Blocks	
Audi RS6	2011-2018	4G	8F Pretens. Frt Left	Output Tests	
Audi RS6	2011-2018	4G	8F Pretens. Frt Left	Specia Functions	
Audi RS6	2011-2018	4G	90 Pretens. Frt Right	Read Fault Codes	
Audi RS6	2011-2018	4G	90 Pretens. Frt Right	Clear Fault Codes	
Audi RS6	2011-2018	4G	90 Pretens. Frt Right	Measuring Blocks	
Audi RS6	2011-2018	4G	90 Pretens. Frt Right	Output Tests	
Audi RS6	2011-2018	4G	90 Pretens. Frt Right	Specia Functions	
Audi RS6	2011-2018	4G	A9 Struct.Borne Sound	Read Fault Codes	
Audi RS6	2011-2018	4G	A9 Struct.Borne Sound	Clear Fault Codes	
Audi RS6	2011-2018	4G	A9 Struct.Borne Sound	Measuring Blocks	
Audi RS6	2011-2018	4G	A9 Struct.Borne Sound	Output Tests	
Audi RS6	2011-2018	4G	A9 Struct.Borne Sound	Specia Functions	
Audi RS6	2011-2018	4G	AC Reductant Control	Read Fault Codes	
Audi RS6	2011-2018	4G	AC Reductant Control	Clear Fault Codes	
Audi RS6	2011-2018	4G	AC Reductant Control	Measuring Blocks	
Audi RS6	2011-2018	4G	AC Reductant Control	Output Tests	
Audi RS6	2011-2018	4G	AC Reductant Control	Specia Functions	
Audi RS6	2011-2018	4G	BA Motor Mounts	Read Fault Codes	
Audi RS6	2011-2018	4G	BA Motor Mounts	Clear Fault Codes	
Audi RS6	2011-2018	4G	BA Motor Mounts	Measuring Blocks	
Audi RS6	2011-2018	4G	BA Motor Mounts	Output Tests	
Audi RS6	2011-2018	4G	BA Motor Mounts	Specia Functions	
Audi RS6	2011-2018	4G	C0 Act. For Ext. Noise	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi RS6	2011-2018	4G	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi RS6	2011-2018	4G	C0 Act. For Ext. Noise	Measuring Blocks	
Audi RS6	2011-2018	4G	C0 Act. For Ext. Noise	Output Tests	
Audi RS6	2011-2018	4G	C0 Act. For Ext. Noise	Specia Functions	
Audi RS6	2011-2018	4G	C6 Batt. Chrg	Read Fault Codes	
Audi RS6	2011-2018	4G	C6 Batt. Chrg	Clear Fault Codes	
Audi RS6	2011-2018	4G	C6 Batt. Chrg	Measuring Blocks	
Audi RS6	2011-2018	4G	C6 Batt. Chrg	Output Tests	
Audi RS6	2011-2018	4G	C6 Batt. Chrg	Specia Functions	
Audi A8	2010-2018	4H	01 Engine Electronics	Read Fault Codes	
Audi A8	2010-2018	4H	01 Engine Electronics	Clear Fault Codes	
Audi A8	2010-2018	4H	01 Engine Electronics	Measuring Blocks	
Audi A8	2010-2018	4H	01 Engine Electronics	Output Tests	
Audi A8	2010-2018	4H	01 Engine Electronics	Specia Functions	
Audi A8	2010-2018	4H	02 Transmission Electronics	Read Fault Codes	
Audi A8	2010-2018	4H	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2010-2018	4H	02 Transmission Electronics	Measuring Blocks	
Audi A8	2010-2018	4H	02 Transmission Electronics	Output Tests	
Audi A8	2010-2018	4H	02 Transmission Electronics	Specia Functions	
Audi A8	2010-2018	4H	03 Brake Electronics	Read Fault Codes	
Audi A8	2010-2018	4H	03 Brake Electronics	Clear Fault Codes	
Audi A8	2010-2018	4H	03 Brake Electronics	Measuring Blocks	
Audi A8	2010-2018	4H	03 Brake Electronics	Output Tests	
Audi A8	2010-2018	4H	03 Brake Electronics	Specia Functions	
Audi A8	2010-2018	4H	05 Access & Permissi.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2010-2018	4H	05 Access & Permissi.	Clear Fault Codes	
Audi A8	2010-2018	4H	05 Access & Permissi.	Measuring Blocks	
Audi A8	2010-2018	4H	05 Access & Permissi.	Output Tests	
Audi A8	2010-2018	4H	05 Access & Permissi.	Specia Functions	
Audi A8	2010-2018	4H	06 Passene. Seat Adj.	Read Fault Codes	
Audi A8	2010-2018	4H	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A8	2010-2018	4H	06 Passene. Seat Adj.	Measuring Blocks	
Audi A8	2010-2018	4H	06 Passene. Seat Adj.	Output Tests	
Audi A8	2010-2018	4H	06 Passene. Seat Adj.	Specia Functions	
Audi A8	2010-2018	4H	08 AC/Heating Electronics	Read Fault Codes	
Audi A8	2010-2018	4H	08 AC/Heating Electronics	Clear Fault Codes	
Audi A8	2010-2018	4H	08 AC/Heating Electronics	Measuring Blocks	
Audi A8	2010-2018	4H	08 AC/Heating Electronics	Output Tests	
Audi A8	2010-2018	4H	08 AC/Heating Electronics	Specia Functions	
Audi A8	2010-2018	4H	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A8	2010-2018	4H	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A8	2010-2018	4H	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A8	2010-2018	4H	09 Electronic Ctrl Electronics	Output Tests	
Audi A8	2010-2018	4H	09 Electronic Ctrl Electronics	Specia Functions	
Audi A8	2010-2018	4H	0E Media Player Position 1	Read Fault Codes	
Audi A8	2010-2018	4H	0E Media Player Position 1	Clear Fault Codes	
Audi A8	2010-2018	4H	0E Media Player Position 1	Measuring Blocks	
Audi A8	2010-2018	4H	0E Media Player Position 1	Output Tests	
Audi A8	2010-2018	4H	0E Media Player Position 1	Specia Functions	
Audi A8	2010-2018	4H	10 Parking Assist System 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2010-2018	4H	10 Parking Assist System 2	Clear Fault Codes	
Audi A8	2010-2018	4H	10 Parking Assist System 2	Measuring Blocks	
Audi A8	2010-2018	4H	10 Parking Assist System 2	Output Tests	
Audi A8	2010-2018	4H	10 Parking Assist System 2	Specia Functions	
Audi A8	2010-2018	4H	11 Engine Electronics 2	Read Fault Codes	
Audi A8	2010-2018	4H	11 Engine Electronics 2	Clear Fault Codes	
Audi A8	2010-2018	4H	11 Engine Electronics 2	Measuring Blocks	
Audi A8	2010-2018	4H	11 Engine Electronics 2	Output Tests	
Audi A8	2010-2018	4H	11 Engine Electronics 2	Specia Functions	
Audi A8	2010-2018	4H	13 Distance Control	Read Fault Codes	
Audi A8	2010-2018	4H	13 Distance Control	Clear Fault Codes	
Audi A8	2010-2018	4H	13 Distance Control	Measuring Blocks	
Audi A8	2010-2018	4H	13 Distance Control	Output Tests	
Audi A8	2010-2018	4H	13 Distance Control	Specia Functions	
Audi A8	2010-2018	4H	15 Airbags	Read Fault Codes	
Audi A8	2010-2018	4H	15 Airbags	Clear Fault Codes	
Audi A8	2010-2018	4H	15 Airbags	Measuring Blocks	
Audi A8	2010-2018	4H	15 Airbags	Output Tests	
Audi A8	2010-2018	4H	15 Airbags	Specia Functions	
Audi A8	2010-2018	4H	16 Steering Wheel Electronics	Read Fault Codes	
Audi A8	2010-2018	4H	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2010-2018	4H	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2010-2018	4H	16 Steering Wheel Electronics	Output Tests	
Audi A8	2010-2018	4H	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2010-2018	4H	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2010-2018	4H	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2010-2018	4H	17 Instrument Cluster	Measuring Blocks	
Audi A8	2010-2018	4H	17 Instrument Cluster	Output Tests	
Audi A8	2010-2018	4H	17 Instrument Cluster	Specia Functions	
Audi A8	2010-2018	4H	18 Aux Heating	Read Fault Codes	
Audi A8	2010-2018	4H	18 Aux Heating	Clear Fault Codes	
Audi A8	2010-2018	4H	18 Aux Heating	Measuring Blocks	
Audi A8	2010-2018	4H	18 Aux Heating	Output Tests	
Audi A8	2010-2018	4H	18 Aux Heating	Specia Functions	
Audi A8	2010-2018	4H	19 Gateway Data Bus	Read Fault Codes	
Audi A8	2010-2018	4H	19 Gateway Data Bus	Clear Fault Codes	
Audi A8	2010-2018	4H	19 Gateway Data Bus	Measuring Blocks	
Audi A8	2010-2018	4H	19 Gateway Data Bus	Output Tests	
Audi A8	2010-2018	4H	19 Gateway Data Bus	Specia Functions	
Audi A8	2010-2018	4H	1B Power-Assisted Steering	Read Fault Codes	
Audi A8	2010-2018	4H	1B Power-Assisted Steering	Clear Fault Codes	
Audi A8	2010-2018	4H	1B Power-Assisted Steering	Measuring Blocks	
Audi A8	2010-2018	4H	1B Power-Assisted Steering	Output Tests	
Audi A8	2010-2018	4H	1B Power-Assisted Steering	Specia Functions	
Audi A8	2010-2018	4H	20 High Beam Assistance Device	Read Fault Codes	
Audi A8	2010-2018	4H	20 High Beam Assistance Device	Clear Fault Codes	
Audi A8	2010-2018	4H	20 High Beam Assistance Device	Measuring Blocks	
Audi A8	2010-2018	4H	20 High Beam Assistance Device	Output Tests	
Audi A8	2010-2018	4H	20 High Beam Assistance Device	Specia Functions	
Audi A8	2010-2018	4H	22 4WD Electronics	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi A8	2010-2018	4H	22 4WD Electronics	Clear Fault Codes	
Audi A8	2010-2018	4H	22 4WD Electronics	Measuring Blocks	
Audi A8	2010-2018	4H	22 4WD Electronics	Output Tests	
Audi A8	2010-2018	4H	22 4WD Electronics	Specia Functions	
Audi A8	2010-2018	4H	28 Climate Control Unit Rear	Read Fault Codes	
Audi A8	2010-2018	4H	28 Climate Control Unit Rear	Clear Fault Codes	
Audi A8	2010-2018	4H	28 Climate Control Unit Rear	Measuring Blocks	
Audi A8	2010-2018	4H	28 Climate Control Unit Rear	Output Tests	
Audi A8	2010-2018	4H	28 Climate Control Unit Rear	Specia Functions	
Audi A8	2010-2018	4H	30 Special Function 2	Read Fault Codes	
Audi A8	2010-2018	4H	30 Special Function 2	Clear Fault Codes	
Audi A8	2010-2018	4H	30 Special Function 2	Measuring Blocks	
Audi A8	2010-2018	4H	30 Special Function 2	Output Tests	
Audi A8	2010-2018	4H	30 Special Function 2	Specia Functions	
Audi A8	2010-2018	4H	34 Self Leveling Suspension	Read Fault Codes	
Audi A8	2010-2018	4H	34 Self Leveling Suspension	Clear Fault Codes	
Audi A8	2010-2018	4H	34 Self Leveling Suspension	Measuring Blocks	
Audi A8	2010-2018	4H	34 Self Leveling Suspension	Output Tests	
Audi A8	2010-2018	4H	34 Self Leveling Suspension	Specia Functions	
Audi A8	2010-2018	4H	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi A8	2010-2018	4H	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi A8	2010-2018	4H	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi A8	2010-2018	4H	36 Side of Driver Seat Adj.	Output Tests	
Audi A8	2010-2018	4H	36 Side of Driver Seat Adj.	Specia Functions	
Audi A8	2010-2018	4H	3B Sensor Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2010-2018	4H	3B Sensor Elect.	Clear Fault Codes	
Audi A8	2010-2018	4H	3B Sensor Elect.	Measuring Blocks	
Audi A8	2010-2018	4H	3B Sensor Elect.	Output Tests	
Audi A8	2010-2018	4H	3B Sensor Elect.	Specia Functions	
Audi A8	2010-2018	4H	3C Lane Departure Assistance System	Read Fault Codes	
Audi A8	2010-2018	4H	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A8	2010-2018	4H	3C Lane Departure Assistance System	Measuring Blocks	
Audi A8	2010-2018	4H	3C Lane Departure Assistance System	Output Tests	
Audi A8	2010-2018	4H	3C Lane Departure Assistance System	Specia Functions	
Audi A8	2010-2018	4H	3D Special Function	Read Fault Codes	
Audi A8	2010-2018	4H	3D Special Function	Clear Fault Codes	
Audi A8	2010-2018	4H	3D Special Function	Measuring Blocks	
Audi A8	2010-2018	4H	3D Special Function	Output Tests	
Audi A8	2010-2018	4H	3D Special Function	Specia Functions	
Audi A8	2010-2018	4H	40 Air Compressor	Read Fault Codes	
Audi A8	2010-2018	4H	40 Air Compressor	Clear Fault Codes	
Audi A8	2010-2018	4H	40 Air Compressor	Measuring Blocks	
Audi A8	2010-2018	4H	40 Air Compressor	Output Tests	
Audi A8	2010-2018	4H	40 Air Compressor	Specia Functions	
Audi A8	2010-2018	4H	42 Driver-Door Elect.	Read Fault Codes	
Audi A8	2010-2018	4H	42 Driver-Door Elect.	Clear Fault Codes	
Audi A8	2010-2018	4H	42 Driver-Door Elect.	Measuring Blocks	
Audi A8	2010-2018	4H	42 Driver-Door Elect.	Output Tests	
Audi A8	2010-2018	4H	42 Driver-Door Elect.	Specia Functions	
Audi A8	2010-2018	4H	44 Steering Assistance	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2010-2018	4H	44 Steering Assistance	Clear Fault Codes	
Audi A8	2010-2018	4H	44 Steering Assistance	Measuring Blocks	
Audi A8	2010-2018	4H	44 Steering Assistance	Output Tests	
Audi A8	2010-2018	4H	44 Steering Assistance	Specia Functions	
Audi A8	2010-2018	4H	46 Central Control Module	Read Fault Codes	
Audi A8	2010-2018	4H	46 Central Control Module	Clear Fault Codes	
Audi A8	2010-2018	4H	46 Central Control Module	Measuring Blocks	
Audi A8	2010-2018	4H	46 Central Control Module	Output Tests	
Audi A8	2010-2018	4H	46 Central Control Module	Specia Functions	
Audi A8	2010-2018	4H	47 Soundsystem	Read Fault Codes	
Audi A8	2010-2018	4H	47 Soundsystem	Clear Fault Codes	
Audi A8	2010-2018	4H	47 Soundsystem	Measuring Blocks	
Audi A8	2010-2018	4H	47 Soundsystem	Output Tests	
Audi A8	2010-2018	4H	47 Soundsystem	Specia Functions	
Audi A8	2010-2018	4H	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi A8	2010-2018	4H	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A8	2010-2018	4H	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A8	2010-2018	4H	48 Drvs Seat Adj.Rear	Output Tests	
Audi A8	2010-2018	4H	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A8	2010-2018	4H	51 Electric Drive	Read Fault Codes	
Audi A8	2010-2018	4H	51 Electric Drive	Clear Fault Codes	
Audi A8	2010-2018	4H	51 Electric Drive	Measuring Blocks	
Audi A8	2010-2018	4H	51 Electric Drive	Output Tests	
Audi A8	2010-2018	4H	51 Electric Drive	Specia Functions	
Audi A8	2010-2018	4H	52 Passe.-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2010-2018	4H	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A8	2010-2018	4H	52 Passe.-Door Elect.	Measuring Blocks	
Audi A8	2010-2018	4H	52 Passe.-Door Elect.	Output Tests	
Audi A8	2010-2018	4H	52 Passe.-Door Elect.	Specia Functions	
Audi A8	2010-2018	4H	53 Parking Brake	Read Fault Codes	
Audi A8	2010-2018	4H	53 Parking Brake	Clear Fault Codes	
Audi A8	2010-2018	4H	53 Parking Brake	Measuring Blocks	
Audi A8	2010-2018	4H	53 Parking Brake	Output Tests	
Audi A8	2010-2018	4H	53 Parking Brake	Specia Functions	
Audi A8	2010-2018	4H	55 Headlight Range Control	Read Fault Codes	
Audi A8	2010-2018	4H	55 Headlight Range Control	Clear Fault Codes	
Audi A8	2010-2018	4H	55 Headlight Range Control	Measuring Blocks	
Audi A8	2010-2018	4H	55 Headlight Range Control	Output Tests	
Audi A8	2010-2018	4H	55 Headlight Range Control	Specia Functions	
Audi A8	2010-2018	4H	56 Radio	Read Fault Codes	
Audi A8	2010-2018	4H	56 Radio	Clear Fault Codes	
Audi A8	2010-2018	4H	56 Radio	Measuring Blocks	
Audi A8	2010-2018	4H	56 Radio	Output Tests	
Audi A8	2010-2018	4H	56 Radio	Specia Functions	
Audi A8	2010-2018	4H	57 TV-Tuner	Read Fault Codes	
Audi A8	2010-2018	4H	57 TV-Tuner	Clear Fault Codes	
Audi A8	2010-2018	4H	57 TV-Tuner	Measuring Blocks	
Audi A8	2010-2018	4H	57 TV-Tuner	Output Tests	
Audi A8	2010-2018	4H	57 TV-Tuner	Specia Functions	
Audi A8	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Clear Fault Codes	
Audi A8	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Measuring Blocks	
Audi A8	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Output Tests	
Audi A8	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Specia Functions	
Audi A8	2010-2018	4H	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A8	2010-2018	4H	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A8	2010-2018	4H	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A8	2010-2018	4H	5F Information Electronic Equipment 1	Output Tests	
Audi A8	2010-2018	4H	5F Information Electronic Equipment 1	Specia Functions	
Audi A8	2010-2018	4H	62 LR-Door Electroni.	Read Fault Codes	
Audi A8	2010-2018	4H	62 LR-Door Electroni.	Clear Fault Codes	
Audi A8	2010-2018	4H	62 LR-Door Electroni.	Measuring Blocks	
Audi A8	2010-2018	4H	62 LR-Door Electroni.	Output Tests	
Audi A8	2010-2018	4H	62 LR-Door Electroni.	Specia Functions	
Audi A8	2010-2018	4H	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8	2010-2018	4H	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8	2010-2018	4H	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8	2010-2018	4H	65 Tyre Pressure Monitoring	Output Tests	
Audi A8	2010-2018	4H	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8	2010-2018	4H	69 Trailer Function	Read Fault Codes	
Audi A8	2010-2018	4H	69 Trailer Function	Clear Fault Codes	
Audi A8	2010-2018	4H	69 Trailer Function	Measuring Blocks	
Audi A8	2010-2018	4H	69 Trailer Function	Output Tests	
Audi A8	2010-2018	4H	69 Trailer Function	Specia Functions	
Audi A8	2010-2018	4H	6C Rear Camera	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2010-2018	4H	6C Rear Camera	Clear Fault Codes	
Audi A8	2010-2018	4H	6C Rear Camera	Measuring Blocks	
Audi A8	2010-2018	4H	6C Rear Camera	Output Tests	
Audi A8	2010-2018	4H	6C Rear Camera	Specia Functions	
Audi A8	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A8	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A8	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A8	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A8	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A8	2010-2018	4H	6F Confort Central Control Unit II	Read Fault Codes	
Audi A8	2010-2018	4H	6F Confort Central Control Unit II	Clear Fault Codes	
Audi A8	2010-2018	4H	6F Confort Central Control Unit II	Measuring Blocks	
Audi A8	2010-2018	4H	6F Confort Central Control Unit II	Output Tests	
Audi A8	2010-2018	4H	6F Confort Central Control Unit II	Specia Functions	
Audi A8	2010-2018	4H	72 RR-Door Electroni.	Read Fault Codes	
Audi A8	2010-2018	4H	72 RR-Door Electroni.	Clear Fault Codes	
Audi A8	2010-2018	4H	72 RR-Door Electroni.	Measuring Blocks	
Audi A8	2010-2018	4H	72 RR-Door Electroni.	Output Tests	
Audi A8	2010-2018	4H	72 RR-Door Electroni.	Specia Functions	
Audi A8	2010-2018	4H	7F Information Electronic Equipment 2	Read Fault Codes	
Audi A8	2010-2018	4H	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi A8	2010-2018	4H	7F Information Electronic Equipment 2	Measuring Blocks	
Audi A8	2010-2018	4H	7F Information Electronic Equipment 2	Output Tests	
Audi A8	2010-2018	4H	7F Information Electronic Equipment 2	Specia Functions	
Audi A8	2010-2018	4H	81 Gear Shift	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2010-2018	4H	81 Gear Shift	Clear Fault Codes	
Audi A8	2010-2018	4H	81 Gear Shift	Measuring Blocks	
Audi A8	2010-2018	4H	81 Gear Shift	Output Tests	
Audi A8	2010-2018	4H	81 Gear Shift	Specia Functions	
Audi A8	2010-2018	4H	82 Heads Up Display	Read Fault Codes	
Audi A8	2010-2018	4H	82 Heads Up Display	Clear Fault Codes	
Audi A8	2010-2018	4H	82 Heads Up Display	Measuring Blocks	
Audi A8	2010-2018	4H	82 Heads Up Display	Output Tests	
Audi A8	2010-2018	4H	82 Heads Up Display	Specia Functions	
Audi A8	2010-2018	4H	84 Night Vision	Read Fault Codes	
Audi A8	2010-2018	4H	84 Night Vision	Clear Fault Codes	
Audi A8	2010-2018	4H	84 Night Vision	Measuring Blocks	
Audi A8	2010-2018	4H	84 Night Vision	Output Tests	
Audi A8	2010-2018	4H	84 Night Vision	Specia Functions	
Audi A8	2010-2018	4H	85 On Board Cam.	Read Fault Codes	
Audi A8	2010-2018	4H	85 On Board Cam.	Clear Fault Codes	
Audi A8	2010-2018	4H	85 On Board Cam.	Measuring Blocks	
Audi A8	2010-2018	4H	85 On Board Cam.	Output Tests	
Audi A8	2010-2018	4H	85 On Board Cam.	Specia Functions	
Audi A8	2010-2018	4H	88 Multicont. Seat Driver	Read Fault Codes	
Audi A8	2010-2018	4H	88 Multicont. Seat Driver	Clear Fault Codes	
Audi A8	2010-2018	4H	88 Multicont. Seat Driver	Measuring Blocks	
Audi A8	2010-2018	4H	88 Multicont. Seat Driver	Output Tests	
Audi A8	2010-2018	4H	88 Multicont. Seat Driver	Specia Functions	
Audi A8	2010-2018	4H	89 Multicont. Seat Driver	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2010-2018	4H	89 Multicont. Seat Driver	Clear Fault Codes	
Audi A8	2010-2018	4H	89 Multicont. Seat Driver	Measuring Blocks	
Audi A8	2010-2018	4H	89 Multicont. Seat Driver	Output Tests	
Audi A8	2010-2018	4H	89 Multicont. Seat Driver	Specia Functions	
Audi A8	2010-2018	4H	8A Multicont. Seat Rear, DS	Read Fault Codes	
Audi A8	2010-2018	4H	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi A8	2010-2018	4H	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi A8	2010-2018	4H	8A Multicont. Seat Rear, DS	Output Tests	
Audi A8	2010-2018	4H	8A Multicont. Seat Rear, DS	Specia Functions	
Audi A8	2010-2018	4H	8B Adaptive Cruise 2	Read Fault Codes	
Audi A8	2010-2018	4H	8B Adaptive Cruise 2	Clear Fault Codes	
Audi A8	2010-2018	4H	8B Adaptive Cruise 2	Measuring Blocks	
Audi A8	2010-2018	4H	8B Adaptive Cruise 2	Output Tests	
Audi A8	2010-2018	4H	8B Adaptive Cruise 2	Specia Functions	
Audi A8	2010-2018	4H	8C Hybrid Battery	Read Fault Codes	
Audi A8	2010-2018	4H	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2010-2018	4H	8C Hybrid Battery	Measuring Blocks	
Audi A8	2010-2018	4H	8C Hybrid Battery	Output Tests	
Audi A8	2010-2018	4H	8C Hybrid Battery	Specia Functions	
Audi A8	2010-2018	4H	8D Multicont.Seat Rear,PS	Read Fault Codes	
Audi A8	2010-2018	4H	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi A8	2010-2018	4H	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi A8	2010-2018	4H	8D Multicont.Seat Rear,PS	Output Tests	
Audi A8	2010-2018	4H	8D Multicont.Seat Rear,PS	Specia Functions	
Audi A8	2010-2018	4H	8E Image Processing	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2010-2018	4H	8E Image Processing	Clear Fault Codes	
Audi A8	2010-2018	4H	8E Image Processing	Measuring Blocks	
Audi A8	2010-2018	4H	8E Image Processing	Output Tests	
Audi A8	2010-2018	4H	8E Image Processing	Specia Functions	
Audi A8	2010-2018	4H	8F Pretens. Frt Left	Read Fault Codes	
Audi A8	2010-2018	4H	8F Pretens. Frt Left	Clear Fault Codes	
Audi A8	2010-2018	4H	8F Pretens. Frt Left	Measuring Blocks	
Audi A8	2010-2018	4H	8F Pretens. Frt Left	Output Tests	
Audi A8	2010-2018	4H	8F Pretens. Frt Left	Specia Functions	
Audi A8	2010-2018	4H	90 Pretens. Frt Right	Read Fault Codes	
Audi A8	2010-2018	4H	90 Pretens. Frt Right	Clear Fault Codes	
Audi A8	2010-2018	4H	90 Pretens. Frt Right	Measuring Blocks	
Audi A8	2010-2018	4H	90 Pretens. Frt Right	Output Tests	
Audi A8	2010-2018	4H	90 Pretens. Frt Right	Specia Functions	
Audi A8	2010-2018	4H	A9 Struct.Borne Sound	Read Fault Codes	
Audi A8	2010-2018	4H	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A8	2010-2018	4H	A9 Struct.Borne Sound	Measuring Blocks	
Audi A8	2010-2018	4H	A9 Struct.Borne Sound	Output Tests	
Audi A8	2010-2018	4H	A9 Struct.Borne Sound	Specia Functions	
Audi A8	2010-2018	4H	AC Reductant Control	Read Fault Codes	
Audi A8	2010-2018	4H	AC Reductant Control	Clear Fault Codes	
Audi A8	2010-2018	4H	AC Reductant Control	Measuring Blocks	
Audi A8	2010-2018	4H	AC Reductant Control	Output Tests	
Audi A8	2010-2018	4H	AC Reductant Control	Specia Functions	
Audi A8	2010-2018	4H	BA Motor Mounts	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2010-2018	4H	BA Motor Mounts	Clear Fault Codes	
Audi A8	2010-2018	4H	BA Motor Mounts	Measuring Blocks	
Audi A8	2010-2018	4H	BA Motor Mounts	Output Tests	
Audi A8	2010-2018	4H	BA Motor Mounts	Specia Functions	
Audi S8	2010-2018	4H	01 Engine Electronics	Read Fault Codes	
Audi S8	2010-2018	4H	01 Engine Electronics	Clear Fault Codes	
Audi S8	2010-2018	4H	01 Engine Electronics	Measuring Blocks	
Audi S8	2010-2018	4H	01 Engine Electronics	Output Tests	
Audi S8	2010-2018	4H	01 Engine Electronics	Specia Functions	
Audi S8	2010-2018	4H	02 Transmission Electronics	Read Fault Codes	
Audi S8	2010-2018	4H	02 Transmission Electronics	Clear Fault Codes	
Audi S8	2010-2018	4H	02 Transmission Electronics	Measuring Blocks	
Audi S8	2010-2018	4H	02 Transmission Electronics	Output Tests	
Audi S8	2010-2018	4H	02 Transmission Electronics	Specia Functions	
Audi S8	2010-2018	4H	03 Brake Electronics	Read Fault Codes	
Audi S8	2010-2018	4H	03 Brake Electronics	Clear Fault Codes	
Audi S8	2010-2018	4H	03 Brake Electronics	Measuring Blocks	
Audi S8	2010-2018	4H	03 Brake Electronics	Output Tests	
Audi S8	2010-2018	4H	03 Brake Electronics	Specia Functions	
Audi S8	2010-2018	4H	05 Access & Permissi.	Read Fault Codes	
Audi S8	2010-2018	4H	05 Access & Permissi.	Clear Fault Codes	
Audi S8	2010-2018	4H	05 Access & Permissi.	Measuring Blocks	
Audi S8	2010-2018	4H	05 Access & Permissi.	Output Tests	
Audi S8	2010-2018	4H	05 Access & Permissi.	Specia Functions	
Audi S8	2010-2018	4H	06 Passene. Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8	2010-2018	4H	06 Passene. Seat Adj.	Clear Fault Codes	
Audi S8	2010-2018	4H	06 Passene. Seat Adj.	Measuring Blocks	
Audi S8	2010-2018	4H	06 Passene. Seat Adj.	Output Tests	
Audi S8	2010-2018	4H	06 Passene. Seat Adj.	Specia Functions	
Audi S8	2010-2018	4H	08 AC/Heating Electronics	Read Fault Codes	
Audi S8	2010-2018	4H	08 AC/Heating Electronics	Clear Fault Codes	
Audi S8	2010-2018	4H	08 AC/Heating Electronics	Measuring Blocks	
Audi S8	2010-2018	4H	08 AC/Heating Electronics	Output Tests	
Audi S8	2010-2018	4H	08 AC/Heating Electronics	Specia Functions	
Audi S8	2010-2018	4H	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi S8	2010-2018	4H	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi S8	2010-2018	4H	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi S8	2010-2018	4H	09 Electronic Ctrl Electronics	Output Tests	
Audi S8	2010-2018	4H	09 Electronic Ctrl Electronics	Specia Functions	
Audi S8	2010-2018	4H	0E Media Player Position 1	Read Fault Codes	
Audi S8	2010-2018	4H	0E Media Player Position 1	Clear Fault Codes	
Audi S8	2010-2018	4H	0E Media Player Position 1	Measuring Blocks	
Audi S8	2010-2018	4H	0E Media Player Position 1	Output Tests	
Audi S8	2010-2018	4H	0E Media Player Position 1	Specia Functions	
Audi S8	2010-2018	4H	10 Parking Assist System 2	Read Fault Codes	
Audi S8	2010-2018	4H	10 Parking Assist System 2	Clear Fault Codes	
Audi S8	2010-2018	4H	10 Parking Assist System 2	Measuring Blocks	
Audi S8	2010-2018	4H	10 Parking Assist System 2	Output Tests	
Audi S8	2010-2018	4H	10 Parking Assist System 2	Specia Functions	
Audi S8	2010-2018	4H	11 Engine Electronics 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8	2010-2018	4H	11 Engine Electronics 2	Clear Fault Codes	
Audi S8	2010-2018	4H	11 Engine Electronics 2	Measuring Blocks	
Audi S8	2010-2018	4H	11 Engine Electronics 2	Output Tests	
Audi S8	2010-2018	4H	11 Engine Electronics 2	Specia Functions	
Audi S8	2010-2018	4H	13 Distance Control	Read Fault Codes	
Audi S8	2010-2018	4H	13 Distance Control	Clear Fault Codes	
Audi S8	2010-2018	4H	13 Distance Control	Measuring Blocks	
Audi S8	2010-2018	4H	13 Distance Control	Output Tests	
Audi S8	2010-2018	4H	13 Distance Control	Specia Functions	
Audi S8	2010-2018	4H	15 Airbags	Read Fault Codes	
Audi S8	2010-2018	4H	15 Airbags	Clear Fault Codes	
Audi S8	2010-2018	4H	15 Airbags	Measuring Blocks	
Audi S8	2010-2018	4H	15 Airbags	Output Tests	
Audi S8	2010-2018	4H	15 Airbags	Specia Functions	
Audi S8	2010-2018	4H	16 Steering Wheel Electronics	Read Fault Codes	
Audi S8	2010-2018	4H	16 Steering Wheel Electronics	Clear Fault Codes	
Audi S8	2010-2018	4H	16 Steering Wheel Electronics	Measuring Blocks	
Audi S8	2010-2018	4H	16 Steering Wheel Electronics	Output Tests	
Audi S8	2010-2018	4H	16 Steering Wheel Electronics	Specia Functions	
Audi S8	2010-2018	4H	17 Instrument Cluster	Read Fault Codes	
Audi S8	2010-2018	4H	17 Instrument Cluster	Clear Fault Codes	
Audi S8	2010-2018	4H	17 Instrument Cluster	Measuring Blocks	
Audi S8	2010-2018	4H	17 Instrument Cluster	Output Tests	
Audi S8	2010-2018	4H	17 Instrument Cluster	Specia Functions	
Audi S8	2010-2018	4H	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8	2010-2018	4H	18 Aux Heating	Clear Fault Codes	
Audi S8	2010-2018	4H	18 Aux Heating	Measuring Blocks	
Audi S8	2010-2018	4H	18 Aux Heating	Output Tests	
Audi S8	2010-2018	4H	18 Aux Heating	Specia Functions	
Audi S8	2010-2018	4H	19 Gateway Data Bus	Read Fault Codes	
Audi S8	2010-2018	4H	19 Gateway Data Bus	Clear Fault Codes	
Audi S8	2010-2018	4H	19 Gateway Data Bus	Measuring Blocks	
Audi S8	2010-2018	4H	19 Gateway Data Bus	Output Tests	
Audi S8	2010-2018	4H	19 Gateway Data Bus	Specia Functions	
Audi S8	2010-2018	4H	1B Power-Assisted Steering	Read Fault Codes	
Audi S8	2010-2018	4H	1B Power-Assisted Steering	Clear Fault Codes	
Audi S8	2010-2018	4H	1B Power-Assisted Steering	Measuring Blocks	
Audi S8	2010-2018	4H	1B Power-Assisted Steering	Output Tests	
Audi S8	2010-2018	4H	1B Power-Assisted Steering	Specia Functions	
Audi S8	2010-2018	4H	20 High Beam Assistance Device	Read Fault Codes	
Audi S8	2010-2018	4H	20 High Beam Assistance Device	Clear Fault Codes	
Audi S8	2010-2018	4H	20 High Beam Assistance Device	Measuring Blocks	
Audi S8	2010-2018	4H	20 High Beam Assistance Device	Output Tests	
Audi S8	2010-2018	4H	20 High Beam Assistance Device	Specia Functions	
Audi S8	2010-2018	4H	22 4WD Electronics	Read Fault Codes	
Audi S8	2010-2018	4H	22 4WD Electronics	Clear Fault Codes	
Audi S8	2010-2018	4H	22 4WD Electronics	Measuring Blocks	
Audi S8	2010-2018	4H	22 4WD Electronics	Output Tests	
Audi S8	2010-2018	4H	22 4WD Electronics	Specia Functions	
Audi S8	2010-2018	4H	28 Climate Control Unit Rear	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8	2010-2018	4H	28 Climate Control Unit Rear	Clear Fault Codes	
Audi S8	2010-2018	4H	28 Climate Control Unit Rear	Measuring Blocks	
Audi S8	2010-2018	4H	28 Climate Control Unit Rear	Output Tests	
Audi S8	2010-2018	4H	28 Climate Control Unit Rear	Specia Functions	
Audi S8	2010-2018	4H	30 Special Function 2	Read Fault Codes	
Audi S8	2010-2018	4H	30 Special Function 2	Clear Fault Codes	
Audi S8	2010-2018	4H	30 Special Function 2	Measuring Blocks	
Audi S8	2010-2018	4H	30 Special Function 2	Output Tests	
Audi S8	2010-2018	4H	30 Special Function 2	Specia Functions	
Audi S8	2010-2018	4H	34 Self Leveling Suspension	Read Fault Codes	
Audi S8	2010-2018	4H	34 Self Leveling Suspension	Clear Fault Codes	
Audi S8	2010-2018	4H	34 Self Leveling Suspension	Measuring Blocks	
Audi S8	2010-2018	4H	34 Self Leveling Suspension	Output Tests	
Audi S8	2010-2018	4H	34 Self Leveling Suspension	Specia Functions	
Audi S8	2010-2018	4H	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi S8	2010-2018	4H	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi S8	2010-2018	4H	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi S8	2010-2018	4H	36 Side of Driver Seat Adj.	Output Tests	
Audi S8	2010-2018	4H	36 Side of Driver Seat Adj.	Specia Functions	
Audi S8	2010-2018	4H	3B Sensor Elect.	Read Fault Codes	
Audi S8	2010-2018	4H	3B Sensor Elect.	Clear Fault Codes	
Audi S8	2010-2018	4H	3B Sensor Elect.	Measuring Blocks	
Audi S8	2010-2018	4H	3B Sensor Elect.	Output Tests	
Audi S8	2010-2018	4H	3B Sensor Elect.	Specia Functions	
Audi S8	2010-2018	4H	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8	2010-2018	4H	3C Lane Departure Assistance System	Clear Fault Codes	
Audi S8	2010-2018	4H	3C Lane Departure Assistance System	Measuring Blocks	
Audi S8	2010-2018	4H	3C Lane Departure Assistance System	Output Tests	
Audi S8	2010-2018	4H	3C Lane Departure Assistance System	Specia Functions	
Audi S8	2010-2018	4H	3D Special Function	Read Fault Codes	
Audi S8	2010-2018	4H	3D Special Function	Clear Fault Codes	
Audi S8	2010-2018	4H	3D Special Function	Measuring Blocks	
Audi S8	2010-2018	4H	3D Special Function	Output Tests	
Audi S8	2010-2018	4H	3D Special Function	Specia Functions	
Audi S8	2010-2018	4H	40 Air Compressor	Read Fault Codes	
Audi S8	2010-2018	4H	40 Air Compressor	Clear Fault Codes	
Audi S8	2010-2018	4H	40 Air Compressor	Measuring Blocks	
Audi S8	2010-2018	4H	40 Air Compressor	Output Tests	
Audi S8	2010-2018	4H	40 Air Compressor	Specia Functions	
Audi S8	2010-2018	4H	42 Driver-Door Elect.	Read Fault Codes	
Audi S8	2010-2018	4H	42 Driver-Door Elect.	Clear Fault Codes	
Audi S8	2010-2018	4H	42 Driver-Door Elect.	Measuring Blocks	
Audi S8	2010-2018	4H	42 Driver-Door Elect.	Output Tests	
Audi S8	2010-2018	4H	42 Driver-Door Elect.	Specia Functions	
Audi S8	2010-2018	4H	44 Steering Assistance	Read Fault Codes	
Audi S8	2010-2018	4H	44 Steering Assistance	Clear Fault Codes	
Audi S8	2010-2018	4H	44 Steering Assistance	Measuring Blocks	
Audi S8	2010-2018	4H	44 Steering Assistance	Output Tests	
Audi S8	2010-2018	4H	44 Steering Assistance	Specia Functions	
Audi S8	2010-2018	4H	46 Central Control Module	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S8	2010-2018	4H	46 Central Control Module	Clear Fault Codes	
Audi S8	2010-2018	4H	46 Central Control Module	Measuring Blocks	
Audi S8	2010-2018	4H	46 Central Control Module	Output Tests	
Audi S8	2010-2018	4H	46 Central Control Module	Specia Functions	
Audi S8	2010-2018	4H	47 Soundsystem	Read Fault Codes	
Audi S8	2010-2018	4H	47 Soundsystem	Clear Fault Codes	
Audi S8	2010-2018	4H	47 Soundsystem	Measuring Blocks	
Audi S8	2010-2018	4H	47 Soundsystem	Output Tests	
Audi S8	2010-2018	4H	47 Soundsystem	Specia Functions	
Audi S8	2010-2018	4H	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi S8	2010-2018	4H	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi S8	2010-2018	4H	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi S8	2010-2018	4H	48 Drvs Seat Adj.Rear	Output Tests	
Audi S8	2010-2018	4H	48 Drvs Seat Adj.Rear	Specia Functions	
Audi S8	2010-2018	4H	51 Electric Drive	Read Fault Codes	
Audi S8	2010-2018	4H	51 Electric Drive	Clear Fault Codes	
Audi S8	2010-2018	4H	51 Electric Drive	Measuring Blocks	
Audi S8	2010-2018	4H	51 Electric Drive	Output Tests	
Audi S8	2010-2018	4H	51 Electric Drive	Specia Functions	
Audi S8	2010-2018	4H	52 Passe.-Door Elect.	Read Fault Codes	
Audi S8	2010-2018	4H	52 Passe.-Door Elect.	Clear Fault Codes	
Audi S8	2010-2018	4H	52 Passe.-Door Elect.	Measuring Blocks	
Audi S8	2010-2018	4H	52 Passe.-Door Elect.	Output Tests	
Audi S8	2010-2018	4H	52 Passe.-Door Elect.	Specia Functions	
Audi S8	2010-2018	4H	53 Parking Brake	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8	2010-2018	4H	53 Parking Brake	Clear Fault Codes	
Audi S8	2010-2018	4H	53 Parking Brake	Measuring Blocks	
Audi S8	2010-2018	4H	53 Parking Brake	Output Tests	
Audi S8	2010-2018	4H	53 Parking Brake	Specia Functions	
Audi S8	2010-2018	4H	55 Headlight Range Control	Read Fault Codes	
Audi S8	2010-2018	4H	55 Headlight Range Control	Clear Fault Codes	
Audi S8	2010-2018	4H	55 Headlight Range Control	Measuring Blocks	
Audi S8	2010-2018	4H	55 Headlight Range Control	Output Tests	
Audi S8	2010-2018	4H	55 Headlight Range Control	Specia Functions	
Audi S8	2010-2018	4H	56 Radio	Read Fault Codes	
Audi S8	2010-2018	4H	56 Radio	Clear Fault Codes	
Audi S8	2010-2018	4H	56 Radio	Measuring Blocks	
Audi S8	2010-2018	4H	56 Radio	Output Tests	
Audi S8	2010-2018	4H	56 Radio	Specia Functions	
Audi S8	2010-2018	4H	57 TV-Tuner	Read Fault Codes	
Audi S8	2010-2018	4H	57 TV-Tuner	Clear Fault Codes	
Audi S8	2010-2018	4H	57 TV-Tuner	Measuring Blocks	
Audi S8	2010-2018	4H	57 TV-Tuner	Output Tests	
Audi S8	2010-2018	4H	57 TV-Tuner	Specia Functions	
Audi S8	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Read Fault Codes	
Audi S8	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Clear Fault Codes	
Audi S8	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Measuring Blocks	
Audi S8	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Output Tests	
Audi S8	2010-2018	4H	5B Seat Adjustment Rear Passenger Side	Specia Functions	
Audi S8	2010-2018	4H	5F Information Electronic Equipment 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8	2010-2018	4H	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi S8	2010-2018	4H	5F Information Electronic Equipment 1	Measuring Blocks	
Audi S8	2010-2018	4H	5F Information Electronic Equipment 1	Output Tests	
Audi S8	2010-2018	4H	5F Information Electronic Equipment 1	Specia Functions	
Audi S8	2010-2018	4H	62 LR-Door Electroni.	Read Fault Codes	
Audi S8	2010-2018	4H	62 LR-Door Electroni.	Clear Fault Codes	
Audi S8	2010-2018	4H	62 LR-Door Electroni.	Measuring Blocks	
Audi S8	2010-2018	4H	62 LR-Door Electroni.	Output Tests	
Audi S8	2010-2018	4H	62 LR-Door Electroni.	Specia Functions	
Audi S8	2010-2018	4H	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi S8	2010-2018	4H	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi S8	2010-2018	4H	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi S8	2010-2018	4H	65 Tyre Pressure Monitoring	Output Tests	
Audi S8	2010-2018	4H	65 Tyre Pressure Monitoring	Specia Functions	
Audi S8	2010-2018	4H	69 Trailer Function	Read Fault Codes	
Audi S8	2010-2018	4H	69 Trailer Function	Clear Fault Codes	
Audi S8	2010-2018	4H	69 Trailer Function	Measuring Blocks	
Audi S8	2010-2018	4H	69 Trailer Function	Output Tests	
Audi S8	2010-2018	4H	69 Trailer Function	Specia Functions	
Audi S8	2010-2018	4H	6C Rear Camera	Read Fault Codes	
Audi S8	2010-2018	4H	6C Rear Camera	Clear Fault Codes	
Audi S8	2010-2018	4H	6C Rear Camera	Measuring Blocks	
Audi S8	2010-2018	4H	6C Rear Camera	Output Tests	
Audi S8	2010-2018	4H	6C Rear Camera	Specia Functions	
Audi S8	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi S8	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi S8	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi S8	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi S8	2010-2018	4H	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi S8	2010-2018	4H	6F Confort Central Control Unit II	Read Fault Codes	
Audi S8	2010-2018	4H	6F Confort Central Control Unit II	Clear Fault Codes	
Audi S8	2010-2018	4H	6F Confort Central Control Unit II	Measuring Blocks	
Audi S8	2010-2018	4H	6F Confort Central Control Unit II	Output Tests	
Audi S8	2010-2018	4H	6F Confort Central Control Unit II	Specia Functions	
Audi S8	2010-2018	4H	72 RR-Door Electroni.	Read Fault Codes	
Audi S8	2010-2018	4H	72 RR-Door Electroni.	Clear Fault Codes	
Audi S8	2010-2018	4H	72 RR-Door Electroni.	Measuring Blocks	
Audi S8	2010-2018	4H	72 RR-Door Electroni.	Output Tests	
Audi S8	2010-2018	4H	72 RR-Door Electroni.	Specia Functions	
Audi S8	2010-2018	4H	7F Information Electronic Equipment 2	Read Fault Codes	
Audi S8	2010-2018	4H	7F Information Electronic Equipment 2	Clear Fault Codes	
Audi S8	2010-2018	4H	7F Information Electronic Equipment 2	Measuring Blocks	
Audi S8	2010-2018	4H	7F Information Electronic Equipment 2	Output Tests	
Audi S8	2010-2018	4H	7F Information Electronic Equipment 2	Specia Functions	
Audi S8	2010-2018	4H	81 Gear Shift	Read Fault Codes	
Audi S8	2010-2018	4H	81 Gear Shift	Clear Fault Codes	
Audi S8	2010-2018	4H	81 Gear Shift	Measuring Blocks	
Audi S8	2010-2018	4H	81 Gear Shift	Output Tests	
Audi S8	2010-2018	4H	81 Gear Shift	Specia Functions	
Audi S8	2010-2018	4H	82 Heads Up Display	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8	2010-2018	4H	82 Heads Up Display	Clear Fault Codes	
Audi S8	2010-2018	4H	82 Heads Up Display	Measuring Blocks	
Audi S8	2010-2018	4H	82 Heads Up Display	Output Tests	
Audi S8	2010-2018	4H	82 Heads Up Display	Specia Functions	
Audi S8	2010-2018	4H	84 Night Vision	Read Fault Codes	
Audi S8	2010-2018	4H	84 Night Vision	Clear Fault Codes	
Audi S8	2010-2018	4H	84 Night Vision	Measuring Blocks	
Audi S8	2010-2018	4H	84 Night Vision	Output Tests	
Audi S8	2010-2018	4H	84 Night Vision	Specia Functions	
Audi S8	2010-2018	4H	85 On Board Cam.	Read Fault Codes	
Audi S8	2010-2018	4H	85 On Board Cam.	Clear Fault Codes	
Audi S8	2010-2018	4H	85 On Board Cam.	Measuring Blocks	
Audi S8	2010-2018	4H	85 On Board Cam.	Output Tests	
Audi S8	2010-2018	4H	85 On Board Cam.	Specia Functions	
Audi S8	2010-2018	4H	88 Multicont. Seat Driver	Read Fault Codes	
Audi S8	2010-2018	4H	88 Multicont. Seat Driver	Clear Fault Codes	
Audi S8	2010-2018	4H	88 Multicont. Seat Driver	Measuring Blocks	
Audi S8	2010-2018	4H	88 Multicont. Seat Driver	Output Tests	
Audi S8	2010-2018	4H	88 Multicont. Seat Driver	Specia Functions	
Audi S8	2010-2018	4H	89 Multicont. Seat Driver	Read Fault Codes	
Audi S8	2010-2018	4H	89 Multicont. Seat Driver	Clear Fault Codes	
Audi S8	2010-2018	4H	89 Multicont. Seat Driver	Measuring Blocks	
Audi S8	2010-2018	4H	89 Multicont. Seat Driver	Output Tests	
Audi S8	2010-2018	4H	89 Multicont. Seat Driver	Specia Functions	
Audi S8	2010-2018	4H	8A Multicont. Seat Rear, DS	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8	2010-2018	4H	8A Multicont. Seat Rear, DS	Clear Fault Codes	
Audi S8	2010-2018	4H	8A Multicont. Seat Rear, DS	Measuring Blocks	
Audi S8	2010-2018	4H	8A Multicont. Seat Rear, DS	Output Tests	
Audi S8	2010-2018	4H	8A Multicont. Seat Rear, DS	Specia Functions	
Audi S8	2010-2018	4H	8B Adaptive Cruise 2	Read Fault Codes	
Audi S8	2010-2018	4H	8B Adaptive Cruise 2	Clear Fault Codes	
Audi S8	2010-2018	4H	8B Adaptive Cruise 2	Measuring Blocks	
Audi S8	2010-2018	4H	8B Adaptive Cruise 2	Output Tests	
Audi S8	2010-2018	4H	8B Adaptive Cruise 2	Specia Functions	
Audi S8	2010-2018	4H	8C Hybrid Battery	Read Fault Codes	
Audi S8	2010-2018	4H	8C Hybrid Battery	Clear Fault Codes	
Audi S8	2010-2018	4H	8C Hybrid Battery	Measuring Blocks	
Audi S8	2010-2018	4H	8C Hybrid Battery	Output Tests	
Audi S8	2010-2018	4H	8C Hybrid Battery	Specia Functions	
Audi S8	2010-2018	4H	8D Multicont.Seat Rear,PS	Read Fault Codes	
Audi S8	2010-2018	4H	8D Multicont.Seat Rear,PS	Clear Fault Codes	
Audi S8	2010-2018	4H	8D Multicont.Seat Rear,PS	Measuring Blocks	
Audi S8	2010-2018	4H	8D Multicont.Seat Rear,PS	Output Tests	
Audi S8	2010-2018	4H	8D Multicont.Seat Rear,PS	Specia Functions	
Audi S8	2010-2018	4H	8E Image Processing	Read Fault Codes	
Audi S8	2010-2018	4H	8E Image Processing	Clear Fault Codes	
Audi S8	2010-2018	4H	8E Image Processing	Measuring Blocks	
Audi S8	2010-2018	4H	8E Image Processing	Output Tests	
Audi S8	2010-2018	4H	8E Image Processing	Specia Functions	
Audi S8	2010-2018	4H	8F Pretens. Frt Left	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi S8	2010-2018	4H	8F Pretens. Frt Left	Clear Fault Codes	
Audi S8	2010-2018	4H	8F Pretens. Frt Left	Measuring Blocks	
Audi S8	2010-2018	4H	8F Pretens. Frt Left	Output Tests	
Audi S8	2010-2018	4H	8F Pretens. Frt Left	Specia Functions	
Audi S8	2010-2018	4H	90 Pretens. Frt Right	Read Fault Codes	
Audi S8	2010-2018	4H	90 Pretens. Frt Right	Clear Fault Codes	
Audi S8	2010-2018	4H	90 Pretens. Frt Right	Measuring Blocks	
Audi S8	2010-2018	4H	90 Pretens. Frt Right	Output Tests	
Audi S8	2010-2018	4H	90 Pretens. Frt Right	Specia Functions	
Audi S8	2010-2018	4H	A9 Struct.Borne Sound	Read Fault Codes	
Audi S8	2010-2018	4H	A9 Struct.Borne Sound	Clear Fault Codes	
Audi S8	2010-2018	4H	A9 Struct.Borne Sound	Measuring Blocks	
Audi S8	2010-2018	4H	A9 Struct.Borne Sound	Output Tests	
Audi S8	2010-2018	4H	A9 Struct.Borne Sound	Specia Functions	
Audi S8	2010-2018	4H	AC Reductant Control	Read Fault Codes	
Audi S8	2010-2018	4H	AC Reductant Control	Clear Fault Codes	
Audi S8	2010-2018	4H	AC Reductant Control	Measuring Blocks	
Audi S8	2010-2018	4H	AC Reductant Control	Output Tests	
Audi S8	2010-2018	4H	AC Reductant Control	Specia Functions	
Audi S8	2010-2018	4H	BA Motor Mounts	Read Fault Codes	
Audi S8	2010-2018	4H	BA Motor Mounts	Clear Fault Codes	
Audi S8	2010-2018	4H	BA Motor Mounts	Measuring Blocks	
Audi S8	2010-2018	4H	BA Motor Mounts	Output Tests	
Audi S8	2010-2018	4H	BA Motor Mounts	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	8W	01 Engine Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	01 Engine Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	01 Engine Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	8W	01 Engine Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	02 Transmission Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	02 Transmission Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	02 Transmission Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	02 Transmission Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	8W	02 Transmission Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	03 Brake Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	03 Brake Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	03 Brake Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	03 Brake Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	8W	03 Brake Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	06 Passene. Seat Adj.	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	06 Passene. Seat Adj.	Output Tests	
Audi Q5 (USA)	2017-2018	8W	06 Passene. Seat Adj.	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	08 AC/Heating Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	08 AC/Heating Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	08 AC/Heating Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	08 AC/Heating Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	8W	08 AC/Heating Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	09 Electronic Ctrl Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	8W	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	09 Electronic Ctrl Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	8W	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	13 Distance Control	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	13 Distance Control	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	13 Distance Control	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	13 Distance Control	Output Tests	
Audi Q5 (USA)	2017-2018	8W	13 Distance Control	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	15 Airbags	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	15 Airbags	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	15 Airbags	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	15 Airbags	Output Tests	
Audi Q5 (USA)	2017-2018	8W	15 Airbags	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	16 Steering Wheel Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	8W	16 Steering Wheel Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	17 Instrument Cluster	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	17 Instrument Cluster	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	17 Instrument Cluster	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	17 Instrument Cluster	Output Tests	
Audi Q5 (USA)	2017-2018	8W	17 Instrument Cluster	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	18 Aux Heating	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	8W	18 Aux Heating	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	18 Aux Heating	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	18 Aux Heating	Output Tests	
Audi Q5 (USA)	2017-2018	8W	18 Aux Heating	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	19 Gateway Data Bus	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	19 Gateway Data Bus	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	19 Gateway Data Bus	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	19 Gateway Data Bus	Output Tests	
Audi Q5 (USA)	2017-2018	8W	19 Gateway Data Bus	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	1B Power-Assisted Steering	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	1B Power-Assisted Steering	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	1B Power-Assisted Steering	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	1B Power-Assisted Steering	Output Tests	
Audi Q5 (USA)	2017-2018	8W	1B Power-Assisted Steering	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	20 High Beam Assistance Device	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	20 High Beam Assistance Device	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	20 High Beam Assistance Device	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	20 High Beam Assistance Device	Output Tests	
Audi Q5 (USA)	2017-2018	8W	20 High Beam Assistance Device	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	21 Engine Electronics 3	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	21 Engine Electronics 3	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	21 Engine Electronics 3	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	21 Engine Electronics 3	Output Tests	
Audi Q5 (USA)	2017-2018	8W	21 Engine Electronics 3	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	22 4WD Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	8W	22 4WD Electronics	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	22 4WD Electronics	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	22 4WD Electronics	Output Tests	
Audi Q5 (USA)	2017-2018	8W	22 4WD Electronics	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	29 Left Light Control	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	29 Left Light Control	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	29 Left Light Control	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	29 Left Light Control	Output Tests	
Audi Q5 (USA)	2017-2018	8W	29 Left Light Control	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	2B Steer Col Lock	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	2B Steer Col Lock	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	2B Steer Col Lock	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	2B Steer Col Lock	Output Tests	
Audi Q5 (USA)	2017-2018	8W	2B Steer Col Lock	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	32 Locking Electronisc	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	32 Locking Electronisc	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	32 Locking Electronisc	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	32 Locking Electronisc	Output Tests	
Audi Q5 (USA)	2017-2018	8W	32 Locking Electronisc	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	36 Side of Driver Seat Adj.	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	36 Side of Driver Seat Adj.	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	36 Side of Driver Seat Adj.	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	36 Side of Driver Seat Adj.	Output Tests	
Audi Q5 (USA)	2017-2018	8W	36 Side of Driver Seat Adj.	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	39 Right Light Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	8W	39 Right Light Control	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	39 Right Light Control	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	39 Right Light Control	Output Tests	
Audi Q5 (USA)	2017-2018	8W	39 Right Light Control	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	3C Lane Departure Assistance System	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	3C Lane Departure Assistance System	Output Tests	
Audi Q5 (USA)	2017-2018	8W	3C Lane Departure Assistance System	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	3D Special Function	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	3D Special Function	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	3D Special Function	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	3D Special Function	Output Tests	
Audi Q5 (USA)	2017-2018	8W	3D Special Function	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	42 Driver-Door Elect.	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	42 Driver-Door Elect.	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	42 Driver-Door Elect.	Output Tests	
Audi Q5 (USA)	2017-2018	8W	42 Driver-Door Elect.	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	44 Steering Assistance	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	44 Steering Assistance	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	44 Steering Assistance	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	44 Steering Assistance	Output Tests	
Audi Q5 (USA)	2017-2018	8W	44 Steering Assistance	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	46 Central Control Module	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q5 (USA)	2017-2018	8W	46 Central Control Module	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	46 Central Control Module	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	46 Central Control Module	Output Tests	
Audi Q5 (USA)	2017-2018	8W	46 Central Control Module	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	47 Soundsystem	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	47 Soundsystem	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	47 Soundsystem	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	47 Soundsystem	Output Tests	
Audi Q5 (USA)	2017-2018	8W	47 Soundsystem	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	4E Control Head RR	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	4E Control Head RR	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	4E Control Head RR	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	4E Control Head RR	Output Tests	
Audi Q5 (USA)	2017-2018	8W	4E Control Head RR	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	52 Passe.-Door Elect.	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	52 Passe.-Door Elect.	Output Tests	
Audi Q5 (USA)	2017-2018	8W	52 Passe.-Door Elect.	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	57 TV-Tuner	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	57 TV-Tuner	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	57 TV-Tuner	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	57 TV-Tuner	Output Tests	
Audi Q5 (USA)	2017-2018	8W	57 TV-Tuner	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	5E Control Head LR	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	8W	5E Control Head LR	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	5E Control Head LR	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	5E Control Head LR	Output Tests	
Audi Q5 (USA)	2017-2018	8W	5E Control Head LR	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	5F Information Electronic Equipment 1	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	5F Information Electronic Equipment 1	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	5F Information Electronic Equipment 1	Output Tests	
Audi Q5 (USA)	2017-2018	8W	5F Information Electronic Equipment 1	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	69 Trailer Function	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	69 Trailer Function	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	69 Trailer Function	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	69 Trailer Function	Output Tests	
Audi Q5 (USA)	2017-2018	8W	69 Trailer Function	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	6C Rear Camera	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	6C Rear Camera	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	6C Rear Camera	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	6C Rear Camera	Output Tests	
Audi Q5 (USA)	2017-2018	8W	6C Rear Camera	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q5 (USA)	2017-2018	8W	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	74 Vehicle Control System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	8W	74 Vehicle Control System	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	74 Vehicle Control System	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	74 Vehicle Control System	Output Tests	
Audi Q5 (USA)	2017-2018	8W	74 Vehicle Control System	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	81 Gear Shift	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	81 Gear Shift	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	81 Gear Shift	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	81 Gear Shift	Output Tests	
Audi Q5 (USA)	2017-2018	8W	81 Gear Shift	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	82 Heads Up Display	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	82 Heads Up Display	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	82 Heads Up Display	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	82 Heads Up Display	Output Tests	
Audi Q5 (USA)	2017-2018	8W	82 Heads Up Display	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	8B Adaptive Cruise 2	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	8B Adaptive Cruise 2	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	8B Adaptive Cruise 2	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	8B Adaptive Cruise 2	Output Tests	
Audi Q5 (USA)	2017-2018	8W	8B Adaptive Cruise 2	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	A5 Frt Sens.Drv.Assist	Output Tests	
Audi Q5 (USA)	2017-2018	8W	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q5 (USA)	2017-2018	8W	A9 Struct.Borne Sound	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	A9 Struct.Borne Sound	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	A9 Struct.Borne Sound	Output Tests	
Audi Q5 (USA)	2017-2018	8W	A9 Struct.Borne Sound	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	AC Reductant Control	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	AC Reductant Control	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	AC Reductant Control	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	AC Reductant Control	Output Tests	
Audi Q5 (USA)	2017-2018	8W	AC Reductant Control	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	BB Door Rear Drv Side	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	BB Door Rear Drv Side	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	BB Door Rear Drv Side	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	BB Door Rear Drv Side	Output Tests	
Audi Q5 (USA)	2017-2018	8W	BB Door Rear Drv Side	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	BC Door Rear Pass Side	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	BC Door Rear Pass Side	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	BC Door Rear Pass Side	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	BC Door Rear Pass Side	Output Tests	
Audi Q5 (USA)	2017-2018	8W	BC Door Rear Pass Side	Specia Functions	
Audi Q5 (USA)	2017-2018	8W	C0 Act. For Ext. Noise	Read Fault Codes	
Audi Q5 (USA)	2017-2018	8W	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi Q5 (USA)	2017-2018	8W	C0 Act. For Ext. Noise	Measuring Blocks	
Audi Q5 (USA)	2017-2018	8W	C0 Act. For Ext. Noise	Output Tests	
Audi Q5 (USA)	2017-2018	8W	C0 Act. For Ext. Noise	Specia Functions	
Audi A8	2018	F8	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	01 Engine Electronics	Clear Fault Codes	
Audi A8	2018	F8	01 Engine Electronics	Measuring Blocks	
Audi A8	2018	F8	01 Engine Electronics	Output Tests	
Audi A8	2018	F8	01 Engine Electronics	Specia Functions	
Audi A8	2018	F8	02 Transmission Electronics	Read Fault Codes	
Audi A8	2018	F8	02 Transmission Electronics	Clear Fault Codes	
Audi A8	2018	F8	02 Transmission Electronics	Measuring Blocks	
Audi A8	2018	F8	02 Transmission Electronics	Output Tests	
Audi A8	2018	F8	02 Transmission Electronics	Specia Functions	
Audi A8	2018	F8	03 Brake Electronics	Read Fault Codes	
Audi A8	2018	F8	03 Brake Electronics	Clear Fault Codes	
Audi A8	2018	F8	03 Brake Electronics	Measuring Blocks	
Audi A8	2018	F8	03 Brake Electronics	Output Tests	
Audi A8	2018	F8	03 Brake Electronics	Specia Functions	
Audi A8	2018	F8	06 Passene. Seat Adj.	Read Fault Codes	
Audi A8	2018	F8	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A8	2018	F8	06 Passene. Seat Adj.	Measuring Blocks	
Audi A8	2018	F8	06 Passene. Seat Adj.	Output Tests	
Audi A8	2018	F8	06 Passene. Seat Adj.	Specia Functions	
Audi A8	2018	F8	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A8	2018	F8	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A8	2018	F8	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A8	2018	F8	09 Electronic Ctrl Electronics	Output Tests	
Audi A8	2018	F8	09 Electronic Ctrl Electronics	Specia Functions	
Audi A8	2018	F8	0E Media Player Position 1	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	0E Media Player Position 1	Clear Fault Codes	
Audi A8	2018	F8	0E Media Player Position 1	Measuring Blocks	
Audi A8	2018	F8	0E Media Player Position 1	Output Tests	
Audi A8	2018	F8	0E Media Player Position 1	Specia Functions	
Audi A8	2018	F8	13 Distance Control	Read Fault Codes	
Audi A8	2018	F8	13 Distance Control	Clear Fault Codes	
Audi A8	2018	F8	13 Distance Control	Measuring Blocks	
Audi A8	2018	F8	13 Distance Control	Output Tests	
Audi A8	2018	F8	13 Distance Control	Specia Functions	
Audi A8	2018	F8	15 Airbags	Read Fault Codes	
Audi A8	2018	F8	15 Airbags	Clear Fault Codes	
Audi A8	2018	F8	15 Airbags	Measuring Blocks	
Audi A8	2018	F8	15 Airbags	Output Tests	
Audi A8	2018	F8	15 Airbags	Specia Functions	
Audi A8	2018	F8	16 Steering Wheel Electronics	Read Fault Codes	
Audi A8	2018	F8	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A8	2018	F8	16 Steering Wheel Electronics	Measuring Blocks	
Audi A8	2018	F8	16 Steering Wheel Electronics	Output Tests	
Audi A8	2018	F8	16 Steering Wheel Electronics	Specia Functions	
Audi A8	2018	F8	17 Instrument Cluster	Read Fault Codes	
Audi A8	2018	F8	17 Instrument Cluster	Clear Fault Codes	
Audi A8	2018	F8	17 Instrument Cluster	Measuring Blocks	
Audi A8	2018	F8	17 Instrument Cluster	Output Tests	
Audi A8	2018	F8	17 Instrument Cluster	Specia Functions	
Audi A8	2018	F8	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	18 Aux Heating	Clear Fault Codes	
Audi A8	2018	F8	18 Aux Heating	Measuring Blocks	
Audi A8	2018	F8	18 Aux Heating	Output Tests	
Audi A8	2018	F8	18 Aux Heating	Specia Functions	
Audi A8	2018	F8	19 Gateway Data Bus	Read Fault Codes	
Audi A8	2018	F8	19 Gateway Data Bus	Clear Fault Codes	
Audi A8	2018	F8	19 Gateway Data Bus	Measuring Blocks	
Audi A8	2018	F8	19 Gateway Data Bus	Output Tests	
Audi A8	2018	F8	19 Gateway Data Bus	Specia Functions	
Audi A8	2018	F8	1B Power-Assisted Steering	Read Fault Codes	
Audi A8	2018	F8	1B Power-Assisted Steering	Clear Fault Codes	
Audi A8	2018	F8	1B Power-Assisted Steering	Measuring Blocks	
Audi A8	2018	F8	1B Power-Assisted Steering	Output Tests	
Audi A8	2018	F8	1B Power-Assisted Steering	Specia Functions	
Audi A8	2018	F8	21 Engine Electronics 3	Read Fault Codes	
Audi A8	2018	F8	21 Engine Electronics 3	Clear Fault Codes	
Audi A8	2018	F8	21 Engine Electronics 3	Measuring Blocks	
Audi A8	2018	F8	21 Engine Electronics 3	Output Tests	
Audi A8	2018	F8	21 Engine Electronics 3	Specia Functions	
Audi A8	2018	F8	23 Braker Booster	Read Fault Codes	
Audi A8	2018	F8	23 Braker Booster	Clear Fault Codes	
Audi A8	2018	F8	23 Braker Booster	Measuring Blocks	
Audi A8	2018	F8	23 Braker Booster	Output Tests	
Audi A8	2018	F8	23 Braker Booster	Specia Functions	
Audi A8	2018	F8	29 Left Light Control	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2018	F8	29 Left Light Control	Clear Fault Codes	
Audi A8	2018	F8	29 Left Light Control	Measuring Blocks	
Audi A8	2018	F8	29 Left Light Control	Output Tests	
Audi A8	2018	F8	29 Left Light Control	Specia Functions	
Audi A8	2018	F8	2B Steer Col Lock	Read Fault Codes	
Audi A8	2018	F8	2B Steer Col Lock	Clear Fault Codes	
Audi A8	2018	F8	2B Steer Col Lock	Measuring Blocks	
Audi A8	2018	F8	2B Steer Col Lock	Output Tests	
Audi A8	2018	F8	2B Steer Col Lock	Specia Functions	
Audi A8	2018	F8	2A Control Unit Wireless Charging	Read Fault Codes	
Audi A8	2018	F8	2A Control Unit Wireless Charging	Clear Fault Codes	
Audi A8	2018	F8	2A Control Unit Wireless Charging	Measuring Blocks	
Audi A8	2018	F8	2A Control Unit Wireless Charging	Output Tests	
Audi A8	2018	F8	2A Control Unit Wireless Charging	Specia Functions	
Audi A8	2018	F8	32 Locking Electronisc	Read Fault Codes	
Audi A8	2018	F8	32 Locking Electronisc	Clear Fault Codes	
Audi A8	2018	F8	32 Locking Electronisc	Measuring Blocks	
Audi A8	2018	F8	32 Locking Electronisc	Output Tests	
Audi A8	2018	F8	32 Locking Electronisc	Specia Functions	
Audi A8	2018	F8	36 Driver`s Side Seat Adj.	Read Fault Codes	
Audi A8	2018	F8	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Audi A8	2018	F8	36 Driver`s Side Seat Adj.	Measuring Blocks	
Audi A8	2018	F8	36 Driver`s Side Seat Adj.	Output Tests	
Audi A8	2018	F8	36 Driver`s Side Seat Adj.	Specia Functions	
Audi A8	2018	F8	39 Right Light Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	39 Right Light Control	Clear Fault Codes	
Audi A8	2018	F8	39 Right Light Control	Measuring Blocks	
Audi A8	2018	F8	39 Right Light Control	Output Tests	
Audi A8	2018	F8	39 Right Light Control	Specia Functions	
Audi A8	2018	F8	3C Lane Departure Assistance System	Read Fault Codes	
Audi A8	2018	F8	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A8	2018	F8	3C Lane Departure Assistance System	Measuring Blocks	
Audi A8	2018	F8	3C Lane Departure Assistance System	Output Tests	
Audi A8	2018	F8	3C Lane Departure Assistance System	Specia Functions	
Audi A8	2018	F8	42 Driver-Door Elect.	Read Fault Codes	
Audi A8	2018	F8	42 Driver-Door Elect.	Clear Fault Codes	
Audi A8	2018	F8	42 Driver-Door Elect.	Measuring Blocks	
Audi A8	2018	F8	42 Driver-Door Elect.	Output Tests	
Audi A8	2018	F8	42 Driver-Door Elect.	Specia Functions	
Audi A8	2018	F8	44 Steering Assistance	Read Fault Codes	
Audi A8	2018	F8	44 Steering Assistance	Clear Fault Codes	
Audi A8	2018	F8	44 Steering Assistance	Measuring Blocks	
Audi A8	2018	F8	44 Steering Assistance	Output Tests	
Audi A8	2018	F8	44 Steering Assistance	Specia Functions	
Audi A8	2018	F8	46 Central Control Module	Read Fault Codes	
Audi A8	2018	F8	46 Central Control Module	Clear Fault Codes	
Audi A8	2018	F8	46 Central Control Module	Measuring Blocks	
Audi A8	2018	F8	46 Central Control Module	Output Tests	
Audi A8	2018	F8	46 Central Control Module	Specia Functions	
Audi A8	2018	F8	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	47 Soundsystem	Clear Fault Codes	
Audi A8	2018	F8	47 Soundsystem	Measuring Blocks	
Audi A8	2018	F8	47 Soundsystem	Output Tests	
Audi A8	2018	F8	47 Soundsystem	Specia Functions	
Audi A8	2018	F8	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi A8	2018	F8	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A8	2018	F8	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A8	2018	F8	48 Drvs Seat Adj.Rear	Output Tests	
Audi A8	2018	F8	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A8	2018	F8	4E Control Head RR	Read Fault Codes	
Audi A8	2018	F8	4E Control Head RR	Clear Fault Codes	
Audi A8	2018	F8	4E Control Head RR	Measuring Blocks	
Audi A8	2018	F8	4E Control Head RR	Output Tests	
Audi A8	2018	F8	4E Control Head RR	Specia Functions	
Audi A8	2018	F8	51 Electric Drive	Read Fault Codes	
Audi A8	2018	F8	51 Electric Drive	Clear Fault Codes	
Audi A8	2018	F8	51 Electric Drive	Measuring Blocks	
Audi A8	2018	F8	51 Electric Drive	Output Tests	
Audi A8	2018	F8	51 Electric Drive	Specia Functions	
Audi A8	2018	F8	52 Passe.-Door Elect.	Read Fault Codes	
Audi A8	2018	F8	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A8	2018	F8	52 Passe.-Door Elect.	Measuring Blocks	
Audi A8	2018	F8	52 Passe.-Door Elect.	Output Tests	
Audi A8	2018	F8	52 Passe.-Door Elect.	Specia Functions	
Audi A8	2018	F8	57 TV-Tuner	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2018	F8	57 TV-Tuner	Clear Fault Codes	
Audi A8	2018	F8	57 TV-Tuner	Measuring Blocks	
Audi A8	2018	F8	57 TV-Tuner	Output Tests	
Audi A8	2018	F8	57 TV-Tuner	Specia Functions	
Audi A8	2018	F8	5E Control Head LR	Read Fault Codes	
Audi A8	2018	F8	5E Control Head LR	Clear Fault Codes	
Audi A8	2018	F8	5E Control Head LR	Measuring Blocks	
Audi A8	2018	F8	5E Control Head LR	Output Tests	
Audi A8	2018	F8	5E Control Head LR	Specia Functions	
Audi A8	2018	F8	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A8	2018	F8	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A8	2018	F8	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A8	2018	F8	5F Information Electronic Equipment 1	Output Tests	
Audi A8	2018	F8	5F Information Electronic Equipment 1	Specia Functions	
Audi A8	2018	F8	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A8	2018	F8	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A8	2018	F8	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A8	2018	F8	65 Tyre Pressure Monitoring	Output Tests	
Audi A8	2018	F8	65 Tyre Pressure Monitoring	Specia Functions	
Audi A8	2018	F8	69 Trailer Function	Read Fault Codes	
Audi A8	2018	F8	69 Trailer Function	Clear Fault Codes	
Audi A8	2018	F8	69 Trailer Function	Measuring Blocks	
Audi A8	2018	F8	69 Trailer Function	Output Tests	
Audi A8	2018	F8	69 Trailer Function	Specia Functions	
Audi A8	2018	F8	6C Rear Camera	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	6C Rear Camera	Clear Fault Codes	
Audi A8	2018	F8	6C Rear Camera	Measuring Blocks	
Audi A8	2018	F8	6C Rear Camera	Output Tests	
Audi A8	2018	F8	6C Rear Camera	Specia Functions	
Audi A8	2018	F8	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A8	2018	F8	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A8	2018	F8	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A8	2018	F8	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A8	2018	F8	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A8	2018	F8	74 Vehicle Control System	Read Fault Codes	
Audi A8	2018	F8	74 Vehicle Control System	Clear Fault Codes	
Audi A8	2018	F8	74 Vehicle Control System	Measuring Blocks	
Audi A8	2018	F8	74 Vehicle Control System	Output Tests	
Audi A8	2018	F8	74 Vehicle Control System	Specia Functions	
Audi A8	2018	F8	75 Emergency Call Module	Read Fault Codes	
Audi A8	2018	F8	75 Emergency Call Module	Clear Fault Codes	
Audi A8	2018	F8	75 Emergency Call Module	Measuring Blocks	
Audi A8	2018	F8	75 Emergency Call Module	Output Tests	
Audi A8	2018	F8	75 Emergency Call Module	Specia Functions	
Audi A8	2018	F8	81 Gear Shift	Read Fault Codes	
Audi A8	2018	F8	81 Gear Shift	Clear Fault Codes	
Audi A8	2018	F8	81 Gear Shift	Measuring Blocks	
Audi A8	2018	F8	81 Gear Shift	Output Tests	
Audi A8	2018	F8	81 Gear Shift	Specia Functions	
Audi A8	2018	F8	82 Heads Up Display	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	82 Heads Up Display	Clear Fault Codes	
Audi A8	2018	F8	82 Heads Up Display	Measuring Blocks	
Audi A8	2018	F8	82 Heads Up Display	Output Tests	
Audi A8	2018	F8	82 Heads Up Display	Specia Functions	
Audi A8	2018	F8	84 Night Vision	Read Fault Codes	
Audi A8	2018	F8	84 Night Vision	Clear Fault Codes	
Audi A8	2018	F8	84 Night Vision	Measuring Blocks	
Audi A8	2018	F8	84 Night Vision	Output Tests	
Audi A8	2018	F8	84 Night Vision	Specia Functions	
Audi A8	2018	F8	8C Hybrid Battery	Read Fault Codes	
Audi A8	2018	F8	8C Hybrid Battery	Clear Fault Codes	
Audi A8	2018	F8	8C Hybrid Battery	Measuring Blocks	
Audi A8	2018	F8	8C Hybrid Battery	Output Tests	
Audi A8	2018	F8	8C Hybrid Battery	Specia Functions	
Audi A8	2018	F8	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A8	2018	F8	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A8	2018	F8	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A8	2018	F8	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A8	2018	F8	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A8	2018	F8	A9 Struct.Borne Sound	Read Fault Codes	
Audi A8	2018	F8	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A8	2018	F8	A9 Struct.Borne Sound	Measuring Blocks	
Audi A8	2018	F8	A9 Struct.Borne Sound	Output Tests	
Audi A8	2018	F8	A9 Struct.Borne Sound	Specia Functions	
Audi A8	2018	F8	AC Reductant Control	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	AC Reductant Control	Clear Fault Codes	
Audi A8	2018	F8	AC Reductant Control	Measuring Blocks	
Audi A8	2018	F8	AC Reductant Control	Output Tests	
Audi A8	2018	F8	AC Reductant Control	Specia Functions	
Audi A8	2018	F8	BA Motor Mounts	Read Fault Codes	
Audi A8	2018	F8	BA Motor Mounts	Clear Fault Codes	
Audi A8	2018	F8	BA Motor Mounts	Measuring Blocks	
Audi A8	2018	F8	BA Motor Mounts	Output Tests	
Audi A8	2018	F8	BA Motor Mounts	Specia Functions	
Audi A8	2018	F8	BB Door Rear Drv Side	Read Fault Codes	
Audi A8	2018	F8	BB Door Rear Drv Side	Clear Fault Codes	
Audi A8	2018	F8	BB Door Rear Drv Side	Measuring Blocks	
Audi A8	2018	F8	BB Door Rear Drv Side	Output Tests	
Audi A8	2018	F8	BB Door Rear Drv Side	Specia Functions	
Audi A8	2018	F8	BC Door Rear Pass Side	Read Fault Codes	
Audi A8	2018	F8	BC Door Rear Pass Side	Clear Fault Codes	
Audi A8	2018	F8	BC Door Rear Pass Side	Measuring Blocks	
Audi A8	2018	F8	BC Door Rear Pass Side	Output Tests	
Audi A8	2018	F8	BC Door Rear Pass Side	Specia Functions	
Audi A8	2018	F8	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A8	2018	F8	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A8	2018	F8	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A8	2018	F8	C0 Act. For Ext. Noise	Output Tests	
Audi A8	2018	F8	C0 Act. For Ext. Noise	Specia Functions	
Audi A8	2018	F8	C4 DC/DC Converter Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	C4 DC/DC Converter Control Module	Clear Fault Codes	
Audi A8	2018	F8	C4 DC/DC Converter Control Module	Measuring Blocks	
Audi A8	2018	F8	C4 DC/DC Converter Control Module	Output Tests	
Audi A8	2018	F8	C4 DC/DC Converter Control Module	Specia Functions	
Audi A8	2018	F8	C5 Thermal Management	Read Fault Codes	
Audi A8	2018	F8	C5 Thermal Management	Clear Fault Codes	
Audi A8	2018	F8	C5 Thermal Management	Measuring Blocks	
Audi A8	2018	F8	C5 Thermal Management	Output Tests	
Audi A8	2018	F8	C5 Thermal Management	Specia Functions	
Audi A8	2018	F8	C6 Batt. Chrg	Read Fault Codes	
Audi A8	2018	F8	C6 Batt. Chrg	Clear Fault Codes	
Audi A8	2018	F8	C6 Batt. Chrg	Measuring Blocks	
Audi A8	2018	F8	C6 Batt. Chrg	Output Tests	
Audi A8	2018	F8	C6 Batt. Chrg	Specia Functions	
Audi A8	2018	F8	CA Control Module For Sunroof	Read Fault Codes	
Audi A8	2018	F8	CA Control Module For Sunroof	Clear Fault Codes	
Audi A8	2018	F8	CA Control Module For Sunroof	Measuring Blocks	
Audi A8	2018	F8	CA Control Module For Sunroof	Output Tests	
Audi A8	2018	F8	CA Control Module For Sunroof	Specia Functions	
Audi A8	2018	F8	CB Rear Axle Steering	Read Fault Codes	
Audi A8	2018	F8	CB Rear Axle Steering	Clear Fault Codes	
Audi A8	2018	F8	CB Rear Axle Steering	Measuring Blocks	
Audi A8	2018	F8	CB Rear Axle Steering	Output Tests	
Audi A8	2018	F8	CB Rear Axle Steering	Specia Functions	
Audi A8	2018	F8	CC Starter / Generator Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	CC Starter / Generator Control Module	Clear Fault Codes	
Audi A8	2018	F8	CC Starter / Generator Control Module	Measuring Blocks	
Audi A8	2018	F8	CC Starter / Generator Control Module	Output Tests	
Audi A8	2018	F8	CC Starter / Generator Control Module	Specia Functions	
Audi A8	2018	F8	CD Laser Scanner	Read Fault Codes	
Audi A8	2018	F8	CD Laser Scanner	Clear Fault Codes	
Audi A8	2018	F8	CD Laser Scanner	Measuring Blocks	
Audi A8	2018	F8	CD Laser Scanner	Output Tests	
Audi A8	2018	F8	CD Laser Scanner	Specia Functions	
Audi A8	2018	F8	CF Control Unit Lane Change Assistant	Read Fault Codes	
Audi A8	2018	F8	CF Control Unit Lane Change Assistant	Clear Fault Codes	
Audi A8	2018	F8	CF Control Unit Lane Change Assistant	Measuring Blocks	
Audi A8	2018	F8	CF Control Unit Lane Change Assistant	Output Tests	
Audi A8	2018	F8	CF Control Unit Lane Change Assistant	Specia Functions	
Audi A8	2018	F8	D4 Roll Control System 1	Read Fault Codes	
Audi A8	2018	F8	D4 Roll Control System 1	Clear Fault Codes	
Audi A8	2018	F8	D4 Roll Control System 1	Measuring Blocks	
Audi A8	2018	F8	D4 Roll Control System 1	Output Tests	
Audi A8	2018	F8	D4 Roll Control System 1	Specia Functions	
Audi A8	2018	F8	D5 Roll Control System 2	Read Fault Codes	
Audi A8	2018	F8	D5 Roll Control System 2	Clear Fault Codes	
Audi A8	2018	F8	D5 Roll Control System 2	Measuring Blocks	
Audi A8	2018	F8	D5 Roll Control System 2	Output Tests	
Audi A8	2018	F8	D5 Roll Control System 2	Specia Functions	
Audi A8	2018	F8	D6 Light Control Left 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A8	2018	F8	D6 Light Control Left 2	Clear Fault Codes	
Audi A8	2018	F8	D6 Light Control Left 2	Measuring Blocks	
Audi A8	2018	F8	D6 Light Control Left 2	Output Tests	
Audi A8	2018	F8	D6 Light Control Left 2	Specia Functions	
Audi A8	2018	F8	D7 Light Control Right 2	Read Fault Codes	
Audi A8	2018	F8	D7 Light Control Right 2	Clear Fault Codes	
Audi A8	2018	F8	D7 Light Control Right 2	Measuring Blocks	
Audi A8	2018	F8	D7 Light Control Right 2	Output Tests	
Audi A8	2018	F8	D7 Light Control Right 2	Specia Functions	
Audi A8	2018	F8	DB Front Corner Radar 1	Read Fault Codes	
Audi A8	2018	F8	DB Front Corner Radar 1	Clear Fault Codes	
Audi A8	2018	F8	DB Front Corner Radar 1	Measuring Blocks	
Audi A8	2018	F8	DB Front Corner Radar 1	Output Tests	
Audi A8	2018	F8	DB Front Corner Radar 1	Specia Functions	
Audi A8	2018	F8	DC Front Corner Radar 2	Read Fault Codes	
Audi A8	2018	F8	DC Front Corner Radar 2	Clear Fault Codes	
Audi A8	2018	F8	DC Front Corner Radar 2	Measuring Blocks	
Audi A8	2018	F8	DC Front Corner Radar 2	Output Tests	
Audi A8	2018	F8	DC Front Corner Radar 2	Specia Functions	
Audi A8	2018	F8	DD Control Module 2 For Sunroof	Read Fault Codes	
Audi A8	2018	F8	DD Control Module 2 For Sunroof	Clear Fault Codes	
Audi A8	2018	F8	DD Control Module 2 For Sunroof	Measuring Blocks	
Audi A8	2018	F8	DD Control Module 2 For Sunroof	Output Tests	
Audi A8	2018	F8	DD Control Module 2 For Sunroof	Specia Functions	
Audi A8	2018	F8	DE Charger 1 Mobile Devices	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A8	2018	F8	DE Charger 1 Mobile Devices	Clear Fault Codes	
Audi A8	2018	F8	DE Charger 1 Mobile Devices	Measuring Blocks	
Audi A8	2018	F8	DE Charger 1 Mobile Devices	Output Tests	
Audi A8	2018	F8	DE Charger 1 Mobile Devices	Specia Functions	
Audi A8	2018	F8	DF Charger 2 Mobile Devices	Read Fault Codes	
Audi A8	2018	F8	DF Charger 2 Mobile Devices	Clear Fault Codes	
Audi A8	2018	F8	DF Charger 2 Mobile Devices	Measuring Blocks	
Audi A8	2018	F8	DF Charger 2 Mobile Devices	Output Tests	
Audi A8	2018	F8	DF Charger 2 Mobile Devices	Specia Functions	
Audi A8	2018	F8	E0 Zusatzanzeige-/Bedieneinheit 1	Read Fault Codes	
Audi A8	2018	F8	E0 Zusatzanzeige-/Bedieneinheit 1	Clear Fault Codes	
Audi A8	2018	F8	E0 Zusatzanzeige-/Bedieneinheit 1	Measuring Blocks	
Audi A8	2018	F8	E0 Zusatzanzeige-/Bedieneinheit 1	Output Tests	
Audi A8	2018	F8	E0 Zusatzanzeige-/Bedieneinheit 1	Specia Functions	
Audi Q8	2018	F2	01 Engine Electronics	Read Fault Codes	
Audi Q8	2018	F2	01 Engine Electronics	Clear Fault Codes	
Audi Q8	2018	F2	01 Engine Electronics	Measuring Blocks	
Audi Q8	2018	F2	01 Engine Electronics	Output Tests	
Audi Q8	2018	F2	01 Engine Electronics	Specia Functions	
Audi Q8	2018	F2	02 Transmission Electronics	Read Fault Codes	
Audi Q8	2018	F2	02 Transmission Electronics	Clear Fault Codes	
Audi Q8	2018	F2	02 Transmission Electronics	Measuring Blocks	
Audi Q8	2018	F2	02 Transmission Electronics	Output Tests	
Audi Q8	2018	F2	02 Transmission Electronics	Specia Functions	
Audi Q8	2018	F2	03 Brake Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q8	2018	F2	03 Brake Electronics	Clear Fault Codes	
Audi Q8	2018	F2	03 Brake Electronics	Measuring Blocks	
Audi Q8	2018	F2	03 Brake Electronics	Output Tests	
Audi Q8	2018	F2	03 Brake Electronics	Specia Functions	
Audi Q8	2018	F2	06 Passene. Seat Adj.	Read Fault Codes	
Audi Q8	2018	F2	06 Passene. Seat Adj.	Clear Fault Codes	
Audi Q8	2018	F2	06 Passene. Seat Adj.	Measuring Blocks	
Audi Q8	2018	F2	06 Passene. Seat Adj.	Output Tests	
Audi Q8	2018	F2	06 Passene. Seat Adj.	Specia Functions	
Audi Q8	2018	F2	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi Q8	2018	F2	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi Q8	2018	F2	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi Q8	2018	F2	09 Electronic Ctrl Electronics	Output Tests	
Audi Q8	2018	F2	09 Electronic Ctrl Electronics	Specia Functions	
Audi Q8	2018	F2	0E Media Player Position 1	Read Fault Codes	
Audi Q8	2018	F2	0E Media Player Position 1	Clear Fault Codes	
Audi Q8	2018	F2	0E Media Player Position 1	Measuring Blocks	
Audi Q8	2018	F2	0E Media Player Position 1	Output Tests	
Audi Q8	2018	F2	0E Media Player Position 1	Specia Functions	
Audi Q8	2018	F2	13 Distance Control	Read Fault Codes	
Audi Q8	2018	F2	13 Distance Control	Clear Fault Codes	
Audi Q8	2018	F2	13 Distance Control	Measuring Blocks	
Audi Q8	2018	F2	13 Distance Control	Output Tests	
Audi Q8	2018	F2	13 Distance Control	Specia Functions	
Audi Q8	2018	F2	15 Airbags	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q8	2018	F2	15 Airbags	Clear Fault Codes	
Audi Q8	2018	F2	15 Airbags	Measuring Blocks	
Audi Q8	2018	F2	15 Airbags	Output Tests	
Audi Q8	2018	F2	15 Airbags	Specia Functions	
Audi Q8	2018	F2	16 Steering Wheel Electronics	Read Fault Codes	
Audi Q8	2018	F2	16 Steering Wheel Electronics	Clear Fault Codes	
Audi Q8	2018	F2	16 Steering Wheel Electronics	Measuring Blocks	
Audi Q8	2018	F2	16 Steering Wheel Electronics	Output Tests	
Audi Q8	2018	F2	16 Steering Wheel Electronics	Specia Functions	
Audi Q8	2018	F2	17 Instrument Cluster	Read Fault Codes	
Audi Q8	2018	F2	17 Instrument Cluster	Clear Fault Codes	
Audi Q8	2018	F2	17 Instrument Cluster	Measuring Blocks	
Audi Q8	2018	F2	17 Instrument Cluster	Output Tests	
Audi Q8	2018	F2	17 Instrument Cluster	Specia Functions	
Audi Q8	2018	F2	18 Aux Heating	Read Fault Codes	
Audi Q8	2018	F2	18 Aux Heating	Clear Fault Codes	
Audi Q8	2018	F2	18 Aux Heating	Measuring Blocks	
Audi Q8	2018	F2	18 Aux Heating	Output Tests	
Audi Q8	2018	F2	18 Aux Heating	Specia Functions	
Audi Q8	2018	F2	19 Gateway Data Bus	Read Fault Codes	
Audi Q8	2018	F2	19 Gateway Data Bus	Clear Fault Codes	
Audi Q8	2018	F2	19 Gateway Data Bus	Measuring Blocks	
Audi Q8	2018	F2	19 Gateway Data Bus	Output Tests	
Audi Q8	2018	F2	19 Gateway Data Bus	Specia Functions	
Audi Q8	2018	F2	1B Power-Assisted Steering	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q8	2018	F2	1B Power-Assisted Steering	Clear Fault Codes	
Audi Q8	2018	F2	1B Power-Assisted Steering	Measuring Blocks	
Audi Q8	2018	F2	1B Power-Assisted Steering	Output Tests	
Audi Q8	2018	F2	1B Power-Assisted Steering	Specia Functions	
Audi Q8	2018	F2	20 High Beam Assistance Device	Read Fault Codes	
Audi Q8	2018	F2	20 High Beam Assistance Device	Clear Fault Codes	
Audi Q8	2018	F2	20 High Beam Assistance Device	Measuring Blocks	
Audi Q8	2018	F2	20 High Beam Assistance Device	Output Tests	
Audi Q8	2018	F2	20 High Beam Assistance Device	Specia Functions	
Audi Q8	2018	F2	21 Engine Electronics 3	Read Fault Codes	
Audi Q8	2018	F2	21 Engine Electronics 3	Clear Fault Codes	
Audi Q8	2018	F2	21 Engine Electronics 3	Measuring Blocks	
Audi Q8	2018	F2	21 Engine Electronics 3	Output Tests	
Audi Q8	2018	F2	21 Engine Electronics 3	Specia Functions	
Audi Q8	2018	F2	22 4WD Electronics	Read Fault Codes	
Audi Q8	2018	F2	22 4WD Electronics	Clear Fault Codes	
Audi Q8	2018	F2	22 4WD Electronics	Measuring Blocks	
Audi Q8	2018	F2	22 4WD Electronics	Output Tests	
Audi Q8	2018	F2	22 4WD Electronics	Specia Functions	
Audi Q8	2018	F2	23 Braker Booster	Read Fault Codes	
Audi Q8	2018	F2	23 Braker Booster	Clear Fault Codes	
Audi Q8	2018	F2	23 Braker Booster	Measuring Blocks	
Audi Q8	2018	F2	23 Braker Booster	Output Tests	
Audi Q8	2018	F2	23 Braker Booster	Specia Functions	
Audi Q8	2018	F2	2B Steer Col Lock	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi Q8	2018	F2	2B Steer Col Lock	Clear Fault Codes	
Audi Q8	2018	F2	2B Steer Col Lock	Measuring Blocks	
Audi Q8	2018	F2	2B Steer Col Lock	Output Tests	
Audi Q8	2018	F2	2B Steer Col Lock	Specia Functions	
Audi Q8	2018	F2	32 Locking Electronisc	Read Fault Codes	
Audi Q8	2018	F2	32 Locking Electronisc	Clear Fault Codes	
Audi Q8	2018	F2	32 Locking Electronisc	Measuring Blocks	
Audi Q8	2018	F2	32 Locking Electronisc	Output Tests	
Audi Q8	2018	F2	32 Locking Electronisc	Specia Functions	
Audi Q8	2018	F2	36 Driver`s Side Seat Adj.	Read Fault Codes	
Audi Q8	2018	F2	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Audi Q8	2018	F2	36 Driver`s Side Seat Adj.	Measuring Blocks	
Audi Q8	2018	F2	36 Driver`s Side Seat Adj.	Output Tests	
Audi Q8	2018	F2	36 Driver`s Side Seat Adj.	Specia Functions	
Audi Q8	2018	F2	3C Lane Departure Assistance System	Read Fault Codes	
Audi Q8	2018	F2	3C Lane Departure Assistance System	Clear Fault Codes	
Audi Q8	2018	F2	3C Lane Departure Assistance System	Measuring Blocks	
Audi Q8	2018	F2	3C Lane Departure Assistance System	Output Tests	
Audi Q8	2018	F2	3C Lane Departure Assistance System	Specia Functions	
Audi Q8	2018	F2	42 Driver-Door Elect.	Read Fault Codes	
Audi Q8	2018	F2	42 Driver-Door Elect.	Clear Fault Codes	
Audi Q8	2018	F2	42 Driver-Door Elect.	Measuring Blocks	
Audi Q8	2018	F2	42 Driver-Door Elect.	Output Tests	
Audi Q8	2018	F2	42 Driver-Door Elect.	Specia Functions	
Audi Q8	2018	F2	44 Steering Assistance	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q8	2018	F2	44 Steering Assistance	Clear Fault Codes	
Audi Q8	2018	F2	44 Steering Assistance	Measuring Blocks	
Audi Q8	2018	F2	44 Steering Assistance	Output Tests	
Audi Q8	2018	F2	44 Steering Assistance	Specia Functions	
Audi Q8	2018	F2	46 Central Control Module	Read Fault Codes	
Audi Q8	2018	F2	46 Central Control Module	Clear Fault Codes	
Audi Q8	2018	F2	46 Central Control Module	Measuring Blocks	
Audi Q8	2018	F2	46 Central Control Module	Output Tests	
Audi Q8	2018	F2	46 Central Control Module	Specia Functions	
Audi Q8	2018	F2	47 Soundsystem	Read Fault Codes	
Audi Q8	2018	F2	47 Soundsystem	Clear Fault Codes	
Audi Q8	2018	F2	47 Soundsystem	Measuring Blocks	
Audi Q8	2018	F2	47 Soundsystem	Output Tests	
Audi Q8	2018	F2	47 Soundsystem	Specia Functions	
Audi Q8	2018	F2	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi Q8	2018	F2	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi Q8	2018	F2	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi Q8	2018	F2	48 Drvs Seat Adj.Rear	Output Tests	
Audi Q8	2018	F2	48 Drvs Seat Adj.Rear	Specia Functions	
Audi Q8	2018	F2	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi Q8	2018	F2	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi Q8	2018	F2	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi Q8	2018	F2	48 Drvs Seat Adj.Rear	Output Tests	
Audi Q8	2018	F2	48 Drvs Seat Adj.Rear	Specia Functions	
Audi Q8	2018	F2	4E Control Head RR	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q8	2018	F2	4E Control Head RR	Clear Fault Codes	
Audi Q8	2018	F2	4E Control Head RR	Measuring Blocks	
Audi Q8	2018	F2	4E Control Head RR	Output Tests	
Audi Q8	2018	F2	4E Control Head RR	Specia Functions	
Audi Q8	2018	F2	51 Electric Drive	Read Fault Codes	
Audi Q8	2018	F2	51 Electric Drive	Clear Fault Codes	
Audi Q8	2018	F2	51 Electric Drive	Measuring Blocks	
Audi Q8	2018	F2	51 Electric Drive	Output Tests	
Audi Q8	2018	F2	51 Electric Drive	Specia Functions	
Audi Q8	2018	F2	52 Passe.-Door Elect.	Read Fault Codes	
Audi Q8	2018	F2	52 Passe.-Door Elect.	Clear Fault Codes	
Audi Q8	2018	F2	52 Passe.-Door Elect.	Measuring Blocks	
Audi Q8	2018	F2	52 Passe.-Door Elect.	Output Tests	
Audi Q8	2018	F2	52 Passe.-Door Elect.	Specia Functions	
Audi Q8	2018	F2	57 TV-Tuner	Read Fault Codes	
Audi Q8	2018	F2	57 TV-Tuner	Clear Fault Codes	
Audi Q8	2018	F2	57 TV-Tuner	Measuring Blocks	
Audi Q8	2018	F2	57 TV-Tuner	Output Tests	
Audi Q8	2018	F2	57 TV-Tuner	Specia Functions	
Audi Q8	2018	F2	5E Control Head LR	Read Fault Codes	
Audi Q8	2018	F2	5E Control Head LR	Clear Fault Codes	
Audi Q8	2018	F2	5E Control Head LR	Measuring Blocks	
Audi Q8	2018	F2	5E Control Head LR	Output Tests	
Audi Q8	2018	F2	5E Control Head LR	Specia Functions	
Audi Q8	2018	F2	5F Information Electronic Equipment 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q8	2018	F2	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi Q8	2018	F2	5F Information Electronic Equipment 1	Measuring Blocks	
Audi Q8	2018	F2	5F Information Electronic Equipment 1	Output Tests	
Audi Q8	2018	F2	5F Information Electronic Equipment 1	Specia Functions	
Audi Q8	2018	F2	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi Q8	2018	F2	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi Q8	2018	F2	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi Q8	2018	F2	65 Tyre Pressure Monitoring	Output Tests	
Audi Q8	2018	F2	65 Tyre Pressure Monitoring	Specia Functions	
Audi Q8	2018	F2	69 Trailer Function	Read Fault Codes	
Audi Q8	2018	F2	69 Trailer Function	Clear Fault Codes	
Audi Q8	2018	F2	69 Trailer Function	Measuring Blocks	
Audi Q8	2018	F2	69 Trailer Function	Output Tests	
Audi Q8	2018	F2	69 Trailer Function	Specia Functions	
Audi Q8	2018	F2	6C Rear Camera	Read Fault Codes	
Audi Q8	2018	F2	6C Rear Camera	Clear Fault Codes	
Audi Q8	2018	F2	6C Rear Camera	Measuring Blocks	
Audi Q8	2018	F2	6C Rear Camera	Output Tests	
Audi Q8	2018	F2	6C Rear Camera	Specia Functions	
Audi Q8	2018	F2	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi Q8	2018	F2	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi Q8	2018	F2	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi Q8	2018	F2	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi Q8	2018	F2	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi Q8	2018	F2	74 Vehicle Control System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q8	2018	F2	74 Vehicle Control System	Clear Fault Codes	
Audi Q8	2018	F2	74 Vehicle Control System	Measuring Blocks	
Audi Q8	2018	F2	74 Vehicle Control System	Output Tests	
Audi Q8	2018	F2	74 Vehicle Control System	Specia Functions	
Audi Q8	2018	F2	75 Emergency Call Module	Read Fault Codes	
Audi Q8	2018	F2	75 Emergency Call Module	Clear Fault Codes	
Audi Q8	2018	F2	75 Emergency Call Module	Measuring Blocks	
Audi Q8	2018	F2	75 Emergency Call Module	Output Tests	
Audi Q8	2018	F2	75 Emergency Call Module	Specia Functions	
Audi Q8	2018	F2	80 Batterieregelung Zusatzspeicher 1	Read Fault Codes	
Audi Q8	2018	F2	80 Batterieregelung Zusatzspeicher 1	Clear Fault Codes	
Audi Q8	2018	F2	80 Batterieregelung Zusatzspeicher 1	Measuring Blocks	
Audi Q8	2018	F2	80 Batterieregelung Zusatzspeicher 1	Output Tests	
Audi Q8	2018	F2	80 Batterieregelung Zusatzspeicher 1	Specia Functions	
Audi Q8	2018	F2	81 Gear Shift	Read Fault Codes	
Audi Q8	2018	F2	81 Gear Shift	Clear Fault Codes	
Audi Q8	2018	F2	81 Gear Shift	Measuring Blocks	
Audi Q8	2018	F2	81 Gear Shift	Output Tests	
Audi Q8	2018	F2	81 Gear Shift	Specia Functions	
Audi Q8	2018	F2	82 Heads Up Display	Read Fault Codes	
Audi Q8	2018	F2	82 Heads Up Display	Clear Fault Codes	
Audi Q8	2018	F2	82 Heads Up Display	Measuring Blocks	
Audi Q8	2018	F2	82 Heads Up Display	Output Tests	
Audi Q8	2018	F2	82 Heads Up Display	Specia Functions	
Audi Q8	2018	F2	84 Night Vision	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q8	2018	F2	84 Night Vision	Clear Fault Codes	
Audi Q8	2018	F2	84 Night Vision	Measuring Blocks	
Audi Q8	2018	F2	84 Night Vision	Output Tests	
Audi Q8	2018	F2	84 Night Vision	Specia Functions	
Audi Q8	2018	F2	8C Hybrid Battery	Read Fault Codes	
Audi Q8	2018	F2	8C Hybrid Battery	Clear Fault Codes	
Audi Q8	2018	F2	8C Hybrid Battery	Measuring Blocks	
Audi Q8	2018	F2	8C Hybrid Battery	Output Tests	
Audi Q8	2018	F2	8C Hybrid Battery	Specia Functions	
Audi Q8	2018	F2	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi Q8	2018	F2	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi Q8	2018	F2	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi Q8	2018	F2	A5 Frt Sens.Drv.Assist	Output Tests	
Audi Q8	2018	F2	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi Q8	2018	F2	A9 Struct.Borne Sound	Read Fault Codes	
Audi Q8	2018	F2	A9 Struct.Borne Sound	Clear Fault Codes	
Audi Q8	2018	F2	A9 Struct.Borne Sound	Measuring Blocks	
Audi Q8	2018	F2	A9 Struct.Borne Sound	Output Tests	
Audi Q8	2018	F2	A9 Struct.Borne Sound	Specia Functions	
Audi Q8	2018	F2	AC Reductant Control	Read Fault Codes	
Audi Q8	2018	F2	AC Reductant Control	Clear Fault Codes	
Audi Q8	2018	F2	AC Reductant Control	Measuring Blocks	
Audi Q8	2018	F2	AC Reductant Control	Output Tests	
Audi Q8	2018	F2	AC Reductant Control	Specia Functions	
Audi Q8	2018	F2	BA Motor Mounts	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q8	2018	F2	BA Motor Mounts	Clear Fault Codes	
Audi Q8	2018	F2	BA Motor Mounts	Measuring Blocks	
Audi Q8	2018	F2	BA Motor Mounts	Output Tests	
Audi Q8	2018	F2	BA Motor Mounts	Specia Functions	
Audi Q8	2018	F2	BB Door Rear Drv Side	Read Fault Codes	
Audi Q8	2018	F2	BB Door Rear Drv Side	Clear Fault Codes	
Audi Q8	2018	F2	BB Door Rear Drv Side	Measuring Blocks	
Audi Q8	2018	F2	BB Door Rear Drv Side	Output Tests	
Audi Q8	2018	F2	BB Door Rear Drv Side	Specia Functions	
Audi Q8	2018	F2	BC Door Rear Pass Side	Read Fault Codes	
Audi Q8	2018	F2	BC Door Rear Pass Side	Clear Fault Codes	
Audi Q8	2018	F2	BC Door Rear Pass Side	Measuring Blocks	
Audi Q8	2018	F2	BC Door Rear Pass Side	Output Tests	
Audi Q8	2018	F2	BC Door Rear Pass Side	Specia Functions	
Audi Q8	2018	F2	C0 Act. For Ext. Noise	Read Fault Codes	
Audi Q8	2018	F2	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi Q8	2018	F2	C0 Act. For Ext. Noise	Measuring Blocks	
Audi Q8	2018	F2	C0 Act. For Ext. Noise	Output Tests	
Audi Q8	2018	F2	C0 Act. For Ext. Noise	Specia Functions	
Audi Q8	2018	F2	C4 DC/DC Converter Control Module	Read Fault Codes	
Audi Q8	2018	F2	C4 DC/DC Converter Control Module	Clear Fault Codes	
Audi Q8	2018	F2	C4 DC/DC Converter Control Module	Measuring Blocks	
Audi Q8	2018	F2	C4 DC/DC Converter Control Module	Output Tests	
Audi Q8	2018	F2	C4 DC/DC Converter Control Module	Specia Functions	
Audi Q8	2018	F2	C5 Thermal Management	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q8	2018	F2	C5 Thermal Management	Clear Fault Codes	
Audi Q8	2018	F2	C5 Thermal Management	Measuring Blocks	
Audi Q8	2018	F2	C5 Thermal Management	Output Tests	
Audi Q8	2018	F2	C5 Thermal Management	Specia Functions	
Audi Q8	2018	F2	C6 Batt. Chrg	Read Fault Codes	
Audi Q8	2018	F2	C6 Batt. Chrg	Clear Fault Codes	
Audi Q8	2018	F2	C6 Batt. Chrg	Measuring Blocks	
Audi Q8	2018	F2	C6 Batt. Chrg	Output Tests	
Audi Q8	2018	F2	C6 Batt. Chrg	Specia Functions	
Audi Q8	2018	F2	CA Control Module For Sunroof	Read Fault Codes	
Audi Q8	2018	F2	CA Control Module For Sunroof	Clear Fault Codes	
Audi Q8	2018	F2	CA Control Module For Sunroof	Measuring Blocks	
Audi Q8	2018	F2	CA Control Module For Sunroof	Output Tests	
Audi Q8	2018	F2	CA Control Module For Sunroof	Specia Functions	
Audi Q8	2018	F2	CB Rear Axle Steering	Read Fault Codes	
Audi Q8	2018	F2	CB Rear Axle Steering	Clear Fault Codes	
Audi Q8	2018	F2	CB Rear Axle Steering	Measuring Blocks	
Audi Q8	2018	F2	CB Rear Axle Steering	Output Tests	
Audi Q8	2018	F2	CB Rear Axle Steering	Specia Functions	
Audi Q8	2018	F2	CC Starter / Generator Control Module	Read Fault Codes	
Audi Q8	2018	F2	CC Starter / Generator Control Module	Clear Fault Codes	
Audi Q8	2018	F2	CC Starter / Generator Control Module	Measuring Blocks	
Audi Q8	2018	F2	CC Starter / Generator Control Module	Output Tests	
Audi Q8	2018	F2	CC Starter / Generator Control Module	Specia Functions	
Audi Q8	2018	F2	CD Laser Scanner	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi Q8	2018	F2	CD Laser Scanner	Clear Fault Codes	
Audi Q8	2018	F2	CD Laser Scanner	Measuring Blocks	
Audi Q8	2018	F2	CD Laser Scanner	Output Tests	
Audi Q8	2018	F2	CD Laser Scanner	Specia Functions	
Audi Q8	2018	F2	CF Control Unit Lane Change Assistant	Read Fault Codes	
Audi Q8	2018	F2	CF Control Unit Lane Change Assistant	Clear Fault Codes	
Audi Q8	2018	F2	CF Control Unit Lane Change Assistant	Measuring Blocks	
Audi Q8	2018	F2	CF Control Unit Lane Change Assistant	Output Tests	
Audi Q8	2018	F2	CF Control Unit Lane Change Assistant	Specia Functions	
Audi Q8	2018	F2	D4 Roll Control System 1	Read Fault Codes	
Audi Q8	2018	F2	D4 Roll Control System 1	Clear Fault Codes	
Audi Q8	2018	F2	D4 Roll Control System 1	Measuring Blocks	
Audi Q8	2018	F2	D4 Roll Control System 1	Output Tests	
Audi Q8	2018	F2	D4 Roll Control System 1	Specia Functions	
Audi Q8	2018	F2	D5 Roll Control System 2	Read Fault Codes	
Audi Q8	2018	F2	D5 Roll Control System 2	Clear Fault Codes	
Audi Q8	2018	F2	D5 Roll Control System 2	Measuring Blocks	
Audi Q8	2018	F2	D5 Roll Control System 2	Output Tests	
Audi Q8	2018	F2	D5 Roll Control System 2	Specia Functions	
Audi Q8	2018	F2	D6 Light Control Left 2	Read Fault Codes	
Audi Q8	2018	F2	D6 Light Control Left 2	Clear Fault Codes	
Audi Q8	2018	F2	D6 Light Control Left 2	Measuring Blocks	
Audi Q8	2018	F2	D6 Light Control Left 2	Output Tests	
Audi Q8	2018	F2	D6 Light Control Left 2	Specia Functions	
Audi Q8	2018	F2	D7 Light Control Right 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q8	2018	F2	D7 Light Control Right 2	Clear Fault Codes	
Audi Q8	2018	F2	D7 Light Control Right 2	Measuring Blocks	
Audi Q8	2018	F2	D7 Light Control Right 2	Output Tests	
Audi Q8	2018	F2	D7 Light Control Right 2	Specia Functions	
Audi Q8	2018	F2	DB Front Corner Radar 1	Read Fault Codes	
Audi Q8	2018	F2	DB Front Corner Radar 1	Clear Fault Codes	
Audi Q8	2018	F2	DB Front Corner Radar 1	Measuring Blocks	
Audi Q8	2018	F2	DB Front Corner Radar 1	Output Tests	
Audi Q8	2018	F2	DB Front Corner Radar 1	Specia Functions	
Audi Q8	2018	F2	DC Front Corner Radar 2	Read Fault Codes	
Audi Q8	2018	F2	DC Front Corner Radar 2	Clear Fault Codes	
Audi Q8	2018	F2	DC Front Corner Radar 2	Measuring Blocks	
Audi Q8	2018	F2	DC Front Corner Radar 2	Output Tests	
Audi Q8	2018	F2	DC Front Corner Radar 2	Specia Functions	
Audi Q8	2018	F2	DD Control Module 2 For Sunroof	Read Fault Codes	
Audi Q8	2018	F2	DD Control Module 2 For Sunroof	Clear Fault Codes	
Audi Q8	2018	F2	DD Control Module 2 For Sunroof	Measuring Blocks	
Audi Q8	2018	F2	DD Control Module 2 For Sunroof	Output Tests	
Audi Q8	2018	F2	DD Control Module 2 For Sunroof	Specia Functions	
Audi Q8	2018	F2	DE Charger 1 Mobile Devices	Read Fault Codes	
Audi Q8	2018	F2	DE Charger 1 Mobile Devices	Clear Fault Codes	
Audi Q8	2018	F2	DE Charger 1 Mobile Devices	Measuring Blocks	
Audi Q8	2018	F2	DE Charger 1 Mobile Devices	Output Tests	
Audi Q8	2018	F2	DE Charger 1 Mobile Devices	Specia Functions	
Audi Q8	2018	F2	E0 Zusatzanzeige-/Bedieneinheit 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi Q8	2018	F2	E0 Zusatzanzeige-/Bedieneinheit 1	Clear Fault Codes	
Audi Q8	2018	F2	E0 Zusatzanzeige-/Bedieneinheit 1	Measuring Blocks	
Audi Q8	2018	F2	E0 Zusatzanzeige-/Bedieneinheit 1	Output Tests	
Audi Q8	2018	F2	E0 Zusatzanzeige-/Bedieneinheit 1	Specia Functions	
Audi A6	2018	F1	01 Engine Electronics	Read Fault Codes	
Audi A6	2018	F1	01 Engine Electronics	Clear Fault Codes	
Audi A6	2018	F1	01 Engine Electronics	Measuring Blocks	
Audi A6	2018	F1	01 Engine Electronics	Output Tests	
Audi A6	2018	F1	01 Engine Electronics	Specia Functions	
Audi A6	2018	F1	02 Transmission Electronics	Read Fault Codes	
Audi A6	2018	F1	02 Transmission Electronics	Clear Fault Codes	
Audi A6	2018	F1	02 Transmission Electronics	Measuring Blocks	
Audi A6	2018	F1	02 Transmission Electronics	Output Tests	
Audi A6	2018	F1	02 Transmission Electronics	Specia Functions	
Audi A6	2018	F1	03 Brake Electronics	Read Fault Codes	
Audi A6	2018	F1	03 Brake Electronics	Clear Fault Codes	
Audi A6	2018	F1	03 Brake Electronics	Measuring Blocks	
Audi A6	2018	F1	03 Brake Electronics	Output Tests	
Audi A6	2018	F1	03 Brake Electronics	Specia Functions	
Audi A6	2018	F1	06 Passene. Seat Adj.	Read Fault Codes	
Audi A6	2018	F1	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6	2018	F1	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6	2018	F1	06 Passene. Seat Adj.	Output Tests	
Audi A6	2018	F1	06 Passene. Seat Adj.	Specia Functions	
Audi A6	2018	F1	09 Electronic Ctrl Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A6	2018	F1	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A6	2018	F1	09 Electronic Ctrl Electronics	Output Tests	
Audi A6	2018	F1	09 Electronic Ctrl Electronics	Specia Functions	
Audi A6	2018	F1	0E Media Player Position 1	Read Fault Codes	
Audi A6	2018	F1	0E Media Player Position 1	Clear Fault Codes	
Audi A6	2018	F1	0E Media Player Position 1	Measuring Blocks	
Audi A6	2018	F1	0E Media Player Position 1	Output Tests	
Audi A6	2018	F1	0E Media Player Position 1	Specia Functions	
Audi A6	2018	F1	13 Distance Control	Read Fault Codes	
Audi A6	2018	F1	13 Distance Control	Clear Fault Codes	
Audi A6	2018	F1	13 Distance Control	Measuring Blocks	
Audi A6	2018	F1	13 Distance Control	Output Tests	
Audi A6	2018	F1	13 Distance Control	Specia Functions	
Audi A6	2018	F1	15 Airbags	Read Fault Codes	
Audi A6	2018	F1	15 Airbags	Clear Fault Codes	
Audi A6	2018	F1	15 Airbags	Measuring Blocks	
Audi A6	2018	F1	15 Airbags	Output Tests	
Audi A6	2018	F1	15 Airbags	Specia Functions	
Audi A6	2018	F1	16 Steering Wheel Electronics	Read Fault Codes	
Audi A6	2018	F1	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6	2018	F1	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6	2018	F1	16 Steering Wheel Electronics	Output Tests	
Audi A6	2018	F1	16 Steering Wheel Electronics	Specia Functions	
Audi A6	2018	F1	17 Instrument Cluster	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	17 Instrument Cluster	Clear Fault Codes	
Audi A6	2018	F1	17 Instrument Cluster	Measuring Blocks	
Audi A6	2018	F1	17 Instrument Cluster	Output Tests	
Audi A6	2018	F1	17 Instrument Cluster	Specia Functions	
Audi A6	2018	F1	18 Aux Heating	Read Fault Codes	
Audi A6	2018	F1	18 Aux Heating	Clear Fault Codes	
Audi A6	2018	F1	18 Aux Heating	Measuring Blocks	
Audi A6	2018	F1	18 Aux Heating	Output Tests	
Audi A6	2018	F1	18 Aux Heating	Specia Functions	
Audi A6	2018	F1	19 Gateway Data Bus	Read Fault Codes	
Audi A6	2018	F1	19 Gateway Data Bus	Clear Fault Codes	
Audi A6	2018	F1	19 Gateway Data Bus	Measuring Blocks	
Audi A6	2018	F1	19 Gateway Data Bus	Output Tests	
Audi A6	2018	F1	19 Gateway Data Bus	Specia Functions	
Audi A6	2018	F1	1B Power-Assisted Steering	Read Fault Codes	
Audi A6	2018	F1	1B Power-Assisted Steering	Clear Fault Codes	
Audi A6	2018	F1	1B Power-Assisted Steering	Measuring Blocks	
Audi A6	2018	F1	1B Power-Assisted Steering	Output Tests	
Audi A6	2018	F1	1B Power-Assisted Steering	Specia Functions	
Audi A6	2018	F1	20 High Beam Assistance Device	Read Fault Codes	
Audi A6	2018	F1	20 High Beam Assistance Device	Clear Fault Codes	
Audi A6	2018	F1	20 High Beam Assistance Device	Measuring Blocks	
Audi A6	2018	F1	20 High Beam Assistance Device	Output Tests	
Audi A6	2018	F1	20 High Beam Assistance Device	Specia Functions	
Audi A6	2018	F1	21 Engine Electronics 3	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	21 Engine Electronics 3	Clear Fault Codes	
Audi A6	2018	F1	21 Engine Electronics 3	Measuring Blocks	
Audi A6	2018	F1	21 Engine Electronics 3	Output Tests	
Audi A6	2018	F1	21 Engine Electronics 3	Specia Functions	
Audi A6	2018	F1	22 4WD Electronics	Read Fault Codes	
Audi A6	2018	F1	22 4WD Electronics	Clear Fault Codes	
Audi A6	2018	F1	22 4WD Electronics	Measuring Blocks	
Audi A6	2018	F1	22 4WD Electronics	Output Tests	
Audi A6	2018	F1	22 4WD Electronics	Specia Functions	
Audi A6	2018	F1	23 Braker Booster	Read Fault Codes	
Audi A6	2018	F1	23 Braker Booster	Clear Fault Codes	
Audi A6	2018	F1	23 Braker Booster	Measuring Blocks	
Audi A6	2018	F1	23 Braker Booster	Output Tests	
Audi A6	2018	F1	23 Braker Booster	Specia Functions	
Audi A6	2018	F1	2B Steer Col Lock	Read Fault Codes	
Audi A6	2018	F1	2B Steer Col Lock	Clear Fault Codes	
Audi A6	2018	F1	2B Steer Col Lock	Measuring Blocks	
Audi A6	2018	F1	2B Steer Col Lock	Output Tests	
Audi A6	2018	F1	2B Steer Col Lock	Specia Functions	
Audi A6	2018	F1	32 Locking Electronisc	Read Fault Codes	
Audi A6	2018	F1	32 Locking Electronisc	Clear Fault Codes	
Audi A6	2018	F1	32 Locking Electronisc	Measuring Blocks	
Audi A6	2018	F1	32 Locking Electronisc	Output Tests	
Audi A6	2018	F1	32 Locking Electronisc	Specia Functions	
Audi A6	2018	F1	36 Driver`s Side Seat Adj.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Audi A6	2018	F1	36 Driver`s Side Seat Adj.	Measuring Blocks	
Audi A6	2018	F1	36 Driver`s Side Seat Adj.	Output Tests	
Audi A6	2018	F1	36 Driver`s Side Seat Adj.	Specia Functions	
Audi A6	2018	F1	3C Lane Departure Assistance System	Read Fault Codes	
Audi A6	2018	F1	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A6	2018	F1	3C Lane Departure Assistance System	Measuring Blocks	
Audi A6	2018	F1	3C Lane Departure Assistance System	Output Tests	
Audi A6	2018	F1	3C Lane Departure Assistance System	Specia Functions	
Audi A6	2018	F1	42 Driver-Door Elect.	Read Fault Codes	
Audi A6	2018	F1	42 Driver-Door Elect.	Clear Fault Codes	
Audi A6	2018	F1	42 Driver-Door Elect.	Measuring Blocks	
Audi A6	2018	F1	42 Driver-Door Elect.	Output Tests	
Audi A6	2018	F1	42 Driver-Door Elect.	Specia Functions	
Audi A6	2018	F1	44 Steering Assistance	Read Fault Codes	
Audi A6	2018	F1	44 Steering Assistance	Clear Fault Codes	
Audi A6	2018	F1	44 Steering Assistance	Measuring Blocks	
Audi A6	2018	F1	44 Steering Assistance	Output Tests	
Audi A6	2018	F1	44 Steering Assistance	Specia Functions	
Audi A6	2018	F1	46 Central Control Module	Read Fault Codes	
Audi A6	2018	F1	46 Central Control Module	Clear Fault Codes	
Audi A6	2018	F1	46 Central Control Module	Measuring Blocks	
Audi A6	2018	F1	46 Central Control Module	Output Tests	
Audi A6	2018	F1	46 Central Control Module	Specia Functions	
Audi A6	2018	F1	47 Soundsystem	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	47 Soundsystem	Clear Fault Codes	
Audi A6	2018	F1	47 Soundsystem	Measuring Blocks	
Audi A6	2018	F1	47 Soundsystem	Output Tests	
Audi A6	2018	F1	47 Soundsystem	Specia Functions	
Audi A6	2018	F1	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi A6	2018	F1	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A6	2018	F1	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A6	2018	F1	48 Drvs Seat Adj.Rear	Output Tests	
Audi A6	2018	F1	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A6	2018	F1	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi A6	2018	F1	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A6	2018	F1	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A6	2018	F1	48 Drvs Seat Adj.Rear	Output Tests	
Audi A6	2018	F1	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A6	2018	F1	4E Control Head RR	Read Fault Codes	
Audi A6	2018	F1	4E Control Head RR	Clear Fault Codes	
Audi A6	2018	F1	4E Control Head RR	Measuring Blocks	
Audi A6	2018	F1	4E Control Head RR	Output Tests	
Audi A6	2018	F1	4E Control Head RR	Specia Functions	
Audi A6	2018	F1	51 Electric Drive	Read Fault Codes	
Audi A6	2018	F1	51 Electric Drive	Clear Fault Codes	
Audi A6	2018	F1	51 Electric Drive	Measuring Blocks	
Audi A6	2018	F1	51 Electric Drive	Output Tests	
Audi A6	2018	F1	51 Electric Drive	Specia Functions	
Audi A6	2018	F1	52 Passe.-Door Elect.	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A6	2018	F1	52 Passe.-Door Elect.	Measuring Blocks	
Audi A6	2018	F1	52 Passe.-Door Elect.	Output Tests	
Audi A6	2018	F1	52 Passe.-Door Elect.	Specia Functions	
Audi A6	2018	F1	57 TV-Tuner	Read Fault Codes	
Audi A6	2018	F1	57 TV-Tuner	Clear Fault Codes	
Audi A6	2018	F1	57 TV-Tuner	Measuring Blocks	
Audi A6	2018	F1	57 TV-Tuner	Output Tests	
Audi A6	2018	F1	57 TV-Tuner	Specia Functions	
Audi A6	2018	F1	5E Control Head LR	Read Fault Codes	
Audi A6	2018	F1	5E Control Head LR	Clear Fault Codes	
Audi A6	2018	F1	5E Control Head LR	Measuring Blocks	
Audi A6	2018	F1	5E Control Head LR	Output Tests	
Audi A6	2018	F1	5E Control Head LR	Specia Functions	
Audi A6	2018	F1	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A6	2018	F1	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A6	2018	F1	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A6	2018	F1	5F Information Electronic Equipment 1	Output Tests	
Audi A6	2018	F1	5F Information Electronic Equipment 1	Specia Functions	
Audi A6	2018	F1	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A6	2018	F1	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6	2018	F1	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6	2018	F1	65 Tyre Pressure Monitoring	Output Tests	
Audi A6	2018	F1	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6	2018	F1	69 Trailer Function	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	69 Trailer Function	Clear Fault Codes	
Audi A6	2018	F1	69 Trailer Function	Measuring Blocks	
Audi A6	2018	F1	69 Trailer Function	Output Tests	
Audi A6	2018	F1	69 Trailer Function	Specia Functions	
Audi A6	2018	F1	6C Rear Camera	Read Fault Codes	
Audi A6	2018	F1	6C Rear Camera	Clear Fault Codes	
Audi A6	2018	F1	6C Rear Camera	Measuring Blocks	
Audi A6	2018	F1	6C Rear Camera	Output Tests	
Audi A6	2018	F1	6C Rear Camera	Specia Functions	
Audi A6	2018	F1	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A6	2018	F1	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A6	2018	F1	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A6	2018	F1	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A6	2018	F1	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A6	2018	F1	74 Vehicle Control System	Read Fault Codes	
Audi A6	2018	F1	74 Vehicle Control System	Clear Fault Codes	
Audi A6	2018	F1	74 Vehicle Control System	Measuring Blocks	
Audi A6	2018	F1	74 Vehicle Control System	Output Tests	
Audi A6	2018	F1	74 Vehicle Control System	Specia Functions	
Audi A6	2018	F1	75 Emergency Call Module	Read Fault Codes	
Audi A6	2018	F1	75 Emergency Call Module	Clear Fault Codes	
Audi A6	2018	F1	75 Emergency Call Module	Measuring Blocks	
Audi A6	2018	F1	75 Emergency Call Module	Output Tests	
Audi A6	2018	F1	75 Emergency Call Module	Specia Functions	
Audi A6	2018	F1	80 Batterieregelung Zusatzspeicher 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	80 Batterieregelung Zusatzspeicher 1	Clear Fault Codes	
Audi A6	2018	F1	80 Batterieregelung Zusatzspeicher 1	Measuring Blocks	
Audi A6	2018	F1	80 Batterieregelung Zusatzspeicher 1	Output Tests	
Audi A6	2018	F1	80 Batterieregelung Zusatzspeicher 1	Specia Functions	
Audi A6	2018	F1	81 Gear Shift	Read Fault Codes	
Audi A6	2018	F1	81 Gear Shift	Clear Fault Codes	
Audi A6	2018	F1	81 Gear Shift	Measuring Blocks	
Audi A6	2018	F1	81 Gear Shift	Output Tests	
Audi A6	2018	F1	81 Gear Shift	Specia Functions	
Audi A6	2018	F1	82 Heads Up Display	Read Fault Codes	
Audi A6	2018	F1	82 Heads Up Display	Clear Fault Codes	
Audi A6	2018	F1	82 Heads Up Display	Measuring Blocks	
Audi A6	2018	F1	82 Heads Up Display	Output Tests	
Audi A6	2018	F1	82 Heads Up Display	Specia Functions	
Audi A6	2018	F1	84 Night Vision	Read Fault Codes	
Audi A6	2018	F1	84 Night Vision	Clear Fault Codes	
Audi A6	2018	F1	84 Night Vision	Measuring Blocks	
Audi A6	2018	F1	84 Night Vision	Output Tests	
Audi A6	2018	F1	84 Night Vision	Specia Functions	
Audi A6	2018	F1	8C Hybrid Battery	Read Fault Codes	
Audi A6	2018	F1	8C Hybrid Battery	Clear Fault Codes	
Audi A6	2018	F1	8C Hybrid Battery	Measuring Blocks	
Audi A6	2018	F1	8C Hybrid Battery	Output Tests	
Audi A6	2018	F1	8C Hybrid Battery	Specia Functions	
Audi A6	2018	F1	A5 Frt Sens.Drv.Assist	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A6	2018	F1	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A6	2018	F1	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A6	2018	F1	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A6	2018	F1	A9 Struct.Borne Sound	Read Fault Codes	
Audi A6	2018	F1	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A6	2018	F1	A9 Struct.Borne Sound	Measuring Blocks	
Audi A6	2018	F1	A9 Struct.Borne Sound	Output Tests	
Audi A6	2018	F1	A9 Struct.Borne Sound	Specia Functions	
Audi A6	2018	F1	AC Reductant Control	Read Fault Codes	
Audi A6	2018	F1	AC Reductant Control	Clear Fault Codes	
Audi A6	2018	F1	AC Reductant Control	Measuring Blocks	
Audi A6	2018	F1	AC Reductant Control	Output Tests	
Audi A6	2018	F1	AC Reductant Control	Specia Functions	
Audi A6	2018	F1	BA Motor Mounts	Read Fault Codes	
Audi A6	2018	F1	BA Motor Mounts	Clear Fault Codes	
Audi A6	2018	F1	BA Motor Mounts	Measuring Blocks	
Audi A6	2018	F1	BA Motor Mounts	Output Tests	
Audi A6	2018	F1	BA Motor Mounts	Specia Functions	
Audi A6	2018	F1	BB Door Rear Drv Side	Read Fault Codes	
Audi A6	2018	F1	BB Door Rear Drv Side	Clear Fault Codes	
Audi A6	2018	F1	BB Door Rear Drv Side	Measuring Blocks	
Audi A6	2018	F1	BB Door Rear Drv Side	Output Tests	
Audi A6	2018	F1	BB Door Rear Drv Side	Specia Functions	
Audi A6	2018	F1	BC Door Rear Pass Side	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	BC Door Rear Pass Side	Clear Fault Codes	
Audi A6	2018	F1	BC Door Rear Pass Side	Measuring Blocks	
Audi A6	2018	F1	BC Door Rear Pass Side	Output Tests	
Audi A6	2018	F1	BC Door Rear Pass Side	Specia Functions	
Audi A6	2018	F1	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A6	2018	F1	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A6	2018	F1	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A6	2018	F1	C0 Act. For Ext. Noise	Output Tests	
Audi A6	2018	F1	C0 Act. For Ext. Noise	Specia Functions	
Audi A6	2018	F1	C4 DC/DC Converter Control Module	Read Fault Codes	
Audi A6	2018	F1	C4 DC/DC Converter Control Module	Clear Fault Codes	
Audi A6	2018	F1	C4 DC/DC Converter Control Module	Measuring Blocks	
Audi A6	2018	F1	C4 DC/DC Converter Control Module	Output Tests	
Audi A6	2018	F1	C4 DC/DC Converter Control Module	Specia Functions	
Audi A6	2018	F1	C5 Thermal Management	Read Fault Codes	
Audi A6	2018	F1	C5 Thermal Management	Clear Fault Codes	
Audi A6	2018	F1	C5 Thermal Management	Measuring Blocks	
Audi A6	2018	F1	C5 Thermal Management	Output Tests	
Audi A6	2018	F1	C5 Thermal Management	Specia Functions	
Audi A6	2018	F1	C6 Batt. Chrg	Read Fault Codes	
Audi A6	2018	F1	C6 Batt. Chrg	Clear Fault Codes	
Audi A6	2018	F1	C6 Batt. Chrg	Measuring Blocks	
Audi A6	2018	F1	C6 Batt. Chrg	Output Tests	
Audi A6	2018	F1	C6 Batt. Chrg	Specia Functions	
Audi A6	2018	F1	CA Control Module For Sunroof	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	CA Control Module For Sunroof	Clear Fault Codes	
Audi A6	2018	F1	CA Control Module For Sunroof	Measuring Blocks	
Audi A6	2018	F1	CA Control Module For Sunroof	Output Tests	
Audi A6	2018	F1	CA Control Module For Sunroof	Specia Functions	
Audi A6	2018	F1	CB Rear Axle Steering	Read Fault Codes	
Audi A6	2018	F1	CB Rear Axle Steering	Clear Fault Codes	
Audi A6	2018	F1	CB Rear Axle Steering	Measuring Blocks	
Audi A6	2018	F1	CB Rear Axle Steering	Output Tests	
Audi A6	2018	F1	CB Rear Axle Steering	Specia Functions	
Audi A6	2018	F1	CC Starter / Generator Control Module	Read Fault Codes	
Audi A6	2018	F1	CC Starter / Generator Control Module	Clear Fault Codes	
Audi A6	2018	F1	CC Starter / Generator Control Module	Measuring Blocks	
Audi A6	2018	F1	CC Starter / Generator Control Module	Output Tests	
Audi A6	2018	F1	CC Starter / Generator Control Module	Specia Functions	
Audi A6	2018	F1	CD Laser Scanner	Read Fault Codes	
Audi A6	2018	F1	CD Laser Scanner	Clear Fault Codes	
Audi A6	2018	F1	CD Laser Scanner	Measuring Blocks	
Audi A6	2018	F1	CD Laser Scanner	Output Tests	
Audi A6	2018	F1	CD Laser Scanner	Specia Functions	
Audi A6	2018	F1	CF Control Unit Lane Change Assistant	Read Fault Codes	
Audi A6	2018	F1	CF Control Unit Lane Change Assistant	Clear Fault Codes	
Audi A6	2018	F1	CF Control Unit Lane Change Assistant	Measuring Blocks	
Audi A6	2018	F1	CF Control Unit Lane Change Assistant	Output Tests	
Audi A6	2018	F1	CF Control Unit Lane Change Assistant	Specia Functions	
Audi A6	2018	F1	D4 Roll Control System 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6	2018	F1	D4 Roll Control System 1	Clear Fault Codes	
Audi A6	2018	F1	D4 Roll Control System 1	Measuring Blocks	
Audi A6	2018	F1	D4 Roll Control System 1	Output Tests	
Audi A6	2018	F1	D4 Roll Control System 1	Specia Functions	
Audi A6	2018	F1	D5 Roll Control System 2	Read Fault Codes	
Audi A6	2018	F1	D5 Roll Control System 2	Clear Fault Codes	
Audi A6	2018	F1	D5 Roll Control System 2	Measuring Blocks	
Audi A6	2018	F1	D5 Roll Control System 2	Output Tests	
Audi A6	2018	F1	D5 Roll Control System 2	Specia Functions	
Audi A6	2018	F1	D6 Light Control Left 2	Read Fault Codes	
Audi A6	2018	F1	D6 Light Control Left 2	Clear Fault Codes	
Audi A6	2018	F1	D6 Light Control Left 2	Measuring Blocks	
Audi A6	2018	F1	D6 Light Control Left 2	Output Tests	
Audi A6	2018	F1	D6 Light Control Left 2	Specia Functions	
Audi A6	2018	F1	D7 Light Control Right 2	Read Fault Codes	
Audi A6	2018	F1	D7 Light Control Right 2	Clear Fault Codes	
Audi A6	2018	F1	D7 Light Control Right 2	Measuring Blocks	
Audi A6	2018	F1	D7 Light Control Right 2	Output Tests	
Audi A6	2018	F1	D7 Light Control Right 2	Specia Functions	
Audi A6	2018	F1	DB Front Corner Radar 1	Read Fault Codes	
Audi A6	2018	F1	DB Front Corner Radar 1	Clear Fault Codes	
Audi A6	2018	F1	DB Front Corner Radar 1	Measuring Blocks	
Audi A6	2018	F1	DB Front Corner Radar 1	Output Tests	
Audi A6	2018	F1	DB Front Corner Radar 1	Specia Functions	
Audi A6	2018	F1	DC Front Corner Radar 2	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6	2018	F1	DC Front Corner Radar 2	Clear Fault Codes	
Audi A6	2018	F1	DC Front Corner Radar 2	Measuring Blocks	
Audi A6	2018	F1	DC Front Corner Radar 2	Output Tests	
Audi A6	2018	F1	DC Front Corner Radar 2	Specia Functions	
Audi A6	2018	F1	DD Control Module 2 For Sunroof	Read Fault Codes	
Audi A6	2018	F1	DD Control Module 2 For Sunroof	Clear Fault Codes	
Audi A6	2018	F1	DD Control Module 2 For Sunroof	Measuring Blocks	
Audi A6	2018	F1	DD Control Module 2 For Sunroof	Output Tests	
Audi A6	2018	F1	DD Control Module 2 For Sunroof	Specia Functions	
Audi A6	2018	F1	DE Charger 1 Mobile Devices	Read Fault Codes	
Audi A6	2018	F1	DE Charger 1 Mobile Devices	Clear Fault Codes	
Audi A6	2018	F1	DE Charger 1 Mobile Devices	Measuring Blocks	
Audi A6	2018	F1	DE Charger 1 Mobile Devices	Output Tests	
Audi A6	2018	F1	DE Charger 1 Mobile Devices	Specia Functions	
Audi A6	2018	F1	E0 Zusatzanzeige-/Bedieneinheit 1	Read Fault Codes	
Audi A6	2018	F1	E0 Zusatzanzeige-/Bedieneinheit 1	Clear Fault Codes	
Audi A6	2018	F1	E0 Zusatzanzeige-/Bedieneinheit 1	Measuring Blocks	
Audi A6	2018	F1	E0 Zusatzanzeige-/Bedieneinheit 1	Output Tests	
Audi A6	2018	F1	E0 Zusatzanzeige-/Bedieneinheit 1	Specia Functions	
Audi A7	2018	4K	01 Engine Electronics	Read Fault Codes	
Audi A7	2018	4K	01 Engine Electronics	Clear Fault Codes	
Audi A7	2018	4K	01 Engine Electronics	Measuring Blocks	
Audi A7	2018	4K	01 Engine Electronics	Output Tests	
Audi A7	2018	4K	01 Engine Electronics	Specia Functions	
Audi A7	2018	4K	02 Transmission Electronics	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	02 Transmission Electronics	Clear Fault Codes	
Audi A7	2018	4K	02 Transmission Electronics	Measuring Blocks	
Audi A7	2018	4K	02 Transmission Electronics	Output Tests	
Audi A7	2018	4K	02 Transmission Electronics	Specia Functions	
Audi A7	2018	4K	03 Brake Electronics	Read Fault Codes	
Audi A7	2018	4K	03 Brake Electronics	Clear Fault Codes	
Audi A7	2018	4K	03 Brake Electronics	Measuring Blocks	
Audi A7	2018	4K	03 Brake Electronics	Output Tests	
Audi A7	2018	4K	03 Brake Electronics	Specia Functions	
Audi A7	2018	4K	06 Passene. Seat Adj.	Read Fault Codes	
Audi A7	2018	4K	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A7	2018	4K	06 Passene. Seat Adj.	Measuring Blocks	
Audi A7	2018	4K	06 Passene. Seat Adj.	Output Tests	
Audi A7	2018	4K	06 Passene. Seat Adj.	Specia Functions	
Audi A7	2018	4K	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A7	2018	4K	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A7	2018	4K	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A7	2018	4K	09 Electronic Ctrl Electronics	Output Tests	
Audi A7	2018	4K	09 Electronic Ctrl Electronics	Specia Functions	
Audi A7	2018	4K	0E Media Player Position 1	Read Fault Codes	
Audi A7	2018	4K	0E Media Player Position 1	Clear Fault Codes	
Audi A7	2018	4K	0E Media Player Position 1	Measuring Blocks	
Audi A7	2018	4K	0E Media Player Position 1	Output Tests	
Audi A7	2018	4K	0E Media Player Position 1	Specia Functions	
Audi A7	2018	4K	13 Distance Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	13 Distance Control	Clear Fault Codes	
Audi A7	2018	4K	13 Distance Control	Measuring Blocks	
Audi A7	2018	4K	13 Distance Control	Output Tests	
Audi A7	2018	4K	13 Distance Control	Specia Functions	
Audi A7	2018	4K	15 Airbags	Read Fault Codes	
Audi A7	2018	4K	15 Airbags	Clear Fault Codes	
Audi A7	2018	4K	15 Airbags	Measuring Blocks	
Audi A7	2018	4K	15 Airbags	Output Tests	
Audi A7	2018	4K	15 Airbags	Specia Functions	
Audi A7	2018	4K	16 Steering Wheel Electronics	Read Fault Codes	
Audi A7	2018	4K	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A7	2018	4K	16 Steering Wheel Electronics	Measuring Blocks	
Audi A7	2018	4K	16 Steering Wheel Electronics	Output Tests	
Audi A7	2018	4K	16 Steering Wheel Electronics	Specia Functions	
Audi A7	2018	4K	17 Instrument Cluster	Read Fault Codes	
Audi A7	2018	4K	17 Instrument Cluster	Clear Fault Codes	
Audi A7	2018	4K	17 Instrument Cluster	Measuring Blocks	
Audi A7	2018	4K	17 Instrument Cluster	Output Tests	
Audi A7	2018	4K	17 Instrument Cluster	Specia Functions	
Audi A7	2018	4K	18 Aux Heating	Read Fault Codes	
Audi A7	2018	4K	18 Aux Heating	Clear Fault Codes	
Audi A7	2018	4K	18 Aux Heating	Measuring Blocks	
Audi A7	2018	4K	18 Aux Heating	Output Tests	
Audi A7	2018	4K	18 Aux Heating	Specia Functions	
Audi A7	2018	4K	19 Gateway Data Bus	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	19 Gateway Data Bus	Clear Fault Codes	
Audi A7	2018	4K	19 Gateway Data Bus	Measuring Blocks	
Audi A7	2018	4K	19 Gateway Data Bus	Output Tests	
Audi A7	2018	4K	19 Gateway Data Bus	Specia Functions	
Audi A7	2018	4K	1B Power-Assisted Steering	Read Fault Codes	
Audi A7	2018	4K	1B Power-Assisted Steering	Clear Fault Codes	
Audi A7	2018	4K	1B Power-Assisted Steering	Measuring Blocks	
Audi A7	2018	4K	1B Power-Assisted Steering	Output Tests	
Audi A7	2018	4K	1B Power-Assisted Steering	Specia Functions	
Audi A7	2018	4K	20 High Beam Assistance Device	Read Fault Codes	
Audi A7	2018	4K	20 High Beam Assistance Device	Clear Fault Codes	
Audi A7	2018	4K	20 High Beam Assistance Device	Measuring Blocks	
Audi A7	2018	4K	20 High Beam Assistance Device	Output Tests	
Audi A7	2018	4K	20 High Beam Assistance Device	Specia Functions	
Audi A7	2018	4K	21 Engine Electronics 3	Read Fault Codes	
Audi A7	2018	4K	21 Engine Electronics 3	Clear Fault Codes	
Audi A7	2018	4K	21 Engine Electronics 3	Measuring Blocks	
Audi A7	2018	4K	21 Engine Electronics 3	Output Tests	
Audi A7	2018	4K	21 Engine Electronics 3	Specia Functions	
Audi A7	2018	4K	22 4WD Electronics	Read Fault Codes	
Audi A7	2018	4K	22 4WD Electronics	Clear Fault Codes	
Audi A7	2018	4K	22 4WD Electronics	Measuring Blocks	
Audi A7	2018	4K	22 4WD Electronics	Output Tests	
Audi A7	2018	4K	22 4WD Electronics	Specia Functions	
Audi A7	2018	4K	23 Braker Booster	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7	2018	4K	23 Braker Booster	Clear Fault Codes	
Audi A7	2018	4K	23 Braker Booster	Measuring Blocks	
Audi A7	2018	4K	23 Braker Booster	Output Tests	
Audi A7	2018	4K	23 Braker Booster	Specia Functions	
Audi A7	2018	4K	2B Steer Col Lock	Read Fault Codes	
Audi A7	2018	4K	2B Steer Col Lock	Clear Fault Codes	
Audi A7	2018	4K	2B Steer Col Lock	Measuring Blocks	
Audi A7	2018	4K	2B Steer Col Lock	Output Tests	
Audi A7	2018	4K	2B Steer Col Lock	Specia Functions	
Audi A7	2018	4K	32 Locking Electronisc	Read Fault Codes	
Audi A7	2018	4K	32 Locking Electronisc	Clear Fault Codes	
Audi A7	2018	4K	32 Locking Electronisc	Measuring Blocks	
Audi A7	2018	4K	32 Locking Electronisc	Output Tests	
Audi A7	2018	4K	32 Locking Electronisc	Specia Functions	
Audi A7	2018	4K	36 Driver`s Side Seat Adj.	Read Fault Codes	
Audi A7	2018	4K	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Audi A7	2018	4K	36 Driver`s Side Seat Adj.	Measuring Blocks	
Audi A7	2018	4K	36 Driver`s Side Seat Adj.	Output Tests	
Audi A7	2018	4K	36 Driver`s Side Seat Adj.	Specia Functions	
Audi A7	2018	4K	3C Lane Departure Assistance System	Read Fault Codes	
Audi A7	2018	4K	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A7	2018	4K	3C Lane Departure Assistance System	Measuring Blocks	
Audi A7	2018	4K	3C Lane Departure Assistance System	Output Tests	
Audi A7	2018	4K	3C Lane Departure Assistance System	Specia Functions	
Audi A7	2018	4K	42 Driver-Door Elect.	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	42 Driver-Door Elect.	Clear Fault Codes	
Audi A7	2018	4K	42 Driver-Door Elect.	Measuring Blocks	
Audi A7	2018	4K	42 Driver-Door Elect.	Output Tests	
Audi A7	2018	4K	42 Driver-Door Elect.	Specia Functions	
Audi A7	2018	4K	44 Steering Assistance	Read Fault Codes	
Audi A7	2018	4K	44 Steering Assistance	Clear Fault Codes	
Audi A7	2018	4K	44 Steering Assistance	Measuring Blocks	
Audi A7	2018	4K	44 Steering Assistance	Output Tests	
Audi A7	2018	4K	44 Steering Assistance	Specia Functions	
Audi A7	2018	4K	46 Central Control Module	Read Fault Codes	
Audi A7	2018	4K	46 Central Control Module	Clear Fault Codes	
Audi A7	2018	4K	46 Central Control Module	Measuring Blocks	
Audi A7	2018	4K	46 Central Control Module	Output Tests	
Audi A7	2018	4K	46 Central Control Module	Specia Functions	
Audi A7	2018	4K	47 Soundsystem	Read Fault Codes	
Audi A7	2018	4K	47 Soundsystem	Clear Fault Codes	
Audi A7	2018	4K	47 Soundsystem	Measuring Blocks	
Audi A7	2018	4K	47 Soundsystem	Output Tests	
Audi A7	2018	4K	47 Soundsystem	Specia Functions	
Audi A7	2018	4K	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi A7	2018	4K	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A7	2018	4K	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A7	2018	4K	48 Drvs Seat Adj.Rear	Output Tests	
Audi A7	2018	4K	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A7	2018	4K	48 Drvs Seat Adj.Rear	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A7	2018	4K	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A7	2018	4K	48 Drvs Seat Adj.Rear	Output Tests	
Audi A7	2018	4K	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A7	2018	4K	4E Control Head RR	Read Fault Codes	
Audi A7	2018	4K	4E Control Head RR	Clear Fault Codes	
Audi A7	2018	4K	4E Control Head RR	Measuring Blocks	
Audi A7	2018	4K	4E Control Head RR	Output Tests	
Audi A7	2018	4K	4E Control Head RR	Specia Functions	
Audi A7	2018	4K	51 Electric Drive	Read Fault Codes	
Audi A7	2018	4K	51 Electric Drive	Clear Fault Codes	
Audi A7	2018	4K	51 Electric Drive	Measuring Blocks	
Audi A7	2018	4K	51 Electric Drive	Output Tests	
Audi A7	2018	4K	51 Electric Drive	Specia Functions	
Audi A7	2018	4K	52 Passe.-Door Elect.	Read Fault Codes	
Audi A7	2018	4K	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A7	2018	4K	52 Passe.-Door Elect.	Measuring Blocks	
Audi A7	2018	4K	52 Passe.-Door Elect.	Output Tests	
Audi A7	2018	4K	52 Passe.-Door Elect.	Specia Functions	
Audi A7	2018	4K	57 TV-Tuner	Read Fault Codes	
Audi A7	2018	4K	57 TV-Tuner	Clear Fault Codes	
Audi A7	2018	4K	57 TV-Tuner	Measuring Blocks	
Audi A7	2018	4K	57 TV-Tuner	Output Tests	
Audi A7	2018	4K	57 TV-Tuner	Specia Functions	
Audi A7	2018	4K	5E Control Head LR	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	5E Control Head LR	Clear Fault Codes	
Audi A7	2018	4K	5E Control Head LR	Measuring Blocks	
Audi A7	2018	4K	5E Control Head LR	Output Tests	
Audi A7	2018	4K	5E Control Head LR	Specia Functions	
Audi A7	2018	4K	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A7	2018	4K	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A7	2018	4K	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A7	2018	4K	5F Information Electronic Equipment 1	Output Tests	
Audi A7	2018	4K	5F Information Electronic Equipment 1	Specia Functions	
Audi A7	2018	4K	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A7	2018	4K	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A7	2018	4K	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A7	2018	4K	65 Tyre Pressure Monitoring	Output Tests	
Audi A7	2018	4K	65 Tyre Pressure Monitoring	Specia Functions	
Audi A7	2018	4K	69 Trailer Function	Read Fault Codes	
Audi A7	2018	4K	69 Trailer Function	Clear Fault Codes	
Audi A7	2018	4K	69 Trailer Function	Measuring Blocks	
Audi A7	2018	4K	69 Trailer Function	Output Tests	
Audi A7	2018	4K	69 Trailer Function	Specia Functions	
Audi A7	2018	4K	6C Rear Camera	Read Fault Codes	
Audi A7	2018	4K	6C Rear Camera	Clear Fault Codes	
Audi A7	2018	4K	6C Rear Camera	Measuring Blocks	
Audi A7	2018	4K	6C Rear Camera	Output Tests	
Audi A7	2018	4K	6C Rear Camera	Specia Functions	
Audi A7	2018	4K	6D Electronic Equipment of Trunk Lid	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A7	2018	4K	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A7	2018	4K	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A7	2018	4K	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A7	2018	4K	74 Vehicle Control System	Read Fault Codes	
Audi A7	2018	4K	74 Vehicle Control System	Clear Fault Codes	
Audi A7	2018	4K	74 Vehicle Control System	Measuring Blocks	
Audi A7	2018	4K	74 Vehicle Control System	Output Tests	
Audi A7	2018	4K	74 Vehicle Control System	Specia Functions	
Audi A7	2018	4K	75 Emergency Call Module	Read Fault Codes	
Audi A7	2018	4K	75 Emergency Call Module	Clear Fault Codes	
Audi A7	2018	4K	75 Emergency Call Module	Measuring Blocks	
Audi A7	2018	4K	75 Emergency Call Module	Output Tests	
Audi A7	2018	4K	75 Emergency Call Module	Specia Functions	
Audi A7	2018	4K	80 Batterieregelung Zusatzspeicher 1	Read Fault Codes	
Audi A7	2018	4K	80 Batterieregelung Zusatzspeicher 1	Clear Fault Codes	
Audi A7	2018	4K	80 Batterieregelung Zusatzspeicher 1	Measuring Blocks	
Audi A7	2018	4K	80 Batterieregelung Zusatzspeicher 1	Output Tests	
Audi A7	2018	4K	80 Batterieregelung Zusatzspeicher 1	Specia Functions	
Audi A7	2018	4K	81 Gear Shift	Read Fault Codes	
Audi A7	2018	4K	81 Gear Shift	Clear Fault Codes	
Audi A7	2018	4K	81 Gear Shift	Measuring Blocks	
Audi A7	2018	4K	81 Gear Shift	Output Tests	
Audi A7	2018	4K	81 Gear Shift	Specia Functions	
Audi A7	2018	4K	82 Heads Up Display	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	82 Heads Up Display	Clear Fault Codes	
Audi A7	2018	4K	82 Heads Up Display	Measuring Blocks	
Audi A7	2018	4K	82 Heads Up Display	Output Tests	
Audi A7	2018	4K	82 Heads Up Display	Specia Functions	
Audi A7	2018	4K	84 Night Vision	Read Fault Codes	
Audi A7	2018	4K	84 Night Vision	Clear Fault Codes	
Audi A7	2018	4K	84 Night Vision	Measuring Blocks	
Audi A7	2018	4K	84 Night Vision	Output Tests	
Audi A7	2018	4K	84 Night Vision	Specia Functions	
Audi A7	2018	4K	8C Hybrid Battery	Read Fault Codes	
Audi A7	2018	4K	8C Hybrid Battery	Clear Fault Codes	
Audi A7	2018	4K	8C Hybrid Battery	Measuring Blocks	
Audi A7	2018	4K	8C Hybrid Battery	Output Tests	
Audi A7	2018	4K	8C Hybrid Battery	Specia Functions	
Audi A7	2018	4K	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A7	2018	4K	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A7	2018	4K	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A7	2018	4K	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A7	2018	4K	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A7	2018	4K	A9 Struct.Borne Sound	Read Fault Codes	
Audi A7	2018	4K	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A7	2018	4K	A9 Struct.Borne Sound	Measuring Blocks	
Audi A7	2018	4K	A9 Struct.Borne Sound	Output Tests	
Audi A7	2018	4K	A9 Struct.Borne Sound	Specia Functions	
Audi A7	2018	4K	AC Reductant Control	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	AC Reductant Control	Clear Fault Codes	
Audi A7	2018	4K	AC Reductant Control	Measuring Blocks	
Audi A7	2018	4K	AC Reductant Control	Output Tests	
Audi A7	2018	4K	AC Reductant Control	Specia Functions	
Audi A7	2018	4K	BA Motor Mounts	Read Fault Codes	
Audi A7	2018	4K	BA Motor Mounts	Clear Fault Codes	
Audi A7	2018	4K	BA Motor Mounts	Measuring Blocks	
Audi A7	2018	4K	BA Motor Mounts	Output Tests	
Audi A7	2018	4K	BA Motor Mounts	Specia Functions	
Audi A7	2018	4K	BB Door Rear Drv Side	Read Fault Codes	
Audi A7	2018	4K	BB Door Rear Drv Side	Clear Fault Codes	
Audi A7	2018	4K	BB Door Rear Drv Side	Measuring Blocks	
Audi A7	2018	4K	BB Door Rear Drv Side	Output Tests	
Audi A7	2018	4K	BB Door Rear Drv Side	Specia Functions	
Audi A7	2018	4K	BC Door Rear Pass Side	Read Fault Codes	
Audi A7	2018	4K	BC Door Rear Pass Side	Clear Fault Codes	
Audi A7	2018	4K	BC Door Rear Pass Side	Measuring Blocks	
Audi A7	2018	4K	BC Door Rear Pass Side	Output Tests	
Audi A7	2018	4K	BC Door Rear Pass Side	Specia Functions	
Audi A7	2018	4K	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A7	2018	4K	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A7	2018	4K	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A7	2018	4K	C0 Act. For Ext. Noise	Output Tests	
Audi A7	2018	4K	C0 Act. For Ext. Noise	Specia Functions	
Audi A7	2018	4K	C4 DC/DC Converter Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	C4 DC/DC Converter Control Module	Clear Fault Codes	
Audi A7	2018	4K	C4 DC/DC Converter Control Module	Measuring Blocks	
Audi A7	2018	4K	C4 DC/DC Converter Control Module	Output Tests	
Audi A7	2018	4K	C4 DC/DC Converter Control Module	Specia Functions	
Audi A7	2018	4K	C5 Thermal Management	Read Fault Codes	
Audi A7	2018	4K	C5 Thermal Management	Clear Fault Codes	
Audi A7	2018	4K	C5 Thermal Management	Measuring Blocks	
Audi A7	2018	4K	C5 Thermal Management	Output Tests	
Audi A7	2018	4K	C5 Thermal Management	Specia Functions	
Audi A7	2018	4K	C6 Batt. Chrg	Read Fault Codes	
Audi A7	2018	4K	C6 Batt. Chrg	Clear Fault Codes	
Audi A7	2018	4K	C6 Batt. Chrg	Measuring Blocks	
Audi A7	2018	4K	C6 Batt. Chrg	Output Tests	
Audi A7	2018	4K	C6 Batt. Chrg	Specia Functions	
Audi A7	2018	4K	CA Control Module For Sunroof	Read Fault Codes	
Audi A7	2018	4K	CA Control Module For Sunroof	Clear Fault Codes	
Audi A7	2018	4K	CA Control Module For Sunroof	Measuring Blocks	
Audi A7	2018	4K	CA Control Module For Sunroof	Output Tests	
Audi A7	2018	4K	CA Control Module For Sunroof	Specia Functions	
Audi A7	2018	4K	CB Rear Axle Steering	Read Fault Codes	
Audi A7	2018	4K	CB Rear Axle Steering	Clear Fault Codes	
Audi A7	2018	4K	CB Rear Axle Steering	Measuring Blocks	
Audi A7	2018	4K	CB Rear Axle Steering	Output Tests	
Audi A7	2018	4K	CB Rear Axle Steering	Specia Functions	
Audi A7	2018	4K	CC Starter / Generator Control Module	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7	2018	4K	CC Starter / Generator Control Module	Clear Fault Codes	
Audi A7	2018	4K	CC Starter / Generator Control Module	Measuring Blocks	
Audi A7	2018	4K	CC Starter / Generator Control Module	Output Tests	
Audi A7	2018	4K	CC Starter / Generator Control Module	Specia Functions	
Audi A7	2018	4K	CD Laser Scanner	Read Fault Codes	
Audi A7	2018	4K	CD Laser Scanner	Clear Fault Codes	
Audi A7	2018	4K	CD Laser Scanner	Measuring Blocks	
Audi A7	2018	4K	CD Laser Scanner	Output Tests	
Audi A7	2018	4K	CD Laser Scanner	Specia Functions	
Audi A7	2018	4K	CF Control Unit Lane Change Assistant	Read Fault Codes	
Audi A7	2018	4K	CF Control Unit Lane Change Assistant	Clear Fault Codes	
Audi A7	2018	4K	CF Control Unit Lane Change Assistant	Measuring Blocks	
Audi A7	2018	4K	CF Control Unit Lane Change Assistant	Output Tests	
Audi A7	2018	4K	CF Control Unit Lane Change Assistant	Specia Functions	
Audi A7	2018	4K	D4 Roll Control System 1	Read Fault Codes	
Audi A7	2018	4K	D4 Roll Control System 1	Clear Fault Codes	
Audi A7	2018	4K	D4 Roll Control System 1	Measuring Blocks	
Audi A7	2018	4K	D4 Roll Control System 1	Output Tests	
Audi A7	2018	4K	D4 Roll Control System 1	Specia Functions	
Audi A7	2018	4K	D5 Roll Control System 2	Read Fault Codes	
Audi A7	2018	4K	D5 Roll Control System 2	Clear Fault Codes	
Audi A7	2018	4K	D5 Roll Control System 2	Measuring Blocks	
Audi A7	2018	4K	D5 Roll Control System 2	Output Tests	
Audi A7	2018	4K	D5 Roll Control System 2	Specia Functions	
Audi A7	2018	4K	D6 Light Control Left 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7	2018	4K	D6 Light Control Left 2	Clear Fault Codes	
Audi A7	2018	4K	D6 Light Control Left 2	Measuring Blocks	
Audi A7	2018	4K	D6 Light Control Left 2	Output Tests	
Audi A7	2018	4K	D6 Light Control Left 2	Specia Functions	
Audi A7	2018	4K	D7 Light Control Right 2	Read Fault Codes	
Audi A7	2018	4K	D7 Light Control Right 2	Clear Fault Codes	
Audi A7	2018	4K	D7 Light Control Right 2	Measuring Blocks	
Audi A7	2018	4K	D7 Light Control Right 2	Output Tests	
Audi A7	2018	4K	D7 Light Control Right 2	Specia Functions	
Audi A7	2018	4K	DB Front Corner Radar 1	Read Fault Codes	
Audi A7	2018	4K	DB Front Corner Radar 1	Clear Fault Codes	
Audi A7	2018	4K	DB Front Corner Radar 1	Measuring Blocks	
Audi A7	2018	4K	DB Front Corner Radar 1	Output Tests	
Audi A7	2018	4K	DB Front Corner Radar 1	Specia Functions	
Audi A7	2018	4K	DC Front Corner Radar 2	Read Fault Codes	
Audi A7	2018	4K	DC Front Corner Radar 2	Clear Fault Codes	
Audi A7	2018	4K	DC Front Corner Radar 2	Measuring Blocks	
Audi A7	2018	4K	DC Front Corner Radar 2	Output Tests	
Audi A7	2018	4K	DC Front Corner Radar 2	Specia Functions	
Audi A7	2018	4K	DD Control Module 2 For Sunroof	Read Fault Codes	
Audi A7	2018	4K	DD Control Module 2 For Sunroof	Clear Fault Codes	
Audi A7	2018	4K	DD Control Module 2 For Sunroof	Measuring Blocks	
Audi A7	2018	4K	DD Control Module 2 For Sunroof	Output Tests	
Audi A7	2018	4K	DD Control Module 2 For Sunroof	Specia Functions	
Audi A7	2018	4K	DE Charger 1 Mobile Devices	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7	2018	4K	DE Charger 1 Mobile Devices	Clear Fault Codes	
Audi A7	2018	4K	DE Charger 1 Mobile Devices	Measuring Blocks	
Audi A7	2018	4K	DE Charger 1 Mobile Devices	Output Tests	
Audi A7	2018	4K	DE Charger 1 Mobile Devices	Specia Functions	
Audi A7	2018	4K	E0 Zusatzanzeige-/Bedieneinheit 1	Read Fault Codes	
Audi A7	2018	4K	E0 Zusatzanzeige-/Bedieneinheit 1	Clear Fault Codes	
Audi A7	2018	4K	E0 Zusatzanzeige-/Bedieneinheit 1	Measuring Blocks	
Audi A7	2018	4K	E0 Zusatzanzeige-/Bedieneinheit 1	Output Tests	
Audi A7	2018	4K	E0 Zusatzanzeige-/Bedieneinheit 1	Specia Functions	
Audi A6 USA/CAN	2018	F2	01 Engine Electronics	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	01 Engine Electronics	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	01 Engine Electronics	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	01 Engine Electronics	Output Tests	
Audi A6 USA/CAN	2018	F2	01 Engine Electronics	Specia Functions	
Audi A6 USA/CAN	2018	F2	02 Transmission Electronics	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	02 Transmission Electronics	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	02 Transmission Electronics	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	02 Transmission Electronics	Output Tests	
Audi A6 USA/CAN	2018	F2	02 Transmission Electronics	Specia Functions	
Audi A6 USA/CAN	2018	F2	03 Brake Electronics	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	03 Brake Electronics	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	03 Brake Electronics	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	03 Brake Electronics	Output Tests	
Audi A6 USA/CAN	2018	F2	03 Brake Electronics	Specia Functions	
Audi A6 USA/CAN	2018	F2	06 Passene. Seat Adj.	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 USA/CAN	2018	F2	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	06 Passene. Seat Adj.	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	06 Passene. Seat Adj.	Output Tests	
Audi A6 USA/CAN	2018	F2	06 Passene. Seat Adj.	Specia Functions	
Audi A6 USA/CAN	2018	F2	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	09 Electronic Ctrl Electronics	Output Tests	
Audi A6 USA/CAN	2018	F2	09 Electronic Ctrl Electronics	Specia Functions	
Audi A6 USA/CAN	2018	F2	0E Media Player Position 1	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	0E Media Player Position 1	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	0E Media Player Position 1	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	0E Media Player Position 1	Output Tests	
Audi A6 USA/CAN	2018	F2	0E Media Player Position 1	Specia Functions	
Audi A6 USA/CAN	2018	F2	13 Distance Control	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	13 Distance Control	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	13 Distance Control	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	13 Distance Control	Output Tests	
Audi A6 USA/CAN	2018	F2	13 Distance Control	Specia Functions	
Audi A6 USA/CAN	2018	F2	15 Airbags	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	15 Airbags	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	15 Airbags	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	15 Airbags	Output Tests	
Audi A6 USA/CAN	2018	F2	15 Airbags	Specia Functions	
Audi A6 USA/CAN	2018	F2	16 Steering Wheel Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 USA/CAN	2018	F2	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	16 Steering Wheel Electronics	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	16 Steering Wheel Electronics	Output Tests	
Audi A6 USA/CAN	2018	F2	16 Steering Wheel Electronics	Specia Functions	
Audi A6 USA/CAN	2018	F2	17 Instrument Cluster	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	17 Instrument Cluster	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	17 Instrument Cluster	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	17 Instrument Cluster	Output Tests	
Audi A6 USA/CAN	2018	F2	17 Instrument Cluster	Specia Functions	
Audi A6 USA/CAN	2018	F2	18 Aux Heating	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	18 Aux Heating	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	18 Aux Heating	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	18 Aux Heating	Output Tests	
Audi A6 USA/CAN	2018	F2	18 Aux Heating	Specia Functions	
Audi A6 USA/CAN	2018	F2	19 Gateway Data Bus	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	19 Gateway Data Bus	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	19 Gateway Data Bus	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	19 Gateway Data Bus	Output Tests	
Audi A6 USA/CAN	2018	F2	19 Gateway Data Bus	Specia Functions	
Audi A6 USA/CAN	2018	F2	1B Power-Assisted Steering	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	1B Power-Assisted Steering	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	1B Power-Assisted Steering	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	1B Power-Assisted Steering	Output Tests	
Audi A6 USA/CAN	2018	F2	1B Power-Assisted Steering	Specia Functions	
Audi A6 USA/CAN	2018	F2	20 High Beam Assistance Device	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 USA/CAN	2018	F2	20 High Beam Assistance Device	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	20 High Beam Assistance Device	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	20 High Beam Assistance Device	Output Tests	
Audi A6 USA/CAN	2018	F2	20 High Beam Assistance Device	Specia Functions	
Audi A6 USA/CAN	2018	F2	21 Engine Electronics 3	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	21 Engine Electronics 3	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	21 Engine Electronics 3	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	21 Engine Electronics 3	Output Tests	
Audi A6 USA/CAN	2018	F2	21 Engine Electronics 3	Specia Functions	
Audi A6 USA/CAN	2018	F2	22 4WD Electronics	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	22 4WD Electronics	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	22 4WD Electronics	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	22 4WD Electronics	Output Tests	
Audi A6 USA/CAN	2018	F2	22 4WD Electronics	Specia Functions	
Audi A6 USA/CAN	2018	F2	23 Braker Booster	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	23 Braker Booster	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	23 Braker Booster	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	23 Braker Booster	Output Tests	
Audi A6 USA/CAN	2018	F2	23 Braker Booster	Specia Functions	
Audi A6 USA/CAN	2018	F2	2B Steer Col Lock	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	2B Steer Col Lock	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	2B Steer Col Lock	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	2B Steer Col Lock	Output Tests	
Audi A6 USA/CAN	2018	F2	2B Steer Col Lock	Specia Functions	
Audi A6 USA/CAN	2018	F2	32 Locking Electronisc	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 USA/CAN	2018	F2	32 Locking Electronisc	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	32 Locking Electronisc	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	32 Locking Electronisc	Output Tests	
Audi A6 USA/CAN	2018	F2	32 Locking Electronisc	Specia Functions	
Audi A6 USA/CAN	2018	F2	36 Driver`s Side Seat Adj.	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	36 Driver`s Side Seat Adj.	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	36 Driver`s Side Seat Adj.	Output Tests	
Audi A6 USA/CAN	2018	F2	36 Driver`s Side Seat Adj.	Specia Functions	
Audi A6 USA/CAN	2018	F2	3C Lane Departure Assistance System	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	3C Lane Departure Assistance System	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	3C Lane Departure Assistance System	Output Tests	
Audi A6 USA/CAN	2018	F2	3C Lane Departure Assistance System	Specia Functions	
Audi A6 USA/CAN	2018	F2	42 Driver-Door Elect.	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	42 Driver-Door Elect.	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	42 Driver-Door Elect.	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	42 Driver-Door Elect.	Output Tests	
Audi A6 USA/CAN	2018	F2	42 Driver-Door Elect.	Specia Functions	
Audi A6 USA/CAN	2018	F2	44 Steering Assistance	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	44 Steering Assistance	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	44 Steering Assistance	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	44 Steering Assistance	Output Tests	
Audi A6 USA/CAN	2018	F2	44 Steering Assistance	Specia Functions	
Audi A6 USA/CAN	2018	F2	46 Central Control Module	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 USA/CAN	2018	F2	46 Central Control Module	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	46 Central Control Module	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	46 Central Control Module	Output Tests	
Audi A6 USA/CAN	2018	F2	46 Central Control Module	Specia Functions	
Audi A6 USA/CAN	2018	F2	47 Soundsystem	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	47 Soundsystem	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	47 Soundsystem	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	47 Soundsystem	Output Tests	
Audi A6 USA/CAN	2018	F2	47 Soundsystem	Specia Functions	
Audi A6 USA/CAN	2018	F2	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	48 Drvs Seat Adj.Rear	Output Tests	
Audi A6 USA/CAN	2018	F2	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A6 USA/CAN	2018	F2	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	48 Drvs Seat Adj.Rear	Output Tests	
Audi A6 USA/CAN	2018	F2	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A6 USA/CAN	2018	F2	4E Control Head RR	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	4E Control Head RR	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	4E Control Head RR	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	4E Control Head RR	Output Tests	
Audi A6 USA/CAN	2018	F2	4E Control Head RR	Specia Functions	
Audi A6 USA/CAN	2018	F2	51 Electric Drive	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 USA/CAN	2018	F2	51 Electric Drive	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	51 Electric Drive	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	51 Electric Drive	Output Tests	
Audi A6 USA/CAN	2018	F2	51 Electric Drive	Specia Functions	
Audi A6 USA/CAN	2018	F2	52 Passe.-Door Elect.	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	52 Passe.-Door Elect.	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	52 Passe.-Door Elect.	Output Tests	
Audi A6 USA/CAN	2018	F2	52 Passe.-Door Elect.	Specia Functions	
Audi A6 USA/CAN	2018	F2	57 TV-Tuner	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	57 TV-Tuner	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	57 TV-Tuner	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	57 TV-Tuner	Output Tests	
Audi A6 USA/CAN	2018	F2	57 TV-Tuner	Specia Functions	
Audi A6 USA/CAN	2018	F2	5E Control Head LR	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	5E Control Head LR	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	5E Control Head LR	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	5E Control Head LR	Output Tests	
Audi A6 USA/CAN	2018	F2	5E Control Head LR	Specia Functions	
Audi A6 USA/CAN	2018	F2	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	5F Information Electronic Equipment 1	Output Tests	
Audi A6 USA/CAN	2018	F2	5F Information Electronic Equipment 1	Specia Functions	
Audi A6 USA/CAN	2018	F2	65 Tyre Pressure Monitoring	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 USA/CAN	2018	F2	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	65 Tyre Pressure Monitoring	Output Tests	
Audi A6 USA/CAN	2018	F2	65 Tyre Pressure Monitoring	Specia Functions	
Audi A6 USA/CAN	2018	F2	69 Trailer Function	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	69 Trailer Function	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	69 Trailer Function	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	69 Trailer Function	Output Tests	
Audi A6 USA/CAN	2018	F2	69 Trailer Function	Specia Functions	
Audi A6 USA/CAN	2018	F2	6C Rear Camera	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	6C Rear Camera	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	6C Rear Camera	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	6C Rear Camera	Output Tests	
Audi A6 USA/CAN	2018	F2	6C Rear Camera	Specia Functions	
Audi A6 USA/CAN	2018	F2	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A6 USA/CAN	2018	F2	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A6 USA/CAN	2018	F2	74 Vehicle Control System	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	74 Vehicle Control System	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	74 Vehicle Control System	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	74 Vehicle Control System	Output Tests	
Audi A6 USA/CAN	2018	F2	74 Vehicle Control System	Specia Functions	
Audi A6 USA/CAN	2018	F2	75 Emergency Call Module	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 USA/CAN	2018	F2	75 Emergency Call Module	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	75 Emergency Call Module	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	75 Emergency Call Module	Output Tests	
Audi A6 USA/CAN	2018	F2	75 Emergency Call Module	Specia Functions	
Audi A6 USA/CAN	2018	F2	80 Batterieregelung Zusatzspeicher 1	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	80 Batterieregelung Zusatzspeicher 1	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	80 Batterieregelung Zusatzspeicher 1	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	80 Batterieregelung Zusatzspeicher 1	Output Tests	
Audi A6 USA/CAN	2018	F2	80 Batterieregelung Zusatzspeicher 1	Specia Functions	
Audi A6 USA/CAN	2018	F2	81 Gear Shift	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	81 Gear Shift	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	81 Gear Shift	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	81 Gear Shift	Output Tests	
Audi A6 USA/CAN	2018	F2	81 Gear Shift	Specia Functions	
Audi A6 USA/CAN	2018	F2	82 Heads Up Display	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	82 Heads Up Display	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	82 Heads Up Display	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	82 Heads Up Display	Output Tests	
Audi A6 USA/CAN	2018	F2	82 Heads Up Display	Specia Functions	
Audi A6 USA/CAN	2018	F2	84 Night Vision	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	84 Night Vision	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	84 Night Vision	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	84 Night Vision	Output Tests	
Audi A6 USA/CAN	2018	F2	84 Night Vision	Specia Functions	
Audi A6 USA/CAN	2018	F2	8C Hybrid Battery	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 USA/CAN	2018	F2	8C Hybrid Battery	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	8C Hybrid Battery	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	8C Hybrid Battery	Output Tests	
Audi A6 USA/CAN	2018	F2	8C Hybrid Battery	Specia Functions	
Audi A6 USA/CAN	2018	F2	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A6 USA/CAN	2018	F2	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A6 USA/CAN	2018	F2	A9 Struct.Borne Sound	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	A9 Struct.Borne Sound	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	A9 Struct.Borne Sound	Output Tests	
Audi A6 USA/CAN	2018	F2	A9 Struct.Borne Sound	Specia Functions	
Audi A6 USA/CAN	2018	F2	AC Reductant Control	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	AC Reductant Control	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	AC Reductant Control	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	AC Reductant Control	Output Tests	
Audi A6 USA/CAN	2018	F2	AC Reductant Control	Specia Functions	
Audi A6 USA/CAN	2018	F2	BA Motor Mounts	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	BA Motor Mounts	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	BA Motor Mounts	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	BA Motor Mounts	Output Tests	
Audi A6 USA/CAN	2018	F2	BA Motor Mounts	Specia Functions	
Audi A6 USA/CAN	2018	F2	BB Door Rear Drv Side	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 USA/CAN	2018	F2	BB Door Rear Drv Side	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	BB Door Rear Drv Side	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	BB Door Rear Drv Side	Output Tests	
Audi A6 USA/CAN	2018	F2	BB Door Rear Drv Side	Specia Functions	
Audi A6 USA/CAN	2018	F2	BC Door Rear Pass Side	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	BC Door Rear Pass Side	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	BC Door Rear Pass Side	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	BC Door Rear Pass Side	Output Tests	
Audi A6 USA/CAN	2018	F2	BC Door Rear Pass Side	Specia Functions	
Audi A6 USA/CAN	2018	F2	C0 Act. For Ext. Noise	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	C0 Act. For Ext. Noise	Output Tests	
Audi A6 USA/CAN	2018	F2	C0 Act. For Ext. Noise	Specia Functions	
Audi A6 USA/CAN	2018	F2	C4 DC/DC Converter Control Module	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	C4 DC/DC Converter Control Module	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	C4 DC/DC Converter Control Module	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	C4 DC/DC Converter Control Module	Output Tests	
Audi A6 USA/CAN	2018	F2	C4 DC/DC Converter Control Module	Specia Functions	
Audi A6 USA/CAN	2018	F2	C5 Thermal Management	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	C5 Thermal Management	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	C5 Thermal Management	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	C5 Thermal Management	Output Tests	
Audi A6 USA/CAN	2018	F2	C5 Thermal Management	Specia Functions	
Audi A6 USA/CAN	2018	F2	C6 Batt. Chrg	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A6 USA/CAN	2018	F2	C6 Batt. Chrg	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	C6 Batt. Chrg	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	C6 Batt. Chrg	Output Tests	
Audi A6 USA/CAN	2018	F2	C6 Batt. Chrg	Specia Functions	
Audi A6 USA/CAN	2018	F2	CA Control Module For Sunroof	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	CA Control Module For Sunroof	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	CA Control Module For Sunroof	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	CA Control Module For Sunroof	Output Tests	
Audi A6 USA/CAN	2018	F2	CA Control Module For Sunroof	Specia Functions	
Audi A6 USA/CAN	2018	F2	CB Rear Axle Steering	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	CB Rear Axle Steering	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	CB Rear Axle Steering	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	CB Rear Axle Steering	Output Tests	
Audi A6 USA/CAN	2018	F2	CB Rear Axle Steering	Specia Functions	
Audi A6 USA/CAN	2018	F2	CC Starter / Generator Control Module	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	CC Starter / Generator Control Module	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	CC Starter / Generator Control Module	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	CC Starter / Generator Control Module	Output Tests	
Audi A6 USA/CAN	2018	F2	CC Starter / Generator Control Module	Specia Functions	
Audi A6 USA/CAN	2018	F2	CD Laser Scanner	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	CD Laser Scanner	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	CD Laser Scanner	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	CD Laser Scanner	Output Tests	
Audi A6 USA/CAN	2018	F2	CD Laser Scanner	Specia Functions	
Audi A6 USA/CAN	2018	F2	CF Control Unit Lane Change Assistant	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 USA/CAN	2018	F2	CF Control Unit Lane Change Assistant	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	CF Control Unit Lane Change Assistant	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	CF Control Unit Lane Change Assistant	Output Tests	
Audi A6 USA/CAN	2018	F2	CF Control Unit Lane Change Assistant	Specia Functions	
Audi A6 USA/CAN	2018	F2	D4 Roll Control System 1	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	D4 Roll Control System 1	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	D4 Roll Control System 1	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	D4 Roll Control System 1	Output Tests	
Audi A6 USA/CAN	2018	F2	D4 Roll Control System 1	Specia Functions	
Audi A6 USA/CAN	2018	F2	D5 Roll Control System 2	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	D5 Roll Control System 2	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	D5 Roll Control System 2	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	D5 Roll Control System 2	Output Tests	
Audi A6 USA/CAN	2018	F2	D5 Roll Control System 2	Specia Functions	
Audi A6 USA/CAN	2018	F2	D6 Light Control Left 2	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	D6 Light Control Left 2	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	D6 Light Control Left 2	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	D6 Light Control Left 2	Output Tests	
Audi A6 USA/CAN	2018	F2	D6 Light Control Left 2	Specia Functions	
Audi A6 USA/CAN	2018	F2	D7 Light Control Right 2	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	D7 Light Control Right 2	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	D7 Light Control Right 2	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	D7 Light Control Right 2	Output Tests	
Audi A6 USA/CAN	2018	F2	D7 Light Control Right 2	Specia Functions	
Audi A6 USA/CAN	2018	F2	DB Front Corner Radar 1	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A6 USA/CAN	2018	F2	DB Front Corner Radar 1	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	DB Front Corner Radar 1	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	DB Front Corner Radar 1	Output Tests	
Audi A6 USA/CAN	2018	F2	DB Front Corner Radar 1	Specia Functions	
Audi A6 USA/CAN	2018	F2	DC Front Corner Radar 2	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	DC Front Corner Radar 2	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	DC Front Corner Radar 2	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	DC Front Corner Radar 2	Output Tests	
Audi A6 USA/CAN	2018	F2	DC Front Corner Radar 2	Specia Functions	
Audi A6 USA/CAN	2018	F2	DD Control Module 2 For Sunroof	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	DD Control Module 2 For Sunroof	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	DD Control Module 2 For Sunroof	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	DD Control Module 2 For Sunroof	Output Tests	
Audi A6 USA/CAN	2018	F2	DD Control Module 2 For Sunroof	Specia Functions	
Audi A6 USA/CAN	2018	F2	DE Charger 1 Mobile Devices	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	DE Charger 1 Mobile Devices	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	DE Charger 1 Mobile Devices	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	DE Charger 1 Mobile Devices	Output Tests	
Audi A6 USA/CAN	2018	F2	DE Charger 1 Mobile Devices	Specia Functions	
Audi A6 USA/CAN	2018	F2	E0 Zusatzanzeige-/Bedieneinheit 1	Read Fault Codes	
Audi A6 USA/CAN	2018	F2	E0 Zusatzanzeige-/Bedieneinheit 1	Clear Fault Codes	
Audi A6 USA/CAN	2018	F2	E0 Zusatzanzeige-/Bedieneinheit 1	Measuring Blocks	
Audi A6 USA/CAN	2018	F2	E0 Zusatzanzeige-/Bedieneinheit 1	Output Tests	
Audi A6 USA/CAN	2018	F2	E0 Zusatzanzeige-/Bedieneinheit 1	Specia Functions	
Audi A7 USA/CAN	2018	F1	01 Engine Electronics	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 USA/CAN	2018	F1	01 Engine Electronics	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	01 Engine Electronics	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	01 Engine Electronics	Output Tests	
Audi A7 USA/CAN	2018	F1	01 Engine Electronics	Specia Functions	
Audi A7 USA/CAN	2018	F1	02 Transmission Electronics	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	02 Transmission Electronics	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	02 Transmission Electronics	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	02 Transmission Electronics	Output Tests	
Audi A7 USA/CAN	2018	F1	02 Transmission Electronics	Specia Functions	
Audi A7 USA/CAN	2018	F1	03 Brake Electronics	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	03 Brake Electronics	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	03 Brake Electronics	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	03 Brake Electronics	Output Tests	
Audi A7 USA/CAN	2018	F1	03 Brake Electronics	Specia Functions	
Audi A7 USA/CAN	2018	F1	06 Passene. Seat Adj.	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	06 Passene. Seat Adj.	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	06 Passene. Seat Adj.	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	06 Passene. Seat Adj.	Output Tests	
Audi A7 USA/CAN	2018	F1	06 Passene. Seat Adj.	Specia Functions	
Audi A7 USA/CAN	2018	F1	09 Electronic Ctrl Electronics	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	09 Electronic Ctrl Electronics	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	09 Electronic Ctrl Electronics	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	09 Electronic Ctrl Electronics	Output Tests	
Audi A7 USA/CAN	2018	F1	09 Electronic Ctrl Electronics	Specia Functions	
Audi A7 USA/CAN	2018	F1	0E Media Player Position 1	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 USA/CAN	2018	F1	0E Media Player Position 1	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	0E Media Player Position 1	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	0E Media Player Position 1	Output Tests	
Audi A7 USA/CAN	2018	F1	0E Media Player Position 1	Specia Functions	
Audi A7 USA/CAN	2018	F1	13 Distance Control	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	13 Distance Control	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	13 Distance Control	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	13 Distance Control	Output Tests	
Audi A7 USA/CAN	2018	F1	13 Distance Control	Specia Functions	
Audi A7 USA/CAN	2018	F1	15 Airbags	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	15 Airbags	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	15 Airbags	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	15 Airbags	Output Tests	
Audi A7 USA/CAN	2018	F1	15 Airbags	Specia Functions	
Audi A7 USA/CAN	2018	F1	16 Steering Wheel Electronics	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	16 Steering Wheel Electronics	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	16 Steering Wheel Electronics	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	16 Steering Wheel Electronics	Output Tests	
Audi A7 USA/CAN	2018	F1	16 Steering Wheel Electronics	Specia Functions	
Audi A7 USA/CAN	2018	F1	17 Instrument Cluster	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	17 Instrument Cluster	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	17 Instrument Cluster	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	17 Instrument Cluster	Output Tests	
Audi A7 USA/CAN	2018	F1	17 Instrument Cluster	Specia Functions	
Audi A7 USA/CAN	2018	F1	18 Aux Heating	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 USA/CAN	2018	F1	18 Aux Heating	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	18 Aux Heating	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	18 Aux Heating	Output Tests	
Audi A7 USA/CAN	2018	F1	18 Aux Heating	Specia Functions	
Audi A7 USA/CAN	2018	F1	19 Gateway Data Bus	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	19 Gateway Data Bus	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	19 Gateway Data Bus	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	19 Gateway Data Bus	Output Tests	
Audi A7 USA/CAN	2018	F1	19 Gateway Data Bus	Specia Functions	
Audi A7 USA/CAN	2018	F1	1B Power-Assisted Steering	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	1B Power-Assisted Steering	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	1B Power-Assisted Steering	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	1B Power-Assisted Steering	Output Tests	
Audi A7 USA/CAN	2018	F1	1B Power-Assisted Steering	Specia Functions	
Audi A7 USA/CAN	2018	F1	20 High Beam Assistance Device	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	20 High Beam Assistance Device	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	20 High Beam Assistance Device	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	20 High Beam Assistance Device	Output Tests	
Audi A7 USA/CAN	2018	F1	20 High Beam Assistance Device	Specia Functions	
Audi A7 USA/CAN	2018	F1	21 Engine Electronics 3	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	21 Engine Electronics 3	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	21 Engine Electronics 3	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	21 Engine Electronics 3	Output Tests	
Audi A7 USA/CAN	2018	F1	21 Engine Electronics 3	Specia Functions	
Audi A7 USA/CAN	2018	F1	22 4WD Electronics	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7 USA/CAN	2018	F1	22 4WD Electronics	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	22 4WD Electronics	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	22 4WD Electronics	Output Tests	
Audi A7 USA/CAN	2018	F1	22 4WD Electronics	Specia Functions	
Audi A7 USA/CAN	2018	F1	23 Braker Booster	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	23 Braker Booster	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	23 Braker Booster	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	23 Braker Booster	Output Tests	
Audi A7 USA/CAN	2018	F1	23 Braker Booster	Specia Functions	
Audi A7 USA/CAN	2018	F1	2B Steer Col Lock	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	2B Steer Col Lock	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	2B Steer Col Lock	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	2B Steer Col Lock	Output Tests	
Audi A7 USA/CAN	2018	F1	2B Steer Col Lock	Specia Functions	
Audi A7 USA/CAN	2018	F1	32 Locking Electronisc	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	32 Locking Electronisc	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	32 Locking Electronisc	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	32 Locking Electronisc	Output Tests	
Audi A7 USA/CAN	2018	F1	32 Locking Electronisc	Specia Functions	
Audi A7 USA/CAN	2018	F1	36 Driver`s Side Seat Adj.	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	36 Driver`s Side Seat Adj.	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	36 Driver`s Side Seat Adj.	Output Tests	
Audi A7 USA/CAN	2018	F1	36 Driver`s Side Seat Adj.	Specia Functions	
Audi A7 USA/CAN	2018	F1	3C Lane Departure Assistance System	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 USA/CAN	2018	F1	3C Lane Departure Assistance System	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	3C Lane Departure Assistance System	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	3C Lane Departure Assistance System	Output Tests	
Audi A7 USA/CAN	2018	F1	3C Lane Departure Assistance System	Specia Functions	
Audi A7 USA/CAN	2018	F1	42 Driver-Door Elect.	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	42 Driver-Door Elect.	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	42 Driver-Door Elect.	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	42 Driver-Door Elect.	Output Tests	
Audi A7 USA/CAN	2018	F1	42 Driver-Door Elect.	Specia Functions	
Audi A7 USA/CAN	2018	F1	44 Steering Assistance	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	44 Steering Assistance	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	44 Steering Assistance	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	44 Steering Assistance	Output Tests	
Audi A7 USA/CAN	2018	F1	44 Steering Assistance	Specia Functions	
Audi A7 USA/CAN	2018	F1	46 Central Control Module	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	46 Central Control Module	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	46 Central Control Module	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	46 Central Control Module	Output Tests	
Audi A7 USA/CAN	2018	F1	46 Central Control Module	Specia Functions	
Audi A7 USA/CAN	2018	F1	47 Soundsystem	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	47 Soundsystem	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	47 Soundsystem	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	47 Soundsystem	Output Tests	
Audi A7 USA/CAN	2018	F1	47 Soundsystem	Specia Functions	
Audi A7 USA/CAN	2018	F1	48 Drvs Seat Adj.Rear	Read Fault Codes	



model	year	chassis	system	function	subfunction
Audi A7 USA/CAN	2018	F1	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	48 Drvs Seat Adj.Rear	Output Tests	
Audi A7 USA/CAN	2018	F1	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A7 USA/CAN	2018	F1	48 Drvs Seat Adj.Rear	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	48 Drvs Seat Adj.Rear	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	48 Drvs Seat Adj.Rear	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	48 Drvs Seat Adj.Rear	Output Tests	
Audi A7 USA/CAN	2018	F1	48 Drvs Seat Adj.Rear	Specia Functions	
Audi A7 USA/CAN	2018	F1	4E Control Head RR	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	4E Control Head RR	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	4E Control Head RR	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	4E Control Head RR	Output Tests	
Audi A7 USA/CAN	2018	F1	4E Control Head RR	Specia Functions	
Audi A7 USA/CAN	2018	F1	51 Electric Drive	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	51 Electric Drive	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	51 Electric Drive	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	51 Electric Drive	Output Tests	
Audi A7 USA/CAN	2018	F1	51 Electric Drive	Specia Functions	
Audi A7 USA/CAN	2018	F1	52 Passe.-Door Elect.	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	52 Passe.-Door Elect.	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	52 Passe.-Door Elect.	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	52 Passe.-Door Elect.	Output Tests	
Audi A7 USA/CAN	2018	F1	52 Passe.-Door Elect.	Specia Functions	
Audi A7 USA/CAN	2018	F1	57 TV-Tuner	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7 USA/CAN	2018	F1	57 TV-Tuner	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	57 TV-Tuner	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	57 TV-Tuner	Output Tests	
Audi A7 USA/CAN	2018	F1	57 TV-Tuner	Specia Functions	
Audi A7 USA/CAN	2018	F1	5E Control Head LR	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	5E Control Head LR	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	5E Control Head LR	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	5E Control Head LR	Output Tests	
Audi A7 USA/CAN	2018	F1	5E Control Head LR	Specia Functions	
Audi A7 USA/CAN	2018	F1	5F Information Electronic Equipment 1	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	5F Information Electronic Equipment 1	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	5F Information Electronic Equipment 1	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	5F Information Electronic Equipment 1	Output Tests	
Audi A7 USA/CAN	2018	F1	5F Information Electronic Equipment 1	Specia Functions	
Audi A7 USA/CAN	2018	F1	65 Tyre Pressure Monitoring	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	65 Tyre Pressure Monitoring	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	65 Tyre Pressure Monitoring	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	65 Tyre Pressure Monitoring	Output Tests	
Audi A7 USA/CAN	2018	F1	65 Tyre Pressure Monitoring	Specia Functions	
Audi A7 USA/CAN	2018	F1	69 Trailer Function	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	69 Trailer Function	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	69 Trailer Function	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	69 Trailer Function	Output Tests	
Audi A7 USA/CAN	2018	F1	69 Trailer Function	Specia Functions	
Audi A7 USA/CAN	2018	F1	6C Rear Camera	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7 USA/CAN	2018	F1	6C Rear Camera	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	6C Rear Camera	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	6C Rear Camera	Output Tests	
Audi A7 USA/CAN	2018	F1	6C Rear Camera	Specia Functions	
Audi A7 USA/CAN	2018	F1	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	6D Electronic Equipment of Trunk Lid	Output Tests	
Audi A7 USA/CAN	2018	F1	6D Electronic Equipment of Trunk Lid	Specia Functions	
Audi A7 USA/CAN	2018	F1	74 Vehicle Control System	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	74 Vehicle Control System	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	74 Vehicle Control System	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	74 Vehicle Control System	Output Tests	
Audi A7 USA/CAN	2018	F1	74 Vehicle Control System	Specia Functions	
Audi A7 USA/CAN	2018	F1	75 Emergency Call Module	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	75 Emergency Call Module	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	75 Emergency Call Module	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	75 Emergency Call Module	Output Tests	
Audi A7 USA/CAN	2018	F1	75 Emergency Call Module	Specia Functions	
Audi A7 USA/CAN	2018	F1	80 Batterieregelung Zusatzspeicher 1	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	80 Batterieregelung Zusatzspeicher 1	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	80 Batterieregelung Zusatzspeicher 1	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	80 Batterieregelung Zusatzspeicher 1	Output Tests	
Audi A7 USA/CAN	2018	F1	80 Batterieregelung Zusatzspeicher 1	Specia Functions	
Audi A7 USA/CAN	2018	F1	81 Gear Shift	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 USA/CAN	2018	F1	81 Gear Shift	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	81 Gear Shift	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	81 Gear Shift	Output Tests	
Audi A7 USA/CAN	2018	F1	81 Gear Shift	Specia Functions	
Audi A7 USA/CAN	2018	F1	82 Heads Up Display	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	82 Heads Up Display	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	82 Heads Up Display	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	82 Heads Up Display	Output Tests	
Audi A7 USA/CAN	2018	F1	82 Heads Up Display	Specia Functions	
Audi A7 USA/CAN	2018	F1	84 Night Vision	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	84 Night Vision	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	84 Night Vision	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	84 Night Vision	Output Tests	
Audi A7 USA/CAN	2018	F1	84 Night Vision	Specia Functions	
Audi A7 USA/CAN	2018	F1	8C Hybrid Battery	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	8C Hybrid Battery	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	8C Hybrid Battery	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	8C Hybrid Battery	Output Tests	
Audi A7 USA/CAN	2018	F1	8C Hybrid Battery	Specia Functions	
Audi A7 USA/CAN	2018	F1	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	A5 Frt Sens.Drv.Assist	Output Tests	
Audi A7 USA/CAN	2018	F1	A5 Frt Sens.Drv.Assist	Specia Functions	
Audi A7 USA/CAN	2018	F1	A9 Struct.Borne Sound	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 USA/CAN	2018	F1	A9 Struct.Borne Sound	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	A9 Struct.Borne Sound	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	A9 Struct.Borne Sound	Output Tests	
Audi A7 USA/CAN	2018	F1	A9 Struct.Borne Sound	Specia Functions	
Audi A7 USA/CAN	2018	F1	AC Reductant Control	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	AC Reductant Control	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	AC Reductant Control	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	AC Reductant Control	Output Tests	
Audi A7 USA/CAN	2018	F1	AC Reductant Control	Specia Functions	
Audi A7 USA/CAN	2018	F1	BA Motor Mounts	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	BA Motor Mounts	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	BA Motor Mounts	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	BA Motor Mounts	Output Tests	
Audi A7 USA/CAN	2018	F1	BA Motor Mounts	Specia Functions	
Audi A7 USA/CAN	2018	F1	BB Door Rear Drv Side	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	BB Door Rear Drv Side	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	BB Door Rear Drv Side	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	BB Door Rear Drv Side	Output Tests	
Audi A7 USA/CAN	2018	F1	BB Door Rear Drv Side	Specia Functions	
Audi A7 USA/CAN	2018	F1	BC Door Rear Pass Side	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	BC Door Rear Pass Side	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	BC Door Rear Pass Side	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	BC Door Rear Pass Side	Output Tests	
Audi A7 USA/CAN	2018	F1	BC Door Rear Pass Side	Specia Functions	
Audi A7 USA/CAN	2018	F1	C0 Act. For Ext. Noise	Read Fault Codes	

model	year	chassis	system	function	subfunction
Audi A7 USA/CAN	2018	F1	C0 Act. For Ext. Noise	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	C0 Act. For Ext. Noise	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	C0 Act. For Ext. Noise	Output Tests	
Audi A7 USA/CAN	2018	F1	C0 Act. For Ext. Noise	Specia Functions	
Audi A7 USA/CAN	2018	F1	C4 DC/DC Converter Control Module	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	C4 DC/DC Converter Control Module	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	C4 DC/DC Converter Control Module	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	C4 DC/DC Converter Control Module	Output Tests	
Audi A7 USA/CAN	2018	F1	C4 DC/DC Converter Control Module	Specia Functions	
Audi A7 USA/CAN	2018	F1	C5 Thermal Management	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	C5 Thermal Management	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	C5 Thermal Management	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	C5 Thermal Management	Output Tests	
Audi A7 USA/CAN	2018	F1	C5 Thermal Management	Specia Functions	
Audi A7 USA/CAN	2018	F1	C6 Batt. Chrg	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	C6 Batt. Chrg	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	C6 Batt. Chrg	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	C6 Batt. Chrg	Output Tests	
Audi A7 USA/CAN	2018	F1	C6 Batt. Chrg	Specia Functions	
Audi A7 USA/CAN	2018	F1	CA Control Module For Sunroof	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	CA Control Module For Sunroof	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	CA Control Module For Sunroof	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	CA Control Module For Sunroof	Output Tests	
Audi A7 USA/CAN	2018	F1	CA Control Module For Sunroof	Specia Functions	
Audi A7 USA/CAN	2018	F1	CB Rear Axle Steering	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 USA/CAN	2018	F1	CB Rear Axle Steering	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	CB Rear Axle Steering	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	CB Rear Axle Steering	Output Tests	
Audi A7 USA/CAN	2018	F1	CB Rear Axle Steering	Specia Functions	
Audi A7 USA/CAN	2018	F1	CC Starter / Generator Control Module	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	CC Starter / Generator Control Module	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	CC Starter / Generator Control Module	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	CC Starter / Generator Control Module	Output Tests	
Audi A7 USA/CAN	2018	F1	CC Starter / Generator Control Module	Specia Functions	
Audi A7 USA/CAN	2018	F1	CD Laser Scanner	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	CD Laser Scanner	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	CD Laser Scanner	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	CD Laser Scanner	Output Tests	
Audi A7 USA/CAN	2018	F1	CD Laser Scanner	Specia Functions	
Audi A7 USA/CAN	2018	F1	CF Control Unit Lane Change Assistant	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	CF Control Unit Lane Change Assistant	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	CF Control Unit Lane Change Assistant	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	CF Control Unit Lane Change Assistant	Output Tests	
Audi A7 USA/CAN	2018	F1	CF Control Unit Lane Change Assistant	Specia Functions	
Audi A7 USA/CAN	2018	F1	D4 Roll Control System 1	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	D4 Roll Control System 1	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	D4 Roll Control System 1	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	D4 Roll Control System 1	Output Tests	
Audi A7 USA/CAN	2018	F1	D4 Roll Control System 1	Specia Functions	
Audi A7 USA/CAN	2018	F1	D5 Roll Control System 2	Read Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 USA/CAN	2018	F1	D5 Roll Control System 2	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	D5 Roll Control System 2	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	D5 Roll Control System 2	Output Tests	
Audi A7 USA/CAN	2018	F1	D5 Roll Control System 2	Specia Functions	
Audi A7 USA/CAN	2018	F1	D6 Light Control Left 2	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	D6 Light Control Left 2	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	D6 Light Control Left 2	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	D6 Light Control Left 2	Output Tests	
Audi A7 USA/CAN	2018	F1	D6 Light Control Left 2	Specia Functions	
Audi A7 USA/CAN	2018	F1	D7 Light Control Right 2	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	D7 Light Control Right 2	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	D7 Light Control Right 2	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	D7 Light Control Right 2	Output Tests	
Audi A7 USA/CAN	2018	F1	D7 Light Control Right 2	Specia Functions	
Audi A7 USA/CAN	2018	F1	DB Front Corner Radar 1	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	DB Front Corner Radar 1	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	DB Front Corner Radar 1	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	DB Front Corner Radar 1	Output Tests	
Audi A7 USA/CAN	2018	F1	DB Front Corner Radar 1	Specia Functions	
Audi A7 USA/CAN	2018	F1	DC Front Corner Radar 2	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	DC Front Corner Radar 2	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	DC Front Corner Radar 2	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	DC Front Corner Radar 2	Output Tests	
Audi A7 USA/CAN	2018	F1	DC Front Corner Radar 2	Specia Functions	
Audi A7 USA/CAN	2018	F1	DD Control Module 2 For Sunroof	Read Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Audi A7 USA/CAN	2018	F1	DD Control Module 2 For Sunroof	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	DD Control Module 2 For Sunroof	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	DD Control Module 2 For Sunroof	Output Tests	
Audi A7 USA/CAN	2018	F1	DD Control Module 2 For Sunroof	Specia Functions	
Audi A7 USA/CAN	2018	F1	DE Charger 1 Mobile Devices	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	DE Charger 1 Mobile Devices	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	DE Charger 1 Mobile Devices	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	DE Charger 1 Mobile Devices	Output Tests	
Audi A7 USA/CAN	2018	F1	DE Charger 1 Mobile Devices	Specia Functions	
Audi A7 USA/CAN	2018	F1	E0 Zusatzanzeige-/Bedieneinheit 1	Read Fault Codes	
Audi A7 USA/CAN	2018	F1	E0 Zusatzanzeige-/Bedieneinheit 1	Clear Fault Codes	
Audi A7 USA/CAN	2018	F1	E0 Zusatzanzeige-/Bedieneinheit 1	Measuring Blocks	
Audi A7 USA/CAN	2018	F1	E0 Zusatzanzeige-/Bedieneinheit 1	Output Tests	
Audi A7 USA/CAN	2018	F1	E0 Zusatzanzeige-/Bedieneinheit 1	Specia Functions	