

Daewoo Diagnostics List (Note:For reference only)

model	year	system	subitem	function	subfunction
Cielo	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Cielo	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Cielo	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Cielo	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Cielo	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	
Cielo	ALL YEAR	AUTOMATIC TRANSAXLE		Data Stream	
Cielo	ALL YEAR	ENGINE DOHC	UNLEAD 1.5L	Read Dtc	
Cielo	ALL YEAR	ENGINE DOHC	UNLEAD 1.5L	Clear Dtc	
Cielo	ALL YEAR	ENGINE DOHC	UNLEAD 1.5L	Data Stream	
Cielo	ALL YEAR	ENGINE DOHC	UNLEAD 1.5L	Actuation	
Cielo	ALL YEAR	ENGINE SOHC	UNLEAD 1.5L	Read Dtc	
Cielo	ALL YEAR	ENGINE SOHC	UNLEAD 1.5L	Clear Dtc	
Cielo	ALL YEAR	ENGINE SOHC	UNLEAD 1.5L	Data Stream	
Cielo	ALL YEAR	ENGINE SOHC	UNLEAD 1.5L	Actuation	
Cielo	ALL YEAR	ENGINE SOHC	UNLEAD 1.8L	Read Dtc	
Cielo	ALL YEAR	ENGINE SOHC	UNLEAD 1.8L	Clear Dtc	
Cielo	ALL YEAR	ENGINE SOHC	UNLEAD 1.8L	Data Stream	
Cielo	ALL YEAR	SRS-AIRBAG		Read Dtc	
Cielo	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Cruze	ALL YEAR	01.ENGINE CONTROL	01.1.6L GASOLINE(LXT)	Read Dtc	
Cruze	ALL YEAR	01.ENGINE CONTROL	01.1.6L GASOLINE(LXT)	Clear Dtc	
Cruze	ALL YEAR	01.ENGINE CONTROL	01.1.6L GASOLINE(LXT)	Actuation	
Cruze	ALL YEAR	01.ENGINE CONTROL	01.1.6L GASOLINE(LXT)	Special Functions	HO2S HEATER LEARN
Cruze	ALL YEAR	01.ENGINE CONTROL	01.1.6L GASOLINE(LXT)	Special Functions	IDLE LEARN
Cruze	ALL YEAR	01.ENGINE CONTROL	01.1.6L GASOLINE(LXT)	Special Functions	FUEL TRIM RESET
Cruze	ALL YEAR	01.ENGINE CONTROL	02.1.6L GASOLINE(LXV)	Read Dtc	

model	year	system	subitem	function	subfunction
Cruze	ALL YEAR	01.ENGINE CONTROL	02.1.6L GASOLINE(LXV)	Clear Dtc	
Cruze	ALL YEAR	01.ENGINE CONTROL	02.1.6L GASOLINE(LXV)	Actuation	
Cruze	ALL YEAR	01.ENGINE CONTROL	02.1.6L GASOLINE(LXV)	Special Functions	ENGINE OIL REMAINING
Cruze	ALL YEAR	01.ENGINE CONTROL	02.1.6L GASOLINE(LXV)	Special Functions	FUEL TRIM RESET
Cruze	ALL YEAR	01.ENGINE CONTROL	03.1.8L GASOLINE(2H0)	Read Dtc	
Cruze	ALL YEAR	01.ENGINE CONTROL	03.1.8L GASOLINE(2H0)	Clear Dtc	
Cruze	ALL YEAR	01.ENGINE CONTROL	03.1.8L GASOLINE(2H0)	Actuation	
Cruze	ALL YEAR	01.ENGINE CONTROL	03.1.8L GASOLINE(2H0)	Special Functions	ENGINE OIL REMAINING
Cruze	ALL YEAR	01.ENGINE CONTROL	03.1.8L GASOLINE(2H0)	Special Functions	FUEL TRIM RESET
Cruze	ALL YEAR	01.ENGINE CONTROL	04.2.0L DIESEL(LLW)	Read Dtc	
Cruze	ALL YEAR	01.ENGINE CONTROL	04.2.0L DIESEL(LLW)	Clear Dtc	
Cruze	ALL YEAR	01.ENGINE CONTROL	04.2.0L DIESEL(LLW)	Actuation	
Cruze	ALL YEAR	01.ENGINE CONTROL	04.2.0L DIESEL(LLW)	Special Functions	LEARN FUNCTION
Cruze	ALL YEAR	01.ENGINE CONTROL	04.2.0L DIESEL(LLW)	Special Functions	RESET FUNCTION
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	01.1.6L(LXT)	Read Dtc	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	01.1.6L(LXT)	Clear Dtc	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	01.1.6L(LXT)	Actuation	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	01.1.6L(LXT)	Special Functions	ADAPTIVE VALUES LEARN
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	02.1.6L(LXV)	Read Dtc	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	02.1.6L(LXV)	Clear Dtc	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	02.1.6L(LXV)	Actuation	

model	year	system	subitem	function	subfunction
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	02.1.6L(LXV)	Special Functions	ADAPTIVE VALUES LEARN
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	03.1.8L(2H0)	Read Dtc	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	03.1.8L(2H0)	Clear Dtc	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	03.1.8L(2H0)	Actuation	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	03.1.8L(2H0)	Special Functions	ADAPTIVE VALUES LEARN
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	04.2.0L(LLW)	Read Dtc	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	04.2.0L(LLW)	Clear Dtc	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	04.2.0L(LLW)	Actuation	
Cruze	ALL YEAR	02.AUTOMATIC TRANSAXLE	04.2.0L(LLW)	Special Functions	ADAPTIVE VALUES LEARN
Cruze	ALL YEAR	03.CHASSIS CONTROL	STABILITY SYSTEM(EQUIP)	Read Dtc	
Cruze	ALL YEAR	03.CHASSIS CONTROL	STABILITY SYSTEM(EQUIP)	Clear Dtc	
Cruze	ALL YEAR	03.CHASSIS CONTROL	STABILITY SYSTEM(EQUIP)	Actuation	
Cruze	ALL YEAR	03.CHASSIS CONTROL	STABILITY SYSTEM(EQUIP)	Special Functions	BRAKE PRESSURE
Cruze	ALL YEAR	03.CHASSIS CONTROL	STABILITY SYSTEM(EQUIP)	Special Functions	STEERING ANGLE SENSOR
Cruze	ALL YEAR	03.CHASSIS CONTROL	STABILITY SYSTEM(EQUIP)	Special Functions	YAW RATE SENSOR LEARN
Cruze	ALL YEAR	03.CHASSIS CONTROL SYSTEM	STABILITY SYSTEM(NOTEQU IP)	Read Dtc	
Cruze	ALL YEAR	03.CHASSIS CONTROL SYSTEM	STABILITY SYSTEM(NOTEQU IP)	Clear Dtc	
Cruze	ALL YEAR	03.CHASSIS CONTROL SYSTEM	STABILITY SYSTEM(NOTEQU IP)	Actuation	
Cruze	ALL YEAR	03.CHASSIS CONTROL SYSTEM	STABILITY SYSTEM(NOTEQU IP)	Special Functions	STEERING ANGLE SENSOR LEARN

model	year	system	subitem	function	subfunction
Cruze	ALL YEAR	04.BODY CONTROL	BCM(BODY CONTROL)	Read Dtc	
Cruze	ALL YEAR	04.BODY CONTROL	BCM(BODY CONTROL)	Clear Dtc	
Cruze	ALL YEAR	04.BODY CONTROL	BCM(BODY CONTROL)	Actuation	
Damas/Rabo	ALL YEAR	ENGINE CONTROL	0.8L LPG	Read Dtc	
Damas/Rabo	ALL YEAR	ENGINE CONTROL	0.8L LPG	Clear Dtc	
Damas/Rabo	ALL YEAR	ENGINE CONTROL	0.8L LPG	Data Stream	
Damas/Rabo	ALL YEAR	ENGINE CONTROL	0.8L LPG	Actuation	
Damas/Rabo	ALL YEAR	ENGINE CONTROL	0.8L LPGI(INTERFACE MODULE)	Read Dtc	
Damas/Rabo	ALL YEAR	ENGINE CONTROL	0.8L LPGI(INTERFACE MODULE)	Clear Dtc	
Damas/Rabo	ALL YEAR	ENGINE CONTROL	0.8L LPGI(INTERFACE MODULE)	Data Stream	
Damas/Rabo	ALL YEAR	ENGINE CONTROL	0.8L LPGi(MAIN MODULE)	Read Dtc	
Damas/Rabo	ALL YEAR	ENGINE CONTROL	0.8L LPGi(MAIN MODULE)	Clear Dtc	
Damas/Rabo	ALL YEAR	ENGINE CONTROL	0.8L LPGi(MAIN MODULE)	Data Stream	
Espero	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Espero	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Espero	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Espero	ALL YEAR	ATUTOMATIC TRANSAXLE		Read Dtc	
Espero	ALL YEAR	ATUTOMATIC TRANSAXLE		Clear Dtc	
Espero	ALL YEAR	ATUTOMATIC TRANSAXLE		Data Stream	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPFI(AFTER 93MY)	Read Dtc	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPFI(AFTER 93MY)	Clear Dtc	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPFI(AFTER 93MY)	Data Stream	

model	year	system	subitem	function	subfunction
Espero	ALL YEAR	ENGINE DOHC	1.5 MPFI(AFTER 93MY)	Actuation	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPFI(BEFORE 93MY)	Read Dtc	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPFI(BEFORE 93MY)	Clear Dtc	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPFI(BEFORE 93MY)	Data Stream	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPFI(BEFORE 93MY)	Actuation	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPI(AFTER 93MY)	Read Dtc	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPI(AFTER 93MY)	Clear Dtc	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPI(AFTER 93MY)	Data Stream	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPI(AFTER 93MY)	Actuation	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPI(BEFORE 93MY)	Read Dtc	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPI(BEFORE 93MY)	Clear Dtc	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPI(BEFORE 93MY)	Data Stream	
Espero	ALL YEAR	ENGINE DOHC	1.5 MPI(BEFORE 93MY)	Actuation	
Espero	ALL YEAR	ENGINE SOHC	1.5 MPI(AFTER 93MY)	Read Dtc	
Espero	ALL YEAR	ENGINE SOHC	1.5 MPI(AFTER 93MY)	Clear Dtc	
Espero	ALL YEAR	ENGINE SOHC	1.5 MPI(AFTER 93MY)	Data Stream	
Espero	ALL YEAR	ENGINE SOHC	1.5 MPI(AFTER 93MY)	Actuation	
Espero	ALL YEAR	ENGINE SOHC	1.5 MPI(BEFORE 93MY)	Read Dtc	
Espero	ALL YEAR	ENGINE SOHC	1.5 MPI(BEFORE 93MY)	Clear Dtc	
Espero	ALL YEAR	ENGINE SOHC	1.5 MPI(BEFORE 93MY)	Data Stream	
Espero	ALL YEAR	ENGINE SOHC	1.5 MPI(BEFORE 93MY)	Actuation	
Espero	ALL YEAR	ENGINE SOHC	1.8 MPI	Read Dtc	

model	year	system	subitem	function	subfunction
Espero	ALL YEAR	ENGINE SOHC	1.8 MPI	Clear Dtc	
Espero	ALL YEAR	ENGINE SOHC	1.8 MPI	Data Stream	
Espero	ALL YEAR	ENGINE SOHC	1.8 MPI	Actuation	
Espero	ALL YEAR	ENGINE SOHC	2.0 MPI	Read Dtc	
Espero	ALL YEAR	ENGINE SOHC	2.0 MPI	Clear Dtc	
Espero	ALL YEAR	ENGINE SOHC	2.0 MPI	Data Stream	
Espero	ALL YEAR	ENGINE SOHC	2.0 MPI	Actuation	
Espero	ALL YEAR	ENGINE SOHC	2.0 TBI	Read Dtc	
Espero	ALL YEAR	ENGINE SOHC	2.0 TBI	Clear Dtc	
Espero	ALL YEAR	ENGINE SOHC	2.0 TBI	Data Stream	
Espero	ALL YEAR	ENGINE SOHC	2.0 TBI	Actuation	
Espero	ALL YEAR	SRS-AIRBAG		Read Dtc	
Espero	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Gentra	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Gentra	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Gentra	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Gentra	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Actuation	
Gentra	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Gentra	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.2 DOHC (SIEMENS)	Read Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.2 DOHC (SIEMENS)	Clear Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.2 DOHC (SIEMENS)	Data Stream	
Gentra	ALL YEAR	ENGINE CONTROL	1.2 DOHC (SIEMENS)	Actuation	
Gentra	ALL YEAR	ENGINE CONTROL	1.2 DOHC (SIEMENS)	Special Functions	ADAPTION RESET
Gentra	ALL YEAR	ENGINE CONTROL	1.2 DOHC (SIEMENS)	Special Functions	EVAP.LEAK
Gentra	ALL YEAR	ENGINE CONTROL	1.2 SOHC (SIEMENS)	Read Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.2 SOHC (SIEMENS)	Clear Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.2 SOHC (SIEMENS)	Data Stream	

model	year	system	subitem	function	subfunction
Gentra	ALL YEAR	ENGINE CONTROL	1.2 SOHC (SIEMENS)	Special Functions	ADAPTION RESET
Gentra	ALL YEAR	ENGINE CONTROL	1.4/1.6 DOHC (DELPHI)	Read Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.4/1.6 DOHC (DELPHI)	Clear Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.4/1.6 DOHC (DELPHI)	Data Stream	
Gentra	ALL YEAR	ENGINE CONTROL	1.4/1.6 DOHC (DELPHI)	Actuation	
Gentra	ALL YEAR	ENGINE CONTROL	1.5 SOHC	Read Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.5 SOHC	Clear Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.5 SOHC	Data Stream	
Gentra	ALL YEAR	ENGINE CONTROL	1.5 SOHC	Actuation	
Gentra	ALL YEAR	ENGINE CONTROL	1.5 SOHC	Read Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.5 SOHC	Clear Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.5 SOHC	Data Stream	
Gentra	ALL YEAR	ENGINE CONTROL	1.5 SOHC	Actuation	
Gentra	ALL YEAR	ENGINE CONTROL	1.6 DOHC	Read Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.6 DOHC	Clear Dtc	
Gentra	ALL YEAR	ENGINE CONTROL	1.6 DOHC	Data Stream	
Gentra	ALL YEAR	SRS-AIRBAG		Read Dtc	
Gentra	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Gentra	ALL YEAR	SRS-AIRBAG		Data Stream	
Kalos/Aveo(~05MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Kalos/Aveo(~05MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Actuation	
Kalos/Aveo(~05MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Special Functions	HCU AIRBREEDING
Kalos/Aveo(~05MY)	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	AUTOMATIC TRANSAXLE		Data Stream	
Kalos/Aveo(~05MY)	ALL YEAR	AUTOMATIC TRANSAXLE		Actuation	

model	year	system	subitem	function	subfunction
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.2 SOHC (SIEMENS)	Read Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.2 SOHC (SIEMENS)	Clear Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.2 SOHC (SIEMENS)	Data Stream	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.2 SOHC (SIEMENS)	Actuation	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.2 SOHC (SIEMENS)	Special Functions	ADAPTION RESET
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.5 SOHC (DELPHI)	Read Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.5 SOHC (DELPHI)	Clear Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.5 SOHC (DELPHI)	Data Stream	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.5 SOHC (DELPHI)	Actuation	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.6 SOHC (DELPHI)	Read Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.6 SOHC (DELPHI)	Clear Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.6 SOHC (DELPHI)	Data Stream	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	1.6 SOHC (DELPHI)	Actuation	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	SOHC	Read Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	SOHC	Clear Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	SOHC	Data Stream	
Kalos/Aveo(~05MY)	ALL YEAR	ENGINE CONTROL	SOHC	Actuation	
Kalos/Aveo(~05MY)	ALL YEAR	SRS-AIRBAG		Read Dtc	
Kalos/Aveo(~05MY)	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Kalos/Aveo/Barina(06MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Kalos/Aveo/Barina(06MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	

model	year	system	subitem	function	subfunction
Kalos/Aveo/ Barina(06MY	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Actuation	
Kalos/Aveo/ Barina(06MY	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Kalos/Aveo/ Barina(06MY	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	
Kalos/Aveo/ Barina(06MY	ALL YEAR	AUTOMATIC TRANSAXLE		Data Stream	
Kalos/Aveo/ Barina(06MY	ALL YEAR	AUTOMATIC TRANSAXLE		Actuation	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.2 SOHC(SIEMENS)	Read Dtc	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.2 SOHC(SIEMENS)	Clear Dtc	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.2 SOHC(SIEMENS)	Data Stream	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.2 SOHC(SIEMENS)	Actuation	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.2 SOHC(SIEMENS)	Special Functions	ADAPTION RESET
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.5 SOHC(DELPHI)	Read Dtc	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.5 SOHC(DELPHI)	Clear Dtc	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.5 SOHC(DELPHI)	Data Stream	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.5 SOHC(DELPHI)	Actuation	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.6 DOHC(DELPHI)	Read Dtc	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.6 DOHC(DELPHI)	Clear Dtc	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.6 DOHC(DELPHI)	Data Stream	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.6 DOHC(DELPHI)	Actuation	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.8 DOHC (DELPHI)	Read Dtc	
Kalos/Aveo/ Barina(06MY	ALL YEAR	ENGINE CONTROL	1.8 DOHC (DELPHI)	Clear Dtc	

model	year	system	subitem	function	subfunction
Kalos/Aveo/Barina(06MY	ALL YEAR	ENGINE CONTROL	1.8 DOHC (DELPHI)	Data Stream	
Kalos/Aveo/Barina(06MY	ALL YEAR	ENGINE CONTROL	1.8 DOHC (DELPHI)	Actuation	
Kalos/Aveo/Barina(06MY	ALL YEAR	SRS-AIRBAG		Read Dtc	
Kalos/Aveo/Barina(06MY	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	01.ECM-GEN3 1.6D&1.8D	Read Dtc	
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	01.ECM-GEN3 1.6D&1.8D	Clear Dtc	
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	01.ECM-GEN3 1.6D&1.8D	Actuation	
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	01.ECM-GEN3 1.6D&1.8D	Special Functions	RESET TPS LEARN VALUE
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	01.ECM-GEN3 1.6D&1.8D	Special Functions	ECM LEARN RESET
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	01.ECM-GEN3 1.6D&1.8D	Special Functions	CLUTCH PEDAL LEARN(M/T)
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	01.ECM-GEN3 1.6D&1.8D	Special Functions	WRITE VIN
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	02.ECM-DIESEL	Read Dtc	
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	02.ECM-DIESEL	Clear Dtc	
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	02.ECM-DIESEL	Data Stream	
Lacetti Premiere/Cruze	ALL YEAR	01. ENGINE CONTROL	02.ECM-DIESEL	Actuation	

model	year	system	subitem	function	subfunction
Lacetti Premiere/Cr uze	ALL YEAR	01. ENGINE CONTROL	03.ECM-FAM 1	Read Dtc	
Lacetti Premiere/Cr uze	ALL YEAR	01. ENGINE CONTROL	03.ECM-FAM 1	Clear Dtc	
Lacetti Premiere/Cr uze	ALL YEAR	02. AUTOMATIC TRANSAXLE	01.TCM-GF6	Read Dtc	
Lacetti Premiere/Cr uze	ALL YEAR	02. AUTOMATIC TRANSAXLE	01.TCM-GF6	Clear Dtc	
Lacetti Premiere/Cr uze	ALL YEAR	02. AUTOMATIC TRANSAXLE	01.TCM-GF6	Actuation	
Lacetti Premiere/Cr uze	ALL YEAR	03.CHASSIS	01.ABS	Read Dtc	
Lacetti Premiere/Cr uze	ALL YEAR	03.CHASSIS	01.ABS	Clear Dtc	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Actuation	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	AUTOMATIC TRANSAXLE		Data Stream	

model	year	system	subitem	function	subfunction
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	AUTOMATIC TRANSAXLE		Actuation	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ENGINE CONTROL	1.5L	Read Dtc	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ENGINE CONTROL	1.5L	Clear Dtc	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ENGINE CONTROL	1.5L	Data Stream	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ENGINE CONTROL	1.5L	Special Functions	Learning value initialization(All)
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ENGINE CONTROL	1.5L	Special Functions	MTIA learning value initaialization
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ENGINE CONTROL	1.5L	Special Functions	Air controlled quantity learning value
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ENGINE CONTROL	1.6L	Read Dtc	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ENGINE CONTROL	1.6L	Clear Dtc	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ENGINE CONTROL	1.6L	Data Stream	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	ENGINE CONTROL	1.6L	Actuation	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	SRS-AIRBAG		Read Dtc	
Lacetti/Optra /Excelle(~05 MY)	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	

model	year	system	subitem	function	subfunction
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Actuation	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 4GEAR(GAS 1.8L)	Read Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 4GEAR(GAS 1.8L)	Clear Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU (DIESEL)	Read Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU (DIESEL)	Clear Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU (DIESEL)	Data Stream	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU (DIESEL)	Special Functions	LEARNING DATA RESET
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU (GASOLINE)	Read Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU (GASOLINE)	Clear Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU (GASOLINE)	Data Stream	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU (GASOLINE)	Actuation	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.5 DOHC (SIEMENS)	Read Dtc	

model	year	system	subitem	function	subfunction
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.5 DOHC (SIEMENS)	Clear Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.5 DOHC (SIEMENS)	Data Stream	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.5 DOHC (SIEMENS)	Actuation	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.5 DOHC (SIEMENS)	Special Functions	ADAPTION RESET
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.6 DOHC (SIEMENS)	Read Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.6 DOHC (SIEMENS)	Clear Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.6 DOHC (SIEMENS)	Data Stream	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.6 DOHC (SIEMENS)	Special Functions	ADAPTION RESET
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.6 DOHC (SIEMENS)	Special Functions	EVAP.LEAK
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.8 DOHC (DELPHI)	Read Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.8 DOHC (DELPHI)	Clear Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.8 DOHC (DELPHI)	Data Stream	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.8 DOHC (DELPHI)	Actuation	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.8 DOHC (SIEMENS)	Read Dtc	

model	year	system	subitem	function	subfunction
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	1.8 DOHC (SIEMENS)	Clear Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	2.0L DIESEL	Read Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	ENGINE CONTROL	2.0L DIESEL	Clear Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	SRS-AIRBAG		Read Dtc	
Lacetti/Optra /Excelle/Viva (06MY~)	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Lanos	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	01.DELPHI	Read Dtc	
Lanos	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	01.DELPHI	Clear Dtc	
Lanos	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	01.DELPHI	Data Stream	
Lanos	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	01.DELPHI	Actuation	
Lanos	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	02.BOSCH	Read Dtc	
Lanos	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	02.BOSCH	Clear Dtc	
Lanos	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	02.BOSCH	Data Stream	
Lanos	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	02.BOSCH	Actuation	
Lanos	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Lanos	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	
Lanos	ALL YEAR	AUTOMATIC TRANSAXLE		Data Stream	
Lanos	ALL YEAR	ENGINE DOHC	1.5L	Read Dtc	
Lanos	ALL YEAR	ENGINE DOHC	1.5L	Clear Dtc	
Lanos	ALL YEAR	ENGINE DOHC	1.5L	Data Stream	
Lanos	ALL YEAR	ENGINE DOHC	1.5L	Actuation	
Lanos	ALL YEAR	ENGINE DOHC	1.6L	Read Dtc	
Lanos	ALL YEAR	ENGINE DOHC	1.6L	Clear Dtc	

model	year	system	subitem	function	subfunction
Lanos	ALL YEAR	ENGINE DOHC	1.6L	Data Stream	
Lanos	ALL YEAR	ENGINE DOHC	1.6L	Actuation	
Lanos	ALL YEAR	ENGINE SOHC	1.3L	Read Dtc	
Lanos	ALL YEAR	ENGINE SOHC	1.3L	Clear Dtc	
Lanos	ALL YEAR	ENGINE SOHC	1.3L	Data Stream	
Lanos	ALL YEAR	ENGINE SOHC	1.3L	Actuation	
Lanos	ALL YEAR	ENGINE SOHC	1.5L	Read Dtc	
Lanos	ALL YEAR	ENGINE SOHC	1.5L	Clear Dtc	
Lanos	ALL YEAR	ENGINE SOHC	1.5L	Data Stream	
Lanos	ALL YEAR	ENGINE SOHC	1.5L	Actuation	
Lanos	ALL YEAR	SRS-AIRBAG		Read Dtc	
Lanos	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Leganza	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Leganza	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Leganza	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Leganza	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Actuation	
Leganza	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Special Functions	Air Bleed
Leganza	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		System Info.	
Leganza	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Read Dtc	
Leganza	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Clear Dtc	
Leganza	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Data Stream	
Leganza	ALL YEAR	ENGINE DOHC	1.8L	Read Dtc	
Leganza	ALL YEAR	ENGINE DOHC	1.8L	Clear Dtc	
Leganza	ALL YEAR	ENGINE DOHC	1.8L	Data Stream	
Leganza	ALL YEAR	ENGINE DOHC	1.8L	Actuation	
Leganza	ALL YEAR	ENGINE DOHC	2.0L	Read Dtc	
Leganza	ALL YEAR	ENGINE DOHC	2.0L	Clear Dtc	
Leganza	ALL YEAR	ENGINE DOHC	2.0L	Data Stream	
Leganza	ALL YEAR	ENGINE DOHC	2.0L	Actuation	
Leganza	ALL YEAR	ENGINE DOHC	2.2L	Read Dtc	
Leganza	ALL YEAR	ENGINE DOHC	2.2L	Clear Dtc	
Leganza	ALL YEAR	ENGINE DOHC	2.2L	Data Stream	
Leganza	ALL YEAR	ENGINE DOHC	2.2L	Actuation	
Leganza	ALL YEAR	ENGINE DOHC	LPG	Read Dtc	

model	year	system	subitem	function	subfunction
Leganza	ALL YEAR	ENGINE DOHC	LPG	Clear Dtc	
Leganza	ALL YEAR	ENGINE SOHC	1.8L	Read Dtc	
Leganza	ALL YEAR	ENGINE SOHC	1.8L	Clear Dtc	
Leganza	ALL YEAR	ENGINE SOHC	1.8L	Data Stream	
Leganza	ALL YEAR	ENGINE SOHC	1.8L	Actuation	
Leganza	ALL YEAR	ENGINE SOHC	2.0L	Read Dtc	
Leganza	ALL YEAR	ENGINE SOHC	2.0L	Clear Dtc	
Leganza	ALL YEAR	ENGINE SOHC	2.0L	Data Stream	
Leganza	ALL YEAR	ENGINE SOHC	2.0L	Actuation	
Leganza	ALL YEAR	ENGINE SOHC	LPG	Read Dtc	
Leganza	ALL YEAR	ENGINE SOHC	LPG	Clear Dtc	
Leganza	ALL YEAR	SRS-AIRBAG		Read Dtc	
Leganza	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Leganza	ALL YEAR	SRS-AIRBAG		Data Stream	
Lemans/Race	ALL YEAR	ENGINE DOHC	1.5 MPI	Read Dtc	
Lemans/Race	ALL YEAR	ENGINE DOHC	1.5 MPI	Clear Dtc	
Lemans/Race	ALL YEAR	ENGINE DOHC	1.5 MPI	Data Stream	
Lemans/Race	ALL YEAR	ENGINE DOHC	1.5 MPI	Actuation	
Lemans/Race	ALL YEAR	ENGINE SOHC	1.5 MPI	Read Dtc	
Lemans/Race	ALL YEAR	ENGINE SOHC	1.5 MPI	Clear Dtc	
Lemans/Race	ALL YEAR	ENGINE SOHC	1.5 MPI	Data Stream	
Lemans/Race	ALL YEAR	ENGINE SOHC	1.5 MPI	Actuation	
Magnus	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Magnus	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Magnus	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Magnus	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Actuation	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE(~2002 MY)	Read Dtc	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE(~2002 MY)	Clear Dtc	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE(~2002 MY)	Data Stream	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE(~2002 MY)	Actuation	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE(2002MY~)	Read Dtc	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE(2002MY~)	Clear Dtc	

model	year	system	subitem	function	subfunction
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE(2002MY~)	Data Stream	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE(2002MY~)	Actuation	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Read Dtc	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Clear Dtc	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Data Stream	
Magnus	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Actuation	
Magnus	ALL YEAR	ENGINE CONTROL	GASOLINE(L4)	Read Dtc	
Magnus	ALL YEAR	ENGINE CONTROL	GASOLINE(L4)	Clear Dtc	
Magnus	ALL YEAR	ENGINE CONTROL	GASOLINE(L4)	Data Stream	
Magnus	ALL YEAR	ENGINE CONTROL	GASOLINE(L4)	Actuation	
Magnus	ALL YEAR	ENGINE CONTROL	LPG	Read Dtc	
Magnus	ALL YEAR	ENGINE CONTROL	LPG	Clear Dtc	
Magnus	ALL YEAR	ENGINE CONTROL	XK(SIEMENS L6)	Read Dtc	
Magnus	ALL YEAR	ENGINE CONTROL	XK(SIEMENS L6)	Clear Dtc	
Magnus	ALL YEAR	ENGINE CONTROL	XK(SIEMENS L6)	Data Stream	
Magnus	ALL YEAR	ISC		Read Dtc	
Magnus	ALL YEAR	ISC		Clear Dtc	
Magnus	ALL YEAR	ISC		Data Stream	
Magnus	ALL YEAR	ISC		Actuation	
Magnus	ALL YEAR	SRS-AIRBAG		Read Dtc	
Magnus	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Matiz(M200)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Matiz(M200)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Matiz(M200)	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Matiz(M200)	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Matiz(M200)	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	
Matiz(M200)	ALL YEAR	AUTOMATIC TRANSAXLE		Data Stream	
Matiz(M200)	ALL YEAR	AUTOMATIC TRANSAXLE		Actuation	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	0.8 SOHC	Read Dtc	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	0.8 SOHC	Clear Dtc	

model	year	system	subitem	function	subfunction
Matiz(M200)	ALL YEAR	ENGINE CONTROL	0.8 SOHC	Data Stream	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	0.8 SOHC KOB(2007MY)	Read Dtc	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	0.8 SOHC KOB(2007MY)	Clear Dtc	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	0.8 SOHC KOB(2007MY)	Data Stream	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	0.8 SOHC KOB(2007MY)	Special Functions	ADAPTION RESET
Matiz(M200)	ALL YEAR	ENGINE CONTROL	0.8 SOHC KOB(2007MY)	Special Functions	EVAP.LEAK
Matiz(M200)	ALL YEAR	ENGINE CONTROL	1.0 SOHC(EURO-	Read Dtc	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	1.0 SOHC(EURO-	Clear Dtc	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	1.0 SOHC(EURO-	Data Stream	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	1.0 SOHC(EURO-	Special Functions	ADAPTION
Matiz(M200)	ALL YEAR	ENGINE CONTROL	1.0 SOHC(EURO- III&IV)	Read Dtc	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	1.0 SOHC(EURO- III&IV)	Clear Dtc	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	1.0 SOHC(EURO- III&IV)	Data Stream	
Matiz(M200)	ALL YEAR	ENGINE CONTROL	1.0 SOHC(EURO- III&IV)	Special Functions	ADAPTION RESET
Matiz(M200)	ALL YEAR	SRS-AIRBAG		Read Dtc	
Matiz(M200)	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	01.ENG.CONTROL MOD.(ECU-D52)	Read Dtc	
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	01.ENG.CONTROL MOD.(ECU-D52)	Clear Dtc	
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	01.ENG.CONTROL MOD.(ECU-D52)	Data Stream	
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	01.ENG.CONTROL MOD.(ECU-D52)	Actuation	
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	01.ENG.CONTROL MOD.(ECU-D52)	Special Functions	ADAPTION RESET
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	01.ENG.CONTROL MOD.(ECU-D52)	Special Functions	EVAP.LEAK
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	02.LPG CONTROL MOD.(ICM-LPGI)	Read Dtc	
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	02.LPG CONTROL MOD.(ICM-LPGI)	Clear Dtc	
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	02.LPG CONTROL MOD.(ICM-LPGI)	Data Stream	

model	year	system	subitem	function	subfunction
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	03.A/T CONTROL MODULE	Read Dtc	
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	03.A/T CONTROL MODULE	Clear Dtc	
Matiz(M300) /Spark	ALL YEAR	01.POWER TRAIN	03.A/T CONTROL MODULE	Data Stream	
Matiz(M300) /Spark	ALL YEAR	02.CHASSIS	01.BRAKE CONTROL MODULE(EBCM)	Read Dtc	
Matiz(M300) /Spark	ALL YEAR	02.CHASSIS	01.BRAKE CONTROL MODULE(EBCM)	Clear Dtc	
Matiz(M300) /Spark	ALL YEAR	02.CHASSIS	01.BRAKE CONTROL MODULE(EBCM)	Data Stream	
Matiz(M300) /Spark	ALL YEAR	02.CHASSIS	01.BRAKE CONTROL MODULE(EBCM)	Special Functions	SAS SENSOR ZERO SETTING
Matiz(M300) /Spark	ALL YEAR	02.CHASSIS	01.BRAKE CONTROL MODULE(EBCM)	Special Functions	WRITE VIN
Matiz(M300) /Spark	ALL YEAR	03.BODY	01.AIRBAG CONTROL MODULE(SDM)	Read Dtc	
Matiz(M300) /Spark	ALL YEAR	03.BODY	01.AIRBAG CONTROL MODULE(SDM)	Clear Dtc	
Matiz(M300) /Spark	ALL YEAR	03.BODY	01.AIRBAG CONTROL MODULE(SDM)	Data Stream	
Matiz(M300) /Spark	ALL YEAR	03.BODY	01.AIRBAG CONTROL MODULE(SDM)	Special Functions	NEW SDM APPLIED SETUP
Matiz(M300) /Spark	ALL YEAR	03.BODY	01.AIRBAG CONTROL MODULE(SDM)	Special Functions	SDM RESET
Matiz(M300) /Spark	ALL YEAR	03.BODY	01.AIRBAG CONTROL MODULE(SDM)	Special Functions	WRITE VIN
Matiz(M300) /Spark	ALL YEAR	03.BODY	02.INS.CLUSTER CTRL MOD(IPC)	Read Dtc	
Matiz(M300) /Spark	ALL YEAR	03.BODY	02.INS.CLUSTER CTRL MOD(IPC)	Clear Dtc	

model	year	system	subitem	function	subfunction
Matiz(M300)/Spark	ALL YEAR	03.BODY	02.INS.CLUSTER CTRL MOD(IPC)	Data Stream	
Matiz/Spark	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Matiz/Spark	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Matiz/Spark	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Matiz/Spark	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Actuation	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	01.0.8L	Read Dtc	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	01.0.8L	Clear Dtc	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	01.0.8L	Data Stream	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	01.0.8L	Actuation	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	01.0.8L	Special Functions	ADAPTION
Matiz/Spark	ALL YEAR	ENGINE CONTORL	01.0.8L	System Info.	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	02.1.0L	Read Dtc	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	02.1.0L	Clear Dtc	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	02.1.0L	Data Stream	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	02.1.0L	Actuation	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	02.1.0L	Special Functions	ADAPTION
Matiz/Spark	ALL YEAR	ENGINE CONTORL	02.1.0L	System Info.	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	03.LEAD	Read Dtc	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	03.LEAD	Clear Dtc	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	03.LEAD	Data Stream	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	Unlead	Read Dtc	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	Unlead	Clear Dtc	
Matiz/Spark	ALL YEAR	ENGINE CONTORL	Unlead	Data Stream	
Matiz/Spark	ALL YEAR	SRS-AIRBAG		Read Dtc	
Matiz/Spark	ALL YEAR	SRS-AIRBAG		Clear Dtc	
New Prince	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
New Prince	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
New Prince	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
New Prince	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		System Info.	
New Prince	ALL YEAR	ENGINE DOHC		Read Dtc	
New Prince	ALL YEAR	ENGINE DOHC		Clear Dtc	
New Prince	ALL YEAR	ENGINE DOHC		Data Stream	
New Prince	ALL YEAR	ENGINE DOHC		Actuation	
New Prince	ALL YEAR	ENGINE SOHC		Read Dtc	

model	year	system	subitem	function	subfunction
New Prince	ALL YEAR	ENGINE SOHC		Clear Dtc	
New Prince	ALL YEAR	ENGINE SOHC		Data Stream	
New Prince	ALL YEAR	ENGINE SOHC		Actuation	
New-Brougham	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
New-Brougham	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
New-Brougham	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
New-Brougham	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		System Info.	
New-Brougham	ALL YEAR	ENGINE DOHC		Read Dtc	
New-Brougham	ALL YEAR	ENGINE DOHC		Clear Dtc	
New-Brougham	ALL YEAR	ENGINE DOHC		Data Stream	
New-Brougham	ALL YEAR	ENGINE DOHC		Actuation	
New-Brougham	ALL YEAR	ENGINE SOHC		Read Dtc	
New-Brougham	ALL YEAR	ENGINE SOHC		Clear Dtc	
New-Brougham	ALL YEAR	ENGINE SOHC		Data Stream	
New-Brougham	ALL YEAR	ENGINE SOHC		Actuation	
New-Lanos	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Read Dtc	
New-Lanos	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Clear Dtc	
New-Lanos	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Data Stream	
New-Lanos	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Actuation	
New-Lanos	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Special Functions	CRANK ANGLE TEC LEARN
New-Lanos	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Special Functions	EVAP.LEAK
New-Lanos	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Special Functions	ECU INFORMATION
New-Lanos	ALL YEAR	02. AUTOMATIC TRANSAXLE		Read Dtc	

model	year	system	subitem	function	subfunction
New-Lanos	ALL YEAR	02. AUTOMATIC TRANSAXLE		Clear Dtc	
New-Lanos	ALL YEAR	02. AUTOMATIC TRANSAXLE		Data Stream	
New-Lanos	ALL YEAR	03. ANTI-LOCK BRAKE SYSTEM		Read Dtc	
New-Lanos	ALL YEAR	03. ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
New-Lanos	ALL YEAR	03. ANTI-LOCK BRAKE SYSTEM		Data Stream	
New-Nexia	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Read Dtc	
New-Nexia	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Clear Dtc	
New-Nexia	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Data Stream	
New-Nexia	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Actuation	
New-Nexia	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Special Functions	CRANK ANGLE TEC LEARN
New-Nexia	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Special Functions	EVAP.LEAK
New-Nexia	ALL YEAR	01. ENGINE CONTROL	01.1.5 SOHC	Special Functions	ECU INFORMATION
New-Nexia	ALL YEAR	01. ENGINE CONTROL	02.1.6 SOHC	Read Dtc	
New-Nexia	ALL YEAR	01. ENGINE CONTROL	02.1.6 SOHC	Clear Dtc	
New-Nexia	ALL YEAR	01. ENGINE CONTROL	02.1.6 SOHC	Data Stream	
New-Nexia	ALL YEAR	01. ENGINE CONTROL	02.1.6 SOHC	Actuation	
New-Nexia	ALL YEAR	01. ENGINE CONTROL	02.1.6 SOHC	Special Functions	EVAP.LEAK
New-Nexia	ALL YEAR	01. ENGINE CONTROL	02.1.6 SOHC	Special Functions	ADAPTION RESET
New-Nexia	ALL YEAR	02. AUTOMATIC TRANSAXLE		Read Dtc	
New-Nexia	ALL YEAR	02. AUTOMATIC TRANSAXLE		Clear Dtc	
New-Nexia	ALL YEAR	02. AUTOMATIC TRANSAXLE		Data Stream	

model	year	system	subitem	function	subfunction
New-Nexia	ALL YEAR	03. ANTI-LOCK BRAKE SYSTEM		Read Dtc	
New-Nexia	ALL YEAR	03. ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
New-Nexia	ALL YEAR	03. ANTI-LOCK BRAKE SYSTEM		Data Stream	
Nexia	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Nexia	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Nexia	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Nexia	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Nexia	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	
Nexia	ALL YEAR	AUTOMATIC TRANSAXLE		Data Stream	
Nexia	ALL YEAR	ENGINE DOHC	LEAD 1.5L	Read Dtc	
Nexia	ALL YEAR	ENGINE DOHC	LEAD 1.5L	Clear Dtc	
Nexia	ALL YEAR	ENGINE DOHC	LEAD 1.5L	Data Stream	
Nexia	ALL YEAR	ENGINE DOHC	LEAD 1.5L	Actuation	
Nexia	ALL YEAR	ENGINE DOHC	UNLEAD 1.5L	Read Dtc	
Nexia	ALL YEAR	ENGINE DOHC	UNLEAD 1.5L	Clear Dtc	
Nexia	ALL YEAR	ENGINE DOHC	UNLEAD 1.5L	Data Stream	
Nexia	ALL YEAR	ENGINE DOHC	UNLEAD 1.5L	Actuation	
Nexia	ALL YEAR	ENGINE SOHC	1.5(rus)	Read Dtc	
Nexia	ALL YEAR	ENGINE SOHC	1.5(rus)	Clear Dtc	
Nexia	ALL YEAR	ENGINE SOHC	1.5(rus)	Data Stream	
Nexia	ALL YEAR	ENGINE SOHC	1.5(rus)	Actuation	
Nexia	ALL YEAR	ENGINE SOHC	LEAD 1.5	Read Dtc	
Nexia	ALL YEAR	ENGINE SOHC	LEAD 1.5	Clear Dtc	
Nexia	ALL YEAR	ENGINE SOHC	LEAD 1.5	Data Stream	
Nexia	ALL YEAR	ENGINE SOHC	LEAD 1.5	Actuation	
Nexia	ALL YEAR	ENGINE SOHC	UNLEAD 1.5L	Read Dtc	
Nexia	ALL YEAR	ENGINE SOHC	UNLEAD 1.5L	Clear Dtc	
Nexia	ALL YEAR	ENGINE SOHC	UNLEAD 1.5L	Data Stream	
Nexia	ALL YEAR	ENGINE SOHC	UNLEAD 1.5L	Actuation	
Nexia	ALL YEAR	ENGINE SOHC	UNLEAD 1.8L	Read Dtc	
Nexia	ALL YEAR	ENGINE SOHC	UNLEAD 1.8L	Clear Dtc	
Nexia	ALL YEAR	ENGINE SOHC	UNLEAD 1.8L	Data Stream	
Nexia	ALL YEAR	SRS-AIRBAG		Read Dtc	
Nexia	ALL YEAR	SRS-AIRBAG		Clear Dtc	

model	year	system	subitem	function	subfunction
Nubira	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Nubira	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Nubira	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Nubira	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Nubira	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	
Nubira	ALL YEAR	AUTOMATIC TRANSAXLE		Data Stream	
Nubira	ALL YEAR	ENGINE DOHC	1.5L	Read Dtc	
Nubira	ALL YEAR	ENGINE DOHC	1.5L	Clear Dtc	
Nubira	ALL YEAR	ENGINE DOHC	1.5L	Data Stream	
Nubira	ALL YEAR	ENGINE DOHC	1.5L	Actuation	
Nubira	ALL YEAR	ENGINE DOHC	1.8L	Read Dtc	
Nubira	ALL YEAR	ENGINE DOHC	1.8L	Clear Dtc	
Nubira	ALL YEAR	ENGINE DOHC	1.8L	Data Stream	
Nubira	ALL YEAR	ENGINE DOHC	1.8L	Actuation	
Nubira	ALL YEAR	ENGINE DOHC	2.0L	Read Dtc	
Nubira	ALL YEAR	ENGINE DOHC	2.0L	Clear Dtc	
Nubira	ALL YEAR	ENGINE DOHC	2.0L	Data Stream	
Nubira	ALL YEAR	ENGINE DOHC	2.0L	Actuation	
Nubira	ALL YEAR	ENGINE SOHC	1.5L	Read Dtc	
Nubira	ALL YEAR	ENGINE SOHC	1.5L	Clear Dtc	
Nubira	ALL YEAR	ENGINE SOHC	1.5L	Data Stream	
Nubira	ALL YEAR	ENGINE SOHC	1.5L	Actuation	
Nubira	ALL YEAR	SRS-AIRBAG		Read Dtc	
Nubira	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Nubira	ALL YEAR	SRS-AIRBAG		Data Stream	
Nubira II	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Nubira II	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Nubira II	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Nubira II	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Actuation	
Nubira II	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Nubira II	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	

model	year	system	subitem	function	subfunction
Nubira II	ALL YEAR	AUTOMATIC TRANSAXLE		Data Stream	
Nubira II	ALL YEAR	ENGINE DOHC	1.5 L	Read Dtc	
Nubira II	ALL YEAR	ENGINE DOHC	1.5 L	Clear Dtc	
Nubira II	ALL YEAR	ENGINE DOHC	1.5 L	Data Stream	
Nubira II	ALL YEAR	ENGINE DOHC	1.5 L	Actuation	
Nubira II	ALL YEAR	ENGINE DOHC	1.6 L	Read Dtc	
Nubira II	ALL YEAR	ENGINE DOHC	1.6 L	Clear Dtc	
Nubira II	ALL YEAR	ENGINE DOHC	1.6 L	Data Stream	
Nubira II	ALL YEAR	ENGINE DOHC	2.0 L	Read Dtc	
Nubira II	ALL YEAR	ENGINE DOHC	2.0 L	Clear Dtc	
Nubira II	ALL YEAR	ENGINE DOHC	2.0 L	Data Stream	
Nubira II	ALL YEAR	ENGINE DOHC	2.0 L	Actuation	
Nubira II	ALL YEAR	ENGINE SOHC	2.0 L	Read Dtc	
Nubira II	ALL YEAR	ENGINE SOHC	2.0 L	Clear Dtc	
Nubira II	ALL YEAR	ENGINE SOHC	2.0 L	Data Stream	
Nubira II	ALL YEAR	ENGINE SOHC	2.0 L	Actuation	
Nubira II	ALL YEAR	SRS-AIRBAG		Read Dtc	
Nubira II	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Nubira II	ALL YEAR	SRS-AIRBAG		Data Stream	
Prince	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Prince	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Prince	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Prince	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		System Info.	
Prince	ALL YEAR	ENGINE SOHC	1.8 MPFI	Read Dtc	
Prince	ALL YEAR	ENGINE SOHC	1.8 MPFI	Clear Dtc	
Prince	ALL YEAR	ENGINE SOHC	1.8 MPFI	Data Stream	
Prince	ALL YEAR	ENGINE SOHC	1.8 MPFI	Actuation	
Prince	ALL YEAR	ENGINE SOHC	2.0 MPFI	Read Dtc	
Prince	ALL YEAR	ENGINE SOHC	2.0 MPFI	Clear Dtc	
Prince	ALL YEAR	ENGINE SOHC	2.0 MPFI	Data Stream	
Prince	ALL YEAR	ENGINE SOHC	2.0 MPFI	Actuation	
Prince	ALL YEAR	ENGINE SOHC	2.0 (rus)	Read Dtc	
Prince	ALL YEAR	ENGINE SOHC	2.0 (rus)	Clear Dtc	
Prince	ALL YEAR	ENGINE SOHC	2.0 (rus)	Data Stream	
Prince	ALL YEAR	ENGINE SOHC	2.0 (rus)	Actuation	
Prince	ALL YEAR	ENGINE SOHC	2.2L MPFI	Read Dtc	
Prince	ALL YEAR	ENGINE SOHC	2.2L MPFI	Clear Dtc	
Prince	ALL YEAR	ENGINE SOHC	2.2L MPFI	Data Stream	

model	year	system	subitem	function	subfunction
Prince	ALL YEAR	ENGINE SOHC	2.2L MPFI	Actuation	
Prince	ALL YEAR	ENGINE SOHC	LPG	Read Dtc	
Prince	ALL YEAR	ENGINE SOHC	LPG	Clear Dtc	
Rezzo/Tacuma	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Rezzo/Tacuma	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Rezzo/Tacuma	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Rezzo/Tacuma	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Actuation	
Rezzo/Tacuma	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Special Functions	HCU AIRBREEDING
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	4HP16	Read Dtc	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	4HP16	Clear Dtc	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	4HP16	Data Stream	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	4HP16	Actuation	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE	Read Dtc	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE	Clear Dtc	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE	Data Stream	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	GASOLINE	Actuation	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Read Dtc	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Clear Dtc	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Data Stream	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	LPG	Actuation	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	SAISIN	Read Dtc	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	SAISIN	Clear Dtc	
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	SAISIN	Data Stream	

model	year	system	subitem	function	subfunction
Rezzo/Tacuma	ALL YEAR	AUTOMATIC TRANSAXLE	SAISIN	Actuation	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE AFTER 2005)	Read Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE AFTER 2005)	Clear Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE AFTER 2005)	Data Stream	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE AFTER 2005)	Actuation	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE AFTER 2005)	Special Functions	ADAPTION RESET
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE BEFORE 2005)	Read Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE BEFORE 2005)	Clear Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE BEFORE 2005)	Data Stream	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE BEFORE 2005)	Actuation	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE BEFORE 2005)	Special Functions	ADAPTION RESET
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.6 DOHC (GASOLINE BEFORE 2005)	Special Functions	WHEEL ADAPTATION VALUE READ
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE AFTER 2005)	Read Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE AFTER 2005)	Clear Dtc	

model	year	system	subitem	function	subfunction
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE AFTER 2005)	Data Stream	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE AFTER 2005)	Actuation	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE AFTER 2005)	Special Functions	ADAPTION RESET
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE BEFORE 2005)	Read Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE BEFORE 2005)	Clear Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE BEFORE 2005)	Data Stream	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE BEFORE 2005)	Actuation	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE BEFORE 2005)	Special Functions	ADAPTION RESET
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	1.8DOHC (GASOLINE BEFORE 2005)	Special Functions	WHEEL ADAPTION VALUE READ
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	2.0 DOHC (GASOLINE AFTER 2005)	Read Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	2.0 DOHC (GASOLINE AFTER 2005)	Clear Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	2.0 DOHC (GASOLINE AFTER 2005)	Data Stream	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	2.0 DOHC (GASOLINE AFTER 2005)	Actuation	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	LPG	Read Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	LPG	Clear Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	NIKKI LPG	Read Dtc	
Rezzo/Tacuma	ALL YEAR	ENGINE CONTROL	NIKKI LPG	Clear Dtc	

model	year	system	subitem	function	subfunction
Rezzo/Tacum	ALL YEAR	ENGINE CONTROL	NIKKI LPG	Data Stream	
Rezzo/Tacum a	ALL YEAR	ENGINE CONTROL	SOHC (GASOLINE AFTER 2005)	Read Dtc	
Rezzo/Tacum a	ALL YEAR	ENGINE CONTROL	SOHC (GASOLINE AFTER 2005)	Clear Dtc	
Rezzo/Tacum a	ALL YEAR	ENGINE CONTROL	SOHC (GASOLINE AFTER 2005)	Data Stream	
Rezzo/Tacum a	ALL YEAR	ENGINE CONTROL	SOHC (GASOLINE AFTER 2005)	Actuation	
Rezzo/Tacum a	ALL YEAR	ENGINE CONTROL	SOHC (GASOLINE BEFORE 2005)	Read Dtc	
Rezzo/Tacum a	ALL YEAR	ENGINE CONTROL	SOHC (GASOLINE BEFORE 2005)	Clear Dtc	
Rezzo/Tacum a	ALL YEAR	ENGINE CONTROL	SOHC (GASOLINE BEFORE 2005)	Data Stream	
Rezzo/Tacum a	ALL YEAR	ENGINE CONTROL	SOHC (GASOLINE BEFORE 2005)	Actuation	
Rezzo/Tacum	ALL YEAR	ENGINE CONTROL	UNLEADED	Read Dtc	
Rezzo/Tacum	ALL YEAR	ENGINE CONTROL	UNLEADED	Clear Dtc	
Rezzo/Tacum	ALL YEAR	ENGINE CONTROL	UNLEADED	Data Stream	
Rezzo/Tacum	ALL YEAR	ENGINE CONTROL	UNLEADED	Actuation	
Rezzo/Tacum	ALL YEAR	SRS-AIRBAG		Read Dtc	
Rezzo/Tacum	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Rezzo/Tacum	ALL YEAR	SRS-AIRBAG		Data Stream	
Stateman	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	ABS	Read Dtc	
Stateman	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	ABS	Clear Dtc	
Stateman	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	ABS	Data Stream	
Stateman	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	ABS	Actuation	
Stateman	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	ABS/ETC(DISABLE)	Read Dtc	
Stateman	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	ABS/ETC(DISABLE)	Clear Dtc	
Stateman	ALL YEAR	ANTI-LOCK BRAKE SYSTEM	ABS/ETC(DISABLE)	Data Stream	
Stateman	ALL YEAR	AUTOMATIC TRANSAXLE		Read Dtc	
Stateman	ALL YEAR	AUTOMATIC TRANSAXLE		Clear Dtc	

model	year	system	subitem	function	subfunction
Stateman	ALL YEAR	AUTOMATIC TRANSAXLE		Data Stream	
Stateman	ALL YEAR	AUTOMATIC TRANSAXLE		Actuation	
Stateman	ALL YEAR	BODY CONTROL SYSTEM	INSTRUMENT	Read Dtc	
Stateman	ALL YEAR	BODY CONTROL SYSTEM	INSTRUMENT	Clear Dtc	
Stateman	ALL YEAR	BODY CONTROL SYSTEM	INSTRUMENT	Data Stream	
Stateman	ALL YEAR	BODY CONTROL SYSTEM	INSTRUMENT - CONFIG	Read Dtc	
Stateman	ALL YEAR	BODY CONTROL SYSTEM	INSTRUMENT - CONFIG	Clear Dtc	
Stateman	ALL YEAR	BODY CONTROL SYSTEM	INSTRUMENT - CONFIG	Data Stream	
Stateman	ALL YEAR	BODY CONTROL SYSTEM	TRIP COMPUTER	Read Dtc	
Stateman	ALL YEAR	BODY CONTROL SYSTEM	TRIP COMPUTER	Clear Dtc	
Stateman	ALL YEAR	BODY CONTROL SYSTEM	TRIP COMPUTER	Data Stream	
Stateman	ALL YEAR	ENGINE CONTROL	V6	Read Dtc	
Stateman	ALL YEAR	ENGINE CONTROL	V6	Clear Dtc	
Stateman	ALL YEAR	ENGINE CONTROL	V6	Data Stream	
Stateman	ALL YEAR	ENGINE CONTROL	V6	Actuation	
Stateman	ALL YEAR	ENGINE CONTROL	V6 OBD	Read Dtc	
Stateman	ALL YEAR	ENGINE CONTROL	V6 OBD	Clear Dtc	
Stateman	ALL YEAR	ENGINE CONTROL	V6 OBD	Data Stream	
Stateman	ALL YEAR	SRS-AIRBAG		Read Dtc	
Stateman	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Stateman	ALL YEAR	SRS-AIRBAG		Data Stream	
Super Salon	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Super Salon	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Super Salon	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Super Salon	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		System Info.	
Super Salon	ALL YEAR	ENGINE SOHC	1.8 MPI	Read Dtc	
Super Salon	ALL YEAR	ENGINE SOHC	1.8 MPI	Clear Dtc	
Super Salon	ALL YEAR	ENGINE SOHC	1.8 MPI	Data Stream	

model	year	system	subitem	function	subfunction
Super Salon	ALL YEAR	ENGINE SOHC	1.8 MPI	Actuation	
Super Salon	ALL YEAR	ENGINE SOHC	2.0 MPI	Read Dtc	
Super Salon	ALL YEAR	ENGINE SOHC	2.0 MPI	Clear Dtc	
Super Salon	ALL YEAR	ENGINE SOHC	2.0 MPI	Data Stream	
Super Salon	ALL YEAR	ENGINE SOHC	2.0 MPI	Actuation	
Tosca/Epica	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Read Dtc	
Tosca/Epica	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Clear Dtc	
Tosca/Epica	ALL YEAR	ANTI-LOCK BRAKE SYSTEM		Data Stream	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 4 GEAR(GAS 1.8L)	Read Dtc	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 4 GEAR(GAS 1.8L)	Clear Dtc	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 4 GEAR(GAS 1.8L)	Data Stream	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 4 GEAR(LPG 2.0L)	Read Dtc	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 4 GEAR(LPG 2.0L)	Clear Dtc	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 4 GEAR(LPG 2.0L)	Data Stream	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 5GEAR(GAS 2.0/2.5L)	Read Dtc	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 5GEAR(GAS 2.0/2.5L)	Clear Dtc	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN 5GEAR(GAS 2.0/2.5L)	Data Stream	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU(DIESEL)	Read Dtc	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU(DIESEL)	Clear Dtc	
Tosca/Epica	ALL YEAR	AUTOMATIC TRANSAXLE	AISIN TCU(DIESEL)	Data Stream	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	2.0L DIESEL	Read Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	2.0L DIESEL	Clear Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	2.0L DIESEL	Data Stream	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	2.0L DIESEL	Special Functions	LEARNING DATA RESET
Tosca/Epica	ALL YEAR	ENGINE CONTROL	GASOLINE 1.8L	Read Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	GASOLINE 1.8L	Clear Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	GASOLINE 1.8L	Data Stream	

model	year	system	subitem	function	subfunction
Tosca/Epica	ALL YEAR	ENGINE CONTROL	GASOLINE 1.8L	Special Functions	LEARNING DATA RESET
Tosca/Epica	ALL YEAR	ENGINE CONTROL	GASOLINE 2.0L/2.5L	Read Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	GASOLINE 2.0L/2.5L	Clear Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	GASOLINE 2.0L/2.5L	Data Stream	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	GASOLINE 2.0L/2.5L	Special Functions	LEARNING DATA RESET
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(INTERFACE)	Read Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(INTERFACE)	Clear Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(INTERFACE)	Data Stream	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(MAIN)	Read Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(MAIN)	Clear Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(MAIN)	Data Stream	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(MAIN)	Special Functions	LEARNING DATA RESET
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(MAIN)-6 AT	Read Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(MAIN)-6 AT	Clear Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(MAIN)-6 AT	Data Stream	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(MAIN)-KULEV	Read Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(MAIN)-KULEV	Clear Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPG 2.0L(MAIN)-KULEV	Data Stream	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPI(EMS ECU)	Read Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPI(EMS ECU)	Clear Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPI(EMS ECU)	Data Stream	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPI(EMS ECU)	Actuation	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPI(IFB ECU)	Read Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPI(IFB ECU)	Clear Dtc	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPI(IFB ECU)	Data Stream	
Tosca/Epica	ALL YEAR	ENGINE CONTROL	LPI(IFB ECU)	Actuation	
Tosca/Epica	ALL YEAR	ISU		Read Dtc	
Tosca/Epica	ALL YEAR	ISU		Clear Dtc	

model	year	system	subitem	function	subfunction
Tosca/Epica	ALL YEAR	ISU		Data Stream	
Tosca/Epica	ALL YEAR	SRS-AIRBAG		Read Dtc	
Tosca/Epica	ALL YEAR	SRS-AIRBAG		Clear Dtc	
Tosca/Epica	ALL YEAR	SRS-AIRBAG		Data Stream	
Winstorm/Captiva/Antaba	ALL YEAR	AUTOMATIC TRANSAXLE	TCM(AISIN CAN)	Read Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	AUTOMATIC TRANSAXLE	TCM(AISIN CAN)	Clear Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	AUTOMATIC TRANSAXLE	TCM(AISIN CAN)	Data Stream	
Winstorm/Captiva/Antaba	ALL YEAR	AUTOMATIC TRANSAXLE	TCM(AISIN CAN)	Special Functions	LEARNING DATA RESET
Winstorm/Captiva/Antaba	ALL YEAR	BODY	BCM	Read Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	BODY	BCM	Clear Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	BODY	BCM	Data Stream	
Winstorm/Captiva/Antaba	ALL YEAR	BODY	BCM	Actuation	
Winstorm/Captiva/Antaba	ALL YEAR	BODY	BCM	Special Functions	WRITE VIN
Winstorm/Captiva/Antaba	ALL YEAR	CHASSIS	01.ABS	Read Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	CHASSIS	01.ABS	Clear Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	CHASSIS	01.ABS	Actuation	
Winstorm/Captiva/Antaba	ALL YEAR	CHASSIS	01.ABS	Special Functions	SAS SENSOR ZERO SETTING
Winstorm/Captiva/Antaba	ALL YEAR	CHASSIS	02.TCCM	Read Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	CHASSIS	02.TCCM	Clear Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	CHASSIS	02.TCCM	Data Stream	
Winstorm/Captiva/Antaba	ALL YEAR	CHASSIS	02.TCCM	Actuation	
Winstorm/Captiva/Antaba	ALL YEAR	CHASSIS	02.TCCM	Special Functions	BANK INFORMATION PROGRAM
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	01.ECM(DIESEL)	Read Dtc	

model	year	system	subitem	function	subfunction
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	01.ECM(DIESEL)	Clear Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	01.ECM(DIESEL)	Data Stream	
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	01.ECM(DIESEL)	Special Functions	LEARNING DATA RESET
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	02.2.4 DOHC(GASOLINE)	Read Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	02.2.4 DOHC(GASOLINE)	Clear Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	02.2.4 DOHC(GASOLINE)	Data Stream	
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	02.2.4 DOHC(GASOLINE)	Actuation	
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	02.2.4 DOHC(GASOLINE)	Special Functions	WHEEL CIRCUMFEREN
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	02.2.4 DOHC(GASOLINE)	Special Functions	ECM IMMOBILIZER
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	03.3.2 DOHC(GASOLINE)	Read Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	03.3.2 DOHC(GASOLINE)	Clear Dtc	
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	03.3.2 DOHC(GASOLINE)	Data Stream	
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	03.3.2 DOHC(GASOLINE)	Actuation	
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	03.3.2 DOHC(GASOLINE)	Special Functions	ENGINE OIL REMAINING
Winstorm/Captiva/Antaba	ALL YEAR	ENGINE CONTROL	03.3.2 DOHC(GASOLINE)	Special Functions	ECM IMMOBILIZER