

JPISUZU Diagnostics List

(Note:For reference only)

| make | model | year | module | area | system | subitem | function | subfunction |
|---------|--------------|------|--------|------|--------------|--------------------------|---------------------|-------------|
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.4L LG1 Euro 3 | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.4L LG1 Euro 3 | Actuation Test | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | V6 Engine | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | V6 Engine | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | V6 Engine | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Engine | V6 Engine | Actuation Test | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | AW30-40LE | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | Automatic Transmission | Version Information | |

| | | | | | | | | |
|---------|--------------|------|----|----|--------------|-----------------------------|---------------------|--|
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | AT JR405E | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | AT JR405E | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Transmission | AT JR405E | Actuation Test | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Chassis | ABS | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Chassis | ABS | Actuation Test | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (Transtron) | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (Transtron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (Transtron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (V6 Engine) | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (V6 Engine) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Immobiliser (V6 Engine) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Airbag | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Powertrain Interface Module | Version Information | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Powertrain Interface Module | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Powertrain Interface Module | Read Data Stream | |
| JPISUZU | TF/UC Series | 2015 | -- | -- | Body | Powertrain Interface Module | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.4L LG1 Euro 3 | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.4L LG1 Euro 3 | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read/Clear DTC | |

| | | | | | | | | |
|---------|--------------|------|----|----|--------------|----------------------------|---------------------|--|
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | V6 Engine | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | V6 Engine | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | V6 Engine | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Engine | V6 Engine | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | AW30-40LE | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | AT JR405E | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | AT JR405E | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Transmission | AT JR405E | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Chassis | ABS | Actuation Test | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read Data Stream | |

| | | | | | | | | |
|---------|--------------|------|----|----|--------|-----------------------------|---------------------|--|
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (Transtron) | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (Transtron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (Transtron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (V6 Engine) | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (V6 Engine) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Immobiliser (V6 Engine) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Airbag | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Powertrain Interface Module | Version Information | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Powertrain Interface Module | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Powertrain Interface Module | Read Data Stream | |
| JPISUZU | TF/UC Series | 2014 | -- | -- | Body | Powertrain Interface Module | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.4L LG1 Euro 3 | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.4L LG1 Euro 3 | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read Data Stream | |

| | | | | | | | | |
|---------|--------------|------|----|----|--------------|----------------------------|---------------------|--|
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | V6 Engine | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | V6 Engine | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | V6 Engine | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Engine | V6 Engine | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | AW30-40LE | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | AT JR405E | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | AT JR405E | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Transmission | AT JR405E | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Chassis | ABS | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Chassis | ABS | Actuation Test | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (Transtron) | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (Transtron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (Transtron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (V6 Engine) | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (V6 Engine) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Immobiliser (V6 Engine) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Airbag | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Airbag | Read Data Stream | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------|-----------------------------|---------------------|----------------------------------|
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Powertrain Interface Module | Version Information | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Powertrain Interface Module | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Powertrain Interface Module | Read Data Stream | |
| JPISUZU | TF/UC Series | 2013 | -- | -- | Body | Powertrain Interface Module | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HV1<CNG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HV1<CNG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HV1<CNG> | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HV1<CNG> | Special Function | ECM DTC reading value |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------------------|-----------------------------|------------------|----------------------------|
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | Hybrid System | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Engine | Hybrid System | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Body | Immobiliser | Special Function | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Transmission | AT A460 | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Transmission | AT A460 | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Transmission | AT A460 | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Transmission | Smoother / Smoother-Ex | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Transmission | Smoother / Smoother-Ex | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|------------------|---------------------|----------------------------------|
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | N Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------|--------------------------|---------------------|----------------------------------|
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Body | Immobiliser | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Body | Airbag | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-----------------------------|---------------------|-------------------------------|
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Chassis | Air Suspension | Version Information | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Chassis | Air Suspension | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-------------------------------|---------------------|----------------------------------|
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Information System | Speedometer Control Equipment | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Transmission | Smoother / Smoother-Fx | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Transmission | Smoother / Smoother-Fx | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |
| JPISUZU | F&G Series Truck | 2012 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Version Information | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Actuation Test | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Version Information | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Version Information | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Body | Drive security reference | Version Information | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Body | Drive security reference | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Body | Drive security reference | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Body | Drive security reference | Actuation Test | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Air Suspension | Version Information | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Air Suspension | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|------------------------------|---------------------|----------------------------------|
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | ABS/IESC | Version Information | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | ABS/IESC | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | ABS/IESC | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | ESC(with EBS) | Version Information | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | ESC(with EBS) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | ESC(with EBS) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Hydraulic retarder | Version Information | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Hydraulic retarder | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Hydraulic retarder | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Millimeter wave radar cruise | Version Information | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Millimeter wave radar cruise | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Millimeter wave radar cruise | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Chassis | Millimeter wave radar cruise | Actuation Test | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2012 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------------|------------------------|---------------------|-----------------------------|
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HF1-TC(CNG) | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HF1-TC(CNG) | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC(C/Rail_Euro2) | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC(C/Rail_Euro2) | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC(C/Rail_Euro3) | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6HK1-TC(C/Rail_Euro3) | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |
| JPISUZU | LT/LV Series Bus | 2012 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read Data Stream | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------|--------------------------|---------------------|--|
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2012 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.4L LG1 Euro 3 | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.4L LG1 Euro 3 | Actuation Test | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Version Information | |

| | | | | | | | | |
|---------|--------------|------|----|----|--------------|--------------------------|---------------------|----------------------------------|
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Injector Programming |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Display Injector Codes |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Injector Programming |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Display Injector Codes |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | V6 Engine | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | V6 Engine | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | V6 Engine | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Engine | V6 Engine | Actuation Test | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Transmission | AW30-40LE | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Transmission | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Transmission | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Transmission | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Transmission | AW30-40LE | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |

| | | | | | | | | |
|---------|----------------|------|----|----|---------|-----------------------------|---------------------|----------------------------------|
| JPISUZU | TF/UC Series | 2012 | -- | -- | Chassis | ABS | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (Delphi) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (Transtron) | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (Transtron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (Transtron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (Transtron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (V6 Engine) | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (V6 Engine) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (V6 Engine) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Immobiliser (V6 Engine) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Airbag | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Powertrain Interface Module | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Powertrain Interface Module | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Powertrain Interface Module | Read Data Stream | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Powertrain Interface Module | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Anti Theft Warning | Version Information | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Anti Theft Warning | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2012 | -- | -- | Body | Anti Theft Warning | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |

| | | | | | | | | |
|---------|----------------|------|----|----|--------|--------------------------|---------------------|----------------------------------|
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HV1<CNG> | Version Information | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HV1<CNG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HV1<CNG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HV1<CNG> | Actuation Test | ECM DTC reading value |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Correction data |

| | | | | | | | | |
|---------|----------------|------|----|----|--------------------|-----------------------------|---------------------|----------------------------|
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | Hybrid System | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Engine | Hybrid System | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Body | Immobiliser | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2011 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Transmission | AT A460 | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Transmission | AT A460 | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Transmission | AT A460 | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Transmission | Smoother / Smoother-Ex | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Transmission | Smoother / Smoother-Ex | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|--------------------------|---------------------|----------------------------------|
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | N Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Actuation Test | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-----------------------------|---------------------|----------------------------|
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Body | Immobiliser | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-------------------------------|---------------------|-------------------------------|
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Information System | Speedometer Control Equipment | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Transmission | Smoother / Smoother-Fx | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Transmission | Smoother / Smoother-Fx | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |
| JPISUZU | F&G Series Truck | 2011 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG1-TC (C/Rail) | Version Information | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG2-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG3-TC (C/Rail) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG4-TC (C/Rail) | Actuation Test | |

| | | | | | | | | |
|---------|------------------|------|----|----|---------|--------------------------|---------------------|----------------------------------|
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG5-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG6-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG7-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG8-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG9-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG10-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG11-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Version Information | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG2-TC (C/Rail_NLT) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG3-TC (C/Rail_NLT) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6WG4-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Version Information | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6UZ2-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6UZ3-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Engine | 6UZ4-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Body | Drive security reference | Version Information | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Body | Drive security reference | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Body | Drive security reference | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Body | Drive security reference | Actuation Test | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Air Suspension | Version Information | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Air Suspension | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | ABS/IESC | Version Information | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | ABS/IESC | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | ABS/IESC | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | ESC(with EBS) | Version Information | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | ESC(with EBS) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | ESC(with EBS) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Hydraulic retarder | Version Information | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Hydraulic retarder | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Hydraulic retarder | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | ABS 6 | Read Data Stream | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|------------------------------|---------------------|----------------------------------|
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Millimeter wave radar cruise | Version Information | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Millimeter wave radar cruise | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Millimeter wave radar cruise | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Chassis | Millimeter wave radar cruise | Actuation Test | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2011 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------------|------------------------|---------------------|------------------------|
| JPISUZU | LT/LV Series Bus | 2011 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Version Information | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------|--------------------------|---------------------|----------------------------------|
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2011 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.4L LG1 Euro 3 | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.4L LG1 Euro 3 | Actuation Test | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Injector Programming |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Display Injector Codes |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Fuel Supply Pump Learn Resetting |

| | | | | | | | | |
|---------|--------------|------|----|----|--------------|----------------------------|---------------------|------------------------|
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Injector Programming |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Display Injector Codes |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | V6 Engine | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | V6 Engine | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | V6 Engine | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Engine | V6 Engine | Actuation Test | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Transmission | AW30-40LE | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Transmission | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Transmission | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Transmission | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Transmission | AW30-40LE | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Chassis | ABS | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (Delphi) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (Transtron) | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (Transtron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (Transtron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (Transtron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (V6 Engine) | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (V6 Engine) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (V6 Engine) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Immobiliser (V6 Engine) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Airbag | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Airbag | Read/Clear DTC | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------|-----------------------------|---------------------|----------------------------------|
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Powertrain Interface Module | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Powertrain Interface Module | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Powertrain Interface Module | Read Data Stream | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Powertrain Interface Module | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Anti Theft Warning | Version Information | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Anti Theft Warning | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2011 | -- | -- | Body | Anti Theft Warning | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HV1<CNG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HV1<CNG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HV1<CNG> | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HV1<CNG> | Special Function | ECM DTC reading value |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read/Clear DTC | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------------|-----------------------------|---------------------|----------------------------|
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | Hybrid System | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Engine | Hybrid System | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Body | Immobiliser | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2010 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Body | Airbag | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Transmission | AT A460 | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Transmission | AT A460 | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Transmission | AT A460 | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Transmission | Smoother / Smoother-Ex | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|------------------------|---------------------|----------------------------------|
| JPISUZU | N Series Truck | 2010 | -- | -- | Transmission | Smoother / Smoother-Ex | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | N Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------|--------------------------|---------------------|----------------------------------|
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Body | Immobiliser | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-----------------------------|---------------------|-------------------------------|
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Body | Immobiliser | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-------------------------------|---------------------|----------------------------------|
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Information System | Speedometer Control Equipment | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Transmission | Smoother / Smoother-Fx | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Transmission | Smoother / Smoother-Fx | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |
| JPISUZU | F&G Series Truck | 2010 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Version Information | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Actuation Test | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Version Information | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Version Information | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Body | Drive security reference | Version Information | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Body | Drive security reference | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Body | Drive security reference | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Body | Drive security reference | Actuation Test | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Air Suspension | Version Information | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Air Suspension | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|------------------------------|---------------------|----------------------------------|
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | ABS/IESC | Version Information | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | ABS/IESC | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | ABS/IESC | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | ESC(with EBS) | Version Information | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | ESC(with EBS) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | ESC(with EBS) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Hydraulic retarder | Version Information | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Hydraulic retarder | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Hydraulic retarder | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Millimeter wave radar cruise | Version Information | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Millimeter wave radar cruise | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Millimeter wave radar cruise | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Chassis | Millimeter wave radar cruise | Actuation Test | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2010 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------------|------------------------|---------------------|-----------------------------|
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |
| JPISUZU | LT/LV Series Bus | 2010 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------|--------------------------|---------------------|----------------------------------|
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2010 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.4L LG1 Euro 3 | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.4L LG1 Euro 3 | Actuation Test | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Injector Programming |

| | | | | | | | | |
|---------|--------------|------|----|----|--------------|----------------------------|---------------------|----------------------------------|
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Display Injector Codes |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Injector Programming |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Display Injector Codes |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | V6 Engine | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | V6 Engine | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | V6 Engine | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Engine | V6 Engine | Actuation Test | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Transmission | AW30-40LE | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Transmission | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Transmission | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Transmission | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Transmission | AW30-40LE | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Chassis | ABS | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read Data Stream | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------|-----------------------------|---------------------|----------------------------------|
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (Delphi) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (Transtron) | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (Transtron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (Transtron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (Transtron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (V6 Engine) | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (V6 Engine) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (V6 Engine) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Immobiliser (V6 Engine) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Airbag | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Powertrain Interface Module | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Powertrain Interface Module | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Powertrain Interface Module | Read Data Stream | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Powertrain Interface Module | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Anti Theft Warning | Version Information | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Anti Theft Warning | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2010 | -- | -- | Body | Anti Theft Warning | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------|--------------------------|---------------------|----------------------------------|
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HV1<CNG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HV1<CNG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HV1<CNG> | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HV1<CNG> | Special Function | ECM DTC reading value |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | Hybrid System | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Engine | Hybrid System | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Body | Immobiliser | Version Information | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------------------|-----------------------------|------------------|-------------------------------|
| JPISUZU | N Series Truck | 2009 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Body | Immobiliser | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2009 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Transmission | AT A460 | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Transmission | AT A460 | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Transmission | AT A460 | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Transmission | Smoother / Smoother-Ex | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Transmission | Smoother / Smoother-Ex | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|--------------------------|---------------------|----------------------------------|
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | N Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-----------------------------|---------------------|----------------------------|
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Body | Immobiliser | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-------------------------------|---------------------|----------------------------------|
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Information System | Speedometer Control Equipment | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Transmission | Smoother / Smoother-Fx | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Transmission | Smoother / Smoother-Fx | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |
| JPISUZU | F&G Series Truck | 2009 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Version Information | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Actuation Test | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | DPD Status Resetting |

| | | | | | | | | |
|---------|------------------|------|----|----|---------|------------------------------|---------------------|--------------------------------|
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Version Information | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Version Information | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Body | Drive security reference | Version Information | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Body | Drive security reference | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Body | Drive security reference | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Body | Drive security reference | Actuation Test | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | ABS/IESC | Version Information | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | ABS/IESC | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | ABS/IESC | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Air Suspension | Version Information | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Air Suspension | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | ESC(with EBS) | Version Information | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | ESC(with EBS) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | ESC(with EBS) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Hydraulic retarder | Version Information | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Hydraulic retarder | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Hydraulic retarder | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Millimeter wave radar cruise | Version Information | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Millimeter wave radar cruise | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Millimeter wave radar cruise | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Chassis | Millimeter wave radar cruise | Actuation Test | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------------------|------------------------|---------------------|----------------------------------|
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2009 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Chassis | ABS 6 | Version Information | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Chassis | ABS 6 | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |
| JPISUZU | LT/LV Series Bus | 2009 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Version Information | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------|------------------------|---------------------|--|
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read/Clear DTC | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------|--------------------------|---------------------|----------------------------------|
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2009 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.4L LG1 Euro 3 | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.4L LG1 Euro 3 | Actuation Test | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Injector Programming |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Display Injector Codes |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 5L V6 6VE1 Hitachi | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Injector Programming |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Display Injector Codes |

| | | | | | | | | |
|---------|--------------|------|----|----|--------------|-----------------------------|---------------------|-----------------|
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | V6 Engine | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | V6 Engine | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | V6 Engine | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Engine | V6 Engine | Actuation Test | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Transmission | AW30-40LE | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Transmission | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Transmission | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Transmission | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Transmission | AW30-40LE | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Chassis | ABS | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (Delphi) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (Transtron) | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (Transtron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (Transtron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (Transtron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (V6 Engine) | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (V6 Engine) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (V6 Engine) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Immobiliser (V6 Engine) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Airbag | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Powertrain Interface Module | Version Information | |

| | | | | | | | | |
|---------|--------------|------|----|----|--------|-----------------------------|---------------------|----------------------------------|
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Powertrain Interface Module | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Powertrain Interface Module | Read Data Stream | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Powertrain Interface Module | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Anti Theft Warning | Version Information | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Anti Theft Warning | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2009 | -- | -- | Body | Anti Theft Warning | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.4L LG1 Euro 3 | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.4L LG1 Euro 3 | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Injector Programming |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 2.5L 4JK1-TC (TransTron) | Special Function | Display Injector Codes |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Injector Programming |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 3.0L 4JJ1-TC (TransTron) | Special Function | Display Injector Codes |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | V6 Engine | Version Information | |

| | | | | | | | | |
|---------|--------------|------|----|----|--------------|------------------------|---------------------|-----------------|
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | V6 Engine | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | V6 Engine | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | V6 Engine | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | XL L4 HV240 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | XL L4 HV240 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 4JA1-TC Bosch | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 4JA1-TC Bosch | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 4JA1-TC Bosch | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 4JA1-TC Bosch | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | 4JH1-TC Bosch | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | AT JR405E | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | AT JR405E | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | AT JR405E | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | AT JR405E | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Engine | AW30-40LE | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | AW30-40LE | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | AW30-40LE | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | AT JR405E | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | AT JR405E | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Transmission | AT JR405E | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Chassis | ABS | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Chassis | ABS | Read/Clear DTC | |

| | | | | | | | | |
|---------|--------------|------|----|----|---------|-----------------------------|---------------------|-----------------|
| JPISUZU | TF/UC Series | 2008 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Chassis | ABS 8 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Chassis | ABS 8 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Chassis | ABS 8 | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Chassis | ABS(VPW) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Chassis | ABS(VPW) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Chassis | ABS(VPW) | Actuation Test | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (Delphi) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (Transtron) | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (Transtron) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (Transtron) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (Transtron) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (V6 Engine) | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (V6 Engine) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (V6 Engine) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Immobiliser (V6 Engine) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Airbag | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Powertrain Interface Module | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Powertrain Interface Module | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Powertrain Interface Module | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Powertrain Interface Module | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Anti Theft Warning | Version Information | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Anti Theft Warning | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Anti Theft Warning | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Airbag (VPW) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Airbag (VPW) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Airbag SIEMENS | Read/Clear DTC | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------|--------------------------|---------------------|----------------------------------|
| JPISUZU | TF/UC Series | 2008 | -- | -- | Body | Airbag SIEMENS | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HV1<CNG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HV1<CNG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HV1<CNG> | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HV1<CNG> | Special Function | ECM DTC reading value |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1/4JJ1 <C/Rail_Euro2> | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |

| | | | | | | | | |
|---------|----------------|------|----|----|--------------------|-----------------------------|---------------------|----------------------------|
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | Hybrid System | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Engine | Hybrid System | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Body | Immobiliser | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2008 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Transmission | AT A460 | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Transmission | AT A460 | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Transmission | AT A460 | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Transmission | Smoother / Smoother-Ex | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Transmission | Smoother / Smoother-Ex | Read Data Stream | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Read Data Stream | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|------------------|---------------------|----------------------------------|
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | N Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |

| | | | | | | | | |
|---------|------------------|------|----|----|--------|-----------------------------|---------------------|--------------------------------|
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro2> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1/6HK1 <C/Rail_Euro3> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Body | Immobiliser | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-------------------------------|---------------------|-------------------------------|
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Information System | Speedometer Control Equipment | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Transmission | Smoother / Smoother-Fx | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Transmission | Smoother / Smoother-Fx | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|------------------------------|---------------------|----------------------------------|
| JPISUZU | F&G Series Truck | 2008 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Version Information | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Actuation Test | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Version Information | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Version Information | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Body | Drive security reference | Version Information | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Body | Drive security reference | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Body | Drive security reference | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Body | Drive security reference | Actuation Test | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Chassis | Air Suspension | Version Information | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Chassis | Air Suspension | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Chassis | Millimeter wave radar cruise | Version Information | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Chassis | Millimeter wave radar cruise | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Chassis | Millimeter wave radar cruise | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Chassis | Millimeter wave radar cruise | Actuation Test | |
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------------------|------------------------|---------------------|----------------------------------|
| JPISUZU | C&E Series Truck | 2008 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |
| JPISUZU | LT/LV Series Bus | 2008 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Actuation Test | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------|------------------------|---------------------|--|
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2008 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 2.4L LG1 Euro 3 | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 2.4L LG1 Euro 3 | Read Data Stream | |

| | | | | | | | | |
|---------|--------------|------|----|----|--------------|---------------------|---------------------|-------------|
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 2.4L LG1 Euro 3 | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 5L 4JK1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 5L 4JK1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 5L 4JK1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 5L 4JK1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 0L 4JJ1-TC (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 0L 4JJ1-TC (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 0L 4JJ1-TC (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 0L 4JJ1-TC (Delphi) | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | V6 Engine | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | V6 Engine | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | V6 Engine | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | V6 Engine | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | XL L4 HV240 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | XL L4 HV240 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 4JA1-TC Bosch | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 4JA1-TC Bosch | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 4JA1-TC Bosch | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 4JA1-TC Bosch | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | 4JH1-TC Bosch | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | AT JR405E | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | AT JR405E | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | AT JR405E | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | AT JR405E | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Engine | AW30-40LE | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Transmission | AW30-40LE | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Transmission | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Transmission | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Transmission | AW30-40LE | Actuation Test | |

| | | | | | | | | |
|---------|--------------|------|----|----|--------------|-----------------------------|---------------------|-----------------|
| JPISUZU | TF/UC Series | 2007 | -- | -- | Transmission | AW30-40LE | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Chassis | ABS | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Chassis | ABS 8 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Chassis | ABS 8 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Chassis | ABS 8 | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Chassis | ABS(VPW) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Chassis | ABS(VPW) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Chassis | ABS(VPW) | Actuation Test | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (4L LG1 Euro3) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (Delphi) | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (Delphi) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (Delphi) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (Delphi) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (V6 Engine) | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (V6 Engine) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (V6 Engine) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Immobiliser (V6 Engine) | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Airbag | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Powertrain Interface Module | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Powertrain Interface Module | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Powertrain Interface Module | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Powertrain Interface Module | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Anti Theft Warning | Version Information | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Anti Theft Warning | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Anti Theft Warning | Read Data Stream | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------|----------------------|---------------------|----------------------------------|
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Airbag (VPW) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Airbag (VPW) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Airbag SIEMENS | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2007 | -- | -- | Body | Airbag SIEMENS | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Version Information | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HV1<CNG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HV1<CNG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HV1<CNG> | Actuation Test | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HV1<CNG> | Special Function | ECM DTC reading value |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read/Clear DTC | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------------------|-----------------------------|------------------|-------------------------------|
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Correction data |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | 4JJ1-TC <C/Rail_NLT> | Special Function | Reset fuel pump correction |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | Hybrid System | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Engine | Hybrid System | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Transmission | AT A460 | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Transmission | AT A460 | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Transmission | AT A460 | Actuation Test | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-----------------------------|---------------------|----------------------------------|
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | N Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | Idle stop <BCM> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | Idle stop <BCM> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Engine | 6HK1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Body | Vehicle Body Control Module | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Body | Vehicle Body Control Module | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Body | Vehicle Body Control Module | Actuation Test | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|-------------------------------|---------------------|-------------------------------|
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Transmission | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Transmission | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Transmission | Smoother / Smoother-Fx | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Transmission | Smoother / Smoother-Fx | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Actuation Test | |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | ECM DTC data |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | DTC data except ECM |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | DCU Lock |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all data clear |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | MIMSMORI all DTC record clear |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | Engine DMU all data clear |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | TCM DMU all data clear |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | Forced engine DMU record |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Special Function | Forced TCM DMU record |
| JPISUZU | F&G Series Truck | 2007 | -- | -- | Information System | Speedometer Control Equipment | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6WG1-TC (C/Rail) | Version Information | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6WG1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6WG1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6WG1-TC (C/Rail) | Actuation Test | |

| | | | | | | | | |
|---------|------------------|------|----|----|--------------------|------------------------------|---------------------|----------------------------------|
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6WG1-TC (C/Rail) | Special Function | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Version Information | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Version Information | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_NLT> | Actuation Test | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Body | Drive security reference | Version Information | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Body | Drive security reference | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Body | Drive security reference | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Body | Drive security reference | Actuation Test | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Chassis | Air Suspension | Version Information | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Chassis | Air Suspension | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Chassis | Millimeter wave radar cruise | Version Information | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Chassis | Millimeter wave radar cruise | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Chassis | Millimeter wave radar cruise | Read Data Stream | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Chassis | Millimeter wave radar cruise | Actuation Test | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Read/Clear DTC | |
| JPISUZU | C&E Series Truck | 2007 | -- | -- | Information System | MIMAMORI | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Version Information | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | VIN Programming |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Programming |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Codes |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Status Resetting |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|---------------|------------------------|---------------------|--------------------------------|
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6HK1-TC (C/Rail) | Special Function | Display Injector Quantity Trim |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_Euro3> | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Transmission: | Automatic Transmission | Version Information | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Transmission: | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Transmission: | Automatic Transmission | Read Data Stream | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Transmission: | Automatic Transmission | Actuation Test | |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Transmission: | Automatic Transmission | Special Function | Clear Adaptive to Fast+Base |
| JPISUZU | LT/LV Series Bus | 2007 | -- | -- | Transmission: | Automatic Transmission | Special Function | Autodetect Information |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Actuation Test | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------|------------------------|---------------------|-------------|
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2007 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4L LG1 Euro 3 | Version Information | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4L LG1 Euro 3 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4L LG1 Euro 3 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4L LG1 Euro 3 | Actuation Test | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | V6 Engine | Version Information | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | V6 Engine | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | V6 Engine | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | V6 Engine | Actuation Test | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | XL L4 HV240 | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | XL L4 HV240 | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4JA1-TC Bosch | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4JA1-TC Bosch | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4JA1-TC Bosch | Actuation Test | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4JA1-TC Bosch | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | 4JH1-TC Bosch | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | AT JR405E | Read/Clear DTC | |

| | | | | | | | | |
|---------|----------------|------|----|----|--------------|-----------------------------|---------------------|-----------------|
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | AT JR405E | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | AT JR405E | Actuation Test | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | AT JR405E | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | AW30-40LE | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | AW30-40LE | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | AW30-40LE | Actuation Test | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Engine | AW30-40LE | Special Function | Program VIN |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Transmission | Automatic Transmission | Version Information | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Transmission | Automatic Transmission | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Transmission | Automatic Transmission | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Transmission | Automatic Transmission | Actuation Test | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Chassis | ABS | Version Information | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Chassis | ABS(VPW) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Chassis | ABS(VPW) | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Chassis | ABS(VPW) | Actuation Test | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Airbag | Version Information | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Powertrain Interface Module | Version Information | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Powertrain Interface Module | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Powertrain Interface Module | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Powertrain Interface Module | Special Function | VIN Programming |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Anti Theft Warning | Version Information | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Anti Theft Warning | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Anti Theft Warning | Read Data Stream | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Airbag (VPW) | Read/Clear DTC | |
| JPISUZU | TF/UC Series | 2006 | -- | -- | Body | Airbag (VPW) | Read Data Stream | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4HV1<CNG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4HV1<CNG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4HV1<CNG> | Actuation Test | |

| | | | | | | | | |
|---------|-------------------------------------|------|----|----|--------------|-------------------------------|---------------------|-----------------------|
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4HV1<CNG> | Special Function | ECM DTC reading value |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4HG1<LPG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4HG1<LPG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4HG1<LPG> | Actuation Test | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4JG2<LPG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4JG2<LPG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4JG2<LPG> | Actuation Test | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4JG2 | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4JG2 | Read Data Stream | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4JG2 | Actuation Test | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | Hybrid System | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Engine | Hybrid System | Read Data Stream | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Transmission | Smoother/Smother-E Auto Shift | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Transmission | Smoother/Smother-E Auto Shift | Read Data Stream | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Transmission | Smoother-E | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2006 | -- | -- | Transmission | Smoother-E | Read Data Stream | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2006 | -- | -- | Chassis | ABS ASR ADVICS | Read/Clear DTC | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2006 | -- | -- | Chassis | ABS ASR ADVICS | Read Data Stream | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2006 | -- | -- | Chassis | ABS ASR ADVICS | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read/Clear DTC | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------|------------------------|---------------------|--|
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read Data Stream | |

| | | | | | | | | |
|---------|---------------------------------------|------|----|----|--------|------------------------|---------------------|----------------|
| JPISUZU | Off-Road Serial Industrial Engine | 2006 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 5L 4JK1-TC | Version Information | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 5L 4JK1-TC | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 5L 4JK1-TC | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 5L 4JK1-TC | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 5L 4JK1-TC | Special Function | ID Information |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 5L 4JK1-TC | Special Function | Snap Shot |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 0L 4JJ1-TC | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 0L 4JJ1-TC | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 0L 4JJ1-TC | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 0L 4JJ1-TC | Special Function | ID Information |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 0L 4JJ1-TC | Special Function | Snap Shot |

| | | | | | | | | |
|---------|---|------|----|----|--------|---------------|------------------|-------------|
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JH1-T Denso | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JH1-T Denso | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JH1-T Denso | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | XL L4 HV240 | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | XL L4 HV240 | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JA1-TC Bosch | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JA1-TC Bosch | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JA1-TC Bosch | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JA1-TC Bosch | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |

| | | | | | | | | |
|---------|---|------|----|----|---------|---------------|------------------|-------------|
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | 4JH1-TC Bosch | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | AT JR405E | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | AT JR405E | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | AT JR405E | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | AT JR405E | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | AW30-40LE | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | AW30-40LE | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | AW30-40LE | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Engine | AW30-40LE | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Chassis | ABS | Read/Clear DTC | |

| | | | | | | | | |
|---------|---|------|----|----|---------|--------------------------------|---------------------|--|
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Chassis | ABS(VPW) | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Chassis | ABS(VPW) | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Chassis | ABS(VPW) | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Body | Immobiliser(kwp D_MAX_IMMO) | Version Information | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Body | Immobiliser(kwp D_MAX_IMMO) | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Body | Immobiliser(kwp D_MAX_IMMO) | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Body | Airbag (VPW) | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2005 | -- | -- | Body | Airbag (VPW) | Read Data Stream | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4HV1<CNG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4HV1<CNG> | Read Data Stream | |

| | | | | | | | | |
|---------|--|------|----|----|--------------|----------------------------------|------------------|-----------------------|
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4HV1<CNG> | Actuation Test | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4HV1<CNG> | Special Function | ECM DTC reading value |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4HG1<LPG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4HG1<LPG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4HG1<LPG> | Actuation Test | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4JG2<LPG> | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4JG2<LPG> | Read Data Stream | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4JG2<LPG> | Actuation Test | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4JG2 | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4JG2 | Read Data Stream | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4JG2 | Actuation Test | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | MIMAMORI | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | MIMAMORI | Read Data Stream | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | MIMAMORI | Special Function | Reading memory |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | MIMAMORI | Special Function | Empty the memory |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | MIMAMORI | Special Function | ECM function |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | MIMAMORI | Special Function | Clear MIMAMORI data |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | Hybrid System | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Engine | Hybrid System | Read Data Stream | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Transmission | Smoothner/Smoothner-E Auto Shift | Read/Clear DTC | |
| JPISUZU | N Series Truck | 2005 | -- | -- | Transmission | Smoothner/Smoothner-E Auto Shift | Read Data Stream | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2005 | -- | -- | Transmission | AT Allison LCT | Read/Clear DTC | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2005 | -- | -- | Transmission | AT Allison LCT | Read Data Stream | |

| | | | | | | | | |
|---------|--|------|----|----|--------------|------------------------|---------------------|--|
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2005 | -- | -- | Transmission | AT Allison LCT | Actuation Test | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2005 | -- | -- | Chassis | ABS ASR ADVICS | Read/Clear DTC | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2005 | -- | -- | Chassis | ABS ASR ADVICS | Read Data Stream | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2005 | -- | -- | Chassis | ABS ASR ADVICS | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 4JJ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 4HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Read Data Stream | |

| | | | | | | | | |
|---------|-----------------------------------|------|----|----|--------|------------------------|---------------------|--|
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6HK1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6UZ1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Version Information | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read/Clear DTC | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Read Data Stream | |
| JPISUZU | Off-Road Serial Industrial Engine | 2005 | -- | -- | Engine | 6WG1-TC <C/Rail_Tier3> | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 2004 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 2004 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 2004 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 2004 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 2004 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 2004 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 2004 | -- | -- | Engine | 4JG2 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 2004 | -- | -- | Engine | 4JG2 | Read Data Stream | |

| | | | | | | | | |
|---------|---|------|----|----|---------|-------------|---------------------|----------------|
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2004 | -- | -- | Engine | 4JG2 | Actuation Test | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2004 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2004 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2004 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2004 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2004 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2004 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2004 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 5L 4JK1-TC | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 5L 4JK1-TC | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 5L 4JK1-TC | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 5L 4JK1-TC | Special Function | ID Information |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 5L 4JK1-TC | Special Function | Snap Shot |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 0L 4JJ1-TC | Read/Clear DTC | |

| | | | | | | | | |
|---------|---|------|----|----|--------|--------------|------------------|----------------|
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 0L 4J1-TC | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 0L 4J1-TC | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 0L 4J1-TC | Special Function | ID Information |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 0L 4J1-TC | Special Function | Snap Shot |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JH1-T Denso | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JH1-T Denso | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JH1-T Denso | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JG2 | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JG2 | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JG2 | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | XL L4 HV240 | Read/Clear DTC | |

| | | | | | | | | |
|---------|---|------|----|----|--------|---------------|------------------|-------------|
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | XL L4 HV240 | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JA1-TC Bosch | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JA1-TC Bosch | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JA1-TC Bosch | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JA1-TC Bosch | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | 4JH1-TC Bosch | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | AT JR405E | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | AT JR405E | Read Data Stream | |

| | | | | | | | | |
|---------|---|------|----|----|---------|-----------|------------------|-------------|
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | AT JR405E | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | AT JR405E | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | AW30-40LE | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | AW30-40LE | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | AW30-40LE | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Engine | AW30-40LE | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Chassis | ABS(VPW) | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Chassis | ABS(VPW) | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Chassis | ABS(VPW) | Actuation Test | |

| | | | | | | | | |
|---------|---|------|----|----|--------|--------------|---------------------|--|
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Body | Immobiliser | Version Information | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Body | Immobiliser | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Body | Airbag (VPW) | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2004 | -- | -- | Body | Airbag (VPW) | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, <VP> | 2004 | -- | -- | Engine | 4HF1<CNG> | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, <VP> | 2004 | -- | -- | Engine | 4HF1<CNG> | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, <VP> | 2004 | -- | -- | Engine | 4HF1<CNG> | Actuation Test | |
| JPISUZU | ELF,NPR,NOR, <VP> | 2004 | -- | -- | Engine | 4HG1<LPG> | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, <VP> | 2004 | -- | -- | Engine | 4HG1<LPG> | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, <VP> | 2004 | -- | -- | Engine | 4HG1<LPG> | Actuation Test | |
| JPISUZU | ELF,NPR,NOR, <VP> | 2004 | -- | -- | Engine | 4JG2<LPG> | Read/Clear DTC | |

| | | | | | | | | |
|---------|---------------------|------|----|----|---------|---------------|------------------|---------------------|
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | 4JG2<LPG> | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | 4JG2<LPG> | Actuation Test | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | 4JG2 | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | 4JG2 | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | 4JG2 | Actuation Test | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | MIMAMORI | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | MIMAMORI | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | MIMAMORI | Special Function | Reading memory |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | MIMAMORI | Special Function | Empty the memory |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | MIMAMORI | Special Function | ECM function |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | MIMAMORI | Special Function | Clear MIMAMORI data |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | Hybrid System | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Engine | Hybrid System | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, VFP | 2004 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |

| | | | | | | | | |
|---------|-------------------------------------|------|----|----|--------------|--------------------------------|------------------|--|
| JPISUZU | <N> ELF,NPR,NOR, | 2004 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | <N> ELF,NPR,NOR, | 2004 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | <N> ELF,NPR,NOR, | 2004 | -- | -- | Transmission | Smoother/Smoother-E Auto Shift | Read/Clear DTC | |
| JPISUZU | <N> ELF,NPR,NOR, | 2004 | -- | -- | Transmission | Smoother/Smoother-E Auto Shift | Read Data Stream | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2004 | -- | -- | Transmission | AT Allison LCT | Read/Clear DTC | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2004 | -- | -- | Transmission | AT Allison LCT | Read Data Stream | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2004 | -- | -- | Transmission | AT Allison LCT | Actuation Test | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2004 | -- | -- | Chassis | ABS ASR ADVICS | Read/Clear DTC | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2004 | -- | -- | Chassis | ABS ASR ADVICS | Read Data Stream | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2004 | -- | -- | Chassis | ABS ASR ADVICS | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2003 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2003 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2003 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2003 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------------------------|------|----|----|---------|-------------|------------------|--|
| JPISUZU | (UB) Trooper, Bighorn | 2003 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2003 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2003 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2003 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2003 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2003 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2003 | -- | -- | Body | Immobiliser | Read/Clear DTC | |

| | | | | | | | | |
|---------|---|------|----|----|---------|---------------------|------------------|--|
| JPISUZU | (OE) Rodeo/Amigo, Wizzard/M411 | 2003 | -- | -- | Body | Immobiliser | Read Data Stream | |
| JPISUZU | (UP) Axiom | 2003 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | (UP) Axiom | 2003 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UP) Axiom | 2003 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (UP) Axiom | 2003 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (UP) Axiom | 2003 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UP) Axiom | 2003 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | D-MAX(4JH1-T Denso) | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | D-MAX(4JH1-T Denso) | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | D-MAX(4JH1-T Denso) | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | XL L4 HV240 | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | XL L4 HV240 | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | XL L4 HV240 | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | 4JA1-TC Bosch | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | 4JA1-TC Bosch | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | 4JA1-TC Bosch | Actuation Test | |

| | | | | | | | | |
|---------|---|------|----|----|--------|---------------|------------------|-------------|
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | 4JA1-TC Bosch | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | 4JH1-TC Bosch | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | AT JR405E | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | AT JR405E | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | AT JR405E | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | AT JR405E | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | AW30-40LE | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | AW30-40LE | Read Data Stream | |

| | | | | | | | | |
|---------|---|------|----|----|---------|--------------|------------------|-------------|
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | AW30-40LE | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Engine | AW30-40LE | Special Function | Program VIN |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Chassis | ABS(VPW) | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Chassis | ABS(VPW) | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Chassis | ABS(VPW) | Actuation Test | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Body | Airbag | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Body | Airbag | Read Data Stream | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Body | Airbag (VPW) | Read/Clear DTC | |
| JPISUZU | (TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo | 2003 | -- | -- | Body | Airbag (VPW) | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, VEP | 2003 | -- | -- | Engine | 4JG2 | Read/Clear DTC | |

| | | | | | | | | |
|---------|--|------|----|----|--------------|------------------------|------------------|--|
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Engine | 4JG2 | Read Data Stream | |
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Engine | 4JG2 | Actuation Test | |
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Chassis | Cultch free system/HSA | Read/Clear DTC | |
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Chassis | Cultch free system/HSA | Read Data Stream | |
| JPISUZU | <N> ELF,NPR,NOR, VFP> | 2003 | -- | -- | Chassis | Cultch free system/HSA | Actuation Test | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2003 | -- | -- | Transmission | AT Allison LCT | Read/Clear DTC | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2003 | -- | -- | Transmission | AT Allison LCT | Read Data Stream | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2003 | -- | -- | Transmission | AT Allison LCT | Actuation Test | |
| JPISUZU | (TBR) | 2003 | -- | -- | Engine | XL L4 HV240 | Read/Clear DTC | |
| JPISUZU | (TBR) | 2003 | -- | -- | Engine | XL L4 HV240 | Read Data Stream | |
| JPISUZU | (TBR) | 2003 | -- | -- | Engine | XL L4 HV240 | Actuation Test | |

| | | | | | | | | |
|---------|------------------------------------|------|----|----|--------|-------------|------------------|--|
| JPISUZU | (UB) Trooper, Bighorn | 2002 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2002 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2002 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2002 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2002 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2002 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2002 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2002 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2002 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2002 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 2L L4 X22SE | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 2L L4 X22SE | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 2L L4 X22SE | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |

| | | | | | | | | |
|---------|---------------------------------------|------|----|----|---------|---------------------|------------------|--|
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2002 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UP) Axiom | 2002 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | (UP) Axiom | 2002 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UP) Axiom | 2002 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (UP) Axiom | 2002 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (UP) Axiom | 2002 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UP) Axiom | 2002 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | TF/UC Thailand | 2002 | -- | -- | Engine | 4JH1-T Denso | Read/Clear DTC | |
| JPISUZU | TF/UC Thailand | 2002 | -- | -- | Engine | 4JH1-T Denso | Read Data Stream | |
| JPISUZU | TF/UC Thailand | 2002 | -- | -- | Engine | 4JH1-T Denso | Actuation Test | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | D-MAX(4JH1-T Denso) | Read/Clear DTC | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | D-MAX(4JH1-T Denso) | Read Data Stream | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | D-MAX(4JH1-T Denso) | Actuation Test | |

| | | | | | | | | |
|---------|---------------------------------------|------|----|----|--------|--------------------|------------------|--|
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 4ZE1 | Read/Clear DTC | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 4ZE1 | Read Data Stream | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 0L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 0L L4 SOHC | Read Data Stream | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 0L L4 SOHC | Actuation Test | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 2L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 2L L4 SOHC | Read Data Stream | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 2L L4 SOHC | Actuation Test | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Actuation Test | |

| | | | | | | | | |
|---------|---------------------------------------|------|----|----|--------|---------------|------------------|-------------|
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 4JA1-TC Bosch | Read/Clear DTC | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 4JA1-TC Bosch | Read Data Stream | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 4JA1-TC Bosch | Actuation Test | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 4JA1-TC Bosch | Special Function | Program VIN |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | 4JH1-TC Bosch | Special Function | Program VIN |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | AT JR405E | Read/Clear DTC | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | AT JR405E | Read Data Stream | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | AT JR405E | Actuation Test | |

| | | | | | | | | |
|---------|--|------|----|----|--------------|------------------------|------------------|-------------|
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Engine | AT JR405E | Special Function | Program VIN |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (TF/UC) LUV,Frontier, LAO-Rodeo | 2002 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | <N> ELF,NPR,NOR, <FP> | 2002 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, <FP> | 2002 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, <FP> | 2002 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | ELF,NPR,NOR, <FP> | 2002 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, <FP> | 2002 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, <FP> | 2002 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF,NPR,NOR, <FP> | 2002 | -- | -- | Chassis | Cultch free system/HSA | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, <FP> | 2002 | -- | -- | Chassis | Cultch free system/HSA | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, <FP> | 2002 | -- | -- | Chassis | Cultch free system/HSA | Actuation Test | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2002 | -- | -- | Transmission | AT Allison LCT | Read/Clear DTC | |
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2002 | -- | -- | Transmission | AT Allison LCT | Read Data Stream | |

| | | | | | | | | |
|---------|--|------|----|----|--------------|----------------|------------------|--|
| JPISUZU | <C*,E*,L*,F*> Heavy, Medium Duty | 2002 | -- | -- | Transmission | AT Allison LCT | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2001 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2001 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2001 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2001 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2001 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2001 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2001 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2001 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2001 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2001 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2001 | -- | -- | Engine | 2L L4 X22SE | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2001 | -- | -- | Engine | 2L L4 X22SE | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2001 | -- | -- | Engine | 2L L4 X22SE | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2001 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2001 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2001 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |

| | | | | | | | | |
|---------|------------------------------------|------|----|----|---------|--------------------|------------------|--|
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2001 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2001 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2001 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2001 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2001 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2001 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 2001 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2001 | -- | -- | Engine | 4ZE1 | Read/Clear DTC | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2001 | -- | -- | Engine | 4ZE1 | Read Data Stream | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2001 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2001 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2001 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Actuation Test | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2001 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2001 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 0L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 0L L4 SOHC | Read Data Stream | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 0L L4 SOHC | Actuation Test | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 2L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 2L L4 SOHC | Read Data Stream | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 2L L4 SOHC | Actuation Test | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |

| | | | | | | | | |
|---------|-----------------------------|------|----|----|---------|--------------------|------------------|-------------|
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Actuation Test | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 4JA1-TC Bosch | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 4JA1-TC Bosch | Read Data Stream | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 4JA1-TC Bosch | Actuation Test | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 4JA1-TC Bosch | Special Function | Program VIN |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Special Function | Program VIN |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 2001 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | TF/UC Thailand | 2001 | -- | -- | Engine | D-MAX | Read/Clear DTC | |
| JPISUZU | TF/UC Thailand | 2001 | -- | -- | Engine | D-MAX | Read Data Stream | |
| JPISUZU | TF/UC Thailand | 2001 | -- | -- | Engine | D-MAX | Actuation Test | |
| JPISUZU | (TBR) | 2001 | -- | -- | Engine | 0L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TBR) | 2001 | -- | -- | Engine | 0L L4 SOHC | Read Data Stream | |
| JPISUZU | (TBR) | 2001 | -- | -- | Engine | 0L L4 SOHC | Actuation Test | |
| JPISUZU | (TBR) | 2001 | -- | -- | Engine | 2L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TBR) | 2001 | -- | -- | Engine | 2L L4 SOHC | Read Data Stream | |
| JPISUZU | (TBR) | 2001 | -- | -- | Engine | 2L L4 SOHC | Actuation Test | |
| JPISUZU | ELF,NPR,NOR, <N> <FP> | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, <N> <FP> | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, <N> <FP> | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | ELF,NPR,NOR, <N> <FP> | 2001 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | ELF,NPR,NOR, <N> <FP> | 2001 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | ELF,NPR,NOR, <N> <FP> | 2001 | -- | -- | Chassis | ABS/ASR | Actuation Test | |

| | | | | | | | | |
|---------|--|------|----|----|--------|--------------------|------------------|-------------|
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2001 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2001 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2001 | -- | -- | Engine | 4JA1-TC Bosch | Read/Clear DTC | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2001 | -- | -- | Engine | 4JA1-TC Bosch | Read Data Stream | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2001 | -- | -- | Engine | 4JA1-TC Bosch | Actuation Test | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2001 | -- | -- | Engine | 4JA1-TC Bosch | Special Function | Program VIN |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Read/Clear DTC | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Read Data Stream | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Actuation Test | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2001 | -- | -- | Engine | 4JH1-TC Bosch | Special Function | Program VIN |
| JPISUZU | <UG> V-Cross | 2001 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | <UG> V-Cross | 2001 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | <UG> V-Cross | 2001 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | <UG> V-Cross | 2001 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | <UG> V-Cross | 2001 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |

| | | | | | | | | |
|---------|---------------------------------|------|----|----|--------|-------------|------------------|--|
| JPISUZU | <UG> V-Cross | 2001 | -- | -- | Engine | 5L V6 6VE1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2000 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2000 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2000 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2000 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2000 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2000 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 2000 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2000 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 2000 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 2000 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2000 | -- | -- | Engine | 2L L4 X22SE | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2000 | -- | -- | Engine | 2L L4 X22SE | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2000 | -- | -- | Engine | 2L L4 X22SE | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2000 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2000 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2000 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Wizard/MLU | 2000 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------------------------|------|----|----|---------|--------------------|------------------|--|
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2000 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2000 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2000 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2000 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2000 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 2000 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UG) V-Cross | 2000 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UG) V-Cross | 2000 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UG) V-Cross | 2000 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UG) V-Cross | 2000 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | (UG) V-Cross | 2000 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UG) V-Cross | 2000 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UG) V-Cross | 2000 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2000 | -- | -- | Engine | 4ZE1 | Read/Clear DTC | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2000 | -- | -- | Engine | 4ZE1 | Read Data Stream | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2000 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2000 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2000 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Actuation Test | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2000 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 2000 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (TF) LUV | 2000 | -- | -- | Engine | 0L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 2000 | -- | -- | Engine | 0L L4 SOHC | Read Data Stream | |

| | | | | | | | | |
|---------|---|------|----|----|---------|------------------------|------------------|--|
| JPISUZU | (TF) LUV | 2000 | -- | -- | Engine | 0L L4 SOHC | Actuation Test | |
| JPISUZU | (TF) LUV | 2000 | -- | -- | Engine | 2L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 2000 | -- | -- | Engine | 2L L4 SOHC | Read Data Stream | |
| JPISUZU | (TF) LUV | 2000 | -- | -- | Engine | 2L L4 SOHC | Actuation Test | |
| JPISUZU | (TF) LUV | 2000 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 2000 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | (TF) LUV | 2000 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Actuation Test | |
| JPISUZU | (TF) LUV | 2000 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 2000 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (TBR) | 2000 | -- | -- | Engine | 0L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TBR) | 2000 | -- | -- | Engine | 0L L4 SOHC | Read Data Stream | |
| JPISUZU | (TBR) | 2000 | -- | -- | Engine | 0L L4 SOHC | Actuation Test | |
| JPISUZU | (TBR) | 2000 | -- | -- | Engine | 2L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TBR) | 2000 | -- | -- | Engine | 2L L4 SOHC | Read Data Stream | |
| JPISUZU | (TBR) | 2000 | -- | -- | Engine | 2L L4 SOHC | Actuation Test | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 2000 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 2000 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 2000 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 2000 | -- | -- | Chassis | Cultch free system/HSA | Read/Clear DTC | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 2000 | -- | -- | Chassis | Cultch free system/HSA | Read Data Stream | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 2000 | -- | -- | Chassis | Cultch free system/HSA | Actuation Test | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2000 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 2000 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |

| | | | | | | | | |
|---------|------------------------------------|------|----|----|--------|-------------|------------------|--|
| JPISUZU | (UB) Trooper, Bighorn | 1999 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 1999 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 1999 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 1999 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 1999 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 1999 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 1999 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 1999 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 1999 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 1999 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Engine | 2L L4 X22SE | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Engine | 2L L4 X22SE | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Engine | 2L L4 X22SE | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |

| | | | | | | | | |
|---------|------------------------------------|------|----|----|---------|--------------------|------------------|--|
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (OE) Rodeo/Amigo, Winged/AMU | 1999 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UG) V-Cross | 1999 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UG) V-Cross | 1999 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UG) V-Cross | 1999 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UG) V-Cross | 1999 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | (UG) V-Cross | 1999 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UG) V-Cross | 1999 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UG) V-Cross | 1999 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 1999 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 1999 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | (UC) Frontier ,LAO- Rodeo | 1999 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Actuation Test | |
| JPISUZU | (TF) LUV | 1999 | -- | -- | Engine | 0L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 1999 | -- | -- | Engine | 0L L4 SOHC | Read Data Stream | |
| JPISUZU | (TF) LUV | 1999 | -- | -- | Engine | 0L L4 SOHC | Actuation Test | |
| JPISUZU | (TF) LUV | 1999 | -- | -- | Engine | 2L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 1999 | -- | -- | Engine | 2L L4 SOHC | Read Data Stream | |
| JPISUZU | (TF) LUV | 1999 | -- | -- | Engine | 2L L4 SOHC | Actuation Test | |
| JPISUZU | (TF) LUV | 1999 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 1999 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | (TF) LUV | 1999 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Actuation Test | |
| JPISUZU | (TBR) | 1999 | -- | -- | Engine | 2L L4 SOHC | Read/Clear DTC | |

| | | | | | | | | |
|---------|--------------------------|------|----|----|---------|------------------------|------------------|--|
| JPISUZU | (TBR) | 1999 | -- | -- | Engine | 2L L4 SOHC | Read Data Stream | |
| JPISUZU | (TBR) | 1999 | -- | -- | Engine | 2L L4 SOHC | Actuation Test | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 1999 | -- | -- | Chassis | ABS/ASR | Read/Clear DTC | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 1999 | -- | -- | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 1999 | -- | -- | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 1999 | -- | -- | Chassis | Cultch free system/HSA | Read/Clear DTC | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 1999 | -- | -- | Chassis | Cultch free system/HSA | Read Data Stream | |
| JPISUZU | <N*>ELF,NPR, NOR,VFR | 1999 | -- | -- | Chassis | Cultch free system/HSA | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Engine | 5L V6 6VE1 | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Engine | 5L V6 6VE1 | Read Data Stream | |
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Engine | 40L30E | Read/Clear DTC | |
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Engine | 40L30E | Read Data Stream | |

| | | | | | | | | |
|---------|-----------------------------|------|----|----|---------|--------------------|------------------|--|
| JPISUZU | (UB) Trooper, Bighorn | 1998 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 2L L4 X22SE | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 2L L4 X22SE | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 2L L4 X22SE | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 0L L4 4JX1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 0L L4 4JX1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 0L L4 4JX1 | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 40L30E | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 40L30E | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 2L V6 6VD1 | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 2L V6 6VD1 | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Engine | 2L V6 6VD1 | Actuation Test | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Chassis | ABS | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Chassis | ABS | Read Data Stream | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Body | AirBag | Read/Clear DTC | |
| JPISUZU | (UE) Rodeo/Amigo, Wipac/AMU | 1998 | -- | -- | Body | AirBag | Read Data Stream | |
| JPISUZU | (UC) Frontier, LAO-Rodeo | 1998 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |

| | | | | | | | | |
|---------|--|------|--------|---------|--------|------------------------|-----------------------|--|
| JPISUZU | (UC) Frontier, LAO-Rodeo | 1998 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | (UC) Frontier, LAO-Rodeo | 1998 | -- | -- | Engine | 40L30E | Read/Clear DTC | |
| JPISUZU | (UC) Frontier, LAO-Rodeo | 1998 | -- | -- | Engine | 40L30E | Read Data Stream | |
| JPISUZU | (TF) LUV | 1998 | -- | -- | Engine | 0L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 1998 | -- | -- | Engine | 0L L4 SOHC | Read Data Stream | |
| JPISUZU | (TF) LUV | 1998 | -- | -- | Engine | 0L L4 SOHC | Actuation Test | |
| JPISUZU | (TF) LUV | 1998 | -- | -- | Engine | 2L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 1998 | -- | -- | Engine | 2L L4 SOHC | Read Data Stream | |
| JPISUZU | (TF) LUV | 1998 | -- | -- | Engine | 2L L4 SOHC | Actuation Test | |
| JPISUZU | (TF) LUV | 1998 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | (TF) LUV | 1998 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 1998 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read/Clear DTC | |
| JPISUZU | <TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo | 1998 | -- | -- | Engine | 2L V6 6VD1 Hitachi | Read Data Stream | |
| JPISUZU | (TBR) | 1998 | -- | -- | Engine | 2L L4 SOHC | Read/Clear DTC | |
| JPISUZU | (TBR) | 1998 | -- | -- | Engine | 2L L4 SOHC | Read Data Stream | |
| JPISUZU | (TBR) | 1998 | -- | -- | Engine | 2L L4 SOHC | Actuation Test | |
| JPISUZU | (N*) ELF,NPR,NOR,VFR | 1998 | -- | -- | Body | Cultch free system/HSA | Read/Clear DTC | |
| JPISUZU | (N*) ELF,NPR,NOR,VFR | 1998 | -- | -- | Body | Cultch free system/HSA | Read Data Stream | |
| JPISUZU | (N*) ELF,NPR,NOR,VFR | 1998 | -- | -- | Body | Cultch free system/HSA | Actuation Test | |
| JPISUZU | (N*) ELF,NPR,NOR,VFR | 1998 | -- | -- | Body | Airbag SRS | Read/Clear DTC | |
| JPISUZU | (N*) ELF,NPR,NOR,VFR | 1998 | -- | -- | Body | Airbag SRS | Read Data Stream | |
| JPISUZU | N-Series | 2010 | MLD-6Q | China 2 | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2010 | MLD-6Q | China 2 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|---------|---------|--------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2010 | MLD-6Q | China 2 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2010 | MLD-6Q | China 2 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2010 | MLD-6Q | China 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2010 | MLD-6Q | China 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2010 | MLD-6Q | China 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2010 | MLD-6Q | China 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2010 | MLD-6Q | China 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2010 | MLD-6Q | China 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Module Information | |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Actuation Test | |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Special Function | PTO Use Mode |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Special Function | PTO Selector Switch |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | N-Series | 2012 | MSB-5BS | China 2 | Engine | 4KH1 | Special Function | CAB Select |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Module Information | |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Actuation Test | |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Special Function | PTO Use Mode |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Special Function | PTO Selector Switch |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | N-Series | 2012 | MSB-5SC | China 2 | Engine | 4KH1 | Special Function | CAB Select |
| JPISUZU | F-Series | 2012 | MLD-6Q | China 2 | Engine | 6HK1-TC (C/Rail) | Module Information | |

| | | | | | | | | |
|---------|------------|------|----------|---------|-------------|------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2012 | MLD-6Q | China 2 | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MLD-6Q | China 2 | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2012 | MLD-6Q | China 2 | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2012 | MLD-6Q | China 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2012 | MLD-6Q | China 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2012 | MLD-6Q | China 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2012 | MLD-6Q | China 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2012 | MLD-6Q | China 2 | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2012 | 9JS11PTA | China 2 | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2012 | 9JS11PTA | China 2 | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | 9JS11PTA | China 2 | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2012 | 9JS11PTA | China 2 | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2012 | 9JS11PTA | China 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2012 | 9JS11PTA | China 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2012 | 9JS11PTA | China 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2012 | 9JS11PTA | China 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2012 | 9JS11PTA | China 2 | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Engine | 6WG1 | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | MIMAMORI | Special Function | EDR Function |

| | | | | | | | | |
|---------|------------|------|--------------|---------|-------------|---------------------|-----------------------|-------------------------------------|
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2013 | MJT | China 2 | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Engine | 6WG1 | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------------|------|--------------|---------|-------------|---------------------|-----------------------|------------------------------------|
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------------|------|----------------|---------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2013 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Engine | 6UZ1 | Special Function | Injector Quantity Trim |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FXFYGX Series | 2014 | 9JS150TA -B | China 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Engine | 6UZ1 | Read Data Strem | |

| | | | | | | | | |
|---------|---------------|------|-----|---------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Engine | 6UZ1 | Special Function | Injector Quantity Trim |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FXFYGX Series | 2014 | 0 | China 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | N-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | N-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | N-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Module Information | |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Actuation Test | |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Special Function | PTO Use Mode |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Special Function | PTO Selector Switch |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | N-Series | 2016 | MSB | China 2 | Engine | 4KH1 | Special Function | CAB Select |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|------------------|---------|--------|---------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 4HK1-TC | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2016 | MLD | China 2 | Engine | 6HK1-TC | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Special Function | DPD Dilution Trip Data Reset |

| | | | | | | | | |
|---------|------------|------|------------------|---------|-------------|---------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2016 | FAST9JS1 19GA | China 2 | Engine | 6HK1-TC | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Engine | 6WG1 | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJT | China 2 | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Engine | 6WG1 | Module Information | |

| | | | | | | | | |
|---------|------------|------|--------------|---------|-------------|------------|-----------------------|------------------------|
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Engine | 6WG1 | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | DRM Function |

| | | | | | | | | |
|---------|------------|------|---------------|---------|-------------|---------------------|-----------------------|-------------------------------------|
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2016 | MJX16 CN2 | China 2 | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Engine | 6WG1 | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|---------------|---------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Engine | 6WG1 | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Engine | 6WG1 | Special Function | Exchange ECM |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Engine | Urea SCR | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Engine | Urea SCR | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Body | Meter | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | C&E Series | 2017 | ZF8S223 OT | China 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|------------|------|---------------|---------|-------------|---------------------|-----------------------|-------------------------------------|
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | MIMAMORI | Special Function | EOL Data Setting/Change |

| | | | | | | | | |
|---------|------------|------|----------------|---------|-------------|----------------------------|-----------------------|------------------------|
| JPISUZU | C&E Series | 2017 | ZF8S223 0T | China 2 | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | 6WG1 | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | 6WG1 | Special Function | Exchange ECM |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | Urea SCR | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Engine | Urea SCR | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Body | Meter | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | Speedometer Control Device | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|----------------|---------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | MIMAMORI | Special Function | EDR Function |

| | | | | | | | | |
|---------|------------|------|----------------|---------|-------------|----------|-----------------------|-----------------------------|
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | C&E Series | 2017 | ZF16S22 30T | China 2 | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | 6UZ1 | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | 6UZ1 | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | 6UZ1 | Special Function | Exchange ECM |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | Urea SCR | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | Urea SCR | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|---------------|---------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Engine | Urea SCR | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Body | Meter | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | MIMAMORI | Module Information | |

| | | | | | | | | |
|---------|------------|------|----------------|---------|-------------|----------|-----------------------|-----------------------------|
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | C&E Series | 2017 | ZF8S203 0T | China 2 | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | 6UZ1 | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | 6UZ1 | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | 6UZ1 | Special Function | Program VIN |

| | | | | | | | | |
|---------|------------|------|----------------|---------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | 6UZ1 | Special Function | Exchange ECM |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | Urea SCR | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Engine | Urea SCR | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Body | Meter | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |

| | | | | | | | | |
|---------|------------|------|----------------|---------|-------------|---------------------|-----------------------|-------------------------------------|
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | C&E Series | 2017 | ZF16S20 30T | China 2 | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Engine | Urea SCR | Module Information | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|-----|---------|--------------|--|-----------------------|-------------------------------------|
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2017 | MJT | China 2 | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------|--------------|--|-----------------------|---|
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2014 | MUA | China 3 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Transmission | AT | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|---------|--------------|--|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|---------|---------|--------------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2014 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Meter | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|---------|---------|--|-----------------------|---|
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Engine | 4JJ1 | Special Function | Program VIN |

| | | | | | | | | |
|---------|-----------|------|-----|---------|--------------|--|-----------------------|---|
| JPISUZU | UC Series | 2015 | MUX | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |

| | | | | | | | | |
|---------|-----------|------|---------|---------|--------------|-------------|-----------------------|--|
| JPISUZU | UC Series | 2015 | MUX | China 3 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2015 | MUX | China 3 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | BCM | Special Function | BCM Data Download |

| | | | | | | | | |
|---------|-----------|------|---------|---------|--------------|--|-----------------------|---|
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2015 | TB-50LS | China 3 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|---------|--------------|--|-----------------------|---|
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2015 | MUA | China 3 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Transmission | TCCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------|--------------|--|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MVL | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | BCM | Special Function | BCM Data Download |

| | | | | | | | | |
|---------|-----------|------|-----|---------|--------------|----------------------------------|-----------------------|---|
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | SRS(Denso) | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | China 3 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | ISS | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | ISS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | ISS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Transmission | AT | Special Function | Program VIN |

| | | | | | | | | |
|---------|-----------|------|-------------|---------|--------------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | 5 | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | SRS(Denso) | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Body | SRS(Denso) | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|---------|--------------|--|-----------------------|---|
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | China 3 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------|---------|--|-----------------------|---|
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | SRS(Denso) | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | MVL | China 3 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---|---------|--------------|--|-----------------------|-----------------------------------|
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | ISS | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | ISS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | ISS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-------------|---------|--------------|---|-----------------------|---|
| JPISUZU | UC Series | 2017 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | SRS(Denso) | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | 5 | China 3 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------|--------------|--|-----------------------|--|
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | SRS(Denso) | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | ISS | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | ISS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | ISS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | TCCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS(Denso) | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | ISS | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | ISS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | ISS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | RZ4E | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | RZ4E | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---|---------|--------------|--|-----------------------|-------------------------------|
| JPISUZU | UC Series | 2018 | 5 | China 3 | Engine | RZ4E | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS(Denso) | Module Information | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|------------|------|-------|------------------|---------|------------------|-----------------------|--------------------|
| JPISUZU | UC Series | 2018 | 5 | China 3 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | 5 | China 3 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Engine | 6WF1-TC (C/Rail) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Engine | 6WF1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Engine | 6WF1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Engine | 6WF1-TC (C/Rail) | Special Function | Fuel Delivery Rate |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Engine | 6WF1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | General Export 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Engine | 6WF1-TC (C/Rail) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Engine | 6WF1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Engine | 6WF1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Engine | 6WF1-TC (C/Rail) | Special Function | Fuel Delivery Rate |

| | | | | | | | | |
|---------|------------|------|-------|------------------|---------|------------------|-----------------------|------------------|
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Engine | 6WF1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 | General Export 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|-----|------------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|------------|------|-----|------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|------------|------|-----|------------------|---------|-------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|-----|------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |

| | | | | | | | | |
|---------|------------|------|-----|------------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------------|------|------------------|------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | MZW | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Engine | 6HK1-TC | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-------------------------|---------------------|--------|---------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Body | BCM | Special Function | ECU Lock |

| | | | | | | | | |
|---------|------------|------|------------------|------------------|---------|-------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|------------------|------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |

| | | | | | | | | |
|---------|------------|------|-------------------------|---------------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | Vehicle Information |

| | | | | | | | | |
|---------|------------|------|--------------|---------------------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Information | Speedometer Control Device | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|--------------|---------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | ECU Replacement |

| | | | | | | | | |
|---------|------------|------|--------------|---------------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Chassis | ABS/ASR | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|------------------|---------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|------------|------|------------------|---------------------|---------|-------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|------------------|---------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------------|--------------|-------------|-----------------------|-----------------------------|
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Transmission | AT(Allison) | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Transmission | AT(Allison) | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Transmission | AT(Allison) | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Transmission | AT(Allison) | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Transmission | AT(Allison) | Special Function | Clear Basic Learn Values |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Transmission | AT(Allison) | Special Function | Clear Variable Learn Values |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Module Information | |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Actuation Test | |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Special Function | PTO Throttle 100Voltage |

| | | | | | | | | |
|---------|----------|------|--------|------------------|--------|------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Special Function | PTO Use Mode |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Special Function | PTO Selector Switch |
| JPISUZU | N-Series | 2014 | MSB | General Export 1 | Engine | 4JH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Module Information | |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Read/Clear Fault Code | |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Read Data Strem | |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Actuation Test | |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Special Function | Program VIN |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Special Function | Injector ID Code |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Special Function | PTO Use Mode |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Special Function | PTO Selector Switch |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 1 | Engine | 4JH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Module Information | |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|-----|------------------|--------|-------------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Actuation Test | |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Special Function | PTO Use Mode |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Special Function | PTO Selector Switch |
| JPISUZU | N-Series | 2015 | MSB | General Export 1 | Engine | 4JH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-----|------------------|---------|-------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-----|------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | MZZ | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|-----|------------------|---------|-------------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|-----|------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |

| | | | | | | | | |
|---------|------------|------|-----|------------------|--------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |

| | | | | | | | | |
|---------|------------|------|------------------|------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | MZW | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Engine | 6HK1-TC | Module Information | |

| | | | | | | | | |
|---------|------------|------|------------------|------------------|--------|---------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|------------------|------------------|------|-----|------------------|--|
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Body | BCM | Special Function | All Accumulation Data Clearing |

| | | | | | | | | |
|---------|------------|------|------------------|------------------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|------------|------|------------------|------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | General Export 2 | Body | BCM | Special Function | ECU Replacement |

| | | | | | | | | |
|---------|------------|------|--------------|---------------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Chassis | ABS/ASR | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|--------------|---------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|------------|------|--------------|---------------------|---------|-------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|------------------|---------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | ZF6S100 0 | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |

| | | | | | | | | |
|---------|------------|------|------------------|---------------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------------|------|------------------|---------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | Fuller FS8209 | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Engine | 6HK1-TC | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------------|--------------|-------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Transmission | AT(Allison) | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Transmission | AT(Allison) | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Transmission | AT(Allison) | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Transmission | AT(Allison) | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Transmission | AT(Allison) | Special Function | Clear Basic Learn Values |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Transmission | AT(Allison) | Special Function | Clear Variable Learn Values |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | Program VIN |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Information | Speedometer Control Device | Module Information | |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | Allison 2500 | General Export 2 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Module Information | |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Actuation Test | |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Special Function | PTO Use Mode |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Special Function | PTO Selector Switch |
| JPISUZU | N-Series | 2014 | MSB | General Export 2 | Engine | 4JH1 | Special Function | Tachometer Pulse Count |

| | | | | | | | | |
|---------|----------|------|--------|------------------|--------|------|-----------------------|----------------------------------|
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Module Information | |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Read/Clear Fault Code | |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Read Data Strem | |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Actuation Test | |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Special Function | Program VIN |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Special Function | Injector ID Code |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Special Function | PTO Use Mode |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Special Function | PTO Selector Switch |
| JPISUZU | Q Series | 2014 | MSB-5S | General Export 2 | Engine | 4JH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Module Information | |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Actuation Test | |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Special Function | Program VIN |

| | | | | | | | | |
|---------|----------|------|-----------|------------------|--------|----------------------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Special Function | PTO Use Mode |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Special Function | PTO Selector Switch |
| JPISUZU | N-Series | 2015 | MSB | General Export 2 | Engine | 4JH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|----------------------|-----------------------|--|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | PTO Requested Engine Speed |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Speedometer Gear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Size |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Compensation |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Final Gear Ratio |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program ABS Install |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program VIN |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|-------------|-----------------------|------------------------------|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|----------------------|-----------------------|----------------------------|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |

| | | | | | | | | |
|---------|-----|------|-----|-------|--------|----------------------|-----------------------|--|
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|------|-------|-------------|----------------------|-----------------------|--|
| JPISUZU | ELF | 2007 | MYY | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2007 | MYY | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |

| | | | | | | | | |
|---------|-----|------|------|-------|--------------|-------------------|-----------------------|-------------------------------------|
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2007 | A460 | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2007 | A460 | Japan | Transmission | AT A460 | Module Information | |
| JPISUZU | ELF | 2007 | A460 | Japan | Transmission | AT A460 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | A460 | Japan | Transmission | AT A460 | Read Data Strem | |
| JPISUZU | ELF | 2007 | A460 | Japan | Transmission | AT A460 | Actuation Test | |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | A460 | Japan | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|----------------------|-----------------------|------------------------------|
| JPISUZU | ELF | 2007 | A460 | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2007 | A460 | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | A460 | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2007 | A460 | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2007 | A460 | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |
| JPISUZU | ELF | 2007 | A460 | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | MAF Compensation |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|----------------------|-----------------------|--|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-------------|-----------------------|----------------------------------|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | PTO Requested Engine Speed |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Speedometer Gear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Size |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Compensation |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Final Gear Ratio |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program ABS Install |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program VIN |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |

| | | | | | | | | |
|---------|-----|------|---------------|-------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|----------|-----------------------|------------------------------|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |

| | | | | | | | | |
|---------|-----|------|-----------|-------|-------------|----------------------|-----------------------|--|
| JPISUZU | ELF | 2007 | r-Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Fuel Data Display Clear |

| | | | | | | | | |
|---------|-----|------|----------|-------|-------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | ELF | 2007 | MY | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | MY | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | MY | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | ELF | 2007 | MY | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | ELF | 2007 | MY | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2007 | MY | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MY | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2007 | MY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2007 | MY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2007 | MY | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2007 | MY | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MY | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2007 | MY | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2007 | MY | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |
| JPISUZU | ELF | 2007 | MY | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | ELF | 2007 | r-Ex(MY) | Japan | Engine | 4HV1 CNG | Module Information | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Injection Learned Value |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | PTO Requested Engine Speed |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Speedometer Gear |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Size |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Compensation |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Final Gear Ratio |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program ABS Install |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program VIN |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|----------|-----------------------|-------------------------------|
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |
| JPISUZU | ELF | 2007 | r- Ex(MYY) | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Injection Learned Value |

| | | | | | | | | |
|---------|-----|------|-----|-------|---------|-------------------|-----------------------|-------------------------------------|
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2007 | MYY | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |
| JPISUZU | ELF | 2007 | MYY | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HF1 (CNG) | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HF1 (CNG) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HF1 (CNG) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Injection Learned Value |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HF1 (CNG) | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HF1 (CNG) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HF1 (CNG) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Injection Learned Value |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | ECU Lock |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZX) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZX) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZX) | Read Data Stream | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZW) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZW) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZW) | Read Data Stream | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZZ) | Module Information | |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|------------------|-----------------------|----------------------------------|
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZZ) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZZ) | Read Data Stream | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Read Data Stream | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|------|-------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------|-----------------------|------------------------------|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update AD Input |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|---------|------|-----|-------|---------|----------------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|---------|------|-----|-------|---------|----------------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|---------|------|---|-------|---------|----------------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|--------|----------------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Read Data Stream | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZX) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZX) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZX) | Read Data Stream | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZW) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZW) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|------------------|-----------------------|----------------------------------|
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZW) | Read Data Stream | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZZ) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZZ) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Transmission | Smoother-Fx(MZZ) | Read Data Stream | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Read Data Stream | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZX) | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|------|-------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------|-----------------------|------------------------------|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|--------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|----------------------------|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZX) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|--------------|----------------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZX) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZX) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZX) | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|------------------|-----------------------|------------------|
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZW) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZW) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZW) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZZ) | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZZ) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZZ) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoother-Fx (MZZ) | Japan | Body | BCM | Special Function | RKE Registration |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|------|-------------|--------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------|-----------------------|------------------------------|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|--------------------|-----------------------------------|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | Engne Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Engne Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | MZX | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |

| | | | | | | | | |
|---------|---------|------|----------------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2007 | MLD | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------|------------------------|-----------------------|--|
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program HW Number |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------|------------------|----------------------------|
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|------------------------|-----------------------|--|
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2007 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program HW Number |
| JPISUZU | GIGA | 2007 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | GIGA | 2007 | MAL | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2007 | MAL | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|---------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program HW Number |
| JPISUZU | GIGA | 2007 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | GIGA | 2007 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------------------|-----------------------|----------------------------|
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2007 | MJT | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------|------------------------|--------------------|----------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------------------------|--------------------|-----------------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Module Information | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------|-----------------------|----------------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------------------|-----------------------|--------------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------|------------------------|-----------------------|----------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------|------------------|----------------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2007.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2007.5 | MJT | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|-----|-------|---------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Air Suspension | Module Information | |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|------------------------|-----------------------|----------------------------|
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2007.5 | MAP | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ABS/IESC | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |

| | | | | | | | | |
|---------|------|--------|---------------|-------|--------------|----------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2007.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | PTO Requested Engine Speed |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-------------|-----------------------|---------------------------|
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Speedometer Gear |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Size |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Compensation |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Final Gear Ratio |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program ABS Install |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program VIN |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|----------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----|------|------|-------|--------------|----------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2009 | MYY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2009 | MYY | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2009 | A460 | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2009 | A460 | Japan | Transmission | AT A460 | Module Information | |
| JPISUZU | ELF | 2009 | A460 | Japan | Transmission | AT A460 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | A460 | Japan | Transmission | AT A460 | Read Data Strem | |
| JPISUZU | ELF | 2009 | A460 | Japan | Transmission | AT A460 | Actuation Test | |
| JPISUZU | ELF | 2009 | A460 | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2009 | A460 | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | A460 | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2009 | A460 | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2009 | A460 | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2009 | A460 | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | A460 | Japan | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|----------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2009 | A460 | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2009 | A460 | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | A460 | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2009 | A460 | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2009 | A460 | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | A460 | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2009 | A460 | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2009 | A460 | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2009 | A460 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2009 | A460 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | A460 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-------------|-----------------------|----------------------------|
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | PTO Requested Engine Speed |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Speedometer Gear |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Size |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Compensation |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Final Gear Ratio |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program ABS Install |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program VIN |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|----------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2009 | MY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | ELF | 2009 | MY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | ELF | 2009 | MY | Japan | Engine | 4JJ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | ELF | 2009 | MY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2009 | MY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2009 | MY | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2009 | MY | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2009 | MY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |

| | | | | | | | | |
|---------|-----|------|-----------|-------|-------------|-------------------|-----------------------|------------------------------|
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2009 | MYY | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2009 | r-Ex(MYY) | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2009 | r-Ex(MYY) | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r-Ex(MYY) | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2009 | r-Ex(MYY) | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2009 | r-Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2009 | r-Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | PTO Requested Engine Speed |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Speedometer Gear |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Size |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Tire Compensation |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program Final Gear Ratio |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program ABS Install |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Transmission | Smoother-EX | Special Function | Program VIN |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|-------------------|-----------------------|------------------------------|
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | r- Ex(MYY) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|-------------|----------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2009 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | BCM | Actuation Test | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | ELF | 2009 | MYY | Japan | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | ELF | 2009 | MYY | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2009 | MYY | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2009 | MYY | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|-----------|-------|--------------|-------------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Transmission | Smoother-Fx(MZX) | Module Information | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Transmission | Smoother-Fx(MZX) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Transmission | Smoother-Fx(MZX) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Transmission | Smoother-Fx(MZW) | Module Information | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Transmission | Smoother-Fx(MZW) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Transmission | Smoother-Fx(MZW) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Transmission | Smoother-Fx(MZZ) | Module Information | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Transmission | Smoother-Fx(MZZ) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Transmission | Smoother-Fx(MZZ) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Body | BCM | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|------|-------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|-------------|----------------|-----------------------|------------------------------|
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |

| | | | | | | | | |
|---------|---------|------|---------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |

| | | | | | | | | |
|---------|---------|------|-----|-------|---------|-------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Engine | 6HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | RKE Registration |

| | | | | | | | | |
|---------|---------|------|---|-------|-------------|----------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2009 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HF1 (CNG) | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HF1 (CNG) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HF1 (CNG) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Injection Learned Value |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Hour Meter Information Clear |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | Engne Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |

| | | | | | | | | |
|---------|---------|------|-----------|-------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2009 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2009 | r-Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Module Information | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|--------------|-------------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Transmission | Smoother-Fx(MZX) | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Transmission | Smoother-Fx(MZX) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Transmission | Smoother-Fx(MZX) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Transmission | Smoother-Fx(MZW) | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Transmission | Smoother-Fx(MZW) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Transmission | Smoother-Fx(MZW) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Transmission | Smoother-Fx(MZZ) | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Transmission | Smoother-Fx(MZZ) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Transmission | Smoother-Fx(MZZ) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|------|-------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|-------------|----------------|-----------------------|------------------------------|
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |

| | | | | | | | | |
|---------|---------|------|---------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2009 | r- Fx(MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|---------|------|-----|-------|---------|----------------------|-----------------------|--|
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2009 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|--------|----------------------|-----------------------|--|
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Read Data Stream | |
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZX) | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZX) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZX) | Read Data Stream | |
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZW) | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoother-Fx (MZZ) | Japan | Transmission | Smoother-Fx(MZW) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|--------------|----------------------|-----------------------|----------------------------------|
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Transmission | Smoothe r-Fx(MZW) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Transmission | Smoothe r-Fx(MZZ) | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Transmission | Smoothe r-Fx(MZZ) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Transmission | Smoothe r-Fx(MZZ) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|------|-------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------|-----------------------|------------------------------|
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|--------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2009 | Smoothe r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Calibration Data (MAF) |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | Reset Fuel Pump Correction |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | 4HK1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Special Function | Update Vehicle Configuration |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Special Function | ECM DTC Data |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Special Function | DTC Data Expect ECM |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|------|------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2009 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2009 | AMT Smoother-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2009 | AMT Smoother-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | AMT Smoother-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read Data Stream | |
| JPISUZU | GIGA | 2009 | AMT Smoother-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2009 | AMT Smoother-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2009 | AMT Smoother-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2009 | AMT Smoother-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2009 | AMT Smoother-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------|------------------------|-----------------------|--|
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program HW Number |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------|------------------|----------------------------|
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|------------------------|-----------------------|--|
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2009 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program HW Number |
| JPISUZU | GIGA | 2009 | MJT | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | GIGA | 2009 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2009 | MJT | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|---------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program HW Number |
| JPISUZU | GIGA | 2009 | MAL | Japan | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | EGR Value Zero Position Step Counter 1 |
| JPISUZU | GIGA | 2009 | MAL | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------------------|-----------------------|----------------------------|
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2009 | MAL | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------|------------------------|--------------------|----------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------------------------|--------------------|-----------------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Module Information | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------|-----------------------|----------------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|------------------------|-----------------------|--------------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ABS/IESC | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------------------|-----------------------|-------------------------|
| JPISUZU | GIGA | 2009.5 | MJT | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS/IESC | Module Information | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|----------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------------------------|-----------------------|------------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------------|-----------------------|--------------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------------------|-----------------------|----------------------------|
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2009.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | MAF Compensation |

| | | | | | | | | |
|---------|------|--------|-------|-------|---------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2009.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | MAF Compensation |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Reset DPD Regenerate |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Engine | 6WG1-TC (C/Rail_NLT) | Special Function | DPD Dry |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ABS/IESC | Module Information | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ABS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ABS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ABS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ABS/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ESC(with EBS) | Module Information | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ESC(with EBS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ESC(with EBS) | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | ESC(with EBS) | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Special Function | Update Final Gear Radio |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Special Function | Prog.ECU Locking Function |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Special Function | EOL Data Upload/Download |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Special Function | DMU Function |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Special Function | Clear MIMAMORI Data |
| JPISUZU | GIGA | 2009.5 | MAP | Japan | Information | MIMAMORI | Special Function | Clear Drive Record Data |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|--------|------|-----------------------|----------------------------------|
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | DPD Dry |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Read Data Stream | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Starter Life Estimated Start Count |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | BCM | Read Data Stream | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | Immobilizer | Read Data Stream | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------|-----------------------|-----------------------------|
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Urea SCR | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | BCM | Special Function | ECU Lock |

| | | | | | | | | |
|---------|---------|------|---|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2010 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|--------|------|-----------------------|--|
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Dry |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Read Data Stream | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Starter Life Estimated Start Count |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoother-Fx (MZW) | Japan | Body | BCM | Read Data Stream | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|------|-------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2010 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |

| | | | | | | | | |
|---------|---------|------|----------------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2010 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Module Information | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------|------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------|----------------------|--------------------|---|
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------------|----------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Module Information | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------------|------------------------|-----------------------|------------------------------|
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Actuation Test | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC Code Information Clear |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | Cluth Learned Value Clear |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC, All Learned Value Clear |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2010 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|-------|-------|---------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|-------|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2010 | MJX16 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|-----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2010 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2010 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2010 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2010 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2010 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2010 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2010 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2010 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Actuation Test | |

| | | | | | | | | |
|---------|------|------|---|-------|---------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | Air Suspension | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|-----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | Urea SCR | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|---------------|-------|--------------|-------------------------------|-----------------------|---|
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2010 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2010 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Module Information | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read Data Strem | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2010 | MAL | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2010 | T280/T35 0 | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |

| | | | | | | | | |
|---------|------|------|---|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2010 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2010 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Module Information | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read Data Strem | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Actuation Test | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Module Information | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read Data Strem | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Actuation Test | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------|-----------------------|-----------------------------|
| JPISUZU | ERGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2010 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------|----------------------|--------------------|---------------------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------------|----------------------|-----------------------|---|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------------|------------------------|-----------------------|--------------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Module Information | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|-----------------------------|-----------------------|--------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DRM Function |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |

| | | | | | | | | |
|---------|------|--------|-----|-------|---------|-----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|-----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2010.5 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Body | Driving Safety Advisor | Module Information | |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2010.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------|------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------|----------------------|--------------------|---------------------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------------|----------------------|-----------------------|---|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|------------------------|-------|--------------|------------------------|-----------------------|--------------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Read Data Stream | |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Read Data Stream | |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Chassis | ABS6/IESC | Module Information | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|-----------------------------|-----------------------|--------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | AMT Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | DRM Function |

| | | | | | | | | |
|---------|------|--------|------------------------|-------|-------------|----------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2010.5 | AMT Smoother-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Read Data Stream | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |

| | | | | | | | | |
|---------|------|--------|-----|-------|---------|-----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|-----------------------------|-----------------------|------------------------------------|
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2010.5 | MAP | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2011 | TMM | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | BCM | Special Function | DRM Function |

| | | | | | | | | |
|---------|-----|------|---------------|-------|---------|-----------------------|-----------------------|----------------------------------|
| JPISUZU | ELF | 2011 | TMM | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | TMM | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2011 | TMM | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2011 | TMM | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | TMM | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2011 | TMM | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2011 | TMM | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2011 | TMM | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-----------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Special Function | DRM Function |

| | | | | | | | | |
|---------|-----|------|---------------|-------|---------|-----------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|-----|-------|---------|-----------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |

| | | | | | | | | |
|---------|-----|------|------|-------|--------------|-----------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2011 | A460 | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2011 | A460 | Japan | Transmission | AT A460 | Module Information | |
| JPISUZU | ELF | 2011 | A460 | Japan | Transmission | AT A460 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | A460 | Japan | Transmission | AT A460 | Read Data Strem | |
| JPISUZU | ELF | 2011 | A460 | Japan | Transmission | AT A460 | Actuation Test | |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|---------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2011 | A460 | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | A460 | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2011 | A460 | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2011 | A460 | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | A460 | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2011 | A460 | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2011 | A460 | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2011 | A460 | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Injection Learned Value |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|---------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2011 | r- Ex(MYY) | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Injection Learned Value |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2011 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | MYY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |

| | | | | | | | | |
|---------|---------|------|-----|-------|---------|-------------------|-----------------------|---|
| JPISUZU | ELF | 2011 | MYY | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2011 | MBJ | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Preventive Maintenance Data |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | 4HK1 | Special Function | DPD Dry |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2011 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|--------|------|-----------------------|--|
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Dry |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Read Data Stream | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Starter Life Estimated Start Count |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | BCM | Read Data Stream | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|-------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | DPD Dry |

| | | | | | | | | |
|---------|---------|------|---------------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|------|------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2011 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|--------|----------|-----------------------|----------------------------------|
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Engine | Urea SCR | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Read Data Stream | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Starter Life Estimated Start Count |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------|-----------------------|-----------------------------|
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2011 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | ECU Lock |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|-------------|----------------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2011 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Read Data Stream | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | Idling Stop (BCM) | Read Data Stream | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Starter Life Estimated Start Count |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |

| | | | | | | | | |
|---------|---------|------|---|-------|-------------|----------------------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | Speedometer Control Device | Module Information | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2011 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HF1 (CNG) | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HF1 (CNG) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HF1 (CNG) | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Injection Learned Value |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | RKE Registration |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | RKE Registration Clear |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Alarm Of Engine Oil Life Mileage |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Mileage |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Starter Duration Of Life Counts |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Hour Meter Information Clear |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Fuel Data Display Clear |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Alarm Of EG Oil Life Distance Clear |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Alarm Of TM Oil Life Distance Clear |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Engine Oil Alarm Value |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Body | BCM | Special Function | Transmission Oil Alarm Value |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | Update Engine Type |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | Update Transmission Type |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | Update Final Gear Ratio |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | Update Tire Rolling Radius |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | Update AD Input |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL Data Clear |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | MIMAMORI ALL DTC REC Clear |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | Engine DMU All Data Clear |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | TCM DMU All Data Clear |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | Forced Engine DMU Record |
| JPISUZU | FORWARD | 2011 | MZW | Japan | Information | MIMAMORI | Special Function | Forced TCM DMU Record |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |

| | | | | | | | | |
|---------|------|------|-----|-------|--------------|-------------------------------|-----------------------|---|
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2011 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2011 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Module Information | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read Data Strem | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2011 | MAL | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2011 | MAL | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2011 | MAL | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2011 | MAL | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2011 | MAL | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2011 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2011 | MAL | Japan | Information | MIMAMORI | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|------|---|-------------------|--------------|-------------------|-----------------------|---|
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2011 | 0 | T280/T35 Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Actuation Test | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Actuation Test | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------|------|---|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HF1 (CNG) | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HF1 (CNG) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HF1 (CNG) | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Injection Learned Value |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2011 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Actuation Test | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Actuation Test | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|-------|--------------|-------------------------------|-----------------------|---|
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2011 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Module Information | |

| | | | | | | | | |
|---------|----------|------|------|-------|--------------|-------------------------------|-----------------------|---|
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Read Data Strem | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA mio | 2011 | MLD | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|----------|------|------|-------|--------------|-----------------------|-----------------------|------------------------------------|
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA mio | 2011 | A581 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2012 | A460 | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2012 | A460 | Japan | Transmission | AT A460 | Module Information | |
| JPISUZU | ELF | 2012 | A460 | Japan | Transmission | AT A460 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | A460 | Japan | Transmission | AT A460 | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-----------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2012 | A460 | Japan | Transmission | AT A460 | Actuation Test | |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | A460 | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2012 | A460 | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2012 | A460 | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | A460 | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2012 | A460 | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2012 | A460 | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2012 | A460 | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-----------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|---------|-------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |

| | | | | | | | | |
|---------|-----|------|-----------|-------|---------|-----------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2012 | r-Ex(MYY) | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Actuation Test | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|-----|-------|---------|-----------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2012 | TMM | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2012 | TMM | Japan | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|---------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2012 | TMM | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2012 | TMM | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2012 | TMM | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | TMM | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2012 | TMM | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2012 | TMM | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2012 | TMM | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Injection Learned Value |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Actuation Test | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|---------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2012 | r- Ex(MYY) | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Injection Learned Value |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2012 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Read Data Strem | |

| | | | | | | | | |
|---------|--------|------|----------------------------------|-------|--------------|------------------------------|-----------------------|---------------------------|
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2012 | MYY | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Engine | 6UZ1-TC | Module Information | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Engine | 6UZ1-TC | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Engine | 6UZ1-TC | Read Data Strem | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Engine | 6UZ1-TC | Actuation Test | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Transmission | 3000SP | Module Information | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Transmission | 3000SP | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Transmission | 3000SP | Read Data Strem | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Transmission | 3000SP | Actuation Test | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Information | Diagnostic Monitoring System | Module Information | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Information | Diagnostic Monitoring System | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2012 | 3000sp | Japan | Information | Diagnostic Monitoring System | Read Data Strem | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Engine | 6UZ1-TC | Module Information | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Engine | 6UZ1-TC | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Engine | 6UZ1-TC | Read Data Strem | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Engine | 6UZ1-TC | Actuation Test | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Information | Diagnostic Monitoring System | Module Information | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Information | Diagnostic Monitoring System | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2012 | MAL | Japan | Information | Diagnostic Monitoring System | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Module Information | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------|------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------|----------------------|--------------------|---|
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |

| | | | | | | | | |
|---------|------|------|------------------------|-------|--------------|----------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|------------------------|-------|--------------|------------------------|-----------------------|------------------------------|
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Actuation Test | |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC Code Information Clear |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | Cluth Learned Value Clear |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC, All Learned Value Clear |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoother-G (MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------|------------------|-----------------------------|
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2012 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |

| | | | | | | | | |
|---------|------|------|-------|-------|---------|-----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|-------|-------|-------------|-----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2012 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|-----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | DRM Function |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2012 | MAL | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2012 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | Speedometer Control Device | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2012 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | ABS6/IESC | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|---|-------|-------------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Offset Steering Angle |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Adjustment Radar Learn Date |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Main Function |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Input/Output |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Vehicle Identification |
| JPISUZU | GIGA | 2012 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Special Function | Radar Learn Flag |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | Speedometer Control Device | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|--------------|-------------------------------|-----------------------|---|
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2012 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2012 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2012 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Module Information | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read Data Strem | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------|------|----------|-------|--------------|-------------------|-----------------------|---|
| JPISUZU | ERGA | 2012 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2012 | MAL | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2012 | T280/T35 | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|---|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Actuation Test | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Actuation Test | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HF1 (CNG) | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HF1 (CNG) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | 6HF1 (CNG) | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2012 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-----|-------|--------------|-------------------|-----------------------|---|
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Actuation Test | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Actuation Test | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2012 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | Idling Stop | Module Information | |

| | | | | | | | | |
|---------|----------|------|------|-------|--------------|-------------------------------|-----------------------|---|
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Module Information | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Read Data Strem | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA mio | 2012 | MLD | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | Idling Stop | Module Information | |

| | | | | | | | | |
|---------|----------|--------|------|-------|-------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | Idling Stop | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA mio | 2012 | A581 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2012.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|--------|-------------------|-------|--------------|-------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Body | BCM | Read Data Stream | |
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoother-Fx (MZW) | Japan | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2012.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |

| | | | | | | | | |
|---------|---------|--------|------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2012.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | DPD Dry |

| | | | | | | | | |
|---------|---------|--------|---------------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|---------|--------|---------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |

| | | | | | | | | |
|---------|---------|--------|----------------------------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2012.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------|------|------------------|-----------------------------|
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------|----------------------|--------------------|---|
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|--------------|--------------------|-----------------------|--|
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------|
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|----------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|---------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |

| | | | | | | | | |
|---------|------|--------|----------------------------------|-------|-------------|----------------------------|--------------------|-------------------------------------|
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2012.5 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|------|--------|------------------------|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2012.5 | AMT Smoother-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2012.5 | AMT Smoother-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|-----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2012.5 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|-----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2012.5 | MAP | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|-----|-------|---------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|---------------------------|-------|-------------|-----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2012.5 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|---------------------------|-------|--------|----------------------|--------------------|-----------------------------|
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |

| | | | | | | | | |
|---------|------|--------|--------------------|-------|--------------|----------------------|-----------------------|---|
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Stream | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Read Data Stream | |

| | | | | | | | | |
|---------|------|--------|--------------------|-------|--------------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Read Data Stream | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Chassis | ABS6/IESC | Read Data Stream | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | Smoother-G (MJX16) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |

| | | | | | | | | |
|---------|------|--------|---------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|---------------------------|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |

| | | | | | | | | |
|---------|------|--------|---------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2012.5 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |

| | | | | | | | | |
|---------|------|--------|-----|-------|--------------|-------------------------------|-----------------------|---|
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Module Information | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2012.5 | MAL | Japan | Information | MIMAMORI | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|--------|---|-------------------|--------------|-------------------|-----------------------|---|
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2012.5 | 0 | T280/T35 Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Module Information | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Transmission | T280/T350 (Gen 4) | Actuation Test | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Module Information | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Actuation Test | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|-----------------------|-----------------------|------------------------------------|
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2012.5 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Actuation Test | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Communication Information |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Hybrid | Actuation Test | |

| | | | | | | | | |
|---------|-----|------|----------|-------|---------|-----------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2013 | MY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2013 | MY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2013 | MY | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2013 | MY | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2013 | MY | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2013 | MY | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2013 | MY | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2013 | MY | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2013 | MY | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MY | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2013 | MY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2013 | MY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2013 | MY | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2013 | MY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MY | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2013 | MY | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2013 | MY | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2013 | MY | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2013 | r-Ex(MY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2013 | r-Ex(MY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r-Ex(MY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |
| JPISUZU | ELF | 2013 | r-Ex(MY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2013 | r-Ex(MY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2013 | r-Ex(MY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2013 | r-Ex(MY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-----------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|---------|-------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |

| | | | | | | | | |
|---------|-----|------|-----------|-------|---------|-----------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2013 | r-Ex(MYY) | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Strem | |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2013 | TMM | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | TMM | Japan | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2013 | TMM | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2013 | TMM | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | TMM | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2013 | TMM | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2013 | TMM | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2013 | TMM | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Injection Learned Value |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2013 | r- Ex(MYY) | Japan | Chassis | ABS | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|-----------|-------|---------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2013 | r-Ex(MYY) | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2013 | r-Ex(MYY) | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | ELF | 2013 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | SRS | Module Information | |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MYY | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | ELF | 2013 | MYY | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2013 | MYY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2013 | MYY | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2013 | MYY | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2013 | MYY | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2013 | MYY | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|---------|------|-----|-------|---------|-------------------|-----------------------|---|
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | MBJ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Special Function | Program VIN |

| | | | | | | | | |
|---------|---------|------|-----|-------|---------|-------------------|-----------------------|---|
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|---|-----------------------|---|
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|--|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|--------|-------------------|-----------------------|--|
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Starter Life Estimated Start Count |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Body | BCM | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|-------------|-----------------------|-----------------------------|
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|--|-----------------------|--|
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|--|--------------------|-------------------------------------|
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Module Information | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|--------------|-------------------|-----------------------|---|
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|--------------|-------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |

| | | | | | | | | |
|---------|---------|------|------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Starer Life Estimated Start Count |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | DRM Function |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|----------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | MIMAMORI | Special Function | Program VIN |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|--------|----------|-----------------------|----------------------------------|
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Engine | Urea SCR | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Starter Life Estimated Start Count |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|------|-------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|----------------|-----------------------|-----------------------------|
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|-------------|---|--------------------|-------------------------------------|
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|-------------|--|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | Smoother-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | Idling Stop (BCM) | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Starter Life Estimated Start Count |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Body | BCM | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Body | Immobilizer | Read Data Stream | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Body | SRS | Read Data Stream | |

| | | | | | | | | |
|---------|---------|------|--------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|---------|------|--------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HF1 (CNG) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HF1 (CNG) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | 6HF1 (CNG) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | SRS | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | SRS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|------------------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2013 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2013 | AMT Smoother-G (MJX12) | Japan | Engine | 6UZ1 | Module Information | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------|------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------|----------------------|--------------------|---|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------------|----------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|------------------------|-------|--------------|------------------------|-----------------------|------------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC Code Information Clear |
| JPISUZU | GIGA | 2013 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | Cluth Learned Value Clear |
| JPISUZU | GIGA | 2013 | AMT Smoother-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC, All Learned Value Clear |
| JPISUZU | GIGA | 2013 | AMT Smoother-G (MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoother-G (MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoother-G (MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoother-G (MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------|------------------|-----------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |

| | | | | | | | | |
|---------|------|------|-------|-------|---------|-----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|-------|-------|-------------|-----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|-----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | MIMAMORI | Special Function | DRM Function |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | MAL | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2013 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|---|-------|-------------|-----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------|------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------|----------------------|--------------------|---------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------------|----------------------|-----------------------|---|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|--------------|------------------------|-----------------------|------------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC Code Information Clear |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | Cluth Learned Value Clear |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC, All Learned Value Clear |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Module Information | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |

| | | | | | | | | |
|---------|------|------|----------------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | AMT Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |

| | | | | | | | | |
|---------|------|------|-------|-------|---------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|-------|-------|-------------|-----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | MJX16 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | 6WG1 | Special Function | MAF Learning |

| | | | | | | | | |
|---------|------|------|-----|-------|---------|-----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | MAP | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Urea SCR | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|-----------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|--------|----------------------|--------------------|---|
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Engine | Urea SCR | Module Information | |

| | | | | | | | | |
|---------|------|------|--------------------|-------|--------------|------------------------|-----------------------|------------------------------|
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Module Information | |
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Actuation Test | |
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Special Function | DTC Code Information Clear |
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Special Function | Cluth Learned Value Clear |
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Transmission | Smoother-G (MJX16) | Special Function | DTC, All Learned Value Clear |
| JPISUZU | GIGA | 2013 | Smoother-G (MJX16) | Japan | Body | Driving Safety Advisor | Module Information | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|---------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|---------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Other Functions |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |

| | | | | | | | | |
|---------|------|------|-----------------|-------|--------------|----------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Transmission | AT(Allison) | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Transmission | AT(Allison) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Transmission | AT(Allison) | Actuation Test | |

| | | | | | | | | |
|---------|------|------|-----------------|-------|---------|------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | Air Suspension | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|-----------------|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | Other Functions |

| | | | | | | | | |
|---------|------|------|-----------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2013 | Allison 4500 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|------|--------------|-------|---------|-------------|-----------------------|---|
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Chassis | ANBH | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|--------------|-------|-------------|-------------|-----------------------|---|
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2013 | EATON AMT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | Idling Stop | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|-----|-------|--------------|-------------------------------|-----------------------|------------------------------------|
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Module Information | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read Data Strem | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2014 | MAL | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2014 | MAL | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2014 | MAL | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2014 | MAL | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2014 | MAL | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2014 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2014 | MAL | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA | 2014 | 0 | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2014 | 0 | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | 0 | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2014 | 0 | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2014 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2014 | 0 | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2014 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2014 | 0 | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2014 | 0 | Japan | Engine | 6HK1 | Special Function | Program VIN |

| | | | | | | | | | |
|---------|------|------|----------|---|-------|--------------|-------------------|-----------------------|---|
| JPISUZU | ERGA | 2014 | T280/T35 | 0 | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Module Information | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read Data Strem | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Actuation Test | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Special Function | Clear Basic Learn Values |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2014 | 0 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |

| | | | | | | | | |
|---------|----------|------|------|-------|-------------|-------------|-----------------------|---|
| JPISUZU | ERGA | 2014 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA mio | 2014 | A581 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|--------|------|-------|--------------|-------------------------------|-----------------------|---|
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Module Information | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Read Data Strem | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA mio | 2014 | MLD | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ELF | 2014.5 | MY Y | Japan | Engine | 4JJ1 | Module Information | |
| JPISUZU | ELF | 2014.5 | MY Y | Japan | Engine | 4JJ1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|--------|-----|-------|---------|---------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | T/M Type |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | Load Capacity |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | Battery Life Reset Request |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | Write Starting Counter |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | Program Vehicle Type |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | Update Load Capacity |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | HSA (ISS&HSA) | Module Information | |

| | | | | | | | | |
|---------|-----|--------|-----|-------|-------------|---------------|-----------------------|-------------------------------------|
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Information | DTU | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | 4JJ1 | Module Information | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | 4JJ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | Hybrid | Special Function | T/M Type |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | Hybrid | Special Function | Load Capacity |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | Hybrid | Special Function | Battery Life Reset Request |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | Hybrid | Special Function | Write Starting Counter |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | Hybrid | Special Function | Program Vehicle Type |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Engine | Hybrid | Special Function | Update Load Capacity |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | BCM | Special Function | DRM Function |

| | | | | | | | | |
|---------|-----|--------|-----|-------|-------------|-------------------|-----------------------|-------------------------------------|
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Information | DTU | Module Information | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | ELF | 2014.5 | TMM | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Injection Learned Value |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | 4HV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |

| | | | | | | | | |
|---------|-----|--------|-----|-------|---------|-------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | T/M Type |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | Load Capacity |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | Battery Life Reset Request |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | Write Starting Counter |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | Program Vehicle Type |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Engine | Hybrid | Special Function | Update Load Capacity |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2014.5 | MYY | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|--------|---------------|-------|--------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Injection Learned Value |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Mobile Elevating Work Platform |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | Update Vehicle Configuration |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Maintenance Data Clear |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Idling Stop (BCM) | Special Function | ISS Drive Data Clear |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Read Data Strem | |

| | | | | | | | | |
|---------|-----|--------|---------------|-------|--------------|------------------|-----------------------|----------------------------|
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | T/M Type |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | Load Capacity |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | Battery Life Reset Request |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | Write Starting Counter |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | Program Vehicle Type |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | Update Load Capacity |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Special Function | DRM Function |

| | | | | | | | | |
|---------|-----|--------|---------------|-------|---------|-------------------------------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Read Data Strem | |

| | | | | | | | | |
|---------|-----|--------|---------------|-------|--------------|------------------|-----------------------|----------------------------|
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | T/M Type |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | Load Capacity |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | Battery Life Reset Request |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | Write Starting Counter |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | Program Vehicle Type |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Special Function | Update Load Capacity |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |

| | | | | | | | | |
|---------|-----|--------|---------------|-------|---------|-------------|-----------------------|--------------------------------|
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|------------|-------|-------------|----------------------------------|-----------------------|-------------------------------------|
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Information | DTU | Module Information | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | ELF | 2014.5 | r-Ex (MYY) | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | ecostop | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|--------|------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|---------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |

| | | | | | | | | |
|---------|---------|--------|---------------|-------|--------------|-------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | ecostop | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | VAT | Module Information | |

| | | | | | | | | |
|---------|---------|--------|---------------|-------|------|-------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |

| | | | | | | | | |
|---------|---------|--------|---------------|-------|---------|----------------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|---------|--------|---------------|-------|---------|----------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Special Function | Initialization Streering Central Position |

| | | | | | | | | |
|---------|---------|--------|---------------|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|--------|---------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Module Information | |

| | | | | | | | | |
|---------|---------|--------|---------------|-------|-------------|----------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2014.5 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | ecostop | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|---------|------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Special Function | Reset AEB Counter |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Special Function | Initialization Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Special Function | Initialization Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | ecostop | Module Information | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|--------|---------|-----------------------|--|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |

| | | | | | | | | |
|---------|---------|--------|-------------------|-------|--------------|-------------|-----------------------|----------------------------|
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Read Data Stream | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|------|-------------|-----------------------|--------------------------------|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|---------|------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|---------|-------------------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|---------|--------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Special Function | Program VIN |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|---------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Special Function | Initialization Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|---|--------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HF1 (CNG) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HF1 (CNG) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|---------|-------------------|-----------------------|------------------------------------|
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HF1 (CNG) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Injection Learned Value |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HF1 (CNG) | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Module Information | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | ecostop | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | Urea SCR | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|---------|------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|----------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZZ | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | ecostop | Module Information | |

| | | | | | | | | |
|---------|---------|--------|---|-------|--------|------------------------|-----------------------|----------------------------------|
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|--------|--------------|-------|---------|------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | ZF9S111 0 | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC/AEBS | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC/AEBS | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ESC/AEBS | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |

| | | | | | | | | |
|---------|---------|--------|--------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | ZF9S111 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | 0 | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | ecostop | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|---------|------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Actuation Test | |

| | | | | | | | | |
|---------|---------|--------|-----|-------|-------------|--|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Special Function | Initialization Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Special Function | Initialization Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ESC/AEBS | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------|--------|--------------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | MZW | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | ecostop | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Module Information | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|--------|----------|-----------------------|----------------------------------|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Engine | Urea SCR | Module Information | |

| | | | | | | | | |
|---------|---------|--------|-------------------|-------|--------------|-------------|-----------------------|----------------------------|
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Read Data Stream | |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoother-Fx (MZW) | Japan | Body | VAT | Special Function | Program VIN |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|------|-------------|-----------------------|--------------------|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | DRM Function |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|------|------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | BCM | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Body | Camera (VAT) | Module Information | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|---------|-------------------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|---------|----------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Special Function | Initialization Streering Central Position |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|---------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Special Function | Initialization Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Special Function | Forced Learning Steering Central Position |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|----------------------------|--------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | EDR Function |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|----------|-----------------------|-----------------------------|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Special Function | Reset To Factory Setting |

| | | | | | | | | |
|---------|---------|--------|--------------------------|-------|-------------|------------------------------|-----------------------|---|
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FORWARD | 2014.5 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|--|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|--|-----------------------|---|
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.5 | MAL | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|--|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|--|-----------------------|---|
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.5 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Body | Driving Safety Advisor | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|------------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | MIMAMORI | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|--------|------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.5 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |

| | | | | | | | | |
|---------|------|--------|------------|-------|--------|----------------------|--------------------|---|
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |

| | | | | | | | | |
|---------|------|--------|------------|-------|--------------|--------------------|-----------------------|------------------------------|
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC Code Information Clear |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | Cluth Learned Value Clear |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC, All Learned Value Clear |

| | | | | | | | | |
|---------|------|--------|------------|-------|---------|------------------------------|-----------------------|--------------------|
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|------------|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |

| | | | | | | | | |
|---------|------|--------|------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.5 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |

| | | | | | | | | |
|---------|------|--------|---|-------|---------|------------------------------|-----------------------|---|
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Special Function | Exchanged ECM |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|--------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2014.5 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.5 | ZF9S131 0 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2014.5 | ZF9S131 0 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2014.5 | ZF9S131 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | ZF9S131 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.5 | ZF9S131 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.5 | ZF9S131 0 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Module Information | |

| | | | | | | | | |
|---------|------|--------|--------------|-------|--------|-------------|-----------------------|---|
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | Urea SCR | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|--------------|-------|-------------|-------------------------------------|-----------------------|-----------------------------|
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Module Information | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Information | MIMAMORI | Special Function | ECU Lock |

| | | | | | | | | |
|---------|------|--------|--------------|-------|-------------|------------------------------|-----------------------|---|
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2014.5 | EATON AMT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|--|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|--|-----------------------|---|
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.6 | MAP | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |

| | | | | | | | | |
|---------|------|--------|-----|-------|-------------|--|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|--|-----------------------|---|
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.6 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Body | Driving Safety Advisor | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|-------|-------|-------------|------------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | MIMAMORI | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|--------|------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.6 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |

| | | | | | | | | |
|---------|------|--------|------------|-------|--------|----------------------|--------------------|---|
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | Urea SCR | Module Information | |

| | | | | | | | | |
|---------|------|--------|------------|-------|--------------|------------------------|-----------------------|------------------------------|
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC Code Information Clear |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | Cluth Learned Value Clear |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Transmission | Smoother-G (MJX12) | Special Function | DTC, All Learned Value Clear |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Body | Driving Safety Advisor | Module Information | |

| | | | | | | | | |
|---------|------|--------|------------|-------|---------|------------------------------|-----------------------|--------------------|
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | ABS6/IESC | Module Information | |

| | | | | | | | | |
|---------|------|--------|------------|-------|---------|----------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|------------|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |

| | | | | | | | | |
|---------|------|--------|------------|-------|-------------|--|--------------------|-------------------------------------|
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.6 | r-G(MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Module Information | |

| | | | | | | | | |
|---------|------|--------|------------|-------|--------|------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | 6WG1 | Special Function | MAF Learning |

| | | | | | | | | |
|---------|------|--------|------------|-------|--------------|----------------------|-----------------------|---|
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Transmission | Smoother-G (MJX16) | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Transmission | Smoother-G (MJX16) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|------------|-------|--------------|------------------------------|-----------------------|------------------------------|
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Transmission | Smoother-G (MJX16) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Transmission | Smoother-G (MJX16) | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Transmission | Smoother-G (MJX16) | Special Function | DTC Code Information Clear |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Transmission | Smoother-G (MJX16) | Special Function | Cluth Learned Value Clear |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Transmission | Smoother-G (MJX16) | Special Function | DTC, All Learned Value Clear |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Body | Driving Safety Advisor | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |

| | | | | | | | | |
|---------|------|--------|------------|-------|---------|------------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | EBS/IESC | Module Information | |

| | | | | | | | | |
|---------|------|--------|------------|-------|---------|-----------------------------|-----------------------|--|
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | EBS/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|------------|-------|-------------|---|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |

| | | | | | | | | |
|---------|------|--------|--------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.6 | r-G(MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|--------|-----------------|-------|--------------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Transmission | AT(Allison) | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Transmission | AT(Allison) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Transmission | AT(Allison) | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Body | Driving Safety Advisor | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Body | Driving Safety Advisor | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Body | Driving Safety Advisor | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|-----------------|-------|---------|------------------------------|-----------------------|--------------------------------|
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Body | Driving Safety Advisor | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Body | Driving Safety Advisor | Special Function | Write 0 Deg Offset |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | Cornering Lamp Control (ISS) | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | Cornering Lamp Control (ISS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | ABS6/IESC | Special Function | Lateral Acceleration Parameter |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | EBS/IESC | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | EBS/IESC | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | EBS/IESC | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | EBS/IESC | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|-----------------|-------|-------------|-----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | Millimeterwave Radar Cruise | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | Millimeterwave Radar Cruise | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | Millimeterwave Radar Cruise | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Chassis | Millimeterwave Radar Cruise | Actuation Test | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |

| | | | | | | | | |
|---------|------|--------|-----------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2014.6 | Allison 4500 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | ecostop | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | RADAR (VAT) | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|--------------------------|-----------------------|---|
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Special Function | Steering Angle Sensor Learn |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Special Function | G Sensor 0 Point Learn |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Wabco with Tractor) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Wabco with Tractor) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Wabco with Tractor) | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Wabco with Tractor) | Special Function | DTC Memory Clear |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Special Function | Reset To Factory Setting |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | ecostop | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | RADAR (VAT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|--|-----------------------|---|
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Special Function | Steering Angle Sensor Learn |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Special Function | G Sensor 0 Point Learn |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Wabco with Tractor) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Wabco with Tractor) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Wabco with Tractor) | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Wabco with Tractor) | Special Function | DTC Memory Clear |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|--------|----------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6UZ1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|--------------------|-------|--------------|---------------------|-----------------------|-------------|
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Engine | ecostop | Module Information | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Read Data Stream | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Body | RADAR (VAT) | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|------|------------|-----------------------|-------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|---------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Special Function | Steering Angle Sensor Learn |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Special Function | G Sensor 0 Point Learn |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|--------------------------|-----------------------|------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Wabco with Tractor) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Wabco with Tractor) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Wabco with Tractor) | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Wabco with Tractor) | Special Function | DTC Memory Clear |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|---|--------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|---------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|----------------------------|--------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|----------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | ecostop | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | RADAR (VAT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|--|-----------------------|---|
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Special Function | Steering Angle Sensor Learn |
| JPISUZU | GIGA | 2015 | MJT | Japan | Body | Vehicle Control Module | Special Function | G Sensor 0 Point Learn |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Wabco with Tractor) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Wabco with Tractor) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Wabco with Tractor) | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Chassis | EBS (Wabco with Tractor) | Special Function | DTC Memory Clear |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |

| | | | | | | | | |
|---------|------|------|-----|-------|---------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | ecostop | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | RADAR (VAT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Special Function | Steering Angle Sensor Learn |
| JPISUZU | GIGA | 2015 | MJX | Japan | Body | Vehicle Control Module | Special Function | G Sensor 0 Point Learn |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | Air Suspension | Actuation Test | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Wabco with Tractor) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Wabco with Tractor) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Wabco with Tractor) | Actuation Test | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Chassis | EBS (Wabco with Tractor) | Special Function | DTC Memory Clear |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | MJX | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|--------|----------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Engine | ecostop | Module Information | |

| | | | | | | | | |
|---------|------|------|--------------------|-------|--------------|---------------------|-----------------------|-------------|
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Body | RADAR (VAT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoother-G (MJX12) | Japan | Body | SRS(Denso) | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|------|------------------------|-----------------------|--|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|---------|--------------------------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Special Function | Steering Angle Sensor Learn |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Body | Vehicle Control Module | Special Function | G Sensor 0 Point Learn |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Wabco with Tractor) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|--------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Wabco with Tractor) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Wabco with Tractor) | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Chassis | EBS (Wabco with Tractor) | Special Function | DTC Memory Clear |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|---------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Other Functions |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX12) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Actuation Test | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|--------|----------|-----------------------|-----------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | 6WG1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | Urea SCR | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|--------------|---------------------|-----------------------|-------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | ecostop | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Transmission | Smoother-Gx (MJX16) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Transmission | Smoother-Gx (MJX16) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Transmission | Smoother-Gx (MJX16) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Transmission | Smoother-Gx (MJX16) | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | RADAR (VAT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | SRS(Denso) | Module Information | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|------|------------------------|-----------------------|----------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|---------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | Vehicle Control Module | Special Function | Steering Angle Sensor Learn |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Body | Vehicle Control Module | Special Function | G Sensor 0 Point Learn |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|--------------------------|-----------------------|--------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | EBS (Wabco with Tractor) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | EBS (Wabco with Tractor) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | EBS (Wabco with Tractor) | Actuation Test | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Chassis | EBS (Wabco with Tractor) | Special Function | DTC Memory Clear |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | DTU | Special Function | Reset To Factory Setting |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|---------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | Smoothe r-G (MJX16) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Actuation Test | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Special Function | DPD Regeneration Data Reset |

| | | | | | | | | |
|---------|------|------|------|-------|---------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | 6NX1 | Special Function | MAF Learning |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | ecostop | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | RADAR (VAT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | Vehicle Control Module | Special Function | Steering Angle Sensor Learn |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Body | Vehicle Control Module | Special Function | G Sensor 0 Point Learn |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Chassis | Air Suspension | Actuation Test | |

| | | | | | | | | |
|---------|------|------|------|-------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | MIMAMORI | Special Function | DRM Function |

| | | | | | | | | |
|---------|------|------|---------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | MEB9 | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Actuation Test | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Special Function | Fuel Delivery Rate |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Special Function | Injector ID Code |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Special Function | MAF Learn Value |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Special Function | DPD Dry |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | 6NX1 | Special Function | MAF Learning |

| | | | | | | | | |
|---------|------|------|---------------|-------|--------------|--------------------|-----------------------|-------------|
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | ecostop | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Actuation Test | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | RADAR (VAT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | VAT | Module Information | |

| | | | | | | | | |
|---------|------|------|---------------|-------|---------|------------------------|-----------------------|---|
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | VAT | Special Function | Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | VAT | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | VAT | Special Function | Reset AEBS Counter |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | Vehicle Control Module | Special Function | Steering Angle Sensor Learn |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Body | Vehicle Control Module | Special Function | G Sensor 0 Point Learn |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Chassis | Air Suspension | Actuation Test | |

| | | | | | | | | |
|---------|------|------|---------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|--------|------|---------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | CAN Converter (FMS) | Special Function | Program VIN |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | CAN Converter (FMS) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | CAN Converter (FMS) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | CAN Converter (FMS) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | CAN Converter (FMS) | Special Function | Reset All Accumulation Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2015 | r-G (MEB9) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Engine | 6UZ1-TC | Module Information | |

| | | | | | | | | |
|---------|--------|------|--------|-------|--------------|------------------------------|-----------------------|-------------------------------------|
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Engine | 6UZ1-TC | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Engine | 6UZ1-TC | Read Data Strem | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Engine | 6UZ1-TC | Actuation Test | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Engine | 6UZ1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Engine | 6UZ1-TC | Special Function | Injector ID Code |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Engine | 6UZ1-TC | Special Function | MAF Learn Value |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Engine | 6UZ1-TC | Special Function | Program VIN |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Module Information | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Read Data Strem | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Actuation Test | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Diagnostic Monitoring System | Module Information | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Diagnostic Monitoring System | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Diagnostic Monitoring System | Read Data Strem | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Diagnostic Monitoring System | Special Function | DRM Function |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Diagnostic Monitoring System | Special Function | EDR Function |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Diagnostic Monitoring System | Special Function | ECU Lock |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Diagnostic Monitoring System | Special Function | Other Functions |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | SKW477 | 2015 | 3000sp | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Engine | 6UZ1-TC | Module Information | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Engine | 6UZ1-TC | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Engine | 6UZ1-TC | Read Data Strem | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Engine | 6UZ1-TC | Actuation Test | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Engine | 6UZ1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Engine | 6UZ1-TC | Special Function | Injector ID Code |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Engine | 6UZ1-TC | Special Function | MAF Learn Value |

| | | | | | | | | |
|---------|--------|------|-----|-------|-------------|------------------------------|-----------------------|---|
| JPISUZU | SKW477 | 2015 | MAL | Japan | Engine | 6UZ1-TC | Special Function | Program VIN |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Diagnostic Monitoring System | Module Information | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Diagnostic Monitoring System | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Diagnostic Monitoring System | Read Data Strem | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Diagnostic Monitoring System | Actuation Test | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Diagnostic Monitoring System | Special Function | Program VIN |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | SKW477 | 2015 | MAL | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |

| | | | | | | | | |
|---------|------|------|----------|-------|--------------|-------------------------------|-----------------------|---|
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Module Information | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Transmission | ACT(Air Control Transmission) | Read Data Strem | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2015 | MAL | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2015 | MAL | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2015 | MAL | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2015 | MAL | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2015 | MAL | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2015 | MAL | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2015 | MAL | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2015 | T280/T35 | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |

| | | | | | | | | |
|---------|----------|------|------|-------|--------------|-------------------|-----------------------|------------------------------------|
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Module Information | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Read Data Strem | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Transmission | T280/T350 (Gen 5) | Actuation Test | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2015 | 0 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2015 | 0 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2015 | 0 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2015 | 0 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2015 | 0 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2015 | 0 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2015 | 0 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Module Information | |

| | | | | | | | | |
|---------|----------|------|------|-------|-------------|-------------|-----------------------|---|
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA mio | 2015 | A581 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|-----|-------|--------------|-------------------------------|-----------------------|---|
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | Idling Stop | Special Function | Program Vehicle Configuration Data |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | Idling Stop | Special Function | Clear ISS Maintenance Data |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Engine | Idling Stop | Special Function | Clear ISS Drive Data |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Module Information | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Transmission | ACT(Air Control Transmission) | Read Data Strem | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA mio | 2015 | MLD | Japan | Information | MIMAMORI | Special Function | Program VIN |

| | | | | | | | | |
|---------|------|--------|--------------|-------|--------|----------|-----------------------|---|
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Engine | Urea SCR | Actuation Test | |

| | | | | | | | | |
|---------|------|--------|-----------|-------|--------------|-------------------------|-----------------------|---|
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Transmission | AMT | Module Information | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Transmission | AMT | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Transmission | AMT | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Transmission | AMT | Special Function | Program Final Gear Ratio |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Transmission | AMT | Special Function | Programming Tire Radius |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Body | Door Control | Module Information | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Body | Door Control | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Body | Door Control | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Body | Door Control | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Chassis | Air Suspension Kneeling | Module Information | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Chassis | Air Suspension Kneeling | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Chassis | Air Suspension Kneeling | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | DTU | Module Information | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | DTU | Read Data Strem | |

| | | | | | | | | |
|---------|------|--------|-----------|-------|-------------|-------------------------|-----------------------|-------------------------------------|
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2015.5 | AMT (MZW) | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | ISS(Idling Stop System) | Module Information | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | ISS(Idling Stop System) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | ISS(Idling Stop System) | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|--------|------|-------|--------------|-------------------------|-----------------------|---|
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Transmission | T280 (Gen 5) | Module Information | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Transmission | T280 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Transmission | T280 (Gen 5) | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Transmission | T280 (Gen 5) | Actuation Test | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Body | Door Control | Module Information | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Body | Door Control | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Body | Door Control | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Body | Door Control | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Chassis | Air Suspension Kneeling | Module Information | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Chassis | Air Suspension Kneeling | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Chassis | Air Suspension Kneeling | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | DTU | Module Information | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | DTU | Special Function | EOL Setup |

| | | | | | | | | |
|---------|------|--------|------|-------|-------------|----------------------|-----------------------|---|
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2015.5 | T280 | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | 6UV1 CNG | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | 6UV1 CNG | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | 6UV1 CNG | Read Data Strem | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | 6UV1 CNG | Special Function | Clear Injection Learned Value |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | 6UV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | 6UV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | 6UV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Setting/Change EOL Data |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Estimate Of Engine Start Counter Of Starter |
| JPISUZU | GIGA | 2016 | MJT | Japan | Engine | Idle Stop (MIMAMORI) | Special Function | Clear Idling Stop System Drive Data |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | RADAR (VAT) | Module Information | |

| | | | | | | | | |
|---------|------|------|-----|-------|-------------|--|-----------------------|---|
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | RADAR (VAT) | Special Function | Program VIN |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | Vehicle Control Module | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | Vehicle Control Module | Special Function | ECU Lock |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | Vehicle Control Module | Special Function | Steering Angle Sensor Learn |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | Vehicle Control Module | Special Function | G Sensor 0 Point Learn |
| JPISUZU | GIGA | 2016 | MJT | Japan | Body | Vehicle Control Module | Special Function | Basic Vehicle Configuration Data |
| JPISUZU | GIGA | 2016 | MJT | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|--------------|--|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | GIGA | 2016 | MJT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Engine | Idle Stop (MIMAMORI) | Module Information | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Engine | Idle Stop (MIMAMORI) | Read Data Strem | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Engine | 6UV1 CNG | Module Information | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Engine | 6UV1 CNG | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Engine | 6UV1 CNG | Read Data Strem | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Module Information | |

| | | | | | | | | |
|---------|------|------|--------------------|-------|--------------|--------------------|-----------------------|--|
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Read Data Stream | |
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Actuation Test | |
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Body | SRS(Denso) | Read Data Stream | |
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Body | VAT | Read Data Stream | |
| JPISUZU | GIGA | 2016 | Smoother-Gx (MEB9) | Japan | Body | Camera (VAT) | Module Information | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|------------------------|-----------------------|--|
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | DTU | Module Information | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|---|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2016 | Smoothe r-Gx (MEB9) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Module Information | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Actuation Test | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Fuel Delivery Rate |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Engine Oil Exchange Reset |

| | | | | | | | | |
|---------|------|------|--------------|-------|---------|-------------|-----------------------|---|
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | 6HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | Idling Stop | Module Information | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | Idling Stop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | Idling Stop | Read Data Strem | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Chassis | ANBH | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|--------|------|--------------|-------|--------------|-------------------------------------|-----------------------|-----------------------------|
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Module Information | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | ERGA | 2016 | EATON AMT | Japan | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Engine | 6UZ1-TC | Module Information | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Engine | 6UZ1-TC | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Engine | 6UZ1-TC | Read Data Strem | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Engine | 6UZ1-TC | Actuation Test | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Engine | 6UZ1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Engine | 6UZ1-TC | Special Function | Injector ID Code |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Engine | 6UZ1-TC | Special Function | MAF Learn Value |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Engine | 6UZ1-TC | Special Function | Program VIN |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Module Information | |

| | | | | | | | | |
|---------|--------|------|--------|-------|--------------|------------------------------|-----------------------|-------------------------------------|
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Read Data Strem | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Actuation Test | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Diagnostic Monitoring System | Module Information | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Diagnostic Monitoring System | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Diagnostic Monitoring System | Read Data Strem | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Diagnostic Monitoring System | Special Function | DRM Function |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Diagnostic Monitoring System | Special Function | EDR Function |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Diagnostic Monitoring System | Special Function | ECU Lock |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Diagnostic Monitoring System | Special Function | Other Functions |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | SKW477 | 2016 | 3000sp | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Engine | 6UZ1-TC | Module Information | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Engine | 6UZ1-TC | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Engine | 6UZ1-TC | Read Data Strem | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Engine | 6UZ1-TC | Actuation Test | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Engine | 6UZ1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Engine | 6UZ1-TC | Special Function | Injector ID Code |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Engine | 6UZ1-TC | Special Function | MAF Learn Value |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Engine | 6UZ1-TC | Special Function | Program VIN |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Diagnostic Monitoring System | Module Information | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Diagnostic Monitoring System | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Diagnostic Monitoring System | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-----|-------|--------------|------------------------------|-----------------------|---|
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Diagnostic Monitoring System | Special Function | DRM Function |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Diagnostic Monitoring System | Special Function | EDR Function |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Diagnostic Monitoring System | Special Function | ECU Lock |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Diagnostic Monitoring System | Special Function | Other Functions |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | SKW477 | 2016 | MAL | Japan | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Special Function | Engine Oil Exchange Reset |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Special Function | Accelerator Pedal Position (Full) Learn Value Reset |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | 4HK1 | Special Function | DPD Dry |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Engine | ecostop | Special Function | G Sensor 0 Point Learning |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Transmission | AMT | Module Information | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Transmission | AMT | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Transmission | AMT | Read Data Strem | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Body | Door Control | Module Information | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Body | Door Control | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Body | Door Control | Read Data Strem | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Body | Door Control | Special Function | Vehicle Configuration Data Individual Programming |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Chassis | ABS 8 | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-----|-------|-------------|-------------------------|-----------------------|-------------------------------------|
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Chassis | Air Suspension Kneeling | Module Information | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Chassis | Air Suspension Kneeling | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Chassis | Air Suspension Kneeling | Read Data Strem | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | DTU | Module Information | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | DTU | Special Function | EOL Setup |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | DTU | Special Function | Program VIN |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | DTU | Special Function | Reset To Factory Setting |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | DTU | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | ERGA mio | 2016 | AMT | Japan | Information | DTU | Special Function | Download Vehicle Configuration Data |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | 4JJ1 | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | ABS | Module Information | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|------------------|-----------------------|--|
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Information | DTU | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|------------------|-----------------------|--|
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|------|------------|-------|-------------|---------------|-----------------------|--|
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Information | DTU | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2017 | TMM | Japan | Engine | 4JJ1 | Module Information | |
| JPISUZU | ELF | 2017 | TMM | Japan | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | TMM | Japan | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | ELF | 2017 | TMM | Japan | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | ELF | 2017 | TMM | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2017 | TMM | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | TMM | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2017 | TMM | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2017 | TMM | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ELF | 2017 | TMM | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | TMM | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2017 | TMM | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | TMM | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2017 | TMM | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | ELF | 2017 | TMM | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | TMM | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | ELF | 2017 | TMM | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | ELF | 2017 | TMM | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | ELF | 2017 | TMM | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | TMM | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | ELF | 2017 | TMM | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2017 | TMM | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | TMM | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2017 | TMM | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2017 | TMM | Japan | Chassis | HSA (ISS&HSA) | Module Information | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|-------------|-------------------|-----------------------|--|
| JPISUZU | ELF | 2017 | TMM | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | TMM | Japan | Information | DTU | Module Information | |
| JPISUZU | ELF | 2017 | TMM | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ELF | 2017 | TMM | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2017 | TMM | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | TMM | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017 | MYY | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----|------|---------------|-------|--------------|-------------------|-----------------------|--|
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MYY) | Japan | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|-----------|-------|---------|----------------------------------|-----------------------|--|
| JPISUZU | ELF | 2017 | r-Ex (MY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MY) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MY) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2017 | r-Ex (MY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2017 | r-Ex (MY) | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MY) | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017 | r-Ex (MY) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017 | r-Ex (MY) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | VAT | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|------|-------|-------------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | DTU | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|------|-------|-------------|---|-----------------------|--|
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | 17 BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|-----|-------|-------------|--|-----------------------|--|
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |

| | | | | | | | | |
|---------|---------|------|------------|-------|--------------|--|-----------------------|--|
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZZ | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Transmission | Smoother-Fx | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|---------------|-------|---------|--------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS | Read Data Strem | |

| | | | | | | | |
|---------|---------|------|---------------|-------|---------|----------------|-----------------------|
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS | Actuation Test |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Module Information |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS/ESC/AEBS | Actuation Test |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS 8 | Read/Clear Fault Code |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS 8 | Read Data Strem |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Module Information |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read/Clear Fault Code |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Read Data Strem |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | Air Suspension | Actuation Test |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | EBS (Knorr) | Module Information |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | EBS (Knorr) | Read Data Strem |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Module Information |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem |

| | | | | | | | | |
|---------|---------|------|---------------|-------|-------------|--|-----------------------|--|
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | r-Fx (MZZ) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Engine | Urea SCR | Module Information | |

| | | | | | | | | |
|---------|---------|------|-----|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | MZW | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------|-------|-------------|---|-----------------------|--|
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MZW | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Engine | 4HK1 | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|-------------------|-------|--------------|------------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MZW) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|------|--------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | 17 BCM | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|--------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|--|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------------|-------|-------------|---|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MZW) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | 6NX1 | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | 6NX1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | 6NX1 | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | 6NX1 | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | VAT | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | 17 BCM | Module Information | |

| | | | | | | | | |
|---------|---------|------|------|-------|-------------|---|-----------------------|--|
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | MEB9 | Japan | Information | CAN Converter (FMS) | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|--------------------|-------|--------------|------------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Engine | 6NX1 | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Engine | 6NX1 | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Engine | 6NX1 | Read Data Stream | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Engine | 6NX1 | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Transmission | Smoother-Fx (MEB9) | Module Information | |

| | | | | | | | | |
|---------|---------|------|--------------------|-------|--------------|--------------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Transmission | Smoother-Fx (MEB9) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Transmission | Smoother-Fx (MEB9) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Transmission | Smoother-Fx (MEB9) | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Body | Meter | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoother-Fx (MEB9) | Japan | Body | VAT | Module Information | |

| | | | | | | | |
|---------|---------|------|---------------------------|-------|---------|--------------|-----------------------|
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Body | VAT | Read/Clear Fault Code |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Body | VAT | Read Data Strem |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Body | Camera (VAT) | Module Information |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Body | RADAR (VAT) | Module Information |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Body | 17 BCM | Module Information |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Body | 17 BCM | Read/Clear Fault Code |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Body | 17 BCM | Read Data Strem |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Body | 17 BCM | Actuation Test |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | ABS | Module Information |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | ABS | Read/Clear Fault Code |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | ABS | Read Data Strem |

| | | | | | | | | |
|---------|---------|------|---------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | ABS/ESC/AEBS | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | ABS/ESC/AEBS | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | ABS/ESC/AEBS | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | ABS/ESC/AEBS | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------|------|---------------------------|-------|-------------|--|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | DTU | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | DTU | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |

| | | | | | | | | |
|---------|---------|------|---------------------------|-------|-------------|------------------------------|-----------------------|--|
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | FORWARD | 2017 | Smoothe r-Fx (MEB9) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Chassis | Air Suspension | Module Information | |

| | | | | | | | | |
|---------|------|------|-------|-------|-------------|---|-----------------------|--|
| JPISUZU | GIGA | 2017 | MJT | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2017 | MJT | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | 17 BCM | Module Information | |

| | | | | | | | | |
|---------|------|------|-------|-------|-------------|---|-----------------------|--|
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2017 | MJX16 | Japan | Information | DTU | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|---------------------|-------|--------------|------------------------------|-----------------------|--|
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Engine | 6UZ1 | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Engine | 6UZ1 | Read Data Stream | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Module Information | |

| | | | | | | | | |
|---------|------|------|---------------------|-------|--------------|------------------------|-----------------------|--|
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Transmission | Smoother-Gx (MJX12) | Actuation Test | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MJX12) | Japan | Body | SRS(Denso) | Module Information | |

| | | | | | | | | |
|---------|------|------|----------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Chassis | Air Suspension | Actuation Test | |

| | | | | | | | | |
|---------|------|------|----------------------------|-------|-------------|--|-----------------------|--|
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | MIMAMORI | Module Information | |

| | | | | | | | | |
|---------|------|------|----------------------------|-------|-------------|------------------------------|-----------------------|--|
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | MAP Unit | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | MAP Unit | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | MAP Unit | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MJX12) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Engine | 6NX1 | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Engine | 6NX1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Engine | 6NX1 | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Engine | 6NX1 | Actuation Test | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | 17 BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------|------|------|-------|-------------|---|-----------------------|--|
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2017 | MEB9 | Japan | Information | DTU | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|--------------------|-------|--------------|------------------------------|-----------------------|--|
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Engine | 6NX1 | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Engine | 6NX1 | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Engine | 6NX1 | Read Data Stream | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Engine | 6NX1 | Actuation Test | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Engine | ISS/HSA(ecostop/HSA/BLS/VCM) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Module Information | |

| | | | | | | | | |
|---------|------|------|--------------------|-------|--------------|------------------------|-----------------------|--|
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Transmission | Smoother-Gx (MEB9) | Actuation Test | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Body | Vehicle Control Module | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Body | Vehicle Control Module | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Body | Meter | Module Information | |
| JPISUZU | GIGA | 2017 | Smoother-Gx (MEB9) | Japan | Body | SRS(Denso) | Module Information | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|---------|----------------|-----------------------|--|
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Body | VAT | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Body | VAT | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Body | VAT | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Body | Camera (VAT) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Body | RADAR (VAT) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Chassis | Air Suspension | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Chassis | Air Suspension | Actuation Test | |

| | | | | | | | | |
|---------|------|------|---------------------------|-------|-------------|--|-----------------------|--|
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Chassis | EBS (Knorr) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Chassis | EBS (Knorr) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Chassis | EBS (Knorr) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | CAN Converter (FMS) | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | CAN Converter (FMS) | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | CAN Converter (FMS) | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | MIMAMORI | Module Information | |

| | | | | | | | | |
|---------|--------|------|---------------------------|-------|--------------|------------------------------|-----------------------|--|
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | DTU | Module Information | |
| JPISUZU | GIGA | 2017 | Smoothe r-Gx (MEB9) | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Engine | 6UZ1-TC | Module Information | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Engine | 6UZ1-TC | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Engine | 6UZ1-TC | Read Data Strem | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Engine | 6UZ1-TC | Actuation Test | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Module Information | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Read Data Strem | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Transmission | Allison 3000(Gen 5) | Actuation Test | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Information | Diagnostic Monitoring System | Module Information | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Information | Diagnostic Monitoring System | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Information | Diagnostic Monitoring System | Read Data Strem | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | SKW477 | 2017 | 3000sp | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Engine | 6UZ1-TC | Module Information | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Engine | 6UZ1-TC | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Engine | 6UZ1-TC | Read Data Strem | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Engine | 6UZ1-TC | Actuation Test | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Chassis | ABS 6 | Module Information | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|--------|------|-----|-------|--------------|--|-----------------------|--|
| JPISUZU | SKW477 | 2017 | MAL | Japan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Information | Diagnostic Monitoring System | Module Information | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Information | Diagnostic Monitoring System | Read/Clear Fault Code | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Information | Diagnostic Monitoring System | Read Data Strem | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | SKW477 | 2017 | MAL | Japan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Transmission | AMT | Module Information | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Transmission | AMT | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Transmission | AMT | Read Data Strem | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Body | Door Control | Module Information | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Body | Door Control | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Body | Door Control | Read Data Strem | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Chassis | Air Suspension Kneeling | Module Information | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Chassis | Air Suspension Kneeling | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Chassis | Air Suspension Kneeling | Read Data Strem | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Information | DTU | Module Information | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |

| | | | | | | | | |
|---------|------|------|------|-------|--------------|--|-----------------------|--|
| JPISUZU | ERGA | 2017 | AMT | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | AMT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | ISS(Idling Stop System) | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | ISS(Idling Stop System) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | ISS(Idling Stop System) | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Transmission | T280 (Gen 5) | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Transmission | T280 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Transmission | T280 (Gen 5) | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Transmission | T280 (Gen 5) | Actuation Test | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Body | Door Control | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Body | Door Control | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Body | Door Control | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Chassis | Air Suspension Kneeling | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Chassis | Air Suspension Kneeling | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Chassis | Air Suspension Kneeling | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Chassis | ANBH | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Chassis | ANBH | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Chassis | ANBH | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Information | DTU | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Information | DTU | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|------|-------|--------------|---|-----------------------|--|
| JPISUZU | ERGA | 2017 | T280 | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA | 2017 | T280 | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Engine | Urea SCR | Module Information | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Engine | Urea SCR | Actuation Test | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Engine | 4HK1 | Module Information | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Engine | 4HK1 | Actuation Test | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Transmission | AMT | Module Information | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Transmission | AMT | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Transmission | AMT | Read Data Strem | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Body | Door Control | Module Information | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Body | Door Control | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Body | Door Control | Read Data Strem | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Chassis | Air Suspension Kneeling | Module Information | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Chassis | Air Suspension Kneeling | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Chassis | Air Suspension Kneeling | Read Data Strem | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Information | DTU | Module Information | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Information | DTU | Read Data Strem | |

| | | | | | | | | |
|---------|----------|--------|-----|-------|-------------|---|-----------------------|--|
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ERGA mio | 2017 | AMT | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Engine | 4JJ1 | Module Information | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Chassis | ABS | Actuation Test | |

| | | | | | | | | |
|---------|-----|--------|---------------|-------|--------------|------------------|-----------------------|--|
| JPISUZU | ELF | 2017.5 | MYY | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Information | DTU | Module Information | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MYY | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Module Information | |

| | | | | | | | | |
|---------|-----|--------|---------------|-------|-------------|---------------|-----------------------|--|
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Information | DTU | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Information | DTU | Read Data Strem | |

| | | | | | | | | |
|---------|-----|--------|-----------|-------|-------------|---------------|-----------------------|--|
| JPISUZU | ELF | 2017.5 | r-Ex (MY) | Japan | Information | MIMAMORI | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY) | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY) | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Engine | 4JJ1 | Module Information | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Engine | ecostop | Module Information | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Body | Keyless Ride | Module Information | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Body | Keyless Ride | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Body | Keyless Ride | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Body | 17 BCM | Module Information | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Body | 17 BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Body | 17 BCM | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Body | 17 BCM | Actuation Test | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Information | DTU | Module Information | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Information | DTU | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Information | MIMAMORI | Module Information | |

| | | | | | | | | |
|---------|-----|--------|----------------|-------|-------------|-------------------|-----------------------|--|
| JPISUZU | ELF | 2017.5 | TMM | Japan | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | TMM | Japan | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Engine | 4HV1 CNG | Actuation Test | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Chassis | (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017.5 | MY Y | Japan | Chassis | (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY Y) | Japan | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY Y) | Japan | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY Y) | Japan | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY Y) | Japan | Engine | 4HV1 CNG | Actuation Test | |

| | | | | | | | | |
|---------|-----|--------|---------------|-------|--------------|-------------------|-----------------------|--|
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | Hybrid | Actuation Test | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Engine | Idling Stop (BCM) | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Transmission | Smoother-Ex(MYY) | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | BCM | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Body | BCM | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Chassis | ABS | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MYY) | Japan | Chassis | ABS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|--------|-----------|------------|--------------|----------------------------------|-----------------------|-------------------------------|
| JPISUZU | ELF | 2017.5 | r-Ex (MY) | Japan | Chassis | ABS | Read Data Strem | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY) | Japan | Chassis | ABS | Actuation Test | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY) | Japan | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY) | Japan | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Module Information | |
| JPISUZU | ELF | 2017.5 | r-Ex (MY) | Japan | Chassis | Cornering Lamp Control (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Transmission | TCCM | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---------|-----------------------|--|
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MSG | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4JJ1-TC | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4JJ1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4JJ1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4JJ1-TC | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4JJ1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4JJ1-TC | Special Function | Program VIN |

| | | | | | | | | |
|---------|----------|------|-----|---------------|---------|---------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4JJ1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|-------------------------------------|
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Malaysia 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MSG | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Engine | 4JJ1 | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|--------------|-----------------------|--|
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | AT(Aisin AW) | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | AT(Aisin AW) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | AT(Aisin AW) | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | AT(Aisin AW) | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | AT(Aisin AW) | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|--------------|-----------------------|--|
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | AT(Aisin AW) | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | AT(Aisin AW) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | AT(Aisin AW) | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | AT(Aisin AW) | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | AT(Aisin AW) | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|---------------|------|---------|---------------|---------|------------|-----------------------|---|
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | Airbag SRS | Module Information | |

| | | | | | | | | |
|---------|---------------|------|-----|---------------|---------|------------|-----------------------|--|
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | Airbag SRS | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | Airbag SRS | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|---------------|------|-----|---------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FXFYGX Series | 2013 | MAL | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | Airbag SRS | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | Airbag SRS | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | Airbag SRS | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|---------------|------|-----|---------------|---------|-------|-----------------------|--|
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|---------------|------|--------------|---------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FXFYGX Series | 2013 | MJT | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | Airbag SRS | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | Airbag SRS | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | Airbag SRS | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |

| | | | | | | | | |
|---------|---------------|------|--------------|---------------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|---------------|------|--------------|---------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | FXFYGX Series | 2013 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |

| | | | | | | | | |
|---------|------------|------|-----|---------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-----|---------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|-----|---------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|------------|------|-------------------------|---------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Delivery Rate |

| | | | | | | | | |
|---------|------------|------|------------------|------------|--------|---------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |

| | | | | | | | | |
|---------|------------|------|------------------|------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|------------|------|------------------|------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | Malaysia 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | Malaysia 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | Malaysia 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S1110 | Malaysia 1 | Engine | 6HK1-TC | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|--------------|---------------|--------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------|--------------|-------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Special Function | Clear Basic Learn Values |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Special Function | Clear Variable Learn Values |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | ECU Lock |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2013 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Module Information | |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Actuation Test | |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Use Mode |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Selector Switch |

| | | | | | | | | |
|---------|----------|------|-----|---------------|---------|---------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | N-Series | 2014 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | CAB Select |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2014 | MYY | Malaysia 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |

| | | | | | | | | |
|---------|------------|------|-----|---------------|--------|-------------|-----------------------|---------------------------------------|
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |

| | | | | | | | | |
|---------|------------|------|-----|---------------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |

| | | | | | | | | |
|---------|------------|------|-----|---------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |

| | | | | | | | | |
|---------|------------|------|-----|---------------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|------------|------|--------------|---------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2014 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Program VIN |

| | | | | | | | | |
|---------|------------|------|--------------|---------------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Module Information | |

| | | | | | | | | |
|---------|------------|------|-------------------------|---------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2014 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2014 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2014 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | F&G Series | 2014 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2014 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | Fuller FSO- 5206B | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |

| | | | | | | | | |
|---------|------------|------|------------------|------------|------|-----|-----------------------|---------------------------------------|
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |

| | | | | | | | | |
|---------|------------|------|------------------|------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|------------------|------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2014 | Fuller FSO-5206B | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------|--------------|-------------|-----------------------|---------------------------------------|
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Module Information | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Actuation Test | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Special Function | Clear Basic Learn Values |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Transmission | AT(Allison) | Special Function | Clear Variable Learn Values |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |

| | | | | | | | | |
|---------|------------|------|-----------------|---------------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2014 | Allison 2500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |

| | | | | | | | | |
|---------|----------|------|-----|---------------|--------|---------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Module Information | |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Actuation Test | |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Use Mode |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Selector Switch |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | N-Series | 2015 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | CAB Select |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Engine | 4HK1-TC | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|-------------------------------------|
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2015 | MYY | Malaysia 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | MSG | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JJ1 | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|---------|-----------------------|--|
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|------------|------|-----------|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | F&G Series | 2015 | 3000/3500 | Malaysia 1 | Engine | 6HK1-TC | Module Information | |

| | | | | | | | | |
|---------|------------|------|---------------|---------------|--------------|-------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Transmission | AT(Allison) | Module Information | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Transmission | AT(Allison) | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Transmission | AT(Allison) | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Transmission | AT(Allison) | Actuation Test | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Transmission | AT(Allison) | Special Function | Clear Basic Learn Values |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | ECU Lock |

| | | | | | | | | |
|---------|------------|------|---------------|---------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | 3000/35 00 | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|-----------|------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2015 | 3000/3500 | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2015 | 3000/3500 | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | 3000/3500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2015 | 3000/3500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2015 | 3000/3500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2015 | 3000/3500 | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Delivery Rate |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-----|---------------|---------|---------|-----------------------|--|
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|---------|---------------|--------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Download Vehicle Configuration Data |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Correction Code |
| JPISUZU | F&G Series | 2015 | MZW | Malaysia 1 | Information | Speedometer Control Device | Special Function | Adjust Part Number |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|-----------------------------------|
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---------|-----------------------|--|
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2015 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---|-----------------------|---|
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2015 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2016 | MSG | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2016 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---|-----------------------|---|
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2016 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JJ1 | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Immobilizer | Read Data Stream | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | SRS | Read Data Stream | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Read Data Stream | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---|-----------------------|---|
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---------|-----------------------|---|
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2016 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | AT | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|------------|-----------------------|---|
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2016 | TB50-LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Body | SRS(Denso) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|----|---------------|---------|------------|-----------------------|---|
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Body | SRS(Denso) | Read Data Stream | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Tire Diameter Programming |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Wheel Base Data |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Initialization Steering Central Position |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS | Read Data Stream | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4JJ1-TC | Module Information | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4JJ1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4JJ1-TC | Read Data Stream | |

| | | | | | | | | |
|---------|----------|------|----|---------------|---------|------------|-----------------------|---|
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4JJ1-TC | Actuation Test | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4JJ1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4JJ1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4JJ1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Tire Diameter Programming |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Wheel Base Data |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Initialization Streering Central Position |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS | Module Information | |

| | | | | | | | | |
|---------|----------|------|----|---------------|---------|------------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4HL1 | Module Information | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4HL1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4HL1 | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4HL1 | Actuation Test | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4HL1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4HL1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Engine | 4HL1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MY | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Tire Diameter Programming |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Wheel Base Data |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Initialization Steering Central Position |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Chassis | ABS | Read Data Stream | |
| JPISUZU | N-Series | 2017 | MYY | Malaysia 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Module Information | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Read Data Stream | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Actuation Test | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Throttle 0Voltage |

| | | | | | | | | |
|---------|----------|------|-----|---------------|---------|------------|-----------------------|---|
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Use Mode |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | PTO Selector Switch |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Engine | 4JH1 | Special Function | CAB Select |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS/ESC | Special Function | Tire Diameter Programming |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS/ESC | Special Function | Wheel Base Data |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS/ESC | Special Function | Initialization Streering Central Position |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS/ESC | Special Function | Forced Learning Steering Central Position |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MSB | Malaysia 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---|-----------------------|---|
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|---------|---|-----------------------|---|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|---------|-----------------------|--|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---|-----------------------|---|
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|--|
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Engine | 4JJ1 | Special Function | Communication Information |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MUX | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---|-----------------------|---|
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MSG | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---|-----------------------|---|
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | RZ4E | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | RZ4E | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | RZ4E | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | RZ4E | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | RZ4E | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Engine | RZ4E | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------------|------|--------------|---------------|---------|----------------------|-----------------------|---|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1-TC (C/Rail_NLT) | Module Information | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1-TC (C/Rail_NLT) | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1-TC (C/Rail_NLT) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1-TC (C/Rail_NLT) | Actuation Test | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Fuel Delivery Rate |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Injector ID Code |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Engine | 6UZ1-TC (C/Rail_NLT) | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|---------------|------|--------------|---------------|-------------|--|-----------------------|-------------------------------------|
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (internal speedometer) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (internal speedometer) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Correction Code |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (internal speedometer) | Special Function | Adjust Part Number |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (stand-alone) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (stand-alone) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Correction Code |
| JPISUZU | FXFYGX Series | 2017 | ZF9S131 0 | Malaysia 1 | Information | Speedometer Control Device (stand-alone) | Special Function | Adjust Part Number |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|--------|---------|---------------|--------------|-------------|-----------------------|----------------------------|
| JPISUZU | UC Series | 2017 | MUA | Malaysia 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|--------|---------|---------------|---------|---|-----------------------|--|
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |

| | | | | | | | | |
|---------|-----------|--------|---------|---------------|--------------|-------------|-----------------------|--|
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|--------|-----|---------------|---------|---|-----------------------|--|
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|--------|-----|---------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2017.5 | MUA | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|-------------|-----------------------|--|
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------|-----------------------|--|
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---------|-----------------------|--|
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|---------|---------|-----------------------|--|
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|---------|----------------------------------|-----------------------|--|
| JPISUZU | TF Series | 2018 | MSG | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Engine | RZ4E | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Engine | RZ4E | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Engine | RZ4E | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Engine | IBS (Intelligent Battery System) | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|---------|-----------------------|--|
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|-------------------------|-----------------------|--|
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Head Lamp Auto Leveling | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------------------|-----------------------|--|
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------------------|-----------------------|--|
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|---------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Head Lamp Auto Leveling | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|-------------------------|-----------------------|--|
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | AT | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---------|---------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|-------------------------|-----------------------|--|
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Engine | RZ4E | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-------------|---------------|---------|-------------------------|-----------------------|--|
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Malaysia 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|------|-------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | ABS/ASR ADVICS | Read Data Stream | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Singapore | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|--------|------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|---------|----------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller FSO-5206B | Singapore | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|---------|----------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | MZW | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Chassis | ABS/ASR | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|-----------------|-----------|-------------|----------------------------|-----------------------|------------------------------------|
| JPISUZU | F-Series | 2011 | MZW | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Singapore | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | 4JJ1-TC (C/Rail_PNLT) | Module Information | |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | 4JJ1-TC (C/Rail_PNLT) | Read/Clear Fault Code | |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | 4JJ1-TC (C/Rail_PNLT) | Read Data Stream | |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | 4JJ1-TC (C/Rail_PNLT) | Actuation Test | |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Injector ID Code |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Engine Oil Exchange Reset |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Program VIN |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | 4JJ1-TC (C/Rail_PNLT) | Special Function | DPD Dry |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | Idling Stop (BCM) | Module Information | |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | Idling Stop (BCM) | Read Data Stream | |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | Idling Stop (BCM) | Special Function | Program Vehicle Configuration Data |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | Idling Stop (BCM) | Special Function | Starter Life Estimated Start Count |
| JPISUZU | NJR | 2011 | Smoothener (MY) | Singapore | Engine | Idling Stop (BCM) | Special Function | Clear ISS Drive Data |

| | | | | | | | | |
|---------|-----|------|---------------|-----------|--------------|-----------------|-----------------------|--------------------------------|
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Transmission | Smoother-Ex(MY) | Module Information | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Transmission | Smoother-Ex(MY) | Read/Clear Fault Code | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Transmission | Smoother-Ex(MY) | Read Data Stream | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | BCM | Module Information | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | BCM | Special Function | DRM Function |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | BCM | Special Function | Forced Drive Electric Function |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | BCM | Special Function | Preventive Maintenance Data |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | BCM | Special Function | Other Functions |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | SRS | Module Information | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | NJR | 2011 | Smoother (MY) | Singapore | Body | SRS | Read Data Stream | |

| | | | | | | | | |
|---------|----------|------|-------------------|---------------|---------|------------------|-----------------------|---------------------------|
| JPISUZU | NJR | 2011 | Smoothe r (MY) | Singapor e | Chassis | ABS | Module Information | |
| JPISUZU | NJR | 2011 | Smoothe r (MY) | Singapor e | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | NJR | 2011 | Smoothe r (MY) | Singapor e | Chassis | ABS | Read Data Strem | |
| JPISUZU | NJR | 2011 | Smoothe r (MY) | Singapor e | Chassis | ABS | Actuation Test | |
| JPISUZU | NJR | 2011 | Smoothe r (MY) | Singapor e | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | NJR | 2011 | Smoothe r (MY) | Singapor e | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MY | Singapor e | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|----------|------|----|-----------|---------|---------|-----------------------|--|
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS/ASR | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|----|-----------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2012 | MY | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | MY | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2012 | MY | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |

| | | | | | | | | |
|---------|----------|------|----|-----------|------|-------------|-----------------------|---------------------------------------|
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Module Information | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | N-Series | 2012 | MY | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |

| | | | | | | | | |
|---------|----------|------|-----|-----------|---------|------------------|-----------------------|--|
| JPISUZU | N-Series | 2012 | MYY | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | N-Series | 2012 | MYY | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | N-Series | 2012 | MYY | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | N-Series | 2012 | MYY | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2012 | MYY | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MYY | Singapore | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MYY | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2012 | MYY | Singapore | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|------|-------------|-----------------------|--|
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Module Information | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |

| | | | | | | | | |
|---------|----------|------|-----|-----------|---------|-------------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2012 | MZZ | Singapore | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2012 | TMM | Singapore | Engine | 4JJ1-TC | Module Information | |
| JPISUZU | N-Series | 2012 | TMM | Singapore | Engine | 4JJ1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | TMM | Singapore | Engine | 4JJ1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2012 | TMM | Singapore | Engine | 4JJ1-TC | Actuation Test | |
| JPISUZU | N-Series | 2012 | TMM | Singapore | Engine | 4JJ1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2012 | TMM | Singapore | Engine | 4JJ1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | TMM | Singapore | Engine | 4JJ1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2012 | TMM | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2012 | TMM | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | TMM | Singapore | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|---------|------------------|-----------------------|--|
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | ABS/ASR ADVICS | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|-------------|----------------------------|-----------------------|------------------------|
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2012 | MZZ | Singapore | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2012 | Fuller FSO-5206B | Singapore | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2012 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|-----------|-------------|----------------------------|-----------------------|-------------------------------|
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2012 | MZW | Singapore | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Engine | 4JJ1 | Read Data Stream | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |

| | | | | | | | | |
|---------|-----------|------|-----|-----------|--------------|-------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2012 | MUX | Singapore | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | Meter | Special Function | Clock Display Setting |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | MUX | Singapore | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Engine | 4JJ1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Engine | 4JJ1 | Read Data Stream | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Transmission | TCCM | Read Data Stream | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Transmission | AT | Read Data Stream | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | BCM | Read Data Stream | |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|---------|------------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | N-Series | 2013 | MYY | Singapore | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Singapore | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Singapore | Engine | 4JJ1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N-Series | 2013 | MYY | Singapore | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Singapore | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | N-Series | 2013 | MYY | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Singapore | Body | Immobilizer | Read Data Stream | |

| | | | | | | | | |
|---------|----------|------|-------------|-----------|--------------|------------------|-----------------------|--|
| JPISUZU | N-Series | 2013 | MY | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | MY | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MY | Singapore | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N-Series | 2013 | MY | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Transmission | Smoother-Ex | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Body | Immobilizer | Read Data Stream | |

| | | | | | | | | |
|---------|----------|------|------------------|---------------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2013 | Smooth r (MY) | Singapor e | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | Smooth r (MY) | Singapor e | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smooth r (MY) | Singapor e | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smooth r (MY) | Singapor e | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MY | Singapor e | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-------------|-----------|---------|------------------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2013 | MY | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2013 | MY | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MY | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | N-Series | 2013 | MY | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | MY | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MY | Singapore | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N-Series | 2013 | MY | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | MY | Singapore | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | Smooth (MY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |

| | | | | | | | | |
|---------|----------|------|----------------|-----------|--------------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Special Function | Program Engine Type |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Special Function | Program Transmission Type |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Special Function | Program Tire Size |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Special Function | Program Tire Compensation |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Special Function | Program Final Gear Ratio |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Special Function | Program ABS Install |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Transmission | Smoother-Ex | Special Function | Program PTO Setting |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Singapore | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|------------------|---------------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2013 | Smooth r (MY) | Singapor e | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smooth r (MY) | Singapor e | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | Smooth r (MY) | Singapor e | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smooth r (MY) | Singapor e | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smooth r (MY) | Singapor e | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | Smooth r (MY) | Singapor e | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZZ | Singapor e | Engine | 4HK1-TC | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|--------|-------------|-----------------------|--|
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |

| | | | | | | | | |
|---------|----------|------|-----|-----------|-------------|----------------------------|-----------------------|--------------------------------|
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2013 | MZZ | Singapore | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|--------|------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | ECU Lock |

| | | | | | | | | |
|---------|----------|------|-----|-----------|---------|---------|-----------------------|--|
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|--------|-------------|-----------------------|--|
| JPISUZU | F-Series | 2013 | MZW | Singapore | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|-------------|----------------------------|-----------------------|--------------------------------|
| JPISUZU | F-Series | 2013 | MZW | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2013 | MZW | Singapore | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|--------|------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC | Read Data Stream | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|------|-------------|-----------------------|---------------------------------------|
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|---------|---------|-----------------------|--|
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Read Data Stream | |

| | | | | | | | | |
|---------|-----------|------|------------------|-----------|--------------|----------------------------|-----------------------|-------------------------------|
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2013 | Fuller FSO-5206B | Singapore | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Engine | 4JJ1 | Read Data Stream | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Transmission | TCCM | Read Data Stream | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|-----------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|--------------|--------------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUX | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | MUX | Singapore | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Engine | 4JJ1 | Read Data Stream | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Transmission | AT(Aisin AW) | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Transmission | AT(Aisin AW) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|--------------|--------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Transmission | AT(Aisin AW) | Read Data Stream | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Transmission | AT(Aisin AW) | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Transmission | AT(Aisin AW) | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Transmission | TCCM | Read Data Stream | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | Meter | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |

| | | | | | | | | |
|---------|---------------|------|----------|-----------|--------|------------|-----------------------|------------------------|
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Engine | 6UZ1 | Special Function | Injector Quantity Trim |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | Airbag SRS | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | Airbag SRS | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | Airbag SRS | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | Vehicle Information |

| | | | | | | | | |
|---------|---------------|------|----------|-----------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | ZF9S1310 | Singapore | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Engine | 6UZ1 | Actuation Test | |

| | | | | | | | | |
|---------|---------------|------|-----|-----------|--------|------------|-----------------------|---------------------------------------|
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Engine | 6UZ1 | Special Function | Injector Quantity Trim |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | Airbag SRS | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | Airbag SRS | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | Airbag SRS | Read Data Stream | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |

| | | | | | | | | |
|---------|---------------|------|-----|-----------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MAL | Singapore | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Engine | 6UZ1 | Read Data Stream | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Engine | 6UZ1 | Special Function | Injector Quantity Trim |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | Airbag SRS | Module Information | |

| | | | | | | | | |
|---------|---------------|------|-----|-----------|---------|------------|-----------------------|--|
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | Airbag SRS | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | Airbag SRS | Read Data Stream | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|---------------|------|--------------|-----------|--------------|----------------------------|-----------------------|--------------------------|
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | MJT | Singapore | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Engine | 6UZ1 | Special Function | Injector Quantity Trim |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Engine | 6UZ1 | Special Function | Injector ID Code |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Engine | 6UZ1 | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | AT(Allison) | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | AT(Allison) | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | AT(Allison) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | AT(Allison) | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | AT(Allison) | Special Function | Clear Basic Learn Values |

| | | | | | | | | |
|---------|---------------|------|--------------|-----------|--------------|---------------------|-----------------------|-----------------------------|
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | AT(Allison) | Special Function | Clear Variable Learn Values |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | Allison 4430(Gen 5) | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | Allison 4430(Gen 5) | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | Allison 4430(Gen 5) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | Allison 4430(Gen 5) | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Transmission | Allison 4430(Gen 5) | Special Function | Clear Basic Learn Values |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | Airbag SRS | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | Airbag SRS | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | Airbag SRS | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | Drive Information & Display |

| | | | | | | | | |
|---------|---------------|------|--------------|-----------|-------------|----------------------------|-----------------------|--|
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | FXFYGX Series | 2013 | Allison 4430 | Singapore | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Engine | 6WG1 | Special Function | Injector Quantity Trim |

| | | | | | | | | |
|---------|------------|------|-----|-----------|-------------|----------------|-----------------------|------------------|
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Information | MIMAMORI | Special Function | DRM Function |

| | | | | | | | | |
|---------|------------|------|-----|-----------|-------------|------------------|-----------------------|-----------------------------|
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | C&E Series | 2013 | MJT | Singapore | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Body | BCM | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Body | BCM | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|---------|------------------|-----------------------|--|
| JPISUZU | N-Series | 2014 | MYY | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Body | BCM | Module Information | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Body | BCM | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|----------|------|-------------------|-----------|--------------|------------------|-----------------------|--|
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MZZ | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Transmission | Smoother-Ex | Read Data Strem | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2014 | Smoothe r (MY) | Singapore | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|----------|------|---------------|-----------|--------------|------------------|-----------------------|--|
| JPISUZU | N-Series | 2014 | Smoother (MY) | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoother (MY) | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | N-Series | 2014 | Smoother (MY) | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2014 | Smoother (MY) | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoother (MY) | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | N-Series | 2014 | Smoother (MY) | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2014 | Smoother (MY) | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoother (MY) | Singapore | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N-Series | 2014 | Smoother (MY) | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2014 | Smoother (MZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2014 | Smoother (MZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoother (MZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N-Series | 2014 | Smoother (MZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2014 | Smoother (MZ) | Singapore | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2014 | Smoother (MZ) | Singapore | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoother (MZ) | Singapore | Transmission | Smoother-Ex | Read Data Stream | |
| JPISUZU | N-Series | 2014 | Smoother (MZ) | Singapore | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|----------|------|--------------------|---------------|---------|------------------|-----------------------|------------------|
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Module Information | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Read Data Strem | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2014 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZZ | Singapor e | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|----------|------|-----|-----------|--------|------------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|---------|----------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Chassis | Air Suspension | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|--------------------|-----------|--------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2014 | MZZ | Singapore | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Transmission | Smoother (MZZ) | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Transmission | Smoother (MZZ) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Transmission | Smoother (MZZ) | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Transmission | Smoother (MZZ) | Special Function | Program Final Gear Ratio |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Transmission | Smoother (MZZ) | Special Function | Programming Tire Radius |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapore | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|--------------------|---------------|---------|-------|-----------------------|--|
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|--------------------|---------------|-------------|----------------------------|-----------------------|------------------------|
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r (MZZ) | Singapor e | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|----------|------|---------------|-----------|--------------|------------------|-----------------------|----------------------------------|
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 (with DOC) | Module Information | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 (with DOC) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 (with DOC) | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 (with DOC) | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 (with DOC) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 (with DOC) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 (with DOC) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 (with DOC) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Transmission | Smoother (MZW) | Module Information | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Transmission | Smoother (MZW) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Transmission | Smoother (MZW) | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Transmission | Smoother (MZW) | Special Function | Program Final Gear Ratio |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Transmission | Smoother (MZW) | Special Function | Programming Tire Radius |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Singapore | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|-------------------|---------------|------|-------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|-------------------|---------------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Singapor e | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZW | Singapor e | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Singapor e | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|--------|------------------|-----------------------|----------------------------------|
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1 (with DOC) | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1 (with DOC) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1 (with DOC) | Read Data Stream | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1 (with DOC) | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1 (with DOC) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1 (with DOC) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1 (with DOC) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Engine | 6HK1 (with DOC) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Read Data Stream | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|------|-------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Body | Immobilizer | Read Data Stream | |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Singapore | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|--------|------------------|-----------------------|----------------------------------|
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1 (with DOC) | Module Information | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1 (with DOC) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1 (with DOC) | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1 (with DOC) | Actuation Test | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1 (with DOC) | Special Function | Injector Quantity Trim |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|--------|-----------------|-----------------------|----------------------------------|
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1 (with DOC) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1 (with DOC) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Engine | 6HK1 (with DOC) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | Drive Information & Display |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|------|-------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|------------------|-----------|---------|----------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|------------------|-----------|--------------|----------------------------|-----------------------|-------------------------------|
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2014 | Fuller-FSO-5206B | Singapore | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|-----------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Transmission | TCCM | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Read Data Stream | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|---------|---------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|-----------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Transmission | TCCM | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2014 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Read Data Stream | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|---------|---------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2014 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Engine | 6HK1 | Module Information | |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Engine | 6HK1 | Actuation Test | |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Engine | 6HK1 | Special Function | Injector Quantity Trim |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------------|-----------|--------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | LT Series | 2014 | MZW | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | LT Series | 2014 | MZW | Singapore | Information | Speedometer Control Device | Read Data Stream | |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 | Module Information | |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 | Read Data Stream | |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 | Actuation Test | |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 | Special Function | Injector Quantity Trim |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 | Special Function | Injector ID Code |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 | Special Function | Program VIN |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Engine | 6HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Transmission | Smoother (MZW) | Module Information | |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Transmission | Smoother (MZW) | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Transmission | Smoother (MZW) | Read Data Stream | |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2014 | Smoother(MZW) | Singapore | Chassis | ABS 6 | Read Data Stream | |

| | | | | | | | | |
|---------|-----------|------|-------------------|---------------|-------------|----------------------------|-----------------------|--|
| JPISUZU | LT Series | 2014 | Smoothe r(MZW) | Singapor e | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | LT Series | 2014 | Smoothe r(MZW) | Singapor e | Information | Speedometer Control Device | Module Information | |
| JPISUZU | LT Series | 2014 | Smoothe r(MZW) | Singapor e | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series | 2015 | TMM | Singapor e | Engine | 4JJ1 Euro5 | Module Information | |
| JPISUZU | N-Series | 2015 | TMM | Singapor e | Engine | 4JJ1 Euro5 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | TMM | Singapor e | Engine | 4JJ1 Euro5 | Read Data Strem | |
| JPISUZU | N-Series | 2015 | TMM | Singapor e | Engine | 4JJ1 Euro5 | Actuation Test | |
| JPISUZU | N-Series | 2015 | Smoothe r(MYY) | Singapor e | Engine | 4JJ1 | Module Information | |
| JPISUZU | N-Series | 2015 | Smoothe r(MYY) | Singapor e | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | Smoothe r(MYY) | Singapor e | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | N-Series | 2015 | Smoothe r(MYY) | Singapor e | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | N-Series | 2015 | Smoothe r(MYY) | Singapor e | Engine | ecostop | Module Information | |
| JPISUZU | N-Series | 2015 | Smoothe r(MYY) | Singapor e | Engine | ecostop | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | Smoothe r(MYY) | Singapor e | Engine | Hybrid | Module Information | |
| JPISUZU | N-Series | 2015 | Smoothe r(MYY) | Singapor e | Engine | Hybrid | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | Smoothe r(MYY) | Singapor e | Engine | Hybrid | Read Data Strem | |
| JPISUZU | N-Series | 2015 | Smoothe r(MYY) | Singapor e | Engine | Hybrid | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|---------------|-----------|--------------|-----------------|-----------------------|----------------------------|
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Engine | Hybrid | Special Function | T/M Type |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Engine | Hybrid | Special Function | Load Capacity |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Engine | Hybrid | Special Function | Battery Life Reset Request |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Engine | Hybrid | Special Function | Write Starting Counter |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Engine | Hybrid | Special Function | Program Vehicle Type |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Engine | Hybrid | Special Function | Update Load Capacity |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Transmission | Smoother-Ex(MY) | Module Information | |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Transmission | Smoother-Ex(MY) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Transmission | Smoother-Ex(MY) | Read Data Stream | |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Body | BCM | Module Information | |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2015 | Smoother (MY) | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------------|---------------|---------|-------------------------------------|-----------------------|-----------------------------|
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Chassis | ABS | Special Function | Tire Diameter Programming |
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Chassis | ABS | Special Function | Program VIN |
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Chassis | HSA (ISS&HSA) | Module Information | |
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Chassis | HSA (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Chassis | Cornering Lamp Control (ISS&HSA) | Module Information | |
| JPISUZU | N-Series | 2015 | Smoothe r (MY) | Singapor e | Chassis | Cornering Lamp Control (ISS&HSA) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | AY6 | Singapor e | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2015 | AY6 | Singapor e | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | AY6 | Singapor e | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | AY6 | Singapor e | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | AY6 | Singapor e | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | AY6 | Singapor e | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |

| | | | | | | | | |
|---------|-----------|------|-----|-----------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Transmission | TCCM | Read Data Stream | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|-----------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | AY6 | Singapore | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Transmission | TCCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|-----------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | Meter | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | SRS | Read Data Stream | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | BCM | Read Data Stream | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | BCM | Special Function | Door Unlocking Timing Setting |

| | | | | | | | | |
|---------|------------|------|---------|-----------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Singapore | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Engine | 6WG1 | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Engine | 6WG1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|------------|------|-----|-----------|-------------|----------------|-----------------------|-----------------------------|
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Chassis | ABS 6 | Read Data Stream | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Chassis | Air Suspension | Module Information | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Chassis | Air Suspension | Read Data Stream | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Information | MIMAMORI | Read Data Stream | |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Information | MIMAMORI | Special Function | Other Functions |

| | | | | | | | | |
|---------|------------|------|------|-----------|-------------|----------|-----------------------|-------------------------|
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | C&E Series | 2016 | MJT | Singapore | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Engine | 6HK1 | Module Information | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Engine | 6HK1 | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Engine | 6HK1 | Read Data Strem | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Engine | 6HK1 | Actuation Test | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Engine | Urea SCR | Module Information | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Engine | Urea SCR | Actuation Test | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2017 | MAL | Singapore | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Engine | 6HK1 | Module Information | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Engine | 6HK1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|------|-----------|--------------|-------------------------|-----------------------|--|
| JPISUZU | LT Series | 2017 | T310 | Singapore | Engine | 6HK1 | Read Data Stream | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Engine | 6HK1 | Actuation Test | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Engine | Urea SCR | Module Information | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Engine | Urea SCR | Actuation Test | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Transmission | T310 (Gen 5) | Module Information | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Transmission | T310 (Gen 5) | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Transmission | T310 (Gen 5) | Read Data Stream | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Transmission | T310 (Gen 5) | Actuation Test | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Chassis | ABS 8 | Read Data Stream | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Information | CAN CONVERTER(Retarder) | Module Information | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Information | CAN CONVERTER(Retarder) | Read/Clear Fault Code | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Information | CAN CONVERTER(Retarder) | Read Data Stream | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | LT Series | 2017 | T310 | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|------|-----------|--------------|---------------|-----------------------|--|
| JPISUZU | LT Series | 2017 | T310 | Singapore | Information | MIMAMORI | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Engine | 4HK1 | Module Information | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Engine | 4HK1 | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Engine | 4HK1 | Actuation Test | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Engine | Urea SCR | Module Information | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Engine | Urea SCR | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Engine | Urea SCR | Actuation Test | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Transmission | Smoother (MY) | Module Information | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Transmission | Smoother (MY) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Transmission | Smoother (MY) | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Body | SRS(Denso) | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|----------------|-----------|-------------|----------|-----------------------|--|
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Chassis | ABS | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Chassis | ABS 8 | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MZZ | Singapore | Information | MIMAMORI | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smoothen (MZZ) | Singapore | Engine | 4HK1 | Module Information | |
| JPISUZU | N-Series | 2018 | Smoothen (MZZ) | Singapore | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoothen (MZZ) | Singapore | Engine | 4HK1 | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smoothen (MZZ) | Singapore | Engine | 4HK1 | Actuation Test | |
| JPISUZU | N-Series | 2018 | Smoothen (MZZ) | Singapore | Engine | Urea SCR | Module Information | |
| JPISUZU | N-Series | 2018 | Smoothen (MZZ) | Singapore | Engine | Urea SCR | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|--------------------|---------------|--------------|---------------|-----------------------|--|
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Engine | Urea SCR | Actuation Test | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Transmission | Smoother (MY) | Module Information | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Transmission | Smoother (MY) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Transmission | Smoother (MY) | Read Data Strem | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Transmission | Smoother-Ex | Read Data Strem | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2018 | Smoothe r (MZZ) | Singapor e | Chassis | ABS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|----------------|-----------|--------------|-----------------------|-----------------------|--|
| JPISUZU | N-Series | 2018 | Smoother (MZZ) | Singapore | Chassis | ABS | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smoother (MZZ) | Singapore | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2018 | Smoother (MZZ) | Singapore | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoother (MZZ) | Singapore | Chassis | ABS 8 | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smoother (MZZ) | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | N-Series | 2018 | Smoother (MZZ) | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoother (MZZ) | Singapore | Information | MIMAMORI | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Engine | 4JJ1-TC with Urea SCR | Module Information | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Engine | 4JJ1-TC with Urea SCR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Engine | 4JJ1-TC with Urea SCR | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Engine | 4JJ1-TC with Urea SCR | Actuation Test | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Transmission | Smoother (MY) | Module Information | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Transmission | Smoother (MY) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Transmission | Smoother (MY) | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Body | SRS(Denso) | Read Data Stream | |

| | | | | | | | | |
|---------|----------|------|-------------------|-----------|-------------|-----------------------|-----------------------|--|
| JPISUZU | N-Series | 2018 | MY | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Chassis | ABS | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Chassis | ABS 8 | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MY | Singapore | Information | MIMAMORI | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smooth er (MY) | Singapore | Engine | 4JJ1-TC with Urea SCR | Module Information | |
| JPISUZU | N-Series | 2018 | Smooth er (MY) | Singapore | Engine | 4JJ1-TC with Urea SCR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smooth er (MY) | Singapore | Engine | 4JJ1-TC with Urea SCR | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smooth er (MY) | Singapore | Engine | 4JJ1-TC with Urea SCR | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|---------------|-----------|--------------|---------------|-----------------------|--|
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Transmission | Smoother (MY) | Module Information | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Transmission | Smoother (MY) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Transmission | Smoother (MY) | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Transmission | Smoother-Ex | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Body | SRS(Denso) | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Chassis | ABS/ESC | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Chassis | ABS | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Chassis | ABS | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|---------------|-----------|--------------|---------------|-----------------------|--|
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Chassis | ABS 8 | Read Data Stream | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | Smoother (MY) | Singapore | Information | MIMAMORI | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Engine | RZ4E | Module Information | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Engine | RZ4E | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Transmission | Smoother (MY) | Module Information | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Transmission | Smoother (MY) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Transmission | Smoother (MY) | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Body | SRS(Denso) | Read Data Stream | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Body | Immobilizer | Read Data Stream | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|-------------|----------|-----------------------|--|
| JPISUZU | N-Series | 2018 | MVC | Singapore | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MVC | Singapore | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Engine | 4HK1 | Module Information | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Engine | 4HK1 | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|-----|-----------|-------------|----------------|-----------------------|--|
| JPISUZU | F-Series | 2018 | MZW | Singapore | Engine | Urea SCR | Module Information | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Engine | Urea SCR | Actuation Test | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Chassis | ABS 8 | Read Data Strem | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Information | MIMAMORI | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----------------|-----------|--------------|---|-----------------------|--|
| JPISUZU | F-Series | 2018 | MZW | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | F-Series | 2018 | MZW | Singapore | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Engine | 4HK1 | Module Information | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Engine | 4HK1 | Actuation Test | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Engine | Urea SCR | Module Information | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Engine | Urea SCR | Actuation Test | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Transmission | Smoother (MZW) | Module Information | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Transmission | Smoother (MZW) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | Smoothe r (MZW) | Singapore | Transmission | Smoother (MZW) | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|----------------|-----------|--------------|----------------|-----------------------|--|
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Transmission | Smoother-Fx | Module Information | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Transmission | Smoother-Fx | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Transmission | Smoother-Fx | Read Data Stream | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Body | Immobilizer | Read Data Stream | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Body | SRS(Denso) | Read Data Stream | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Chassis | ABS/ASR ADVICS | Read Data Stream | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Chassis | ABS 8 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Chassis | ABS 8 | Read Data Stream | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | F-Series | 2018 | Smoother (MZW) | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------------|------|-------------------|---------------|--------------|--|-----------------------|--|
| JPISUZU | F-Series | 2018 | Smooth r (MZW) | Singapor e | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | F-Series | 2018 | Smooth r (MZW) | Singapor e | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | F-Series | 2018 | Smooth r (MZW) | Singapor e | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | F-Series | 2018 | Smooth r (MZW) | Singapor e | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | F-Series | 2018 | Smooth r (MZW) | Singapor e | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Engine | Urea SCR | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Transmission | Allison 4430(Gen 5) | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Transmission | Allison 4430(Gen 5) | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Transmission | Allison 4430(Gen 5) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapor e | Transmission | Allison 4430(Gen 5) | Actuation Test | |

| | | | | | | | | |
|---------|---------------|------|--------------|-----------|-------------|---|-----------------------|--|
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|---------------|------|--------------|-----------|-------------|------------|-----------------------|--|
| JPISUZU | FXFYGX Series | 2018 | Allison 4430 | Singapore | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Engine | 6UZ1 | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Engine | 6UZ1 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Engine | 6UZ1 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Engine | 6UZ1 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Engine | Urea SCR | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Engine | Urea SCR | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Engine | Urea SCR | Actuation Test | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Chassis | ABS6/IESC | Module Information | |

| | | | | | | | | |
|---------|---------------|------|-----|-----------|-------------|---|-----------------------|--|
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Information | Speedometer Control Device (internal speedometer) | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Information | Speedometer Control Device (internal speedometer) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Information | Speedometer Control Device (stand-alone) | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Information | Speedometer Control Device (stand-alone) | Read Data Strem | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | FXFYGX Series | 2018 | MJT | Singapore | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Engine | Urea SCR | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Engine | Urea SCR | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Engine | Urea SCR | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-----|-----------|-------------|----------------------------|-----------------------|--|
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Engine | Urea SCR | Actuation Test | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Chassis | ABS6/IESC | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Chassis | ABS6/IESC | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Chassis | ABS6/IESC | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Chassis | ABS6/IESC | Actuation Test | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Information | Speedometer Control Device | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJT | Singapore | Information | MIMAMORI | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-------------------|--------|--------|------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Drive Information & Display |

| | | | | | | | | |
|---------|----------|------|-------------------|--------|---------|-------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS/ASR | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|-------------------|--------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | All Accumulation Data Clearing |

| | | | | | | | | |
|---------|----------|------|-----|--------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Engine Log Data Force Recording |

| | | | | | | | | |
|---------|----------|------|-----|--------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | ECU Replacement |

| | | | | | | | | |
|---------|----------|------|-------------------|--------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|-------------------|--------|--------|------------------|-----------------------|---------------------------------------|
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Transmission Log Data Force Recording |

| | | | | | | | | |
|---------|----------|------|-------------------|--------|---------|----------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | Air Suspension | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|-------------------|--------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | Fuller ES11109 | Taiwan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|-----|--------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | MZZ | Taiwan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Engine Log Data Force Recording |

| | | | | | | | | |
|---------|----------|------|-----|--------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | MZW | Taiwan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|--------------------------|------|-----|--------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2011 | 0 | Taiwan | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |

| | | | | | | | | |
|---------|--------------------------|------|-----|--------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Chassis | ABS 6 | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2012 | MZZ | Taiwan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |

| | | | | | | | | |
|---------|--------------------------|------|-----|----------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Chassis | ABS 6 | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2012 | MYY | Taiwan | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |

| | | | | | | | | |
|---------|----------|------|--------------------|----------|---------|------------------|-----------------------|--|
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Module Information | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | MZZ | Taiwan 2 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|----------------|----------|--------------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Engine Type |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Transmission Type |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Tire Size |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Tire Compensation |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Final Gear Ratio |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program ABS Install |

| | | | | | | | | |
|---------|----------|------|----------------|----------|--------------|-------------|-----------------------|--|
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program PTO Setting |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | SRS | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | N-Series | 2013 | Smoother (MZZ) | Taiwan 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |

| | | | | | | | | |
|---------|----------|------|--------------------|----------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | Smoothe r (MZZ) | Taiwan 2 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | ECU Replacement |

| | | | | | | | | |
|---------|----------|------|--------------------|----------|---------|------------------|-----------------------|--|
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2013 | Smoothe r (MYY) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2013 | Smoothe r (MYY) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoothe r (MYY) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smoothe r (MYY) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2013 | Smoothe r (MYY) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | Smoothe r (MYY) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2013 | Smoothe r (MYY) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2013 | Smoothe r (MYY) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |

| | | | | | | | | |
|---------|----------|------|----------------|----------|--------------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Engine Type |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Transmission Type |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Tire Size |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Tire Compensation |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Final Gear Ratio |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program ABS Install |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program PTO Setting |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|----------|------|-------------------|----------|---------|-------------|-----------------------|--|
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smoothe r (MY) | Taiwan 2 | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|----------|------|---------------|----------|--------------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Chassis | ABS/ASR | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Read Data Stream | |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Read Data Stream | |

| | | | | | | | | |
|---------|----------|------|----------------|----------|--------------|-------------|-----------------------|---------------------------|
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Engine Type |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Transmission Type |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Tire Size |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Tire Compensation |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Final Gear Ratio |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program ABS Install |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program PTO Setting |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | Smoother (MYY) | Taiwan 2 | Chassis | ABS/ASR | Read Data Strem | |

| | | | | | | | | |
|---------|-----------------------------|------|--------------------|----------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2013 | Smoothe r (MYY) | Taiwan 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | Smoothe r (MYY) | Taiwan 2 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Taiwan 2 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Engine | 4HK1 | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Engine | 4HK1 | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Engine | 4HK1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|--------------------------|------|-----|----------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Engine | 4HK1 | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2013 | MYY | Taiwan 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Engine | 4HK1 | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Engine | 4HK1 | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Engine | 4HK1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|--------------------------|------|-----|----------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Engine | 4HK1 | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2013 | MZZ | Taiwan 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Engine | 6WG1 | Special Function | Injector Quantity Trim |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Engine | 6WG1 | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Engine | 6WG1 | Special Function | Program VIN |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------------|------|-------------------|----------|-------------|------------------|-----------------------|----------------------------------|
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Chassis | Air Suspension | Module Information | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Information | MIMAMORI | Special Function | DRM Function |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Information | MIMAMORI | Special Function | EDR Function |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Information | MIMAMORI | Special Function | Preventive Maintenance Data |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Information | MIMAMORI | Special Function | ECU Lock |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Information | MIMAMORI | Special Function | Other Functions |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Information | MIMAMORI | Special Function | EOL Data Setting/Change |
| JPISUZU | C&E Series | 2013 | MAP | Taiwan 2 | Information | MIMAMORI | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Engine | 6HK1 (with DOC) | Module Information | |

| | | | | | | | | |
|---------|----------|------|---------------|----------|--------------|-----------------|-----------------------|----------------------------------|
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Engine | 6HK1 (with DOC) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Engine | 6HK1 (with DOC) | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Engine | 6HK1 (with DOC) | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Transmission | Smoother (MZW) | Module Information | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Transmission | Smoother (MZW) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Transmission | Smoother (MZW) | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Transmission | Smoother (MZW) | Special Function | Program Final Gear Ratio |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Transmission | Smoother (MZW) | Special Function | Programming Tire Radius |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Body | BCM | Read Data Stream | |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2014 | Smoother(MZW) | Taiwan 2 | Body | BCM | Special Function | ECU Lock |

| | | | | | | | | |
|---------|----------|------|-------------------|----------|---------|-------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|-------------------|----------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2014 | Smoothe r(MZW) | Taiwan 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1 (with DOC) | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1 (with DOC) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1 (with DOC) | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-----|----------|---------|-----------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1 (with DOC) | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | Air Suspension | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|-----|----------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2014 | MZW | Taiwan 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1 (with DOC) | Module Information | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1 (with DOC) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1 (with DOC) | Read Data Strem | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1 (with DOC) | Actuation Test | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Engine | 6HK1 (with DOC) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|--------------------------|------|-----|----------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2014 | 0 | Taiwan 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Engine | 4HK1 | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Engine | 4HK1 | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Engine | 4HK1 | Special Function | DPD Forced Automatic Regeneration |

| | | | | | | | | |
|---------|--------------------------|------|-----|----------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2014 | MYY | Taiwan 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Engine | 4HK1 | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Engine | 4HK1 | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Engine | 4HK1 | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Engine | 4HK1 | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Engine | 4HK1 | Special Function | Injector ID Code |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Engine | 4HK1 | Special Function | Program VIN |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Engine | 4HK1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Engine | 4HK1 | Special Function | DPD Forced Automatic Regeneration |

| | | | | | | | | |
|---------|--------------------------|------|-----|----------|-------------|----------------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | N-Series(Full air brake) | 2014 | MZZ | Taiwan 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | SRS | Module Information | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | SRS | Read Data Strem | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|--------------------|----------|-------------|----------------------------|-----------------------|--|
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Module Information | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Read Data Strem | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | ECU Replacement |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | ECU Lock |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | Program VIN |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | Vehicle Information |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | Drive Information & Display |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | Engine Log Data Force Recording |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | Transmission Log Data Force Recording |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | Accumulated Engine Log Data Clearing |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | Accumulated Transmission Log Data Clearing |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | Recorded DTC Data Clearing |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Body | BCM | Special Function | All Accumulation Data Clearing |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | ABS/ASR ADVICS | Module Information | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | ABS/ASR ADVICS | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | ABS/ASR ADVICS | Read Data Strem | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | ABS/ASR ADVICS | Actuation Test | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | Air Suspension | Module Information | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | Air Suspension | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | Air Suspension | Read Data Strem | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Chassis | Air Suspension | Actuation Test | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2015 | 0 | Taiwan 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series | 2016 | Smoothe r (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2016 | Smoothe r (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoothe r (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|----------------|----------|--------------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Read Data Stream | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program VIN |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Engine Type |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Transmission Type |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Tire Size |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Tire Compensation |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Final Gear Ratio |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program ABS Install |

| | | | | | | | | |
|---------|----------|------|----------------|----------|--------------|------------------|-----------------------|---------------------|
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program PTO Setting |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2016 | Smoother (MZZ) | Taiwan 2 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|----------|------|-----|----------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MYY | Taiwan 2 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Body | SRS(Denso) | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-------------------|----------|--------------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MZZ | Taiwan 2 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Transmission | Smoother-Ex | Module Information | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Transmission | Smoother-Ex | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Transmission | Smoother-Ex | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|---------------|----------|--------------|-------------|-----------------------|---------------------------|
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program VIN |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Engine Type |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Transmission Type |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Tire Size |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Tire Compensation |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program Final Gear Ratio |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program ABS Install |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Transmission | Smoother-Ex | Special Function | Program PTO Setting |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Body | Immobilizer | Read Data Stream | |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Body | SRS(Denso) | Read Data Stream | |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoother (MY) | Taiwan 2 | Chassis | ABS/ESC | Read Data Stream | |

| | | | | | | | | |
|---------|------------|------|-------------------|----------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2016 | Smoothe r (MY) | Taiwan 2 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Body | Immobilizer | Module Information | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2016 | MY | Taiwan 2 | Chassis | ABS | Actuation Test | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Engine | 6WG1 | Module Information | |

| | | | | | | | | |
|---------|------------|------|-----|-----------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | C&E Series | 2018 | MAP | Taiwan 2 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Engine | 4JJ1-TC | Module Information | |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Engine | 4JJ1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Engine | 4JJ1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Engine | 4JJ1-TC | Actuation Test | |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2011 | MYV | Vietnam 1 | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|---------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-----|--------------|---------|-------------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2011 | MYY | Vietnam 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------------|------|-----|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2011 | MZZ | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|--------------|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2011 | MZW | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|------------|------|--------------|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2011 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Module Information | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Actuation Test | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|---------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|---------|-----------------------|-------------------------------|
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2012 | MYY | Vietnam 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JJ1 | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|--|
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MSG | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-----|--------------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------------|------|-----|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2012 | MZZ | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|--------------|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2012 | MZW | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|------------|------|--------------|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2012 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|---------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MYY | Vietnam 1 | Body | SRS | Read Data Strem | |

| | | | | | | | | | |
|---------|----------|------|---------|---------|---|---------|---------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2013 | MY | Vietnam | 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2013 | MY | Vietnam | 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2013 | MY | Vietnam | 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2013 | MY | Vietnam | 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2013 | MY | Vietnam | 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | ZF9S111 | Vietnam | 1 | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|--------------|--------------|-------------|----------------------------|-----------------------|-------------------------------------|
| JPISUZU | F-Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F-Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F-Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F-Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F-Series | 2013 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F-Series | 2013 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MSG | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-----------------------------------|
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|--------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | AT(Aisin AW) | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | AT(Aisin AW) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | AT(Aisin AW) | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | AT(Aisin AW) | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | AT(Aisin AW) | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|--------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | AT(Aisin AW) | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | AT(Aisin AW) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | AT(Aisin AW) | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | AT(Aisin AW) | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | AT(Aisin AW) | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|---------|--------------|---------|------------------|-----------------------|---|
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Special Function | Download Fuel Delivery Rate |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-------|--------------|---------|------------------|-----------------------|-----------------------------|
| JPISUZU | C&E Series | 2013 | MJT | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Special Function | Download Fuel Delivery Rate |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Engine | 6WF1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2013 | MJX16 | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-----|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | MZZ | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-----|--------------|---------|---------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|--------------|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | MZW | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|------------|------|--------------|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2013 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Actuation Test | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|---------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2014 | MYY | Vietnam 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |

| | | | | | | | | |
|---------|------------|------|-----|--------------|---------|-------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-----|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2014 | MZZ | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------------|------|--------------|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2014 | MZW | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|--------------|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2014 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Module Information | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Actuation Test | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4JJ1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|---------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | N-Series | 2015 | MYY | Vietnam 1 | Chassis | ABS/ASR | Special Function | Programming Rear Tire Radius |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | MSG | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|------------|------|---------|--------------|---------|-------------|-----------------------|--|
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Engine | 4HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Chassis | ABS 6 | Module Information | |

| | | | | | | | | |
|---------|------------|------|-----|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2015 | MZZ | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Chassis | ABS/ASR | Module Information | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|--------------|--------------|-------------|----------------------------|-----------------------|----------------------------------|
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2015 | MZW | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Module Information | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Actuation Test | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Upload Fuel Delivery Rate |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Download Fuel Delivery Rate |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Program VIN |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Engine | 6HK1-TC | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Module Information | |

| | | | | | | | | |
|---------|------------|------|--------------|--------------|--------------|----------------------------|-----------------------|-------------------------------|
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Chassis | ABS/ASR | Actuation Test | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | F&G Series | 2015 | ZF9S111 0 | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-----------------------------------|
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|--|
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2015 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---|-----------------------|---|
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|-------------|-----------------------|--|
| JPISUZU | UC Series | 2015 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---|-----------------------|---|
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2016 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|---|
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---|-----------------------|---|
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|--|
| JPISUZU | UC Series | 2016 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---|-----------------------|---|
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2016 | TB50-LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | N-Series | 2017 | MYV | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|------------------|-----------------------|-----------------------------------|
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Regeneration Data Reset |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|-----------|-----------------------|----------------------------------|
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Module Information | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Actuation Test | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Special Function | Program VIN |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Special Function | Injector ID Code |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Special Function | PTO Throttle 0Voltage |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Special Function | PTO Throttle 100Voltage |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Special Function | PTO Use Mode |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|------------|-----------------------|------------------------|
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Special Function | PTO Selector Switch |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Special Function | Tachometer Pulse Count |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MSB | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HV1 CNG | Module Information | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HV1 CNG | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HV1 CNG | Read Data Strem | |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HV1 CNG | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------|------------------|-----------------------|------------------------------------|
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HV1 CNG | Special Function | Clear Injection Learned Value |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HV1 CNG | Special Function | Clear Air Fuel Ratio Threshold |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HV1 CNG | Special Function | Clear Throttle Idle Learned Value |
| JPISUZU | N-Series | 2017 | MYY | Vietnam 1 | Engine | 4HV1 CNG | Special Function | Clear Close Throttle Learned Value |
| JPISUZU | F-Series | 2017 | MZZ | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F-Series | 2017 | MZZ | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F-Series | 2017 | MZZ | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F-Series | 2017 | MZZ | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F-Series | 2017 | MZZ | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F-Series | 2017 | MZZ | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F-Series | 2017 | MZZ | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F-Series | 2017 | MZZ | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MUX | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-----------------------------------|
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|-------------|-----------------------|-------------------------------|
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Stream | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Stream | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Stream | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MSG | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---|-----------------------|---|
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|--|
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | RZ4E | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | RZ4E | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | RZ4E | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | RZ4E | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | RZ4E | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | RZ4E | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Engine | RZ4E | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Immobilizer | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|---|
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|--------------|---------|-----------------------|--|
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Special Function | DPD Regeneration Data Reset |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|--------------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|-------------------|--------------|---------|------------------|-----------------------|---|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | F&G Series | 2017 | MZW | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F&G Series | 2017 | MZW | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2017 | MZW | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | F&G Series | 2017 | MZW | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series | 2017 | MZW | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F&G Series | 2017 | MZW | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2017 | MZW | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F&G Series | 2017 | MZW | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2017 | MZW | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | F&G Series | 2017 | Fuller ES11109 | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Module Information | |
| JPISUZU | F&G Series | 2017 | Fuller ES11109 | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | F&G Series | 2017 | Fuller ES11109 | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Read Data Strem | |

| | | | | | | | | |
|---------|------------|------|-------------------|--------------|--------------|------------------|-----------------------|-----------------------------------|
| JPISUZU | F&G Series | 2017 | Fuller ES11109 | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Actuation Test | |
| JPISUZU | F&G Series | 2017 | Fuller ES11109 | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector Quantity Trim |
| JPISUZU | F&G Series | 2017 | Fuller ES11109 | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Special Function | Injector ID Code |
| JPISUZU | F&G Series | 2017 | Fuller ES11109 | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Special Function | Program VIN |
| JPISUZU | F&G Series | 2017 | Fuller ES11109 | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Special Function | Fuel Supply Pump Learn Resetting |
| JPISUZU | F&G Series | 2017 | Fuller ES11109 | Vietnam 1 | Engine | 6HK1-TC (C/Rail) | Special Function | DPD Forced Automatic Regeneration |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|--------------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Regeneration Data Reset |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Engine | 4JJ1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | SRS | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MVL | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | AT | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---------|-----------------------|---|
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | TB-50LS | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | DPD Regeneration Data Reset |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | DPD Dilution Trip Data Reset |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Engine | 4JK1 | Special Function | Program VIN |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---|-----------------------|-------------------------------------|
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|--------|-------------|--------------|--------------|---------|-----------------------|---|
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017 | MUA | Vietnam 1 | Chassis | TPMS | Special Function | Programming TPMS Sensor ID |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|--------|-------------|--------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |

| | | | | | | | | |
|---------|-----------|--------|-------------|--------------|---------|-------------------------|-----------------------|--|
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Actuation Test | |

| | | | | | | | | |
|---------|-----------|--------|-------------|--------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|--------|-------------|--------------|---------|---|-----------------------|--|
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Engine | RZ4E | Module Information | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Engine | RZ4E | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|--------|-----|--------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Engine | RZ4E | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Engine | RZ4E | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |

| | | | | | | | | |
|---------|-----------|--------|-----|--------------|---------|-------------------------|-----------------------|--|
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2017.5 | MVL | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Engine | 4HK1-TC (C/Rail) | Actuation Test | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|------------------|-----------------------|--|
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Body | SRS(Denso) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|------------|-----------------------|--|
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MYY | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Module Information | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Engine | 4JH1/4KH1 | Actuation Test | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS | Module Information | |

| | | | | | | | | |
|---------|----------|------|-----|--------------|---------|------------------|-----------------------|--|
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Module Information | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Engine | 4JJ1-TC (C/Rail) | Actuation Test | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Body | SRS(Denso) | Module Information | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS | Module Information | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|--|
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS | Actuation Test | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | N-Series | 2018 | MSB | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUX | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|--------------|-------------|-----------------------|--|
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | SRS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Engine | 4JJ1 | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | TPMS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|--|
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|-------------|-----------------------|--|
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | AY6 | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---------|-----------------------|--|
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MSG | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Engine | RZ4E | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Engine | RZ4E | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Engine | RZ4E | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |

| | | | | | | | | |
|---------|------------|------|-----|--------------|---------|---|-----------------------|--|
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Engine | 6WG1 | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|-------|--------------|-------------|----------------------------|-----------------------|--|
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | C&E Series | 2018 | MJT | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Engine | 6WG1 | Module Information | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|------------|------|-------------|--------------|--------------|----------------------------|-----------------------|--|
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Information | MIMAMORI | Module Information | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Information | MIMAMORI | Read/Clear Fault Code | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Information | MIMAMORI | Read Data Strem | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Information | Speedometer Control Device | Module Information | |
| JPISUZU | C&E Series | 2018 | MJX16 | Vietnam 1 | Information | Speedometer Control Device | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|--------------|-------------|-----------------------|--|
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|--|
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MVL | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JJ1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|-------------|-----------------------|--|
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|---------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|--------------|---------|-----------------------|--|
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | MUA | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Engine | 4JK1 | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Transmission | TCCM | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|---------|--------------|------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Head Lamp Auto Leveling | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|--------------|---------|-----------------------|--|
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | TB-50LS | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Engine | RZ4E | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | AT | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|--------------|---|-----------------------|--|
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Transmission | TCCM | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Immobilizer | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Meter | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | SRS | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | SRS | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | BCM | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | BCM | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-------------|--------------|---------|-------------------------|-----------------------|--|
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Body | Head Lamp Auto Leveling | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | ABS/ESC | Actuation Test | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Module Information | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read/Clear Fault Code | |
| JPISUZU | UC Series | 2018 | AWR6B4 5 | Vietnam 1 | Chassis | TPMS | Read Data Strem | |
| JPISUZU | LV Series | 2018 | MJT | Vietnam 1 | Engine | 6WG1 | Module Information | |
| JPISUZU | LV Series | 2018 | MJT | Vietnam 1 | Engine | 6WG1 | Read/Clear Fault Code | |
| JPISUZU | LV Series | 2018 | MJT | Vietnam 1 | Engine | 6WG1 | Read Data Strem | |
| JPISUZU | LV Series | 2018 | MJT | Vietnam 1 | Engine | 6WG1 | Actuation Test | |
| JPISUZU | LV Series | 2018 | MJT | Vietnam 1 | Chassis | ABS 6 | Module Information | |
| JPISUZU | LV Series | 2018 | MJT | Vietnam 1 | Chassis | ABS 6 | Read/Clear Fault Code | |
| JPISUZU | LV Series | 2018 | MJT | Vietnam 1 | Chassis | ABS 6 | Read Data Strem | |
| JPISUZU | LV Series | 2018 | MJT | Vietnam 1 | Chassis | ABS 6 | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-----|--------------|--------------|-------------|-----------------------|---|
| JPISUZU | Q Series | 2018 | MSB | Vietnam 1 | Engine | 4JH1 | Module Information | |
| JPISUZU | Q Series | 2018 | MSB | Vietnam 1 | Engine | 4JH1 | Read/Clear Fault Code | |
| JPISUZU | Q Series | 2018 | MSB | Vietnam 1 | Engine | 4JH1 | Read Data Strem | |
| JPISUZU | Q Series | 2018 | MSB | Vietnam 1 | Engine | 4JH1 | Actuation Test | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Engine | 4JK1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | MUX | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Transmission | AT | Special Function | Program VIN |

| | | | | | | | | |
|---------|-----------|------|---------|----------|---------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2012 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |

| | | | | | | | | |
|---------|-----------|------|-----|----------|--------------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUX | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | PESS | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | PESS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | PESS | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | PESS | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | PESS | Special Function | Vehicle Configuration Setting |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|-----------------------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer with PESS | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer with PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer with PESS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer with PESS | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer with PESS | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer with PESS | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer with PESS | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Body | Immobilizer with PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |

| | | | | | | | | |
|---------|-----------|------|---------|----------|---------|-----------------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|-------------|-----------------------|---|
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Engine | 4JK1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|-----------------------|-----------------------|---|
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | PESS | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | PESS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | PESS | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | PESS | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | PESS | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer with PESS | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer with PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer with PESS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer with PESS | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer with PESS | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer with PESS | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer with PESS | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Body | Immobilizer with PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | AT | Special Function | Program VIN |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|-----------------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | PESS | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|----------------------------------|-----------------------|---|
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2013 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer with PESS | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|----------|---------|-----------------------|-----------------------|---|
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer with PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer with PESS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer with PESS | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer with PESS | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer with PESS | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer with PESS | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Immobilizer with PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | PESS | Module Information | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | PESS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | PESS | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | PESS | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | PESS | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|----------------------------------|-----------------------|---|
| JPISUZU | TF Series | 2014 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Meter | Special Function | Clock Display Setting |

| | | | | | | | | |
|---------|-----------|------|---------|----------|---------|----------------------------------|-----------------------|---|
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Engine | 4JK1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-----|----------|--------------|-----------------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2014 | MUA | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer with PESS | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer with PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer with PESS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer with PESS | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer with PESS | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer with PESS | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer with PESS | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Immobilizer with PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | PESS | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | PESS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | PESS | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | PESS | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | PESS | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|----------------------------------|-----------------------|---|
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2014 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |

| | | | | | | | | |
|---------|-----------|------|---------|----------|---------|-----------------------|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Immobilizer with PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Special Function | Program VIN |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | PESS | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|--|-----------------------|---|
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2014 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|--|-----------------------|---|
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|----------|------|--|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | SRS | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|--|-----------------------|---|
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Engine | 4JK1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|--|-----------------------|---|
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Engine | 4JK1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | TCCM | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|--|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |

| | | | | | | | | |
|---------|-----------|------|---------|----------|--------------|----------------------------------|-----------------------|---|
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2015 | TB-50LS | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | ISS | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | ISS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | ISS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |

| | | | | | | | | |
|---------|-----------|------|---|----------|---------|--|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|----------|--------------|----------------------------------|-----------------------|---|
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|----------|--------------|--|-----------------------|---|
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2016 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Engine | 4JK1 | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Engine | 4JK1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Engine | 4JK1 | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Engine | 4JK1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Engine | 4JK1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Engine | 4JK1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Transmission | TCCM | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|----------|--------------|--|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2016 | MUA | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |

| | | | | | | | | |
|---------|-----------|------|-----|----------|--------------|--|-----------------------|---|
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2016 | MUA | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | RZ4E | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | RZ4E | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | RZ4E | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | RZ4E | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | RZ4E | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | ISS | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | ISS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Engine | ISS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|---|----------|---------|--|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|----------|--------------|----------------------------------|-----------------------|---|
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2016 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Engine | RZ4E | Module Information | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Engine | RZ4E | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Engine | RZ4E | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Engine | RZ4E | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Engine | RZ4E | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Meter | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|----------|---------|--|-----------------------|---|
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | SRS | Module Information | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | SRS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Body | SRS | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2016 | MVL | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|----------|--------------|--|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | MUX | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |

| | | | | | | | | |
|---------|-----------|------|-----|----------|--------------|----------------------------------|-----------------------|---|
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | SRS(Denso) | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MUX | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | 4JJ1 | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | 4JJ1 | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | 4JJ1 | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | 4JJ1 | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | 4JJ1 | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | 4JJ1 | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | ISS | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | ISS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | ISS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Read/Clear Fault Code | |

| | | | | | | | | |
|---------|-----------|------|-------------|----------|------|---|-----------------------|-------------------------------------|
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | SRS(Denso) | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | SRS(Denso) | Read Data Strem | |

| | | | | | | | | |
|---------|-----------|------|-----|----------|--------------|--|-----------------------|---|
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Engine | RZ4E | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Engine | RZ4E | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Engine | RZ4E | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Engine | RZ4E | Special Function | Vehicle Speed Correction Data |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Engine | RZ4E | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |

| | | | | | | | | |
|---------|-----------|------|-----|----------|---------|--|-----------------------|---|
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | SRS(Denso) | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | MVL | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | RZ4E | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | RZ4E | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | RZ4E | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | RZ4E | Special Function | Injector ID Code |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | RZ4E | Special Function | Vehicle Speed Correction Data |

| | | | | | | | | |
|---------|-----------|------|---|----------|--------------|--|-----------------------|---|
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | RZ4E | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | ISS | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | ISS | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | ISS | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | IBS (Intelligent Battery System) | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Engine | IBS (Intelligent Battery System) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | AT | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | AT | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | AT | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | AT | Actuation Test | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | AT | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | TCCM | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | TCCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Transmission | TCCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Program Transponder-Keys |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Erase Transponder-Keys |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Reset Engine Control Module |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Reset Immobilizer |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Program Immobilizer Function |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Immobilizer | Special Function | Program VIN |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Meter | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Meter | Special Function | Clock Display Setting |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Meter | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Meter | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Actuation Test | |

| | | | | | | | | |
|---------|-----------|------|-------------|----------|---------|---|-----------------------|---|
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | AWR6B4 5 | Thailand | Body | Passive Entry and Start System (Push Type) | Special Function | Vehicle Configuration Setting |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Special Function | BCM Data Setting/Change |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Special Function | Door Unlocking Timing Setting |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Special Function | BCM Data Upload |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | BCM | Special Function | BCM Data Download |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | SRS(Denso) | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | SRS(Denso) | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Body | SRS(Denso) | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Module Information | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Read/Clear Fault Code | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Read Data Strem | |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Program VIN (Vehicle Identification Number) |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Upload Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Download Vehicle Configuration Data |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Learning For Steering Central Position |
| JPISUZU | TF Series | 2017 | 5 | Thailand | Chassis | ABS/ESC | Special Function | Learning For S-Sensor Central Position |