

LANDROVER JAGUAR Diagnostics List
(Note:For reference only)

make	model	year	system	function	subfunction
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Adaption clear
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Boost pressure actuator replacement
LANDROVER	Freelander 2	2007 - 2010	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Transmission control module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Transmission control module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Transmission control module	Special Function	Adaption clear
LANDROVER	Freelander 2	2007 - 2010	Transmission control module	Special Function	Gear selector sensor calibration
LANDROVER	Freelander 2	2007 - 2010	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Anti-lock Braking System	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Anti-lock Braking System	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Anti-lock Braking System	Special Function	Lateral accelerometer calibration
LANDROVER	Freelander 2	2007 - 2010	Anti-lock Braking System	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Freelander 2	2007 - 2010	Anti-lock Braking System	Special Function	Pressure sensor calibration
LANDROVER	Freelander 2	2007 - 2010	Anti-lock Braking System	Special Function	Roll rate sensor calibration
LANDROVER	Freelander 2	2007 - 2010	Anti-lock Braking System	Special Function	Yaw Rate sensor calibration
LANDROVER	Freelander 2	2007 - 2010	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Freelander 2	2007 - 2010	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Instrument cluster control module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Instrument cluster control module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Freelander 2	2007 - 2010	Instrument cluster control module	Special Function	Fuel consumption units
LANDROVER	Freelander 2	2007 - 2010	Instrument cluster control module	Special Function	Message centre display contrast
LANDROVER	Freelander 2	2007 - 2010	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Body control module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Body control module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Body control module	Special Function	Sunroof calibration
LANDROVER	Freelander 2	2007 - 2010	Body control module	Special Function	Security - Keyfob remote functionality
LANDROVER	Freelander 2	2007 - 2010	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Freelander 2	2007 - 2010	Body control module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Freelander 2	2007 - 2010	Body control module	Special Function	Battery replacement
LANDROVER	Freelander 2	2007 - 2010	Body control module	Special Function	Program keys
LANDROVER	Freelander 2	2007 - 2010	Body control module	Special Function	Transportation mode
LANDROVER	Freelander 2	2007 - 2010	Body control module	Special Function	Tire pressure monitor transmitter functionality
LANDROVER	Freelander 2	2007 - 2010	Body control module	Special Function	Crash status reset
LANDROVER	Freelander 2	2007 - 2010	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Heating ventilation and air conditioning control module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Heating ventilation and air conditioning control module	Special Function	Humidity sensor replacement
LANDROVER	Freelander 2	2007 - 2010	Heating ventilation and air conditioning control module	Special Function	Seat heater module calibration
LANDROVER	Freelander 2	2007 - 2010	Heating ventilation and air conditioning control module	Special Function	Stepper motor replacement
LANDROVER	Freelander 2	2007 - 2010	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
LANDROVER	Freelander 2	2007 - 2010	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Steering angle sensor module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Steering angle sensor module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Parking assist control module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Parking assist control module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Freelander 2	2007 - 2010	Auxiliary heater control module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Auxiliary heater control module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Auxiliary heater control module	Special Function	Auxiliary heater activation test
LANDROVER	Freelander 2	2007 - 2010	Auxiliary heater control module	Special Function	Auxiliary heater fuel delivery test
LANDROVER	Freelander 2	2007 - 2010	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Driver's door module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Driver's door module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Driver's door module	Special Function	Driver's door window glass calibration
LANDROVER	Freelander 2	2007 - 2010	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Driver's seat module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Driver's seat module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Freelander 2	2007 - 2010	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Passenger's door module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Passenger's door module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Passenger's door module	Special Function	Passenger's door window glass calibration
LANDROVER	Freelander 2	2007 - 2010	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	All terrain control module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	All terrain control module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Rear differential control module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Rear differential control module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Restraints occupant classification system module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Restraints occupant classification system module	Special Function	Seats - Seat cover replacement
LANDROVER	Freelander 2	2007 - 2010	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Headlamp Control Module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Headlamp Control Module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Freelander 2	2007 - 2010	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Audio amplifier module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Audio amplifier module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2007 - 2010	Audio front control module	Read Data Stream	
LANDROVER	Freelander 2	2007 - 2010	Audio front control module	Version Information	
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Injector replacement
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Diesel fueling adaption re - initialization
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Exhaust gas recirculation replacement
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Diesel particulate filter air temperature sensor replacement
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Diesel lambda sensor replacement
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Idle speed - Adjustment
LANDROVER	Freelander 2	2007 - 2010	Powertrain control module	Special Function	Display injector correction factors
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Adaption clear
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Boost pressure actuator replacement
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Diesel fueling adaption re - initialization
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Injector replacement
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Idle speed - Adjustment
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Fuel Prime Routine
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Powertrain control module adaption clear
LANDROVER	Freelander 2	2011 - 2012	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Freelander 2	2011 - 2012	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Transmission control module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Transmission control module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Transmission control module	Special Function	Adaption clear
LANDROVER	Freelander 2	2011 - 2012	Transmission control module	Special Function	Gear selector sensor calibration

make	model	year	system	function	subfunction
LANDROVER	Freelander 2	2011 - 2012	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Anti-lock Braking System	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Anti-lock Braking System	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Anti-lock Braking System	Special Function	Yaw Rate sensor calibration
LANDROVER	Freelander 2	2011 - 2012	Anti-lock Braking System	Special Function	Lateral accelerometer calibration
LANDROVER	Freelander 2	2011 - 2012	Anti-lock Braking System	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Freelander 2	2011 - 2012	Anti-lock Braking System	Special Function	Pressure sensor calibration
LANDROVER	Freelander 2	2011 - 2012	Anti-lock Braking System	Special Function	Roll rate sensor calibration
LANDROVER	Freelander 2	2011 - 2012	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Freelander 2	2011 - 2012	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Instrument cluster control module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Instrument cluster control module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Freelander 2	2011 - 2012	Instrument cluster control module	Special Function	Fuel consumption units
LANDROVER	Freelander 2	2011 - 2012	Instrument cluster control module	Special Function	Message centre display contrast
LANDROVER	Freelander 2	2011 - 2012	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Body control module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Body control module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Body control module	Special Function	Sunroof calibration
LANDROVER	Freelander 2	2011 - 2012	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Freelander 2	2011 - 2012	Body control module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Freelander 2	2011 - 2012	Body control module	Special Function	Battery replacement
LANDROVER	Freelander 2	2011 - 2012	Body control module	Special Function	Security - Keyfob remote functionality
LANDROVER	Freelander 2	2011 - 2012	Body control module	Special Function	Program keys
LANDROVER	Freelander 2	2011 - 2012	Body control module	Special Function	Crash status reset
LANDROVER	Freelander 2	2011 - 2012	Body control module	Special Function	Transportation mode
LANDROVER	Freelander 2	2011 - 2012	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Heating ventilation and air conditioning control module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Heating ventilation and air conditioning control module	Special Function	Humidity sensor replacement
LANDROVER	Freelander 2	2011 - 2012	Heating ventilation and air conditioning control module	Special Function	Seat heater module calibration
LANDROVER	Freelander 2	2011 - 2012	Heating ventilation and air conditioning control module	Special Function	Stepper motor replacement
LANDROVER	Freelander 2	2011 - 2012	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
LANDROVER	Freelander 2	2011 - 2012	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Steering angle sensor module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Steering angle sensor module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Parking assist control module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Parking assist control module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Auxiliary heater control module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Auxiliary heater control module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Auxiliary heater control module	Special Function	Auxiliary heater priming routine
LANDROVER	Freelander 2	2011 - 2012	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Driver's door module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Driver's door module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Driver's door module	Special Function	Driver's door window glass calibration
LANDROVER	Freelander 2	2011 - 2012	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Driver's seat module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Driver's seat module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Freelander 2	2011 - 2012	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Passenger's door module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Passenger's door module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Passenger's door module	Special Function	Passenger's door window glass calibration
LANDROVER	Freelander 2	2011 - 2012	All terrain control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Freelander 2	2011 - 2012	All terrain control module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	All terrain control module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Rear differential control module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Rear differential control module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Restraints occupant classification system module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Headlamp Control Module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Headlamp Control Module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Freelander 2	2011 - 2012	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Audio amplifier module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Audio amplifier module	Version Information	
LANDROVER	Freelander 2	2011 - 2012	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	2011 - 2012	Audio front control module	Read Data Stream	
LANDROVER	Freelander 2	2011 - 2012	Audio front control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Adaption clear
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Injector valve test
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Fuel Lift Pump
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Service interval reset
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Freelander 2	As of 2013	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Transmission control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Transmission control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Transmission control module	Special Function	Transmission control module oil counter reset
LANDROVER	Freelander 2	As of 2013	Transmission control module	Special Function	Adaption clear
LANDROVER	Freelander 2	As of 2013	Transmission control module	Special Function	Gear selector sensor calibration
LANDROVER	Freelander 2	As of 2013	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Anti-lock Braking System	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Anti-lock Braking System	Version Information	
LANDROVER	Freelander 2	As of 2013	Anti-lock Braking System	Special Function	Steering wheel angle sensor calibration
LANDROVER	Freelander 2	As of 2013	Anti-lock Braking System	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Freelander 2	As of 2013	Anti-lock Braking System	Special Function	Lateral accelerometer calibration
LANDROVER	Freelander 2	As of 2013	Anti-lock Braking System	Special Function	Pressure sensor calibration
LANDROVER	Freelander 2	As of 2013	Anti-lock Braking System	Special Function	Roll rate sensor calibration
LANDROVER	Freelander 2	As of 2013	Anti-lock Braking System	Special Function	ABS configuration clear
LANDROVER	Freelander 2	As of 2013	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Freelander 2	As of 2013	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Freelander 2	As of 2013	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Instrument cluster control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Instrument cluster control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Freelander 2	As of 2013	Instrument cluster control module	Special Function	Vehicle reset
LANDROVER	Freelander 2	As of 2013	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Body control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Body control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Freelander 2	As of 2013	Body control module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Freelander 2	As of 2013	Body control module	Special Function	Tire pressure monitor sensor identification display
LANDROVER	Freelander 2	As of 2013	Body control module	Special Function	Valet mode reset
LANDROVER	Freelander 2	As of 2013	Body control module	Special Function	Battery replacement
LANDROVER	Freelander 2	As of 2013	Body control module	Special Function	Sunroof calibration
LANDROVER	Freelander 2	As of 2013	Body control module	Special Function	Fuel pump supply - Enable/disable
LANDROVER	Freelander 2	As of 2013	Body control module	Special Function	Verify Keys
LANDROVER	Freelander 2	As of 2013	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Heating ventilation and air conditioning control module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Freelander 2	As of 2013	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
LANDROVER	Freelander 2	As of 2013	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Freelander 2	As of 2013	Heating ventilation and air conditioning control module	Special Function	Re - program all stepper motors
LANDROVER	Freelander 2	As of 2013	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Steering angle sensor module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Steering angle sensor module	Version Information	
LANDROVER	Freelander 2	As of 2013	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Freelander 2	As of 2013	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Parking brake control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Parking brake control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Freelander 2	As of 2013	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Freelander 2	As of 2013	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Freelander 2	As of 2013	Parking brake control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Freelander 2	As of 2013	Parking brake control module	Special Function	Parking brake activation
LANDROVER	Freelander 2	As of 2013	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Parking assist control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Parking assist control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Auxiliary heater control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Auxiliary heater control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Auxiliary heater control module	Special Function	Auxiliary heater priming routine
LANDROVER	Freelander 2	As of 2013	Auxiliary heater control module	Special Function	Auxiliary heater activation test
LANDROVER	Freelander 2	As of 2013	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Vehicle immobilizer control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Driver's door module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Driver's door module	Version Information	
LANDROVER	Freelander 2	As of 2013	Driver's door module	Special Function	Driver's door window glass calibration
LANDROVER	Freelander 2	As of 2013	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Driver's seat module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Driver's seat module	Version Information	
LANDROVER	Freelander 2	As of 2013	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Freelander 2	As of 2013	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Passenger's door module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Passenger's door module	Version Information	
LANDROVER	Freelander 2	As of 2013	Passenger's door module	Special Function	Passenger's door window glass calibration
LANDROVER	Freelander 2	As of 2013	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
LANDROVER	Freelander 2	As of 2013	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	All terrain control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	All terrain control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Transfer case control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Transfer case control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Speed control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Speed control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Rear differential control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Rear differential control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Rear differential control module	Special Function	Control module calibration

make	model	year	system	function	subfunction
LANDROVER	Freelander 2	As of 2013	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Restraints occupant classification system module	Version Information	
LANDROVER	Freelander 2	As of 2013	Restraints occupant classification system module	Special Function	Seats - Seat cover replacement
LANDROVER	Freelander 2	As of 2013	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Headlamp Control Module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Headlamp Control Module	Version Information	
LANDROVER	Freelander 2	As of 2013	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Freelander 2	As of 2013	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Keyless vehicle module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Keyless vehicle module	Version Information	
LANDROVER	Freelander 2	As of 2013	Keyless vehicle module	Special Function	Check all antennas
LANDROVER	Freelander 2	As of 2013	Keyless vehicle module	Special Function	Check passive keys enabled
LANDROVER	Freelander 2	As of 2013	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Audio amplifier module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Audio amplifier module	Version Information	
LANDROVER	Freelander 2	As of 2013	Audio amplifier module	Special Function	DVD region counter reset
LANDROVER	Freelander 2	As of 2013	Audio amplifier module	Special Function	Calibrate dynamic volume control
LANDROVER	Freelander 2	As of 2013	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Image processing module B	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Image processing module B	Version Information	
LANDROVER	Freelander 2	As of 2013	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander 2	As of 2013	Audio front control module	Read Data Stream	
LANDROVER	Freelander 2	As of 2013	Audio front control module	Version Information	
LANDROVER	Freelander 2	As of 2013	Audio front control module	Special Function	Navigation reset
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Injector replacement
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Idle speed - Adjustment
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Display injector correction factors
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Diesel fueling adaption re - initialization
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Turbine shut - off valve
LANDROVER	Freelander 2	As of 2013	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Defender	2007 - 2010	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	2007 - 2010	Powertrain control module	Read Data Stream	
LANDROVER	Defender	2007 - 2010	Powertrain control module	Version Information	
LANDROVER	Defender	2007 - 2010	Powertrain control module	Special Function	Injector replacement
LANDROVER	Defender	2007 - 2010	Powertrain control module	Special Function	Pilot correction learning
LANDROVER	Defender	2007 - 2010	Powertrain control module	Special Function	Pre - delivery inspection
LANDROVER	Defender	2007 - 2010	Powertrain control module	Special Function	Pump replacement
LANDROVER	Defender	2007 - 2010	Powertrain control module	Special Function	Speed limitation
LANDROVER	Defender	2007 - 2010	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	2007 - 2010	Instrument cluster control module	Read Data Stream	
LANDROVER	Defender	2007 - 2010	Instrument cluster control module	Version Information	
LANDROVER	Defender	2007 - 2010	Instrument cluster control module	Special Function	Speed limitation
LANDROVER	Defender	2007 - 2010	Instrument cluster control module	Special Function	Tyre circumference
LANDROVER	Defender	2007 - 2010	Instrument cluster control module	Special Function	Fuel tank volume
LANDROVER	Defender	2011	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	2011	Powertrain control module	Read Data Stream	
LANDROVER	Defender	2011	Powertrain control module	Version Information	
LANDROVER	Defender	2011	Powertrain control module	Special Function	Injector replacement
LANDROVER	Defender	2011	Powertrain control module	Special Function	Pilot correction learning
LANDROVER	Defender	2011	Powertrain control module	Special Function	Pre - delivery inspection
LANDROVER	Defender	2011	Powertrain control module	Special Function	Pump replacement
LANDROVER	Defender	2011	Powertrain control module	Special Function	Speed limitation
LANDROVER	Defender	2011	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	2011	Anti-lock Braking System	Read Data Stream	
LANDROVER	Defender	2011	Anti-lock Braking System	Version Information	
LANDROVER	Defender	2011	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	2011	Instrument cluster control module	Read Data Stream	
LANDROVER	Defender	2011	Instrument cluster control module	Version Information	
LANDROVER	Defender	As of 2012	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	As of 2012	Powertrain control module	Read Data Stream	
LANDROVER	Defender	As of 2012	Powertrain control module	Version Information	
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Adaption clear
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration

make	model	year	system	function	subfunction
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Injector valve test
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Oil change reset
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Diesel particulate filter reset
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Exhaust gas recirculation throttle replacement reset
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	High pressure fuel pump replacement reset
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Lambda sensor gain adjustment reset
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Injector replacement resets
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Exhaust gas recirculation valve replacement reset
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Turbocharger replacement reset
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Mass air flow sensor replacement reset
LANDROVER	Defender	As of 2012	Powertrain control module	Special Function	Diesel particulate filter pressure sensor replacement reset
LANDROVER	Defender	As of 2012	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	As of 2012	Anti-lock Braking System	Read Data Stream	
LANDROVER	Defender	As of 2012	Anti-lock Braking System	Version Information	
LANDROVER	Defender	As of 2012	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	As of 2012	Instrument cluster control module	Read Data Stream	
LANDROVER	Defender	As of 2012	Instrument cluster control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Special Function	Adaption clear
LANDROVER	Discovery III	2005 - 2009	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Transmission control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Transmission control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Transmission control module	Special Function	Adaption clear
LANDROVER	Discovery III	2005 - 2009	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Anti-lock Braking System	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Anti-lock Braking System	Version Information	
LANDROVER	Discovery III	2005 - 2009	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Discovery III	2005 - 2009	Supplemental Inflatable Restraint System	Special Function	Seats - Seat cover replacement
LANDROVER	Discovery III	2005 - 2009	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Instrument cluster control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Instrument cluster control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Discovery III	2005 - 2009	Instrument cluster control module	Special Function	Vehicle reset
LANDROVER	Discovery III	2005 - 2009	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Ride level control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Ride level control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Discovery III	2005 - 2009	Ride level control module	Special Function	Air suspension deflation
LANDROVER	Discovery III	2005 - 2009	Ride level control module	Special Function	Air suspension enable
LANDROVER	Discovery III	2005 - 2009	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Discovery III	2005 - 2009	Ride level control module	Special Function	Suspension tight tolerance control
LANDROVER	Discovery III	2005 - 2009	Ride level control module	Special Function	Set/un - set air suspension geometry set - up
LANDROVER	Discovery III	2005 - 2009	Ride level control module	Special Function	Ride level control module inflation (showroom)
LANDROVER	Discovery III	2005 - 2009	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Body control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Body control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Body control module	Special Function	Rain sensor initialisation
LANDROVER	Discovery III	2005 - 2009	Body control module	Special Function	Sliding roof module initialisation
LANDROVER	Discovery III	2005 - 2009	Body control module	Special Function	Driver's memory seat calibration
LANDROVER	Discovery III	2005 - 2009	Body control module	Special Function	Program keys
LANDROVER	Discovery III	2005 - 2009	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Heating ventilation and air conditioning control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Vehicle dynamics control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Vehicle dynamics control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Discovery III	2005 - 2009	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Steering angle sensor module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Discovery III	2005 - 2009	Steering angle sensor module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Steering angle sensor module	Special Function	Steering wheel angle sensor calibration
LANDROVER	Discovery III	2005 - 2009	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Discovery III	2005 - 2009	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Tire pressure monitor module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Tire pressure monitor module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Discovery III	2005 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Discovery III	2005 - 2009	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Parking brake control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Parking brake control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Parking brake control module	Special Function	Drive the parking brake to the mounting position
LANDROVER	Discovery III	2005 - 2009	Parking brake control module	Special Function	Drive the parking brake to the latching position
LANDROVER	Discovery III	2005 - 2009	Parking brake control module	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Discovery III	2005 - 2009	Parking brake control module	Special Function	Parking brake unjam procedure
LANDROVER	Discovery III	2005 - 2009	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Parking assist control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Parking assist control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Parking assist control module	Special Function	Front parking aid sensors 'Auto - On' activation
LANDROVER	Discovery III	2005 - 2009	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Auxiliary heater control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Auxiliary heater control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Auxiliary heater control module	Special Function	Auxiliary heater fuel delivery test
LANDROVER	Discovery III	2005 - 2009	Auxiliary heater control module	Special Function	Auxiliary heater priming routine
LANDROVER	Discovery III	2005 - 2009	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	All terrain control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	All terrain control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Transfer case control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Transfer case control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Transfer case control module	Special Function	Stepper motor replacement
LANDROVER	Discovery III	2005 - 2009	Transfer case control module	Special Function	Solenoid replacement
LANDROVER	Discovery III	2005 - 2009	Transfer case control module	Special Function	Adaption status
LANDROVER	Discovery III	2005 - 2009	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Discovery III	2005 - 2009	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Speed control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Speed control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Rear differential control module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Rear differential control module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery III	2005 - 2009	Audio amplifier module	Read Data Stream	
LANDROVER	Discovery III	2005 - 2009	Audio amplifier module	Version Information	
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Special Function	Idle speed test
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Special Function	OBDII readiness tests
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Discovery III	2005 - 2009	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Injector replacement
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Turbine shut - off valve
LANDROVER	Discovery 4	2010 - 2011	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Transmission control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Transmission control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Transmission control module	Special Function	Adaption clear
LANDROVER	Discovery 4	2010 - 2011	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Anti-lock Braking System	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Anti-lock Braking System	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Anti-lock Braking System	Special Function	Brake bleed
LANDROVER	Discovery 4	2010 - 2011	Anti-lock Braking System	Special Function	Yaw Rate sensor calibration
LANDROVER	Discovery 4	2010 - 2011	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Instrument cluster control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Instrument cluster control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Discovery 4	2010 - 2011	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Ride level control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Ride level control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Discovery 4	2010 - 2011	Ride level control module	Special Function	Air suspension deflation
LANDROVER	Discovery 4	2010 - 2011	Ride level control module	Special Function	Air suspension enable
LANDROVER	Discovery 4	2010 - 2011	Ride level control module	Special Function	Set/un - set air suspension manufacturing/freeze mode
LANDROVER	Discovery 4	2010 - 2011	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Discovery 4	2010 - 2011	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Body control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Body control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Discovery 4	2010 - 2011	Body control module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Discovery 4	2010 - 2011	Body control module	Special Function	Battery replacement
LANDROVER	Discovery 4	2010 - 2011	Body control module	Special Function	Sunroof calibration
LANDROVER	Discovery 4	2010 - 2011	Body control module	Special Function	Valet mode reset
LANDROVER	Discovery 4	2010 - 2011	Body control module	Special Function	Steering column calibration
LANDROVER	Discovery 4	2010 - 2011	Body control module	Special Function	Transportation mode
LANDROVER	Discovery 4	2010 - 2011	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Heating ventilation and air conditioning control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Heating ventilation and air conditioning control module	Special Function	Evaporator and heater test
LANDROVER	Discovery 4	2010 - 2011	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Discovery 4	2010 - 2011	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
LANDROVER	Discovery 4	2010 - 2011	Heating ventilation and air conditioning control module	Special Function	Restraints build mode
LANDROVER	Discovery 4	2010 - 2011	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Steering angle sensor module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Steering angle sensor module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Steering angle sensor module	Special Function	Steering wheel angle sensor calibration
LANDROVER	Discovery 4	2010 - 2011	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Discovery 4	2010 - 2011	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Parking brake control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Parking brake control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Parking brake control module	Special Function	Drive the parking brake to the mounting position

make	model	year	system	function	subfunction
LANDROVER	Discovery 4	2010 - 2011	Parking brake control module	Special Function	Drive the parking brake to the latching position
LANDROVER	Discovery 4	2010 - 2011	Parking brake control module	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Discovery 4	2010 - 2011	Parking brake control module	Special Function	Parking brake unjam procedure
LANDROVER	Discovery 4	2010 - 2011	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Parking assist control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Parking assist control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Auxiliary heater control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Auxiliary heater control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Auxiliary heater control module	Special Function	Auxiliary heater priming routine
LANDROVER	Discovery 4	2010 - 2011	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Vehicle immobilizer control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Driver's door module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Driver's door module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Driver's door module	Special Function	Driver's door window glass calibration
LANDROVER	Discovery 4	2010 - 2011	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Driver's seat module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Driver's seat module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Discovery 4	2010 - 2011	Driver's seat module	Special Function	Seat entry/exit enable
LANDROVER	Discovery 4	2010 - 2011	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Passenger's door module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Passenger's door module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Passenger's door module	Special Function	Passenger's door window glass calibration
LANDROVER	Discovery 4	2010 - 2011	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	All terrain control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	All terrain control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Transfer case control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Transfer case control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Discovery 4	2010 - 2011	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Speed control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Speed control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Rear differential control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Rear differential control module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Rear differential control module	Special Function	Control module calibration
LANDROVER	Discovery 4	2010 - 2011	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Restraints occupant classification system module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Restraints occupant classification system module	Special Function	Seat cushion replacement
LANDROVER	Discovery 4	2010 - 2011	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Headlamp Control Module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Headlamp Control Module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Discovery 4	2010 - 2011	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Keyless vehicle module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Keyless vehicle module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Discovery 4	2010 - 2011	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Audio amplifier module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Audio amplifier module	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Image processing module B	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Image processing module B	Version Information	
LANDROVER	Discovery 4	2010 - 2011	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2010 - 2011	Audio front control module	Read Data Stream	
LANDROVER	Discovery 4	2010 - 2011	Audio front control module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Adaption clear
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Discovery 4	2010 - 2011	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Rest of world - Service interval options
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Discovery 4	2012 - 2013	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Discovery 4	2012 - 2013	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Transmission control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Transmission control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Transmission control module	Special Function	Transmission control module adaption clear
LANDROVER	Discovery 4	2012 - 2013	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Anti-lock Braking System	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Anti-lock Braking System	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Anti-lock Braking System	Special Function	Yaw rate sensor calibration
LANDROVER	Discovery 4	2012 - 2013	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Discovery 4	2012 - 2013	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Instrument cluster control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Instrument cluster control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Discovery 4	2012 - 2013	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Ride level control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Ride level control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Discovery 4	2012 - 2013	Ride level control module	Special Function	Air suspension deflation
LANDROVER	Discovery 4	2012 - 2013	Ride level control module	Special Function	Air suspension enable
LANDROVER	Discovery 4	2012 - 2013	Ride level control module	Special Function	Set/un - set air suspension manufacturing/freeze
LANDROVER	Discovery 4	2012 - 2013	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Discovery 4	2012 - 2013	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Body control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Body control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Discovery 4	2012 - 2013	Body control module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Discovery 4	2012 - 2013	Body control module	Special Function	Tire pressure monitor sensor identification display
LANDROVER	Discovery 4	2012 - 2013	Body control module	Special Function	Sunroof calibration
LANDROVER	Discovery 4	2012 - 2013	Body control module	Special Function	Tire pressure monitoring tire pressure sensor test
LANDROVER	Discovery 4	2012 - 2013	Body control module	Special Function	Transportation mode
LANDROVER	Discovery 4	2012 - 2013	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Heating ventilation and air conditioning control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Steering angle sensor module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Steering angle sensor module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Steering angle sensor module	Special Function	Steering wheel angle sensor calibration
LANDROVER	Discovery 4	2012 - 2013	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Discovery 4	2012 - 2013	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Parking brake control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Parking brake control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Parking brake control module	Special Function	Drive the parking brake to the mounting position
LANDROVER	Discovery 4	2012 - 2013	Parking brake control module	Special Function	Drive the parking brake to the latching position

make	model	year	system	function	subfunction
LANDROVER	Discovery 4	2012 - 2013	Parking brake control module	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Discovery 4	2012 - 2013	Parking brake control module	Special Function	Parking brake unjam procedure
LANDROVER	Discovery 4	2012 - 2013	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Parking assist control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Parking assist control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Auxiliary heater control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Auxiliary heater control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Auxiliary heater control module	Special Function	Auxiliary heater fuel delivery test
LANDROVER	Discovery 4	2012 - 2013	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Vehicle immobilizer control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Driver's door module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Driver's door module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Driver's seat module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Driver's seat module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Driver's seat module	Special Function	Driver's Seat Calibration
LANDROVER	Discovery 4	2012 - 2013	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Passenger's door module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Passenger's door module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	All terrain control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	All terrain control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Transfer case control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Transfer case control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Discovery 4	2012 - 2013	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Speed control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Speed control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Rear differential control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Rear differential control module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Restraints occupant classification system module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Restraints occupant classification system module	Special Function	Seats - Seat cover replacement
LANDROVER	Discovery 4	2012 - 2013	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Headlamp Control Module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Headlamp Control Module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Discovery 4	2012 - 2013	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Keyless vehicle module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Keyless vehicle module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Keyless vehicle module	Special Function	Check passive keys enabled
LANDROVER	Discovery 4	2012 - 2013	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Discovery 4	2012 - 2013	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Audio amplifier module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Audio amplifier module	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Audio amplifier module	Special Function	DVD region counter reset
LANDROVER	Discovery 4	2012 - 2013	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Image processing module B	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Image processing module B	Version Information	
LANDROVER	Discovery 4	2012 - 2013	Image processing module B	Special Function	Camera auto learn routine
LANDROVER	Discovery 4	2012 - 2013	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	2012 - 2013	Audio front control module	Read Data Stream	
LANDROVER	Discovery 4	2012 - 2013	Audio front control module	Version Information	
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Service interval reset
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Injector replacement

make	model	year	system	function	subfunction
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Diesel fueling adaption re - initialization
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Turbine shut - off valve
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Rest of world - Service interval options
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Fuel Lift Pump
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Adaption clear
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Reset selective catalyst reduction quality monitor
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Engine control module low pressure LOR adaption clear
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Powertrain control module adaption clear
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Discovery 4	As of 2014	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Discovery 4	As of 2014	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Transmission control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Anti-lock Braking System	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Anti-lock Braking System	Special Function	Yaw Rate sensor calibration
LANDROVER	Discovery 4	As of 2014	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Discovery 4	As of 2014	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Instrument cluster control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Instrument cluster control module	Special Function	Vehicle reset
LANDROVER	Discovery 4	As of 2014	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Ride level control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Ride level control module	Special Function	Air suspension enable
LANDROVER	Discovery 4	As of 2014	Ride level control module	Special Function	Set/un - set air suspension manufacturing/freeze mode
LANDROVER	Discovery 4	As of 2014	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Discovery 4	As of 2014	Ride level control module	Special Function	Set/un - set air suspension geometry set - up
LANDROVER	Discovery 4	As of 2014	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Body control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Body control module	Special Function	Sunroof calibration
LANDROVER	Discovery 4	As of 2014	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Discovery 4	As of 2014	Body control module	Special Function	Valet mode reset
LANDROVER	Discovery 4	As of 2014	Body control module	Special Function	Steering column calibration
LANDROVER	Discovery 4	As of 2014	Body control module	Special Function	Tire pressure monitor sensor identification display
LANDROVER	Discovery 4	As of 2014	Body control module	Special Function	Transportation mode
LANDROVER	Discovery 4	As of 2014	Body control module	Special Function	Verify Keys
LANDROVER	Discovery 4	As of 2014	Body control module	Special Function	Motor replacement
LANDROVER	Discovery 4	As of 2014	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Discovery 4	As of 2014	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
LANDROVER	Discovery 4	As of 2014	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Steering angle sensor module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Steering angle sensor module	Special Function	Steering wheel angle sensor calibration
LANDROVER	Discovery 4	As of 2014	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Discovery 4	As of 2014	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Parking brake control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Parking brake control module	Special Function	Drive the parking brake to the mounting position
LANDROVER	Discovery 4	As of 2014	Parking brake control module	Special Function	Drive the parking brake to the latching position
LANDROVER	Discovery 4	As of 2014	Parking brake control module	Special Function	Parking brake unjam procedure

make	model	year	system	function	subfunction
LANDROVER	Discovery 4	As of 2014	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Discovery 4	As of 2014	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Parking assist control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Discovery 4	As of 2014	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Auxiliary heater control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Auxiliary heater control module	Special Function	Auxiliary heater priming routine
LANDROVER	Discovery 4	As of 2014	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Gateway module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Gateway module	Special Function	Battery replacement
LANDROVER	Discovery 4	As of 2014	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Discovery 4	As of 2014	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Driver's door module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Driver's seat module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Discovery 4	As of 2014	Driver's seat module	Special Function	Seat entry/exit enable
LANDROVER	Discovery 4	As of 2014	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Passenger's door module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	All terrain control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Transfer case control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Discovery 4	As of 2014	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Speed control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Speed control module	Version Information	
LANDROVER	Discovery 4	As of 2014	Speed control module	Special Function	Speed control alignment
LANDROVER	Discovery 4	As of 2014	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Rear differential control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Rear differential control module	Special Function	Control module calibration
LANDROVER	Discovery 4	As of 2014	Light check module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Light check module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Restraints occupant classification system module	Special Function	Seats - Seat cover replacement
LANDROVER	Discovery 4	As of 2014	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Headlamp Control Module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Discovery 4	As of 2014	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Keyless vehicle module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Keyless vehicle module	Special Function	Check all antennas
LANDROVER	Discovery 4	As of 2014	Keyless vehicle module	Special Function	Check passive keys enabled
LANDROVER	Discovery 4	As of 2014	Keyless vehicle module	Special Function	Recover programmed keys
LANDROVER	Discovery 4	As of 2014	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Audio amplifier module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Audio amplifier module	Special Function	Calibrate dynamic volume control
LANDROVER	Discovery 4	As of 2014	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Rear gate/trunk module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Image processing module B	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Image processing module B	Special Function	Camera auto learn routine
LANDROVER	Discovery 4	As of 2014	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Audio front control module	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Side object detection control module - Left	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Side object detection control module - Right	Read Data Stream	
LANDROVER	Discovery 4	As of 2014	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery 4	As of 2014	Gear shift module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Special Function	Adaption clear
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Special Function	Idle speed test
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Sport	2005 - 2009	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Transmission control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Transmission control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Transmission control module	Special Function	Adaption clear
LANDROVER	Range Rover Sport	2005 - 2009	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Anti-lock Braking System	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Supplemental Inflatable Restraint System	Special Function	Seat cushion replacement
LANDROVER	Range Rover Sport	2005 - 2009	Supplemental Inflatable Restraint System	Special Function	Third button configuration
LANDROVER	Range Rover Sport	2005 - 2009	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Instrument cluster control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Range Rover Sport	2005 - 2009	Instrument cluster control module	Special Function	Vehicle reset
LANDROVER	Range Rover Sport	2005 - 2009	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Ride level control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Ride level control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover Sport	2005 - 2009	Ride level control module	Special Function	Air suspension deflation
LANDROVER	Range Rover Sport	2005 - 2009	Ride level control module	Special Function	Air suspension enable
LANDROVER	Range Rover Sport	2005 - 2009	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Range Rover Sport	2005 - 2009	Ride level control module	Special Function	Suspension tight tolerance control
LANDROVER	Range Rover Sport	2005 - 2009	Ride level control module	Special Function	Set/un - set air suspension geometry set - up
LANDROVER	Range Rover Sport	2005 - 2009	Ride level control module	Special Function	Ride level control module inflation (showroom)
LANDROVER	Range Rover Sport	2005 - 2009	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Body control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Body control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Body control module	Special Function	Rain sensor initialisation
LANDROVER	Range Rover Sport	2005 - 2009	Body control module	Special Function	Sliding roof module initialisation
LANDROVER	Range Rover Sport	2005 - 2009	Body control module	Special Function	Driver's memory seat calibration
LANDROVER	Range Rover Sport	2005 - 2009	Body control module	Special Function	Steering column calibration
LANDROVER	Range Rover Sport	2005 - 2009	Body control module	Special Function	Program keys
LANDROVER	Range Rover Sport	2005 - 2009	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Heating ventilation and air conditioning control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Vehicle dynamics control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Vehicle dynamics control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Range Rover Sport	2005 - 2009	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Steering angle sensor module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Steering angle sensor module	Special Function	Steering wheel angle sensor calibration
LANDROVER	Range Rover Sport	2005 - 2009	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Sport	2005 - 2009	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Sport	2005 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover Sport	2005 - 2009	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Parking brake control module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2005 - 2009	Parking brake control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Parking brake control module	Special Function	Drive the parking brake to the mounting position
LANDROVER	Range Rover Sport	2005 - 2009	Parking brake control module	Special Function	Drive the parking brake to the latching position
LANDROVER	Range Rover Sport	2005 - 2009	Parking brake control module	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Range Rover Sport	2005 - 2009	Parking brake control module	Special Function	Parking brake unjam procedure
LANDROVER	Range Rover Sport	2005 - 2009	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Parking assist control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Parking assist control module	Special Function	Front parking aid sensors 'Auto - On' activation
LANDROVER	Range Rover Sport	2005 - 2009	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Auxiliary heater control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Auxiliary heater control module	Special Function	Auxiliary heater fuel delivery test
LANDROVER	Range Rover Sport	2005 - 2009	Auxiliary heater control module	Special Function	Auxiliary heater priming routine
LANDROVER	Range Rover Sport	2005 - 2009	Auxiliary heater control module	Special Function	Auxiliary heater activation test
LANDROVER	Range Rover Sport	2005 - 2009	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	All terrain control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Transfer case control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Transfer case control module	Special Function	Stepper motor replacement
LANDROVER	Range Rover Sport	2005 - 2009	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Range Rover Sport	2005 - 2009	Transfer case control module	Special Function	Solenoid replacement
LANDROVER	Range Rover Sport	2005 - 2009	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Speed control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Speed control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Rear differential control module	Version Information	
LANDROVER	Range Rover Sport	2005 - 2009	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2005 - 2009	Audio front control module	Read Data Stream	
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Range Rover Sport	2005 - 2009	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Security - Keyfob remote functionality
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Turbine shut - off valve
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Adaption clear
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Fuel Prime Routine
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover Sport	2010 - 2011	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover Sport	2010 - 2011	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Transmission control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Transmission control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Transmission control module	Special Function	Adaption clear

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2010 - 2011	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Anti-lock Braking System	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Anti-lock Braking System	Special Function	Brake bleed
LANDROVER	Range Rover Sport	2010 - 2011	Anti-lock Braking System	Special Function	Yaw Rate sensor calibration
LANDROVER	Range Rover Sport	2010 - 2011	Anti-lock Braking System	Special Function	Steering angle sensor calibration
LANDROVER	Range Rover Sport	2010 - 2011	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Instrument cluster control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Range Rover Sport	2010 - 2011	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Ride level control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Ride level control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover Sport	2010 - 2011	Ride level control module	Special Function	Air suspension deflation
LANDROVER	Range Rover Sport	2010 - 2011	Ride level control module	Special Function	Air suspension enable
LANDROVER	Range Rover Sport	2010 - 2011	Ride level control module	Special Function	Set/un - set air suspension manufacturing/freeze mode
LANDROVER	Range Rover Sport	2010 - 2011	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Range Rover Sport	2010 - 2011	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Body control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Body control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Sport	2010 - 2011	Body control module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover Sport	2010 - 2011	Body control module	Special Function	Battery replacement
LANDROVER	Range Rover Sport	2010 - 2011	Body control module	Special Function	Sunroof calibration
LANDROVER	Range Rover Sport	2010 - 2011	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover Sport	2010 - 2011	Body control module	Special Function	Motor replacement
LANDROVER	Range Rover Sport	2010 - 2011	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Heating ventilation and air conditioning control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Heating ventilation and air conditioning control module	Special Function	Evaporator and heater test
LANDROVER	Range Rover Sport	2010 - 2011	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover Sport	2010 - 2011	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
LANDROVER	Range Rover Sport	2010 - 2011	Heating ventilation and air conditioning control module	Special Function	Restraints build mode
LANDROVER	Range Rover Sport	2010 - 2011	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Vehicle dynamics control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Vehicle dynamics control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Range Rover Sport	2010 - 2011	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Steering angle sensor module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Steering angle sensor module	Special Function	Steering wheel angle sensor calibration
LANDROVER	Range Rover Sport	2010 - 2011	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Sport	2010 - 2011	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Sport	2010 - 2011	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover Sport	2010 - 2011	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Parking brake control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Parking brake control module	Special Function	Drive the parking brake to the mounting position

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2010 - 2011	Parking brake control module	Special Function	Drive the parking brake to the latching position
LANDROVER	Range Rover Sport	2010 - 2011	Parking brake control module	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Range Rover Sport	2010 - 2011	Parking brake control module	Special Function	Parking brake unjam procedure
LANDROVER	Range Rover Sport	2010 - 2011	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Parking assist control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Auxiliary heater control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Auxiliary heater control module	Special Function	Auxiliary heater fuel delivery test
LANDROVER	Range Rover Sport	2010 - 2011	Auxiliary heater control module	Special Function	Auxiliary heater priming routine
LANDROVER	Range Rover Sport	2010 - 2011	Auxiliary heater control module	Special Function	Auxiliary heater activation test
LANDROVER	Range Rover Sport	2010 - 2011	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Vehicle immobilizer control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Driver's door module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Driver's door module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Driver's door module	Special Function	Driver's door window glass calibration
LANDROVER	Range Rover Sport	2010 - 2011	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Driver's seat module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Range Rover Sport	2010 - 2011	Driver's seat module	Special Function	Seat entry/exit enable
LANDROVER	Range Rover Sport	2010 - 2011	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Passenger's door module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Passenger's door module	Special Function	Passenger's door window glass calibration
LANDROVER	Range Rover Sport	2010 - 2011	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	All terrain control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Transfer case control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Range Rover Sport	2010 - 2011	Transfer case control module	Special Function	Transfer case replacement
LANDROVER	Range Rover Sport	2010 - 2011	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Adaptive damping control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Adaptive damping control module	Special Function	Build mode
LANDROVER	Range Rover Sport	2010 - 2011	Adaptive damping control module	Special Function	Calibration learn
LANDROVER	Range Rover Sport	2010 - 2011	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Speed control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Speed control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Speed control module	Special Function	Speed control alignment
LANDROVER	Range Rover Sport	2010 - 2011	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Rear differential control module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Rear differential control module	Special Function	Control module calibration
LANDROVER	Range Rover Sport	2010 - 2011	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Restraints occupant classification system module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Restraints occupant classification system module	Special Function	Seat cushion replacement

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2010 - 2011	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Headlamp Control Module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Headlamp Control Module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Range Rover Sport	2010 - 2011	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Keyless vehicle module	Version Information	
LANDROVER	Range Rover Sport	2010 - 2011	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Range Rover Sport	2010 - 2011	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Image processing module B	Read Data Stream	
LANDROVER	Range Rover Sport	2010 - 2011	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2010 - 2011	Audio front control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Rest of world - Service interval options
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Adaption clear
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Idle speed - Adjustment
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Service history data
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Fuel Prime Routine
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Sport	2012 - 2013	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover Sport	2012 - 2013	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Transmission control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Transmission control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Transmission control module	Special Function	Adaption clear
LANDROVER	Range Rover Sport	2012 - 2013	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Anti-lock Braking System	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Anti-lock Braking System	Special Function	Brake bleed
LANDROVER	Range Rover Sport	2012 - 2013	Anti-lock Braking System	Special Function	Steering angle sensor calibration
LANDROVER	Range Rover Sport	2012 - 2013	Anti-lock Braking System	Special Function	Yaw rate sensor calibration
LANDROVER	Range Rover Sport	2012 - 2013	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Range Rover Sport	2012 - 2013	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Instrument cluster control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Range Rover Sport	2012 - 2013	Instrument cluster control module	Special Function	Vehicle reset
LANDROVER	Range Rover Sport	2012 - 2013	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Ride level control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Ride level control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover Sport	2012 - 2013	Ride level control module	Special Function	Air suspension deflation
LANDROVER	Range Rover Sport	2012 - 2013	Ride level control module	Special Function	Air suspension enable
LANDROVER	Range Rover Sport	2012 - 2013	Ride level control module	Special Function	Set/un - set air suspension manufacturing/freeze mode
LANDROVER	Range Rover Sport	2012 - 2013	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Range Rover Sport	2012 - 2013	Ride level control module	Special Function	Set/un - set air suspension geometry set - up
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Special Function	Steering column calibration
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Special Function	Tire pressure monitor sensor identification display
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Special Function	Tire pressure monitoring tire pressure sensor test
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Special Function	Battery replacement
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Special Function	Sunroof calibration
LANDROVER	Range Rover Sport	2012 - 2013	Body control module	Special Function	Motor replacement
LANDROVER	Range Rover Sport	2012 - 2013	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Heating ventilation and air conditioning control module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2012 - 2013	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
LANDROVER	Range Rover Sport	2012 - 2013	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover Sport	2012 - 2013	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Vehicle dynamics control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Vehicle dynamics control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Range Rover Sport	2012 - 2013	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Steering angle sensor module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Steering angle sensor module	Special Function	Steering wheel angle sensor calibration
LANDROVER	Range Rover Sport	2012 - 2013	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Sport	2012 - 2013	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Sport	2012 - 2013	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover Sport	2012 - 2013	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Parking brake control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Parking brake control module	Special Function	Drive the parking brake to the mounting position
LANDROVER	Range Rover Sport	2012 - 2013	Parking brake control module	Special Function	Drive the parking brake to the latching position
LANDROVER	Range Rover Sport	2012 - 2013	Parking brake control module	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Range Rover Sport	2012 - 2013	Parking brake control module	Special Function	Parking brake unjam procedure
LANDROVER	Range Rover Sport	2012 - 2013	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Parking assist control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Auxiliary heater control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Auxiliary heater control module	Special Function	Auxiliary heater activation test
LANDROVER	Range Rover Sport	2012 - 2013	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Vehicle immobilizer control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Driver's door module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Driver's door module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Driver's seat module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Driver's seat module	Special Function	Driver's Seat Calibration
LANDROVER	Range Rover Sport	2012 - 2013	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Passenger's door module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Passenger's door module	Special Function	Passenger's door window glass calibration
LANDROVER	Range Rover Sport	2012 - 2013	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
LANDROVER	Range Rover Sport	2012 - 2013	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	All terrain control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Transfer case control module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2012 - 2013	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Range Rover Sport	2012 - 2013	Transfer case control module	Special Function	Transfer case replacement
LANDROVER	Range Rover Sport	2012 - 2013	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Adaptive damping control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Adaptive damping control module	Special Function	Build mode
LANDROVER	Range Rover Sport	2012 - 2013	Adaptive damping control module	Special Function	Calibration learn
LANDROVER	Range Rover Sport	2012 - 2013	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Speed control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Speed control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Speed control module	Special Function	Speed control alignment
LANDROVER	Range Rover Sport	2012 - 2013	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Rear differential control module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Rear differential control module	Special Function	Control module calibration
LANDROVER	Range Rover Sport	2012 - 2013	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Restraints occupant classification system module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Restraints occupant classification system module	Special Function	Seats - Seat cover replacement
LANDROVER	Range Rover Sport	2012 - 2013	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Headlamp Control Module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Headlamp Control Module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Range Rover Sport	2012 - 2013	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Keyless vehicle module	Version Information	
LANDROVER	Range Rover Sport	2012 - 2013	Keyless vehicle module	Special Function	Check all antennas
LANDROVER	Range Rover Sport	2012 - 2013	Keyless vehicle module	Special Function	Check passive keys enabled
LANDROVER	Range Rover Sport	2012 - 2013	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Range Rover Sport	2012 - 2013	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Audio amplifier module	Special Function	DVD region counter reset
LANDROVER	Range Rover Sport	2012 - 2013	Audio amplifier module	Special Function	Calibrate dynamic volume control
LANDROVER	Range Rover Sport	2012 - 2013	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Rear gate/trunk module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Rear gate/trunk module	Special Function	Tailgate/trunk calibration
LANDROVER	Range Rover Sport	2012 - 2013	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Image processing module B	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Image processing module B	Special Function	Camera auto learn routine
LANDROVER	Range Rover Sport	2012 - 2013	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Audio front control module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2012 - 2013	Gear shift module	Read Data Stream	
LANDROVER	Range Rover Sport	2012 - 2013	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Range Rover Sport	2012 - 2013	Parking brake control module	Special Function	Drive the parking brake to the mounting position
LANDROVER	Range Rover Sport	2012 - 2013	Parking brake control module	Special Function	Drive the parking brake to the latching position
LANDROVER	Range Rover Sport	2012 - 2013	Parking brake control module	Special Function	Parking brake unjam procedure
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Idle speed test
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Service interval reset
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Adaption clear
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover Sport	2014 - 2015	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Transmission control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Anti-lock Braking System	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2014 - 2015	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Range Rover Sport	2014 - 2015	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Instrument cluster control module	Special Function	Vehicle reset
LANDROVER	Range Rover Sport	2014 - 2015	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Ride level control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Ride level control module	Special Function	Set/un - set air suspension geometry set - up
LANDROVER	Range Rover Sport	2014 - 2015	Safety belt pretensioner control module A - drivers side	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Safety belt pretensioner control module A - drivers side	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Safety belt pretensioner control module B - passengers side	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Safety belt pretensioner control module B - passengers side	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data
LANDROVER	Range Rover Sport	2014 - 2015	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Power steering control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover Sport	2014 - 2015	Telematic control unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Telematic control unit module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Telematic control unit module	Special Function	Reset/clear WiFi hotspot
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Special Function	Verify Keys
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Special Function	Sunroof calibration
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Special Function	Steering column calibration
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Special Function	Tire pressure monitor sensor identification display
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Special Function	Fuel pump supply - Enable/disable
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Special Function	Roof blind Calibration
LANDROVER	Range Rover Sport	2014 - 2015	Body control module	Special Function	Motor replacement
LANDROVER	Range Rover Sport	2014 - 2015	Battery energy control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Battery energy control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Battery energy control module	Special Function	Hybrid electric vehicle battery pack coolant pump replacement
LANDROVER	Range Rover Sport	2014 - 2015	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Auxiliary heater control module	Special Function	Air suspension deflation
LANDROVER	Range Rover Sport	2014 - 2015	Auxiliary heater control module	Special Function	Air suspension enable
LANDROVER	Range Rover Sport	2014 - 2015	Auxiliary heater control module	Special Function	Height recalibration
LANDROVER	Range Rover Sport	2014 - 2015	Auxiliary heater control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Range Rover Sport	2014 - 2015	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Reset compressor protection counter
LANDROVER	Range Rover Sport	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Seat climate control module calibration
LANDROVER	Range Rover Sport	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover Sport	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
LANDROVER	Range Rover Sport	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Seat climate control module calibration

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2014 - 2015	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Vehicle dynamics control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Vehicle dynamics control module	Version Information	
LANDROVER	Range Rover Sport	2014 - 2015	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Range Rover Sport	2014 - 2015	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Sport	2014 - 2015	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Sport	2014 - 2015	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover Sport	2014 - 2015	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Range Rover Sport	2014 - 2015	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover Sport	2014 - 2015	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover Sport	2014 - 2015	Parking brake control module	Special Function	Parking brake activation
LANDROVER	Range Rover Sport	2014 - 2015	Parking brake control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Range Rover Sport	2014 - 2015	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Passenger's seat module	Special Function	Power steering soft - lock end stops reset routine
LANDROVER	Range Rover Sport	2014 - 2015	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Parking assist control module	Special Function	Parking aid switch-Enable(disable)
LANDROVER	Range Rover Sport	2014 - 2015	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Range Rover Sport	2014 - 2015	Parking assist control module	Special Function	Parking aid control module reset configuration state
LANDROVER	Range Rover Sport	2014 - 2015	Auxiliary heater control module	Special Function	Auxiliary heater priming routine
LANDROVER	Range Rover Sport	2014 - 2015	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Gateway module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Range Rover Sport	2014 - 2015	Gateway module	Special Function	Battery replacement
LANDROVER	Range Rover Sport	2014 - 2015	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Driver's door module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Driver's door module	Special Function	Driver's door window glass calibration
LANDROVER	Range Rover Sport	2014 - 2015	Rear seat - Control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Rear seat - Control module - Right	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Rear seat - Control module - Right	Special Function	Rear right seat massage on demand self test
LANDROVER	Range Rover Sport	2014 - 2015	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Range Rover Sport	2014 - 2015	Driver's seat module	Special Function	Driver's seat massage on demand self test
LANDROVER	Range Rover Sport	2014 - 2015	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Passenger's door module	Special Function	Passenger's door window glass calibration
LANDROVER	Range Rover Sport	2014 - 2015	Passenger's seat module	Special Function	Passenger's seat calibration
LANDROVER	Range Rover Sport	2014 - 2015	Passenger's seat module	Special Function	Passenger's seat massage on demand self test
LANDROVER	Range Rover Sport	2014 - 2015	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Transfer case control module	Special Function	Absolute position sensor replacement

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2014 - 2015	Transfer case control module	Special Function	Transfer case replacement
LANDROVER	Range Rover Sport	2014 - 2015	Air suspension module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Air suspension module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Air suspension module	Special Function	Height calibration
LANDROVER	Range Rover Sport	2014 - 2015	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Adaptive damping control module	Version Information	
LANDROVER	Range Rover Sport	2014 - 2015	Adaptive damping control module	Special Function	Build mode
LANDROVER	Range Rover Sport	2014 - 2015	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Speed control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Speed control module	Special Function	Speed control alignment
LANDROVER	Range Rover Sport	2014 - 2015	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Rear differential control module	Special Function	Control module calibration
LANDROVER	Range Rover Sport	2014 - 2015	Running board control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Running board control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Running board control module	Special Function	Service mode enabled
LANDROVER	Range Rover Sport	2014 - 2015	Running board control module	Special Function	Service mode disabled
LANDROVER	Range Rover Sport	2014 - 2015	Light check module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Light check module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Restraints occupant classification system module	Special Function	Seats - Seat cover replacement
LANDROVER	Range Rover Sport	2014 - 2015	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Headlamp Control Module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Keyless vehicle module	Special Function	Recover programmed keys
LANDROVER	Range Rover Sport	2014 - 2015	Keyless vehicle module	Special Function	Check all antennas
LANDROVER	Range Rover Sport	2014 - 2015	Keyless vehicle module	Special Function	Check passive keys enabled
LANDROVER	Range Rover Sport	2014 - 2015	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Audio amplifier module	Special Function	Calibrate dynamic volume control
LANDROVER	Range Rover Sport	2014 - 2015	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Rear gate/trunk module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Rear gate/trunk module	Special Function	Tailgate/trunk calibration
LANDROVER	Range Rover Sport	2014 - 2015	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Image processing module B	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Image processing module B	Special Function	Camera auto learn routine
LANDROVER	Range Rover Sport	2014 - 2015	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Audio front control module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Audio front control module	Special Function	Navigation reset
LANDROVER	Range Rover Sport	2014 - 2015	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	2014 - 2015	Gear shift module	Read Data Stream	
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Diesel fueling adaption re - initialization
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Turbine shut - off valve
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Rest of world - Service interval options
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Fuel Lift Pump
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	DC to DC electric power inverter converter module mode
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover Sport	2014 - 2015	Powertrain control module	Special Function	Fuel lift pump

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	2014 - 2015	Head up display	Special Function	Head up display control module reset
LANDROVER	Range Rover Sport	2014 - 2015	Head up display	Special Function	Activate test picture
LANDROVER	Range Rover Sport	2014 - 2015	Head up display	Special Function	Rear left seat massage on demand self test
LANDROVER	Range Rover Sport	As of 2016	ABS control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	ABS control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Body control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Body control module	Special Function	Steering column calibration
LANDROVER	Range Rover Sport	As of 2016	Body control module	Special Function	Headlamp leveling height sensor calibration
LANDROVER	Range Rover Sport	As of 2016	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover Sport	As of 2016	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover Sport	As of 2016	Body control module	Special Function	Fuel pump supply - Enable/disable
LANDROVER	Range Rover Sport	As of 2016	Body control module	Special Function	Roof blind Calibration
LANDROVER	Range Rover Sport	As of 2016	Body control module	Special Function	Sunroof calibration
LANDROVER	Range Rover Sport	As of 2016	Body control module	Special Function	Motor replacement
LANDROVER	Range Rover Sport	As of 2016	Battery energy control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Battery energy control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Battery energy control module	Special Function	Hybrid electric vehicle battery pack coolant pump replacement
LANDROVER	Range Rover Sport	As of 2016	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Speed control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Chassis control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Chassis control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Chassis control module	Special Function	Adaptive speed control - Speed control alignment
LANDROVER	Range Rover Sport	As of 2016	Chassis control module	Special Function	Set/un-set air suspension geometry set-up
LANDROVER	Range Rover Sport	As of 2016	Chassis control module	Special Function	Set/un-Set Air Suspension Tight Tolerance Mode (Headlamp Setting)
LANDROVER	Range Rover Sport	As of 2016	Chassis control module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Chassis control module B	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Image processing control module A	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Image processing control module A	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Image processing control module A	Special Function	Automatic high beam camera calibration
LANDROVER	Range Rover Sport	As of 2016	Electric power inverter converter module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Electric power inverter converter module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	General proximity sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	General proximity sensor module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Gear shift module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Gateway module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Gateway module	Special Function	Battery replacement
LANDROVER	Range Rover Sport	As of 2016	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Range Rover Sport	As of 2016	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Restraints occupant classification system module	Special Function	Seat Cushion Replacement
LANDROVER	Range Rover Sport	As of 2016	Air suspension module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Air suspension module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Air suspension module	Special Function	Height calibration
LANDROVER	Range Rover Sport	As of 2016	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Range Rover Sport	As of 2016	Parking assist control module	Special Function	Parking aid control module reset configuration state
LANDROVER	Range Rover Sport	As of 2016	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Parking brake control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Range Rover Sport	As of 2016	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover Sport	As of 2016	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover Sport	As of 2016	Parking brake control module	Special Function	Parking brake activation

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	As of 2016	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Service interval reset
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Idle speed test
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Powertrain control module adaption clear
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Engine control module low pressure EGR adaption clear
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Enable/disable glow plugs
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	DC to DC electric power inverter converter module mode
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Powertrain control module adaption clear
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover Sport	As of 2016	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover Sport	As of 2016	Restraints control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Restraints control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Restraints control module	Special Function	Restraints build mode
LANDROVER	Range Rover Sport	As of 2016	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Power steering control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover Sport	As of 2016	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Rear differential control module	Special Function	Control module calibration
LANDROVER	Range Rover Sport	As of 2016	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Sport	As of 2016	Safety belt pretensioner control module A - drivers side	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Safety belt pretensioner control module A - drivers side	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Safety belt pretensioner control module B - passengers side	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Safety belt pretensioner control module B - passengers side	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data
LANDROVER	Range Rover Sport	As of 2016	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Transmission control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Transmission control module	Special Function	Telematics server communication check
LANDROVER	Range Rover Sport	As of 2016	Telematic control unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Telematic control unit module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Telematic control unit module	Special Function	Activate telematics control module
LANDROVER	Range Rover Sport	As of 2016	Telematic control unit module	Special Function	Network registration status
LANDROVER	Range Rover Sport	As of 2016	Telematic control unit module	Special Function	Pre-activate telematics control module
LANDROVER	Range Rover Sport	As of 2016	Telematic control unit module	Special Function	Telematics sim card type
LANDROVER	Range Rover Sport	As of 2016	Telematic control unit module	Special Function	Operational mode
LANDROVER	Range Rover Sport	As of 2016	Telematic control unit module	Special Function	Test internal backup battery

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	As of 2016	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
LANDROVER	Range Rover Sport	As of 2016	Telematic control unit module	Special Function	Brazilian telematics identification transfer
LANDROVER	Range Rover Sport	As of 2016	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Sport	As of 2016	Tire pressure monitor module	Special Function	Tire pressure monitor sensor identification display
LANDROVER	Range Rover Sport	As of 2016	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Range Rover Sport	As of 2016	Transfer case control module	Special Function	Transfer case replacement
LANDROVER	Range Rover Sport	As of 2016	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Head-up display cooling fan module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Connect and view module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Connect and view module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Driver's door module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Driver's door module	Special Function	Door Window Calibration
LANDROVER	Range Rover Sport	As of 2016	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Driver's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Driver's seat module	Special Function	Driver's Seat Calibration
LANDROVER	Range Rover Sport	As of 2016	Driver's seat module	Special Function	Rear seat calibration
LANDROVER	Range Rover Sport	As of 2016	Driver's seat module	Special Function	Rear right seat massage on demand self test
LANDROVER	Range Rover Sport	As of 2016	Driver's seat module	Special Function	Driver's seat massage on demand self test
LANDROVER	Range Rover Sport	As of 2016	Front control/display interface module (high level display front)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Front control/display interface module (high level display front)	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Front control/display interface module (high level display front)	Special Function	Calibrate dynamic volume control
LANDROVER	Range Rover Sport	As of 2016	Front controls interface module C (front audio control panel)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Front controls interface module C (front audio control panel)	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Front controls interface module (heating ventilation air conditioning controls)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Front controls interface module (heating ventilation air conditioning controls)	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Front controls interface module B (front audio control panel)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Front controls interface module B (front audio control panel)	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
LANDROVER	Range Rover Sport	As of 2016	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover Sport	As of 2016	Heating ventilation and air conditioning control module	Special Function	Seat climate control module calibration
LANDROVER	Range Rover Sport	As of 2016	Head up display	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Head up display	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Head up display	Special Function	Head up display control module reset
LANDROVER	Range Rover Sport	As of 2016	Head up display	Special Function	Activate test picture
LANDROVER	Range Rover Sport	As of 2016	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Image processing module B	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Sport	As of 2016	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Range Rover Sport	As of 2016	Navigation control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Navigation control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Passenger's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Passenger's seat module	Special Function	Passenger's seat massage on demand self test
LANDROVER	Range Rover Sport	As of 2016	Passenger's seat module	Special Function	Rear left seat massage on demand self test
LANDROVER	Range Rover Sport	As of 2016	Passenger's seat module	Special Function	Rear seat calibration - passenger side
LANDROVER	Range Rover Sport	As of 2016	Running board control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Running board control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Rear gate / trunk module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Rear Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Rear Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Audio front control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Digital audio broadcast module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Navigation control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Navigation control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Rear entertainment control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Rear entertainment control module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Satellite audio unit module	Read Data Stream	
LANDROVER	Range Rover Sport	As of 2016	Television module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Sport	As of 2016	Television module	Read Data Stream	
LANDROVER	Range Rover	2006	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover	2006	Powertrain control module	Version Information	
LANDROVER	Range Rover	2006	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Transmission control module	Read Data Stream	
LANDROVER	Range Rover	2006	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover	2006	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Range Rover	2006	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover	2006	Instrument cluster control module	Version Information	
LANDROVER	Range Rover	2006	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Range Rover	2006	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Ride level control module	Read Data Stream	
LANDROVER	Range Rover	2006	Ride level control module	Version Information	
LANDROVER	Range Rover	2006	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover	2006	Ride level control module	Special Function	Air suspension deflation
LANDROVER	Range Rover	2006	Ride level control module	Special Function	Air suspension enable
LANDROVER	Range Rover	2006	Ride level control module	Special Function	Set/un - set air suspension manufacturing/freeze
LANDROVER	Range Rover	2006	Ride level control module	Special Function	Set/un - set air suspension geometry set - up
LANDROVER	Range Rover	2006	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Range Rover	2006	Ride level control module	Special Function	Suspension tight tolerance control
LANDROVER	Range Rover	2006	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Body control module	Special Function	Sliding roof module initialisation

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2006	Body control module	Special Function	Program keys
LANDROVER	Range Rover	2006	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover	2006	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Vehicle dynamics control module	Read Data Stream	
LANDROVER	Range Rover	2006	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover	2006	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover	2006	Tire pressure monitor module	Version Information	
LANDROVER	Range Rover	2006	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover	2006	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover	2006	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover	2006	Parking brake control module	Version Information	
LANDROVER	Range Rover	2006	Parking brake control module	Special Function	Drive the parking brake to the mounting position
LANDROVER	Range Rover	2006	Parking brake control module	Special Function	Drive the parking brake to the latching position
LANDROVER	Range Rover	2006	Parking brake control module	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Range Rover	2006	Parking brake control module	Special Function	Parking brake unjam procedure
LANDROVER	Range Rover	2006	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover	2006	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover	2006	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover	2006	Vehicle immobilizer control module	Version Information	
LANDROVER	Range Rover	2006	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover	2006	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	All terrain control module	Read Data Stream	
LANDROVER	Range Rover	2006	All terrain control module	Version Information	
LANDROVER	Range Rover	2006	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover	2006	Transfer case control module	Version Information	
LANDROVER	Range Rover	2006	Transfer case control module	Special Function	Stepper motor replacement
LANDROVER	Range Rover	2006	Transfer case control module	Special Function	Solenoid replacement
LANDROVER	Range Rover	2006	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Range Rover	2006	Rain Sensor	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Rain Sensor	Special Function	Rain sensor initialisation
LANDROVER	Range Rover	2006	Rain Sensor	Special Function	Rain sensor windshield setup
LANDROVER	Range Rover	2006	Running board control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Running board control module	Read Data Stream	
LANDROVER	Range Rover	2006	Running board control module	Version Information	
LANDROVER	Range Rover	2006	Running board control module	Special Function	Service mode enabled
LANDROVER	Range Rover	2006	Running board control module	Special Function	Service mode disabled
LANDROVER	Range Rover	2006	Light check module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Light check module	Read Data Stream	
LANDROVER	Range Rover	2006	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2006	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover	2006	Restraints occupant classification system module	Version Information	
LANDROVER	Range Rover	2006	Restraints occupant classification system module	Special Function	Seat cushion replacement
LANDROVER	Range Rover	2006	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover	2006	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2006	Audio front control module	Read Data Stream	
LANDROVER	Range Rover	2006	Powertrain control module	Special Function	Adaption clear
LANDROVER	Range Rover	2006	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover	2006	Powertrain control module	Special Function	OBDII readiness tests
LANDROVER	Range Rover	2006	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover	2006	Transmission control module	Version Information	
LANDROVER	Range Rover	2006	Transmission control module	Special Function	Adaption clear
LANDROVER	Range Rover	2006	Vehicle dynamics control module	Version Information	
LANDROVER	Range Rover	2006	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Range Rover	2006	Steering angle sensor module	Version Information	
LANDROVER	Range Rover	2006	Steering angle sensor module	Special Function	Steering wheel angle sensor calibration
LANDROVER	Range Rover	2006	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Special Function	Adaption clear
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Special Function	Idle speed test
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Special Function	OBDII readiness tests
LANDROVER	Range Rover	2007 - 2009	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Transmission control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Transmission control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Transmission control module	Special Function	Adaption clear
LANDROVER	Range Rover	2007 - 2009	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Anti-lock Braking System	Version Information	
LANDROVER	Range Rover	2007 - 2009	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Range Rover	2007 - 2009	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Instrument cluster control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Range Rover	2007 - 2009	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Ride level control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Ride level control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover	2007 - 2009	Ride level control module	Special Function	Air suspension deflation
LANDROVER	Range Rover	2007 - 2009	Ride level control module	Special Function	Air suspension enable
LANDROVER	Range Rover	2007 - 2009	Ride level control module	Special Function	Set/un - set air suspension manufacturing/freeze mode
LANDROVER	Range Rover	2007 - 2009	Ride level control module	Special Function	Set/un - set air suspension geometry set - up
LANDROVER	Range Rover	2007 - 2009	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Range Rover	2007 - 2009	Ride level control module	Special Function	Suspension tight tolerance control
LANDROVER	Range Rover	2007 - 2009	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Body control module	Special Function	Sliding roof module initialisation
LANDROVER	Range Rover	2007 - 2009	Body control module	Special Function	Program keys
LANDROVER	Range Rover	2007 - 2009	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Vehicle dynamics control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Vehicle dynamics control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Range Rover	2007 - 2009	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Steering angle sensor module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2007 - 2009	Steering angle sensor module	Special Function	Steering wheel angle sensor calibration
LANDROVER	Range Rover	2007 - 2009	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover	2007 - 2009	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Tire pressure monitor module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover	2007 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover	2007 - 2009	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Parking brake control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Parking brake control module	Special Function	Drive the parking brake to the mounting position
LANDROVER	Range Rover	2007 - 2009	Parking brake control module	Special Function	Drive the parking brake to the latching position
LANDROVER	Range Rover	2007 - 2009	Parking brake control module	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Range Rover	2007 - 2009	Parking brake control module	Special Function	Parking brake unjam procedure
LANDROVER	Range Rover	2007 - 2009	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Vehicle immobilizer control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	All terrain control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	All terrain control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Transfer case control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Transfer case control module	Special Function	Stepper motor replacement
LANDROVER	Range Rover	2007 - 2009	Transfer case control module	Special Function	Solenoid replacement
LANDROVER	Range Rover	2007 - 2009	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Range Rover	2007 - 2009	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Rear differential control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Running board control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Running board control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Running board control module	Version Information	
LANDROVER	Range Rover	2007 - 2009	Running board control module	Special Function	Service mode enabled
LANDROVER	Range Rover	2007 - 2009	Running board control module	Special Function	Service mode disabled
LANDROVER	Range Rover	2007 - 2009	Light check module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Light check module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Restraints occupant classification system module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2007 - 2009	Restraints occupant classification system module	Special Function	Seat cushion replacement
LANDROVER	Range Rover	2007 - 2009	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2007 - 2009	Audio front control module	Read Data Stream	
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Range Rover	2007 - 2009	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Adaption clear
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Idle speed - Adjustment
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Fuel Prime Routine
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover	2010 - 2012	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover	2010 - 2012	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Transmission control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Transmission control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Transmission control module	Special Function	Adaption clear
LANDROVER	Range Rover	2010 - 2012	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Anti-lock Braking System	Version Information	
LANDROVER	Range Rover	2010 - 2012	Anti-lock Braking System	Special Function	Brake bleed
LANDROVER	Range Rover	2010 - 2012	Anti-lock Braking System	Special Function	Yaw Rate sensor calibration
LANDROVER	Range Rover	2010 - 2012	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Range Rover	2010 - 2012	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Instrument cluster control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Range Rover	2010 - 2012	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Ride level control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Ride level control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover	2010 - 2012	Ride level control module	Special Function	Air suspension deflation
LANDROVER	Range Rover	2010 - 2012	Ride level control module	Special Function	Air suspension enable
LANDROVER	Range Rover	2010 - 2012	Ride level control module	Special Function	Set/un - set air suspension manufacturing/freeze mode
LANDROVER	Range Rover	2010 - 2012	Ride level control module	Special Function	Build mode
LANDROVER	Range Rover	2010 - 2012	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Range Rover	2010 - 2012	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Body control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Body control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover	2010 - 2012	Body control module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover	2010 - 2012	Body control module	Special Function	Battery replacement
LANDROVER	Range Rover	2010 - 2012	Body control module	Special Function	Sunroof calibration
LANDROVER	Range Rover	2010 - 2012	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover	2010 - 2012	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover	2010 - 2012	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover	2010 - 2012	Body control module	Special Function	Motor replacement
LANDROVER	Range Rover	2010 - 2012	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Heating ventilation and air conditioning control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Heating ventilation and air conditioning control module	Special Function	Evaporator and heater test
LANDROVER	Range Rover	2010 - 2012	Heating ventilation and air conditioning control module	Special Function	Reset compressor protection counter
LANDROVER	Range Rover	2010 - 2012	Heating ventilation and air conditioning control module	Special Function	Restraints build mode
LANDROVER	Range Rover	2010 - 2012	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Vehicle dynamics control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Vehicle dynamics control module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2010 - 2012	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Range Rover	2010 - 2012	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Steering angle sensor module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Steering angle sensor module	Special Function	Steering wheel angle sensor calibration
LANDROVER	Range Rover	2010 - 2012	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover	2010 - 2012	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Tire pressure monitor module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover	2010 - 2012	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover	2010 - 2012	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Parking brake control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Parking brake control module	Special Function	Drive the parking brake to the mounting position
LANDROVER	Range Rover	2010 - 2012	Parking brake control module	Special Function	Drive the parking brake to the latching position
LANDROVER	Range Rover	2010 - 2012	Parking brake control module	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Range Rover	2010 - 2012	Parking brake control module	Special Function	Parking brake unjam procedure
LANDROVER	Range Rover	2010 - 2012	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Parking assist control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Vehicle immobilizer control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Driver's door module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Driver's door module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Driver's door module	Special Function	Driver's door window glass calibration
LANDROVER	Range Rover	2010 - 2012	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Driver's seat module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Range Rover	2010 - 2012	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Passenger's door module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Passenger's door module	Special Function	Passenger's door window glass calibration
LANDROVER	Range Rover	2010 - 2012	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Passenger's seat module	Version Information	
LANDROVER	Range Rover	2010 - 2012	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	All terrain control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	All terrain control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Transfer case control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Range Rover	2010 - 2012	Transfer case control module	Special Function	Transfer case replacement
LANDROVER	Range Rover	2010 - 2012	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Adaptive damping control module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2010 - 2012	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Speed control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Speed control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Rear differential control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Rear differential control module	Special Function	Control module calibration
LANDROVER	Range Rover	2010 - 2012	Rain Sensor	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Rain Sensor	Special Function	Rain sensor initialisation
LANDROVER	Range Rover	2010 - 2012	Rain Sensor	Special Function	Rain sensor windshield setup
LANDROVER	Range Rover	2010 - 2012	Running board control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Running board control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Running board control module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Running board control module	Special Function	Service mode enabled
LANDROVER	Range Rover	2010 - 2012	Running board control module	Special Function	Service mode disabled
LANDROVER	Range Rover	2010 - 2012	Light check module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Light check module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Restraints occupant classification system module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Restraints occupant classification system module	Special Function	Seat cushion replacement
LANDROVER	Range Rover	2010 - 2012	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Headlamp Control Module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Headlamp Control Module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Keyless vehicle module	Version Information	
LANDROVER	Range Rover	2010 - 2012	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Range Rover	2010 - 2012	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Image processing module B	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Audio front control module	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover	2010 - 2012	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2010 - 2012	Gear shift module	Read Data Stream	
LANDROVER	Range Rover	2013	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover	2013	Powertrain control module	Version Information	
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Adaption status
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover	2013	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Transmission control module	Read Data Stream	
LANDROVER	Range Rover	2013	Transmission control module	Version Information	
LANDROVER	Range Rover	2013	Transmission control module	Special Function	Adaption clear
LANDROVER	Range Rover	2013	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover	2013	Anti-lock Braking System	Version Information	
LANDROVER	Range Rover	2013	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover	2013	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Range Rover	2013	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Range Rover	2013	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover	2013	Instrument cluster control module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2013	Instrument cluster control module	Special Function	Vehicle reset
LANDROVER	Range Rover	2013	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Ride level control module	Read Data Stream	
LANDROVER	Range Rover	2013	Ride level control module	Version Information	
LANDROVER	Range Rover	2013	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover	2013	Ride level control module	Special Function	Air suspension deflation
LANDROVER	Range Rover	2013	Ride level control module	Special Function	Air suspension enable
LANDROVER	Range Rover	2013	Ride level control module	Special Function	Set/un - set air suspension manufacturing/freeze mode
LANDROVER	Range Rover	2013	Ride level control module	Special Function	Build mode
LANDROVER	Range Rover	2013	Ride level control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Range Rover	2013	Safety belt pretensioner control module B - passengers side	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Safety belt pretensioner control module B - passengers side	Read Data Stream	
LANDROVER	Range Rover	2013	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data
LANDROVER	Range Rover	2013	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Power steering control module	Read Data Stream	
LANDROVER	Range Rover	2013	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover	2013	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Body control module	Read Data Stream	
LANDROVER	Range Rover	2013	Body control module	Version Information	
LANDROVER	Range Rover	2013	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover	2013	Body control module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover	2013	Body control module	Special Function	Steering column calibration
LANDROVER	Range Rover	2013	Body control module	Special Function	Tire pressure monitor sensor identification display
LANDROVER	Range Rover	2013	Body control module	Special Function	Fuel pump supply - Enable/disable
LANDROVER	Range Rover	2013	Body control module	Special Function	Sunroof calibration
LANDROVER	Range Rover	2013	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover	2013	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover	2013	Body control module	Special Function	Verify Keys
LANDROVER	Range Rover	2013	Body control module	Special Function	Tire pressure monitoring tire pressure sensor test
LANDROVER	Range Rover	2013	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover	2013	Auxiliary heater control module	Version Information	
LANDROVER	Range Rover	2013	Auxiliary heater control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover	2013	Auxiliary heater control module	Special Function	Air suspension deflation
LANDROVER	Range Rover	2013	Auxiliary heater control module	Special Function	Air suspension enable
LANDROVER	Range Rover	2013	Auxiliary heater control module	Special Function	Set/un - set air suspension manufacturing/freeze mode
LANDROVER	Range Rover	2013	Auxiliary heater control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Range Rover	2013	Auxiliary heater control module	Special Function	Set/un - set air suspension geometry set - up
LANDROVER	Range Rover	2013	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover	2013	Heating ventilation and air conditioning control module	Version Information	
LANDROVER	Range Rover	2013	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover	2013	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
LANDROVER	Range Rover	2013	Heating ventilation and air conditioning control module	Special Function	Auxiliary heater priming routine
LANDROVER	Range Rover	2013	Heating ventilation and air conditioning control module	Special Function	Reset compressor protection counter
LANDROVER	Range Rover	2013	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Vehicle dynamics control module	Read Data Stream	
LANDROVER	Range Rover	2013	Vehicle dynamics control module	Version Information	
LANDROVER	Range Rover	2013	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Range Rover	2013	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover	2013	Steering angle sensor module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2013	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover	2013	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover	2013	Tire pressure monitor module	Version Information	
LANDROVER	Range Rover	2013	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover	2013	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover	2013	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover	2013	Parking brake control module	Version Information	
LANDROVER	Range Rover	2013	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover	2013	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover	2013	Parking brake control module	Special Function	Parking brake activation
LANDROVER	Range Rover	2013	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Range Rover	2013	Parking brake control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Range Rover	2013	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover	2013	Passenger's seat module	Version Information	
LANDROVER	Range Rover	2013	Passenger's seat module	Special Function	Power steering soft - lock end stops reset routine
LANDROVER	Range Rover	2013	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover	2013	Parking assist control module	Version Information	
LANDROVER	Range Rover	2013	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover	2013	Vehicle immobilizer control module	Version Information	
LANDROVER	Range Rover	2013	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Gateway module	Read Data Stream	
LANDROVER	Range Rover	2013	Gateway module	Version Information	
LANDROVER	Range Rover	2013	Gateway module	Special Function	Test dual battery system
LANDROVER	Range Rover	2013	Gateway module	Special Function	Battery replacement
LANDROVER	Range Rover	2013	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Range Rover	2013	Gateway module	Special Function	Verify secondary battery charging
LANDROVER	Range Rover	2013	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Driver's door module	Read Data Stream	
LANDROVER	Range Rover	2013	Driver's door module	Version Information	
LANDROVER	Range Rover	2013	Driver's door module	Special Function	Driver's door window glass calibration
LANDROVER	Range Rover	2013	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover	2013	Driver's seat module	Version Information	
LANDROVER	Range Rover	2013	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Range Rover	2013	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover	2013	Passenger's door module	Version Information	
LANDROVER	Range Rover	2013	Passenger's door module	Special Function	Passenger's door window glass calibration
LANDROVER	Range Rover	2013	Passenger's seat module	Special Function	Passenger's seat calibration
LANDROVER	Range Rover	2013	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	All terrain control module	Read Data Stream	
LANDROVER	Range Rover	2013	All terrain control module	Version Information	
LANDROVER	Range Rover	2013	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover	2013	Transfer case control module	Version Information	
LANDROVER	Range Rover	2013	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Range Rover	2013	Transfer case control module	Special Function	Motor replacement
LANDROVER	Range Rover	2013	Transfer case control module	Special Function	Transfer case replacement
LANDROVER	Range Rover	2013	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover	2013	Adaptive damping control module	Version Information	
LANDROVER	Range Rover	2013	Speed control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2013	Speed control module	Read Data Stream	
LANDROVER	Range Rover	2013	Speed control module	Version Information	
LANDROVER	Range Rover	2013	Speed control module	Special Function	Speed control alignment
LANDROVER	Range Rover	2013	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover	2013	Rear differential control module	Version Information	
LANDROVER	Range Rover	2013	Rear differential control module	Special Function	Control module calibration
LANDROVER	Range Rover	2013	Rain Sensor	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Rain Sensor	Special Function	Rain sensor initialisation
LANDROVER	Range Rover	2013	Rain Sensor	Special Function	Rain sensor windshield setup
LANDROVER	Range Rover	2013	Running board control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Running board control module	Read Data Stream	
LANDROVER	Range Rover	2013	Running board control module	Version Information	
LANDROVER	Range Rover	2013	Running board control module	Special Function	Service mode enabled
LANDROVER	Range Rover	2013	Running board control module	Special Function	Service mode disabled
LANDROVER	Range Rover	2013	Light check module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Light check module	Read Data Stream	
LANDROVER	Range Rover	2013	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover	2013	Restraints occupant classification system module	Version Information	
LANDROVER	Range Rover	2013	Restraints occupant classification system module	Special Function	Seats - Seat cover replacement
LANDROVER	Range Rover	2013	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Headlamp Control Module	Read Data Stream	
LANDROVER	Range Rover	2013	Headlamp Control Module	Version Information	
LANDROVER	Range Rover	2013	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Range Rover	2013	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover	2013	Keyless vehicle module	Version Information	
LANDROVER	Range Rover	2013	Keyless vehicle module	Special Function	Check all antennas
LANDROVER	Range Rover	2013	Keyless vehicle module	Special Function	Check passive keys enabled
LANDROVER	Range Rover	2013	Keyless vehicle module	Special Function	Keyless latch configuration
LANDROVER	Range Rover	2013	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover	2013	Audio amplifier module	Version Information	
LANDROVER	Range Rover	2013	Audio amplifier module	Special Function	DVD region counter reset
LANDROVER	Range Rover	2013	Audio amplifier module	Special Function	Calibrate dynamic volume control
LANDROVER	Range Rover	2013	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Rear gate/trunk module	Read Data Stream	
LANDROVER	Range Rover	2013	Air suspension module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Air suspension module	Read Data Stream	
LANDROVER	Range Rover	2013	Air suspension module	Special Function	Height calibration
LANDROVER	Range Rover	2013	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Image processing module B	Read Data Stream	
LANDROVER	Range Rover	2013	Image processing module B	Special Function	Camera auto learn routine
LANDROVER	Range Rover	2013	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Audio front control module	Read Data Stream	
LANDROVER	Range Rover	2013	Audio front control module	Version Information	
LANDROVER	Range Rover	2013	Audio front control module	Special Function	Navigation reset
LANDROVER	Range Rover	2013	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover	2013	Side object detection control module - Left	Version Information	
LANDROVER	Range Rover	2013	Side object detection control module - Left	Special Function	Side object detection mode history
LANDROVER	Range Rover	2013	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover	2013	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2013	Gear shift module	Read Data Stream	
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Reset water fuel detection
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Rest of world - Service interval options
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Turbine shut - off valve
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Fuel Lift Pump
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Oxidation catalyst

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover	2013	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Idle speed test
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Service interval reset
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Adaption clear
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover	2014 - 2015	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Transmission control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	ABS control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	ABS control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	ABS control module	Special Function	Brake pedal position sensor - Calibration
LANDROVER	Range Rover	2014 - 2015	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Range Rover	2014 - 2015	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Instrument cluster control module	Special Function	Vehicle reset
LANDROVER	Range Rover	2014 - 2015	Ride level control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Ride level control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Ride level control module	Special Function	Set/un - set air suspension geometry set - up
LANDROVER	Range Rover	2014 - 2015	Safety belt pretensioner control module B - passengers side	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Safety belt pretensioner control module B - passengers side	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data
LANDROVER	Range Rover	2014 - 2015	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Power steering control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover	2014 - 2015	Telematic control unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Telematic control unit module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Telematic control unit module	Special Function	Reset/clear WiFi hotspot
LANDROVER	Range Rover	2014 - 2015	Telematic control unit module	Special Function	Brazilian telematics identification transfer
LANDROVER	Range Rover	2014 - 2015	Battery energy control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Battery energy control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Battery energy control module	Special Function	Hybrid electric vehicle battery pack coolant pump replacement
LANDROVER	Range Rover	2014 - 2015	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Body control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Sunroof calibration
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Steering column calibration
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Tire pressure monitor sensor identification display
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Fuel pump supply - Enable/disable
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Verify Keys
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Calf rest calibration
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Ignition cycle counter reset
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Roof blind Calibration
LANDROVER	Range Rover	2014 - 2015	Body control module	Special Function	Motor replacement
LANDROVER	Range Rover	2014 - 2015	Chassis control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Chassis control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Chassis control module	Special Function	Adaptive speed control - Speed control alignment
LANDROVER	Range Rover	2014 - 2015	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Auxiliary heater control module	Special Function	Air suspension deflation
LANDROVER	Range Rover	2014 - 2015	Auxiliary heater control module	Special Function	Air suspension enable

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2014 - 2015	Auxiliary heater control module	Special Function	Set/un - set air suspension manufacturing/freeze mode
LANDROVER	Range Rover	2014 - 2015	Auxiliary heater control module	Special Function	Set/un - set air suspension tight tolerance mode (headlamp setting)
LANDROVER	Range Rover	2014 - 2015	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Reset compressor protection counter
LANDROVER	Range Rover	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Seat climate control module calibration
LANDROVER	Range Rover	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
LANDROVER	Range Rover	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Seat climate control module calibration
LANDROVER	Range Rover	2014 - 2015	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Vehicle dynamics control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Vehicle dynamics control module	Version Information	
LANDROVER	Range Rover	2014 - 2015	Vehicle dynamics control module	Special Function	Brake bleed
LANDROVER	Range Rover	2014 - 2015	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover	2014 - 2015	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Tire pressure monitor module	Version Information	
LANDROVER	Range Rover	2014 - 2015	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover	2014 - 2015	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover	2014 - 2015	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Range Rover	2014 - 2015	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover	2014 - 2015	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover	2014 - 2015	Parking brake control module	Special Function	Parking brake activation
LANDROVER	Range Rover	2014 - 2015	Parking brake control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Range Rover	2014 - 2015	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Passenger's seat module	Special Function	Power steering soft - lock end stops reset routine
LANDROVER	Range Rover	2014 - 2015	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Parking assist control module	Special Function	Parking aid switch-Enable(disable)
LANDROVER	Range Rover	2014 - 2015	Parking assist control module	Special Function	Parking aid control module reset configuration state.
LANDROVER	Range Rover	2014 - 2015	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Range Rover	2014 - 2015	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Gateway module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Range Rover	2014 - 2015	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Driver's door module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Driver's door module	Special Function	Passenger side - Rear door blind initialisation
LANDROVER	Range Rover	2014 - 2015	Driver's door module	Special Function	Passenger's side - Door glass window calibration
LANDROVER	Range Rover	2014 - 2015	Rear seat - Control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Rear seat - Control module - Right	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Rear seat - Control module - Right	Special Function	Rear right seat massage on demand self test

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2014 - 2015	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Driver's seat module	Version Information	
LANDROVER	Range Rover	2014 - 2015	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Range Rover	2014 - 2015	Driver's seat module	Special Function	Driver's seat massage on demand self test
LANDROVER	Range Rover	2014 - 2015	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Passenger's seat module	Special Function	Passenger's seat calibration
LANDROVER	Range Rover	2014 - 2015	Passenger's seat module	Special Function	Passenger's seat massage on demand self test
LANDROVER	Range Rover	2014 - 2015	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	All terrain control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Range Rover	2014 - 2015	Transfer case control module	Special Function	Transfer case replacement
LANDROVER	Range Rover	2014 - 2015	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Adaptive damping control module	Version Information	
LANDROVER	Range Rover	2014 - 2015	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Speed control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Speed control module	Special Function	Speed control alignment
LANDROVER	Range Rover	2014 - 2015	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Rear differential control module	Special Function	Control module calibration
LANDROVER	Range Rover	2014 - 2015	Rain Sensor	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Rain Sensor	Special Function	Rain sensor initialisation
LANDROVER	Range Rover	2014 - 2015	Rain Sensor	Special Function	Rain sensor windshield setup
LANDROVER	Range Rover	2014 - 2015	Running board control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Running board control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Running board control module	Special Function	Service mode enabled
LANDROVER	Range Rover	2014 - 2015	Running board control module	Special Function	Service mode disabled
LANDROVER	Range Rover	2014 - 2015	Light check module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Light check module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Restraints occupant classification system module	Special Function	Seats - Seat cover replacement
LANDROVER	Range Rover	2014 - 2015	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Headlamp Control Module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Range Rover	2014 - 2015	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Keyless vehicle module	Special Function	Check all antennas
LANDROVER	Range Rover	2014 - 2015	Keyless vehicle module	Special Function	Recover programmed keys
LANDROVER	Range Rover	2014 - 2015	Gateway module	Special Function	Battery replacement
LANDROVER	Range Rover	2014 - 2015	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Audio amplifier module	Special Function	DVD region counter reset
LANDROVER	Range Rover	2014 - 2015	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Rear gate/trunk module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Rear gate/trunk module	Special Function	Tailgate/trunk calibration
LANDROVER	Range Rover	2014 - 2015	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Image processing module B	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Air suspension module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Air suspension module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Air suspension module	Special Function	Height calibration
LANDROVER	Range Rover	2014 - 2015	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Audio front control module	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Audio front control module	Special Function	Navigation reset
LANDROVER	Range Rover	2014 - 2015	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Gear shift module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2014 - 2015	Front control/display interface module (high level display front)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2014 - 2015	Front control/display interface module (high level display front)	Read Data Stream	
LANDROVER	Range Rover	2014 - 2015	Front control/display interface module (high level display front)	Special Function	Calibrate dynamic volume control
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Diesel fueling adaption re - initialization
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Turbine shut - off valve
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Fuel Lift Pump
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	DC to DC electric power inverter converter module mode
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover	2014 - 2015	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover	2014 - 2015	Head up display	Special Function	Head up display control module reset
LANDROVER	Range Rover	2014 - 2015	Head up display	Special Function	Activate test picture
LANDROVER	Range Rover	2014 - 2015	Head up display	Special Function	Rear left seat massage on demand self test
LANDROVER	Range Rover	As of 2016	ABS control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	ABS control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	ABS control module	Special Function	Brake pedal position sensor - Calibration
LANDROVER	Range Rover	As of 2016	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	All terrain control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Body control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Body control module	Special Function	Steering column calibration
LANDROVER	Range Rover	As of 2016	Body control module	Special Function	Headlamp leveling height sensor calibration
LANDROVER	Range Rover	As of 2016	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover	As of 2016	Body control module	Special Function	Fuel pump supply - Enable/disable
LANDROVER	Range Rover	As of 2016	Body control module	Special Function	Ignition cycle counter reset
LANDROVER	Range Rover	As of 2016	Body control module	Special Function	Roof blind Calibration
LANDROVER	Range Rover	As of 2016	Body control module	Special Function	Sunroof calibration
LANDROVER	Range Rover	As of 2016	Body control module	Special Function	Motor replacement
LANDROVER	Range Rover	As of 2016	Battery energy control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Battery energy control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Battery energy control module	Special Function	Hybrid electric vehicle battery pack coolant pump replacement
LANDROVER	Range Rover	As of 2016	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Speed control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Chassis control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Chassis control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Chassis control module	Special Function	Adaptive speed control - Speed control alignment
LANDROVER	Range Rover	As of 2016	Chassis control module	Special Function	Set/un-set air suspension geometry set-up
LANDROVER	Range Rover	As of 2016	Chassis control module	Special Function	Set/un-Set Air Suspension Tight Tolerance Mode (Headlamp Setting)
LANDROVER	Range Rover	As of 2016	Chassis control module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Chassis control module B	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Electric power inverter converter module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Electric power inverter converter module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	General proximity sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	General proximity sensor module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Gear shift module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Gateway module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Gateway module	Special Function	Battery replacement
LANDROVER	Range Rover	As of 2016	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Range Rover	As of 2016	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Image processing control module A	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Image processing control module A	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Image processing control module A	Special Function	Automatic high beam camera calibration
LANDROVER	Range Rover	As of 2016	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	As of 2016	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Restraints occupant classification system module	Special Function	Seat cushion replacement
LANDROVER	Range Rover	As of 2016	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Parking assist control module	Special Function	Parking aid control module reset configuration state.
LANDROVER	Range Rover	As of 2016	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Range Rover	As of 2016	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Parking brake control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Range Rover	As of 2016	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover	As of 2016	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover	As of 2016	Parking brake control module	Special Function	Parking brake activation
LANDROVER	Range Rover	As of 2016	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Range Rover	As of 2016	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Service interval reset
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Idle speed test
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Powertrain control module adaption clear
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Reset selective catalyst reduction quality monitor
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Enable\disable glow plugs
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	DC to DC electric power inverter converter module mode
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover	As of 2016	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover	As of 2016	Restraints control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Restraints control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Restraints control module	Special Function	Restraints build mode
LANDROVER	Range Rover	As of 2016	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Power steering control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover	As of 2016	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Rear differential control module	Special Function	Control module calibration
LANDROVER	Range Rover	As of 2016	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover	As of 2016	Safety belt pretensioner control module A - drivers side	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Safety belt pretensioner control module A - drivers side	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Safety belt pretensioner control module B - passengers side	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	As of 2016	Safety belt pretensioner control module B - passengers side	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data
LANDROVER	Range Rover	As of 2016	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Transmission control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Transmission control module	Special Function	Telematics server communication check
LANDROVER	Range Rover	As of 2016	Telematic control unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Telematic control unit module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Telematic control unit module	Special Function	Activate telematics control module
LANDROVER	Range Rover	As of 2016	Telematic control unit module	Special Function	Reset/clear WiFi hotspot
LANDROVER	Range Rover	As of 2016	Telematic control unit module	Special Function	Network registration status
LANDROVER	Range Rover	As of 2016	Telematic control unit module	Special Function	Pre-activate telematics control module
LANDROVER	Range Rover	As of 2016	Telematic control unit module	Special Function	Telematics sim card type
LANDROVER	Range Rover	As of 2016	Telematic control unit module	Special Function	Operational mode
LANDROVER	Range Rover	As of 2016	Telematic control unit module	Special Function	Test internal backup battery
LANDROVER	Range Rover	As of 2016	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
LANDROVER	Range Rover	As of 2016	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Transfer case control module	Special Function	Absolute position sensor replacement
LANDROVER	Range Rover	As of 2016	Transfer case control module	Special Function	Transfer case replacement
LANDROVER	Range Rover	As of 2016	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Tire pressure monitor module	Special Function	Tire Pressure Sensor Replacement
LANDROVER	Range Rover	As of 2016	Tire pressure monitor module	Special Function	Tire Pressure Monitor Sensor Identification Display
LANDROVER	Range Rover	As of 2016	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Head-up display cooling fan module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Connect and view module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Connect and view module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Calf rest table module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Calf rest table module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Driver's door module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Driver's door module	Special Function	Door Window Calibration
LANDROVER	Range Rover	As of 2016	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Driver's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Driver's (side) rear door module	Special Function	Passenger side - Rear door blind initialisation
LANDROVER	Range Rover	As of 2016	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Driver's seat module	Special Function	Driver's Seat Calibration
LANDROVER	Range Rover	As of 2016	Driver's seat module	Special Function	Rear seat calibration
LANDROVER	Range Rover	As of 2016	Driver's seat module	Special Function	Rear right seat massage on demand self test
LANDROVER	Range Rover	As of 2016	Driver's seat module	Special Function	Driver's seat massage on demand self test
LANDROVER	Range Rover	As of 2016	Front control/display interface module (high level display front)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Front control/display interface module (high level display front)	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Front control/display interface module (high level display front)	Special Function	Calibrate dynamic volume control
LANDROVER	Range Rover	As of 2016	Front controls interface module C (front audio control panel)	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	As of 2016	Front controls interface module C (front audio control panel)	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Front controls interface module (heating ventilation air conditioning controls)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Front controls interface module (heating ventilation air conditioning controls)	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Front controls interface module B (front audio control panel)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Front controls interface module B (front audio control panel)	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Heating ventilation and air conditioning control module	Special Function	Reset compressor protection counter
LANDROVER	Range Rover	As of 2016	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
LANDROVER	Range Rover	As of 2016	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover	As of 2016	Heating ventilation and air conditioning control module	Special Function	Seat climate control module calibration
LANDROVER	Range Rover	As of 2016	Air suspension module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Air suspension module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Air suspension module	Special Function	Height calibration
LANDROVER	Range Rover	As of 2016	Head up display	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Head up display	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Head up display	Special Function	Head up display control module reset
LANDROVER	Range Rover	As of 2016	Head up display	Special Function	Activate test picture
LANDROVER	Range Rover	As of 2016	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Image processing module B	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Range Rover	As of 2016	Navigation control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Navigation control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Passenger's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Passenger's seat module	Special Function	Passenger's seat massage on demand self test
LANDROVER	Range Rover	As of 2016	Passenger's seat module	Special Function	Rear left seat massage on demand self test
LANDROVER	Range Rover	As of 2016	Passenger's seat module	Special Function	Rear seat calibration - passenger side
LANDROVER	Range Rover	As of 2016	Running board control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Running board control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Running board control module	Special Function	Service mode disabled
LANDROVER	Range Rover	As of 2016	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Rear gate / trunk module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Lower - Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Lower - Rear gate/trunk module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Rear Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Rear Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Audio front control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Digital audio broadcast module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	As of 2016	Navigation control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Navigation control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Rear entertainment control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Rear entertainment control module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Satellite audio unit module	Read Data Stream	
LANDROVER	Range Rover	As of 2016	Television module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	As of 2016	Television module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Adaption clear
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Fuel Lift Pump
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Injector valve test
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Adaptive fuel trim display
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Idle speed - Adjustment
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Display injector correction factors
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover Evoque	2012 - 2013	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover Evoque	2012 - 2013	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Transmission control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Transmission control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Transmission control module	Special Function	Transmission control module oil counter reset
LANDROVER	Range Rover Evoque	2012 - 2013	Transmission control module	Special Function	Adaption clear
LANDROVER	Range Rover Evoque	2012 - 2013	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Anti-lock Braking System	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Anti-lock Braking System	Special Function	Steering wheel angle sensor calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Anti-lock Braking System	Special Function	Longitudinal accelerometer sensor calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Anti-lock Braking System	Special Function	Lateral accelerometer calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Anti-lock Braking System	Special Function	Pressure sensor calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Anti-lock Braking System	Special Function	Roll rate sensor calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Anti-lock Braking System	Special Function	ABS control module configuration clear
LANDROVER	Range Rover Evoque	2012 - 2013	All wheel drive control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	All wheel drive control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	All wheel drive control module	Special Function	All wheel drive system - Pump bleed
LANDROVER	Range Rover Evoque	2012 - 2013	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Supplemental Inflatable Restraint System	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Range Rover Evoque	2012 - 2013	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Instrument cluster control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Instrument cluster control module	Special Function	Service interval reset
LANDROVER	Range Rover Evoque	2012 - 2013	Instrument cluster control module	Special Function	Vehicle reset
LANDROVER	Range Rover Evoque	2012 - 2013	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Power steering control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Special Function	Tire pressure monitor confirmation application
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Special Function	Battery replacement
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Special Function	Tire pressure monitor sensor identification display

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Special Function	Tire pressure monitoring tire pressure sensor test
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Special Function	Roof blind - Calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Body control module	Special Function	Height sensor-Calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Heating ventilation and air conditioning control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
LANDROVER	Range Rover Evoque	2012 - 2013	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover Evoque	2012 - 2013	Heating ventilation and air conditioning control module	Special Function	Re - program all stepper motors
LANDROVER	Range Rover Evoque	2012 - 2013	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Steering angle sensor module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Evoque	2012 - 2013	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Parking brake control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover Evoque	2012 - 2013	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover Evoque	2012 - 2013	Parking brake control module	Special Function	Parking brake activation
LANDROVER	Range Rover Evoque	2012 - 2013	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Parking brake control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Range Rover Evoque	2012 - 2013	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Passenger's seat module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Parking assist control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Auxiliary heater control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Auxiliary heater control module	Special Function	Auxiliary heater priming routine
LANDROVER	Range Rover Evoque	2012 - 2013	Auxiliary heater control module	Special Function	Auxiliary heater activation test
LANDROVER	Range Rover Evoque	2012 - 2013	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Vehicle immobilizer control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Driver's door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Driver's door module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Driver's door module	Special Function	Driver's door window glass calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Driver's seat module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
LANDROVER	Range Rover Evoque	2012 - 2013	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	All terrain control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Adaptive damping control module	Version Information	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque	2012 - 2013	Adaptive damping control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Rear differential control module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Restraints occupant classification system module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Restraints occupant classification system module	Special Function	Seats - Seat cover replacement
LANDROVER	Range Rover Evoque	2012 - 2013	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Headlamp Control Module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Headlamp Control Module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Keyless vehicle module	Special Function	Check all antennas
LANDROVER	Range Rover Evoque	2012 - 2013	Keyless vehicle module	Special Function	Recover programmed keys
LANDROVER	Range Rover Evoque	2012 - 2013	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Audio amplifier module	Special Function	DVD region counter reset
LANDROVER	Range Rover Evoque	2012 - 2013	Audio amplifier module	Special Function	Calibrate dynamic volume control
LANDROVER	Range Rover Evoque	2012 - 2013	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Rear gate/trunk module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Rear gate/trunk module	Special Function	Tailgate/trunk calibration
LANDROVER	Range Rover Evoque	2012 - 2013	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Image processing module B	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Image processing module B	Special Function	Camera auto learn routine
LANDROVER	Range Rover Evoque	2012 - 2013	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Audio front control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Audio front control module	Special Function	Navigation reset
LANDROVER	Range Rover Evoque	2012 - 2013	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Side object detection control module - Left	Special Function	Side object detection mode history
LANDROVER	Range Rover Evoque	2012 - 2013	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2012 - 2013	Gear shift module	Read Data Stream	
LANDROVER	Range Rover Evoque	2012 - 2013	Keyless vehicle module	Version Information	
LANDROVER	Range Rover Evoque	2012 - 2013	Keyless vehicle module	Special Function	Check passive keys enabled
LANDROVER	Range Rover Evoque	2012 - 2013	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Service interval reset
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Adaption clear
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover Evoque	2014 - 2015	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Transmission control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Anti-lock Braking System	Special Function	Steering wheel angle sensor calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Anti-lock Braking System	Special Function	Pressure sensor calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Anti-lock Braking System	Special Function	ABS control module configuration clear
LANDROVER	Range Rover Evoque	2014 - 2015	All wheel drive control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	All wheel drive control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	All wheel drive control module	Special Function	All wheel drive system - Pump bleed
LANDROVER	Range Rover Evoque	2014 - 2015	All wheel drive control module	Special Function	All wheel drive system - Pump venting
LANDROVER	Range Rover Evoque	2014 - 2015	All wheel drive control module	Special Function	High oil temperature reset
LANDROVER	Range Rover Evoque	2014 - 2015	Supplemental Inflatable Restraint System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Supplemental Inflatable Restraint System	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Supplemental Inflatable Restraint System	Special Function	Restraints build mode
LANDROVER	Range Rover Evoque	2014 - 2015	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Ride level control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque	2014 - 2015	Ride level control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Ride level control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Power steering control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Special Function	Tire pressure monitor sensor identification display
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Special Function	Fuel pump supply - Enable/disable
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Special Function	Roof blind calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Special Function	Verify Keys
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Special Function	Ignition cycle counter reset
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Special Function	Roof blind - Calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Body control module	Special Function	Height sensor-Calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover Evoque	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
LANDROVER	Range Rover Evoque	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Re - program all stepper motors
LANDROVER	Range Rover Evoque	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Seat climate control module calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Run in air conditioning compressor
LANDROVER	Range Rover Evoque	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Climate seat unlock
LANDROVER	Range Rover Evoque	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Reset air conditioning compressor
LANDROVER	Range Rover Evoque	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Climate seat unlock
LANDROVER	Range Rover Evoque	2014 - 2015	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Evoque	2014 - 2015	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover Evoque	2014 - 2015	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover Evoque	2014 - 2015	Parking brake control module	Special Function	Parking brake activation
LANDROVER	Range Rover Evoque	2014 - 2015	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Passenger's seat module	Special Function	Power steering soft - lock end stops reset routine
LANDROVER	Range Rover Evoque	2014 - 2015	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Range Rover Evoque	2014 - 2015	Parking assist control module	Special Function	Parking aid control module reset configuration state
LANDROVER	Range Rover Evoque	2014 - 2015	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Auxiliary heater control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Auxiliary heater control module	Special Function	Auxiliary heater priming routine
LANDROVER	Range Rover Evoque	2014 - 2015	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Gateway module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Gateway module	Special Function	Battery replacement
LANDROVER	Range Rover Evoque	2014 - 2015	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Range Rover Evoque	2014 - 2015	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Driver's door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Driver's door module	Special Function	Driver's door window glass calibration

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque	2014 - 2015	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Driver's seat module	Special Function	Driver's seat calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Passenger's door module	Special Function	Passenger's door window glass calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Passenger's seat module	Version Information	
LANDROVER	Range Rover Evoque	2014 - 2015	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Transfer case control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Transfer case control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Adaptive damping control module	Version Information	
LANDROVER	Range Rover Evoque	2014 - 2015	Adaptive damping control module	Special Function	Air suspension height calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Speed control module	Special Function	Speed control alignment
LANDROVER	Range Rover Evoque	2014 - 2015	Rear differential control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Rear differential control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Light check module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Light check module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Restraints occupant classification system module	Special Function	Seats - Seat cover replacement
LANDROVER	Range Rover Evoque	2014 - 2015	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Headlamp Control Module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Headlamp Control Module	Special Function	Headlamp control module system calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Keyless vehicle module	Special Function	Check all antennas
LANDROVER	Range Rover Evoque	2014 - 2015	Keyless vehicle module	Special Function	Check passive keys enabled
LANDROVER	Range Rover Evoque	2014 - 2015	Keyless vehicle module	Special Function	Recover programmed keys
LANDROVER	Range Rover Evoque	2014 - 2015	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Audio amplifier module	Special Function	Calibrate dynamic volume control
LANDROVER	Range Rover Evoque	2014 - 2015	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Rear gate/trunk module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Rear gate/trunk module	Special Function	Tailgate/trunk calibration
LANDROVER	Range Rover Evoque	2014 - 2015	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Image processing module B	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Image processing module B	Special Function	Camera auto learn routine
LANDROVER	Range Rover Evoque	2014 - 2015	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Audio front control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Gear shift module	Read Data Stream	
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Diesel fueling adaption re - initialization
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Fuel Lift Pump
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Idle speed - Adjustment
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Turbine shut - off valve
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Oil change reset
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover Evoque	2014 - 2015	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover Evoque	2014 - 2015	Head up display	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2014 - 2015	Head up display	Special Function	Head up display control module reset
LANDROVER	Range Rover Evoque	2014 - 2015	Head up display	Special Function	Activate test picture
LANDROVER	Range Rover Evoque	2016	ABS control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque	2016	ABS control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	ABS control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Range Rover Evoque	2016	ABS control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover Evoque	2016	ABS control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover Evoque	2016	ABS control module	Special Function	Parking brake activation
LANDROVER	Range Rover Evoque	2016	ABS control module	Special Function	Apply and release electric park brake
LANDROVER	Range Rover Evoque	2016	ABS control module	Special Function	Steering angle sensor calibration
LANDROVER	Range Rover Evoque	2016	ABS control module	Special Function	Pressure sensor calibration
LANDROVER	Range Rover Evoque	2016	ABS control module	Special Function	ABS control module configuration clear
LANDROVER	Range Rover Evoque	2016	All wheel drive control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	All wheel drive control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	All wheel drive control module	Special Function	All wheel drive system - Pump bleed
LANDROVER	Range Rover Evoque	2016	All wheel drive control module	Special Function	All wheel drive system - Pump venting
LANDROVER	Range Rover Evoque	2016	All wheel drive control module	Special Function	High oil temperature reset
LANDROVER	Range Rover Evoque	2016	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Body control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Body control module	Special Function	Fuel pump supply - Enable/disable
LANDROVER	Range Rover Evoque	2016	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover Evoque	2016	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover Evoque	2016	Body control module	Special Function	Ignition cycle counter reset
LANDROVER	Range Rover Evoque	2016	Body control module	Special Function	Roof blind - Calibration
LANDROVER	Range Rover Evoque	2016	Body control module	Special Function	Height sensor-Calibration
LANDROVER	Range Rover Evoque	2016	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Speed control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Gear shift module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Gateway module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Gateway module	Special Function	Battery replacement
LANDROVER	Range Rover Evoque	2016	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Range Rover Evoque	2016	Headlamp control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Headlamp control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Headlamp control module	Special Function	Headlamp control module system calibration
LANDROVER	Range Rover Evoque	2016	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Restraints occupant classification system module	Special Function	Seat cushion replacement
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Powertrain control module adaption clear
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Service interval reset
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Fuel Prime Routine
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Engine control module reset fuel pump adaption
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Engine control module swirl valve adaption clear
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Enable\disable glow plugs
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Engine control module reset crank case pressure sensor
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover Evoque	2016	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover Evoque	2016	Restraints control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Restraints control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Restraints control module	Special Function	Restraints build mode
LANDROVER	Range Rover Evoque	2016	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Transmission control module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque	2016	Transmission control module	Special Function	Telematics server communication check
LANDROVER	Range Rover Evoque	2016	Telematic control unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Telematic control unit module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Telematic control unit module	Special Function	Activate telematics control module
LANDROVER	Range Rover Evoque	2016	Telematic control unit module	Special Function	Network registration status
LANDROVER	Range Rover Evoque	2016	Telematic control unit module	Special Function	Pre-activate telematics control module
LANDROVER	Range Rover Evoque	2016	Telematic control unit module	Special Function	Telematics sim card type
LANDROVER	Range Rover Evoque	2016	Telematic control unit module	Special Function	Operational mode
LANDROVER	Range Rover Evoque	2016	Telematic control unit module	Special Function	Test internal backup battery
LANDROVER	Range Rover Evoque	2016	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
LANDROVER	Range Rover Evoque	2016	Telematic control unit module	Special Function	Brazilian telematics identification transfer
LANDROVER	Range Rover Evoque	2016	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Tire pressure monitor module	Special Function	Tire Pressure Sensor Replacement
LANDROVER	Range Rover Evoque	2016	Tire pressure monitor module	Special Function	Tire Pressure Monitor Sensor Identification Display
LANDROVER	Range Rover Evoque	2016	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	General proximity sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	General proximity sensor module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Image processing control module A	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Image processing control module A	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Image processing control module A	Special Function	Automatic high beam camera calibration
LANDROVER	Range Rover Evoque	2016	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Range Rover Evoque	2016	Parking assist control module	Special Function	Parking aid control module reset configuration state
LANDROVER	Range Rover Evoque	2016	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Power steering control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Power steering control module	Special Function	Power steering soft-lock end stops reset routine
LANDROVER	Range Rover Evoque	2016	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover Evoque	2016	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Evoque	2016	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Range Rover Evoque	2016	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Driver's door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Driver's door module	Special Function	Door Window Calibration
LANDROVER	Range Rover Evoque	2016	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Driver's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Driver's seat module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque	2016	Driver's seat module	Special Function	Driver's Seat Calibration
LANDROVER	Range Rover Evoque	2016	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Range Rover Evoque	2016	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Passenger's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Rear gate / trunk module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	InControl Touch audio head unit	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	InControl Touch audio head unit	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Head-up display cooling fan module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Connect and view module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Connect and view module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Front control/display interface module (high level display front)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Front control/display interface module (high level display front)	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Head up display	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Head up display	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Head up display	Special Function	Head up display control module reset
LANDROVER	Range Rover Evoque	2016	Head up display	Special Function	Activate test picture
LANDROVER	Range Rover Evoque	2016	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
LANDROVER	Range Rover Evoque	2016	Heating ventilation and air conditioning control module	Special Function	Reset air conditioning compressor
LANDROVER	Range Rover Evoque	2016	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover Evoque	2016	Heating ventilation and air conditioning control module	Special Function	Climate seat unlock
LANDROVER	Range Rover Evoque	2016	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Image processing module B	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Navigation control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Navigation control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Audio front control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Digital audio broadcast module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Navigation control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Navigation control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Rear entertainment control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Rear entertainment control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Satellite audio unit module	Read Data Stream	
LANDROVER	Range Rover Evoque	2016	Television module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2016	Television module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	ABS control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	ABS control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	ABS control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Range Rover Evoque	2017	ABS control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover Evoque	2017	ABS control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover Evoque	2017	ABS control module	Special Function	Parking brake activation
LANDROVER	Range Rover Evoque	2017	ABS control module	Special Function	Apply and release electric park brake
LANDROVER	Range Rover Evoque	2017	ABS control module	Special Function	Steering angle sensor calibration

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque	2017	ABS control module	Special Function	ABS control module configuration clear
LANDROVER	Range Rover Evoque	2017	All wheel drive control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	All wheel drive control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	All wheel drive control module	Special Function	All wheel drive system - Pump bleed
LANDROVER	Range Rover Evoque	2017	All wheel drive control module	Special Function	All wheel drive system - Pump venting
LANDROVER	Range Rover Evoque	2017	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Body control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover Evoque	2017	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover Evoque	2017	Body control module	Special Function	Ignition cycle counter reset
LANDROVER	Range Rover Evoque	2017	Body control module	Special Function	Roof blind - Calibration
LANDROVER	Range Rover Evoque	2017	Body control module	Special Function	Height sensor-Calibration
LANDROVER	Range Rover Evoque	2017	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Speed control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Gear shift module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Gateway module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Gateway module	Special Function	Battery replacement
LANDROVER	Range Rover Evoque	2017	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Range Rover Evoque	2017	Headlamp control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Headlamp control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Headlamp control module	Special Function	Headlamp control module system calibration
LANDROVER	Range Rover Evoque	2017	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Restraints occupant classification system module	Special Function	Seat cushion replacement
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Service interval reset
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Fuel Prime Routine
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Engine control module low pressure LOR adaption
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Engine control module reset fuel pump adaption
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Reset selective catalyst reduction quality monitor
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Enable\disable glow plugs
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Engine control module reset crank case pressure sensor
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover Evoque	2017	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover Evoque	2017	Restraints control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Restraints control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Restraints control module	Special Function	Restraints build mode
LANDROVER	Range Rover Evoque	2017	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Transmission control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Transmission control module	Special Function	Telematics server communication check
LANDROVER	Range Rover Evoque	2017	Telematic control unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Telematic control unit module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Telematic control unit module	Special Function	Activate telematics control module
LANDROVER	Range Rover Evoque	2017	Telematic control unit module	Special Function	Network registration status
LANDROVER	Range Rover Evoque	2017	Telematic control unit module	Special Function	Pre-activate telematics control module
LANDROVER	Range Rover Evoque	2017	Telematic control unit module	Special Function	Telematics sim card type
LANDROVER	Range Rover Evoque	2017	Telematic control unit module	Special Function	Operational mode
LANDROVER	Range Rover Evoque	2017	Telematic control unit module	Special Function	Test internal backup battery

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque	2017	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
LANDROVER	Range Rover Evoque	2017	Telematic control unit module	Special Function	Brazilian telematics identification transfer
LANDROVER	Range Rover Evoque	2017	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Folding top control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Folding top control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Folding top control module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Folding top control module B	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	General proximity sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	General proximity sensor module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Image processing control module A	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Image processing control module A	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Image processing control module A	Special Function	Automatic high beam camera calibration
LANDROVER	Range Rover Evoque	2017	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Range Rover Evoque	2017	Parking assist control module	Special Function	Parking aid control module reset configuration state
LANDROVER	Range Rover Evoque	2017	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Power steering control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Power steering control module	Special Function	Power steering soft-lock end stops reset routine
LANDROVER	Range Rover Evoque	2017	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover Evoque	2017	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Evoque	2017	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	InControl Touch audio head unit	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	InControl Touch audio head unit	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Head-up display cooling fan module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Head up display	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Head up display	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Head up display	Special Function	Head up display control module reset
LANDROVER	Range Rover Evoque	2017	Head up display	Special Function	Activate test picture
LANDROVER	Range Rover Evoque	2017	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
LANDROVER	Range Rover Evoque	2017	Heating ventilation and air conditioning control module	Special Function	Reset air conditioning compressor
LANDROVER	Range Rover Evoque	2017	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover Evoque	2017	Heating ventilation and air conditioning control module	Special Function	Climate seat unlock
LANDROVER	Range Rover Evoque	2017	InControl Touch Pro infotainment master controller	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	InControl Touch Pro infotainment master controller	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Image processing module B	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque	2017	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	InControl Touch Pro audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	InControl Touch Pro audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	InControl Touch Pro infotainment slave controller	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	InControl Touch Pro infotainment slave controller	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Driver's door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Driver's door module	Special Function	Door Window Calibration
LANDROVER	Range Rover Evoque	2017	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Driver's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Driver's seat module	Special Function	Driver's Seat Calibration
LANDROVER	Range Rover Evoque	2017	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Range Rover Evoque	2017	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Passenger's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque	2017	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque	2017	Rear gate / trunk module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	ABS control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	ABS control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	ABS control module	Special Function	Steering angle sensor calibration
LANDROVER	Range Rover Evoque convertible	2016	ABS control module	Special Function	Pressure sensor calibration
LANDROVER	Range Rover Evoque convertible	2016	ABS control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Range Rover Evoque convertible	2016	ABS control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover Evoque convertible	2016	ABS control module	Special Function	Parking brake activation
LANDROVER	Range Rover Evoque convertible	2016	ABS control module	Special Function	Apply and release electric park brake
LANDROVER	Range Rover Evoque convertible	2016	ABS control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover Evoque convertible	2016	All wheel drive control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	All wheel drive control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	All wheel drive control module	Special Function	All wheel drive system - Pump venting
LANDROVER	Range Rover Evoque convertible	2016	All wheel drive control module	Special Function	All wheel drive system - Pump bleed
LANDROVER	Range Rover Evoque convertible	2016	All wheel drive control module	Special Function	High oil temperature reset
LANDROVER	Range Rover Evoque convertible	2016	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Body control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover Evoque convertible	2016	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover Evoque convertible	2016	Body control module	Special Function	Fuel pump supply - Enable/disable
LANDROVER	Range Rover Evoque convertible	2016	Body control module	Special Function	Ignition cycle counter reset
LANDROVER	Range Rover Evoque convertible	2016	Body control module	Special Function	Height sensor-Calibration
LANDROVER	Range Rover Evoque convertible	2016	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Speed control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Speed control module	Special Function	Speed control alignment
LANDROVER	Range Rover Evoque convertible	2016	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Gear shift module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque convertible	2016	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Gateway module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Gateway module	Special Function	Battery replacement
LANDROVER	Range Rover Evoque convertible	2016	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Range Rover Evoque convertible	2016	Headlamp control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Headlamp control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Headlamp control module	Special Function	Headlamp control module system calibration
LANDROVER	Range Rover Evoque convertible	2016	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Service interval reset
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Powertrain control module adaption clear
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Oil change reset
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Engine control module low pressure EGR adaption clear
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Activate glow plug control
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Engine control module reset fuel pump adaption
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Engine control module swirl valve adaption clear
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Reset selective catalyst reduction quality monitor
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Enable\disable glow plugs
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Evaporative system diagnostic test

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque convertible	2016	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover Evoque convertible	2016	Restraints control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Restraints control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Restraints control module	Special Function	Restraints build mode
LANDROVER	Range Rover Evoque convertible	2016	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Transmission control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Transmission control module	Special Function	Telematics server communication check
LANDROVER	Range Rover Evoque convertible	2016	Telematic control unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Telematic control unit module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Telematic control unit module	Special Function	Activate telematics control module
LANDROVER	Range Rover Evoque convertible	2016	Telematic control unit module	Special Function	Network registration status
LANDROVER	Range Rover Evoque convertible	2016	Telematic control unit module	Special Function	Pre-activate telematics control module
LANDROVER	Range Rover Evoque convertible	2016	Telematic control unit module	Special Function	Telematics sim card type
LANDROVER	Range Rover Evoque convertible	2016	Telematic control unit module	Special Function	Operational mode
LANDROVER	Range Rover Evoque convertible	2016	Telematic control unit module	Special Function	Test internal backup battery
LANDROVER	Range Rover Evoque convertible	2016	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
LANDROVER	Range Rover Evoque convertible	2016	Telematic control unit module	Special Function	Brazilian telematics identification transfer
LANDROVER	Range Rover Evoque convertible	2016	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Tire pressure monitor module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
LANDROVER	Range Rover Evoque convertible	2016	Tire pressure monitor module	Special Function	Tire pressure monitor sensor identification display
LANDROVER	Range Rover Evoque convertible	2016	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Folding top control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Folding top control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Folding top control module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Folding top control module B	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	General proximity sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	General proximity sensor module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Image processing control module A	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Image processing control module A	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Image processing control module A	Special Function	Automatic high beam camera calibration
LANDROVER	Range Rover Evoque convertible	2016	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Range Rover Evoque convertible	2016	Parking assist control module	Special Function	Parking aid control module reset configuration state
LANDROVER	Range Rover Evoque convertible	2016	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Power steering control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover Evoque convertible	2016	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Steering angle sensor module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque convertible	2016	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Evoque convertible	2016	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	InControl Touch audio head unit	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	InControl Touch audio head unit	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Head-up display cooling fan module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Head up display	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Head up display	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Head up display	Special Function	Head up display control module reset
LANDROVER	Range Rover Evoque convertible	2016	Head up display	Special Function	Activate test picture
LANDROVER	Range Rover Evoque convertible	2016	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
LANDROVER	Range Rover Evoque convertible	2016	Heating ventilation and air conditioning control module	Special Function	Reset air conditioning compressor
LANDROVER	Range Rover Evoque convertible	2016	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Range Rover Evoque convertible	2016	Heating ventilation and air conditioning control module	Special Function	Climate seat unlock
LANDROVER	Range Rover Evoque convertible	2016	InControl Touch Pro infotainment master controller	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	InControl Touch Pro infotainment master controller	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Image processing module B	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	InControl Touch Pro audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	InControl Touch Pro audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Driver's door module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Driver's door module	Special Function	Door Window Calibration
LANDROVER	Range Rover Evoque convertible	2016	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Driver's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Driver's seat module	Special Function	Driver's Seat Calibration
LANDROVER	Range Rover Evoque convertible	2016	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Range Rover Evoque convertible	2016	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Passenger's (side) rear door module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque convertible	2016	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque convertible	2016	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque convertible	2016	Rear gate / trunk module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	ABS control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	ABS control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	ABS control module	Special Function	Steering angle sensor calibration
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	ABS control module	Special Function	Pressure sensor calibration
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	ABS control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	ABS control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	ABS control module	Special Function	Parking brake activation
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	ABS control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	All wheel drive control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	All wheel drive control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	All wheel drive control module	Special Function	All wheel drive system - Pump venting
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	All wheel drive control module	Special Function	All wheel drive system - Pump bleed
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	All wheel drive control module	Special Function	High oil temperature reset
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Body control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Body control module	Special Function	Valet mode reset
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Body control module	Special Function	Transportation mode
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Body control module	Special Function	Fuel pump supply - Enable/disable
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Body control module	Special Function	Ignition cycle counter reset
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Body control module	Special Function	Roof blind - Calibration
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Body control module	Special Function	Height sensor-Calibration
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Speed control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Speed control module	Special Function	Speed control alignment
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Gear shift module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Gateway module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Gateway module	Special Function	Battery replacement
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Headlamp control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Headlamp control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Headlamp control module	Special Function	Headlamp control module system calibration
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Instrument cluster control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Service interval reset
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Fuel prime routine
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Powertrain control module adaption clear
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Oil change reset
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Injector replacement
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Throttle valve actuator replacement
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Restraints control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Restraints control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Restraints control module	Special Function	Restraints build mode
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Transmission control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Transmission control module	Special Function	Telematics server communication check
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Telematic control unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Telematic control unit module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Telematic control unit module	Special Function	Activate telematics control module
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Telematic control unit module	Special Function	Network registration status
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Telematic control unit module	Special Function	Pre-activate telematics control module
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Telematic control unit module	Special Function	Telematics sim card type
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Telematic control unit module	Special Function	Operational mode
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Telematic control unit module	Special Function	Test internal backup battery
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Telematic control unit module	Special Function	Brazilian telematics identification transfer
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	All terrain control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	General proximity sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	General proximity sensor module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Image processing control module A	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Image processing control module A	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Image processing control module A	Special Function	Automatic high beam camera calibration
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Parking assist control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Parking assist control module	Special Function	Parking aid control module reset configuration state
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Parking brake control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Parking brake control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Parking brake control module	Special Function	Longitudinal accelerometer calibration
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Power steering control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Power steering control module	Special Function	Power steering soft-lock end stops reset routine
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Steering angle sensor module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Adaptive damping control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Driver's door module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Driver's door module	Special Function	Door Window Calibration
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Driver's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Driver's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Driver's seat module	Special Function	Driver's Seat Calibration
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Keyless vehicle module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Passenger's door module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Passenger's (side) rear door module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Passenger's seat module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Rear gate / trunk module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	InControl Touch audio head unit	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	InControl Touch audio head unit	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Head-up display cooling fan module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Connect and view module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Connect and view module	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Front control/display interface module (high level display front)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Front control/display interface module (high level display front)	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Head up display	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Head up display	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Head up display	Special Function	Head up display control module reset
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Head up display	Special Function	Activate test picture
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Heating ventilation and air conditioning control module	Special Function	Reset air conditioning compressor
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Heating ventilation and air conditioning control module	Special Function	Climate seat unlock
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Image processing module B	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Navigation control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Navigation control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Side object detection control module - Left	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Side object detection control module - Right	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Audio amplifier module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Audio front control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Digital audio broadcast module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Navigation control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Navigation control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Rear entertainment control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Rear entertainment control module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Satellite audio unit module	Read Data Stream	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Television module	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover Evoque(L538JV)	As of 2016	Television module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	ABS control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	ABS control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	ABS control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Discovery Sport	2015 - 2016	ABS control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Discovery Sport	2015 - 2016	ABS control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Discovery Sport	2015 - 2016	ABS control module	Special Function	Parking brake activation
LANDROVER	Discovery Sport	2015 - 2016	ABS control module	Special Function	Apply and release electric park brake
LANDROVER	Discovery Sport	2015 - 2016	ABS control module	Special Function	Steering angle sensor calibration
LANDROVER	Discovery Sport	2015 - 2016	ABS control module	Special Function	ABS control module configuration clear
LANDROVER	Discovery Sport	2015 - 2016	ABS control module	Special Function	Pressure sensor calibration
LANDROVER	Discovery Sport	2015 - 2016	Chassis control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Chassis control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Chassis control module	Special Function	Adaptive speed control - Speed control alignment
LANDROVER	Discovery Sport	2015 - 2016	All wheel drive control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Discovery Sport	2015 - 2016	All wheel drive control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	All wheel drive control module	Special Function	All wheel drive system - Pump venting
LANDROVER	Discovery Sport	2015 - 2016	All wheel drive control module	Special Function	All wheel drive system - Pump bleed
LANDROVER	Discovery Sport	2015 - 2016	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Body control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Body control module	Special Function	Valet mode reset
LANDROVER	Discovery Sport	2015 - 2016	Body control module	Special Function	Transportation mode
LANDROVER	Discovery Sport	2015 - 2016	Body control module	Special Function	Fuel pump supply - Enable(disable)
LANDROVER	Discovery Sport	2015 - 2016	Body control module	Special Function	Ignition cycle counter reset
LANDROVER	Discovery Sport	2015 - 2016	Body control module	Special Function	Roof blind - Calibration
LANDROVER	Discovery Sport	2015 - 2016	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Speed control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Gear shift module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Gateway module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Gateway module	Special Function	Battery replacement
LANDROVER	Discovery Sport	2015 - 2016	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Discovery Sport	2015 - 2016	Headlamp control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Headlamp control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Headlamp control module	Special Function	Headlamp control module system calibration
LANDROVER	Discovery Sport	2015 - 2016	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Instrument cluster control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Restraints occupant classification system module	Special Function	Seat cushion replacement
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Service interval reset
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Powertrain control module adaption clear
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Fuel Prime Routine
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Injector replacement
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Engine control module low pressure EGR adaption
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Engine control module reset fuel pump adaption
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Engine control module swirl valve adaption clear
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Reset selective catalyst reduction quality monitor
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Enable\disable glow plugs
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Engine control module reset crank case pressure sensor
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Discovery Sport	2015 - 2016	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Discovery Sport	2015 - 2016	Restraints control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Restraints control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Restraints control module	Special Function	Restraints build mode
LANDROVER	Discovery Sport	2015 - 2016	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Transmission control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Transmission control module	Special Function	Telematics server communication check
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Special Function	Telematics control module battery replacement reset
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Special Function	Activate telematics control module
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Special Function	Network registration status
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Special Function	Pre-activate telematics control module
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Special Function	Telematics sim card type

make	model	year	system	function	subfunction
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Special Function	Operational mode
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Special Function	Test internal backup battery
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
LANDROVER	Discovery Sport	2015 - 2016	Telematic control unit module	Special Function	Brazilian telematics identification transfer
LANDROVER	Discovery Sport	2015 - 2016	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Adaptive damping control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	All terrain control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	General proximity sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	General proximity sensor module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Image processing control module A	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Image processing control module A	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Image processing control module A	Special Function	Automatic high beam camera calibration
LANDROVER	Discovery Sport	2015 - 2016	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Parking assist control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Discovery Sport	2015 - 2016	Parking assist control module	Special Function	Parking aid control module reset configuration state
LANDROVER	Discovery Sport	2015 - 2016	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Power steering control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Power steering control module	Special Function	Power steering soft-lock end stops reset routine
LANDROVER	Discovery Sport	2015 - 2016	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Discovery Sport	2015 - 2016	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Steering angle sensor module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Discovery Sport	2015 - 2016	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Driver's door module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Driver's door module	Special Function	Door Window Calibration
LANDROVER	Discovery Sport	2015 - 2016	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Driver's (side) rear door module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Driver's seat module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Driver's seat module	Special Function	Driver's Seat Calibration
LANDROVER	Discovery Sport	2015 - 2016	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Keyless vehicle module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Discovery Sport	2015 - 2016	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Passenger's door module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Passenger's (side) rear door module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Passenger's seat module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Rear gate / trunk module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Auxiliary heater control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	InControl Touch audio head unit	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	InControl Touch audio head unit	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Head-up display cooling fan module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Connect and view module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Discovery Sport	2015 - 2016	Connect and view module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Front control/display interface module (high level display front)	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Front control/display interface module (high level display front)	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Front control/display interface module (high level display front)	Special Function	Calibrate dynamic volume control
LANDROVER	Discovery Sport	2015 - 2016	Head up display	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Head up display	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Head up display	Special Function	Head up display control module reset
LANDROVER	Discovery Sport	2015 - 2016	Head up display	Special Function	Activate test picture
LANDROVER	Discovery Sport	2015 - 2016	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
LANDROVER	Discovery Sport	2015 - 2016	Heating ventilation and air conditioning control module	Special Function	Reset air conditioning compressor
LANDROVER	Discovery Sport	2015 - 2016	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Discovery Sport	2015 - 2016	Heating ventilation and air conditioning control module	Special Function	Climate seat unlock
LANDROVER	Discovery Sport	2015 - 2016	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Image processing module B	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Navigation control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Navigation control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Side object detection control module - Left	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Side object detection control module - Right	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Deployable towbar control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Deployable towbar control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Deployable towbar control module	special Function	Stow deployable towbar
LANDROVER	Discovery Sport	2015 - 2016	Deployable towbar control module	special Function	Deploy deployable towbar
LANDROVER	Discovery Sport	2015 - 2016	Deployable towbar control module	special Function	Unlock deployable towbar
LANDROVER	Discovery Sport	2015 - 2016	Deployable towbar control module	special Function	Deployable towbar recovery
LANDROVER	Discovery Sport	2015 - 2016	Audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Audio amplifier module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Audio front control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Audio front control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Digital audio broadcast module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Navigation control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Navigation control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Rear entertainment control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Rear entertainment control module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Satellite audio unit module	Read Data Stream	
LANDROVER	Discovery Sport	2015 - 2016	Television module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	2015 - 2016	Television module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	ABS control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	ABS control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	ABS control module	Special Function	Brake caliper replacement assembly test
LANDROVER	Discovery Sport	As of 2017	ABS control module	Special Function	Parking brake pad replacement - Release to service position
LANDROVER	Discovery Sport	As of 2017	ABS control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
LANDROVER	Discovery Sport	As of 2017	ABS control module	Special Function	Parking brake activation
LANDROVER	Discovery Sport	As of 2017	ABS control module	Special Function	Apply and release electric park brake
LANDROVER	Discovery Sport	As of 2017	ABS control module	Special Function	Steering angle sensor calibration
LANDROVER	Discovery Sport	As of 2017	ABS control module	Special Function	ABS control module configuration clear
LANDROVER	Discovery Sport	As of 2017	ABS control module	Special Function	Pressure sensor calibration
LANDROVER	Discovery Sport	As of 2017	Chassis control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Chassis control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Chassis control module	Special Function	Adaptive speed control - Speed control alignment
LANDROVER	Discovery Sport	As of 2017	All wheel drive control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
LANDROVER	Discovery Sport	As of 2017	All wheel drive control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	All wheel drive control module	Special Function	All wheel drive system - Pump venting
LANDROVER	Discovery Sport	As of 2017	All wheel drive control module	Special Function	All wheel drive system - Pump bleed
LANDROVER	Discovery Sport	As of 2017	Body control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Body control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Body control module	Special Function	Valet mode reset
LANDROVER	Discovery Sport	As of 2017	Body control module	Special Function	Transportation mode
LANDROVER	Discovery Sport	As of 2017	Body control module	Special Function	Fuel pump supply - Enable(disable)
LANDROVER	Discovery Sport	As of 2017	Body control module	Special Function	Ignition cycle counter reset
LANDROVER	Discovery Sport	As of 2017	Body control module	Special Function	Roof blind - Calibration
LANDROVER	Discovery Sport	As of 2017	Speed control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Speed control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Gear shift module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Gear shift module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Gateway module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Gateway module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Gateway module	Special Function	Battery replacement
LANDROVER	Discovery Sport	As of 2017	Gateway module	Special Function	Quiescent current control module internal check
LANDROVER	Discovery Sport	As of 2017	Headlamp control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Headlamp control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Headlamp control module	Special Function	Headlamp control module system calibration
LANDROVER	Discovery Sport	As of 2017	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Instrument cluster control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Restraints occupant classification system module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Restraints occupant classification system module	Special Function	Seat cushion replacement
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Oil service counter reset
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Service interval reset
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Diesel particulate filter replacement
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Powertrain control module adaption clear
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Reset water in fuel detection
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Fuel Prime Routine
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Throttle valve actuator
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Injector replacement
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Oxygen sensor
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Oxidation catalyst
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Engine control module low pressure LGR adaption
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Engine control module reset fuel pump adaption
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Engine control module swirl valve adaption clear
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Exhaust gas recirculation valve
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Purge valve self test
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Enable/disable glow plugs
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Engine control module reset crank case pressure sensor
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Evaporative system diagnostic test
LANDROVER	Discovery Sport	As of 2017	Powertrain control module	Special Function	Fuel lift pump
LANDROVER	Discovery Sport	As of 2017	Restraints control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Restraints control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Restraints control module	Special Function	Restraints build mode
LANDROVER	Discovery Sport	As of 2017	Transmission control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Transmission control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Transmission control module	Special Function	Telematics server communication check
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Special Function	Telematics control module battery replacement reset
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Special Function	Activate telematics control module
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Special Function	Network registration status
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Special Function	Pre-activate telematics control module
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Special Function	Telematics sim card type

make	model	year	system	function	subfunction
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Special Function	Operational mode
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Special Function	Test internal backup battery
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
LANDROVER	Discovery Sport	As of 2017	Telematic control unit module	Special Function	Brazilian telematics identification transfer
LANDROVER	Discovery Sport	As of 2017	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Vehicle immobilizer control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	All terrain control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	All terrain control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	General proximity sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	General proximity sensor module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Image processing control module A	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Image processing control module A	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Image processing control module A	Special Function	Automatic high beam camera calibration
LANDROVER	Discovery Sport	As of 2017	Parking assist control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Parking assist control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Parking assist control module	Special Function	Parking aid control module reset
LANDROVER	Discovery Sport	As of 2017	Parking assist control module	Special Function	Parking aid control module reset configuration state
LANDROVER	Discovery Sport	As of 2017	Power steering control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Power steering control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Power steering control module	Special Function	Power steering soft-lock end stops reset routine
LANDROVER	Discovery Sport	As of 2017	Power steering control module	Special Function	Lock steering tune to vehicle
LANDROVER	Discovery Sport	As of 2017	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Steering angle sensor module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Steering angle sensor module	Special Function	Steering angle sensor module
LANDROVER	Discovery Sport	As of 2017	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Adaptive damping control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	InControl Touch audio head unit	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	InControl Touch audio head unit	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Head-up display cooling fan module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Head up display	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Head up display	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Head up display	Special Function	Head up display control module reset
LANDROVER	Discovery Sport	As of 2017	Head up display	Special Function	Activate test picture
LANDROVER	Discovery Sport	As of 2017	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Heating ventilation and air conditioning control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
LANDROVER	Discovery Sport	As of 2017	Heating ventilation and air conditioning control module	Special Function	Reset air conditioning compressor
LANDROVER	Discovery Sport	As of 2017	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
LANDROVER	Discovery Sport	As of 2017	Heating ventilation and air conditioning control module	Special Function	Climate seat unlock
LANDROVER	Discovery Sport	As of 2017	InControl Touch Pro infotainment master controller	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	InControl Touch Pro infotainment master controller	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Image processing module B	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Image processing module B	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Side object detection control module - Left	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Discovery Sport	As of 2017	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Side object detection control module - Right	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	InControl Touch Pro audio amplifier module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	InControl Touch Pro audio amplifier module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	InControl Touch Pro infotainment slave controller	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	InControl Touch Pro infotainment slave controller	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Driver's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Driver's door module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Driver's door module	Special Function	Door Window Calibration
LANDROVER	Discovery Sport	As of 2017	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Driver's (side) rear door module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Driver's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Driver's seat module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Driver's seat module	Special Function	Driver's Seat Calibration
LANDROVER	Discovery Sport	As of 2017	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Keyless vehicle module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Keyless vehicle module	Special Function	Verify Keys
LANDROVER	Discovery Sport	As of 2017	Passenger's door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Passenger's door module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Passenger's (side) rear door module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Passenger's seat module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Passenger's seat module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Rear gate / trunk module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Deployable towbar control module	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery Sport	As of 2017	Deployable towbar control module	Read Data Stream	
LANDROVER	Discovery Sport	As of 2017	Deployable towbar control module	special Function	Stow deployable towbar
LANDROVER	Discovery Sport	As of 2017	Deployable towbar control module	special Function	Deploy deployable towbar
LANDROVER	Discovery Sport	As of 2017	Deployable towbar control module	special Function	Unlock deployable towbar
LANDROVER	Discovery Sport	As of 2017	Deployable towbar control module	special Function	Deployable towbar recovery
LANDROVER	Range Rover	2002 - 2005	Anti-lock Braking System	Version Information	
LANDROVER	Range Rover	2002 - 2005	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Anti-lock Braking System	Actuation Test	
LANDROVER	Range Rover	2002 - 2005	Anti-lock Braking System	Sub System Tests	
LANDROVER	Range Rover	2002 - 2005	Anti-lock Braking System	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Anti-lock Braking System	Special Function	Brake Bleeding
LANDROVER	Range Rover	2002 - 2005	Anti-lock Braking System	Special Function	Steering Angle Calibration
LANDROVER	Range Rover	2002 - 2005	Anti-lock Braking System	Special Function	Steering Angle Sensor Renewal
LANDROVER	Range Rover	2002 - 2005	Anti-lock Braking System	Special Function	Brake Assist Sensitivity
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Version Information	
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Actuation Test	
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Special Function	Height Recalibration
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Special Function	Deflation : Front Left Bellow Valve
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Special Function	Deflation : Front Right Bellow Valve
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Special Function	Deflation : Rear Left Bellow Valve
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Special Function	Deflation : Rear Right Bellow Valve
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Special Function	Deflation : Exhaust Valve
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Special Function	Inflation
LANDROVER	Range Rover	2002 - 2005	Air Suspension	Special Function	Headlight Calibration
LANDROVER	Range Rover	2002 - 2005	Airbag	Version Information	
LANDROVER	Range Rover	2002 - 2005	Airbag	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Airbag	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Airbag	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Alarms/Security	Version Information	
LANDROVER	Range Rover	2002 - 2005	Alarms/Security	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Alarms/Security	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Alarms/Security	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Alarms/Security	Special Function	Immobilisation Learn (Synchronise Immobilisation)
LANDROVER	Range Rover	2002 - 2005	Alarms/Security	Special Function	Identify Key
LANDROVER	Range Rover	2002 - 2005	Alarms/Security	Special Function	Key Store
LANDROVER	Range Rover	2002 - 2005	Alarms/Security	Special Function	Key Programming
LANDROVER	Range Rover	2002 - 2005	Body Control	Version Information	
LANDROVER	Range Rover	2002 - 2005	Body Control	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Body Control	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Body Control	Actuation Test	

make	model	year	system	function	subfunction
LANDROVER	Range Rover	2002 - 2005	Body Control	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Body Control	Special Function	Identify Keys
LANDROVER	Range Rover	2002 - 2005	Body Control	Special Function	ECU Code
LANDROVER	Range Rover	2002 - 2005	Body Control	Special Function	Rain Sensor Reset
LANDROVER	Range Rover	2002 - 2005	Body Control	Special Function	Initialise Sunroof
LANDROVER	Range Rover	2002 - 2005	Body Control	Special Function	Information Memory
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Version Information	
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Actuation Test	
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Special Function	ECU Checks And Renewal
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Special Function	Immobilisation Learn
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Special Function	Reset Adaptons
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Special Function	Idle CO Adjust
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Special Function	Erase Driver Demand Fault
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Special Function	Secondary Air Test
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Special Function	Purge Valve Test
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Special Function	VCC Test 1
LANDROVER	Range Rover	2002 - 2005	Engine(ME7.2 EMS)	Special Function	Idle Speed Test
LANDROVER	Range Rover	2002 - 2005	Engine(TD6)	Version Information	
LANDROVER	Range Rover	2002 - 2005	Engine(TD6)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Engine(TD6)	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Engine(TD6)	Actuation Test	
LANDROVER	Range Rover	2002 - 2005	Engine(TD6)	Special Function	ECU Checks & Renewal
LANDROVER	Range Rover	2002 - 2005	Engine(TD6)	Special Function	Immobilisation Learn
LANDROVER	Range Rover	2002 - 2005	Engine(TD6)	Special Function	Idle Speed
LANDROVER	Range Rover	2002 - 2005	Engine(TD6)	Special Function	HFM Sensor
LANDROVER	Range Rover	2002 - 2005	Engine(TD6)	Special Function	Reset Adaptons
LANDROVER	Range Rover	2002 - 2005	Engine(TD6)	Special Function	Injector Grade Compensation
LANDROVER	Range Rover	2002 - 2005	Fuel Burning Heater	Version Information	
LANDROVER	Range Rover	2002 - 2005	Fuel Burning Heater	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Fuel Burning Heater	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Fuel Burning Heater	Actuation Test	
LANDROVER	Range Rover	2002 - 2005	Fuel Burning Heater	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Fuel Burning Heater	Special Function	Prime System
LANDROVER	Range Rover	2002 - 2005	Heater electron ventilation air conditioning	Version Information	
LANDROVER	Range Rover	2002 - 2005	Heater electron ventilation air conditioning	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Heater electron ventilation air conditioning	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Heater electron ventilation air conditioning	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Instrumentation	Version Information	
LANDROVER	Range Rover	2002 - 2005	Instrumentation	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Instrumentation	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Instrumentation	Actuation Test	
LANDROVER	Range Rover	2002 - 2005	Instrumentation	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Instrumentation	Special Function	Pack Language
LANDROVER	Range Rover	2002 - 2005	Instrumentation	Special Function	Service Reset
LANDROVER	Range Rover	2002 - 2005	Exterior Lighting	Version Information	
LANDROVER	Range Rover	2002 - 2005	Exterior Lighting	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Exterior Lighting	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Exterior Lighting	Actuation Test	
LANDROVER	Range Rover	2002 - 2005	Exterior Lighting	Sub System Tests	
LANDROVER	Range Rover	2002 - 2005	Exterior Lighting	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Memory Seats	Version Information	
LANDROVER	Range Rover	2002 - 2005	Memory Seats	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Memory Seats	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Memory Seats	Actuation Test	
LANDROVER	Range Rover	2002 - 2005	Information Systems	Version Information	
LANDROVER	Range Rover	2002 - 2005	Information Systems	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Information Systems	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Information Systems	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Parking Aid	Version Information	
LANDROVER	Range Rover	2002 - 2005	Parking Aid	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Parking Aid	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Parking Aid	Actuation Test	
LANDROVER	Range Rover	2002 - 2005	Parking Aid	Sub System Tests	
LANDROVER	Range Rover	2002 - 2005	Parking Aid	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Transfer Box	Version Information	
LANDROVER	Range Rover	2002 - 2005	Transfer Box	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Transfer Box	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Transfer Box	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Transfer Box	Special Function	Calibration
LANDROVER	Range Rover	2002 - 2005	Transmission	Version Information	
LANDROVER	Range Rover	2002 - 2005	Transmission	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover	2002 - 2005	Transmission	Read Data Stream	
LANDROVER	Range Rover	2002 - 2005	Transmission	Actuation Test	
LANDROVER	Range Rover	2002 - 2005	Transmission	Sub System Tests	
LANDROVER	Range Rover	2002 - 2005	Transmission	Special Function	ECU Renewal
LANDROVER	Range Rover	2002 - 2005	Transmission	Special Function	Reset Adaptons
LANDROVER	Range Rover(P38)	1995 - 2001	Anti-lock Braking System	Version Information	
LANDROVER	Range Rover(P38)	1995 - 2001	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(P38)	1995 - 2001	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover(P38)	1995 - 2001	Anti-lock Braking System	Actuation Test	

make	model	year	system	function	subfunction
LANDROVER	Range Rover(P38)	1995 - 2001	Anti-lock Braking System	Sub System Tests	
LANDROVER	Range Rover(P38)	1995 - 2001	Anti-lock Braking System	Special Function	ECU Replacement
LANDROVER	Range Rover(P38)	1995 - 2001	Anti-lock Braking System	Special Function	Brake Bleeding
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Read Data Stream	
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Actuation Test	
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Sub System Tests	
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Special Function	Transport Mode
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Special Function	High Lock Mode
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Special Function	Adjust Heights : Raise Fully
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Special Function	Adjust Heights : Lower Fully
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Special Function	Adjust Heights : Adjust To High Profile
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Special Function	Adjust Heights : Adjust To Standard
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Special Function	Adjust Heights : Adjust To Low Profile
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Special Function	Adjust Heights : Adjust To Access
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Special Function	Calibrate
LANDROVER	Range Rover(P38)	1995 - 2001	Air Suspension	Special Function	Deflate System
LANDROVER	Range Rover(P38)	1995 - 2001	Airbag	Version Information	
LANDROVER	Range Rover(P38)	1995 - 2001	Airbag	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(P38)	1995 - 2001	Body Control	Version Information	
LANDROVER	Range Rover(P38)	1995 - 2001	Body Control	Sub System Tests	
LANDROVER	Range Rover(P38)	1995 - 2001	Body Control	Special Function	Odomter Update
LANDROVER	Range Rover(P38)	1995 - 2001	Climate Control	Version Information	
LANDROVER	Range Rover(P38)	1995 - 2001	Climate Control	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(P38)	1995 - 2001	Climate Control	Read Data Stream	
LANDROVER	Range Rover(P38)	1995 - 2001	Climate Control	Actuation Test	
LANDROVER	Range Rover(P38)	1995 - 2001	Climate Control	Sub System Tests	
LANDROVER	Range Rover(P38)	1995 - 2001	Climate Control	Special Function	Perform Servo Tune
LANDROVER	Range Rover(P38)	1995 - 2001	Climate Control	Special Function	Replace ECU
LANDROVER	Range Rover(P38)	1995 - 2001	Cruise Control	Version Information	
LANDROVER	Range Rover(P38)	1995 - 2001	Cruise Control	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(P38)	1995 - 2001	Cruise Control	Read Data Stream	
LANDROVER	Range Rover(P38)	1995 - 2001	Cruise Control	Sub System Tests	
LANDROVER	Range Rover(P38)	1995 - 2001	Cruise Control	Special Function	Tune Information
LANDROVER	Range Rover(P38)	1995 - 2001	Cruise Control	Special Function	Last Shut Off
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(GEMS)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(GEMS)	Read Data Stream	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(GEMS)	Sub System Tests	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(EDC)	Version Information	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(EDC)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(EDC)	Read Data Stream	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(EDC)	Sub System Tests	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Version Information	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Read Data Stream	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Actuation Test	
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Special Function	Immobilisation Reprogram
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Special Function	LEV1 1.0mm Evap Leak Test
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Special Function	LEV2 0.5mm Leak Tracing
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Special Function	Reset Adaptions
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Special Function	Repair Validation
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Special Function	Open Loop Tune
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Special Function	Programming History
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Special Function	ECU Checks & Renewal
LANDROVER	Range Rover(P38)	1995 - 2001	Engine(M5 2.1 EMS)	Special Function	Non Start Diagnostics
LANDROVER	Range Rover(P38)	1995 - 2001	Transmission	Version Information	
LANDROVER	Range Rover(P38)	1995 - 2001	Transmission	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(P38)	1995 - 2001	Transmission	Read Data Stream	
LANDROVER	Range Rover(P38)	1995 - 2001	Transmission	Special Function	Reset Adaptions
LANDROVER	Range Rover(P38)	1995 - 2001	Transmission	Special Function	Read VIN
LANDROVER	Range Rover(P38)	1995 - 2001	Transmission	Special Function	Program VIN
LANDROVER	Range Rover(P38)	1995 - 2001	Transmission	Special Function	Read Tune Select
LANDROVER	Range Rover(P38)	1995 - 2001	Transmission	Special Function	Program Tune Select
LANDROVER	Range Rover(classic)	Up to 1995	Anti-lock Braking System	Version Information	
LANDROVER	Range Rover(classic)	Up to 1995	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(classic)	Up to 1995	Anti-lock Braking System	Read Data Stream	
LANDROVER	Range Rover(classic)	Up to 1995	Airbag	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(classic)	Up to 1995	Engine	Read Fault Code;Clear Fault Memory	
LANDROVER	Range Rover(classic)	Up to 1995	Engine	Read Data Stream	
LANDROVER	Freelander	1997 - 2001	Anti-lock Braking System	Version Information	
LANDROVER	Freelander	1997 - 2001	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	1997 - 2001	Anti-lock Braking System	Read Data Stream	
LANDROVER	Freelander	1997 - 2001	Anti-lock Braking System	Actuation Test	
LANDROVER	Freelander	1997 - 2001	Anti-lock Braking System	Sub System Tests	
LANDROVER	Freelander	1997 - 2001	Anti-lock Braking System	Special Function	Brake Bleeding
LANDROVER	Freelander	1997 - 2001	Anti-lock Braking System	Special Function	ECU Replacement
LANDROVER	Freelander	1997 - 2001	Airbag	Version Information	
LANDROVER	Freelander	1997 - 2001	Airbag	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	1997 - 2001	Body Control	Version Information	
LANDROVER	Freelander	1997 - 2001	Body Control	Read Data Stream	
LANDROVER	Freelander	1997 - 2001	Body Control	Actuation Test	
LANDROVER	Freelander	1997 - 2001	Body Control	Sub System Tests	
LANDROVER	Freelander	1997 - 2001	Engine(MEMS 1.9)	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	1997 - 2001	Engine(MEMS 1.9)	Sub System Tests	
LANDROVER	Freelander	1997 - 2001	Engine(MEMS 1.9)	Special Function	Immobilisation Reprogram
LANDROVER	Freelander	1997 - 2001	Engine(MEMS 1.9)	Special Function	Service Ignition Offset

make	model	year	system	function	subfunction
LANDROVER	Freelander	1997 - 2001	Engine(MEMS 1.9)	Special Function	Service Idle Speed Offset
LANDROVER	Freelander	1997 - 2001	Engine(MEMS 1.9)	Special Function	Reset Adaptons
LANDROVER	Freelander	1997 - 2001	Engine(EDC)	Version Information	
LANDROVER	Freelander	1997 - 2001	Engine(EDC)	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	1997 - 2001	Engine(EDC)	Read Data Stream	
LANDROVER	Freelander	1997 - 2001	Engine(EDC)	Sub System Tests	
LANDROVER	Freelander	1997 - 2001	Transmission	Version Information	
LANDROVER	Freelander	1997 - 2001	Transmission	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	1997 - 2001	Transmission	Read Data Stream	
LANDROVER	Freelander	1997 - 2001	Transmission	Actuation Test	
LANDROVER	Freelander	1997 - 2001	Transmission	Sub System Tests	
LANDROVER	Freelander	1997 - 2001	Transmission	Special Function	ECU Checks & Renewal
LANDROVER	Freelander	2001 - 2006	Anti-lock Braking System	Version Information	
LANDROVER	Freelander	2001 - 2006	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Anti-lock Braking System	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Anti-lock Braking System	Actuation Test	
LANDROVER	Freelander	2001 - 2006	Anti-lock Braking System	Sub System Tests	
LANDROVER	Freelander	2001 - 2006	Anti-lock Braking System	Special Function	ECU Renewal
LANDROVER	Freelander	2001 - 2006	Anti-lock Braking System	Special Function	Brake Bleeding
LANDROVER	Freelander	2001 - 2006	Anti-lock Braking System	Special Function	Calibrate 'G' Sensor
LANDROVER	Freelander	2001 - 2006	Anti-lock Braking System	Special Function	Vac Fill Valve Sequence
LANDROVER	Freelander	2001 - 2006	Airbag	Version Information	
LANDROVER	Freelander	2001 - 2006	Airbag	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Airbag	Special Function	Display ECU Data
LANDROVER	Freelander	2001 - 2006	Airbag	Special Function	Renew ECU
LANDROVER	Freelander	2001 - 2006	Alarms/Security	Version Information	
LANDROVER	Freelander	2001 - 2006	Alarms/Security	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Alarms/Security	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Alarms/Security	Special Function	ECU Renewal
LANDROVER	Freelander	2001 - 2006	Alarms/Security	Special Function	Synchronise Immobilisation
LANDROVER	Freelander	2001 - 2006	Alarms/Security	Special Function	Identify Key
LANDROVER	Freelander	2001 - 2006	Alarms/Security	Special Function	Key Store
LANDROVER	Freelander	2001 - 2006	Alarms/Security	Special Function	Key Programming
LANDROVER	Freelander	2001 - 2006	Body Control	Version Information	
LANDROVER	Freelander	2001 - 2006	Body Control	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Body Control	Actuation Test	
LANDROVER	Freelander	2001 - 2006	Body Control	Sub System Tests	
LANDROVER	Freelander	2001 - 2006	Body Control	Special Function	ECU Renewal
LANDROVER	Freelander	2001 - 2006	Body Control	Special Function	Plip Programming
LANDROVER	Freelander	2001 - 2006	Body Control	Special Function	Volumetric Settings
LANDROVER	Freelander	2001 - 2006	Cruise Control	Version Information	
LANDROVER	Freelander	2001 - 2006	Cruise Control	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Cruise Control	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Cruise Control	Sub System Tests	
LANDROVER	Freelander	2001 - 2006	Cruise Control	Special Function	Tune Information
LANDROVER	Freelander	2001 - 2006	Cruise Control	Special Function	Last Shut Off
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Version Information	
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Actuation Test	
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Sub System Tests	
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	ECU Renewal
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	Immobilisation Learn
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	Reset Closed Throttle Position
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	Adjust Throttle Stop Setting
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	Reset Fuelling Adaptons
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	Reset Flywheel Adaptons
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	Reset Idle Adaptons
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	Reset Adaptons for Engine
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	Set Service Ignition Offset
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	Set Service Fueling Offset
LANDROVER	Freelander	2001 - 2006	Engine(MEMS 3)	Special Function	Misfire Count
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Version Information	
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Actuation Test	
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Special Function	ECU Checks & Renewal
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Special Function	Immobilisation Learn
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Special Function	Idle Speed
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Special Function	Show AIF
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Special Function	HFM Sensor
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Special Function	Reset Adaptons
LANDROVER	Freelander	2001 - 2006	Engine(TD4)	Special Function	Injector Grade Compensation
LANDROVER	Freelander	2001 - 2006	Engine(EMS 2000)	Version Information	
LANDROVER	Freelander	2001 - 2006	Engine(EMS 2000)	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Engine(EMS 2000)	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Engine(EMS 2000)	Actuation Test	
LANDROVER	Freelander	2001 - 2006	Engine(EMS 2000)	Special Function	ECU Checks And Renewal
LANDROVER	Freelander	2001 - 2006	Engine(EMS 2000)	Special Function	Immobilisation Learn
LANDROVER	Freelander	2001 - 2006	Engine(EMS 2000)	Special Function	Reset Adaptons
LANDROVER	Freelander	2001 - 2006	Engine(EMS 2000)	Special Function	Idle CO Adjust
LANDROVER	Freelander	2001 - 2006	Engine(KV6 (NAS Only))	Version Information	
LANDROVER	Freelander	2001 - 2006	Engine(KV6 (NAS Only))	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Engine(KV6 (NAS Only))	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Engine(KV6 (NAS Only))	Actuation Test	
LANDROVER	Freelander	2001 - 2006	Engine(KV6 (NAS Only))	Special Function	Immobilisation Learn

make	model	year	system	function	subfunction
LANDROVER	Freelander	2001 - 2006	Engine(KV6 (NAS Only))	Special Function	Reset Adoptions
LANDROVER	Freelander	2001 - 2006	Engine(KV6 (NAS Only))	Special Function	Idle Speed Adjust
LANDROVER	Freelander	2001 - 2006	Engine(KV6 (NAS Only))	Special Function	Programming History
LANDROVER	Freelander	2001 - 2006	Fuel Burning Heater	Version Information	
LANDROVER	Freelander	2001 - 2006	Fuel Burning Heater	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Fuel Burning Heater	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Fuel Burning Heater	Actuation Test	
LANDROVER	Freelander	2001 - 2006	Fuel Burning Heater	Special Function	Set CO2 Level
LANDROVER	Freelander	2001 - 2006	Fuel Burning Heater	Special Function	Prime System
LANDROVER	Freelander	2001 - 2006	Instrumentation	Version Information	
LANDROVER	Freelander	2001 - 2006	Instrumentation	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Instrumentation	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Instrumentation	Actuation Test	
LANDROVER	Freelander	2001 - 2006	Instrumentation	Sub System Tests	
LANDROVER	Freelander	2001 - 2006	Instrumentation	Special Function	ECU Renewal
LANDROVER	Freelander	2001 - 2006	Instrumentation	Special Function	NAS AAT Information
LANDROVER	Freelander	2001 - 2006	Instrumentation	Special Function	NAS/Canada OAT Information
LANDROVER	Freelander	2001 - 2006	Transmission	Version Information	
LANDROVER	Freelander	2001 - 2006	Transmission	Read Fault Code;Clear Fault Memory	
LANDROVER	Freelander	2001 - 2006	Transmission	Read Data Stream	
LANDROVER	Freelander	2001 - 2006	Transmission	Actuation Test	
LANDROVER	Freelander	2001 - 2006	Transmission	Sub System Tests	
LANDROVER	Freelander	2001 - 2006	Transmission	Special Function	ECU Checks & Renewal
LANDROVER	Discovery	1996 - 1999	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1996 - 1999	Anti-lock Braking System	Sub System Tests	
LANDROVER	Discovery	1996 - 1999	Airbag	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1996 - 1999	Alarms/Security	Sub System Tests	
LANDROVER	Discovery	1996 - 1999	Alarms/Security	Special Function	Plip Programming
LANDROVER	Discovery	1996 - 1999	Engine(GEMS)	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1996 - 1999	Engine(GEMS)	Read Data Stream	
LANDROVER	Discovery	1996 - 1999	Engine(GEMS)	Sub System Tests	
LANDROVER	Discovery	1996 - 1999	Engine(MEMS 1.9)	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1996 - 1999	Engine(MEMS 1.9)	Sub System Tests	
LANDROVER	Discovery	1996 - 1999	Engine(MEMS 1.9)	Special Function	Immobilisation Reprogram
LANDROVER	Discovery	1996 - 1999	Engine(MEMS 1.9)	Special Function	Service Ignition Offset
LANDROVER	Discovery	1996 - 1999	Engine(MEMS 1.9)	Special Function	Service Idle Speed Offset
LANDROVER	Discovery	1996 - 1999	Engine(MEMS 1.9)	Special Function	Reset Adoptions
LANDROVER	Discovery	1996 - 1999	Engine(14CUX)	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1996 - 1999	Engine(14CUX)	Read Data Stream	
LANDROVER	Discovery	1996 - 1999	Engine(EDC)	Version Information	
LANDROVER	Discovery	1996 - 1999	Engine(EDC)	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1996 - 1999	Engine(EDC)	Read Data Stream	
LANDROVER	Discovery	1996 - 1999	Engine(EDC)	Sub System Tests	
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Version Information	
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Read Data Stream	
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Actuation Test	
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Sub System Tests	
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Special Function	Read ECU Configuration
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Special Function	Brake Bleeding
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Special Function	ECU Replacement
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Special Function	Differential Lock
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Special Function	Suspension Configuration
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Special Function	SLS Transportation
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Special Function	SLS Calibration
LANDROVER	Discovery	1999 - 2004	Anti-lock Braking System	Special Function	SLS Deflation
LANDROVER	Discovery	1999 - 2004	Active Cornering Enhancement	Version Information	
LANDROVER	Discovery	1999 - 2004	Active Cornering Enhancement	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1999 - 2004	Active Cornering Enhancement	Read Data Stream	
LANDROVER	Discovery	1999 - 2004	Active Cornering Enhancement	Actuation Test	
LANDROVER	Discovery	1999 - 2004	Active Cornering Enhancement	Sub System Tests	
LANDROVER	Discovery	1999 - 2004	Active Cornering Enhancement	Special Function	New ECU
LANDROVER	Discovery	1999 - 2004	Active Cornering Enhancement	Special Function	Calibrate ACE System
LANDROVER	Discovery	1999 - 2004	Active Cornering Enhancement	Special Function	Bleed System
LANDROVER	Discovery	1999 - 2004	Airbag	Version Information	
LANDROVER	Discovery	1999 - 2004	Airbag	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1999 - 2004	Airbag	Special Function	Program VIN
LANDROVER	Discovery	1999 - 2004	Body Control	Version Information	
LANDROVER	Discovery	1999 - 2004	Body Control	Read Data Stream	
LANDROVER	Discovery	1999 - 2004	Body Control	Actuation Test	
LANDROVER	Discovery	1999 - 2004	Body Control	Sub System Tests	
LANDROVER	Discovery	1999 - 2004	Body Control	Special Function	EKA Display
LANDROVER	Discovery	1999 - 2004	Body Control	Special Function	Plip Programming
LANDROVER	Discovery	1999 - 2004	Body Control	Special Function	Mobilisation Learn
LANDROVER	Discovery	1999 - 2004	Body Control	Special Function	Alarm Triggers
LANDROVER	Discovery	1999 - 2004	Cruise Control	Version Information	
LANDROVER	Discovery	1999 - 2004	Cruise Control	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1999 - 2004	Cruise Control	Read Data Stream	

make	model	year	system	function	subfunction
LANDROVER	Discovery	1999 - 2004	Cruise Control	Sub System Tests	
LANDROVER	Discovery	1999 - 2004	Cruise Control	Special Function	Tune Information
LANDROVER	Discovery	1999 - 2004	Cruise Control	Special Function	Last Shut Off
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Version Information	
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Read Data Stream	
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Actuation Test	
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Special Function	Immobilisation Reprogram
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Special Function	LEV1 1.0mm Evap Leak Test
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Special Function	LEV2 0.5mm Leak Tracing
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Special Function	Reset Adoptions
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Special Function	Repair Validation
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Special Function	Open Loop Tune
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Special Function	Programming History
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Special Function	ECU Checks & Renewal
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Special Function	Non Start Diagnostics
LANDROVER	Discovery	1999 - 2004	Engine(M5 2.1 EMS)	Special Function	NAS/EU3 OBDII Support
LANDROVER	Discovery	1999 - 2004	Engine(TD5)	Version Information	
LANDROVER	Discovery	1999 - 2004	Engine(TD5)	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1999 - 2004	Engine(TD5)	Read Data Stream	
LANDROVER	Discovery	1999 - 2004	Engine(TD5)	Actuation Test	
LANDROVER	Discovery	1999 - 2004	Engine(TD5)	Sub System Tests	
LANDROVER	Discovery	1999 - 2004	Engine(TD5)	Special Function	Security Status
LANDROVER	Discovery	1999 - 2004	Engine(TD5)	Special Function	Read/Set Injector Codes
LANDROVER	Discovery	1999 - 2004	Engine(TD5)	Special Function	Security Reprogram
LANDROVER	Discovery	1999 - 2004	Engine(TD5)	Special Function	ECM Checks & Renewal
LANDROVER	Discovery	1999 - 2004	Engine(TD5)	Special Function	Set 2/3 Track Pedal Pot
LANDROVER	Discovery	1999 - 2004	Fuel Burning Heater	Version Information	
LANDROVER	Discovery	1999 - 2004	Fuel Burning Heater	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1999 - 2004	Fuel Burning Heater	Read Data Stream	
LANDROVER	Discovery	1999 - 2004	Fuel Burning Heater	Actuation Test	
LANDROVER	Discovery	1999 - 2004	Fuel Burning Heater	Special Function	Set CO2 Level
LANDROVER	Discovery	1999 - 2004	Fuel Burning Heater	Special Function	Prime System
LANDROVER	Discovery	1999 - 2004	Transmission	Version Information	
LANDROVER	Discovery	1999 - 2004	Transmission	Read Fault Code;Clear Fault Memory	
LANDROVER	Discovery	1999 - 2004	Transmission	Read Data Stream	
LANDROVER	Discovery	1999 - 2004	Transmission	Special Function	Reset Adoptions
LANDROVER	Discovery	1999 - 2004	Transmission	Special Function	Read VIN
LANDROVER	Discovery	1999 - 2004	Transmission	Special Function	Program VIN
LANDROVER	Defender	Up to 2007	Anti-lock Braking System	Version Information	
LANDROVER	Defender	Up to 2007	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	Up to 2007	Anti-lock Braking System	Read Data Stream	
LANDROVER	Defender	Up to 2007	Anti-lock Braking System	Actuation Test	
LANDROVER	Defender	Up to 2007	Anti-lock Braking System	Sub System Tests	
LANDROVER	Defender	Up to 2007	Anti-lock Braking System	Special Function	Brake Bleeding
LANDROVER	Defender	Up to 2007	Anti-lock Braking System	Special Function	ECU Renewal
LANDROVER	Defender	Up to 2007	Alarms/Security	Sub System Tests	
LANDROVER	Defender	Up to 2007	Alarms/Security	Special Function	Plip Programming
LANDROVER	Defender	Up to 2007	Engine(GEMS)	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	Up to 2007	Engine(GEMS)	Read Data Stream	
LANDROVER	Defender	Up to 2007	Engine(GEMS)	Sub System Tests	
LANDROVER	Defender	Up to 2007	Engine(14CUX)	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	Up to 2007	Engine(14CUX)	Read Data Stream	
LANDROVER	Defender	Up to 2007	Engine(TD5)	Version Information	
LANDROVER	Defender	Up to 2007	Engine(TD5)	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	Up to 2007	Engine(TD5)	Read Data Stream	
LANDROVER	Defender	Up to 2007	Engine(TD5)	Actuation Test	
LANDROVER	Defender	Up to 2007	Engine(TD5)	Sub System Tests	
LANDROVER	Defender	Up to 2007	Engine(TD5)	Special Function	Security Status
LANDROVER	Defender	Up to 2007	Engine(TD5)	Special Function	Read/Set Injector Codes
LANDROVER	Defender	Up to 2007	Engine(TD5)	Special Function	Security Reprogram
LANDROVER	Defender	Up to 2007	Engine(TD5)	Special Function	ECM Checks & Renewal
LANDROVER	Defender	Up to 2007	Engine(TD5)	Special Function	Set 2/3 Track Pedal Pot
LANDROVER	Defender	Up to 2007	Engine(MS41)	Read Fault Code;Clear Fault Memory	
LANDROVER	Defender	Up to 2007	Engine(MS41)	Read Data Stream	
LANDROVER	Defender	Up to 2007	Engine(MS41)	Sub System Tests	
JAGUAR	X-TYPE	2001 - 2003	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Powertrain control module	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Powertrain control module	Special Function	Evaporative system leak check
JAGUAR	X-TYPE	2001 - 2003	Headlamp levelling system	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Headlamp levelling system	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Headlamp levelling system	Special Function	Front axle sensor and/or rear axle sensor
JAGUAR	X-TYPE	2001 - 2003	Headlamp levelling system	Special Function	Right headlamp and/or left headlamp
JAGUAR	X-TYPE	2001 - 2003	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Transmission control module	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Anti-lock Braking System	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Restraints control module	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Instrument cluster control module	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	X-TYPE	2001 - 2003	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Parking assist control module	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Audio unit	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Headlamp Control Module	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	General electronics control module	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Navigation control module	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Cellular telephone control module	Read Data Stream	
JAGUAR	X-TYPE	2001 - 2003	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2001 - 2003	Voice activation control module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Powertrain control module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Powertrain control module	Special Function	Evaporative system leak check
JAGUAR	X-TYPE	2004 - 2009	Headlamp levelling system	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Headlamp levelling system	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Headlamp levelling system	Special Function	Front axle sensor and/or rear axle sensor
JAGUAR	X-TYPE	2004 - 2009	Headlamp levelling system	Special Function	Right headlamp and/or left headlamp
JAGUAR	X-TYPE	2004 - 2009	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Transmission control module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Transmission control module	Special Function	Transmission control module adaptation clear
JAGUAR	X-TYPE	2004 - 2009	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Anti-lock Braking System	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Restraints control module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Instrument cluster control module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Tire pressure monitor module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	X-TYPE	2004 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	X-TYPE	2004 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	X-TYPE	2004 - 2009	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Parking assist control module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Audio unit	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Driver's seat module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Headlamp Control Module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	General electronics control module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Intrusion sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Intrusion sensor module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Audio amplifier module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Navigation control module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Cellular telephone control module	Read Data Stream	
JAGUAR	X-TYPE	2004 - 2009	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	X-TYPE	2004 - 2009	Voice activation control module	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Powertrain control module	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	S-TYPE	1999 - 2000	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Anti-lock Braking System	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Restraints control module	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Instrument cluster control module	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Adaptive damping control module	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Parking assist control module	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Audio unit	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Driver's door module	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Driver's seat module	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	General electronics control module	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Steering Lock Module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Cellular telephone control module	Read Data Stream	
JAGUAR	S-TYPE	1999 - 2000	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	1999 - 2000	Voice activation control module	Read Data Stream	
JAGUAR	S-TYPE	2001	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Powertrain control module	Read Data Stream	
JAGUAR	S-TYPE	2001	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Anti-lock Braking System	Read Data Stream	
JAGUAR	S-TYPE	2001	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Restraints control module	Read Data Stream	
JAGUAR	S-TYPE	2001	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Instrument cluster control module	Read Data Stream	
JAGUAR	S-TYPE	2001	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Adaptive damping control module	Read Data Stream	
JAGUAR	S-TYPE	2001	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	S-TYPE	2001	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Parking assist control module	Read Data Stream	
JAGUAR	S-TYPE	2001	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Audio unit	Read Data Stream	
JAGUAR	S-TYPE	2001	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Driver's door module	Read Data Stream	
JAGUAR	S-TYPE	2001	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Driver's seat module	Read Data Stream	
JAGUAR	S-TYPE	2001	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	General electronics control module	Read Data Stream	
JAGUAR	S-TYPE	2001	Steering Lock Module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Cellular telephone control module	Read Data Stream	
JAGUAR	S-TYPE	2001	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2001	Voice activation control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Powertrain control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Transmission control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Anti-lock Braking System	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	S-TYPE	2002 - 2003	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Restraints control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Instrument cluster control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Adaptive damping control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Parking brake control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	S-TYPE	2002 - 2003	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Parking assist control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Speed control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Audio unit	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Driver's door module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Driver's seat module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Headlamp Control Module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	General electronics control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Intrusion sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Intrusion sensor module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Steering Lock Module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Steering Lock Module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Audio amplifier module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Navigation control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Cellular telephone control module	Read Data Stream	
JAGUAR	S-TYPE	2002 - 2003	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2002 - 2003	Voice activation control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Powertrain control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Powertrain control module	Special Function	Particle filter regeneration
JAGUAR	S-TYPE	2004 - 2005	Powertrain control module	Special Function	Oil service counter reset
JAGUAR	S-TYPE	2004 - 2005	Powertrain control module	Special Function	Reset the diesel particulate filter stored values
JAGUAR	S-TYPE	2004 - 2005	Powertrain control module	Special Function	Evaporative system leak check
JAGUAR	S-TYPE	2004 - 2005	Headlamp levelling system	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Headlamp levelling system	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Headlamp levelling system	Special Function	Front axle sensor and/or rear axle sensor
JAGUAR	S-TYPE	2004 - 2005	Headlamp levelling system	Special Function	Right headlamp and/or left headlamp
JAGUAR	S-TYPE	2004 - 2005	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Transmission control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Anti-lock Braking System	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Anti-lock Braking System	Special Function	Brake sensor set-up
JAGUAR	S-TYPE	2004 - 2005	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Restraints control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Instrument cluster control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Instrument cluster control module	Special Function	Steering column calibration
JAGUAR	S-TYPE	2004 - 2005	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Adaptive damping control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Heating ventilation and air conditioning control module	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	S-TYPE	2004 - 2005	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Parking brake control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	S-TYPE	2004 - 2005	Parking brake control module	Special Function	Electric parking brake clutch calibration
JAGUAR	S-TYPE	2004 - 2005	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Parking assist control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Speed control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Audio unit	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Driver's door module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Driver's seat module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Headlamp Control Module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	General electronics control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Auxiliary heater control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Auxiliary heater control module	Special Function	Fuel burn heater - fuel prime application
JAGUAR	S-TYPE	2004 - 2005	Intrusion sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Intrusion sensor module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Steering Lock Module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Steering Lock Module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Audio amplifier module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Navigation control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Cellular telephone control module	Read Data Stream	
JAGUAR	S-TYPE	2004 - 2005	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2004 - 2005	Voice activation control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Special Function	Oil service counter level
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Special Function	Engine fuel priming routine
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Special Function	Idle speed control
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Special Function	OBDII readiness tests
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Special Function	Petrol engine control module adaption clear
JAGUAR	S-TYPE	2006 - 2008	Powertrain control module	Special Function	Purge valve self test
JAGUAR	S-TYPE	2006 - 2008	Headlamp levelling system	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Headlamp levelling system	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Headlamp levelling system	Special Function	Right headlamp and/or left headlamp
JAGUAR	S-TYPE	2006 - 2008	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Transmission control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Anti-lock Braking System	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Restraints control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Instrument cluster control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Instrument cluster control module	Special Function	Steering column calibration
JAGUAR	S-TYPE	2006 - 2008	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Adaptive damping control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Parking brake control module	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	S-TYPE	2006 - 2008	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	S-TYPE	2006 - 2008	Parking brake control module	Special Function	Electric parking brake clutch calibration
JAGUAR	S-TYPE	2006 - 2008	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Tire pressure monitor module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	S-TYPE	2006 - 2008	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	S-TYPE	2006 - 2008	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	S-TYPE	2006 - 2008	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Parking assist control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Speed control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Audio unit	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Driver's door module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Driver's seat module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Headlamp Control Module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	General electronics control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Auxiliary heater control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Auxiliary heater control module	Special Function	Fuel burn heater - fuel prime application
JAGUAR	S-TYPE	2006 - 2008	Auxiliary heater control module	Special Function	Fuel burn heater - operation check
JAGUAR	S-TYPE	2006 - 2008	Intrusion sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Intrusion sensor module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Steering Lock Module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Steering Lock Module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Audio amplifier module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Navigation control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Cellular telephone control module	Read Data Stream	
JAGUAR	S-TYPE	2006 - 2008	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	S-TYPE	2006 - 2008	Voice activation control module	Read Data Stream	
JAGUAR	XJ	1994	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1994	Powertrain control module	Read Data Stream	
JAGUAR	XJ	1994	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1994	Transmission control module	Read Data Stream	
JAGUAR	XJ	1994	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1994	Anti-lock Braking System	Read Data Stream	
JAGUAR	XJ	1994	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1994	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XJ	1994	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1994	Driver's seat module	Read Data Stream	
JAGUAR	XJ	1994	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1994	Security locking module	Read Data Stream	
JAGUAR	XJ	1995 - 1997	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1995 - 1997	Powertrain control module	Read Data Stream	
JAGUAR	XJ	1995 - 1997	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1995 - 1997	Transmission control module	Read Data Stream	
JAGUAR	XJ	1995 - 1997	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1995 - 1997	Anti-lock Braking System	Read Data Stream	
JAGUAR	XJ	1995 - 1997	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1995 - 1997	Instrument cluster control module	Read Data Stream	
JAGUAR	XJ	1995 - 1997	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1995 - 1997	Body control module	Read Data Stream	
JAGUAR	XJ	1995 - 1997	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1995 - 1997	Heating ventilation and air conditioning control module	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	XJ	1995 - 1997	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1995 - 1997	Driver's seat module	Read Data Stream	
JAGUAR	XJ	1995 - 1997	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1995 - 1997	Passenger's seat module	Read Data Stream	
JAGUAR	XJ	1995 - 1997	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1995 - 1997	Security locking module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Powertrain control module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Transmission control module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Anti-lock Braking System	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Restraints control module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Instrument cluster control module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Adaptive damping control module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Body control module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Driver's door module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Driver's seat module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Passenger's door module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Passenger's seat module	Read Data Stream	
JAGUAR	XJ	1998 - 2001	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	1998 - 2001	Security locking module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Powertrain control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Powertrain control module	Special Function	Evaporative system leak check
JAGUAR	XJ	2002 - 2005	Powertrain control module	Special Function	Reset the diesel particulate filter stored values
JAGUAR	XJ	2002 - 2005	Air suspension module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Air suspension module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Air suspension module	Special Function	Air suspension calibration
JAGUAR	XJ	2002 - 2005	Air suspension module	Special Function	Air suspension deflation
JAGUAR	XJ	2002 - 2005	Air suspension module	Special Function	Air suspension inflation
JAGUAR	XJ	2002 - 2005	Air suspension module	Special Function	Air suspension pre-geometry
JAGUAR	XJ	2002 - 2005	Air suspension module	Special Function	Air suspension transportation/customer mode
JAGUAR	XJ	2002 - 2005	Headlamp levelling system	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Headlamp levelling system	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Headlamp levelling system	Special Function	Right headlamp and/or left headlamp
JAGUAR	XJ	2002 - 2005	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Transmission control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Anti-lock Braking System	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Anti-lock Braking System	Special Function	Brake sensor set-up
JAGUAR	XJ	2002 - 2005	Anti-lock Braking System	Special Function	ABS control module configuration clear
JAGUAR	XJ	2002 - 2005	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Restraints control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Instrument cluster control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Adaptive damping control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Body control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Parking brake control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XJ	2002 - 2005	Parking assist control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XJ	2002 - 2005	Parking assist control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Speed control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Audio unit	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Driver's door module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Driver's seat module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Passenger's door module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Passenger's seat module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Rear seat control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Rear seat control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Headlamp Control Module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	General electronics control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Security locking module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Intrusion sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Intrusion sensor module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Steering Lock Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Steering Lock Module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Audio amplifier module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Navigation control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Cellular telephone control module	Read Data Stream	
JAGUAR	XJ	2002 - 2005	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2002 - 2005	Voice activation control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Powertrain control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Evaporative system leak check
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Reset the diesel particulate filter stored values
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	OBDII readiness tests
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Engine fuel priming routine
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Idle speed control
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Petrol engine control module adaption clear
JAGUAR	XJ	2006 - 2007	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XJ	2006 - 2007	Air suspension module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Air suspension module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Air suspension module	Special Function	Air suspension calibration
JAGUAR	XJ	2006 - 2007	Air suspension module	Special Function	Air suspension deflation
JAGUAR	XJ	2006 - 2007	Air suspension module	Special Function	Air suspension inflation
JAGUAR	XJ	2006 - 2007	Air suspension module	Special Function	Air suspension pre-geometry
JAGUAR	XJ	2006 - 2007	Air suspension module	Special Function	Air suspension transportation/customer mode
JAGUAR	XJ	2006 - 2007	Headlamp levelling system	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Headlamp levelling system	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Headlamp levelling system	Special Function	Right headlamp and/or left headlamp
JAGUAR	XJ	2006 - 2007	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Transmission control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Transmission control module	Special Function	Transmission control module adaption clear
JAGUAR	XJ	2006 - 2007	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Anti-lock Braking System	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Restraints control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Instrument cluster control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Instrument cluster control module	Special Function	Steering column calibration
JAGUAR	XJ	2006 - 2007	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Adaptive damping control module	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	XJ	2006 - 2007	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Body control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Parking brake control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XJ	2006 - 2007	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Tire pressure monitor module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	XJ	2006 - 2007	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XJ	2006 - 2007	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	XJ	2006 - 2007	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Parking assist control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Speed control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Audio unit	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Driver's door module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Driver's seat module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Passenger's door module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Passenger's seat module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Rear seat control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Rear seat control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Headlamp Control Module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	General electronics control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Auxiliary heater control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Auxiliary heater control module	Special Function	Fuel burn heater - operation check
JAGUAR	XJ	2006 - 2007	Auxiliary heater control module	Special Function	Fuel burning heater, fuel priming routine
JAGUAR	XJ	2006 - 2007	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Security locking module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Intrusion sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Intrusion sensor module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Steering Lock Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Steering Lock Module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Audio amplifier module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Navigation control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Cellular telephone control module	Read Data Stream	
JAGUAR	XJ	2006 - 2007	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2006 - 2007	Voice activation control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Powertrain control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Evaporative system leak check
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Reset the diesel particulate filter stored values
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Engine fuel priming routine

make	model	year	system	function	subfunction
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Idle speed control
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Petrol engine control module adaption clear
JAGUAR	XJ	2008 - 2009	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XJ	2008 - 2009	Air suspension module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Air suspension module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Air suspension module	Special Function	Air suspension calibration
JAGUAR	XJ	2008 - 2009	Air suspension module	Special Function	Air suspension deflation
JAGUAR	XJ	2008 - 2009	Air suspension module	Special Function	Air suspension inflation
JAGUAR	XJ	2008 - 2009	Air suspension module	Special Function	Air suspension pre-geometry
JAGUAR	XJ	2008 - 2009	Air suspension module	Special Function	Air suspension transportation/customer mode
JAGUAR	XJ	2008 - 2009	Headlamp levelling system	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Headlamp levelling system	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Headlamp levelling system	Special Function	Right headlamp and/or left headlamp
JAGUAR	XJ	2008 - 2009	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Transmission control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Transmission control module	Special Function	Transmission control module adaption clear
JAGUAR	XJ	2008 - 2009	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Anti-lock Braking System	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Restraints control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Instrument cluster control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Instrument cluster control module	Special Function	Steering column calibration
JAGUAR	XJ	2008 - 2009	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Adaptive damping control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Body control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Parking brake control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XJ	2008 - 2009	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Tire pressure monitor module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	XJ	2008 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XJ	2008 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	XJ	2008 - 2009	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Parking assist control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Speed control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Audio unit	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Driver's door module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Driver's seat module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Passenger's door module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Passenger's seat module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Rear seat control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Rear seat control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Driver's climate seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Driver's climate seat module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Headlamp Control Module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	General electronics control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Auxiliary heater control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Auxiliary heater control module	Special Function	Fuel burn heater - operation check

make	model	year	system	function	subfunction
JAGUAR	XJ	2008 - 2009	Auxiliary heater control module	Special Function	Fuel burning heater, fuel priming routine
JAGUAR	XJ	2008 - 2009	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Security locking module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Intrusion sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Intrusion sensor module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Steering Lock Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Steering Lock Module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Audio amplifier module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Navigation control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Cellular telephone control module	Read Data Stream	
JAGUAR	XJ	2008 - 2009	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2008 - 2009	Voice activation control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Powertrain control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Injector replacement
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Throttle valve actuator (Diesel)
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Exhaust gas recirculation valve
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Reset water in fuel detection
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Turbine shut-off valve
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Oxygen sensor
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Oxidation catalyst
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Rest of world - Service interval options
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Idle speed test
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	OBDII readiness tests
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Service history data
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Engine control modul VIN learn application
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Evaporative system diagnostic test
JAGUAR	XJ	2010 - 2012	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XJ	2010 - 2012	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Transmission control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Transmission control module	Special Function	Transmission control module adaption clear
JAGUAR	XJ	2010 - 2012	Transmission control module	Special Function	Paddle shift configuration
JAGUAR	XJ	2010 - 2012	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Anti-lock Braking System	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Anti-lock Braking System	Special Function	Brake bleed
JAGUAR	XJ	2010 - 2012	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Restraints control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Restraints control module	Special Function	Restraints build mode
JAGUAR	XJ	2010 - 2012	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Instrument cluster control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Instrument cluster control module	Special Function	Service interval reset
JAGUAR	XJ	2010 - 2012	Instrument cluster control module	Special Function	Vehicle reset
JAGUAR	XJ	2010 - 2012	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Adaptive damping control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Adaptive damping control module	Special Function	Calibration learn
JAGUAR	XJ	2010 - 2012	Adaptive damping control module	Special Function	Build mode
JAGUAR	XJ	2010 - 2012	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Body control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Body control module	Special Function	Tire pressure sensor replacement
JAGUAR	XJ	2010 - 2012	Body control module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XJ	2010 - 2012	Body control module	Special Function	Tyre pressure monitor ID value display
JAGUAR	XJ	2010 - 2012	Body control module	Special Function	Battery replacement
JAGUAR	XJ	2010 - 2012	Body control module	Special Function	Steering column calibration
JAGUAR	XJ	2010 - 2012	Body control module	Special Function	Sunroof calibration
JAGUAR	XJ	2010 - 2012	Body control module	Special Function	Transportation mode
JAGUAR	XJ	2010 - 2012	Body control module	Special Function	Valet mode reset

make	model	year	system	function	subfunction
JAGUAR	XJ	2010 - 2012	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
JAGUAR	XJ	2010 - 2012	Heating ventilation and air conditioning control module	Special Function	Evaporator and heater test
JAGUAR	XJ	2010 - 2012	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Parking brake control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XJ	2010 - 2012	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Tire pressure monitor module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	XJ	2010 - 2012	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XJ	2010 - 2012	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	XJ	2010 - 2012	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Parking assist control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Speed control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Speed control module	Special Function	Speed control alignment
JAGUAR	XJ	2010 - 2012	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Audio unit	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Gear shift module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Driver's door module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Driver's door module	Special Function	Driver's side - Door glass window calibration
JAGUAR	XJ	2010 - 2012	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Driver's seat module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	XJ	2010 - 2012	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Passenger's door module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
JAGUAR	XJ	2010 - 2012	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Passenger's seat module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Passenger's seat module	Special Function	Passenger's seat calibration
JAGUAR	XJ	2010 - 2012	Rear seat control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Rear seat control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Rear seat control module	Special Function	Rear seat calibration - Right
JAGUAR	XJ	2010 - 2012	Rear seat control module	Special Function	Rear seat calibration - Left
JAGUAR	XJ	2010 - 2012	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Rear gate/trunk module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Rear gate/trunk module	Special Function	Tailgate/trunk calibration
JAGUAR	XJ	2010 - 2012	Driver's climate seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Driver's climate seat module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Side object detection control module-Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Side object detection control module-Left	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Side object detection control module-Left	Special Function	Side object detection module history
JAGUAR	XJ	2010 - 2012	Side object detection control module-Right	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Side object detection control module-Right	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Side object detection control module-Right	Special Function	Side object detection module history
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module A - drivers side	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module A - drivers side	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module A - drivers side	Special Function	Dynamic safety belt retract and release - SPMA
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module A - drivers side	Special Function	Dynamic safety belt retract and release - SPMB
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module A - drivers side	Special Function	Clear module learn data - SPMA
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module A - drivers side	Special Function	Clear module learn data - SPMB

make	model	year	system	function	subfunction
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module B - passengers side	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module B - passengers side	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module B - passengers side	Special Function	Dynamic safety belt retract and release - SPMA
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module B - passengers side	Special Function	Dynamic safety belt retract and release - SPMB
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data - SPMA
JAGUAR	XJ	2010 - 2012	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data - SPMB
JAGUAR	XJ	2010 - 2012	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Headlamp Control Module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Headlamp Control Module	Special Function	Headlamp control module system calibration
JAGUAR	XJ	2010 - 2012	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	General electronics control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Rear differential control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Rear differential control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Rear differential control module	Special Function	Control module calibration
JAGUAR	XJ	2010 - 2012	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Auxiliary heater control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	XJ	2010 - 2012	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Keyless vehicle module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Keyless vehicle module	Special Function	Verify Keys
JAGUAR	XJ	2010 - 2012	Keyless vehicle module	Special Function	Check all antennas
JAGUAR	XJ	2010 - 2012	Keyless vehicle module	Special Function	Immobiliser Antenna Unit Functionality Check
JAGUAR	XJ	2010 - 2012	Keyless vehicle module	Special Function	Add additional keys
JAGUAR	XJ	2010 - 2012	Keyless vehicle module	Special Function	Replace faulty/lost keys
JAGUAR	XJ	2010 - 2012	Keyless vehicle module	Special Function	Recover programmed keys
JAGUAR	XJ	2010 - 2012	Keyless vehicle module	Special Function	Check passive keys enabled
JAGUAR	XJ	2010 - 2012	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Security locking module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Intrusion sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Intrusion sensor module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Steering Lock Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Steering Lock Module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Audio amplifier module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Audio amplifier module	Special Function	Calibrate dynamic volume control
JAGUAR	XJ	2010 - 2012	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Audio front control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Audio front control module	Special Function	DVD region counter reset
JAGUAR	XJ	2010 - 2012	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Navigation control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Satellite audio unit module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Cellular telephone control module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Television module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Television module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Digital audio broadcast module	Read Data Stream	
JAGUAR	XJ	2010 - 2012	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2010 - 2012	Voice activation control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Powertrain control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XJ	2013 - 2015	Powertrain control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Injector replacement
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Throttle valve actuator (Diesel)
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Exhaust gas recirculation valve
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Reset water in fuel detection
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Turbine shut-off valve
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Oxidation catalyst
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Rest of world - Service interval options
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Idle speed test
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Injector valve test
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Oxygen sensor
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Evaporative system diagnostic test
JAGUAR	XJ	2013 - 2015	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XJ	2013 - 2015	Front control/display interface module (high level display front)	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Front control/display interface module (high level display front)	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Front control/display interface module (high level display front)	Special Function	Navigation reset
JAGUAR	XJ	2013 - 2015	Front control/display interface module (high level display front)	Special Function	Calibrate Dynamic Volume Control
JAGUAR	XJ	2013 - 2015	Chassis control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Chassis control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Chassis control module	Special Function	Adaptive speed control - Speed control alignment
JAGUAR	XJ	2013 - 2015	Chassis control module	Special Function	Set Air Suspension Control Module Manufacturing/Freeze Mode
JAGUAR	XJ	2013 - 2015	Image processing control module A	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Image processing control module A	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Image processing control module A	Special Function	Service interval reset
JAGUAR	XJ	2013 - 2015	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Transmission control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Transmission control module	Special Function	Transmission control module adaption clear
JAGUAR	XJ	2013 - 2015	Transmission control module	Special Function	Calibrate clutch
JAGUAR	XJ	2013 - 2015	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Anti-lock Braking System	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Anti-lock Braking System	Special Function	Brake bleed
JAGUAR	XJ	2013 - 2015	Anti-lock Braking System	Special Function	Yaw rate sensor calibration
JAGUAR	XJ	2013 - 2015	Anti-lock Braking System	Special Function	Apply and release electric park brake
JAGUAR	XJ	2013 - 2015	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Restraints control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Restraints control module	Special Function	Restraints build mode
JAGUAR	XJ	2013 - 2015	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Instrument cluster control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Instrument cluster control module	Special Function	Service interval reset
JAGUAR	XJ	2013 - 2015	Instrument cluster control module	Special Function	Vehicle reset
JAGUAR	XJ	2013 - 2015	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Adaptive damping control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Adaptive damping control module	Special Function	Calibration learn
JAGUAR	XJ	2013 - 2015	Adaptive damping control module	Special Function	Build mode
JAGUAR	XJ	2013 - 2015	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Body control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Body control module	Special Function	Tire pressure sensor replacement
JAGUAR	XJ	2013 - 2015	Body control module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XJ	2013 - 2015	Body control module	Special Function	Tyre pressure monitor ID value display
JAGUAR	XJ	2013 - 2015	Body control module	Special Function	Steering column calibration
JAGUAR	XJ	2013 - 2015	Body control module	Special Function	Sunroof calibration
JAGUAR	XJ	2013 - 2015	Body control module	Special Function	Transportation mode
JAGUAR	XJ	2013 - 2015	Body control module	Special Function	Valet mode reset
JAGUAR	XJ	2013 - 2015	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Heating ventilation and air conditioning control module	Special Function	Evaporator and heater test

make	model	year	system	function	subfunction
JAGUAR	XJ	2013 - 2015	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
JAGUAR	XJ	2013 - 2015	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Parking brake control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XJ	2013 - 2015	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Tire pressure monitor module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	XJ	2013 - 2015	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XJ	2013 - 2015	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	XJ	2013 - 2015	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Parking assist control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Speed control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Speed control module	Special Function	Speed control alignment
JAGUAR	XJ	2013 - 2015	Audio unit	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Audio unit	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Gear shift module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Driver's door module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Driver's door module	Special Function	Driver's side - Door glass window calibration
JAGUAR	XJ	2013 - 2015	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Driver's seat module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	XJ	2013 - 2015	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Passenger's door module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
JAGUAR	XJ	2013 - 2015	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Passenger's seat module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Passenger's seat module	Special Function	Passenger's seat calibration
JAGUAR	XJ	2013 - 2015	Rear seat control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Rear seat control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Rear seat control module	Special Function	Rear seat calibration - Right
JAGUAR	XJ	2013 - 2015	Rear seat control module	Special Function	Rear seat calibration - Left
JAGUAR	XJ	2013 - 2015	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Rear gate/trunk module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Rear gate/trunk module	Special Function	Tailgate/trunk calibration
JAGUAR	XJ	2013 - 2015	Driver's climate seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Driver's climate seat module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Side object detection control module-Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Side object detection control module-Left	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Side object detection control module-Right	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Side object detection control module-Right	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module A - drivers side	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module A - drivers side	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module A - drivers side	Special Function	Dynamic safety belt retract and release - SPMA
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module A - drivers side	Special Function	Dynamic safety belt retract and release - SPMB
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module A - drivers side	Special Function	Clear module learn data - SPMA
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module A - drivers side	Special Function	Clear module learn data - SPMB
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module B - passengers side	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module B - passengers side	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module B - passengers side	Special Function	Dynamic safety belt retract and release - SPMA

make	model	year	system	function	subfunction
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module B - passengers side	Special Function	Dynamic safety belt retract and release - SPMB
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data - SPMA
JAGUAR	XJ	2013 - 2015	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data - SPMB
JAGUAR	XJ	2013 - 2015	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Headlamp Control Module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Headlamp Control Module	Special Function	Headlamp control module system calibration
JAGUAR	XJ	2013 - 2015	General electronics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	General electronics control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Rear differential control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Rear differential control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Rear differential control module	Special Function	Control module calibration
JAGUAR	XJ	2013 - 2015	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Gateway module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Gateway module	Special Function	Battery replacement
JAGUAR	XJ	2013 - 2015	Gateway module	Special Function	Test dual battery system
JAGUAR	XJ	2013 - 2015	Gateway module	Special Function	Verify secondary battery charging
JAGUAR	XJ	2013 - 2015	Gateway module	Special Function	Quiescent current control module internal check
JAGUAR	XJ	2013 - 2015	Auxiliary heater control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Auxiliary heater control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	XJ	2013 - 2015	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Keyless vehicle module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Keyless vehicle module	Special Function	Verify Keys
JAGUAR	XJ	2013 - 2015	Keyless vehicle module	Special Function	Check all antennas
JAGUAR	XJ	2013 - 2015	Keyless vehicle module	Special Function	Immobiliser Antenna Unit Functionality Check
JAGUAR	XJ	2013 - 2015	Keyless vehicle module	Special Function	Add additional keys
JAGUAR	XJ	2013 - 2015	Keyless vehicle module	Special Function	Replace faulty/lost keys
JAGUAR	XJ	2013 - 2015	Keyless vehicle module	Special Function	Recover programmed keys
JAGUAR	XJ	2013 - 2015	Keyless vehicle module	Special Function	Check passive keys enabled
JAGUAR	XJ	2013 - 2015	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Security locking module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Intrusion sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Intrusion sensor module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Steering Lock Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Steering Lock Module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Audio amplifier module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Audio front control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Audio front control module	Special Function	Navigation reset
JAGUAR	XJ	2013 - 2015	Audio front control module	Special Function	DVD region counter reset
JAGUAR	XJ	2013 - 2015	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Navigation control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Satellite audio unit module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Cellular telephone control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Television module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Television module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Digital audio broadcast module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Voice activation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	2013 - 2015	Voice activation control module	Read Data Stream	
JAGUAR	XJ	2013 - 2015	Transfer case control module	Special Function	Oil change reset
JAGUAR	XJ	As of 2016	ABS control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	ABS control module	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	XJ	As of 2016	ABS control module	Special Function	Apply and release electric park brake
JAGUAR	XJ	As of 2016	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Body control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Body control module	Special Function	Steering column calibration
JAGUAR	XJ	As of 2016	Body control module	Special Function	Valet mode reset
JAGUAR	XJ	As of 2016	Body control module	Special Function	Transportation mode
JAGUAR	XJ	As of 2016	Body control module	Special Function	Fuel pump supply - Enable(disable)
JAGUAR	XJ	As of 2016	Body control module	Special Function	Ignition cycle counter reset
JAGUAR	XJ	As of 2016	Body control module	Special Function	Sunroof calibration
JAGUAR	XJ	As of 2016	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Speed control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Gear shift module	Read Data Stream	
JAGUAR	XJ	As of 2016	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Gateway module	Read Data Stream	
JAGUAR	XJ	As of 2016	Gateway module	Special Function	Battery replacement
JAGUAR	XJ	As of 2016	Gateway module	Special Function	Quiescent current control module internal check
JAGUAR	XJ	As of 2016	Headlamp control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Headlamp control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XJ	As of 2016	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Parking brake control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Parking brake control module	Special Function	Longitudinal accelerometer calibration
JAGUAR	XJ	As of 2016	Parking brake control module	Special Function	Brake caliper replacement assembly test
JAGUAR	XJ	As of 2016	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
JAGUAR	XJ	As of 2016	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
JAGUAR	XJ	As of 2016	Parking brake control module	Special Function	Parking brake activation
JAGUAR	XJ	As of 2016	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Powertrain control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Reset water in fuel detection
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Idle speed test
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Service interval reset
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Fuel Prime Routine
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Throttle Valve Actuator
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Injector replacement
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Oxygen sensor
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Oxidation catalyst
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Engine control module low pressure LOR adaption
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Engine control module reset fuel pump adaption
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Enable\disable glow plugs
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Engine control module reset crank case pressure sensor
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Evaporative system diagnostic test
JAGUAR	XJ	As of 2016	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XJ	As of 2016	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Anti-lock Braking System	Read Data Stream	
JAGUAR	XJ	As of 2016	Anti-lock Braking System	Special Function	Yaw rate sensor calibration
JAGUAR	XJ	As of 2016	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Restraints control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Rear differential control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Rear differential control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Transfer case control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Transfer case control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Transfer case control module	Special Function	Oil change reset
JAGUAR	XJ	As of 2016	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Transmission control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Transmission control module	Special Function	Calibrate clutch
JAGUAR	XJ	As of 2016	Transmission control module	Special Function	Telematics server communication check

make	model	year	system	function	subfunction
JAGUAR	XJ	As of 2016	Telematic control unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Telematic control unit module	Read Data Stream	
JAGUAR	XJ	As of 2016	Telematic control unit module	Special Function	Activate telematics control module
JAGUAR	XJ	As of 2016	Telematic control unit module	Special Function	Network registration status
JAGUAR	XJ	As of 2016	Telematic control unit module	Special Function	Pre-activate telematics control module
JAGUAR	XJ	As of 2016	Telematic control unit module	Special Function	Telematics sim card type
JAGUAR	XJ	As of 2016	Telematic control unit module	Special Function	Operational mode
JAGUAR	XJ	As of 2016	Telematic control unit module	Special Function	Test internal backup battery
JAGUAR	XJ	As of 2016	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
JAGUAR	XJ	As of 2016	Telematic control unit module	Special Function	Telematics control module battery replacement reset
JAGUAR	XJ	As of 2016	Telematic control unit module	Special Function	Brazilian telematics identification transfer
JAGUAR	XJ	As of 2016	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Tire pressure monitor module	Read Data Stream	
JAGUAR	XJ	As of 2016	Tire pressure monitor module	Special Function	Tire Pressure Sensor Replacement
JAGUAR	XJ	As of 2016	Tire pressure monitor module	Special Function	Tire Pressure Monitor Sensor Identification Display
JAGUAR	XJ	As of 2016	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XJ	As of 2016	InControl Touch Pro infotainment master controller	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	InControl Touch Pro infotainment master controller	Read Data Stream	
JAGUAR	XJ	As of 2016	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Integrated control panel	Read Data Stream	
JAGUAR	XJ	As of 2016	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
JAGUAR	XJ	As of 2016	Heating ventilation and air conditioning control module	Special Function	Seat climate control module calibration
JAGUAR	XJ	As of 2016	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Instrument cluster control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Image processing module B	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Image processing module B	Read Data Stream	
JAGUAR	XJ	As of 2016	Rear Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Rear Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Side object detection control module - Left	Read Data Stream	
JAGUAR	XJ	As of 2016	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Side object detection control module - Right	Read Data Stream	
JAGUAR	XJ	As of 2016	Chassis control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Chassis control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Chassis control module	Special Function	Adaptive speed control - Speed control alignment
JAGUAR	XJ	As of 2016	Chassis control module	Special Function	Set Air Suspension Geometry
JAGUAR	XJ	As of 2016	Chassis control module	Special Function	Set Air Suspension Tight Tolerance Mode (Headlamp Setting)
JAGUAR	XJ	As of 2016	Chassis control module	Special Function	Set Air Suspension Control Module Manufacturing/Freeze Mode
JAGUAR	XJ	As of 2016	Image processing control module A	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Image processing control module A	Read Data Stream	
JAGUAR	XJ	As of 2016	Image processing control module A	Special Function	Automatic high beam camera calibration
JAGUAR	XJ	As of 2016	Parking assist control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XJ	As of 2016	Parking assist control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Power steering control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Power steering control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Power steering control module	Special Function	Lock steering tune to vehicle
JAGUAR	XJ	As of 2016	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Steering angle sensor module	Read Data Stream	
JAGUAR	XJ	As of 2016	Steering angle sensor module	Special Function	Steering angle sensor module
JAGUAR	XJ	As of 2016	Vehicle dynamics control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Vehicle dynamics control module	Read Data Stream	
JAGUAR	XJ	As of 2016	Vehicle dynamics control module	Special Function	Yaw rate sensor calibration
JAGUAR	XJ	As of 2016	InControl Touch Pro audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	InControl Touch Pro audio amplifier module	Read Data Stream	
JAGUAR	XJ	As of 2016	InControl Touch Pro infotainment slave controller	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	InControl Touch Pro infotainment slave controller	Read Data Stream	
JAGUAR	XJ	As of 2016	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Driver's door module	Read Data Stream	
JAGUAR	XJ	As of 2016	Driver's door module	Special Function	Door Glass Window Calibration
JAGUAR	XJ	As of 2016	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Driver's seat module	Read Data Stream	
JAGUAR	XJ	As of 2016	Driver's seat module	Special Function	Rear right seat massage on demand self test
JAGUAR	XJ	As of 2016	Driver's seat module	Special Function	Driver's seat massage on demand self test
JAGUAR	XJ	As of 2016	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Keyless vehicle module	Read Data Stream	
JAGUAR	XJ	As of 2016	Keyless vehicle module	Special Function	Verify Keys
JAGUAR	XJ	As of 2016	Keyless vehicle module	Special Function	Recover programmed keys
JAGUAR	XJ	As of 2016	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Passenger's door module	Read Data Stream	
JAGUAR	XJ	As of 2016	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
JAGUAR	XJ	As of 2016	Passenger's door module	Special Function	Passenger side - Rear door blind initialisation
JAGUAR	XJ	As of 2016	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Passenger's seat module	Read Data Stream	
JAGUAR	XJ	As of 2016	Passenger's seat module	Special Function	Passenger's seat massage on demand self test
JAGUAR	XJ	As of 2016	Passenger's seat module	Special Function	Rear left seat massage on demand self test
JAGUAR	XJ	As of 2016	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Rear gate / trunk module	Read Data Stream	
JAGUAR	XJ	As of 2016	Rear seat - Control module - Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Rear seat - Control module - Left	Read Data Stream	
JAGUAR	XJ	As of 2016	Rear seat - Control module - Right	Read Fault Code;Clear Fault Memory	
JAGUAR	XJ	As of 2016	Rear seat - Control module - Right	Read Data Stream	
JAGUAR	XF	2008 - 2009	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Powertrain control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Diesel particulate filter fuel related component replacement
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	High pressure injection pump replacement
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Idle speed test
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Air conditioning system adaption reset
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Diesel particulate filter condition (stored values)
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Key programming
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Erase all existing keys
JAGUAR	XF	2008 - 2009	Powertrain control module	Special Function	Verify Keys
JAGUAR	XF	2008 - 2009	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Transmission control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Transmission control module	Special Function	Transmission control module adaption clear
JAGUAR	XF	2008 - 2009	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Anti-lock Braking System	Read Data Stream	
JAGUAR	XF	2008 - 2009	Anti-lock Braking System	Special Function	Brake bleed
JAGUAR	XF	2008 - 2009	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Restraints control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Restraints control module	Special Function	Restraints build mode
JAGUAR	XF	2008 - 2009	Restraints control module	Special Function	Passenger restraint disable switch
JAGUAR	XF	2008 - 2009	Instrument cluster control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XF	2008 - 2009	Instrument cluster control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Instrument cluster control module	Special Function	Steering column calibration
JAGUAR	XF	2008 - 2009	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Adaptive damping control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Adaptive damping control module	Special Function	Calibration learn
JAGUAR	XF	2008 - 2009	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Body control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Auxiliary junction box (body control module B)	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Auxiliary junction box (body control module B)	Read Data Stream	
JAGUAR	XF	2008 - 2009	Auxiliary junction box (body control module B)	Special Function	Battery replacement
JAGUAR	XF	2008 - 2009	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
JAGUAR	XF	2008 - 2009	Heating ventilation and air conditioning control module	Special Function	Vent actuators test
JAGUAR	XF	2008 - 2009	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Parking brake control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XF	2008 - 2009	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Tire pressure monitor module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	XF	2008 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XF	2008 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	XF	2008 - 2009	Tire pressure monitor module	Special Function	Tyre pressure monitor ID value display
JAGUAR	XF	2008 - 2009	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Parking assist control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Speed control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Speed control module	Special Function	Speed control alignment
JAGUAR	XF	2008 - 2009	Speed control module	Special Function	Speed control internal state
JAGUAR	XF	2008 - 2009	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Gear shift module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Driver's door module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Driver's door module	Special Function	Driver's side - Door glass window calibration
JAGUAR	XF	2008 - 2009	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Driver's seat module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	XF	2008 - 2009	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Passenger's door module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
JAGUAR	XF	2008 - 2009	Driver's climate seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Driver's climate seat module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Side object detection control module-Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Side object detection control module-Left	Read Data Stream	
JAGUAR	XF	2008 - 2009	Side object detection control module-Left	Special Function	Side object detection configuration - Right
JAGUAR	XF	2008 - 2009	Side object detection control module-Left	Special Function	Side object detection configuration - Left
JAGUAR	XF	2008 - 2009	Side object detection control module-Right	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Side object detection control module-Right	Read Data Stream	
JAGUAR	XF	2008 - 2009	Side object detection control module-Right	Special Function	Side object detection configuration - Right
JAGUAR	XF	2008 - 2009	Side object detection control module-Right	Special Function	Side object detection configuration - Left
JAGUAR	XF	2008 - 2009	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Headlamp Control Module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Headlamp Control Module	Special Function	Headlamp control module system calibration
JAGUAR	XF	2008 - 2009	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Gateway module	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	XF	2008 - 2009	Impact classification system	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Impact classification system	Read Data Stream	
JAGUAR	XF	2008 - 2009	Impact classification system	Special Function	Pedestrian impact crash status reset
JAGUAR	XF	2008 - 2009	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	XF	2008 - 2009	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Keyless vehicle module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Audio amplifier module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Audio front control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Navigation control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Satellite audio unit module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Cellular telephone control module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Television module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Television module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Accessory protocol interface module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Accessory protocol interface module	Read Data Stream	
JAGUAR	XF	2008 - 2009	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2008 - 2009	Digital audio broadcast module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Powertrain control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Reset oil level
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Check the engine oil level
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Injector replacement
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Throttle valve actuator (Diesel)
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Exhaust gas recirculation valve
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Reset water in fuel detection
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Turbine shut-off valve
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Oxygen sensor
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Oxidation catalyst
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Idle speed test
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	OBDII readiness tests
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Service history data
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Engine control module VIN learn application
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Check engine oil level
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Service interval options
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XF	2010 - 2011	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XF	2010 - 2011	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Transmission control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Transmission control module	Special Function	Transmission control module adaption clear
JAGUAR	XF	2010 - 2011	Transmission control module	Special Function	Paddle shift configuration
JAGUAR	XF	2010 - 2011	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Anti-lock Braking System	Read Data Stream	
JAGUAR	XF	2010 - 2011	Anti-lock Braking System	Special Function	Brake bleed
JAGUAR	XF	2010 - 2011	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Restraints control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Restraints control module	Special Function	Restraints build mode
JAGUAR	XF	2010 - 2011	Restraints control module	Special Function	Passenger restraint disable switch
JAGUAR	XF	2010 - 2011	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Instrument cluster control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Instrument cluster control module	Special Function	Steering column calibration
JAGUAR	XF	2010 - 2011	Instrument cluster control module	Special Function	Tire size (rolling circumference)
JAGUAR	XF	2010 - 2011	Instrument cluster control module	Special Function	Key programming
JAGUAR	XF	2010 - 2011	Instrument cluster control module	Special Function	Erase all existing keys

make	model	year	system	function	subfunction
JAGUAR	XF	2010 - 2011	Instrument cluster control module	Special Function	Verify Keys
JAGUAR	XF	2010 - 2011	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Adaptive damping control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Adaptive damping control module	Special Function	Calibration learn
JAGUAR	XF	2010 - 2011	Adaptive damping control module	Special Function	Build mode
JAGUAR	XF	2010 - 2011	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Body control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Body control module	Special Function	Alarm trigger history
JAGUAR	XF	2010 - 2011	Auxiliary junction box (body control module B)	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Auxiliary junction box (body control module B)	Read Data Stream	
JAGUAR	XF	2010 - 2011	Auxiliary junction box (body control module B)	Special Function	Battery replacement
JAGUAR	XF	2010 - 2011	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
JAGUAR	XF	2010 - 2011	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Parking brake control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XF	2010 - 2011	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Tire pressure monitor module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	XF	2010 - 2011	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XF	2010 - 2011	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	XF	2010 - 2011	Tire pressure monitor module	Special Function	Tyre pressure monitor ID value display
JAGUAR	XF	2010 - 2011	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Parking assist control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Speed control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Speed control module	Special Function	Speed control alignment
JAGUAR	XF	2010 - 2011	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Gear shift module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Driver's door module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Driver's door module	Special Function	Driver's side - Door glass window calibration
JAGUAR	XF	2010 - 2011	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Driver's seat module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Passenger's door module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
JAGUAR	XF	2010 - 2011	Driver's climate seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Driver's climate seat module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Side object detection control module-Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Side object detection control module-Left	Read Data Stream	
JAGUAR	XF	2010 - 2011	Side object detection control module-Left	Special Function	Side object detection configuration - Right
JAGUAR	XF	2010 - 2011	Side object detection control module-Left	Special Function	Side object detection configuration - Left
JAGUAR	XF	2010 - 2011	Side object detection control module-Left	Special Function	Side object detection module history
JAGUAR	XF	2010 - 2011	Side object detection control module-Right	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Side object detection control module-Right	Read Data Stream	
JAGUAR	XF	2010 - 2011	Side object detection control module-Right	Special Function	Side object detection configuration - Right
JAGUAR	XF	2010 - 2011	Side object detection control module-Right	Special Function	Side object detection configuration - Left
JAGUAR	XF	2010 - 2011	Side object detection control module-Right	Special Function	Side object detection module history
JAGUAR	XF	2010 - 2011	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Headlamp Control Module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Headlamp Control Module	Special Function	Headlamp control module system calibration

make	model	year	system	function	subfunction
JAGUAR	XF	2010 - 2011	Rear differential control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Rear differential control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Rear differential control module	Special Function	Control module calibration
JAGUAR	XF	2010 - 2011	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Gateway module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Impact classification system	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Impact classification system	Read Data Stream	
JAGUAR	XF	2010 - 2011	Impact classification system	Special Function	Pedestrian impact crash status reset
JAGUAR	XF	2010 - 2011	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	XF	2010 - 2011	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Keyless vehicle module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Integrated control panel	Read Data Stream	
JAGUAR	XF	2010 - 2011	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Audio amplifier module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Audio front control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Navigation control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Satellite audio unit module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Cellular telephone control module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Television module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Television module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Accessory protocol interface module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Accessory protocol interface module	Read Data Stream	
JAGUAR	XF	2010 - 2011	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2010 - 2011	Digital audio broadcast module	Read Data Stream	
JAGUAR	XF	2012	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Powertrain control module	Read Data Stream	
JAGUAR	XF	2012	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XF	2012	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XF	2012	Powertrain control module	Special Function	Reset oil level
JAGUAR	XF	2012	Powertrain control module	Special Function	Check the engine oil level
JAGUAR	XF	2012	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XF	2012	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XF	2012	Powertrain control module	Special Function	Injector replacement
JAGUAR	XF	2012	Powertrain control module	Special Function	Throttle valve actuator (Diesel)
JAGUAR	XF	2012	Powertrain control module	Special Function	Exhaust gas recirculation valve
JAGUAR	XF	2012	Powertrain control module	Special Function	Reset water in fuel detection
JAGUAR	XF	2012	Powertrain control module	Special Function	Turbine shut-off valve
JAGUAR	XF	2012	Powertrain control module	Special Function	Oxygen sensor
JAGUAR	XF	2012	Powertrain control module	Special Function	Oxidation catalyst
JAGUAR	XF	2012	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XF	2012	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
JAGUAR	XF	2012	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
JAGUAR	XF	2012	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	XF	2012	Powertrain control module	Special Function	Display injector correction factors
JAGUAR	XF	2012	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XF	2012	Powertrain control module	Special Function	Rest of world - Service interval options
JAGUAR	XF	2012	Powertrain control module	Special Function	Idle speed adjustment
JAGUAR	XF	2012	Powertrain control module	Special Function	Idle speed test
JAGUAR	XF	2012	Powertrain control module	Special Function	Service history data
JAGUAR	XF	2012	Powertrain control module	Special Function	Key programming
JAGUAR	XF	2012	Powertrain control module	Special Function	Erase all existing keys
JAGUAR	XF	2012	Powertrain control module	Special Function	Verify Keys
JAGUAR	XF	2012	Powertrain control module	Special Function	Check engine oil level
JAGUAR	XF	2012	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XF	2012	Powertrain control module	Special Function	Evaporative system diagnostic test
JAGUAR	XF	2012	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XF	2012	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Transmission control module	Read Data Stream	
JAGUAR	XF	2012	Transmission control module	Special Function	Transmission control module adaption clear
JAGUAR	XF	2012	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Anti-lock Braking System	Read Data Stream	
JAGUAR	XF	2012	Anti-lock Braking System	Special Function	Brake bleed

make	model	year	system	function	subfunction
JAGUAR	XF	2012	Anti-lock Braking System	Special Function	Yaw rate sensor calibration
JAGUAR	XF	2012	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Restraints control module	Read Data Stream	
JAGUAR	XF	2012	Restraints control module	Special Function	Restraints build mode
JAGUAR	XF	2012	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Instrument cluster control module	Read Data Stream	
JAGUAR	XF	2012	Instrument cluster control module	Special Function	Steering column calibration
JAGUAR	XF	2012	Instrument cluster control module	Special Function	Tire size (rolling circumference)
JAGUAR	XF	2012	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Adaptive damping control module	Read Data Stream	
JAGUAR	XF	2012	Adaptive damping control module	Special Function	Calibration learn
JAGUAR	XF	2012	Adaptive damping control module	Special Function	Build mode
JAGUAR	XF	2012	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Body control module	Read Data Stream	
JAGUAR	XF	2012	Auxiliary junction box (body control module B)	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Auxiliary junction box (body control module B)	Read Data Stream	
JAGUAR	XF	2012	Auxiliary junction box (body control module B)	Special Function	Battery replacement
JAGUAR	XF	2012	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XF	2012	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
JAGUAR	XF	2012	Heating ventilation and air conditioning control module	Special Function	Vent actuators test
JAGUAR	XF	2012	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Parking brake control module	Read Data Stream	
JAGUAR	XF	2012	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XF	2012	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Tire pressure monitor module	Read Data Stream	
JAGUAR	XF	2012	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	XF	2012	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XF	2012	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	XF	2012	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Parking assist control module	Read Data Stream	
JAGUAR	XF	2012	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Speed control module	Read Data Stream	
JAGUAR	XF	2012	Speed control module	Special Function	Speed control alignment
JAGUAR	XF	2012	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Gear shift module	Read Data Stream	
JAGUAR	XF	2012	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Driver's door module	Read Data Stream	
JAGUAR	XF	2012	Driver's door module	Special Function	Driver's side - Door glass window calibration
JAGUAR	XF	2012	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Driver's seat module	Read Data Stream	
JAGUAR	XF	2012	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	XF	2012	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Passenger's door module	Read Data Stream	
JAGUAR	XF	2012	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
JAGUAR	XF	2012	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Passenger's seat module	Read Data Stream	
JAGUAR	XF	2012	Passenger's seat module	Special Function	Passenger's seat calibration
JAGUAR	XF	2012	Driver's climate seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Driver's climate seat module	Read Data Stream	
JAGUAR	XF	2012	Side object detection control module-Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Side object detection control module-Left	Read Data Stream	
JAGUAR	XF	2012	Side object detection control module-Left	Special Function	Side object detection configuration - Right
JAGUAR	XF	2012	Side object detection control module-Left	Special Function	Side object detection configuration - Left
JAGUAR	XF	2012	Side object detection control module-Right	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XF	2012	Side object detection control module-Right	Read Data Stream	
JAGUAR	XF	2012	Side object detection control module-Right	Special Function	Side object detection configuration - Right
JAGUAR	XF	2012	Side object detection control module-Right	Special Function	Side object detection configuration - Left
JAGUAR	XF	2012	Safety belt pretensioner control module A - drivers side	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Safety belt pretensioner control module A - drivers side	Read Data Stream	
JAGUAR	XF	2012	Safety belt pretensioner control module A - drivers side	Special Function	Dynamic safety belt retract and release - SPMA
JAGUAR	XF	2012	Safety belt pretensioner control module A - drivers side	Special Function	Dynamic safety belt retract and release - SPMB
JAGUAR	XF	2012	Safety belt pretensioner control module A - drivers side	Special Function	Clear module learn data - SPMA
JAGUAR	XF	2012	Safety belt pretensioner control module A - drivers side	Special Function	Clear module learn data - SPMB
JAGUAR	XF	2012	Safety belt pretensioner control module B - passengers side	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Safety belt pretensioner control module B - passengers side	Read Data Stream	
JAGUAR	XF	2012	Safety belt pretensioner control module B - passengers side	Special Function	Dynamic safety belt retract and release - SPMA
JAGUAR	XF	2012	Safety belt pretensioner control module B - passengers side	Special Function	Dynamic safety belt retract and release - SPMB
JAGUAR	XF	2012	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data - SPMA
JAGUAR	XF	2012	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data - SPMB
JAGUAR	XF	2012	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Headlamp Control Module	Read Data Stream	
JAGUAR	XF	2012	Headlamp Control Module	Special Function	Headlamp control module system calibration
JAGUAR	XF	2012	Rear differential control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Rear differential control module	Read Data Stream	
JAGUAR	XF	2012	Rear differential control module	Special Function	Control module calibration
JAGUAR	XF	2012	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Gateway module	Read Data Stream	
JAGUAR	XF	2012	Impact classification system	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Impact classification system	Read Data Stream	
JAGUAR	XF	2012	Impact classification system	Special Function	Pedestrian impact crash status reset
JAGUAR	XF	2012	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XF	2012	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	XF	2012	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XF	2012	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Keyless vehicle module	Read Data Stream	
JAGUAR	XF	2012	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Integrated control panel	Read Data Stream	
JAGUAR	XF	2012	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Audio amplifier module	Read Data Stream	
JAGUAR	XF	2012	Audio amplifier module	Special Function	Calibrate dynamic volume control
JAGUAR	XF	2012	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Audio front control module	Read Data Stream	
JAGUAR	XF	2012	Audio front control module	Special Function	Navigation reset
JAGUAR	XF	2012	Audio front control module	Special Function	DVD region counter reset
JAGUAR	XF	2012	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Navigation control module	Read Data Stream	
JAGUAR	XF	2012	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Satellite audio unit module	Read Data Stream	
JAGUAR	XF	2012	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Cellular telephone control module	Read Data Stream	
JAGUAR	XF	2012	Television module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XF	2012	Television module	Read Data Stream	
JAGUAR	XF	2012	Accessory protocol interface module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Accessory protocol interface module	Read Data Stream	
JAGUAR	XF	2012	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2012	Digital audio broadcast module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Powertrain control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Service interval reset
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Injector replacement
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Throttle valve actuator (Diesel)
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Exhaust gas recirculation valve
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Reset water in fuel detection
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Turbine shut-off valve
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Oxygen sensor
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Oxidation catalyst
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Display injector correction factors
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Rest of world - Service interval options
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Idle speed adjustment
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Idle speed test
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Injector valve test
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Evaporative system diagnostic test
JAGUAR	XF	2013 - 2015	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XF	2013 - 2015	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Transmission control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Transmission control module	Special Function	Transmission control module adaption clear
JAGUAR	XF	2013 - 2015	Transmission control module	Special Function	Calibrate clutch
JAGUAR	XF	2013 - 2015	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Anti-lock Braking System	Read Data Stream	
JAGUAR	XF	2013 - 2015	Anti-lock Braking System	Special Function	Brake bleed
JAGUAR	XF	2013 - 2015	Anti-lock Braking System	Special Function	Yaw rate sensor calibration
JAGUAR	XF	2013 - 2015	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Restraints control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Restraints control module	Special Function	Restraints build mode
JAGUAR	XF	2013 - 2015	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Instrument cluster control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Instrument cluster control module	Special Function	Service interval reset
JAGUAR	XF	2013 - 2015	Instrument cluster control module	Special Function	Steering column calibration
JAGUAR	XF	2013 - 2015	Instrument cluster control module	Special Function	Tire size (rolling circumference)
JAGUAR	XF	2013 - 2015	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Adaptive damping control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Adaptive damping control module	Special Function	Calibration learn
JAGUAR	XF	2013 - 2015	Adaptive damping control module	Special Function	Build mode
JAGUAR	XF	2013 - 2015	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Body control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Auxiliary junction box (body control module B)	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Auxiliary junction box (body control module B)	Read Data Stream	
JAGUAR	XF	2013 - 2015	Auxiliary junction box (body control module B)	Special Function	Battery replacement
JAGUAR	XF	2013 - 2015	Auxiliary junction box (body control module B)	Special Function	Transportation mode
JAGUAR	XF	2013 - 2015	Auxiliary junction box (body control module B)	Special Function	Fuel pump supply - Enable/disable
JAGUAR	XF	2013 - 2015	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
JAGUAR	XF	2013 - 2015	Heating ventilation and air conditioning control module	Special Function	Vent actuators test

make	model	year	system	function	subfunction
JAGUAR	XF	2013 - 2015	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Parking brake control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XF	2013 - 2015	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Tire pressure monitor module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	XF	2013 - 2015	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XF	2013 - 2015	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	XF	2013 - 2015	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Parking assist control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Speed control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Speed control module	Special Function	Speed control alignment
JAGUAR	XF	2013 - 2015	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Gear shift module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Driver's door module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Driver's door module	Special Function	Driver's side - Door glass window calibration
JAGUAR	XF	2013 - 2015	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Driver's seat module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	XF	2013 - 2015	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Passenger's door module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
JAGUAR	XF	2013 - 2015	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Passenger's seat module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Passenger's seat module	Special Function	Passenger's seat calibration
JAGUAR	XF	2013 - 2015	Driver's climate seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Driver's climate seat module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Side object detection control module-Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Side object detection control module-Left	Read Data Stream	
JAGUAR	XF	2013 - 2015	Side object detection control module-Left	Special Function	Side object detection configuration - Right
JAGUAR	XF	2013 - 2015	Side object detection control module-Left	Special Function	Side object detection configuration - Left
JAGUAR	XF	2013 - 2015	Side object detection control module-Right	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Side object detection control module-Right	Read Data Stream	
JAGUAR	XF	2013 - 2015	Side object detection control module-Right	Special Function	Side object detection configuration - Right
JAGUAR	XF	2013 - 2015	Side object detection control module-Right	Special Function	Side object detection configuration - Left
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module A - drivers side	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module A - drivers side	Read Data Stream	
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module A - drivers side	Special Function	Dynamic safety belt retract and release - SPMA
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module A - drivers side	Special Function	Dynamic safety belt retract and release - SPMB
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module A - drivers side	Special Function	Clear module learn data - SPMA
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module A - drivers side	Special Function	Clear module learn data - SPMB
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module B - passengers side	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module B - passengers side	Read Data Stream	
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module B - passengers side	Special Function	Dynamic safety belt retract and release - SPMA
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module B - passengers side	Special Function	Dynamic safety belt retract and release - SPMB

make	model	year	system	function	subfunction
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data - SPMA
JAGUAR	XF	2013 - 2015	Safety belt pretensioner control module B - passengers side	Special Function	Clear module learn data - SPMB
JAGUAR	XF	2013 - 2015	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Headlamp Control Module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Headlamp Control Module	Special Function	Headlamp control module system calibration
JAGUAR	XF	2013 - 2015	Rear differential control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Rear differential control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Rear differential control module	Special Function	Control module calibration
JAGUAR	XF	2013 - 2015	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Gateway module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Gateway module	Special Function	Test dual battery system
JAGUAR	XF	2013 - 2015	Gateway module	Special Function	Verify secondary battery charging
JAGUAR	XF	2013 - 2015	Gateway module	Special Function	Quiescent current control module internal check
JAGUAR	XF	2013 - 2015	Impact classification system	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Impact classification system	Read Data Stream	
JAGUAR	XF	2013 - 2015	Impact classification system	Special Function	Pedestrian impact crash status reset
JAGUAR	XF	2013 - 2015	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	XF	2013 - 2015	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Keyless vehicle module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Keyless vehicle module	Special Function	Verify Keys
JAGUAR	XF	2013 - 2015	Keyless vehicle module	Special Function	Check all antennas
JAGUAR	XF	2013 - 2015	Keyless vehicle module	Special Function	Immobiliser Antenna Unit Functionality Check
JAGUAR	XF	2013 - 2015	Keyless vehicle module	Special Function	Add additional keys
JAGUAR	XF	2013 - 2015	Keyless vehicle module	Special Function	Replace faulty/lost keys
JAGUAR	XF	2013 - 2015	Keyless vehicle module	Special Function	Recover programmed keys
JAGUAR	XF	2013 - 2015	Keyless vehicle module	Special Function	Check passive keys enabled
JAGUAR	XF	2013 - 2015	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Integrated control panel	Read Data Stream	
JAGUAR	XF	2013 - 2015	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Audio amplifier module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Audio amplifier module	Special Function	Calibrate dynamic volume control
JAGUAR	XF	2013 - 2015	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Audio front control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Audio front control module	Special Function	Navigation reset
JAGUAR	XF	2013 - 2015	Audio front control module	Special Function	DVD region counter reset
JAGUAR	XF	2013 - 2015	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Navigation control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Satellite audio unit module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Cellular telephone control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Television module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Television module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Chassis control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Chassis control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Chassis control module	Special Function	Set/un-set air suspension control module manufacturing/freeze mode
JAGUAR	XF	2013 - 2015	Accessory protocol interface module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Accessory protocol interface module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Digital audio broadcast module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Transfer case control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	2013 - 2015	Transfer case control module	Read Data Stream	
JAGUAR	XF	2013 - 2015	Transfer case control module	Special Function	Oil change reset
JAGUAR	XF	As of 2016	ABS control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	ABS control module	Read Data Stream	
JAGUAR	XF	As of 2016	ABS control module	Special Function	Brake caliper replacement assembly test
JAGUAR	XF	As of 2016	ABS control module	Special Function	Parking brake pad replacement - Release to service position
JAGUAR	XF	As of 2016	ABS control module	Special Function	Parking brake pad replacement - Exit maintenance mode application

make	model	year	system	function	subfunction
JAGUAR	XF	As of 2016	ABS control module	Special Function	Parking brake activation
JAGUAR	XF	As of 2016	ABS control module	Special Function	Apply and release electric park brake
JAGUAR	XF	As of 2016	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Body control module	Read Data Stream	
JAGUAR	XF	As of 2016	Body control module	Special Function	Steering column calibration
JAGUAR	XF	As of 2016	Body control module	Special Function	Headlamp leveling height sensor calibration
JAGUAR	XF	As of 2016	Body control module	Special Function	Valet mode reset
JAGUAR	XF	As of 2016	Body control module	Special Function	Transportation mode
JAGUAR	XF	As of 2016	Body control module	Special Function	Fuel pump supply - Enable(disable)
JAGUAR	XF	As of 2016	Body control module	Special Function	Ignition cycle counter reset
JAGUAR	XF	As of 2016	Body control module	Special Function	Roof blind-Calibration
JAGUAR	XF	As of 2016	Body control module	Special Function	Sunroof calibration
JAGUAR	XF	As of 2016	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Speed control module	Read Data Stream	
JAGUAR	XF	As of 2016	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Gear shift module	Read Data Stream	
JAGUAR	XF	As of 2016	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Gateway module	Read Data Stream	
JAGUAR	XF	As of 2016	Gateway module	Special Function	Quiescent current control module internal check
JAGUAR	XF	As of 2016	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Instrument cluster control module	Read Data Stream	
JAGUAR	XF	As of 2016	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XF	As of 2016	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	XF	As of 2016	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Powertrain control module	Read Data Stream	
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Reset water in fuel detection
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Service interval reset
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Idle speed test
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Fuel Prime Routine
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Injector replacement
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Oxygen sensor
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Oxidation catalyst
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Engine control module low pressure LGR adaption clear
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Throttle Valve Actuator
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Engine control module reset fuel pump adaption
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Engine control module swirl valve adaption clear
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Reset selective catalyst reduction quality monitor
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Enable\disable glow plugs
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Engine control module reset crank case pressure sensor
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Evaporative system diagnostic test
JAGUAR	XF	As of 2016	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XF	As of 2016	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Restraints control module	Read Data Stream	
JAGUAR	XF	As of 2016	Restraints control module	Special Function	Restraints build mode
JAGUAR	XF	As of 2016	Transfer case control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Transfer case control module	Read Data Stream	
JAGUAR	XF	As of 2016	Transfer case control module	Special Function	All wheel drive system - Pump venting
JAGUAR	XF	As of 2016	Transfer case control module	Special Function	All wheel drive system - Transfer case control module Reset - Clear specified function
JAGUAR	XF	As of 2016	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Transmission control module	Read Data Stream	
JAGUAR	XF	As of 2016	Transmission control module	Special Function	Telematics server communication check
JAGUAR	XF	As of 2016	Telematic control unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Telematic control unit module	Read Data Stream	
JAGUAR	XF	As of 2016	Telematic control unit module	Special Function	Activate telematics control module
JAGUAR	XF	As of 2016	Telematic control unit module	Special Function	Reset/clear WiFi hotspot

make	model	year	system	function	subfunction
JAGUAR	XF	As of 2016	Telematic control unit module	Special Function	Network registration status
JAGUAR	XF	As of 2016	Telematic control unit module	Special Function	Pre-activate telematics control module
JAGUAR	XF	As of 2016	Telematic control unit module	Special Function	Telematics sim card type
JAGUAR	XF	As of 2016	Telematic control unit module	Special Function	Operational mode
JAGUAR	XF	As of 2016	Telematic control unit module	Special Function	Test internal backup battery
JAGUAR	XF	As of 2016	Telematic control unit module	Special Function	Telematics control module battery replacement reset
JAGUAR	XF	As of 2016	Telematic control unit module	Special Function	Brazilian telematics identification transfer
JAGUAR	XF	As of 2016	InControl Touch audio head unit	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	InControl Touch audio head unit	Read Data Stream	
JAGUAR	XF	As of 2016	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Head-up display cooling fan module	Read Data Stream	
JAGUAR	XF	As of 2016	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Integrated control panel	Read Data Stream	
JAGUAR	XF	As of 2016	Head up display	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Head up display	Read Data Stream	
JAGUAR	XF	As of 2016	Head up display	Special Function	Head up display control module reset
JAGUAR	XF	As of 2016	Head up display	Special Function	Activate test picture
JAGUAR	XF	As of 2016	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XF	As of 2016	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
JAGUAR	XF	As of 2016	Heating ventilation and air conditioning control module	Special Function	Reset compressor protection counter
JAGUAR	XF	As of 2016	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
JAGUAR	XF	As of 2016	InControl Touch Pro infotainment master controller	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	InControl Touch Pro infotainment master controller	Read Data Stream	
JAGUAR	XF	As of 2016	Image processing control module A	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Image processing control module A	Read Data Stream	
JAGUAR	XF	As of 2016	Image processing control module A	Special Function	Automatic high beam camera calibration
JAGUAR	XF	As of 2016	Image processing module B	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Image processing module B	Read Data Stream	
JAGUAR	XF	As of 2016	Rear Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Rear Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XF	As of 2016	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Side object detection control module - Left	Read Data Stream	
JAGUAR	XF	As of 2016	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Side object detection control module - Right	Read Data Stream	
JAGUAR	XF	As of 2016	All terrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	All terrain control module	Read Data Stream	
JAGUAR	XF	As of 2016	Chassis control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Chassis control module	Read Data Stream	
JAGUAR	XF	As of 2016	Chassis control module	Special Function	Adaptive speed control - Speed control alignment
JAGUAR	XF	As of 2016	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Parking assist control module	Read Data Stream	
JAGUAR	XF	As of 2016	Power steering control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Power steering control module	Read Data Stream	
JAGUAR	XF	As of 2016	Power steering control module	Special Function	Lock steering tune to vehicle
JAGUAR	XF	As of 2016	Power steering control module	Special Function	Power steering soft-lock end stops reset routine
JAGUAR	XF	As of 2016	Steering angle sensor module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XF	As of 2016	Steering angle sensor module	Read Data Stream	
JAGUAR	XF	As of 2016	Steering angle sensor module	Special Function	Steering angle sensor module
JAGUAR	XF	As of 2016	InControl Touch Pro audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	InControl Touch Pro audio amplifier module	Read Data Stream	
JAGUAR	XF	As of 2016	InControl Touch Pro infotainment slave controller	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	InControl Touch Pro infotainment slave controller	Read Data Stream	
JAGUAR	XF	As of 2016	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Driver's door module	Read Data Stream	
JAGUAR	XF	As of 2016	Driver's door module	Special Function	Door window calibration
JAGUAR	XF	As of 2016	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Driver's (side) rear door module	Read Data Stream	
JAGUAR	XF	As of 2016	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Driver's seat module	Read Data Stream	
JAGUAR	XF	As of 2016	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	XF	As of 2016	Driver's seat module	Special Function	Driver's seat massage on demand self test
JAGUAR	XF	As of 2016	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Keyless vehicle module	Read Data Stream	
JAGUAR	XF	As of 2016	Keyless vehicle module	Special Function	Verify Keys
JAGUAR	XF	As of 2016	Keyless vehicle module	Special Function	Recover programmed keys
JAGUAR	XF	As of 2016	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Passenger's door module	Read Data Stream	
JAGUAR	XF	As of 2016	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Passenger's (side) rear door module	Read Data Stream	
JAGUAR	XF	As of 2016	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Passenger's seat module	Read Data Stream	
JAGUAR	XF	As of 2016	Passenger's seat module	Special Function	Passenger's seat massage on demand self test
JAGUAR	XF	As of 2016	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Rear gate / trunk module	Read Data Stream	
JAGUAR	XF	As of 2016	Deployable towbar control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XF	As of 2016	Deployable towbar control module	Read Data Stream	
JAGUAR	XF	As of 2016	Deployable towbar control module	Special Function	Stow deployable towbar
JAGUAR	XF	As of 2016	Deployable towbar control module	Special Function	Deploy deployable towbar
JAGUAR	XF	As of 2016	Deployable towbar control module	Special Function	Unlock deployable towbar
JAGUAR	XF	As of 2016	Deployable towbar control module	Special Function	Deployable towbar recovery
JAGUAR	XK	1997 - 1999	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Powertrain control module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Transmission control module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Anti-lock Braking System	Read Data Stream	
JAGUAR	XK	1997 - 1999	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Restraints control module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Instrument cluster control module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Adaptive damping control module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Body control module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Body control module	Special Function	Program new transponders
JAGUAR	XK	1997 - 1999	Body control module	Special Function	Clear lost keyfob transmitters
JAGUAR	XK	1997 - 1999	Body control module	Special Function	Program new keyfob transmitters
JAGUAR	XK	1997 - 1999	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Driver's door module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Driver's seat module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Passenger's door module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Passenger's seat module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	1997 - 1999	Key transponder module	Read Data Stream	
JAGUAR	XK	1997 - 1999	Security locking module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XK	1997 - 1999	Security locking module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Powertrain control module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Transmission control module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Anti-lock Braking System	Read Data Stream	
JAGUAR	XK	2000 - 2002	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Restraints control module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Instrument cluster control module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Adaptive damping control module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Body control module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Driver's door module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Driver's seat module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Passenger's door module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Passenger's seat module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Key transponder module	Read Data Stream	
JAGUAR	XK	2000 - 2002	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2000 - 2002	Security locking module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Powertrain control module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Powertrain control module	Special Function	Evaporative system leak check
JAGUAR	XK	2003 - 2005	Headlamp levelling system	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Headlamp levelling system	Read Data Stream	
JAGUAR	XK	2003 - 2005	Headlamp levelling system	Special Function	Right headlamp and/or left headlamp
JAGUAR	XK	2003 - 2005	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Transmission control module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Anti-lock Braking System	Read Data Stream	
JAGUAR	XK	2003 - 2005	Anti-lock Braking System	Special Function	Brake sensor set-up
JAGUAR	XK	2003 - 2005	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Restraints control module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Instrument cluster control module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Adaptive damping control module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Body control module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Parking assist control module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Speed control module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Driver's door module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Driver's seat module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Passenger's door module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Passenger's seat module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Headlamp Control Module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Key transponder module	Read Data Stream	
JAGUAR	XK	2003 - 2005	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2003 - 2005	Security locking module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Powertrain control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Powertrain control module	Special Function	Powertrain control module adaption clear

make	model	year	system	function	subfunction
JAGUAR	XK	2006 - 2009	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	XK	2006 - 2009	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XK	2006 - 2009	Powertrain control module	Special Function	Idle speed test
JAGUAR	XK	2006 - 2009	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Transmission control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Transmission control module	Special Function	Transmission control module adaption clear
JAGUAR	XK	2006 - 2009	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Anti-lock Braking System	Read Data Stream	
JAGUAR	XK	2006 - 2009	Anti-lock Braking System	Special Function	Yaw rate sensor calibration
JAGUAR	XK	2006 - 2009	Anti-lock Braking System	Special Function	Lateral accelerometer calibration
JAGUAR	XK	2006 - 2009	Anti-lock Braking System	Special Function	Pressure sensor calibration
JAGUAR	XK	2006 - 2009	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Restraints control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Restraints control module	Special Function	Seat cushion replacement
JAGUAR	XK	2006 - 2009	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Instrument cluster control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Instrument cluster control module	Special Function	Steering column calibration
JAGUAR	XK	2006 - 2009	Instrument cluster control module	Special Function	Vehicle reset
JAGUAR	XK	2006 - 2009	Instrument cluster control module	Special Function	Key programming
JAGUAR	XK	2006 - 2009	Instrument cluster control module	Special Function	Erase all existing keys
JAGUAR	XK	2006 - 2009	Instrument cluster control module	Special Function	Verify Keys
JAGUAR	XK	2006 - 2009	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Adaptive damping control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Body control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Auxiliary junction box (body control module B)	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Auxiliary junction box (body control module B)	Read Data Stream	
JAGUAR	XK	2006 - 2009	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Parking brake control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XK	2006 - 2009	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Tire pressure monitor module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	XK	2006 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XK	2006 - 2009	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	XK	2006 - 2009	Tire pressure monitor module	Special Function	Tyre pressure monitor ID value display
JAGUAR	XK	2006 - 2009	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Parking assist control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Speed control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Speed control module	Special Function	Speed control alignment
JAGUAR	XK	2006 - 2009	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Driver's door module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Driver's door module	Special Function	Driver's side - Door glass window calibration
JAGUAR	XK	2006 - 2009	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Driver's seat module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	XK	2006 - 2009	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Passenger's door module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
JAGUAR	XK	2006 - 2009	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Passenger's seat module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Passenger's seat module	Special Function	Passenger's seat calibration
JAGUAR	XK	2006 - 2009	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Headlamp Control Module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Headlamp Control Module	Special Function	Headlamp and axle sensor calibration
JAGUAR	XK	2006 - 2009	Impact classification system	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Impact classification system	Read Data Stream	
JAGUAR	XK	2006 - 2009	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XK	2006 - 2009	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Keyless vehicle module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Key transponder module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Security locking module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Audio amplifier module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Audio front control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Navigation control module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Satellite audio unit module	Read Data Stream	
JAGUAR	XK	2006 - 2009	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	2006 - 2009	Cellular telephone control module	Read Data Stream	
JAGUAR	XK	As of 2010	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Powertrain control module	Read Data Stream	
JAGUAR	XK	As of 2010	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XK	As of 2010	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XK	As of 2010	Powertrain control module	Special Function	Reset oil level
JAGUAR	XK	As of 2010	Powertrain control module	Special Function	Check the engine oil level
JAGUAR	XK	As of 2010	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XK	As of 2010	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	XK	As of 2010	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XK	As of 2010	Powertrain control module	Special Function	Idle speed test
JAGUAR	XK	As of 2010	Powertrain control module	Special Function	Engine control module VIN learn application
JAGUAR	XK	As of 2010	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Transmission control module	Read Data Stream	
JAGUAR	XK	As of 2010	Transmission control module	Special Function	Transmission control module adaption clear
JAGUAR	XK	As of 2010	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Anti-lock Braking System	Read Data Stream	
JAGUAR	XK	As of 2010	Anti-lock Braking System	Special Function	Brake bleed
JAGUAR	XK	As of 2010	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Restraints control module	Read Data Stream	
JAGUAR	XK	As of 2010	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Instrument cluster control module	Read Data Stream	
JAGUAR	XK	As of 2010	Instrument cluster control module	Special Function	Steering column calibration
JAGUAR	XK	As of 2010	Instrument cluster control module	Special Function	Vehicle reset
JAGUAR	XK	As of 2010	Instrument cluster control module	Special Function	Key programming
JAGUAR	XK	As of 2010	Instrument cluster control module	Special Function	Erase all existing keys
JAGUAR	XK	As of 2010	Instrument cluster control module	Special Function	Verify Keys
JAGUAR	XK	As of 2010	Adaptive damping control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Adaptive damping control module	Read Data Stream	
JAGUAR	XK	As of 2010	Adaptive damping control module	Special Function	Calibration learn
JAGUAR	XK	As of 2010	Adaptive damping control module	Special Function	Build mode
JAGUAR	XK	As of 2010	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Body control module	Read Data Stream	
JAGUAR	XK	As of 2010	Body control module	Special Function	Alarm trigger history
JAGUAR	XK	As of 2010	Auxiliary junction box (body control module B)	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Auxiliary junction box (body control module B)	Read Data Stream	
JAGUAR	XK	As of 2010	Auxiliary junction box (body control module B)	Special Function	Battery replacement
JAGUAR	XK	As of 2010	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XK	As of 2010	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
JAGUAR	XK	As of 2010	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Parking brake control module	Read Data Stream	
JAGUAR	XK	As of 2010	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	XK	As of 2010	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XK	As of 2010	Tire pressure monitor module	Read Data Stream	
JAGUAR	XK	As of 2010	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	XK	As of 2010	Tire pressure monitor module	Special Function	Tire pressure monitor confirmation application
JAGUAR	XK	As of 2010	Tire pressure monitor module	Special Function	Tire pressure monitor receiver calibration
JAGUAR	XK	As of 2010	Tire pressure monitor module	Special Function	Tyre pressure monitor ID value display
JAGUAR	XK	As of 2010	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Parking assist control module	Read Data Stream	
JAGUAR	XK	As of 2010	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Speed control module	Read Data Stream	
JAGUAR	XK	As of 2010	Speed control module	Special Function	Speed control alignment
JAGUAR	XK	As of 2010	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Gear shift module	Read Data Stream	
JAGUAR	XK	As of 2010	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Driver's door module	Read Data Stream	
JAGUAR	XK	As of 2010	Driver's door module	Special Function	Driver's side - Door glass window calibration
JAGUAR	XK	As of 2010	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Driver's seat module	Read Data Stream	
JAGUAR	XK	As of 2010	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	XK	As of 2010	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Passenger's door module	Read Data Stream	
JAGUAR	XK	As of 2010	Passenger's door module	Special Function	Passenger's side - Door glass window calibration
JAGUAR	XK	As of 2010	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Passenger's seat module	Read Data Stream	
JAGUAR	XK	As of 2010	Passenger's seat module	Special Function	Passenger's seat calibration
JAGUAR	XK	As of 2010	Driver's climate seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Driver's climate seat module	Read Data Stream	
JAGUAR	XK	As of 2010	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Headlamp Control Module	Read Data Stream	
JAGUAR	XK	As of 2010	Headlamp Control Module	Special Function	Headlamp and axle sensor calibration
JAGUAR	XK	As of 2010	Rear differential control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Rear differential control module	Read Data Stream	
JAGUAR	XK	As of 2010	Rear differential control module	Special Function	Control module calibration
JAGUAR	XK	As of 2010	Impact classification system	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Impact classification system	Read Data Stream	
JAGUAR	XK	As of 2010	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XK	As of 2010	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	XK	As of 2010	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XK	As of 2010	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Keyless vehicle module	Read Data Stream	
JAGUAR	XK	As of 2010	Key transponder module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Key transponder module	Read Data Stream	
JAGUAR	XK	As of 2010	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Integrated control panel	Read Data Stream	
JAGUAR	XK	As of 2010	Security locking module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Security locking module	Read Data Stream	
JAGUAR	XK	As of 2010	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Audio amplifier module	Read Data Stream	
JAGUAR	XK	As of 2010	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Audio front control module	Read Data Stream	
JAGUAR	XK	As of 2010	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Navigation control module	Read Data Stream	
JAGUAR	XK	As of 2010	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Satellite audio unit module	Read Data Stream	
JAGUAR	XK	As of 2010	Cellular telephone control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Cellular telephone control module	Read Data Stream	
JAGUAR	XK	As of 2010	Accessory protocol interface module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Accessory protocol interface module	Read Data Stream	
JAGUAR	XK	As of 2010	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
JAGUAR	XK	As of 2010	Digital audio broadcast module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Special Function	Oil service counter level
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Special Function	Service interval reset

make	model	year	system	function	subfunction
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Special Function	Idle speed test
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Special Function	Throttle valve actuator (Diesel)
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Special Function	Fuel prime routine
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Special Function	Engine control module unlock application
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Special Function	Fuel Prime Routine
JAGUAR	F-TYPE	2014 - 2015	Powertrain control module	Special Function	Purge valve self test
JAGUAR	F-TYPE	2014 - 2015	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Transmission control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Anti-lock Braking System	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Anti-lock Braking System	Special Function	Steering angle sensor calibration
JAGUAR	F-TYPE	2014 - 2015	Anti-lock Braking System	Special Function	Apply and release electric park brake
JAGUAR	F-TYPE	2014 - 2015	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Restraints control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Restraints control module	Special Function	Restraints build mode
JAGUAR	F-TYPE	2014 - 2015	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Instrument cluster control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Instrument cluster control module	Special Function	Vehicle reset
JAGUAR	F-TYPE	2014 - 2015	Instrument cluster control module	Special Function	Odometer calibration
JAGUAR	F-TYPE	2014 - 2015	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Body control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Body control module	Special Function	Tire pressure sensor replacement
JAGUAR	F-TYPE	2014 - 2015	Body control module	Special Function	Tyre pressure monitor ID value display
JAGUAR	F-TYPE	2014 - 2015	Body control module	Special Function	Transportation mode
JAGUAR	F-TYPE	2014 - 2015	Body control module	Special Function	Fuel pump supply - Enable/disable
JAGUAR	F-TYPE	2014 - 2015	Body control module	Special Function	Dynamic safety belt retract and release - SPMB
JAGUAR	F-TYPE	2014 - 2015	Body control module	Special Function	Steering column calibration
JAGUAR	F-TYPE	2014 - 2015	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
JAGUAR	F-TYPE	2014 - 2015	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Parking brake control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	F-TYPE	2014 - 2015	Parking brake control module	Special Function	Longitudinal accelerometer calibration
JAGUAR	F-TYPE	2014 - 2015	Parking brake control module	Special Function	Brake caliper replacement assembly test
JAGUAR	F-TYPE	2014 - 2015	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
JAGUAR	F-TYPE	2014 - 2015	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
JAGUAR	F-TYPE	2014 - 2015	Parking brake control module	Special Function	Parking brake activation
JAGUAR	F-TYPE	2014 - 2015	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Parking assist control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Gear shift module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Driver's door module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Driver's door module	Special Function	Driver's side - Door glass window calibration
JAGUAR	F-TYPE	2014 - 2015	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Driver's seat module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	F-TYPE	2014 - 2015	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Passenger's door module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Passenger's seat module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Passenger's seat module	Special Function	Passenger's seat calibration
JAGUAR	F-TYPE	2014 - 2015	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Rear gate/trunk module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Rear gate/trunk module	Special Function	Tailgate/trunk calibration
JAGUAR	F-TYPE	2014 - 2015	Side object detection control module-Left	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Side object detection control module-Left	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Side object detection control module-Right	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Side object detection control module-Right	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Headlamp Control Module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Headlamp Control Module	Special Function	Headlamp control module system calibration

make	model	year	system	function	subfunction
JAGUAR	F-TYPE	2014 - 2015	Rear differential control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Rear differential control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Rear differential control module	Special Function	Control module calibration
JAGUAR	F-TYPE	2014 - 2015	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Gateway module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Gateway module	Special Function	Battery replacement
JAGUAR	F-TYPE	2014 - 2015	Gateway module	Special Function	Test dual battery system
JAGUAR	F-TYPE	2014 - 2015	Gateway module	Special Function	Verify secondary battery charging
JAGUAR	F-TYPE	2014 - 2015	Gateway module	Special Function	Quiescent current control module internal check
JAGUAR	F-TYPE	2014 - 2015	Gateway module	Special Function	Set/un-set air suspension manufacturing/freeze mode
JAGUAR	F-TYPE	2014 - 2015	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Restraints occupant classification system module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	F-TYPE	2014 - 2015	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Keyless vehicle module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Keyless vehicle module	Special Function	Verify Keys
JAGUAR	F-TYPE	2014 - 2015	Keyless vehicle module	Special Function	Check passive keys enabled
JAGUAR	F-TYPE	2014 - 2015	Keyless vehicle module	Special Function	Recover programmed keys
JAGUAR	F-TYPE	2014 - 2015	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Integrated control panel	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Audio amplifier module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Audio front control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Audio front control module	Special Function	DVD region counter reset
JAGUAR	F-TYPE	2014 - 2015	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Navigation control module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Satellite audio unit module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Television module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Television module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Television module	Special Function	Front control display interface module - Graphics update
JAGUAR	F-TYPE	2014 - 2015	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Digital audio broadcast module	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Front control/display interface module (high level display front)	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	2014 - 2015	Front control/display interface module (high level display front)	Read Data Stream	
JAGUAR	F-TYPE	2014 - 2015	Front control/display interface module (high level display front)	Special Function	Calibrate Dynamic Volume Control
JAGUAR	F-TYPE	As of 2016	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Powertrain control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Powertrain control module	Special Function	Oil service counter level
JAGUAR	F-TYPE	As of 2016	Powertrain control module	Special Function	Service interval reset
JAGUAR	F-TYPE	As of 2016	Powertrain control module	Special Function	Idle speed test
JAGUAR	F-TYPE	As of 2016	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	F-TYPE	As of 2016	Powertrain control module	Special Function	Reset water fuel detection
JAGUAR	F-TYPE	As of 2016	Powertrain control module	Special Function	Fuel Prime Routine
JAGUAR	F-TYPE	As of 2016	Powertrain control module	Special Function	Purge valve self test
JAGUAR	F-TYPE	As of 2016	Powertrain control module	Special Function	Evaporative system diagnostic test
JAGUAR	F-TYPE	As of 2016	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Restraints occupant classification system module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	F-TYPE	As of 2016	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Transmission control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Transmission control module	Special Function	Calibrate clutch
JAGUAR	F-TYPE	As of 2016	Transmission control module	Special Function	Telematics server communication check
JAGUAR	F-TYPE	As of 2016	Anti-lock Braking System	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Anti-lock Braking System	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Anti-lock Braking System	Special Function	Apply and release electric park brake
JAGUAR	F-TYPE	As of 2016	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Restraints control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Restraints control module	Special Function	Restraints build mode
JAGUAR	F-TYPE	As of 2016	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Instrument cluster control module	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	F-TYPE	As of 2016	Power steering control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Power steering control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Power steering control module	Special Function	Lock steering tune to vehicle
JAGUAR	F-TYPE	As of 2016	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Steering angle sensor module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Steering angle sensor module	Special Function	Steering angle sensor module
JAGUAR	F-TYPE	As of 2016	Telematic control unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Telematic control unit module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Telematic control unit module	Special Function	Activate telematics control module
JAGUAR	F-TYPE	As of 2016	Telematic control unit module	Special Function	Network registration status
JAGUAR	F-TYPE	As of 2016	Telematic control unit module	Special Function	Pre-activate telematics control module
JAGUAR	F-TYPE	As of 2016	Telematic control unit module	Special Function	Telematics sim card type
JAGUAR	F-TYPE	As of 2016	Telematic control unit module	Special Function	Operational mode
JAGUAR	F-TYPE	As of 2016	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
JAGUAR	F-TYPE	As of 2016	Telematic control unit module	Special Function	Telematics control module battery replacement reset
JAGUAR	F-TYPE	As of 2016	Telematic control unit module	Special Function	Brazilian telematics identification transfer
JAGUAR	F-TYPE	As of 2016	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Body control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Body control module	Special Function	Steering column calibration
JAGUAR	F-TYPE	As of 2016	Body control module	Special Function	Valet mode reset
JAGUAR	F-TYPE	As of 2016	Body control module	Special Function	Transportation mode
JAGUAR	F-TYPE	As of 2016	Body control module	Special Function	Fuel pump supply - Enable(disable)
JAGUAR	F-TYPE	As of 2016	Body control module	Special Function	Ignition cycle counter reset
JAGUAR	F-TYPE	As of 2016	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
JAGUAR	F-TYPE	As of 2016	Heating ventilation and air conditioning control module	Special Function	Reset compressor protection counter
JAGUAR	F-TYPE	As of 2016	Parking brake control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Parking brake control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Parking brake control module	Special Function	Parking brake release to service position
JAGUAR	F-TYPE	As of 2016	Parking brake control module	Special Function	Longitudinal accelerometer calibration
JAGUAR	F-TYPE	As of 2016	Parking brake control module	Special Function	Brake caliper replacement assembly test
JAGUAR	F-TYPE	As of 2016	Parking brake control module	Special Function	Parking brake pad replacement - Release to service position
JAGUAR	F-TYPE	As of 2016	Parking brake control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
JAGUAR	F-TYPE	As of 2016	Parking brake control module	Special Function	Parking brake activation
JAGUAR	F-TYPE	As of 2016	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Parking assist control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Parking assist control module	Special Function	Parking aid control module reset
JAGUAR	F-TYPE	As of 2016	Parking assist control module	Special Function	Parking aid control module reset configuration state
JAGUAR	F-TYPE	As of 2016	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Gear shift module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Driver's door module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Driver's door module	Special Function	Driver's side - Door glass window calibration
JAGUAR	F-TYPE	As of 2016	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Driver's seat module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Passenger's door module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Passenger's seat module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Passenger's seat module	Special Function	Driver's seat calibration
JAGUAR	F-TYPE	As of 2016	Rear gate/trunk module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Rear gate/trunk module	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	F-TYPE	As of 2016	Side object detection control module-Left	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Side object detection control module-Left	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Side object detection control module-Right	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Side object detection control module-Right	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Headlamp Control Module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Headlamp Control Module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Headlamp Control Module	Special Function	Headlamp control module system calibration
JAGUAR	F-TYPE	As of 2016	Rear differential control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Rear differential control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Gateway module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Gateway module	Special Function	Battery replacement
JAGUAR	F-TYPE	As of 2016	Gateway module	Special Function	Quiescent current control module internal check
JAGUAR	F-TYPE	As of 2016	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Keyless vehicle module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Keyless vehicle module	Special Function	Verify Keys
JAGUAR	F-TYPE	As of 2016	Keyless vehicle module	Special Function	Check passive keys enabled
JAGUAR	F-TYPE	As of 2016	Keyless vehicle module	Special Function	Recover programmed keys
JAGUAR	F-TYPE	As of 2016	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Integrated control panel	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Audio amplifier module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Audio front control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Navigation control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Satellite audio unit module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Television module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Television module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Tire pressure monitor module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Tire pressure monitor module	Special Function	Tire pressure sensor replacement
JAGUAR	F-TYPE	As of 2016	Tire pressure monitor module	Special Function	Tire pressure monitor sensor identification display
JAGUAR	F-TYPE	As of 2016	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Digital audio broadcast module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Front control/display interface module (high level display front)	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Front control/display interface module (high level display front)	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Front control/display interface module (high level display front)	Special Function	Calibrate Dynamic Volume Control
JAGUAR	F-TYPE	As of 2016	Transfer case control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-TYPE	As of 2016	Transfer case control module	Read Data Stream	
JAGUAR	F-TYPE	As of 2016	Transfer case control module	Special Function	Oil change reset
JAGUAR	XE	2016	ABS control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	ABS control module	Read Data Stream	
JAGUAR	XE	2016	ABS control module	Special Function	Brake caliper replacement assembly test
JAGUAR	XE	2016	ABS control module	Special Function	Parking brake pad replacement - Release to service position
JAGUAR	XE	2016	ABS control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
JAGUAR	XE	2016	ABS control module	Special Function	Parking brake activation
JAGUAR	XE	2016	ABS control module	Special Function	Apply and release electric park brake
JAGUAR	XE	2016	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Body control module	Read Data Stream	
JAGUAR	XE	2016	Body control module	Special Function	Steering column calibration
JAGUAR	XE	2016	Body control module	Special Function	Headlamp leveling height sensor calibration
JAGUAR	XE	2016	Body control module	Special Function	Valet mode reset
JAGUAR	XE	2016	Body control module	Special Function	Transportation mode
JAGUAR	XE	2016	Body control module	Special Function	Fuel pump supply - Enable(disable)
JAGUAR	XE	2016	Body control module	Special Function	Ignition cycle counter reset
JAGUAR	XE	2016	Body control module	Special Function	Roof blind - Calibration
JAGUAR	XE	2016	Body control module	Special Function	Sunroof calibration

make	model	year	system	function	subfunction
JAGUAR	XE	2016	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Speed control module	Read Data Stream	
JAGUAR	XE	2016	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Gear shift module	Read Data Stream	
JAGUAR	XE	2016	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Gateway module	Read Data Stream	
JAGUAR	XE	2016	Gateway module	Special Function	Battery replacement
JAGUAR	XE	2016	Gateway module	Special Function	Quiescent current control module internal check
JAGUAR	XE	2016	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Instrument cluster control module	Read Data Stream	
JAGUAR	XE	2016	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XE	2016	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	XE	2016	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Powertrain control module	Read Data Stream	
JAGUAR	XE	2016	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XE	2016	Powertrain control module	Special Function	Service interval reset
JAGUAR	XE	2016	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XE	2016	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XE	2016	Powertrain control module	Special Function	Throttle valve actuator
JAGUAR	XE	2016	Powertrain control module	Special Function	Idle speed test
JAGUAR	XE	2016	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XE	2016	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
JAGUAR	XE	2016	Powertrain control module	Special Function	Reset water in fuel detection
JAGUAR	XE	2016	Powertrain control module	Special Function	Fuel Prime Routine
JAGUAR	XE	2016	Powertrain control module	Special Function	Injector replacement
JAGUAR	XE	2016	Powertrain control module	Special Function	Oxygen sensor
JAGUAR	XE	2016	Powertrain control module	Special Function	Oxidation catalyst
JAGUAR	XE	2016	Powertrain control module	Special Function	Engine control module low pressure LGR adaption clear
JAGUAR	XE	2016	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
JAGUAR	XE	2016	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
JAGUAR	XE	2016	Powertrain control module	Special Function	Engine control module reset fuel pump adaption
JAGUAR	XE	2016	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XE	2016	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
JAGUAR	XE	2016	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
JAGUAR	XE	2016	Powertrain control module	Special Function	Engine control module swirl valve adaption clear
JAGUAR	XE	2016	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
JAGUAR	XE	2016	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
JAGUAR	XE	2016	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XE	2016	Powertrain control module	Special Function	Enable\disable glow plugs
JAGUAR	XE	2016	Powertrain control module	Special Function	Engine control module reset crank case pressure sensor
JAGUAR	XE	2016	Powertrain control module	Special Function	Evaporative system diagnostic test
JAGUAR	XE	2016	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XE	2016	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Restraints control module	Read Data Stream	
JAGUAR	XE	2016	Restraints control module	Special Function	Restraints build mode
JAGUAR	XE	2016	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Transmission control module	Read Data Stream	
JAGUAR	XE	2016	Transmission control module	Special Function	Telematics server communication check
JAGUAR	XE	2016	Telematic control unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Telematic control unit module	Read Data Stream	
JAGUAR	XE	2016	Telematic control unit module	Special Function	Activate telematics control module
JAGUAR	XE	2016	Telematic control unit module	Special Function	Reset/clear WiFi hotspot
JAGUAR	XE	2016	Telematic control unit module	Special Function	Network registration status
JAGUAR	XE	2016	Telematic control unit module	Special Function	Pre-activate telematics control module
JAGUAR	XE	2016	Telematic control unit module	Special Function	Telematics sim card type
JAGUAR	XE	2016	Telematic control unit module	Special Function	Operational mode
JAGUAR	XE	2016	Telematic control unit module	Special Function	Test internal backup battery
JAGUAR	XE	2016	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
JAGUAR	XE	2016	Telematic control unit module	Special Function	Telematics control module battery replacement reset
JAGUAR	XE	2016	Telematic control unit module	Special Function	Brazilian telematics identification transfer
JAGUAR	XE	2016	Tire pressure monitor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Tire pressure monitor module	Read Data Stream	
JAGUAR	XE	2016	Tire pressure monitor module	Special Function	Tire pressure sensor replacement

make	model	year	system	function	subfunction
JAGUAR	XE	2016	Tire pressure monitor module	Special Function	Tire pressure monitor sensor identification display
JAGUAR	XE	2016	Vehicle immobilizer control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Vehicle immobilizer control module	Read Data Stream	
JAGUAR	XE	2016	All terrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	All terrain control module	Read Data Stream	
JAGUAR	XE	2016	Chassis control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Chassis control module	Read Data Stream	
JAGUAR	XE	2016	Chassis control module	Special Function	Adaptive speed control - Speed control alignment
JAGUAR	XE	2016	Chassis control module	Special Function	Set Air Suspension Control Module Manufacturing/Freeze Mode
JAGUAR	XE	2016	Image processing control module A	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Image processing control module A	Read Data Stream	
JAGUAR	XE	2016	Image processing control module A	Special Function	Automatic high beam camera calibration
JAGUAR	XE	2016	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Parking assist control module	Read Data Stream	
JAGUAR	XE	2016	Power steering control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Power steering control module	Read Data Stream	
JAGUAR	XE	2016	Power steering control module	Special Function	Power steering soft-lock end stops reset routine
JAGUAR	XE	2016	Power steering control module	Special Function	Lock steering tune to vehicle
JAGUAR	XE	2016	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Steering angle sensor module	Read Data Stream	
JAGUAR	XE	2016	Steering angle sensor module	Special Function	Steering angle sensor module
JAGUAR	XF	2016	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Driver's door module	Read Data Stream	
JAGUAR	XE	2016	Driver's door module	Special Function	Door window calibration
JAGUAR	XE	2016	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Driver's (side) rear door module	Read Data Stream	
JAGUAR	XE	2016	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Driver's seat module	Read Data Stream	
JAGUAR	XE	2016	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	XE	2016	Driver's seat module	Special Function	Driver's seat massage on demand self test
JAGUAR	XE	2016	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Keyless vehicle module	Read Data Stream	
JAGUAR	XE	2016	Keyless vehicle module	Special Function	Verify Keys
JAGUAR	XE	2016	Keyless vehicle module	Special Function	Recover programmed keys
JAGUAR	XE	2016	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Passenger's door module	Read Data Stream	
JAGUAR	XE	2016	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Passenger's (side) rear door module	Read Data Stream	
JAGUAR	XE	2016	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Rear gate / trunk module	Read Data Stream	
JAGUAR	XE	2016	Deployable towbar control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Deployable towbar control module	Read Data Stream	
JAGUAR	XE	2016	Deployable towbar control module	Special Function	Stow deployable towbar
JAGUAR	XE	2016	Deployable towbar control module	Special Function	Deploy deployable towbar
JAGUAR	XE	2016	Deployable towbar control module	Special Function	Unlock deployable towbar
JAGUAR	XE	2016	Deployable towbar control module	Special Function	Deployable towbar recovery
JAGUAR	XE	2016	InControl Touch audio head unit	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	InControl Touch audio head unit	Read Data Stream	
JAGUAR	XE	2016	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Head-up display cooling fan module	Read Data Stream	
JAGUAR	XE	2016	Connect and view module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Connect and view module	Read Data Stream	
JAGUAR	XE	2016	Front control/display interface module (high level display front)	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XE	2016	Front control/display interface module (high level display front)	Read Data Stream	
JAGUAR	XE	2016	Front control/display interface module (high level display front)	Special Function	Calibrate Dynamic Volume Control
JAGUAR	XE	2016	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Integrated control panel	Read Data Stream	
JAGUAR	XE	2016	Head up display	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Head up display	Read Data Stream	
JAGUAR	XE	2016	Head up display	Special Function	Head up display control module reset
JAGUAR	XE	2016	Head up display	Special Function	Activate test picture
JAGUAR	XE	2016	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XE	2016	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
JAGUAR	XE	2016	Heating ventilation and air conditioning control module	Special Function	Reset compressor protection counter
JAGUAR	XE	2016	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
JAGUAR	XE	2016	Image processing module B	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Image processing module B	Read Data Stream	
JAGUAR	XE	2016	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Navigation control module	Read Data Stream	
JAGUAR	XE	2016	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Side object detection control module - Left	Read Data Stream	
JAGUAR	XE	2016	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Side object detection control module - Right	Read Data Stream	
JAGUAR	XE	2016	Audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Audio amplifier module	Read Data Stream	
JAGUAR	XE	2016	Audio front control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Audio front control module	Read Data Stream	
JAGUAR	XE	2016	Digital audio broadcast module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Digital audio broadcast module	Read Data Stream	
JAGUAR	XE	2016	Navigation control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Navigation control module	Read Data Stream	
JAGUAR	XE	2016	Satellite audio unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Satellite audio unit module	Read Data Stream	
JAGUAR	XE	2016	Television module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	2016	Television module	Read Data Stream	
JAGUAR	XE	As of 2017	ABS control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	ABS control module	Read Data Stream	
JAGUAR	XE	As of 2017	ABS control module	Special Function	Brake caliper replacement assembly test
JAGUAR	XE	As of 2017	ABS control module	Special Function	Parking brake pad replacement - Release to service position
JAGUAR	XE	As of 2017	ABS control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
JAGUAR	XE	As of 2017	ABS control module	Special Function	Parking brake activation
JAGUAR	XE	As of 2017	ABS control module	Special Function	Apply and release electric park brake
JAGUAR	XE	As of 2017	Transfer case control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Transfer case control module	Read Data Stream	
JAGUAR	XE	As of 2017	Transfer case control module	Special Function	All wheel drive system - Pump venting
JAGUAR	XE	As of 2017	Transfer case control module	Special Function	All wheel drive system - Transfer case control module Reset - Clear specified function
JAGUAR	XE	As of 2017	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Transmission control module	Read Data Stream	
JAGUAR	XE	As of 2017	Transmission control module	Special Function	Telematics server communication check
JAGUAR	XE	As of 2017	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Body control module	Read Data Stream	
JAGUAR	XE	As of 2017	Body control module	Special Function	Steering column calibration
JAGUAR	XE	As of 2017	Body control module	Special Function	Headlamp leveling height sensor calibration
JAGUAR	XE	As of 2017	Body control module	Special Function	Valet mode reset
JAGUAR	XE	As of 2017	Body control module	Special Function	Transportation mode
JAGUAR	XE	As of 2017	Body control module	Special Function	Fuel pump supply - Enable(disable)
JAGUAR	XE	As of 2017	Body control module	Special Function	Ignition cycle counter reset
JAGUAR	XE	As of 2017	Body control module	Special Function	Roof blind - Calibration
JAGUAR	XE	As of 2017	Body control module	Special Function	Sunroof calibration
JAGUAR	XE	As of 2017	Gear shift module	Read Data Stream	
JAGUAR	XE	As of 2017	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Gateway module	Read Data Stream	
JAGUAR	XE	As of 2017	Gateway module	Special Function	Battery replacement
JAGUAR	XE	As of 2017	Gateway module	Special Function	Quiescent current control module internal check
JAGUAR	XE	As of 2017	Instrument cluster control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	XE	As of 2017	Instrument cluster control module	Read Data Stream	
JAGUAR	XE	As of 2017	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Restraints occupant classification system module	Read Data Stream	
JAGUAR	XE	As of 2017	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	XE	As of 2017	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Powertrain control module	Read Data Stream	
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Oil service counter level
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Service interval reset
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Throttle valve actuator
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Idle speed test
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Reset water in fuel detection
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Fuel Prime Routine
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Injector replacement
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Oxygen sensor
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Oxidation catalyst
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Engine control module low pressure LOR adaption clear
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Engine control module reset fuel pump adaption
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Engine control module swirl valve adaption clear
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Reset selective catalyst reduction quality monitor
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Exhaust gas recirculation valve
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Purge valve self test
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Enable\disable glow plugs
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Engine control module reset crank case pressure sensor
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Exhaust gas recirculation valve
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Evaporative system diagnostic test
JAGUAR	XE	As of 2017	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	XE	As of 2017	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Restraints control module	Read Data Stream	
JAGUAR	XE	As of 2017	Restraints control module	Special Function	Restraints build mode
JAGUAR	XE	As of 2017	Telematic control unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Telematic control unit module	Read Data Stream	
JAGUAR	XE	As of 2017	Telematic control unit module	Special Function	Activate telematics control module
JAGUAR	XE	As of 2017	Telematic control unit module	Special Function	Reset/clear WiFi hotspot
JAGUAR	XE	As of 2017	Telematic control unit module	Special Function	Network registration status
JAGUAR	XE	As of 2017	Telematic control unit module	Special Function	Pre-activate telematics control module
JAGUAR	XE	As of 2017	Telematic control unit module	Special Function	Telematics sim card type
JAGUAR	XE	As of 2017	Telematic control unit module	Special Function	Operational mode
JAGUAR	XE	As of 2017	Telematic control unit module	Special Function	Test internal backup battery
JAGUAR	XE	As of 2017	Telematic control unit module	Special Function	Emergency call and breakdown call switch illumination test
JAGUAR	XE	As of 2017	Telematic control unit module	Special Function	Telematics control module battery replacement reset
JAGUAR	XE	As of 2017	Telematic control unit module	Special Function	Brazilian telematics identification transfer
JAGUAR	XE	As of 2017	All terrain control module	Read Data Stream	
JAGUAR	XE	As of 2017	Chassis control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Chassis control module	Read Data Stream	
JAGUAR	XE	As of 2017	Chassis control module	Special Function	Set Air Suspension Control Module Manufacturing/Freeze Mode
JAGUAR	XE	As of 2017	Image processing control module A	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Image processing control module A	Read Data Stream	
JAGUAR	XE	As of 2017	Image processing control module A	Special Function	Automatic high beam camera calibration
JAGUAR	XE	As of 2017	Parking assist control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Parking assist control module	Read Data Stream	

make	model	year	system	function	subfunction
JAGUAR	XE	As of 2017	Power steering control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Power steering control module	Read Data Stream	
JAGUAR	XE	As of 2017	Power steering control module	Special Function	Lock steering tune to vehicle
JAGUAR	XE	As of 2017	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Steering angle sensor module	Read Data Stream	
JAGUAR	XE	As of 2017	Steering angle sensor module	Special Function	Steering angle sensor module
JAGUAR	XE	As of 2017	InControl Touch audio head unit	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	InControl Touch audio head unit	Read Data Stream	
JAGUAR	XE	As of 2017	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Head-up display cooling fan module	Read Data Stream	
JAGUAR	XE	As of 2017	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Integrated control panel	Read Data Stream	
JAGUAR	XE	As of 2017	Head up display	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Head up display	Read Data Stream	
JAGUAR	XE	As of 2017	Head up display	Special Function	Head up display control module reset
JAGUAR	XE	As of 2017	Head up display	Special Function	Activate test picture
JAGUAR	XE	As of 2017	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	XE	As of 2017	Heating ventilation and air conditioning control module	Special Function	Stepper Motor Initialisation
JAGUAR	XE	As of 2017	Heating ventilation and air conditioning control module	Special Function	Reset compressor protection counter
JAGUAR	XE	As of 2017	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
JAGUAR	XE	As of 2017	InControl Touch Pro infotainment master controller	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	InControl Touch Pro infotainment master controller	Read Data Stream	
JAGUAR	XF	As of 2017	Image processing module B	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Image processing module B	Read Data Stream	
JAGUAR	XE	As of 2017	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Side object detection control module - Left	Read Data Stream	
JAGUAR	XE	As of 2017	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Side object detection control module - Right	Read Data Stream	
JAGUAR	XE	As of 2017	InControl Touch Pro audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	InControl Touch Pro audio amplifier module	Read Data Stream	
JAGUAR	XE	As of 2017	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Driver's door module	Read Data Stream	
JAGUAR	XE	As of 2017	Driver's door module	Special Function	Door window calibration
JAGUAR	XE	As of 2017	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Driver's (side) rear door module	Read Data Stream	
JAGUAR	XE	As of 2017	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Driver's seat module	Read Data Stream	
JAGUAR	XE	As of 2017	Driver's seat module	Special Function	Driver's seat calibration
JAGUAR	XE	As of 2017	Driver's seat module	Special Function	Driver's seat massage on demand self test
JAGUAR	XE	As of 2017	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Keyless vehicle module	Read Data Stream	
JAGUAR	XE	As of 2017	Keyless vehicle module	Special Function	Verify Keys
JAGUAR	XE	As of 2017	Keyless vehicle module	Special Function	Recover programmed keys
JAGUAR	XE	As of 2017	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Passenger's door module	Read Data Stream	
JAGUAR	XE	As of 2017	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Passenger's (side) rear door module	Read Data Stream	
JAGUAR	XE	As of 2017	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Rear gate / trunk module	Read Data Stream	
JAGUAR	XE	As of 2017	Deployable towbar control module	Read Fault Code;Clear Fault Memory	
JAGUAR	XE	As of 2017	Deployable towbar control module	Read Data Stream	
JAGUAR	XE	As of 2017	Deployable towbar control module	Special Function	Stow deployable towbar

make	model	year	system	function	subfunction
JAGUAR	XE	As of 2017	Deployable towbar control module	Special Function	Deploy deployable towbar
JAGUAR	XE	As of 2017	Deployable towbar control module	Special Function	Unlock deployable towbar
JAGUAR	XE	As of 2017	Deployable towbar control module	Special Function	Deployable towbar recovery
JAGUAR	F-Pace	As of 2017	ABS control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	ABS control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	ABS control module	Special Function	Brake caliper replacement assembly test
JAGUAR	F-Pace	As of 2017	ABS control module	Special Function	Parking brake pad replacement - Release to service position
JAGUAR	F-Pace	As of 2017	ABS control module	Special Function	Parking brake pad replacement - Exit maintenance mode application
JAGUAR	F-Pace	As of 2017	ABS control module	Special Function	Parking brake activation
JAGUAR	F-Pace	As of 2017	ABS control module	Special Function	Apply and release electric park brake
JAGUAR	F-Pace	As of 2017	Body control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Body control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Body control module	Special Function	Steering column calibration
JAGUAR	F-Pace	As of 2017	Body control module	Special Function	Headlamps leveling height sensor calibration
JAGUAR	F-Pace	As of 2017	Body control module	Special Function	Valet mode reset
JAGUAR	F-Pace	As of 2017	Body control module	Special Function	Transportation mode
JAGUAR	F-Pace	As of 2017	Body control module	Special Function	Fuel pump supply - Enable(disable)
JAGUAR	F-Pace	As of 2017	Body control module	Special Function	Ignition cycle counter reset
JAGUAR	F-Pace	As of 2017	Body control module	Special Function	Roof blind - Calibration
JAGUAR	F-Pace	As of 2017	Body control module	Special Function	Sunroof calibration
JAGUAR	F-Pace	As of 2017	Speed control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Speed control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Gear shift module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Gear shift module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Gateway module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Gateway module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Gateway module	Special Function	Battery replacement
JAGUAR	F-Pace	As of 2017	Gateway module	Special Function	Quiescent current control module internal check
JAGUAR	F-Pace	As of 2017	Instrument cluster control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Instrument cluster control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Restraints occupant classification system module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Restraints occupant classification system module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Restraints occupant classification system module	Special Function	Seat cushion replacement
JAGUAR	F-Pace	As of 2017	Powertrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Powertrain control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Oil service counter level
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Service interval reset
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Diesel particulate filter dynamic regeneration
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Diesel particulate filter replacement
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Throttle valve actuator
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Idle speed test
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Powertrain control module adaption clear
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Diesel particulate filter differential pressure sensor replacement
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Reset water in fuel detection
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Fuel Prime Routine
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Injector replacement
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Oxygen sensor
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Oxidation catalyst
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Engine control module low pressure EGR adaption
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Engine control module mass air flow adaption clear
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Reset selective catalyst reduction start inhibit
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Engine control module reset fuel pump adaption
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Diesel exhaust fluid injection pump replacement
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Diesel exhaust fluid tank level sensor replacement
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Engine control module swirl valve adaption clear
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Reset selective catalyst reduction quality monitor
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Exhaust gas recirculation valve
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Diesel fueling adaption re-initialization
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Diesel exhaust fluid prime and pressure test
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Purge valve self test
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Enable\disable glow plugs
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Engine control module reset crank case pressure sensor
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Evaporative system diagnostic test
JAGUAR	F-Pace	As of 2017	Powertrain control module	Special Function	Fuel lift pump
JAGUAR	F-Pace	As of 2017	Restraints control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Restraints control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Restraints control module	Special Function	Restraints build mode
JAGUAR	F-Pace	As of 2017	Transfer case control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Transfer case control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Transfer case control module	Special Function	All wheel drive system - Pump venting

make	model	year	system	function	subfunction
JAGUAR	F-Pace	As of 2017	Transfer case control module	Special Function	All wheel drive system - Transfer case control module Reset - Clear specified function
JAGUAR	F-Pace	As of 2017	Transmission control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Transmission control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Transmission control module	Special Function	Telematics server communication check
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Special Function	Activate telematics control module
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Special Function	Reset/clear WiFi hotspot
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Special Function	Network registration status
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Special Function	Pre-activate telematics control module
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Special Function	Telematics sim card type
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Special Function	Operational mode
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Special Function	Test internal backup battery
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Special Function	Telematics control module battery replacement reset
JAGUAR	F-Pace	As of 2017	Telematic control unit module	Special Function	Brazilian telematics identification transfer
JAGUAR	F-Pace	As of 2017	InControl Touch audio head unit	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Head-up display cooling fan module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Head-up display cooling fan module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Integrated control panel	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Integrated control panel	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Head up display	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Head up display	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Head up display	Special Function	Head up display control module reset
JAGUAR	F-Pace	As of 2017	Head up display	Special Function	Activate test picture
JAGUAR	F-Pace	As of 2017	Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Heating ventilation and air conditioning control module	Special Function	Stepper motor initialisation
JAGUAR	F-Pace	As of 2017	Heating ventilation and air conditioning control module	Special Function	Reset compressor protection counter
JAGUAR	F-Pace	As of 2017	Heating ventilation and air conditioning control module	Special Function	Actuators end stop detection
JAGUAR	F-Pace	As of 2017	InControl Touch Pro infotainment master controller	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	InControl Touch Pro infotainment master controller	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Image processing control module A	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Image processing control module A	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Image processing control module A	Special Function	Automatic high beam camera calibration
JAGUAR	F-Pace	As of 2017	Image processing module B	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Image processing module B	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Rear Heating ventilation and air conditioning control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Rear Heating ventilation and air conditioning control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Side object detection control module - Left	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Side object detection control module - Left	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Side object detection control module - Right	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Side object detection control module - Right	Read Data Stream	
JAGUAR	F-Pace	As of 2017	All terrain control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	All terrain control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Chassis control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Chassis control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Chassis control module	Special Function	Adaptive speed control - Speed control alignment
JAGUAR	F-Pace	As of 2017	Chassis control module	Special Function	Set Air Suspension Control Module Manufacturing/Freeze Mode
JAGUAR	F-Pace	As of 2017	Parking assist control module	Read Fault Code;Clear Fault Memory	

make	model	year	system	function	subfunction
JAGUAR	F-Pace	As of 2017	Parking assist control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Power steering control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Power steering control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Power steering control module	Special Function	Lock steering tune to vehicle
JAGUAR	F-Pace	As of 2017	Steering angle sensor module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Steering angle sensor module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Steering angle sensor module	Special Function	Steering angle sensor module
JAGUAR	F-Pace	As of 2017	InControl Touch Pro audio amplifier module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	InControl Touch Pro audio amplifier module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	InControl Touch Pro infotainment slave controller	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	InControl Touch Pro infotainment slave controller	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Driver's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Driver's door module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Driver's door module	Special Function	Door Window Calibration
JAGUAR	F-Pace	As of 2017	Driver's (side) rear door module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Driver's (side) rear door module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Driver's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Driver's seat module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Driver's seat module	Special Function	Driver's Seat Calibration
JAGUAR	F-Pace	As of 2017	Driver's seat module	Special Function	Driver's seat massage on demand self test
JAGUAR	F-Pace	As of 2017	Keyless vehicle module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Keyless vehicle module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Keyless vehicle module	Special Function	Verify Keys
JAGUAR	F-Pace	As of 2017	Keyless vehicle module	Special Function	Recover programmed keys
JAGUAR	F-Pace	As of 2017	Passenger's door module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Passenger's door module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Passenger's (side) rear door module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Passenger's (side) rear door module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Passenger's seat module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Passenger's seat module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Passenger's seat module	Special Function	Passenger's seat massage on demand self test
JAGUAR	F-Pace	As of 2017	Rear gate / trunk module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Rear gate / trunk module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Deployable towbar control module	Read Fault Code;Clear Fault Memory	
JAGUAR	F-Pace	As of 2017	Deployable towbar control module	Read Data Stream	
JAGUAR	F-Pace	As of 2017	Deployable towbar control module	Special Function	Stow deployable towbar
JAGUAR	F-Pace	As of 2017	Deployable towbar control module	Special Function	Deploy deployable towbar
JAGUAR	F-Pace	As of 2017	Deployable towbar control module	Special Function	Unlock deployable towbar
JAGUAR	F-Pace	As of 2017	Deployable towbar control module	Special Function	Deployable towbar recovery