

**Mercedes-Sprinter Diagnostics List
(Note:For reference only)**

model	year	system	function	subfunction
906	Up to 2013	AAG 906	Sys. Info.	
906	Up to 2013	AAG 906	Read code	
906	Up to 2013	AAG 906	Clear code	
906	Up to 2013	AAG 906	Data stream	
906	Up to 2013	AAG 906	Actuation	
906	Up to 2013	AAG 906	Special Functions	Coding display
906	Up to 2013	AAG 906	Special Functions	Initial startup
906	Up to 2013	ASG 906	Sys. Info.	
906	Up to 2013	ASG 906	Read code	
906	Up to 2013	ASG 906	Clear code	
906	Up to 2013	ASG 906	Data stream	
906	Up to 2013	ASG 906	Actuation	
906	Up to 2013	ASG 906	Special Functions	Learning process for clutch grip point
906	Up to 2013	ASG 906	Special Functions	Teach-in of transmission
906	Up to 2013	ASG 906	Special Functions	Read coding and change if necessary
906	Up to 2013	CDI3 906	Sys. Info.	
906	Up to 2013	CDI3 906	Read code	
906	Up to 2013	CDI3 906	Clear code	
906	Up to 2013	CDI3 906	Data stream	
906	Up to 2013	CDI3 906	Actuation	
906	Up to 2013	CDI3 906	Special Functions	Tire size
906	Up to 2013	CDI3 906	Special Functions	Adjustment of injector injection quantities
906	Up to 2013	CDI3 906	Special Functions	Limit values Working speed control
906	Up to 2013	CDI4 906	Sys. Info.	
906	Up to 2013	CDI4 906	Read code	
906	Up to 2013	CDI4 906	Clear code	
906	Up to 2013	CDI4 906	Data stream	
906	Up to 2013	CDI4 906	Actuation	
906	Up to 2013	CDI4 906	Special Functions	Tire size
906	Up to 2013	CDI4 906	Special Functions	Initialization after component replacement
906	Up to 2013	CDI4 906	Special Functions	Diesel particulate filter
906	Up to 2013	CDI4 906	Special Functions	Drive authorization
906	Up to 2013	CDI4 906	Special Functions	Maximum vehicle speed limit
906	Up to 2013	CDI4 906	Special Functions	Write VIN
906	Up to 2013	CDI4 906	Special Functions	Functions in combination with control unit PSM
906	Up to 2013	CDI6 906	Sys. Info.	
906	Up to 2013	CDI6 906	Read code	
906	Up to 2013	CDI6 906	Clear code	
906	Up to 2013	CDI6 906	Data stream	
906	Up to 2013	CDI6 906	Actuation	
906	Up to 2013	CDI6 906	Special Functions	Adjustment of injector injection quantities
906	Up to 2013	CDI6 906	Special Functions	Initialization after component replacement
906	Up to 2013	CDI6 906	Special Functions	Diesel particulate filter
906	Up to 2013	CDI6 906	Special Functions	Drive authorization
906	Up to 2013	CDI6 906	Special Functions	Maximum vehicle speed limit
906	Up to 2013	CDI6 906	Special Functions	Write VIN
906	Up to 2013	CDID2 906	Sys. Info.	
906	Up to 2013	CDID2 906	Read code	
906	Up to 2013	CDID2 906	Clear code	
906	Up to 2013	CDID2 906	Data stream	
906	Up to 2013	CDID2 906	Actuation	
906	Up to 2013	CDID2 906	Special Functions	Initialization after component replacement
906	Up to 2013	CDID2 906	Special Functions	Diesel particulate filter
906	Up to 2013	CDID2 906	Special Functions	Zero quantity calibration
906	Up to 2013	CDID2 906	Special Functions	Control module programming: Reset adaptation data.
906	Up to 2013	DBE 906	Sys. Info.	
906	Up to 2013	DBE 906	Read code	
906	Up to 2013	DBE 906	Clear code	
906	Up to 2013	DBE 906	Data stream	
906	Up to 2013	DBE 906	Actuation	
906	Up to 2013	DBE 906	Special Functions	Teach in component Rain/light sensor.
906	Up to 2013	EIS 906	Sys. Info.	
906	Up to 2013	EIS 906	Read code	
906	Up to 2013	EIS 906	Clear code	
906	Up to 2013	EIS 906	Data stream	
906	Up to 2013	EIS 906	Actuation	
906	Up to 2013	EIS 906	Special Functions	Activation (ELV Electric steering lock)
906	Up to 2013	EIS 906	Special Functions	Central locking (Customer-specific settings)
906	Up to 2013	EIS 906	Special Functions	Key or key track
906	Up to 2013	EIS 906	Special Functions	Activate drive authorization system
906	Up to 2013	EIS 906	Special Functions	Write VIN

model	year	system	function	subfunction
906	Up to 2013	EIS 906	Special Functions	Control unit replacement N26/5 (ESL [ELV] control unit)
906	Up to 2013	ENR - Electronic level control	Sys. Info.	
906	Up to 2013	ENR - Electronic level control	Read code	
906	Up to 2013	ENR - Electronic level control	Clear code	
906	Up to 2013	ENR - Electronic level control	Data stream	
906	Up to 2013	ENR - Electronic level control	Actuation	
906	Up to 2013	ENR - Electronic level control	Special Functions	Level calibration
906	Up to 2013	ENR - Electronic level control	Special Functions	Initialization after component replacement
906	Up to 2013	ESP 906	Sys. Info.	
906	Up to 2013	ESP 906	Read code	
906	Up to 2013	ESP 906	Clear code	
906	Up to 2013	ESP 906	Data stream	
906	Up to 2013	ESP 906	Actuation	
906	Up to 2013	ESP 906	Special Functions	Adaptations in other control units
906	Up to 2013	ESP 906	Special Functions	B24/15 (Yaw rate lateral and longitudinal acceleration sensor)
906	Up to 2013	ESP9 906	Sys. Info.	
906	Up to 2013	ESP9 906	Read code	
906	Up to 2013	ESP9 906	Clear code	
906	Up to 2013	ESP9 906	Data stream	
906	Up to 2013	ESP9 906	Actuation	
906	Up to 2013	ESP9 906	Special Functions	Component Sensor Yaw rate lateral and longitudinal acceleration: Perform calibration
906	Up to 2013	ETC 906	Sys. Info.	
906	Up to 2013	ETC 906	Read code	
906	Up to 2013	ETC 906	Clear code	
906	Up to 2013	ETC 906	Data stream	
906	Up to 2013	ETC 906	Actuation	
906	Up to 2013	ETC 906	Special Functions	resetting of adaptation data
906	Up to 2013	EWM 906	Sys. Info.	
906	Up to 2013	EWM 906	Read code	
906	Up to 2013	EWM 906	Clear code	
906	Up to 2013	EWM 906	Data stream	
906	Up to 2013	EWM 906	Actuation	
906	Up to 2013	EWM 906	Special Functions	Initial startup
906	Up to 2013	FSCU 906	Sys. Info.	
906	Up to 2013	FSCU 906	Read code	
906	Up to 2013	FSCU 906	Clear code	
906	Up to 2013	FSCU 906	Data stream	
906	Up to 2013	FSCU 906	Actuation	
906	Up to 2013	KE 906	Sys. Info.	
906	Up to 2013	KE 906	Read code	
906	Up to 2013	KE 906	Clear code	
906	Up to 2013	KE 906	Data stream	
906	Up to 2013	KE 906	Actuation	
906	Up to 2013	KE 906	Special Functions	Initial startup
906	Up to 2013	KI 906	Sys. Info.	
906	Up to 2013	KI 906	Read code	
906	Up to 2013	KI 906	Clear code	
906	Up to 2013	KI 906	Data stream	
906	Up to 2013	KI 906	Actuation	
906	Up to 2013	KI 906	Special Functions	Reset of maintenance interval display(Oil change)
906	Up to 2013	KLA 906	Sys. Info.	
906	Up to 2013	KLA 906	Read code	
906	Up to 2013	KLA 906	Clear code	
906	Up to 2013	KLA 906	Data stream	
906	Up to 2013	KLA 906	Actuation	
906	Up to 2013	LWR 906	Sys. Info.	
906	Up to 2013	LWR 906	Read code	
906	Up to 2013	LWR 906	Clear code	
906	Up to 2013	LWR 906	Data stream	
906	Up to 2013	LWR 906	Special Functions	Calibrate control unit LWR
906	Up to 2013	ME 906	Sys. Info.	
906	Up to 2013	ME 906	Read code	
906	Up to 2013	ME 906	Clear code	
906	Up to 2013	ME 906	Data stream	
906	Up to 2013	ME 906	Special Functions	Drive authorization system
906	Up to 2013	ME 906	Special Functions	Initial startup
906	Up to 2013	ME 906	Special Functions	Maximum vehicle speed limit
906	Up to 2013	ME 906	Special Functions	Learning processes
906	Up to 2013	ME 906	Special Functions	Correction programming
906	As of 2004	ME97 906	Sys. Info.	
906	As of 2004	ME97 906	Read code	
906	As of 2004	ME97 906	Clear code	

model	year	system	function	subfunction
906	As of 2004	ME97 906	Data stream	
906	As of 2004	ME97 906	Special Functions	Drive authorization
906	Up to 2013	MRM 906	Sys. Info.	
906	Up to 2013	MRM 906	Read code	
906	Up to 2013	MRM 906	Clear code	
906	Up to 2013	MRM 906	Data stream	
906	Up to 2013	MRM 906	Actuation	
906	Up to 2013	MRM 906	Special Functions	Initial startup
906	Up to 2013	OBF 906	Sys. Info.	
906	Up to 2013	OBF 906	Read code	
906	Up to 2013	OBF 906	Clear code	
906	Up to 2013	OBF 906	Data stream	
906	Up to 2013	OBF 906	Actuation	
906	Up to 2013	OBF 906	Special Functions	Initial startup
906	Up to 2013	OBF2 906	Sys. Info.	
906	Up to 2013	OBF2 906	Read code	
906	Up to 2013	OBF2 906	Clear code	
906	Up to 2013	OBF2 906	Data stream	
906	Up to 2013	OBF2 906	Special Functions	Initial startup
906	Up to 2013	PSM 906	Sys. Info.	
906	Up to 2013	PSM 906	Read code	
906	Up to 2013	PSM 906	Clear code	
906	Up to 2013	PSM 906	Data stream	
906	Up to 2013	PSM 906	Special Functions	Correction of FMS data
906	Up to 2013	PTC 906	Sys. Info.	
906	Up to 2013	PTC 906	Read code	
906	Up to 2013	PTC 906	Clear code	
906	Up to 2013	PTC 906	Data stream	
906	Up to 2013	PTC 906	Actuation	
906	Up to 2013	PTC 906	Special Functions	Initial startup
906	Up to 2013	PTS 906	Sys. Info.	
906	Up to 2013	PTS 906	Read code	
906	Up to 2013	PTS 906	Clear code	
906	Up to 2013	PTS 906	Data stream	
906	Up to 2013	PTS 906	Actuation	
906	Up to 2013	PTS 906	Special Functions	Customer-specific settings
906	Up to 2013	RDK(As of 2011) 906	Sys. Info.	
906	Up to 2013	RDK(As of 2011) 906	Read code	
906	Up to 2013	RDK(As of 2011) 906	Clear code	
906	Up to 2013	RDK(As of 2011) 906	Data stream	
906	Up to 2013	RDK(As of 2011) 906	Actuation	
906	Up to 2013	RDK(As of 2011) 906	Special Functions	Write wheel electronics identification number.
906	Up to 2013	RDK(Up to 2010) 906	Sys. Info.	
906	Up to 2013	RDK(Up to 2010) 906	Read code	
906	Up to 2013	RDK(Up to 2010) 906	Clear code	
906	Up to 2013	RDK(Up to 2010) 906	Data stream	
906	Up to 2013	RDK(Up to 2010) 906	Actuation	
906	Up to 2013	RDK(Up to 2010) 906	Special Functions	unit
906	Up to 2013	SAM 906	Sys. Info.	
906	Up to 2013	SAM 906	Read code	
906	Up to 2013	SAM 906	Clear code	
906	Up to 2013	SAM 906	Data stream	
906	Up to 2013	SAM 906	Actuation	
906	Up to 2013	SAM 906	Special Functions	Initial startup
906	As of 2004	SCR 906	Sys. Info.	
906	As of 2004	SCR 906	Read code	
906	As of 2004	SCR 906	Clear code	
906	As of 2004	SCR 906	Data stream	
906	As of 2004	SCR 906	Actuation	
906	As of 2004	CDI60 906	Sys. Info.	
906	As of 2004	CDI60 906	Read code	
906	As of 2004	CDI60 906	Clear code	
906	As of 2004	CDI60 906	Data stream	
906	As of 2004	CDI60 906	Special Functions	Injector injection quantity adjustment
906	As of 2004	CDI60 906	Special Functions	Regeneration of diesel particulate filter when driving
906	Up to 2013	SRS 906	Sys. Info.	
906	Up to 2013	SRS 906	Read code	
906	Up to 2013	SRS 906	Clear code	
906	Up to 2013	SRS 906	Data stream	
906	Up to 2013	SRS 906	Actuation	
906	Up to 2013	SRS 906	Special Functions	Interlock control module
906	Up to 2013	SRS-L 906	Sys. Info.	
906	Up to 2013	SRS-L 906	Read code	

model	year	system	function	subfunction
906	Up to 2013	SRS-L 906	Clear code	
906	Up to 2013	SRS-L 906	Data stream	
906	Up to 2013	SRS-L 906	Actuation	
906	Up to 2013	SRS-L 906	Special Functions	Interlock control module
906	Up to 2013	STL 906	Sys. Info.	
906	Up to 2013	STL 906	Read code	
906	Up to 2013	STL 906	Clear code	
906	Up to 2013	STL 906	Data stream	
906	Up to 2013	STL 906	Actuation	
906	Up to 2013	STR 906	Sys. Info.	
906	Up to 2013	STR 906	Read code	
906	Up to 2013	STR 906	Clear code	
906	Up to 2013	STR 906	Data stream	
906	Up to 2013	STR 906	Actuation	
906	Up to 2013	TSG 906	Sys. Info.	
906	Up to 2013	TSG 906	Read code	
906	Up to 2013	TSG 906	Clear code	
906	Up to 2013	TSG 906	Data stream	
906	Up to 2013	TSG 906	Actuation	
906	Up to 2013	TSG 906	Special Functions	Initial startup
906	Up to 2013	VG 906	Sys. Info.	
906	Up to 2013	VG 906	Read code	
906	Up to 2013	VG 906	Clear code	
906	Up to 2013	VG 906	Data stream	
906	Up to 2013	ZHE 906	Sys. Info.	
906	Up to 2013	ZHE 906	Read code	
906	Up to 2013	ZHE 906	Clear code	
906	Up to 2013	ZHE 906	Data stream	
906	Up to 2013	ZHE 906	Actuation	
906	Up to 2013	ZHE 906	Special Functions	Initial startup
447	As of 2004	RD - Radio	Sys. Info.	
447	As of 2004	RD - Radio	Read code	
447	As of 2004	RD - Radio	Clear code	
447	As of 2004	RD - Radio	Data stream	
447	As of 2004	KAB - Camera cover	Sys. Info.	
447	As of 2004	KAB - Camera cover	Read code	
447	As of 2004	KAB - Camera cover	Clear code	
447	As of 2004	KAB - Camera cover	Data stream	
447	As of 2004	DTCO - Tachograph	Sys. Info.	
447	As of 2004	DTCO - Tachograph	Read code	
447	As of 2004	DTCO - Tachograph	Clear code	
447	As of 2004	DTCO - Tachograph	Data stream	
447	As of 2004	SG - AWF - Control unit COLLISION PREVENTION ASSIST	Sys. Info.	
447	As of 2004	SG - AWF - Control unit COLLISION PREVENTION ASSIST	Read code	
447	As of 2004	SG - AWF - Control unit COLLISION PREVENTION ASSIST	Clear code	
447	As of 2004	SG - AWF - Control unit COLLISION PREVENTION ASSIST	Data stream	
447	As of 2004	SG - AWF - Control unit COLLISION PREVENTION ASSIST	Special Functions	Resetting of learned values of component B162 (Collision warning system radar sensor)
447	As of 2004	radar sensor system	Sys. Info.	
447	As of 2004	radar sensor system	Read code	
447	As of 2004	radar sensor system	Clear code	
447	As of 2004	radar sensor system	Data stream	
447	As of 2004	radar sensor system	Sys. Info.	
447	As of 2004	radar sensor system	Read code	
447	As of 2004	radar sensor system	Clear code	
447	As of 2004	radar sensor system	Data stream	
447	As of 2004	IC-Instrument cluster	Sys. Info.	
447	As of 2004	IC-Instrument cluster	Read code	
447	As of 2004	IC-Instrument cluster	Clear code	
447	As of 2004	IC-Instrument cluster	Data stream	
447	As of 2004	IC-Instrument cluster	Actuation	
447	As of 2004	IC-Instrument cluster	Special Functions	Control unit reset

model	year	system	function	subfunction
447	As of 2004	NAV - Navigation module	Sys. Info.	
447	As of 2004	NAV - Navigation module	Read code	
447	As of 2004	NAV - Navigation module	Clear code	
447	As of 2004	NAV - Navigation module	Data stream	
447	As of 2004	PTS - PARKTRONIC	Sys. Info.	
447	As of 2004	PTS - PARKTRONIC	Read code	
447	As of 2004	PTS - PARKTRONIC	Clear code	
447	As of 2004	PTS - PARKTRONIC	Data stream	
447	As of 2004	RFK - Backup camera	Sys. Info.	
447	As of 2004	RFK - Backup camera	Read code	
447	As of 2004	RFK - Backup camera	Clear code	
447	As of 2004	RFK - Backup camera	Data stream	
447	As of 2004	MFK - Multifunct camera	Sys. Info.	
447	As of 2004	MFK - Multifunct camera	Clear code	
447	As of 2004	MFK - Multifunct camera	Data stream	
447	As of 2004	MFK - Multifunct camera	Special Functions	Calibration
447	As of 2004	DCU - LF - Left front door	Sys. Info.	
447	As of 2004	DCU - LF - Left front door	Read code	
447	As of 2004	DCU - LF - Left front door	Clear code	
447	As of 2004	DCU - LF - Left front door	Special Functions	Normalization of power window
447	As of 2004	DCU - LF - Left front door	Data stream	
447	As of 2004	DCU - RF - Right front door	Sys. Info.	
447	As of 2004	DCU - RF - Right front door	Read code	
447	As of 2004	DCU - RF - Right front door	Clear code	
447	As of 2004	DCU - RF - Right front door	Data stream	
447	As of 2004	EST - L - Left electric sliding door	Sys. Info.	
447	As of 2004	EST - L - Left electric sliding door	Read code	
447	As of 2004	EST - L - Left electric sliding door	Clear code	
447	As of 2004	EST - L - Left electric sliding door	Data stream	
447	As of 2004	EST - R - Right electric sliding door	Sys. Info.	
447	As of 2004	EST - R - Right electric sliding door	Read code	
447	As of 2004	EST - R - Right electric sliding door	Clear code	
447	As of 2004	EST - R - Right electric sliding door	Data stream	
447	As of 2004	Driver with memory function	Sys. Info.	
447	As of 2004	Driver with memory function	Read code	
447	As of 2004	Driver with memory function	Clear code	
447	As of 2004	Driver with memory function	Data stream	
447	As of 2004	adjustment Front passenger with	Sys. Info.	
447	As of 2004	adjustment Front passenger with	Read code	
447	As of 2004	adjustment Front passenger with	Clear code	
447	As of 2004	adjustment Front passenger with	Data stream	
447	As of 2004	ISM - Shift module	Sys. Info.	
447	As of 2004	ISM - Shift module	Read code	
447	As of 2004	ISM - Shift module	Clear code	
447	As of 2004	ISM - Shift module	Data stream	
447	As of 2004	AAC - Air conditioning	Sys. Info.	
447	As of 2004	AAC - Air conditioning	Read code	
447	As of 2004	AAC - Air conditioning	Clear code	
447	As of 2004	AAC - Air conditioning	Data stream	
447	As of 2004	FSCU - Control unit Fuel Pump	Sys. Info.	
447	As of 2004	FSCU - Control unit Fuel Pump	Read code	
447	As of 2004	FSCU - Control unit Fuel Pump	Clear code	
447	As of 2004	FSCU - Control unit Fuel Pump	Data stream	
447	As of 2004	TPM - Tire pressure monitor	Sys. Info.	
447	As of 2004	TPM - Tire pressure monitor	Read code	
447	As of 2004	TPM - Tire pressure monitor	Clear code	

model	year	system	function	subfunction
447	As of 2004	TPM - Tire pressure monitor	Data stream	
447	As of 2004	control	Sys. Info.	
447	As of 2004	control	Read code	
447	As of 2004	control	Clear code	
447	As of 2004	control	Data stream	
447	As of 2004	control	Actuation	
447	As of 2004	control	Special Functions	Teach-in processes
447	As of 2004	SCR - Srlrctive catalytic reduction	Sys. Info.	
447	As of 2004	SCR - Srlrctive catalytic reduction	Read code	
447	As of 2004	SCR - Srlrctive catalytic reduction	Clear code	
447	As of 2004	SCR - Srlrctive catalytic reduction	Data stream	
447	As of 2004	ES - Electrical power steering	Sys. Info.	
447	As of 2004	ES - Electrical power steering	Read code	
447	As of 2004	ES - Electrical power steering	Clear code	
447	As of 2004	ES - Electrical power steering	Data stream	
447	As of 2004	ESP - Electrical stability program	Sys. Info.	
447	As of 2004	ESP - Electrical stability program	Read code	
447	As of 2004	ESP - Electrical stability program	Clear code	
447	As of 2004	ESP - Electrical stability program	Data stream	
447	As of 2004	ESP - Electrical stability program	Special Functions	Normalization
447	As of 2004	ESP - Electrical stability program	Special Functions	Denormalization of steering limiter
447	As of 2004	ESP - Electrical stability program	Special Functions	Resetting the center position of the steering
447	As of 2004	ESP - Electrical stability program	Special Functions	Control unit reset
447	As of 2004	ESP - Electrical stability program	Special Functions	Normalization Steering gear NEW
447	As of 2004	AAG - Trailer recognition	Sys. Info.	
447	As of 2004	AAG - Trailer recognition	Read code	
447	As of 2004	AAG - Trailer recognition	Clear code	
447	As of 2004	AAG - Trailer recognition	Data stream	
447	As of 2004	ATA - Anti-theft alarm system	Sys. Info.	
447	As of 2004	ATA - Anti-theft alarm system	Read code	
447	As of 2004	ATA - Anti-theft alarm system	Clear code	
447	As of 2004	ATA - Anti-theft alarm system	Data stream	
447	As of 2004	EZS - Electronic ignition lock	Sys. Info.	
447	As of 2004	EZS - Electronic ignition lock	Read code	
447	As of 2004	EZS - Electronic ignition lock	Clear code	
447	As of 2004	EZS - Electronic ignition lock	Data stream	
447	As of 2004	OCP - Overhead control panel	Sys. Info.	
447	As of 2004	OCP - Overhead control panel	Read code	
447	As of 2004	OCP - Overhead control panel	Clear code	
447	As of 2004	OCP - Overhead control panel	Data stream	
447	As of 2004	PSM-Parameterizable special module	Sys. Info.	
447	As of 2004	PSM-Parameterizable special module	Read code	
447	As of 2004	PSM-Parameterizable special module	Clear code	
447	As of 2004	PSM-Parameterizable special module	Data stream	
447	As of 2004	SCM - Steering column module	Sys. Info.	
447	As of 2004	SCM - Steering column module	Read code	
447	As of 2004	SCM - Steering column module	Clear code	
447	As of 2004	SCM - Steering column module	Data stream	
447	As of 2004	SRS - Supplemental restraint system	Sys. Info.	
447	As of 2004	SRS - Supplemental restraint system	Read code	
447	As of 2004	SRS - Supplemental restraint system	Clear code	
447	As of 2004	SRS - Supplemental restraint system	Data stream	
447	As of 2004	RevETR - LF - Left front reversible emergency tensioning retractor	Sys. Info.	
447	As of 2004	RevETR - LF - Left front reversible emergency tensioning retractor	Read code	
447	As of 2004	RevETR - LF - Left front reversible emergency tensioning retractor	Clear code	
447	As of 2004	RevETR - LF - Left front reversible emergency tensioning retractor	Data stream	
447	As of 2004	emergency tensioning retractor	Sys. Info.	
447	As of 2004	emergency tensioning retractor	Read code	
447	As of 2004	emergency tensioning retractor	Clear code	
447	As of 2004	emergency tensioning retractor	Data stream	
447	As of 2004	module	Sys. Info.	
447	As of 2004	module	Read code	

model	year	system	function	subfunction
447	As of 2004	module	Clear code	
447	As of 2004	module	Data stream	
447	As of 2004	SG - LEDSW-L - Left headlamp	Sys. Info.	
447	As of 2004	SG - LEDSW-L - Left headlamp	Read code	
447	As of 2004	SG - LEDSW-L - Left headlamp	Clear code	
447	As of 2004	SG - LEDSW-L - Left headlamp	Data stream	
447	As of 2004	SG - LEDSW-R - Right headlamp	Sys. Info.	
447	As of 2004	SG - LEDSW-R - Right headlamp	Read code	
447	As of 2004	SG - LEDSW-R - Right headlamp	Clear code	
447	As of 2004	SG - LEDSW-R - Right headlamp	Data stream	
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Sys. Info.	
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Read code	
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Clear code	
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Data stream	
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Teach in component M18 (Exhaust flap actuator motor)
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Teach in component M72/3 (Intake port shutoff actuator motor).
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Teach in component Y27/22 (Exhaust gas recirculation actuator, low pressure).
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Teach in component Y27/20 (Exhaust gas recirculation actuator, high pressure).
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Teach in diesel particulate filter again.
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Teach in used diesel particulate filter.
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Resetting of learned values of component B28/8 (Differential pressure sensor (DPF))
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Reset learned values for AdBlue(R) metering.
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	SCR catalytic converter
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Teach-in process of component B85/6 (Oxygen sensor)
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Resetting of learned values of component B2/16 (Hot film mass air flow sensor)
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Resetting of contamination level of air filter
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Resetting adaptation values of component Turbocharger
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Reset values of quantity mean value adaptation.
447	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Special Functions	Activate fuel pump
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Sys. Info.	
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Read code	
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Clear code	
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Data stream	
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Actuation	
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Teach in diesel particulate filter again.
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	injector injection quantity adjustment(Manual entry).
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Activate fuel pump.
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Initialization after replacement of components

model	year	system	function	subfunction
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Intake port shutoff
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Oxygen sensor
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Hot film mass air flow sensor
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Air filter
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Pressure regulator valve
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Diesel particulate filter/ Oxidation catalytic converter
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Differential pressure sensor of diesel particular filter
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Quantity control valve
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Position sensor Neutral position of transmission
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	NOx sensors
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	SCR catalytic converter
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Y130 (AdBlue(R) injection valve)
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Temperature sensor upstream of SCR catalytic converter
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Reset learned values for AdBlue(R) metering.
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Resetting parameters: Number of engine starts
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Special procedure COP
447	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Teach-in processes
447	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Sys. Info.	
447	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Read code	
447	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Clear code	
447	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Actuation	
447	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Special Functions	Teach-in processes
447	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Sys. Info.	
447	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Read code	
447	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Clear code	
447	As of 2004	N112/9 (HERMES control unit)	Sys. Info.	
447	As of 2004	N112/9 (HERMES control unit)	Read code	
447	As of 2004	N112/9 (HERMES control unit)	Clear code	
447	As of 2004	SCM - Steering column module	Sys. Info.	
447	As of 2004	SCM - Steering column module	Read code	
447	As of 2004	SCM - Steering column module	Clear code	
447	As of 2004	control unit)	Sys. Info.	
447	As of 2004	control unit)	Read code	
447	As of 2004	control unit)	Clear code	
448	As of 2004	RD - Radio	Sys. Info.	
448	As of 2004	RD - Radio	Read code	
448	As of 2004	RD - Radio	Clear code	
448	As of 2004	RD - Radio	Data stream	
448	As of 2004	KAB - Camera cover	Sys. Info.	
448	As of 2004	KAB - Camera cover	Read code	
448	As of 2004	KAB - Camera cover	Clear code	
448	As of 2004	KAB - Camera cover	Data stream	
448	As of 2004	DTCO - Tachograph	Sys. Info.	

model	year	system	function	subfunction
448	As of 2004	DTCO - Tachograph	Read code	
448	As of 2004	DTCO - Tachograph	Clear code	
448	As of 2004	DTCO - Tachograph	Data stream	
448	As of 2004	SG - AWF - Control unit COLLISION PREVENTION ASSIST	Sys. Info.	
448	As of 2004	SG - AWF - Control unit COLLISION PREVENTION ASSIST	Read code	
448	As of 2004	SG - AWF - Control unit COLLISION PREVENTION ASSIST	Clear code	
448	As of 2004	SG - AWF - Control unit COLLISION PREVENTION ASSIST	Data stream	
448	As of 2004	radar sensor system	Sys. Info.	
448	As of 2004	radar sensor system	Read code	
448	As of 2004	radar sensor system	Clear code	
448	As of 2004	radar sensor system	Data stream	
448	As of 2004	radar sensor system	Sys. Info.	
448	As of 2004	radar sensor system	Read code	
448	As of 2004	radar sensor system	Clear code	
448	As of 2004	radar sensor system	Data stream	
448	As of 2004	IC-Instrument cluster	Sys. Info.	
448	As of 2004	IC-Instrument cluster	Read code	
448	As of 2004	IC-Instrument cluster	Clear code	
448	As of 2004	IC-Instrument cluster	Data stream	
448	As of 2004	IC-Instrument cluster	Actuation	
448	As of 2004	IC-Instrument cluster	Special Functions	Control unit reset
448	As of 2004	NAV - Navigation module	Sys. Info.	
448	As of 2004	NAV - Navigation module	Read code	
448	As of 2004	NAV - Navigation module	Clear code	
448	As of 2004	NAV - Navigation module	Data stream	
448	As of 2004	PTS - PARKTRONIC	Sys. Info.	
448	As of 2004	PTS - PARKTRONIC	Read code	
448	As of 2004	PTS - PARKTRONIC	Clear code	
448	As of 2004	PTS - PARKTRONIC	Data stream	
448	As of 2004	RFK - Backup camera	Sys. Info.	
448	As of 2004	RFK - Backup camera	Read code	
448	As of 2004	RFK - Backup camera	Clear code	
448	As of 2004	RFK - Backup camera	Data stream	
448	As of 2004	MFK - Multifunctor camera	Sys. Info.	
448	As of 2004	MFK - Multifunctor camera	Read code	
448	As of 2004	MFK - Multifunctor camera	Clear code	
448	As of 2004	MFK - Multifunctor camera	Data stream	
448	As of 2004	DCU - LF - Left front door	Sys. Info.	
448	As of 2004	DCU - LF - Left front door	Read code	
448	As of 2004	DCU - LF - Left front door	Clear code	
448	As of 2004	DCU - LF - Left front door	Data stream	
448	As of 2004	DCU - RF - Right front door	Sys. Info.	
448	As of 2004	DCU - RF - Right front door	Read code	
448	As of 2004	DCU - RF - Right front door	Clear code	
448	As of 2004	DCU - RF - Right front door	Data stream	
448	As of 2004	EST - L - Left electric sliding door	Sys. Info.	
448	As of 2004	EST - L - Left electric sliding door	Read code	
448	As of 2004	EST - L - Left electric sliding door	Clear code	
448	As of 2004	EST - L - Left electric sliding door	Data stream	
448	As of 2004	EST - R - Right electric sliding door	Sys. Info.	
448	As of 2004	EST - R - Right electric sliding door	Read code	
448	As of 2004	EST - R - Right electric sliding door	Clear code	
448	As of 2004	EST - R - Right electric sliding door	Data stream	
448	As of 2004	Driver with memory function	Sys. Info.	
448	As of 2004	Driver with memory function	Read code	

model	year	system	function	subfunction
448	As of 2004	Driver with memory function	Clear code	
448	As of 2004	Driver with memory function	Data stream	
448	As of 2004	adjustment Front passenger with	Sys. Info.	
448	As of 2004	adjustment Front passenger with	Read code	
448	As of 2004	adjustment Front passenger with	Clear code	
448	As of 2004	adjustment Front passenger with	Data stream	
448	As of 2004	ISM - Shift module	Sys. Info.	
448	As of 2004	ISM - Shift module	Read code	
448	As of 2004	ISM - Shift module	Clear code	
448	As of 2004	ISM - Shift module	Data stream	
448	As of 2004	AAC - Air conditioning	Sys. Info.	
448	As of 2004	AAC - Air conditioning	Read code	
448	As of 2004	AAC - Air conditioning	Clear code	
448	As of 2004	AAC - Air conditioning	Data stream	
448	As of 2004	FSCU - Control unit Fuel Pump	Sys. Info.	
448	As of 2004	FSCU - Control unit Fuel Pump	Read code	
448	As of 2004	FSCU - Control unit Fuel Pump	Clear code	
448	As of 2004	FSCU - Control unit Fuel Pump	Data stream	
448	As of 2004	TPM - Tire pressure monitor	Sys. Info.	
448	As of 2004	TPM - Tire pressure monitor	Read code	
448	As of 2004	TPM - Tire pressure monitor	Clear code	
448	As of 2004	TPM - Tire pressure monitor	Data stream	
448	As of 2004	control	Sys. Info.	
448	As of 2004	control	Read code	
448	As of 2004	control	Clear code	
448	As of 2004	control	Data stream	
448	As of 2004	control	Actuation	
448	As of 2004	control	Special Functions	Teach-in processes
448	As of 2004	SCR - Srlrctive catalytic reduction	Sys. Info.	
448	As of 2004	SCR - Srlrctive catalytic reduction	Read code	
448	As of 2004	SCR - Srlrctive catalytic reduction	Clear code	
448	As of 2004	SCR - Srlrctive catalytic reduction	Data stream	
448	As of 2004	ES - Electrical power steering	Sys. Info.	
448	As of 2004	ES - Electrical power steering	Read code	
448	As of 2004	ES - Electrical power steering	Clear code	
448	As of 2004	ES - Electrical power steering	Data stream	
448	As of 2004	ESP - Electrical stability program	Sys. Info.	
448	As of 2004	ESP - Electrical stability program	Read code	
448	As of 2004	ESP - Electrical stability program	Clear code	
448	As of 2004	ESP - Electrical stability program	Data stream	
448	As of 2004	AAG - Trailer recognition	Sys. Info.	
448	As of 2004	AAG - Trailer recognition	Read code	
448	As of 2004	AAG - Trailer recognition	Clear code	
448	As of 2004	AAG - Trailer recognition	Data stream	
448	As of 2004	ATA - Anti-theft alarm system	Sys. Info.	
448	As of 2004	ATA - Anti-theft alarm system	Read code	
448	As of 2004	ATA - Anti-theft alarm system	Clear code	
448	As of 2004	ATA - Anti-theft alarm system	Data stream	
448	As of 2004	EZS - Electronic ignition lock	Sys. Info.	
448	As of 2004	EZS - Electronic ignition lock	Read code	
448	As of 2004	EZS - Electronic ignition lock	Clear code	
448	As of 2004	EZS - Electronic ignition lock	Data stream	
448	As of 2004	OCP - Overhead control panel	Sys. Info.	
448	As of 2004	OCP - Overhead control panel	Read code	
448	As of 2004	OCP - Overhead control panel	Clear code	
448	As of 2004	OCP - Overhead control panel	Data stream	
448	As of 2004	PSM-Parameterizable special module	Sys. Info.	
448	As of 2004	PSM-Parameterizable special module	Read code	
448	As of 2004	PSM-Parameterizable special module	Clear code	
448	As of 2004	PSM-Parameterizable special module	Data stream	
448	As of 2004	SCM - Steering column module	Sys. Info.	
448	As of 2004	SCM - Steering column module	Read code	
448	As of 2004	SCM - Steering column module	Clear code	
448	As of 2004	SCM - Steering column module	Data stream	

model	year	system	function	subfunction
448	As of 2004	SRS - Supplemental restraint system	Sys. Info.	
448	As of 2004	SRS - Supplemental restraint system	Read code	
448	As of 2004	SRS - Supplemental restraint system	Clear code	
448	As of 2004	SRS - Supplemental restraint system	Data stream	
448	As of 2004	RevETR - LF - Left front reversible emergency tensioning retractor	Sys. Info.	
448	As of 2004	RevETR - LF - Left front reversible emergency tensioning retractor	Read code	
448	As of 2004	RevETR - LF - Left front reversible emergency tensioning retractor	Clear code	
448	As of 2004	RevETR - LF - Left front reversible emergency tensioning retractor	Data stream	
448	As of 2004	emergency tensioning retractor	Sys. Info.	
448	As of 2004	emergency tensioning retractor	Read code	
448	As of 2004	emergency tensioning retractor	Clear code	
448	As of 2004	emergency tensioning retractor	Data stream	
448	As of 2004	module	Sys. Info.	
448	As of 2004	module	Read code	
448	As of 2004	module	Clear code	
448	As of 2004	module	Data stream	
448	As of 2004	SG - LEDSW-L - Left headlamp	Sys. Info.	
448	As of 2004	SG - LEDSW-L - Left headlamp	Read code	
448	As of 2004	SG - LEDSW-L - Left headlamp	Clear code	
448	As of 2004	SG - LEDSW-L - Left headlamp	Data stream	
448	As of 2004	SG - LEDSW-R - Right headlamp	Sys. Info.	
448	As of 2004	SG - LEDSW-R - Right headlamp	Read code	
448	As of 2004	SG - LEDSW-R - Right headlamp	Clear code	
448	As of 2004	SG - LEDSW-R - Right headlamp	Data stream	
448	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Sys. Info.	
448	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Read code	
448	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Clear code	
448	As of 2004	CDI - Motor electronics CR41R for combustion engine OM622	Data stream	
448	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Sys. Info.	
448	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Read code	
448	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Clear code	
448	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Data stream	
448	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Actuation	
448	As of 2004	CDI - Motor electronics CR41 for combustion engine OM651	Special Functions	Teach-in processes
448	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Sys. Info.	
448	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Read code	
448	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Clear code	

model	year	system	function	subfunction
448	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Actuation	
448	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Special Functions	Teach-in processes
448	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Sys. Info.	
448	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Read code	
448	As of 2004	ME - Motor electronics MED40 for combustion engine M274	Clear code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	AB-Airbag	Sys. Info.	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	AB-Airbag	Read code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	AB-Airbag	Clear code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ABS-Anti-lock braking system	Sys. Info.	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ABS-Anti-lock braking system	Read code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ABS-Anti-lock braking system	Clear code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ABS-Anti-lock braking system	Data stream	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ABS-Anti-lock braking system	Actuation	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Sys. Info.	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Read code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Clear code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Data stream	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Actuation	

model	year	system	function	subfunction
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Vehicle data
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Vehicle model
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Tire size
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Tire condition
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Components
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	CD changer
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Bose sound system
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Traffic data memory
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Audio parameters
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Speed-responsive volume adaptation
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Volume adaptation for traffic program
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Anti-theft diode
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	APS-Auto pilot system	Special Functions	Afterrunning
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ATA - Anti-theft alarm system	Sys. Info.	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ATA - Anti-theft alarm system	Read code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ATA - Anti-theft alarm system	Clear code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ATA - Anti-theft alarm system	Data stream	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ATA - Anti-theft alarm system	Actuation	

model	year	system	function	subfunction
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ATA - Anti-theft alarm system	Special Functions	Parameterization
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ATA - Anti-theft alarm system	Special Functions	Parameterizing battery horn
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ATA - Anti-theft alarm system	Special Functions	Netherlands (as per SCM)
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ATA - Anti-theft alarm system	Special Functions	Standard
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ERE、EVE、ASF	Sys. Info.	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ERE、EVE、ASF	Read code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ERE、EVE、ASF	Clear code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ERE、EVE、ASF	Data stream	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ERE、EVE、ASF	Actuation	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	ERE、EVE、ASF	Special Functions	Identification
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	HZR-heating control	Sys. Info.	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	HZR-heating control	Read code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	HZR-heating control	Clear code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	HZR-heating control	Data stream	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	HZR-heating control	Actuation	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	HZR-heating control	Special Functions	Parameterization
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	HZR-heating control	Special Functions	Equipment version
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	HZR-heating control	Special Functions	Engine versions

model	year	system	function	subfunction
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	HZR-heating control	Special Functions	Temperature unit
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	HZR-heating control	Special Functions	Fault recognition
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	WSP-immobilizer	Sys. Info.	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	WSP-immobilizer	Read code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	WSP-immobilizer	Clear code	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	WSP-immobilizer	Data stream	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	WSP-immobilizer	Actuation	
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	WSP-immobilizer	Special Functions	Programming / deleting keys
901.0/3/4 902.0/3/4 903.0/3/4 904.0/3/4	As of 2004	WSP-immobilizer	Special Functions	Programming a new key
902.0/3/4 903.0/3/4	As of 2004	WSP-immobilizer	Special Functions	Deleting all keys and programming keys (when key is lost)
902.0/3/4 903.0/3/4	As of 2004	WSP-immobilizer	Special Functions	Parameterization
902.0/3/4 903.0/3/4	As of 2004	WSP-immobilizer	Special Functions	Deactivating/activating keys
902.0/3/4 903.0/3/4	As of 2004	ZHE-heater booster	Sys. Info.	
902.0/3/4 903.0/3/4	As of 2004	ZHE-heater booster	Read code	
902.0/3/4 903.0/3/4	As of 2004	ZHE-heater booster	Clear code	
902.0/3/4 903.0/3/4	As of 2004	ZHE-heater booster	Data stream	
902.0/3/4 903.0/3/4	As of 2004	ZHE-heater booster	Actuation	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	AB-Airbag	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	AB-Airbag	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	AB-Airbag	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABS-Anti-lock braking system	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABS-Anti-lock braking system	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABS-Anti-lock braking system	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABS-Anti-lock braking system	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABS-Anti-lock braking system	Special Functions	Parameterization
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABW-Airbag with widow bag	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABW-Airbag with widow bag	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABW-Airbag with widow bag	Clear code	

model	year	system	function	subfunction
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABW-Airbag with widow bag	Actuation	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABW-Airbag with widow bag	Special Functions	Parameterization
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABW-Airbag with widow bag	Special Functions	Parameterization of vehicle equipment
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ABW-Airbag with widow bag	Special Functions	Parameterization of crash parameter set
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	APS Auto pilot system	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	APS Auto pilot system	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	APS Auto pilot system	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	APS Auto pilot system	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	APS Auto pilot system	Actuation	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	APS Auto pilot system	Special Functions	Parameterization
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	APS Auto pilot system	Special Functions	Parameterization of vehicle components
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	APS Auto pilot system	Special Functions	Parameterization of vehicle data
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	APS Auto pilot system	Special Functions	Parameterizing of audio data
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	APS Auto pilot system	Special Functions	Control unit replacement
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ARS All-wheel system	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ARS All-wheel system	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ARS All-wheel system	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ARS All-wheel system	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ARS All-wheel system	Actuation	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Special Functions	Injector classification
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Special Functions	Change to injector classificationclassification
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Special Functions	Initialization of injector calssification
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Special Functions	Activate control module CDI
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Special Functions	Other parameterization
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Special Functions	Maximum vehicle speed limit
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CDI-common rail	Special Functions	Tire size
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CR-common rail	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CR-common rail	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CR-common rail	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CR-common rail	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CR-common rail	Special Functions	Interlock control module.
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CR-common rail	Special Functions	Injector classification
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	CR-common rail	Special Functions	Maximum vehicle speed limit(HGB)

model	year	system	function	subfunction
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Actuation	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Special Functions	Automatic control module replacement
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Special Functions	Parameterization of control module functions
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Special Functions	Version
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Special Functions	Audible alarm system
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Special Functions	Analyzed inputs
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Special Functions	Number of repeat alarms activated by interior sensors
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Special Functions	Panic alarm output
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Special Functions	Body
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Special Functions	Vehicle wheelbase
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EDW 2 anti-theft alarm	Special Functions	Permissible gross weight
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EGS electronic transmission control	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EGS electronic transmission control	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EGS electronic transmission control	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EGS electronic transmission control	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EGS electronic transmission control	Special Functions	Automatic control module replacement
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EGS electronic transmission control	Special Functions	Teach-in of transmission (Adaptation)
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EGS electronic transmission control	Special Functions	Resetting of adaptation data
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Special Functions	Parameterization
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Special Functions	Right-hand steering
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Special Functions	Model designation
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Special Functions	Wheelbase
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Special Functions	Retarder
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Special Functions	Automatic control module replacement
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ESP Electronic Stability Program	Special Functions	Calibration of steering angle sensor
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EWM electronic selector lever module	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EWM electronic selector lever module	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EWM electronic selector lever module	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	EWM electronic selector lever module	Data stream	

model	year	system	function	subfunction
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	HZR heating control	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	HZR heating control	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	HZR heating control	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	HZR heating control	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	HZR heating control	Actuation	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	HZR heating control	Special Functions	Size of passenger compartment
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	HZR heating control	Special Functions	Engine version
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	KI-Instrument cluster	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	KI-Instrument cluster	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	KI-Instrument cluster	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	KI-Instrument cluster	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	KI-Instrument cluster	Special Functions	ASSYST Active Service System
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	LPG Liquefied Petroleum Gas	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	LPG Liquefied Petroleum Gas	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	LPG Liquefied Petroleum Gas	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	LPG Liquefied Petroleum Gas	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	LPG Liquefied Petroleum Gas	Special Functions	Automatic control module replacement
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Variant coding
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Pollutant standard
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Air conditioning
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Tire size
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Automatic control module replacement
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Manual replacement of control module
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Interlock control module.
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Correction programming
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Ignition RON (research octane number)
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Fuel quantity
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	CO setting for vehicles without TWC
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Desensibilize shutoff threshold of smooth engine running.
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ME-Motor electronics	Special Functions	Maximum vehicle speed limit(HGB)
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	RFH backup assist	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	RFH backup assist	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	RFH backup assist	Clear code	

model	year	system	function	subfunction
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	RFH backup assist	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	RFH backup assist	Actuation	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	RFH backup assist	Special Functions	Control unit adaptation
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SCR Control unit AdBlue	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SCR Control unit AdBlue	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SCR Control unit AdBlue	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SCR Control unit AdBlue	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SCR Control unit AdBlue	Actuation	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Actuation	Pressure reduction
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Actuation	Move transmission into 'emergency neutral' position
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Special Functions	Learn gears
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Special Functions	Learn clutch
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Special Functions	Learning process for clutch closing point
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Special Functions	Learning process for clutch grip point
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	SSG Sprintshift transmission	Special Functions	Learning process for clutch transmission index
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	WSP-Immobilizer	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	WSP-Immobilizer	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	WSP-Immobilizer	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	WSP-Immobilizer	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	WSP-Immobilizer	Special Functions	Learn transponder key
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	WSP-Immobilizer	Special Functions	Learn additional transponder key
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	WSP-Immobilizer	Special Functions	Erase all the transponder keys and relearn the current one
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE auxiliary heater	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE auxiliary heater	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE auxiliary heater	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE auxiliary heater	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE auxiliary heater	Actuation	Filling lines for initial startup
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE auxiliary heater	Actuation	Glow pin
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE auxiliary heater	Actuation	Blower motor
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE auxiliary heater	Actuation	Circulation pump
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE auxiliary heater	Actuation	Front end blower
904.6 905.6 690.6	As of 2004	ZUH	Sys. Info.	
904.6 905.6 690.6	As of 2004	ZUH	Read code	
904.6 905.6 690.6	As of 2004	ZUH	Clear code	
904.6 905.6 690.6	As of 2004	ZUH	Data stream	

model	year	system	function	subfunction
904.6 905.6 690.6	As of 2004	ZUH	Actuation	Filling lines for initial startup
904.6 905.6 690.7	As of 2004	ZUH	Actuation	Glow pin
904.6 905.6 690.8	As of 2004	ZUH	Actuation	Blower motor
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE-L auxiliary heater warm air	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE-L auxiliary heater warm air	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE-L auxiliary heater warm air	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZHE-L auxiliary heater warm air	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Sys. Info.	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Read code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Clear code	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Data stream	
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Parameterization of doors
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Drivers door
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Passenger door
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Left side door
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Right side door
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Tailgate
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Control module functions:Other body
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Unlocking of doors
901.6 902.6 903.6 904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Locking of vehicle when a door already locked is closed
904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Automatic locking of doors which are still open
904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Locking in the case of opened doors
904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Automatic locking by means of V signal
904.6 905.6 690.6	As of 2004	ZV central locking system	Special Functions	Reset control module functions to standard settings
Citan 415	As of 2004	(SRS))	Sys. Info.	
Citan 415	As of 2004	(SRS))	Clear code	
Citan 415	As of 2004	(SRS))	Read code	
Citan 415	As of 2004	(SRS))	Clear code	
Citan 415	As of 2004	N62 (Parktronic system (PTS))	Sys. Info.	
Citan 415	As of 2004	N62 (Parktronic system (PTS))	Clear code	
Citan 415	As of 2004	N62 (Parktronic system (PTS))	Read code	
Citan 415	As of 2004	N62 (Parktronic system (PTS))	Clear code	
Citan 415	As of 2004	Fuse and relay modules	Sys. Info.	
Citan 415	As of 2004	Fuse and relay modules	Clear code	
Citan 415	As of 2004	Fuse and relay modules	Read code	
Citan 415	As of 2004	Fuse and relay modules	Clear code	
Citan 415	As of 2004	N88/1 (Tire pressure monitor (TPM [RDK]) control unit	Sys. Info.	
Citan 415	As of 2004	N88/1 (Tire pressure monitor (TPM [RDK]) control unit	Clear code	
Citan 415	As of 2004	N88/1 (Tire pressure monitor (TPM [RDK]) control unit	Read code	
Citan 415	As of 2004	N88/1 (Tire pressure monitor (TPM [RDK]) control unit	Clear code	
Citan 415	As of 2004	N68 (Electrical power steering (ES) control unit)	Sys. Info.	
Citan 415	As of 2004	N68 (Electrical power steering (ES) control unit)	Clear code	

model	year	system	function	subfunction
Citan 415	As of 2004	N68 (Electrical power steering (ES) control unit)	Read code	
Citan 415	As of 2004	N68 (Electrical power steering (ES) control unit)	Clear code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO1/MO2)	Sys. Info.	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO1/MO2)	Clear code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO1/MO2)	Read code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO1/MO2)	Clear code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO3)	Sys. Info.	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO3)	Clear code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO3)	Read code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO3)	Clear code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO1/MO2+MB6)	Sys. Info.	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO1/MO2+MB6)	Clear code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO1/MO2+MB6)	Read code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO1/MO2+MB6)	Clear code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO3+MB6)	Sys. Info.	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO3+MB6)	Clear code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO3+MB6)	Read code	
Citan 415	As of 2004	CDI-for combustion engine .OM607.(Code:MO3+MB6)	Clear code	
Citan 415	As of 2004	.M200.(Code:MO4)	Sys. Info.	
Citan 415	As of 2004	.M200.(Code:MO4)	Clear code	
Citan 415	As of 2004	.M200.(Code:MO4)	Read code	
Citan 415	As of 2004	.M200.(Code:MO4)	Clear code	
Citan 415	As of 2004	ME-for combustion engine .M200.(Code:MO4+MB6)	Sys. Info.	
Citan 415	As of 2004	ME-for combustion engine .M200.(Code:MO4+MB6)	Clear code	
Citan 415	As of 2004	ME-for combustion engine .M200.(Code:MO4+MB6)	Read code	
Citan 415	As of 2004	ME-for combustion engine .M200.(Code:MO4+MB6)	Clear code	
Citan 415	As of 2004	AAC - Air conditioning	Sys. Info.	
Citan 415	As of 2004	AAC - Air conditioning	Clear code	
Citan 415	As of 2004	AAC - Air conditioning	Read code	
Citan 415	As of 2004	AAC - Air conditioning	Clear code	
Citan 415	As of 2004	DKG-Electronic transmission control for double-plate clutch transmission	Sys. Info.	
Citan 415	As of 2004	DKG-Electronic transmission control for double-plate clutch transmission	Clear code	
Citan 415	As of 2004	DKG-Electronic transmission control for double-plate clutch transmission	Read code	
Citan 415	As of 2004	DKG-Electronic transmission control for double-plate clutch transmission	Clear code	
Citan 415	As of 2004	(ESP))	Sys. Info.	
Citan 415	As of 2004	(ESP))	Clear code	
Citan 415	As of 2004	(ESP))	Read code	
Citan 415	As of 2004	(ESP))	Clear code	
Citan 415	As of 2004	N10 (Signal acquisition and actuation module (SAM))	Sys. Info.	
Citan 415	As of 2004	N10 (Signal acquisition and actuation module (SAM))	Clear code	
Citan 415	As of 2004	N10 (Signal acquisition and actuation module (SAM))	Read code	

model	year	system	function	subfunction
Citan 415	As of 2004	N10 (Signal acquisition and actuation module (SAM))	Clear code	
Citan 415	As of 2004	IC - instrument cluster	Sys. Info.	
Citan 415	As of 2004	IC - instrument cluster	Clear code	
Citan 415	As of 2004	IC - instrument cluster	Read code	
Citan 415	As of 2004	IC - instrument cluster	Clear code	
SPRINTER III	As of 2014	mrm - steering column module	Sys. Info.	
SPRINTER III	As of 2014	mrm - steering column module	Read code	
SPRINTER III	As of 2014	mrm - steering column module	Clear code	
SPRINTER III	As of 2014	ahc trailer recognition	Sys. Info.	
SPRINTER III	As of 2014	ahc trailer recognition	Read code	
SPRINTER III	As of 2014	ahc trailer recognition	Clear code	
SPRINTER III	As of 2014	cng compressed natural gas	Sys. Info.	
SPRINTER III	As of 2014	cng compressed natural gas	Read code	
SPRINTER III	As of 2014	cng compressed natural gas	Clear code	
SPRINTER III	As of 2014	n15/3 (electronic transmission control (etc [egs]))	Sys. Info.	
SPRINTER III	As of 2014	n15/3 (electronic transmission control (etc [egs]))	Read code	
SPRINTER III	As of 2014	n15/3 (electronic transmission control (etc [egs]))	Clear code	
SPRINTER III	As of 2014	n62 (parktronic system (pts))	Sys. Info.	
SPRINTER III	As of 2014	n62 (parktronic system (pts))	Read code	
SPRINTER III	As of 2014	n62 (parktronic system (pts))	Clear code	
SPRINTER III	As of 2014	irs	Sys. Info.	
SPRINTER III	As of 2014	irs	Read code	
SPRINTER III	As of 2014	irs	Clear code	
SPRINTER III	As of 2014	motor control module	Sys. Info.	
SPRINTER III	As of 2014	motor control module	Read code	
SPRINTER III	As of 2014	motor control module	Clear code	
SPRINTER III	As of 2014	motor control module	Special Functions	Teach-in of diesel particulate filter after replacement of control unit CDI
SPRINTER III	As of 2014	motor control module	Special Functions	Teach in diesel particulate filter again.
SPRINTER III	As of 2014	motor control module	Special Functions	Throttle valve
SPRINTER III	As of 2014	motor control module	Special Functions	Position sensor of camshaft
SPRINTER III	As of 2014	motor control module	Special Functions	Position sensor of crankshaft
SPRINTER III	As of 2014	motor control module	Special Functions	Diesel particulate filter /Oxidation catalytic converter NEW
SPRINTER III	As of 2014	motor control module	Special Functions	Diesel particulate filter /Oxidation catalytic converter OLD
SPRINTER III	As of 2014	motor control module	Special Functions	Reset of lambda values
SPRINTER III	As of 2014	motor control module	Special Functions	Self-adjustment in idle speed range ENABLED
SPRINTER III	As of 2014	motor control module	Special Functions	Quick teach-in of the zero quantity calibration values at idle
SPRINTER III	As of 2014	motor control module	Special Functions	Quick teach-in of the zero quantity calibration values while driving
SPRINTER III	As of 2014	motor control module	Special Functions	Teach-in of drive authorization system
SPRINTER III	As of 2014	motor control module	Special Functions	Maximum vehicle speed limit
SPRINTER III	As of 2014	motor control module	Special Functions	Procedure for symptom The combustion engine does not start after work on the fuel injectors.
SPRINTER III	As of 2014	motor control module	Special Functions	Determine fill level of diesel particulate filter.
SPRINTER III	As of 2014	motor control module	Special Functions	Special procedure " COP "
SPRINTER III	As of 2014	motor control module	Special Functions	Rail pressure sensor
SPRINTER III	As of 2014	motor control module	Special Functions	Pressure regulator valve
SPRINTER III	As of 2014	motor control module	Special Functions	Air filter
SPRINTER III	As of 2014	motor control module	Special Functions	Hot film mass air flow sensor
SPRINTER III	As of 2014	motor control module	Special Functions	Oxygen sensor
SPRINTER III	As of 2014	motor control module	Special Functions	Exhaust gas recirculation valve
SPRINTER III	As of 2014	motor control module	Special Functions	Differential pressure sensor of diesel particular filter
SPRINTER III	As of 2014	motor control module	Special Functions	Position sensor Neutral position of transmission
SPRINTER III	As of 2014	motor control module	Special Functions	SCR catalytic converter
SPRINTER III	As of 2014	motor control module	Special Functions	NOx sensors
SPRINTER III	As of 2014	motor control module	Special Functions	Temperature sensor SCR catalytic converter
SPRINTER III	As of 2014	motor control module	Special Functions	AdBlue(R) metering valve
SPRINTER III	As of 2014	motor control module	Special Functions	Activate fuel pump.
SPRINTER III	As of 2014	motor control module	Special Functions	Resetting warning message .Number of engine starts.
SPRINTER III	As of 2014	motor control module	Special Functions	Test of exhaust aftertreatment
SPRINTER III	As of 2014	special-purpose vehicles	Sys. Info.	
SPRINTER III	As of 2014	special-purpose vehicles	Read code	
SPRINTER III	As of 2014	special-purpose vehicles	Clear code	
SPRINTER III	As of 2014	driver assistance system	Sys. Info.	
SPRINTER III	As of 2014	driver assistance system	Read code	
SPRINTER III	As of 2014	driver assistance system	Clear code	
SPRINTER III	As of 2014	n33/4 (ptc heater booster control unit)	Sys. Info.	
SPRINTER III	As of 2014	n33/4 (ptc heater booster control unit)	Read code	
SPRINTER III	As of 2014	n33/4 (ptc heater booster control unit)	Clear code	

model	year	system	function	subfunction
SPRINTER III	As of 2014	left side intelligent radar sensor system	Sys. Info.	
SPRINTER III	As of 2014	left side intelligent radar sensor system	Read code	
SPRINTER III	As of 2014	left side intelligent radar sensor system	Clear code	
SPRINTER III	As of 2014	b84/8 (multifunction camera (mfk) control unit)	Sys. Info.	
SPRINTER III	As of 2014	b84/8 (multifunction camera (mfk) control unit)	Read code	
SPRINTER III	As of 2014	b84/8 (multifunction camera (mfk) control unit)	Clear code	
SPRINTER III	As of 2014	b84/8 (multifunction camera (mfk) control unit)	Special Functions	Default- Vehicle
SPRINTER III	As of 2014	b84/8 (multifunction camera (mfk) control unit)	Special Functions	Unlock
SPRINTER III	As of 2014	b84/8 (multifunction camera (mfk) control unit)	Special Functions	Control unit reset1
SPRINTER III	As of 2014	b84/8 (multifunction camera (mfk) control unit)	Special Functions	Control unit reset2
SPRINTER III	As of 2014	tpm - tire pressure monitor	Sys. Info.	
SPRINTER III	As of 2014	tpm - tire pressure monitor	Read code	
SPRINTER III	As of 2014	tpm - tire pressure monitor	Clear code	
SPRINTER III	As of 2014	ezs - electronic ignition lock	Sys. Info.	
SPRINTER III	As of 2014	ezs - electronic ignition lock	Read code	
SPRINTER III	As of 2014	ezs - electronic ignition lock	Clear code	
SPRINTER III	As of 2014	srs - supplemental restraint system	Sys. Info.	
SPRINTER III	As of 2014	srs - supplemental restraint system	Read code	
SPRINTER III	As of 2014	srs - supplemental restraint system	Clear code	
SPRINTER III	As of 2014	rd - radio	Sys. Info.	
SPRINTER III	As of 2014	rd - radio	Read code	
SPRINTER III	As of 2014	rd - radio	Clear code	
SPRINTER III	As of 2014	sg - awf - control unit .collision prevention assist.	Sys. Info.	
SPRINTER III	As of 2014	sg - awf - control unit .collision prevention assist.	Read code	
SPRINTER III	As of 2014	sg - awf - control unit .collision prevention assist.	Clear code	
SPRINTER III	As of 2014	nav - navigation module	Sys. Info.	
SPRINTER III	As of 2014	nav - navigation module	Read code	
SPRINTER III	As of 2014	nav - navigation module	Clear code	
SPRINTER III	As of 2014	ecall russia(e-call-ru)	Sys. Info.	
SPRINTER III	As of 2014	ecall russia(e-call-ru)	Read code	
SPRINTER III	As of 2014	ecall russia(e-call-ru)	Clear code	
SPRINTER III	As of 2014	ke-keyless entry & slide	Sys. Info.	
SPRINTER III	As of 2014	ke-keyless entry & slide	Read code	
SPRINTER III	As of 2014	ke-keyless entry & slide	Clear code	
SPRINTER III	As of 2014	kla - air conditioning	Sys. Info.	
SPRINTER III	As of 2014	kla - air conditioning	Read code	
SPRINTER III	As of 2014	kla - air conditioning	Clear code	
SPRINTER III	As of 2014	kla - air conditioning	Special Functions	Teach-in of actuator motors
SPRINTER III	As of 2014	zhz - heater booster(hb)	Sys. Info.	
SPRINTER III	As of 2014	zhz - heater booster(hb)	Read code	
SPRINTER III	As of 2014	zhz - heater booster(hb)	Clear code	
SPRINTER III	As of 2014	esm - electronic selector module(ewm)	Sys. Info.	
SPRINTER III	As of 2014	esm - electronic selector module(ewm)	Read code	
SPRINTER III	As of 2014	esm - electronic selector module(ewm)	Clear code	
SPRINTER III	As of 2014	y3/8n4-fully integrated transmission control control unit(nag2)	Sys. Info.	
SPRINTER III	As of 2014	y3/8n4-fully integrated transmission control control unit(nag2)	Read code	
SPRINTER III	As of 2014	y3/8n4-fully integrated transmission control control unit(nag2)	Clear code	
SPRINTER III	As of 2014	fscu1 - fuel pump	Sys. Info.	
SPRINTER III	As of 2014	fscu1 - fuel pump	Read code	
SPRINTER III	As of 2014	fscu1 - fuel pump	Clear code	
SPRINTER III	As of 2014	fscu2 - fuel pump	Sys. Info.	
SPRINTER III	As of 2014	fscu2 - fuel pump	Read code	
SPRINTER III	As of 2014	fscu2 - fuel pump	Clear code	
SPRINTER III	As of 2014	n26/15 (parameterizable special module (psm))	Sys. Info.	
SPRINTER III	As of 2014	n26/15 (parameterizable special module (psm))	Read code	
SPRINTER III	As of 2014	n26/15 (parameterizable special module (psm))	Clear code	
SPRINTER III	As of 2014	scr selective catalytic reduction	Sys. Info.	
SPRINTER III	As of 2014	scr selective catalytic reduction	Read code	

model	year	system	function	subfunction
SPRINTER III	As of 2014	scr selective catalytic reduction	Clear code	
SPRINTER III	As of 2014	automatic transmission	Sys. Info.	
SPRINTER III	As of 2014	automatic transmission	Read code	
SPRINTER III	As of 2014	automatic transmission	Clear code	
SPRINTER III	As of 2014	ic - instrument cluster	Sys. Info.	
SPRINTER III	As of 2014	ic - instrument cluster	Read code	
SPRINTER III	As of 2014	ic - instrument cluster	Clear code	
SPRINTER III	As of 2014	esp - electronic stability program	Sys. Info.	
SPRINTER III	As of 2014	esp - electronic stability program	Read code	
SPRINTER III	As of 2014	esp - electronic stability program	Clear code	
SPRINTER III	As of 2014	sth - stationary heater	Sys. Info.	
SPRINTER III	As of 2014	sth - stationary heater	Read code	
SPRINTER III	As of 2014	sth - stationary heater	Clear code	
SPRINTER III	As of 2014	enr - electronic level control	Sys. Info.	
SPRINTER III	As of 2014	enr - electronic level control	Read code	
SPRINTER III	As of 2014	enr - electronic level control	Clear code	
SPRINTER III	As of 2014	sam - signal acquisition and actuation module	Sys. Info.	
SPRINTER III	As of 2014	sam - signal acquisition and actuation module	Read code	
SPRINTER III	As of 2014	sam - signal acquisition and actuation module	Clear code	
SPRINTER III	As of 2014	vg - transfer case	Sys. Info.	
SPRINTER III	As of 2014	vg - transfer case	Read code	
SPRINTER III	As of 2014	vg - transfer case	Clear code	
SPRINTER III	As of 2014	dbe - overhead control panel	Sys. Info.	
SPRINTER III	As of 2014	dbe - overhead control panel	Read code	
SPRINTER III	As of 2014	dbe - overhead control panel	Clear code	
SPRINTER III	As of 2014	lwr - headlamp range adjustment	Sys. Info.	
SPRINTER III	As of 2014	lwr - headlamp range adjustment	Read code	
SPRINTER III	As of 2014	lwr - headlamp range adjustment	Clear code	
SPRINTER III	As of 2014	obf - upper control panel	Sys. Info.	
SPRINTER III	As of 2014	obf - upper control panel	Read code	
SPRINTER III	As of 2014	obf - upper control panel	Clear code	
SPRINTER III	As of 2014	stl - left electric sliding door	Sys. Info.	
SPRINTER III	As of 2014	stl - left electric sliding door	Read code	
SPRINTER III	As of 2014	stl - left electric sliding door	Clear code	
SPRINTER III	As of 2014	str - right electric sliding door	Sys. Info.	
SPRINTER III	As of 2014	str - right electric sliding door	Read code	
SPRINTER III	As of 2014	str - right electric sliding door	Clear code	
SPRINTER III	As of 2014	MFK - Multifuncton camera	Sys. Info.	
SPRINTER III	As of 2014	MFK - Multifuncton camera	Read code	
SPRINTER III	As of 2014	MFK - Multifuncton camera	Clear code	
SPRINTER III	As of 2014	tsg - door control module	Sys. Info.	
SPRINTER III	As of 2014	tsg - door control module	Read code	
SPRINTER III	As of 2014	tsg - door control module	Clear code	
Sprinter(USA)	UP to 2000	ABS - Anti-lock Braking System	Sys. Info.	
Sprinter(USA)	UP to 2000	ABS - Anti-lock Braking System	Read code	
Sprinter(USA)	UP to 2000	ABS - Anti-lock Braking System	Clear code	
Sprinter(USA)	UP to 2000	CCN - Cabin Compartment Node	Sys. Info.	
Sprinter(USA)	UP to 2000	CCN - Cabin Compartment Node	Read code	
Sprinter(USA)	UP to 2000	CCN - Cabin Compartment Node	Clear code	
Sprinter(USA)	UP to 2000	DDM - Driver Door Module	Sys. Info.	
Sprinter(USA)	UP to 2000	DDM - Driver Door Module	Read code	
Sprinter(USA)	UP to 2000	DDM - Driver Door Module	Clear code	
Sprinter(USA)	UP to 2000	FCM - Front Control Module	Sys. Info.	
Sprinter(USA)	UP to 2000	FCM - Front Control Module	Read code	
Sprinter(USA)	UP to 2000	FCM - Front Control Module	Clear code	
Sprinter(USA)	UP to 2000	HVAC - Heat Ventilation & A/C	Sys. Info.	
Sprinter(USA)	UP to 2000	HVAC - Heat Ventilation & A/C	Read code	
Sprinter(USA)	UP to 2000	HVAC - Heat Ventilation & A/C	Clear code	
Sprinter(USA)	UP to 2000	OCM - Occupant Classification Module	Sys. Info.	
Sprinter(USA)	UP to 2000	OCM - Occupant Classification Module	Read code	
Sprinter(USA)	UP to 2000	OCM - Occupant Classification Module	Clear code	
Sprinter(USA)	UP to 2000	ORC - Occupant Restraint Controller	Sys. Info.	
Sprinter(USA)	UP to 2000	ORC - Occupant Restraint Controller	Read code	
Sprinter(USA)	UP to 2000	ORC - Occupant Restraint Controller	Clear code	
Sprinter(USA)	UP to 2000	PCM - Power Control Module	Sys. Info.	
Sprinter(USA)	UP to 2000	PCM - Power Control Module	Read code	
Sprinter(USA)	UP to 2000	PCM - Power Control Module	Clear code	
Sprinter(USA)	UP to 2000	TCM - Transmission Control Module	Sys. Info.	
Sprinter(USA)	UP to 2000	TCM - Transmission Control Module	Read code	
Sprinter(USA)	UP to 2000	TCM - Transmission Control Module	Clear code	
Sprinter(USA)	UP to 2000	WCM - Wireless Control Module	Sys. Info.	
Sprinter(USA)	UP to 2000	WCM - Wireless Control Module	Read code	

model	year	system	function	subfunction
Sprinter(USA)	UP to 2000	WCM - Wireless Control Module	Clear code	
Vaneo	As of 2004	AB-Airbag	Sys. Info.	
Vaneo	As of 2004	AB-Airbag	Read code	
Vaneo	As of 2004	AB-Airbag	Clear code	
Vaneo	As of 2004	AB-Airbag	Data stream	
Vaneo	As of 2004	AB-Airbag	Actuation	
Vaneo	As of 2004	AB-Airbag	Special Functions	Read coding and change if necessary.
Vaneo	As of 2004	AB-Airbag	Special Functions	Left-hand steering or right-hand steering
Vaneo	As of 2004	AB-Airbag	Special Functions	Installation recognition for front passenger seat
Vaneo	As of 2004	AB-Airbag	Special Functions	Rear emergency tensioning retractors are fitted
Vaneo	As of 2004	AB-Airbag	Special Functions	Coding of a new control module (Standard equipment)
Vaneo	As of 2004	AB-Airbag	Special Functions	Coding of a new control module (Movability)
Vaneo	As of 2004	AB-Airbag	Special Functions	Only valid for vehicles with special equipment ZY6
Vaneo	As of 2004	AB-Airbag	Special Functions	Only valid for vehicles without special equipment ZY6
Vaneo	As of 2004	AB-Airbag	Special Functions	Coded vehicle data
Vaneo	As of 2004	AB-Airbag	Special Functions	Chassis number
Vaneo	As of 2004	ACS-Automatic clutch system	Sys. Info.	
Vaneo	As of 2004	ACS-Automatic clutch system	Read code	
Vaneo	As of 2004	ACS-Automatic clutch system	Clear code	
Vaneo	As of 2004	ACS-Automatic clutch system	Data stream	
Vaneo	As of 2004	ACS-Automatic clutch system	Actuation	
Vaneo	As of 2004	ACS-Automatic clutch system	Special Functions	Bleeding
Vaneo	As of 2004	ACS-Automatic clutch system	Special Functions	AKS setting
Vaneo	As of 2004	ACS-Automatic clutch system	Special Functions	Engagement point determination
Vaneo	As of 2004	ATA - Anti-theft alarm system	Sys. Info.	
Vaneo	As of 2004	ATA - Anti-theft alarm system	Read code	
Vaneo	As of 2004	ATA - Anti-theft alarm system	Clear code	
Vaneo	As of 2004	ATA - Anti-theft alarm system	Data stream	
Vaneo	As of 2004	ATA - Anti-theft alarm system	Actuation	
Vaneo	As of 2004	ATA - Anti-theft alarm system	Special Functions	Control unit replacement
Vaneo	As of 2004	ATA - Anti-theft alarm system	Special Functions	Read coding and change if necessary.
Vaneo	As of 2004	CDI-Common Rail Diesel Injection	Sys. Info.	
Vaneo	As of 2004	CDI-Common Rail Diesel Injection	Read code	
Vaneo	As of 2004	CDI-Common Rail Diesel Injection	Clear code	
Vaneo	As of 2004	CDI-Common Rail Diesel Injection	Data stream	
Vaneo	As of 2004	CDI-Common Rail Diesel Injection	Actuation	
Vaneo	As of 2004	CDI-Common Rail Diesel Injection	Special Functions	Drive authorization : Learning process (identification)
Vaneo	As of 2004	CDI-Common Rail Diesel Injection	Special Functions	Tester identification
Vaneo	As of 2004	CDI-Common Rail Diesel Injection	Special Functions	Control unit replacement
Vaneo	As of 2004	CL - Central locking	Sys. Info.	
Vaneo	As of 2004	CL - Central locking	Read code	
Vaneo	As of 2004	CL - Central locking	Clear code	
Vaneo	As of 2004	CL - Central locking	Data stream	
Vaneo	As of 2004	CL - Central locking	Actuation	
Vaneo	As of 2004	CL - Central locking	Special Functions	Control unit replacement
Vaneo	As of 2004	CL - Central locking	Special Functions	Read coding and change if necessary
Vaneo	As of 2004	CL - Central locking	Special Functions	Doors
Vaneo	As of 2004	CL - Central locking	Special Functions	Variant coding
Vaneo	As of 2004	CL - Central locking	Special Functions	Reset overload protection counter
Vaneo	As of 2004	DAS-Drive authorization system	Sys. Info.	
Vaneo	As of 2004	DAS-Drive authorization system	Read code	
Vaneo	As of 2004	DAS-Drive authorization system	Clear code	
Vaneo	As of 2004	DAS-Drive authorization system	Data stream	
Vaneo	As of 2004	DAS-Drive authorization system	Actuation	
Vaneo	As of 2004	DAS-Drive authorization system	Special Functions	Control unit replacement
Vaneo	As of 2004	DAS-Drive authorization system	Special Functions	Inhibit or re-authorize key
Vaneo	As of 2004	DAS-Drive authorization system	Special Functions	Revocably deactivate key
Vaneo	As of 2004	DAS-Drive authorization system	Special Functions	Irrevocably deactivate key
Vaneo	As of 2004	DAS-Drive authorization system	Special Functions	Reactivate key
Vaneo	As of 2004	DAS-Drive authorization system	Special Functions	Read coding and change if necessary
Vaneo	As of 2004	ECM-Engine Control module	Sys. Info.	
Vaneo	As of 2004	ECM-Engine Control module	Read code	
Vaneo	As of 2004	ECM-Engine Control module	Clear code	
Vaneo	As of 2004	ECM-Engine Control module	Data stream	
Vaneo	As of 2004	ECM-Engine Control module	Actuation	
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Variant coding
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Read coding and change if necessary
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Drive authorization
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Coding Cruise control
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Coding according to plant data
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Default initialization
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Correction programming
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Ignition
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Fuel quantity
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Idle speed set value

model	year	system	function	subfunction
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Injection valve shutoff upon detection of combustion misfirings
Vaneo	As of 2004	ECM-Engine Control module	Special Functions	Electric suction fan for engine or air conditioning
Vaneo	As of 2004	ESM-Electronic selector module	Sys. Info.	
Vaneo	As of 2004	ESM-Electronic selector module	Read code	
Vaneo	As of 2004	ESM-Electronic selector module	Clear code	
Vaneo	As of 2004	ESM-Electronic selector module	Data stream	
Vaneo	As of 2004	ESM-Electronic selector module	Actuation	
Vaneo	As of 2004	ESP-Electronic stability program	Sys. Info.	
Vaneo	As of 2004	ESP-Electronic stability program	Read code	
Vaneo	As of 2004	ESP-Electronic stability program	Clear code	
Vaneo	As of 2004	ESP-Electronic stability program	Data stream	
Vaneo	As of 2004	ESP-Electronic stability program	Actuation	
Vaneo	As of 2004	ESP-Electronic stability program	Special Functions	Road test
Vaneo	As of 2004	FTC-Front transmission control	Sys. Info.	
Vaneo	As of 2004	FTC-Front transmission control	Read code	
Vaneo	As of 2004	FTC-Front transmission control	Clear code	
Vaneo	As of 2004	FTC-Front transmission control	Data stream	
Vaneo	As of 2004	FTC-Front transmission control	Actuation	
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Control unit replacement
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Control unit replacement:Save coding and load it into the new control module.
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Control unit replacement:Saving coding in DAS
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Control unit replacement:Transferring saved coding into new control module
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Control unit replacement:Display of all stored data
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Adaptation
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Definition
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Display adaption data.
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Resetting of adaptation data
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Performing adaptation if transmission replaced or transmission repaired
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Diagnosis routines
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Service information:Noise reduction
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Noise reduction
Vaneo	As of 2004	FTC-Front transmission control	Special Functions	Force-free in position D
Vaneo	As of 2004	IC-Instrument cluster	Sys. Info.	
Vaneo	As of 2004	IC-Instrument cluster	Read code	
Vaneo	As of 2004	IC-Instrument cluster	Clear code	
Vaneo	As of 2004	IC-Instrument cluster	Data stream	
Vaneo	As of 2004	IC-Instrument cluster	Actuation	
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Read coding and transfer to the new control unit.
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Read coding and change if necessary.
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Special equipment
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Codings specific for instrument cluster
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Instrument cluster settings
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Time
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Setting main odometer forward
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Resetting of main odometer
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Fuel tank characteristic curve
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Oil change
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	ASSYST settings
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Warning threshold in km or miles
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Warning threshold in days
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Distance driven since last oil change
Vaneo	As of 2004	IC-Instrument cluster	Special Functions	Days since last oil change
Vaneo	As of 2004	PTS-Parktronic system	Sys. Info.	
Vaneo	As of 2004	PTS-Parktronic system	Read code	
Vaneo	As of 2004	PTS-Parktronic system	Clear code	
Vaneo	As of 2004	PTS-Parktronic system	Data stream	
Vaneo	As of 2004	PTS-Parktronic system	Actuation	
Vaneo	As of 2004	PTS-Parktronic system	Special Functions	Read coding and change if necessary
Vaneo	As of 2004	STH - Stationary heater	Sys. Info.	
Vaneo	As of 2004	STH - Stationary heater	Read code	
Vaneo	As of 2004	STH - Stationary heater	Clear code	
Vaneo	As of 2004	STH - Stationary heater	Data stream	
Vaneo	As of 2004	STH - Stationary heater	Actuation	
Vaneo	As of 2004	TAC - Automatic temperature + PTC heater booster	Sys. Info.	
Vaneo	As of 2004	TAC - Automatic temperature + PTC heater booster	Read code	
Vaneo	As of 2004	TAC - Automatic temperature + PTC heater booster	Clear code	
Vaneo	As of 2004	TAC - Automatic temperature + PTC heater booster	Data stream	
Vaneo	As of 2004	TAC - Automatic temperature + PTC heater booster	Actuation	

model	year	system	function	subfunction
Vito/V - Class (38PIN)	As of 2004	AB	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	AB	Read code	
Vito/V - Class (38PIN)	As of 2004	AB	Clear code	
Vito/V - Class (38PIN)	As of 2004	AB	Data stream	
Vito/V - Class (38PIN)	As of 2004	ABS	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	ABS	Read code	
Vito/V - Class (38PIN)	As of 2004	ABS	Clear code	
Vito/V - Class (38PIN)	As of 2004	ABS	Data stream	
Vito/V - Class (38PIN)	As of 2004	ABS	Actuation	
Vito/V - Class (38PIN)	As of 2004	AGN	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	AGN	Read code	
Vito/V - Class (38PIN)	As of 2004	AGN	Clear code	
Vito/V - Class (38PIN)	As of 2004	AGN	Data stream	
Vito/V - Class (38PIN)	As of 2004	AGN	Actuation	
Vito/V - Class (38PIN)	As of 2004	APS	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	APS	Read code	
Vito/V - Class (38PIN)	As of 2004	APS	Clear code	
Vito/V - Class (38PIN)	As of 2004	APS	Data stream	
Vito/V - Class (38PIN)	As of 2004	APS	Actuation	
Vito/V - Class (38PIN)	As of 2004	ATA	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	ATA	Read code	
Vito/V - Class (38PIN)	As of 2004	ATA	Clear code	
Vito/V - Class (38PIN)	As of 2004	ATA	Data stream	
Vito/V - Class (38PIN)	As of 2004	ATA	Actuation	
Vito/V - Class (38PIN)	As of 2004	CDI	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	CDI	Read code	
Vito/V - Class (38PIN)	As of 2004	CDI	Clear code	
Vito/V - Class (38PIN)	As of 2004	CDI	Data stream	
Vito/V - Class (38PIN)	As of 2004	ERE、EVE、ASF	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	ERE、EVE、ASF	Read code	
Vito/V - Class (38PIN)	As of 2004	ERE、EVE、ASF	Clear code	
Vito/V - Class (38PIN)	As of 2004	ERE、EVE、ASF	Data stream	
Vito/V - Class (38PIN)	As of 2004	ERE、EVE、ASF	Actuation	
Vito/V - Class (38PIN)	As of 2004	HZR	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	HZR	Read code	
Vito/V - Class (38PIN)	As of 2004	HZR	Clear code	
Vito/V - Class (38PIN)	As of 2004	HZR	Data stream	

model	year	system	function	subfunction
Vito/V - Class (38PIN)	As of 2004	HZR	Actuation	
Vito/V - Class (38PIN)	As of 2004	KI	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	KI	Read code	
Vito/V - Class (38PIN)	As of 2004	KI	Clear code	
Vito/V - Class (38PIN)	As of 2004	KI	Data stream	
Vito/V - Class (38PIN)	As of 2004	KI	Actuation	
Vito/V - Class (38PIN)	As of 2004	KI	Special Functions	Oil change
Vito/V - Class (38PIN)	As of 2004	KR	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	KR	Read code	
Vito/V - Class (38PIN)	As of 2004	KR	Clear code	
Vito/V - Class (38PIN)	As of 2004	KR	Data stream	
Vito/V - Class (38PIN)	As of 2004	KR	Actuation	
Vito/V - Class (38PIN)	As of 2004	KR	Special Functions	Rear hinged door
Vito/V - Class (38PIN)	As of 2004	KR	Special Functions	Tailgate
Vito/V - Class (38PIN)	As of 2004	KR	Special Functions	Individual parameterization
Vito/V - Class (38PIN)	As of 2004	KR	Special Functions	Rear window heater cut - off delay
Vito/V - Class (38PIN)	As of 2004	KR	Special Functions	Time period between wash and wiper
Vito/V - Class (38PIN)	As of 2004	KR	Special Functions	Final wipe time from end of keyin pulse
Vito/V - Class (38PIN)	As of 2004	KR	Special Functions	Final wipe time with R function
Vito/V - Class (38PIN)	As of 2004	KR	Special Functions	Intermittent time at stage 1
Vito/V - Class (38PIN)	As of 2004	KR	Special Functions	Intermittent time at stage 2
Vito/V - Class (38PIN)	As of 2004	KR	Special Functions	Washer pump active with R function
Vito/V - Class (38PIN)	As of 2004	ME2	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	ME2	Read code	
Vito/V - Class (38PIN)	As of 2004	ME2	Clear code	
Vito/V - Class (38PIN)	As of 2004	ME2	Data stream	
Vito/V - Class (38PIN)	As of 2004	ME2	Actuation	
Vito/V - Class (38PIN)	As of 2004	V6	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	V6	Read code	
Vito/V - Class (38PIN)	As of 2004	V6	Clear code	
Vito/V - Class (38PIN)	As of 2004	V6	Data stream	
Vito/V - Class (38PIN)	As of 2004	V6	Actuation	
Vito/V - Class (38PIN)	As of 2004	WSP	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	WSP	Read code	
Vito/V - Class (38PIN)	As of 2004	WSP	Clear code	
Vito/V - Class (38PIN)	As of 2004	WSP	Data stream	
Vito/V - Class (38PIN)	As of 2004	WSP	Actuation	

model	year	system	function	subfunction
Vito/V - Class (38PIN)	As of 2004	ZHE	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	ZHE	Read code	
Vito/V - Class (38PIN)	As of 2004	ZHE	Clear code	
Vito/V - Class (38PIN)	As of 2004	ZHE	Data stream	
Vito/V - Class (38PIN)	As of 2004	ZHE	Actuation	
Vito/V - Class (38PIN)	As of 2004	ZHZ	Sys. Info.	
Vito/V - Class (38PIN)	As of 2004	ZHZ	Read code	
Vito/V - Class (38PIN)	As of 2004	ZHZ	Clear code	
Vito/V - Class (38PIN)	As of 2004	ZHZ	Data stream	
Vito/V - Class (38PIN)	As of 2004	ZHZ	Actuation	
Vito/V - Class (OBDII)	As of 2004	AB	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	AB	Read code	
Vito/V - Class (OBDII)	As of 2004	AB	Clear code	
Vito/V - Class (OBDII)	As of 2004	AB	Data stream	
Vito/V - Class (OBDII)	As of 2004	ABS	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	ABS	Read code	
Vito/V - Class (OBDII)	As of 2004	ABS	Clear code	
Vito/V - Class (OBDII)	As of 2004	ABS	Data stream	
Vito/V - Class (OBDII)	As of 2004	ABS	Actuation	
Vito/V - Class (OBDII)	As of 2004	AGN	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	AGN	Read code	
Vito/V - Class (OBDII)	As of 2004	AGN	Clear code	
Vito/V - Class (OBDII)	As of 2004	AGN	Data stream	
Vito/V - Class (OBDII)	As of 2004	AGN	Actuation	
Vito/V - Class (OBDII)	As of 2004	APS	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	APS	Read code	
Vito/V - Class (OBDII)	As of 2004	APS	Clear code	
Vito/V - Class (OBDII)	As of 2004	APS	Data stream	
Vito/V - Class (OBDII)	As of 2004	APS	Actuation	
Vito/V - Class (OBDII)	As of 2004	APS	Special Functions	Variant coding:Vehicle data
Vito/V - Class (OBDII)	As of 2004	APS	Special Functions	Vehicle model
Vito/V - Class (OBDII)	As of 2004	APS	Special Functions	Tire size
Vito/V - Class (OBDII)	As of 2004	APS	Special Functions	Tire condition
Vito/V - Class (OBDII)	As of 2004	APS	Special Functions	Variant coding:Components
Vito/V - Class (OBDII)	As of 2004	APS	Special Functions	CD changer
Vito/V - Class (OBDII)	As of 2004	APS	Special Functions	Bose sound system
Vito/V - Class (OBDII)	As of 2004	APS	Special Functions	Traffic data memory

model	year	system	function	subfunction
Vito/V - Class (OBDII)	As of 2004	ATA	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	ATA	Read code	
Vito/V - Class (OBDII)	As of 2004	ATA	Clear code	
Vito/V - Class (OBDII)	As of 2004	ATA	Data stream	
Vito/V - Class (OBDII)	As of 2004	ATA	Actuation	
Vito/V - Class (OBDII)	As of 2004	ATA	Special Functions	Parameterization
Vito/V - Class (OBDII)	As of 2004	ATA	Special Functions	Parameterizing battery horn
Vito/V - Class (OBDII)	As of 2004	CDI	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	CDI	Read code	
Vito/V - Class (OBDII)	As of 2004	CDI	Clear code	
Vito/V - Class (OBDII)	As of 2004	CDI	Data stream	
Vito/V - Class (OBDII)	As of 2004	CDI	Special Functions	Read coding and transfer to new control module
Vito/V - Class (OBDII)	As of 2004	CDI	Special Functions	Read/change coding
Vito/V - Class (OBDII)	As of 2004	CDI	Special Functions	Erase coding
Vito/V - Class (OBDII)	As of 2004	CDI	Special Functions	Identification
Vito/V - Class (OBDII)	As of 2004	HZR	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	HZR	Read code	
Vito/V - Class (OBDII)	As of 2004	HZR	Clear code	
Vito/V - Class (OBDII)	As of 2004	HZR	Data stream	
Vito/V - Class (OBDII)	As of 2004	HZR	Actuation	
Vito/V - Class (OBDII)	As of 2004	HZR	Special Functions	Parameterization
Vito/V - Class (OBDII)	As of 2004	HZR	Special Functions	Equipment version
Vito/V - Class (OBDII)	As of 2004	HZR	Special Functions	Engine versions
Vito/V - Class (OBDII)	As of 2004	HZR	Special Functions	Temperature unit
Vito/V - Class (OBDII)	As of 2004	HZR	Special Functions	Fault recognition
Vito/V - Class (OBDII)	As of 2004	KI	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	KI	Read code	
Vito/V - Class (OBDII)	As of 2004	KI	Clear code	
Vito/V - Class (OBDII)	As of 2004	KI	Data stream	
Vito/V - Class (OBDII)	As of 2004	KI	Actuation	
Vito/V - Class (OBDII)	As of 2004	KI	Special Functions	Oil change
Vito/V - Class (OBDII)	As of 2004	KR	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	KR	Read code	
Vito/V - Class (OBDII)	As of 2004	KR	Clear code	
Vito/V - Class (OBDII)	As of 2004	KR	Data stream	
Vito/V - Class (OBDII)	As of 2004	KR	Actuation	
Vito/V - Class (OBDII)	As of 2004	KR	Special Functions	Rear hinged door

model	year	system	function	subfunction
Vito/V - Class (OBDII)	As of 2004	KR	Special Functions	Tailgate
Vito/V - Class (OBDII)	As of 2004	KR	Special Functions	Individual parameterization
Vito/V - Class (OBDII)	As of 2004	KR	Special Functions	Rear window heater cut - off delay
Vito/V - Class (OBDII)	As of 2004	KR	Special Functions	Time period between wash and wiper
Vito/V - Class (OBDII)	As of 2004	KR	Special Functions	Final wipe time from end of keyin pulse
Vito/V - Class (OBDII)	As of 2004	KR	Special Functions	Final wipe time with R function
Vito/V - Class (OBDII)	As of 2004	KR	Special Functions	Intermittent time at stage 1
Vito/V - Class (OBDII)	As of 2004	KR	Special Functions	Intermittent time at stage 2
Vito/V - Class (OBDII)	As of 2004	KR	Special Functions	Washer pump active with R function
Vito/V - Class (OBDII)	As of 2004	ME2	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	ME2	Read code	
Vito/V - Class (OBDII)	As of 2004	ME2	Clear code	
Vito/V - Class (OBDII)	As of 2004	ME2	Data stream	
Vito/V - Class (OBDII)	As of 2004	ME2	Actuation	
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Version coding
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Erase coding
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Carry out identification without coding
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Correction program
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Ignition
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Fuel quantity
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Time lag
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	CO setting for models without TWC
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Electric induction fan Engine/Air conditioning
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Self-adaptation
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Boot strapping
Vito/V - Class (OBDII)	As of 2004	ME2	Special Functions	Reset sensor rotor adaptation
Vito/V - Class (OBDII)	As of 2004	V6	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	V6	Read code	
Vito/V - Class (OBDII)	As of 2004	V6	Clear code	
Vito/V - Class (OBDII)	As of 2004	V6	Data stream	
Vito/V - Class (OBDII)	As of 2004	V6	Actuation	
Vito/V - Class (OBDII)	As of 2004	WSP	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	WSP	Read code	
Vito/V - Class (OBDII)	As of 2004	WSP	Clear code	
Vito/V - Class (OBDII)	As of 2004	WSP	Data stream	
Vito/V - Class (OBDII)	As of 2004	WSP	Actuation	
Vito/V - Class (OBDII)	As of 2004	WSP	Special Functions	Parameterization

model	year	system	function	subfunction
Vito/V - Class (OBDII)	As of 2004	WSP	Special Functions	Parameterizing battery horn
Vito/V - Class (OBDII)	As of 2004	ZHE	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	ZHE	Read code	
Vito/V - Class (OBDII)	As of 2004	ZHE	Clear code	
Vito/V - Class (OBDII)	As of 2004	ZHE	Data stream	
Vito/V - Class (OBDII)	As of 2004	ZHE	Actuation	
Vito/V - Class (OBDII)	As of 2004	ZHZ	Sys. Info.	
Vito/V - Class (OBDII)	As of 2004	ZHZ	Read code	
Vito/V - Class (OBDII)	As of 2004	ZHZ	Clear code	
Vito/V - Class (OBDII)	As of 2004	ZHZ	Data stream	
Vito/V - Class (OBDII)	As of 2004	ZHZ	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	temperature control/heating-ventilation	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	temperature control/heating-ventilation	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	temperature control/heating-ventilation	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	temperature control/heating-ventilation	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	temperature control/heating-ventilation	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	temperature control/heating-ventilation	Special Functions	Normalizing of positioning motors
VITO/VIANO (CAN BUSII)	As of 2008	AAG Trailer connection unit	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	AAG Trailer connection unit	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	AAG Trailer connection unit	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	AAG Trailer connection unit	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	AAG Trailer connection unit	Actuation	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI3-4 Cylinder	Sys. Info.	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI3-4 Cylinder	Read code	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI3-4 Cylinder	Clear code	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI3-4 Cylinder	Data stream	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI3-4 Cylinder	Actuation	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI3-4 Cylinder	Special Functions	Readign coding and change if necessary.
VITO/VIANO (CAN BUSII)	Up to 2008	CDI3-4 Cylinder	Special Functions	Adjustment of injector injection quantities/ Injector shutoff
VITO/VIANO (CAN BUSII)	Up to 2008	CDI3-4 Cylinder	Special Functions	Tire circumference parameter
VITO/VIANO (CAN BUSII)	Up to 2008	CDI3-4 Cylinder	Special Functions	Maximum vehicle speed limit
VITO/VIANO (CAN BUSII)	Up to 2008	CDI3-4 Cylinder	Special Functions	Extensioin of run-on time
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Actuation	

model	year	system	function	subfunction
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Special Functions	Drive authorization
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Special Functions	Adjustment of injector injection quantities/ Injector shutoff
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Special Functions	Initialization of system Air intake, turbocharging
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Special Functions	Initialization of system Catalytic converter
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Special Functions	Initialization of system Diesel particulate filter
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Special Functions	Regeneration of diesel particulate filter when driving
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Special Functions	Tire circumference parameter
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Special Functions	Maximum vehicle speed limit
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Special Functions	Idle speed adjustment
VITO/VIANO (CAN BUSII)	As of 2008	CDI3-4 Cylinder	Special Functions	Extension of run-on time
VITO/VIANO (CAN BUSII)	Up to 2008	CDI4-4 Cylinder	Sys. Info.	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI4-4 Cylinder	Read code	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI4-4 Cylinder	Clear code	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI4-4 Cylinder	Data stream	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI4-4 Cylinder	Actuation	
VITO/VIANO (CAN BUSII)	Up to 2008	CDI4-4 Cylinder	Special Functions	Maximum vehicle speed limit
VITO/VIANO (CAN BUSII)	Up to 2008	CDI4-4 Cylinder	Special Functions	Circumference of tires
VITO/VIANO (CAN BUSII)	Up to 2008	CDI4-4 Cylinder	Special Functions	Adjustment of injector injection quantities
VITO/VIANO (CAN BUSII)	Up to 2008	CDI4-4 Cylinder	Special Functions	Initialization of system Air filter
VITO/VIANO (CAN BUSII)	Up to 2008	CDI4-4 Cylinder	Special Functions	Initialization of system Air intake turbocharging
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Special Functions	Maximum vehicle speed limit
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Special Functions	Adjustment of injector injection quantities
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Special Functions	Initialization of system Air filter
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Special Functions	Initialization of system Air intake, turbocharging
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Special Functions	Initialization of system Diesel particulate filter
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Special Functions	Teach in used diesel particulate filter.
VITO/VIANO (CAN BUSII)	As of 2008	CDI4-4 Cylinder	Special Functions	Regeneration of diesel particulate filter when driving
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Read code	
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Clear code	
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Data stream	
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Actuation	

model	year	system	function	subfunction
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Drive authorization
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Maximum vehicle speed limit
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Coding according to plant data
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Adjustment of injector injection quantities
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Initialization of system Air filter
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Initialization of system Throttle valve positioner
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Initialization of system Air intake, turbocharging
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Initialization of system Common Rail
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Initialization of system Diesel particulate filter
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Teach in used diesel particulate filter.
VITO/VIANO (CAN BUSII)	As of 2004	CDI4-6Cylinder 639	Special Functions	Regeneration of diesel particulate filter when driving
VITO/VIANO (CAN BUSII)	As of 2008	CDID2 Cylinder	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Special Functions	Activate drive authorization system
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Special Functions	Maximum vehicle speed limit
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Special Functions	Adjustment of injector injection quantities
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Special Functions	Initialization after component replacement
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Special Functions	Diesel particulate filter
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Special Functions	Zero quantity calibration
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Special Functions	Control module programming: Reset adaptation data.
VITO/VIANO (CAN BUSII)	As of 2008	CDID2-4 Cylinder	Special Functions	Write VIN.
VITO/VIANO (CAN BUSII)	As of 2008	COMMANDED	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	COMMANDED	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	COMMANDED	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FL - Door control module front left	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FL - Door control module front left	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FL - Door control module front left	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FL - Door control module front left	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FL - Door control module front left	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FL - Door control module front left	Special Functions	Parameterization of N69/1 (Left front door control unit (DCM-LF [TSG-VL])) Power window
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FR - Door control module front right	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FR - Door control module front right	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FR - Door control module front right	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FR - Door control module front right	Data stream	

model	year	system	function	subfunction
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FR - Door control module front right	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	DCM-FR - Door control module front right	Special Functions	Parameterization of N69/2 (Right front door control unit (DCM-RF [TSG-VR])) Power window
VITO/VIANO (CAN BUSII)	As of 2008	EIS - Electronic ignition switch	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	EIS - Electronic ignition switch	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	EIS - Electronic ignition switch	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	EIS - Electronic ignition switch	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	EIS - Electronic ignition switch	Special Functions	Drive authorization system(EZSESLME-SFI) - Detach transport protection.Personalizing.Activating
VITO/VIANO (CAN BUSII)	As of 2008	EIS - Electronic ignition switch	Special Functions	Options central locking
VITO/VIANO (CAN BUSII)	As of 2008	EIS - Electronic ignition switch	Special Functions	Key or key track
VITO/VIANO (CAN BUSII)	As of 2008	ENR - Electronic level control	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	ENR - Electronic level control	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	ENR - Electronic level control	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	ENR - Electronic level control	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	ENR - Electronic level control	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	ENR - Electronic level control	Special Functions	Replace control module. (Only the calibration data are transferred.)
VITO/VIANO (CAN BUSII)	As of 2008	ESA driver- Electric seat adjustment driver	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	ESA driver- Electric seat adjustment driver	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	ESA driver- Electric seat adjustment driver	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	ESA driver- Electric seat adjustment driver	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	ESA driver- Electric seat adjustment driver	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	ESA driver- Electric seat adjustment driver	Special Functions	Read coding and change if necessary.
VITO/VIANO (CAN BUSII)	As of 2008	ESA driver- Electric seat adjustment driver	Special Functions	Normalizing of forward/back adjustment
VITO/VIANO (CAN BUSII)	As of 2008	ESA passenger- Electric seat adjustment passenger	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	ESA passenger- Electric seat adjustment passenger	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	ESA passenger- Electric seat adjustment passenger	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	ESA passenger- Electric seat adjustment passenger	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	ESA passenger- Electric seat adjustment passenger	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	ESA passenger- Electric seat adjustment passenger	Special Functions	Read coding and change if necessary.
VITO/VIANO (CAN BUSII)	As of 2008	ESA passenger- Electric seat adjustment passenger	Special Functions	Normalizing of forward/back adjustment
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-L -Left electric sliding door	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-L -Left electric sliding door	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-L -Left electric sliding door	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-L -Left electric sliding door	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-L -Left electric sliding door	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-L -Left electric sliding door	Special Functions	Detection of sliding movement
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-L -Left electric sliding door	Special Functions	Denormalization
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-R -Right electric sliding door	Sys. Info.	

model	year	system	function	subfunction
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-R -Right electric sliding door	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-R -Right electric sliding door	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-R -Right electric sliding door	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-R -Right electric sliding door	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-R -Right electric sliding door	Special Functions	Detection of sliding movement
VITO/VIANO (CAN BUSII)	As of 2008	ESD [STE]-R -Right electric sliding door	Special Functions	Denormalization
VITO/VIANO (CAN BUSII)	As of 2008	ESP-Electronic stability program	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	ESP-Electronic stability program	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	ESP-Electronic stability program	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	ESP-Electronic stability program	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	ESP-Electronic stability program	Actuation	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-1 639	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-1 639	Read code	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-1 639	Clear code	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-1 639	Data stream	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-1 639	Actuation	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-1 639	Special Functions	Definition
VITO/VIANO (CAN BUSII)	As of 2004	ETC-1 639	Special Functions	Display adaption data.
VITO/VIANO (CAN BUSII)	As of 2004	ETC-1 639	Special Functions	Limit values of adaptation with additional information
VITO/VIANO (CAN BUSII)	As of 2004	ETC-1 639	Special Functions	Resetting of adaptation data
VITO/VIANO (CAN BUSII)	As of 2004	ETC-1 639	Special Functions	Performing adaptation
VITO/VIANO (CAN BUSII)	As of 2004	ETC-2 639	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-2 639	Read code	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-2 639	Clear code	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-2 639	Data stream	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-2 639	Actuation	
VITO/VIANO (CAN BUSII)	As of 2004	ETC-2 639	Special Functions	Definition
VITO/VIANO (CAN BUSII)	As of 2004	ETC-2 639	Special Functions	Important information on adaptation limit values
VITO/VIANO (CAN BUSII)	As of 2004	ETC-2 639	Special Functions	Important information on the combination possibilities for adaption end stop values
VITO/VIANO (CAN BUSII)	As of 2004	ETC-2 639	Special Functions	Display and reset of adaptation data
VITO/VIANO (CAN BUSII)	As of 2008	ETC-Electronic transmission control	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	ETC-Electronic transmission control	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	ETC-Electronic transmission control	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	ETC-Electronic transmission control	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	ETC-Electronic transmission control	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	IC - Instrument cluster	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	IC - Instrument cluster	Read code	

model	year	system	function	subfunction
VITO/VIANO (CAN BUSII)	As of 2008	IC - Instrument cluster	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	IC - Instrument cluster	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	IC - Instrument cluster	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	IC - Instrument cluster	Special Functions	Coding
VITO/VIANO (CAN BUSII)	As of 2008	IC - Instrument cluster	Special Functions	Personalizing
VITO/VIANO (CAN BUSII)	As of 2008	IC - Instrument cluster	Special Functions	Setting main odometer forward
VITO/VIANO (CAN BUSII)	As of 2008	IC - Instrument cluster	Special Functions	Oil change
VITO/VIANO (CAN BUSII)	As of 2004	IC - Instrument cluster	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2004	IC - Instrument cluster	Read code	
VITO/VIANO (CAN BUSII)	As of 2004	IC - Instrument cluster	Clear code	
VITO/VIANO (CAN BUSII)	As of 2004	IC - Instrument cluster	Data stream	
VITO/VIANO (CAN BUSII)	As of 2004	IC - Instrument cluster	Actuation	
VITO/VIANO (CAN BUSII)	As of 2004	IC - Instrument cluster	Special Functions	Personalizing
VITO/VIANO (CAN BUSII)	As of 2004	IC - Instrument cluster	Special Functions	Oil change
VITO/VIANO (CAN BUSII)	As of 2004	IC - Instrument cluster	Special Functions	Setting main odometer forward
VITO/VIANO (CAN BUSII)	As of 2004	IC - Instrument cluster	Special Functions	ASSYST Active Service System
VITO/VIANO (CAN BUSII)	As of 2008	LWR Headlamp range adjustment	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	LWR Headlamp range adjustment	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	LWR Headlamp range adjustment	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	LWR Headlamp range adjustment	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	LWR Headlamp range adjustment	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	LWR Headlamp range adjustment	Special Functions	Calibrate control unit LWR
VITO/VIANO (CAN BUSII)	As of 2004	ME97	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2004	ME97	Read code	
VITO/VIANO (CAN BUSII)	As of 2004	ME97	Clear code	
VITO/VIANO (CAN BUSII)	As of 2004	ME97	Data stream	
VITO/VIANO (CAN BUSII)	As of 2004	ME97	Special Functions	Reset adaptation values.
VITO/VIANO (CAN BUSII)	As of 2004	ME97	Special Functions	Learning of the throttle valve stop
VITO/VIANO (CAN BUSII)	As of 2008	ME-SFI-Motor electronics	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	ME-SFI-Motor electronics	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	ME-SFI-Motor electronics	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	ME-SFI-Motor electronics	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	PSM Parameterizable special module	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	PSM Parameterizable special module	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	PSM Parameterizable special module	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	PSM Parameterizable special module	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	PTC - Electric heater control	Sys. Info.	

model	year	system	function	subfunction
VITO/VIANO (CAN BUSII)	As of 2008	PTC - Electric heater control	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	PTC - Electric heater control	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	PTC - Electric heater control	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	PTS-Parktronic system	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	PTS-Parktronic system	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	PTS-Parktronic system	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	PTS-Parktronic system	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	PTS-Parktronic system	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	PTS-Parktronic system	Special Functions	Control unit replacement
VITO/VIANO (CAN BUSII)	As of 2008	PTS-Parktronic system	Special Functions	Read coding and change if necessary
VITO/VIANO (CAN BUSII)	As of 2008	SAM - Signal acquisition and actuation module	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	SAM - Signal acquisition and actuation module	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	SAM - Signal acquisition and actuation module	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	SAM - Signal acquisition and actuation module	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	SAM - Signal acquisition and actuation module	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	SDE-H - Rear sliding/tilting sunroof unit	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	SDE-H - Rear sliding/tilting sunroof unit	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	SDE-H - Rear sliding/tilting sunroof unit	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	SDE-H - Rear sliding/tilting sunroof unit	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	SDE-H - Rear sliding/tilting sunroof unit	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	SDE-H - Rear sliding/tilting sunroof unit	Special Functions	Normalizing routine / Learning process
VITO/VIANO (CAN BUSII)	As of 2008	SDE-H - Rear sliding/tilting sunroof unit	Special Functions	dapt obstruction protection
VITO/VIANO (CAN BUSII)	As of 2008	SDE-H - Rear sliding/tilting sunroof unit	Special Functions	Coding of sliding/tilting roof function of .automatic operation.
VITO/VIANO (CAN BUSII)	As of 2008	SRS - Supplemental restraint system	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	SRS - Supplemental restraint system	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	SRS - Supplemental restraint system	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	SRS - Supplemental restraint system	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	SRS - Supplemental restraint system	Actuation	
VITO/VIANO (CAN BUSII)	As of 2004	SRS 906	Read code	
VITO/VIANO (CAN BUSII)	As of 2004	SRS 906	Clear code	
VITO/VIANO (CAN BUSII)	As of 2004	SRS 906	Data stream	
VITO/VIANO (CAN BUSII)	As of 2004	SRS 906	Actuation	
VITO/VIANO (CAN BUSII)	As of 2004	SRS 906	Special Functions	Transmit key ID to control unit N2/11 (Supplemental restraint system (SRS)).
VITO/VIANO (CAN BUSII)	As of 2004	SRS 906	Special Functions	Interlock control module.
VITO/VIANO (CAN BUSII)	As of 2008	STH-Stationary heater/Heater booster	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	STH-Stationary heater/Heater booster	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	STH-Stationary heater/Heater booster	Clear code	

model	year	system	function	subfunction
VITO/VIANO (CAN BUSII)	As of 2008	STH-Stationary heater/Heater booster	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	STH-Stationary heater/Heater booster	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	TPC-Tire pressure monitor	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	TPC-Tire pressure monitor	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	TPC-Tire pressure monitor	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	TPC-Tire pressure monitor	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	TPC-Tire pressure monitor	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	TPC-Tire pressure monitor	Special Functions	Writing of specified pressure values.
VITO/VIANO (CAN BUSII)	As of 2008	UCP-Upper control panel	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	UCP-Upper control panel	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	UCP-Upper control panel	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	UCP-Upper control panel	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	UCP-Upper control panel	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	UCP-Upper control panel	Special Functions	Control unit replacement
VITO/VIANO (CAN BUSII)	As of 2008	UCP-Upper control panel	Special Functions	Read coding and change if necessary
VITO/VIANO (CAN BUSII)	As of 2008	DBE - Overhead control panel	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	DBE - Overhead control panel	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	DBE - Overhead control panel	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	DBE - Overhead control panel	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	DBE - Overhead control panel	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	REAR AC - Rear air conditioning / Rear heater	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	REAR AC - Rear air conditioning / Rear heater	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	REAR AC - Rear air conditioning / Rear heater	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	REAR AC - Rear air conditioning / Rear heater	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	REAR AC - Rear air conditioning / Rear heater	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	REAR AC - Rear air conditioning / Rear heater	Special Functions	Perform normalizing of component A32/2m3 (Rear blending air flap actuator motor)
VITO/VIANO (CAN BUSII)	As of 2008	FSE - Hands-free system (Bluetooth)	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	FSE - Hands-free system (Bluetooth)	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	FSE - Hands-free system (Bluetooth)	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	FSE - Hands-free system (Bluetooth)	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	FSE - Hands-free system (Bluetooth)	Actuation	
VITO/VIANO (CAN BUSII)	As of 2008	HU25 - COMAND or AUDIO (NTG2.5)	Sys. Info.	
VITO/VIANO (CAN BUSII)	As of 2008	HU25 - COMAND or AUDIO (NTG2.5)	Read code	
VITO/VIANO (CAN BUSII)	As of 2008	HU25 - COMAND or AUDIO (NTG2.5)	Clear code	
VITO/VIANO (CAN BUSII)	As of 2008	HU25 - COMAND or AUDIO (NTG2.5)	Data stream	
VITO/VIANO (CAN BUSII)	As of 2008	HU25 - COMAND or AUDIO (NTG2.5)	Actuation	
VITO/VIANO (OBDII)	Up to 2008	HU25 - COMAND or AUDIO (NTG2.6)	Special Functions	Retrofitting of MOST components

model	year	system	function	subfunction
VITO/VIANO (OBDII)	Up to 2008	HU25 - COMAND or AUDIO (NTG2.7)	Special Functions	Restart of optical ring
VITO/VIANO (OBDII)	Up to 2008	temperature control/heating-ventilation	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	temperature control/heating-ventilation	Read code	
VITO/VIANO (OBDII)	Up to 2008	temperature control/heating-ventilation	Clear code	
VITO/VIANO (OBDII)	Up to 2008	temperature control/heating-ventilation	Data stream	
VITO/VIANO (OBDII)	Up to 2008	temperature control/heating-ventilation	Actuation	
VITO/VIANO (OBDII)	Up to 2008	temperature control/heating-ventilation	Special Functions	Normalizing of positioning motors
VITO/VIANO (OBDII)	Up to 2008	AAG Trailer connection unit	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	AAG Trailer connection unit	Read code	
VITO/VIANO (OBDII)	Up to 2008	AAG Trailer connection unit	Clear code	
VITO/VIANO (OBDII)	Up to 2008	AAG Trailer connection unit	Data stream	
VITO/VIANO (OBDII)	Up to 2008	AAG Trailer connection unit	Actuation	
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Read code	
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Clear code	
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Data stream	
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Actuation	
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Maximum vehicle speed limit
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Circumference of tires
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Adjustment of injector injection quantities
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Initialization of system Air filter
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Initialization of system Air intake turbocharging
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Initialization of system Diesel particulate filter
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Teach in used diesel particulate filter.
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Regeneration of diesel particulate filter when driving
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Regeneration of diesel particulate filter when driving
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Initialization of system Common Rail
VITO/VIANO (OBDII)	Up to 2008	CDI4-6 Cylinder	Special Functions	Initialization of system Throttle valve positioner
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Sys. Info.	
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Read code	
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Clear code	
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Data stream	
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Actuation	
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Special Functions	Drive authorization
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Special Functions	Reading coding and change if necessary.
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Special Functions	Control unit replacement
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Special Functions	Adjustment of injector injection quantities/ Injector shutoff

model	year	system	function	subfunction
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Special Functions	Tire circumference parameter
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Special Functions	Maximum vehicle speed limit
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Special Functions	Idle speed adjustment (840 1/min)
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Special Functions	Extensio
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Special Functions	Adjustment value of start quantity
VITO/VIANO (OBDII)	As of 2004	CDI3-4 Cylinder	Special Functions	Coding according to plant data
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Sys. Info.	
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Read code	
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Clear code	
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Data stream	
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Actuation	
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Special Functions	Drive authorization
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Special Functions	Reading coding and change if necessary.
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Special Functions	Adjustment of injector injection quantities
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Special Functions	Adjustment of injector injection quantities/ Injector shutoff
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Special Functions	Initialization of system Air filter
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Special Functions	Initialization of system Air intake, turbocharging
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Special Functions	Initialization of system Common Rail
VITO/VIANO (OBDII)	As of 2004	CDI4-4 Cylinder	Special Functions	Extensio
VITO/VIANO (OBDII)	Up to 2008	DCM-FL - Door control module front left	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	DCM-FL - Door control module front left	Read code	
VITO/VIANO (OBDII)	Up to 2008	DCM-FL - Door control module front left	Clear code	
VITO/VIANO (OBDII)	Up to 2008	DCM-FL - Door control module front left	Data stream	
VITO/VIANO (OBDII)	Up to 2008	DCM-FL - Door control module front left	Actuation	
VITO/VIANO (OBDII)	Up to 2008	DCM-FL - Door control module front left	Special Functions	Parameterization of N69/1 (Left front door control unit (DCM-LF [TSG-VL])) Power window
VITO/VIANO (OBDII)	Up to 2008	DCM-FL - Door control module front left	Special Functions	Switch illumination
VITO/VIANO (OBDII)	Up to 2008	DCM-FR - Door control module front right	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	DCM-FR - Door control module front right	Read code	
VITO/VIANO (OBDII)	Up to 2008	DCM-FR - Door control module front right	Clear code	
VITO/VIANO (OBDII)	Up to 2008	DCM-FR - Door control module front right	Data stream	
VITO/VIANO (OBDII)	Up to 2008	DCM-FR - Door control module front right	Actuation	
VITO/VIANO (OBDII)	Up to 2008	DCM-FR - Door control module front right	Special Functions	Parameterization of N69/2 (Right front door control unit (DCM-RF [TSG-VR])) Power window
VITO/VIANO (OBDII)	Up to 2008	EIS-Electronic ignition switch	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	EIS-Electronic ignition switch	Read code	
VITO/VIANO (OBDII)	Up to 2008	EIS-Electronic ignition switch	Clear code	
VITO/VIANO (OBDII)	Up to 2008	EIS-Electronic ignition switch	Data stream	
VITO/VIANO (OBDII)	Up to 2008	EIS-Electronic ignition switch	Actuation	Detach transport protection. N73 (Electronic ignition switch (EIS [EZS]))

model	year	system	function	subfunction
VITO/VIANO (OBDII)	Up to 2008	EIS-Electronic ignition switch	Actuation	Detach transport protection. N26/5 (Electric steering lock)
VITO/VIANO (OBDII)	Up to 2008	EIS-Electronic ignition switch	Actuation	Personalizing N73 (Electronic ignition switch (EIS [EZS]))
VITO/VIANO (OBDII)	Up to 2008	EIS-Electronic ignition switch	Actuation	Personalizing N26/5 (Electric steering lock)
VITO/VIANO (OBDII)	Up to 2008	EIS-Electronic ignition switch	Actuation	Drive authorization system (EZS) - Detach transport protection. Personalizing. Activating
VITO/VIANO (OBDII)	Up to 2008	EIS-Electronic ignition switch	Actuation	Drive authorization system (ESL) - Detach transport protection. Personalizing. Activating
VITO/VIANO (OBDII)	Up to 2008	ENR - Electronic level control	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	ENR - Electronic level control	Read code	
VITO/VIANO (OBDII)	Up to 2008	ENR - Electronic level control	Clear code	
VITO/VIANO (OBDII)	Up to 2008	ENR - Electronic level control	Data stream	
VITO/VIANO (OBDII)	Up to 2008	ENR - Electronic level control	Actuation	
VITO/VIANO (OBDII)	Up to 2008	ENR - Electronic level control	Special Functions	Replace control module. (Only the calibration data are transferred.)
VITO/VIANO (OBDII)	Up to 2008	ENR - Electronic level control	Special Functions	Level calibration
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Read code	
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Clear code	
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Data stream	
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Actuation	
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Special Functions	Read coding and change if necessary.
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Special Functions	Normalizing of forward/back adjustment
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Special Functions	Normalizing of height adjustment at front
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Special Functions	Normalizing of height adjustment at rear
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Special Functions	Normalizing of head restraint adjustment
VITO/VIANO (OBDII)	Up to 2008	ESA driver- Electric seat adjustment driver	Special Functions	Normalizing of backrest adjustment
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Read code	
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Clear code	
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Data stream	
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Actuation	
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Special Functions	Read coding and change if necessary.
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Special Functions	Normalizing of forward/back adjustment
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Special Functions	Normalizing of height adjustment at front
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Special Functions	Normalizing of height adjustment at rear
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Special Functions	Normalizing of head restraint adjustment
VITO/VIANO (OBDII)	Up to 2008	ESA passenger- Electric seat adjustment passenger	Special Functions	Normalizing of backrest adjustment
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-L -Left electric sliding door	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-L -Left electric sliding door	Read code	
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-L -Left electric sliding door	Clear code	

model	year	system	function	subfunction
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-L -Left electric sliding door	Data stream	
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-L -Left electric sliding door	Actuation	
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-L -Left electric sliding door	Special Functions	Detection of sliding movement
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-L -Left electric sliding door	Special Functions	Denormalization
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-L -Left electric sliding door	Special Functions	Normalizing
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-R -Right electric sliding door	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-R -Right electric sliding door	Read code	
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-R -Right electric sliding door	Clear code	
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-R -Right electric sliding door	Data stream	
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-R -Right electric sliding door	Actuation	
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-R -Right electric sliding door	Special Functions	Detection of sliding movement
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-R -Right electric sliding door	Special Functions	Denormalization
VITO/VIANO (OBDII)	Up to 2008	ESD [STE]-R -Right electric sliding door	Special Functions	Normalizing
VITO/VIANO (OBDII)	Up to 2008	ESM-Electronic selector module	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	ESM-Electronic selector module	Read code	
VITO/VIANO (OBDII)	Up to 2008	ESM-Electronic selector module	Clear code	
VITO/VIANO (OBDII)	Up to 2008	ESM-Electronic selector module	Data stream	
VITO/VIANO (OBDII)	Up to 2008	ESM-Electronic selector module	Actuation	
VITO/VIANO (OBDII)	Up to 2008	ESP-Electronic stability program	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	ESP-Electronic stability program	Read code	
VITO/VIANO (OBDII)	Up to 2008	ESP-Electronic stability program	Clear code	
VITO/VIANO (OBDII)	Up to 2008	ESP-Electronic stability program	Data stream	
VITO/VIANO (OBDII)	Up to 2008	ESP-Electronic stability program	Actuation	
VITO/VIANO (OBDII)	Up to 2008	ESP-Electronic stability program	Special Functions	Component B24/8 (Steering angle sensor):Perform calibration.
VITO/VIANO (OBDII)	Up to 2008	ESP-Electronic stability program	Special Functions	Component B24/5 (Yaw rate lateral and longitudinal acceleration sensor):Perform calibration.
VITO/VIANO (OBDII)	Up to 2008	ESP-Electronic stability program	Special Functions	Start-off assist
VITO/VIANO (OBDII)	Up to 2008	ETC-Electronic transmission control	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	ETC-Electronic transmission control	Read code	
VITO/VIANO (OBDII)	Up to 2008	ETC-Electronic transmission control	Clear code	
VITO/VIANO (OBDII)	Up to 2008	ETC-Electronic transmission control	Data stream	
VITO/VIANO (OBDII)	Up to 2008	ETC-Electronic transmission control	Actuation	
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Read code	
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Clear code	
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Data stream	
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Actuation	
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Special Functions	Coding.

model	year	system	function	subfunction
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Special Functions	Personalizing.
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Special Functions	Read coding and change if necessary.
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Special Functions	ASSYST settings
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Special Functions	Learning to the dirve authorization system
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Special Functions	Setting main odometer forward and back
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Special Functions	Perform oil change
VITO/VIANO (OBDII)	Up to 2008	IC-Instrument cluster	Special Functions	Control unit replacement
VITO/VIANO (OBDII)	Up to 2013	ME 28 639	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2013	ME 28 639	Read code	
VITO/VIANO (OBDII)	Up to 2013	ME 28 639	Clear code	
VITO/VIANO (OBDII)	Up to 2013	ME 28 639	Data stream	
VITO/VIANO (OBDII)	Up to 2013	ME 28 639	Special Functions	Default initialization
VITO/VIANO (OBDII)	Up to 2013	ME 28 639	Special Functions	Correction programming
VITO/VIANO (OBDII)	Up to 2013	ME 28 639	Special Functions	Adaptation
VITO/VIANO (OBDII)	Up to 2008	ME-SFI - Motor electronics	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	ME-SFI - Motor electronics	Read code	
VITO/VIANO (OBDII)	Up to 2008	ME-SFI - Motor electronics	Clear code	
VITO/VIANO (OBDII)	Up to 2008	ME-SFI - Motor electronics	Data stream	
VITO/VIANO (OBDII)	Up to 2008	OCP-Overhead control panel	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	OCP-Overhead control panel	Read code	
VITO/VIANO (OBDII)	Up to 2008	OCP-Overhead control panel	Clear code	
VITO/VIANO (OBDII)	Up to 2008	OCP-Overhead control panel	Data stream	
VITO/VIANO (OBDII)	Up to 2008	OCP-Overhead control panel	Actuation	
VITO/VIANO (OBDII)	Up to 2008	OCP-Overhead control panel	Special Functions	Normalizing routine / Learning process
VITO/VIANO (OBDII)	Up to 2008	OCP-Overhead control panel	Special Functions	Initialization of system EDW anti-theft alarm
VITO/VIANO (OBDII)	Up to 2008	PTC - Electric heater control	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	PTC - Electric heater control	Read code	
VITO/VIANO (OBDII)	Up to 2008	PTC - Electric heater control	Clear code	
VITO/VIANO (OBDII)	Up to 2008	PTC - Electric heater control	Data stream	
VITO/VIANO (OBDII)	Up to 2008	PTS-Parktronic system	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	PTS-Parktronic system	Read code	
VITO/VIANO (OBDII)	Up to 2008	PTS-Parktronic system	Clear code	
VITO/VIANO (OBDII)	Up to 2008	PTS-Parktronic system	Data stream	
VITO/VIANO (OBDII)	Up to 2008	PTS-Parktronic system	Actuation	
VITO/VIANO (OBDII)	Up to 2008	PTS-Parktronic system	Special Functions	Control unit replacement
VITO/VIANO (OBDII)	Up to 2008	PTS-Parktronic system	Special Functions	Read coding and change if necessary
VITO/VIANO (OBDII)	Up to 2008	REAR AC-Rear air conditioning/Rear heater	Sys. Info.	

model	year	system	function	subfunction
VITO/VIANO (OBDII)	Up to 2008	REAR AC-Rear air conditioning/Rear heater	Read code	
VITO/VIANO (OBDII)	Up to 2008	REAR AC-Rear air conditioning/Rear heater	Clear code	
VITO/VIANO (OBDII)	Up to 2008	REAR AC-Rear air conditioning/Rear heater	Data stream	
VITO/VIANO (OBDII)	Up to 2008	REAR AC-Rear air conditioning/Rear heater	Actuation	
VITO/VIANO (OBDII)	Up to 2008	REAR AC-Rear air conditioning/Rear heater	Special Functions	Perform normalizing of component A32/2m3 (Rear blending air flap actuator motor)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Read code	
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Clear code	
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Data stream	
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1/6e1 (Left high beam)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1/6e2 (Left low beam)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1/6e3 (Left standing and parking lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1/6e6 (Left curve and front fog light)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1/6e5 (Left turn signal lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1/6e7 (Left daytime running light)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1e1 (High beam)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1e2 (Low beam)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1e3 (Standing and parking lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1e4 (Fog lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1e5 (Turn signal lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E1e7 (Left daytime running light)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2/6e1 (Right high beam)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2/6e2 (Right low beam)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2/6e3 (Right standing and parking lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2/6e6 (Right curve and front fog light)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2/6e5 (Right turn signal lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2/6e7 (Right daytime running light)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2e1 (High beam)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2e2 (Low beam)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2e3 (Standing and parking lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2e4 (Fog lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2e5 (Turn signal lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E2e7 (Right daytime running light)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E3e1 (Turn signal lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E3e2 (Taillamp and parking lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E3e3 (Backup lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E3e4 (Stop lamp)

model	year	system	function	subfunction
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E3e5 (Rear fog lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E4e1 (Turn signal lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E4e2 (Taillamp and parking lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E4e3 (Backup lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E4e4 (Stop lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	E4e5 (Rear fog lamp)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	Center high-mounted stop lamp
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	License plate lights
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	Blower motor in control module box
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	Rear window defroster
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	Interior lighting
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	K40/9k1 (Horn relay)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	K40/9k2 (Wiper ON/OFF relay)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	K40/9k3 (Wiper stage 2 relay)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	K40/9k7 (Circuit 15R relay)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	K40/9k8 (Circuit 15 relay)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	K40/9k7 (Circuit 15R relay)- K40/9k8 (Circuit 15 relay)- K40/9k11 (Terminal 15 relief relay)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	K40/9k9 (Heated rear window relay)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	Audible warning device
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	Switch illumination
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	M5/1 (Windshield washer fluid pump)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	M6/1 (Windshield wiper motor):STAGE 1
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	M6/1 (Windshield wiper motor):STAGE 2
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	M5/3 (Windshield washer fluid pump)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	M6/10 (Left rear-end door wiper motor)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	M6/11 (Right rear-end door wiper motor)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	M6/12 (Tailgate wiper motor)
VITO/VIANO (OBDII)	Up to 2008	SAM-Signal acquisition and actuation module	Special Functions	M5/2 (Headlamp cleaning system pump)
VITO/VIANO (OBDII)	Up to 2008	SDE-H - Rear sliding/tilting sunroof unit	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	SDE-H - Rear sliding/tilting sunroof unit	Read code	
VITO/VIANO (OBDII)	Up to 2008	SDE-H - Rear sliding/tilting sunroof unit	Clear code	
VITO/VIANO (OBDII)	Up to 2008	SDE-H - Rear sliding/tilting sunroof unit	Data stream	
VITO/VIANO (OBDII)	Up to 2008	SDE-H - Rear sliding/tilting sunroof unit	Actuation	
VITO/VIANO (OBDII)	Up to 2008	SDE-H - Rear sliding/tilting sunroof unit	Special Functions	Normalizing routine / Learning process
VITO/VIANO (OBDII)	Up to 2008	SDE-H - Rear sliding/tilting sunroof unit	Special Functions	Adapt obstruction protection.
VITO/VIANO (OBDII)	Up to 2008	SDE-H - Rear sliding/tilting sunroof unit	Special Functions	Coding of sliding/tilting roof function of automatic operation
VITO/VIANO (OBDII)	Up to 2008	SRS-Supplemental restraint system	Sys. Info.	

model	year	system	function	subfunction
VITO/VIANO (OBDII)	Up to 2008	SRS-Supplemental restraint system	Read code	
VITO/VIANO (OBDII)	Up to 2008	SRS-Supplemental restraint system	Clear code	
VITO/VIANO (OBDII)	Up to 2008	SRS-Supplemental restraint system	Data stream	
VITO/VIANO (OBDII)	Up to 2008	TPC-Tire pressure monitor	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	TPC-Tire pressure monitor	Read code	
VITO/VIANO (OBDII)	Up to 2008	TPC-Tire pressure monitor	Clear code	
VITO/VIANO (OBDII)	Up to 2008	TPC-Tire pressure monitor	Data stream	
VITO/VIANO (OBDII)	Up to 2008	TPC-Tire pressure monitor	Actuation	
VITO/VIANO (OBDII)	Up to 2008	TPC-Tire pressure monitor	Actuation	Test of component A2/108 (Left front TPM [RDK] wheel antenna)
VITO/VIANO (OBDII)	Up to 2008	TPC-Tire pressure monitor	Actuation	Test of component A2/109 (Right front TPM [RDK] wheel antenna)
VITO/VIANO (OBDII)	Up to 2008	TPC-Tire pressure monitor	Actuation	Writing of specified pressure values
VITO/VIANO (OBDII)	Up to 2008	UCP-Upper control panel	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	UCP-Upper control panel	Read code	
VITO/VIANO (OBDII)	Up to 2008	UCP-Upper control panel	Clear code	
VITO/VIANO (OBDII)	Up to 2008	UCP-Upper control panel	Data stream	
VITO/VIANO (OBDII)	Up to 2008	UCP-Upper control panel	Actuation	
VITO/VIANO (OBDII)	Up to 2008	UCP-Upper control panel	Special Functions	Control unit replacement
VITO/VIANO (OBDII)	Up to 2008	UCP-Upper control panel	Special Functions	Read coding and change if necessary
VITO/VIANO (OBDII)	Up to 2008	CGW [ZGW]	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	CGW [ZGW]	Read code	
VITO/VIANO (OBDII)	Up to 2008	CGW [ZGW]	Clear code	
VITO/VIANO (OBDII)	Up to 2008	CGW [ZGW]	Data stream	
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Read code	
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Clear code	
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Data stream	
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Cabling test of speed sensors
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Display test images on the LCD display.
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Output of test tone
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Check of volume, balance and fader settings
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Test of voice output (Navigation system)
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Test of antenna amplifier
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Radio reception measurements
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Display test images on the LCD display.
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Test of antenna amplifier
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Radio reception measurements
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Cabling test of speed sensors

model	year	system	function	subfunction
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Display test images on the LCD display.
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Output of test tone
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Check of volume, balance and fader settings
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Test of voice output(Navigation system)
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Test of antenna amplifier
VITO/VIANO (OBDII)	Up to 2008	COMAND or SOUND 50 APS	Actuation	Radio reception measurements
VITO/VIANO (OBDII)	Up to 2008	PSM - Parameterizable special module	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	PSM - Parameterizable special module	Read code	
VITO/VIANO (OBDII)	Up to 2008	PSM - Parameterizable special module	Clear code	
VITO/VIANO (OBDII)	Up to 2008	PSM - Parameterizable special module	Data stream	
VITO/VIANO (OBDII)	Up to 2008	PSM - Parameterizable special module	Actuation	Carry out control unit reset
VITO/VIANO (OBDII)	Up to 2008	PSM - Parameterizable special module	Actuation	Perform reset of control unit PSM.
VITO/VIANO (OBDII)	Up to 2008	PSM - Parameterizable special module	Actuation	PWM function test
VITO/VIANO (OBDII)	Up to 2008	PSM - Parameterizable special module	Actuation	Output 01-----Output 20
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Read code	
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Clear code	
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Data stream	
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	Switch on stationary heater (normal mode).
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	Switch on stationary heater (test mode).
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	A6m1 (Combustion air blower)
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	A6r1 (Glow pin)
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	M46/1 (Stationary heater metering pump)
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	Switch on LEDs in the control switch.
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	Canceling the overheating, fault and crash interlock
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	Switch on stationary heater (normal mode).
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	Switch on stationary heater (test mode).
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	A6m1 (Combustion air blower)
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	A6r1 (Glow pin)
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	K23/1 (Blower motor relay)
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	M13/5 (Coolant circulation pump)
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	M46/1 (Stationary heater metering pump)
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	Switch on LEDs in the control switch.
VITO/VIANO (OBDII)	Up to 2008	STH - Stationary heater	Actuation	Canceling the overheating, fault and crash interlock
VITO/VIANO (OBDII)	Up to 2008	AGW - Audio gateway	Sys. Info.	
VITO/VIANO (OBDII)	Up to 2008	AGW - Audio gateway	Read code	
VITO/VIANO (OBDII)	Up to 2008	AGW - Audio gateway	Clear code	

model	year	system	function	subfunction
VITO/VIANO (OBDII)	Up to 2008	AGW - Audio gateway	Data stream	
VITO/VIANO (OBDII)	Up to 2008	AGW - Audio gateway	Actuation	Check of wake-up line to the MOST components
VITO/VIANO (OBDII)	Up to 2008	AGW - Audio gateway	Actuation	Optical ring test
VITO/VIANO (OBDII)	Up to 2008	AGW - Audio gateway	Actuation	Check of volume, balance and fader settings
VITO/VIANO (OBDII)	Up to 2008	AGW - Audio gateway	Actuation	Retrofitting of MOST components
VITO/VIANO (OBDII)	Up to 2008	AGW - Audio gateway	Actuation	Restart of optical ring
909	Up to 2013	CR4_NFZ*1	Sys. Info.	
909	Up to 2013	CR4_NFZ*1	Read code	
909	Up to 2013	CR4_NFZ*1	Clear code	
909	Up to 2013	CR4_NFZ*1	Data stream	
909	Up to 2013	CR4_NFZ*1	Actuation	Quantity correction values of smooth-running control(Idle speed)
909	Up to 2013	CR4_NFZ*1	Actuation	Quantity correction values of smooth-running control(Engine speed (1500)Rail pressure(1500 bar))
909	Up to 2013	CR4_NFZ*1	Actuation	Test of compression
909	Up to 2013	CR4_NFZ*1	Actuation	ActuationCharge pressure positioner
909	Up to 2013	CR4_NFZ*1	Actuation	Actuation of exhaust gas recirculation
909	Up to 2013	CR4_NFZ*1	Actuation	Generator
909	Up to 2013	CR4_NFZ*1	Actuation	Fuel pump
909	Up to 2013	CR4_NFZ*1	Actuation	Throttle valve positioner
909	Up to 2013	CR4_NFZ*1	Actuation	Injector shutoff
909	Up to 2013	ZV909	Sys. Info.	
909	Up to 2013	ZV909	Read code	
909	Up to 2013	ZV909	Clear code	
909	Up to 2013	ZV909	Data stream	
909	Up to 2013	ZV909	Actuation	AllDoorsLOCK/UNLOCK
909	Up to 2013	ZV909	Actuation	LED 1 of interior pushbutton
909	Up to 2013	ZV910	Actuation	LED 2 of interior pushbutton
909	Up to 2013	E-CALL-RU	Sys. Info.	
909	Up to 2013	E-CALL-RU	Read code	
909	Up to 2013	E-CALL-RU	Clear code	
909	Up to 2013	E-CALL-RU	Data stream	
909	Up to 2013	E-CALL-RU	Actuation	Workshop mode
909	Up to 2013	E-CALL-RU	Actuation	Selftest
909	Up to 2013	E-CALL-RU	Actuation	Loudspeaker
909	Up to 2013	E-CALL-RU	Actuation	Status of LEDS
909	Up to 2013	E-CALL-RU	Actuation	Emergency call
909	Up to 2013	E-CALL-RU	Special Functions	Carry out control unit reset
909	Up to 2013	ZV909	Sys. Info.	
909	Up to 2013	ZV909	Read code	
909	Up to 2013	ZV909	Clear code	
909	Up to 2013	ZV909	Data stream	
909	Up to 2013	ZV909	Actuation	AllDoorsLOCK/UNLOCK
909	Up to 2013	ZV909	Actuation	LED 1 of interior pushbutton
909	Up to 2013	ZV910	Actuation	LED 2 of interior pushbutton
909	Up to 2013	ESP909	Sys. Info.	
909	Up to 2013	ESP909	Read code	
909	Up to 2013	ESP909	Clear code	
909	Up to 2013	ESP909	Data stream	
909	Up to 2013	ESP909	Actuation	Return pump
909	Up to 2013	ESP909	Actuation	Exceptional bleeding
909	Up to 2013	ESP909	Special Functions	Calibration of component Sensor 'Yaw rate, lateral and longitudinal acceleration'
909	Up to 2013	ESP909	Special Functions	Calibration of component B143 (Steering angle sensor)
909	Up to 2013	HZRKL909	Sys. Info.	
909	Up to 2013	HZRKL909	Read code	
909	Up to 2013	HZRKL909	Clear code	
909	Up to 2013	HZRKL909	Data stream	
909	Up to 2013	HZRKL909	Actuation	Heater booster
909	Up to 2013	HZRKL909	Actuation	Blower
909	Up to 2013	HZRKL909	Actuation	Compressor clutch
909	Up to 2013	HZRKL909	Actuation	'Recirculated air' solenoid valve
909	Up to 2013	HZRKL909	Actuation	Circulation pump
909	Up to 2013	HZRKL909	Actuation	Regulation valve 'Coolant circuit'
909	Up to 2013	HZRKL909	Actuation	Auxiliary fan
909	Up to 2013	HZRKL909	Actuation	Function test
909	Up to 2013	KI909	Sys. Info.	
909	Up to 2013	KI909	Read code	
909	Up to 2013	KI909	Clear code	
909	Up to 2013	KI909	Data stream	
909	Up to 2013	KI909	Actuation	Actuate warning buzzer.

model	year	system	function	subfunction
909	Up to 2013	KI909	Actuation	Move instrument pointer.
909	Up to 2013	KI909	Actuation	Indicator lamps
909	Up to 2013	KI909	Actuation	LCD
909	Up to 2013	KI909	Special Functions	Interlock control module
909	Up to 2013	WSP909	Sys. Info.	
909	Up to 2013	WSP909	Read code	
909	Up to 2013	WSP909	Clear code	
909	Up to 2013	WSP909	Data stream	
909	Up to 2013	SRS909	Sys. Info.	
909	Up to 2013	SRS909	Read code	
909	Up to 2013	SRS909	Clear code	
909	Up to 2013	SRS909	Data stream	
909	Up to 2013	SRS909	Actuation	Selftest of control module A10 (Airbag control unit)