

**Seat Diagnostics List**  
**(Note:For reference only)**

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza PA	2009-2016	6J	01 Engine Electronics	Read Fault Codes	
Ibiza PA	2009-2016	6J	01 Engine Electronics	Clear Fault Codes	
Ibiza PA	2009-2016	6J	01 Engine Electronics	Measuring Blocks	
Ibiza PA	2009-2016	6J	01 Engine Electronics	Output Tests	
Ibiza PA	2009-2016	6J	01 Engine Electronics	Specia Functions	
Ibiza PA	2009-2016	6J	02 Transmission Electronics	Read Fault Codes	
Ibiza PA	2009-2016	6J	02 Transmission Electronics	Clear Fault Codes	
Ibiza PA	2009-2016	6J	02 Transmission Electronics	Measuring Blocks	
Ibiza PA	2009-2016	6J	02 Transmission Electronics	Output Tests	
Ibiza PA	2009-2016	6J	02 Transmission Electronics	Specia Functions	
Ibiza PA	2009-2016	6J	03 Brake Electronics	Read Fault Codes	
Ibiza PA	2009-2016	6J	03 Brake Electronics	Clear Fault Codes	
Ibiza PA	2009-2016	6J	03 Brake Electronics	Measuring Blocks	
Ibiza PA	2009-2016	6J	03 Brake Electronics	Output Tests	
Ibiza PA	2009-2016	6J	03 Brake Electronics	Specia Functions	
Ibiza PA	2009-2016	6J	04 Steering Position	Read Fault Codes	
Ibiza PA	2009-2016	6J	04 Steering Position	Clear Fault Codes	
Ibiza PA	2009-2016	6J	04 Steering Position	Measuring Blocks	
Ibiza PA	2009-2016	6J	04 Steering Position	Output Tests	
Ibiza PA	2009-2016	6J	04 Steering Position	Specia Functions	
Ibiza PA	2009-2016	6J	08 AC/Heating Electronics	Read Fault Codes	
Ibiza PA	2009-2016	6J	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza PA	2009-2016	6J	08 AC/Heating Electronics	Measuring Blocks	
Ibiza PA	2009-2016	6J	08 AC/Heating Electronics	Output Tests	
Ibiza PA	2009-2016	6J	08 AC/Heating Electronics	Specia Functions	
Ibiza PA	2009-2016	6J	09 Electronic Ctrl Electronics	Read Fault Codes	
Ibiza PA	2009-2016	6J	09 Electronic Ctrl Electronics	Clear Fault Codes	
Ibiza PA	2009-2016	6J	09 Electronic Ctrl Electronics	Measuring Blocks	
Ibiza PA	2009-2016	6J	09 Electronic Ctrl Electronics	Output Tests	
Ibiza PA	2009-2016	6J	09 Electronic Ctrl Electronics	Specia Functions	
Ibiza PA	2009-2016	6J	10 Parking Assist System 2	Read Fault Codes	
Ibiza PA	2009-2016	6J	10 Parking Assist System 2	Clear Fault Codes	
Ibiza PA	2009-2016	6J	10 Parking Assist System 2	Measuring Blocks	
Ibiza PA	2009-2016	6J	10 Parking Assist System 2	Output Tests	
Ibiza PA	2009-2016	6J	10 Parking Assist System 2	Specia Functions	
Ibiza PA	2009-2016	6J	11 Engine Electronics 2	Read Fault Codes	
Ibiza PA	2009-2016	6J	11 Engine Electronics 2	Clear Fault Codes	
Ibiza PA	2009-2016	6J	11 Engine Electronics 2	Measuring Blocks	
Ibiza PA	2009-2016	6J	11 Engine Electronics 2	Output Tests	
Ibiza PA	2009-2016	6J	11 Engine Electronics 2	Specia Functions	
Ibiza PA	2009-2016	6J	15 Airbags	Read Fault Codes	
Ibiza PA	2009-2016	6J	15 Airbags	Clear Fault Codes	
Ibiza PA	2009-2016	6J	15 Airbags	Measuring Blocks	
Ibiza PA	2009-2016	6J	15 Airbags	Output Tests	
Ibiza PA	2009-2016	6J	15 Airbags	Specia Functions	
Ibiza PA	2009-2016	6J	17 Instrument Cluster	Read Fault Codes	
Ibiza PA	2009-2016	6J	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza PA	2009-2016	6J	17 Instrument Cluster	Measuring Blocks	
Ibiza PA	2009-2016	6J	17 Instrument Cluster	Output Tests	
Ibiza PA	2009-2016	6J	17 Instrument Cluster	Specia Functions	
Ibiza PA	2009-2016	6J	19 Gateway Data Bus	Read Fault Codes	
Ibiza PA	2009-2016	6J	19 Gateway Data Bus	Clear Fault Codes	
Ibiza PA	2009-2016	6J	19 Gateway Data Bus	Measuring Blocks	
Ibiza PA	2009-2016	6J	19 Gateway Data Bus	Output Tests	
Ibiza PA	2009-2016	6J	19 Gateway Data Bus	Specia Functions	
Ibiza PA	2009-2016	6J	25 Immobilizer	Read Fault Codes	
Ibiza PA	2009-2016	6J	25 Immobilizer	Clear Fault Codes	
Ibiza PA	2009-2016	6J	25 Immobilizer	Measuring Blocks	
Ibiza PA	2009-2016	6J	25 Immobilizer	Output Tests	
Ibiza PA	2009-2016	6J	25 Immobilizer	Specia Functions	
Ibiza PA	2009-2016	6J	2E Media Player Position 3	Read Fault Codes	
Ibiza PA	2009-2016	6J	2E Media Player Position 3	Clear Fault Codes	
Ibiza PA	2009-2016	6J	2E Media Player Position 3	Measuring Blocks	
Ibiza PA	2009-2016	6J	2E Media Player Position 3	Output Tests	
Ibiza PA	2009-2016	6J	2E Media Player Position 3	Specia Functions	
Ibiza PA	2009-2016	6J	44 Steering Assistance	Read Fault Codes	
Ibiza PA	2009-2016	6J	44 Steering Assistance	Clear Fault Codes	
Ibiza PA	2009-2016	6J	44 Steering Assistance	Measuring Blocks	
Ibiza PA	2009-2016	6J	44 Steering Assistance	Output Tests	
Ibiza PA	2009-2016	6J	44 Steering Assistance	Specia Functions	
Ibiza PA	2009-2016	6J	4B Multifunction Module	Read Fault Codes	
Ibiza PA	2009-2016	6J	4B Multifunction Module	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza PA	2009-2016	6J	4B Multifunction Module	Measuring Blocks	
Ibiza PA	2009-2016	6J	4B Multifunction Module	Output Tests	
Ibiza PA	2009-2016	6J	4B Multifunction Module	Specia Functions	
Ibiza PA	2009-2016	6J	55 Headlight Range Control	Read Fault Codes	
Ibiza PA	2009-2016	6J	55 Headlight Range Control	Clear Fault Codes	
Ibiza PA	2009-2016	6J	55 Headlight Range Control	Measuring Blocks	
Ibiza PA	2009-2016	6J	55 Headlight Range Control	Output Tests	
Ibiza PA	2009-2016	6J	55 Headlight Range Control	Specia Functions	
Ibiza PA	2009-2016	6J	56 Radio	Read Fault Codes	
Ibiza PA	2009-2016	6J	56 Radio	Clear Fault Codes	
Ibiza PA	2009-2016	6J	56 Radio	Measuring Blocks	
Ibiza PA	2009-2016	6J	56 Radio	Output Tests	
Ibiza PA	2009-2016	6J	56 Radio	Specia Functions	
Ibiza PA	2009-2016	6J	61 Battery Control	Read Fault Codes	
Ibiza PA	2009-2016	6J	61 Battery Control	Clear Fault Codes	
Ibiza PA	2009-2016	6J	61 Battery Control	Measuring Blocks	
Ibiza PA	2009-2016	6J	61 Battery Control	Output Tests	
Ibiza PA	2009-2016	6J	61 Battery Control	Specia Functions	
Ibiza PA	2009-2016	6J	69 Trailer Function	Read Fault Codes	
Ibiza PA	2009-2016	6J	69 Trailer Function	Clear Fault Codes	
Ibiza PA	2009-2016	6J	69 Trailer Function	Measuring Blocks	
Ibiza PA	2009-2016	6J	69 Trailer Function	Output Tests	
Ibiza PA	2009-2016	6J	69 Trailer Function	Specia Functions	
Ibiza PA	2009-2016	6J	77 Telephone	Read Fault Codes	
Ibiza PA	2009-2016	6J	77 Telephone	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza PA	2009-2016	6J	77 Telephone	Measuring Blocks	
Ibiza PA	2009-2016	6J	77 Telephone	Output Tests	
Ibiza PA	2009-2016	6J	77 Telephone	Specia Functions	
Toledo	2013-2018	NH	01 Engine Electronics	Read Fault Codes	
Toledo	2013-2018	NH	01 Engine Electronics	Clear Fault Codes	
Toledo	2013-2018	NH	01 Engine Electronics	Measuring Blocks	
Toledo	2013-2018	NH	01 Engine Electronics	Output Tests	
Toledo	2013-2018	NH	01 Engine Electronics	Specia Functions	
Toledo	2013-2018	NH	02 Transmission Electronics	Read Fault Codes	
Toledo	2013-2018	NH	02 Transmission Electronics	Clear Fault Codes	
Toledo	2013-2018	NH	02 Transmission Electronics	Measuring Blocks	
Toledo	2013-2018	NH	02 Transmission Electronics	Output Tests	
Toledo	2013-2018	NH	02 Transmission Electronics	Specia Functions	
Toledo	2013-2018	NH	03 Brake Electronics	Read Fault Codes	
Toledo	2013-2018	NH	03 Brake Electronics	Clear Fault Codes	
Toledo	2013-2018	NH	03 Brake Electronics	Measuring Blocks	
Toledo	2013-2018	NH	03 Brake Electronics	Output Tests	
Toledo	2013-2018	NH	03 Brake Electronics	Specia Functions	
Toledo	2013-2018	NH	04 Steering Position	Read Fault Codes	
Toledo	2013-2018	NH	04 Steering Position	Clear Fault Codes	
Toledo	2013-2018	NH	04 Steering Position	Measuring Blocks	
Toledo	2013-2018	NH	04 Steering Position	Output Tests	
Toledo	2013-2018	NH	04 Steering Position	Specia Functions	
Toledo	2013-2018	NH	08 AC/Heating Electronics	Read Fault Codes	
Toledo	2013-2018	NH	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2013-2018	NH	08 AC/Heating Electronics	Measuring Blocks	
Toledo	2013-2018	NH	08 AC/Heating Electronics	Output Tests	
Toledo	2013-2018	NH	08 AC/Heating Electronics	Specia Functions	
Toledo	2013-2018	NH	09 Electronic Ctrl Electronics	Read Fault Codes	
Toledo	2013-2018	NH	09 Electronic Ctrl Electronics	Clear Fault Codes	
Toledo	2013-2018	NH	09 Electronic Ctrl Electronics	Measuring Blocks	
Toledo	2013-2018	NH	09 Electronic Ctrl Electronics	Output Tests	
Toledo	2013-2018	NH	09 Electronic Ctrl Electronics	Specia Functions	
Toledo	2013-2018	NH	10 Parking Assist System 2	Read Fault Codes	
Toledo	2013-2018	NH	10 Parking Assist System 2	Clear Fault Codes	
Toledo	2013-2018	NH	10 Parking Assist System 2	Measuring Blocks	
Toledo	2013-2018	NH	10 Parking Assist System 2	Output Tests	
Toledo	2013-2018	NH	10 Parking Assist System 2	Specia Functions	
Toledo	2013-2018	NH	13 Distance Control	Read Fault Codes	
Toledo	2013-2018	NH	13 Distance Control	Clear Fault Codes	
Toledo	2013-2018	NH	13 Distance Control	Measuring Blocks	
Toledo	2013-2018	NH	13 Distance Control	Output Tests	
Toledo	2013-2018	NH	13 Distance Control	Specia Functions	
Toledo	2013-2018	NH	15 Airbags	Read Fault Codes	
Toledo	2013-2018	NH	15 Airbags	Clear Fault Codes	
Toledo	2013-2018	NH	15 Airbags	Measuring Blocks	
Toledo	2013-2018	NH	15 Airbags	Output Tests	
Toledo	2013-2018	NH	15 Airbags	Specia Functions	
Toledo	2013-2018	NH	17 Instrument Cluster	Read Fault Codes	
Toledo	2013-2018	NH	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2013-2018	NH	17 Instrument Cluster	Measuring Blocks	
Toledo	2013-2018	NH	17 Instrument Cluster	Output Tests	
Toledo	2013-2018	NH	17 Instrument Cluster	Specia Functions	
Toledo	2013-2018	NH	19 Gateway Data Bus	Read Fault Codes	
Toledo	2013-2018	NH	19 Gateway Data Bus	Clear Fault Codes	
Toledo	2013-2018	NH	19 Gateway Data Bus	Measuring Blocks	
Toledo	2013-2018	NH	19 Gateway Data Bus	Output Tests	
Toledo	2013-2018	NH	19 Gateway Data Bus	Specia Functions	
Toledo	2013-2018	NH	25 Immobilizer	Read Fault Codes	
Toledo	2013-2018	NH	25 Immobilizer	Clear Fault Codes	
Toledo	2013-2018	NH	25 Immobilizer	Measuring Blocks	
Toledo	2013-2018	NH	25 Immobilizer	Output Tests	
Toledo	2013-2018	NH	25 Immobilizer	Specia Functions	
Toledo	2013-2018	NH	2B Steer Col Lock	Read Fault Codes	
Toledo	2013-2018	NH	2B Steer Col Lock	Clear Fault Codes	
Toledo	2013-2018	NH	2B Steer Col Lock	Measuring Blocks	
Toledo	2013-2018	NH	2B Steer Col Lock	Output Tests	
Toledo	2013-2018	NH	2B Steer Col Lock	Specia Functions	
Toledo	2013-2018	NH	2E Media Player Position 3	Read Fault Codes	
Toledo	2013-2018	NH	2E Media Player Position 3	Clear Fault Codes	
Toledo	2013-2018	NH	2E Media Player Position 3	Measuring Blocks	
Toledo	2013-2018	NH	2E Media Player Position 3	Output Tests	
Toledo	2013-2018	NH	2E Media Player Position 3	Specia Functions	
Toledo	2013-2018	NH	37 Navigation	Read Fault Codes	
Toledo	2013-2018	NH	37 Navigation	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2013-2018	NH	37 Navigation	Measuring Blocks	
Toledo	2013-2018	NH	37 Navigation	Output Tests	
Toledo	2013-2018	NH	37 Navigation	Specia Functions	
Toledo	2013-2018	NH	44 Steering Assistance	Read Fault Codes	
Toledo	2013-2018	NH	44 Steering Assistance	Clear Fault Codes	
Toledo	2013-2018	NH	44 Steering Assistance	Measuring Blocks	
Toledo	2013-2018	NH	44 Steering Assistance	Output Tests	
Toledo	2013-2018	NH	44 Steering Assistance	Specia Functions	
Toledo	2013-2018	NH	55 Headlight Range Control	Read Fault Codes	
Toledo	2013-2018	NH	55 Headlight Range Control	Clear Fault Codes	
Toledo	2013-2018	NH	55 Headlight Range Control	Measuring Blocks	
Toledo	2013-2018	NH	55 Headlight Range Control	Output Tests	
Toledo	2013-2018	NH	55 Headlight Range Control	Specia Functions	
Toledo	2013-2018	NH	56 Radio	Read Fault Codes	
Toledo	2013-2018	NH	56 Radio	Clear Fault Codes	
Toledo	2013-2018	NH	56 Radio	Measuring Blocks	
Toledo	2013-2018	NH	56 Radio	Output Tests	
Toledo	2013-2018	NH	56 Radio	Specia Functions	
Toledo	2013-2018	NH	5F Information Electronic Equipment 1	Read Fault Codes	
Toledo	2013-2018	NH	5F Information Electronic Equipment 1	Clear Fault Codes	
Toledo	2013-2018	NH	5F Information Electronic Equipment 1	Measuring Blocks	
Toledo	2013-2018	NH	5F Information Electronic Equipment 1	Output Tests	
Toledo	2013-2018	NH	5F Information Electronic Equipment 1	Specia Functions	
Toledo	2013-2018	NH	61 Battery Control	Read Fault Codes	
Toledo	2013-2018	NH	61 Battery Control	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2013-2018	NH	61 Battery Control	Measuring Blocks	
Toledo	2013-2018	NH	61 Battery Control	Output Tests	
Toledo	2013-2018	NH	61 Battery Control	Specia Functions	
Toledo	2013-2018	NH	69 Trailer Function	Read Fault Codes	
Toledo	2013-2018	NH	69 Trailer Function	Clear Fault Codes	
Toledo	2013-2018	NH	69 Trailer Function	Measuring Blocks	
Toledo	2013-2018	NH	69 Trailer Function	Output Tests	
Toledo	2013-2018	NH	69 Trailer Function	Specia Functions	
Toledo	2013-2018	NH	76 Parking Aid	Read Fault Codes	
Toledo	2013-2018	NH	76 Parking Aid	Clear Fault Codes	
Toledo	2013-2018	NH	76 Parking Aid	Measuring Blocks	
Toledo	2013-2018	NH	76 Parking Aid	Output Tests	
Toledo	2013-2018	NH	76 Parking Aid	Specia Functions	
Toledo	2013-2018	NH	77 Telephone	Read Fault Codes	
Toledo	2013-2018	NH	77 Telephone	Clear Fault Codes	
Toledo	2013-2018	NH	77 Telephone	Measuring Blocks	
Toledo	2013-2018	NH	77 Telephone	Output Tests	
Toledo	2013-2018	NH	77 Telephone	Specia Functions	
Toledo	2013-2018	NH	B7 Access Start Interf	Read Fault Codes	
Toledo	2013-2018	NH	B7 Access Start Interf	Clear Fault Codes	
Toledo	2013-2018	NH	B7 Access Start Interf	Measuring Blocks	
Toledo	2013-2018	NH	B7 Access Start Interf	Output Tests	
Toledo	2013-2018	NH	B7 Access Start Interf	Specia Functions	
Leon NF	2013-2018	5F	01 Engine Electronics	Read Fault Codes	
Leon NF	2013-2018	5F	01 Engine Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon NF	2013-2018	5F	01 Engine Electronics	Measuring Blocks	
Leon NF	2013-2018	5F	01 Engine Electronics	Output Tests	
Leon NF	2013-2018	5F	01 Engine Electronics	Specia Functions	
Leon NF	2013-2018	5F	02 Transmission Electronics	Read Fault Codes	
Leon NF	2013-2018	5F	02 Transmission Electronics	Clear Fault Codes	
Leon NF	2013-2018	5F	02 Transmission Electronics	Measuring Blocks	
Leon NF	2013-2018	5F	02 Transmission Electronics	Output Tests	
Leon NF	2013-2018	5F	02 Transmission Electronics	Specia Functions	
Leon NF	2013-2018	5F	03 Brake Electronics	Read Fault Codes	
Leon NF	2013-2018	5F	03 Brake Electronics	Clear Fault Codes	
Leon NF	2013-2018	5F	03 Brake Electronics	Measuring Blocks	
Leon NF	2013-2018	5F	03 Brake Electronics	Output Tests	
Leon NF	2013-2018	5F	03 Brake Electronics	Specia Functions	
Leon NF	2013-2018	5F	08 AC/Heating Electronics	Read Fault Codes	
Leon NF	2013-2018	5F	08 AC/Heating Electronics	Clear Fault Codes	
Leon NF	2013-2018	5F	08 AC/Heating Electronics	Measuring Blocks	
Leon NF	2013-2018	5F	08 AC/Heating Electronics	Output Tests	
Leon NF	2013-2018	5F	08 AC/Heating Electronics	Specia Functions	
Leon NF	2013-2018	5F	09 Electronic Ctrl Electronics	Read Fault Codes	
Leon NF	2013-2018	5F	09 Electronic Ctrl Electronics	Clear Fault Codes	
Leon NF	2013-2018	5F	09 Electronic Ctrl Electronics	Measuring Blocks	
Leon NF	2013-2018	5F	09 Electronic Ctrl Electronics	Output Tests	
Leon NF	2013-2018	5F	09 Electronic Ctrl Electronics	Specia Functions	
Leon NF	2013-2018	5F	13 Distance Control	Read Fault Codes	
Leon NF	2013-2018	5F	13 Distance Control	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon NF	2013-2018	5F	13 Distance Control	Measuring Blocks	
Leon NF	2013-2018	5F	13 Distance Control	Output Tests	
Leon NF	2013-2018	5F	13 Distance Control	Specia Functions	
Leon NF	2013-2018	5F	14 Wheel Damping Electronics	Read Fault Codes	
Leon NF	2013-2018	5F	14 Wheel Damping Electronics	Clear Fault Codes	
Leon NF	2013-2018	5F	14 Wheel Damping Electronics	Measuring Blocks	
Leon NF	2013-2018	5F	14 Wheel Damping Electronics	Output Tests	
Leon NF	2013-2018	5F	14 Wheel Damping Electronics	Specia Functions	
Leon NF	2013-2018	5F	15 Airbags	Read Fault Codes	
Leon NF	2013-2018	5F	15 Airbags	Clear Fault Codes	
Leon NF	2013-2018	5F	15 Airbags	Measuring Blocks	
Leon NF	2013-2018	5F	15 Airbags	Output Tests	
Leon NF	2013-2018	5F	15 Airbags	Specia Functions	
Leon NF	2013-2018	5F	16 Steering Wheel Electronics	Read Fault Codes	
Leon NF	2013-2018	5F	16 Steering Wheel Electronics	Clear Fault Codes	
Leon NF	2013-2018	5F	16 Steering Wheel Electronics	Measuring Blocks	
Leon NF	2013-2018	5F	16 Steering Wheel Electronics	Output Tests	
Leon NF	2013-2018	5F	16 Steering Wheel Electronics	Specia Functions	
Leon NF	2013-2018	5F	17 Instrument Cluster	Read Fault Codes	
Leon NF	2013-2018	5F	17 Instrument Cluster	Clear Fault Codes	
Leon NF	2013-2018	5F	17 Instrument Cluster	Measuring Blocks	
Leon NF	2013-2018	5F	17 Instrument Cluster	Output Tests	
Leon NF	2013-2018	5F	17 Instrument Cluster	Specia Functions	
Leon NF	2013-2018	5F	19 Gateway Data Bus	Read Fault Codes	
Leon NF	2013-2018	5F	19 Gateway Data Bus	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon NF	2013-2018	5F	19 Gateway Data Bus	Measuring Blocks	
Leon NF	2013-2018	5F	19 Gateway Data Bus	Output Tests	
Leon NF	2013-2018	5F	19 Gateway Data Bus	Specia Functions	
Leon NF	2013-2018	5F	22 4WD Electronics	Read Fault Codes	
Leon NF	2013-2018	5F	22 4WD Electronics	Clear Fault Codes	
Leon NF	2013-2018	5F	22 4WD Electronics	Measuring Blocks	
Leon NF	2013-2018	5F	22 4WD Electronics	Output Tests	
Leon NF	2013-2018	5F	22 4WD Electronics	Specia Functions	
Leon NF	2013-2018	5F	2B Steer Col Lock	Read Fault Codes	
Leon NF	2013-2018	5F	2B Steer Col Lock	Clear Fault Codes	
Leon NF	2013-2018	5F	2B Steer Col Lock	Measuring Blocks	
Leon NF	2013-2018	5F	2B Steer Col Lock	Output Tests	
Leon NF	2013-2018	5F	2B Steer Col Lock	Specia Functions	
Leon NF	2013-2018	5F	32 Locking Electronisc	Read Fault Codes	
Leon NF	2013-2018	5F	32 Locking Electronisc	Clear Fault Codes	
Leon NF	2013-2018	5F	32 Locking Electronisc	Measuring Blocks	
Leon NF	2013-2018	5F	32 Locking Electronisc	Output Tests	
Leon NF	2013-2018	5F	32 Locking Electronisc	Specia Functions	
Leon NF	2013-2018	5F	3C Lane Departure Assistance System	Read Fault Codes	
Leon NF	2013-2018	5F	3C Lane Departure Assistance System	Clear Fault Codes	
Leon NF	2013-2018	5F	3C Lane Departure Assistance System	Measuring Blocks	
Leon NF	2013-2018	5F	3C Lane Departure Assistance System	Output Tests	
Leon NF	2013-2018	5F	3C Lane Departure Assistance System	Specia Functions	
Leon NF	2013-2018	5F	3D Special Function	Read Fault Codes	
Leon NF	2013-2018	5F	3D Special Function	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon NF	2013-2018	5F	3D Special Function	Measuring Blocks	
Leon NF	2013-2018	5F	3D Special Function	Output Tests	
Leon NF	2013-2018	5F	3D Special Function	Specia Functions	
Leon NF	2013-2018	5F	42 Driver-Door Elect.	Read Fault Codes	
Leon NF	2013-2018	5F	42 Driver-Door Elect.	Clear Fault Codes	
Leon NF	2013-2018	5F	42 Driver-Door Elect.	Measuring Blocks	
Leon NF	2013-2018	5F	42 Driver-Door Elect.	Output Tests	
Leon NF	2013-2018	5F	42 Driver-Door Elect.	Specia Functions	
Leon NF	2013-2018	5F	44 Steering Assistance	Read Fault Codes	
Leon NF	2013-2018	5F	44 Steering Assistance	Clear Fault Codes	
Leon NF	2013-2018	5F	44 Steering Assistance	Measuring Blocks	
Leon NF	2013-2018	5F	44 Steering Assistance	Output Tests	
Leon NF	2013-2018	5F	44 Steering Assistance	Specia Functions	
Leon NF	2013-2018	5F	52 Passe.-Door Elect.	Read Fault Codes	
Leon NF	2013-2018	5F	52 Passe.-Door Elect.	Clear Fault Codes	
Leon NF	2013-2018	5F	52 Passe.-Door Elect.	Measuring Blocks	
Leon NF	2013-2018	5F	52 Passe.-Door Elect.	Output Tests	
Leon NF	2013-2018	5F	52 Passe.-Door Elect.	Specia Functions	
Leon NF	2013-2018	5F	55 Headlight Range Control	Read Fault Codes	
Leon NF	2013-2018	5F	55 Headlight Range Control	Clear Fault Codes	
Leon NF	2013-2018	5F	55 Headlight Range Control	Measuring Blocks	
Leon NF	2013-2018	5F	55 Headlight Range Control	Output Tests	
Leon NF	2013-2018	5F	55 Headlight Range Control	Specia Functions	
Leon NF	2013-2018	5F	5F Information Electronic Equipment 1	Read Fault Codes	
Leon NF	2013-2018	5F	5F Information Electronic Equipment 1	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon NF	2013-2018	5F	5F Information Electronic Equipment 1	Measuring Blocks	
Leon NF	2013-2018	5F	5F Information Electronic Equipment 1	Output Tests	
Leon NF	2013-2018	5F	5F Information Electronic Equipment 1	Specia Functions	
Leon NF	2013-2018	5F	69 Trailer Function	Read Fault Codes	
Leon NF	2013-2018	5F	69 Trailer Function	Clear Fault Codes	
Leon NF	2013-2018	5F	69 Trailer Function	Measuring Blocks	
Leon NF	2013-2018	5F	69 Trailer Function	Output Tests	
Leon NF	2013-2018	5F	69 Trailer Function	Specia Functions	
Leon NF	2013-2018	5F	6C Rear Camera	Read Fault Codes	
Leon NF	2013-2018	5F	6C Rear Camera	Clear Fault Codes	
Leon NF	2013-2018	5F	6C Rear Camera	Measuring Blocks	
Leon NF	2013-2018	5F	6C Rear Camera	Output Tests	
Leon NF	2013-2018	5F	6C Rear Camera	Specia Functions	
Leon NF	2013-2018	5F	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Leon NF	2013-2018	5F	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Leon NF	2013-2018	5F	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Leon NF	2013-2018	5F	6D Electronic Equipment of Trunk Lid	Output Tests	
Leon NF	2013-2018	5F	6D Electronic Equipment of Trunk Lid	Specia Functions	
Leon NF	2013-2018	5F	76 Parking Aid	Read Fault Codes	
Leon NF	2013-2018	5F	76 Parking Aid	Clear Fault Codes	
Leon NF	2013-2018	5F	76 Parking Aid	Measuring Blocks	
Leon NF	2013-2018	5F	76 Parking Aid	Output Tests	
Leon NF	2013-2018	5F	76 Parking Aid	Specia Functions	
Leon NF	2013-2018	5F	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Leon NF	2013-2018	5F	A5 Frt Sens.Drv.Assist	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon NF	2013-2018	5F	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Leon NF	2013-2018	5F	A5 Frt Sens.Drv.Assist	Output Tests	
Leon NF	2013-2018	5F	A5 Frt Sens.Drv.Assist	Specia Functions	
Leon NF	2013-2018	5F	A9 Struct.Borne Sound	Read Fault Codes	
Leon NF	2013-2018	5F	A9 Struct.Borne Sound	Clear Fault Codes	
Leon NF	2013-2018	5F	A9 Struct.Borne Sound	Measuring Blocks	
Leon NF	2013-2018	5F	A9 Struct.Borne Sound	Output Tests	
Leon NF	2013-2018	5F	A9 Struct.Borne Sound	Specia Functions	
Leon NF	2013-2018	5F	B7 Access Start Interf	Read Fault Codes	
Leon NF	2013-2018	5F	B7 Access Start Interf	Clear Fault Codes	
Leon NF	2013-2018	5F	B7 Access Start Interf	Measuring Blocks	
Leon NF	2013-2018	5F	B7 Access Start Interf	Output Tests	
Leon NF	2013-2018	5F	B7 Access Start Interf	Specia Functions	
Toledo	2009-2015	1P	01 Engine Electronics	Read Fault Codes	
Toledo	2009-2015	1P	01 Engine Electronics	Clear Fault Codes	
Toledo	2009-2015	1P	01 Engine Electronics	Measuring Blocks	
Toledo	2009-2015	1P	01 Engine Electronics	Output Tests	
Toledo	2009-2015	1P	01 Engine Electronics	Specia Functions	
Toledo	2009-2015	1P	02 Transmission Electronics	Read Fault Codes	
Toledo	2009-2015	1P	02 Transmission Electronics	Clear Fault Codes	
Toledo	2009-2015	1P	02 Transmission Electronics	Measuring Blocks	
Toledo	2009-2015	1P	02 Transmission Electronics	Output Tests	
Toledo	2009-2015	1P	02 Transmission Electronics	Specia Functions	
Toledo	2009-2015	1P	03 Brake Electronics	Read Fault Codes	
Toledo	2009-2015	1P	03 Brake Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2009-2015	1P	03 Brake Electronics	Measuring Blocks	
Toledo	2009-2015	1P	03 Brake Electronics	Output Tests	
Toledo	2009-2015	1P	03 Brake Electronics	Specia Functions	
Toledo	2009-2015	1P	08 AC/Heating Electronics	Read Fault Codes	
Toledo	2009-2015	1P	08 AC/Heating Electronics	Clear Fault Codes	
Toledo	2009-2015	1P	08 AC/Heating Electronics	Measuring Blocks	
Toledo	2009-2015	1P	08 AC/Heating Electronics	Output Tests	
Toledo	2009-2015	1P	08 AC/Heating Electronics	Specia Functions	
Toledo	2009-2015	1P	09 Electronic Ctrl Electronics	Read Fault Codes	
Toledo	2009-2015	1P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Toledo	2009-2015	1P	09 Electronic Ctrl Electronics	Measuring Blocks	
Toledo	2009-2015	1P	09 Electronic Ctrl Electronics	Output Tests	
Toledo	2009-2015	1P	09 Electronic Ctrl Electronics	Specia Functions	
Toledo	2009-2015	1P	10 Parking Assist System 2	Read Fault Codes	
Toledo	2009-2015	1P	10 Parking Assist System 2	Clear Fault Codes	
Toledo	2009-2015	1P	10 Parking Assist System 2	Measuring Blocks	
Toledo	2009-2015	1P	10 Parking Assist System 2	Output Tests	
Toledo	2009-2015	1P	10 Parking Assist System 2	Specia Functions	
Toledo	2009-2015	1P	11 Engine Electronics 2	Read Fault Codes	
Toledo	2009-2015	1P	11 Engine Electronics 2	Clear Fault Codes	
Toledo	2009-2015	1P	11 Engine Electronics 2	Measuring Blocks	
Toledo	2009-2015	1P	11 Engine Electronics 2	Output Tests	
Toledo	2009-2015	1P	11 Engine Electronics 2	Specia Functions	
Toledo	2009-2015	1P	15 Airbags	Read Fault Codes	
Toledo	2009-2015	1P	15 Airbags	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2009-2015	1P	15 Airbags	Measuring Blocks	
Toledo	2009-2015	1P	15 Airbags	Output Tests	
Toledo	2009-2015	1P	15 Airbags	Specia Functions	
Toledo	2009-2015	1P	16 Steering Wheel Electronics	Read Fault Codes	
Toledo	2009-2015	1P	16 Steering Wheel Electronics	Clear Fault Codes	
Toledo	2009-2015	1P	16 Steering Wheel Electronics	Measuring Blocks	
Toledo	2009-2015	1P	16 Steering Wheel Electronics	Output Tests	
Toledo	2009-2015	1P	16 Steering Wheel Electronics	Specia Functions	
Toledo	2009-2015	1P	17 Instrument Cluster	Read Fault Codes	
Toledo	2009-2015	1P	17 Instrument Cluster	Clear Fault Codes	
Toledo	2009-2015	1P	17 Instrument Cluster	Measuring Blocks	
Toledo	2009-2015	1P	17 Instrument Cluster	Output Tests	
Toledo	2009-2015	1P	17 Instrument Cluster	Specia Functions	
Toledo	2009-2015	1P	19 Gateway Data Bus	Read Fault Codes	
Toledo	2009-2015	1P	19 Gateway Data Bus	Clear Fault Codes	
Toledo	2009-2015	1P	19 Gateway Data Bus	Measuring Blocks	
Toledo	2009-2015	1P	19 Gateway Data Bus	Output Tests	
Toledo	2009-2015	1P	19 Gateway Data Bus	Specia Functions	
Toledo	2009-2015	1P	22 4WD Electronics	Read Fault Codes	
Toledo	2009-2015	1P	22 4WD Electronics	Clear Fault Codes	
Toledo	2009-2015	1P	22 4WD Electronics	Measuring Blocks	
Toledo	2009-2015	1P	22 4WD Electronics	Output Tests	
Toledo	2009-2015	1P	22 4WD Electronics	Specia Functions	
Toledo	2009-2015	1P	25 Immobilizer	Read Fault Codes	
Toledo	2009-2015	1P	25 Immobilizer	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2009-2015	1P	25 Immobilizer	Measuring Blocks	
Toledo	2009-2015	1P	25 Immobilizer	Output Tests	
Toledo	2009-2015	1P	25 Immobilizer	Specia Functions	
Toledo	2009-2015	1P	2E Media Player Position 3	Read Fault Codes	
Toledo	2009-2015	1P	2E Media Player Position 3	Clear Fault Codes	
Toledo	2009-2015	1P	2E Media Player Position 3	Measuring Blocks	
Toledo	2009-2015	1P	2E Media Player Position 3	Output Tests	
Toledo	2009-2015	1P	2E Media Player Position 3	Specia Functions	
Toledo	2009-2015	1P	37 Navigation	Read Fault Codes	
Toledo	2009-2015	1P	37 Navigation	Clear Fault Codes	
Toledo	2009-2015	1P	37 Navigation	Measuring Blocks	
Toledo	2009-2015	1P	37 Navigation	Output Tests	
Toledo	2009-2015	1P	37 Navigation	Specia Functions	
Toledo	2009-2015	1P	42 Driver-Door Elect.	Read Fault Codes	
Toledo	2009-2015	1P	42 Driver-Door Elect.	Clear Fault Codes	
Toledo	2009-2015	1P	42 Driver-Door Elect.	Measuring Blocks	
Toledo	2009-2015	1P	42 Driver-Door Elect.	Output Tests	
Toledo	2009-2015	1P	42 Driver-Door Elect.	Specia Functions	
Toledo	2009-2015	1P	44 Steering Assistance	Read Fault Codes	
Toledo	2009-2015	1P	44 Steering Assistance	Clear Fault Codes	
Toledo	2009-2015	1P	44 Steering Assistance	Measuring Blocks	
Toledo	2009-2015	1P	44 Steering Assistance	Output Tests	
Toledo	2009-2015	1P	44 Steering Assistance	Specia Functions	
Toledo	2009-2015	1P	46 Central Control Module	Read Fault Codes	
Toledo	2009-2015	1P	46 Central Control Module	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2009-2015	1P	46 Central Control Module	Measuring Blocks	
Toledo	2009-2015	1P	46 Central Control Module	Output Tests	
Toledo	2009-2015	1P	46 Central Control Module	Specia Functions	
Toledo	2009-2015	1P	51 Electric Drive	Read Fault Codes	
Toledo	2009-2015	1P	51 Electric Drive	Clear Fault Codes	
Toledo	2009-2015	1P	51 Electric Drive	Measuring Blocks	
Toledo	2009-2015	1P	51 Electric Drive	Output Tests	
Toledo	2009-2015	1P	51 Electric Drive	Specia Functions	
Toledo	2009-2015	1P	52 Passe.-Door Elect.	Read Fault Codes	
Toledo	2009-2015	1P	52 Passe.-Door Elect.	Clear Fault Codes	
Toledo	2009-2015	1P	52 Passe.-Door Elect.	Measuring Blocks	
Toledo	2009-2015	1P	52 Passe.-Door Elect.	Output Tests	
Toledo	2009-2015	1P	52 Passe.-Door Elect.	Specia Functions	
Toledo	2009-2015	1P	55 Headlight Range Control	Read Fault Codes	
Toledo	2009-2015	1P	55 Headlight Range Control	Clear Fault Codes	
Toledo	2009-2015	1P	55 Headlight Range Control	Measuring Blocks	
Toledo	2009-2015	1P	55 Headlight Range Control	Output Tests	
Toledo	2009-2015	1P	55 Headlight Range Control	Specia Functions	
Toledo	2009-2015	1P	56 Radio	Read Fault Codes	
Toledo	2009-2015	1P	56 Radio	Clear Fault Codes	
Toledo	2009-2015	1P	56 Radio	Measuring Blocks	
Toledo	2009-2015	1P	56 Radio	Output Tests	
Toledo	2009-2015	1P	56 Radio	Specia Functions	
Toledo	2009-2015	1P	61 Battery Control	Read Fault Codes	
Toledo	2009-2015	1P	61 Battery Control	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2009-2015	1P	61 Battery Control	Measuring Blocks	
Toledo	2009-2015	1P	61 Battery Control	Output Tests	
Toledo	2009-2015	1P	61 Battery Control	Specia Functions	
Toledo	2009-2015	1P	62 LR-Door Electroni.	Read Fault Codes	
Toledo	2009-2015	1P	62 LR-Door Electroni.	Clear Fault Codes	
Toledo	2009-2015	1P	62 LR-Door Electroni.	Measuring Blocks	
Toledo	2009-2015	1P	62 LR-Door Electroni.	Output Tests	
Toledo	2009-2015	1P	62 LR-Door Electroni.	Specia Functions	
Toledo	2009-2015	1P	69 Trailer Function	Read Fault Codes	
Toledo	2009-2015	1P	69 Trailer Function	Clear Fault Codes	
Toledo	2009-2015	1P	69 Trailer Function	Measuring Blocks	
Toledo	2009-2015	1P	69 Trailer Function	Output Tests	
Toledo	2009-2015	1P	69 Trailer Function	Specia Functions	
Toledo	2009-2015	1P	72 RR-Door Electroni.	Read Fault Codes	
Toledo	2009-2015	1P	72 RR-Door Electroni.	Clear Fault Codes	
Toledo	2009-2015	1P	72 RR-Door Electroni.	Measuring Blocks	
Toledo	2009-2015	1P	72 RR-Door Electroni.	Output Tests	
Toledo	2009-2015	1P	72 RR-Door Electroni.	Specia Functions	
Toledo	2009-2015	1P	77 Telephone	Read Fault Codes	
Toledo	2009-2015	1P	77 Telephone	Clear Fault Codes	
Toledo	2009-2015	1P	77 Telephone	Measuring Blocks	
Toledo	2009-2015	1P	77 Telephone	Output Tests	
Toledo	2009-2015	1P	77 Telephone	Specia Functions	
Toledo	2009-2015	1P	8C Hybrid Battery	Read Fault Codes	
Toledo	2009-2015	1P	8C Hybrid Battery	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2009-2015	1P	8C Hybrid Battery	Measuring Blocks	
Toledo	2009-2015	1P	8C Hybrid Battery	Output Tests	
Toledo	2009-2015	1P	8C Hybrid Battery	Specia Functions	
Toledo	2009-2015	1P	BD Hi Vlot. Batt. Charger	Read Fault Codes	
Toledo	2009-2015	1P	BD Hi Vlot. Batt. Charger	Clear Fault Codes	
Toledo	2009-2015	1P	BD Hi Vlot. Batt. Charger	Measuring Blocks	
Toledo	2009-2015	1P	BD Hi Vlot. Batt. Charger	Output Tests	
Toledo	2009-2015	1P	BD Hi Vlot. Batt. Charger	Specia Functions	
Altea	2009-2015	5P	01 Engine Electronics	Read Fault Codes	
Altea	2009-2015	5P	01 Engine Electronics	Clear Fault Codes	
Altea	2009-2015	5P	01 Engine Electronics	Measuring Blocks	
Altea	2009-2015	5P	01 Engine Electronics	Output Tests	
Altea	2009-2015	5P	01 Engine Electronics	Specia Functions	
Altea	2009-2015	5P	02 Transmission Electronics	Read Fault Codes	
Altea	2009-2015	5P	02 Transmission Electronics	Clear Fault Codes	
Altea	2009-2015	5P	02 Transmission Electronics	Measuring Blocks	
Altea	2009-2015	5P	02 Transmission Electronics	Output Tests	
Altea	2009-2015	5P	02 Transmission Electronics	Specia Functions	
Altea	2009-2015	5P	03 Brake Electronics	Read Fault Codes	
Altea	2009-2015	5P	03 Brake Electronics	Clear Fault Codes	
Altea	2009-2015	5P	03 Brake Electronics	Measuring Blocks	
Altea	2009-2015	5P	03 Brake Electronics	Output Tests	
Altea	2009-2015	5P	03 Brake Electronics	Specia Functions	
Altea	2009-2015	5P	08 AC/Heating Electronics	Read Fault Codes	
Altea	2009-2015	5P	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2009-2015	5P	08 AC/Heating Electronics	Measuring Blocks	
Altea	2009-2015	5P	08 AC/Heating Electronics	Output Tests	
Altea	2009-2015	5P	08 AC/Heating Electronics	Specia Functions	
Altea	2009-2015	5P	09 Electronic Ctrl Electronics	Read Fault Codes	
Altea	2009-2015	5P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Altea	2009-2015	5P	09 Electronic Ctrl Electronics	Measuring Blocks	
Altea	2009-2015	5P	09 Electronic Ctrl Electronics	Output Tests	
Altea	2009-2015	5P	09 Electronic Ctrl Electronics	Specia Functions	
Altea	2009-2015	5P	10 Parking Assist System 2	Read Fault Codes	
Altea	2009-2015	5P	10 Parking Assist System 2	Clear Fault Codes	
Altea	2009-2015	5P	10 Parking Assist System 2	Measuring Blocks	
Altea	2009-2015	5P	10 Parking Assist System 2	Output Tests	
Altea	2009-2015	5P	10 Parking Assist System 2	Specia Functions	
Altea	2009-2015	5P	11 Engine Electronics 2	Read Fault Codes	
Altea	2009-2015	5P	11 Engine Electronics 2	Clear Fault Codes	
Altea	2009-2015	5P	11 Engine Electronics 2	Measuring Blocks	
Altea	2009-2015	5P	11 Engine Electronics 2	Output Tests	
Altea	2009-2015	5P	11 Engine Electronics 2	Specia Functions	
Altea	2009-2015	5P	15 Airbags	Read Fault Codes	
Altea	2009-2015	5P	15 Airbags	Clear Fault Codes	
Altea	2009-2015	5P	15 Airbags	Measuring Blocks	
Altea	2009-2015	5P	15 Airbags	Output Tests	
Altea	2009-2015	5P	15 Airbags	Specia Functions	
Altea	2009-2015	5P	16 Steering Wheel Electronics	Read Fault Codes	
Altea	2009-2015	5P	16 Steering Wheel Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2009-2015	5P	16 Steering Wheel Electronics	Measuring Blocks	
Altea	2009-2015	5P	16 Steering Wheel Electronics	Output Tests	
Altea	2009-2015	5P	16 Steering Wheel Electronics	Specia Functions	
Altea	2009-2015	5P	17 Instrument Cluster	Read Fault Codes	
Altea	2009-2015	5P	17 Instrument Cluster	Clear Fault Codes	
Altea	2009-2015	5P	17 Instrument Cluster	Measuring Blocks	
Altea	2009-2015	5P	17 Instrument Cluster	Output Tests	
Altea	2009-2015	5P	17 Instrument Cluster	Specia Functions	
Altea	2009-2015	5P	19 Gateway Data Bus	Read Fault Codes	
Altea	2009-2015	5P	19 Gateway Data Bus	Clear Fault Codes	
Altea	2009-2015	5P	19 Gateway Data Bus	Measuring Blocks	
Altea	2009-2015	5P	19 Gateway Data Bus	Output Tests	
Altea	2009-2015	5P	19 Gateway Data Bus	Specia Functions	
Altea	2009-2015	5P	22 4WD Electronics	Read Fault Codes	
Altea	2009-2015	5P	22 4WD Electronics	Clear Fault Codes	
Altea	2009-2015	5P	22 4WD Electronics	Measuring Blocks	
Altea	2009-2015	5P	22 4WD Electronics	Output Tests	
Altea	2009-2015	5P	22 4WD Electronics	Specia Functions	
Altea	2009-2015	5P	25 Immobilizer	Read Fault Codes	
Altea	2009-2015	5P	25 Immobilizer	Clear Fault Codes	
Altea	2009-2015	5P	25 Immobilizer	Measuring Blocks	
Altea	2009-2015	5P	25 Immobilizer	Output Tests	
Altea	2009-2015	5P	25 Immobilizer	Specia Functions	
Altea	2009-2015	5P	2E Media Player Position 3	Read Fault Codes	
Altea	2009-2015	5P	2E Media Player Position 3	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2009-2015	5P	2E Media Player Position 3	Measuring Blocks	
Altea	2009-2015	5P	2E Media Player Position 3	Output Tests	
Altea	2009-2015	5P	2E Media Player Position 3	Specia Functions	
Altea	2009-2015	5P	37 Navigation	Read Fault Codes	
Altea	2009-2015	5P	37 Navigation	Clear Fault Codes	
Altea	2009-2015	5P	37 Navigation	Measuring Blocks	
Altea	2009-2015	5P	37 Navigation	Output Tests	
Altea	2009-2015	5P	37 Navigation	Specia Functions	
Altea	2009-2015	5P	42 Driver-Door Elect.	Read Fault Codes	
Altea	2009-2015	5P	42 Driver-Door Elect.	Clear Fault Codes	
Altea	2009-2015	5P	42 Driver-Door Elect.	Measuring Blocks	
Altea	2009-2015	5P	42 Driver-Door Elect.	Output Tests	
Altea	2009-2015	5P	42 Driver-Door Elect.	Specia Functions	
Altea	2009-2015	5P	44 Steering Assistance	Read Fault Codes	
Altea	2009-2015	5P	44 Steering Assistance	Clear Fault Codes	
Altea	2009-2015	5P	44 Steering Assistance	Measuring Blocks	
Altea	2009-2015	5P	44 Steering Assistance	Output Tests	
Altea	2009-2015	5P	44 Steering Assistance	Specia Functions	
Altea	2009-2015	5P	46 Central Control Module	Read Fault Codes	
Altea	2009-2015	5P	46 Central Control Module	Clear Fault Codes	
Altea	2009-2015	5P	46 Central Control Module	Measuring Blocks	
Altea	2009-2015	5P	46 Central Control Module	Output Tests	
Altea	2009-2015	5P	46 Central Control Module	Specia Functions	
Altea	2009-2015	5P	51 Electric Drive	Read Fault Codes	
Altea	2009-2015	5P	51 Electric Drive	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2009-2015	5P	51 Electric Drive	Measuring Blocks	
Altea	2009-2015	5P	51 Electric Drive	Output Tests	
Altea	2009-2015	5P	51 Electric Drive	Specia Functions	
Altea	2009-2015	5P	52 Passe.-Door Elect.	Read Fault Codes	
Altea	2009-2015	5P	52 Passe.-Door Elect.	Clear Fault Codes	
Altea	2009-2015	5P	52 Passe.-Door Elect.	Measuring Blocks	
Altea	2009-2015	5P	52 Passe.-Door Elect.	Output Tests	
Altea	2009-2015	5P	52 Passe.-Door Elect.	Specia Functions	
Altea	2009-2015	5P	55 Headlight Range Control	Read Fault Codes	
Altea	2009-2015	5P	55 Headlight Range Control	Clear Fault Codes	
Altea	2009-2015	5P	55 Headlight Range Control	Measuring Blocks	
Altea	2009-2015	5P	55 Headlight Range Control	Output Tests	
Altea	2009-2015	5P	55 Headlight Range Control	Specia Functions	
Altea	2009-2015	5P	56 Radio	Read Fault Codes	
Altea	2009-2015	5P	56 Radio	Clear Fault Codes	
Altea	2009-2015	5P	56 Radio	Measuring Blocks	
Altea	2009-2015	5P	56 Radio	Output Tests	
Altea	2009-2015	5P	56 Radio	Specia Functions	
Altea	2009-2015	5P	61 Battery Control	Read Fault Codes	
Altea	2009-2015	5P	61 Battery Control	Clear Fault Codes	
Altea	2009-2015	5P	61 Battery Control	Measuring Blocks	
Altea	2009-2015	5P	61 Battery Control	Output Tests	
Altea	2009-2015	5P	61 Battery Control	Specia Functions	
Altea	2009-2015	5P	62 LR-Door Electroni.	Read Fault Codes	
Altea	2009-2015	5P	62 LR-Door Electroni.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2009-2015	5P	62 LR-Door Electroni.	Measuring Blocks	
Altea	2009-2015	5P	62 LR-Door Electroni.	Output Tests	
Altea	2009-2015	5P	62 LR-Door Electroni.	Specia Functions	
Altea	2009-2015	5P	69 Trailer Function	Read Fault Codes	
Altea	2009-2015	5P	69 Trailer Function	Clear Fault Codes	
Altea	2009-2015	5P	69 Trailer Function	Measuring Blocks	
Altea	2009-2015	5P	69 Trailer Function	Output Tests	
Altea	2009-2015	5P	69 Trailer Function	Specia Functions	
Altea	2009-2015	5P	72 RR-Door Electroni.	Read Fault Codes	
Altea	2009-2015	5P	72 RR-Door Electroni.	Clear Fault Codes	
Altea	2009-2015	5P	72 RR-Door Electroni.	Measuring Blocks	
Altea	2009-2015	5P	72 RR-Door Electroni.	Output Tests	
Altea	2009-2015	5P	72 RR-Door Electroni.	Specia Functions	
Altea	2009-2015	5P	77 Telephone	Read Fault Codes	
Altea	2009-2015	5P	77 Telephone	Clear Fault Codes	
Altea	2009-2015	5P	77 Telephone	Measuring Blocks	
Altea	2009-2015	5P	77 Telephone	Output Tests	
Altea	2009-2015	5P	77 Telephone	Specia Functions	
Altea	2009-2015	5P	8C Hybrid Battery	Read Fault Codes	
Altea	2009-2015	5P	8C Hybrid Battery	Clear Fault Codes	
Altea	2009-2015	5P	8C Hybrid Battery	Measuring Blocks	
Altea	2009-2015	5P	8C Hybrid Battery	Output Tests	
Altea	2009-2015	5P	8C Hybrid Battery	Specia Functions	
Altea	2009-2015	5P	BD Hi Vlot. Batt. Charger	Read Fault Codes	
Altea	2009-2015	5P	BD Hi Vlot. Batt. Charger	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2009-2015	5P	BD Hi Vlot. Batt. Charger	Measuring Blocks	
Altea	2009-2015	5P	BD Hi Vlot. Batt. Charger	Output Tests	
Altea	2009-2015	5P	BD Hi Vlot. Batt. Charger	Specia Functions	
Altea XL	2009-2015	5P	01 Engine Electronics	Read Fault Codes	
Altea XL	2009-2015	5P	01 Engine Electronics	Clear Fault Codes	
Altea XL	2009-2015	5P	01 Engine Electronics	Measuring Blocks	
Altea XL	2009-2015	5P	01 Engine Electronics	Output Tests	
Altea XL	2009-2015	5P	01 Engine Electronics	Specia Functions	
Altea XL	2009-2015	5P	02 Transmission Electronics	Read Fault Codes	
Altea XL	2009-2015	5P	02 Transmission Electronics	Clear Fault Codes	
Altea XL	2009-2015	5P	02 Transmission Electronics	Measuring Blocks	
Altea XL	2009-2015	5P	02 Transmission Electronics	Output Tests	
Altea XL	2009-2015	5P	02 Transmission Electronics	Specia Functions	
Altea XL	2009-2015	5P	03 Brake Electronics	Read Fault Codes	
Altea XL	2009-2015	5P	03 Brake Electronics	Clear Fault Codes	
Altea XL	2009-2015	5P	03 Brake Electronics	Measuring Blocks	
Altea XL	2009-2015	5P	03 Brake Electronics	Output Tests	
Altea XL	2009-2015	5P	03 Brake Electronics	Specia Functions	
Altea XL	2009-2015	5P	08 AC/Heating Electronics	Read Fault Codes	
Altea XL	2009-2015	5P	08 AC/Heating Electronics	Clear Fault Codes	
Altea XL	2009-2015	5P	08 AC/Heating Electronics	Measuring Blocks	
Altea XL	2009-2015	5P	08 AC/Heating Electronics	Output Tests	
Altea XL	2009-2015	5P	08 AC/Heating Electronics	Specia Functions	
Altea XL	2009-2015	5P	09 Electronic Ctrl Electronics	Read Fault Codes	
Altea XL	2009-2015	5P	09 Electronic Ctrl Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2009-2015	5P	09 Electronic Ctrl Electronics	Measuring Blocks	
Altea XL	2009-2015	5P	09 Electronic Ctrl Electronics	Output Tests	
Altea XL	2009-2015	5P	09 Electronic Ctrl Electronics	Specia Functions	
Altea XL	2009-2015	5P	10 Parking Assist System 2	Read Fault Codes	
Altea XL	2009-2015	5P	10 Parking Assist System 2	Clear Fault Codes	
Altea XL	2009-2015	5P	10 Parking Assist System 2	Measuring Blocks	
Altea XL	2009-2015	5P	10 Parking Assist System 2	Output Tests	
Altea XL	2009-2015	5P	10 Parking Assist System 2	Specia Functions	
Altea XL	2009-2015	5P	11 Engine Electronics 2	Read Fault Codes	
Altea XL	2009-2015	5P	11 Engine Electronics 2	Clear Fault Codes	
Altea XL	2009-2015	5P	11 Engine Electronics 2	Measuring Blocks	
Altea XL	2009-2015	5P	11 Engine Electronics 2	Output Tests	
Altea XL	2009-2015	5P	11 Engine Electronics 2	Specia Functions	
Altea XL	2009-2015	5P	15 Airbags	Read Fault Codes	
Altea XL	2009-2015	5P	15 Airbags	Clear Fault Codes	
Altea XL	2009-2015	5P	15 Airbags	Measuring Blocks	
Altea XL	2009-2015	5P	15 Airbags	Output Tests	
Altea XL	2009-2015	5P	15 Airbags	Specia Functions	
Altea XL	2009-2015	5P	16 Steering Wheel Electronics	Read Fault Codes	
Altea XL	2009-2015	5P	16 Steering Wheel Electronics	Clear Fault Codes	
Altea XL	2009-2015	5P	16 Steering Wheel Electronics	Measuring Blocks	
Altea XL	2009-2015	5P	16 Steering Wheel Electronics	Output Tests	
Altea XL	2009-2015	5P	16 Steering Wheel Electronics	Specia Functions	
Altea XL	2009-2015	5P	17 Instrument Cluster	Read Fault Codes	
Altea XL	2009-2015	5P	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2009-2015	5P	17 Instrument Cluster	Measuring Blocks	
Altea XL	2009-2015	5P	17 Instrument Cluster	Output Tests	
Altea XL	2009-2015	5P	17 Instrument Cluster	Specia Functions	
Altea XL	2009-2015	5P	19 Gateway Data Bus	Read Fault Codes	
Altea XL	2009-2015	5P	19 Gateway Data Bus	Clear Fault Codes	
Altea XL	2009-2015	5P	19 Gateway Data Bus	Measuring Blocks	
Altea XL	2009-2015	5P	19 Gateway Data Bus	Output Tests	
Altea XL	2009-2015	5P	19 Gateway Data Bus	Specia Functions	
Altea XL	2009-2015	5P	22 4WD Electronics	Read Fault Codes	
Altea XL	2009-2015	5P	22 4WD Electronics	Clear Fault Codes	
Altea XL	2009-2015	5P	22 4WD Electronics	Measuring Blocks	
Altea XL	2009-2015	5P	22 4WD Electronics	Output Tests	
Altea XL	2009-2015	5P	22 4WD Electronics	Specia Functions	
Altea XL	2009-2015	5P	25 Immobilizer	Read Fault Codes	
Altea XL	2009-2015	5P	25 Immobilizer	Clear Fault Codes	
Altea XL	2009-2015	5P	25 Immobilizer	Measuring Blocks	
Altea XL	2009-2015	5P	25 Immobilizer	Output Tests	
Altea XL	2009-2015	5P	25 Immobilizer	Specia Functions	
Altea XL	2009-2015	5P	2E Media Player Position 3	Read Fault Codes	
Altea XL	2009-2015	5P	2E Media Player Position 3	Clear Fault Codes	
Altea XL	2009-2015	5P	2E Media Player Position 3	Measuring Blocks	
Altea XL	2009-2015	5P	2E Media Player Position 3	Output Tests	
Altea XL	2009-2015	5P	2E Media Player Position 3	Specia Functions	
Altea XL	2009-2015	5P	37 Navigation	Read Fault Codes	
Altea XL	2009-2015	5P	37 Navigation	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2009-2015	5P	37 Navigation	Measuring Blocks	
Altea XL	2009-2015	5P	37 Navigation	Output Tests	
Altea XL	2009-2015	5P	37 Navigation	Specia Functions	
Altea XL	2009-2015	5P	42 Driver-Door Elect.	Read Fault Codes	
Altea XL	2009-2015	5P	42 Driver-Door Elect.	Clear Fault Codes	
Altea XL	2009-2015	5P	42 Driver-Door Elect.	Measuring Blocks	
Altea XL	2009-2015	5P	42 Driver-Door Elect.	Output Tests	
Altea XL	2009-2015	5P	42 Driver-Door Elect.	Specia Functions	
Altea XL	2009-2015	5P	44 Steering Assistance	Read Fault Codes	
Altea XL	2009-2015	5P	44 Steering Assistance	Clear Fault Codes	
Altea XL	2009-2015	5P	44 Steering Assistance	Measuring Blocks	
Altea XL	2009-2015	5P	44 Steering Assistance	Output Tests	
Altea XL	2009-2015	5P	44 Steering Assistance	Specia Functions	
Altea XL	2009-2015	5P	46 Central Control Module	Read Fault Codes	
Altea XL	2009-2015	5P	46 Central Control Module	Clear Fault Codes	
Altea XL	2009-2015	5P	46 Central Control Module	Measuring Blocks	
Altea XL	2009-2015	5P	46 Central Control Module	Output Tests	
Altea XL	2009-2015	5P	46 Central Control Module	Specia Functions	
Altea XL	2009-2015	5P	51 Electric Drive	Read Fault Codes	
Altea XL	2009-2015	5P	51 Electric Drive	Clear Fault Codes	
Altea XL	2009-2015	5P	51 Electric Drive	Measuring Blocks	
Altea XL	2009-2015	5P	51 Electric Drive	Output Tests	
Altea XL	2009-2015	5P	51 Electric Drive	Specia Functions	
Altea XL	2009-2015	5P	52 Passe.-Door Elect.	Read Fault Codes	
Altea XL	2009-2015	5P	52 Passe.-Door Elect.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2009-2015	5P	52 Passe.-Door Elect.	Measuring Blocks	
Altea XL	2009-2015	5P	52 Passe.-Door Elect.	Output Tests	
Altea XL	2009-2015	5P	52 Passe.-Door Elect.	Specia Functions	
Altea XL	2009-2015	5P	55 Headlight Range Control	Read Fault Codes	
Altea XL	2009-2015	5P	55 Headlight Range Control	Clear Fault Codes	
Altea XL	2009-2015	5P	55 Headlight Range Control	Measuring Blocks	
Altea XL	2009-2015	5P	55 Headlight Range Control	Output Tests	
Altea XL	2009-2015	5P	55 Headlight Range Control	Specia Functions	
Altea XL	2009-2015	5P	56 Radio	Read Fault Codes	
Altea XL	2009-2015	5P	56 Radio	Clear Fault Codes	
Altea XL	2009-2015	5P	56 Radio	Measuring Blocks	
Altea XL	2009-2015	5P	56 Radio	Output Tests	
Altea XL	2009-2015	5P	56 Radio	Specia Functions	
Altea XL	2009-2015	5P	61 Battery Control	Read Fault Codes	
Altea XL	2009-2015	5P	61 Battery Control	Clear Fault Codes	
Altea XL	2009-2015	5P	61 Battery Control	Measuring Blocks	
Altea XL	2009-2015	5P	61 Battery Control	Output Tests	
Altea XL	2009-2015	5P	61 Battery Control	Specia Functions	
Altea XL	2009-2015	5P	62 LR-Door Electroni.	Read Fault Codes	
Altea XL	2009-2015	5P	62 LR-Door Electroni.	Clear Fault Codes	
Altea XL	2009-2015	5P	62 LR-Door Electroni.	Measuring Blocks	
Altea XL	2009-2015	5P	62 LR-Door Electroni.	Output Tests	
Altea XL	2009-2015	5P	62 LR-Door Electroni.	Specia Functions	
Altea XL	2009-2015	5P	69 Trailer Function	Read Fault Codes	
Altea XL	2009-2015	5P	69 Trailer Function	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2009-2015	5P	69 Trailer Function	Measuring Blocks	
Altea XL	2009-2015	5P	69 Trailer Function	Output Tests	
Altea XL	2009-2015	5P	69 Trailer Function	Specia Functions	
Altea XL	2009-2015	5P	72 RR-Door Electroni.	Read Fault Codes	
Altea XL	2009-2015	5P	72 RR-Door Electroni.	Clear Fault Codes	
Altea XL	2009-2015	5P	72 RR-Door Electroni.	Measuring Blocks	
Altea XL	2009-2015	5P	72 RR-Door Electroni.	Output Tests	
Altea XL	2009-2015	5P	72 RR-Door Electroni.	Specia Functions	
Altea XL	2009-2015	5P	77 Telephone	Read Fault Codes	
Altea XL	2009-2015	5P	77 Telephone	Clear Fault Codes	
Altea XL	2009-2015	5P	77 Telephone	Measuring Blocks	
Altea XL	2009-2015	5P	77 Telephone	Output Tests	
Altea XL	2009-2015	5P	77 Telephone	Specia Functions	
Altea XL	2009-2015	5P	8C Hybrid Battery	Read Fault Codes	
Altea XL	2009-2015	5P	8C Hybrid Battery	Clear Fault Codes	
Altea XL	2009-2015	5P	8C Hybrid Battery	Measuring Blocks	
Altea XL	2009-2015	5P	8C Hybrid Battery	Output Tests	
Altea XL	2009-2015	5P	8C Hybrid Battery	Specia Functions	
Altea XL	2009-2015	5P	BD Hi Vlot. Batt. Charger	Read Fault Codes	
Altea XL	2009-2015	5P	BD Hi Vlot. Batt. Charger	Clear Fault Codes	
Altea XL	2009-2015	5P	BD Hi Vlot. Batt. Charger	Measuring Blocks	
Altea XL	2009-2015	5P	BD Hi Vlot. Batt. Charger	Output Tests	
Altea XL	2009-2015	5P	BD Hi Vlot. Batt. Charger	Specia Functions	
Freetrack	2009-2015	5P	01 Engine Electronics	Read Fault Codes	
Freetrack	2009-2015	5P	01 Engine Electronics	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Freetrack	2009-2015	5P	01 Engine Electronics	Measuring Blocks	
Freetrack	2009-2015	5P	01 Engine Electronics	Output Tests	
Freetrack	2009-2015	5P	01 Engine Electronics	Specia Functions	
Freetrack	2009-2015	5P	02 Transmission Electronics	Read Fault Codes	
Freetrack	2009-2015	5P	02 Transmission Electronics	Clear Fault Codes	
Freetrack	2009-2015	5P	02 Transmission Electronics	Measuring Blocks	
Freetrack	2009-2015	5P	02 Transmission Electronics	Output Tests	
Freetrack	2009-2015	5P	02 Transmission Electronics	Specia Functions	
Freetrack	2009-2015	5P	03 Brake Electronics	Read Fault Codes	
Freetrack	2009-2015	5P	03 Brake Electronics	Clear Fault Codes	
Freetrack	2009-2015	5P	03 Brake Electronics	Measuring Blocks	
Freetrack	2009-2015	5P	03 Brake Electronics	Output Tests	
Freetrack	2009-2015	5P	03 Brake Electronics	Specia Functions	
Freetrack	2009-2015	5P	08 AC/Heating Electronics	Read Fault Codes	
Freetrack	2009-2015	5P	08 AC/Heating Electronics	Clear Fault Codes	
Freetrack	2009-2015	5P	08 AC/Heating Electronics	Measuring Blocks	
Freetrack	2009-2015	5P	08 AC/Heating Electronics	Output Tests	
Freetrack	2009-2015	5P	08 AC/Heating Electronics	Specia Functions	
Freetrack	2009-2015	5P	09 Electronic Ctrl Electronics	Read Fault Codes	
Freetrack	2009-2015	5P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Freetrack	2009-2015	5P	09 Electronic Ctrl Electronics	Measuring Blocks	
Freetrack	2009-2015	5P	09 Electronic Ctrl Electronics	Output Tests	
Freetrack	2009-2015	5P	09 Electronic Ctrl Electronics	Specia Functions	
Freetrack	2009-2015	5P	10 Parking Assist System 2	Read Fault Codes	
Freetrack	2009-2015	5P	10 Parking Assist System 2	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Freetrack	2009-2015	5P	10 Parking Assist System 2	Measuring Blocks	
Freetrack	2009-2015	5P	10 Parking Assist System 2	Output Tests	
Freetrack	2009-2015	5P	10 Parking Assist System 2	Specia Functions	
Freetrack	2009-2015	5P	11 Engine Electronics 2	Read Fault Codes	
Freetrack	2009-2015	5P	11 Engine Electronics 2	Clear Fault Codes	
Freetrack	2009-2015	5P	11 Engine Electronics 2	Measuring Blocks	
Freetrack	2009-2015	5P	11 Engine Electronics 2	Output Tests	
Freetrack	2009-2015	5P	11 Engine Electronics 2	Specia Functions	
Freetrack	2009-2015	5P	15 Airbags	Read Fault Codes	
Freetrack	2009-2015	5P	15 Airbags	Clear Fault Codes	
Freetrack	2009-2015	5P	15 Airbags	Measuring Blocks	
Freetrack	2009-2015	5P	15 Airbags	Output Tests	
Freetrack	2009-2015	5P	15 Airbags	Specia Functions	
Freetrack	2009-2015	5P	16 Steering Wheel Electronics	Read Fault Codes	
Freetrack	2009-2015	5P	16 Steering Wheel Electronics	Clear Fault Codes	
Freetrack	2009-2015	5P	16 Steering Wheel Electronics	Measuring Blocks	
Freetrack	2009-2015	5P	16 Steering Wheel Electronics	Output Tests	
Freetrack	2009-2015	5P	16 Steering Wheel Electronics	Specia Functions	
Freetrack	2009-2015	5P	17 Instrument Cluster	Read Fault Codes	
Freetrack	2009-2015	5P	17 Instrument Cluster	Clear Fault Codes	
Freetrack	2009-2015	5P	17 Instrument Cluster	Measuring Blocks	
Freetrack	2009-2015	5P	17 Instrument Cluster	Output Tests	
Freetrack	2009-2015	5P	17 Instrument Cluster	Specia Functions	
Freetrack	2009-2015	5P	19 Gateway Data Bus	Read Fault Codes	
Freetrack	2009-2015	5P	19 Gateway Data Bus	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Freetrack	2009-2015	5P	19 Gateway Data Bus	Measuring Blocks	
Freetrack	2009-2015	5P	19 Gateway Data Bus	Output Tests	
Freetrack	2009-2015	5P	19 Gateway Data Bus	Specia Functions	
Freetrack	2009-2015	5P	22 4WD Electronics	Read Fault Codes	
Freetrack	2009-2015	5P	22 4WD Electronics	Clear Fault Codes	
Freetrack	2009-2015	5P	22 4WD Electronics	Measuring Blocks	
Freetrack	2009-2015	5P	22 4WD Electronics	Output Tests	
Freetrack	2009-2015	5P	22 4WD Electronics	Specia Functions	
Freetrack	2009-2015	5P	25 Immobilizer	Read Fault Codes	
Freetrack	2009-2015	5P	25 Immobilizer	Clear Fault Codes	
Freetrack	2009-2015	5P	25 Immobilizer	Measuring Blocks	
Freetrack	2009-2015	5P	25 Immobilizer	Output Tests	
Freetrack	2009-2015	5P	25 Immobilizer	Specia Functions	
Freetrack	2009-2015	5P	2E Media Player Position 3	Read Fault Codes	
Freetrack	2009-2015	5P	2E Media Player Position 3	Clear Fault Codes	
Freetrack	2009-2015	5P	2E Media Player Position 3	Measuring Blocks	
Freetrack	2009-2015	5P	2E Media Player Position 3	Output Tests	
Freetrack	2009-2015	5P	2E Media Player Position 3	Specia Functions	
Freetrack	2009-2015	5P	37 Navigation	Read Fault Codes	
Freetrack	2009-2015	5P	37 Navigation	Clear Fault Codes	
Freetrack	2009-2015	5P	37 Navigation	Measuring Blocks	
Freetrack	2009-2015	5P	37 Navigation	Output Tests	
Freetrack	2009-2015	5P	37 Navigation	Specia Functions	
Freetrack	2009-2015	5P	42 Driver-Door Elect.	Read Fault Codes	
Freetrack	2009-2015	5P	42 Driver-Door Elect.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Freetrack	2009-2015	5P	42 Driver-Door Elect.	Measuring Blocks	
Freetrack	2009-2015	5P	42 Driver-Door Elect.	Output Tests	
Freetrack	2009-2015	5P	42 Driver-Door Elect.	Specia Functions	
Freetrack	2009-2015	5P	44 Steering Assistance	Read Fault Codes	
Freetrack	2009-2015	5P	44 Steering Assistance	Clear Fault Codes	
Freetrack	2009-2015	5P	44 Steering Assistance	Measuring Blocks	
Freetrack	2009-2015	5P	44 Steering Assistance	Output Tests	
Freetrack	2009-2015	5P	44 Steering Assistance	Specia Functions	
Freetrack	2009-2015	5P	46 Central Control Module	Read Fault Codes	
Freetrack	2009-2015	5P	46 Central Control Module	Clear Fault Codes	
Freetrack	2009-2015	5P	46 Central Control Module	Measuring Blocks	
Freetrack	2009-2015	5P	46 Central Control Module	Output Tests	
Freetrack	2009-2015	5P	46 Central Control Module	Specia Functions	
Freetrack	2009-2015	5P	51 Electric Drive	Read Fault Codes	
Freetrack	2009-2015	5P	51 Electric Drive	Clear Fault Codes	
Freetrack	2009-2015	5P	51 Electric Drive	Measuring Blocks	
Freetrack	2009-2015	5P	51 Electric Drive	Output Tests	
Freetrack	2009-2015	5P	51 Electric Drive	Specia Functions	
Freetrack	2009-2015	5P	52 Passe.-Door Elect.	Read Fault Codes	
Freetrack	2009-2015	5P	52 Passe.-Door Elect.	Clear Fault Codes	
Freetrack	2009-2015	5P	52 Passe.-Door Elect.	Measuring Blocks	
Freetrack	2009-2015	5P	52 Passe.-Door Elect.	Output Tests	
Freetrack	2009-2015	5P	52 Passe.-Door Elect.	Specia Functions	
Freetrack	2009-2015	5P	55 Headlight Range Control	Read Fault Codes	
Freetrack	2009-2015	5P	55 Headlight Range Control	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Freetrack	2009-2015	5P	55 Headlight Range Control	Measuring Blocks	
Freetrack	2009-2015	5P	55 Headlight Range Control	Output Tests	
Freetrack	2009-2015	5P	55 Headlight Range Control	Specia Functions	
Freetrack	2009-2015	5P	56 Radio	Read Fault Codes	
Freetrack	2009-2015	5P	56 Radio	Clear Fault Codes	
Freetrack	2009-2015	5P	56 Radio	Measuring Blocks	
Freetrack	2009-2015	5P	56 Radio	Output Tests	
Freetrack	2009-2015	5P	56 Radio	Specia Functions	
Freetrack	2009-2015	5P	61 Battery Control	Read Fault Codes	
Freetrack	2009-2015	5P	61 Battery Control	Clear Fault Codes	
Freetrack	2009-2015	5P	61 Battery Control	Measuring Blocks	
Freetrack	2009-2015	5P	61 Battery Control	Output Tests	
Freetrack	2009-2015	5P	61 Battery Control	Specia Functions	
Freetrack	2009-2015	5P	62 LR-Door Electroni.	Read Fault Codes	
Freetrack	2009-2015	5P	62 LR-Door Electroni.	Clear Fault Codes	
Freetrack	2009-2015	5P	62 LR-Door Electroni.	Measuring Blocks	
Freetrack	2009-2015	5P	62 LR-Door Electroni.	Output Tests	
Freetrack	2009-2015	5P	62 LR-Door Electroni.	Specia Functions	
Freetrack	2009-2015	5P	69 Trailer Function	Read Fault Codes	
Freetrack	2009-2015	5P	69 Trailer Function	Clear Fault Codes	
Freetrack	2009-2015	5P	69 Trailer Function	Measuring Blocks	
Freetrack	2009-2015	5P	69 Trailer Function	Output Tests	
Freetrack	2009-2015	5P	69 Trailer Function	Specia Functions	
Freetrack	2009-2015	5P	72 RR-Door Electroni.	Read Fault Codes	
Freetrack	2009-2015	5P	72 RR-Door Electroni.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Freetrack	2009-2015	5P	72 RR-Door Electroni.	Measuring Blocks	
Freetrack	2009-2015	5P	72 RR-Door Electroni.	Output Tests	
Freetrack	2009-2015	5P	72 RR-Door Electroni.	Specia Functions	
Freetrack	2009-2015	5P	77 Telephone	Read Fault Codes	
Freetrack	2009-2015	5P	77 Telephone	Clear Fault Codes	
Freetrack	2009-2015	5P	77 Telephone	Measuring Blocks	
Freetrack	2009-2015	5P	77 Telephone	Output Tests	
Freetrack	2009-2015	5P	77 Telephone	Specia Functions	
Freetrack	2009-2015	5P	8C Hybrid Battery	Read Fault Codes	
Freetrack	2009-2015	5P	8C Hybrid Battery	Clear Fault Codes	
Freetrack	2009-2015	5P	8C Hybrid Battery	Measuring Blocks	
Freetrack	2009-2015	5P	8C Hybrid Battery	Output Tests	
Freetrack	2009-2015	5P	8C Hybrid Battery	Specia Functions	
Freetrack	2009-2015	5P	BD Hi Vlot. Batt. Charger	Read Fault Codes	
Freetrack	2009-2015	5P	BD Hi Vlot. Batt. Charger	Clear Fault Codes	
Freetrack	2009-2015	5P	BD Hi Vlot. Batt. Charger	Measuring Blocks	
Freetrack	2009-2015	5P	BD Hi Vlot. Batt. Charger	Output Tests	
Freetrack	2009-2015	5P	BD Hi Vlot. Batt. Charger	Specia Functions	
Leon	2009-2015	5P	01 Engine Electronics	Read Fault Codes	
Leon	2009-2015	5P	01 Engine Electronics	Clear Fault Codes	
Leon	2009-2015	5P	01 Engine Electronics	Measuring Blocks	
Leon	2009-2015	5P	01 Engine Electronics	Output Tests	
Leon	2009-2015	5P	01 Engine Electronics	Specia Functions	
Leon	2009-2015	5P	02 Transmission Electronics	Read Fault Codes	
Leon	2009-2015	5P	02 Transmission Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2009-2015	5P	02 Transmission Electronics	Measuring Blocks	
Leon	2009-2015	5P	02 Transmission Electronics	Output Tests	
Leon	2009-2015	5P	02 Transmission Electronics	Specia Functions	
Leon	2009-2015	5P	03 Brake Electronics	Read Fault Codes	
Leon	2009-2015	5P	03 Brake Electronics	Clear Fault Codes	
Leon	2009-2015	5P	03 Brake Electronics	Measuring Blocks	
Leon	2009-2015	5P	03 Brake Electronics	Output Tests	
Leon	2009-2015	5P	03 Brake Electronics	Specia Functions	
Leon	2009-2015	5P	08 AC/Heating Electronics	Read Fault Codes	
Leon	2009-2015	5P	08 AC/Heating Electronics	Clear Fault Codes	
Leon	2009-2015	5P	08 AC/Heating Electronics	Measuring Blocks	
Leon	2009-2015	5P	08 AC/Heating Electronics	Output Tests	
Leon	2009-2015	5P	08 AC/Heating Electronics	Specia Functions	
Leon	2009-2015	5P	09 Electronic Ctrl Electronics	Read Fault Codes	
Leon	2009-2015	5P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Leon	2009-2015	5P	09 Electronic Ctrl Electronics	Measuring Blocks	
Leon	2009-2015	5P	09 Electronic Ctrl Electronics	Output Tests	
Leon	2009-2015	5P	09 Electronic Ctrl Electronics	Specia Functions	
Leon	2009-2015	5P	10 Parking Assist System 2	Read Fault Codes	
Leon	2009-2015	5P	10 Parking Assist System 2	Clear Fault Codes	
Leon	2009-2015	5P	10 Parking Assist System 2	Measuring Blocks	
Leon	2009-2015	5P	10 Parking Assist System 2	Output Tests	
Leon	2009-2015	5P	10 Parking Assist System 2	Specia Functions	
Leon	2009-2015	5P	11 Engine Electronics 2	Read Fault Codes	
Leon	2009-2015	5P	11 Engine Electronics 2	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2009-2015	5P	11 Engine Electronics 2	Measuring Blocks	
Leon	2009-2015	5P	11 Engine Electronics 2	Output Tests	
Leon	2009-2015	5P	11 Engine Electronics 2	Specia Functions	
Leon	2009-2015	5P	15 Airbags	Read Fault Codes	
Leon	2009-2015	5P	15 Airbags	Clear Fault Codes	
Leon	2009-2015	5P	15 Airbags	Measuring Blocks	
Leon	2009-2015	5P	15 Airbags	Output Tests	
Leon	2009-2015	5P	15 Airbags	Specia Functions	
Leon	2009-2015	5P	16 Steering Wheel Electronics	Read Fault Codes	
Leon	2009-2015	5P	16 Steering Wheel Electronics	Clear Fault Codes	
Leon	2009-2015	5P	16 Steering Wheel Electronics	Measuring Blocks	
Leon	2009-2015	5P	16 Steering Wheel Electronics	Output Tests	
Leon	2009-2015	5P	16 Steering Wheel Electronics	Specia Functions	
Leon	2009-2015	5P	17 Instrument Cluster	Read Fault Codes	
Leon	2009-2015	5P	17 Instrument Cluster	Clear Fault Codes	
Leon	2009-2015	5P	17 Instrument Cluster	Measuring Blocks	
Leon	2009-2015	5P	17 Instrument Cluster	Output Tests	
Leon	2009-2015	5P	17 Instrument Cluster	Specia Functions	
Leon	2009-2015	5P	19 Gateway Data Bus	Read Fault Codes	
Leon	2009-2015	5P	19 Gateway Data Bus	Clear Fault Codes	
Leon	2009-2015	5P	19 Gateway Data Bus	Measuring Blocks	
Leon	2009-2015	5P	19 Gateway Data Bus	Output Tests	
Leon	2009-2015	5P	19 Gateway Data Bus	Specia Functions	
Leon	2009-2015	5P	22 4WD Electronics	Read Fault Codes	
Leon	2009-2015	5P	22 4WD Electronics	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2009-2015	5P	22 4WD Electronics	Measuring Blocks	
Leon	2009-2015	5P	22 4WD Electronics	Output Tests	
Leon	2009-2015	5P	22 4WD Electronics	Specia Functions	
Leon	2009-2015	5P	25 Immobilizer	Read Fault Codes	
Leon	2009-2015	5P	25 Immobilizer	Clear Fault Codes	
Leon	2009-2015	5P	25 Immobilizer	Measuring Blocks	
Leon	2009-2015	5P	25 Immobilizer	Output Tests	
Leon	2009-2015	5P	25 Immobilizer	Specia Functions	
Leon	2009-2015	5P	2E Media Player Position 3	Read Fault Codes	
Leon	2009-2015	5P	2E Media Player Position 3	Clear Fault Codes	
Leon	2009-2015	5P	2E Media Player Position 3	Measuring Blocks	
Leon	2009-2015	5P	2E Media Player Position 3	Output Tests	
Leon	2009-2015	5P	2E Media Player Position 3	Specia Functions	
Leon	2009-2015	5P	37 Navigation	Read Fault Codes	
Leon	2009-2015	5P	37 Navigation	Clear Fault Codes	
Leon	2009-2015	5P	37 Navigation	Measuring Blocks	
Leon	2009-2015	5P	37 Navigation	Output Tests	
Leon	2009-2015	5P	37 Navigation	Specia Functions	
Leon	2009-2015	5P	42 Driver-Door Elect.	Read Fault Codes	
Leon	2009-2015	5P	42 Driver-Door Elect.	Clear Fault Codes	
Leon	2009-2015	5P	42 Driver-Door Elect.	Measuring Blocks	
Leon	2009-2015	5P	42 Driver-Door Elect.	Output Tests	
Leon	2009-2015	5P	42 Driver-Door Elect.	Specia Functions	
Leon	2009-2015	5P	44 Steering Assistance	Read Fault Codes	
Leon	2009-2015	5P	44 Steering Assistance	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2009-2015	5P	44 Steering Assistance	Measuring Blocks	
Leon	2009-2015	5P	44 Steering Assistance	Output Tests	
Leon	2009-2015	5P	44 Steering Assistance	Specia Functions	
Leon	2009-2015	5P	46 Central Control Module	Read Fault Codes	
Leon	2009-2015	5P	46 Central Control Module	Clear Fault Codes	
Leon	2009-2015	5P	46 Central Control Module	Measuring Blocks	
Leon	2009-2015	5P	46 Central Control Module	Output Tests	
Leon	2009-2015	5P	46 Central Control Module	Specia Functions	
Leon	2009-2015	5P	51 Electric Drive	Read Fault Codes	
Leon	2009-2015	5P	51 Electric Drive	Clear Fault Codes	
Leon	2009-2015	5P	51 Electric Drive	Measuring Blocks	
Leon	2009-2015	5P	51 Electric Drive	Output Tests	
Leon	2009-2015	5P	51 Electric Drive	Specia Functions	
Leon	2009-2015	5P	52 Passe.-Door Elect.	Read Fault Codes	
Leon	2009-2015	5P	52 Passe.-Door Elect.	Clear Fault Codes	
Leon	2009-2015	5P	52 Passe.-Door Elect.	Measuring Blocks	
Leon	2009-2015	5P	52 Passe.-Door Elect.	Output Tests	
Leon	2009-2015	5P	52 Passe.-Door Elect.	Specia Functions	
Leon	2009-2015	5P	55 Headlight Range Control	Read Fault Codes	
Leon	2009-2015	5P	55 Headlight Range Control	Clear Fault Codes	
Leon	2009-2015	5P	55 Headlight Range Control	Measuring Blocks	
Leon	2009-2015	5P	55 Headlight Range Control	Output Tests	
Leon	2009-2015	5P	55 Headlight Range Control	Specia Functions	
Leon	2009-2015	5P	56 Radio	Read Fault Codes	
Leon	2009-2015	5P	56 Radio	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2009-2015	5P	56 Radio	Measuring Blocks	
Leon	2009-2015	5P	56 Radio	Output Tests	
Leon	2009-2015	5P	56 Radio	Specia Functions	
Leon	2009-2015	5P	61 Battery Control	Read Fault Codes	
Leon	2009-2015	5P	61 Battery Control	Clear Fault Codes	
Leon	2009-2015	5P	61 Battery Control	Measuring Blocks	
Leon	2009-2015	5P	61 Battery Control	Output Tests	
Leon	2009-2015	5P	61 Battery Control	Specia Functions	
Leon	2009-2015	5P	62 LR-Door Electroni.	Read Fault Codes	
Leon	2009-2015	5P	62 LR-Door Electroni.	Clear Fault Codes	
Leon	2009-2015	5P	62 LR-Door Electroni.	Measuring Blocks	
Leon	2009-2015	5P	62 LR-Door Electroni.	Output Tests	
Leon	2009-2015	5P	62 LR-Door Electroni.	Specia Functions	
Leon	2009-2015	5P	69 Trailer Function	Read Fault Codes	
Leon	2009-2015	5P	69 Trailer Function	Clear Fault Codes	
Leon	2009-2015	5P	69 Trailer Function	Measuring Blocks	
Leon	2009-2015	5P	69 Trailer Function	Output Tests	
Leon	2009-2015	5P	69 Trailer Function	Specia Functions	
Leon	2009-2015	5P	72 RR-Door Electroni.	Read Fault Codes	
Leon	2009-2015	5P	72 RR-Door Electroni.	Clear Fault Codes	
Leon	2009-2015	5P	72 RR-Door Electroni.	Measuring Blocks	
Leon	2009-2015	5P	72 RR-Door Electroni.	Output Tests	
Leon	2009-2015	5P	72 RR-Door Electroni.	Specia Functions	
Leon	2009-2015	5P	77 Telephone	Read Fault Codes	
Leon	2009-2015	5P	77 Telephone	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2009-2015	5P	77 Telephone	Measuring Blocks	
Leon	2009-2015	5P	77 Telephone	Output Tests	
Leon	2009-2015	5P	77 Telephone	Specia Functions	
Leon	2009-2015	5P	8C Hybrid Battery	Read Fault Codes	
Leon	2009-2015	5P	8C Hybrid Battery	Clear Fault Codes	
Leon	2009-2015	5P	8C Hybrid Battery	Measuring Blocks	
Leon	2009-2015	5P	8C Hybrid Battery	Output Tests	
Leon	2009-2015	5P	8C Hybrid Battery	Specia Functions	
Leon	2009-2015	5P	BD Hi Vlot. Batt. Charger	Read Fault Codes	
Leon	2009-2015	5P	BD Hi Vlot. Batt. Charger	Clear Fault Codes	
Leon	2009-2015	5P	BD Hi Vlot. Batt. Charger	Measuring Blocks	
Leon	2009-2015	5P	BD Hi Vlot. Batt. Charger	Output Tests	
Leon	2009-2015	5P	BD Hi Vlot. Batt. Charger	Specia Functions	
Exeo	2009-2014	3R	01 Engine Electronics	Read Fault Codes	
Exeo	2009-2014	3R	01 Engine Electronics	Clear Fault Codes	
Exeo	2009-2014	3R	01 Engine Electronics	Measuring Blocks	
Exeo	2009-2014	3R	01 Engine Electronics	Output Tests	
Exeo	2009-2014	3R	01 Engine Electronics	Specia Functions	
Exeo	2009-2014	3R	02 Transmission Electronics	Read Fault Codes	
Exeo	2009-2014	3R	02 Transmission Electronics	Clear Fault Codes	
Exeo	2009-2014	3R	02 Transmission Electronics	Measuring Blocks	
Exeo	2009-2014	3R	02 Transmission Electronics	Output Tests	
Exeo	2009-2014	3R	02 Transmission Electronics	Specia Functions	
Exeo	2009-2014	3R	03 Brake Electronics	Read Fault Codes	
Exeo	2009-2014	3R	03 Brake Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Exeo	2009-2014	3R	03 Brake Electronics	Measuring Blocks	
Exeo	2009-2014	3R	03 Brake Electronics	Output Tests	
Exeo	2009-2014	3R	03 Brake Electronics	Specia Functions	
Exeo	2009-2014	3R	08 AC/Heating Electronics	Read Fault Codes	
Exeo	2009-2014	3R	08 AC/Heating Electronics	Clear Fault Codes	
Exeo	2009-2014	3R	08 AC/Heating Electronics	Measuring Blocks	
Exeo	2009-2014	3R	08 AC/Heating Electronics	Output Tests	
Exeo	2009-2014	3R	08 AC/Heating Electronics	Specia Functions	
Exeo	2009-2014	3R	09 Electronic Ctrl Electronics	Read Fault Codes	
Exeo	2009-2014	3R	09 Electronic Ctrl Electronics	Clear Fault Codes	
Exeo	2009-2014	3R	09 Electronic Ctrl Electronics	Measuring Blocks	
Exeo	2009-2014	3R	09 Electronic Ctrl Electronics	Output Tests	
Exeo	2009-2014	3R	09 Electronic Ctrl Electronics	Specia Functions	
Exeo	2009-2014	3R	10 Parking Assist System 2	Read Fault Codes	
Exeo	2009-2014	3R	10 Parking Assist System 2	Clear Fault Codes	
Exeo	2009-2014	3R	10 Parking Assist System 2	Measuring Blocks	
Exeo	2009-2014	3R	10 Parking Assist System 2	Output Tests	
Exeo	2009-2014	3R	10 Parking Assist System 2	Specia Functions	
Exeo	2009-2014	3R	15 Airbags	Read Fault Codes	
Exeo	2009-2014	3R	15 Airbags	Clear Fault Codes	
Exeo	2009-2014	3R	15 Airbags	Measuring Blocks	
Exeo	2009-2014	3R	15 Airbags	Output Tests	
Exeo	2009-2014	3R	15 Airbags	Specia Functions	
Exeo	2009-2014	3R	16 Steering Wheel Electronics	Read Fault Codes	
Exeo	2009-2014	3R	16 Steering Wheel Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Exeo	2009-2014	3R	16 Steering Wheel Electronics	Measuring Blocks	
Exeo	2009-2014	3R	16 Steering Wheel Electronics	Output Tests	
Exeo	2009-2014	3R	16 Steering Wheel Electronics	Specia Functions	
Exeo	2009-2014	3R	17 Instrument Cluster	Read Fault Codes	
Exeo	2009-2014	3R	17 Instrument Cluster	Clear Fault Codes	
Exeo	2009-2014	3R	17 Instrument Cluster	Measuring Blocks	
Exeo	2009-2014	3R	17 Instrument Cluster	Output Tests	
Exeo	2009-2014	3R	17 Instrument Cluster	Specia Functions	
Exeo	2009-2014	3R	19 Gateway Data Bus	Read Fault Codes	
Exeo	2009-2014	3R	19 Gateway Data Bus	Clear Fault Codes	
Exeo	2009-2014	3R	19 Gateway Data Bus	Measuring Blocks	
Exeo	2009-2014	3R	19 Gateway Data Bus	Output Tests	
Exeo	2009-2014	3R	19 Gateway Data Bus	Specia Functions	
Exeo	2009-2014	3R	25 Immobilizer	Read Fault Codes	
Exeo	2009-2014	3R	25 Immobilizer	Clear Fault Codes	
Exeo	2009-2014	3R	25 Immobilizer	Measuring Blocks	
Exeo	2009-2014	3R	25 Immobilizer	Output Tests	
Exeo	2009-2014	3R	25 Immobilizer	Specia Functions	
Exeo	2009-2014	3R	36 Driver`s Side Seat Adj.	Read Fault Codes	
Exeo	2009-2014	3R	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Exeo	2009-2014	3R	36 Driver`s Side Seat Adj.	Measuring Blocks	
Exeo	2009-2014	3R	36 Driver`s Side Seat Adj.	Output Tests	
Exeo	2009-2014	3R	36 Driver`s Side Seat Adj.	Specia Functions	
Exeo	2009-2014	3R	37 Navigation	Read Fault Codes	
Exeo	2009-2014	3R	37 Navigation	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Exeo	2009-2014	3R	37 Navigation	Measuring Blocks	
Exeo	2009-2014	3R	37 Navigation	Output Tests	
Exeo	2009-2014	3R	37 Navigation	Specia Functions	
Exeo	2009-2014	3R	45 Interior Monitoring	Read Fault Codes	
Exeo	2009-2014	3R	45 Interior Monitoring	Clear Fault Codes	
Exeo	2009-2014	3R	45 Interior Monitoring	Measuring Blocks	
Exeo	2009-2014	3R	45 Interior Monitoring	Output Tests	
Exeo	2009-2014	3R	45 Interior Monitoring	Specia Functions	
Exeo	2009-2014	3R	46 Central Control Module	Read Fault Codes	
Exeo	2009-2014	3R	46 Central Control Module	Clear Fault Codes	
Exeo	2009-2014	3R	46 Central Control Module	Measuring Blocks	
Exeo	2009-2014	3R	46 Central Control Module	Output Tests	
Exeo	2009-2014	3R	46 Central Control Module	Specia Functions	
Exeo	2009-2014	3R	4C Tyre Pressure Monitor II	Read Fault Codes	
Exeo	2009-2014	3R	4C Tyre Pressure Monitor II	Clear Fault Codes	
Exeo	2009-2014	3R	4C Tyre Pressure Monitor II	Measuring Blocks	
Exeo	2009-2014	3R	4C Tyre Pressure Monitor II	Output Tests	
Exeo	2009-2014	3R	4C Tyre Pressure Monitor II	Specia Functions	
Exeo	2009-2014	3R	55 Headlight Range Control	Read Fault Codes	
Exeo	2009-2014	3R	55 Headlight Range Control	Clear Fault Codes	
Exeo	2009-2014	3R	55 Headlight Range Control	Measuring Blocks	
Exeo	2009-2014	3R	55 Headlight Range Control	Output Tests	
Exeo	2009-2014	3R	55 Headlight Range Control	Specia Functions	
Exeo	2009-2014	3R	56 Radio	Read Fault Codes	
Exeo	2009-2014	3R	56 Radio	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Exeo	2009-2014	3R	56 Radio	Measuring Blocks	
Exeo	2009-2014	3R	56 Radio	Output Tests	
Exeo	2009-2014	3R	56 Radio	Specia Functions	
Exeo	2009-2014	3R	61 Battery Control	Read Fault Codes	
Exeo	2009-2014	3R	61 Battery Control	Clear Fault Codes	
Exeo	2009-2014	3R	61 Battery Control	Measuring Blocks	
Exeo	2009-2014	3R	61 Battery Control	Output Tests	
Exeo	2009-2014	3R	61 Battery Control	Specia Functions	
Exeo	2009-2014	3R	77 Telephone	Read Fault Codes	
Exeo	2009-2014	3R	77 Telephone	Clear Fault Codes	
Exeo	2009-2014	3R	77 Telephone	Measuring Blocks	
Exeo	2009-2014	3R	77 Telephone	Output Tests	
Exeo	2009-2014	3R	77 Telephone	Specia Functions	
Alhambra	2011-2018	7N	01 Engine Electronics	Read Fault Codes	
Alhambra	2011-2018	7N	01 Engine Electronics	Clear Fault Codes	
Alhambra	2011-2018	7N	01 Engine Electronics	Measuring Blocks	
Alhambra	2011-2018	7N	01 Engine Electronics	Output Tests	
Alhambra	2011-2018	7N	01 Engine Electronics	Specia Functions	
Alhambra	2011-2018	7N	02 Transmission Electronics	Read Fault Codes	
Alhambra	2011-2018	7N	02 Transmission Electronics	Clear Fault Codes	
Alhambra	2011-2018	7N	02 Transmission Electronics	Measuring Blocks	
Alhambra	2011-2018	7N	02 Transmission Electronics	Output Tests	
Alhambra	2011-2018	7N	02 Transmission Electronics	Specia Functions	
Alhambra	2011-2018	7N	03 Brake Electronics	Read Fault Codes	
Alhambra	2011-2018	7N	03 Brake Electronics	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	03 Brake Electronics	Measuring Blocks	
Alhambra	2011-2018	7N	03 Brake Electronics	Output Tests	
Alhambra	2011-2018	7N	03 Brake Electronics	Specia Functions	
Alhambra	2011-2018	7N	05 Access & Permissi.	Read Fault Codes	
Alhambra	2011-2018	7N	05 Access & Permissi.	Clear Fault Codes	
Alhambra	2011-2018	7N	05 Access & Permissi.	Measuring Blocks	
Alhambra	2011-2018	7N	05 Access & Permissi.	Output Tests	
Alhambra	2011-2018	7N	05 Access & Permissi.	Specia Functions	
Alhambra	2011-2018	7N	06 Passene. Seat Adj.	Read Fault Codes	
Alhambra	2011-2018	7N	06 Passene. Seat Adj.	Clear Fault Codes	
Alhambra	2011-2018	7N	06 Passene. Seat Adj.	Measuring Blocks	
Alhambra	2011-2018	7N	06 Passene. Seat Adj.	Output Tests	
Alhambra	2011-2018	7N	06 Passene. Seat Adj.	Specia Functions	
Alhambra	2011-2018	7N	08 AC/Heating Electronics	Read Fault Codes	
Alhambra	2011-2018	7N	08 AC/Heating Electronics	Clear Fault Codes	
Alhambra	2011-2018	7N	08 AC/Heating Electronics	Measuring Blocks	
Alhambra	2011-2018	7N	08 AC/Heating Electronics	Output Tests	
Alhambra	2011-2018	7N	08 AC/Heating Electronics	Specia Functions	
Alhambra	2011-2018	7N	09 Electronic Ctrl Electronics	Read Fault Codes	
Alhambra	2011-2018	7N	09 Electronic Ctrl Electronics	Clear Fault Codes	
Alhambra	2011-2018	7N	09 Electronic Ctrl Electronics	Measuring Blocks	
Alhambra	2011-2018	7N	09 Electronic Ctrl Electronics	Output Tests	
Alhambra	2011-2018	7N	09 Electronic Ctrl Electronics	Specia Functions	
Alhambra	2011-2018	7N	0F Radio Tuner-Digital	Read Fault Codes	
Alhambra	2011-2018	7N	0F Radio Tuner-Digital	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	0F Radio Tuner-Digital	Measuring Blocks	
Alhambra	2011-2018	7N	0F Radio Tuner-Digital	Output Tests	
Alhambra	2011-2018	7N	0F Radio Tuner-Digital	Specia Functions	
Alhambra	2011-2018	7N	10 Parking Assist System 2	Read Fault Codes	
Alhambra	2011-2018	7N	10 Parking Assist System 2	Clear Fault Codes	
Alhambra	2011-2018	7N	10 Parking Assist System 2	Measuring Blocks	
Alhambra	2011-2018	7N	10 Parking Assist System 2	Output Tests	
Alhambra	2011-2018	7N	10 Parking Assist System 2	Specia Functions	
Alhambra	2011-2018	7N	11 Engine Electronics 2	Read Fault Codes	
Alhambra	2011-2018	7N	11 Engine Electronics 2	Clear Fault Codes	
Alhambra	2011-2018	7N	11 Engine Electronics 2	Measuring Blocks	
Alhambra	2011-2018	7N	11 Engine Electronics 2	Output Tests	
Alhambra	2011-2018	7N	11 Engine Electronics 2	Specia Functions	
Alhambra	2011-2018	7N	13 Distance Control	Read Fault Codes	
Alhambra	2011-2018	7N	13 Distance Control	Clear Fault Codes	
Alhambra	2011-2018	7N	13 Distance Control	Measuring Blocks	
Alhambra	2011-2018	7N	13 Distance Control	Output Tests	
Alhambra	2011-2018	7N	13 Distance Control	Specia Functions	
Alhambra	2011-2018	7N	14 Wheel Damping Electronics	Read Fault Codes	
Alhambra	2011-2018	7N	14 Wheel Damping Electronics	Clear Fault Codes	
Alhambra	2011-2018	7N	14 Wheel Damping Electronics	Measuring Blocks	
Alhambra	2011-2018	7N	14 Wheel Damping Electronics	Output Tests	
Alhambra	2011-2018	7N	14 Wheel Damping Electronics	Specia Functions	
Alhambra	2011-2018	7N	15 Airbags	Read Fault Codes	
Alhambra	2011-2018	7N	15 Airbags	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	15 Airbags	Measuring Blocks	
Alhambra	2011-2018	7N	15 Airbags	Output Tests	
Alhambra	2011-2018	7N	15 Airbags	Specia Functions	
Alhambra	2011-2018	7N	16 Steering Wheel Electronics	Read Fault Codes	
Alhambra	2011-2018	7N	16 Steering Wheel Electronics	Clear Fault Codes	
Alhambra	2011-2018	7N	16 Steering Wheel Electronics	Measuring Blocks	
Alhambra	2011-2018	7N	16 Steering Wheel Electronics	Output Tests	
Alhambra	2011-2018	7N	16 Steering Wheel Electronics	Specia Functions	
Alhambra	2011-2018	7N	17 Instrument Cluster	Read Fault Codes	
Alhambra	2011-2018	7N	17 Instrument Cluster	Clear Fault Codes	
Alhambra	2011-2018	7N	17 Instrument Cluster	Measuring Blocks	
Alhambra	2011-2018	7N	17 Instrument Cluster	Output Tests	
Alhambra	2011-2018	7N	17 Instrument Cluster	Specia Functions	
Alhambra	2011-2018	7N	18 Aux Heating	Read Fault Codes	
Alhambra	2011-2018	7N	18 Aux Heating	Clear Fault Codes	
Alhambra	2011-2018	7N	18 Aux Heating	Measuring Blocks	
Alhambra	2011-2018	7N	18 Aux Heating	Output Tests	
Alhambra	2011-2018	7N	18 Aux Heating	Specia Functions	
Alhambra	2011-2018	7N	19 Gateway Data Bus	Read Fault Codes	
Alhambra	2011-2018	7N	19 Gateway Data Bus	Clear Fault Codes	
Alhambra	2011-2018	7N	19 Gateway Data Bus	Measuring Blocks	
Alhambra	2011-2018	7N	19 Gateway Data Bus	Output Tests	
Alhambra	2011-2018	7N	19 Gateway Data Bus	Specia Functions	
Alhambra	2011-2018	7N	1C Vehicle Position Detection	Read Fault Codes	
Alhambra	2011-2018	7N	1C Vehicle Position Detection	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	1C Vehicle Position Detection	Measuring Blocks	
Alhambra	2011-2018	7N	1C Vehicle Position Detection	Output Tests	
Alhambra	2011-2018	7N	1C Vehicle Position Detection	Specia Functions	
Alhambra	2011-2018	7N	20 High Beam Assistance Device	Read Fault Codes	
Alhambra	2011-2018	7N	20 High Beam Assistance Device	Clear Fault Codes	
Alhambra	2011-2018	7N	20 High Beam Assistance Device	Measuring Blocks	
Alhambra	2011-2018	7N	20 High Beam Assistance Device	Output Tests	
Alhambra	2011-2018	7N	20 High Beam Assistance Device	Specia Functions	
Alhambra	2011-2018	7N	22 4WD Electronics	Read Fault Codes	
Alhambra	2011-2018	7N	22 4WD Electronics	Clear Fault Codes	
Alhambra	2011-2018	7N	22 4WD Electronics	Measuring Blocks	
Alhambra	2011-2018	7N	22 4WD Electronics	Output Tests	
Alhambra	2011-2018	7N	22 4WD Electronics	Specia Functions	
Alhambra	2011-2018	7N	25 Immobilizer	Read Fault Codes	
Alhambra	2011-2018	7N	25 Immobilizer	Clear Fault Codes	
Alhambra	2011-2018	7N	25 Immobilizer	Measuring Blocks	
Alhambra	2011-2018	7N	25 Immobilizer	Output Tests	
Alhambra	2011-2018	7N	25 Immobilizer	Specia Functions	
Alhambra	2011-2018	7N	26 Electric Roof Control	Read Fault Codes	
Alhambra	2011-2018	7N	26 Electric Roof Control	Clear Fault Codes	
Alhambra	2011-2018	7N	26 Electric Roof Control	Measuring Blocks	
Alhambra	2011-2018	7N	26 Electric Roof Control	Output Tests	
Alhambra	2011-2018	7N	26 Electric Roof Control	Specia Functions	
Alhambra	2011-2018	7N	2B Steer Col Lock	Read Fault Codes	
Alhambra	2011-2018	7N	2B Steer Col Lock	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	2B Steer Col Lock	Measuring Blocks	
Alhambra	2011-2018	7N	2B Steer Col Lock	Output Tests	
Alhambra	2011-2018	7N	2B Steer Col Lock	Specia Functions	
Alhambra	2011-2018	7N	2E Media Player Position 3	Read Fault Codes	
Alhambra	2011-2018	7N	2E Media Player Position 3	Clear Fault Codes	
Alhambra	2011-2018	7N	2E Media Player Position 3	Measuring Blocks	
Alhambra	2011-2018	7N	2E Media Player Position 3	Output Tests	
Alhambra	2011-2018	7N	2E Media Player Position 3	Specia Functions	
Alhambra	2011-2018	7N	30 Special Function 2	Read Fault Codes	
Alhambra	2011-2018	7N	30 Special Function 2	Clear Fault Codes	
Alhambra	2011-2018	7N	30 Special Function 2	Measuring Blocks	
Alhambra	2011-2018	7N	30 Special Function 2	Output Tests	
Alhambra	2011-2018	7N	30 Special Function 2	Specia Functions	
Alhambra	2011-2018	7N	36 Driver`s Side Seat Adj.	Read Fault Codes	
Alhambra	2011-2018	7N	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Alhambra	2011-2018	7N	36 Driver`s Side Seat Adj.	Measuring Blocks	
Alhambra	2011-2018	7N	36 Driver`s Side Seat Adj.	Output Tests	
Alhambra	2011-2018	7N	36 Driver`s Side Seat Adj.	Specia Functions	
Alhambra	2011-2018	7N	37 Navigation	Read Fault Codes	
Alhambra	2011-2018	7N	37 Navigation	Clear Fault Codes	
Alhambra	2011-2018	7N	37 Navigation	Measuring Blocks	
Alhambra	2011-2018	7N	37 Navigation	Output Tests	
Alhambra	2011-2018	7N	37 Navigation	Specia Functions	
Alhambra	2011-2018	7N	3C Lane Departure Assistance System	Read Fault Codes	
Alhambra	2011-2018	7N	3C Lane Departure Assistance System	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	3C Lane Departure Assistance System	Measuring Blocks	
Alhambra	2011-2018	7N	3C Lane Departure Assistance System	Output Tests	
Alhambra	2011-2018	7N	3C Lane Departure Assistance System	Specia Functions	
Alhambra	2011-2018	7N	3D Special Function	Read Fault Codes	
Alhambra	2011-2018	7N	3D Special Function	Clear Fault Codes	
Alhambra	2011-2018	7N	3D Special Function	Measuring Blocks	
Alhambra	2011-2018	7N	3D Special Function	Output Tests	
Alhambra	2011-2018	7N	3D Special Function	Specia Functions	
Alhambra	2011-2018	7N	42 Driver-Door Elect.	Read Fault Codes	
Alhambra	2011-2018	7N	42 Driver-Door Elect.	Clear Fault Codes	
Alhambra	2011-2018	7N	42 Driver-Door Elect.	Measuring Blocks	
Alhambra	2011-2018	7N	42 Driver-Door Elect.	Output Tests	
Alhambra	2011-2018	7N	42 Driver-Door Elect.	Specia Functions	
Alhambra	2011-2018	7N	44 Steering Assistance	Read Fault Codes	
Alhambra	2011-2018	7N	44 Steering Assistance	Clear Fault Codes	
Alhambra	2011-2018	7N	44 Steering Assistance	Measuring Blocks	
Alhambra	2011-2018	7N	44 Steering Assistance	Output Tests	
Alhambra	2011-2018	7N	44 Steering Assistance	Specia Functions	
Alhambra	2011-2018	7N	46 Central Control Module	Read Fault Codes	
Alhambra	2011-2018	7N	46 Central Control Module	Clear Fault Codes	
Alhambra	2011-2018	7N	46 Central Control Module	Measuring Blocks	
Alhambra	2011-2018	7N	46 Central Control Module	Output Tests	
Alhambra	2011-2018	7N	46 Central Control Module	Specia Functions	
Alhambra	2011-2018	7N	47 Soundsystem	Read Fault Codes	
Alhambra	2011-2018	7N	47 Soundsystem	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	47 Soundsystem	Measuring Blocks	
Alhambra	2011-2018	7N	47 Soundsystem	Output Tests	
Alhambra	2011-2018	7N	47 Soundsystem	Specia Functions	
Alhambra	2011-2018	7N	4F Electronic Central Electric II	Read Fault Codes	
Alhambra	2011-2018	7N	4F Electronic Central Electric II	Clear Fault Codes	
Alhambra	2011-2018	7N	4F Electronic Central Electric II	Measuring Blocks	
Alhambra	2011-2018	7N	4F Electronic Central Electric II	Output Tests	
Alhambra	2011-2018	7N	4F Electronic Central Electric II	Specia Functions	
Alhambra	2011-2018	7N	51 Electric Drive	Read Fault Codes	
Alhambra	2011-2018	7N	51 Electric Drive	Clear Fault Codes	
Alhambra	2011-2018	7N	51 Electric Drive	Measuring Blocks	
Alhambra	2011-2018	7N	51 Electric Drive	Output Tests	
Alhambra	2011-2018	7N	51 Electric Drive	Specia Functions	
Alhambra	2011-2018	7N	52 Passe.-Door Elect.	Read Fault Codes	
Alhambra	2011-2018	7N	52 Passe.-Door Elect.	Clear Fault Codes	
Alhambra	2011-2018	7N	52 Passe.-Door Elect.	Measuring Blocks	
Alhambra	2011-2018	7N	52 Passe.-Door Elect.	Output Tests	
Alhambra	2011-2018	7N	52 Passe.-Door Elect.	Specia Functions	
Alhambra	2011-2018	7N	53 Parking Brake	Read Fault Codes	
Alhambra	2011-2018	7N	53 Parking Brake	Clear Fault Codes	
Alhambra	2011-2018	7N	53 Parking Brake	Measuring Blocks	
Alhambra	2011-2018	7N	53 Parking Brake	Output Tests	
Alhambra	2011-2018	7N	53 Parking Brake	Specia Functions	
Alhambra	2011-2018	7N	55 Headlight Range Control	Read Fault Codes	
Alhambra	2011-2018	7N	55 Headlight Range Control	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	55 Headlight Range Control	Measuring Blocks	
Alhambra	2011-2018	7N	55 Headlight Range Control	Output Tests	
Alhambra	2011-2018	7N	55 Headlight Range Control	Specia Functions	
Alhambra	2011-2018	7N	56 Radio	Read Fault Codes	
Alhambra	2011-2018	7N	56 Radio	Clear Fault Codes	
Alhambra	2011-2018	7N	56 Radio	Measuring Blocks	
Alhambra	2011-2018	7N	56 Radio	Output Tests	
Alhambra	2011-2018	7N	56 Radio	Specia Functions	
Alhambra	2011-2018	7N	57 TV-Tuner	Read Fault Codes	
Alhambra	2011-2018	7N	57 TV-Tuner	Clear Fault Codes	
Alhambra	2011-2018	7N	57 TV-Tuner	Measuring Blocks	
Alhambra	2011-2018	7N	57 TV-Tuner	Output Tests	
Alhambra	2011-2018	7N	57 TV-Tuner	Specia Functions	
Alhambra	2011-2018	7N	5F Information Electronic Equipment 1	Read Fault Codes	
Alhambra	2011-2018	7N	5F Information Electronic Equipment 1	Clear Fault Codes	
Alhambra	2011-2018	7N	5F Information Electronic Equipment 1	Measuring Blocks	
Alhambra	2011-2018	7N	5F Information Electronic Equipment 1	Output Tests	
Alhambra	2011-2018	7N	5F Information Electronic Equipment 1	Specia Functions	
Alhambra	2011-2018	7N	61 Battery Control	Read Fault Codes	
Alhambra	2011-2018	7N	61 Battery Control	Clear Fault Codes	
Alhambra	2011-2018	7N	61 Battery Control	Measuring Blocks	
Alhambra	2011-2018	7N	61 Battery Control	Output Tests	
Alhambra	2011-2018	7N	61 Battery Control	Specia Functions	
Alhambra	2011-2018	7N	62 LR-Door Electroni.	Read Fault Codes	
Alhambra	2011-2018	7N	62 LR-Door Electroni.	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	62 LR-Door Electroni.	Measuring Blocks	
Alhambra	2011-2018	7N	62 LR-Door Electroni.	Output Tests	
Alhambra	2011-2018	7N	62 LR-Door Electroni.	Specia Functions	
Alhambra	2011-2018	7N	63 Drvs Boarding Ass1	Read Fault Codes	
Alhambra	2011-2018	7N	63 Drvs Boarding Ass1	Clear Fault Codes	
Alhambra	2011-2018	7N	63 Drvs Boarding Ass1	Measuring Blocks	
Alhambra	2011-2018	7N	63 Drvs Boarding Ass1	Output Tests	
Alhambra	2011-2018	7N	63 Drvs Boarding Ass1	Specia Functions	
Alhambra	2011-2018	7N	65 Tyre Pressure Monitoring	Read Fault Codes	
Alhambra	2011-2018	7N	65 Tyre Pressure Monitoring	Clear Fault Codes	
Alhambra	2011-2018	7N	65 Tyre Pressure Monitoring	Measuring Blocks	
Alhambra	2011-2018	7N	65 Tyre Pressure Monitoring	Output Tests	
Alhambra	2011-2018	7N	65 Tyre Pressure Monitoring	Specia Functions	
Alhambra	2011-2018	7N	69 Trailer Function	Read Fault Codes	
Alhambra	2011-2018	7N	69 Trailer Function	Clear Fault Codes	
Alhambra	2011-2018	7N	69 Trailer Function	Measuring Blocks	
Alhambra	2011-2018	7N	69 Trailer Function	Output Tests	
Alhambra	2011-2018	7N	69 Trailer Function	Specia Functions	
Alhambra	2011-2018	7N	6C Rear Camera	Read Fault Codes	
Alhambra	2011-2018	7N	6C Rear Camera	Clear Fault Codes	
Alhambra	2011-2018	7N	6C Rear Camera	Measuring Blocks	
Alhambra	2011-2018	7N	6C Rear Camera	Output Tests	
Alhambra	2011-2018	7N	6C Rear Camera	Specia Functions	
Alhambra	2011-2018	7N	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Alhambra	2011-2018	7N	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Alhambra	2011-2018	7N	6D Electronic Equipment of Trunk Lid	Output Tests	
Alhambra	2011-2018	7N	6D Electronic Equipment of Trunk Lid	Specia Functions	
Alhambra	2011-2018	7N	72 RR-Door Electroni.	Read Fault Codes	
Alhambra	2011-2018	7N	72 RR-Door Electroni.	Clear Fault Codes	
Alhambra	2011-2018	7N	72 RR-Door Electroni.	Measuring Blocks	
Alhambra	2011-2018	7N	72 RR-Door Electroni.	Output Tests	
Alhambra	2011-2018	7N	72 RR-Door Electroni.	Specia Functions	
Alhambra	2011-2018	7N	73 Drvs Boarding Ass2	Read Fault Codes	
Alhambra	2011-2018	7N	73 Drvs Boarding Ass2	Clear Fault Codes	
Alhambra	2011-2018	7N	73 Drvs Boarding Ass2	Measuring Blocks	
Alhambra	2011-2018	7N	73 Drvs Boarding Ass2	Output Tests	
Alhambra	2011-2018	7N	73 Drvs Boarding Ass2	Specia Functions	
Alhambra	2011-2018	7N	75 Emergency Call Module	Read Fault Codes	
Alhambra	2011-2018	7N	75 Emergency Call Module	Clear Fault Codes	
Alhambra	2011-2018	7N	75 Emergency Call Module	Measuring Blocks	
Alhambra	2011-2018	7N	75 Emergency Call Module	Output Tests	
Alhambra	2011-2018	7N	75 Emergency Call Module	Specia Functions	
Alhambra	2011-2018	7N	76 Parking Aid	Read Fault Codes	
Alhambra	2011-2018	7N	76 Parking Aid	Clear Fault Codes	
Alhambra	2011-2018	7N	76 Parking Aid	Measuring Blocks	
Alhambra	2011-2018	7N	76 Parking Aid	Output Tests	
Alhambra	2011-2018	7N	76 Parking Aid	Specia Functions	
Alhambra	2011-2018	7N	77 Telephone	Read Fault Codes	
Alhambra	2011-2018	7N	77 Telephone	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	77 Telephone	Measuring Blocks	
Alhambra	2011-2018	7N	77 Telephone	Output Tests	
Alhambra	2011-2018	7N	77 Telephone	Specia Functions	
Alhambra	2011-2018	7N	7D Auxiliary Heater	Read Fault Codes	
Alhambra	2011-2018	7N	7D Auxiliary Heater	Clear Fault Codes	
Alhambra	2011-2018	7N	7D Auxiliary Heater	Measuring Blocks	
Alhambra	2011-2018	7N	7D Auxiliary Heater	Output Tests	
Alhambra	2011-2018	7N	7D Auxiliary Heater	Specia Functions	
Alhambra	2011-2018	7N	8C Hybrid Battery	Read Fault Codes	
Alhambra	2011-2018	7N	8C Hybrid Battery	Clear Fault Codes	
Alhambra	2011-2018	7N	8C Hybrid Battery	Measuring Blocks	
Alhambra	2011-2018	7N	8C Hybrid Battery	Output Tests	
Alhambra	2011-2018	7N	8C Hybrid Battery	Specia Functions	
Alhambra	2011-2018	7N	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Alhambra	2011-2018	7N	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Alhambra	2011-2018	7N	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Alhambra	2011-2018	7N	A5 Frt Sens.Drv.Assist	Output Tests	
Alhambra	2011-2018	7N	A5 Frt Sens.Drv.Assist	Specia Functions	
Alhambra	2011-2018	7N	B9 Aux.Display	Read Fault Codes	
Alhambra	2011-2018	7N	B9 Aux.Display	Clear Fault Codes	
Alhambra	2011-2018	7N	B9 Aux.Display	Measuring Blocks	
Alhambra	2011-2018	7N	B9 Aux.Display	Output Tests	
Alhambra	2011-2018	7N	B9 Aux.Display	Specia Functions	
Alhambra	2011-2018	7N	BD Hi Vlot. Batt. Charger	Read Fault Codes	
Alhambra	2011-2018	7N	BD Hi Vlot. Batt. Charger	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2011-2018	7N	BD Hi Vlot. Batt. Charger	Measuring Blocks	
Alhambra	2011-2018	7N	BD Hi Vlot. Batt. Charger	Output Tests	
Alhambra	2011-2018	7N	BD Hi Vlot. Batt. Charger	Specia Functions	
Alhambra	2011-2018	7N	BE Sliding Door Left	Read Fault Codes	
Alhambra	2011-2018	7N	BE Sliding Door Left	Clear Fault Codes	
Alhambra	2011-2018	7N	BE Sliding Door Left	Measuring Blocks	
Alhambra	2011-2018	7N	BE Sliding Door Left	Output Tests	
Alhambra	2011-2018	7N	BE Sliding Door Left	Specia Functions	
Alhambra	2011-2018	7N	BF Sliding Door Right	Read Fault Codes	
Alhambra	2011-2018	7N	BF Sliding Door Right	Clear Fault Codes	
Alhambra	2011-2018	7N	BF Sliding Door Right	Measuring Blocks	
Alhambra	2011-2018	7N	BF Sliding Door Right	Output Tests	
Alhambra	2011-2018	7N	BF Sliding Door Right	Specia Functions	
Mii	2012-2018	AA	01 Engine Electronics	Read Fault Codes	
Mii	2012-2018	AA	01 Engine Electronics	Clear Fault Codes	
Mii	2012-2018	AA	01 Engine Electronics	Measuring Blocks	
Mii	2012-2018	AA	01 Engine Electronics	Output Tests	
Mii	2012-2018	AA	01 Engine Electronics	Specia Functions	
Mii	2012-2018	AA	02 Transmission Electronics	Read Fault Codes	
Mii	2012-2018	AA	02 Transmission Electronics	Clear Fault Codes	
Mii	2012-2018	AA	02 Transmission Electronics	Measuring Blocks	
Mii	2012-2018	AA	02 Transmission Electronics	Output Tests	
Mii	2012-2018	AA	02 Transmission Electronics	Specia Functions	
Mii	2012-2018	AA	03 Brake Electronics	Read Fault Codes	
Mii	2012-2018	AA	03 Brake Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Mii	2012-2018	AA	03 Brake Electronics	Measuring Blocks	
Mii	2012-2018	AA	03 Brake Electronics	Output Tests	
Mii	2012-2018	AA	03 Brake Electronics	Specia Functions	
Mii	2012-2018	AA	08 AC/Heating Electronics	Read Fault Codes	
Mii	2012-2018	AA	08 AC/Heating Electronics	Clear Fault Codes	
Mii	2012-2018	AA	08 AC/Heating Electronics	Measuring Blocks	
Mii	2012-2018	AA	08 AC/Heating Electronics	Output Tests	
Mii	2012-2018	AA	08 AC/Heating Electronics	Specia Functions	
Mii	2012-2018	AA	09 Electronic Ctrl Electronics	Read Fault Codes	
Mii	2012-2018	AA	09 Electronic Ctrl Electronics	Clear Fault Codes	
Mii	2012-2018	AA	09 Electronic Ctrl Electronics	Measuring Blocks	
Mii	2012-2018	AA	09 Electronic Ctrl Electronics	Output Tests	
Mii	2012-2018	AA	09 Electronic Ctrl Electronics	Specia Functions	
Mii	2012-2018	AA	10 Parking Assist System 2	Read Fault Codes	
Mii	2012-2018	AA	10 Parking Assist System 2	Clear Fault Codes	
Mii	2012-2018	AA	10 Parking Assist System 2	Measuring Blocks	
Mii	2012-2018	AA	10 Parking Assist System 2	Output Tests	
Mii	2012-2018	AA	10 Parking Assist System 2	Specia Functions	
Mii	2012-2018	AA	15 Airbags	Read Fault Codes	
Mii	2012-2018	AA	15 Airbags	Clear Fault Codes	
Mii	2012-2018	AA	15 Airbags	Measuring Blocks	
Mii	2012-2018	AA	15 Airbags	Output Tests	
Mii	2012-2018	AA	15 Airbags	Specia Functions	
Mii	2012-2018	AA	17 Instrument Cluster	Read Fault Codes	
Mii	2012-2018	AA	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Mii	2012-2018	AA	17 Instrument Cluster	Measuring Blocks	
Mii	2012-2018	AA	17 Instrument Cluster	Output Tests	
Mii	2012-2018	AA	17 Instrument Cluster	Specia Functions	
Mii	2012-2018	AA	19 Gateway Data Bus	Read Fault Codes	
Mii	2012-2018	AA	19 Gateway Data Bus	Clear Fault Codes	
Mii	2012-2018	AA	19 Gateway Data Bus	Measuring Blocks	
Mii	2012-2018	AA	19 Gateway Data Bus	Output Tests	
Mii	2012-2018	AA	19 Gateway Data Bus	Specia Functions	
Mii	2012-2018	AA	23 Braker Booster	Read Fault Codes	
Mii	2012-2018	AA	23 Braker Booster	Clear Fault Codes	
Mii	2012-2018	AA	23 Braker Booster	Measuring Blocks	
Mii	2012-2018	AA	23 Braker Booster	Output Tests	
Mii	2012-2018	AA	23 Braker Booster	Specia Functions	
Mii	2012-2018	AA	25 Immobilizer	Read Fault Codes	
Mii	2012-2018	AA	25 Immobilizer	Clear Fault Codes	
Mii	2012-2018	AA	25 Immobilizer	Measuring Blocks	
Mii	2012-2018	AA	25 Immobilizer	Output Tests	
Mii	2012-2018	AA	25 Immobilizer	Specia Functions	
Mii	2012-2018	AA	44 Steering Assistance	Read Fault Codes	
Mii	2012-2018	AA	44 Steering Assistance	Clear Fault Codes	
Mii	2012-2018	AA	44 Steering Assistance	Measuring Blocks	
Mii	2012-2018	AA	44 Steering Assistance	Output Tests	
Mii	2012-2018	AA	44 Steering Assistance	Specia Functions	
Mii	2012-2018	AA	47 Soundsystem	Read Fault Codes	
Mii	2012-2018	AA	47 Soundsystem	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Mii	2012-2018	AA	47 Soundsystem	Measuring Blocks	
Mii	2012-2018	AA	47 Soundsystem	Output Tests	
Mii	2012-2018	AA	47 Soundsystem	Specia Functions	
Mii	2012-2018	AA	51 Electric Drive	Read Fault Codes	
Mii	2012-2018	AA	51 Electric Drive	Clear Fault Codes	
Mii	2012-2018	AA	51 Electric Drive	Measuring Blocks	
Mii	2012-2018	AA	51 Electric Drive	Output Tests	
Mii	2012-2018	AA	51 Electric Drive	Specia Functions	
Mii	2012-2018	AA	56 Radio	Read Fault Codes	
Mii	2012-2018	AA	56 Radio	Clear Fault Codes	
Mii	2012-2018	AA	56 Radio	Measuring Blocks	
Mii	2012-2018	AA	56 Radio	Output Tests	
Mii	2012-2018	AA	56 Radio	Specia Functions	
Mii	2012-2018	AA	5F Information Electronic Equipment 1	Read Fault Codes	
Mii	2012-2018	AA	5F Information Electronic Equipment 1	Clear Fault Codes	
Mii	2012-2018	AA	5F Information Electronic Equipment 1	Measuring Blocks	
Mii	2012-2018	AA	5F Information Electronic Equipment 1	Output Tests	
Mii	2012-2018	AA	5F Information Electronic Equipment 1	Specia Functions	
Mii	2012-2018	AA	61 Battery Control	Read Fault Codes	
Mii	2012-2018	AA	61 Battery Control	Clear Fault Codes	
Mii	2012-2018	AA	61 Battery Control	Measuring Blocks	
Mii	2012-2018	AA	61 Battery Control	Output Tests	
Mii	2012-2018	AA	61 Battery Control	Specia Functions	
Mii	2012-2018	AA	69 Trailer Function	Read Fault Codes	
Mii	2012-2018	AA	69 Trailer Function	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Mii	2012-2018	AA	69 Trailer Function	Measuring Blocks	
Mii	2012-2018	AA	69 Trailer Function	Output Tests	
Mii	2012-2018	AA	69 Trailer Function	Specia Functions	
Mii	2012-2018	AA	75 Emergency Call Module	Read Fault Codes	
Mii	2012-2018	AA	75 Emergency Call Module	Clear Fault Codes	
Mii	2012-2018	AA	75 Emergency Call Module	Measuring Blocks	
Mii	2012-2018	AA	75 Emergency Call Module	Output Tests	
Mii	2012-2018	AA	75 Emergency Call Module	Specia Functions	
Mii	2012-2018	AA	8C Hybrid Battery	Read Fault Codes	
Mii	2012-2018	AA	8C Hybrid Battery	Clear Fault Codes	
Mii	2012-2018	AA	8C Hybrid Battery	Measuring Blocks	
Mii	2012-2018	AA	8C Hybrid Battery	Output Tests	
Mii	2012-2018	AA	8C Hybrid Battery	Specia Functions	
Mii	2012-2018	AA	AD Brake Sensors	Read Fault Codes	
Mii	2012-2018	AA	AD Brake Sensors	Clear Fault Codes	
Mii	2012-2018	AA	AD Brake Sensors	Measuring Blocks	
Mii	2012-2018	AA	AD Brake Sensors	Output Tests	
Mii	2012-2018	AA	AD Brake Sensors	Specia Functions	
Mii	2012-2018	AA	BD Hi Vlot. Batt. Charger	Read Fault Codes	
Mii	2012-2018	AA	BD Hi Vlot. Batt. Charger	Clear Fault Codes	
Mii	2012-2018	AA	BD Hi Vlot. Batt. Charger	Measuring Blocks	
Mii	2012-2018	AA	BD Hi Vlot. Batt. Charger	Output Tests	
Mii	2012-2018	AA	BD Hi Vlot. Batt. Charger	Specia Functions	
Mii	2012-2018	AA	C0 Act. For Ext. Noise	Read Fault Codes	
Mii	2012-2018	AA	C0 Act. For Ext. Noise	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Mii	2012-2018	AA	C0 Act. For Ext. Noise	Measuring Blocks	
Mii	2012-2018	AA	C0 Act. For Ext. Noise	Output Tests	
Mii	2012-2018	AA	C0 Act. For Ext. Noise	Specia Functions	
Mii	2012-2018	AA	C6 Batt. Chrg	Read Fault Codes	
Mii	2012-2018	AA	C6 Batt. Chrg	Clear Fault Codes	
Mii	2012-2018	AA	C6 Batt. Chrg	Measuring Blocks	
Mii	2012-2018	AA	C6 Batt. Chrg	Output Tests	
Mii	2012-2018	AA	C6 Batt. Chrg	Specia Functions	
Ibiza GP2	2016-2017	6J	01 Engine Electronics	Read Fault Codes	
Ibiza GP2	2016-2017	6J	01 Engine Electronics	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	01 Engine Electronics	Measuring Blocks	
Ibiza GP2	2016-2017	6J	01 Engine Electronics	Output Tests	
Ibiza GP2	2016-2017	6J	01 Engine Electronics	Specia Functions	
Ibiza GP2	2016-2017	6J	02 Transmission Electronics	Read Fault Codes	
Ibiza GP2	2016-2017	6J	02 Transmission Electronics	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	02 Transmission Electronics	Measuring Blocks	
Ibiza GP2	2016-2017	6J	02 Transmission Electronics	Output Tests	
Ibiza GP2	2016-2017	6J	02 Transmission Electronics	Specia Functions	
Ibiza GP2	2016-2017	6J	03 Brake Electronics	Read Fault Codes	
Ibiza GP2	2016-2017	6J	03 Brake Electronics	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	03 Brake Electronics	Measuring Blocks	
Ibiza GP2	2016-2017	6J	03 Brake Electronics	Output Tests	
Ibiza GP2	2016-2017	6J	03 Brake Electronics	Specia Functions	
Ibiza GP2	2016-2017	6J	08 AC/Heating Electronics	Read Fault Codes	
Ibiza GP2	2016-2017	6J	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza GP2	2016-2017	6J	08 AC/Heating Electronics	Measuring Blocks	
Ibiza GP2	2016-2017	6J	08 AC/Heating Electronics	Output Tests	
Ibiza GP2	2016-2017	6J	08 AC/Heating Electronics	Specia Functions	
Ibiza GP2	2016-2017	6J	09 Electronic Ctrl Electronics	Read Fault Codes	
Ibiza GP2	2016-2017	6J	09 Electronic Ctrl Electronics	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	09 Electronic Ctrl Electronics	Measuring Blocks	
Ibiza GP2	2016-2017	6J	09 Electronic Ctrl Electronics	Output Tests	
Ibiza GP2	2016-2017	6J	09 Electronic Ctrl Electronics	Specia Functions	
Ibiza GP2	2016-2017	6J	14 Wheel Damping Electronics	Read Fault Codes	
Ibiza GP2	2016-2017	6J	14 Wheel Damping Electronics	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	14 Wheel Damping Electronics	Measuring Blocks	
Ibiza GP2	2016-2017	6J	14 Wheel Damping Electronics	Output Tests	
Ibiza GP2	2016-2017	6J	14 Wheel Damping Electronics	Specia Functions	
Ibiza GP2	2016-2017	6J	15 Airbags	Read Fault Codes	
Ibiza GP2	2016-2017	6J	15 Airbags	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	15 Airbags	Measuring Blocks	
Ibiza GP2	2016-2017	6J	15 Airbags	Output Tests	
Ibiza GP2	2016-2017	6J	15 Airbags	Specia Functions	
Ibiza GP2	2016-2017	6J	17 Instrument Cluster	Read Fault Codes	
Ibiza GP2	2016-2017	6J	17 Instrument Cluster	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	17 Instrument Cluster	Measuring Blocks	
Ibiza GP2	2016-2017	6J	17 Instrument Cluster	Output Tests	
Ibiza GP2	2016-2017	6J	17 Instrument Cluster	Specia Functions	
Ibiza GP2	2016-2017	6J	19 Gateway Data Bus	Read Fault Codes	
Ibiza GP2	2016-2017	6J	19 Gateway Data Bus	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza GP2	2016-2017	6J	19 Gateway Data Bus	Measuring Blocks	
Ibiza GP2	2016-2017	6J	19 Gateway Data Bus	Output Tests	
Ibiza GP2	2016-2017	6J	19 Gateway Data Bus	Specia Functions	
Ibiza GP2	2016-2017	6J	44 Steering Assistance	Read Fault Codes	
Ibiza GP2	2016-2017	6J	44 Steering Assistance	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	44 Steering Assistance	Measuring Blocks	
Ibiza GP2	2016-2017	6J	44 Steering Assistance	Output Tests	
Ibiza GP2	2016-2017	6J	44 Steering Assistance	Specia Functions	
Ibiza GP2	2016-2017	6J	55 Headlight Range Control	Read Fault Codes	
Ibiza GP2	2016-2017	6J	55 Headlight Range Control	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	55 Headlight Range Control	Measuring Blocks	
Ibiza GP2	2016-2017	6J	55 Headlight Range Control	Output Tests	
Ibiza GP2	2016-2017	6J	55 Headlight Range Control	Specia Functions	
Ibiza GP2	2016-2017	6J	5F Information Electronic Equipment 1	Read Fault Codes	
Ibiza GP2	2016-2017	6J	5F Information Electronic Equipment 1	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	5F Information Electronic Equipment 1	Measuring Blocks	
Ibiza GP2	2016-2017	6J	5F Information Electronic Equipment 1	Output Tests	
Ibiza GP2	2016-2017	6J	5F Information Electronic Equipment 1	Specia Functions	
Ibiza GP2	2016-2017	6J	69 Trailer Function	Read Fault Codes	
Ibiza GP2	2016-2017	6J	69 Trailer Function	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	69 Trailer Function	Measuring Blocks	
Ibiza GP2	2016-2017	6J	69 Trailer Function	Output Tests	
Ibiza GP2	2016-2017	6J	69 Trailer Function	Specia Functions	
Ibiza GP2	2016-2017	6J	76 Parking Aid	Read Fault Codes	
Ibiza GP2	2016-2017	6J	76 Parking Aid	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza GP2	2016-2017	6J	76 Parking Aid	Measuring Blocks	
Ibiza GP2	2016-2017	6J	76 Parking Aid	Output Tests	
Ibiza GP2	2016-2017	6J	76 Parking Aid	Specia Functions	
Ibiza GP2	2016-2017	6J	A9 Struct.Borne Sound	Read Fault Codes	
Ibiza GP2	2016-2017	6J	A9 Struct.Borne Sound	Clear Fault Codes	
Ibiza GP2	2016-2017	6J	A9 Struct.Borne Sound	Measuring Blocks	
Ibiza GP2	2016-2017	6J	A9 Struct.Borne Sound	Output Tests	
Ibiza GP2	2016-2017	6J	A9 Struct.Borne Sound	Specia Functions	
Leon	2006-2007	1P	01 Engine Electronics	Read Fault Codes	
Leon	2006-2007	1P	01 Engine Electronics	Clear Fault Codes	
Leon	2006-2007	1P	01 Engine Electronics	Measuring Blocks	
Leon	2006-2007	1P	01 Engine Electronics	Output Tests	
Leon	2006-2007	1P	01 Engine Electronics	Specia Functions	
Leon	2006-2007	1P	02 Transmission Electronics	Read Fault Codes	
Leon	2006-2007	1P	02 Transmission Electronics	Clear Fault Codes	
Leon	2006-2007	1P	02 Transmission Electronics	Measuring Blocks	
Leon	2006-2007	1P	02 Transmission Electronics	Output Tests	
Leon	2006-2007	1P	02 Transmission Electronics	Specia Functions	
Leon	2006-2007	1P	03 Brake Electronics	Read Fault Codes	
Leon	2006-2007	1P	03 Brake Electronics	Clear Fault Codes	
Leon	2006-2007	1P	03 Brake Electronics	Measuring Blocks	
Leon	2006-2007	1P	03 Brake Electronics	Output Tests	
Leon	2006-2007	1P	03 Brake Electronics	Specia Functions	
Leon	2006-2007	1P	08 AC/Heating Electronics	Read Fault Codes	
Leon	2006-2007	1P	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2006-2007	1P	08 AC/Heating Electronics	Measuring Blocks	
Leon	2006-2007	1P	08 AC/Heating Electronics	Output Tests	
Leon	2006-2007	1P	08 AC/Heating Electronics	Specia Functions	
Leon	2006-2007	1P	09 Electronic Ctrl Electronics	Read Fault Codes	
Leon	2006-2007	1P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Leon	2006-2007	1P	09 Electronic Ctrl Electronics	Measuring Blocks	
Leon	2006-2007	1P	09 Electronic Ctrl Electronics	Output Tests	
Leon	2006-2007	1P	09 Electronic Ctrl Electronics	Specia Functions	
Leon	2006-2007	1P	11 Engine Electronics 2	Read Fault Codes	
Leon	2006-2007	1P	11 Engine Electronics 2	Clear Fault Codes	
Leon	2006-2007	1P	11 Engine Electronics 2	Measuring Blocks	
Leon	2006-2007	1P	11 Engine Electronics 2	Output Tests	
Leon	2006-2007	1P	11 Engine Electronics 2	Specia Functions	
Leon	2006-2007	1P	15 Airbags	Read Fault Codes	
Leon	2006-2007	1P	15 Airbags	Clear Fault Codes	
Leon	2006-2007	1P	15 Airbags	Measuring Blocks	
Leon	2006-2007	1P	15 Airbags	Output Tests	
Leon	2006-2007	1P	15 Airbags	Specia Functions	
Leon	2006-2007	1P	16 Steering Wheel Electronics	Read Fault Codes	
Leon	2006-2007	1P	16 Steering Wheel Electronics	Clear Fault Codes	
Leon	2006-2007	1P	16 Steering Wheel Electronics	Measuring Blocks	
Leon	2006-2007	1P	16 Steering Wheel Electronics	Output Tests	
Leon	2006-2007	1P	16 Steering Wheel Electronics	Specia Functions	
Leon	2006-2007	1P	17 Instrument Cluster	Read Fault Codes	
Leon	2006-2007	1P	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2006-2007	1P	17 Instrument Cluster	Measuring Blocks	
Leon	2006-2007	1P	17 Instrument Cluster	Output Tests	
Leon	2006-2007	1P	17 Instrument Cluster	Specia Functions	
Leon	2006-2007	1P	19 Gateway Data Bus	Read Fault Codes	
Leon	2006-2007	1P	19 Gateway Data Bus	Clear Fault Codes	
Leon	2006-2007	1P	19 Gateway Data Bus	Measuring Blocks	
Leon	2006-2007	1P	19 Gateway Data Bus	Output Tests	
Leon	2006-2007	1P	19 Gateway Data Bus	Specia Functions	
Leon	2006-2007	1P	25 Immobilizer	Read Fault Codes	
Leon	2006-2007	1P	25 Immobilizer	Clear Fault Codes	
Leon	2006-2007	1P	25 Immobilizer	Measuring Blocks	
Leon	2006-2007	1P	25 Immobilizer	Output Tests	
Leon	2006-2007	1P	25 Immobilizer	Specia Functions	
Leon	2006-2007	1P	37 Navigation	Read Fault Codes	
Leon	2006-2007	1P	37 Navigation	Clear Fault Codes	
Leon	2006-2007	1P	37 Navigation	Measuring Blocks	
Leon	2006-2007	1P	37 Navigation	Output Tests	
Leon	2006-2007	1P	37 Navigation	Specia Functions	
Leon	2006-2007	1P	42 Driver-Door Elect.	Read Fault Codes	
Leon	2006-2007	1P	42 Driver-Door Elect.	Clear Fault Codes	
Leon	2006-2007	1P	42 Driver-Door Elect.	Measuring Blocks	
Leon	2006-2007	1P	42 Driver-Door Elect.	Output Tests	
Leon	2006-2007	1P	42 Driver-Door Elect.	Specia Functions	
Leon	2006-2007	1P	44 Steering Assistance	Read Fault Codes	
Leon	2006-2007	1P	44 Steering Assistance	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2006-2007	1P	44 Steering Assistance	Measuring Blocks	
Leon	2006-2007	1P	44 Steering Assistance	Output Tests	
Leon	2006-2007	1P	44 Steering Assistance	Specia Functions	
Leon	2006-2007	1P	46 Central Control Module	Read Fault Codes	
Leon	2006-2007	1P	46 Central Control Module	Clear Fault Codes	
Leon	2006-2007	1P	46 Central Control Module	Measuring Blocks	
Leon	2006-2007	1P	46 Central Control Module	Output Tests	
Leon	2006-2007	1P	46 Central Control Module	Specia Functions	
Leon	2006-2007	1P	51 Electric Drive	Read Fault Codes	
Leon	2006-2007	1P	51 Electric Drive	Clear Fault Codes	
Leon	2006-2007	1P	51 Electric Drive	Measuring Blocks	
Leon	2006-2007	1P	51 Electric Drive	Output Tests	
Leon	2006-2007	1P	51 Electric Drive	Specia Functions	
Leon	2006-2007	1P	52 Passe.-Door Elect.	Read Fault Codes	
Leon	2006-2007	1P	52 Passe.-Door Elect.	Clear Fault Codes	
Leon	2006-2007	1P	52 Passe.-Door Elect.	Measuring Blocks	
Leon	2006-2007	1P	52 Passe.-Door Elect.	Output Tests	
Leon	2006-2007	1P	52 Passe.-Door Elect.	Specia Functions	
Leon	2006-2007	1P	55 Headlight Range Control	Read Fault Codes	
Leon	2006-2007	1P	55 Headlight Range Control	Clear Fault Codes	
Leon	2006-2007	1P	55 Headlight Range Control	Measuring Blocks	
Leon	2006-2007	1P	55 Headlight Range Control	Output Tests	
Leon	2006-2007	1P	55 Headlight Range Control	Specia Functions	
Leon	2006-2007	1P	56 Radio	Read Fault Codes	
Leon	2006-2007	1P	56 Radio	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2006-2007	1P	56 Radio	Measuring Blocks	
Leon	2006-2007	1P	56 Radio	Output Tests	
Leon	2006-2007	1P	56 Radio	Specia Functions	
Leon	2006-2007	1P	62 LR-Door Electroni.	Read Fault Codes	
Leon	2006-2007	1P	62 LR-Door Electroni.	Clear Fault Codes	
Leon	2006-2007	1P	62 LR-Door Electroni.	Measuring Blocks	
Leon	2006-2007	1P	62 LR-Door Electroni.	Output Tests	
Leon	2006-2007	1P	62 LR-Door Electroni.	Specia Functions	
Leon	2006-2007	1P	69 Trailer Function	Read Fault Codes	
Leon	2006-2007	1P	69 Trailer Function	Clear Fault Codes	
Leon	2006-2007	1P	69 Trailer Function	Measuring Blocks	
Leon	2006-2007	1P	69 Trailer Function	Output Tests	
Leon	2006-2007	1P	69 Trailer Function	Specia Functions	
Leon	2006-2007	1P	72 RR-Door Electroni.	Read Fault Codes	
Leon	2006-2007	1P	72 RR-Door Electroni.	Clear Fault Codes	
Leon	2006-2007	1P	72 RR-Door Electroni.	Measuring Blocks	
Leon	2006-2007	1P	72 RR-Door Electroni.	Output Tests	
Leon	2006-2007	1P	72 RR-Door Electroni.	Specia Functions	
Leon	2006-2007	1P	76 Parking Aid	Read Fault Codes	
Leon	2006-2007	1P	76 Parking Aid	Clear Fault Codes	
Leon	2006-2007	1P	76 Parking Aid	Measuring Blocks	
Leon	2006-2007	1P	76 Parking Aid	Output Tests	
Leon	2006-2007	1P	76 Parking Aid	Specia Functions	
Leon	2006-2007	1P	77 Telephone	Read Fault Codes	
Leon	2006-2007	1P	77 Telephone	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2006-2007	1P	77 Telephone	Measuring Blocks	
Leon	2006-2007	1P	77 Telephone	Output Tests	
Leon	2006-2007	1P	77 Telephone	Specia Functions	
Leon	2006-2007	1P	7D Auxiliary Heater	Read Fault Codes	
Leon	2006-2007	1P	7D Auxiliary Heater	Clear Fault Codes	
Leon	2006-2007	1P	7D Auxiliary Heater	Measuring Blocks	
Leon	2006-2007	1P	7D Auxiliary Heater	Output Tests	
Leon	2006-2007	1P	7D Auxiliary Heater	Specia Functions	
Leon	2006-2007	1P	8C Hybrid Battery	Read Fault Codes	
Leon	2006-2007	1P	8C Hybrid Battery	Clear Fault Codes	
Leon	2006-2007	1P	8C Hybrid Battery	Measuring Blocks	
Leon	2006-2007	1P	8C Hybrid Battery	Output Tests	
Leon	2006-2007	1P	8C Hybrid Battery	Specia Functions	
Leon	2008	1P	01 Engine Electronics	Read Fault Codes	
Leon	2008	1P	01 Engine Electronics	Clear Fault Codes	
Leon	2008	1P	01 Engine Electronics	Measuring Blocks	
Leon	2008	1P	01 Engine Electronics	Output Tests	
Leon	2008	1P	01 Engine Electronics	Specia Functions	
Leon	2008	1P	02 Transmission Electronics	Read Fault Codes	
Leon	2008	1P	02 Transmission Electronics	Clear Fault Codes	
Leon	2008	1P	02 Transmission Electronics	Measuring Blocks	
Leon	2008	1P	02 Transmission Electronics	Output Tests	
Leon	2008	1P	02 Transmission Electronics	Specia Functions	
Leon	2008	1P	03 Brake Electronics	Read Fault Codes	
Leon	2008	1P	03 Brake Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2008	1P	03 Brake Electronics	Measuring Blocks	
Leon	2008	1P	03 Brake Electronics	Output Tests	
Leon	2008	1P	03 Brake Electronics	Specia Functions	
Leon	2008	1P	08 AC/Heating Electronics	Read Fault Codes	
Leon	2008	1P	08 AC/Heating Electronics	Clear Fault Codes	
Leon	2008	1P	08 AC/Heating Electronics	Measuring Blocks	
Leon	2008	1P	08 AC/Heating Electronics	Output Tests	
Leon	2008	1P	08 AC/Heating Electronics	Specia Functions	
Leon	2008	1P	09 Electronic Ctrl Electronics	Read Fault Codes	
Leon	2008	1P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Leon	2008	1P	09 Electronic Ctrl Electronics	Measuring Blocks	
Leon	2008	1P	09 Electronic Ctrl Electronics	Output Tests	
Leon	2008	1P	09 Electronic Ctrl Electronics	Specia Functions	
Leon	2008	1P	10 Parking Assist System 2	Read Fault Codes	
Leon	2008	1P	10 Parking Assist System 2	Clear Fault Codes	
Leon	2008	1P	10 Parking Assist System 2	Measuring Blocks	
Leon	2008	1P	10 Parking Assist System 2	Output Tests	
Leon	2008	1P	10 Parking Assist System 2	Specia Functions	
Leon	2008	1P	11 Engine Electronics 2	Read Fault Codes	
Leon	2008	1P	11 Engine Electronics 2	Clear Fault Codes	
Leon	2008	1P	11 Engine Electronics 2	Measuring Blocks	
Leon	2008	1P	11 Engine Electronics 2	Output Tests	
Leon	2008	1P	11 Engine Electronics 2	Specia Functions	
Leon	2008	1P	15 Airbags	Read Fault Codes	
Leon	2008	1P	15 Airbags	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2008	1P	15 Airbags	Measuring Blocks	
Leon	2008	1P	15 Airbags	Output Tests	
Leon	2008	1P	15 Airbags	Specia Functions	
Leon	2008	1P	16 Steering Wheel Electronics	Read Fault Codes	
Leon	2008	1P	16 Steering Wheel Electronics	Clear Fault Codes	
Leon	2008	1P	16 Steering Wheel Electronics	Measuring Blocks	
Leon	2008	1P	16 Steering Wheel Electronics	Output Tests	
Leon	2008	1P	16 Steering Wheel Electronics	Specia Functions	
Leon	2008	1P	17 Instrument Cluster	Read Fault Codes	
Leon	2008	1P	17 Instrument Cluster	Clear Fault Codes	
Leon	2008	1P	17 Instrument Cluster	Measuring Blocks	
Leon	2008	1P	17 Instrument Cluster	Output Tests	
Leon	2008	1P	17 Instrument Cluster	Specia Functions	
Leon	2008	1P	19 Gateway Data Bus	Read Fault Codes	
Leon	2008	1P	19 Gateway Data Bus	Clear Fault Codes	
Leon	2008	1P	19 Gateway Data Bus	Measuring Blocks	
Leon	2008	1P	19 Gateway Data Bus	Output Tests	
Leon	2008	1P	19 Gateway Data Bus	Specia Functions	
Leon	2008	1P	25 Immobilizer	Read Fault Codes	
Leon	2008	1P	25 Immobilizer	Clear Fault Codes	
Leon	2008	1P	25 Immobilizer	Measuring Blocks	
Leon	2008	1P	25 Immobilizer	Output Tests	
Leon	2008	1P	25 Immobilizer	Specia Functions	
Leon	2008	1P	37 Navigation	Read Fault Codes	
Leon	2008	1P	37 Navigation	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2008	1P	37 Navigation	Measuring Blocks	
Leon	2008	1P	37 Navigation	Output Tests	
Leon	2008	1P	37 Navigation	Specia Functions	
Leon	2008	1P	42 Driver-Door Elect.	Read Fault Codes	
Leon	2008	1P	42 Driver-Door Elect.	Clear Fault Codes	
Leon	2008	1P	42 Driver-Door Elect.	Measuring Blocks	
Leon	2008	1P	42 Driver-Door Elect.	Output Tests	
Leon	2008	1P	42 Driver-Door Elect.	Specia Functions	
Leon	2008	1P	44 Steering Assistance	Read Fault Codes	
Leon	2008	1P	44 Steering Assistance	Clear Fault Codes	
Leon	2008	1P	44 Steering Assistance	Measuring Blocks	
Leon	2008	1P	44 Steering Assistance	Output Tests	
Leon	2008	1P	44 Steering Assistance	Specia Functions	
Leon	2008	1P	46 Central Control Module	Read Fault Codes	
Leon	2008	1P	46 Central Control Module	Clear Fault Codes	
Leon	2008	1P	46 Central Control Module	Measuring Blocks	
Leon	2008	1P	46 Central Control Module	Output Tests	
Leon	2008	1P	46 Central Control Module	Specia Functions	
Leon	2008	1P	51 Electric Drive	Read Fault Codes	
Leon	2008	1P	51 Electric Drive	Clear Fault Codes	
Leon	2008	1P	51 Electric Drive	Measuring Blocks	
Leon	2008	1P	51 Electric Drive	Output Tests	
Leon	2008	1P	51 Electric Drive	Specia Functions	
Leon	2008	1P	52 Passe.-Door Elect.	Read Fault Codes	
Leon	2008	1P	52 Passe.-Door Elect.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2008	1P	52 Passe.-Door Elect.	Measuring Blocks	
Leon	2008	1P	52 Passe.-Door Elect.	Output Tests	
Leon	2008	1P	52 Passe.-Door Elect.	Specia Functions	
Leon	2008	1P	55 Headlight Range Control	Read Fault Codes	
Leon	2008	1P	55 Headlight Range Control	Clear Fault Codes	
Leon	2008	1P	55 Headlight Range Control	Measuring Blocks	
Leon	2008	1P	55 Headlight Range Control	Output Tests	
Leon	2008	1P	55 Headlight Range Control	Specia Functions	
Leon	2008	1P	56 Radio	Read Fault Codes	
Leon	2008	1P	56 Radio	Clear Fault Codes	
Leon	2008	1P	56 Radio	Measuring Blocks	
Leon	2008	1P	56 Radio	Output Tests	
Leon	2008	1P	56 Radio	Specia Functions	
Leon	2008	1P	62 LR-Door Electroni.	Read Fault Codes	
Leon	2008	1P	62 LR-Door Electroni.	Clear Fault Codes	
Leon	2008	1P	62 LR-Door Electroni.	Measuring Blocks	
Leon	2008	1P	62 LR-Door Electroni.	Output Tests	
Leon	2008	1P	62 LR-Door Electroni.	Specia Functions	
Leon	2008	1P	69 Trailer Function	Read Fault Codes	
Leon	2008	1P	69 Trailer Function	Clear Fault Codes	
Leon	2008	1P	69 Trailer Function	Measuring Blocks	
Leon	2008	1P	69 Trailer Function	Output Tests	
Leon	2008	1P	69 Trailer Function	Specia Functions	
Leon	2008	1P	72 RR-Door Electroni.	Read Fault Codes	
Leon	2008	1P	72 RR-Door Electroni.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2008	1P	72 RR-Door Electroni.	Measuring Blocks	
Leon	2008	1P	72 RR-Door Electroni.	Output Tests	
Leon	2008	1P	72 RR-Door Electroni.	Specia Functions	
Leon	2008	1P	76 Parking Aid	Read Fault Codes	
Leon	2008	1P	76 Parking Aid	Clear Fault Codes	
Leon	2008	1P	76 Parking Aid	Measuring Blocks	
Leon	2008	1P	76 Parking Aid	Output Tests	
Leon	2008	1P	76 Parking Aid	Specia Functions	
Leon	2008	1P	77 Telephone	Read Fault Codes	
Leon	2008	1P	77 Telephone	Clear Fault Codes	
Leon	2008	1P	77 Telephone	Measuring Blocks	
Leon	2008	1P	77 Telephone	Output Tests	
Leon	2008	1P	77 Telephone	Specia Functions	
Leon	2008	1P	7D Auxiliary Heater	Read Fault Codes	
Leon	2008	1P	7D Auxiliary Heater	Clear Fault Codes	
Leon	2008	1P	7D Auxiliary Heater	Measuring Blocks	
Leon	2008	1P	7D Auxiliary Heater	Output Tests	
Leon	2008	1P	7D Auxiliary Heater	Specia Functions	
Leon	2008	1P	8C Hybrid Battery	Read Fault Codes	
Leon	2008	1P	8C Hybrid Battery	Clear Fault Codes	
Leon	2008	1P	8C Hybrid Battery	Measuring Blocks	
Leon	2008	1P	8C Hybrid Battery	Output Tests	
Leon	2008	1P	8C Hybrid Battery	Specia Functions	
Altea	2004-2007	5P	01 Engine Electronics	Read Fault Codes	
Altea	2004-2007	5P	01 Engine Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2004-2007	5P	01 Engine Electronics	Measuring Blocks	
Altea	2004-2007	5P	01 Engine Electronics	Output Tests	
Altea	2004-2007	5P	01 Engine Electronics	Specia Functions	
Altea	2004-2007	5P	02 Transmission Electronics	Read Fault Codes	
Altea	2004-2007	5P	02 Transmission Electronics	Clear Fault Codes	
Altea	2004-2007	5P	02 Transmission Electronics	Measuring Blocks	
Altea	2004-2007	5P	02 Transmission Electronics	Output Tests	
Altea	2004-2007	5P	02 Transmission Electronics	Specia Functions	
Altea	2004-2007	5P	03 Brake Electronics	Read Fault Codes	
Altea	2004-2007	5P	03 Brake Electronics	Clear Fault Codes	
Altea	2004-2007	5P	03 Brake Electronics	Measuring Blocks	
Altea	2004-2007	5P	03 Brake Electronics	Output Tests	
Altea	2004-2007	5P	03 Brake Electronics	Specia Functions	
Altea	2004-2007	5P	08 AC/Heating Electronics	Read Fault Codes	
Altea	2004-2007	5P	08 AC/Heating Electronics	Clear Fault Codes	
Altea	2004-2007	5P	08 AC/Heating Electronics	Measuring Blocks	
Altea	2004-2007	5P	08 AC/Heating Electronics	Output Tests	
Altea	2004-2007	5P	08 AC/Heating Electronics	Specia Functions	
Altea	2004-2007	5P	09 Electronic Ctrl Electronics	Read Fault Codes	
Altea	2004-2007	5P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Altea	2004-2007	5P	09 Electronic Ctrl Electronics	Measuring Blocks	
Altea	2004-2007	5P	09 Electronic Ctrl Electronics	Output Tests	
Altea	2004-2007	5P	09 Electronic Ctrl Electronics	Specia Functions	
Altea	2004-2007	5P	11 Engine Electronics 2	Read Fault Codes	
Altea	2004-2007	5P	11 Engine Electronics 2	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2004-2007	5P	11 Engine Electronics 2	Measuring Blocks	
Altea	2004-2007	5P	11 Engine Electronics 2	Output Tests	
Altea	2004-2007	5P	11 Engine Electronics 2	Specia Functions	
Altea	2004-2007	5P	15 Airbags	Read Fault Codes	
Altea	2004-2007	5P	15 Airbags	Clear Fault Codes	
Altea	2004-2007	5P	15 Airbags	Measuring Blocks	
Altea	2004-2007	5P	15 Airbags	Output Tests	
Altea	2004-2007	5P	15 Airbags	Specia Functions	
Altea	2004-2007	5P	16 Steering Wheel Electronics	Read Fault Codes	
Altea	2004-2007	5P	16 Steering Wheel Electronics	Clear Fault Codes	
Altea	2004-2007	5P	16 Steering Wheel Electronics	Measuring Blocks	
Altea	2004-2007	5P	16 Steering Wheel Electronics	Output Tests	
Altea	2004-2007	5P	16 Steering Wheel Electronics	Specia Functions	
Altea	2004-2007	5P	17 Instrument Cluster	Read Fault Codes	
Altea	2004-2007	5P	17 Instrument Cluster	Clear Fault Codes	
Altea	2004-2007	5P	17 Instrument Cluster	Measuring Blocks	
Altea	2004-2007	5P	17 Instrument Cluster	Output Tests	
Altea	2004-2007	5P	17 Instrument Cluster	Specia Functions	
Altea	2004-2007	5P	19 Gateway Data Bus	Read Fault Codes	
Altea	2004-2007	5P	19 Gateway Data Bus	Clear Fault Codes	
Altea	2004-2007	5P	19 Gateway Data Bus	Measuring Blocks	
Altea	2004-2007	5P	19 Gateway Data Bus	Output Tests	
Altea	2004-2007	5P	19 Gateway Data Bus	Specia Functions	
Altea	2004-2007	5P	25 Immobilizer	Read Fault Codes	
Altea	2004-2007	5P	25 Immobilizer	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2004-2007	5P	25 Immobilizer	Measuring Blocks	
Altea	2004-2007	5P	25 Immobilizer	Output Tests	
Altea	2004-2007	5P	25 Immobilizer	Specia Functions	
Altea	2004-2007	5P	37 Navigation	Read Fault Codes	
Altea	2004-2007	5P	37 Navigation	Clear Fault Codes	
Altea	2004-2007	5P	37 Navigation	Measuring Blocks	
Altea	2004-2007	5P	37 Navigation	Output Tests	
Altea	2004-2007	5P	37 Navigation	Specia Functions	
Altea	2004-2007	5P	42 Driver-Door Elect.	Read Fault Codes	
Altea	2004-2007	5P	42 Driver-Door Elect.	Clear Fault Codes	
Altea	2004-2007	5P	42 Driver-Door Elect.	Measuring Blocks	
Altea	2004-2007	5P	42 Driver-Door Elect.	Output Tests	
Altea	2004-2007	5P	42 Driver-Door Elect.	Specia Functions	
Altea	2004-2007	5P	44 Steering Assistance	Read Fault Codes	
Altea	2004-2007	5P	44 Steering Assistance	Clear Fault Codes	
Altea	2004-2007	5P	44 Steering Assistance	Measuring Blocks	
Altea	2004-2007	5P	44 Steering Assistance	Output Tests	
Altea	2004-2007	5P	44 Steering Assistance	Specia Functions	
Altea	2004-2007	5P	46 Central Control Module	Read Fault Codes	
Altea	2004-2007	5P	46 Central Control Module	Clear Fault Codes	
Altea	2004-2007	5P	46 Central Control Module	Measuring Blocks	
Altea	2004-2007	5P	46 Central Control Module	Output Tests	
Altea	2004-2007	5P	46 Central Control Module	Specia Functions	
Altea	2004-2007	5P	51 Electric Drive	Read Fault Codes	
Altea	2004-2007	5P	51 Electric Drive	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2004-2007	5P	51 Electric Drive	Measuring Blocks	
Altea	2004-2007	5P	51 Electric Drive	Output Tests	
Altea	2004-2007	5P	51 Electric Drive	Specia Functions	
Altea	2004-2007	5P	52 Passe.-Door Elect.	Read Fault Codes	
Altea	2004-2007	5P	52 Passe.-Door Elect.	Clear Fault Codes	
Altea	2004-2007	5P	52 Passe.-Door Elect.	Measuring Blocks	
Altea	2004-2007	5P	52 Passe.-Door Elect.	Output Tests	
Altea	2004-2007	5P	52 Passe.-Door Elect.	Specia Functions	
Altea	2004-2007	5P	55 Headlight Range Control	Read Fault Codes	
Altea	2004-2007	5P	55 Headlight Range Control	Clear Fault Codes	
Altea	2004-2007	5P	55 Headlight Range Control	Measuring Blocks	
Altea	2004-2007	5P	55 Headlight Range Control	Output Tests	
Altea	2004-2007	5P	55 Headlight Range Control	Specia Functions	
Altea	2004-2007	5P	56 Radio	Read Fault Codes	
Altea	2004-2007	5P	56 Radio	Clear Fault Codes	
Altea	2004-2007	5P	56 Radio	Measuring Blocks	
Altea	2004-2007	5P	56 Radio	Output Tests	
Altea	2004-2007	5P	56 Radio	Specia Functions	
Altea	2004-2007	5P	62 LR-Door Electroni.	Read Fault Codes	
Altea	2004-2007	5P	62 LR-Door Electroni.	Clear Fault Codes	
Altea	2004-2007	5P	62 LR-Door Electroni.	Measuring Blocks	
Altea	2004-2007	5P	62 LR-Door Electroni.	Output Tests	
Altea	2004-2007	5P	62 LR-Door Electroni.	Specia Functions	
Altea	2004-2007	5P	69 Trailer Function	Read Fault Codes	
Altea	2004-2007	5P	69 Trailer Function	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2004-2007	5P	69 Trailer Function	Measuring Blocks	
Altea	2004-2007	5P	69 Trailer Function	Output Tests	
Altea	2004-2007	5P	69 Trailer Function	Specia Functions	
Altea	2004-2007	5P	72 RR-Door Electroni.	Read Fault Codes	
Altea	2004-2007	5P	72 RR-Door Electroni.	Clear Fault Codes	
Altea	2004-2007	5P	72 RR-Door Electroni.	Measuring Blocks	
Altea	2004-2007	5P	72 RR-Door Electroni.	Output Tests	
Altea	2004-2007	5P	72 RR-Door Electroni.	Specia Functions	
Altea	2004-2007	5P	76 Parking Aid	Read Fault Codes	
Altea	2004-2007	5P	76 Parking Aid	Clear Fault Codes	
Altea	2004-2007	5P	76 Parking Aid	Measuring Blocks	
Altea	2004-2007	5P	76 Parking Aid	Output Tests	
Altea	2004-2007	5P	76 Parking Aid	Specia Functions	
Altea	2004-2007	5P	77 Telephone	Read Fault Codes	
Altea	2004-2007	5P	77 Telephone	Clear Fault Codes	
Altea	2004-2007	5P	77 Telephone	Measuring Blocks	
Altea	2004-2007	5P	77 Telephone	Output Tests	
Altea	2004-2007	5P	77 Telephone	Specia Functions	
Altea	2004-2007	5P	7D Auxiliary Heater	Read Fault Codes	
Altea	2004-2007	5P	7D Auxiliary Heater	Clear Fault Codes	
Altea	2004-2007	5P	7D Auxiliary Heater	Measuring Blocks	
Altea	2004-2007	5P	7D Auxiliary Heater	Output Tests	
Altea	2004-2007	5P	7D Auxiliary Heater	Specia Functions	
Altea	2004-2007	5P	8C Hybrid Battery	Read Fault Codes	
Altea	2004-2007	5P	8C Hybrid Battery	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2004-2007	5P	8C Hybrid Battery	Measuring Blocks	
Altea	2004-2007	5P	8C Hybrid Battery	Output Tests	
Altea	2004-2007	5P	8C Hybrid Battery	Specia Functions	
Altea XL	2004-2007	5P	01 Engine Electronics	Read Fault Codes	
Altea XL	2004-2007	5P	01 Engine Electronics	Clear Fault Codes	
Altea XL	2004-2007	5P	01 Engine Electronics	Measuring Blocks	
Altea XL	2004-2007	5P	01 Engine Electronics	Output Tests	
Altea XL	2004-2007	5P	01 Engine Electronics	Specia Functions	
Altea XL	2004-2007	5P	02 Transmission Electronics	Read Fault Codes	
Altea XL	2004-2007	5P	02 Transmission Electronics	Clear Fault Codes	
Altea XL	2004-2007	5P	02 Transmission Electronics	Measuring Blocks	
Altea XL	2004-2007	5P	02 Transmission Electronics	Output Tests	
Altea XL	2004-2007	5P	02 Transmission Electronics	Specia Functions	
Altea XL	2004-2007	5P	03 Brake Electronics	Read Fault Codes	
Altea XL	2004-2007	5P	03 Brake Electronics	Clear Fault Codes	
Altea XL	2004-2007	5P	03 Brake Electronics	Measuring Blocks	
Altea XL	2004-2007	5P	03 Brake Electronics	Output Tests	
Altea XL	2004-2007	5P	03 Brake Electronics	Specia Functions	
Altea XL	2004-2007	5P	08 AC/Heating Electronics	Read Fault Codes	
Altea XL	2004-2007	5P	08 AC/Heating Electronics	Clear Fault Codes	
Altea XL	2004-2007	5P	08 AC/Heating Electronics	Measuring Blocks	
Altea XL	2004-2007	5P	08 AC/Heating Electronics	Output Tests	
Altea XL	2004-2007	5P	08 AC/Heating Electronics	Specia Functions	
Altea XL	2004-2007	5P	09 Electronic Ctrl Electronics	Read Fault Codes	
Altea XL	2004-2007	5P	09 Electronic Ctrl Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2004-2007	5P	09 Electronic Ctrl Electronics	Measuring Blocks	
Altea XL	2004-2007	5P	09 Electronic Ctrl Electronics	Output Tests	
Altea XL	2004-2007	5P	09 Electronic Ctrl Electronics	Specia Functions	
Altea XL	2004-2007	5P	11 Engine Electronics 2	Read Fault Codes	
Altea XL	2004-2007	5P	11 Engine Electronics 2	Clear Fault Codes	
Altea XL	2004-2007	5P	11 Engine Electronics 2	Measuring Blocks	
Altea XL	2004-2007	5P	11 Engine Electronics 2	Output Tests	
Altea XL	2004-2007	5P	11 Engine Electronics 2	Specia Functions	
Altea XL	2004-2007	5P	15 Airbags	Read Fault Codes	
Altea XL	2004-2007	5P	15 Airbags	Clear Fault Codes	
Altea XL	2004-2007	5P	15 Airbags	Measuring Blocks	
Altea XL	2004-2007	5P	15 Airbags	Output Tests	
Altea XL	2004-2007	5P	15 Airbags	Specia Functions	
Altea XL	2004-2007	5P	16 Steering Wheel Electronics	Read Fault Codes	
Altea XL	2004-2007	5P	16 Steering Wheel Electronics	Clear Fault Codes	
Altea XL	2004-2007	5P	16 Steering Wheel Electronics	Measuring Blocks	
Altea XL	2004-2007	5P	16 Steering Wheel Electronics	Output Tests	
Altea XL	2004-2007	5P	16 Steering Wheel Electronics	Specia Functions	
Altea XL	2004-2007	5P	17 Instrument Cluster	Read Fault Codes	
Altea XL	2004-2007	5P	17 Instrument Cluster	Clear Fault Codes	
Altea XL	2004-2007	5P	17 Instrument Cluster	Measuring Blocks	
Altea XL	2004-2007	5P	17 Instrument Cluster	Output Tests	
Altea XL	2004-2007	5P	17 Instrument Cluster	Specia Functions	
Altea XL	2004-2007	5P	19 Gateway Data Bus	Read Fault Codes	
Altea XL	2004-2007	5P	19 Gateway Data Bus	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2004-2007	5P	19 Gateway Data Bus	Measuring Blocks	
Altea XL	2004-2007	5P	19 Gateway Data Bus	Output Tests	
Altea XL	2004-2007	5P	19 Gateway Data Bus	Specia Functions	
Altea XL	2004-2007	5P	25 Immobilizer	Read Fault Codes	
Altea XL	2004-2007	5P	25 Immobilizer	Clear Fault Codes	
Altea XL	2004-2007	5P	25 Immobilizer	Measuring Blocks	
Altea XL	2004-2007	5P	25 Immobilizer	Output Tests	
Altea XL	2004-2007	5P	25 Immobilizer	Specia Functions	
Altea XL	2004-2007	5P	37 Navigation	Read Fault Codes	
Altea XL	2004-2007	5P	37 Navigation	Clear Fault Codes	
Altea XL	2004-2007	5P	37 Navigation	Measuring Blocks	
Altea XL	2004-2007	5P	37 Navigation	Output Tests	
Altea XL	2004-2007	5P	37 Navigation	Specia Functions	
Altea XL	2004-2007	5P	42 Driver-Door Elect.	Read Fault Codes	
Altea XL	2004-2007	5P	42 Driver-Door Elect.	Clear Fault Codes	
Altea XL	2004-2007	5P	42 Driver-Door Elect.	Measuring Blocks	
Altea XL	2004-2007	5P	42 Driver-Door Elect.	Output Tests	
Altea XL	2004-2007	5P	42 Driver-Door Elect.	Specia Functions	
Altea XL	2004-2007	5P	44 Steering Assistance	Read Fault Codes	
Altea XL	2004-2007	5P	44 Steering Assistance	Clear Fault Codes	
Altea XL	2004-2007	5P	44 Steering Assistance	Measuring Blocks	
Altea XL	2004-2007	5P	44 Steering Assistance	Output Tests	
Altea XL	2004-2007	5P	44 Steering Assistance	Specia Functions	
Altea XL	2004-2007	5P	46 Central Control Module	Read Fault Codes	
Altea XL	2004-2007	5P	46 Central Control Module	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2004-2007	5P	46 Central Control Module	Measuring Blocks	
Altea XL	2004-2007	5P	46 Central Control Module	Output Tests	
Altea XL	2004-2007	5P	46 Central Control Module	Specia Functions	
Altea XL	2004-2007	5P	51 Electric Drive	Read Fault Codes	
Altea XL	2004-2007	5P	51 Electric Drive	Clear Fault Codes	
Altea XL	2004-2007	5P	51 Electric Drive	Measuring Blocks	
Altea XL	2004-2007	5P	51 Electric Drive	Output Tests	
Altea XL	2004-2007	5P	51 Electric Drive	Specia Functions	
Altea XL	2004-2007	5P	52 Passe.-Door Elect.	Read Fault Codes	
Altea XL	2004-2007	5P	52 Passe.-Door Elect.	Clear Fault Codes	
Altea XL	2004-2007	5P	52 Passe.-Door Elect.	Measuring Blocks	
Altea XL	2004-2007	5P	52 Passe.-Door Elect.	Output Tests	
Altea XL	2004-2007	5P	52 Passe.-Door Elect.	Specia Functions	
Altea XL	2004-2007	5P	55 Headlight Range Control	Read Fault Codes	
Altea XL	2004-2007	5P	55 Headlight Range Control	Clear Fault Codes	
Altea XL	2004-2007	5P	55 Headlight Range Control	Measuring Blocks	
Altea XL	2004-2007	5P	55 Headlight Range Control	Output Tests	
Altea XL	2004-2007	5P	55 Headlight Range Control	Specia Functions	
Altea XL	2004-2007	5P	56 Radio	Read Fault Codes	
Altea XL	2004-2007	5P	56 Radio	Clear Fault Codes	
Altea XL	2004-2007	5P	56 Radio	Measuring Blocks	
Altea XL	2004-2007	5P	56 Radio	Output Tests	
Altea XL	2004-2007	5P	56 Radio	Specia Functions	
Altea XL	2004-2007	5P	62 LR-Door Electroni.	Read Fault Codes	
Altea XL	2004-2007	5P	62 LR-Door Electroni.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2004-2007	5P	62 LR-Door Electroni.	Measuring Blocks	
Altea XL	2004-2007	5P	62 LR-Door Electroni.	Output Tests	
Altea XL	2004-2007	5P	62 LR-Door Electroni.	Specia Functions	
Altea XL	2004-2007	5P	69 Trailer Function	Read Fault Codes	
Altea XL	2004-2007	5P	69 Trailer Function	Clear Fault Codes	
Altea XL	2004-2007	5P	69 Trailer Function	Measuring Blocks	
Altea XL	2004-2007	5P	69 Trailer Function	Output Tests	
Altea XL	2004-2007	5P	69 Trailer Function	Specia Functions	
Altea XL	2004-2007	5P	72 RR-Door Electroni.	Read Fault Codes	
Altea XL	2004-2007	5P	72 RR-Door Electroni.	Clear Fault Codes	
Altea XL	2004-2007	5P	72 RR-Door Electroni.	Measuring Blocks	
Altea XL	2004-2007	5P	72 RR-Door Electroni.	Output Tests	
Altea XL	2004-2007	5P	72 RR-Door Electroni.	Specia Functions	
Altea XL	2004-2007	5P	76 Parking Aid	Read Fault Codes	
Altea XL	2004-2007	5P	76 Parking Aid	Clear Fault Codes	
Altea XL	2004-2007	5P	76 Parking Aid	Measuring Blocks	
Altea XL	2004-2007	5P	76 Parking Aid	Output Tests	
Altea XL	2004-2007	5P	76 Parking Aid	Specia Functions	
Altea XL	2004-2007	5P	77 Telephone	Read Fault Codes	
Altea XL	2004-2007	5P	77 Telephone	Clear Fault Codes	
Altea XL	2004-2007	5P	77 Telephone	Measuring Blocks	
Altea XL	2004-2007	5P	77 Telephone	Output Tests	
Altea XL	2004-2007	5P	77 Telephone	Specia Functions	
Altea XL	2004-2007	5P	7D Auxiliary Heater	Read Fault Codes	
Altea XL	2004-2007	5P	7D Auxiliary Heater	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2004-2007	5P	7D Auxiliary Heater	Measuring Blocks	
Altea XL	2004-2007	5P	7D Auxiliary Heater	Output Tests	
Altea XL	2004-2007	5P	7D Auxiliary Heater	Specia Functions	
Altea XL	2004-2007	5P	8C Hybrid Battery	Read Fault Codes	
Altea XL	2004-2007	5P	8C Hybrid Battery	Clear Fault Codes	
Altea XL	2004-2007	5P	8C Hybrid Battery	Measuring Blocks	
Altea XL	2004-2007	5P	8C Hybrid Battery	Output Tests	
Altea XL	2004-2007	5P	8C Hybrid Battery	Specia Functions	
Toledo	2004-2007	5P	01 Engine Electronics	Read Fault Codes	
Toledo	2004-2007	5P	01 Engine Electronics	Clear Fault Codes	
Toledo	2004-2007	5P	01 Engine Electronics	Measuring Blocks	
Toledo	2004-2007	5P	01 Engine Electronics	Output Tests	
Toledo	2004-2007	5P	01 Engine Electronics	Specia Functions	
Toledo	2004-2007	5P	02 Transmission Electronics	Read Fault Codes	
Toledo	2004-2007	5P	02 Transmission Electronics	Clear Fault Codes	
Toledo	2004-2007	5P	02 Transmission Electronics	Measuring Blocks	
Toledo	2004-2007	5P	02 Transmission Electronics	Output Tests	
Toledo	2004-2007	5P	02 Transmission Electronics	Specia Functions	
Toledo	2004-2007	5P	03 Brake Electronics	Read Fault Codes	
Toledo	2004-2007	5P	03 Brake Electronics	Clear Fault Codes	
Toledo	2004-2007	5P	03 Brake Electronics	Measuring Blocks	
Toledo	2004-2007	5P	03 Brake Electronics	Output Tests	
Toledo	2004-2007	5P	03 Brake Electronics	Specia Functions	
Toledo	2004-2007	5P	08 AC/Heating Electronics	Read Fault Codes	
Toledo	2004-2007	5P	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2004-2007	5P	08 AC/Heating Electronics	Measuring Blocks	
Toledo	2004-2007	5P	08 AC/Heating Electronics	Output Tests	
Toledo	2004-2007	5P	08 AC/Heating Electronics	Specia Functions	
Toledo	2004-2007	5P	09 Electronic Ctrl Electronics	Read Fault Codes	
Toledo	2004-2007	5P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Toledo	2004-2007	5P	09 Electronic Ctrl Electronics	Measuring Blocks	
Toledo	2004-2007	5P	09 Electronic Ctrl Electronics	Output Tests	
Toledo	2004-2007	5P	09 Electronic Ctrl Electronics	Specia Functions	
Toledo	2004-2007	5P	11 Engine Electronics 2	Read Fault Codes	
Toledo	2004-2007	5P	11 Engine Electronics 2	Clear Fault Codes	
Toledo	2004-2007	5P	11 Engine Electronics 2	Measuring Blocks	
Toledo	2004-2007	5P	11 Engine Electronics 2	Output Tests	
Toledo	2004-2007	5P	11 Engine Electronics 2	Specia Functions	
Toledo	2004-2007	5P	15 Airbags	Read Fault Codes	
Toledo	2004-2007	5P	15 Airbags	Clear Fault Codes	
Toledo	2004-2007	5P	15 Airbags	Measuring Blocks	
Toledo	2004-2007	5P	15 Airbags	Output Tests	
Toledo	2004-2007	5P	15 Airbags	Specia Functions	
Toledo	2004-2007	5P	16 Steering Wheel Electronics	Read Fault Codes	
Toledo	2004-2007	5P	16 Steering Wheel Electronics	Clear Fault Codes	
Toledo	2004-2007	5P	16 Steering Wheel Electronics	Measuring Blocks	
Toledo	2004-2007	5P	16 Steering Wheel Electronics	Output Tests	
Toledo	2004-2007	5P	16 Steering Wheel Electronics	Specia Functions	
Toledo	2004-2007	5P	17 Instrument Cluster	Read Fault Codes	
Toledo	2004-2007	5P	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2004-2007	5P	17 Instrument Cluster	Measuring Blocks	
Toledo	2004-2007	5P	17 Instrument Cluster	Output Tests	
Toledo	2004-2007	5P	17 Instrument Cluster	Specia Functions	
Toledo	2004-2007	5P	19 Gateway Data Bus	Read Fault Codes	
Toledo	2004-2007	5P	19 Gateway Data Bus	Clear Fault Codes	
Toledo	2004-2007	5P	19 Gateway Data Bus	Measuring Blocks	
Toledo	2004-2007	5P	19 Gateway Data Bus	Output Tests	
Toledo	2004-2007	5P	19 Gateway Data Bus	Specia Functions	
Toledo	2004-2007	5P	25 Immobilizer	Read Fault Codes	
Toledo	2004-2007	5P	25 Immobilizer	Clear Fault Codes	
Toledo	2004-2007	5P	25 Immobilizer	Measuring Blocks	
Toledo	2004-2007	5P	25 Immobilizer	Output Tests	
Toledo	2004-2007	5P	25 Immobilizer	Specia Functions	
Toledo	2004-2007	5P	37 Navigation	Read Fault Codes	
Toledo	2004-2007	5P	37 Navigation	Clear Fault Codes	
Toledo	2004-2007	5P	37 Navigation	Measuring Blocks	
Toledo	2004-2007	5P	37 Navigation	Output Tests	
Toledo	2004-2007	5P	37 Navigation	Specia Functions	
Toledo	2004-2007	5P	42 Driver-Door Elect.	Read Fault Codes	
Toledo	2004-2007	5P	42 Driver-Door Elect.	Clear Fault Codes	
Toledo	2004-2007	5P	42 Driver-Door Elect.	Measuring Blocks	
Toledo	2004-2007	5P	42 Driver-Door Elect.	Output Tests	
Toledo	2004-2007	5P	42 Driver-Door Elect.	Specia Functions	
Toledo	2004-2007	5P	44 Steering Assistance	Read Fault Codes	
Toledo	2004-2007	5P	44 Steering Assistance	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2004-2007	5P	44 Steering Assistance	Measuring Blocks	
Toledo	2004-2007	5P	44 Steering Assistance	Output Tests	
Toledo	2004-2007	5P	44 Steering Assistance	Specia Functions	
Toledo	2004-2007	5P	46 Central Control Module	Read Fault Codes	
Toledo	2004-2007	5P	46 Central Control Module	Clear Fault Codes	
Toledo	2004-2007	5P	46 Central Control Module	Measuring Blocks	
Toledo	2004-2007	5P	46 Central Control Module	Output Tests	
Toledo	2004-2007	5P	46 Central Control Module	Specia Functions	
Toledo	2004-2007	5P	51 Electric Drive	Read Fault Codes	
Toledo	2004-2007	5P	51 Electric Drive	Clear Fault Codes	
Toledo	2004-2007	5P	51 Electric Drive	Measuring Blocks	
Toledo	2004-2007	5P	51 Electric Drive	Output Tests	
Toledo	2004-2007	5P	51 Electric Drive	Specia Functions	
Toledo	2004-2007	5P	52 Passe.-Door Elect.	Read Fault Codes	
Toledo	2004-2007	5P	52 Passe.-Door Elect.	Clear Fault Codes	
Toledo	2004-2007	5P	52 Passe.-Door Elect.	Measuring Blocks	
Toledo	2004-2007	5P	52 Passe.-Door Elect.	Output Tests	
Toledo	2004-2007	5P	52 Passe.-Door Elect.	Specia Functions	
Toledo	2004-2007	5P	55 Headlight Range Control	Read Fault Codes	
Toledo	2004-2007	5P	55 Headlight Range Control	Clear Fault Codes	
Toledo	2004-2007	5P	55 Headlight Range Control	Measuring Blocks	
Toledo	2004-2007	5P	55 Headlight Range Control	Output Tests	
Toledo	2004-2007	5P	55 Headlight Range Control	Specia Functions	
Toledo	2004-2007	5P	56 Radio	Read Fault Codes	
Toledo	2004-2007	5P	56 Radio	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2004-2007	5P	56 Radio	Measuring Blocks	
Toledo	2004-2007	5P	56 Radio	Output Tests	
Toledo	2004-2007	5P	56 Radio	Specia Functions	
Toledo	2004-2007	5P	62 LR-Door Electroni.	Read Fault Codes	
Toledo	2004-2007	5P	62 LR-Door Electroni.	Clear Fault Codes	
Toledo	2004-2007	5P	62 LR-Door Electroni.	Measuring Blocks	
Toledo	2004-2007	5P	62 LR-Door Electroni.	Output Tests	
Toledo	2004-2007	5P	62 LR-Door Electroni.	Specia Functions	
Toledo	2004-2007	5P	69 Trailer Function	Read Fault Codes	
Toledo	2004-2007	5P	69 Trailer Function	Clear Fault Codes	
Toledo	2004-2007	5P	69 Trailer Function	Measuring Blocks	
Toledo	2004-2007	5P	69 Trailer Function	Output Tests	
Toledo	2004-2007	5P	69 Trailer Function	Specia Functions	
Toledo	2004-2007	5P	72 RR-Door Electroni.	Read Fault Codes	
Toledo	2004-2007	5P	72 RR-Door Electroni.	Clear Fault Codes	
Toledo	2004-2007	5P	72 RR-Door Electroni.	Measuring Blocks	
Toledo	2004-2007	5P	72 RR-Door Electroni.	Output Tests	
Toledo	2004-2007	5P	72 RR-Door Electroni.	Specia Functions	
Toledo	2004-2007	5P	76 Parking Aid	Read Fault Codes	
Toledo	2004-2007	5P	76 Parking Aid	Clear Fault Codes	
Toledo	2004-2007	5P	76 Parking Aid	Measuring Blocks	
Toledo	2004-2007	5P	76 Parking Aid	Output Tests	
Toledo	2004-2007	5P	76 Parking Aid	Specia Functions	
Toledo	2004-2007	5P	77 Telephone	Read Fault Codes	
Toledo	2004-2007	5P	77 Telephone	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2004-2007	5P	77 Telephone	Measuring Blocks	
Toledo	2004-2007	5P	77 Telephone	Output Tests	
Toledo	2004-2007	5P	77 Telephone	Specia Functions	
Toledo	2004-2007	5P	7D Auxiliary Heater	Read Fault Codes	
Toledo	2004-2007	5P	7D Auxiliary Heater	Clear Fault Codes	
Toledo	2004-2007	5P	7D Auxiliary Heater	Measuring Blocks	
Toledo	2004-2007	5P	7D Auxiliary Heater	Output Tests	
Toledo	2004-2007	5P	7D Auxiliary Heater	Specia Functions	
Toledo	2004-2007	5P	8C Hybrid Battery	Read Fault Codes	
Toledo	2004-2007	5P	8C Hybrid Battery	Clear Fault Codes	
Toledo	2004-2007	5P	8C Hybrid Battery	Measuring Blocks	
Toledo	2004-2007	5P	8C Hybrid Battery	Output Tests	
Toledo	2004-2007	5P	8C Hybrid Battery	Specia Functions	
Altea	2008	5P	01 Engine Electronics	Read Fault Codes	
Altea	2008	5P	01 Engine Electronics	Clear Fault Codes	
Altea	2008	5P	01 Engine Electronics	Measuring Blocks	
Altea	2008	5P	01 Engine Electronics	Output Tests	
Altea	2008	5P	01 Engine Electronics	Specia Functions	
Altea	2008	5P	02 Transmission Electronics	Read Fault Codes	
Altea	2008	5P	02 Transmission Electronics	Clear Fault Codes	
Altea	2008	5P	02 Transmission Electronics	Measuring Blocks	
Altea	2008	5P	02 Transmission Electronics	Output Tests	
Altea	2008	5P	02 Transmission Electronics	Specia Functions	
Altea	2008	5P	03 Brake Electronics	Read Fault Codes	
Altea	2008	5P	03 Brake Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2008	5P	03 Brake Electronics	Measuring Blocks	
Altea	2008	5P	03 Brake Electronics	Output Tests	
Altea	2008	5P	03 Brake Electronics	Specia Functions	
Altea	2008	5P	08 AC/Heating Electronics	Read Fault Codes	
Altea	2008	5P	08 AC/Heating Electronics	Clear Fault Codes	
Altea	2008	5P	08 AC/Heating Electronics	Measuring Blocks	
Altea	2008	5P	08 AC/Heating Electronics	Output Tests	
Altea	2008	5P	08 AC/Heating Electronics	Specia Functions	
Altea	2008	5P	09 Electronic Ctrl Electronics	Read Fault Codes	
Altea	2008	5P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Altea	2008	5P	09 Electronic Ctrl Electronics	Measuring Blocks	
Altea	2008	5P	09 Electronic Ctrl Electronics	Output Tests	
Altea	2008	5P	09 Electronic Ctrl Electronics	Specia Functions	
Altea	2008	5P	10 Parking Assist System 2	Read Fault Codes	
Altea	2008	5P	10 Parking Assist System 2	Clear Fault Codes	
Altea	2008	5P	10 Parking Assist System 2	Measuring Blocks	
Altea	2008	5P	10 Parking Assist System 2	Output Tests	
Altea	2008	5P	10 Parking Assist System 2	Specia Functions	
Altea	2008	5P	11 Engine Electronics 2	Read Fault Codes	
Altea	2008	5P	11 Engine Electronics 2	Clear Fault Codes	
Altea	2008	5P	11 Engine Electronics 2	Measuring Blocks	
Altea	2008	5P	11 Engine Electronics 2	Output Tests	
Altea	2008	5P	11 Engine Electronics 2	Specia Functions	
Altea	2008	5P	15 Airbags	Read Fault Codes	
Altea	2008	5P	15 Airbags	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2008	5P	15 Airbags	Measuring Blocks	
Altea	2008	5P	15 Airbags	Output Tests	
Altea	2008	5P	15 Airbags	Specia Functions	
Altea	2008	5P	16 Steering Wheel Electronics	Read Fault Codes	
Altea	2008	5P	16 Steering Wheel Electronics	Clear Fault Codes	
Altea	2008	5P	16 Steering Wheel Electronics	Measuring Blocks	
Altea	2008	5P	16 Steering Wheel Electronics	Output Tests	
Altea	2008	5P	16 Steering Wheel Electronics	Specia Functions	
Altea	2008	5P	17 Instrument Cluster	Read Fault Codes	
Altea	2008	5P	17 Instrument Cluster	Clear Fault Codes	
Altea	2008	5P	17 Instrument Cluster	Measuring Blocks	
Altea	2008	5P	17 Instrument Cluster	Output Tests	
Altea	2008	5P	17 Instrument Cluster	Specia Functions	
Altea	2008	5P	19 Gateway Data Bus	Read Fault Codes	
Altea	2008	5P	19 Gateway Data Bus	Clear Fault Codes	
Altea	2008	5P	19 Gateway Data Bus	Measuring Blocks	
Altea	2008	5P	19 Gateway Data Bus	Output Tests	
Altea	2008	5P	19 Gateway Data Bus	Specia Functions	
Altea	2008	5P	22 4WD Electronics	Read Fault Codes	
Altea	2008	5P	22 4WD Electronics	Clear Fault Codes	
Altea	2008	5P	22 4WD Electronics	Measuring Blocks	
Altea	2008	5P	22 4WD Electronics	Output Tests	
Altea	2008	5P	22 4WD Electronics	Specia Functions	
Altea	2008	5P	25 Immobilizer	Read Fault Codes	
Altea	2008	5P	25 Immobilizer	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2008	5P	25 Immobilizer	Measuring Blocks	
Altea	2008	5P	25 Immobilizer	Output Tests	
Altea	2008	5P	25 Immobilizer	Specia Functions	
Altea	2008	5P	37 Navigation	Read Fault Codes	
Altea	2008	5P	37 Navigation	Clear Fault Codes	
Altea	2008	5P	37 Navigation	Measuring Blocks	
Altea	2008	5P	37 Navigation	Output Tests	
Altea	2008	5P	37 Navigation	Specia Functions	
Altea	2008	5P	42 Driver-Door Elect.	Read Fault Codes	
Altea	2008	5P	42 Driver-Door Elect.	Clear Fault Codes	
Altea	2008	5P	42 Driver-Door Elect.	Measuring Blocks	
Altea	2008	5P	42 Driver-Door Elect.	Output Tests	
Altea	2008	5P	42 Driver-Door Elect.	Specia Functions	
Altea	2008	5P	44 Steering Assistance	Read Fault Codes	
Altea	2008	5P	44 Steering Assistance	Clear Fault Codes	
Altea	2008	5P	44 Steering Assistance	Measuring Blocks	
Altea	2008	5P	44 Steering Assistance	Output Tests	
Altea	2008	5P	44 Steering Assistance	Specia Functions	
Altea	2008	5P	46 Central Control Module	Read Fault Codes	
Altea	2008	5P	46 Central Control Module	Clear Fault Codes	
Altea	2008	5P	46 Central Control Module	Measuring Blocks	
Altea	2008	5P	46 Central Control Module	Output Tests	
Altea	2008	5P	46 Central Control Module	Specia Functions	
Altea	2008	5P	51 Electric Drive	Read Fault Codes	
Altea	2008	5P	51 Electric Drive	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2008	5P	51 Electric Drive	Measuring Blocks	
Altea	2008	5P	51 Electric Drive	Output Tests	
Altea	2008	5P	51 Electric Drive	Specia Functions	
Altea	2008	5P	52 Passe.-Door Elect.	Read Fault Codes	
Altea	2008	5P	52 Passe.-Door Elect.	Clear Fault Codes	
Altea	2008	5P	52 Passe.-Door Elect.	Measuring Blocks	
Altea	2008	5P	52 Passe.-Door Elect.	Output Tests	
Altea	2008	5P	52 Passe.-Door Elect.	Specia Functions	
Altea	2008	5P	55 Headlight Range Control	Read Fault Codes	
Altea	2008	5P	55 Headlight Range Control	Clear Fault Codes	
Altea	2008	5P	55 Headlight Range Control	Measuring Blocks	
Altea	2008	5P	55 Headlight Range Control	Output Tests	
Altea	2008	5P	55 Headlight Range Control	Specia Functions	
Altea	2008	5P	56 Radio	Read Fault Codes	
Altea	2008	5P	56 Radio	Clear Fault Codes	
Altea	2008	5P	56 Radio	Measuring Blocks	
Altea	2008	5P	56 Radio	Output Tests	
Altea	2008	5P	56 Radio	Specia Functions	
Altea	2008	5P	62 LR-Door Electroni.	Read Fault Codes	
Altea	2008	5P	62 LR-Door Electroni.	Clear Fault Codes	
Altea	2008	5P	62 LR-Door Electroni.	Measuring Blocks	
Altea	2008	5P	62 LR-Door Electroni.	Output Tests	
Altea	2008	5P	62 LR-Door Electroni.	Specia Functions	
Altea	2008	5P	69 Trailer Function	Read Fault Codes	
Altea	2008	5P	69 Trailer Function	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2008	5P	69 Trailer Function	Measuring Blocks	
Altea	2008	5P	69 Trailer Function	Output Tests	
Altea	2008	5P	69 Trailer Function	Specia Functions	
Altea	2008	5P	72 RR-Door Electroni.	Read Fault Codes	
Altea	2008	5P	72 RR-Door Electroni.	Clear Fault Codes	
Altea	2008	5P	72 RR-Door Electroni.	Measuring Blocks	
Altea	2008	5P	72 RR-Door Electroni.	Output Tests	
Altea	2008	5P	72 RR-Door Electroni.	Specia Functions	
Altea	2008	5P	76 Parking Aid	Read Fault Codes	
Altea	2008	5P	76 Parking Aid	Clear Fault Codes	
Altea	2008	5P	76 Parking Aid	Measuring Blocks	
Altea	2008	5P	76 Parking Aid	Output Tests	
Altea	2008	5P	76 Parking Aid	Specia Functions	
Altea	2008	5P	77 Telephone	Read Fault Codes	
Altea	2008	5P	77 Telephone	Clear Fault Codes	
Altea	2008	5P	77 Telephone	Measuring Blocks	
Altea	2008	5P	77 Telephone	Output Tests	
Altea	2008	5P	77 Telephone	Specia Functions	
Altea	2008	5P	7D Auxiliary Heater	Read Fault Codes	
Altea	2008	5P	7D Auxiliary Heater	Clear Fault Codes	
Altea	2008	5P	7D Auxiliary Heater	Measuring Blocks	
Altea	2008	5P	7D Auxiliary Heater	Output Tests	
Altea	2008	5P	7D Auxiliary Heater	Specia Functions	
Altea	2008	5P	8C Hybrid Battery	Read Fault Codes	
Altea	2008	5P	8C Hybrid Battery	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea	2008	5P	8C Hybrid Battery	Measuring Blocks	
Altea	2008	5P	8C Hybrid Battery	Output Tests	
Altea	2008	5P	8C Hybrid Battery	Specia Functions	
Altea XL	2008	5P	01 Engine Electronics	Read Fault Codes	
Altea XL	2008	5P	01 Engine Electronics	Clear Fault Codes	
Altea XL	2008	5P	01 Engine Electronics	Measuring Blocks	
Altea XL	2008	5P	01 Engine Electronics	Output Tests	
Altea XL	2008	5P	01 Engine Electronics	Specia Functions	
Altea XL	2008	5P	02 Transmission Electronics	Read Fault Codes	
Altea XL	2008	5P	02 Transmission Electronics	Clear Fault Codes	
Altea XL	2008	5P	02 Transmission Electronics	Measuring Blocks	
Altea XL	2008	5P	02 Transmission Electronics	Output Tests	
Altea XL	2008	5P	02 Transmission Electronics	Specia Functions	
Altea XL	2008	5P	03 Brake Electronics	Read Fault Codes	
Altea XL	2008	5P	03 Brake Electronics	Clear Fault Codes	
Altea XL	2008	5P	03 Brake Electronics	Measuring Blocks	
Altea XL	2008	5P	03 Brake Electronics	Output Tests	
Altea XL	2008	5P	03 Brake Electronics	Specia Functions	
Altea XL	2008	5P	08 AC/Heating Electronics	Read Fault Codes	
Altea XL	2008	5P	08 AC/Heating Electronics	Clear Fault Codes	
Altea XL	2008	5P	08 AC/Heating Electronics	Measuring Blocks	
Altea XL	2008	5P	08 AC/Heating Electronics	Output Tests	
Altea XL	2008	5P	08 AC/Heating Electronics	Specia Functions	
Altea XL	2008	5P	09 Electronic Ctrl Electronics	Read Fault Codes	
Altea XL	2008	5P	09 Electronic Ctrl Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2008	5P	09 Electronic Ctrl Electronics	Measuring Blocks	
Altea XL	2008	5P	09 Electronic Ctrl Electronics	Output Tests	
Altea XL	2008	5P	09 Electronic Ctrl Electronics	Specia Functions	
Altea XL	2008	5P	10 Parking Assist System 2	Read Fault Codes	
Altea XL	2008	5P	10 Parking Assist System 2	Clear Fault Codes	
Altea XL	2008	5P	10 Parking Assist System 2	Measuring Blocks	
Altea XL	2008	5P	10 Parking Assist System 2	Output Tests	
Altea XL	2008	5P	10 Parking Assist System 2	Specia Functions	
Altea XL	2008	5P	11 Engine Electronics 2	Read Fault Codes	
Altea XL	2008	5P	11 Engine Electronics 2	Clear Fault Codes	
Altea XL	2008	5P	11 Engine Electronics 2	Measuring Blocks	
Altea XL	2008	5P	11 Engine Electronics 2	Output Tests	
Altea XL	2008	5P	11 Engine Electronics 2	Specia Functions	
Altea XL	2008	5P	15 Airbags	Read Fault Codes	
Altea XL	2008	5P	15 Airbags	Clear Fault Codes	
Altea XL	2008	5P	15 Airbags	Measuring Blocks	
Altea XL	2008	5P	15 Airbags	Output Tests	
Altea XL	2008	5P	15 Airbags	Specia Functions	
Altea XL	2008	5P	16 Steering Wheel Electronics	Read Fault Codes	
Altea XL	2008	5P	16 Steering Wheel Electronics	Clear Fault Codes	
Altea XL	2008	5P	16 Steering Wheel Electronics	Measuring Blocks	
Altea XL	2008	5P	16 Steering Wheel Electronics	Output Tests	
Altea XL	2008	5P	16 Steering Wheel Electronics	Specia Functions	
Altea XL	2008	5P	17 Instrument Cluster	Read Fault Codes	
Altea XL	2008	5P	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2008	5P	17 Instrument Cluster	Measuring Blocks	
Altea XL	2008	5P	17 Instrument Cluster	Output Tests	
Altea XL	2008	5P	17 Instrument Cluster	Specia Functions	
Altea XL	2008	5P	19 Gateway Data Bus	Read Fault Codes	
Altea XL	2008	5P	19 Gateway Data Bus	Clear Fault Codes	
Altea XL	2008	5P	19 Gateway Data Bus	Measuring Blocks	
Altea XL	2008	5P	19 Gateway Data Bus	Output Tests	
Altea XL	2008	5P	19 Gateway Data Bus	Specia Functions	
Altea XL	2008	5P	22 4WD Electronics	Read Fault Codes	
Altea XL	2008	5P	22 4WD Electronics	Clear Fault Codes	
Altea XL	2008	5P	22 4WD Electronics	Measuring Blocks	
Altea XL	2008	5P	22 4WD Electronics	Output Tests	
Altea XL	2008	5P	22 4WD Electronics	Specia Functions	
Altea XL	2008	5P	25 Immobilizer	Read Fault Codes	
Altea XL	2008	5P	25 Immobilizer	Clear Fault Codes	
Altea XL	2008	5P	25 Immobilizer	Measuring Blocks	
Altea XL	2008	5P	25 Immobilizer	Output Tests	
Altea XL	2008	5P	25 Immobilizer	Specia Functions	
Altea XL	2008	5P	37 Navigation	Read Fault Codes	
Altea XL	2008	5P	37 Navigation	Clear Fault Codes	
Altea XL	2008	5P	37 Navigation	Measuring Blocks	
Altea XL	2008	5P	37 Navigation	Output Tests	
Altea XL	2008	5P	37 Navigation	Specia Functions	
Altea XL	2008	5P	42 Driver-Door Elect.	Read Fault Codes	
Altea XL	2008	5P	42 Driver-Door Elect.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2008	5P	42 Driver-Door Elect.	Measuring Blocks	
Altea XL	2008	5P	42 Driver-Door Elect.	Output Tests	
Altea XL	2008	5P	42 Driver-Door Elect.	Specia Functions	
Altea XL	2008	5P	44 Steering Assistance	Read Fault Codes	
Altea XL	2008	5P	44 Steering Assistance	Clear Fault Codes	
Altea XL	2008	5P	44 Steering Assistance	Measuring Blocks	
Altea XL	2008	5P	44 Steering Assistance	Output Tests	
Altea XL	2008	5P	44 Steering Assistance	Specia Functions	
Altea XL	2008	5P	46 Central Control Module	Read Fault Codes	
Altea XL	2008	5P	46 Central Control Module	Clear Fault Codes	
Altea XL	2008	5P	46 Central Control Module	Measuring Blocks	
Altea XL	2008	5P	46 Central Control Module	Output Tests	
Altea XL	2008	5P	46 Central Control Module	Specia Functions	
Altea XL	2008	5P	51 Electric Drive	Read Fault Codes	
Altea XL	2008	5P	51 Electric Drive	Clear Fault Codes	
Altea XL	2008	5P	51 Electric Drive	Measuring Blocks	
Altea XL	2008	5P	51 Electric Drive	Output Tests	
Altea XL	2008	5P	51 Electric Drive	Specia Functions	
Altea XL	2008	5P	52 Passe.-Door Elect.	Read Fault Codes	
Altea XL	2008	5P	52 Passe.-Door Elect.	Clear Fault Codes	
Altea XL	2008	5P	52 Passe.-Door Elect.	Measuring Blocks	
Altea XL	2008	5P	52 Passe.-Door Elect.	Output Tests	
Altea XL	2008	5P	52 Passe.-Door Elect.	Specia Functions	
Altea XL	2008	5P	55 Headlight Range Control	Read Fault Codes	
Altea XL	2008	5P	55 Headlight Range Control	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2008	5P	55 Headlight Range Control	Measuring Blocks	
Altea XL	2008	5P	55 Headlight Range Control	Output Tests	
Altea XL	2008	5P	55 Headlight Range Control	Specia Functions	
Altea XL	2008	5P	56 Radio	Read Fault Codes	
Altea XL	2008	5P	56 Radio	Clear Fault Codes	
Altea XL	2008	5P	56 Radio	Measuring Blocks	
Altea XL	2008	5P	56 Radio	Output Tests	
Altea XL	2008	5P	56 Radio	Specia Functions	
Altea XL	2008	5P	62 LR-Door Electroni.	Read Fault Codes	
Altea XL	2008	5P	62 LR-Door Electroni.	Clear Fault Codes	
Altea XL	2008	5P	62 LR-Door Electroni.	Measuring Blocks	
Altea XL	2008	5P	62 LR-Door Electroni.	Output Tests	
Altea XL	2008	5P	62 LR-Door Electroni.	Specia Functions	
Altea XL	2008	5P	69 Trailer Function	Read Fault Codes	
Altea XL	2008	5P	69 Trailer Function	Clear Fault Codes	
Altea XL	2008	5P	69 Trailer Function	Measuring Blocks	
Altea XL	2008	5P	69 Trailer Function	Output Tests	
Altea XL	2008	5P	69 Trailer Function	Specia Functions	
Altea XL	2008	5P	72 RR-Door Electroni.	Read Fault Codes	
Altea XL	2008	5P	72 RR-Door Electroni.	Clear Fault Codes	
Altea XL	2008	5P	72 RR-Door Electroni.	Measuring Blocks	
Altea XL	2008	5P	72 RR-Door Electroni.	Output Tests	
Altea XL	2008	5P	72 RR-Door Electroni.	Specia Functions	
Altea XL	2008	5P	76 Parking Aid	Read Fault Codes	
Altea XL	2008	5P	76 Parking Aid	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Altea XL	2008	5P	76 Parking Aid	Measuring Blocks	
Altea XL	2008	5P	76 Parking Aid	Output Tests	
Altea XL	2008	5P	76 Parking Aid	Specia Functions	
Altea XL	2008	5P	77 Telephone	Read Fault Codes	
Altea XL	2008	5P	77 Telephone	Clear Fault Codes	
Altea XL	2008	5P	77 Telephone	Measuring Blocks	
Altea XL	2008	5P	77 Telephone	Output Tests	
Altea XL	2008	5P	77 Telephone	Specia Functions	
Altea XL	2008	5P	7D Auxiliary Heater	Read Fault Codes	
Altea XL	2008	5P	7D Auxiliary Heater	Clear Fault Codes	
Altea XL	2008	5P	7D Auxiliary Heater	Measuring Blocks	
Altea XL	2008	5P	7D Auxiliary Heater	Output Tests	
Altea XL	2008	5P	7D Auxiliary Heater	Specia Functions	
Altea XL	2008	5P	8C Hybrid Battery	Read Fault Codes	
Altea XL	2008	5P	8C Hybrid Battery	Clear Fault Codes	
Altea XL	2008	5P	8C Hybrid Battery	Measuring Blocks	
Altea XL	2008	5P	8C Hybrid Battery	Output Tests	
Altea XL	2008	5P	8C Hybrid Battery	Specia Functions	
Toledo	2008	5P	01 Engine Electronics	Read Fault Codes	
Toledo	2008	5P	01 Engine Electronics	Clear Fault Codes	
Toledo	2008	5P	01 Engine Electronics	Measuring Blocks	
Toledo	2008	5P	01 Engine Electronics	Output Tests	
Toledo	2008	5P	01 Engine Electronics	Specia Functions	
Toledo	2008	5P	02 Transmission Electronics	Read Fault Codes	
Toledo	2008	5P	02 Transmission Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2008	5P	02 Transmission Electronics	Measuring Blocks	
Toledo	2008	5P	02 Transmission Electronics	Output Tests	
Toledo	2008	5P	02 Transmission Electronics	Specia Functions	
Toledo	2008	5P	03 Brake Electronics	Read Fault Codes	
Toledo	2008	5P	03 Brake Electronics	Clear Fault Codes	
Toledo	2008	5P	03 Brake Electronics	Measuring Blocks	
Toledo	2008	5P	03 Brake Electronics	Output Tests	
Toledo	2008	5P	03 Brake Electronics	Specia Functions	
Toledo	2008	5P	08 AC/Heating Electronics	Read Fault Codes	
Toledo	2008	5P	08 AC/Heating Electronics	Clear Fault Codes	
Toledo	2008	5P	08 AC/Heating Electronics	Measuring Blocks	
Toledo	2008	5P	08 AC/Heating Electronics	Output Tests	
Toledo	2008	5P	08 AC/Heating Electronics	Specia Functions	
Toledo	2008	5P	09 Electronic Ctrl Electronics	Read Fault Codes	
Toledo	2008	5P	09 Electronic Ctrl Electronics	Clear Fault Codes	
Toledo	2008	5P	09 Electronic Ctrl Electronics	Measuring Blocks	
Toledo	2008	5P	09 Electronic Ctrl Electronics	Output Tests	
Toledo	2008	5P	09 Electronic Ctrl Electronics	Specia Functions	
Toledo	2008	5P	10 Parking Assist System 2	Read Fault Codes	
Toledo	2008	5P	10 Parking Assist System 2	Clear Fault Codes	
Toledo	2008	5P	10 Parking Assist System 2	Measuring Blocks	
Toledo	2008	5P	10 Parking Assist System 2	Output Tests	
Toledo	2008	5P	10 Parking Assist System 2	Specia Functions	
Toledo	2008	5P	11 Engine Electronics 2	Read Fault Codes	
Toledo	2008	5P	11 Engine Electronics 2	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2008	5P	11 Engine Electronics 2	Measuring Blocks	
Toledo	2008	5P	11 Engine Electronics 2	Output Tests	
Toledo	2008	5P	11 Engine Electronics 2	Specia Functions	
Toledo	2008	5P	15 Airbags	Read Fault Codes	
Toledo	2008	5P	15 Airbags	Clear Fault Codes	
Toledo	2008	5P	15 Airbags	Measuring Blocks	
Toledo	2008	5P	15 Airbags	Output Tests	
Toledo	2008	5P	15 Airbags	Specia Functions	
Toledo	2008	5P	16 Steering Wheel Electronics	Read Fault Codes	
Toledo	2008	5P	16 Steering Wheel Electronics	Clear Fault Codes	
Toledo	2008	5P	16 Steering Wheel Electronics	Measuring Blocks	
Toledo	2008	5P	16 Steering Wheel Electronics	Output Tests	
Toledo	2008	5P	16 Steering Wheel Electronics	Specia Functions	
Toledo	2008	5P	17 Instrument Cluster	Read Fault Codes	
Toledo	2008	5P	17 Instrument Cluster	Clear Fault Codes	
Toledo	2008	5P	17 Instrument Cluster	Measuring Blocks	
Toledo	2008	5P	17 Instrument Cluster	Output Tests	
Toledo	2008	5P	17 Instrument Cluster	Specia Functions	
Toledo	2008	5P	19 Gateway Data Bus	Read Fault Codes	
Toledo	2008	5P	19 Gateway Data Bus	Clear Fault Codes	
Toledo	2008	5P	19 Gateway Data Bus	Measuring Blocks	
Toledo	2008	5P	19 Gateway Data Bus	Output Tests	
Toledo	2008	5P	19 Gateway Data Bus	Specia Functions	
Toledo	2008	5P	22 4WD Electronics	Read Fault Codes	
Toledo	2008	5P	22 4WD Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2008	5P	22 4WD Electronics	Measuring Blocks	
Toledo	2008	5P	22 4WD Electronics	Output Tests	
Toledo	2008	5P	22 4WD Electronics	Specia Functions	
Toledo	2008	5P	25 Immobilizer	Read Fault Codes	
Toledo	2008	5P	25 Immobilizer	Clear Fault Codes	
Toledo	2008	5P	25 Immobilizer	Measuring Blocks	
Toledo	2008	5P	25 Immobilizer	Output Tests	
Toledo	2008	5P	25 Immobilizer	Specia Functions	
Toledo	2008	5P	37 Navigation	Read Fault Codes	
Toledo	2008	5P	37 Navigation	Clear Fault Codes	
Toledo	2008	5P	37 Navigation	Measuring Blocks	
Toledo	2008	5P	37 Navigation	Output Tests	
Toledo	2008	5P	37 Navigation	Specia Functions	
Toledo	2008	5P	42 Driver-Door Elect.	Read Fault Codes	
Toledo	2008	5P	42 Driver-Door Elect.	Clear Fault Codes	
Toledo	2008	5P	42 Driver-Door Elect.	Measuring Blocks	
Toledo	2008	5P	42 Driver-Door Elect.	Output Tests	
Toledo	2008	5P	42 Driver-Door Elect.	Specia Functions	
Toledo	2008	5P	44 Steering Assistance	Read Fault Codes	
Toledo	2008	5P	44 Steering Assistance	Clear Fault Codes	
Toledo	2008	5P	44 Steering Assistance	Measuring Blocks	
Toledo	2008	5P	44 Steering Assistance	Output Tests	
Toledo	2008	5P	44 Steering Assistance	Specia Functions	
Toledo	2008	5P	46 Central Control Module	Read Fault Codes	
Toledo	2008	5P	46 Central Control Module	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2008	5P	46 Central Control Module	Measuring Blocks	
Toledo	2008	5P	46 Central Control Module	Output Tests	
Toledo	2008	5P	46 Central Control Module	Specia Functions	
Toledo	2008	5P	51 Electric Drive	Read Fault Codes	
Toledo	2008	5P	51 Electric Drive	Clear Fault Codes	
Toledo	2008	5P	51 Electric Drive	Measuring Blocks	
Toledo	2008	5P	51 Electric Drive	Output Tests	
Toledo	2008	5P	51 Electric Drive	Specia Functions	
Toledo	2008	5P	52 Passe.-Door Elect.	Read Fault Codes	
Toledo	2008	5P	52 Passe.-Door Elect.	Clear Fault Codes	
Toledo	2008	5P	52 Passe.-Door Elect.	Measuring Blocks	
Toledo	2008	5P	52 Passe.-Door Elect.	Output Tests	
Toledo	2008	5P	52 Passe.-Door Elect.	Specia Functions	
Toledo	2008	5P	55 Headlight Range Control	Read Fault Codes	
Toledo	2008	5P	55 Headlight Range Control	Clear Fault Codes	
Toledo	2008	5P	55 Headlight Range Control	Measuring Blocks	
Toledo	2008	5P	55 Headlight Range Control	Output Tests	
Toledo	2008	5P	55 Headlight Range Control	Specia Functions	
Toledo	2008	5P	56 Radio	Read Fault Codes	
Toledo	2008	5P	56 Radio	Clear Fault Codes	
Toledo	2008	5P	56 Radio	Measuring Blocks	
Toledo	2008	5P	56 Radio	Output Tests	
Toledo	2008	5P	56 Radio	Specia Functions	
Toledo	2008	5P	62 LR-Door Electroni.	Read Fault Codes	
Toledo	2008	5P	62 LR-Door Electroni.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2008	5P	62 LR-Door Electroni.	Measuring Blocks	
Toledo	2008	5P	62 LR-Door Electroni.	Output Tests	
Toledo	2008	5P	62 LR-Door Electroni.	Specia Functions	
Toledo	2008	5P	69 Trailer Function	Read Fault Codes	
Toledo	2008	5P	69 Trailer Function	Clear Fault Codes	
Toledo	2008	5P	69 Trailer Function	Measuring Blocks	
Toledo	2008	5P	69 Trailer Function	Output Tests	
Toledo	2008	5P	69 Trailer Function	Specia Functions	
Toledo	2008	5P	72 RR-Door Electroni.	Read Fault Codes	
Toledo	2008	5P	72 RR-Door Electroni.	Clear Fault Codes	
Toledo	2008	5P	72 RR-Door Electroni.	Measuring Blocks	
Toledo	2008	5P	72 RR-Door Electroni.	Output Tests	
Toledo	2008	5P	72 RR-Door Electroni.	Specia Functions	
Toledo	2008	5P	76 Parking Aid	Read Fault Codes	
Toledo	2008	5P	76 Parking Aid	Clear Fault Codes	
Toledo	2008	5P	76 Parking Aid	Measuring Blocks	
Toledo	2008	5P	76 Parking Aid	Output Tests	
Toledo	2008	5P	76 Parking Aid	Specia Functions	
Toledo	2008	5P	77 Telephone	Read Fault Codes	
Toledo	2008	5P	77 Telephone	Clear Fault Codes	
Toledo	2008	5P	77 Telephone	Measuring Blocks	
Toledo	2008	5P	77 Telephone	Output Tests	
Toledo	2008	5P	77 Telephone	Specia Functions	
Toledo	2008	5P	7D Auxiliary Heater	Read Fault Codes	
Toledo	2008	5P	7D Auxiliary Heater	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2008	5P	7D Auxiliary Heater	Measuring Blocks	
Toledo	2008	5P	7D Auxiliary Heater	Output Tests	
Toledo	2008	5P	7D Auxiliary Heater	Specia Functions	
Toledo	2008	5P	8C Hybrid Battery	Read Fault Codes	
Toledo	2008	5P	8C Hybrid Battery	Clear Fault Codes	
Toledo	2008	5P	8C Hybrid Battery	Measuring Blocks	
Toledo	2008	5P	8C Hybrid Battery	Output Tests	
Toledo	2008	5P	8C Hybrid Battery	Specia Functions	
Alhambra	1995-2003	7V	01 Engine Electronics	Read Fault Codes	
Alhambra	1995-2003	7V	01 Engine Electronics	Clear Fault Codes	
Alhambra	1995-2003	7V	01 Engine Electronics	Measuring Blocks	
Alhambra	1995-2003	7V	01 Engine Electronics	Output Tests	
Alhambra	1995-2003	7V	01 Engine Electronics	Specia Functions	
Alhambra	1995-2003	7V	02 Transmission Electronics	Read Fault Codes	
Alhambra	1995-2003	7V	02 Transmission Electronics	Clear Fault Codes	
Alhambra	1995-2003	7V	02 Transmission Electronics	Measuring Blocks	
Alhambra	1995-2003	7V	02 Transmission Electronics	Output Tests	
Alhambra	1995-2003	7V	02 Transmission Electronics	Specia Functions	
Alhambra	1995-2003	7V	03 Brake Electronics	Read Fault Codes	
Alhambra	1995-2003	7V	03 Brake Electronics	Clear Fault Codes	
Alhambra	1995-2003	7V	03 Brake Electronics	Measuring Blocks	
Alhambra	1995-2003	7V	03 Brake Electronics	Output Tests	
Alhambra	1995-2003	7V	03 Brake Electronics	Specia Functions	
Alhambra	1995-2003	7V	08 AC/Heating Electronics	Read Fault Codes	
Alhambra	1995-2003	7V	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	1995-2003	7V	08 AC/Heating Electronics	Measuring Blocks	
Alhambra	1995-2003	7V	08 AC/Heating Electronics	Output Tests	
Alhambra	1995-2003	7V	08 AC/Heating Electronics	Specia Functions	
Alhambra	1995-2003	7V	09 Electronic Ctrl Electronics	Read Fault Codes	
Alhambra	1995-2003	7V	09 Electronic Ctrl Electronics	Clear Fault Codes	
Alhambra	1995-2003	7V	09 Electronic Ctrl Electronics	Measuring Blocks	
Alhambra	1995-2003	7V	09 Electronic Ctrl Electronics	Output Tests	
Alhambra	1995-2003	7V	09 Electronic Ctrl Electronics	Specia Functions	
Alhambra	1995-2003	7V	11 Engine Electronics 2	Read Fault Codes	
Alhambra	1995-2003	7V	11 Engine Electronics 2	Clear Fault Codes	
Alhambra	1995-2003	7V	11 Engine Electronics 2	Measuring Blocks	
Alhambra	1995-2003	7V	11 Engine Electronics 2	Output Tests	
Alhambra	1995-2003	7V	11 Engine Electronics 2	Specia Functions	
Alhambra	1995-2003	7V	15 Airbags	Read Fault Codes	
Alhambra	1995-2003	7V	15 Airbags	Clear Fault Codes	
Alhambra	1995-2003	7V	15 Airbags	Measuring Blocks	
Alhambra	1995-2003	7V	15 Airbags	Output Tests	
Alhambra	1995-2003	7V	15 Airbags	Specia Functions	
Alhambra	1995-2003	7V	16 Steering Wheel Electronics	Read Fault Codes	
Alhambra	1995-2003	7V	16 Steering Wheel Electronics	Clear Fault Codes	
Alhambra	1995-2003	7V	16 Steering Wheel Electronics	Measuring Blocks	
Alhambra	1995-2003	7V	16 Steering Wheel Electronics	Output Tests	
Alhambra	1995-2003	7V	16 Steering Wheel Electronics	Specia Functions	
Alhambra	1995-2003	7V	17 Instrument Cluster	Read Fault Codes	
Alhambra	1995-2003	7V	17 Instrument Cluster	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	1995-2003	7V	17 Instrument Cluster	Measuring Blocks	
Alhambra	1995-2003	7V	17 Instrument Cluster	Output Tests	
Alhambra	1995-2003	7V	17 Instrument Cluster	Specia Functions	
Alhambra	1995-2003	7V	18 Aux Heating	Read Fault Codes	
Alhambra	1995-2003	7V	18 Aux Heating	Clear Fault Codes	
Alhambra	1995-2003	7V	18 Aux Heating	Measuring Blocks	
Alhambra	1995-2003	7V	18 Aux Heating	Output Tests	
Alhambra	1995-2003	7V	18 Aux Heating	Specia Functions	
Alhambra	1995-2003	7V	19 Gateway Data Bus	Read Fault Codes	
Alhambra	1995-2003	7V	19 Gateway Data Bus	Clear Fault Codes	
Alhambra	1995-2003	7V	19 Gateway Data Bus	Measuring Blocks	
Alhambra	1995-2003	7V	19 Gateway Data Bus	Output Tests	
Alhambra	1995-2003	7V	19 Gateway Data Bus	Specia Functions	
Alhambra	1995-2003	7V	22 4WD Electronics	Read Fault Codes	
Alhambra	1995-2003	7V	22 4WD Electronics	Clear Fault Codes	
Alhambra	1995-2003	7V	22 4WD Electronics	Measuring Blocks	
Alhambra	1995-2003	7V	22 4WD Electronics	Output Tests	
Alhambra	1995-2003	7V	22 4WD Electronics	Specia Functions	
Alhambra	1995-2003	7V	25 Immobilizer	Read Fault Codes	
Alhambra	1995-2003	7V	25 Immobilizer	Clear Fault Codes	
Alhambra	1995-2003	7V	25 Immobilizer	Measuring Blocks	
Alhambra	1995-2003	7V	25 Immobilizer	Output Tests	
Alhambra	1995-2003	7V	25 Immobilizer	Specia Functions	
Alhambra	1995-2003	7V	29 Left Light Control	Read Fault Codes	
Alhambra	1995-2003	7V	29 Left Light Control	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	1995-2003	7V	29 Left Light Control	Measuring Blocks	
Alhambra	1995-2003	7V	29 Left Light Control	Output Tests	
Alhambra	1995-2003	7V	29 Left Light Control	Specia Functions	
Alhambra	1995-2003	7V	35 Central Locking	Read Fault Codes	
Alhambra	1995-2003	7V	35 Central Locking	Clear Fault Codes	
Alhambra	1995-2003	7V	35 Central Locking	Measuring Blocks	
Alhambra	1995-2003	7V	35 Central Locking	Output Tests	
Alhambra	1995-2003	7V	35 Central Locking	Specia Functions	
Alhambra	1995-2003	7V	37 Navigation	Read Fault Codes	
Alhambra	1995-2003	7V	37 Navigation	Clear Fault Codes	
Alhambra	1995-2003	7V	37 Navigation	Measuring Blocks	
Alhambra	1995-2003	7V	37 Navigation	Output Tests	
Alhambra	1995-2003	7V	37 Navigation	Specia Functions	
Alhambra	1995-2003	7V	39 Right Light Control	Read Fault Codes	
Alhambra	1995-2003	7V	39 Right Light Control	Clear Fault Codes	
Alhambra	1995-2003	7V	39 Right Light Control	Measuring Blocks	
Alhambra	1995-2003	7V	39 Right Light Control	Output Tests	
Alhambra	1995-2003	7V	39 Right Light Control	Specia Functions	
Alhambra	1995-2003	7V	51 Electric Drive	Read Fault Codes	
Alhambra	1995-2003	7V	51 Electric Drive	Clear Fault Codes	
Alhambra	1995-2003	7V	51 Electric Drive	Measuring Blocks	
Alhambra	1995-2003	7V	51 Electric Drive	Output Tests	
Alhambra	1995-2003	7V	51 Electric Drive	Specia Functions	
Alhambra	1995-2003	7V	56 Radio	Read Fault Codes	
Alhambra	1995-2003	7V	56 Radio	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	1995-2003	7V	56 Radio	Measuring Blocks	
Alhambra	1995-2003	7V	56 Radio	Output Tests	
Alhambra	1995-2003	7V	56 Radio	Specia Functions	
Alhambra	1995-2003	7V	76 Parking Aid	Read Fault Codes	
Alhambra	1995-2003	7V	76 Parking Aid	Clear Fault Codes	
Alhambra	1995-2003	7V	76 Parking Aid	Measuring Blocks	
Alhambra	1995-2003	7V	76 Parking Aid	Output Tests	
Alhambra	1995-2003	7V	76 Parking Aid	Specia Functions	
Alhambra	1995-2003	7V	8C Hybrid Battery	Read Fault Codes	
Alhambra	1995-2003	7V	8C Hybrid Battery	Clear Fault Codes	
Alhambra	1995-2003	7V	8C Hybrid Battery	Measuring Blocks	
Alhambra	1995-2003	7V	8C Hybrid Battery	Output Tests	
Alhambra	1995-2003	7V	8C Hybrid Battery	Specia Functions	
Alhambra	2004-2005	7V	01 Engine Electronics	Read Fault Codes	
Alhambra	2004-2005	7V	01 Engine Electronics	Clear Fault Codes	
Alhambra	2004-2005	7V	01 Engine Electronics	Measuring Blocks	
Alhambra	2004-2005	7V	01 Engine Electronics	Output Tests	
Alhambra	2004-2005	7V	01 Engine Electronics	Specia Functions	
Alhambra	2004-2005	7V	02 Transmission Electronics	Read Fault Codes	
Alhambra	2004-2005	7V	02 Transmission Electronics	Clear Fault Codes	
Alhambra	2004-2005	7V	02 Transmission Electronics	Measuring Blocks	
Alhambra	2004-2005	7V	02 Transmission Electronics	Output Tests	
Alhambra	2004-2005	7V	02 Transmission Electronics	Specia Functions	
Alhambra	2004-2005	7V	03 Brake Electronics	Read Fault Codes	
Alhambra	2004-2005	7V	03 Brake Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2004-2005	7V	03 Brake Electronics	Measuring Blocks	
Alhambra	2004-2005	7V	03 Brake Electronics	Output Tests	
Alhambra	2004-2005	7V	03 Brake Electronics	Specia Functions	
Alhambra	2004-2005	7V	08 AC/Heating Electronics	Read Fault Codes	
Alhambra	2004-2005	7V	08 AC/Heating Electronics	Clear Fault Codes	
Alhambra	2004-2005	7V	08 AC/Heating Electronics	Measuring Blocks	
Alhambra	2004-2005	7V	08 AC/Heating Electronics	Output Tests	
Alhambra	2004-2005	7V	08 AC/Heating Electronics	Specia Functions	
Alhambra	2004-2005	7V	09 Electronic Ctrl Electronics	Read Fault Codes	
Alhambra	2004-2005	7V	09 Electronic Ctrl Electronics	Clear Fault Codes	
Alhambra	2004-2005	7V	09 Electronic Ctrl Electronics	Measuring Blocks	
Alhambra	2004-2005	7V	09 Electronic Ctrl Electronics	Output Tests	
Alhambra	2004-2005	7V	09 Electronic Ctrl Electronics	Specia Functions	
Alhambra	2004-2005	7V	11 Engine Electronics 2	Read Fault Codes	
Alhambra	2004-2005	7V	11 Engine Electronics 2	Clear Fault Codes	
Alhambra	2004-2005	7V	11 Engine Electronics 2	Measuring Blocks	
Alhambra	2004-2005	7V	11 Engine Electronics 2	Output Tests	
Alhambra	2004-2005	7V	11 Engine Electronics 2	Specia Functions	
Alhambra	2004-2005	7V	15 Airbags	Read Fault Codes	
Alhambra	2004-2005	7V	15 Airbags	Clear Fault Codes	
Alhambra	2004-2005	7V	15 Airbags	Measuring Blocks	
Alhambra	2004-2005	7V	15 Airbags	Output Tests	
Alhambra	2004-2005	7V	15 Airbags	Specia Functions	
Alhambra	2004-2005	7V	16 Steering Wheel Electronics	Read Fault Codes	
Alhambra	2004-2005	7V	16 Steering Wheel Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2004-2005	7V	16 Steering Wheel Electronics	Measuring Blocks	
Alhambra	2004-2005	7V	16 Steering Wheel Electronics	Output Tests	
Alhambra	2004-2005	7V	16 Steering Wheel Electronics	Specia Functions	
Alhambra	2004-2005	7V	17 Instrument Cluster	Read Fault Codes	
Alhambra	2004-2005	7V	17 Instrument Cluster	Clear Fault Codes	
Alhambra	2004-2005	7V	17 Instrument Cluster	Measuring Blocks	
Alhambra	2004-2005	7V	17 Instrument Cluster	Output Tests	
Alhambra	2004-2005	7V	17 Instrument Cluster	Specia Functions	
Alhambra	2004-2005	7V	18 Aux Heating	Read Fault Codes	
Alhambra	2004-2005	7V	18 Aux Heating	Clear Fault Codes	
Alhambra	2004-2005	7V	18 Aux Heating	Measuring Blocks	
Alhambra	2004-2005	7V	18 Aux Heating	Output Tests	
Alhambra	2004-2005	7V	18 Aux Heating	Specia Functions	
Alhambra	2004-2005	7V	19 Gateway Data Bus	Read Fault Codes	
Alhambra	2004-2005	7V	19 Gateway Data Bus	Clear Fault Codes	
Alhambra	2004-2005	7V	19 Gateway Data Bus	Measuring Blocks	
Alhambra	2004-2005	7V	19 Gateway Data Bus	Output Tests	
Alhambra	2004-2005	7V	19 Gateway Data Bus	Specia Functions	
Alhambra	2004-2005	7V	22 4WD Electronics	Read Fault Codes	
Alhambra	2004-2005	7V	22 4WD Electronics	Clear Fault Codes	
Alhambra	2004-2005	7V	22 4WD Electronics	Measuring Blocks	
Alhambra	2004-2005	7V	22 4WD Electronics	Output Tests	
Alhambra	2004-2005	7V	22 4WD Electronics	Specia Functions	
Alhambra	2004-2005	7V	25 Immobilizer	Read Fault Codes	
Alhambra	2004-2005	7V	25 Immobilizer	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2004-2005	7V	25 Immobilizer	Measuring Blocks	
Alhambra	2004-2005	7V	25 Immobilizer	Output Tests	
Alhambra	2004-2005	7V	25 Immobilizer	Specia Functions	
Alhambra	2004-2005	7V	29 Left Light Control	Read Fault Codes	
Alhambra	2004-2005	7V	29 Left Light Control	Clear Fault Codes	
Alhambra	2004-2005	7V	29 Left Light Control	Measuring Blocks	
Alhambra	2004-2005	7V	29 Left Light Control	Output Tests	
Alhambra	2004-2005	7V	29 Left Light Control	Specia Functions	
Alhambra	2004-2005	7V	35 Central Locking	Read Fault Codes	
Alhambra	2004-2005	7V	35 Central Locking	Clear Fault Codes	
Alhambra	2004-2005	7V	35 Central Locking	Measuring Blocks	
Alhambra	2004-2005	7V	35 Central Locking	Output Tests	
Alhambra	2004-2005	7V	35 Central Locking	Specia Functions	
Alhambra	2004-2005	7V	37 Navigation	Read Fault Codes	
Alhambra	2004-2005	7V	37 Navigation	Clear Fault Codes	
Alhambra	2004-2005	7V	37 Navigation	Measuring Blocks	
Alhambra	2004-2005	7V	37 Navigation	Output Tests	
Alhambra	2004-2005	7V	37 Navigation	Specia Functions	
Alhambra	2004-2005	7V	39 Right Light Control	Read Fault Codes	
Alhambra	2004-2005	7V	39 Right Light Control	Clear Fault Codes	
Alhambra	2004-2005	7V	39 Right Light Control	Measuring Blocks	
Alhambra	2004-2005	7V	39 Right Light Control	Output Tests	
Alhambra	2004-2005	7V	39 Right Light Control	Specia Functions	
Alhambra	2004-2005	7V	51 Electric Drive	Read Fault Codes	
Alhambra	2004-2005	7V	51 Electric Drive	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2004-2005	7V	51 Electric Drive	Measuring Blocks	
Alhambra	2004-2005	7V	51 Electric Drive	Output Tests	
Alhambra	2004-2005	7V	51 Electric Drive	Specia Functions	
Alhambra	2004-2005	7V	56 Radio	Read Fault Codes	
Alhambra	2004-2005	7V	56 Radio	Clear Fault Codes	
Alhambra	2004-2005	7V	56 Radio	Measuring Blocks	
Alhambra	2004-2005	7V	56 Radio	Output Tests	
Alhambra	2004-2005	7V	56 Radio	Specia Functions	
Alhambra	2004-2005	7V	76 Parking Aid	Read Fault Codes	
Alhambra	2004-2005	7V	76 Parking Aid	Clear Fault Codes	
Alhambra	2004-2005	7V	76 Parking Aid	Measuring Blocks	
Alhambra	2004-2005	7V	76 Parking Aid	Output Tests	
Alhambra	2004-2005	7V	76 Parking Aid	Specia Functions	
Alhambra	2004-2005	7V	8C Hybrid Battery	Read Fault Codes	
Alhambra	2004-2005	7V	8C Hybrid Battery	Clear Fault Codes	
Alhambra	2004-2005	7V	8C Hybrid Battery	Measuring Blocks	
Alhambra	2004-2005	7V	8C Hybrid Battery	Output Tests	
Alhambra	2004-2005	7V	8C Hybrid Battery	Specia Functions	
Alhambra	2006-2010	7V	01 Engine Electronics	Read Fault Codes	
Alhambra	2006-2010	7V	01 Engine Electronics	Clear Fault Codes	
Alhambra	2006-2010	7V	01 Engine Electronics	Measuring Blocks	
Alhambra	2006-2010	7V	01 Engine Electronics	Output Tests	
Alhambra	2006-2010	7V	01 Engine Electronics	Specia Functions	
Alhambra	2006-2010	7V	02 Transmission Electronics	Read Fault Codes	
Alhambra	2006-2010	7V	02 Transmission Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2006-2010	7V	02 Transmission Electronics	Measuring Blocks	
Alhambra	2006-2010	7V	02 Transmission Electronics	Output Tests	
Alhambra	2006-2010	7V	02 Transmission Electronics	Specia Functions	
Alhambra	2006-2010	7V	03 Brake Electronics	Read Fault Codes	
Alhambra	2006-2010	7V	03 Brake Electronics	Clear Fault Codes	
Alhambra	2006-2010	7V	03 Brake Electronics	Measuring Blocks	
Alhambra	2006-2010	7V	03 Brake Electronics	Output Tests	
Alhambra	2006-2010	7V	03 Brake Electronics	Specia Functions	
Alhambra	2006-2010	7V	08 AC/Heating Electronics	Read Fault Codes	
Alhambra	2006-2010	7V	08 AC/Heating Electronics	Clear Fault Codes	
Alhambra	2006-2010	7V	08 AC/Heating Electronics	Measuring Blocks	
Alhambra	2006-2010	7V	08 AC/Heating Electronics	Output Tests	
Alhambra	2006-2010	7V	08 AC/Heating Electronics	Specia Functions	
Alhambra	2006-2010	7V	09 Electronic Ctrl Electronics	Read Fault Codes	
Alhambra	2006-2010	7V	09 Electronic Ctrl Electronics	Clear Fault Codes	
Alhambra	2006-2010	7V	09 Electronic Ctrl Electronics	Measuring Blocks	
Alhambra	2006-2010	7V	09 Electronic Ctrl Electronics	Output Tests	
Alhambra	2006-2010	7V	09 Electronic Ctrl Electronics	Specia Functions	
Alhambra	2006-2010	7V	11 Engine Electronics 2	Read Fault Codes	
Alhambra	2006-2010	7V	11 Engine Electronics 2	Clear Fault Codes	
Alhambra	2006-2010	7V	11 Engine Electronics 2	Measuring Blocks	
Alhambra	2006-2010	7V	11 Engine Electronics 2	Output Tests	
Alhambra	2006-2010	7V	11 Engine Electronics 2	Specia Functions	
Alhambra	2006-2010	7V	15 Airbags	Read Fault Codes	
Alhambra	2006-2010	7V	15 Airbags	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2006-2010	7V	15 Airbags	Measuring Blocks	
Alhambra	2006-2010	7V	15 Airbags	Output Tests	
Alhambra	2006-2010	7V	15 Airbags	Specia Functions	
Alhambra	2006-2010	7V	16 Steering Wheel Electronics	Read Fault Codes	
Alhambra	2006-2010	7V	16 Steering Wheel Electronics	Clear Fault Codes	
Alhambra	2006-2010	7V	16 Steering Wheel Electronics	Measuring Blocks	
Alhambra	2006-2010	7V	16 Steering Wheel Electronics	Output Tests	
Alhambra	2006-2010	7V	16 Steering Wheel Electronics	Specia Functions	
Alhambra	2006-2010	7V	17 Instrument Cluster	Read Fault Codes	
Alhambra	2006-2010	7V	17 Instrument Cluster	Clear Fault Codes	
Alhambra	2006-2010	7V	17 Instrument Cluster	Measuring Blocks	
Alhambra	2006-2010	7V	17 Instrument Cluster	Output Tests	
Alhambra	2006-2010	7V	17 Instrument Cluster	Specia Functions	
Alhambra	2006-2010	7V	18 Aux Heating	Read Fault Codes	
Alhambra	2006-2010	7V	18 Aux Heating	Clear Fault Codes	
Alhambra	2006-2010	7V	18 Aux Heating	Measuring Blocks	
Alhambra	2006-2010	7V	18 Aux Heating	Output Tests	
Alhambra	2006-2010	7V	18 Aux Heating	Specia Functions	
Alhambra	2006-2010	7V	19 Gateway Data Bus	Read Fault Codes	
Alhambra	2006-2010	7V	19 Gateway Data Bus	Clear Fault Codes	
Alhambra	2006-2010	7V	19 Gateway Data Bus	Measuring Blocks	
Alhambra	2006-2010	7V	19 Gateway Data Bus	Output Tests	
Alhambra	2006-2010	7V	19 Gateway Data Bus	Specia Functions	
Alhambra	2006-2010	7V	22 4WD Electronics	Read Fault Codes	
Alhambra	2006-2010	7V	22 4WD Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2006-2010	7V	22 4WD Electronics	Measuring Blocks	
Alhambra	2006-2010	7V	22 4WD Electronics	Output Tests	
Alhambra	2006-2010	7V	22 4WD Electronics	Specia Functions	
Alhambra	2006-2010	7V	25 Immobilizer	Read Fault Codes	
Alhambra	2006-2010	7V	25 Immobilizer	Clear Fault Codes	
Alhambra	2006-2010	7V	25 Immobilizer	Measuring Blocks	
Alhambra	2006-2010	7V	25 Immobilizer	Output Tests	
Alhambra	2006-2010	7V	25 Immobilizer	Specia Functions	
Alhambra	2006-2010	7V	29 Left Light Control	Read Fault Codes	
Alhambra	2006-2010	7V	29 Left Light Control	Clear Fault Codes	
Alhambra	2006-2010	7V	29 Left Light Control	Measuring Blocks	
Alhambra	2006-2010	7V	29 Left Light Control	Output Tests	
Alhambra	2006-2010	7V	29 Left Light Control	Specia Functions	
Alhambra	2006-2010	7V	35 Central Locking	Read Fault Codes	
Alhambra	2006-2010	7V	35 Central Locking	Clear Fault Codes	
Alhambra	2006-2010	7V	35 Central Locking	Measuring Blocks	
Alhambra	2006-2010	7V	35 Central Locking	Output Tests	
Alhambra	2006-2010	7V	35 Central Locking	Specia Functions	
Alhambra	2006-2010	7V	37 Navigation	Read Fault Codes	
Alhambra	2006-2010	7V	37 Navigation	Clear Fault Codes	
Alhambra	2006-2010	7V	37 Navigation	Measuring Blocks	
Alhambra	2006-2010	7V	37 Navigation	Output Tests	
Alhambra	2006-2010	7V	37 Navigation	Specia Functions	
Alhambra	2006-2010	7V	39 Right Light Control	Read Fault Codes	
Alhambra	2006-2010	7V	39 Right Light Control	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2006-2010	7V	39 Right Light Control	Measuring Blocks	
Alhambra	2006-2010	7V	39 Right Light Control	Output Tests	
Alhambra	2006-2010	7V	39 Right Light Control	Specia Functions	
Alhambra	2006-2010	7V	51 Electric Drive	Read Fault Codes	
Alhambra	2006-2010	7V	51 Electric Drive	Clear Fault Codes	
Alhambra	2006-2010	7V	51 Electric Drive	Measuring Blocks	
Alhambra	2006-2010	7V	51 Electric Drive	Output Tests	
Alhambra	2006-2010	7V	51 Electric Drive	Specia Functions	
Alhambra	2006-2010	7V	56 Radio	Read Fault Codes	
Alhambra	2006-2010	7V	56 Radio	Clear Fault Codes	
Alhambra	2006-2010	7V	56 Radio	Measuring Blocks	
Alhambra	2006-2010	7V	56 Radio	Output Tests	
Alhambra	2006-2010	7V	56 Radio	Specia Functions	
Alhambra	2006-2010	7V	76 Parking Aid	Read Fault Codes	
Alhambra	2006-2010	7V	76 Parking Aid	Clear Fault Codes	
Alhambra	2006-2010	7V	76 Parking Aid	Measuring Blocks	
Alhambra	2006-2010	7V	76 Parking Aid	Output Tests	
Alhambra	2006-2010	7V	76 Parking Aid	Specia Functions	
Alhambra	2006-2010	7V	77 Telephone	Read Fault Codes	
Alhambra	2006-2010	7V	77 Telephone	Clear Fault Codes	
Alhambra	2006-2010	7V	77 Telephone	Measuring Blocks	
Alhambra	2006-2010	7V	77 Telephone	Output Tests	
Alhambra	2006-2010	7V	77 Telephone	Specia Functions	
Alhambra	2006-2010	7V	8C Hybrid Battery	Read Fault Codes	
Alhambra	2006-2010	7V	8C Hybrid Battery	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Alhambra	2006-2010	7V	8C Hybrid Battery	Measuring Blocks	
Alhambra	2006-2010	7V	8C Hybrid Battery	Output Tests	
Alhambra	2006-2010	7V	8C Hybrid Battery	Specia Functions	
Cordoba	2002-2004	6L	01 Engine Electronics	Read Fault Codes	
Cordoba	2002-2004	6L	01 Engine Electronics	Clear Fault Codes	
Cordoba	2002-2004	6L	01 Engine Electronics	Measuring Blocks	
Cordoba	2002-2004	6L	01 Engine Electronics	Output Tests	
Cordoba	2002-2004	6L	01 Engine Electronics	Specia Functions	
Cordoba	2002-2004	6L	02 Transmission Electronics	Read Fault Codes	
Cordoba	2002-2004	6L	02 Transmission Electronics	Clear Fault Codes	
Cordoba	2002-2004	6L	02 Transmission Electronics	Measuring Blocks	
Cordoba	2002-2004	6L	02 Transmission Electronics	Output Tests	
Cordoba	2002-2004	6L	02 Transmission Electronics	Specia Functions	
Cordoba	2002-2004	6L	03 Brake Electronics	Read Fault Codes	
Cordoba	2002-2004	6L	03 Brake Electronics	Clear Fault Codes	
Cordoba	2002-2004	6L	03 Brake Electronics	Measuring Blocks	
Cordoba	2002-2004	6L	03 Brake Electronics	Output Tests	
Cordoba	2002-2004	6L	03 Brake Electronics	Specia Functions	
Cordoba	2002-2004	6L	08 AC/Heating Electronics	Read Fault Codes	
Cordoba	2002-2004	6L	08 AC/Heating Electronics	Clear Fault Codes	
Cordoba	2002-2004	6L	08 AC/Heating Electronics	Measuring Blocks	
Cordoba	2002-2004	6L	08 AC/Heating Electronics	Output Tests	
Cordoba	2002-2004	6L	08 AC/Heating Electronics	Specia Functions	
Cordoba	2002-2004	6L	09 Electronic Ctrl Electronics	Read Fault Codes	
Cordoba	2002-2004	6L	09 Electronic Ctrl Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	2002-2004	6L	09 Electronic Ctrl Electronics	Measuring Blocks	
Cordoba	2002-2004	6L	09 Electronic Ctrl Electronics	Output Tests	
Cordoba	2002-2004	6L	09 Electronic Ctrl Electronics	Specia Functions	
Cordoba	2002-2004	6L	11 Engine Electronics 2	Read Fault Codes	
Cordoba	2002-2004	6L	11 Engine Electronics 2	Clear Fault Codes	
Cordoba	2002-2004	6L	11 Engine Electronics 2	Measuring Blocks	
Cordoba	2002-2004	6L	11 Engine Electronics 2	Output Tests	
Cordoba	2002-2004	6L	11 Engine Electronics 2	Specia Functions	
Cordoba	2002-2004	6L	13 Distance Control	Read Fault Codes	
Cordoba	2002-2004	6L	13 Distance Control	Clear Fault Codes	
Cordoba	2002-2004	6L	13 Distance Control	Measuring Blocks	
Cordoba	2002-2004	6L	13 Distance Control	Output Tests	
Cordoba	2002-2004	6L	13 Distance Control	Specia Functions	
Cordoba	2002-2004	6L	15 Airbags	Read Fault Codes	
Cordoba	2002-2004	6L	15 Airbags	Clear Fault Codes	
Cordoba	2002-2004	6L	15 Airbags	Measuring Blocks	
Cordoba	2002-2004	6L	15 Airbags	Output Tests	
Cordoba	2002-2004	6L	15 Airbags	Specia Functions	
Cordoba	2002-2004	6L	17 Instrument Cluster	Read Fault Codes	
Cordoba	2002-2004	6L	17 Instrument Cluster	Clear Fault Codes	
Cordoba	2002-2004	6L	17 Instrument Cluster	Measuring Blocks	
Cordoba	2002-2004	6L	17 Instrument Cluster	Output Tests	
Cordoba	2002-2004	6L	17 Instrument Cluster	Specia Functions	
Cordoba	2002-2004	6L	19 Gateway Data Bus	Read Fault Codes	
Cordoba	2002-2004	6L	19 Gateway Data Bus	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	2002-2004	6L	19 Gateway Data Bus	Measuring Blocks	
Cordoba	2002-2004	6L	19 Gateway Data Bus	Output Tests	
Cordoba	2002-2004	6L	19 Gateway Data Bus	Specia Functions	
Cordoba	2002-2004	6L	25 Immobilizer	Read Fault Codes	
Cordoba	2002-2004	6L	25 Immobilizer	Clear Fault Codes	
Cordoba	2002-2004	6L	25 Immobilizer	Measuring Blocks	
Cordoba	2002-2004	6L	25 Immobilizer	Output Tests	
Cordoba	2002-2004	6L	25 Immobilizer	Specia Functions	
Cordoba	2002-2004	6L	37 Navigation	Read Fault Codes	
Cordoba	2002-2004	6L	37 Navigation	Clear Fault Codes	
Cordoba	2002-2004	6L	37 Navigation	Measuring Blocks	
Cordoba	2002-2004	6L	37 Navigation	Output Tests	
Cordoba	2002-2004	6L	37 Navigation	Specia Functions	
Cordoba	2002-2004	6L	44 Steering Assistance	Read Fault Codes	
Cordoba	2002-2004	6L	44 Steering Assistance	Clear Fault Codes	
Cordoba	2002-2004	6L	44 Steering Assistance	Measuring Blocks	
Cordoba	2002-2004	6L	44 Steering Assistance	Output Tests	
Cordoba	2002-2004	6L	44 Steering Assistance	Specia Functions	
Cordoba	2002-2004	6L	46 Central Control Module	Read Fault Codes	
Cordoba	2002-2004	6L	46 Central Control Module	Clear Fault Codes	
Cordoba	2002-2004	6L	46 Central Control Module	Measuring Blocks	
Cordoba	2002-2004	6L	46 Central Control Module	Output Tests	
Cordoba	2002-2004	6L	46 Central Control Module	Specia Functions	
Cordoba	2002-2004	6L	51 Electric Drive	Read Fault Codes	
Cordoba	2002-2004	6L	51 Electric Drive	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	2002-2004	6L	51 Electric Drive	Measuring Blocks	
Cordoba	2002-2004	6L	51 Electric Drive	Output Tests	
Cordoba	2002-2004	6L	51 Electric Drive	Specia Functions	
Cordoba	2002-2004	6L	56 Radio	Read Fault Codes	
Cordoba	2002-2004	6L	56 Radio	Clear Fault Codes	
Cordoba	2002-2004	6L	56 Radio	Measuring Blocks	
Cordoba	2002-2004	6L	56 Radio	Output Tests	
Cordoba	2002-2004	6L	56 Radio	Specia Functions	
Cordoba	2002-2004	6L	8C Hybrid Battery	Read Fault Codes	
Cordoba	2002-2004	6L	8C Hybrid Battery	Clear Fault Codes	
Cordoba	2002-2004	6L	8C Hybrid Battery	Measuring Blocks	
Cordoba	2002-2004	6L	8C Hybrid Battery	Output Tests	
Cordoba	2002-2004	6L	8C Hybrid Battery	Specia Functions	
Ibiza	2002-2004	6L	01 Engine Electronics	Read Fault Codes	
Ibiza	2002-2004	6L	01 Engine Electronics	Clear Fault Codes	
Ibiza	2002-2004	6L	01 Engine Electronics	Measuring Blocks	
Ibiza	2002-2004	6L	01 Engine Electronics	Output Tests	
Ibiza	2002-2004	6L	01 Engine Electronics	Specia Functions	
Ibiza	2002-2004	6L	02 Transmission Electronics	Read Fault Codes	
Ibiza	2002-2004	6L	02 Transmission Electronics	Clear Fault Codes	
Ibiza	2002-2004	6L	02 Transmission Electronics	Measuring Blocks	
Ibiza	2002-2004	6L	02 Transmission Electronics	Output Tests	
Ibiza	2002-2004	6L	02 Transmission Electronics	Specia Functions	
Ibiza	2002-2004	6L	03 Brake Electronics	Read Fault Codes	
Ibiza	2002-2004	6L	03 Brake Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2002-2004	6L	03 Brake Electronics	Measuring Blocks	
Ibiza	2002-2004	6L	03 Brake Electronics	Output Tests	
Ibiza	2002-2004	6L	03 Brake Electronics	Specia Functions	
Ibiza	2002-2004	6L	08 AC/Heating Electronics	Read Fault Codes	
Ibiza	2002-2004	6L	08 AC/Heating Electronics	Clear Fault Codes	
Ibiza	2002-2004	6L	08 AC/Heating Electronics	Measuring Blocks	
Ibiza	2002-2004	6L	08 AC/Heating Electronics	Output Tests	
Ibiza	2002-2004	6L	08 AC/Heating Electronics	Specia Functions	
Ibiza	2002-2004	6L	09 Electronic Ctrl Electronics	Read Fault Codes	
Ibiza	2002-2004	6L	09 Electronic Ctrl Electronics	Clear Fault Codes	
Ibiza	2002-2004	6L	09 Electronic Ctrl Electronics	Measuring Blocks	
Ibiza	2002-2004	6L	09 Electronic Ctrl Electronics	Output Tests	
Ibiza	2002-2004	6L	09 Electronic Ctrl Electronics	Specia Functions	
Ibiza	2002-2004	6L	11 Engine Electronics 2	Read Fault Codes	
Ibiza	2002-2004	6L	11 Engine Electronics 2	Clear Fault Codes	
Ibiza	2002-2004	6L	11 Engine Electronics 2	Measuring Blocks	
Ibiza	2002-2004	6L	11 Engine Electronics 2	Output Tests	
Ibiza	2002-2004	6L	11 Engine Electronics 2	Specia Functions	
Ibiza	2002-2004	6L	13 Distance Control	Read Fault Codes	
Ibiza	2002-2004	6L	13 Distance Control	Clear Fault Codes	
Ibiza	2002-2004	6L	13 Distance Control	Measuring Blocks	
Ibiza	2002-2004	6L	13 Distance Control	Output Tests	
Ibiza	2002-2004	6L	13 Distance Control	Specia Functions	
Ibiza	2002-2004	6L	15 Airbags	Read Fault Codes	
Ibiza	2002-2004	6L	15 Airbags	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2002-2004	6L	15 Airbags	Measuring Blocks	
Ibiza	2002-2004	6L	15 Airbags	Output Tests	
Ibiza	2002-2004	6L	15 Airbags	Specia Functions	
Ibiza	2002-2004	6L	17 Instrument Cluster	Read Fault Codes	
Ibiza	2002-2004	6L	17 Instrument Cluster	Clear Fault Codes	
Ibiza	2002-2004	6L	17 Instrument Cluster	Measuring Blocks	
Ibiza	2002-2004	6L	17 Instrument Cluster	Output Tests	
Ibiza	2002-2004	6L	17 Instrument Cluster	Specia Functions	
Ibiza	2002-2004	6L	19 Gateway Data Bus	Read Fault Codes	
Ibiza	2002-2004	6L	19 Gateway Data Bus	Clear Fault Codes	
Ibiza	2002-2004	6L	19 Gateway Data Bus	Measuring Blocks	
Ibiza	2002-2004	6L	19 Gateway Data Bus	Output Tests	
Ibiza	2002-2004	6L	19 Gateway Data Bus	Specia Functions	
Ibiza	2002-2004	6L	25 Immobilizer	Read Fault Codes	
Ibiza	2002-2004	6L	25 Immobilizer	Clear Fault Codes	
Ibiza	2002-2004	6L	25 Immobilizer	Measuring Blocks	
Ibiza	2002-2004	6L	25 Immobilizer	Output Tests	
Ibiza	2002-2004	6L	25 Immobilizer	Specia Functions	
Ibiza	2002-2004	6L	37 Navigation	Read Fault Codes	
Ibiza	2002-2004	6L	37 Navigation	Clear Fault Codes	
Ibiza	2002-2004	6L	37 Navigation	Measuring Blocks	
Ibiza	2002-2004	6L	37 Navigation	Output Tests	
Ibiza	2002-2004	6L	37 Navigation	Specia Functions	
Ibiza	2002-2004	6L	44 Steering Assistance	Read Fault Codes	
Ibiza	2002-2004	6L	44 Steering Assistance	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2002-2004	6L	44 Steering Assistance	Measuring Blocks	
Ibiza	2002-2004	6L	44 Steering Assistance	Output Tests	
Ibiza	2002-2004	6L	44 Steering Assistance	Specia Functions	
Ibiza	2002-2004	6L	46 Central Control Module	Read Fault Codes	
Ibiza	2002-2004	6L	46 Central Control Module	Clear Fault Codes	
Ibiza	2002-2004	6L	46 Central Control Module	Measuring Blocks	
Ibiza	2002-2004	6L	46 Central Control Module	Output Tests	
Ibiza	2002-2004	6L	46 Central Control Module	Specia Functions	
Ibiza	2002-2004	6L	51 Electric Drive	Read Fault Codes	
Ibiza	2002-2004	6L	51 Electric Drive	Clear Fault Codes	
Ibiza	2002-2004	6L	51 Electric Drive	Measuring Blocks	
Ibiza	2002-2004	6L	51 Electric Drive	Output Tests	
Ibiza	2002-2004	6L	51 Electric Drive	Specia Functions	
Ibiza	2002-2004	6L	56 Radio	Read Fault Codes	
Ibiza	2002-2004	6L	56 Radio	Clear Fault Codes	
Ibiza	2002-2004	6L	56 Radio	Measuring Blocks	
Ibiza	2002-2004	6L	56 Radio	Output Tests	
Ibiza	2002-2004	6L	56 Radio	Specia Functions	
Ibiza	2002-2004	6L	8C Hybrid Battery	Read Fault Codes	
Ibiza	2002-2004	6L	8C Hybrid Battery	Clear Fault Codes	
Ibiza	2002-2004	6L	8C Hybrid Battery	Measuring Blocks	
Ibiza	2002-2004	6L	8C Hybrid Battery	Output Tests	
Ibiza	2002-2004	6L	8C Hybrid Battery	Specia Functions	
Cordoba	2005-2007	6L	01 Engine Electronics	Read Fault Codes	
Cordoba	2005-2007	6L	01 Engine Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	2005-2007	6L	01 Engine Electronics	Measuring Blocks	
Cordoba	2005-2007	6L	01 Engine Electronics	Output Tests	
Cordoba	2005-2007	6L	01 Engine Electronics	Specia Functions	
Cordoba	2005-2007	6L	02 Transmission Electronics	Read Fault Codes	
Cordoba	2005-2007	6L	02 Transmission Electronics	Clear Fault Codes	
Cordoba	2005-2007	6L	02 Transmission Electronics	Measuring Blocks	
Cordoba	2005-2007	6L	02 Transmission Electronics	Output Tests	
Cordoba	2005-2007	6L	02 Transmission Electronics	Specia Functions	
Cordoba	2005-2007	6L	03 Brake Electronics	Read Fault Codes	
Cordoba	2005-2007	6L	03 Brake Electronics	Clear Fault Codes	
Cordoba	2005-2007	6L	03 Brake Electronics	Measuring Blocks	
Cordoba	2005-2007	6L	03 Brake Electronics	Output Tests	
Cordoba	2005-2007	6L	03 Brake Electronics	Specia Functions	
Cordoba	2005-2007	6L	08 AC/Heating Electronics	Read Fault Codes	
Cordoba	2005-2007	6L	08 AC/Heating Electronics	Clear Fault Codes	
Cordoba	2005-2007	6L	08 AC/Heating Electronics	Measuring Blocks	
Cordoba	2005-2007	6L	08 AC/Heating Electronics	Output Tests	
Cordoba	2005-2007	6L	08 AC/Heating Electronics	Specia Functions	
Cordoba	2005-2007	6L	09 Electronic Ctrl Electronics	Read Fault Codes	
Cordoba	2005-2007	6L	09 Electronic Ctrl Electronics	Clear Fault Codes	
Cordoba	2005-2007	6L	09 Electronic Ctrl Electronics	Measuring Blocks	
Cordoba	2005-2007	6L	09 Electronic Ctrl Electronics	Output Tests	
Cordoba	2005-2007	6L	09 Electronic Ctrl Electronics	Specia Functions	
Cordoba	2005-2007	6L	11 Engine Electronics 2	Read Fault Codes	
Cordoba	2005-2007	6L	11 Engine Electronics 2	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	2005-2007	6L	11 Engine Electronics 2	Measuring Blocks	
Cordoba	2005-2007	6L	11 Engine Electronics 2	Output Tests	
Cordoba	2005-2007	6L	11 Engine Electronics 2	Specia Functions	
Cordoba	2005-2007	6L	15 Airbags	Read Fault Codes	
Cordoba	2005-2007	6L	15 Airbags	Clear Fault Codes	
Cordoba	2005-2007	6L	15 Airbags	Measuring Blocks	
Cordoba	2005-2007	6L	15 Airbags	Output Tests	
Cordoba	2005-2007	6L	15 Airbags	Specia Functions	
Cordoba	2005-2007	6L	17 Instrument Cluster	Read Fault Codes	
Cordoba	2005-2007	6L	17 Instrument Cluster	Clear Fault Codes	
Cordoba	2005-2007	6L	17 Instrument Cluster	Measuring Blocks	
Cordoba	2005-2007	6L	17 Instrument Cluster	Output Tests	
Cordoba	2005-2007	6L	17 Instrument Cluster	Specia Functions	
Cordoba	2005-2007	6L	19 Gateway Data Bus	Read Fault Codes	
Cordoba	2005-2007	6L	19 Gateway Data Bus	Clear Fault Codes	
Cordoba	2005-2007	6L	19 Gateway Data Bus	Measuring Blocks	
Cordoba	2005-2007	6L	19 Gateway Data Bus	Output Tests	
Cordoba	2005-2007	6L	19 Gateway Data Bus	Specia Functions	
Cordoba	2005-2007	6L	25 Immobilizer	Read Fault Codes	
Cordoba	2005-2007	6L	25 Immobilizer	Clear Fault Codes	
Cordoba	2005-2007	6L	25 Immobilizer	Measuring Blocks	
Cordoba	2005-2007	6L	25 Immobilizer	Output Tests	
Cordoba	2005-2007	6L	25 Immobilizer	Specia Functions	
Cordoba	2005-2007	6L	37 Navigation	Read Fault Codes	
Cordoba	2005-2007	6L	37 Navigation	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	2005-2007	6L	37 Navigation	Measuring Blocks	
Cordoba	2005-2007	6L	37 Navigation	Output Tests	
Cordoba	2005-2007	6L	37 Navigation	Specia Functions	
Cordoba	2005-2007	6L	44 Steering Assistance	Read Fault Codes	
Cordoba	2005-2007	6L	44 Steering Assistance	Clear Fault Codes	
Cordoba	2005-2007	6L	44 Steering Assistance	Measuring Blocks	
Cordoba	2005-2007	6L	44 Steering Assistance	Output Tests	
Cordoba	2005-2007	6L	44 Steering Assistance	Specia Functions	
Cordoba	2005-2007	6L	46 Central Control Module	Read Fault Codes	
Cordoba	2005-2007	6L	46 Central Control Module	Clear Fault Codes	
Cordoba	2005-2007	6L	46 Central Control Module	Measuring Blocks	
Cordoba	2005-2007	6L	46 Central Control Module	Output Tests	
Cordoba	2005-2007	6L	46 Central Control Module	Specia Functions	
Cordoba	2005-2007	6L	51 Electric Drive	Read Fault Codes	
Cordoba	2005-2007	6L	51 Electric Drive	Clear Fault Codes	
Cordoba	2005-2007	6L	51 Electric Drive	Measuring Blocks	
Cordoba	2005-2007	6L	51 Electric Drive	Output Tests	
Cordoba	2005-2007	6L	51 Electric Drive	Specia Functions	
Cordoba	2005-2007	6L	56 Radio	Read Fault Codes	
Cordoba	2005-2007	6L	56 Radio	Clear Fault Codes	
Cordoba	2005-2007	6L	56 Radio	Measuring Blocks	
Cordoba	2005-2007	6L	56 Radio	Output Tests	
Cordoba	2005-2007	6L	56 Radio	Specia Functions	
Cordoba	2005-2007	6L	8C Hybrid Battery	Read Fault Codes	
Cordoba	2005-2007	6L	8C Hybrid Battery	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	2005-2007	6L	8C Hybrid Battery	Measuring Blocks	
Cordoba	2005-2007	6L	8C Hybrid Battery	Output Tests	
Cordoba	2005-2007	6L	8C Hybrid Battery	Specia Functions	
Ibiza	2005-2007	6L	01 Engine Electronics	Read Fault Codes	
Ibiza	2005-2007	6L	01 Engine Electronics	Clear Fault Codes	
Ibiza	2005-2007	6L	01 Engine Electronics	Measuring Blocks	
Ibiza	2005-2007	6L	01 Engine Electronics	Output Tests	
Ibiza	2005-2007	6L	01 Engine Electronics	Specia Functions	
Ibiza	2005-2007	6L	02 Transmission Electronics	Read Fault Codes	
Ibiza	2005-2007	6L	02 Transmission Electronics	Clear Fault Codes	
Ibiza	2005-2007	6L	02 Transmission Electronics	Measuring Blocks	
Ibiza	2005-2007	6L	02 Transmission Electronics	Output Tests	
Ibiza	2005-2007	6L	02 Transmission Electronics	Specia Functions	
Ibiza	2005-2007	6L	03 Brake Electronics	Read Fault Codes	
Ibiza	2005-2007	6L	03 Brake Electronics	Clear Fault Codes	
Ibiza	2005-2007	6L	03 Brake Electronics	Measuring Blocks	
Ibiza	2005-2007	6L	03 Brake Electronics	Output Tests	
Ibiza	2005-2007	6L	03 Brake Electronics	Specia Functions	
Ibiza	2005-2007	6L	08 AC/Heating Electronics	Read Fault Codes	
Ibiza	2005-2007	6L	08 AC/Heating Electronics	Clear Fault Codes	
Ibiza	2005-2007	6L	08 AC/Heating Electronics	Measuring Blocks	
Ibiza	2005-2007	6L	08 AC/Heating Electronics	Output Tests	
Ibiza	2005-2007	6L	08 AC/Heating Electronics	Specia Functions	
Ibiza	2005-2007	6L	09 Electronic Ctrl Electronics	Read Fault Codes	
Ibiza	2005-2007	6L	09 Electronic Ctrl Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2005-2007	6L	09 Electronic Ctrl Electronics	Measuring Blocks	
Ibiza	2005-2007	6L	09 Electronic Ctrl Electronics	Output Tests	
Ibiza	2005-2007	6L	09 Electronic Ctrl Electronics	Specia Functions	
Ibiza	2005-2007	6L	11 Engine Electronics 2	Read Fault Codes	
Ibiza	2005-2007	6L	11 Engine Electronics 2	Clear Fault Codes	
Ibiza	2005-2007	6L	11 Engine Electronics 2	Measuring Blocks	
Ibiza	2005-2007	6L	11 Engine Electronics 2	Output Tests	
Ibiza	2005-2007	6L	11 Engine Electronics 2	Specia Functions	
Ibiza	2005-2007	6L	15 Airbags	Read Fault Codes	
Ibiza	2005-2007	6L	15 Airbags	Clear Fault Codes	
Ibiza	2005-2007	6L	15 Airbags	Measuring Blocks	
Ibiza	2005-2007	6L	15 Airbags	Output Tests	
Ibiza	2005-2007	6L	15 Airbags	Specia Functions	
Ibiza	2005-2007	6L	17 Instrument Cluster	Read Fault Codes	
Ibiza	2005-2007	6L	17 Instrument Cluster	Clear Fault Codes	
Ibiza	2005-2007	6L	17 Instrument Cluster	Measuring Blocks	
Ibiza	2005-2007	6L	17 Instrument Cluster	Output Tests	
Ibiza	2005-2007	6L	17 Instrument Cluster	Specia Functions	
Ibiza	2005-2007	6L	19 Gateway Data Bus	Read Fault Codes	
Ibiza	2005-2007	6L	19 Gateway Data Bus	Clear Fault Codes	
Ibiza	2005-2007	6L	19 Gateway Data Bus	Measuring Blocks	
Ibiza	2005-2007	6L	19 Gateway Data Bus	Output Tests	
Ibiza	2005-2007	6L	19 Gateway Data Bus	Specia Functions	
Ibiza	2005-2007	6L	25 Immobilizer	Read Fault Codes	
Ibiza	2005-2007	6L	25 Immobilizer	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2005-2007	6L	25 Immobilizer	Measuring Blocks	
Ibiza	2005-2007	6L	25 Immobilizer	Output Tests	
Ibiza	2005-2007	6L	25 Immobilizer	Specia Functions	
Ibiza	2005-2007	6L	37 Navigation	Read Fault Codes	
Ibiza	2005-2007	6L	37 Navigation	Clear Fault Codes	
Ibiza	2005-2007	6L	37 Navigation	Measuring Blocks	
Ibiza	2005-2007	6L	37 Navigation	Output Tests	
Ibiza	2005-2007	6L	37 Navigation	Specia Functions	
Ibiza	2005-2007	6L	44 Steering Assistance	Read Fault Codes	
Ibiza	2005-2007	6L	44 Steering Assistance	Clear Fault Codes	
Ibiza	2005-2007	6L	44 Steering Assistance	Measuring Blocks	
Ibiza	2005-2007	6L	44 Steering Assistance	Output Tests	
Ibiza	2005-2007	6L	44 Steering Assistance	Specia Functions	
Ibiza	2005-2007	6L	46 Central Control Module	Read Fault Codes	
Ibiza	2005-2007	6L	46 Central Control Module	Clear Fault Codes	
Ibiza	2005-2007	6L	46 Central Control Module	Measuring Blocks	
Ibiza	2005-2007	6L	46 Central Control Module	Output Tests	
Ibiza	2005-2007	6L	46 Central Control Module	Specia Functions	
Ibiza	2005-2007	6L	51 Electric Drive	Read Fault Codes	
Ibiza	2005-2007	6L	51 Electric Drive	Clear Fault Codes	
Ibiza	2005-2007	6L	51 Electric Drive	Measuring Blocks	
Ibiza	2005-2007	6L	51 Electric Drive	Output Tests	
Ibiza	2005-2007	6L	51 Electric Drive	Specia Functions	
Ibiza	2005-2007	6L	56 Radio	Read Fault Codes	
Ibiza	2005-2007	6L	56 Radio	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2005-2007	6L	56 Radio	Measuring Blocks	
Ibiza	2005-2007	6L	56 Radio	Output Tests	
Ibiza	2005-2007	6L	56 Radio	Specia Functions	
Ibiza	2005-2007	6L	8C Hybrid Battery	Read Fault Codes	
Ibiza	2005-2007	6L	8C Hybrid Battery	Clear Fault Codes	
Ibiza	2005-2007	6L	8C Hybrid Battery	Measuring Blocks	
Ibiza	2005-2007	6L	8C Hybrid Battery	Output Tests	
Ibiza	2005-2007	6L	8C Hybrid Battery	Specia Functions	
Cordoba	2008-2009	6L	01 Engine Electronics	Read Fault Codes	
Cordoba	2008-2009	6L	01 Engine Electronics	Clear Fault Codes	
Cordoba	2008-2009	6L	01 Engine Electronics	Measuring Blocks	
Cordoba	2008-2009	6L	01 Engine Electronics	Output Tests	
Cordoba	2008-2009	6L	01 Engine Electronics	Specia Functions	
Cordoba	2008-2009	6L	02 Transmission Electronics	Read Fault Codes	
Cordoba	2008-2009	6L	02 Transmission Electronics	Clear Fault Codes	
Cordoba	2008-2009	6L	02 Transmission Electronics	Measuring Blocks	
Cordoba	2008-2009	6L	02 Transmission Electronics	Output Tests	
Cordoba	2008-2009	6L	02 Transmission Electronics	Specia Functions	
Cordoba	2008-2009	6L	03 Brake Electronics	Read Fault Codes	
Cordoba	2008-2009	6L	03 Brake Electronics	Clear Fault Codes	
Cordoba	2008-2009	6L	03 Brake Electronics	Measuring Blocks	
Cordoba	2008-2009	6L	03 Brake Electronics	Output Tests	
Cordoba	2008-2009	6L	03 Brake Electronics	Specia Functions	
Cordoba	2008-2009	6L	08 AC/Heating Electronics	Read Fault Codes	
Cordoba	2008-2009	6L	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	2008-2009	6L	08 AC/Heating Electronics	Measuring Blocks	
Cordoba	2008-2009	6L	08 AC/Heating Electronics	Output Tests	
Cordoba	2008-2009	6L	08 AC/Heating Electronics	Specia Functions	
Cordoba	2008-2009	6L	09 Electronic Ctrl Electronics	Read Fault Codes	
Cordoba	2008-2009	6L	09 Electronic Ctrl Electronics	Clear Fault Codes	
Cordoba	2008-2009	6L	09 Electronic Ctrl Electronics	Measuring Blocks	
Cordoba	2008-2009	6L	09 Electronic Ctrl Electronics	Output Tests	
Cordoba	2008-2009	6L	09 Electronic Ctrl Electronics	Specia Functions	
Cordoba	2008-2009	6L	11 Engine Electronics 2	Read Fault Codes	
Cordoba	2008-2009	6L	11 Engine Electronics 2	Clear Fault Codes	
Cordoba	2008-2009	6L	11 Engine Electronics 2	Measuring Blocks	
Cordoba	2008-2009	6L	11 Engine Electronics 2	Output Tests	
Cordoba	2008-2009	6L	11 Engine Electronics 2	Specia Functions	
Cordoba	2008-2009	6L	15 Airbags	Read Fault Codes	
Cordoba	2008-2009	6L	15 Airbags	Clear Fault Codes	
Cordoba	2008-2009	6L	15 Airbags	Measuring Blocks	
Cordoba	2008-2009	6L	15 Airbags	Output Tests	
Cordoba	2008-2009	6L	15 Airbags	Specia Functions	
Cordoba	2008-2009	6L	17 Instrument Cluster	Read Fault Codes	
Cordoba	2008-2009	6L	17 Instrument Cluster	Clear Fault Codes	
Cordoba	2008-2009	6L	17 Instrument Cluster	Measuring Blocks	
Cordoba	2008-2009	6L	17 Instrument Cluster	Output Tests	
Cordoba	2008-2009	6L	17 Instrument Cluster	Specia Functions	
Cordoba	2008-2009	6L	19 Gateway Data Bus	Read Fault Codes	
Cordoba	2008-2009	6L	19 Gateway Data Bus	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	2008-2009	6L	19 Gateway Data Bus	Measuring Blocks	
Cordoba	2008-2009	6L	19 Gateway Data Bus	Output Tests	
Cordoba	2008-2009	6L	19 Gateway Data Bus	Specia Functions	
Cordoba	2008-2009	6L	25 Immobilizer	Read Fault Codes	
Cordoba	2008-2009	6L	25 Immobilizer	Clear Fault Codes	
Cordoba	2008-2009	6L	25 Immobilizer	Measuring Blocks	
Cordoba	2008-2009	6L	25 Immobilizer	Output Tests	
Cordoba	2008-2009	6L	25 Immobilizer	Specia Functions	
Cordoba	2008-2009	6L	37 Navigation	Read Fault Codes	
Cordoba	2008-2009	6L	37 Navigation	Clear Fault Codes	
Cordoba	2008-2009	6L	37 Navigation	Measuring Blocks	
Cordoba	2008-2009	6L	37 Navigation	Output Tests	
Cordoba	2008-2009	6L	37 Navigation	Specia Functions	
Cordoba	2008-2009	6L	44 Steering Assistance	Read Fault Codes	
Cordoba	2008-2009	6L	44 Steering Assistance	Clear Fault Codes	
Cordoba	2008-2009	6L	44 Steering Assistance	Measuring Blocks	
Cordoba	2008-2009	6L	44 Steering Assistance	Output Tests	
Cordoba	2008-2009	6L	44 Steering Assistance	Specia Functions	
Cordoba	2008-2009	6L	46 Central Control Module	Read Fault Codes	
Cordoba	2008-2009	6L	46 Central Control Module	Clear Fault Codes	
Cordoba	2008-2009	6L	46 Central Control Module	Measuring Blocks	
Cordoba	2008-2009	6L	46 Central Control Module	Output Tests	
Cordoba	2008-2009	6L	46 Central Control Module	Specia Functions	
Cordoba	2008-2009	6L	51 Electric Drive	Read Fault Codes	
Cordoba	2008-2009	6L	51 Electric Drive	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	2008-2009	6L	51 Electric Drive	Measuring Blocks	
Cordoba	2008-2009	6L	51 Electric Drive	Output Tests	
Cordoba	2008-2009	6L	51 Electric Drive	Specia Functions	
Cordoba	2008-2009	6L	56 Radio	Read Fault Codes	
Cordoba	2008-2009	6L	56 Radio	Clear Fault Codes	
Cordoba	2008-2009	6L	56 Radio	Measuring Blocks	
Cordoba	2008-2009	6L	56 Radio	Output Tests	
Cordoba	2008-2009	6L	56 Radio	Specia Functions	
Cordoba	2008-2009	6L	8C Hybrid Battery	Read Fault Codes	
Cordoba	2008-2009	6L	8C Hybrid Battery	Clear Fault Codes	
Cordoba	2008-2009	6L	8C Hybrid Battery	Measuring Blocks	
Cordoba	2008-2009	6L	8C Hybrid Battery	Output Tests	
Cordoba	2008-2009	6L	8C Hybrid Battery	Specia Functions	
Ibiza	2008-2009	6L	01 Engine Electronics	Read Fault Codes	
Ibiza	2008-2009	6L	01 Engine Electronics	Clear Fault Codes	
Ibiza	2008-2009	6L	01 Engine Electronics	Measuring Blocks	
Ibiza	2008-2009	6L	01 Engine Electronics	Output Tests	
Ibiza	2008-2009	6L	01 Engine Electronics	Specia Functions	
Ibiza	2008-2009	6L	02 Transmission Electronics	Read Fault Codes	
Ibiza	2008-2009	6L	02 Transmission Electronics	Clear Fault Codes	
Ibiza	2008-2009	6L	02 Transmission Electronics	Measuring Blocks	
Ibiza	2008-2009	6L	02 Transmission Electronics	Output Tests	
Ibiza	2008-2009	6L	02 Transmission Electronics	Specia Functions	
Ibiza	2008-2009	6L	03 Brake Electronics	Read Fault Codes	
Ibiza	2008-2009	6L	03 Brake Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2008-2009	6L	03 Brake Electronics	Measuring Blocks	
Ibiza	2008-2009	6L	03 Brake Electronics	Output Tests	
Ibiza	2008-2009	6L	03 Brake Electronics	Specia Functions	
Ibiza	2008-2009	6L	08 AC/Heating Electronics	Read Fault Codes	
Ibiza	2008-2009	6L	08 AC/Heating Electronics	Clear Fault Codes	
Ibiza	2008-2009	6L	08 AC/Heating Electronics	Measuring Blocks	
Ibiza	2008-2009	6L	08 AC/Heating Electronics	Output Tests	
Ibiza	2008-2009	6L	08 AC/Heating Electronics	Specia Functions	
Ibiza	2008-2009	6L	09 Electronic Ctrl Electronics	Read Fault Codes	
Ibiza	2008-2009	6L	09 Electronic Ctrl Electronics	Clear Fault Codes	
Ibiza	2008-2009	6L	09 Electronic Ctrl Electronics	Measuring Blocks	
Ibiza	2008-2009	6L	09 Electronic Ctrl Electronics	Output Tests	
Ibiza	2008-2009	6L	09 Electronic Ctrl Electronics	Specia Functions	
Ibiza	2008-2009	6L	11 Engine Electronics 2	Read Fault Codes	
Ibiza	2008-2009	6L	11 Engine Electronics 2	Clear Fault Codes	
Ibiza	2008-2009	6L	11 Engine Electronics 2	Measuring Blocks	
Ibiza	2008-2009	6L	11 Engine Electronics 2	Output Tests	
Ibiza	2008-2009	6L	11 Engine Electronics 2	Specia Functions	
Ibiza	2008-2009	6L	15 Airbags	Read Fault Codes	
Ibiza	2008-2009	6L	15 Airbags	Clear Fault Codes	
Ibiza	2008-2009	6L	15 Airbags	Measuring Blocks	
Ibiza	2008-2009	6L	15 Airbags	Output Tests	
Ibiza	2008-2009	6L	15 Airbags	Specia Functions	
Ibiza	2008-2009	6L	17 Instrument Cluster	Read Fault Codes	
Ibiza	2008-2009	6L	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2008-2009	6L	17 Instrument Cluster	Measuring Blocks	
Ibiza	2008-2009	6L	17 Instrument Cluster	Output Tests	
Ibiza	2008-2009	6L	17 Instrument Cluster	Specia Functions	
Ibiza	2008-2009	6L	19 Gateway Data Bus	Read Fault Codes	
Ibiza	2008-2009	6L	19 Gateway Data Bus	Clear Fault Codes	
Ibiza	2008-2009	6L	19 Gateway Data Bus	Measuring Blocks	
Ibiza	2008-2009	6L	19 Gateway Data Bus	Output Tests	
Ibiza	2008-2009	6L	19 Gateway Data Bus	Specia Functions	
Ibiza	2008-2009	6L	25 Immobilizer	Read Fault Codes	
Ibiza	2008-2009	6L	25 Immobilizer	Clear Fault Codes	
Ibiza	2008-2009	6L	25 Immobilizer	Measuring Blocks	
Ibiza	2008-2009	6L	25 Immobilizer	Output Tests	
Ibiza	2008-2009	6L	25 Immobilizer	Specia Functions	
Ibiza	2008-2009	6L	37 Navigation	Read Fault Codes	
Ibiza	2008-2009	6L	37 Navigation	Clear Fault Codes	
Ibiza	2008-2009	6L	37 Navigation	Measuring Blocks	
Ibiza	2008-2009	6L	37 Navigation	Output Tests	
Ibiza	2008-2009	6L	37 Navigation	Specia Functions	
Ibiza	2008-2009	6L	44 Steering Assistance	Read Fault Codes	
Ibiza	2008-2009	6L	44 Steering Assistance	Clear Fault Codes	
Ibiza	2008-2009	6L	44 Steering Assistance	Measuring Blocks	
Ibiza	2008-2009	6L	44 Steering Assistance	Output Tests	
Ibiza	2008-2009	6L	44 Steering Assistance	Specia Functions	
Ibiza	2008-2009	6L	46 Central Control Module	Read Fault Codes	
Ibiza	2008-2009	6L	46 Central Control Module	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2008-2009	6L	46 Central Control Module	Measuring Blocks	
Ibiza	2008-2009	6L	46 Central Control Module	Output Tests	
Ibiza	2008-2009	6L	46 Central Control Module	Specia Functions	
Ibiza	2008-2009	6L	51 Electric Drive	Read Fault Codes	
Ibiza	2008-2009	6L	51 Electric Drive	Clear Fault Codes	
Ibiza	2008-2009	6L	51 Electric Drive	Measuring Blocks	
Ibiza	2008-2009	6L	51 Electric Drive	Output Tests	
Ibiza	2008-2009	6L	51 Electric Drive	Specia Functions	
Ibiza	2008-2009	6L	56 Radio	Read Fault Codes	
Ibiza	2008-2009	6L	56 Radio	Clear Fault Codes	
Ibiza	2008-2009	6L	56 Radio	Measuring Blocks	
Ibiza	2008-2009	6L	56 Radio	Output Tests	
Ibiza	2008-2009	6L	56 Radio	Specia Functions	
Ibiza	2008-2009	6L	8C Hybrid Battery	Read Fault Codes	
Ibiza	2008-2009	6L	8C Hybrid Battery	Clear Fault Codes	
Ibiza	2008-2009	6L	8C Hybrid Battery	Measuring Blocks	
Ibiza	2008-2009	6L	8C Hybrid Battery	Output Tests	
Ibiza	2008-2009	6L	8C Hybrid Battery	Specia Functions	
Leon	1999	1M	01 Engine Electronics	Read Fault Codes	
Leon	1999	1M	01 Engine Electronics	Clear Fault Codes	
Leon	1999	1M	01 Engine Electronics	Measuring Blocks	
Leon	1999	1M	01 Engine Electronics	Output Tests	
Leon	1999	1M	01 Engine Electronics	Specia Functions	
Leon	1999	1M	02 Transmission Electronics	Read Fault Codes	
Leon	1999	1M	02 Transmission Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	1999	1M	02 Transmission Electronics	Measuring Blocks	
Leon	1999	1M	02 Transmission Electronics	Output Tests	
Leon	1999	1M	02 Transmission Electronics	Specia Functions	
Leon	1999	1M	03 Brake Electronics	Read Fault Codes	
Leon	1999	1M	03 Brake Electronics	Clear Fault Codes	
Leon	1999	1M	03 Brake Electronics	Measuring Blocks	
Leon	1999	1M	03 Brake Electronics	Output Tests	
Leon	1999	1M	03 Brake Electronics	Specia Functions	
Leon	1999	1M	08 AC/Heating Electronics	Read Fault Codes	
Leon	1999	1M	08 AC/Heating Electronics	Clear Fault Codes	
Leon	1999	1M	08 AC/Heating Electronics	Measuring Blocks	
Leon	1999	1M	08 AC/Heating Electronics	Output Tests	
Leon	1999	1M	08 AC/Heating Electronics	Specia Functions	
Leon	1999	1M	11 Engine Electronics 2	Read Fault Codes	
Leon	1999	1M	11 Engine Electronics 2	Clear Fault Codes	
Leon	1999	1M	11 Engine Electronics 2	Measuring Blocks	
Leon	1999	1M	11 Engine Electronics 2	Output Tests	
Leon	1999	1M	11 Engine Electronics 2	Specia Functions	
Leon	1999	1M	15 Airbags	Read Fault Codes	
Leon	1999	1M	15 Airbags	Clear Fault Codes	
Leon	1999	1M	15 Airbags	Measuring Blocks	
Leon	1999	1M	15 Airbags	Output Tests	
Leon	1999	1M	15 Airbags	Specia Functions	
Leon	1999	1M	17 Instrument Cluster	Read Fault Codes	
Leon	1999	1M	17 Instrument Cluster	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	1999	1M	17 Instrument Cluster	Measuring Blocks	
Leon	1999	1M	17 Instrument Cluster	Output Tests	
Leon	1999	1M	17 Instrument Cluster	Specia Functions	
Leon	1999	1M	25 Immobilizer	Read Fault Codes	
Leon	1999	1M	25 Immobilizer	Clear Fault Codes	
Leon	1999	1M	25 Immobilizer	Measuring Blocks	
Leon	1999	1M	25 Immobilizer	Output Tests	
Leon	1999	1M	25 Immobilizer	Specia Functions	
Leon	1999	1M	35 Central Locking	Read Fault Codes	
Leon	1999	1M	35 Central Locking	Clear Fault Codes	
Leon	1999	1M	35 Central Locking	Measuring Blocks	
Leon	1999	1M	35 Central Locking	Output Tests	
Leon	1999	1M	35 Central Locking	Specia Functions	
Leon	1999	1M	37 Navigation	Read Fault Codes	
Leon	1999	1M	37 Navigation	Clear Fault Codes	
Leon	1999	1M	37 Navigation	Measuring Blocks	
Leon	1999	1M	37 Navigation	Output Tests	
Leon	1999	1M	37 Navigation	Specia Functions	
Leon	1999	1M	46 Central Control Module	Read Fault Codes	
Leon	1999	1M	46 Central Control Module	Clear Fault Codes	
Leon	1999	1M	46 Central Control Module	Measuring Blocks	
Leon	1999	1M	46 Central Control Module	Output Tests	
Leon	1999	1M	46 Central Control Module	Specia Functions	
Leon	1999	1M	47 Soundsystem	Read Fault Codes	
Leon	1999	1M	47 Soundsystem	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	1999	1M	47 Soundsystem	Measuring Blocks	
Leon	1999	1M	47 Soundsystem	Output Tests	
Leon	1999	1M	47 Soundsystem	Specia Functions	
Leon	1999	1M	51 Electric Drive	Read Fault Codes	
Leon	1999	1M	51 Electric Drive	Clear Fault Codes	
Leon	1999	1M	51 Electric Drive	Measuring Blocks	
Leon	1999	1M	51 Electric Drive	Output Tests	
Leon	1999	1M	51 Electric Drive	Specia Functions	
Leon	1999	1M	56 Radio	Read Fault Codes	
Leon	1999	1M	56 Radio	Clear Fault Codes	
Leon	1999	1M	56 Radio	Measuring Blocks	
Leon	1999	1M	56 Radio	Output Tests	
Leon	1999	1M	56 Radio	Specia Functions	
Leon	1999	1M	8C Hybrid Battery	Read Fault Codes	
Leon	1999	1M	8C Hybrid Battery	Clear Fault Codes	
Leon	1999	1M	8C Hybrid Battery	Measuring Blocks	
Leon	1999	1M	8C Hybrid Battery	Output Tests	
Leon	1999	1M	8C Hybrid Battery	Specia Functions	
Toledo	1999	1M	01 Engine Electronics	Read Fault Codes	
Toledo	1999	1M	01 Engine Electronics	Clear Fault Codes	
Toledo	1999	1M	01 Engine Electronics	Measuring Blocks	
Toledo	1999	1M	01 Engine Electronics	Output Tests	
Toledo	1999	1M	01 Engine Electronics	Specia Functions	
Toledo	1999	1M	02 Transmission Electronics	Read Fault Codes	
Toledo	1999	1M	02 Transmission Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	1999	1M	02 Transmission Electronics	Measuring Blocks	
Toledo	1999	1M	02 Transmission Electronics	Output Tests	
Toledo	1999	1M	02 Transmission Electronics	Specia Functions	
Toledo	1999	1M	03 Brake Electronics	Read Fault Codes	
Toledo	1999	1M	03 Brake Electronics	Clear Fault Codes	
Toledo	1999	1M	03 Brake Electronics	Measuring Blocks	
Toledo	1999	1M	03 Brake Electronics	Output Tests	
Toledo	1999	1M	03 Brake Electronics	Specia Functions	
Toledo	1999	1M	08 AC/Heating Electronics	Read Fault Codes	
Toledo	1999	1M	08 AC/Heating Electronics	Clear Fault Codes	
Toledo	1999	1M	08 AC/Heating Electronics	Measuring Blocks	
Toledo	1999	1M	08 AC/Heating Electronics	Output Tests	
Toledo	1999	1M	08 AC/Heating Electronics	Specia Functions	
Toledo	1999	1M	11 Engine Electronics 2	Read Fault Codes	
Toledo	1999	1M	11 Engine Electronics 2	Clear Fault Codes	
Toledo	1999	1M	11 Engine Electronics 2	Measuring Blocks	
Toledo	1999	1M	11 Engine Electronics 2	Output Tests	
Toledo	1999	1M	11 Engine Electronics 2	Specia Functions	
Toledo	1999	1M	15 Airbags	Read Fault Codes	
Toledo	1999	1M	15 Airbags	Clear Fault Codes	
Toledo	1999	1M	15 Airbags	Measuring Blocks	
Toledo	1999	1M	15 Airbags	Output Tests	
Toledo	1999	1M	15 Airbags	Specia Functions	
Toledo	1999	1M	17 Instrument Cluster	Read Fault Codes	
Toledo	1999	1M	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	1999	1M	17 Instrument Cluster	Measuring Blocks	
Toledo	1999	1M	17 Instrument Cluster	Output Tests	
Toledo	1999	1M	17 Instrument Cluster	Specia Functions	
Toledo	1999	1M	25 Immobilizer	Read Fault Codes	
Toledo	1999	1M	25 Immobilizer	Clear Fault Codes	
Toledo	1999	1M	25 Immobilizer	Measuring Blocks	
Toledo	1999	1M	25 Immobilizer	Output Tests	
Toledo	1999	1M	25 Immobilizer	Specia Functions	
Toledo	1999	1M	35 Central Locking	Read Fault Codes	
Toledo	1999	1M	35 Central Locking	Clear Fault Codes	
Toledo	1999	1M	35 Central Locking	Measuring Blocks	
Toledo	1999	1M	35 Central Locking	Output Tests	
Toledo	1999	1M	35 Central Locking	Specia Functions	
Toledo	1999	1M	37 Navigation	Read Fault Codes	
Toledo	1999	1M	37 Navigation	Clear Fault Codes	
Toledo	1999	1M	37 Navigation	Measuring Blocks	
Toledo	1999	1M	37 Navigation	Output Tests	
Toledo	1999	1M	37 Navigation	Specia Functions	
Toledo	1999	1M	46 Central Control Module	Read Fault Codes	
Toledo	1999	1M	46 Central Control Module	Clear Fault Codes	
Toledo	1999	1M	46 Central Control Module	Measuring Blocks	
Toledo	1999	1M	46 Central Control Module	Output Tests	
Toledo	1999	1M	46 Central Control Module	Specia Functions	
Toledo	1999	1M	47 Soundsystem	Read Fault Codes	
Toledo	1999	1M	47 Soundsystem	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	1999	1M	47 Soundsystem	Measuring Blocks	
Toledo	1999	1M	47 Soundsystem	Output Tests	
Toledo	1999	1M	47 Soundsystem	Specia Functions	
Toledo	1999	1M	51 Electric Drive	Read Fault Codes	
Toledo	1999	1M	51 Electric Drive	Clear Fault Codes	
Toledo	1999	1M	51 Electric Drive	Measuring Blocks	
Toledo	1999	1M	51 Electric Drive	Output Tests	
Toledo	1999	1M	51 Electric Drive	Specia Functions	
Toledo	1999	1M	56 Radio	Read Fault Codes	
Toledo	1999	1M	56 Radio	Clear Fault Codes	
Toledo	1999	1M	56 Radio	Measuring Blocks	
Toledo	1999	1M	56 Radio	Output Tests	
Toledo	1999	1M	56 Radio	Specia Functions	
Toledo	1999	1M	8C Hybrid Battery	Read Fault Codes	
Toledo	1999	1M	8C Hybrid Battery	Clear Fault Codes	
Toledo	1999	1M	8C Hybrid Battery	Measuring Blocks	
Toledo	1999	1M	8C Hybrid Battery	Output Tests	
Toledo	1999	1M	8C Hybrid Battery	Specia Functions	
Leon	2000	1M	01 Engine Electronics	Read Fault Codes	
Leon	2000	1M	01 Engine Electronics	Clear Fault Codes	
Leon	2000	1M	01 Engine Electronics	Measuring Blocks	
Leon	2000	1M	01 Engine Electronics	Output Tests	
Leon	2000	1M	01 Engine Electronics	Specia Functions	
Leon	2000	1M	02 Transmission Electronics	Read Fault Codes	
Leon	2000	1M	02 Transmission Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2000	1M	02 Transmission Electronics	Measuring Blocks	
Leon	2000	1M	02 Transmission Electronics	Output Tests	
Leon	2000	1M	02 Transmission Electronics	Specia Functions	
Leon	2000	1M	03 Brake Electronics	Read Fault Codes	
Leon	2000	1M	03 Brake Electronics	Clear Fault Codes	
Leon	2000	1M	03 Brake Electronics	Measuring Blocks	
Leon	2000	1M	03 Brake Electronics	Output Tests	
Leon	2000	1M	03 Brake Electronics	Specia Functions	
Leon	2000	1M	08 AC/Heating Electronics	Read Fault Codes	
Leon	2000	1M	08 AC/Heating Electronics	Clear Fault Codes	
Leon	2000	1M	08 AC/Heating Electronics	Measuring Blocks	
Leon	2000	1M	08 AC/Heating Electronics	Output Tests	
Leon	2000	1M	08 AC/Heating Electronics	Specia Functions	
Leon	2000	1M	11 Engine Electronics 2	Read Fault Codes	
Leon	2000	1M	11 Engine Electronics 2	Clear Fault Codes	
Leon	2000	1M	11 Engine Electronics 2	Measuring Blocks	
Leon	2000	1M	11 Engine Electronics 2	Output Tests	
Leon	2000	1M	11 Engine Electronics 2	Specia Functions	
Leon	2000	1M	15 Airbags	Read Fault Codes	
Leon	2000	1M	15 Airbags	Clear Fault Codes	
Leon	2000	1M	15 Airbags	Measuring Blocks	
Leon	2000	1M	15 Airbags	Output Tests	
Leon	2000	1M	15 Airbags	Specia Functions	
Leon	2000	1M	17 Instrument Cluster	Read Fault Codes	
Leon	2000	1M	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2000	1M	17 Instrument Cluster	Measuring Blocks	
Leon	2000	1M	17 Instrument Cluster	Output Tests	
Leon	2000	1M	17 Instrument Cluster	Specia Functions	
Leon	2000	1M	19 Gateway Data Bus	Read Fault Codes	
Leon	2000	1M	19 Gateway Data Bus	Clear Fault Codes	
Leon	2000	1M	19 Gateway Data Bus	Measuring Blocks	
Leon	2000	1M	19 Gateway Data Bus	Output Tests	
Leon	2000	1M	19 Gateway Data Bus	Specia Functions	
Leon	2000	1M	22 4WD Electronics	Read Fault Codes	
Leon	2000	1M	22 4WD Electronics	Clear Fault Codes	
Leon	2000	1M	22 4WD Electronics	Measuring Blocks	
Leon	2000	1M	22 4WD Electronics	Output Tests	
Leon	2000	1M	22 4WD Electronics	Specia Functions	
Leon	2000	1M	25 Immobilizer	Read Fault Codes	
Leon	2000	1M	25 Immobilizer	Clear Fault Codes	
Leon	2000	1M	25 Immobilizer	Measuring Blocks	
Leon	2000	1M	25 Immobilizer	Output Tests	
Leon	2000	1M	25 Immobilizer	Specia Functions	
Leon	2000	1M	35 Central Locking	Read Fault Codes	
Leon	2000	1M	35 Central Locking	Clear Fault Codes	
Leon	2000	1M	35 Central Locking	Measuring Blocks	
Leon	2000	1M	35 Central Locking	Output Tests	
Leon	2000	1M	35 Central Locking	Specia Functions	
Leon	2000	1M	36 Driver`s Side Seat Adj.	Read Fault Codes	
Leon	2000	1M	36 Driver`s Side Seat Adj.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2000	1M	36 Driver`s Side Seat Adj.	Measuring Blocks	
Leon	2000	1M	36 Driver`s Side Seat Adj.	Output Tests	
Leon	2000	1M	36 Driver`s Side Seat Adj.	Specia Functions	
Leon	2000	1M	37 Navigation	Read Fault Codes	
Leon	2000	1M	37 Navigation	Clear Fault Codes	
Leon	2000	1M	37 Navigation	Measuring Blocks	
Leon	2000	1M	37 Navigation	Output Tests	
Leon	2000	1M	37 Navigation	Specia Functions	
Leon	2000	1M	46 Central Control Module	Read Fault Codes	
Leon	2000	1M	46 Central Control Module	Clear Fault Codes	
Leon	2000	1M	46 Central Control Module	Measuring Blocks	
Leon	2000	1M	46 Central Control Module	Output Tests	
Leon	2000	1M	46 Central Control Module	Specia Functions	
Leon	2000	1M	47 Soundsystem	Read Fault Codes	
Leon	2000	1M	47 Soundsystem	Clear Fault Codes	
Leon	2000	1M	47 Soundsystem	Measuring Blocks	
Leon	2000	1M	47 Soundsystem	Output Tests	
Leon	2000	1M	47 Soundsystem	Specia Functions	
Leon	2000	1M	51 Electric Drive	Read Fault Codes	
Leon	2000	1M	51 Electric Drive	Clear Fault Codes	
Leon	2000	1M	51 Electric Drive	Measuring Blocks	
Leon	2000	1M	51 Electric Drive	Output Tests	
Leon	2000	1M	51 Electric Drive	Specia Functions	
Leon	2000	1M	56 Radio	Read Fault Codes	
Leon	2000	1M	56 Radio	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2000	1M	56 Radio	Measuring Blocks	
Leon	2000	1M	56 Radio	Output Tests	
Leon	2000	1M	56 Radio	Specia Functions	
Leon	2000	1M	8C Hybrid Battery	Read Fault Codes	
Leon	2000	1M	8C Hybrid Battery	Clear Fault Codes	
Leon	2000	1M	8C Hybrid Battery	Measuring Blocks	
Leon	2000	1M	8C Hybrid Battery	Output Tests	
Leon	2000	1M	8C Hybrid Battery	Specia Functions	
Toledo	2000	1M	01 Engine Electronics	Read Fault Codes	
Toledo	2000	1M	01 Engine Electronics	Clear Fault Codes	
Toledo	2000	1M	01 Engine Electronics	Measuring Blocks	
Toledo	2000	1M	01 Engine Electronics	Output Tests	
Toledo	2000	1M	01 Engine Electronics	Specia Functions	
Toledo	2000	1M	02 Transmission Electronics	Read Fault Codes	
Toledo	2000	1M	02 Transmission Electronics	Clear Fault Codes	
Toledo	2000	1M	02 Transmission Electronics	Measuring Blocks	
Toledo	2000	1M	02 Transmission Electronics	Output Tests	
Toledo	2000	1M	02 Transmission Electronics	Specia Functions	
Toledo	2000	1M	03 Brake Electronics	Read Fault Codes	
Toledo	2000	1M	03 Brake Electronics	Clear Fault Codes	
Toledo	2000	1M	03 Brake Electronics	Measuring Blocks	
Toledo	2000	1M	03 Brake Electronics	Output Tests	
Toledo	2000	1M	03 Brake Electronics	Specia Functions	
Toledo	2000	1M	08 AC/Heating Electronics	Read Fault Codes	
Toledo	2000	1M	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2000	1M	08 AC/Heating Electronics	Measuring Blocks	
Toledo	2000	1M	08 AC/Heating Electronics	Output Tests	
Toledo	2000	1M	08 AC/Heating Electronics	Specia Functions	
Toledo	2000	1M	11 Engine Electronics 2	Read Fault Codes	
Toledo	2000	1M	11 Engine Electronics 2	Clear Fault Codes	
Toledo	2000	1M	11 Engine Electronics 2	Measuring Blocks	
Toledo	2000	1M	11 Engine Electronics 2	Output Tests	
Toledo	2000	1M	11 Engine Electronics 2	Specia Functions	
Toledo	2000	1M	15 Airbags	Read Fault Codes	
Toledo	2000	1M	15 Airbags	Clear Fault Codes	
Toledo	2000	1M	15 Airbags	Measuring Blocks	
Toledo	2000	1M	15 Airbags	Output Tests	
Toledo	2000	1M	15 Airbags	Specia Functions	
Toledo	2000	1M	17 Instrument Cluster	Read Fault Codes	
Toledo	2000	1M	17 Instrument Cluster	Clear Fault Codes	
Toledo	2000	1M	17 Instrument Cluster	Measuring Blocks	
Toledo	2000	1M	17 Instrument Cluster	Output Tests	
Toledo	2000	1M	17 Instrument Cluster	Specia Functions	
Toledo	2000	1M	19 Gateway Data Bus	Read Fault Codes	
Toledo	2000	1M	19 Gateway Data Bus	Clear Fault Codes	
Toledo	2000	1M	19 Gateway Data Bus	Measuring Blocks	
Toledo	2000	1M	19 Gateway Data Bus	Output Tests	
Toledo	2000	1M	19 Gateway Data Bus	Specia Functions	
Toledo	2000	1M	22 4WD Electronics	Read Fault Codes	
Toledo	2000	1M	22 4WD Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2000	1M	22 4WD Electronics	Measuring Blocks	
Toledo	2000	1M	22 4WD Electronics	Output Tests	
Toledo	2000	1M	22 4WD Electronics	Specia Functions	
Toledo	2000	1M	25 Immobilizer	Read Fault Codes	
Toledo	2000	1M	25 Immobilizer	Clear Fault Codes	
Toledo	2000	1M	25 Immobilizer	Measuring Blocks	
Toledo	2000	1M	25 Immobilizer	Output Tests	
Toledo	2000	1M	25 Immobilizer	Specia Functions	
Toledo	2000	1M	35 Central Locking	Read Fault Codes	
Toledo	2000	1M	35 Central Locking	Clear Fault Codes	
Toledo	2000	1M	35 Central Locking	Measuring Blocks	
Toledo	2000	1M	35 Central Locking	Output Tests	
Toledo	2000	1M	35 Central Locking	Specia Functions	
Toledo	2000	1M	36 Driver`s Side Seat Adj.	Read Fault Codes	
Toledo	2000	1M	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Toledo	2000	1M	36 Driver`s Side Seat Adj.	Measuring Blocks	
Toledo	2000	1M	36 Driver`s Side Seat Adj.	Output Tests	
Toledo	2000	1M	36 Driver`s Side Seat Adj.	Specia Functions	
Toledo	2000	1M	37 Navigation	Read Fault Codes	
Toledo	2000	1M	37 Navigation	Clear Fault Codes	
Toledo	2000	1M	37 Navigation	Measuring Blocks	
Toledo	2000	1M	37 Navigation	Output Tests	
Toledo	2000	1M	37 Navigation	Specia Functions	
Toledo	2000	1M	46 Central Control Module	Read Fault Codes	
Toledo	2000	1M	46 Central Control Module	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2000	1M	46 Central Control Module	Measuring Blocks	
Toledo	2000	1M	46 Central Control Module	Output Tests	
Toledo	2000	1M	46 Central Control Module	Specia Functions	
Toledo	2000	1M	47 Soundsystem	Read Fault Codes	
Toledo	2000	1M	47 Soundsystem	Clear Fault Codes	
Toledo	2000	1M	47 Soundsystem	Measuring Blocks	
Toledo	2000	1M	47 Soundsystem	Output Tests	
Toledo	2000	1M	47 Soundsystem	Specia Functions	
Toledo	2000	1M	51 Electric Drive	Read Fault Codes	
Toledo	2000	1M	51 Electric Drive	Clear Fault Codes	
Toledo	2000	1M	51 Electric Drive	Measuring Blocks	
Toledo	2000	1M	51 Electric Drive	Output Tests	
Toledo	2000	1M	51 Electric Drive	Specia Functions	
Toledo	2000	1M	56 Radio	Read Fault Codes	
Toledo	2000	1M	56 Radio	Clear Fault Codes	
Toledo	2000	1M	56 Radio	Measuring Blocks	
Toledo	2000	1M	56 Radio	Output Tests	
Toledo	2000	1M	56 Radio	Specia Functions	
Toledo	2000	1M	8C Hybrid Battery	Read Fault Codes	
Toledo	2000	1M	8C Hybrid Battery	Clear Fault Codes	
Toledo	2000	1M	8C Hybrid Battery	Measuring Blocks	
Toledo	2000	1M	8C Hybrid Battery	Output Tests	
Toledo	2000	1M	8C Hybrid Battery	Specia Functions	
Leon	2001	1M	01 Engine Electronics	Read Fault Codes	
Leon	2001	1M	01 Engine Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2001	1M	01 Engine Electronics	Measuring Blocks	
Leon	2001	1M	01 Engine Electronics	Output Tests	
Leon	2001	1M	01 Engine Electronics	Specia Functions	
Leon	2001	1M	02 Transmission Electronics	Read Fault Codes	
Leon	2001	1M	02 Transmission Electronics	Clear Fault Codes	
Leon	2001	1M	02 Transmission Electronics	Measuring Blocks	
Leon	2001	1M	02 Transmission Electronics	Output Tests	
Leon	2001	1M	02 Transmission Electronics	Specia Functions	
Leon	2001	1M	03 Brake Electronics	Read Fault Codes	
Leon	2001	1M	03 Brake Electronics	Clear Fault Codes	
Leon	2001	1M	03 Brake Electronics	Measuring Blocks	
Leon	2001	1M	03 Brake Electronics	Output Tests	
Leon	2001	1M	03 Brake Electronics	Specia Functions	
Leon	2001	1M	08 AC/Heating Electronics	Read Fault Codes	
Leon	2001	1M	08 AC/Heating Electronics	Clear Fault Codes	
Leon	2001	1M	08 AC/Heating Electronics	Measuring Blocks	
Leon	2001	1M	08 AC/Heating Electronics	Output Tests	
Leon	2001	1M	08 AC/Heating Electronics	Specia Functions	
Leon	2001	1M	11 Engine Electronics 2	Read Fault Codes	
Leon	2001	1M	11 Engine Electronics 2	Clear Fault Codes	
Leon	2001	1M	11 Engine Electronics 2	Measuring Blocks	
Leon	2001	1M	11 Engine Electronics 2	Output Tests	
Leon	2001	1M	11 Engine Electronics 2	Specia Functions	
Leon	2001	1M	15 Airbags	Read Fault Codes	
Leon	2001	1M	15 Airbags	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2001	1M	15 Airbags	Measuring Blocks	
Leon	2001	1M	15 Airbags	Output Tests	
Leon	2001	1M	15 Airbags	Specia Functions	
Leon	2001	1M	17 Instrument Cluster	Read Fault Codes	
Leon	2001	1M	17 Instrument Cluster	Clear Fault Codes	
Leon	2001	1M	17 Instrument Cluster	Measuring Blocks	
Leon	2001	1M	17 Instrument Cluster	Output Tests	
Leon	2001	1M	17 Instrument Cluster	Specia Functions	
Leon	2001	1M	19 Gateway Data Bus	Read Fault Codes	
Leon	2001	1M	19 Gateway Data Bus	Clear Fault Codes	
Leon	2001	1M	19 Gateway Data Bus	Measuring Blocks	
Leon	2001	1M	19 Gateway Data Bus	Output Tests	
Leon	2001	1M	19 Gateway Data Bus	Specia Functions	
Leon	2001	1M	22 4WD Electronics	Read Fault Codes	
Leon	2001	1M	22 4WD Electronics	Clear Fault Codes	
Leon	2001	1M	22 4WD Electronics	Measuring Blocks	
Leon	2001	1M	22 4WD Electronics	Output Tests	
Leon	2001	1M	22 4WD Electronics	Specia Functions	
Leon	2001	1M	25 Immobilizer	Read Fault Codes	
Leon	2001	1M	25 Immobilizer	Clear Fault Codes	
Leon	2001	1M	25 Immobilizer	Measuring Blocks	
Leon	2001	1M	25 Immobilizer	Output Tests	
Leon	2001	1M	25 Immobilizer	Specia Functions	
Leon	2001	1M	35 Central Locking	Read Fault Codes	
Leon	2001	1M	35 Central Locking	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2001	1M	35 Central Locking	Measuring Blocks	
Leon	2001	1M	35 Central Locking	Output Tests	
Leon	2001	1M	35 Central Locking	Specia Functions	
Leon	2001	1M	36 Driver`s Side Seat Adj.	Read Fault Codes	
Leon	2001	1M	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Leon	2001	1M	36 Driver`s Side Seat Adj.	Measuring Blocks	
Leon	2001	1M	36 Driver`s Side Seat Adj.	Output Tests	
Leon	2001	1M	36 Driver`s Side Seat Adj.	Specia Functions	
Leon	2001	1M	37 Navigation	Read Fault Codes	
Leon	2001	1M	37 Navigation	Clear Fault Codes	
Leon	2001	1M	37 Navigation	Measuring Blocks	
Leon	2001	1M	37 Navigation	Output Tests	
Leon	2001	1M	37 Navigation	Specia Functions	
Leon	2001	1M	46 Central Control Module	Read Fault Codes	
Leon	2001	1M	46 Central Control Module	Clear Fault Codes	
Leon	2001	1M	46 Central Control Module	Measuring Blocks	
Leon	2001	1M	46 Central Control Module	Output Tests	
Leon	2001	1M	46 Central Control Module	Specia Functions	
Leon	2001	1M	47 Soundsystem	Read Fault Codes	
Leon	2001	1M	47 Soundsystem	Clear Fault Codes	
Leon	2001	1M	47 Soundsystem	Measuring Blocks	
Leon	2001	1M	47 Soundsystem	Output Tests	
Leon	2001	1M	47 Soundsystem	Specia Functions	
Leon	2001	1M	51 Electric Drive	Read Fault Codes	
Leon	2001	1M	51 Electric Drive	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2001	1M	51 Electric Drive	Measuring Blocks	
Leon	2001	1M	51 Electric Drive	Output Tests	
Leon	2001	1M	51 Electric Drive	Specia Functions	
Leon	2001	1M	56 Radio	Read Fault Codes	
Leon	2001	1M	56 Radio	Clear Fault Codes	
Leon	2001	1M	56 Radio	Measuring Blocks	
Leon	2001	1M	56 Radio	Output Tests	
Leon	2001	1M	56 Radio	Specia Functions	
Leon	2001	1M	8C Hybrid Battery	Read Fault Codes	
Leon	2001	1M	8C Hybrid Battery	Clear Fault Codes	
Leon	2001	1M	8C Hybrid Battery	Measuring Blocks	
Leon	2001	1M	8C Hybrid Battery	Output Tests	
Leon	2001	1M	8C Hybrid Battery	Specia Functions	
Toledo	2001	1M	01 Engine Electronics	Read Fault Codes	
Toledo	2001	1M	01 Engine Electronics	Clear Fault Codes	
Toledo	2001	1M	01 Engine Electronics	Measuring Blocks	
Toledo	2001	1M	01 Engine Electronics	Output Tests	
Toledo	2001	1M	01 Engine Electronics	Specia Functions	
Toledo	2001	1M	02 Transmission Electronics	Read Fault Codes	
Toledo	2001	1M	02 Transmission Electronics	Clear Fault Codes	
Toledo	2001	1M	02 Transmission Electronics	Measuring Blocks	
Toledo	2001	1M	02 Transmission Electronics	Output Tests	
Toledo	2001	1M	02 Transmission Electronics	Specia Functions	
Toledo	2001	1M	03 Brake Electronics	Read Fault Codes	
Toledo	2001	1M	03 Brake Electronics	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2001	1M	03 Brake Electronics	Measuring Blocks	
Toledo	2001	1M	03 Brake Electronics	Output Tests	
Toledo	2001	1M	03 Brake Electronics	Specia Functions	
Toledo	2001	1M	08 AC/Heating Electronics	Read Fault Codes	
Toledo	2001	1M	08 AC/Heating Electronics	Clear Fault Codes	
Toledo	2001	1M	08 AC/Heating Electronics	Measuring Blocks	
Toledo	2001	1M	08 AC/Heating Electronics	Output Tests	
Toledo	2001	1M	08 AC/Heating Electronics	Specia Functions	
Toledo	2001	1M	11 Engine Electronics 2	Read Fault Codes	
Toledo	2001	1M	11 Engine Electronics 2	Clear Fault Codes	
Toledo	2001	1M	11 Engine Electronics 2	Measuring Blocks	
Toledo	2001	1M	11 Engine Electronics 2	Output Tests	
Toledo	2001	1M	11 Engine Electronics 2	Specia Functions	
Toledo	2001	1M	15 Airbags	Read Fault Codes	
Toledo	2001	1M	15 Airbags	Clear Fault Codes	
Toledo	2001	1M	15 Airbags	Measuring Blocks	
Toledo	2001	1M	15 Airbags	Output Tests	
Toledo	2001	1M	15 Airbags	Specia Functions	
Toledo	2001	1M	17 Instrument Cluster	Read Fault Codes	
Toledo	2001	1M	17 Instrument Cluster	Clear Fault Codes	
Toledo	2001	1M	17 Instrument Cluster	Measuring Blocks	
Toledo	2001	1M	17 Instrument Cluster	Output Tests	
Toledo	2001	1M	17 Instrument Cluster	Specia Functions	
Toledo	2001	1M	19 Gateway Data Bus	Read Fault Codes	
Toledo	2001	1M	19 Gateway Data Bus	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2001	1M	19 Gateway Data Bus	Measuring Blocks	
Toledo	2001	1M	19 Gateway Data Bus	Output Tests	
Toledo	2001	1M	19 Gateway Data Bus	Specia Functions	
Toledo	2001	1M	22 4WD Electronics	Read Fault Codes	
Toledo	2001	1M	22 4WD Electronics	Clear Fault Codes	
Toledo	2001	1M	22 4WD Electronics	Measuring Blocks	
Toledo	2001	1M	22 4WD Electronics	Output Tests	
Toledo	2001	1M	22 4WD Electronics	Specia Functions	
Toledo	2001	1M	25 Immobilizer	Read Fault Codes	
Toledo	2001	1M	25 Immobilizer	Clear Fault Codes	
Toledo	2001	1M	25 Immobilizer	Measuring Blocks	
Toledo	2001	1M	25 Immobilizer	Output Tests	
Toledo	2001	1M	25 Immobilizer	Specia Functions	
Toledo	2001	1M	35 Central Locking	Read Fault Codes	
Toledo	2001	1M	35 Central Locking	Clear Fault Codes	
Toledo	2001	1M	35 Central Locking	Measuring Blocks	
Toledo	2001	1M	35 Central Locking	Output Tests	
Toledo	2001	1M	35 Central Locking	Specia Functions	
Toledo	2001	1M	36 Driver`s Side Seat Adj.	Read Fault Codes	
Toledo	2001	1M	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Toledo	2001	1M	36 Driver`s Side Seat Adj.	Measuring Blocks	
Toledo	2001	1M	36 Driver`s Side Seat Adj.	Output Tests	
Toledo	2001	1M	36 Driver`s Side Seat Adj.	Specia Functions	
Toledo	2001	1M	37 Navigation	Read Fault Codes	
Toledo	2001	1M	37 Navigation	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2001	1M	37 Navigation	Measuring Blocks	
Toledo	2001	1M	37 Navigation	Output Tests	
Toledo	2001	1M	37 Navigation	Specia Functions	
Toledo	2001	1M	46 Central Control Module	Read Fault Codes	
Toledo	2001	1M	46 Central Control Module	Clear Fault Codes	
Toledo	2001	1M	46 Central Control Module	Measuring Blocks	
Toledo	2001	1M	46 Central Control Module	Output Tests	
Toledo	2001	1M	46 Central Control Module	Specia Functions	
Toledo	2001	1M	47 Soundsystem	Read Fault Codes	
Toledo	2001	1M	47 Soundsystem	Clear Fault Codes	
Toledo	2001	1M	47 Soundsystem	Measuring Blocks	
Toledo	2001	1M	47 Soundsystem	Output Tests	
Toledo	2001	1M	47 Soundsystem	Specia Functions	
Toledo	2001	1M	51 Electric Drive	Read Fault Codes	
Toledo	2001	1M	51 Electric Drive	Clear Fault Codes	
Toledo	2001	1M	51 Electric Drive	Measuring Blocks	
Toledo	2001	1M	51 Electric Drive	Output Tests	
Toledo	2001	1M	51 Electric Drive	Specia Functions	
Toledo	2001	1M	56 Radio	Read Fault Codes	
Toledo	2001	1M	56 Radio	Clear Fault Codes	
Toledo	2001	1M	56 Radio	Measuring Blocks	
Toledo	2001	1M	56 Radio	Output Tests	
Toledo	2001	1M	56 Radio	Specia Functions	
Toledo	2001	1M	8C Hybrid Battery	Read Fault Codes	
Toledo	2001	1M	8C Hybrid Battery	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2001	1M	8C Hybrid Battery	Measuring Blocks	
Toledo	2001	1M	8C Hybrid Battery	Output Tests	
Toledo	2001	1M	8C Hybrid Battery	Specia Functions	
Leon	2002	1M	01 Engine Electronics	Read Fault Codes	
Leon	2002	1M	01 Engine Electronics	Clear Fault Codes	
Leon	2002	1M	01 Engine Electronics	Measuring Blocks	
Leon	2002	1M	01 Engine Electronics	Output Tests	
Leon	2002	1M	01 Engine Electronics	Specia Functions	
Leon	2002	1M	02 Transmission Electronics	Read Fault Codes	
Leon	2002	1M	02 Transmission Electronics	Clear Fault Codes	
Leon	2002	1M	02 Transmission Electronics	Measuring Blocks	
Leon	2002	1M	02 Transmission Electronics	Output Tests	
Leon	2002	1M	02 Transmission Electronics	Specia Functions	
Leon	2002	1M	03 Brake Electronics	Read Fault Codes	
Leon	2002	1M	03 Brake Electronics	Clear Fault Codes	
Leon	2002	1M	03 Brake Electronics	Measuring Blocks	
Leon	2002	1M	03 Brake Electronics	Output Tests	
Leon	2002	1M	03 Brake Electronics	Specia Functions	
Leon	2002	1M	08 AC/Heating Electronics	Read Fault Codes	
Leon	2002	1M	08 AC/Heating Electronics	Clear Fault Codes	
Leon	2002	1M	08 AC/Heating Electronics	Measuring Blocks	
Leon	2002	1M	08 AC/Heating Electronics	Output Tests	
Leon	2002	1M	08 AC/Heating Electronics	Specia Functions	
Leon	2002	1M	11 Engine Electronics 2	Read Fault Codes	
Leon	2002	1M	11 Engine Electronics 2	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2002	1M	11 Engine Electronics 2	Measuring Blocks	
Leon	2002	1M	11 Engine Electronics 2	Output Tests	
Leon	2002	1M	11 Engine Electronics 2	Specia Functions	
Leon	2002	1M	15 Airbags	Read Fault Codes	
Leon	2002	1M	15 Airbags	Clear Fault Codes	
Leon	2002	1M	15 Airbags	Measuring Blocks	
Leon	2002	1M	15 Airbags	Output Tests	
Leon	2002	1M	15 Airbags	Specia Functions	
Leon	2002	1M	17 Instrument Cluster	Read Fault Codes	
Leon	2002	1M	17 Instrument Cluster	Clear Fault Codes	
Leon	2002	1M	17 Instrument Cluster	Measuring Blocks	
Leon	2002	1M	17 Instrument Cluster	Output Tests	
Leon	2002	1M	17 Instrument Cluster	Specia Functions	
Leon	2002	1M	19 Gateway Data Bus	Read Fault Codes	
Leon	2002	1M	19 Gateway Data Bus	Clear Fault Codes	
Leon	2002	1M	19 Gateway Data Bus	Measuring Blocks	
Leon	2002	1M	19 Gateway Data Bus	Output Tests	
Leon	2002	1M	19 Gateway Data Bus	Specia Functions	
Leon	2002	1M	22 4WD Electronics	Read Fault Codes	
Leon	2002	1M	22 4WD Electronics	Clear Fault Codes	
Leon	2002	1M	22 4WD Electronics	Measuring Blocks	
Leon	2002	1M	22 4WD Electronics	Output Tests	
Leon	2002	1M	22 4WD Electronics	Specia Functions	
Leon	2002	1M	25 Immobilizer	Read Fault Codes	
Leon	2002	1M	25 Immobilizer	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2002	1M	25 Immobilizer	Measuring Blocks	
Leon	2002	1M	25 Immobilizer	Output Tests	
Leon	2002	1M	25 Immobilizer	Specia Functions	
Leon	2002	1M	35 Central Locking	Read Fault Codes	
Leon	2002	1M	35 Central Locking	Clear Fault Codes	
Leon	2002	1M	35 Central Locking	Measuring Blocks	
Leon	2002	1M	35 Central Locking	Output Tests	
Leon	2002	1M	35 Central Locking	Specia Functions	
Leon	2002	1M	36 Driver`s Side Seat Adj.	Read Fault Codes	
Leon	2002	1M	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Leon	2002	1M	36 Driver`s Side Seat Adj.	Measuring Blocks	
Leon	2002	1M	36 Driver`s Side Seat Adj.	Output Tests	
Leon	2002	1M	36 Driver`s Side Seat Adj.	Specia Functions	
Leon	2002	1M	37 Navigation	Read Fault Codes	
Leon	2002	1M	37 Navigation	Clear Fault Codes	
Leon	2002	1M	37 Navigation	Measuring Blocks	
Leon	2002	1M	37 Navigation	Output Tests	
Leon	2002	1M	37 Navigation	Specia Functions	
Leon	2002	1M	46 Central Control Module	Read Fault Codes	
Leon	2002	1M	46 Central Control Module	Clear Fault Codes	
Leon	2002	1M	46 Central Control Module	Measuring Blocks	
Leon	2002	1M	46 Central Control Module	Output Tests	
Leon	2002	1M	46 Central Control Module	Specia Functions	
Leon	2002	1M	51 Electric Drive	Read Fault Codes	
Leon	2002	1M	51 Electric Drive	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2002	1M	51 Electric Drive	Measuring Blocks	
Leon	2002	1M	51 Electric Drive	Output Tests	
Leon	2002	1M	51 Electric Drive	Specia Functions	
Leon	2002	1M	56 Radio	Read Fault Codes	
Leon	2002	1M	56 Radio	Clear Fault Codes	
Leon	2002	1M	56 Radio	Measuring Blocks	
Leon	2002	1M	56 Radio	Output Tests	
Leon	2002	1M	56 Radio	Specia Functions	
Leon	2002	1M	8C Hybrid Battery	Read Fault Codes	
Leon	2002	1M	8C Hybrid Battery	Clear Fault Codes	
Leon	2002	1M	8C Hybrid Battery	Measuring Blocks	
Leon	2002	1M	8C Hybrid Battery	Output Tests	
Leon	2002	1M	8C Hybrid Battery	Specia Functions	
Toledo	2002	1M	01 Engine Electronics	Read Fault Codes	
Toledo	2002	1M	01 Engine Electronics	Clear Fault Codes	
Toledo	2002	1M	01 Engine Electronics	Measuring Blocks	
Toledo	2002	1M	01 Engine Electronics	Output Tests	
Toledo	2002	1M	01 Engine Electronics	Specia Functions	
Toledo	2002	1M	02 Transmission Electronics	Read Fault Codes	
Toledo	2002	1M	02 Transmission Electronics	Clear Fault Codes	
Toledo	2002	1M	02 Transmission Electronics	Measuring Blocks	
Toledo	2002	1M	02 Transmission Electronics	Output Tests	
Toledo	2002	1M	02 Transmission Electronics	Specia Functions	
Toledo	2002	1M	03 Brake Electronics	Read Fault Codes	
Toledo	2002	1M	03 Brake Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2002	1M	03 Brake Electronics	Measuring Blocks	
Toledo	2002	1M	03 Brake Electronics	Output Tests	
Toledo	2002	1M	03 Brake Electronics	Specia Functions	
Toledo	2002	1M	08 AC/Heating Electronics	Read Fault Codes	
Toledo	2002	1M	08 AC/Heating Electronics	Clear Fault Codes	
Toledo	2002	1M	08 AC/Heating Electronics	Measuring Blocks	
Toledo	2002	1M	08 AC/Heating Electronics	Output Tests	
Toledo	2002	1M	08 AC/Heating Electronics	Specia Functions	
Toledo	2002	1M	11 Engine Electronics 2	Read Fault Codes	
Toledo	2002	1M	11 Engine Electronics 2	Clear Fault Codes	
Toledo	2002	1M	11 Engine Electronics 2	Measuring Blocks	
Toledo	2002	1M	11 Engine Electronics 2	Output Tests	
Toledo	2002	1M	11 Engine Electronics 2	Specia Functions	
Toledo	2002	1M	15 Airbags	Read Fault Codes	
Toledo	2002	1M	15 Airbags	Clear Fault Codes	
Toledo	2002	1M	15 Airbags	Measuring Blocks	
Toledo	2002	1M	15 Airbags	Output Tests	
Toledo	2002	1M	15 Airbags	Specia Functions	
Toledo	2002	1M	17 Instrument Cluster	Read Fault Codes	
Toledo	2002	1M	17 Instrument Cluster	Clear Fault Codes	
Toledo	2002	1M	17 Instrument Cluster	Measuring Blocks	
Toledo	2002	1M	17 Instrument Cluster	Output Tests	
Toledo	2002	1M	17 Instrument Cluster	Specia Functions	
Toledo	2002	1M	19 Gateway Data Bus	Read Fault Codes	
Toledo	2002	1M	19 Gateway Data Bus	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2002	1M	19 Gateway Data Bus	Measuring Blocks	
Toledo	2002	1M	19 Gateway Data Bus	Output Tests	
Toledo	2002	1M	19 Gateway Data Bus	Specia Functions	
Toledo	2002	1M	22 4WD Electronics	Read Fault Codes	
Toledo	2002	1M	22 4WD Electronics	Clear Fault Codes	
Toledo	2002	1M	22 4WD Electronics	Measuring Blocks	
Toledo	2002	1M	22 4WD Electronics	Output Tests	
Toledo	2002	1M	22 4WD Electronics	Specia Functions	
Toledo	2002	1M	25 Immobilizer	Read Fault Codes	
Toledo	2002	1M	25 Immobilizer	Clear Fault Codes	
Toledo	2002	1M	25 Immobilizer	Measuring Blocks	
Toledo	2002	1M	25 Immobilizer	Output Tests	
Toledo	2002	1M	25 Immobilizer	Specia Functions	
Toledo	2002	1M	35 Central Locking	Read Fault Codes	
Toledo	2002	1M	35 Central Locking	Clear Fault Codes	
Toledo	2002	1M	35 Central Locking	Measuring Blocks	
Toledo	2002	1M	35 Central Locking	Output Tests	
Toledo	2002	1M	35 Central Locking	Specia Functions	
Toledo	2002	1M	36 Driver`s Side Seat Adj.	Read Fault Codes	
Toledo	2002	1M	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Toledo	2002	1M	36 Driver`s Side Seat Adj.	Measuring Blocks	
Toledo	2002	1M	36 Driver`s Side Seat Adj.	Output Tests	
Toledo	2002	1M	36 Driver`s Side Seat Adj.	Specia Functions	
Toledo	2002	1M	37 Navigation	Read Fault Codes	
Toledo	2002	1M	37 Navigation	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2002	1M	37 Navigation	Measuring Blocks	
Toledo	2002	1M	37 Navigation	Output Tests	
Toledo	2002	1M	37 Navigation	Specia Functions	
Toledo	2002	1M	46 Central Control Module	Read Fault Codes	
Toledo	2002	1M	46 Central Control Module	Clear Fault Codes	
Toledo	2002	1M	46 Central Control Module	Measuring Blocks	
Toledo	2002	1M	46 Central Control Module	Output Tests	
Toledo	2002	1M	46 Central Control Module	Specia Functions	
Toledo	2002	1M	51 Electric Drive	Read Fault Codes	
Toledo	2002	1M	51 Electric Drive	Clear Fault Codes	
Toledo	2002	1M	51 Electric Drive	Measuring Blocks	
Toledo	2002	1M	51 Electric Drive	Output Tests	
Toledo	2002	1M	51 Electric Drive	Specia Functions	
Toledo	2002	1M	56 Radio	Read Fault Codes	
Toledo	2002	1M	56 Radio	Clear Fault Codes	
Toledo	2002	1M	56 Radio	Measuring Blocks	
Toledo	2002	1M	56 Radio	Output Tests	
Toledo	2002	1M	56 Radio	Specia Functions	
Toledo	2002	1M	8C Hybrid Battery	Read Fault Codes	
Toledo	2002	1M	8C Hybrid Battery	Clear Fault Codes	
Toledo	2002	1M	8C Hybrid Battery	Measuring Blocks	
Toledo	2002	1M	8C Hybrid Battery	Output Tests	
Toledo	2002	1M	8C Hybrid Battery	Specia Functions	
Leon	2003-2004	1M	01 Engine Electronics	Read Fault Codes	
Leon	2003-2004	1M	01 Engine Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2003-2004	1M	01 Engine Electronics	Measuring Blocks	
Leon	2003-2004	1M	01 Engine Electronics	Output Tests	
Leon	2003-2004	1M	01 Engine Electronics	Specia Functions	
Leon	2003-2004	1M	02 Transmission Electronics	Read Fault Codes	
Leon	2003-2004	1M	02 Transmission Electronics	Clear Fault Codes	
Leon	2003-2004	1M	02 Transmission Electronics	Measuring Blocks	
Leon	2003-2004	1M	02 Transmission Electronics	Output Tests	
Leon	2003-2004	1M	02 Transmission Electronics	Specia Functions	
Leon	2003-2004	1M	03 Brake Electronics	Read Fault Codes	
Leon	2003-2004	1M	03 Brake Electronics	Clear Fault Codes	
Leon	2003-2004	1M	03 Brake Electronics	Measuring Blocks	
Leon	2003-2004	1M	03 Brake Electronics	Output Tests	
Leon	2003-2004	1M	03 Brake Electronics	Specia Functions	
Leon	2003-2004	1M	08 AC/Heating Electronics	Read Fault Codes	
Leon	2003-2004	1M	08 AC/Heating Electronics	Clear Fault Codes	
Leon	2003-2004	1M	08 AC/Heating Electronics	Measuring Blocks	
Leon	2003-2004	1M	08 AC/Heating Electronics	Output Tests	
Leon	2003-2004	1M	08 AC/Heating Electronics	Specia Functions	
Leon	2003-2004	1M	11 Engine Electronics 2	Read Fault Codes	
Leon	2003-2004	1M	11 Engine Electronics 2	Clear Fault Codes	
Leon	2003-2004	1M	11 Engine Electronics 2	Measuring Blocks	
Leon	2003-2004	1M	11 Engine Electronics 2	Output Tests	
Leon	2003-2004	1M	11 Engine Electronics 2	Specia Functions	
Leon	2003-2004	1M	15 Airbags	Read Fault Codes	
Leon	2003-2004	1M	15 Airbags	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2003-2004	1M	15 Airbags	Measuring Blocks	
Leon	2003-2004	1M	15 Airbags	Output Tests	
Leon	2003-2004	1M	15 Airbags	Specia Functions	
Leon	2003-2004	1M	17 Instrument Cluster	Read Fault Codes	
Leon	2003-2004	1M	17 Instrument Cluster	Clear Fault Codes	
Leon	2003-2004	1M	17 Instrument Cluster	Measuring Blocks	
Leon	2003-2004	1M	17 Instrument Cluster	Output Tests	
Leon	2003-2004	1M	17 Instrument Cluster	Specia Functions	
Leon	2003-2004	1M	19 Gateway Data Bus	Read Fault Codes	
Leon	2003-2004	1M	19 Gateway Data Bus	Clear Fault Codes	
Leon	2003-2004	1M	19 Gateway Data Bus	Measuring Blocks	
Leon	2003-2004	1M	19 Gateway Data Bus	Output Tests	
Leon	2003-2004	1M	19 Gateway Data Bus	Specia Functions	
Leon	2003-2004	1M	22 4WD Electronics	Read Fault Codes	
Leon	2003-2004	1M	22 4WD Electronics	Clear Fault Codes	
Leon	2003-2004	1M	22 4WD Electronics	Measuring Blocks	
Leon	2003-2004	1M	22 4WD Electronics	Output Tests	
Leon	2003-2004	1M	22 4WD Electronics	Specia Functions	
Leon	2003-2004	1M	25 Immobilizer	Read Fault Codes	
Leon	2003-2004	1M	25 Immobilizer	Clear Fault Codes	
Leon	2003-2004	1M	25 Immobilizer	Measuring Blocks	
Leon	2003-2004	1M	25 Immobilizer	Output Tests	
Leon	2003-2004	1M	25 Immobilizer	Specia Functions	
Leon	2003-2004	1M	35 Central Locking	Read Fault Codes	
Leon	2003-2004	1M	35 Central Locking	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2003-2004	1M	35 Central Locking	Measuring Blocks	
Leon	2003-2004	1M	35 Central Locking	Output Tests	
Leon	2003-2004	1M	35 Central Locking	Specia Functions	
Leon	2003-2004	1M	36 Driver`s Side Seat Adj.	Read Fault Codes	
Leon	2003-2004	1M	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Leon	2003-2004	1M	36 Driver`s Side Seat Adj.	Measuring Blocks	
Leon	2003-2004	1M	36 Driver`s Side Seat Adj.	Output Tests	
Leon	2003-2004	1M	36 Driver`s Side Seat Adj.	Specia Functions	
Leon	2003-2004	1M	37 Navigation	Read Fault Codes	
Leon	2003-2004	1M	37 Navigation	Clear Fault Codes	
Leon	2003-2004	1M	37 Navigation	Measuring Blocks	
Leon	2003-2004	1M	37 Navigation	Output Tests	
Leon	2003-2004	1M	37 Navigation	Specia Functions	
Leon	2003-2004	1M	46 Central Control Module	Read Fault Codes	
Leon	2003-2004	1M	46 Central Control Module	Clear Fault Codes	
Leon	2003-2004	1M	46 Central Control Module	Measuring Blocks	
Leon	2003-2004	1M	46 Central Control Module	Output Tests	
Leon	2003-2004	1M	46 Central Control Module	Specia Functions	
Leon	2003-2004	1M	51 Electric Drive	Read Fault Codes	
Leon	2003-2004	1M	51 Electric Drive	Clear Fault Codes	
Leon	2003-2004	1M	51 Electric Drive	Measuring Blocks	
Leon	2003-2004	1M	51 Electric Drive	Output Tests	
Leon	2003-2004	1M	51 Electric Drive	Specia Functions	
Leon	2003-2004	1M	56 Radio	Read Fault Codes	
Leon	2003-2004	1M	56 Radio	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2003-2004	1M	56 Radio	Measuring Blocks	
Leon	2003-2004	1M	56 Radio	Output Tests	
Leon	2003-2004	1M	56 Radio	Specia Functions	
Leon	2003-2004	1M	8C Hybrid Battery	Read Fault Codes	
Leon	2003-2004	1M	8C Hybrid Battery	Clear Fault Codes	
Leon	2003-2004	1M	8C Hybrid Battery	Measuring Blocks	
Leon	2003-2004	1M	8C Hybrid Battery	Output Tests	
Leon	2003-2004	1M	8C Hybrid Battery	Specia Functions	
Toledo	2003-2004	1M	01 Engine Electronics	Read Fault Codes	
Toledo	2003-2004	1M	01 Engine Electronics	Clear Fault Codes	
Toledo	2003-2004	1M	01 Engine Electronics	Measuring Blocks	
Toledo	2003-2004	1M	01 Engine Electronics	Output Tests	
Toledo	2003-2004	1M	01 Engine Electronics	Specia Functions	
Toledo	2003-2004	1M	02 Transmission Electronics	Read Fault Codes	
Toledo	2003-2004	1M	02 Transmission Electronics	Clear Fault Codes	
Toledo	2003-2004	1M	02 Transmission Electronics	Measuring Blocks	
Toledo	2003-2004	1M	02 Transmission Electronics	Output Tests	
Toledo	2003-2004	1M	02 Transmission Electronics	Specia Functions	
Toledo	2003-2004	1M	03 Brake Electronics	Read Fault Codes	
Toledo	2003-2004	1M	03 Brake Electronics	Clear Fault Codes	
Toledo	2003-2004	1M	03 Brake Electronics	Measuring Blocks	
Toledo	2003-2004	1M	03 Brake Electronics	Output Tests	
Toledo	2003-2004	1M	03 Brake Electronics	Specia Functions	
Toledo	2003-2004	1M	08 AC/Heating Electronics	Read Fault Codes	
Toledo	2003-2004	1M	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2003-2004	1M	08 AC/Heating Electronics	Measuring Blocks	
Toledo	2003-2004	1M	08 AC/Heating Electronics	Output Tests	
Toledo	2003-2004	1M	08 AC/Heating Electronics	Specia Functions	
Toledo	2003-2004	1M	11 Engine Electronics 2	Read Fault Codes	
Toledo	2003-2004	1M	11 Engine Electronics 2	Clear Fault Codes	
Toledo	2003-2004	1M	11 Engine Electronics 2	Measuring Blocks	
Toledo	2003-2004	1M	11 Engine Electronics 2	Output Tests	
Toledo	2003-2004	1M	11 Engine Electronics 2	Specia Functions	
Toledo	2003-2004	1M	15 Airbags	Read Fault Codes	
Toledo	2003-2004	1M	15 Airbags	Clear Fault Codes	
Toledo	2003-2004	1M	15 Airbags	Measuring Blocks	
Toledo	2003-2004	1M	15 Airbags	Output Tests	
Toledo	2003-2004	1M	15 Airbags	Specia Functions	
Toledo	2003-2004	1M	17 Instrument Cluster	Read Fault Codes	
Toledo	2003-2004	1M	17 Instrument Cluster	Clear Fault Codes	
Toledo	2003-2004	1M	17 Instrument Cluster	Measuring Blocks	
Toledo	2003-2004	1M	17 Instrument Cluster	Output Tests	
Toledo	2003-2004	1M	17 Instrument Cluster	Specia Functions	
Toledo	2003-2004	1M	19 Gateway Data Bus	Read Fault Codes	
Toledo	2003-2004	1M	19 Gateway Data Bus	Clear Fault Codes	
Toledo	2003-2004	1M	19 Gateway Data Bus	Measuring Blocks	
Toledo	2003-2004	1M	19 Gateway Data Bus	Output Tests	
Toledo	2003-2004	1M	19 Gateway Data Bus	Specia Functions	
Toledo	2003-2004	1M	22 4WD Electronics	Read Fault Codes	
Toledo	2003-2004	1M	22 4WD Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2003-2004	1M	22 4WD Electronics	Measuring Blocks	
Toledo	2003-2004	1M	22 4WD Electronics	Output Tests	
Toledo	2003-2004	1M	22 4WD Electronics	Specia Functions	
Toledo	2003-2004	1M	25 Immobilizer	Read Fault Codes	
Toledo	2003-2004	1M	25 Immobilizer	Clear Fault Codes	
Toledo	2003-2004	1M	25 Immobilizer	Measuring Blocks	
Toledo	2003-2004	1M	25 Immobilizer	Output Tests	
Toledo	2003-2004	1M	25 Immobilizer	Specia Functions	
Toledo	2003-2004	1M	35 Central Locking	Read Fault Codes	
Toledo	2003-2004	1M	35 Central Locking	Clear Fault Codes	
Toledo	2003-2004	1M	35 Central Locking	Measuring Blocks	
Toledo	2003-2004	1M	35 Central Locking	Output Tests	
Toledo	2003-2004	1M	35 Central Locking	Specia Functions	
Toledo	2003-2004	1M	36 Driver`s Side Seat Adj.	Read Fault Codes	
Toledo	2003-2004	1M	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Toledo	2003-2004	1M	36 Driver`s Side Seat Adj.	Measuring Blocks	
Toledo	2003-2004	1M	36 Driver`s Side Seat Adj.	Output Tests	
Toledo	2003-2004	1M	36 Driver`s Side Seat Adj.	Specia Functions	
Toledo	2003-2004	1M	37 Navigation	Read Fault Codes	
Toledo	2003-2004	1M	37 Navigation	Clear Fault Codes	
Toledo	2003-2004	1M	37 Navigation	Measuring Blocks	
Toledo	2003-2004	1M	37 Navigation	Output Tests	
Toledo	2003-2004	1M	37 Navigation	Specia Functions	
Toledo	2003-2004	1M	46 Central Control Module	Read Fault Codes	
Toledo	2003-2004	1M	46 Central Control Module	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2003-2004	1M	46 Central Control Module	Measuring Blocks	
Toledo	2003-2004	1M	46 Central Control Module	Output Tests	
Toledo	2003-2004	1M	46 Central Control Module	Specia Functions	
Toledo	2003-2004	1M	51 Electric Drive	Read Fault Codes	
Toledo	2003-2004	1M	51 Electric Drive	Clear Fault Codes	
Toledo	2003-2004	1M	51 Electric Drive	Measuring Blocks	
Toledo	2003-2004	1M	51 Electric Drive	Output Tests	
Toledo	2003-2004	1M	51 Electric Drive	Specia Functions	
Toledo	2003-2004	1M	56 Radio	Read Fault Codes	
Toledo	2003-2004	1M	56 Radio	Clear Fault Codes	
Toledo	2003-2004	1M	56 Radio	Measuring Blocks	
Toledo	2003-2004	1M	56 Radio	Output Tests	
Toledo	2003-2004	1M	56 Radio	Specia Functions	
Toledo	2003-2004	1M	8C Hybrid Battery	Read Fault Codes	
Toledo	2003-2004	1M	8C Hybrid Battery	Clear Fault Codes	
Toledo	2003-2004	1M	8C Hybrid Battery	Measuring Blocks	
Toledo	2003-2004	1M	8C Hybrid Battery	Output Tests	
Toledo	2003-2004	1M	8C Hybrid Battery	Specia Functions	
Leon	2005-2006	1M	01 Engine Electronics	Read Fault Codes	
Leon	2005-2006	1M	01 Engine Electronics	Clear Fault Codes	
Leon	2005-2006	1M	01 Engine Electronics	Measuring Blocks	
Leon	2005-2006	1M	01 Engine Electronics	Output Tests	
Leon	2005-2006	1M	01 Engine Electronics	Specia Functions	
Leon	2005-2006	1M	02 Transmission Electronics	Read Fault Codes	
Leon	2005-2006	1M	02 Transmission Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2005-2006	1M	02 Transmission Electronics	Measuring Blocks	
Leon	2005-2006	1M	02 Transmission Electronics	Output Tests	
Leon	2005-2006	1M	02 Transmission Electronics	Specia Functions	
Leon	2005-2006	1M	03 Brake Electronics	Read Fault Codes	
Leon	2005-2006	1M	03 Brake Electronics	Clear Fault Codes	
Leon	2005-2006	1M	03 Brake Electronics	Measuring Blocks	
Leon	2005-2006	1M	03 Brake Electronics	Output Tests	
Leon	2005-2006	1M	03 Brake Electronics	Specia Functions	
Leon	2005-2006	1M	08 AC/Heating Electronics	Read Fault Codes	
Leon	2005-2006	1M	08 AC/Heating Electronics	Clear Fault Codes	
Leon	2005-2006	1M	08 AC/Heating Electronics	Measuring Blocks	
Leon	2005-2006	1M	08 AC/Heating Electronics	Output Tests	
Leon	2005-2006	1M	08 AC/Heating Electronics	Specia Functions	
Leon	2005-2006	1M	11 Engine Electronics 2	Read Fault Codes	
Leon	2005-2006	1M	11 Engine Electronics 2	Clear Fault Codes	
Leon	2005-2006	1M	11 Engine Electronics 2	Measuring Blocks	
Leon	2005-2006	1M	11 Engine Electronics 2	Output Tests	
Leon	2005-2006	1M	11 Engine Electronics 2	Specia Functions	
Leon	2005-2006	1M	15 Airbags	Read Fault Codes	
Leon	2005-2006	1M	15 Airbags	Clear Fault Codes	
Leon	2005-2006	1M	15 Airbags	Measuring Blocks	
Leon	2005-2006	1M	15 Airbags	Output Tests	
Leon	2005-2006	1M	15 Airbags	Specia Functions	
Leon	2005-2006	1M	17 Instrument Cluster	Read Fault Codes	
Leon	2005-2006	1M	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2005-2006	1M	17 Instrument Cluster	Measuring Blocks	
Leon	2005-2006	1M	17 Instrument Cluster	Output Tests	
Leon	2005-2006	1M	17 Instrument Cluster	Specia Functions	
Leon	2005-2006	1M	19 Gateway Data Bus	Read Fault Codes	
Leon	2005-2006	1M	19 Gateway Data Bus	Clear Fault Codes	
Leon	2005-2006	1M	19 Gateway Data Bus	Measuring Blocks	
Leon	2005-2006	1M	19 Gateway Data Bus	Output Tests	
Leon	2005-2006	1M	19 Gateway Data Bus	Specia Functions	
Leon	2005-2006	1M	25 Immobilizer	Read Fault Codes	
Leon	2005-2006	1M	25 Immobilizer	Clear Fault Codes	
Leon	2005-2006	1M	25 Immobilizer	Measuring Blocks	
Leon	2005-2006	1M	25 Immobilizer	Output Tests	
Leon	2005-2006	1M	25 Immobilizer	Specia Functions	
Leon	2005-2006	1M	35 Central Locking	Read Fault Codes	
Leon	2005-2006	1M	35 Central Locking	Clear Fault Codes	
Leon	2005-2006	1M	35 Central Locking	Measuring Blocks	
Leon	2005-2006	1M	35 Central Locking	Output Tests	
Leon	2005-2006	1M	35 Central Locking	Specia Functions	
Leon	2005-2006	1M	36 Driver`s Side Seat Adj.	Read Fault Codes	
Leon	2005-2006	1M	36 Driver`s Side Seat Adj.	Clear Fault Codes	
Leon	2005-2006	1M	36 Driver`s Side Seat Adj.	Measuring Blocks	
Leon	2005-2006	1M	36 Driver`s Side Seat Adj.	Output Tests	
Leon	2005-2006	1M	36 Driver`s Side Seat Adj.	Specia Functions	
Leon	2005-2006	1M	37 Navigation	Read Fault Codes	
Leon	2005-2006	1M	37 Navigation	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Leon	2005-2006	1M	37 Navigation	Measuring Blocks	
Leon	2005-2006	1M	37 Navigation	Output Tests	
Leon	2005-2006	1M	37 Navigation	Specia Functions	
Leon	2005-2006	1M	46 Central Control Module	Read Fault Codes	
Leon	2005-2006	1M	46 Central Control Module	Clear Fault Codes	
Leon	2005-2006	1M	46 Central Control Module	Measuring Blocks	
Leon	2005-2006	1M	46 Central Control Module	Output Tests	
Leon	2005-2006	1M	46 Central Control Module	Specia Functions	
Leon	2005-2006	1M	51 Electric Drive	Read Fault Codes	
Leon	2005-2006	1M	51 Electric Drive	Clear Fault Codes	
Leon	2005-2006	1M	51 Electric Drive	Measuring Blocks	
Leon	2005-2006	1M	51 Electric Drive	Output Tests	
Leon	2005-2006	1M	51 Electric Drive	Specia Functions	
Leon	2005-2006	1M	56 Radio	Read Fault Codes	
Leon	2005-2006	1M	56 Radio	Clear Fault Codes	
Leon	2005-2006	1M	56 Radio	Measuring Blocks	
Leon	2005-2006	1M	56 Radio	Output Tests	
Leon	2005-2006	1M	56 Radio	Specia Functions	
Leon	2005-2006	1M	8C Hybrid Battery	Read Fault Codes	
Leon	2005-2006	1M	8C Hybrid Battery	Clear Fault Codes	
Leon	2005-2006	1M	8C Hybrid Battery	Measuring Blocks	
Leon	2005-2006	1M	8C Hybrid Battery	Output Tests	
Leon	2005-2006	1M	8C Hybrid Battery	Specia Functions	
Toledo	2005-2006	1M	01 Engine Electronics	Read Fault Codes	
Toledo	2005-2006	1M	01 Engine Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2005-2006	1M	01 Engine Electronics	Measuring Blocks	
Toledo	2005-2006	1M	01 Engine Electronics	Output Tests	
Toledo	2005-2006	1M	01 Engine Electronics	Specia Functions	
Toledo	2005-2006	1M	02 Transmission Electronics	Read Fault Codes	
Toledo	2005-2006	1M	02 Transmission Electronics	Clear Fault Codes	
Toledo	2005-2006	1M	02 Transmission Electronics	Measuring Blocks	
Toledo	2005-2006	1M	02 Transmission Electronics	Output Tests	
Toledo	2005-2006	1M	02 Transmission Electronics	Specia Functions	
Toledo	2005-2006	1M	03 Brake Electronics	Read Fault Codes	
Toledo	2005-2006	1M	03 Brake Electronics	Clear Fault Codes	
Toledo	2005-2006	1M	03 Brake Electronics	Measuring Blocks	
Toledo	2005-2006	1M	03 Brake Electronics	Output Tests	
Toledo	2005-2006	1M	03 Brake Electronics	Specia Functions	
Toledo	2005-2006	1M	08 AC/Heating Electronics	Read Fault Codes	
Toledo	2005-2006	1M	08 AC/Heating Electronics	Clear Fault Codes	
Toledo	2005-2006	1M	08 AC/Heating Electronics	Measuring Blocks	
Toledo	2005-2006	1M	08 AC/Heating Electronics	Output Tests	
Toledo	2005-2006	1M	08 AC/Heating Electronics	Specia Functions	
Toledo	2005-2006	1M	11 Engine Electronics 2	Read Fault Codes	
Toledo	2005-2006	1M	11 Engine Electronics 2	Clear Fault Codes	
Toledo	2005-2006	1M	11 Engine Electronics 2	Measuring Blocks	
Toledo	2005-2006	1M	11 Engine Electronics 2	Output Tests	
Toledo	2005-2006	1M	11 Engine Electronics 2	Specia Functions	
Toledo	2005-2006	1M	15 Airbags	Read Fault Codes	
Toledo	2005-2006	1M	15 Airbags	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2005-2006	1M	15 Airbags	Measuring Blocks	
Toledo	2005-2006	1M	15 Airbags	Output Tests	
Toledo	2005-2006	1M	15 Airbags	Specia Functions	
Toledo	2005-2006	1M	17 Instrument Cluster	Read Fault Codes	
Toledo	2005-2006	1M	17 Instrument Cluster	Clear Fault Codes	
Toledo	2005-2006	1M	17 Instrument Cluster	Measuring Blocks	
Toledo	2005-2006	1M	17 Instrument Cluster	Output Tests	
Toledo	2005-2006	1M	17 Instrument Cluster	Specia Functions	
Toledo	2005-2006	1M	19 Gateway Data Bus	Read Fault Codes	
Toledo	2005-2006	1M	19 Gateway Data Bus	Clear Fault Codes	
Toledo	2005-2006	1M	19 Gateway Data Bus	Measuring Blocks	
Toledo	2005-2006	1M	19 Gateway Data Bus	Output Tests	
Toledo	2005-2006	1M	19 Gateway Data Bus	Specia Functions	
Toledo	2005-2006	1M	25 Immobilizer	Read Fault Codes	
Toledo	2005-2006	1M	25 Immobilizer	Clear Fault Codes	
Toledo	2005-2006	1M	25 Immobilizer	Measuring Blocks	
Toledo	2005-2006	1M	25 Immobilizer	Output Tests	
Toledo	2005-2006	1M	25 Immobilizer	Specia Functions	
Toledo	2005-2006	1M	35 Central Locking	Read Fault Codes	
Toledo	2005-2006	1M	35 Central Locking	Clear Fault Codes	
Toledo	2005-2006	1M	35 Central Locking	Measuring Blocks	
Toledo	2005-2006	1M	35 Central Locking	Output Tests	
Toledo	2005-2006	1M	35 Central Locking	Specia Functions	
Toledo	2005-2006	1M	36 Driver`s Side Seat Adj.	Read Fault Codes	
Toledo	2005-2006	1M	36 Driver`s Side Seat Adj.	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2005-2006	1M	36 Driver`s Side Seat Adj.	Measuring Blocks	
Toledo	2005-2006	1M	36 Driver`s Side Seat Adj.	Output Tests	
Toledo	2005-2006	1M	36 Driver`s Side Seat Adj.	Specia Functions	
Toledo	2005-2006	1M	37 Navigation	Read Fault Codes	
Toledo	2005-2006	1M	37 Navigation	Clear Fault Codes	
Toledo	2005-2006	1M	37 Navigation	Measuring Blocks	
Toledo	2005-2006	1M	37 Navigation	Output Tests	
Toledo	2005-2006	1M	37 Navigation	Specia Functions	
Toledo	2005-2006	1M	46 Central Control Module	Read Fault Codes	
Toledo	2005-2006	1M	46 Central Control Module	Clear Fault Codes	
Toledo	2005-2006	1M	46 Central Control Module	Measuring Blocks	
Toledo	2005-2006	1M	46 Central Control Module	Output Tests	
Toledo	2005-2006	1M	46 Central Control Module	Specia Functions	
Toledo	2005-2006	1M	51 Electric Drive	Read Fault Codes	
Toledo	2005-2006	1M	51 Electric Drive	Clear Fault Codes	
Toledo	2005-2006	1M	51 Electric Drive	Measuring Blocks	
Toledo	2005-2006	1M	51 Electric Drive	Output Tests	
Toledo	2005-2006	1M	51 Electric Drive	Specia Functions	
Toledo	2005-2006	1M	56 Radio	Read Fault Codes	
Toledo	2005-2006	1M	56 Radio	Clear Fault Codes	
Toledo	2005-2006	1M	56 Radio	Measuring Blocks	
Toledo	2005-2006	1M	56 Radio	Output Tests	
Toledo	2005-2006	1M	56 Radio	Specia Functions	
Toledo	2005-2006	1M	8C Hybrid Battery	Read Fault Codes	
Toledo	2005-2006	1M	8C Hybrid Battery	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	2005-2006	1M	8C Hybrid Battery	Measuring Blocks	
Toledo	2005-2006	1M	8C Hybrid Battery	Output Tests	
Toledo	2005-2006	1M	8C Hybrid Battery	Specia Functions	
Arosa	1997-2004	6H	01 Engine Electronics	Read Fault Codes	
Arosa	1997-2004	6H	01 Engine Electronics	Clear Fault Codes	
Arosa	1997-2004	6H	01 Engine Electronics	Measuring Blocks	
Arosa	1997-2004	6H	01 Engine Electronics	Output Tests	
Arosa	1997-2004	6H	01 Engine Electronics	Specia Functions	
Arosa	1997-2004	6H	02 Transmission Electronics	Read Fault Codes	
Arosa	1997-2004	6H	02 Transmission Electronics	Clear Fault Codes	
Arosa	1997-2004	6H	02 Transmission Electronics	Measuring Blocks	
Arosa	1997-2004	6H	02 Transmission Electronics	Output Tests	
Arosa	1997-2004	6H	02 Transmission Electronics	Specia Functions	
Arosa	1997-2004	6H	03 Brake Electronics	Read Fault Codes	
Arosa	1997-2004	6H	03 Brake Electronics	Clear Fault Codes	
Arosa	1997-2004	6H	03 Brake Electronics	Measuring Blocks	
Arosa	1997-2004	6H	03 Brake Electronics	Output Tests	
Arosa	1997-2004	6H	03 Brake Electronics	Specia Functions	
Arosa	1997-2004	6H	11 Engine Electronics 2	Read Fault Codes	
Arosa	1997-2004	6H	11 Engine Electronics 2	Clear Fault Codes	
Arosa	1997-2004	6H	11 Engine Electronics 2	Measuring Blocks	
Arosa	1997-2004	6H	11 Engine Electronics 2	Output Tests	
Arosa	1997-2004	6H	11 Engine Electronics 2	Specia Functions	
Arosa	1997-2004	6H	15 Airbags	Read Fault Codes	
Arosa	1997-2004	6H	15 Airbags	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Arosa	1997-2004	6H	15 Airbags	Measuring Blocks	
Arosa	1997-2004	6H	15 Airbags	Output Tests	
Arosa	1997-2004	6H	15 Airbags	Specia Functions	
Arosa	1997-2004	6H	17 Instrument Cluster	Read Fault Codes	
Arosa	1997-2004	6H	17 Instrument Cluster	Clear Fault Codes	
Arosa	1997-2004	6H	17 Instrument Cluster	Measuring Blocks	
Arosa	1997-2004	6H	17 Instrument Cluster	Output Tests	
Arosa	1997-2004	6H	17 Instrument Cluster	Specia Functions	
Arosa	1997-2004	6H	25 Immobilizer	Read Fault Codes	
Arosa	1997-2004	6H	25 Immobilizer	Clear Fault Codes	
Arosa	1997-2004	6H	25 Immobilizer	Measuring Blocks	
Arosa	1997-2004	6H	25 Immobilizer	Output Tests	
Arosa	1997-2004	6H	25 Immobilizer	Specia Functions	
Arosa	1997-2004	6H	35 Central Locking	Read Fault Codes	
Arosa	1997-2004	6H	35 Central Locking	Clear Fault Codes	
Arosa	1997-2004	6H	35 Central Locking	Measuring Blocks	
Arosa	1997-2004	6H	35 Central Locking	Output Tests	
Arosa	1997-2004	6H	35 Central Locking	Specia Functions	
Arosa	1997-2004	6H	51 Electric Drive	Read Fault Codes	
Arosa	1997-2004	6H	51 Electric Drive	Clear Fault Codes	
Arosa	1997-2004	6H	51 Electric Drive	Measuring Blocks	
Arosa	1997-2004	6H	51 Electric Drive	Output Tests	
Arosa	1997-2004	6H	51 Electric Drive	Specia Functions	
Arosa	1997-2004	6H	56 Radio	Read Fault Codes	
Arosa	1997-2004	6H	56 Radio	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Arosa	1997-2004	6H	56 Radio	Measuring Blocks	
Arosa	1997-2004	6H	56 Radio	Output Tests	
Arosa	1997-2004	6H	56 Radio	Specia Functions	
Arosa	1997-2004	6H	8C Hybrid Battery	Read Fault Codes	
Arosa	1997-2004	6H	8C Hybrid Battery	Clear Fault Codes	
Arosa	1997-2004	6H	8C Hybrid Battery	Measuring Blocks	
Arosa	1997-2004	6H	8C Hybrid Battery	Output Tests	
Arosa	1997-2004	6H	8C Hybrid Battery	Specia Functions	
Inca	1995-2001	9K	01 Engine Electronics	Read Fault Codes	
Inca	1995-2001	9K	01 Engine Electronics	Clear Fault Codes	
Inca	1995-2001	9K	01 Engine Electronics	Measuring Blocks	
Inca	1995-2001	9K	01 Engine Electronics	Output Tests	
Inca	1995-2001	9K	01 Engine Electronics	Specia Functions	
Inca	1995-2001	9K	02 Transmission Electronics	Read Fault Codes	
Inca	1995-2001	9K	02 Transmission Electronics	Clear Fault Codes	
Inca	1995-2001	9K	02 Transmission Electronics	Measuring Blocks	
Inca	1995-2001	9K	02 Transmission Electronics	Output Tests	
Inca	1995-2001	9K	02 Transmission Electronics	Specia Functions	
Inca	1995-2001	9K	03 Brake Electronics	Read Fault Codes	
Inca	1995-2001	9K	03 Brake Electronics	Clear Fault Codes	
Inca	1995-2001	9K	03 Brake Electronics	Measuring Blocks	
Inca	1995-2001	9K	03 Brake Electronics	Output Tests	
Inca	1995-2001	9K	03 Brake Electronics	Specia Functions	
Inca	1995-2001	9K	11 Engine Electronics 2	Read Fault Codes	
Inca	1995-2001	9K	11 Engine Electronics 2	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Inca	1995-2001	9K	11 Engine Electronics 2	Measuring Blocks	
Inca	1995-2001	9K	11 Engine Electronics 2	Output Tests	
Inca	1995-2001	9K	11 Engine Electronics 2	Specia Functions	
Inca	1995-2001	9K	15 Airbags	Read Fault Codes	
Inca	1995-2001	9K	15 Airbags	Clear Fault Codes	
Inca	1995-2001	9K	15 Airbags	Measuring Blocks	
Inca	1995-2001	9K	15 Airbags	Output Tests	
Inca	1995-2001	9K	15 Airbags	Specia Functions	
Inca	1995-2001	9K	17 Instrument Cluster	Read Fault Codes	
Inca	1995-2001	9K	17 Instrument Cluster	Clear Fault Codes	
Inca	1995-2001	9K	17 Instrument Cluster	Measuring Blocks	
Inca	1995-2001	9K	17 Instrument Cluster	Output Tests	
Inca	1995-2001	9K	17 Instrument Cluster	Specia Functions	
Inca	1995-2001	9K	25 Immobilizer	Read Fault Codes	
Inca	1995-2001	9K	25 Immobilizer	Clear Fault Codes	
Inca	1995-2001	9K	25 Immobilizer	Measuring Blocks	
Inca	1995-2001	9K	25 Immobilizer	Output Tests	
Inca	1995-2001	9K	25 Immobilizer	Specia Functions	
Inca	1995-2001	9K	51 Electric Drive	Read Fault Codes	
Inca	1995-2001	9K	51 Electric Drive	Clear Fault Codes	
Inca	1995-2001	9K	51 Electric Drive	Measuring Blocks	
Inca	1995-2001	9K	51 Electric Drive	Output Tests	
Inca	1995-2001	9K	51 Electric Drive	Specia Functions	
Inca	1995-2001	9K	56 Radio	Read Fault Codes	
Inca	1995-2001	9K	56 Radio	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Inca	1995-2001	9K	56 Radio	Measuring Blocks	
Inca	1995-2001	9K	56 Radio	Output Tests	
Inca	1995-2001	9K	56 Radio	Specia Functions	
Inca	1995-2001	9K	8C Hybrid Battery	Read Fault Codes	
Inca	1995-2001	9K	8C Hybrid Battery	Clear Fault Codes	
Inca	1995-2001	9K	8C Hybrid Battery	Measuring Blocks	
Inca	1995-2001	9K	8C Hybrid Battery	Output Tests	
Inca	1995-2001	9K	8C Hybrid Battery	Specia Functions	
Inca	2002-2004	9K	01 Engine Electronics	Read Fault Codes	
Inca	2002-2004	9K	01 Engine Electronics	Clear Fault Codes	
Inca	2002-2004	9K	01 Engine Electronics	Measuring Blocks	
Inca	2002-2004	9K	01 Engine Electronics	Output Tests	
Inca	2002-2004	9K	01 Engine Electronics	Specia Functions	
Inca	2002-2004	9K	02 Transmission Electronics	Read Fault Codes	
Inca	2002-2004	9K	02 Transmission Electronics	Clear Fault Codes	
Inca	2002-2004	9K	02 Transmission Electronics	Measuring Blocks	
Inca	2002-2004	9K	02 Transmission Electronics	Output Tests	
Inca	2002-2004	9K	02 Transmission Electronics	Specia Functions	
Inca	2002-2004	9K	03 Brake Electronics	Read Fault Codes	
Inca	2002-2004	9K	03 Brake Electronics	Clear Fault Codes	
Inca	2002-2004	9K	03 Brake Electronics	Measuring Blocks	
Inca	2002-2004	9K	03 Brake Electronics	Output Tests	
Inca	2002-2004	9K	03 Brake Electronics	Specia Functions	
Inca	2002-2004	9K	11 Engine Electronics 2	Read Fault Codes	
Inca	2002-2004	9K	11 Engine Electronics 2	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Inca	2002-2004	9K	11 Engine Electronics 2	Measuring Blocks	
Inca	2002-2004	9K	11 Engine Electronics 2	Output Tests	
Inca	2002-2004	9K	11 Engine Electronics 2	Specia Functions	
Inca	2002-2004	9K	15 Airbags	Read Fault Codes	
Inca	2002-2004	9K	15 Airbags	Clear Fault Codes	
Inca	2002-2004	9K	15 Airbags	Measuring Blocks	
Inca	2002-2004	9K	15 Airbags	Output Tests	
Inca	2002-2004	9K	15 Airbags	Specia Functions	
Inca	2002-2004	9K	17 Instrument Cluster	Read Fault Codes	
Inca	2002-2004	9K	17 Instrument Cluster	Clear Fault Codes	
Inca	2002-2004	9K	17 Instrument Cluster	Measuring Blocks	
Inca	2002-2004	9K	17 Instrument Cluster	Output Tests	
Inca	2002-2004	9K	17 Instrument Cluster	Specia Functions	
Inca	2002-2004	9K	25 Immobilizer	Read Fault Codes	
Inca	2002-2004	9K	25 Immobilizer	Clear Fault Codes	
Inca	2002-2004	9K	25 Immobilizer	Measuring Blocks	
Inca	2002-2004	9K	25 Immobilizer	Output Tests	
Inca	2002-2004	9K	25 Immobilizer	Specia Functions	
Inca	2002-2004	9K	51 Electric Drive	Read Fault Codes	
Inca	2002-2004	9K	51 Electric Drive	Clear Fault Codes	
Inca	2002-2004	9K	51 Electric Drive	Measuring Blocks	
Inca	2002-2004	9K	51 Electric Drive	Output Tests	
Inca	2002-2004	9K	51 Electric Drive	Specia Functions	
Inca	2002-2004	9K	56 Radio	Read Fault Codes	
Inca	2002-2004	9K	56 Radio	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Inca	2002-2004	9K	56 Radio	Measuring Blocks	
Inca	2002-2004	9K	56 Radio	Output Tests	
Inca	2002-2004	9K	56 Radio	Specia Functions	
Inca	2002-2004	9K	8C Hybrid Battery	Read Fault Codes	
Inca	2002-2004	9K	8C Hybrid Battery	Clear Fault Codes	
Inca	2002-2004	9K	8C Hybrid Battery	Measuring Blocks	
Inca	2002-2004	9K	8C Hybrid Battery	Output Tests	
Inca	2002-2004	9K	8C Hybrid Battery	Specia Functions	
Cordoba	1993-2002	6K	01 Engine Electronics	Read Fault Codes	
Cordoba	1993-2002	6K	01 Engine Electronics	Clear Fault Codes	
Cordoba	1993-2002	6K	01 Engine Electronics	Measuring Blocks	
Cordoba	1993-2002	6K	01 Engine Electronics	Output Tests	
Cordoba	1993-2002	6K	01 Engine Electronics	Specia Functions	
Cordoba	1993-2002	6K	02 Transmission Electronics	Read Fault Codes	
Cordoba	1993-2002	6K	02 Transmission Electronics	Clear Fault Codes	
Cordoba	1993-2002	6K	02 Transmission Electronics	Measuring Blocks	
Cordoba	1993-2002	6K	02 Transmission Electronics	Output Tests	
Cordoba	1993-2002	6K	02 Transmission Electronics	Specia Functions	
Cordoba	1993-2002	6K	03 Brake Electronics	Read Fault Codes	
Cordoba	1993-2002	6K	03 Brake Electronics	Clear Fault Codes	
Cordoba	1993-2002	6K	03 Brake Electronics	Measuring Blocks	
Cordoba	1993-2002	6K	03 Brake Electronics	Output Tests	
Cordoba	1993-2002	6K	03 Brake Electronics	Specia Functions	
Cordoba	1993-2002	6K	08 AC/Heating Electronics	Read Fault Codes	
Cordoba	1993-2002	6K	08 AC/Heating Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	1993-2002	6K	08 AC/Heating Electronics	Measuring Blocks	
Cordoba	1993-2002	6K	08 AC/Heating Electronics	Output Tests	
Cordoba	1993-2002	6K	08 AC/Heating Electronics	Specia Functions	
Cordoba	1993-2002	6K	11 Engine Electronics 2	Read Fault Codes	
Cordoba	1993-2002	6K	11 Engine Electronics 2	Clear Fault Codes	
Cordoba	1993-2002	6K	11 Engine Electronics 2	Measuring Blocks	
Cordoba	1993-2002	6K	11 Engine Electronics 2	Output Tests	
Cordoba	1993-2002	6K	11 Engine Electronics 2	Specia Functions	
Cordoba	1993-2002	6K	15 Airbags	Read Fault Codes	
Cordoba	1993-2002	6K	15 Airbags	Clear Fault Codes	
Cordoba	1993-2002	6K	15 Airbags	Measuring Blocks	
Cordoba	1993-2002	6K	15 Airbags	Output Tests	
Cordoba	1993-2002	6K	15 Airbags	Specia Functions	
Cordoba	1993-2002	6K	17 Instrument Cluster	Read Fault Codes	
Cordoba	1993-2002	6K	17 Instrument Cluster	Clear Fault Codes	
Cordoba	1993-2002	6K	17 Instrument Cluster	Measuring Blocks	
Cordoba	1993-2002	6K	17 Instrument Cluster	Output Tests	
Cordoba	1993-2002	6K	17 Instrument Cluster	Specia Functions	
Cordoba	1993-2002	6K	25 Immobilizer	Read Fault Codes	
Cordoba	1993-2002	6K	25 Immobilizer	Clear Fault Codes	
Cordoba	1993-2002	6K	25 Immobilizer	Measuring Blocks	
Cordoba	1993-2002	6K	25 Immobilizer	Output Tests	
Cordoba	1993-2002	6K	25 Immobilizer	Specia Functions	
Cordoba	1993-2002	6K	51 Electric Drive	Read Fault Codes	
Cordoba	1993-2002	6K	51 Electric Drive	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Cordoba	1993-2002	6K	51 Electric Drive	Measuring Blocks	
Cordoba	1993-2002	6K	51 Electric Drive	Output Tests	
Cordoba	1993-2002	6K	51 Electric Drive	Specia Functions	
Cordoba	1993-2002	6K	56 Radio	Read Fault Codes	
Cordoba	1993-2002	6K	56 Radio	Clear Fault Codes	
Cordoba	1993-2002	6K	56 Radio	Measuring Blocks	
Cordoba	1993-2002	6K	56 Radio	Output Tests	
Cordoba	1993-2002	6K	56 Radio	Specia Functions	
Cordoba	1993-2002	6K	8C Hybrid Battery	Read Fault Codes	
Cordoba	1993-2002	6K	8C Hybrid Battery	Clear Fault Codes	
Cordoba	1993-2002	6K	8C Hybrid Battery	Measuring Blocks	
Cordoba	1993-2002	6K	8C Hybrid Battery	Output Tests	
Cordoba	1993-2002	6K	8C Hybrid Battery	Specia Functions	
Ibiza	1993-2002	6K	01 Engine Electronics	Read Fault Codes	
Ibiza	1993-2002	6K	01 Engine Electronics	Clear Fault Codes	
Ibiza	1993-2002	6K	01 Engine Electronics	Measuring Blocks	
Ibiza	1993-2002	6K	01 Engine Electronics	Output Tests	
Ibiza	1993-2002	6K	01 Engine Electronics	Specia Functions	
Ibiza	1993-2002	6K	02 Transmission Electronics	Read Fault Codes	
Ibiza	1993-2002	6K	02 Transmission Electronics	Clear Fault Codes	
Ibiza	1993-2002	6K	02 Transmission Electronics	Measuring Blocks	
Ibiza	1993-2002	6K	02 Transmission Electronics	Output Tests	
Ibiza	1993-2002	6K	02 Transmission Electronics	Specia Functions	
Ibiza	1993-2002	6K	03 Brake Electronics	Read Fault Codes	
Ibiza	1993-2002	6K	03 Brake Electronics	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	1993-2002	6K	03 Brake Electronics	Measuring Blocks	
Ibiza	1993-2002	6K	03 Brake Electronics	Output Tests	
Ibiza	1993-2002	6K	03 Brake Electronics	Specia Functions	
Ibiza	1993-2002	6K	08 AC/Heating Electronics	Read Fault Codes	
Ibiza	1993-2002	6K	08 AC/Heating Electronics	Clear Fault Codes	
Ibiza	1993-2002	6K	08 AC/Heating Electronics	Measuring Blocks	
Ibiza	1993-2002	6K	08 AC/Heating Electronics	Output Tests	
Ibiza	1993-2002	6K	08 AC/Heating Electronics	Specia Functions	
Ibiza	1993-2002	6K	11 Engine Electronics 2	Read Fault Codes	
Ibiza	1993-2002	6K	11 Engine Electronics 2	Clear Fault Codes	
Ibiza	1993-2002	6K	11 Engine Electronics 2	Measuring Blocks	
Ibiza	1993-2002	6K	11 Engine Electronics 2	Output Tests	
Ibiza	1993-2002	6K	11 Engine Electronics 2	Specia Functions	
Ibiza	1993-2002	6K	15 Airbags	Read Fault Codes	
Ibiza	1993-2002	6K	15 Airbags	Clear Fault Codes	
Ibiza	1993-2002	6K	15 Airbags	Measuring Blocks	
Ibiza	1993-2002	6K	15 Airbags	Output Tests	
Ibiza	1993-2002	6K	15 Airbags	Specia Functions	
Ibiza	1993-2002	6K	17 Instrument Cluster	Read Fault Codes	
Ibiza	1993-2002	6K	17 Instrument Cluster	Clear Fault Codes	
Ibiza	1993-2002	6K	17 Instrument Cluster	Measuring Blocks	
Ibiza	1993-2002	6K	17 Instrument Cluster	Output Tests	
Ibiza	1993-2002	6K	17 Instrument Cluster	Specia Functions	
Ibiza	1993-2002	6K	25 Immobilizer	Read Fault Codes	
Ibiza	1993-2002	6K	25 Immobilizer	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	1993-2002	6K	25 Immobilizer	Measuring Blocks	
Ibiza	1993-2002	6K	25 Immobilizer	Output Tests	
Ibiza	1993-2002	6K	25 Immobilizer	Specia Functions	
Ibiza	1993-2002	6K	51 Electric Drive	Read Fault Codes	
Ibiza	1993-2002	6K	51 Electric Drive	Clear Fault Codes	
Ibiza	1993-2002	6K	51 Electric Drive	Measuring Blocks	
Ibiza	1993-2002	6K	51 Electric Drive	Output Tests	
Ibiza	1993-2002	6K	51 Electric Drive	Specia Functions	
Ibiza	1993-2002	6K	56 Radio	Read Fault Codes	
Ibiza	1993-2002	6K	56 Radio	Clear Fault Codes	
Ibiza	1993-2002	6K	56 Radio	Measuring Blocks	
Ibiza	1993-2002	6K	56 Radio	Output Tests	
Ibiza	1993-2002	6K	56 Radio	Specia Functions	
Ibiza	1993-2002	6K	8C Hybrid Battery	Read Fault Codes	
Ibiza	1993-2002	6K	8C Hybrid Battery	Clear Fault Codes	
Ibiza	1993-2002	6K	8C Hybrid Battery	Measuring Blocks	
Ibiza	1993-2002	6K	8C Hybrid Battery	Output Tests	
Ibiza	1993-2002	6K	8C Hybrid Battery	Specia Functions	
Toledo	1996-1999	1L	01 Engine Electronics	Read Fault Codes	
Toledo	1996-1999	1L	01 Engine Electronics	Clear Fault Codes	
Toledo	1996-1999	1L	01 Engine Electronics	Measuring Blocks	
Toledo	1996-1999	1L	01 Engine Electronics	Output Tests	
Toledo	1996-1999	1L	01 Engine Electronics	Specia Functions	
Toledo	1996-1999	1L	02 Transmission Electronics	Read Fault Codes	
Toledo	1996-1999	1L	02 Transmission Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	1996-1999	1L	02 Transmission Electronics	Measuring Blocks	
Toledo	1996-1999	1L	02 Transmission Electronics	Output Tests	
Toledo	1996-1999	1L	02 Transmission Electronics	Specia Functions	
Toledo	1996-1999	1L	03 Brake Electronics	Read Fault Codes	
Toledo	1996-1999	1L	03 Brake Electronics	Clear Fault Codes	
Toledo	1996-1999	1L	03 Brake Electronics	Measuring Blocks	
Toledo	1996-1999	1L	03 Brake Electronics	Output Tests	
Toledo	1996-1999	1L	03 Brake Electronics	Specia Functions	
Toledo	1996-1999	1L	08 AC/Heating Electronics	Read Fault Codes	
Toledo	1996-1999	1L	08 AC/Heating Electronics	Clear Fault Codes	
Toledo	1996-1999	1L	08 AC/Heating Electronics	Measuring Blocks	
Toledo	1996-1999	1L	08 AC/Heating Electronics	Output Tests	
Toledo	1996-1999	1L	08 AC/Heating Electronics	Specia Functions	
Toledo	1996-1999	1L	11 Engine Electronics 2	Read Fault Codes	
Toledo	1996-1999	1L	11 Engine Electronics 2	Clear Fault Codes	
Toledo	1996-1999	1L	11 Engine Electronics 2	Measuring Blocks	
Toledo	1996-1999	1L	11 Engine Electronics 2	Output Tests	
Toledo	1996-1999	1L	11 Engine Electronics 2	Specia Functions	
Toledo	1996-1999	1L	15 Airbags	Read Fault Codes	
Toledo	1996-1999	1L	15 Airbags	Clear Fault Codes	
Toledo	1996-1999	1L	15 Airbags	Measuring Blocks	
Toledo	1996-1999	1L	15 Airbags	Output Tests	
Toledo	1996-1999	1L	15 Airbags	Specia Functions	
Toledo	1996-1999	1L	17 Instrument Cluster	Read Fault Codes	
Toledo	1996-1999	1L	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	1996-1999	1L	17 Instrument Cluster	Measuring Blocks	
Toledo	1996-1999	1L	17 Instrument Cluster	Output Tests	
Toledo	1996-1999	1L	17 Instrument Cluster	Specia Functions	
Toledo	1996-1999	1L	25 Immobilizer	Read Fault Codes	
Toledo	1996-1999	1L	25 Immobilizer	Clear Fault Codes	
Toledo	1996-1999	1L	25 Immobilizer	Measuring Blocks	
Toledo	1996-1999	1L	25 Immobilizer	Output Tests	
Toledo	1996-1999	1L	25 Immobilizer	Specia Functions	
Toledo	1996-1999	1L	35 Central Locking	Read Fault Codes	
Toledo	1996-1999	1L	35 Central Locking	Clear Fault Codes	
Toledo	1996-1999	1L	35 Central Locking	Measuring Blocks	
Toledo	1996-1999	1L	35 Central Locking	Output Tests	
Toledo	1996-1999	1L	35 Central Locking	Specia Functions	
Toledo	1996-1999	1L	51 Electric Drive	Read Fault Codes	
Toledo	1996-1999	1L	51 Electric Drive	Clear Fault Codes	
Toledo	1996-1999	1L	51 Electric Drive	Measuring Blocks	
Toledo	1996-1999	1L	51 Electric Drive	Output Tests	
Toledo	1996-1999	1L	51 Electric Drive	Specia Functions	
Toledo	1996-1999	1L	56 Radio	Read Fault Codes	
Toledo	1996-1999	1L	56 Radio	Clear Fault Codes	
Toledo	1996-1999	1L	56 Radio	Measuring Blocks	
Toledo	1996-1999	1L	56 Radio	Output Tests	
Toledo	1996-1999	1L	56 Radio	Specia Functions	
Toledo	1996-1999	1L	8C Hybrid Battery	Read Fault Codes	
Toledo	1996-1999	1L	8C Hybrid Battery	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Toledo	1996-1999	1L	8C Hybrid Battery	Measuring Blocks	
Toledo	1996-1999	1L	8C Hybrid Battery	Output Tests	
Toledo	1996-1999	1L	8C Hybrid Battery	Specia Functions	
Ateca	2016-2018	5F	01 Engine Electronics	Read Fault Codes	
Ateca	2016-2018	5F	01 Engine Electronics	Clear Fault Codes	
Ateca	2016-2018	5F	01 Engine Electronics	Measuring Blocks	
Ateca	2016-2018	5F	01 Engine Electronics	Output Tests	
Ateca	2016-2018	5F	01 Engine Electronics	Specia Functions	
Ateca	2016-2018	5F	02 Transmission Electronics	Read Fault Codes	
Ateca	2016-2018	5F	02 Transmission Electronics	Clear Fault Codes	
Ateca	2016-2018	5F	02 Transmission Electronics	Measuring Blocks	
Ateca	2016-2018	5F	02 Transmission Electronics	Output Tests	
Ateca	2016-2018	5F	02 Transmission Electronics	Specia Functions	
Ateca	2016-2018	5F	03 Brake Electronics	Read Fault Codes	
Ateca	2016-2018	5F	03 Brake Electronics	Clear Fault Codes	
Ateca	2016-2018	5F	03 Brake Electronics	Measuring Blocks	
Ateca	2016-2018	5F	03 Brake Electronics	Output Tests	
Ateca	2016-2018	5F	03 Brake Electronics	Specia Functions	
Ateca	2016-2018	5F	08 AC/Heating Electronics	Read Fault Codes	
Ateca	2016-2018	5F	08 AC/Heating Electronics	Clear Fault Codes	
Ateca	2016-2018	5F	08 AC/Heating Electronics	Measuring Blocks	
Ateca	2016-2018	5F	08 AC/Heating Electronics	Output Tests	
Ateca	2016-2018	5F	08 AC/Heating Electronics	Specia Functions	
Ateca	2016-2018	5F	09 Electronic Ctrl Electronics	Read Fault Codes	
Ateca	2016-2018	5F	09 Electronic Ctrl Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ateca	2016-2018	5F	09 Electronic Ctrl Electronics	Measuring Blocks	
Ateca	2016-2018	5F	09 Electronic Ctrl Electronics	Output Tests	
Ateca	2016-2018	5F	09 Electronic Ctrl Electronics	Specia Functions	
Ateca	2016-2018	5F	13 Distance Control	Read Fault Codes	
Ateca	2016-2018	5F	13 Distance Control	Clear Fault Codes	
Ateca	2016-2018	5F	13 Distance Control	Measuring Blocks	
Ateca	2016-2018	5F	13 Distance Control	Output Tests	
Ateca	2016-2018	5F	13 Distance Control	Specia Functions	
Ateca	2016-2018	5F	14 Wheel Damping Electronics	Read Fault Codes	
Ateca	2016-2018	5F	14 Wheel Damping Electronics	Clear Fault Codes	
Ateca	2016-2018	5F	14 Wheel Damping Electronics	Measuring Blocks	
Ateca	2016-2018	5F	14 Wheel Damping Electronics	Output Tests	
Ateca	2016-2018	5F	14 Wheel Damping Electronics	Specia Functions	
Ateca	2016-2018	5F	15 Airbags	Read Fault Codes	
Ateca	2016-2018	5F	15 Airbags	Clear Fault Codes	
Ateca	2016-2018	5F	15 Airbags	Measuring Blocks	
Ateca	2016-2018	5F	15 Airbags	Output Tests	
Ateca	2016-2018	5F	15 Airbags	Specia Functions	
Ateca	2016-2018	5F	16 Steering Wheel Electronics	Read Fault Codes	
Ateca	2016-2018	5F	16 Steering Wheel Electronics	Clear Fault Codes	
Ateca	2016-2018	5F	16 Steering Wheel Electronics	Measuring Blocks	
Ateca	2016-2018	5F	16 Steering Wheel Electronics	Output Tests	
Ateca	2016-2018	5F	16 Steering Wheel Electronics	Specia Functions	
Ateca	2016-2018	5F	17 Instrument Cluster	Read Fault Codes	
Ateca	2016-2018	5F	17 Instrument Cluster	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ateca	2016-2018	5F	17 Instrument Cluster	Measuring Blocks	
Ateca	2016-2018	5F	17 Instrument Cluster	Output Tests	
Ateca	2016-2018	5F	17 Instrument Cluster	Specia Functions	
Ateca	2016-2018	5F	19 Gateway Data Bus	Read Fault Codes	
Ateca	2016-2018	5F	19 Gateway Data Bus	Clear Fault Codes	
Ateca	2016-2018	5F	19 Gateway Data Bus	Measuring Blocks	
Ateca	2016-2018	5F	19 Gateway Data Bus	Output Tests	
Ateca	2016-2018	5F	19 Gateway Data Bus	Specia Functions	
Ateca	2016-2018	5F	22 4WD Electronics	Read Fault Codes	
Ateca	2016-2018	5F	22 4WD Electronics	Clear Fault Codes	
Ateca	2016-2018	5F	22 4WD Electronics	Measuring Blocks	
Ateca	2016-2018	5F	22 4WD Electronics	Output Tests	
Ateca	2016-2018	5F	22 4WD Electronics	Specia Functions	
Ateca	2016-2018	5F	2B Steer Col Lock	Read Fault Codes	
Ateca	2016-2018	5F	2B Steer Col Lock	Clear Fault Codes	
Ateca	2016-2018	5F	2B Steer Col Lock	Measuring Blocks	
Ateca	2016-2018	5F	2B Steer Col Lock	Output Tests	
Ateca	2016-2018	5F	2B Steer Col Lock	Specia Functions	
Ateca	2016-2018	5F	32 Locking Electronisc	Read Fault Codes	
Ateca	2016-2018	5F	32 Locking Electronisc	Clear Fault Codes	
Ateca	2016-2018	5F	32 Locking Electronisc	Measuring Blocks	
Ateca	2016-2018	5F	32 Locking Electronisc	Output Tests	
Ateca	2016-2018	5F	32 Locking Electronisc	Specia Functions	
Ateca	2016-2018	5F	3C Lane Departure Assistance System	Read Fault Codes	
Ateca	2016-2018	5F	3C Lane Departure Assistance System	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ateca	2016-2018	5F	3C Lane Departure Assistance System	Measuring Blocks	
Ateca	2016-2018	5F	3C Lane Departure Assistance System	Output Tests	
Ateca	2016-2018	5F	3C Lane Departure Assistance System	Specia Functions	
Ateca	2016-2018	5F	3D Special Function	Read Fault Codes	
Ateca	2016-2018	5F	3D Special Function	Clear Fault Codes	
Ateca	2016-2018	5F	3D Special Function	Measuring Blocks	
Ateca	2016-2018	5F	3D Special Function	Output Tests	
Ateca	2016-2018	5F	3D Special Function	Specia Functions	
Ateca	2016-2018	5F	42 Driver-Door Elect.	Read Fault Codes	
Ateca	2016-2018	5F	42 Driver-Door Elect.	Clear Fault Codes	
Ateca	2016-2018	5F	42 Driver-Door Elect.	Measuring Blocks	
Ateca	2016-2018	5F	42 Driver-Door Elect.	Output Tests	
Ateca	2016-2018	5F	42 Driver-Door Elect.	Specia Functions	
Ateca	2016-2018	5F	44 Steering Assistance	Read Fault Codes	
Ateca	2016-2018	5F	44 Steering Assistance	Clear Fault Codes	
Ateca	2016-2018	5F	44 Steering Assistance	Measuring Blocks	
Ateca	2016-2018	5F	44 Steering Assistance	Output Tests	
Ateca	2016-2018	5F	44 Steering Assistance	Specia Functions	
Ateca	2016-2018	5F	52 Passe.-Door Elect.	Read Fault Codes	
Ateca	2016-2018	5F	52 Passe.-Door Elect.	Clear Fault Codes	
Ateca	2016-2018	5F	52 Passe.-Door Elect.	Measuring Blocks	
Ateca	2016-2018	5F	52 Passe.-Door Elect.	Output Tests	
Ateca	2016-2018	5F	52 Passe.-Door Elect.	Specia Functions	
Ateca	2016-2018	5F	55 Headlight Range Control	Read Fault Codes	
Ateca	2016-2018	5F	55 Headlight Range Control	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ateca	2016-2018	5F	55 Headlight Range Control	Measuring Blocks	
Ateca	2016-2018	5F	55 Headlight Range Control	Output Tests	
Ateca	2016-2018	5F	55 Headlight Range Control	Specia Functions	
Ateca	2016-2018	5F	5F Information Electronic Equipment 1	Read Fault Codes	
Ateca	2016-2018	5F	5F Information Electronic Equipment 1	Clear Fault Codes	
Ateca	2016-2018	5F	5F Information Electronic Equipment 1	Measuring Blocks	
Ateca	2016-2018	5F	5F Information Electronic Equipment 1	Output Tests	
Ateca	2016-2018	5F	5F Information Electronic Equipment 1	Specia Functions	
Ateca	2016-2018	5F	69 Trailer Function	Read Fault Codes	
Ateca	2016-2018	5F	69 Trailer Function	Clear Fault Codes	
Ateca	2016-2018	5F	69 Trailer Function	Measuring Blocks	
Ateca	2016-2018	5F	69 Trailer Function	Output Tests	
Ateca	2016-2018	5F	69 Trailer Function	Specia Functions	
Ateca	2016-2018	5F	6C Rear Camera	Read Fault Codes	
Ateca	2016-2018	5F	6C Rear Camera	Clear Fault Codes	
Ateca	2016-2018	5F	6C Rear Camera	Measuring Blocks	
Ateca	2016-2018	5F	6C Rear Camera	Output Tests	
Ateca	2016-2018	5F	6C Rear Camera	Specia Functions	
Ateca	2016-2018	5F	6D Electronic Equipment of Trunk Lid	Read Fault Codes	
Ateca	2016-2018	5F	6D Electronic Equipment of Trunk Lid	Clear Fault Codes	
Ateca	2016-2018	5F	6D Electronic Equipment of Trunk Lid	Measuring Blocks	
Ateca	2016-2018	5F	6D Electronic Equipment of Trunk Lid	Output Tests	
Ateca	2016-2018	5F	6D Electronic Equipment of Trunk Lid	Specia Functions	
Ateca	2016-2018	5F	76 Parking Aid	Read Fault Codes	
Ateca	2016-2018	5F	76 Parking Aid	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ateca	2016-2018	5F	76 Parking Aid	Measuring Blocks	
Ateca	2016-2018	5F	76 Parking Aid	Output Tests	
Ateca	2016-2018	5F	76 Parking Aid	Specia Functions	
Ateca	2016-2018	5F	A5 Frt Sens.Drv.Assist	Read Fault Codes	
Ateca	2016-2018	5F	A5 Frt Sens.Drv.Assist	Clear Fault Codes	
Ateca	2016-2018	5F	A5 Frt Sens.Drv.Assist	Measuring Blocks	
Ateca	2016-2018	5F	A5 Frt Sens.Drv.Assist	Output Tests	
Ateca	2016-2018	5F	A5 Frt Sens.Drv.Assist	Specia Functions	
Ateca	2016-2018	5F	A9 Struct.Borne Sound	Read Fault Codes	
Ateca	2016-2018	5F	A9 Struct.Borne Sound	Clear Fault Codes	
Ateca	2016-2018	5F	A9 Struct.Borne Sound	Measuring Blocks	
Ateca	2016-2018	5F	A9 Struct.Borne Sound	Output Tests	
Ateca	2016-2018	5F	A9 Struct.Borne Sound	Specia Functions	
Ateca	2016-2018	5F	B7 Access Start Interf	Read Fault Codes	
Ateca	2016-2018	5F	B7 Access Start Interf	Clear Fault Codes	
Ateca	2016-2018	5F	B7 Access Start Interf	Measuring Blocks	
Ateca	2016-2018	5F	B7 Access Start Interf	Output Tests	
Ateca	2016-2018	5F	B7 Access Start Interf	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	01 Engine Electronics	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	01 Engine Electronics	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	01 Engine Electronics	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	01 Engine Electronics	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	01 Engine Electronics	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	02 Transmission Electronics	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	02 Transmission Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza GP2 USA/AGCC	2016-2017	KZ	02 Transmission Electronics	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	02 Transmission Electronics	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	02 Transmission Electronics	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	03 Brake Electronics	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	03 Brake Electronics	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	03 Brake Electronics	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	03 Brake Electronics	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	03 Brake Electronics	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	08 AC/Heating Electronics	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	08 AC/Heating Electronics	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	08 AC/Heating Electronics	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	08 AC/Heating Electronics	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	08 AC/Heating Electronics	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	09 Electronic Ctrl Electronics	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	09 Electronic Ctrl Electronics	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	09 Electronic Ctrl Electronics	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	09 Electronic Ctrl Electronics	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	09 Electronic Ctrl Electronics	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	14 Wheel Damping Electronics	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	14 Wheel Damping Electronics	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	14 Wheel Damping Electronics	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	14 Wheel Damping Electronics	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	14 Wheel Damping Electronics	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	15 Airbags	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	15 Airbags	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza GP2 USA/AGCC	2016-2017	KZ	15 Airbags	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	15 Airbags	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	15 Airbags	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	17 Instrument Cluster	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	17 Instrument Cluster	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	17 Instrument Cluster	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	17 Instrument Cluster	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	17 Instrument Cluster	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	19 Gateway Data Bus	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	19 Gateway Data Bus	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	19 Gateway Data Bus	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	19 Gateway Data Bus	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	19 Gateway Data Bus	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	44 Steering Assistance	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	44 Steering Assistance	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	44 Steering Assistance	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	44 Steering Assistance	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	44 Steering Assistance	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	55 Headlight Range Control	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	55 Headlight Range Control	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	55 Headlight Range Control	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	55 Headlight Range Control	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	55 Headlight Range Control	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	5F Information Electronic Equipment 1	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	5F Information Electronic Equipment 1	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza GP2 USA/AGCC	2016-2017	KZ	5F Information Electronic Equipment 1	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	5F Information Electronic Equipment 1	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	5F Information Electronic Equipment 1	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	69 Trailer Function	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	69 Trailer Function	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	69 Trailer Function	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	69 Trailer Function	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	69 Trailer Function	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	76 Parking Aid	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	76 Parking Aid	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	76 Parking Aid	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	76 Parking Aid	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	76 Parking Aid	Specia Functions	
Ibiza GP2 USA/AGCC	2016-2017	KZ	A9 Struct.Borne Sound	Read Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	A9 Struct.Borne Sound	Clear Fault Codes	
Ibiza GP2 USA/AGCC	2016-2017	KZ	A9 Struct.Borne Sound	Measuring Blocks	
Ibiza GP2 USA/AGCC	2016-2017	KZ	A9 Struct.Borne Sound	Output Tests	
Ibiza GP2 USA/AGCC	2016-2017	KZ	A9 Struct.Borne Sound	Specia Functions	
Ibiza	2017-2018	KJ	01 Engine Electronics	Read Fault Codes	
Ibiza	2017-2018	KJ	01 Engine Electronics	Clear Fault Codes	
Ibiza	2017-2018	KJ	01 Engine Electronics	Measuring Blocks	
Ibiza	2017-2018	KJ	01 Engine Electronics	Output Tests	
Ibiza	2017-2018	KJ	01 Engine Electronics	Specia Functions	
Ibiza	2017-2018	KJ	02 Transmission Electronics	Read Fault Codes	
Ibiza	2017-2018	KJ	02 Transmission Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2017-2018	KJ	02 Transmission Electronics	Measuring Blocks	
Ibiza	2017-2018	KJ	02 Transmission Electronics	Output Tests	
Ibiza	2017-2018	KJ	02 Transmission Electronics	Specia Functions	
Ibiza	2017-2018	KJ	03 Brake Electronics	Read Fault Codes	
Ibiza	2017-2018	KJ	03 Brake Electronics	Clear Fault Codes	
Ibiza	2017-2018	KJ	03 Brake Electronics	Measuring Blocks	
Ibiza	2017-2018	KJ	03 Brake Electronics	Output Tests	
Ibiza	2017-2018	KJ	03 Brake Electronics	Specia Functions	
Ibiza	2017-2018	KJ	08 AC/Heating Electronics	Read Fault Codes	
Ibiza	2017-2018	KJ	08 AC/Heating Electronics	Clear Fault Codes	
Ibiza	2017-2018	KJ	08 AC/Heating Electronics	Measuring Blocks	
Ibiza	2017-2018	KJ	08 AC/Heating Electronics	Output Tests	
Ibiza	2017-2018	KJ	08 AC/Heating Electronics	Specia Functions	
Ibiza	2017-2018	KJ	09 Electronic Ctrl Electronics	Read Fault Codes	
Ibiza	2017-2018	KJ	09 Electronic Ctrl Electronics	Clear Fault Codes	
Ibiza	2017-2018	KJ	09 Electronic Ctrl Electronics	Measuring Blocks	
Ibiza	2017-2018	KJ	09 Electronic Ctrl Electronics	Output Tests	
Ibiza	2017-2018	KJ	09 Electronic Ctrl Electronics	Specia Functions	
Ibiza	2017-2018	KJ	13 Distance Control	Read Fault Codes	
Ibiza	2017-2018	KJ	13 Distance Control	Clear Fault Codes	
Ibiza	2017-2018	KJ	13 Distance Control	Measuring Blocks	
Ibiza	2017-2018	KJ	13 Distance Control	Output Tests	
Ibiza	2017-2018	KJ	13 Distance Control	Specia Functions	
Ibiza	2017-2018	KJ	14 Wheel Damping Electronics	Read Fault Codes	
Ibiza	2017-2018	KJ	14 Wheel Damping Electronics	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2017-2018	KJ	14 Wheel Damping Electronics	Measuring Blocks	
Ibiza	2017-2018	KJ	14 Wheel Damping Electronics	Output Tests	
Ibiza	2017-2018	KJ	14 Wheel Damping Electronics	Specia Functions	
Ibiza	2017-2018	KJ	15 Airbags	Read Fault Codes	
Ibiza	2017-2018	KJ	15 Airbags	Clear Fault Codes	
Ibiza	2017-2018	KJ	15 Airbags	Measuring Blocks	
Ibiza	2017-2018	KJ	15 Airbags	Output Tests	
Ibiza	2017-2018	KJ	15 Airbags	Specia Functions	
Ibiza	2017-2018	KJ	16 Steering Wheel Electronics	Read Fault Codes	
Ibiza	2017-2018	KJ	16 Steering Wheel Electronics	Clear Fault Codes	
Ibiza	2017-2018	KJ	16 Steering Wheel Electronics	Measuring Blocks	
Ibiza	2017-2018	KJ	16 Steering Wheel Electronics	Output Tests	
Ibiza	2017-2018	KJ	16 Steering Wheel Electronics	Specia Functions	
Ibiza	2017-2018	KJ	17 Instrument Cluster	Read Fault Codes	
Ibiza	2017-2018	KJ	17 Instrument Cluster	Clear Fault Codes	
Ibiza	2017-2018	KJ	17 Instrument Cluster	Measuring Blocks	
Ibiza	2017-2018	KJ	17 Instrument Cluster	Output Tests	
Ibiza	2017-2018	KJ	17 Instrument Cluster	Specia Functions	
Ibiza	2017-2018	KJ	19 Gateway Data Bus	Read Fault Codes	
Ibiza	2017-2018	KJ	19 Gateway Data Bus	Clear Fault Codes	
Ibiza	2017-2018	KJ	19 Gateway Data Bus	Measuring Blocks	
Ibiza	2017-2018	KJ	19 Gateway Data Bus	Output Tests	
Ibiza	2017-2018	KJ	19 Gateway Data Bus	Specia Functions	
Ibiza	2017-2018	KJ	2B Steer Col Lock	Read Fault Codes	
Ibiza	2017-2018	KJ	2B Steer Col Lock	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2017-2018	KJ	2B Steer Col Lock	Measuring Blocks	
Ibiza	2017-2018	KJ	2B Steer Col Lock	Output Tests	
Ibiza	2017-2018	KJ	2B Steer Col Lock	Specia Functions	
Ibiza	2017-2018	KJ	3C Lane Departure Assistance System	Read Fault Codes	
Ibiza	2017-2018	KJ	3C Lane Departure Assistance System	Clear Fault Codes	
Ibiza	2017-2018	KJ	3C Lane Departure Assistance System	Measuring Blocks	
Ibiza	2017-2018	KJ	3C Lane Departure Assistance System	Output Tests	
Ibiza	2017-2018	KJ	3C Lane Departure Assistance System	Specia Functions	
Ibiza	2017-2018	KJ	44 Steering Assistance	Read Fault Codes	
Ibiza	2017-2018	KJ	44 Steering Assistance	Clear Fault Codes	
Ibiza	2017-2018	KJ	44 Steering Assistance	Measuring Blocks	
Ibiza	2017-2018	KJ	44 Steering Assistance	Output Tests	
Ibiza	2017-2018	KJ	44 Steering Assistance	Specia Functions	
Ibiza	2017-2018	KJ	47 Soundsystem	Read Fault Codes	
Ibiza	2017-2018	KJ	47 Soundsystem	Clear Fault Codes	
Ibiza	2017-2018	KJ	47 Soundsystem	Measuring Blocks	
Ibiza	2017-2018	KJ	47 Soundsystem	Output Tests	
Ibiza	2017-2018	KJ	47 Soundsystem	Specia Functions	
Ibiza	2017-2018	KJ	55 Headlight Range Control	Read Fault Codes	
Ibiza	2017-2018	KJ	55 Headlight Range Control	Clear Fault Codes	
Ibiza	2017-2018	KJ	55 Headlight Range Control	Measuring Blocks	
Ibiza	2017-2018	KJ	55 Headlight Range Control	Output Tests	
Ibiza	2017-2018	KJ	55 Headlight Range Control	Specia Functions	
Ibiza	2017-2018	KJ	5F Information Electronic Equipment 1	Read Fault Codes	
Ibiza	2017-2018	KJ	5F Information Electronic Equipment 1	Clear Fault Codes	



<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2017-2018	KJ	5F Information Electronic Equipment 1	Measuring Blocks	
Ibiza	2017-2018	KJ	5F Information Electronic Equipment 1	Output Tests	
Ibiza	2017-2018	KJ	5F Information Electronic Equipment 1	Specia Functions	
Ibiza	2017-2018	KJ	69 Trailer Function	Read Fault Codes	
Ibiza	2017-2018	KJ	69 Trailer Function	Clear Fault Codes	
Ibiza	2017-2018	KJ	69 Trailer Function	Measuring Blocks	
Ibiza	2017-2018	KJ	69 Trailer Function	Output Tests	
Ibiza	2017-2018	KJ	69 Trailer Function	Specia Functions	
Ibiza	2017-2018	KJ	76 Parking Aid	Read Fault Codes	
Ibiza	2017-2018	KJ	76 Parking Aid	Clear Fault Codes	
Ibiza	2017-2018	KJ	76 Parking Aid	Measuring Blocks	
Ibiza	2017-2018	KJ	76 Parking Aid	Output Tests	
Ibiza	2017-2018	KJ	76 Parking Aid	Specia Functions	
Ibiza	2017-2018	KJ	B7 Access Start Interf	Read Fault Codes	
Ibiza	2017-2018	KJ	B7 Access Start Interf	Clear Fault Codes	
Ibiza	2017-2018	KJ	B7 Access Start Interf	Measuring Blocks	
Ibiza	2017-2018	KJ	B7 Access Start Interf	Output Tests	
Ibiza	2017-2018	KJ	B7 Access Start Interf	Specia Functions	
Ibiza	2017-2018	KJ	CA Control Module For Sunroof	Read Fault Codes	
Ibiza	2017-2018	KJ	CA Control Module For Sunroof	Clear Fault Codes	
Ibiza	2017-2018	KJ	CA Control Module For Sunroof	Measuring Blocks	
Ibiza	2017-2018	KJ	CA Control Module For Sunroof	Output Tests	
Ibiza	2017-2018	KJ	CA Control Module For Sunroof	Specia Functions	
Ibiza	2017-2018	KJ	D6 Light Control Left 2	Read Fault Codes	
Ibiza	2017-2018	KJ	D6 Light Control Left 2	Clear Fault Codes	

<b>model</b>	<b>year</b>	<b>chassis</b>	<b>system</b>	<b>function</b>	<b>subfunction</b>
Ibiza	2017-2018	KJ	D6 Light Control Left 2	Measuring Blocks	
Ibiza	2017-2018	KJ	D6 Light Control Left 2	Output Tests	
Ibiza	2017-2018	KJ	D6 Light Control Left 2	Specia Functions	
Ibiza	2017-2018	KJ	D7 Light Control Right 2	Read Fault Codes	
Ibiza	2017-2018	KJ	D7 Light Control Right 2	Clear Fault Codes	
Ibiza	2017-2018	KJ	D7 Light Control Right 2	Measuring Blocks	
Ibiza	2017-2018	KJ	D7 Light Control Right 2	Output Tests	
Ibiza	2017-2018	KJ	D7 Light Control Right 2	Specia Functions	
Ibiza	2017-2018	KJ	DD Control Module 2 For Sunroof	Read Fault Codes	
Ibiza	2017-2018	KJ	DD Control Module 2 For Sunroof	Clear Fault Codes	
Ibiza	2017-2018	KJ	DD Control Module 2 For Sunroof	Measuring Blocks	
Ibiza	2017-2018	KJ	DD Control Module 2 For Sunroof	Output Tests	
Ibiza	2017-2018	KJ	DD Control Module 2 For Sunroof	Specia Functions	