



Function List

AutoMaker:Byd

NOTES:

√ This function is supported.

X This function is not supported.

vehicle	model	model	model	model	Information	Fualt	Freeze	Erase	LiveData	ActiveTest	SpecilFunc
BYD	Qin	Qin_DM (2013.12-2015.04)	Engine System	1.5 TID Electronic Injection	√	√	x	√	√	√	0001 0002
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	High Voltage Battery Manager	√	√	x	√	√	x	0003 0004
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	Low Voltage Battery Manager	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	Drive Motor Controller	√	√	x	√	√	x	0005 0006
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	Gear Controller	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	DC-DC Assembly Module	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	Gear P Motor Controller	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	Combination Instrument System	√	√	x	√	x	x	0007
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	On-Board Charger	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	EV-HEV Switch	√	√	x	√	x	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	Active discharging module	√	x	x	x	√	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Power module	Battery Management System	√	√	x	√	√	√	0008 0009
BYD	Qin	Qin_DM (2013.12-2015.04)	Automatic Transmission System	BYD DCT Transmission Control System	√	√	x	√	√	√	000A
BYD	Qin	Qin_DM (2013.12-2015.04)	Electronic Stability Program	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	Qin	Qin_DM (2013.12-2015.04)	Supplementary Restraint System	SRS (CAN)	√	√	x	√	√	x	000E
BYD	Qin	Qin_DM (2013.12-2015.04)	Power Steering System	Power Steering System	√	√	x	√	√	x	000F 0010
BYD	Qin	Qin_DM (2013.12-2015.04)	Electronic Parking Brake	Electronic Parking Brake	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Smart Key System	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Body Control System	√	√	x	√	√	√	0011
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Steering Shaft Lock System	√	√	x	√	x	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Parking Auxiliary System	√	√	x	√	x	x	0012
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	OCS	√	√	x	√	√	√	0013
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Combination switch module	√	√	x	√	x	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Relay Control Module	√	√	x	√	x	√	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Tire Pressure Monitoring System (TPMS)	√	√	x	√	√	x	0014 0015
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Gateway	√	√	x	√	x	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Front Left Window Control Module	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	A/C Compressor Module	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Electrical Columns Adjustment Module	√	√	x	√	√	√	0016
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Front Right Door Control Module	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Front Left Door Control Module	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Seat Memory System	√	√	x	√	√	√	0017
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Panoramic Controller	√	√	x	√	x	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Panoramic Steering Wheel Switch	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Rear Seat	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Information Station	√	√	x	√	x	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	1#Switching Group	√	√	x	√	x	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Front Passenger Seat Heating Switch	√	√	x	√	x	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Automatic Cruise Control	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Multimedia	√	x	x	x	x	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Around View DSP	√	x	x	x	√	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Cloud Service System	√	x	x	x	x	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	A/C Water Heater	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2013.12-2015.04)	Body Control System	Engine Sound Simulator	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2013.12-2015.04)	BOSCH ACM System	Hydraulic Power Brake	√	√	x	√	√	x	0018
BYD	Qin	Qin_DM (2013.12-2015.04)	Immobilizer System	Immobilizer System	x	x	x	x	x	x	0019
BYD	Qin	Qin_DM (2015.05-2017.01)	Power module	On-Board Charger	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2015.05-2017.01)	Power module	Low Voltage Battery Management System	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Power module	Battery Controller	√	x	x	x	x	x	
BYD	Qin	Qin_DM (2015.05-2017.01)	Power module	Battery Management System	√	√	x	√	√	√	0008 0009
BYD	Qin	Qin_DM (2015.05-2017.01)	Power module	EV-HEV Switch	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2015.05-2017.01)	Power module	Electric Leakage Sensor	√	√	x	√	√	x	

BYD	Qin	Qin_DM (2015.05-2017.01)	Power module	Instrument Cluster	√	√	×	√	×	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	ECM module	Dual-clutch Transmission	√	√	×	√	√	√	001A 001B 001C 001D
BYD	Qin	Qin_DM (2015.05-2017.01)	ECM module	DC-DC Assembly	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	ECM module	Gear Controller	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	ECM module	Drive Motor Controller	√	√	×	√	√	×	001E
BYD	Qin	Qin_DM (2015.05-2017.01)	ECM module	1.5 TID Electronic Injection	√	√	×	√	√	√	0001 0002
BYD	Qin	Qin_DM (2015.05-2017.01)	ECM module	Active Leak Controller	√	×	×	×	√	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Chassis module	Electronic Parking System	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Chassis module	Power-assisted Steering	√	√	×	√	√	×	000F 0010
BYD	Qin	Qin_DM (2015.05-2017.01)	Chassis module	ESP	√	√	×	√	√	×	000B 000C 000D
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Supplementary Restraint System	√	√	×	√	√	×	000E 001F
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Parking Assist System	√	√	×	√	√	×	0020
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Door Multiple Controller	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Electric Steering Column	√	√	×	√	√	√	0016
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Multimedia	√	×	×	×	×	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Front Passenger Ventilation And Heating Switch	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	4G Communication Module	√	×	×	×	×	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	No.1 Switch Combination	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Rear Multimedia Control Switch	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	A/C Water Heater	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	A/C Compressor Controller	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Green Purification System	√	√	×	√	√	×	0021
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Front Hood Distribution Box	√	√	×	√	×	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Around View DSP	√	×	×	×	√	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Around View MCU	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Tire pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Automobile Data Recorder	√	×	×	×	×	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Information Station	√	√	×	√	×	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Engine Sound Simulator	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Right Front Door Control	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Cloud Service System	√	×	×	×	×	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Driver Seat	√	√	×	√	√	√	0026
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Combined Switch	√	√	×	√	×	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Body module	Left Front Door Control	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Immobilizer module	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Immobilizer module	Body Controller	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2015.05-2017.01)	Immobilizer module	Intelligent Key	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2015.05-2017.01)	Gateway module	Gateway	√	√	×	√	×	×	
BYD	Qin	Qin_DM (2017.02-)	Power module	On-Board Charger	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2017.02-)	Power module	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Power module	Battery Controller	√	×	×	×	×	×	
BYD	Qin	Qin_DM (2017.02-)	Power module	Battery Management System_Ternary 100	√	√	×	√	√	√	0008 0009
BYD	Qin	Qin_DM (2017.02-)	Power module	Battery Management System_Ternary 60	√	√	×	√	√	√	0008 0009
BYD	Qin	Qin_DM (2017.02-)	Power module	Battery Management System (BMS)_Ternary 80	√	√	×	√	√	√	0008 0009
BYD	Qin	Qin_DM (2017.02-)	Power module	EV-HEV Switch	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2017.02-)	Power module	Electric Leakage Sensor	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2017.02-)	Power module	Instrument Cluster	√	√	×	√	×	×	0027
BYD	Qin	Qin_DM (2017.02-)	ECM module	Transmission Control Unit (TCU) - Dry Type	√	√	×	√	√	√	001A 001B 001C 001D
BYD	Qin	Qin_DM (2017.02-)	ECM module	DC-DC Assembly	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2017.02-)	ECM module	Gear Sensor	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2017.02-)	ECM module	Engine Controller 1.5TID	√	√	×	√	√	√	0001 0002 0028
BYD	Qin	Qin_DM (2017.02-)	ECM module	Drive Motor Controller	√	√	×	√	√	×	001E 0029 002A
BYD	Qin	Qin_DM (2017.02-)	ECM module	Active Leak Controller	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2017.02-)	Chassis module	ESP	√	√	×	√	√	×	000B 000C 000D
BYD	Qin	Qin_DM (2017.02-)	Chassis module	Electrical Parking Brake	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Chassis module	Electronic Parking (SAC)	√	√	×	√	√	√	002B
BYD	Qin	Qin_DM (2017.02-)	Chassis module	Main Blind Area Monitoring	√	√	×	√	×	×	
BYD	Qin	Qin_DM (2017.02-)	Chassis module	Power-assisted Steering	√	√	×	√	√	×	002C 002D
BYD	Qin	Qin_DM (2017.02-)	Chassis module	Adaptive Cruise System	√	√	×	√	√	√	002E 002F
BYD	Qin	Qin_DM (2017.02-)	Body module	Supplementary Restraint System	√	√	×	√	√	×	000E 001F
BYD	Qin	Qin_DM (2017.02-)	Body module	Parking Assist System	√	√	×	√	√	×	0020
BYD	Qin	Qin_DM (2017.02-)	Body module	Door Multiple Controller	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Car Refrigerator	√	√	×	√	√	×	
BYD	Qin	Qin_DM (2017.02-)	Body module	Battery Cooling Controller	√	√	×	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Electric Steering Column System	√	√	×	√	√	√	0016
BYD	Qin	Qin_DM (2017.02-)	Body module	Multimedia	√	×	×	×	×	×	

BYD	Qin	Qin_DM (2017.02-)	Body module	Multimedia Power Supply	√	x	x	x	x	x	
BYD	Qin	Qin_DM (2017.02-)	Body module	Multimedia Panel	√	x	x	x	x	x	
BYD	Qin	Qin_DM (2017.02-)	Body module	Front Passenger Seat Adjustment Switch	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Front Passenger Seat System	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	4G Communication Module	√	x	x	x	x	x	
BYD	Qin	Qin_DM (2017.02-)	Body module	A/C Control Panel	√	√	x	√	x	x	
BYD	Qin	Qin_DM (2017.02-)	Body module	Automatic Cruise Control	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	A/C Water Heater	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2017.02-)	Body module	A/C Compressor Controller	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2017.02-)	Body module	Green Purification System	√	√	x	√	√	x	0021
BYD	Qin	Qin_DM (2017.02-)	Body module	Internal Rear View Mirror	√	√	x	√	x	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Front Hood Distribution Box	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Panoramic video	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2017.02-)	Body module	Panoramic Steering Wheel Switch	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Tire pressure Management Module	√	√	x	√	√	x	0022 0023 0024 0025
BYD	Qin	Qin_DM (2017.02-)	Body module	Tire Pressure Management Module (Baolong)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Qin	Qin_DM (2017.02-)	Body module	Tire Pressure Management Module (Sentasa)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Qin	Qin_DM (2017.02-)	Body module	Variable Fan	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Cruise Switch	√	√	x	√	√	x	
BYD	Qin	Qin_DM (2017.02-)	Body module	Engine Sound Simulator	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Right Front Door Control	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Driver Seat Adjustment Switch	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Driver Seat System	√	√	x	√	√	√	0026
BYD	Qin	Qin_DM (2017.02-)	Body module	Combined Switch	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Body module	Left Front Door Control	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Immobilizer module	Steering Shaft Lock	√	√	x	√	x	x	
BYD	Qin	Qin_DM (2017.02-)	Immobilizer module	Body Controller	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Immobilizer module	Intelligent Key	√	√	x	√	√	√	
BYD	Qin	Qin_DM (2017.02-)	Gateway module	Gateway	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	Master Controller	√	√	x	√	√	x	0032 0033
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	Battery Management System	√	√	x	√	√	√	0003 0004
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	Battery Controller	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	Active Leak Controller	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	DC-DC Assembly Module	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	Gear Controller	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	Instrument Cluster	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	Low Voltage Battery Management System	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	Electric Leakage Sensor	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	Mode Switch	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	On-Board Charger	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	VTOG Driving	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	VTOG Mode	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	VTOG Charging	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Power module	VTOG_DSP2	√	√	x	√	√	√	0034
BYD	Qin	Qin_EV (2016.03-2017.03)	Chassis module	Electronic Parking System	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Chassis module	Power Steering System	√	√	x	√	√	x	000F 0010
BYD	Qin	Qin_EV (2016.03-2017.03)	Chassis module	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Automatic Cruise Control	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	A/C Compressor Controller	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Combined Switch	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Front Passenger Ventilation Heating Switch	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Cloud Service System	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Front Left Door Control Module	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Front Right Door Control Module	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Door Multiple Controller	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Panoramic video	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Panoramic Steering Wheel Switch	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Information Station	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Multimedia System	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Multimedia Panel	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Parking Assist System	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Green Purification System	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	A/C Water Heater	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Electronic Steering Column	√	√	x	√	√	√	0016
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Front Hood Distribution Box	√	√	x	√	x	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Driver Seat System	√	√	x	√	√	√	0026
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Supplementary Restraint System	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	No.1 Switch Combination	√	√	x	√	√	√	

BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Tire Pressure Monitoring System (TPMS)	√	√	×	√	√	×	0014 0015
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	On-board terminal module	√		×	×	×	×	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Automobile Data Recorder	√		×	×	×	×	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	4G Communication Module	√		×	×	×	×	
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Battery Cooling Controller	√		√	×	√	√	√
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	A/C Control Panel	√		√	×	√	×	×
BYD	Qin	Qin_EV (2016.03-2017.03)	Body module	Engine Sound Simulator	√		√	×	√	√	√
BYD	Qin	Qin_EV (2016.03-2017.03)	Immobilizer module	Steering Shaft Lock System	√		√	×	√	×	×
BYD	Qin	Qin_EV (2016.03-2017.03)	Immobilizer module	Body Controller	√		√	×	√	√	√
BYD	Qin	Qin_EV (2016.03-2017.03)	Immobilizer module	Intelligent Key	√		√	×	√	√	√
BYD	Qin	Qin_EV (2016.03-2017.03)	Gateway module	Gateway	√		√	×	√	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	DC-DC Assembly	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Gear Controller	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Low Voltage Battery Management System	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Battery Controller	√		×	×	×	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Battery Management System	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Electric Leakage Sensor	√		×	×	×	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Mode Switch	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	VTOG_DSP2	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	VTOG Charging	√		×	×	×	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	VTOG Driving	√		×	×	×	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	VTOG Mode	√		×	×	×	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Active Leak Controller	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Master Controller	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Instrument Cluster	√		√	×	√	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Car Charger (3.3 KW)	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	Car Charger (7KW)	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Power module	VTOG_DSP2 Simple Version	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Chassis module	ESP	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Chassis module	Electrical Parking Brake	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Chassis module	Electronic Parking (SAC)	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Chassis module	Power-assisted Steering	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Chassis module	Adaptive Cruise System	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Supplementary Restraint System	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Parking Assist System	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Door Multiple Controller	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Battery Heater	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Battery Cooling Controller	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Electric Steering Column	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Multimedia	√		×	×	×	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Multimedia Power Supply	√		×	×	×	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Multimedia Panel	√		×	×	×	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Front Passenger Seat Adjustment Switch	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Front Passenger Seat System	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	4G Communication Module	√		×	×	×	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Automatic Cruise Control	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	A/C Water Heater	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	A/C Compressor	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Green Purification System	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Internal Rear View Mirror	√		×	×	×	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Front Hood Distribution Box	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Panoramic video	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Panoramic Steering Wheel Switch	√		√	×	√	√	√
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Tire pressure Management Module	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Tire Pressure Management Module (Baolong)	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Tire Pressure Management Module (Sentasa)	√		√	×	√	√	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Automobile Data Recorder	√		×	×	×	×	×
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Cruise Switch	√		√	×	√	√	×

BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Engine Sound Simulator	√	√	×	√	√	√	
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Right Front Door Control	√	√	×	√	√	√	
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Driver Seat Adjustment Switch	√	√	×	√	√	√	
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Driver Seat System	√	√	×	√	√	√	0026
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Combined Switch	√	√	×	√	√	√	
BYD	Qin	Qin_EV (2017.04-2019.10)	Body module	Left Front Door Control	√	√	×	√	√	√	
BYD	Qin	Qin_EV (2017.04-2019.10)	Immobilizer module	Body Controller	√	√	×	√	√	√	
BYD	Qin	Qin_EV (2017.04-2019.10)	Immobilizer module	Intelligent Key	√	√	×	√	√	√	
BYD	Qin	Qin_EV (2017.04-2019.10)	Immobilizer module	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Qin	Qin_EV (2017.04-2019.10)	Gateway module	Gateway	√	√	×	√	×	×	
BYD	Qin	Qin Pro_EV	Power network	Vehicle Controller	√	√	×	√	√	×	0002 0001 0037 0038 0034 0039
BYD	Qin	Qin Pro_EV	Power network	On-Board Charger	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Power network	Electric Leakage Sensor	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Power network	Front Drive Motor Controller	√	√	×	√	√	×	003A
BYD	Qin	Qin Pro_EV	Power network	DC-DC Assembly	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Power network	Battery Heater	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Power network	Battery Controller	√	×	×	×	×	×	
BYD	Qin	Qin Pro_EV	Power network	Battery Management System	√	√	×	√	√	√	0008 0009 0035 003B
BYD	Qin	Qin Pro_EV	Power network	Ternary Battery Manager 500	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Power network	Ternary Battery Manager 330	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Power network	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Power network	Gear Sensor	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Power network	Power Charging And Distribution Assembly	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Power network	Boost DC	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Power network	Battery Manager 400	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Power network	Battery Manager 500	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Power network	Shift Operation Mechanism Panel Assembly	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Start network	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Qin	Qin Pro_EV	Start network	Body Controller	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Start network	Intelligent Key	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Start network	Body Controller No.2	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Fuel heater	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Engine Sound Simulator	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Engine Sound Simulator (Bodun Electronics)	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Multimedia Control Panel	√	×	×	×	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Switch Cluster	√	×	×	×	×	×	
BYD	Qin	Qin Pro_EV	Comfort net	Multimedia	√	×	×	×	×	×	
BYD	Qin	Qin Pro_EV	Comfort net	Instrument Cluster	√	√	×	√	×	×	
BYD	Qin	Qin Pro_EV	Comfort net	Green Purification System	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Aux Heat	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Comfort net	Supplementary Restraint System	√	√	×	√	×	×	000E 001F
BYD	Qin	Qin Pro_EV	Comfort net	Left Front Door Control	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Right Front Door Control	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Internal Rear View Mirror	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Driver Seat System	√	√	×	√	√	√	0026
BYD	Qin	Qin Pro_EV	Comfort net	Front Passenger Seat System	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Parking Assist System	√	√	×	√	×	√	
BYD	Qin	Qin Pro_EV	Comfort net	Multi-function Display	√	√	×	√	×	×	
BYD	Qin	Qin Pro_EV	Comfort net	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Qin	Qin Pro_EV	Comfort net	4G Communication Module	√	√	×	√	×	×	
BYD	Qin	Qin Pro_EV	Comfort net	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	A/C Compressor	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Comfort net	Door Multiple Controller	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Panoramic video	√	√	×	√	×	×	
BYD	Qin	Qin Pro_EV	Comfort net	Sunroof Controller	√	√	×	√	×	×	
BYD	Qin	Qin Pro_EV	Comfort net	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Automobile Data Recorder	√	√	×	√	×	√	
BYD	Qin	Qin Pro_EV	Comfort net	External Power Amplifier	√	√	×	√	×	×	
BYD	Qin	Qin Pro_EV	Comfort net	NFC Control Module	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Comfort net	Center Console Switch	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Comfort net	Wireless Charging	√	√	×	√	×	×	
BYD	Qin	Qin Pro_EV	Comfort net	Water Auxiliary Heating	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Comfort net	Wind Auxiliary Heating	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Comfort net	Combination Switch	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	(KSTAR)	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	Comfort net	Airbag (New)	√	√	×	√	×	×	000E
BYD	Qin	Qin Pro_EV	Comfort net	Multimedia Power Supply	√	×	×	×	×	×	
BYD	Qin	Qin Pro_EV	Gateway module	Gateway	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Gateway module	Security Gateway	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	Gateway module	Integrated Body Controller A	√	√	×	√	√	√	
BYD	Qin	Qin Pro_EV	ESC network	(Sensata) Tire Pressure Management Module	√	√	×	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Qin	Qin Pro_EV	ESC network	Electronic Parking System (Sark)	√	√	×	√	√	√	002B
BYD	Qin	Qin Pro_EV	ESC network	ESP	√	√	×	√	√	×	0040 0041 0042 0043 0044 000B 000C 000D
BYD	Qin	Qin Pro_EV	ESC network	Power-assisted Steering	√	√	×	√	√	×	0040 0041 0045 002C
BYD	Qin	Qin Pro_EV	ESC network	Electric Power Steering (Mobis)	√	√	×	√	√	×	002C
BYD	Qin	Qin Pro_EV	ESC network	Electric Power Steering (Yubei)	√	√	×	√	√	×	002C
BYD	Qin	Qin Pro_EV	ESC network	Steering Wheel Angle Sensor	√	√	×	√	√	×	
BYD	Qin	Qin Pro_EV	ESC network	Blind Area Detection	√	√	×	√	√	×	0046 0047
BYD	Qin	Qin Pro_EV	ESC network	Multi-function Video Controller	√	√	×	√	√	×	0048 0049 004A 0043 004B 004C 004D
BYD	Qin	Qin Pro_EV	ESC network	Adaptive Cruise System	√	√	×	√	√	√	0048 0049 004E 0043 002E 002F
BYD	Qin	Qin Pro_EV	ESC network	Electric Fluid Brake (Bosch)	√	√	×	√	√	×	000B 004F
BYD	Qin	Qin Pro_DM	Power network	Battery Heater	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	Power network	Battery Management System_Ternary 50	√	√	×	√	√	√	0008 0009
BYD	Qin	Qin Pro_DM	Power network	Battery Management System_Ternary 60	√	√	×	√	√	√	0008 0009

BYD	Qin	Qin Pro_DM	Power network	Battery Management System (BMS)_Ternary 80	√	√	×	√	√	√	0008 0009 0035 003B
BYD	Qin	Qin Pro_DM	Power network	Battery Management System_Ternary 100	√	√	×	√	√	√	0008 0009
BYD	Qin	Qin Pro_DM	Power network	Battery Controller	√	×	×	×	×	×	
BYD	Qin	Qin Pro_DM	Power network	Two-way On-board Power Supply Assembly (Shinyr)	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	Power network	On-Board Charger	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	Power network	Ternary Battery Leakage Sensor	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	Start network	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Qin	Qin Pro_DM	Start network	Intelligent Key	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Start network	Body Controller	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Start network	Body Controller No.2	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	A/C Compressor	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	Comfort net	External Power Amplifier	√	√	×	√	×	×	
BYD	Qin	Qin Pro_DM	Comfort net	Center Console Switch	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	Comfort net	Door Multiple Controller	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	Left Front Door Control	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	Right Front Door Control	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	Image Integration	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	Comfort net	Instrument Cluster	√	√	×	√	×	×	
BYD	Qin	Qin Pro_DM	Comfort net	Internal Rear View Mirror	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	Multimedia	√	×	×	×	×	×	
BYD	Qin	Qin Pro_DM	Comfort net	Multimedia Power Supply	√	×	×	×	×	×	
BYD	Qin	Qin Pro_DM	Comfort net	Driver Seat	√	√	×	√	√	√	0026
BYD	Qin	Qin Pro_DM	Comfort net	Parking Assist System	√	√	×	√	×	√	
BYD	Qin	Qin Pro_DM	Comfort net	Green Purification System	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	Aux Heat	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	Comfort net	Supplementary Restraint System	√	√	×	√	×	×	000E 001F
BYD	Qin	Qin Pro_DM	Comfort net	Steering Wheel Switch	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	Engine Sound Simulator	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	Automobile Data Recorder	√	√	×	√	×	×	
BYD	Qin	Qin Pro_DM	Comfort net	Speech Noise Reduction	√	×	×	×	×	×	
BYD	Qin	Qin Pro_DM	Comfort net	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Qin	Qin Pro_DM	Comfort net	NFC Control Module	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	Comfort net	Multimedia Control Panel	√	×	×	×	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	Switch Cluster	√	×	×	×	×	×	
BYD	Qin	Qin Pro_DM	Comfort net	Sunroof Controller	√	√	×	√	×	×	
BYD	Qin	Qin Pro_DM	Comfort net	Engine Sound Simulator (Bodun Electronics)	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	Comfort net	Wireless Charging	√	√	×	√	×	×	
BYD	Qin	Qin Pro_DM	Gateway module	Integrated Gateway Controller	√	√	×	√	√	√	0050 0051 0030 0031
BYD	Qin	Qin Pro_DM	Gateway module	Gateway	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	ESC network	Blind Spot Detection	√	×	×	×	×	×	
BYD	Qin	Qin Pro_DM	ESC network	Electronic Parking System (SAC)	√	√	×	√	√	√	002B
BYD	Qin	Qin Pro_DM	ESC network	ESP	√	√	×	√	√	×	0044 000B 000C 000D 004F
BYD	Qin	Qin Pro_DM	ESC network	Power Steering (Tianhe)	√	√	×	√	√	×	0040 0041 0045 002C
BYD	Qin	Qin Pro_DM	ESC network	Electric Power Steering (Mobis)	√	√	×	√	√	×	002C
BYD	Qin	Qin Pro_DM	ESC network	Adaptive Cruise System	√	√	×	√	×	√	0052 0043 002F 002E
BYD	Qin	Qin Pro_DM	ESC network	Multi-function Video Controller	√	√	×	√	×	×	0052 0043 004B 004C
BYD	Qin	Qin Pro_DM	ESC network	Steering Wheel Angle Sensor	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	ESC network	(Baolong) Tire Pressure Management Module	√	√	×	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Qin	Qin Pro_DM	ESC network	(Sensata) Tire Pressure Management Module	√	√	×	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Qin	Qin Pro_DM	ECM network	BSG	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	ECM network	DC_DC	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	ECM network	Engine Controller 1.5TID	√	√	×	√	√	√	0002 0001 0053
BYD	Qin	Qin Pro_DM	ECM network	Engine Controller (1.5TID) (China 6)	√	√	×	√	√	√	0054 0055
BYD	Qin	Qin Pro_DM	ECM network	Front Active Pressure Relief	√	√	×	√	×	×	
BYD	Qin	Qin Pro_DM	ECM network	Front Drive Motor Controller	√	√	×	√	√	×	0029 002A 001E
BYD	Qin	Qin Pro_DM	ECM network	Gear Sensor	√	√	×	√	√	×	
BYD	Qin	Qin Pro_DM	ECM network	Dry Dual Clutch Transmission (DCT)	√	√	×	√	√	√	001A 001B 001C 001D
BYD	Qin	Qin Pro_DM	ECM network	Controller	√	√	×	√	√	√	0029 002A 0056 0057 0058 001E
BYD	Qin	Qin Pro_DM	ECM network	Vehicle Controller	√	√	×	√	√	√	
BYD	Qin	Qin Pro_DM	ECM network	Dual Clutch Transmission_20	√	√	×	√	√	√	0059 005A 005B 005C
BYD	Qin	Qin Pro_DM	ECM network	Low Pressure Oil pump Controller	√	√	×	√	√	×	
BYD	Qin	Qin Pro_Fuel	Power network	Engine Controller 1.5TI	√	√	×	√	√	×	0001
BYD	Qin	Qin Pro_Fuel	Power network	Engine Controller 1.5TID	√	√	×	√	√	√	0001 005D
BYD	Qin	Qin Pro_Fuel	Power network	Engine Controller_ME1788	√	√	×	√	√	√	0001
BYD	Qin	Qin Pro_Fuel	Power network	Electronic Parking System	√	√	×	√	√	√	
BYD	Qin	Qin Pro_Fuel	Power network	Power Steering (Tianhe)	√	√	×	√	×	×	0040 0041 0042 002C 002D
BYD	Qin	Qin Pro_Fuel	Power network	(Longrun) Power Steering	√	√	×	√	√	×	
BYD	Qin	Qin Pro_Fuel	Power network	ESP	√	√	×	√	√	×	0044 000B 000C 000D
BYD	Qin	Qin Pro_Fuel	Power network	Adaptive Cruise System	√	√	×	√	×	√	005E 0043 002E 002F
BYD	Qin	Qin Pro_Fuel	Power network	Multi-function Video Controller	√	√	×	√	×	×	005E 005F 0043 004B 004C 004D
BYD	Qin	Qin Pro_Fuel	Power network	Gear Sensor	√	√	×	√	√	×	
BYD	Qin	Qin Pro_Fuel	Power network	Dual-clutch Transmission (BYD) Wet Dual Clutch Transmission (DCT)	√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Qin	Qin Pro_Fuel	Power network	Controller_II	√	√	×	√	√	√	006A 006B 006C 006D 006E 006F 0070 0071 0072 0073 005A 005C
BYD	Qin	Qin Pro_Fuel	Power network	(UMC) Engine Controller (1.5TID) (China 6)	√	√	×	√	√	√	0074 0075 005D
BYD	Qin	Qin Pro_Fuel	Power network	(UMC) Engine Controller (1.5TI) (China 6)	√	√	×	√	√	√	0074 0075 005D
BYD	Qin	Qin Pro_Fuel	Power network	(BYD) Engine Controller (1.5TID) (China 6)	√	√	×	√	√	√	0054 0055
BYD	Qin	Qin Pro_Fuel	Power network	(BYD) Engine Controller (1.5TI) (China 6)	√	√	×	√	√	√	0054 0055
BYD	Qin	Qin Pro_Fuel	Start network	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Qin	Qin Pro_Fuel	Start network	Intelligent Key	√	√	×	√	√	√	
BYD	Qin	Qin Pro_Fuel	Start network	Body Controller	√	√	×	√	√	√	
BYD	Qin	Qin Pro_Fuel	Start network	Body Controller No.2	√	√	×	√	√	√	
BYD	Qin	Qin Pro_Fuel	Comfort net	4G	√	√	×	√	×	×	
BYD	Qin	Qin Pro_Fuel	Comfort net	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Qin	Qin Pro_Fuel	Comfort net	External Power Amplifier	√	×	×	×	×	×	
BYD	Qin	Qin Pro_Fuel	Comfort net	Center Console Switch	√	√	×	√	×	×	
BYD	Qin	Qin Pro_Fuel	Comfort net	Door Multiple Controller	√	√	×	√	√	√	
BYD	Qin	Qin Pro_Fuel	Comfort net	Image Integration	√	√	×	√	√	×	
BYD	Qin	Qin Pro_Fuel	Comfort net	Internal Rear View Mirror	√	√	×	√	×	√	
BYD	Qin	Qin Pro_Fuel	Comfort net	Instrument Cluster	√	√	×	√	×	×	
BYD	Qin	Qin Pro_Fuel	Comfort net	Instrument Cluster (BYD)	√	√	×	√	×	√	
BYD	Qin	Qin Pro_Fuel	Comfort net	Speech Noise Reduction	√	×	×	×	×	×	

BYD	Qin	Qin_Pro_Fuel	Comfort net	Multimedia Power Supply	√	x	x	x	x	x	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Multimedia	√	x	x	x	x	x	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Multimedia Panel	√	x	x	x	x	x	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Multimedia Control Panel	√	x	x	x	√	√	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Switch Cluster	√	x	x	x	x	x	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Display Bracket Assembly	√	√	x	√	x	√	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Parking Assist System	√	√	x	√	x	√	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Green Purification System	√	√	x	√	√	√	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Radio	√	√	x	√	x	x	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Steering Wheel Switch	√	√	x	√	x	√	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Sunroof Controller	√	√	x	√	x	x	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Supplementary Restraint System	√	√	x	√	x	x	000E 001F
BYD	Qin	Qin_Pro_Fuel	Comfort net	(Baolong) Tire Pressure Management Module	√	√	x	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Qin	Qin_Pro_Fuel	Comfort net	(Sensata) Tire Pressure Management Module	√	√	x	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Qin	Qin_Pro_Fuel	Comfort net	Automobile Data Recorder	√	√	x	√	x	x	
BYD	Qin	Qin_Pro_Fuel	Comfort net	Wireless Charging	√	√	x	√	x	x	
BYD	Qin	Qin_Pro_Fuel	Comfort net	NFC Control Module	√	√	x	√	√	x	
BYD	Qin	Qin_Pro_Fuel	Gateway module	Integrated Body Controller A	√	√	x	√	√	√	
BYD	Qin	Qin_Pro_Fuel	Gateway module	Gateway	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Power network	Gear Sensor	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Power network	Low Voltage Battery Manager	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2019.11-)	Power network	Battery Controller	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2019.11-)	Power network	Battery Manager 300	√	√	x	√	√	√	0008 0009 0076
BYD	Qin	Qin_EV (2019.11-)	Power network	Battery Manager 400	√	√	x	√	√	√	0035 0038 0008 0009 0076
BYD	Qin	Qin_EV (2019.11-)	Power network	Battery Manager (Private 400KM)	√	√	x	√	√	√	0008 0009 0077 0035 0076
BYD	Qin	Qin_EV (2019.11-)	Power network	Battery Manager (Public 450KM)	√	√	x	√	√	√	0008 0009
BYD	Qin	Qin_EV (2019.11-)	Power network	Vehicle Controller	√	√	x	√	√	x	0002 0039 0034 0001 0078
BYD	Qin	Qin_EV (2019.11-)	Power network	Front Drive Motor Controller	√	√	x	√	√	x	003A
BYD	Qin	Qin_EV (2019.11-)	Power network	DC-DC Assembly	√	√	x	√	√	√	0079 007A 007B
BYD	Qin	Qin_EV (2019.11-)	Power network	On-Board Charger	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Power network	Electric Leakage Sensor	√	√	x	√	√	x	007C
BYD	Qin	Qin_EV (2019.11-)	Power network	(Xin Tongda) Instrument Cluster	√	√	x	√	x	√	
BYD	Qin	Qin_EV (2019.11-)	Start network	Body Controller	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2019.11-)	Start network	Intelligent Key	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2019.11-)	Comfort net	NFC Control Module	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net	4G	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net	Shift Operation Panel Assembly	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 1	Parking Assist System (Longhorn)	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 1	Parking Assist System (Chongqing Guangda)	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 1	Airbag (Generation III)	√	√	x	√	x	x	000E
BYD	Qin	Qin_EV (2019.11-)	Comfort net 1	Combination Switch (KSTAR)	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 1	Door Multiple Controller	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Radio	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Multimedia	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	System_Android	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	A/C Controller (Chongqing Ruiyang)	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Automatic Cruise Control	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Steering Wheel Switch	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Wind Heating Positive Temperature Coefficient (PTC)	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Water Heating Positive Temperature Coefficient (PTC)	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	A/C Compressor(Aotecar)	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Motor Compressor	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Center Console Switch	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Cluster (Changjiang Electronics)	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Display Bracket Assembly	√	x	x	x	x	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Internal Power Amplifier	√	√	x	√	x	x	
BYD	Qin	Qin_EV (2019.11-)	Comfort net 2	Digital Signal Processor (DSP)	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2019.11-)	Gateway module	Fuel heater	√	√	x	√	√	√	
BYD	Qin	Qin_EV (2019.11-)	Gateway module	Gateway	√	√	x	√	√	x	
BYD	Qin	Qin_EV (2019.11-)	Gateway module	Integrated Body Controller A	√	√	x	√	√	√	007D
BYD	Qin	Qin_EV (2019.11-)	ESC network	Tire Pressure Monitoring Module (Sensata)	√	√	x	√	√	√	0022 0023 0024 0025 003C 003D 003E 003F 0030 0031
BYD	Qin	Qin_EV (2019.11-)	ESC network	Tire Pressure Monitoring Module (Baolong)	√	√	x	√	√	√	0022 0023 0024 0025 003C 003D 003E 003F 0030 0031
BYD	Qin	Qin_EV (2019.11-)	ESC network	Electronic Parking (SAC)	√	√	x	√	√	√	007E 007F 0080 0081
BYD	Qin	Qin_EV (2019.11-)	ESC network	Electric Fluid Brake (Bosch)	√	√	x	√	√	√	0008 0082 0083 0084 004F 0043 0085
BYD	Qin	Qin_EV (2019.11-)	ESC network	ABS	√	√	x	√	√	x	0086 0087 000B 004F
BYD	Qin	Qin_EV (2019.11-)	ESC network	ESP	√	√	x	√	√	x	0088 0043 0089 000B 000C 008A
BYD	Qin	Qin_EV (2019.11-)	ESC network	(Yubei) Electric Power Steering	√	√	x	√	√	x	008B
BYD	Qin	Brand New Qin_Fuel	Power network	ESP	√	√	x	√	√	x	0044 000B 000C 000D
BYD	Qin	Brand New Qin_Fuel	Power network	ABS	√	√	x	√	√	x	0088 0043 008C 000B 004F
BYD	Qin	Brand New Qin_Fuel	Power network	(BYD) Engine Controller (1.5TI) (China 6)	√	√	x	√	√	√	0054 0055
BYD	Qin	Brand New Qin_Fuel	Power network	Gear Sensor	√	√	x	√	√	x	
BYD	Qin	Brand New Qin_Fuel	Power network	(WanLiYang) Transmission System	√	√	x	√	√	x	008D 008E 008F 0090 0091 0092 0093 0094
BYD	Qin	Brand New Qin_Fuel	Power network	(Sensata) Tire Pressure Management Module	√	√	x	√	√	x	0095 0030 0031 0096
BYD	Qin	Brand New Qin_Fuel	Power network	(Baolong) Tire Pressure Management Module	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Qin	Brand New Qin_Fuel	Power network	Electronic Parking (Wanxiang)	√	√	x	√	√	√	
BYD	Qin	Brand New Qin_Fuel	Power network	(Yubei) Electric Power Steering	√	√	x	√	√	x	008B
BYD	Qin	Brand New Qin_Fuel	Power network	NFC Control Module	√	√	x	√	√	x	
BYD	Qin	Brand New Qin_Fuel	Start network	Body Controller	√	√	x	√	√	√	
BYD	Qin	Brand New Qin_Fuel	Start network	Steering Shaft Lock	√	√	x	√	x	x	
BYD	Qin	Brand New Qin_Fuel	Start network	Intelligent Key	√	√	x	√	√	√	
BYD	Qin	Brand New Qin_Fuel	Comfort net	4G Communication Module	√	√	x	√	x	x	
BYD	Qin	Brand New Qin_Fuel	Comfort net 1	Parking Assist System (Longhorn)	√	√	x	√	x	x	
BYD	Qin	Brand New Qin_Fuel	Comfort net 1	Parking Assist System (Chongqing Guangda)	√	√	x	√	x	x	
BYD	Qin	Brand New Qin_Fuel	Comfort net 1	Airbag (Generation III)	√	√	x	√	x	x	000E

BYD	Qin	Brand New Qin_Fuel	Comfort net 1	Combined Switch	√	√	x	√	√	√	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	Steering Wheel Switch	√	√	x	√	√	√	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	A/C Controller (Chongqing Ruiyang)	√	√	x	√	√	√	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	Automatic Cruise Control	√	√	x	√	√	√	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	Radio	√	x	x	x	x	x	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	Multimedia System_Android	√	√	x	√	x	x	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	Multimedia Panel	√	x	x	x	x	x	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	Center Console Switch Cluster (Changjiang Electronics)	√	x	x	x	x	x	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	(Xin Tongda) Instrument Cluster	√	√	x	√	x	√	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	Instrument Cluster	√	√	x	√	x	√	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	Display Bracket Assembly	√	x	x	x	x	x	
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	Internal Power Amplifier							
BYD	Qin	Brand New Qin_Fuel	Comfort net 2	Digital Signal Processor (DSP)	√	√	x	√	x	x	
BYD	Qin	Brand New Qin_Fuel	Gateway module	Gateway	√	√	x	√	x	x	
BYD	Qin	Brand New Qin_Fuel	Gateway module	Integrated Body Controller A	√	√	x	√	√	√	
BYD	Qin	Brand New Qin_Fuel	Chassis network	Sun Blind Controller	√	x	x	x	x	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Power module	On-Board Charger	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Power module	Low Voltage Battery Management System	√	√	x	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Power module	Battery Controller	√	x	x	x	x	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Power module	EV-HEV Switch	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Power module	Electric Leakage Sensor	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Power module	Automatic Headlamp Leveling System (ALS)	√	√	x	√	√	x	0097 0098
BYD	Tang	Tang_DM(2015.06-2017.01)	Power module	Instrument Cluster	√	√	x	√	x	x	0027
BYD	Tang	Tang_DM(2015.06-2017.01)	Power module	High Voltage Battery Manager	√	√	x	√	√	x	0003 0004
BYD	Tang	Tang_DM(2015.06-2017.01)	Power module	Battery Management System (Low-power version)	√	√	x	√	√	√	0008 0009
BYD	Tang	Tang_DM(2015.06-2017.01)	ECM module	DC-DC Assembly	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	ECM module	Gear Controller	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	ECM module	Engine Controller_2.0TID	√	√	x	√	√	√	0001 0002
BYD	Tang	Tang_DM(2015.06-2017.01)	ECM module	Rear Driving Motor Controller	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	ECM module	Rear Active Venting System	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	ECM module	Front Drive Motor Controller	√	√	x	√	√	√	001E
BYD	Tang	Tang_DM(2015.06-2017.01)	ECM module	Front Active Pressure Relief	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	ECM module	Wet Dual-clutch Transmission	√	√	x	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Tang	Tang_DM(2015.06-2017.01)	Chassis module	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	Tang	Tang_DM(2015.06-2017.01)	Chassis module	Electronic Parking (SAC)	√	√	x	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Chassis module	Power-assisted Steering	√	√	x	√	√	x	000F 0010
BYD	Tang	Tang_DM(2015.06-2017.01)	Chassis module	BYD EPB	√	√	x	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Supplementary Restraint System	√	√	x	√	√	x	000E 001F
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Parking Assist System	√	√	x	√	x	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Door Multiple Controller	√	√	x	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Vehicle Terminal	√	x	x	x	x	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Electric Steering Column	√	√	x	√	√	√	0016
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Multi-function Display	√	√	x	√	x	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Multimedia	√	x	x	x	x	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	4G Communication Module	√	x	x	x	x	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Rear Multimedia Control Switch	√	√	x	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Automatic Cruise Control	√	√	x	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	A/C Water Heater	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	A/C Compressor Controller	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Green Purification System	√	√	x	√	√	x	0021
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Front Hood Distribution Box	√	√	x	√	x	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Around View DSP	√	x	x	x	x	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Around View MCU	√	√	x	√	√	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Panoramic Steering Wheel Switch	√	√	x	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Tire pressure Management Module	√	√	x	√	√	x	0022 0023 0024 0025
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Automobile Data Recorder	√	x	x	x	x	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Right Front Door Control	√	√	x	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Cloud Service System	√	x	x	x	x	x	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Driver Seat System	√	√	x	√	√	√	0026
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Combined Switch	√	√	x	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Left Front Door Control	√	√	x	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Body module	Engine Sound Simulator	√	√	x	√	√	√	

BYD	Tang	Tang_DM(2015.06-2017.01)	Immobilizer module	Body Controller	√	√	×	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Immobilizer module	Intelligent Key	√	√	×	√	√	√	
BYD	Tang	Tang_DM(2015.06-2017.01)	Immobilizer module	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Tang	Tang_DM(2015.06-2017.01)	Gateway module	Gateway	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	On-Board Charger	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	Battery Controller	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	EV-HEV Switch	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	Automatic Headlamp Leveling System (ALS)	√	√	×	√	√	√	0098
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	Instrument Cluster	√	√	×	√	×	×	0027
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	Ternary Battery Leakage Sensor	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	Fe Battery Leakage Sensor	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	Battery Management System (BMS)_ Ternary 80	√	√	×	√	√	√	0008 0009
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	Battery Management System_ Ternary 100	√	√	×	√	√	√	0008 0009
BYD	Tang	Tang_DM (2017.02-2018.05)	Power module	Battery Management System_Fe battery 80	√	√	×	√	√	√	0008 0009
BYD	Tang	Tang_DM (2017.02-2018.05)	ECM module	Transmission Controller - Wet Type	√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Tang	Tang_DM (2017.02-2018.05)	ECM module	DC-DC Assembly	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	ECM module	Gear Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	ECM module	Engine Controller_2.0TID	√	√	×	√	√	√	0002 0001
BYD	Tang	Tang_DM (2017.02-2018.05)	ECM module	Rear Driving Motor Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	ECM module	Rear Active Venting System	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	ECM module	Front Drive Motor Controller	√	√	×	√	√	√	001E 0099 009A 0098 0029 002A
BYD	Tang	Tang_DM (2017.02-2018.05)	ECM module	Front Active Pressure Relief	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Chassis module	Lane Departure Warning System	√	×	×	×	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Chassis module	ESP	√	√	×	√	√	×	0044 000B 000C 000D
BYD	Tang	Tang_DM (2017.02-2018.05)	Chassis module	Electronic Parking System (SAC)	√	√	×	√	√	√	002B
BYD	Tang	Tang_DM (2017.02-2018.05)	Chassis module	Auxiliary Blind Area Monitoring	√	√	×	√	√	×	009C 009D
BYD	Tang	Tang_DM (2017.02-2018.05)	Chassis module	Main Blind Area Monitoring	√	√	×	√	√	×	009C 009D
BYD	Tang	Tang_DM (2017.02-2018.05)	Chassis module	Power-assisted Steering	√	√	×	√	√	×	002C 002D
BYD	Tang	Tang_DM (2017.02-2018.05)	Chassis module	Adaptive Cruise System	√	√	×	√	√	√	002E 002F
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Supplementary Restraint System	√	√	×	√	√	×	000E 001F
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Parking Assist System	√	√	×	√	√	×	0020
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Door Multiple Controller	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Battery Cooling Controller	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Power Trunk	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Electric Steering Column	√	√	×	√	√	√	0016
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Multi-function Display	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Multimedia	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Multimedia Panel	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	4G Communication Module	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Rear Compartment Power Distribution Box	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Rear Multimedia Control Switch	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Relay Controller	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	A/C Water Heater	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	A/C Compressor Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Green Purification System	√	√	×	√	√	×	0021
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Internal Rear View Mirror	√	√	×	√	×	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Around View DSP	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Tire Pressure Management Module (Baolong)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Variable Fan	√	√	×	√	√	×	009E
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Automobile Data Recorder	√	√	×	√	×	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Cruise Switch	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Right Front Door Control	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Center Console Switch	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Driver Seat	√	√	×	√	√	√	0026
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Combined Switch	√	√	×	√	√	√	

BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Left Front Door Control	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Tire Pressure Management Module (Sensata)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Tang	Tang_DM (2017.02-2018.05)	Body module	Engine Sound Simulator	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Immobilizer module	Body Controller	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Immobilizer module	Intelligent Key	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2017.02-2018.05)	Immobilizer module	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2017.02-2018.05)	Gateway module	Gateway	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	Ternary Battery Management System_80	√	√	×	√	√	√	0008 0009
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	Ternary Battery Management System_100	√	√	×	√	√	√	0008 0009
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	Battery Heater	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	Battery Controller	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	EV-HEV Switch	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	Instrument Cluster	√	√	×	√	×	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	Ternary Battery Leakage Sensor	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	Vehicle Charger (3.3 kW)	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	Vehicle Charger (7 kW)	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Power network	NFC Control Module	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Start network	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Start network	Body Controller	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Start network	Intelligent Key	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Ambience Lamps	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Power Trunk	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Combined Switch	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Left Front Door Control	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Right Front Door Control	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Door Multiple Controller	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Left Front Combination Lamp	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Right Front Combination Lamp	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Indoor Lamp	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Light Switch Set	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Parking Assist System	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Electric Steering Column	√	√	×	√	√	√	0016
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Driver Seat Adjustment Switch	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Front Passenger Seat Adjustment Switch	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Driver Seat	√	√	×	√	√	√	0026
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Front Passenger Seat	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Air Bag III	√	√	×	√	√	×	000E 001F
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Sunroof Controller	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Sunroof Shade Motor	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 1	Rear Compartment Power Distribution Box	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	14.Cooling Fan	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Condenser Fan	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Rear A/C Panel	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Rear A/C Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	A/C Compressor Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	External Power Amplifier	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Image Integration	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Speech Noise Reduction	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Internal Rear View Mirror	√	√	×	√	×	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Multimedia Power Supply	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Multimedia	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Multimedia Panel	√	×	×	×	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Green Purification System	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Green Clean System (MAXMAC)	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Stepless Fan Speed Adjustment	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Display Bracket Assembly	√	×	×	×	×	×	

BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Front A/C Wind Heater	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Rear A/C Air Heater	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Engine Sound Simulator	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2018.06-2020.07)	Comfort net 2	Automobile Data Recorder	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	Gateway module	Gateway	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	ESC network	Blind Area Detection	√	√	×	√	√	×	0052 0043
BYD	Tang	Tang_DM (2018.06-2020.07)	ESC network	Electronic Parking (Sark)	√	√	×	√	√	√	002B
BYD	Tang	Tang_DM (2018.06-2020.07)	ESC network	Power-assisted Steering	√	√	×	√	√	×	0052 009F 0046 00A0 002C
BYD	Tang	Tang_DM (2018.06-2020.07)	ESC network	ESP	√	√	×	√	√	×	00A1 00A2 0043 0044 000B 000C 000D
BYD	Tang	Tang_DM (2018.06-2020.07)	ESC network	Multi-function Video Controller	√	√	×	√	×	×	00A3 00A0 00A4 0043 004B 004C 004D
BYD	Tang	Tang_DM (2018.06-2020.07)	ESC network	Adaptive Cruise System	√	√	×	√	√	√	00A5 0046 0043 002E 002F
BYD	Tang	Tang_DM (2018.06-2020.07)	ESC network	(Baolong) Tire Pressure Management Module	√	√	×	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Tang	Tang_DM (2018.06-2020.07)	ESC network	(Sensata) Tire Pressure Management Module	√	√	×	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	BSG	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	DC-DC Assembly	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	Engine Controller_2.0TID	√	√	×	√	√	√	0002 0001
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	Engine Controller (2.0TID) (China 6)	√	√	×	√	√	√	0054 0055
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	Front Active Pressure Relief	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	Front Drive Motor Controller	√	√	×	√	√	×	003A 001E
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	Rear Active Venting System	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	Rear Driving Motor Controller	√	√	×	√	√	×	003A
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	Low Pressure Oil pump Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	Gear Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	Wet Dual-clutch Transmission	√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Tang	Tang_DM (2018.06-2020.07)	ECM network	Vehicle Controller Unit_BSG	√	√	×	√	√	√	0029 002A 00A6 0056 001E
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	(UMC) Engine Controller (China 6)	√	√	×	√	√	√	0074 0075 005D
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	Engine Controller_2.0TID	√	√	×	√	√	√	0001
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	Electrical Parking Brake	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	Power-assisted Steering	√	√	×	√	√	×	0052 00A7 0046 00A8 00A9 002C
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	ESP	√	√	×	√	√	×	0044 000B 000C 000D
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	Low Pressure Oil pump Controller	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	Adaptive Cruise System	√	√	×	√	√	√	00A5 0047 002E 002F
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	Multi-function Video Controller	√	√	×	√	×	×	00A5 0043 004B 004C
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	Gear Controller	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	Wet Dual-clutch Transmission	√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	Hydraulic A/T	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	Rear Adaptive Cruise Control (ACC) System	√	√	×	√	√	×	00A5 00AA 0047
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Power network	NFC Control Module	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Start network	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Start network	Body Controller	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Start network	Intelligent Key	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Rear A/C Panel	√	×	×	×	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	External Power Amplifier	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Power Trunk	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Combined Switch	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Auxiliary Driving Switch Combination	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Left Front Door Control	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Right Front Door Control	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Door Multiple Controller	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Left Front Combination Lamp	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Right Front Combination Lamp	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Image Integration Module	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Indoor Lamp	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Instrument Cluster	√	√	×	√	×	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Internal Rear View Mirror	√	√	×	√	×	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Light Switch Set	√	√	×	√	√	√	

BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Multimedia Power Supply	√	×	×	×	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Multimedia (Android)	√	×	×	×	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Multimedia Panel (Android)	√	×	×	×	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Parking Assist System	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Green Purification System	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Green Clean System (MAXMAC)	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Variable Fan	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Driver Seat	√	√	×	√	√	√	0026
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Air Bag III	√	√	×	√	√	×	000E 001F
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Sunroof Controller	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Sunroof Shade Motor	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Rear Compartment Power Distribution Box	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	(Baolong) Tire Pressure Management Module	√	√	×	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	(Sensata) Tire Pressure Management Module	√	√	×	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Comfort net	Automobile Data Recorder	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2018.06-2020.07)	Gateway module	Gateway	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2020.08-)	Power network	Battery Heater	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	Power network	Battery Controller	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2020.08-)	Power network	Ternary Battery Management System_80	√	√	×	√	√	√	0008 0009
BYD	Tang	Tang_DM (2020.08-)	Power network	Ternary Battery Management System_100	√	√	×	√	√	√	0008 0009
BYD	Tang	Tang_DM (2020.08-)	Power network	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2020.08-)	Power network	Two-way On-board Power Supply Assembly (Shinyr)	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	Power network	Ternary Battery Leakage Sensor	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	Power network	Rear A/C Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	Power network	A/C Compressor Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	Power network	Green Clean System (MAXMAC)	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	Power network	Front A/C Wind Heater	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	Power network	Rear A/C Air Heater	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	Power network	NFC Control Module	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Integrated Body Controller B1	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Integrated Body Controller B2	√	√	×	√	√	√	0050 0051 0030 0031 0096
BYD	Tang	Tang_DM (2020.08-)	Comfort net	14.Cooling Fan	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Condenser Fan	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Ambience Lamps	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Power Trunk	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Combination Switch (KSTAR)	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Wireless Charging	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Door Multiple Controller	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Sunroof Motor	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Left Front Combination Lamp	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Right Front Combination Lamp	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Indoor Lamp	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Electric Steering Column	√	√	×	√	√	√	0016
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Driver Seat	√	√	×	√	√	√	0026
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Rear Compartment Power Distribution Box	√	√	×	√	√	√	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Rear A/C Panel	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Internal Rear View Mirror	√	√	×	√	×	√	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Multimedia System_Android	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2020.08-)	Comfort net	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Tang	Tang_DM (2020.08-)	ESC network	Electronic Parking (Sark)	√	√	×	√	√	√	002B
BYD	Tang	Tang_DM (2020.08-)	ESC network	Power Steering (Tianhe)	√	√	×	√	√	×	002C
BYD	Tang	Tang_DM (2020.08-)	ESC network	Multi-function Video Controller	√	√	×	√	×	×	00A3 00A0 00A4 0043 004B 004C 004D
BYD	Tang	Tang_DM (2020.08-)	ESC network	(Baolong) Tire Pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Tang	Tang_DM (2020.08-)	ESC network	Electric Fluid Brake (Bosch)	√	√	×	√	√	×	000B 004F
BYD	Tang	Tang_DM (2020.08-)	ESC network	Auxiliary Blind Area Monitoring	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	ESC network	Night Vision System	√	√	×	√	×	×	
BYD	Tang	Tang_DM (2020.08-)	ECM network	BSG	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	ECM network	Engine Controller (2.0TID) (China 6)	√	√	×	√	√	√	0054 0055
BYD	Tang	Tang_DM (2020.08-)	ECM network	Front Drive Motor Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	ECM network	Gear Controller	√	√	×	√	√	×	
BYD	Tang	Tang_DM (2020.08-)	ECM network	Wet Dual-clutch Transmission	√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Tang	Tang_Fuel (2020.08-)	Power network	Blind Spot Detection	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2020.08-)	Power network	Auxiliary Blind Area Monitoring	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2020.08-)	Power network	(UMC) Engine Controller (China 6)	√	√	×	√	√	√	0074 0075 005D
BYD	Tang	Tang_Fuel (2020.08-)	Power network	Electrical Parking Brake	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2020.08-)	Power network	ESP	√	√	×	√	√	×	0044 000B 000C 000D
BYD	Tang	Tang_Fuel (2020.08-)	Power network	Multi-function Video Controller	√	√	×	√	×	×	00A5 0043 004B 004C
BYD	Tang	Tang_Fuel (2020.08-)	Power network	Hydraulic A/T	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2020.08-)	Power network	Tire Pressure Management Module (Baolong)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031

BYD	Tang	Tang_Fuel (2020.08-)	Power network	(Sensata) Tire Pressure Management Module	√	√	×	√	√	×	0095 0030 0031 0096
BYD	Tang	Tang_Fuel (2020.08-)	Power network	NFC Control Module	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Wireless Charging	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Integrated Body Controller B1	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Integrated Body Controller B2	√	√	×	√	√	√	0050 0051 0030 0031 0096
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Power Trunk	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Combination Switch (KSTAR)	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Sunroof Controller	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Sunroof Shade Motor	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Left Front Combination Lamp	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Right Front Combination Lamp	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Image Integration Module	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Ambience Lamps	√	√	×	√	×	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Indoor Lamp	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 1	Rear Compartment Power Distribution Box	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 2	Rear A/C Panel	√	×	×	×	×	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 2	Left Front Door Control	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 2	Right Front Door Control	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 2	Instrument Cluster	√	√	×	√	×	√	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 2	Internal Rear View Mirror	√	√	×	√	×	√	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 2	Multimedia Panel (Android)	√	×	×	×	×	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 2	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 2	Green Clean System (MAXMAC)	√	√	×	√	√	×	
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 2	Driver Seat	√	√	×	√	√	√	0026
BYD	Tang	Tang_Fuel (2020.08-)	Comfort net 2	Auxiliary Driving Switch Combination	√	√	×	√	√	√	
BYD	Tang	Tang_Fuel (2020.08-)	Gateway module	Multimedia System_Android	√	√	×	√	×	×	
BYD	Tang	Tang_EV	Power network	Battery Management System_Ternary 100	√	√	×	√	√	√	0008 0009
BYD	Tang	Tang_EV	Power network	Battery Controller	√	×	×	×	×	×	
BYD	Tang	Tang_EV	Power network	Battery Heater	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Power network	Boost DC	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Power network	EV-HEV Switch	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Power network	Front Drive Motor Controller	√	√	×	√	√	×	003A
BYD	Tang	Tang_EV	Power network	Instrument Cluster	√	√	×	√	×	√	
BYD	Tang	Tang_EV	Power network	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Power network	Gear Controller	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Power network	Image Integration	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Power network	NFC Control Module	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Start network	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Tang	Tang_EV	Start network	Body Controller	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Start network	Intelligent Key	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Ambience Lamps	√	√	×	√	×	×	
BYD	Tang	Tang_EV	Comfort net 1	Power Trunk	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Combined Switch	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Left Front Door Control	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Right Front Door Control	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Door Multiple Controller	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Sunroof Controller	√	×	×	×	×	×	
BYD	Tang	Tang_EV	Comfort net 1	Sunroof Shade Motor	√	×	×	×	×	×	
BYD	Tang	Tang_EV	Comfort net 1	Left Front Combination Lamp	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Right Front Combination Lamp	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Indoor Lamp	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Comfort net 1	Light Switch Set	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Parking Assist System	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Electric Steering Column	√	√	×	√	√	√	0016
BYD	Tang	Tang_EV	Comfort net 1	Driver Seat Adjustment Switch	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Front Passenger Seat Adjustment Switch	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Driver Seat	√	√	×	√	√	√	0026
BYD	Tang	Tang_EV	Comfort net 1	Front Passenger Seat	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 1	Air Bag III	√	√	×	√	√	×	000E 001F
BYD	Tang	Tang_EV	Comfort net 1	Rear Compartment Power Distribution Box	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 2	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 2	Rear A/C Panel	√	×	×	×	×	×	
BYD	Tang	Tang_EV	Comfort net 2	Rear A/C Controller	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Comfort net 2	A/C Compressor Controller	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Comfort net 2	External Power Amplifier	√	×	×	×	×	×	
BYD	Tang	Tang_EV	Comfort net 2	Speech Noise Reduction	√	×	×	×	×	×	
BYD	Tang	Tang_EV	Comfort net 2	Internal Rear View Mirror	√	√	×	√	×	√	
BYD	Tang	Tang_EV	Comfort net 2	Multimedia Power Supply	√	×	×	×	×	×	
BYD	Tang	Tang_EV	Comfort net 2	Multimedia	√	×	×	×	×	×	
BYD	Tang	Tang_EV	Comfort net 2	Multimedia Panel	√	×	×	×	√	√	
BYD	Tang	Tang_EV	Comfort net 2	Green Purification System	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 2	Green Clean System (MAXMAC)	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Comfort net 2	Stepless Fan Speed Adjustment	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 2	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Tang	Tang_EV	Comfort net 2	Front A/C Wind Heater	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Comfort net 2	Rear A/C Air Heater	√	√	×	√	√	×	
BYD	Tang	Tang_EV	Comfort net 2	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 2	Engine Sound Simulator	√	√	×	√	√	√	
BYD	Tang	Tang_EV	Comfort net 2	Automobile Data Recorder	√	√	×	√	×	×	

BYD	Tang	Tang_EV	Gateway module	Gateway	√	√	x	√	x	x	
BYD	Tang	Tang_EV	ESC network	Blind Area Detection	√	√	x	√	√	x	0052 0043
BYD	Tang	Tang_EV	ESC network	Electronic Parking (Sark)	√	√	x	√	√	√	002B
BYD	Tang	Tang_EV	ESC network	Power-assisted Steering	√	√	x	√	√	x	0052 009F 0046 00A0 002C
BYD	Tang	Tang_EV	ESC network	ESP	√	√	x	√	√	x	00A1 00A2 0043 0044 000B 000C 000D
BYD	Tang	Tang_EV	ESC network	Multi-function Video Controller	√	√	x	√	x	x	00A3 00A0 00A4 0043 004B 004C 004D
BYD	Tang	Tang_EV	ESC network	Adaptive Cruise System	√	√	x	√	√	√	00A5 0046 0043 002E 002F
BYD	Tang	Tang_EV	ESC network	(Baolong) Tire Pressure Management Module	√	√	x	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Tang	Tang_EV	ESC network	(Sensata) Tire Pressure Management Module	√	√	x	√	√	√	0030 0031 0022 0023 0024 0025 003C 003D 003E 003F
BYD	Song	Song_DM	Power module	Main Blind Area Monitoring	√	√	x	√	√	x	
BYD	Song	Song_DM	Power module	Auxiliary Blind Area Monitoring	√	√	x	√	√	x	
BYD	Song	Song_DM	Power module	On-Board Charger	√	√	x	√	√	x	
BYD	Song	Song_DM	Power module	Low Voltage Battery Management System	√	√	x	√	√	√	
BYD	Song	Song_DM	Power module	Battery Collection System	√	x	x	x	x	x	
BYD	Song	Song_DM	Power module	Battery Heater	√	√	x	√	√	x	
BYD	Song	Song_DM	Power module	EV-HEV Switch	√	√	x	√	x	x	
BYD	Song	Song_DM	Power module	Electric Leakage Sensor	√	√	x	√	√	x	
BYD	Song	Song_DM	Power module	Instrument Cluster	√	√	x	√	x	x	0027
BYD	Song	Song_DM	Power module	Vehicle Controller	√	√	x	√	√	√	001E
BYD	Song	Song_DM	Power module	Battery Management System (BMS)_Ternary 80	√	√	x	√	√	√	0008 0009
BYD	Song	Song_DM	Power module	Battery Management System Ternary 80_Belt Starter Generator (BSG)	√	√	x	√	√	√	0008 0009
BYD	Song	Song_DM	Power module	Battery Management System_Ternary 60	√	√	x	√	√	√	0008 0009
BYD	Song	Song_DM	Power module	Vehicle Controller Unit_BSG	√	√	x	√	√	√	00AB 00AC 001E
BYD	Song	Song_DM	Power module	Vehicle Controller_4WD BSG	√	√	x	√	√	√	00AB 00AC 001E
BYD	Song	Song_DM	Power module	NFC Control Module	√	√	x	√	√	x	
BYD	Song	Song_DM	Chassis module	Electronic Parking System (SAC)	√	√	x	√	√	√	
BYD	Song	Song_DM	Chassis module	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	Song	Song_DM	Chassis module	Power-assisted Steering	√	√	x	√	√	x	002C 002D
BYD	Song	Song_DM	Chassis module	Power Steering (Tianhe)	√	√	x	√	√	x	0052 00AD 0046 00AE 002C
BYD	Song	Song_DM	Chassis module	Lane Departure System	√	√	x	√	x	x	
BYD	Song	Song_DM	ECM module	BSG	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Gear Sensor	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Engine Controller 1.5TID	√	√	x	√	√	√	0002 0001
BYD	Song	Song_DM	ECM module	Rear Driving Motor Controller	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Rear Drive Motor Controller_4WD BSG	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Rear Active Venting System	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Rear Active Pressure Relief_4WD BSG	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Front Drive Motor Controller	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Front Drive Motor Controller_4WD BSG	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Transmission Controller_Dry Type	√	√	x	√	√	√	001A 001B 001C 001D
BYD	Song	Song_DM	ECM module	Active Leak Controller	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	DC-DC Assembly	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Transmission Controller_wet_BSG	√	√	x	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Song	Song_DM	ECM module	DC-DC_BSG Assembly	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Engine Controller 1.5TID_BSG	√	√	x	√	√	√	0002 0001 0053
BYD	Song	Song_DM	ECM module	Front Active Venting_BSG	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Drive Motor Controller_BSG	√	√	x	√	√	x	
BYD	Song	Song_DM	ECM module	Engine Controller (1.5TID) (China 6)	√	√	x	√	√	√	0054 0055
BYD	Song	Song_DM	ECM module	Transmission Controller_Dry_BSG	√	√	x	√	√	√	0059 005A 00AF 005C
BYD	Song	Song_DM	ECM module	Transmission Controller	√	√	x	√	√	√	006A 006B 006C 006D 006E 006F 0070 0071 0072 0073 005A 005C
BYD	Song	Song_DM	Body module	Air Bag III	√	√	x	√	√	x	000E 001F
BYD	Song	Song_DM	Body module	Parking Assist System	√	√	x	√	√	x	002D
BYD	Song	Song_DM	Body module	Door Multiple Controller	√	√	x	√	√	√	
BYD	Song	Song_DM	Body module	Battery Cooling Controller	√	√	x	√	√	√	
BYD	Song	Song_DM	Body module	Power Trunk	√	√	x	√	√	√	0080
BYD	Song	Song_DM	Body module	Electric Steering Column System	√	√	x	√	√	√	0016
BYD	Song	Song_DM	Body module	Multimedia	√	x	x	x	x	x	
BYD	Song	Song_DM	Body module	Multimedia Panel	√	x	x	x	x	x	
BYD	Song	Song_DM	Body module	Front Passenger Seat Adjustment Switch	√	√	x	√	x	x	
BYD	Song	Song_DM	Body module	Front Passenger Seat System	√	√	x	√	√	√	
BYD	Song	Song_DM	Body module	4G Communication Module	√	x	x	x	x	x	
BYD	Song	Song_DM	Body module	A/C Control Panel	√	√	x	√	x	x	
BYD	Song	Song_DM	Body module	Automatic Cruise Control	√	√	x	√	√	√	
BYD	Song	Song_DM	Body module	A/C Water Heater	√	√	x	√	√	x	
BYD	Song	Song_DM	Body module	A/C Compressor Controller	√	√	x	√	√	x	
BYD	Song	Song_DM	Body module	Green Purification System	√	√	x	√	√	x	0021
BYD	Song	Song_DM	Body module	Front Hood Distribution Box	√	√	x	√	√	√	
BYD	Song	Song_DM	Body module	Panoramic video	√	√	x	√	√	x	
BYD	Song	Song_DM	Body module	Panoramic Steering Wheel Switch	√	√	x	√	√	√	
BYD	Song	Song_DM	Body module	Variable Fan	√	√	x	√	√	x	009E
BYD	Song	Song_DM	Body module	Automobile Data Recorder	√	x	x	x	x	x	
BYD	Song	Song_DM	Body module	Right Front Door Control	√	√	x	√	√	√	
BYD	Song	Song_DM	Body module	Driver Seat Adjustment Switch	√	√	x	√	x	x	
BYD	Song	Song_DM	Body module	Driver Seat System	√	√	x	√	√	√	0026
BYD	Song	Song_DM	Body module	Combined Switch	√	√	x	√	√	√	
BYD	Song	Song_DM	Body module	Left Front Door Control	√	√	x	√	√	√	
BYD	Song	Song_DM	Body module	Tire pressure Management Module	√	√	x	√	√	x	0022 0023 0024 0025
BYD	Song	Song_DM	Body module	Tire Pressure Management Module (Baolong)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Song	Song_DM	Body module	Tire Pressure Management Module (Sensata)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Song	Song_DM	Body module	Engine Sound Simulator	√	√	x	√	√	√	
BYD	Song	Song_DM	Body module	External Power Amplifier	√	√	x	√	x	x	

BYD	Song	Song_DM	Body module	Center Console Switch	√	√	x	√	x	x	
BYD	Song	Song_DM	Body module	Internal Rear View Mirror	√	√	x	√	x	x	
BYD	Song	Song_DM	Body module	Multimedia Power Supply	√	x	x	x	x	x	
BYD	Song	Song_DM	Body module	Display Bracket Assembly	√	x	x	x	x	x	
BYD	Song	Song_DM	Immobilizer module	Steering Shaft Lock	√	√	x	√	x	x	
BYD	Song	Song_DM	Immobilizer module	Body Controller	√	√	x	√	√	√	
BYD	Song	Song_DM	Immobilizer module	Intelligent Key	√	√	x	√	√	√	
BYD	Song	Song_DM	Gateway module	Gateway	√	√	x	√	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Power module	Gear Actuator	√	√	x	√	√	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Power module	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	Song	Song_Fuel (2015.10-2018.07)	Power module	Electronic Parking System (SAC)	√	√	x	√	√	√	
BYD	Song	Song_Fuel (2015.10-2018.07)	Power module	Wet Dual-clutch Transmission	√	√	x	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Song	Song_Fuel (2015.10-2018.07)	Power module	1.5 TID Electronic Injection	√	√	x	√	√	√	0001
BYD	Song	Song_Fuel (2015.10-2018.07)	Power module	1.5 TID Electronic Injection	√	√	x	√	√	√	0001
BYD	Song	Song_Fuel (2015.10-2018.07)	Power module	2.0 TID Electronic Injection	√	√	x	√	√	√	0001
BYD	Song	Song_Fuel (2015.10-2018.07)	Power module	Power Steering (DIAS)	√	√	x	√	√	x	002C 002D
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Supplementary Restraint System	√	√	x	√	√	x	000E
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Air Bag III	√	√	x	√	√	x	000E 001F
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Parking Assist System	√	√	x	√	√	x	0020
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Door Multiple Controller	√	√	x	√	√	√	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Vehicle Terminal	√	x	x	x	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Multimedia	√	x	x	x	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Multimedia Panel	√	x	x	x	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	4G Communication Module	√	x	x	x	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	A/C Control Panel	√	√	x	√	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Automatic Cruise Control	√	√	x	√	√	√	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Green Purification System	√	√	x	√	√	x	0021
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Front Hood Distribution Box	√	√	x	√	x	√	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Around View DSP	√	x	x	x	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Around View MCU	√	√	x	√	√	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Panoramic Steering Wheel Switch	√	√	x	√	√	√	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Radio	√	x	x	x	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Tire pressure Management Module	√	√	x	√	√	x	0022 0023 0024 0025
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Sunroof Motor	√	x	x	x	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Sunroof Shade Motor	√	x	x	x	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Automobile Data Recorder	√	√	x	√	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Right Front Door Control	√	√	x	√	√	√	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Driver Seat System	√	√	x	√	√	√	0026
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Combined Switch	√	√	x	√	√	√	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Instrument Cluster	√	√	x	√	x	x	0027
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Left Front Door Control	√	√	x	√	√	√	
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Tire Pressure Management Module (Baolong)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Song	Song_Fuel (2015.10-2018.07)	Body module	Tire Pressure Management Module (Sentasa)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Song	Song_Fuel (2015.10-2018.07)	Immobilizer module	Body Controller	√	√	x	√	√	√	
BYD	Song	Song_Fuel (2015.10-2018.07)	Immobilizer module	Intelligent Key	√	√	x	√	√	√	
BYD	Song	Song_Fuel (2015.10-2018.07)	Immobilizer module	Steering Shaft Lock	√	√	x	√	x	x	
BYD	Song	Song_Fuel (2015.10-2018.07)	Gateway module	Gateway (1)	√	√	x	√	√	x	
BYD	Song	Song_Fuel (2018.08-)	Power module	Gear Actuator	√	√	x	√	√	x	
BYD	Song	Song_Fuel (2018.08-)	Power module	ESP	√	√	x	√	√	x	000B 000C 000D 0081
BYD	Song	Song_Fuel (2018.08-)	Power module	Electric Power Steering	√	√	x	√	√	x	
BYD	Song	Song_Fuel (2018.08-)	Power module	Electronic Parking System	√	√	x	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Power module	Wet Dual-clutch Transmission	√	√	x	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Song	Song_Fuel (2018.08-)	Power module	1.5 TID Electronic Injection	√	√	x	√	√	√	0001
BYD	Song	Song_Fuel (2018.08-)	Power module	1.5 TID Electronic Injection	√	√	x	√	√	√	0001
BYD	Song	Song_Fuel (2018.08-)	Power module	2.0 TID Electronic Injection	√	√	x	√	√	√	0001
BYD	Song	Song_Fuel (2018.08-)	Power module	Power Steering (DIAS)	√	√	x	√	√	x	002C 002D
BYD	Song	Song_Fuel (2018.08-)	Power module	Main Blind Area Monitoring	√	√	x	√	√	x	
BYD	Song	Song_Fuel (2018.08-)	Power module	Auxiliary Blind Area Monitoring	√	√	x	√	√	x	
BYD	Song	Song_Fuel (2018.08-)	Power module	Lane Departure Warning System	√	√	x	√	x	x	
BYD	Song	Song_Fuel (2018.08-)	Power module	(Yubei) Power Steering	√	√	x	√	√	x	002C
BYD	Song	Song_Fuel (2018.08-)	Power module	Gear Actuator_Electronic Gear Shift	√	√	x	√	√	x	
BYD	Song	Song_Fuel (2018.08-)	Power module	(BYD) Engine Controller (1.5TID) (China 6)	√	√	x	√	√	√	0054 0055

BYD	Song	Song_Fuel (2018.08-)	Power module	(UMC) Engine Controller (1.5TID) (China 6)	√	√	×	√	√	√	0074 0075 005D
BYD	Song	Song_Fuel (2018.08-)	Power module	(BYD) Engine Controller (1.5Ti) (China 6)	√	√	×	√	√	√	0054 0055
BYD	Song	Song_Fuel (2018.08-)	Power module	(BYD) Wet Dual Clutch Transmission (DCT) Controller_II	√	√	×	√	√	√	006A 006B 006C 006D 006E 006F 0070 0071 0072 0073 005A 005C
BYD	Song	Song_Fuel (2018.08-)	Power module	Steering Angle Sensor (KSTAR)	√	√	×	√	√	×	
BYD	Song	Song_Fuel (2018.08-)	Power module	NFC Control Module	√	√	×	√	√	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Air Bag III	√	√	×	√	√	×	000E 001F
BYD	Song	Song_Fuel (2018.08-)	Body module	Parking Assist System	√	√	×	√	√	×	0020
BYD	Song	Song_Fuel (2018.08-)	Body module	Door Multiple Controller	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Power Trunk	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Multimedia	√	×	×	×	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Multimedia Panel	√	×	×	×	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Front Passenger Seat Adjustment Switch	√	√	×	√	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Front Passenger Seat System	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	4G Communication Module	√	×	×	×	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	A/C Control Panel	√	√	×	√	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Green Purification System	√	√	×	√	√	×	0021
BYD	Song	Song_Fuel (2018.08-)	Body module	Front Hood Distribution Box	√	√	×	√	×	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Around View MCU	√	√	×	√	√	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Panoramic Steering Wheel Switch SWS	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Panoramic Steering Wheel Switch FVH	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Radio	√	√	×	√	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Automobile Data Recorder	√	√	×	√	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Right Front Door Control	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Driver Seat Adjustment Switch	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Driver Seat System	√	√	×	√	√	√	0026
BYD	Song	Song_Fuel (2018.08-)	Body module	Combination Switch (SWITCH)	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Instrument Cluster	√	√	×	√	×	×	0007
BYD	Song	Song_Fuel (2018.08-)	Body module	Left Front Door Control	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Tire Pressure Management Module (Baolong)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Song	Song_Fuel (2018.08-)	Body module	Tire Pressure Management Module (Sentasa)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Song	Song_Fuel (2018.08-)	Body module	External Power Amplifier	√	√	×	√	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Center Console Switch	√	√	×	√	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Combination Switch (CS)	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Body module	Internal Rear View Mirror	√	√	×	√	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Multimedia Power Supply	√	×	×	×	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Combination Switch (KSTAR)	√	√	×	√	×	×	
BYD	Song	Song_Fuel (2018.08-)	Body module	Door Multiplex Controller_With 4-door Anti-pinch And Without 4-door Anti-pinch (BYD)	√	√	×	√	×	×	
BYD	Song	Song_Fuel (2018.08-)	Immobilizer module	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Song	Song_Fuel (2018.08-)	Immobilizer module	Body Controller	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Immobilizer module	Intelligent Key	√	√	×	√	√	√	
BYD	Song	Song_Fuel (2018.08-)	Gateway module	Gateway (1)	√	√	×	√	√	×	
BYD	Song	Song_Fuel (2018.08-)	Gateway module	Gateway (2)	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Power module	Main Blind Area Monitoring	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Power module	Auxiliary Blind Area Monitoring	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Power module	On-Board Charger	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Power module	DC-DC Assembly	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Power module	Gear Sensor	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Power module	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Power module	Battery Collection System	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Power module	Battery Management System	√	√	×	√	√	√	0008 0009 0035
BYD	Song	Song_EV (2WD)	Power module	Electric Leakage Sensor	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Power module	Mode Switch	√	√	×	√	×	×	
BYD	Song	Song_EV (2WD)	Power module	VTOG_DSP2	√	√	×	√	√	√	0034
BYD	Song	Song_EV (2WD)	Power module	VTOG Charging	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Power module	VTOG Mode	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Power module	VTOG Driving	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Power module	Active Leak Controller	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Power module	Master Controller	√	√	×	√	√	×	0033
BYD	Song	Song_EV (2WD)	Power module	Vehicle Charger_7 kW	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Power module	Instrument Cluster	√	√	×	√	×	×	0027
BYD	Song	Song_EV (2WD)	Power module	Battery Management System_Liquid Cooling	√	√	×	√	√	√	0008 0009 0035 0038
BYD	Song	Song_EV (2WD)	Power module	VTOG_Simple Version	√	√	×	√	√	√	0034
BYD	Song	Song_EV (2WD)	Power module	NFC Control Module	√	√	×	√	√	×	

BYD	Song	Song_EV (2WD)	Chassis module	Electronic Parking System (SAC)	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Chassis module	Power-assisted Steering	√	√	×	√	√	×	002C 002D
BYD	Song	Song_EV (2WD)	Chassis module	Power Steering (Tianhe)	√	√	×	√	√	×	002C
BYD	Song	Song_EV (2WD)	Chassis module	ESP	√	√	×	√	√	×	000B 000C 000D
BYD	Song	Song_EV (2WD)	Chassis module	Lane Departure System	√	√	×	√	×	×	
BYD	Song	Song_EV (2WD)	Body module	Air Bag III	√	√	×	√	√	×	000E 001F
BYD	Song	Song_EV (2WD)	Body module	Parking Assist System	√	√	×	√	√	×	002D
BYD	Song	Song_EV (2WD)	Body module	Door Multiple Controller	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	Battery Heater	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Body module	Battery Cooling Controller	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	Power Trunk	√	√	×	√	√	√	00B0
BYD	Song	Song_EV (2WD)	Body module	Electric Steering Column System	√	√	×	√	√	√	0016
BYD	Song	Song_EV (2WD)	Body module	Multimedia	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Body module	Multimedia Panel	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Body module	Front Passenger Seat Adjustment Switch	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	Front Passenger Seat System	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	4G Communication Module	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Body module	A/C Control Panel	√	√	×	√	×	×	
BYD	Song	Song_EV (2WD)	Body module	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	A/C Water Heater	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Body module	A/C Compressor Controller	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Body module	Green Purification System	√	√	×	√	√	×	0021
BYD	Song	Song_EV (2WD)	Body module	Front Hood Distribution Box	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	Panoramic video	√	√	×	√	√	×	
BYD	Song	Song_EV (2WD)	Body module	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	Tachograph (Medium Configuration)	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Body module	Right Front Door Control	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	Driver Seat Adjustment Switch	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	Driver Seat System	√	√	×	√	√	√	0026
BYD	Song	Song_EV (2WD)	Body module	Combined Switch	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	Left Front Door Control	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	Tire pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025
BYD	Song	Song_EV (2WD)	Body module	Tire Pressure Management Module (Baolong)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Song	Song_EV (2WD)	Body module	Tire Pressure Management Module (Sensata)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Song	Song_EV (2WD)	Body module	Engine Sound Simulator	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Body module	Automobile Data Recorder	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Body module	External Power Amplifier	√	√	×	√	×	×	
BYD	Song	Song_EV (2WD)	Body module	Center Console Switch	√	√	×	√	×	×	
BYD	Song	Song_EV (2WD)	Body module	Internal Rear View Mirror	√	√	×	√	×	×	
BYD	Song	Song_EV (2WD)	Body module	Multimedia Power Supply	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Body module	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Song	Song_EV (2WD)	Immobilizer module	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Song	Song_EV (2WD)	Immobilizer module	Body Controller	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Immobilizer module	Intelligent Key	√	√	×	√	√	√	
BYD	Song	Song_EV (2WD)	Gateway module	Gateway	√	√	×	√	×	×	
BYD	Song	Song_EV (4WD)	Power network	Battery Controller	√	×	×	×	×	×	
BYD	Song	Song_EV (4WD)	Power network	Active Leak Controller	√	√	×	√	√	×	
BYD	Song	Song_EV (4WD)	Power network	DC-DC Assembly	√	√	×	√	√	×	
BYD	Song	Song_EV (4WD)	Power network	Gear Controller	√	√	×	√	×	×	
BYD	Song	Song_EV (4WD)	Power network	Instrument Cluster	√	√	×	√	×	√	
BYD	Song	Song_EV (4WD)	Power network	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Power network	Electric Leakage Sensor	√	√	×	√	√	×	
BYD	Song	Song_EV (4WD)	Power network	Mode Switch	√	√	×	√	×	×	
BYD	Song	Song_EV (4WD)	Power network	VTOG Charging	√	×	×	×	×	×	
BYD	Song	Song_EV (4WD)	Power network	VTOG Driving	√	×	×	×	×	×	
BYD	Song	Song_EV (4WD)	Power network	VTOG Mode	√	×	×	×	×	×	
BYD	Song	Song_EV (4WD)	Power network	VTOG_DSP2	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Start network	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Song	Song_EV (4WD)	Start network	Body Controller	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Start network	Intelligent Key	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Comfort net	4G Communication Module	√	×	×	×	×	×	
BYD	Song	Song_EV (4WD)	Comfort net	A/C Control Panel	√	√	×	√	×	×	
BYD	Song	Song_EV (4WD)	Comfort net	A/C Compressor Controller	√	√	×	√	√	×	
BYD	Song	Song_EV (4WD)	Comfort net	Engine Sound Simulator	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Comfort net	Left Front Door Control	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Comfort net	Right Front Door Control	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Comfort net	Door Multiple Controller	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Comfort net	Panoramic video	√	√	×	√	√	×	
BYD	Song	Song_EV (4WD)	Comfort net	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Comfort net	Multimedia	√	×	×	×	×	×	
BYD	Song	Song_EV (4WD)	Comfort net	Multimedia Panel	√	×	×	×	×	×	
BYD	Song	Song_EV (4WD)	Comfort net	(Baolong) Tire Pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Song	Song_EV (4WD)	Comfort net	(Sensata) Tire Pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Song	Song_EV (4WD)	Comfort net	Vehicle Terminal	√	√	×	√	×	×	
BYD	Song	Song_EV (4WD)	Comfort net	Combination Switch (CS)	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Comfort net	Driver Seat	√	√	×	√	√	√	0026
BYD	Song	Song_EV (4WD)	Comfort net	Front Passenger Seat	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Comfort net	Electric Steering Column	√	√	×	√	√	√	0016
BYD	Song	Song_EV (4WD)	Comfort net	Power Trunk	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	Gateway module	Gateway	√	√	×	√	×	×	
BYD	Song	Song_EV (4WD)	ESC network	Electronic Parking System (SAC)	√	√	×	√	√	√	
BYD	Song	Song_EV (4WD)	ESC network	ESP	√	√	×	√	√	×	000B 000C 000D
BYD	Song	Song_Pro_DM	Power network	Blind Spot Detection	√	√	×	√	√	×	
BYD	Song	Song_Pro_DM	Power network	Battery Heater	√	√	×	√	√	×	
BYD	Song	Song_Pro_DM	Power network	Battery Controller	√	×	×	×	×	×	
BYD	Song	Song_Pro_DM	Power network	Battery Management System_Ternary 50	√	√	×	√	√	√	0008 0009
BYD	Song	Song_Pro_DM	Power network	Instrument Cluster	√	√	×	√	×	√	
BYD	Song	Song_Pro_DM	Power network	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	Song	Song_Pro_DM	Power network	Electric Leakage Sensor	√	√	×	√	√	×	
BYD	Song	Song_Pro_DM	Power network	Two-way On-board Power Supply Assembly (Shinry)	√	√	×	√	√	×	
BYD	Song	Song_Pro_DM	Start network	Body Controller	√	√	×	√	√	√	
BYD	Song	Song_Pro_DM	Start network	Body Controller	√	√	×	√	√	√	
BYD	Song	Song_Pro_DM	Start network	Intelligent Key	√	√	×	√	√	√	
BYD	Song	Song_Pro_DM	Comfort net	NFC Control Module	√	√	×	√	√	×	

BYD	Song	Song Pro_DM	Comfort net	Sunroof Controller	√	x	x	x	x	x	
BYD	Song	Song Pro_DM	Comfort net	Sunroof Motor	√	x	x	x	x	x	
BYD	Song	Song Pro_DM	Comfort net	Door Multiple Controller	√	√	x	√	√	√	
BYD	Song	Song Pro_DM	Comfort net	Display Bracket Assembly	√	x	x	x	x	x	
BYD	Song	Song Pro_DM	Comfort net	Wireless Charging	√	√	x	√	x	x	
BYD	Song	Song Pro_DM	Comfort net	Mode Switch	√	√	x	√	√	x	
BYD	Song	Song Pro_DM	Comfort net	A/C Compressor	√	√	x	√	√	x	
BYD	Song	Song Pro_DM	Comfort net	External Power Amplifier	√	√	x	√	x	x	
BYD	Song	Song Pro_DM	Comfort net	Power Trunk	√	√	x	√	√	√	
BYD	Song	Song Pro_DM	Comfort net	Power Trunk	√	√	x	√	√	√	
BYD	Song	Song Pro_DM	Comfort net	Combination Switch (KSTAR)	√	√	x	√	√	√	
BYD	Song	Song Pro_DM	Comfort net	Left Front Door Control	√	√	x	√	√	√	
BYD	Song	Song Pro_DM	Comfort net	Right Front Door Control	√	√	x	√	√	√	
BYD	Song	Song Pro_DM	Comfort net	Multimedia System MCU (Not Dlink)	√	√	x	√	x	x	
BYD	Song	Song Pro_DM	Comfort net	Green Clean System (MAXMAC)	√	√	x	√	√	x	
BYD	Song	Song Pro_DM	Comfort net	Driver Seat	√	√	x	√	√	√	0026
BYD	Song	Song Pro_DM	Comfort net	Airbag (Generation III)	√	√	x	√	x	x	000E
BYD	Song	Song Pro_DM	Comfort net	Panoramic Steering Wheel Switch	√	√	x	√	√	√	
BYD	Song	Song Pro_DM	Comfort net	Engine Sound Simulator (Bodun Electronics)	√	√	x	√	√	√	
BYD	Song	Song Pro_DM	Comfort net	Multimedia Power Supply	√	x	x	x	x	x	
BYD	Song	Song Pro_DM	Comfort net	Body Controller No.2	√	√	x	√	√	√	
BYD	Song	Song Pro_DM	Gateway module	Gateway	√	√	x	√	x	x	
BYD	Song	Song Pro_DM	Gateway module	Multimedia System MCU (Not Dlink)	√	√	x	√	x	x	
BYD	Song	Song Pro_DM	ESC network	Blind Spot Detection	√	√	x	√	√	x	
BYD	Song	Song Pro_DM	ESC network	Auxiliary Blind Area Monitoring	√	√	x	√	√	x	
BYD	Song	Song Pro_DM	ESC network	Electronic Parking System (SAC)	√	√	x	√	√	√	
BYD	Song	Song Pro_DM	ESC network	Power Steering (Tianhe)	√	√	x	√	√	x	002C
BYD	Song	Song Pro_DM	ESC network	Steering Wheel Angle Sensor	√	√	x	√	√	x	
BYD	Song	Song Pro_DM	ESC network	(Sensata) Tire Pressure Management Module	√	√	x	√	√	x	0095 0030 0031 0096
BYD	Song	Song Pro_DM	ECM network	Low Pressure Oil pump Controller	√	√	x	√	√	x	
BYD	Song	Song Pro_DM	ECM network	Dry Dual Clutch Transmission (DCT) Controller	√	√	x	√	√	√	001A 001B 001C 001D
BYD	Song	Song Pro_DM	ECM network	Wet Dual-clutch Transmission	√	√	x	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Song	Song Pro_DM	ECM network	Gear Controller	√	√	x	√	x	x	
BYD	Song	Song Pro_DM	ECM network	Vehicle Controller_4WD BSG	√	√	x	√	√	√	00AB 00AC 001E
BYD	Song	Song Pro_DM	ECM network	Drive Motor Controller_BSG	√	√	x	√	√	x	
BYD	Song	Song Pro_DM	ECM network	Rear Drive Motor Controller_4WD BSG	√	√	x	√	√	x	
BYD	Song	Song Pro_DM	ECM network	Engine Controller (473MT) (China 6)	√	√	x	√	√	√	005D
BYD	Song	Song Pro_EV	Power network	Power Charging And Distribution Assembly	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	Power network	Low Voltage Battery Management System	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Power network	Battery Heater	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	Power network	Battery Manager 300 (Private)	√	√	x	√	√	√	0008 0009 0076
BYD	Song	Song Pro_EV	Power network	Battery Manager 400	√	√	x	√	√	√	0008 0009 0076
BYD	Song	Song Pro_EV	Power network	Battery Collection System	√	x	x	x	x	x	
BYD	Song	Song Pro_EV	Power network	Boost DC	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	Power network	Blind Spot Detection	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	Start network	Steering Shaft Lock	√	√	x	√	x	x	
BYD	Song	Song Pro_EV	Start network	Body Controller	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Start network	Intelligent Key	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net	Body Controller No.2	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net	Sunroof Controller	√	x	x	x	x	x	
BYD	Song	Song Pro_EV	Comfort net	Sunroof Controller	√	x	x	x	x	x	
BYD	Song	Song Pro_EV	Comfort net	Power Trunk	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net	Power Trunk	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net	NFC Control Module	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	Comfort net 1	Parking Assist System (Chongqing Guangda)	√	√	x	√	x	x	
BYD	Song	Song Pro_EV	Comfort net 1	Driver Seat	√	√	x	√	√	√	0026
BYD	Song	Song Pro_EV	Comfort net 1	Left Front Door Control	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net 1	Right Front Door Control	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net 1	Door Multiple Controller	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net 1	Combination Switch (KSTAR)	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net 1	Multimedia Power Supply	√	x	x	x	x	x	
BYD	Song	Song Pro_EV	Comfort net 2	Multimedia	√	√	x	√	x	x	
BYD	Song	Song Pro_EV	Comfort net 2	System_Android	√	√	x	√	x	x	
BYD	Song	Song Pro_EV	Comfort net 2	Internal Power Amplifier	√	√	x	√	x	x	
BYD	Song	Song Pro_EV	Comfort net 2	Panoramic Steering Wheel Switch	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net 2	Steering Wheel Switch	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net 2	Rear A/C Air Heater	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	Comfort net 2	Green Clean System (MAXMAC)	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	Comfort net 2	Engine Sound Simulator	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net 2	Engine Sound Simulator (Bodun Electronics)	√	√	x	√	√	√	
BYD	Song	Song Pro_EV	Comfort net 2	Display Bracket Assembly	√	x	x	x	x	x	
BYD	Song	Song Pro_EV	Comfort net 2	Automobile Data Recorder	√	√	x	√	x	x	
BYD	Song	Song Pro_EV	Comfort net 2	A/C Compressor Controller	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	Gateway module	Multimedia System MCU (Not Dlink)	√	√	x	√	x	x	
BYD	Song	Song Pro_EV	Gateway module	Gateway	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	ESC network	Electronic Parking (Sark)	√	√	x	√	√	√	002B
BYD	Song	Song Pro_EV	ESC network	ESP	√	√	x	√	√	x	0044 000B 000C 000D
BYD	Song	Song Pro_EV	ESC network	Steering Angle Sensor (KSTAR)	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	ESC network	Auxiliary Blind Area Monitoring	√	√	x	√	√	x	
BYD	Song	Song Pro_EV	ESC network	Power Steering (Tianhe)	√	√	x	√	√	x	002C
BYD	Song	Song Pro_EV	ESC network	(Sensata) Tire Pressure Management Module	√	√	x	√	√	x	0095 0030 0031 0096
BYD	Song	Song Pro_EV	ESC network	Airbag (New)	√	√	x	√	x	x	000E
BYD	Song	Song Pro_Fuel	Power network	Auxiliary Blind Area Monitoring	√	√	x	√	√	x	
BYD	Song	Song Pro_Fuel	Power network	Power Steering (Tianhe)	√	√	x	√	√	x	00B2
BYD	Song	Song Pro_Fuel	Power network	(Yubei) Power Steering	√	√	x	√	√	x	002C

BYD	Song	Song Pro_Fuel	Power network	Steering Angle Sensor (KSTAR)	√	√	×	√	√	×	
BYD	Song	Song Pro_Fuel	Power network	(BYD) Engine Controller (1.5TI) (China 6)	√	√	×	√	√	√	0054 0055
BYD	Song	Song Pro_Fuel	Power network	(UMC) Engine Controller (1.5TID) (China 6)	√	√	×	√	√	√	0074 0075 005D
BYD	Song	Song Pro_Fuel	Power network	Engine Controller (1.5TID) (China 6)	√	√	×	√	√	√	0054 0055
BYD	Song	Song Pro_Fuel	Power network	(BYD) Wet Dual Clutch Transmission (DCT) Controller_II	√	√	×	√	√	√	006A 006B 006C 006D 006E 006F 0070 0071 0072 0073 005A 005C
BYD	Song	Song Pro_Fuel	Power network	Wet Dual-clutch Transmission	√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Song	Song Pro_Fuel	Start network	Intelligent Key	√	√	×	√	√	√	
BYD	Song	Song Pro_Fuel	Start network	Body Controller	√	√	×	√	√	√	
BYD	Song	Song Pro_Fuel	Comfort net	External Power Amplifier	√	√	×	√	×	×	
BYD	Song	Song Pro_Fuel	Comfort net	Combination Switch (KSTAR)	√	√	×	√	√	×	
BYD	Song	Song Pro_Fuel	Comfort net	Door Multiple Controller	√	√	×	√	√	√	
BYD	Song	Song Pro_Fuel	Comfort net	Sunroof Motor	√	×	×	×	×	×	
BYD	Song	Song Pro_Fuel	Comfort net	Sunroof Controller	√	×	×	×	×	×	
BYD	Song	Song Pro_Fuel	Comfort net	Around View MCU	√	√	×	√	√	×	
BYD	Song	Song Pro_Fuel	Comfort net	Multimedia Power Supply	√	×	×	×	×	×	
BYD	Song	Song Pro_Fuel	Comfort net	Multimedia System MCU (Not Dlink)	√	√	×	√	×	×	
BYD	Song	Song Pro_Fuel	Comfort net	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Song	Song Pro_Fuel	Comfort net	Wireless Charging	√	√	×	√	×	×	
BYD	Song	Song Pro_Fuel	Comfort net	Green Clean System (MAXMAC)	√	√	×	√	√	×	
BYD	Song	Song Pro_Fuel	Comfort net	Driver Seat System	√	√	×	√	√	√	0026
BYD	Song	Song Pro_Fuel	Comfort net	Airbag (Generation III)	√	√	×	√	×	×	000E
BYD	Song	Song Pro_Fuel	Comfort net	Steering Wheel Switch (Sensata) Tire Pressure Management Module	√	√	×	√	√	×	0095 0030 0031 0096
BYD	Song	Song Pro_Fuel	Comfort net	Power Trunk	√	√	×	√	√	√	
BYD	Song	Song Pro_Fuel	Comfort net	NFC Control Module	√	√	×	√	√	×	
BYD	Song	Song Pro_Fuel	Comfort net	Automobile Data Recorder	√	√	×	√	×	×	
BYD	Song	Song Pro_Fuel	Gateway module	Gateway (2)	√	√	×	√	√	×	
BYD	Song	Song Pro_Fuel	Gateway module	Multimedia System MCU (Not Dlink)	√	√	×	√	×	×	
BYD	Song	Song PLUS_EV	Power network	Power Charging And Distribution Assembly	√	√	×	√	√	×	
BYD	Song	Song PLUS_EV	Comfort net 1	Driver Seat	√	√	×	√	√	√	0026
BYD	Song	Song PLUS_EV	Comfort net 1	Left Front Door Control	√	√	×	√	√	√	
BYD	Song	Song PLUS_EV	Comfort net 1	Sunroof Controller	√	×	×	×	×	×	
BYD	Song	Song PLUS_EV	Comfort net 1	Combination Switch (KSTAR)	√	√	×	√	√	√	
BYD	Song	Song PLUS_EV	Comfort net 1	Airbag (New)	√	√	×	√	×	×	000E
BYD	Song	Song PLUS_EV	Comfort net 1	Wireless Charging	√	√	×	√	×	×	
BYD	Song	Song PLUS_EV	Comfort net 1	Integrated Body Controller B1	√	√	×	√	√	√	
BYD	Song	Song PLUS_EV	Comfort net 1	Integrated Body Controller B2	√	√	×	√	√	√	0050 0051 0030 0031 0096
BYD	Song	Song PLUS_EV	Comfort net 2	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Song	Song PLUS_EV	Comfort net 2	Aux Heat	√	√	×	√	√	×	
BYD	Song	Song PLUS_EV	Comfort net 2	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Song	Song PLUS_EV	Comfort net 2	A/C Compressor	√	√	×	√	√	×	
BYD	Song	Song PLUS_EV	Gateway module	Left Front Combination Lamp	√	√	×	√	√	√	
BYD	Song	Song PLUS_EV	Gateway module	Right Front Combination Lamp	√	√	×	√	√	√	
BYD	Song	Song PLUS_EV	Gateway module	Multimedia System MCU (Not Dlink)	√	√	×	√	×	×	
BYD	Song	Song PLUS_EV	Gateway module	NFC Control Module	√	√	×	√	√	×	
BYD	Song	Song PLUS_EV	ESC network	Electronic Parking System (SAC)	√	√	×	√	√	√	
BYD	Song	Song PLUS_EV	ESC network	Electric Fluid Brake (Bosch)	√	√	×	√	√	×	000B 004F
BYD	Song	Song PLUS_EV	ESC network	Auxiliary Blind Area Monitoring	√	√	×	√	√	×	
BYD	Song	Song PLUS_EV	ESC network	(Baolong) Tire Pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Song	Song PLUS_Fuel	Power network	(UMC) 1.5TID Electronic Injection (China 6)	√	√	×	√	√	√	0074 0075 005D
BYD	Song	Song PLUS_Fuel	Power network	(BYD) Engine Controller (1.5TID) (China 6)	√	√	×	√	√	√	0054 0055
BYD	Song	Song PLUS_Fuel	Power network	Electronic Parking System (SAC)	√	√	×	√	√	√	
BYD	Song	Song PLUS_Fuel	Power network	Power Steering (Tianhe)	√	√	×	√	√	×	002C
BYD	Song	Song PLUS_Fuel	Power network	Adaptive Cruise Control	√	√	×	√	√	√	
BYD	Song	Song PLUS_Fuel	Power network	Wet Dual-clutch Transmission	√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Song	Song PLUS_Fuel	Power network	NFC Control Module	√	√	×	√	√	×	
BYD	Song	Song PLUS_Fuel	Comfort net	Combination Switch (KSTAR)	√	√	×	√	√	√	
BYD	Song	Song PLUS_Fuel	Comfort net	Door Multiple Controller	√	√	×	√	√	√	
BYD	Song	Song PLUS_Fuel	Comfort net	Sunroof Controller	√	×	×	×	×	×	
BYD	Song	Song PLUS_Fuel	Comfort net	Display Bracket Assembly	√	×	×	×	×	×	
BYD	Song	Song PLUS_Fuel	Comfort net	Green Clean System (MAXMAC)	√	√	×	√	√	×	
BYD	Song	Song PLUS_Fuel	Comfort net	Airbag (New)	√	√	×	√	×	×	000E
BYD	Song	Song PLUS_Fuel	Comfort net	Steering Wheel Switch	√	√	×	√	√	√	
BYD	Song	Song PLUS_Fuel	Comfort net	Wireless Charging	√	√	×	√	×	×	
BYD	Song	Song PLUS_Fuel	Comfort net 1	Integrated Body Controller B1	√	√	×	√	√	√	
BYD	Song	Song PLUS_Fuel	Comfort net 1	Integrated Body Controller B2	√	√	×	√	√	√	0050 0051 0030 0031 0096
BYD	Song	Song PLUS_Fuel	Gateway module	Multimedia System MCU (Not Dlink)	√	√	×	√	×	×	
BYD	Song	Song PLUS_Fuel	ESC network	Left Front Combination Lamp	√	√	×	√	√	√	
BYD	Song	Song PLUS_Fuel	ESC network	Right Front Combination Lamp	√	√	×	√	√	√	
BYD	Song	Song PLUS_Fuel	ESC network	(Baolong) Tire Pressure Management Module	√	√	×	√	√	×	0030 0031 0022 0023 0024 0025
BYD	Song	Song PLUS_Fuel	ESC network	(Sensata) Tire Pressure Management Module	√	√	×	√	√	×	0095 0030 0031 0096
BYD	Song	Song MAX_DM	Power network	Battery Heater	√	√	×	√	√	×	
BYD	Song	Song MAX_DM	Power network	Battery Controller	√	×	×	×	×	×	
BYD	Song	Song MAX_DM	Power network	Ternary Battery Management System_80	√	√	×	√	√	√	0008 0009
BYD	Song	Song MAX_DM	Power network	Instrument Cluster	√	√	×	√	×	√	
BYD	Song	Song MAX_DM	Power network	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	Song	Song MAX_DM	Power network	Electric Leakage Sensor	√	√	×	√	√	×	
BYD	Song	Song MAX_DM	Power network	On-Board Charger	√	√	×	√	√	×	
BYD	Song	Song MAX_DM	Start network	Steering Shaft Lock	√	√	×	√	×	×	

BYD	Song	Song MAX_DM	Start network	Body Controller	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Start network	Intelligent Key	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Sunroof Shade Motor	√	x	x	x	x	x	
BYD	Song	Song MAX_DM	Comfort net	Door Multiple Controller	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Sunroof Controller	√	x	x	x	x	x	
BYD	Song	Song MAX_DM	Comfort net	4G	√	√	x	√	x	x	
BYD	Song	Song MAX_DM	Comfort net	Automatic Cruise Control	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	A/C Compressor Controller	√	√	x	√	√	x	
BYD	Song	Song MAX_DM	Comfort net	Rear Automatic A/C Control Panel	√	x	x	x	x	x	
BYD	Song	Song MAX_DM	Comfort net	External Power Amplifier	√	x	x	x	x	x	
BYD	Song	Song MAX_DM	Comfort net	Center Console Switch	√	√	x	√	x	x	
BYD	Song	Song MAX_DM	Comfort net	Combined Switch	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Left Front Door Control	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Right Front Door Control	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Left Front Combination Lamp	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Right Front Combination Lamp	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Image Integration	√	√	x	√	√	x	
BYD	Song	Song MAX_DM	Comfort net	Speech Noise Reduction	√	x	x	x	x	x	
BYD	Song	Song MAX_DM	Comfort net	Internal Rear View Mirror	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Light Switch Set	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Multimedia Power Supply	√	x	x	x	x	x	
BYD	Song	Song MAX_DM	Comfort net	Multimedia Control Panel	√	x	x	x	x	x	
BYD	Song	Song MAX_DM	Comfort net	Switch Cluster	√	x	x	x	x	x	
BYD	Song	Song MAX_DM	Comfort net	Display Bracket Assembly	√	x	x	x	x	x	
BYD	Song	Song MAX_DM	Comfort net	Parking Assist System	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Green Clean System (MAXMAC)	√	√	x	√	√	x	
BYD	Song	Song MAX_DM	Comfort net	Aux Heat	√	√	x	√	√	x	
BYD	Song	Song MAX_DM	Comfort net	Variable Fan	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Driver Seat Adjustment Switch	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Front Passenger Seat Adjustment Switch	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Driver Seat	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Front Passenger Seat System	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Air Bag III	√	√	x	√	√	x	000E 001F
BYD	Song	Song MAX_DM	Comfort net	Steering Wheel Switch	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Engine Sound Simulator	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Automobile Data Recorder	√	√	x	√	x	x	
BYD	Song	Song MAX_DM	Comfort net	Integrated Body Controller B1	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	Comfort net	Integrated Body Controller B2	√	√	x	√	√	√	0050 0051 0030 0031 0096
BYD	Song	Song MAX_DM	Comfort net	Gateway	√	√	x	√	x	x	
BYD	Song	Song MAX_DM	Comfort net	NFC Control Module	√	√	x	√	√	x	
BYD	Song	Song MAX_DM	ESC network	Blind Spot Detection	√	√	x	√	√	x	
BYD	Song	Song MAX_DM	ESC network	Electronic Parking System (SAC)	√	√	x	√	√	√	002B
BYD	Song	Song MAX_DM	ESC network	Power Steering (Tianhe)	√	√	x	√	x	x	0040 0041 0042 002C 002D
BYD	Song	Song MAX_DM	ESC network	ESP	√	√	x	√	√	x	0040 0041 0042 0043 0044 000B 000C 000D
BYD	Song	Song MAX_DM	ESC network	Multi-function Video Controller	√	√	x	√	x	x	
BYD	Song	Song MAX_DM	ESC network	Adaptive Cruise Control (Sensata) Tire Pressure Management Module	√	√	x	√	√	√	
BYD	Song	Song MAX_DM	ESC network		√	√	x	√	√	x	0095 0030 0031 0096
BYD	Song	Song MAX_DM	ECM network	Front Active Pressure Relief	√	√	x	√	x	x	
BYD	Song	Song MAX_DM	ECM network	Low Pressure Oil pump Controller	√	√	x	√	√	x	
BYD	Song	Song MAX_DM	ECM network	DC-DC Assembly	√	√	x	√	√	x	
BYD	Song	Song MAX_DM	ECM network	Drive Motor Controller_BSG	√	√	x	√	√	x	
BYD	Song	Song MAX_DM	ECM network	Wet Dual-clutch Transmission	√	√	x	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	Song	Song MAX_DM	ECM network	Gear Controller	√	√	x	√	√	x	
BYD	Song	Song MAX_DM	ECM network	Vehicle Controller Unit_BSG	√	√	x	√	√	√	00AB 00AC 001E
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Power module	Gear Sensor	√	√	x	√	√	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Power module	ESP	√	√	x	√	√	x	0044 00B1 000B 000C 000D 004F
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Power module	Electronic Parking System	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Power module	Power Steering (Tianhe)	√	√	x	√	√	x	00B2
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Power module	Engine Controller 1.5TI	√	√	x	√	√	√	0001
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Power module	Engine Controller 1.5TI	√	√	x	√	√	√	0001
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Power module	Engine Controller UAES ME1788	√	√	x	√	√	√	0001
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Power module	(UMC) 1.5TID Electronic Injection (China 6)	√	√	x	√	√	√	0074 0075 005D
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Power module	(UMC) 1.5TI Electronic Injection (China 6)	√	√	x	√	√	√	0074 0075 005D
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Power module	Dual-clutch Transmission	√	√	x	√	√	√	001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069 0060
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Integrated Body Controller B1	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Integrated Body Controller B2	√	√	x	√	√	√	0050 0051 0030 0031 0096
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Gateway	√	√	x	√	√	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Air Bag III	√	√	x	√	x	x	000E 001F
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Parking Assist System	√	√	x	√	√	x	0020
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Door Multiple Controller	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Light Switch Set	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Power Trunk	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Multimedia	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Multimedia Panel	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Front Passenger Seat	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Front Passenger Seat Adjustment Switch	√	√	x	√	√	√	

BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	4G	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Rear Automatic A/C Control Panel	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Automatic Cruise Control	√	√	x	√	√	x	00B3
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Green Purification System	√	√	x	√	√	x	0021
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Internal Rear View Mirror	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Front Automatic A/C Control Panel	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Panoramic ECU	√	√	x	√	√	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Right Front Combination Lamp	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Driver Seat	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Driver Seat Adjustment Switch	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Steering Wheel Switch	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Combined Switch	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Instrument Cluster	√	√	x	√	x	x	0027
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Left Front Combination Lamp	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Tire Pressure Management Module (Baolong)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Tire Pressure Management Module (Sentasa)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	External Power Amplifier	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Speech Noise Reduction	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Multimedia Power Supply	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Display Bracket Assembly	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Sunroof Controller	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Sunroof Shade Motor	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Automobile Data Recorder	√	√	x	√	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	A/C Aontroller (Chongqing Ruiyang)	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Rear Automatic A/C Control Panel (Changjiang Electronics)	√	x	x	x	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	Door Multiplex Controller (ChangJiang Electronics)	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Body module	NFC Control Module	√	√	x	√	√	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Immobilizer module	Body Controller	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Immobilizer module	Intelligent Key	√	√	x	√	√	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	Immobilizer module	Steering Shaft Lock	√	√	x	√	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	ESC network	Multi-function Video Controller	√	√	x	√	x	x	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	ESC network	Adaptive Cruise Control	√	√	x	√	√	√	
BYD	Song	Song MAX_Fuel (2017.09-2020.07)	ESC network	Blind Spot Detection	√	√	x	√	√	x	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	Gear Actuator	√	√	x	√	√	x	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	Master Controller	√	√	x	√	√	x	0032 0033
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	Battery Management System	√	√	x	√	√	√	0035 003B 0008 0009
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	Battery Controller	√	x	x	x	x	x	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	Active Leak Controller	√	√	x	√	√	x	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	DC-DC Assembly	√	√	x	√	√	x	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	Instrument Cluster	√	√	x	√	x	√	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	Electric Leakage Sensor	√	x	x	x	√	x	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	On-Board Charger	√	√	x	√	√	x	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	VTOG Charging	√	x	x	x	x	x	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	VTOG Driving	√	x	x	x	√	x	003A
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	VTOG Mode	√	x	x	x	x	x	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Power network	VTOG_DSP2	√	√	x	√	√	√	0034
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Start network	Steering Shaft Lock	√	√	x	√	x	x	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Start network	Body Controller	√	√	x	√	√	√	
BYD	Yuan	Yuan_EV360(High- power 160KW edition)	Start network	Intelligent Key	√	√	x	√	√	√	

BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	4G Communication Module	√		x	x	x	x	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Automatic Cruise Control	√		√	x	√	√	√	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	A/C Control Panel	√		√	x	√	x	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	A/C Compressor Controller	√		√	x	√	√	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Battery Cooling Controller	√		√	x	√	x	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Engine Sound Simulator	√		√	x	√	√	√	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Door Multiple Controller	√		√	x	√	√	√	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Panoramic video	√		√	x	√	√	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Multimedia	√		x	x	x	x	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Multimedia Panel	√		x	x	x	x	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Parking Auxiliary System	√		√	x	√	√	√	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Green Purification System	√		√	x	√	√	√	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	A/C Water Heater	√		√	x	√	√	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Supplementary Restraint System	√		√	x	√	√	x	000E 001F
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Sunroof Motor	√		x	x	x	x	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Sunroof Shade Motor	√		x	x	x	x	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Panoramic Steering Wheel Switch	√		√	x	√	√	√	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	(Baolong) Tire Pressure Management Module	√		√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	(Sensata) Tire Pressure Management Module	√		√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Comfort net	Automobile Data Recorder	√		x	x	x	x	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	Gateway module	Gateway	√		√	x	√	x	x	
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	ESC network	Electronic Parking System (Sark)	√		√	x	√	√	√	00B4
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	ESC network	Power-assisted Steering	√		√	x	√	√	x	002C 00B5 00B6 00B7
BYD	Yuan	Yuan_EV360(High-power 160KW edition)	ESC network	ESP	√		√	x	√	√	x	000B 000C 000D
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Master Controller	√		√	x	√	√	x	0032 0033
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Battery Management System	√		√	x	√	√	√	0008 0009
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Battery Controller	√		x	x	x	x	x	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Active Leak Controller	√		√	x	√	√	x	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	DC-DC Assembly	√		√	x	√	√	x	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Front Drive Motor Controller	√		√	x	√	√	x	003A
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Instrument Cluster	√		√	x	√	x	√	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Low Voltage Battery Management System	√		√	x	√	√	√	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Electric Leakage Sensor	√		√	x	√	√	x	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Mode Switch	√		√	x	√	√	x	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	On-Board Charger	√		√	x	√	√	x	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Gear Actuator	√		√	x	√	√	x	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Power network	Vehicle Controller	√		√	x	√	√	x	0002 0034 0001 0039
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Start network	Steering Shaft Lock	√		√	x	√	x	x	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Start network	Body Controller	√		√	x	√	√	√	

BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Start network	Intelligent Key	√	√	×	√	√	√	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	4G Communication Module	√	√	×	√	√	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	A/C Control Panel	√	√	×	√	×	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	A/C Compressor Controller	√	√	×	√	√	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Door Multiple Controller	√	√	×	√	√	√	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Panoramic video	√	√	×	√	√	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Multimedia	√	×	×	×	×	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Multimedia Panel	√	×	×	×	×	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Parking Auxiliary System	√	√	×	√	√	√	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Green Purification System	√	√	×	√	√	√	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	A/C Water Heater	√	√	×	√	√	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Radio	√	×	×	×	×	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Supplementary Restraint System	√	√	×	√	√	×	000E 001F
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Sunroof Motor	√	×	×	×	×	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Sunroof Shade Motor	√	×	×	×	×	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	(Baolong) Tire Pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	(Sensata) Tire Pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Engine Sound Simulator	√	√	×	√	√	√	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Vehicle Terminal	√	√	×	√	×	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Comfort net	Automobile Data Recorder	√	×	×	×	×	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	Gateway module	Gateway	√	√	×	√	×	×	
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	ESC network	Electronic Parking System (Sark)	√	√	×	√	√	√	00B4
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	ESC network	Power-assisted Steering	√	√	×	√	√	×	002C 00B8 00B9 00B5 00B6
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	ESC network	ESP	√	√	×	√	√	×	000B 000C 000D
BYD	Yuan	Yuan_EV360(Low-power 70KW edition)	ESC network	Lane Departure Warning System	√	√	×	√	√	×	
BYD	Yuan	Yuan_Fuel	Power module	ABS	√	√	×	√	√	√	000B 000C 000D
BYD	Yuan	Yuan_Fuel	Power module	Gear Actuator	√	√	×	√	√	×	
BYD	Yuan	Yuan_Fuel	Power module	ESP	√	√	×	√	√	×	000B 000C 000D
BYD	Yuan	Yuan_Fuel	Power module	Electronic Parking System (SAC)	√	√	×	√	√	√	
BYD	Yuan	Yuan_Fuel	Power module	Engine Controller 1.5TI	√	√	×	√	√	√	0001
BYD	Yuan	Yuan_Fuel	Power module	Engine Controller 1.5TI	√	√	×	√	√	√	0001
BYD	Yuan	Yuan_Fuel	Power module	Engine Controller 473DCT	√	√	×	√	√	√	0001
BYD	Yuan	Yuan_Fuel	Power module	Engine Controller UAES ME1788	√	√	×	√	√	√	0001
BYD	Yuan	Yuan_Fuel	Power module	Dual-clutch Transmission	√	√	×	√	√	√	001A 001B 001C 001D
BYD	Yuan	Yuan_Fuel	Power module	Power Steering (DIAS)	√	√	×	√	√	×	002C 002D
BYD	Yuan	Yuan_Fuel	Body module	Supplementary Restraint System	√	√	×	√	√	×	000E 001F
BYD	Yuan	Yuan_Fuel	Body module	Air Bag III	√	√	×	√	√	×	000E 001F
BYD	Yuan	Yuan_Fuel	Body module	Parking Assist System	√	√	×	√	×	×	0020
BYD	Yuan	Yuan_Fuel	Body module	Vehicle Terminal	√	×	×	×	×	×	
BYD	Yuan	Yuan_Fuel	Body module	Multimedia	√	×	×	×	×	×	
BYD	Yuan	Yuan_Fuel	Body module	Multimedia Panel	√	×	×	×	×	×	
BYD	Yuan	Yuan_Fuel	Body module	4G Communication Module	√	×	×	×	×	×	
BYD	Yuan	Yuan_Fuel	Body module	A/C Control Panel	√	√	×	√	×	×	
BYD	Yuan	Yuan_Fuel	Body module	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Yuan	Yuan_Fuel	Body module	Green Purification System	√	√	×	√	√	×	0021
BYD	Yuan	Yuan_Fuel	Body module	Panoramic Video System	√	√	×	√	×	×	
BYD	Yuan	Yuan_Fuel	Body module	Around View Monitor (AVM) system (II)	√	√	×	√	√	×	
BYD	Yuan	Yuan_Fuel	Body module	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Yuan	Yuan_Fuel	Body module	Radio	√	×	×	×	×	×	
BYD	Yuan	Yuan_Fuel	Body module	Tire pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025
BYD	Yuan	Yuan_Fuel	Body module	Sunroof Motor	√	×	×	×	×	×	
BYD	Yuan	Yuan_Fuel	Body module	Sunroof Shade Motor	√	×	×	×	×	×	
BYD	Yuan	Yuan_Fuel	Body module	Automobile Data Recorder	√	×	×	×	×	×	
BYD	Yuan	Yuan_Fuel	Body module	Information Station	√	√	×	√	×	×	

BYD	Yuan	Yuan_Fuel	Body module	Occupant Classification System	√	√	×	√	√	√	0013
BYD	Yuan	Yuan_Fuel	Body module	Instrument Cluster	√	√	×	√	×	×	
BYD	Yuan	Yuan_Fuel	Body module	Left Front Window Controller	√	√	×	√	√	√	
BYD	Yuan	Yuan_Fuel	Body module	Tire Pressure Management Module (Baolong)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Yuan	Yuan_Fuel	Body module	Tire Pressure Management Module (Sentasa)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Yuan	Yuan_Fuel	Immobilizer module	Body Controller	√	√	×	√	√	√	
BYD	Yuan	Yuan_Fuel	Immobilizer module	Intelligent Key	√	√	×	√	√	×	
BYD	Yuan	Yuan_Fuel	Immobilizer module	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Yuan	Yuan_Fuel	Gateway module	Gateway	√	√	×	√	×	×	
BYD	F0	Engine System	Union Electron Engine System		√	√	√	√	√	√	0088
BYD	F0	Engine System	UAES M787CAN Engine System		√	√	×	√	√	√	0001
BYD	F0	Engine System	Delphi MT22 Engine System		√	√	×	√	√	√	007D
BYD	F0	Engine System	UAES ME17.88		√	√	×	√	√	√	0001
BYD	F0	Engine System	BU100 Electronic Injection		√	√	×	√	√	√	
BYD	F0	Engine System	371 Electronic Injection		√	√	×	√	√	√	0001
BYD	F0	Anti-lock Brake System	Delphi ABS System		√	√	×	√	√	√	008A
BYD	F0	Anti-lock Brake System	BWI ABS		√	√	×	√	√	√	008A
BYD	F0	Anti-lock Brake System	Bosch ABS (ABS9)		√	√	×	√	√	√	008B
BYD	F0	Supplementary Restraint System	Airbag 2		√	√	×	√	√	×	
BYD	F0	Body Control System	Steering Shaft Lock		√	√	×	√	×	×	
BYD	F0	Body Control System	Instrument System		√	√	×	√	×	×	
BYD	F0	Body Control System	Keyless System		√	√	×	√	√	×	
BYD	F0	Body Control System	Body Control System		√	√	×	√	×	√	008C 008D
BYD	F0	Automatic Transmission System	Marelli TCU		√	√	×	√	√	√	008E
BYD	F0	Immobilizer System	Immobilizer System		×	×	×	×	×	×	0019
BYD	F3	First-generation F3/F3R	Engine System	Engine Controller 473DCT	√	√	×	√	√	√	0001
BYD	F3	First-generation F3/F3R	Engine System	Engine Controller_473DCTSS	√	√	×	√	√	√	0001 008F
BYD	F3	First-generation F3/F3R	Engine System	Delphi MT20U Engine System	√	√	×	√	√	√	007D
BYD	F3	First-generation F3/F3R	Engine System	Delphi MT20U2 Engine System	√	√	×	√	√	√	007D
BYD	F3	First-generation F3/F3R	Engine System	Engine Controller_Delphi MT22	√	√	×	√	√	√	007D
BYD	F3	First-generation F3/F3R	Engine System	Engine Controller_UMC M79	√	√	×	√	√	√	0001
BYD	F3	First-generation F3/F3R	Engine System	UAES M79 Engine System	√	√	×	√	√	√	007D
BYD	F3	First-generation F3/F3R	Engine System	Mitsubishi Engine System	√	√	√	√	√	√	
BYD	F3	First-generation F3/F3R	Engine System	Engine Controller_473MTSS	√	√	×	√	√	√	0001
BYD	F3	First-generation F3/F3R	Engine System	(BYD) Engine Controller (473MT) (China 6)	√	√	×	√	√	√	0054 0055
BYD	F3	First-generation F3/F3R	Automatic Transmission System	Mitsubishi Electronic Control Transmission	√	√	√	√	√	√	
BYD	F3	First-generation F3/F3R	Automatic Transmission System	Dual-clutch Transmission	√	√	×	√	√	√	001A 001B 001C 001D
BYD	F3	First-generation F3/F3R	Anti-lock Brake System	Delphi ABS System	√	√	×	√	√	√	008A
BYD	F3	First-generation F3/F3R	Anti-lock Brake System	BOSCH Anti-Lock Braking System (ABS8)	√	√	×	√	√	√	008B
BYD	F3	First-generation F3/F3R	Anti-lock Brake System	BWI ABS	√	√	×	√	√	√	008A
BYD	F3	First-generation F3/F3R	Anti-lock Brake System	ABS (Bosch ABS9)	√	√	×	√	√	√	
BYD	F3	First-generation F3/F3R	Anti-lock Brake System	SABS MK70 System	√	√	×	√	√	√	
BYD	F3	First-generation F3/F3R	Anti-lock Brake System	Wheel ABS_(ABS9) (Bosch)	√	√	×	√	√	×	000B 004F
BYD	F3	First-generation F3/F3R	Supplementary Restraint System	Supplementary Restraint System	√	√	×	√	√	×	
BYD	F3	First-generation F3/F3R	Supplementary Restraint System	Airbag 2	√	√	×	√	√	×	
BYD	F3	First-generation F3/F3R	Power Steering System	Power Steering System	√	√	×	√	×	×	000F 0010
BYD	F3	First-generation F3/F3R	Immobilizer System	Immobilizer System	×	×	×	×	×	×	0019
BYD	F3	First-generation F3/F3R	Instrument Panel System	Instrument Cluster	√	√	×	√	×	×	
BYD	F3	First-generation F3/F3R	Tire Pressure Monitoring System	(Sensata) Tire Pressure Management Module	√	√	×	√	√	×	0095 0030 0031 0096
BYD	F3	F3 II	Engine System	BYD TI Engine Management System	√	√	×	√	√	√	00C0
BYD	F3	F3 II	Engine System	Engine Controller 473DCT	√	√	×	√	√	√	0001
BYD	F3	F3 II	Engine System	Engine Controller_473DCTSS	√	√	×	√	√	√	0001 008F
BYD	F3	F3 II	Engine System	M787 CAN Electronic Injection (UMC)	√	√	×	√	√	√	0001
BYD	F3	F3 II	Engine System	Delphi MT22 Start-Stop Engine System	√	√	×	√	√	√	00C1 007D
BYD	F3	F3 II	Engine System	Engine Controller_UMC M79_K	√	√	×	√	√	√	007D
BYD	F3	F3 II	Engine System	Engine Controller 1.5TI	√	√	×	√	√	√	0001
BYD	F3	F3 II	Automatic Transmission System	BYD DCT Transmission Control System	√	√	×	√	√	√	000A
BYD	F3	F3 II	Anti-Lock Braking System/Electronic Stability Control	Bosch ABS (ABS9)	√	√	×	√	√	√	008B
BYD	F3	F3 II	Anti-Lock Braking System/Electronic Stability Control	Bosch ESP9 System	√	√	×	√	√	×	00C2
BYD	F3	F3 II	Power Steering System	Power Steering System	√	√	×	√	×	×	000F 0010
BYD	F3	F3 II	Supplementary Restraint System	Airbag 2	√	√	×	√	√	×	
BYD	F3	F3 II	Supplementary Restraint System	SRS (CAN)	√	√	×	√	×	×	000E
BYD	F3	F3 II	Body Control System	Instrument System	√	√	×	√	×	×	
BYD	F3	F3 II	Body Control System	Steering Shaft Lock System	√	√	×	√	×	×	

BYD	F3	F3 II	Body Control System	Parking Auxiliary System	√	√	x	√	x	x	
BYD	F3	F3 II	Body Control System	Keyless System	√	√	x	√	√	x	
BYD	F3	F3 II	Body Control System	Body Control System	√	√	x	√	x	√	
BYD	F3	F3 II	Body Control System	Gateway	√	√	x	√	√	x	
BYD	F3	F3 II	Immobilizer System	Immobilizer System	x	x	x	x	x	x	0019
BYD	F3	F3 III	Power module	Engine Controller_UMC M788_K	√	√	x	√	x	√	007D
BYD	F3	F3 III	Power module	Engine Controller_Delphi MT22	√	√	x	√	√	√	0001
BYD	F3	F3 III	Power module	Engine Controller_Delphi MT22	√	√	x	√	√	√	0001
BYD	F3	F3 III	Power module	Engine Controller UAES ME1788	√	√	x	√	√	√	0001
BYD	F3	F3 III	Power module	Engine Controller UAES ME1788	√	√	x	√	√	√	0001
BYD	F3	F3 III	Power module	Engine Controller 473DCT	√	√	x	√	√	√	0001
BYD	F3	F3 III	Power module	Engine Controller_473DCTSS	√	√	x	√	√	√	0001 008F
BYD	F3	F3 III	Power module	Dual-clutch Transmission	√	√	x	√	√	√	001A 001B 001C 001D
BYD	F3	F3 III	Power module	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	F3	F3 III	Power module	ABS (Bosch)	√	√	x	√	√	√	
BYD	F3	F3 III	Power module	Engine Controller_473MT	√	√	x	√	√	√	0001
BYD	F3	F3 III	Power module	Engine Controller_473MTSS	√	√	x	√	√	√	0001
BYD	F3	F3 III	Power module	Engine Controller (473MT) (China 6)	√	√	x	√	√	√	005D
BYD	F3	F3 III	Power module	(BYD) Engine Controller (473CVT)	√	√	x	√	√	√	0054 0055
BYD	F3	F3 III	Power module	(WanLiYang) Transmission System	√	√	x	√	√	x	008D 008E 008F 0090 0091 0092 0093 0094
BYD	F3	F3 III	Power module	(BYD) Engine Controller (472MT) (China 6)	√	√	x	√	√	√	0054 0055
BYD	F3	F3 III	Body module	Supplementary Restraint System	√	√	x	√	√	x	000E 001F
BYD	F3	F3 III	Body module	Air Bag III	√	√	x	√	√	x	000E 001F
BYD	F3	F3 III	Body module	Door Multiple Controller	√	√	x	√	x	x	
BYD	F3	F3 III	Body module	Multi-function Display	√	√	x	√	x	x	
BYD	F3	F3 III	Body module	Automatic Cruise Control	√	√	x	√	√	x	
BYD	F3	F3 III	Body module	Automobile Data Recorder	√	x	x	x	x	x	
BYD	F3	F3 III	Body module	Parking Auxiliary System	√	√	x	√	x	x	00C3
BYD	F3	F3 III	Body module	Instrument Cluster	√	√	x	√	x	x	
BYD	F3	F3 III	Body module	Tire Pressure Management Module (Sentasa)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	F3	F3 III	Body module	Tire Pressure Management Module (Baolong)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	F3	F3 III	Immobilizer module	BCM	√	√	x	√	x	√	
BYD	F3	F3 III	Immobilizer module	Intelligent Key	√	√	x	√	√	x	
BYD	F3	F3 III	Immobilizer module	Steering Shaft Lock	√	√	x	√	x	x	
BYD	F3	F3 III	Gateway module	Gateway	√	√	x	√	√	x	
BYD	F3	F3_DM	Anti-lock Brake System	BOSCH Anti-Lock Braking System (ABS8)	√	√	x	√	√	√	00BB
BYD	F3	F3_DM	Supplementary Restraint System	Airbag 2	√	√	x	√	√	x	
BYD	F3	F3_DM	Power Steering System	Power Steering (100K)	x	x	x	x	x	x	000F 0010 00C4
BYD	F3	F3_DM	Power Steering System	Power Steering (250K)	x	x	x	x	x	x	000F 0010
BYD	F3	F3_DM	Power Steering System	Power Steering (500K)	x	x	x	x	x	x	000F 0010
BYD	F3	F3CK	Engine System	UAES M79 Engine System	√	√	x	√	√	√	007D
BYD	F3	F3CK	Anti-lock Brake System	Delphi ABS System	√	√	x	√	√	√	00BA
BYD	F3	F3CK	Supplementary Restraint System	Airbag 2	√	√	x	√	√	x	
BYD	F3	F3CK	Body Control System	Steering Shaft Lock System	√	√	x	√	√	x	
BYD	F3	F3CK	Body Control System	F3CK Body Control Module	√	√	x	√	x	x	
BYD	F3	F3CK	Body Control System	Keyless System	√	√	x	√	√	x	
BYD	F3	F3CK	Body Control System	Instrument System	√	√	x	√	√	x	
BYD	F3	F3CK	Body Control System	A/C	√	√	x	√	x	x	
BYD	F3	F3CK	Body Control System	Multifunctional Screen	√	√	x	√	x	x	
BYD	F3	F3CK	Body Control System	Parking Auxiliary System	√	√	x	√	x	x	
BYD	F3	F3CK	Immobilizer System	Immobilizer System	x	x	x	x	x	x	0019
BYD	F6	Engine System	UAES M79 Engine System		√	√	x	√	√	√	007D
BYD	F6	Engine System	Mitsubishi Engine System		√	√	√	√	√	√	
BYD	F6	Anti-lock Brake System	BOSCH Anti-Lock Braking System (ABS8)		√	√	x	√	√	√	00BB
BYD	F6	Anti-lock Brake System	Bosch ABS (ABS9)		√	√	x	√	√	√	00BB
BYD	F6	Anti-lock Brake System	BWI ABS		√	√	x	√	√	√	00BA
BYD	F6	Body Control System	F6 BODY Control System		√	√	x	√	x	x	
BYD	F6	Body Control System	Door Multicircuit Control Module		√	√	x	√	x	x	
BYD	F6	Body Control System	Forecabin Distribution Box Relay Circuit Template		√	√	x	√	x	x	
BYD	F6	Body Control System	Combination Switch Module		√	√	x	√	x	x	
BYD	F6	Body Control System	A/C		√	√	x	√	√	x	
BYD	F6	Body Control System	Instrument System		√	√	x	√	x	x	
BYD	F6	Body Control System	Gateway		√	√	x	√	√	x	
BYD	F6	Body Control System	Front Hood Distribution Box		√	√	x	√	x	x	
BYD	F6	Supplementary Restraint System	SRS (CAN)		√	√	x	√	√	x	000E
BYD	F6	Automatic Transmission System	Mitsubishi Electronic Control Transmission Continuously Variable Transmission (CVT) (Punch)		√	√	√	√	√	√	
BYD	F6	Automatic Transmission System			√	√	x	√	√	x	00C5 00C6 00C7
BYD	F6	Immobilizer System	Immobilizer System		x	x	x	x	x	x	0019
BYD	S6	Engine System	UAES M787CAN Engine System		√	√	x	√	√	√	0001
BYD	S6	Engine System	Mitsubishi Engine System		√	√	√	√	√	√	
BYD	S6	Engine System	Engine Controller_UMC M7971		√	√	x	√	√	√	0001
BYD	S6	Engine System	BYD TI Engine Management System		√	√	x	√	√	√	00C0
BYD	S6	Engine System	Engine Controller UAES ME1788		√	√	x	√	√	√	0001
BYD	S6	Engine System	Engine Controller 1.5TI		√	√	x	√	√	√	0001
BYD	S6	Anti-lock Brake System	Wheel ABS (ABS 8)		√	√	x	√	√	x	

	S6	Anti-lock Brake System	Wheel ABS (ABS 9)		√	√	×	√	√	×	
BYD	S6	Anti-lock Brake System	The Continent ABS System		√	√	×	√	√	×	
BYD	S6	Anti-lock Brake System	ESP		√	√	×	√	√	×	000B 000C 000D
BYD	S6	Automatic Transmission System	Mitsubishi Electronic Control Transmission		√	√	√	√	√	√	
BYD	S6	Automatic Transmission System	Dual-clutch Transmission		√	√	×	√	√	√	001A 001B 001C 001D
BYD	S6	Automatic Transmission System	BYD Wet-type DCT Transmission Control System		√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 00C8 00C9 0067 0068 001C 0069
BYD	S6	Supplementary Restraint System	SRS (CAN)		√	√	×	√	√	×	000E 00CA
BYD	S6	Supplementary Restraint System	Air Bag III		√	√	×	√	√	×	000E 001F
BYD	S6	Body Control System	Instrument System		√	√	×	√	×	×	0007
BYD	S6	Body Control System	Body Control System		√	√	×	√	×	×	00BC 00BD
BYD	S6	Body Control System	Keyless System		√	√	×	√	√	×	
BYD	S6	Body Control System	Steering Shaft Lock System		√	√	×	√	×	×	
BYD	S6	Body Control System	Door Multicircuit Control Module		√	√	×	√	×	×	
BYD	S6	Body Control System	Parking Auxiliary System		√	√	×	√	×	×	
BYD	S6	Body Control System	Combination Switch Module		√	√	×	√	×	×	
BYD	S6	Body Control System	Forecabin Distribution Box Relay Circuit Template		√	√	×	√	×	×	
BYD	S6	Body Control System	A/C		√	√	×	√	√	×	
BYD	S6	Body Control System	Multifunctional Screen		√	√	×	√	×	×	
BYD	S6	Body Control System	Gateway		√	√	×	√	√	×	
BYD	S6	Body Control System	Sunroof		√	√	×	√	√	√	
BYD	S6	Immobilizer System	Immobilizer System		×	×	×	×	×	×	0019
BYD	S7	S7 (2014.10-2017.01)	Engine System	2.0 TID Electronic Injection	√	√	×	√	√	√	0001
BYD	S7	S7 (2014.10-2017.01)	Engine System	1.5Tl Electronic Injection	√	√	×	√	√	√	0001
BYD	S7	S7 (2014.10-2017.01)	Automatic Transmission System	BYD Wet-type DCT Transmission Control System	√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 00C8 00C9 0067 0068 001C 0069
BYD	S7	S7 (2014.10-2017.01)	Electronic Stability Program	Bosch ESP9 System	√	√	×	√	√	×	00C2
BYD	S7	S7 (2014.10-2017.01)	Supplementary Restraint System	Air Bag III	√	√	×	√	√	×	000E 001F
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Steering Shaft Lock System	√	√	×	√	×	×	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Combination Instrument System	√	√	×	√	×	×	0007
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Parking Auxiliary System	√	√	×	√	×	×	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Body Control System	√	√	×	√	√	√	00BD
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Smart Key System	√	√	×	√	√	×	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Combination switch module	√	√	×	√	√	√	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Relay Control Module	√	√	×	√	×	√	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Automatic Cruise Control	√	√	×	√	√	√	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Gateway	√	√	×	√	×	×	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Tire Pressure Monitoring System (TPMS)	√	√	×	√	√	×	00CB
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Rear Seat	√	√	×	√	√	√	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Panoramic video	√	√	×	√	√	×	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Multifunctional Screen	√	√	×	√	×	×	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Green Purification System	√	√	×	√	×	×	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Front Left Window Control Module	√	√	×	√	√	√	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Front Left Door Control Module	√	√	×	√	√	√	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Front Right Door Control Module	√	√	×	√	√	√	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Seat Memory System	√	√	×	√	√	√	00CC
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Electrical Columns Adjustment Module	√	√	×	√	√	√	00CC
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Cloud Service System	√	×	×	×	×	×	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Around View DSP	√	×	×	×	×	×	
BYD	S7	S7 (2014.10-2017.01)	Body Control System	Multimedia	√	×	×	×	×	×	
BYD	S7	S7 (2014.10-2017.01)	Electronic Parking Brake	Mando Electric Parking Brakes	√	√	×	√	√	×	
BYD	S7	S7 (2014.10-2017.01)	Electronic Parking Brake	Universal Electronic Parking Brake (EPB) System	√	√	×	√	√	√	
BYD	S7	S7 (2014.10-2017.01)	Immobilizer System	Immobilizer System	×	×	×	×	×	×	0019
BYD	S7	S7 (2017.02-)	Power module	Gear Sensor	√	√	×	√	√	×	
BYD	S7	S7 (2017.02-)	Power module	ESP	√	√	×	√	√	×	000B 000C 000D
BYD	S7	S7 (2017.02-)	Power module	Electronic Parking (Wanxiang)	√	√	×	√	√	√	
BYD	S7	S7 (2017.02-)	Power module	Wet Dual-clutch Transmission	√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	S7	S7 (2017.02-)	Power module	4WD Controller	√	√	×	√	×	×	
BYD	S7	S7 (2017.02-)	Power module	2.0 TID Electronic Injection	√	√	×	√	√	√	0001
BYD	S7	S7 (2017.02-)	Power module	1.5Tl Electronic Injection	√	√	×	√	√	√	0001

BYD	S7	S7 (2017.02-)	Body module	Supplementary Restraint System	√	√	×	√	√	×	000E 001F
BYD	S7	S7 (2017.02-)	Body module	Air Bag III	√	√	×	√	√	×	000E 001F
BYD	S7	S7 (2017.02-)	Body module	Parking Assist System	√	√	×	√	√	×	0020
BYD	S7	S7 (2017.02-)	Body module	Door Multiple Controller	√	√	×	√	√	√	
BYD	S7	S7 (2017.02-)	Body module	Vehicle Terminal	√	×	×	×	×	×	
BYD	S7	S7 (2017.02-)	Body module	Power Back Door	√	√	×	√	√	√	0026
BYD	S7	S7 (2017.02-)	Body module	Multifunctional Screen	√	√	×	√	×	×	
BYD	S7	S7 (2017.02-)	Body module	Multimedia	√	×	×	×	×	×	
BYD	S7	S7 (2017.02-)	Body module	Multimedia Panel	√	×	×	×	×	×	
BYD	S7	S7 (2017.02-)	Body module	4G Communication Module	√	×	×	×	×	×	
BYD	S7	S7 (2017.02-)	Body module	Automatic Cruise Control	√	√	×	√	√	√	
BYD	S7	S7 (2017.02-)	Body module	Green Purification System	√	√	×	√	√	×	0021
BYD	S7	S7 (2017.02-)	Body module	Front Hood Distribution Box	√	√	×	√	√	√	
BYD	S7	S7 (2017.02-)	Body module	Panoramic Video System	√	√	×	√	√	×	
BYD	S7	S7 (2017.02-)	Body module	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	S7	S7 (2017.02-)	Body module	Tire pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025
BYD	S7	S7 (2017.02-)	Body module	Tire Pressure Management Module (Baolong)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	S7	S7 (2017.02-)	Body module	Tire Pressure Management Module (Sentasa)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	S7	S7 (2017.02-)	Body module	Sunroof Motor	√	×	×	×	×	×	
BYD	S7	S7 (2017.02-)	Body module	Sunroof Shade Motor	√	×	×	×	×	×	
BYD	S7	S7 (2017.02-)	Body module	Automobile Data Recorder	√	√	×	√	×	×	
BYD	S7	S7 (2017.02-)	Body module	Right Front Door Control	√	√	×	√	√	√	
BYD	S7	S7 (2017.02-)	Body module	Driver Seat	√	√	×	√	√	√	0026
BYD	S7	S7 (2017.02-)	Body module	Steering Column	√	√	×	√	√	√	0016
BYD	S7	S7 (2017.02-)	Body module	Combined Switch	√	√	×	√	√	√	
BYD	S7	S7 (2017.02-)	Body module	Instrument Cluster	√	√	×	√	×	×	0027
BYD	S7	S7 (2017.02-)	Body module	Left Front Door Control	√	√	×	√	√	√	
BYD	S7	S7 (2017.02-)	Immobilizer module	Body Controller	√	√	×	√	√	√	
BYD	S7	S7 (2017.02-)	Immobilizer module	Intelligent Key	√	√	×	√	√	√	
BYD	S7	S7 (2017.02-)	Immobilizer module	Steering Shaft Lock	√	√	×	√	×	×	
BYD	S7	S7 (2017.02-)	Gateway module	Gateway	√	√	×	√	√	×	
BYD	S8	Engine System	UAES M79 Engine System		√	√	×	√	√	√	007D
BYD	S8	Automatic Transmission System	Continuously Variable Transmission (CVT) (Punch)		√	√	×	√	√	×	00C5 00C6 00C7
BYD	S8	Anti-lock Brake System	BWI ABS		√	√	×	√	√	√	00BA
BYD	S8	Body Control System	Steering Shaft Lock System		√	√	×	√	√	×	
BYD	S8	Body Control System	Keyless System		√	√	×	√	√	×	
BYD	S8	Body Control System	SRS (CAN)		√	√	×	√	×	×	
BYD	S8	Body Control System	Hardtop-500K		√	√	×	√	×	×	
BYD	S8	Body Control System	Forecabin Distribution Box Relay Circuit Template		√	√	×	√	×	×	
BYD	S8	Body Control System	Body Control System		√	√	×	√	×	×	
BYD	S8	Body Control System	Hardtop-125K		√	√	×	√	×	×	
BYD	Surui	Surui (2012.08-2015.02)	Engine System	Engine Controller 1.5TI	√	√	×	√	√	√	0001
BYD	Surui	Surui (2012.08-2015.02)	Engine System	UAES ME17.88	√	√	×	√	√	√	0001
BYD	Surui	Surui (2012.08-2015.02)	Engine System	473QE_DTC Electronic Injection	√	√	×	√	√	√	0001
BYD	Surui	Surui (2012.08-2015.02)	Engine System	473QE_DTC Start/Stop	√	√	×	√	√	√	0001 00BF
BYD	Surui	Surui (2012.08-2015.02)	Engine System	Engine Controller 1.5TID	√	√	×	√	√	√	0001
BYD	Surui	Surui (2012.08-2015.02)	Gear P Motor Controller	Gear P Motor Controller	√	√	×	√	√	×	
BYD	Surui	Surui (2012.08-2015.02)	Anti-lock Brake System	Wheel ABS (ABS 9)	√	√	×	√	√	×	
BYD	Surui	Surui (2012.08-2015.02)	Anti-lock Brake System	ESP	√	√	×	√	√	×	000B 000C 000D
BYD	Surui	Surui (2012.08-2015.02)	Automatic Transmission System	Dual Clutch Transmission_TI Adaptation	√	√	×	√	√	√	001A 001B 001C 001D
BYD	Surui	Surui (2012.08-2015.02)	Automatic Transmission System	BYD DCT Transmission Control System	√	√	×	√	√	√	000A
BYD	Surui	Surui (2012.08-2015.02)	Automatic Transmission System	Dual-clutch Transmission_Self-priming Fit	√	√	×	√	√	√	001A 001B 001C 001D
BYD	Surui	Surui (2012.08-2015.02)	Power Steering System	Power Steering System	√	√	×	√	×	×	000F 0010
BYD	Surui	Surui (2012.08-2015.02)	Electronic Parking Brake	Electronic Parking Brake	√	√	×	√	√	√	
BYD	Surui	Surui (2012.08-2015.02)	Supplementary Restraint System	SRS (CAN)	√	√	×	√	√	×	000E 001F
BYD	Surui	Surui (2012.08-2015.02)	Supplementary Restraint System	Air Bag III	√	√	×	√	√	×	000E 001F
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Door Multicircuit Control Module	√	√	×	√	×	×	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Steering Shaft Lock System	√	√	×	√	×	×	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Parking Auxiliary System	√	√	×	√	×	×	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Combination Switch Module	√	√	×	√	×	×	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Intelligent Key	√	√	×	√	√	×	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	BCM	√	√	×	√	√	√	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Gateway	√	√	×	√	√	×	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Relay Control Module	√	√	×	√	×	×	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Tire pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	A/C	√	√	×	√	√	√	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Multifunctional Screen	√	√	×	√	×	×	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Instrument System	√	√	×	√	×	√	

BYD	Surui	Surui (2012.08-2015.02)	Body Control System	CD Changer Assembly	√	×	×	×	×	×	
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Tire Pressure Management Module (Baolong)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Tire Pressure Management Module (Sentasa)	√	√	×	√	√	×	0022 0023 0024 0025 0030 0031
BYD	Surui	Surui (2012.08-2015.02)	Body Control System	Multimedia	√	×	×	×	×	×	
BYD	Surui	Surui (2012.08-2015.02)	Immobilizer System	Immobilizer System	×	×	×	×	×	×	0019
BYD	Surui	Surui (2015.03-)	Power module	ABS	√	√	×	√	√	×	
BYD	Surui	Surui (2015.03-)	Power module	ESP	√	√	×	√	√	×	000B 000C 000D
BYD	Surui	Surui (2015.03-)	Power module	Electronic Parking System	√	√	×	√	√	√	
BYD	Surui	Surui (2015.03-)	Power module	ME 1788 Electronic Injection (UMC)	√	√	×	√	√	√	0001
BYD	Surui	Surui (2015.03-)	Power module	Gear P Controller	√	√	×	√	√	×	
BYD	Surui	Surui (2015.03-)	Power module	473QE_DTC Electronic Injection	√	√	×	√	√	√	0001
BYD	Surui	Surui (2015.03-)	Power module	473QE_DTC Start/Stop	√	√	×	√	√	√	0001 008F
BYD	Surui	Surui (2015.03-)	Power module	473QE_MT Electronic Injection	√	√	×	√	√	√	0001
BYD	Surui	Surui (2015.03-)	Power module	Dual-clutch Transmission	√	√	×	√	√	√	001A 001B 001C 001D
BYD	Surui	Surui (2015.03-)	Power module	1.5 TID Electronic Injection	√	√	×	√	√	√	0001
BYD	Surui	Surui (2015.03-)	Power module	Power-assisted Steering	√	√	×	√	×	×	000F 0010
BYD	Surui	Surui (2015.03-)	Power module	1.5T1 Electronic Injection	√	√	×	√	√	√	0001
BYD	Surui	Surui (2015.03-)	Body module	Supplementary Restraint System	√	√	×	√	√	×	000E
BYD	Surui	Surui (2015.03-)	Body module	Air Bag III	√	√	×	√	√	×	000E
BYD	Surui	Surui (2015.03-)	Body module	Parking Assist System	√	√	×	√	×	×	
BYD	Surui	Surui (2015.03-)	Body module	CD Changer Assembly	√	×	×	×	×	×	
BYD	Surui	Surui (2015.03-)	Body module	Door Multiple Controller	√	√	×	√	√	√	
BYD	Surui	Surui (2015.03-)	Body module	Vehicle Terminal	√	×	×	×	×	×	
BYD	Surui	Surui (2015.03-)	Body module	Multi-function Display	√	√	×	√	×	×	
BYD	Surui	Surui (2015.03-)	Body module	Automatic Cruise Control	√	√	×	√	√	√	
BYD	Surui	Surui (2015.03-)	Body module	Green Purification System	√	√	×	√	√	×	0021
BYD	Surui	Surui (2015.03-)	Body module	Front Hood Distribution Box	√	√	×	√	×	√	
BYD	Surui	Surui (2015.03-)	Body module	Around View DSP	√	×	×	×	×	×	
BYD	Surui	Surui (2015.03-)	Body module	Around View MCU	√	√	×	√	√	×	
BYD	Surui	Surui (2015.03-)	Body module	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	Surui	Surui (2015.03-)	Body module	Tire pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025
BYD	Surui	Surui (2015.03-)	Body module	Automobile Data Recorder	√	×	×	×	×	×	
BYD	Surui	Surui (2015.03-)	Body module	Information Station	√	√	×	√	×	×	
BYD	Surui	Surui (2015.03-)	Body module	Combined Switch	√	√	×	√	√	√	
BYD	Surui	Surui (2015.03-)	Body module	Instrument Cluster	√	√	×	√	×	×	0027
BYD	Surui	Surui (2015.03-)	Body module	Multimedia	√	×	×	×	×	×	
BYD	Surui	Surui (2015.03-)	Immobilizer module	Body Controller - Independent Board	√	√	×	√	√	√	
BYD	Surui	Surui (2015.03-)	Immobilizer module	Body Controller - Integrated Board	√	√	×	√	√	√	
BYD	Surui	Surui (2015.03-)	Immobilizer module	Intelligent Key	√	√	×	√	√	×	
BYD	Surui	Surui (2015.03-)	Immobilizer module	Steering Shaft Lock	√	√	×	√	×	×	
BYD	Surui	Surui (2015.03-)	Gateway module	Gateway	√	√	×	√	√	×	
BYD	Sirui	Engine System	UAE5 ME17.88		√	√	×	√	√	√	0001
BYD	Sirui	Engine System	BYD TI Engine Management System		√	√	×	√	√	√	00C0
BYD	Sirui	Engine System	Engine Controller 1.5TI		√	√	×	√	√	√	0001
BYD	Sirui	Engine System	Engine Controller 1.5TID		√	√	×	√	√	√	0001
BYD	Sirui	Engine System	Engine Controller_2.0TID		√	√	×	√	√	√	0001
BYD	Sirui	Power module	Gear P Motor Controller		√	√	×	√	√	×	
BYD	Sirui	Automatic Transmission System	BYD DCT Transmission Control System		√	√	×	√	√	√	000A
BYD	Sirui	Automatic Transmission System	BYD Wet-type DCT Transmission Control System		√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 00C8 00C9 0067 0068 001C 0069
BYD	Sirui	Electronic Stability Program	ESP		√	√	×	√	√	×	000B 000C 000D
BYD	Sirui	Supplementary Restraint System	SRS (CAN)		√	√	×	√	√	×	000E
BYD	Sirui	Power Steering System	Power Steering System		√	√	×	√	×	×	000F 0010
BYD	Sirui	Electronic Parking Brake	Electronic Parking Brake		√	√	×	√	√	√	
BYD	Sirui	Electronic Parking Brake	BYD EPB		√	√	×	√	√	√	
BYD	Sirui	Body Control System	AFS System		√	√	×	√	√	√	00CC
BYD	Sirui	Body Control System	Automatic Cruise Control		√	√	×	√	√	√	
BYD	Sirui	Body Control System	Door Multiple Control Module		√	√	×	√	×	×	
BYD	Sirui	Body Control System	Panoramic video		√	√	×	√	√	×	
BYD	Sirui	Body Control System	Gateway		√	√	×	√	×	×	
BYD	Sirui	Body Control System	Column ECU		√	√	×	√	√	√	00CC
BYD	Sirui	Body Control System	Rear Seat		√	√	×	√	√	√	
BYD	Sirui	Body Control System	Combination Instrument System		√	√	×	√	×	√	
BYD	Sirui	Body Control System	Smart Key System		√	√	×	√	√	×	
BYD	Sirui	Body Control System	Parking Auxiliary System		√	√	×	√	√	×	0020
BYD	Sirui	Body Control System	Panoramic Steering Wheel Switch		√	√	×	√	√	√	
BYD	Sirui	Body Control System	Steering Shaft Lock System		√	√	×	√	×	×	
BYD	Sirui	Body Control System	Tire Pressure Monitoring System (TPMS)		√	√	×	√	√	×	00CB
BYD	Sirui	Body Control System	Head Up Display System		√	√	×	√	×	×	
BYD	Sirui	Body Control System	Body Control System		√	√	×	√	√	√	0011
BYD	Sirui	Body Control System	Front Right Door Control ECU		√	√	×	√	√	√	
BYD	Sirui	Body Control System	Night Vision System		√	√	×	√	×	×	
BYD	Sirui	Body Control System	Front Left Door Control ECU		√	√	×	√	√	√	
BYD	Sirui	Body Control System	Combination switch module		√	√	×	√	√	√	

BYD	Sirui	Body Control System	Seat ECU	✓	✓	×	✓	✓	✓	00CC
BYD	Sirui	Body Control System	Green Purification System	✓	✓	×	✓	×	×	
BYD	Sirui	Body Control System	Information Station	✓	✓	×	✓	×	×	
BYD	Sirui	Body Control System	Medium Front Left Door Lock ECU Memory System	✓	✓	×	✓	×	✓	
BYD	Sirui	Body Control System	Medium Front Right Door Lock ECU Memory System	✓	✓	×	✓	×	✓	
BYD	Sirui	Body Control System	Front Hood Distribution Box	✓	✓	×	✓	×	✓	
BYD	Sirui	Body Control System	Instrument Cluster (IC) - 3 Display Panels	✓	✓	×	✓	×	×	
BYD	Sirui	Body Control System	Around View DSP	✓	×	×	×	×	×	
BYD	Sirui	Immobilizer System	Immobilizer System	×	×	×	×	×	×	0019
BYD	E2/E3	Power network	Battery Manager 300 (Private)	✓	✓	×	✓	✓	✓	0008 0009 0076
BYD	E2/E3	Power network	Battery Manager 300 (Public)	✓	✓	×	✓	✓	✓	0008 0009 0076
BYD	E2/E3	Power network	Ternary Battery Manager 400	✓	✓	×	✓	✓	✓	0008 0009 0076
BYD	E2/E3	Power network	Front Drive Motor Controller	✓	✓	×	✓	✓	×	003A
BYD	E2/E3	Power network	Vehicle Controller	✓	✓	×	✓	✓	×	0002 0039 0034 0001 0078
BYD	E2/E3	Power network	Battery Manager 400	✓	✓	×	✓	✓	✓	0008 0009 0076
BYD	E2/E3	ESC network	ESP	✓	✓	×	✓	✓	×	0088 0043 00CD 000B 000C 004F
BYD	E5	E5 (general)	Power module	Master Controller	✓	✓	×	✓	✓	0032 0033
BYD	E5	E5 (general)	Power module	Battery Management System	✓	✓	×	✓	✓	0003 0004
BYD	E5	E5 (general)	Power module	Battery Management System_South America	✓	✓	×	✓	✓	0003 0004
BYD	E5	E5 (general)	Power module	Battery Management System_water cooling	✓	✓	×	✓	✓	0003 0004
BYD	E5	E5 (general)	Power module	Battery Controller	✓	×	×	×	×	
BYD	E5	E5 (general)	Power module	Active Leak Controller	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Power module	DC-DC Assembly Module	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Power module	Gear Controller	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Power module	Low Voltage Battery Management System	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Power module	Electric Leakage Sensor	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Power module	Instrument Cluster	✓	✓	×	✓	×	×
BYD	E5	E5 (general)	Power module	On-Board Charger	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Power module	VOG Driving	✓	×	×	×	×	×
BYD	E5	E5 (general)	Power module	VOG Mode	✓	×	×	×	×	×
BYD	E5	E5 (general)	Power module	VOG Charging	✓	×	×	×	×	×
BYD	E5	E5 (general)	Power module	VOG_DSP2	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Power module	Instrument Cluster (IC)_II	✓	✓	×	✓	×	×
BYD	E5	E5 (general)	Power module	Battery Management System_400	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Power module	Vehicle Charger_7 kW	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Power module	VOG_DSP2_South American Version	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Power module	VOG_DSP2_Simple Version	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Chassis module	Electronic Parking System	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Chassis module	Electronic Parking System (SAC)	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Chassis module	Power Steering System	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Chassis module	Anti-lock Brake System	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Chassis module	ESP	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Body module	Automatic Cruise Control	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Body module	A/C Compressor Controller	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Body module	Combined Switch	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Body module	Door Multiple Controller	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Body module	Multifunctional Screen	✓	✓	×	✓	×	×
BYD	E5	E5 (general)	Body module	Multimedia System	✓	×	×	×	×	×
BYD	E5	E5 (general)	Body module	Parking Assist System	✓	✓	×	✓	×	×
BYD	E5	E5 (general)	Body module	Parking Assist System (II)	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Body module	A/C Water Heater	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Body module	Front Hood Distribution Box Module	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Body module	Driver Seat Regulation Switch Module	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Body module	Front Passenger Seat Regulation Switch Module	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Body module	SRS System	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Body module	On-board terminal module	✓	×	×	×	×	×
BYD	E5	E5 (general)	Body module	CD Changer Assembly	✓	×	×	×	×	×
BYD	E5	E5 (general)	Body module	Battery Heater	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Body module	Battery Cooling Controller	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Body module	Multimedia (Android)	✓	×	×	×	×	×
BYD	E5	E5 (general)	Body module	Multimedia Panel	✓	×	×	×	×	×
BYD	E5	E5 (general)	Body module	Multimedia Panel (Android)	✓	×	×	×	×	×
BYD	E5	E5 (general)	Body module	4G Communication Module	✓	×	×	×	×	×
BYD	E5	E5 (general)	Body module	A/C Control Panel	✓	×	×	×	×	×
BYD	E5	E5 (general)	Body module	Radio	✓	×	×	×	×	×
BYD	E5	E5 (general)	Body module	Green Purification System	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Body module	Tire Pressure Management Module (Baolong)	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Body module	Tire pressure Management Module	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Body module	Tire Pressure Management Module (Sentasa)	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Body module	Engine Sound Simulator	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Body module	Water Cooling Vehicle Model Power Distribution Box	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Immobilizer module	Steering Shaft Lock System	✓	✓	×	✓	×	×
BYD	E5	E5 (general)	Immobilizer module	Body Controller	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Immobilizer module	Body Controller (II)	✓	✓	×	✓	✓	✓
BYD	E5	E5 (general)	Immobilizer module	Smart Key System	✓	✓	×	✓	✓	×
BYD	E5	E5 (general)	Gateway module	Gateway	✓	✓	×	✓	×	×
BYD	E5	E5 travel edition	Power network	Battery Heater	✓	✓	×	✓	✓	×
BYD	E5	E5 travel edition	Power network	Battery Controller	✓	×	×	×	×	×
BYD	E5	E5 travel edition	Power network	Battery Management System_300	✓	✓	×	✓	✓	✓
BYD	E5	E5 travel edition	Power network	Battery Management System_400	✓	✓	×	✓	✓	✓
BYD	E5	E5 travel edition	Power network	DC-DC Assembly	✓	✓	×	✓	✓	×

BYD	E5	E5 travel edition	Power network	Front Drive Motor Controller	√	√	x	√	√	x	003A
BYD	E5	E5 travel edition	Power network	Gear Controller	√	√	x	√	√	x	
BYD	E5	E5 travel edition	Power network	Low Voltage Battery Management System	√	√	x	√	√	√	
BYD	E5	E5 travel edition	Power network	Electric Leakage Sensor	√	√	x	√	√	x	00CF
BYD	E5	E5 travel edition	Power network	Vehicle Charger 7 kW	√	√	x	√	√	x	
BYD	E5	E5 travel edition	Power network	Vehicle Controller	√	√	x	√	√	x	0002 0001 0034 0039 00CE
BYD	E5	E5 travel edition	Start network	Steering Shaft Lock	√	√	x	√	x	x	
BYD	E5	E5 travel edition	Start network	Body Controller	√	√	x	√	√	√	
BYD	E5	E5 travel edition	Start network	Intelligent Key	√	√	x	√	√	x	
BYD	E5	E5 travel edition	Comfort net	4G Communication Module	√	x	x	x	x	x	
BYD	E5	E5 travel edition	Comfort net	Automatic Cruise Control	√	√	x	√	√	√	
BYD	E5	E5 travel edition	Comfort net	A/C Compressor Controller	√	√	x	√	√	x	
BYD	E5	E5 travel edition	Comfort net	A/C Control Panel	√	x	x	x	x	x	
BYD	E5	E5 travel edition	Comfort net	Combined Switch	√	√	x	√	√	√	
BYD	E5	E5 travel edition	Comfort net	Door Multiple Controller	√	√	x	√	√	√	
BYD	E5	E5 travel edition	Comfort net	Instrument Cluster	√	√	x	√	x	√	
BYD	E5	E5 travel edition	Comfort net	Multifunctional Screen	√	√	x	√	x	x	
BYD	E5	E5 travel edition	Comfort net	Multimedia (Android)	√	x	x	x	x	x	
BYD	E5	E5 travel edition	Comfort net	Multimedia Panel (Android Version)	√	x	x	x	x	x	
BYD	E5	E5 travel edition	Comfort net	A/C Water Heater	√	√	x	√	√	x	
BYD	E5	E5 travel edition	Comfort net	Radio	√	x	x	x	x	x	
BYD	E5	E5 travel edition	Comfort net	Front Hood Distribution Box	√	√	x	√	√	√	
BYD	E5	E5 travel edition	Comfort net	Supplementary Restraint System	√	√	x	√	√	x	000E 001F
BYD	E5	E5 travel edition	Comfort net	(Baolong) Tire Pressure Management Module	√	√	x	√	√	x	0030 0031 0022 0023 0024 0025
BYD	E5	E5 travel edition	Comfort net	(Sensata) Tire Pressure Management Module	√	√	x	√	√	x	0030 0031 0022 0023 0024 0025
BYD	E5	E5 travel edition	Comfort net	Engine Sound Simulator	√	√	x	√	√	√	
BYD	E5	E5 travel edition	Comfort net	Vehicle Terminal	√	x	x	x	x	x	
BYD	E5	E5 travel edition	Comfort net	Automobile Data Recorder	√	x	x	x	x	x	
BYD	E5	E5 travel edition	Comfort net	Fuel heater	√	√	x	√	√	√	
BYD	E5	E5 travel edition	Comfort net	Engine Sound Simulator (Bodun Electronics)	√	√	x	√	√	√	
BYD	E5	E5 travel edition	Gateway module	Gateway	√	√	x	√	x	x	
BYD	E5	E5 travel edition	ESC network	Brake Control System	√	√	x	√	√	√	000B 000D 000D 00D1
BYD	E5	E5 travel edition	ESC network	ABS	√	√	x	√	√	x	000B
BYD	E5	E5 travel edition	ESC network	ESP	√	√	x	√	√	x	0044 000B 000C 000D
BYD	E5	E5 travel edition	ESC network	Electronic Parking System (Sark)	√	√	x	√	√	√	00B4
BYD	E5	E5 travel edition	ESC network	Power-assisted Steering	√	√	x	√	√	x	00B2
BYD	E6	E6A	Power module	MG2 Motor Controller	√	√	x	√	√	x	
BYD	E6	E6A	Power module	Gear P Motor Controller	√	√	x	√	√	x	
BYD	E6	E6A	Power module	Gear Controller	√	√	x	√	√	x	
BYD	E6	E6A	Power module	Traction Battery Manager	√	√	x	√	√	x	
BYD	E6	E6A	Power module	Air Conditioner Driver	√	√	x	√	√	x	
BYD	E6	E6A	Power module	Master Controller	√	√	x	√	√	x	
BYD	E6	E6A	Power module	Combination Instrument System	√	√	x	√	x	x	
BYD	E6	E6A	Power module	Automatic Cruise Control	√	√	x	√	√	x	
BYD	E6	E6A	Power module	Electric Power Steering System	√	√	x	√	√	x	
BYD	E6	E6A	Anti-lock Brake System	Bosch ABS9	√	√	x	√	√	x	00BA
BYD	E6	E6A	Anti-lock Brake System	BOSCH ABS System	√	√	x	√	√	x	00BA
BYD	E6	E6A	Anti-lock Brake System	Bosch ESP9 System	√	√	x	√	√	x	00C2
BYD	E6	E6A	Supplementary Restraint System	SRS (CAN)	√	√	x	√	√	x	000E 00CA
BYD	E6	E6A	Body Control System	Steering Shaft Lock System	√	√	x	√	x	x	
BYD	E6	E6A	Body Control System	BCM	√	√	x	√	x	x	
BYD	E6	E6A	Body Control System	Smart Key System	√	√	x	√	√	x	
BYD	E6	E6A	Body Control System	Door Multiple Control Module	√	√	x	√	x	x	
BYD	E6	E6A	Body Control System	Combination switch module	√	√	x	√	x	x	
BYD	E6	E6A	Body Control System	Relay Control	√	√	x	√	x	x	
BYD	E6	E6A	Body Control System	Gateway	√	√	x	√	x	x	
BYD	E6	E6A	Body Control System	Park Pilot	√	√	x	√	x	x	
BYD	E6	E6A	BOSCH ACM System	BOSCH ACM System	√	√	x	√	√	x	0018
BYD	E6	E6A	Immobilizer System	Immobilizer System	x	x	x	x	x	x	0019
BYD	E6	E6B(E6 Forerunner)	Power module	MG2 Motor Controller	√	√	x	√	√	x	
BYD	E6	E6B(E6 Forerunner)	Power module	Gear P Motor Controller	√	√	x	√	√	x	
BYD	E6	E6B(E6 Forerunner)	Power module	Gear Controller	√	√	x	√	√	x	
BYD	E6	E6B(E6 Forerunner)	Power module	Power Battery Management System	√	√	x	√	√	x	
BYD	E6	E6B(E6 Forerunner)	Power module	Air Conditioner Driver	√	√	x	√	√	x	
BYD	E6	E6B(E6 Forerunner)	Power module	Master Controller	√	√	x	√	√	x	
BYD	E6	E6B(E6 Forerunner)	Power module	Combination Instrument System	√	√	x	√	x	x	
BYD	E6	E6B(E6 Forerunner)	Power module	Automatic Cruise Control	√	√	x	√	√	x	
BYD	E6	E6B(E6 Forerunner)	Power module	Electric Power Steering System	√	√	x	√	√	x	
BYD	E6	E6B(E6 Forerunner)	System/Electronic Stability Control	Anti-Lock Braking System/Electronic Stability Control	√	√	x	√	√	x	00BA
BYD	E6	E6B(E6 Forerunner)	System/Electronic Stability Control	Bosch ESP9 System	√	√	x	√	√	x	00C2
BYD	E6	E6B(E6 Forerunner)	Body Control System	Door Multicircuit Control Module	√	√	x	√	x	x	
BYD	E6	E6B(E6 Forerunner)	Body Control System	Gateway	√	√	x	√	x	x	
BYD	E6	E6B(E6 Forerunner)	Body Control System	Keyless System	√	√	x	√	√	x	
BYD	E6	E6B(E6 Forerunner)	Body Control System	Relay Control Module	√	√	x	√	x	x	
BYD	E6	E6B(E6 Forerunner)	Body Control System	Steering Shaft Lock System	√	√	x	√	x	x	
BYD	E6	E6B(E6 Forerunner)	Body Control System	Body Control System	√	√	x	√	x	x	
BYD	E6	E6B(E6 Forerunner)	Body Control System	Parking Auxiliary System	√	√	x	√	x	x	
BYD	E6	E6B(E6 Forerunner)	Body Control System	Combination Switch Module	√	√	x	√	x	x	
BYD	E6	E6B(E6 Forerunner)	Body Control System	Park Pilot	√	√	x	√	x	x	
BYD	E6	E6B(E6 Forerunner)	System	Supplementary Restraint System	√	√	x	√	√	x	000E 00CA
BYD	E6	E6B(E6 Forerunner)	System	Tire Pressure Monitoring System (TPMS)	√	√	x	√	√	x	00CB
BYD	E6	E6B(E6 Forerunner)	System	BOSCH ACM System	√	√	x	√	√	x	0018
BYD	E6	E6B(E6 Forerunner)	System	Immobilizer System	x	x	x	x	x	x	0019
BYD	E6	E6H	Power module	DC1	√	√	x	√	√	x	
BYD	E6	E6H	Power module	DC2	√	√	x	√	√	x	
BYD	E6	E6H	Power module	Gear Controller	√	√	x	√	√	x	
BYD	E6	E6H	Power module	Battery Management System	√	√	x	√	√	x	00D2
BYD	E6	E6H	Power module	E6G Battery Management System	√	√	x	√	√	x	

BYD	E6	E6H	Power module	A/C 1 Controller	√	√	x	√	√	√	
BYD	E6	E6H	Power module	A/C 1 Compressor	√	√	x	√	√	x	
BYD	E6	E6H	Power module	A/C Control Panel	√	x	x	x	√	x	
BYD	E6	E6H	Power module	A/C Water Heater	√	√	x	√	√	x	
BYD	E6	E6H	Power module	Electric Leakage Sensor	√	√	x	√	√	x	
BYD	E6	E6H	Power module	Gear P Controller	√	√	x	√	√	x	
BYD	E6	E6H	Power module	VTOG_DSP2	√	√	x	√	√	√	
BYD	E6	E6H	Power module	VTOG Charging	√	x	x	x	x	x	
BYD	E6	E6H	Power module	VTOG Driving	√	x	x	x	x	x	
BYD	E6	E6H	Power module	Hydraulic Power Brake	√	√	x	√	√	x	
BYD	E6	E6H	Power module	Master Controller	√	√	x	√	√	x	0032 0033
BYD	E6	E6H	Power module	Instrument Cluster	√	√	x	√	x	x	
BYD	E6	E6H	Chassis module	ABS	√	√	x	√	√	x	
BYD	E6	E6H	Chassis module	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	E6	E6H	Chassis module	Electronic Parking System (SAC)	√	√	x	√	√	√	002B
BYD	E6	E6H	Chassis module	Electronic Parking Brake System (Mando)	√	√	x	√	√	√	
BYD	E6	E6H	Chassis module	Power-assisted Steering	√	√	x	√	√	x	
BYD	E6	E6H	Body module	Supplementary Restraint System	√	√	x	√	√	x	000E 001F
BYD	E6	E6H	Body module	Parking Assist System	√	√	x	√	√	x	0020
BYD	E6	E6H	Body module	Door Multiple Controller	√	√	x	√	x	x	
BYD	E6	E6H	Body module	Vehicle Terminal	√	x	x	x	x	x	
BYD	E6	E6H	Body module	Battery Heater	√	√	x	√	√	x	
BYD	E6	E6H	Body module	Battery Cooling Controller	√	√	x	√	√	√	
BYD	E6	E6H	Body module	Multimedia	√	x	x	x	x	x	
BYD	E6	E6H	Body module	4G Communication Module	√	x	x	x	x	x	
BYD	E6	E6H	Body module	A/C 2 Controller	√	√	x	√	√	√	
BYD	E6	E6H	Body module	A/C 2 Compressor	√	√	x	√	√	x	
BYD	E6	E6H	Body module	Rear Impact ECU	√	√	x	√	√	x	000E 001F
BYD	E6	E6H	Body module	Green Purification System	√	√	x	√	√	x	0021
BYD	E6	E6H	Body module	Front Hood Distribution Box	√	√	x	√	x	x	
BYD	E6	E6H	Body module	Tire pressure Management Module	√	√	x	√	√	x	0022 0023 0024 0025
BYD	E6	E6H	Body module	Tire Pressure Management Module (Baolong)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	E6	E6H	Body module	Tire Pressure Management Module (Sentasa)	√	√	x	√	√	x	0022 0023 0024 0025 0030 0031
BYD	E6	E6H	Body module	Engine Sound Simulator	√	√	x	√	√	√	
BYD	E6	E6H	Body module	Cloud Service System	√	x	x	x	x	x	
BYD	E6	E6H	Body module	Combined Switch	√	√	x	√	x	x	
BYD	E6	E6H	Immobilizer module	Body Controller	√	√	x	√	x	x	
BYD	E6	E6H	Immobilizer module	Intelligent Key	√	√	x	√	√	x	
BYD	E6	E6H	Immobilizer module	Steering Shaft Lock	√	√	x	√	x	x	
BYD	E6	E6H	Gateway module	Gateway	√	√	x	√	x	x	
BYD	E6	E6Y	Power module	High Voltage Battery Management System	√	√	x	√	√	x	
BYD	E6	E6Y	Power module	Gear Controller	√	√	x	√	√	x	
BYD	E6	E6Y	Power module	12 V DC_1	√	√	x	√	√	x	
BYD	E6	E6Y	Power module	12 V DC_2	√	√	x	√	√	x	
BYD	E6	E6Y	Power module	Master Controller	√	√	x	√	√	x	0032 0033
BYD	E6	E6Y	Power module	A/C Compressor	√	√	x	√	√	x	
BYD	E6	E6Y	Power module	Automatic Cruise Control	√	√	x	√	√	x	
BYD	E6	E6Y	Power module	PTC Module	√	√	x	√	√	x	
BYD	E6	E6Y	Power module	Gear P Motor Controller	√	√	x	√	√	x	
BYD	E6	E6Y	Power module	Combination Instrument System	√	√	x	√	x	x	
BYD	E6	E6Y	Power module	Electric Power Steering System	√	√	x	√	√	x	
BYD	E6	E6Y	Power module	VTOG_DSP2	√	√	x	√	√	√	
BYD	E6	E6Y	Power module	VTOG Mode	√	x	x	x	x	x	
BYD	E6	E6Y	Power module	VTOG Charging	√	x	x	x	x	x	
BYD	E6	E6Y	Power module	VTOG Driving	√	x	x	x	x	x	
BYD	E6	E6Y	Anti-Lock Braking System/Electronic Stability Control	BOSCH ABS System	√	√	x	√	√	x	00BA
BYD	E6	E6Y	Anti-Lock Braking System/Electronic Stability Control	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	E6	E6Y	Electronic Parking Brake	Electronic Parking Brake	√	√	x	√	√	√	
BYD	E6	E6Y	Supplementary Restraint System	SRS (CAN)	√	√	x	√	√	x	000E 00CA
BYD	E6	E6Y	Body Control System	Steering Shaft Lock System	√	√	x	√	x	x	
BYD	E6	E6Y	Body Control System	BCM	√	√	x	√	x	x	
BYD	E6	E6Y	Body Control System	Smart Key System	√	√	x	√	√	x	
BYD	E6	E6Y	Body Control System	Door Multiple Control Module	√	√	x	√	x	x	
BYD	E6	E6Y	Body Control System	Combination switch module	√	√	x	√	x	x	
BYD	E6	E6Y	Body Control System	Relay Control	√	√	x	√	x	x	
BYD	E6	E6Y	Body Control System	Gateway	√	√	x	√	x	x	
BYD	E6	E6Y	Body Control System	Park Pilot	√	√	x	√	x	x	
BYD	E6	E6Y	Body Control System	Rear Impact ECU	√	√	x	√	√	x	000E 00CA
BYD	E6	E6Y	Body Control System	Tire Pressure Monitoring System (TPMS)	√	√	x	√	√	x	00CB
BYD	E6	E6Y	Body Control System	OCS	√	√	x	√	√	x	
BYD	E6	E6Y	Body Control System	Engine Sound Simulator	√	√	x	√	√	√	
BYD	E6	E6Y	BOSCH ACM System	BOSCH ACM System	√	√	x	√	√	x	0018
BYD	E6	E6Y	Immobilizer System	Immobilizer System	x	x	x	x	x	x	0019
BYD	E6	E6M	Power network	ABS	√	√	x	√	√	x	
BYD	E6	E6M	Power network	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	E6	E6M	Power network	Hydraulic Power Brake	√	√	x	√	√	x	
BYD	E6	E6M	Power network	Master Controller	√	√	x	√	√	x	0032 0033
BYD	E6	E6M	Power network	Battery Management System	√	√	x	√	√	x	
BYD	E6	E6M	Power network	DC1	√	√	x	√	√	x	
BYD	E6	E6M	Power network	DC2	√	√	x	√	√	x	
BYD	E6	E6M	Power network	Power-assisted Steering	√	√	x	√	√	x	
BYD	E6	E6M	Power network	Electronic Parking System (Wandu)	√	√	x	√	√	√	
BYD	E6	E6M	Power network	Gear Controller	√	√	x	√	√	x	
BYD	E6	E6M	Power network	Gear P Controller	√	√	x	√	√	x	
BYD	E6	E6M	Power network	VTOG Charging	√	x	x	x	x	x	
BYD	E6	E6M	Power network	VTOG Driving	√	x	x	x	x	x	
BYD	E6	E6M	Power network	VTOG Mode	√	x	x	x	x	x	
BYD	E6	E6M	Power network	VTOG_DSP2	√	√	x	√	√	√	
BYD	E6	E6M	Start network	Steering Shaft Lock	√	√	x	√	x	x	
BYD	E6	E6M	Start network	Body Controller	√	√	x	√	x	x	
BYD	E6	E6M	Start network	Intelligent Key	√	√	x	√	√	x	
BYD	E6	E6M	Comfort net	Automatic Cruise Control	√	√	x	√	√	√	
BYD	E6	E6M	Comfort net	A/C Compressor Controller	√	√	x	√	√	x	
BYD	E6	E6M	Comfort net	Combined Switch	√	√	x	√	x	x	
BYD	E6	E6M	Comfort net	Door Multiple Controller	√	√	x	√	x	x	

BYD	E6	E6M	Comfort net	Instrument Cluster	√	√	x	√	x	x	
BYD	E6	E6M	Comfort net	Parking Assist System	√	√	x	√	√	x	
BYD	E6	E6M	Comfort net	A/C Water Heater	√	√	x	√	√	x	
BYD	E6	E6M	Comfort net	Front Hood Distribution Box	√	√	x	√	x	x	
BYD	E6	E6M	Comfort net	Rear Impact ECU	√	√	x	√	√	x	000E 001F
BYD	E6	E6M	Comfort net	Supplementary Restraint System	√	√	x	√	√	x	000E 001F
BYD	E6	E6M	Comfort net	Tire pressure Management Module	√	√	x	√	√	x	
BYD	E6	E6M	Gateway module	Gateway	x	√	x	√	x	x	
BYD	G3	Engine System	UAES M787CAN Engine System		√	√	x	√	√	√	0001
BYD	G3	Engine System	Delphi MT22 Engine System		√	√	x	√	√	√	007D
BYD	G3	Engine System	Engine Controller 473DCT		√	√	x	√	√	√	0001
BYD	G3	Engine System	UAES M78_473QE System		√	√	x	√	√	√	
BYD	G3	Engine System	Engine Controller_473DCTSS		√	√	x	√	√	√	0001 008F
BYD	G3	Engine System	Engine Controller_473MTSS		√	√	x	√	√	√	0001
BYD	G3	Automatic Transmission System	Continuously Variable Transmission (CVT) (Punch)		√	√	x	√	√	x	00C5 00C6 00C7
BYD	G3	Automatic Transmission System	BYD DCT Transmission Control System		√	√	x	√	√	√	000A
BYD	G3	Anti-lock Brake System	BOSCH Anti-Lock Braking System (ABS8)		√	√	x	√	√	√	00BB
BYD	G3	Anti-lock Brake System	Bosch ABS (ABS9)		√	√	x	√	√	√	00BB
BYD	G3	Anti-lock Brake System	Delphi ABS System		√	√	x	√	√	√	00BA
BYD	G3	Anti-lock Brake System	BWI ABS		√	√	x	√	√	√	00BA
BYD	G3	Body Control System	Communication System		x	x	x	x	x	√	
BYD	G3	Body Control System	Instrument System		√	√	x	√	x	x	
BYD	G3	Body Control System	Steering Shaft Lock System		√	√	x	√	x	x	
BYD	G3	Body Control System	Parking Auxiliary System		√	√	x	√	x	x	
BYD	G3	Body Control System	Keyless System		√	√	x	√	√	x	
BYD	G3	Body Control System	Customization		x	x	x	x	x	x	0011
BYD	G3	Body Control System	BCM		√	√	x	√	x	√	
BYD	G3	Body Control System	Gateway		√	√	x	√	√	x	
BYD	G3	Supplementary Restraint System	Supplementary Restraint System		√	√	x	√	√	x	000E
BYD	G3	Power Steering System	Power Steering System		√	√	x	√	x	x	000F 0010
BYD	G3	Immobilizer System	Immobilizer System		x	x	x	x	x	x	0019
BYD	G5	Engine System	BYD TI Engine Management System		√	√	x	√	√	√	00C0
BYD	G5	Engine System	UAES ME17.88		√	√	x	√	√	√	0001
BYD	G5	Engine System	Delphi MT22 Engine System		√	√	x	√	√	√	007D
BYD	G5	Engine System	UAES ME17.88 Start-Stop System		√	√	x	√	√	√	
BYD	G5	Engine System	Engine Controller 473DCT		√	√	x	√	√	√	0001
BYD	G5	Engine System	Engine Controller_473MT		√	√	x	√	√	√	0001
BYD	G5	Engine System	Engine Controller 1.5TID		√	√	x	√	√	√	0001
BYD	G5	Engine System	Engine Controller 1.5TI		√	√	x	√	√	√	0001
BYD	G5	Engine System	Engine Controller_Delphi MT22		√	√	x	√	√	√	0001
BYD	G5	Engine System	Engine Controller UAES ME1788		√	√	x	√	√	√	0001
BYD	G5	Gear P Motor Controller	Gear P Motor Controller		√	√	x	√	√	x	
BYD	G5	Automatic Transmission System	BYD DCT Transmission Control System		√	√	x	√	√	√	000A
BYD	G5	Supplementary Restraint System	SRS (CAN)		√	√	x	√	√	x	000E 00CA
BYD	G5	Supplementary Restraint System	Air Bag III		√	√	x	√	x	x	000E 001F
BYD	G5	Anti-Lock Braking System/Electronic Stability Control	ABS		√	√	x	√	√	x	
BYD	G5	Anti-Lock Braking System/Electronic Stability Control	Bosch ESP9 System		√	√	x	√	√	x	00C2
BYD	G5	Power Steering System	Power Steering System		√	√	x	√	x	x	000F 0010
BYD	G5	Power Steering System	Power Steering (DIAS)		√	√	x	√	√	x	002C 002D
BYD	G5	Electronic Parking Brake	Electronic Parking Brake		√	√	x	√	√	√	
BYD	G5	Body Control System	Steering Shaft Lock System		√	√	x	√	x	x	
BYD	G5	Body Control System	Combination Instrument System		√	√	x	√	x	x	0007
BYD	G5	Body Control System	Parking Auxiliary System		√	√	x	√	x	x	0012
BYD	G5	Body Control System	Body Controller - Independent Board		√	√	x	√	√	√	
BYD	G5	Body Control System	Smart Key System		√	√	x	√	√	x	
BYD	G5	Body Control System	Door Multiple Controller		√	√	x	√	√	√	
BYD	G5	Body Control System	Combination switch module		√	√	x	√	√	√	
BYD	G5	Body Control System	Relay Control Module		√	√	x	√	x	√	
BYD	G5	Body Control System	Automatic Cruise Control		√	√	x	√	√	√	
BYD	G5	Body Control System	Gateway		√	√	x	√	x	x	
BYD	G5	Body Control System	Tire Pressure Monitoring System (TPMS)		√	√	x	√	√	x	00CB

BYD	G5	Body Control System	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	G5	Body Control System	Panoramic video	√	√	×	√	√	×	
BYD	G5	Body Control System	Front Left Door Control Module	√	√	×	√	√	√	
BYD	G5	Body Control System	Front Right Door Control Module	√	√	×	√	√	√	
BYD	G5	Body Control System	Seat Memory System	√	√	×	√	√	√	00CC
BYD	G5	Body Control System	Information Station	√	√	×	√	×	×	
BYD	G5	Body Control System	Green Purification System	√	√	×	√	√	×	0021
BYD	G5	Body Control System	BCM Integration Builds	√	√	×	√	√	√	0011
BYD	G5	Body Control System	Multimedia Panel	√	×	×	×	×	×	
BYD	G5	Body Control System	Multimedia	√	×	×	×	×	×	
BYD	G5	Body Control System	Around View DSP	√	×	×	×	×	×	
BYD	G5	Immobilizer System	Immobilizer System	×	×	×	×	×	×	0019
BYD	G6	Engine System	UAES M79_473QE System	√	√	×	√	√	√	
BYD	G6	Engine System	Engine controller 1.5 T1_ with cruise	√	√	×	√	√	√	0001
BYD	G6	Engine System	Engine controller 1.5 T1_ with cruise	√	√	×	√	√	√	0001
BYD	G6	Engine System	Engine Controller_UMC M79	√	√	×	√	√	√	0001
BYD	G6	Engine System	Engine Controller UAES ME1788	√	√	×	√	√	√	0001
BYD	G6	Engine System	Engine Controller 1.5TID	√	√	×	√	√	√	0001
BYD	G6	Engine System	Engine Controller_2.0TID	√	√	×	√	√	√	0001
BYD	G6	Automatic Transmission System	Wet Dual-clutch Transmission	√	√	×	√	√	√	0060 001A 0061 0062 0063 0064 0065 0066 0067 0068 001C 0069
BYD	G6	Automatic Transmission System	Dual-clutch Transmission	√	√	×	√	√	√	001A 001B 001C 001D
BYD	G6	Automatic Transmission System	Continuously Variable Transmission (CVT) (Punch)	√	√	×	√	√	×	
BYD	G6	Anti-Lock Braking System/Electronic Stability Control	BOSCH Anti-Lock Braking System (ABS8)	√	√	×	√	√	√	00BB
BYD	G6	Anti-Lock Braking System/Electronic Stability Control	Bosch ABS (ABS9)	√	√	×	√	√	√	00BB
BYD	G6	Anti-Lock Braking System/Electronic Stability Control	ESP	√	√	×	√	√	×	000B 000C 000D
BYD	G6	Power Steering System	Power Steering System	√	√	×	√	×	×	000F 0010
BYD	G6	Body Control System	Combination Instrument System	√	√	×	√	×	√	
BYD	G6	Body Control System	Steering Shaft Lock System	√	√	×	√	×	×	
BYD	G6	Body Control System	Combination Switch Module	√	√	×	√	×	×	
BYD	G6	Body Control System	Forecabin Distribution Box Relay Circuit Template	√	√	×	√	×	×	
BYD	G6	Body Control System	Multifunctional Screen	√	√	×	√	×	×	
BYD	G6	Body Control System	Headlamp Adjustment Unit	√	√	×	√	√	√	
BYD	G6	Body Control System	Vehicle Terminal	√	×	×	×	×	×	
BYD	G6	Body Control System	Electronic Parking System	√	√	×	√	√	√	
BYD	G6	Body Control System	Parking Assist System	√	√	×	√	×	×	00C3
BYD	G6	Body Control System	Body Controller	√	√	×	√	√	√	
BYD	G6	Body Control System	Intelligent Key	√	√	×	√	√	×	
BYD	G6	Body Control System	Door Multiple Controller	√	√	×	√	×	×	
BYD	G6	Body Control System	Automatic Cruise Control	√	√	×	√	√	×	
BYD	G6	Body Control System	Gateway	√	√	×	√	√	×	
BYD	G6	Body Control System	Tire pressure Management Module	√	√	×	√	√	×	0022 0023 0024 0025 0014
BYD	G6	Body Control System	Green Purification System	√	√	×	√	√	×	
BYD	G6	Body Control System	Around View DSP	√	×	×	×	×	×	
BYD	G6	Body Control System	Around View MCU	√	√	×	√	√	×	
BYD	G6	Body Control System	Panoramic Steering Wheel Switch	√	√	×	√	√	√	
BYD	G6	Body Control System	Information Station	√	√	×	√	×	×	
BYD	G6	Body Control System	Rear Multimedia Control Switch	√	√	×	√	√	√	
BYD	G6	Supplementary Restraint System	Supplementary Restraint System	√	√	×	√	√	×	000E
BYD	G6	Supplementary Restraint System	Air Bag III	√	√	×	√	√	×	000E 001F
BYD	G6	Immobilizer System	Immobilizer System	×	×	×	×	×	×	0019
BYD	T3	Power module	On-Board Charger	√	√	×	√	√	×	
BYD	T3	Power module	DC-DC Assembly	√	√	×	√	√	×	
BYD	T3	Power module	Gear Controller	√	√	×	√	√	×	
BYD	T3	Power module	Low Voltage Battery Management System	√	√	×	√	√	√	
BYD	T3	Power module	Battery Collection System	√	×	×	×	×	×	
BYD	T3	Power module	Battery Management System	√	√	×	√	√	√	0008 0009
BYD	T3	Power module	Electric Leakage Sensor	√	√	×	√	√	×	
BYD	T3	Power module	Mode Switch	√	√	×	√	√	×	
BYD	T3	Power module	VTQG_DSP2	√	√	×	√	√	√	0034
BYD	T3	Power module	VTQG Charging	√	×	×	×	×	×	
BYD	T3	Power module	VTQG Mode	√	×	×	×	×	×	
BYD	T3	Power module	VTQG Driving	√	×	×	×	×	×	

BYD	T3	Power module	Active Leak Controller	√	√	x	√	√	x	
BYD	T3	Power module	Master Controller	√	√	x	√	√	x	0032 0033
BYD	T3	Power module	Instrument Cluster	√	√	x	√	x	x	
BYD	T3	Power module	VT OG_DSP2_South American Version	√	√	x	√	√	√	0034
BYD	T3	Body module	Supplementary Restraint System	√	√	x	√	√	x	000E
BYD	T3	Body module	Air Bag III	√	√	x	√	√	x	000E 001F
BYD	T3	Body module	Parking Assist System	√	√	x	√	x	x	
BYD	T3	Body module	Door Multiple Controller	√	√	x	√	x	x	
BYD	T3	Body module	Vehicle Terminal	√	x	x	x	x	x	
BYD	T3	Body module	Multimedia	√	x	x	x	x	x	
BYD	T3	Body module	4G Communication Module	√	x	x	x	x	x	
BYD	T3	Body module	A/C Control Panel	√	x	x	x	x	x	
BYD	T3	Body module	Automatic Cruise Control	√	√	x	√	√	√	
BYD	T3	Body module	A/C Controller (2.0)	√	√	x	√	√	√	
BYD	T3	Body module	A/C Water Heater	√	√	x	√	√	x	
BYD	T3	Body module	A/C Compressor Controller	√	√	x	√	√	x	
BYD	T3	Body module	Cloud Service System	√	x	x	x	x	x	
BYD	T3	Body module	Engine Sound Simulator	√	√	x	√	√	√	
BYD	T3	Chassis module	ABS	√	√	x	√	√	x	000B 000C 008A
BYD	T3	Chassis module	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	T3	Chassis module	Electronic Parking System	√	√	x	√	√	√	
BYD	T3	Chassis module	Power-assisted Steering	√	√	x	√	√	x	
BYD	T3	Immobilizer module	Steering Shaft Lock	√	√	x	√	x	x	
BYD	T3	Immobilizer module	Body Controller	√	√	x	√	√	√	
BYD	T3	Immobilizer module	Intelligent Key	√	√	x	√	√	x	
BYD	T3	Gateway module	Gateway	√	√	x	√	x	x	
BYD	M3	M3_DM	Power module	On-Board Charger	√	√	x	√	√	x
BYD	M3	M3_DM	Power module	Gear Controller	√	√	x	√	√	x
BYD	M3	M3_DM	Power module	Low Voltage Battery Management System	√	√	x	√	√	√
BYD	M3	M3_DM	Power module	Battery Collection System	√	x	x	x	x	x
BYD	M3	M3_DM	Power module	Battery Management System	√	√	x	√	√	√
BYD	M3	M3_DM	Power module	Battery Management System (Low-power Version)	√	√	x	√	√	√
BYD	M3	M3_DM	Power module	EV-HEV Switch	√	√	x	√	x	x
BYD	M3	M3_DM	Power module	Electric Leakage Sensor	√	√	x	√	√	x
BYD	M3	M3_DM	Power module	Instrument Cluster	√	√	x	√	x	x
BYD	M3	M3_DM	Body module	Supplementary Restraint System	√	√	x	√	√	x
BYD	M3	M3_DM	Body module	Supplementary Restraint System	√	√	x	√	√	x
BYD	M3	M3_DM	Body module	Parking Assist System	√	√	x	√	√	x
BYD	M3	M3_DM	Body module	Door Multiple Controller	√	√	x	√	x	x
BYD	M3	M3_DM	Body module	Vehicle Terminal	√	x	x	x	x	x
BYD	M3	M3_DM	Body module	Multimedia	√	x	x	x	x	x
BYD	M3	M3_DM	Body module	4G Communication Module	√	x	x	x	x	x
BYD	M3	M3_DM	Body module	Rear Interior Light	√	√	x	√	x	x
BYD	M3	M3_DM	Body module	A/C Control Panel	√	x	x	x	x	x
BYD	M3	M3_DM	Body module	Automatic Cruise Control	√	√	x	√	√	√
BYD	M3	M3_DM	Body module	A/C Water Heater	√	√	x	√	√	x
BYD	M3	M3_DM	Body module	A/C Compressor Controller	√	√	x	√	√	x
BYD	M3	M3_DM	Body module	Information Station	√	√	x	√	x	x
BYD	M3	M3_DM	Body module	Cloud Service System	√	x	x	x	x	x
BYD	M3	M3_DM	Body module	Engine Sound Simulator	√	√	x	√	√	√
BYD	M3	M3_DM	ECM module	DC-DC Assembly	√	√	x	√	√	x
BYD	M3	M3_DM	ECM module	Engine Controller	√	√	x	√	√	√
BYD	M3	M3_DM	ECM module	Drive Motor Controller	√	√	x	√	√	x
BYD	M3	M3_DM	ECM module	Dual-clutch Transmission	√	√	x	√	√	√
BYD	M3	M3_DM	ECM module	Active Leak Controller	√	x	x	x	√	x
BYD	M3	M3_DM	Chassis module	ABS	√	√	x	√	√	x
BYD	M3	M3_DM	Chassis module	ESP	√	√	x	√	√	x
BYD	M3	M3_DM	Chassis module	Electronic Parking System	√	√	x	√	√	√
BYD	M3	M3_DM	Chassis module	Power Steering (DIAS)	√	√	x	√	√	x
BYD	M3	M3_DM	Chassis module	Power-assisted Steering	√	√	x	√	√	x
BYD	M3	M3_DM	Immobilizer module	Steering Shaft Lock	√	√	x	√	x	x
BYD	M3	M3_DM	Immobilizer module	Body Controller	√	√	x	√	√	√
BYD	M3	M3_DM	Immobilizer module	Intelligent Key	√	√	x	√	√	x
BYD	M3	M3_DM	Gateway module	Gateway	√	√	x	√	x	x
BYD	M6	Engine System	Mitsubishi Engine System	√	√	√	√	√	√	
BYD	M6	Engine System	UAES M787CAN Engine System	√	√	x	√	√	√	0001
BYD	M6	Engine System	Engine Controller_UMC M7971	√	√	x	√	√	√	0001
BYD	M6	Engine System	Engine Controller UAES ME1788	√	√	x	√	√	√	0001
BYD	M6	Anti-lock Brake System	Wheel ABS (ABS 8)	√	√	x	√	√	x	
BYD	M6	Anti-lock Brake System	Wheel ABS (ABS 9)	√	√	x	√	√	x	
BYD	M6	Anti-lock Brake System	ESP	√	√	x	√	√	x	000B 000C 000D
BYD	M6	Automatic Transmission System	Mitsubishi Electronic Control Transmission	√	√	√	√	√	√	
BYD	M6	Automatic Transmission System	Dual-clutch Transmission	√	√	x	√	√	√	00D3 00AF 0073 0059
BYD	M6	Automatic Transmission System	BYD Wet-type DCT Transmission Control System	√	√	x	√	√	√	0060 001A 0061 0062 0063 0064 00C8 00C9 0067 0068 001C 0069
BYD	M6	Supplementary Restraint System	SRS (CAN)	√	√	x	√	√	x	000E 00CA
BYD	M6	Body Control System	Instrument System	√	√	x	√	x	x	
BYD	M6	Body Control System	Body Control System	√	√	x	√	x	x	
BYD	M6	Body Control System	Keyless System	√	√	x	√	√	x	
BYD	M6	Body Control System	Steering Shaft Lock System	√	√	x	√	x	x	
BYD	M6	Body Control System	Door Multicircuit Control Module	√	√	x	√	x	x	
BYD	M6	Body Control System	Panoramic Steering Wheel Switch	√	√	x	√	√	√	
BYD	M6	Body Control System	Combination Switch Module	√	√	x	√	x	x	

BYD	M6	Body Control System	Forecabin Distribution Box Relay Circuit Template	√	√	x	√	x	x	
BYD	M6	Body Control System	A/C	√	√	x	√	√	x	
BYD	M6	Body Control System	Multifunctional Screen	√	√	x	√	x	x	
BYD	M6	Body Control System	Park Pilot	√	√	x	√	x	x	
BYD	M6	Body Control System	Left Slide Door	√	√	x	√	√	x	
BYD	M6	Body Control System	Right Slide Door	√	√	x	√	√	√	
BYD	M6	Body Control System	Panoramic ECU	√	√	x	√	x	x	
BYD	M6	Body Control System	Gateway	√	√	x	√	√	x	
BYD	M6	Body Control System	Around View DSP	√	x	x	x	x	x	
BYD	M6	Immobilizer System	Immobilizer System	x	x	x	x	x	x	0019
BYD	L3	Engine System	M787 CAN Electronic Injection (UMC)	√	√	x	√	√	√	0001
BYD	L3	Engine System	Engine Controller 473DCT	√	√	x	√	√	√	0001
BYD	L3	Engine System	UAES M78_473QE System	√	√	x	√	√	√	
BYD	L3	Engine System	Engine Controller_473DCTSS	√	√	x	√	√	√	0001 00BF
BYD	L3	Engine System	BYD T1 Engine Management System	√	√	x	√	√	√	00C0
BYD	L3	Engine System	Delphi MT22 Engine System	√	√	x	√	√	√	007D
BYD	L3	Engine System	Engine Controller_473MTSS	√	√	x	√	√	√	0001
BYD	L3	Anti-lock Brake System	Delphi ABS System	√	√	x	√	√	√	00BA
BYD	L3	Anti-lock Brake System	BOSCH Anti-Lock Braking System (ABS8)	√	√	x	√	√	√	00BB
BYD	L3	Anti-lock Brake System	Bosch ABS (ABS9)	√	√	x	√	√	√	00BB
BYD	L3	Anti-lock Brake System	BWI ABS	√	√	x	√	√	√	00BA
BYD	L3	Supplementary Restraint System	SRS (CAN)	√	√	x	√	√	x	000E
BYD	L3	Automatic Transmission System	Transmission (Punch)	√	√	x	√	√	x	00C5 00D4 00D5
BYD	L3	Automatic Transmission System	BYD DCT Transmission Control System	√	√	x	√	√	√	000A
BYD	L3	Power Steering System	Power Steering System	√	√	x	√	x	x	000F 0010
BYD	L3	Body Control System	Instrument System	√	√	x	√	x	x	
BYD	L3	Body Control System	Steering Shaft Lock System	√	√	x	√	x	x	
BYD	L3	Body Control System	Parking Auxiliary System	√	√	x	√	x	x	
BYD	L3	Body Control System	Keyless System	√	√	x	√	√	x	
BYD	L3	Body Control System	Gateway	√	√	x	√	√	x	
BYD	L3	Body Control System	Customization	x	x	x	x	x	x	0011
BYD	L3	Body Control System	Body Control System	√	√	x	√	x	√	
BYD	L3	Immobilizer System	Immobilizer System	x	x	x	x	x	x	0019
BYD	K9A	Power module	Left Motor Controller	√	√	x	√	√	x	0005
BYD	K9A	Power module	Right Motor Controller	√	√	x	√	√	x	0005
BYD	K9A	Power module	24 V DC module	√	√	x	√	√	x	
BYD	K9A	Power module	Main Gateway Controller	√	√	x	√	x	x	
BYD	K9A	Power module	J1939 Gateway	√	√	x	√	x	x	
BYD	K9A	Power module	Traction Battery Manager	√	√	x	√	√	x	007D 00D6 00D7
BYD	K9A	Power module	Front Auxiliary Controller	√	√	x	√	√	x	
BYD	K9A	Power module	Rear Auxiliary Controller	√	√	x	√	√	x	
BYD	K9A	Power module	Air Compressor Controller	√	√	x	√	√	x	
BYD	K9A	Power module	Steering Motor Controller	√	√	x	√	√	x	
BYD	K9A	Power module	Electric water pump module	√	√	x	√	x	x	
BYD	K9A	Body Control System	Steering Shaft Lock System	√	√	x	√	x	x	
BYD	K9A	Body Control System	Body Control System	√	√	x	√	x	x	
BYD	K9A	Body Control System	Smart Key System	√	√	x	√	√	x	
BYD	K9A	Body Control System	Air Conditioning System	√	√	x	√	√	x	
BYD	K9A	Body Control System	Distribution Box	√	√	x	√	x	x	
BYD	K9A	Body Control System	Combination Instrument System	√	√	x	√	x	x	
BYD	K9A	Body Control System	On-board terminal module	√	√	x	√	√	x	
BYD	K9A	Immobilizer System	Immobilizer System	x	x	x	x	x	x	0019
BYD	K9B Dayun Model	Power module	Left Motor Controller	√	√	x	√	√	x	00D8 0005
BYD	K9B Dayun Model	Power module	Right Motor Controller	√	√	x	√	√	x	00D8 0005
BYD	K9B Dayun Model	Power module	24 V DC Module	√	√	x	√	√	x	
BYD	K9B Dayun Model	Power module	Solar Charger Module	√	√	x	√	√	x	
BYD	K9B Dayun Model	Power module	Traction Battery Manager	√	√	x	√	√	x	
BYD	K9B Dayun Model	Power module	Front Auxiliary Controller	√	√	x	√	√	x	
BYD	K9B Dayun Model	Power module	Rear Auxiliary Controller	√	√	x	√	√	x	
BYD	K9B Dayun Model	Power module	Air Compressor Controller 1	√	√	x	√	√	x	
BYD	K9B Dayun Model	Power module	Air Compressor Controller 2	√	√	x	√	√	x	
BYD	K9B Dayun Model	Power module	Air Compressor Controller 3	√	√	x	√	√	x	
BYD	K9B Dayun Model	Power module	Steering Motor Controller	√	√	x	√	√	x	
BYD	K9B Dayun Model	Power module	Gateway	√	√	x	√	x	x	
BYD	K9B Dayun Model	Power module	Electric Water Pump	√	√	x	√	x	x	
BYD	K9B Dayun Model	Body Control System	Steering Shaft Lock System	√	√	x	√	x	x	
BYD	K9B Dayun Model	Body Control System	Body Control System	√	√	x	√	x	x	
BYD	K9B Dayun Model	Body Control System	Smart Key System	√	√	x	√	√	x	
BYD	K9B Dayun Model	Body Control System	Air Conditioning System	√	√	x	√	√	x	
BYD	K9B Dayun Model	Body Control System	Distribution Box	√	√	x	√	x	x	
BYD	K9B Dayun Model	Body Control System	Combination Instrument System	√	√	x	√	x	x	
BYD	K9B Dayun Model	Immobilizer System	Immobilizer System	x	x	x	x	x	x	0019
BYD	K9 Electric Bus	Body Control System	Steering Shaft Lock System	√	√	x	√	x	x	
BYD	K9 Electric Bus	Body Control System	Body Control System	√	√	x	√	x	x	
BYD	K9 Electric Bus	Body Control System	Smart Key System	√	√	x	√	√	x	
BYD	K9 Electric Bus	Body Control System	Air Conditioning System	√	√	x	√	√	x	
BYD	K9 Electric Bus	Body Control System	Distribution Box	√	√	x	√	x	x	
BYD	K9 Electric Bus	Body Control System	Combination Instrument System	√	√	x	√	x	x	

BYD	K9	K9 Electric Bus	Immobilizer System	Immobilizer System	x	x	x	x	x	x	0019
BYD	Other	FLYER QCJ7081BD	Engine System	Flyer 7081BD UAES	x	√	x	√	√	√	
BYD	Other	FLYER QCJ7081BD	Anti-lock Brake System	BYD ABS	√	√	x	√	√	√	00BA
BYD	Other	FLYER QCJ7081BD	Supplementary Restraint System	BYD SRS	√	√	x	√	√	√	
BYD	Other	FLYER QCJ7081DD	Engine System	MATIZ Engine	√	√	x	√	√	x	
BYD	Other	FLYER QCJ7081DD	Anti-lock Brake System	BYD ABS	√	√	x	√	√	√	00BA
BYD	Other	FLYER QCJ7081DD	Supplementary Restraint System	BYD SRS	√	√	x	√	√	√	
BYD	Other	FLYER QCJ7110	Engine System	Delphi Engine System	√	√	x	√	√	√	
BYD	Other	FLYER QCJ7110	Anti-lock Brake System	BYD ABS	√	√	x	√	√	√	00BA
BYD	Other	FLYER QCJ7110	Supplementary Restraint System	BYD SRS	√	√	x	√	√	√	
BYD	Other	BOSCH M154 engine	Engine System	BOSCH M154 Engine System	√	√	x	√	√	√	

Special Function

Index	Special Function Name
0001	VIN self-learning
0002	Reset vacuum pump operation time
0003	Battery pack factory capacity calibration
0004	Battery pack actual capacity calibration
0005	Inclination sensor calibration
0006	Motor system configuration settings
0007	Reset accumulated average fuel consumption
0008	Factory battery pack calibration
0009	Actual battery pack calibration
000A	Adaptation
000B	Wheel bleeding
000C	Yaw rate sensor calibration
000D	SAS calibration
000E	ECU unlock
000F	Torque calibration
0010	Steering wheel angle calibration
0011	Customization
0012	System configuration type
0013	OCS calibration
0014	Manual pairing reset method.
0015	Tire pressure monitoring module registration
0016	Power column calibration
0017	One-Click Initialization
0018	ACM Calibration
0019	Security programming
001A	Gear action adaptation
001B	Clutch adaptation
001C	Grade sensor adaptation
001D	Transmission adaptation
001E	Angle calibration
001F	Warning lamp test
0020	Parking aid system configuration settings
0021	Writing PM2.5 base value test
0022	Left front wheel learning
0023	Right front wheel learning
0024	Left rear wheel learning
0025	Right rear wheel learning
0026	Driver seat calibration
0027	Accumulated average fuel consumption reset test
0028	Write vacuum pump time
0029	Cruise control (CC) calibration
002A	ACC calibration
002B	Gradient sensor calibration
002C	Steering angle zero calibration
002D	Torque zero calibration
002E	After-sales calibration
002F	Driving calibration service calibration (SDA)

0030	Write front axle standard pressure
0031	Write rear axle standard pressure
0032	Write continental pump operation time
0033	Reset the continental pump operation time
0034	Inclination EOL calibration
0035	One-button battery heating active test
0036	Zero calibration
0037	Cruise control configurations written
0038	Active cruise control (ACC) configuration written
0039	Write vacuum pump operation time
003A	Motor zero point calibration
003B	One-button battery heating active test closed
003C	Write left front wheel tire pressure monitoring module ID
003D	Write right front wheel tire pressure monitoring module ID
003E	Write left rear wheel tire pressure monitoring module ID
003F	Write right rear wheel tire pressure monitoring module ID
0040	Configuration calibration for 2018 model
0041	Configuration calibration for 2019 model
0042	Configuration calibration for 2020 model
0043	Clear model configuration
0044	Reset ecu
0045	Configuration calibration
0046	Write noble configuration
0047	Configuration erased
0048	Write luxury model and distinguished model configurations
0049	Write 2019 Luxury, Distinguished, and Distinguished 500 km configuration
004A	Write 2020 Distinguished 500 km configuration
004B	Initial dynamic calibration
004C	Disable dynamic calibration
004D	Static calibration
004E	Write 2020 HAZEF Distinguished configuration
004F	Tire pressure reset
0050	Wheel matching - old version
0051	Wheel matching - new version
0052	Write flagship configuration
0053	Oil level learning
0054	Gasoline Particulate Filter (GPF) active regeneration activation calibration
0055	Replace new Gasoline Particulate Filter (GPF)
0056	80 ternary battery pack
0057	60 ternary battery pack
0058	50 ternary battery pack
0059	Normalized angle acceleration pedal
005A	TCU calculation vehicle speed status
005B	CAN VSPEED
005C	Acceleration pedal position status
005D	Gasoline Particulate Filter (GPF) regeneration triggering calibration
005E	Write glory model and distinguished model configurations
005F	Write 2019 Glory configuration
0060	One kye adaptation
0061	Oil pump adaptation

0062	Main pressure valve adaptation
0063	Safety 1 valve adaptation
0064	Safety 2 valve adaptation
0065	Clutch valve 1 adaptation
0066	Clutch valve 2 adaptation
0067	Clutch 1 adaptation
0068	Clutch 2 adaptation
0069	Electronic fuel pump adaptation
006A	TCU measuring engine speed
006B	MC pressure value
006C	CAN engine spd
006D	CAN engine status
006E	Successful switch of standard diagnostic mode
006F	Brake pedal state
0070	Engine indication torque
0071	Engine torque loss
0072	Throttle position
0073	Battery voltage
0074	Gasoline Particulate Filter (GPF) replacement calibration
0075	Gasoline Particulate Filter (GPF) differential pressure sensor replacement calibration
0076	Forced balance active test
0077	One-touch battery cooling active test
0078	Reset ECU
0079	LS control switch disconnection status control: started
007A	LS control switch disconnection status control: result requested
007B	LS control switch disconnection status control: stopped
007C	LS control switch disconnection status control
007D	Read & write VIN code
007E	HDEF Distinguished configuration word writing
007F	HDEE Luxury configuration word writing
0080	HDEG Elite configuration word writing
0081	HDEM Standard configuration word writing
0082	Terminal line calibration
0083	Installation mode activation
0084	Stand mode calibration
0085	HDEG model configuration word writing
0086	Erase configuration word
0087	Write configuration word
0088	reset ecu
0089	Write Comfort, Luxury, and Distinguished
008A	SAS Calibration
008B	Steering wheel zero point calibration
008C	Write vehicle model configuration
008D	Check conditions
008E	Clear system fault data
008F	Learning value clearing
0090	Gear P sensor self-learning
0091	Gear R sensor self-learning
0092	Gear N sensor self-learning
0093	Gear D sensor self-learning

0094	Gear L sensor self-learning
0095	Wheel matching
0096	Write tire pressure monitoring module ID
0097	Headlamp adjustment
0098	Headlamp initialization
0099	Tang 100 three-cell battery pack calibration
009A	Tang 80 three-cell battery pack calibration
009B	Tang 80 iron battery pack calibration
009C	BSD static calibration
009D	BSD dynamic calibration
009E	Enter duty cycle
009F	Write honorable, honorable 20 inch configuration
00A0	Write elite configuration
00A1	Write flagship, honorable, honorable 20 inch
00A2	Write noble
00A3	Writing flagship model, honorable model and exclusive model configurations
00A4	Write Distinguished (LKS) configuration
00A5	Write flagship model and glory model configurations
00A6	100 ternary battery pack
00A7	Write honorable configuration
00A8	Write luxury configuration
00A9	Write comfort configuration
00AA	Write STFA Flagship
00AB	80 ternary battery pack calibration
00AC	60 ternary battery pack calibration
00AD	Write honor model configurations
00AE	Write luxury model
00AF	Temperature sensor in control unit
00B0	One-click initialization
00B1	Write EPB variant configuration
00B2	Steering wheel zero calibration
00B3	Radiator fan (stepless) speed percentage test
00B4	Slope calibration
00B5	The calibrated model is the comfort model
00B6	The calibrated model is the luxury model
00B7	The calibrated model is the premium model
00B8	The calibrated model is the standard model
00B9	The calibrated model is the shared model
00BA	Air Bleed Mode
00BB	Bleed Function
00BC	Personalize content
00BD	Restore default settings
00BE	EOL Test and After-Sale Self-Learning
00BF	Start/stop function and A/C correlation set
00C0	Self-Learning Erased
00C1	A/C associated settings
00C2	Offline check
00C3	Parking aid system configuration type settings
00C4	Return force calibration
00C5	System reset

00C6	Clearing gear self learn value
00C7	Clutch self-learning (adaptation)
00C8	Clutch 1 valve adaptation
00C9	Clutch 2 valve adaptation
00CA	Warning light function test
00CB	Detection Program Control Service
00CC	EOL Calibration
00CD	Write medium/high configuration
00CE	ECU reset
00CF	Vehicle model calibration
00D0	Inertial sensor calibration
00D1	Brake depth sensor calibration
00D2	Battery capacity calibration
00D3	Throttle position status
00D4	Clear gear self-learning
00D5	Clutch self-learning (adaptation learning)
00D6	Battery manager ID calibration
00D7	Battery box ID calibration
00D8	Inclination sensor reset