Special Function

index	Special Function	index	Special Function
0005	Programmable Module Installation	0098	Reset the Diesel Particulate Filter Learned Values
0006	Module Reprogramming	0099	Reset the Exhaust Gas Recirculation Valve Learned Values
0007	Programmable Parameters	009A	Reset the Intake Air Throttle Valve Learned Values
0008	ABS Service Bleed	009B	Reset / Clear Specified Function
0009	PATS Functions	009C	SCR Dosing Measurement Test
000A	Remote Keyless Entry	009D	SCR Parameter Reset
000B	G Sensor Calibration	009E	SCR System Emptying
000C	Passenger System Reset	009F	SCR System Refill Activation
000D	Neutral Position Setting	00A0	SCR Visual Leak Check
000E	Ride Height Calibration	00A1	System Prime
000F	Factory Keyless Entry Code	00A2	WIF Reset
0010	Stop Use of Transmission Adaptive	00A3	DPF Reset
0011	Power Seat Calibration	00A4	Enter the Fuel Injector Default Count Value
0012	IVD Initialization Sequence	00A5	Clutch Switch Learn
0013	Pneumatic Test	00A6	Engine Oil Quality History
0014	Accurate Trim Test	00A7	Fuel Injection Pump Learn
0015	Passenger Zero Seat Weight Test	00A8	Fuel Injector Pilot Correction Learn
0016	Microphone Test	00A9	Fuel System Leak Test

0017	Audio Speaker Walkaround Test	00AA	Initialize the Exhaust Gas Related Component.
0018	Infotainment Display Test	00AB	Reset Differential Pressure Sensor Learned Values
0019	Tones Test	00AC	Reset KAM
001A	TPMS Functions	00AD	Reset MAF Sensor Drift.
001B	Zero Speed Test	00AE	Reset MAF Sensor Offset.
001C	Rear Tones Test	00AF	Reset the air conditioning compressor learned
001D	Monotones Test	00B0	Reset the Diesel Particulate Filter Differential Pressure
001E	Sensor Initialization	00B1	Reset the Exhaust Gas Temperature Value
001F	EPB calibration.	00B2	Reset the Fuel Injection Pump Learned Values
0020	EATC Operation Check	00B3	Reset the Fuel Injector Learned Values
0021	Rain Sensor Reset	00B4	Reset the Fuel Metering Valve Learned Values
0022	LPSDM and RPSDM Service Function	00B5	Reset the Fuel Pressure Relief Valve Open Count Learned
0023	Power Balance	00B6	Reset the Fuel Pressure Relief Valve Open Duration Learned
0024	EVAP Test	00B7	Reset the Fuel Rail Pressure Sensor Learned Values
0025	Reset PCM KAM	00B8	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values
0026	OBDII Modes	00B9	Reset the Mass Air Flow Sensor Learned Values
0027	Clear Transmission Adaptive Learning	00BA	Reset the Neutral Gear Position Learned Value
0028	Clear Transmission Adaptive Tables	00BB	Reset the oil change indicator.
0029	Configure All Three Sensors Together.	00BC	Reset the Powertrain Control Module Learned Values
002A	Configure Both the Yaw Rate Sensor and the Lateral Acceleration	00BD	Reset the Turbocharger Learned Values.

002B	Configure the lateral acceleration sensor.	00BE	Reset the Turbocharger Variable Vane Actuator Learned Values
002C	Configure the pressure sensor.	00BF	Reset the Turbocharger Variable Vane Position Sensor Learned Values
002D	FFH SelfTest and Prefill Utility	00C0	Reset the Vehicle Speed Limit
002E	FFH Start Heater Utility	00C1	Reset the water in fuel Warning Indicator.
002F	FFH Unlock Utility	00C2	rpm Controller
0030	Auxiliary vehicle ID reset	00C3	Stop-Start Activation
0031	Halt Transmission Adaptive Learning	00C4	Speed Limiting
0032	Headlamp Alignment	00C5	TR Sensor Test
0033	Resume Transmission Adaptive Learning	00C6	Transmission Fluid Level Test
0034	Resume Transmission Adaptive Tables	00C7	Automatic Transmission PRNDL Display Test
0035	Keyfob Training	00C8	BSI Solenoid Test
0036	Transmission	00C9	Automatic Transmission Park Switch Test
0037	Transmission Learning	00CA	ABS reset and configuration.
0038	Transmission Solenoid Body IDN	00CB	PDC Reset
0039	VSM Service Functions	00CC	Steering Wheel Position Sensor Calibration
003A	A/C Test	00CD	Preliminary Checks
003B	ACM	00CE	Reset TCM KAM
003C	ACM Security Bypass Test	00CF	Fuel System Prime
003D	Air/Fuel Learning	00D0	Remote Start
003E	AM Antenna Reception Sensitivity Test	00D1	TBM SIM RAV_ID

003F	ASM Service Functions	00D2	Reset TBM Password
0040	audio configuration	00D3	TBM Transit Mode
0041	Auto Leveling Sensor Re-zero Procedure	00D4	CEI Lock Configuration
0042	Tire pressure monitoring system	00D5	BMS Reset
0043	BSM Radar Test	00D6	Navigation
0044	Button Test	00D7	Calibrate Steering Angle Sensor
0045	CAN Bus Fault Test	00D8	Configure the steering column assembly
0046	CCM Calibration	00D9	Configure the longitudinal acceleration sensor
0047	Clear EGR Adaptive Tables	00DA	Configure the intermediate shaft
0048	Clear Fuel Injector & HP Pump Adaptive Tables	00DB	Module Initialization
0050	Clearing of Learning Value	00DC	Pull Drift Compensation
0051	Component/Parameter Reset	00DD	Calibrate Longitudinal Acceleration Sensor
0053	Configure the steering angle sensor.	00DE	Inhibit longitudinal accelerometer monitoring
0054	Configure the yaw rate sensor.	00DF	Pull Drift Compensation enable/disable
0055	Data Reset	00E0	Straight Ahead Adaption Angle Reset
0056	DPF	00E1	Steering Rack Limiter Configuration
0057	DPF Component Parameter	00E2	Pressure Sensor Calibration
0058	DPF Manual Regeneration	00E3	Reset Pressure Sensor Offset
0059	DPF Parameter Reset	00E4	Enable/Disable hill launch assist
005A	Electronic Throttle Control	00E5	Camera Alignment

005B	EPS Steering Angle Calibration	00E6	Shift fork system learn.
005C	ETB/EGR Initialization	00E7	Reset the High Pressure Fuel System Learned Values
005D	FACM	00E8	BleedMASTER
005E	FFH Operation Check	00E9	FCDIM_Keycode_reset
005F	Gauge Test	00EA	EPB
0060	ICCM Aiming Adjustment	0101	Audio
0061	Illumination Test	0102	Battery saver
0062	Input and Data Test	0103	Body Type
0063	Interior Scan Test	0104	Courtesy Lamp
0064	Keyless Entry Keypad Code Reset	0105	Door Trigger Disable Mode
0065	Learning	0106	Body and Fuel Type
0066	Misfire Check	0107	Hazard Warning
0067	Misfire Monitor Neutral Profile Correction	0108	Horn Warning
0068	Module Identification	0109	Master Door Trigger Disable Mode
0069	Multifunction Output Test	010A	Panic Alarm
006A	Network Test	010B	Police Mode
006B	New FACM	010C	Traction control system
006C	Parking Aid Switch Test	010D	Autolamp Off Setting
006D	Passenger Seat Weight Sensor ReZero	010E	Autolamp On Setting
006E	Rebalance	010F	Police Speedometer Offset

006F	Reset the Knock Sensor Learned Values	0110	Cabin Temperature Sensor Calibration Factor
0070	Reset Transmission Tables	0111	Taxi Mode
0071	Resetting adaptive values	0112	Low Coolant Warning
0072	RVM Aiming	0113	Parking Brake Warning
0074	Service Routine	0114	Headlamp Delay Door Open
0075	Special Ignition ON	0115	Headlamp Delay Ignition Off
0076	Steering angle sensor calibration	0116	Headlamp Delay Remote Lock Pressed
0077	Supplemental Heater Test	0117	Dynamic Stability Control
0080	Mode 1 Powertrain Data	0118	Hill Descent Control LED
0081	Mode 6 On-Board Test Results	0119	Brake System Configuration
0082	Mode 8 - On-Board device control	011A	BPM fitted
0083	Mode 9 - Vehicle Information	011B	Camera fitted
0084	OBD Drive Cycle	011C	Audio Interface Module
0085	Service Functions	011D	Sonar fitted
0090	Diesel Particulate Filter Static Regeneration	011E	Navigation System
0091	DPF Regeneration Suspension	011F	Parking Aid Module
0092	Fuel Injector Correction Factors	0120	Odometer Write
0093	IQA	0121	Subwoofer
0094	Refill the FAT.	0122	Driver Beltminder Status
0095	Relearn Vehicle Data	0123	Alarm

0096	Reset Charge Air Cooler Bypass Valve Position Offset.	0124	Audio Configure
0097	Reset the Cooling Fan Motor Learned Values		

Function List

AutoMaker: Ford

NOTES:

√ This function is supported.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Special Function
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	4X4	√	√	√	√	○
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	ABS	√	√	√	√	8
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	GEM	√	√	√	√	000A 000F
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	IC	√	√	√	√	○
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	PAM	√	√	√	√	○
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	PCM	√	√	√	√	0009 0023 0025 00C5
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	RCM	√	√	√	√	000C
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	4X4	√	√	√	√	○
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	ABS	√	√	√	√	8
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	GEM	√	√	√	√	000A 000F
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	IC	√	√	√	√	5
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	PAM	√	√	√	√	○
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	PCM	√	√	√	√	0009 0023 0025 00C5
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	RCM	√	√	√	√	000C

626 / 626 WAGON / TELSTAR	1.8L	FP	1997 - 2000	PCM	√	√	√	√	0023 0025
626 / 626 WAGON / TELSTAR	1.8L	FP	1999	ABS	√	√	√	√	○
626 / 626 WAGON / TELSTAR	1.8L	FP	2000	ABS/TCS	√	√	√	√	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1997 - 1999	ABS	√	√	√	√	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1997 - 2001	PCM	√	√	√	√	0023 0025
626 / 626 WAGON / TELSTAR	2.0L	FS	1998 - 2001	ABS/TCS	√	√	√	√	○
626 / 626 WAGON / TELSTAR	2.0L	RF-T	1997 - 2000	PCM	√	√	√	√	○
626 / 626 WAGON / TELSTAR	2.0L	RF-T	1999 - 2000	ABS	√	√	√	√	○
626 / 626 WAGON / TELSTAR	2.5L	KL	1997 - 2001	PCM	√	√	√	√	0023 0025
626 / 626 WAGON / TELSTAR	2.5L	KL	1998 - 2001	ABS/TCS	√	√	√	√	○
AEROSTAR	3.0L	Other	1996 - 1997	PCM	√	√	√	√	0023 0025
AEROSTAR	4.0L	Other	1996 - 1997	PCM	√	√	√	√	0023 0025
Aspire	1.3L	Other	1996 - 1997	PCM	√	√	√	√	○
Aspire	1.5L	Other	1997	PCM	√	√	√	√	25
Aviator	4.6L	4V	2003	VEMS	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	4X4	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	ABS/TCS	√	√	√	√	0008 0012
Aviator	4.6L	4V	2003 - 2005	DCSM	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	DSM	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	EATC	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	IC	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	NAV	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	PAM	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033 00C6
Aviator	4.6L	4V	2003 - 2005	PCSM	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	RCM	√	√	√	√	000C
Aviator	4.6L	4V	2003 - 2005	TPM	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	VAPS	√	√	√	√	○
Aviator	4.6L	4V	2003 - 2005	VSM	√	√	√	√	000A 000F
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		ABS	√	√	√	○	00DB
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		ACM	√	√	√	○	○

B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		APIM	√	√	√	√	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		BCMii	√	√	√	√	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		DDM	√	√	√	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		FCDIM	√	√	√	√	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		FDSM	√	√	√	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		GPSM	√	√	√	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		GWM	√	√	√	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		HVAC	√	√	√	√	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		IPC	√	√	√	√	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		PCM	√	√	√	√	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		PDM	√	√	√	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		PSCM	√	√	√	○	00D7 00DC
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		RCM	√	√	√	○	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection		RFA	√	√	√	○	○
B-Max	1.25L	DURATEC 16V	2008	ABS	√	√	√	√	○
B-Max	1.25L	DURATEC 16V	2008	ACM	√	√	√	√	○
B-Max	1.25L	DURATEC 16V	2008	BCMii	√	√	√	√	○
B-Max	1.25L	DURATEC 16V	2008	FCDIM	√	√	√	√	○
B-Max	1.25L	DURATEC 16V	2008	HVAC	√	√	√	√	○
B-Max	1.25L	DURATEC 16V	2008	IPC	√	√	√	√	9
B-Max	1.25L	DURATEC 16V	2008	PCM	√	√	√	√	○
B-Max	1.25L	DURATEC 16V	2008	PSCM	√	√	√	√	○
B-Max	1.25L	DURATEC 16V	2008	RCM	√	√	√	√	○
B-Max	1.25L	DURATEC 16V	2008	RFA	√	√	√	√	○
B-Max	1.25L	DURATEC 16V	2008	SRM	√	√	√	√	○
B-Max	1.4L	DURATEC 16V		APIM	√	√	√	√	○
B-Max	1.4L	DURATEC 16V		DDM	√	√	√	○	○
B-Max	1.4L	DURATEC 16V		FDSM	√	√	√	○	○
B-Max	1.4L	DURATEC 16V		GPSM	√	√	√	○	○
B-Max	1.4L	DURATEC 16V		GWM	√	√	√	○	○
B-Max	1.4L	DURATEC 16V		PDM	√	√	√	○	○
B-Max	1.4L	DURATEC 16V	-2008	ABS	√	√	√	○	00DB
B-Max	1.4L	DURATEC 16V	-2008	ACM	√	√	√	○	○
B-Max	1.4L	DURATEC 16V	-2008	BCMii	√	√	√	√	○
B-Max	1.4L	DURATEC 16V	-2008	FCDIM	√	√	√	√	○
B-Max	1.4L	DURATEC 16V	-2008	HVAC	√	√	√	√	○
B-Max	1.4L	DURATEC 16V	-2008	IPC	√	√	√	√	9
B-Max	1.4L	DURATEC 16V	-2008	PCM	√	√	√	○	○
B-Max	1.4L	DURATEC 16V	-2008	PSCM	√	√	√	○	00D7 00DC
B-Max	1.4L	DURATEC 16V	-2008	RCM	√	√	√	○	○
B-Max	1.4L	DURATEC 16V	-2008	RFA	√	√	√	○	○
B-Max	1.4L	DURATEC 16V	2008	SRM	√	√	√	√	○
B-Max	1.4L	DURATEC 16V	2008	TCM	√	√	√	√	○
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	√	√	√	√	○
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	√	√	√	√	○
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	√	√	√	√	○
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	√	√	√	√	○
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	√	√	√	√	○
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	√	√	√	√	9
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	√	√	√	√	0099 009A 00B4 00BC 00C1
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	√	√	√	√	○
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	√	√	√	√	○

B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	√	√	√	√	○
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	√	√	√	√	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		ABS	√	√	√	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		ACM	√	√	√	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		APIM	√	√	√	√	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		BCMii	√	√	√	√	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		DDM	√	√	√	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		FCDIM	√	√	√	√	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		FDSM	√	√	√	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		GPSM	√	√	√	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		GWM	√	√	√	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		HVAC	√	√	√	√	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		IPC	√	√	√	√	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		PCM	√	√	√	√	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		PDM	√	√	√	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		PSCM	√	√	√	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		RCM	√	√	√	○	○
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection		RFA	√	√	√	○	○
B-Max	1.6L	DURATEC VCT		APIM	√	√	√	√	○
B-Max	1.6L	DURATEC VCT		DDM	√	√	√	○	○
B-Max	1.6L	DURATEC VCT		FDSM	√	√	√	○	○
B-Max	1.6L	DURATEC VCT		GPSM	√	√	√	○	○
B-Max	1.6L	DURATEC VCT		GWM	√	√	√	○	○
B-Max	1.6L	DURATEC VCT		PDM	√	√	√	○	○
B-Max	1.6L	DURATEC VCT		TCM	√	√	√	√	○
B-Max	1.6L	DURATEC VCT	-2008	ABS	√	√	√	○	00DB
B-Max	1.6L	DURATEC VCT	-2008	ACM	√	√	√	○	○
B-Max	1.6L	DURATEC VCT	-2008	BCMii	√	√	√	√	○
B-Max	1.6L	DURATEC VCT	-2008	FCDIM	√	√	√	√	○
B-Max	1.6L	DURATEC VCT	-2008	HVAC	√	√	√	√	○
B-Max	1.6L	DURATEC VCT	-2008	IPC	√	√	√	√	9
B-Max	1.6L	DURATEC VCT	-2008	PCM	√	√	√	○	○
B-Max	1.6L	DURATEC VCT	-2008	PSCM	√	√	√	○	00D7 00DC
B-Max	1.6L	DURATEC VCT	-2008	RCM	√	√	√	○	○
B-Max	1.6L	DURATEC VCT	-2008	RFA	√	√	√	○	○
B-Max	1.6L	DURATEC VCT	2008	SRM	√	√	√	√	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	√	√	√	√	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	√	√	√	√	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	√	√	√	√	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	√	√	√	√	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	√	√	√	√	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	√	√	√	√	9
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	√	√	√	√	0090 0092 0098 0099 00AA 00B0 00B1
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	√	√	√	√	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	√	√	√	√	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	√	√	√	√	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	√	√	√	√	○
B-Max	1.6L	TDCi ECO II		ABS	√	√	√	○	○
B-Max	1.6L	TDCi ECO II		ACM	√	√	√	○	○
B-Max	1.6L	TDCi ECO II		APIM	√	√	√	√	○
B-Max	1.6L	TDCi ECO II		BCMii	√	√	√	√	○
B-Max	1.6L	TDCi ECO II		DDM	√	√	√	○	○
B-Max	1.6L	TDCi ECO II		FCDIM	√	√	√	√	○
B-Max	1.6L	TDCi ECO II		FDSM	√	√	√	○	○
B-Max	1.6L	TDCi ECO II		GPSM	√	√	√	○	○
B-Max	1.6L	TDCi ECO II		GWM	√	√	√	○	○
B-Max	1.6L	TDCi ECO II		HVAC	√	√	√	√	○
B-Max	1.6L	TDCi ECO II		IPC	√	√	√	√	○

B-Max	1.6L	TDCi ECO II		PCM	√	√	√	√	○
B-Max	1.6L	TDCi ECO II		PDM	√	√	√	○	○
B-Max	1.6L	TDCi ECO II		PSCM	√	√	√	○	○
B-Max	1.6L	TDCi ECO II		RCM	√	√	√	○	○
B-Max	1.6L	TDCi ECO II		RFA	√	√	√	○	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	1996 - Other	PCM	√	√	√	√	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	2001	PCM	√	√	√	√	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	2001 - 2002	ABS	√	√	√	√	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2001 - 2005	ABS	√	√	√	√	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2001 - 2005	PCM	√	√	√	√	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	1996 - 1999	PCM	√	√	√	√	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	1999	ABS	√	√	√	√	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.9L	W9	2002	ABS	√	√	√	√	○
BBCV	6.8L	3V	2012	PCM	√	√	√	√	0023 0025
BONGO / BONGO BRAWNY / SPECTRON	1.8L	F8	1999	ABS	√	√	√	√	○
BONGO / BONGO BRAWNY / SPECTRON	1.8L	F8	1999 - 2002	PCM	√	√	√	√	○
BONGO / BONGO BRAWNY / SPECTRON	1.8L	F8	2002	ABS/TCS	√	√	√	√	○
BONGO / BONGO BRAWNY / SPECTRON	1.8L	F8	2002	TCM	√	√	√	√	○

BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2010	ABS	√	√	√	√	○
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2010	IC	√	√	√	○	○
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2010	PCM	√	√	√	√	○
BONGO / BONGO BRAWNY / SPECTRON	1.8L	L8	2010	TCM	√	√	√	√	○
BONGO / BONGO BRAWNY / SPECTRON	2.0L	RF-T	2003 - 2007	ABS/TCS	√	√	√	√	○
BONGO / BONGO BRAWNY / SPECTRON	2.0L	RF-T	2003 - 2007	PCM	√	√	√	√	○
BONGO / BONGO BRAWNY / SPECTRON	2.0L	RF-T	2003 - 2007	TCM	√	√	√	√	○
BONGO / BONGO BRAWNY / SPECTRON	2.2L	R2	1999	ABS	√	√	√	√	○
BONGO / BONGO BRAWNY / SPECTRON	2.2L	R2	1999	PCM	√	√	√	√	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	1.8L	F8	1999	ABS	√	√	√	√	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	1.8L	F8	1999	PCM	√	√	√	√	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1997 - 1999	ABS	√	√	√	√	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1997 - 2002	PCM	√	√	√	√	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	2002	ABS/TCS	√	√	√	√	○

BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	2002	TCM	√	√	√	√	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.2L	R2	1999	ABS	√	√	√	√	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.2L	R2	1999	PCM	√	√	√	√	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.5L	WL	1999	ABS	√	√	√	√	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.5L	WL	1999	PCM	√	√	√	√	○
BT-50 / Ranger	2.2L	F2	2007	ABS/TCS	√	√	√	√	○
BT-50 / Ranger	2.2L	F2	2007	PCM	√	√	√	√	○
BT-50 / Ranger	2.2L	F2	2007	RCM	√	√	√	√	○
BT-50 / Ranger	2.5L	L5	2012	ABS	√	√	√	√	○
BT-50 / Ranger	2.5L	L5	2012	PCM	√	√	√	○	○
BT-50 / Ranger	2.5L	WL	2007	ABS/TCS	√	√	√	√	○
BT-50 / Ranger	2.5L	WL	2007	PCM	√	√	√	√	○
BT-50 / Ranger	2.5L	WL	2007	RCM	√	√	√	√	○
BT-50 / Ranger	2.5L	WL-CD	2007	ABS/TCS	√	√	√	√	○
BT-50 / Ranger	2.5L	WL-CD	2007	PCM	√	√	√	√	○
BT-50 / Ranger	2.5L	WL-CD	2007	RCM	√	√	√	√	○
BT-50 / Ranger	2.5L	WL-CD	2007	TCM	√	√	√	√	○
BT-50 / Ranger	2.6L	G6	2007	ABS/TCS	√	√	√	√	○
BT-50 / Ranger	2.6L	G6	2007	PCM	√	√	√	√	○
BT-50 / Ranger	2.6L	G6	2007	RCM	√	√	√	√	○
BT-50 / Ranger	3.0L	WE-CD	2007	ABS/TCS	√	√	√	√	○
BT-50 / Ranger	3.0L	WE-CD	2007	PCM	√	√	√	√	○
BT-50 / Ranger	3.0L	WE-CD	2007	RCM	√	√	√	√	○
BT-50 / Ranger	3.0L	WE-CD	2007	TCM	√	√	√	√	○
BT-50 / Ranger	4.0L	V6 SOHC	2007	ABS/TCS	√	√	√	√	8
BT-50 / Ranger	4.0L	V6 SOHC	2007	ESOF	√	√	√	√	○
BT-50 / Ranger	4.0L	V6 SOHC	2007	PCM	√	√	√	√	23
BT-50 / Ranger	4.0L	V6 SOHC	2007	RCM	√	√	√	√	○
Bantam	1.3L	Zetec Rocam	2001 - 2006	PCM	√	√	√	√	9
Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	2009	IC	√	√	√	○	○
Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	2009	PCM	√	√	√	√	9
Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	2009	RCM	√	√	√	√	○
Bantam	1.6L	Zetec Rocam	2001 - 2006	PCM	√	√	√	√	9
Blackwood	5.4L	4V	2002 - 2003	ABS/TCS	√	√	√	√	8

Blackwood	5.4L	4V	2002 - 2003	DSM	√	√	√	√	○
Blackwood	5.4L	4V	2002 - 2003	EATC	√	√	√	√	○
Blackwood	5.4L	4V	2002 - 2003	GEM	√	√	√	√	○
Blackwood	5.4L	4V	2002 - 2003	HEC	√	√	√	√	9
Blackwood	5.4L	4V	2002 - 2003	LTM	√	√	√	√	○
Blackwood	5.4L	4V	2002 - 2003	PAM	√	√	√	√	○
Blackwood	5.4L	4V	2002 - 2003	PCM	√	√	√	√	0023 0025
Blackwood	5.4L	4V	2002 - 2003	RAP	√	√	√	√	000A 000F
Blackwood	5.4L	4V	2002 - 2003	RASM	√	√	√	√	○
Blackwood	5.4L	4V	2002 - 2003	RCM	√	√	√	√	○
Bronco	5.0L	Other	1996	PCM	√	√	√	√	0023 0025
Bronco	5.8L	Other	1996	PCM	√	√	√	√	0023 0025
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR W	1.8L	FP	1997 - 1999	PCM	√	√	√	√	○
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR W	1.8L	FP	1999	ABS	√	√	√	√	○
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR W	2.0L	FS	1997 - 1999	PCM	√	√	√	√	○
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR W	2.0L	FS	1999	ABS	√	√	√	√	○
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR W	2.0L	RF	1997	PCM	√	√	√	√	○
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR W	2.5L	KL	1999	ABS	√	√	√	√	○
CF/LCF	4.5L	Direct Injection - Turbo	2006 - 2009	ABS	√	√	√	√	8
CF/LCF	4.5L	Direct Injection - Turbo	2006 - 2009	TCM	√	√	√	√	○
Cargo	7.3L	ECOTORQ	2004	PCM	√	√	√	√	○
Cargo	Other	ISBe	2009 - 2012	TBM	√	√	√	√	○
Cargo	Other	ISBe	2012	HEC	√	√	√	○	○
Cargo	Other	ISBe	2012	RKE	√	√	√	√	○
Cargo	Other	ISCe	2009 - 2012	TBM	√	√	√	√	○
Cargo	Other	ISCe	2012	HEC	√	√	√	○	○
Cargo	Other	ISCe	2012	RKE	√	√	√	√	○
Cargo	Other	Mechanical	2009 - 2012	TBM	√	√	√	√	○
Cargo	Other	Mechanical	2012	HEC	√	√	√	○	○
Cargo	Other	Mechanical	2012	RKE	√	√	√	√	○
Continental	4.6L	4V	1995 - 2002	ABS/TCS	√	√	√	√	8
Continental	4.6L	4V	1995 - 2002	ACM	√	√	√	√	○
Continental	4.6L	4V	1995 - 2002	CPM	√	√	√	√	○
Continental	4.6L	4V	1995 - 2002	DDM	√	√	√	√	000F 000A

Continental	4.6L	4V	1995 - 2002	DSM	√	√	√	√	○
Continental	4.6L	4V	1995 - 2002	EATC	√	√	√	√	○
Continental	4.6L	4V	1995 - 2002	LCM	√	√	√	√	○
Continental	4.6L	4V	1995 - 2002	PCM	√	√	√	√	0023 0025
Continental	4.6L	4V	1995 - 2002	VDM	√	√	√	√	○
Continental	4.6L	4V	1995 - 2002	VIC	√	√	√	√	9
Continental	4.6L	4V	1996 - 1997	IAB	√	√	√	√	○
Continental	4.6L	4V	1996 - 2000	RESCU	√	√	√	√	○
Continental	4.6L	4V	1998	ECS	√	√	√	√	○
Continental	4.6L	4V	1998 - 2002	NGSC	√	√	√	√	○
Continental	4.6L	4V	1999 - 2002	RCM	√	√	√	√	○
Contour	2.0L	GFP	1996 - 2000	ABS/TCS	√	√	√	√	8
Contour	2.0L	GFP	1996 - 2000	PCM	√	√	√	√	0023 0025 0009
Contour	2.0L	GFP	1998	PATS	√	√	√	√	9
Contour	2.0L	GFP	1998 - 2000	CSM	√	√	√	√	○
Contour	2.0L	GFP	1999 - 2000	RCM	√	√	√	√	○
Contour	2.0L	Zetec	1996 - 2000	ABS/TCS	√	√	√	√	8
Contour	2.0L	Zetec	1996 - 2000	PCM	√	√	√	√	0023 0025 0009
Contour	2.0L	Zetec	1998	PATS	√	√	√	√	9
Contour	2.0L	Zetec	1998 - 2000	CSM	√	√	√	√	○
Contour	2.0L	Zetec	1999 - 2000	RCM	√	√	√	√	○
Contour	2.5L	Duratec-VE	1996 - 2000	ABS/TCS	√	√	√	√	8
Contour	2.5L	Duratec-VE	1996 - 2000	PCM	√	√	√	√	0023 0025 0009
Contour	2.5L	Duratec-VE	1998	PATS	√	√	√	√	9
Contour	2.5L	Duratec-VE	1998 - 2000	CSM	√	√	√	√	○
Contour	2.5L	Duratec-VE	1999 - 2000	RCM	√	√	√	√	○
Contour	2.5L	HO	1998	PATS	√	√	√	√	9
Contour	2.5L	HO	1998 - 2000	ABS/TCS	√	√	√	√	8
Contour	2.5L	HO	1998 - 2000	CSM	√	√	√	√	○
Contour	2.5L	HO	1998 - 2000	PCM	√	√	√	√	9
Contour	2.5L	HO	1999 - 2000	RCM	√	√	√	√	○
Cougar	2.0L	Zetec	1998 - 2002	ABS/TCS	√	√	√	√	8
Cougar	2.0L	Zetec	1998 - 2002	CSM	√	√	√	√	○
Cougar	2.0L	Zetec	1998 - 2002	HEC	√	√	√	√	○
Cougar	2.0L	Zetec	1998 - 2002	IAB	√	√	√	√	○
Cougar	2.0L	Zetec	1998 - 2002	PCM	√	√	√	√	0023 0025 0009
Cougar	2.5L	Duratec-VE	1998 - 2002	ABS/TCS	√	√	√	√	8
Cougar	2.5L	Duratec-VE	1998 - 2002	CSM	√	√	√	√	○
Cougar	2.5L	Duratec-VE	1998 - 2002	HEC	√	√	√	√	○
Cougar	2.5L	Duratec-VE	1998 - 2002	IAB	√	√	√	√	○
Cougar	2.5L	Duratec-VE	1998 - 2002	PCM	√	√	√	√	0023 0025 0009
Cougar	2.5L	Duratec-VE	2001	ABS	√	√	√	√	○
Cougar	2.5L	Duratec-VE	2001	IC	√	√	√	√	○
Cougar	2.5L	Duratec-VE	2001	MC	√	√	√	√	○
Cougar	2.5L	Duratec-VE	2001	REM	√	√	√	√	○
Cougar	3.8L	Other	1996 - 1997	ABS/TCS	√	√	√	√	○
Cougar	3.8L	Other	1996 - 1997	HEC	√	√	√	√	○
Cougar	3.8L	Other	1996 - 1997	PCM	√	√	√	√	0023 0025
Cougar	4.6L	2V	1994 - 1997	ABS/TCS	√	√	√	√	○
Cougar	4.6L	2V	1994 - 1997	HEC	√	√	√	√	○

Cougar	4.6L	2V	1994 - 1997	PCM	√	√	√	√	0023 0025
Crown Victoria	4.6L	2V	1995 - 1997	DSM	√	√	√	√	○
Crown Victoria	4.6L	2V	1995 - 2004	ABS/TCS	√	√	√	√	8
Crown Victoria	4.6L	2V	1995 - 2007	EATC	√	√	√	√	○
Crown Victoria	4.6L	2V	1995 - 2011	DDM	√	√	√	√	000F 000A 0042 0005
Crown Victoria	4.6L	2V	1995 - 2011	LCM	√	√	√	√	○
Crown Victoria	4.6L	2V	1995 - 2011	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033 0009
Crown Victoria	4.6L	2V	1996 - 1997	IAB	√	√	√	√	○
Crown Victoria	4.6L	2V	1998 - 2000	ECS	√	√	√	√	○
Crown Victoria	4.6L	2V	1998 - 2002	PATS	√	√	√	√	9
Crown Victoria	4.6L	2V	2000 - 2011	RCM	√	√	√	√	000C
Crown Victoria	4.6L	2V	2003 - 2006	RASM	√	√	√	√	13
Crown Victoria	4.6L	2V	2003 - 2006	VAPS	√	√	√	√	○
Crown Victoria	4.6L	2V	2004 - 2010	MC	√	√	√	√	○
Crown Victoria	4.6L	2V	2005 - 2011	ABS	√	√	√	√	8
Crown Victoria	4.6L	2V	2005 - 2011	FSSM	√	√	√	√	○
Crown Victoria	4.6L	2V	2006 - 2011	IC	√	√	√	√	5
Crown Victoria	4.6L	2V	2007 - 2011	VDM	√	√	√	√	5
Crown Victoria	4.6L	2V	2008 - 2011	HVAC	√	√	√	√	○
Crown Victoria	4.6L	2V_NGV	1996 - 1997	DSM	√	√	√	√	○
Crown Victoria	4.6L	2V_NGV	1996 - 1997	IAB	√	√	√	√	○
Crown Victoria	4.6L	2V_NGV	1996 - 2000	ABS/TCS	√	√	√	√	8
Crown Victoria	4.6L	2V_NGV	1996 - 2000	DDM	√	√	√	√	000F 000A
Crown Victoria	4.6L	2V_NGV	1996 - 2000	FIM	√	√	√	√	○
Crown Victoria	4.6L	2V_NGV	1996 - 2000	LCM	√	√	√	√	○
Crown Victoria	4.6L	2V_NGV	1996 - 2000	PCM	√	√	√	√	0023 0010 0028 0031 0033
Crown Victoria	4.6L	2V_NGV	1998 - 2000	EATC	√	√	√	√	○
Crown Victoria	4.6L	2V_NGV	1998 - 2000	ECS	√	√	√	√	○
Crown Victoria	4.6L	2V_NGV	1998 - 2000	PATS	√	√	√	√	9
Crown Victoria	4.6L	2V_NGV	2000	RCM	√	√	√	√	○
Crown Victoria	4.6L	Other	1995	ABS/TCS	√	√	√	√	8
Crown Victoria	4.6L	Other	1995	PCM	√	√	√	√	0023 0025
DEMIO / FESTIVA MINI WAGON	1.3L	B3	1996 - 1999	ABS	√	√	√	√	○
DEMIO / FESTIVA MINI WAGON	1.3L	B3	1996 - Other	PCM	√	√	√	√	○
DEMIO / FESTIVA MINI WAGON	1.3L	B3	2000	ABS/TCS	√	√	√	√	○
DEMIO / FESTIVA MINI WAGON	1.5L	B5	1996 - 1999	ABS	√	√	√	√	○
E-Series	4.2L	Other	1997 - 2003	ABS/TCS	√	√	√	√	8
E-Series	4.2L	Other	1997 - 2003	ECS	√	√	√	√	○

E-Series	4.2L	Other	1997 - 2003	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
E-Series	4.6L	2V	2003	ECS	√	√	√	√	○
E-Series	4.6L	2V	2003 - 2007	ABS/TCS	√	√	√	√	0008 001B
E-Series	4.6L	2V	2003 - 2013	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
E-Series	4.6L	2V	2004 - 2006	RAP	√	√	√	√	000A 000F
E-Series	4.6L	2V	2004 - 2008	IC	√	√	√	√	0005 0009
E-Series	4.6L	2V	2004 - 2013	RCM	√	√	√	√	○
E-Series	4.6L	2V	2006 - 2013	ABS	√	√	√	√	0008 0012
E-Series	4.6L	2V	2007 - 2008	VSM	√	√	√	√	000A 0042
E-Series	4.6L	2V	2007 - 2013	PAM	√	√	√	√	○
E-Series	4.6L	2V	2009 - 2011	GEM / SJB	√	√	√	√	000A 0042
E-Series	4.6L	2V	2009 - 2013	ACM	√	√	√	√	0017 0018
E-Series	4.6L	2V	2009 - 2013	IPC	√	√	√	√	○
E-Series	4.6L	2V	2009 - 2013	TBC	√	√	√	√	○
E-Series	4.6L	2V	2010 - 2013	APIM	√	√	√	√	19
E-Series	4.6L	2V	2010 - 2013	GPSM	√	√	√	○	○
E-Series	4.6L	2V	2010 - 2013	SDARS	√	√	√	√	○
E-Series	4.6L	Other	1997 - 2002	ABS/TCS	√	√	√	√	8
E-Series	4.6L	Other	1997 - 2002	ECS	√	√	√	√	○
E-Series	4.6L	Other	1997 - 2002	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
E-Series	4.9L	GFP	1996	ABS/TCS	√	√	√	√	8
E-Series	4.9L	GFP	1996	PCM	√	√	√	√	23
E-Series	4.9L	Other	1996	ABS/TCS	√	√	√	√	8
E-Series	4.9L	Other	1996	PCM	√	√	√	√	0023 0025
E-Series	5.0L	Other	1996	ABS/TCS	√	√	√	√	8
E-Series	5.0L	Other	1996	PCM	√	√	√	√	0023 0025
E-Series	5.4L	2V	2004	AFCM	√	√	√	√	○
E-Series	5.4L	2V	2004 - 2006	RAP	√	√	√	√	000A 000F
E-Series	5.4L	2V	2004 - 2007	ABS/TCS	√	√	√	√	0008 001B
E-Series	5.4L	2V	2004 - 2008	IC	√	√	√	√	0005 0009
E-Series	5.4L	2V	2004 - 2013	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
E-Series	5.4L	2V	2004 - 2013	RCM	√	√	√	√	5
E-Series	5.4L	2V	2006 - 2013	ABS	√	√	√	√	0008 0012
E-Series	5.4L	2V	2007 - 2008	VSM	√	√	√	√	000A 0042
E-Series	5.4L	2V	2007 - 2013	PAM	√	√	√	√	○
E-Series	5.4L	2V	2009 - 2012	GEM / SJB	√	√	√	√	000A 0042
E-Series	5.4L	2V	2009 - 2013	ACM	√	√	√	√	○
E-Series	5.4L	2V	2009 - 2013	IPC	√	√	√	√	○
E-Series	5.4L	2V	2009 - 2013	TBC	√	√	√	√	○
E-Series	5.4L	2V	2010 - 2013	APIM	√	√	√	√	○
E-Series	5.4L	2V	2010 - 2013	GPSM	√	√	√	○	○
E-Series	5.4L	2V	2010 - 2013	SDARS	√	√	√	√	○
E-Series	5.4L	BIF	1999	ABS/TCS	√	√	√	√	8
E-Series	5.4L	BIF	1999	AFCM	√	√	√	√	○
E-Series	5.4L	BIF	1999	ECS	√	√	√	√	○

E-Series	5.4L	BIF	1999	PCM	√	√	√	√	23
E-Series	5.4L	NGV	1997 - 2000	ABS/TCS	√	√	√	√	8
E-Series	5.4L	NGV	1997 - 2000	ECS	√	√	√	√	○
E-Series	5.4L	NGV	1997 - 2000	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
E-Series	5.4L	NGV	1998 - 2000	FIM	√	√	√	√	○
E-Series	5.4L	Other	1997 - 2003	ABS/TCS	√	√	√	√	8
E-Series	5.4L	Other	1997 - 2003	ECS	√	√	√	√	○
E-Series	5.4L	Other	1997 - 2003	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
E-Series	5.8L	Other	1996	ABS/TCS	√	√	√	√	8
E-Series	5.8L	Other	1996	PCM	√	√	√	√	0023 0025
E-Series	6.0L	Direct Injection - Turbo	2004 - 2006	RAP	√	√	√	√	000A 000F
E-Series	6.0L	Direct Injection - Turbo	2004 - 2007	ABS/TCS	√	√	√	√	0008 001B
E-Series	6.0L	Direct Injection - Turbo	2004 - 2008	IC	√	√	√	√	0005 0009
E-Series	6.0L	Direct Injection - Turbo	2004 - 2010	PCM	√	√	√	√	○
E-Series	6.0L	Direct Injection - Turbo	2004 - 2010	RCM	√	√	√	√	○
E-Series	6.0L	Direct Injection - Turbo	2004 - 2010	TCM	√	√	√	√	○
E-Series	6.0L	Direct Injection - Turbo	2006 - 2010	ABS	√	√	√	√	0008 0012 0005
E-Series	6.0L	Direct Injection - Turbo	2007 - 2008	VSM	√	√	√	√	000A 0042
E-Series	6.0L	Direct Injection - Turbo	2007 - 2010	PAM	√	√	√	√	○
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	ACM	√	√	√	√	○
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	GEM / SJB	√	√	√	√	000A 0042
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	IPC	√	√	√	√	○
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	TBC	√	√	√	√	○
E-Series	6.0L	Direct Injection - Turbo	2010	APIM	√	√	√	√	○
E-Series	6.0L	Direct Injection - Turbo	2010	GPSM	√	√	√	○	○
E-Series	6.0L	Direct Injection - Turbo	2010	SDARS	√	√	√	√	○
E-Series	6.8L	2V	2004 - 2006	RAP	√	√	√	√	000A 000F
E-Series	6.8L	2V	2004 - 2007	ABS/TCS	√	√	√	√	0008 001B
E-Series	6.8L	2V	2004 - 2008	IC	√	√	√	√	9
E-Series	6.8L	2V	2004 - 2012	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
E-Series	6.8L	2V	2004 - 2012	RCM	√	√	√	√	○
E-Series	6.8L	2V	2006 - 2012	ABS	√	√	√	√	0008 0012 0005
E-Series	6.8L	2V	2007 - 2008	VSM	√	√	√	√	000A 0042
E-Series	6.8L	2V	2007 - 2012	PAM	√	√	√	√	○
E-Series	6.8L	2V	2009 - 2012	ACM	√	√	√	√	0017 0018
E-Series	6.8L	2V	2009 - 2012	GEM / SJB	√	√	√	√	000A 0042
E-Series	6.8L	2V	2009 - 2012	IPC	√	√	√	√	○
E-Series	6.8L	2V	2009 - 2012	TBC	√	√	√	√	○
E-Series	6.8L	2V	2010 - 2012	APIM	√	√	√	√	19
E-Series	6.8L	2V	2010 - 2012	GPSM	√	√	√	○	○
E-Series	6.8L	2V	2010 - 2012	SDARS	√	√	√	√	○
E-Series	6.8L	Other	1997 - 2003	ABS/TCS	√	√	√	√	8
E-Series	6.8L	Other	1997 - 2003	ECS	√	√	√	√	○

E-Series	6.8L	Other	1997 - 2003	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
E-Series	7.3L	Direct Injection - Turbo	1995 - 2003	ABS/TCS	√	√	√	√	8
E-Series	7.3L	Direct Injection - Turbo	1995 - 2003	PCM	√	√	√	√	0025 0010 0028 0031 0033
E-Series	7.3L	Direct Injection - Turbo	1997 - 2003	ECS	√	√	√	√	○
E-Series	7.5L	Other	1996	ABS/TCS	√	√	√	√	8
E-Series	7.5L	Other	1996	PCM	√	√	√	√	0023 0025
E-Series	Other	Other	2012	ABS	√	√	√	√	○
E-Series	Other	Other	2012	ACM	√	√	√	√	○
E-Series	Other	Other	2012	APIM	√	√	√	√	○
E-Series	Other	Other	2012	GEM / SJB	√	√	√	√	42
E-Series	Other	Other	2012	GPSM	√	√	√	√	○
E-Series	Other	Other	2012	IPC	√	√	√	√	○
E-Series	Other	Other	2012	PAM	√	√	√	√	○
E-Series	Other	Other	2012	PCM	√	√	√	√	○
E-Series	Other	Other	2012	RCM	√	√	√	√	○
E-Series	Other	Other	2012	SDARS	√	√	√	√	○
E-Series	Other	Other	2012	TBC	√	√	√	√	○
E-Series Shuttle Bus	6.8L	H2ICE	2006	ABS/TCS	√	√	√	√	○
E-Series Shuttle Bus	6.8L	H2ICE	2006	AFCM	√	√	√	√	○
E-Series Shuttle Bus	6.8L	H2ICE	2006	EMM	√	√	√	√	○
E-Series Shuttle Bus	6.8L	H2ICE	2006	IC	√	√	√	√	○
E-Series Shuttle Bus	6.8L	H2ICE	2006	PCM	√	√	√	√	23
E-Series Shuttle Bus	6.8L	H2ICE	2006	RCM	√	√	√	√	○
EcoSport	1.0L	Zetec Rocam	2003	ABS/TCS	√	√	√	√	0008 000B
EcoSport	1.0L	Zetec Rocam	2003	GEM	√	√	√	√	○
EcoSport	1.0L	Zetec Rocam	2003	IC	√	√	√	√	○
EcoSport	1.0L	Zetec Rocam	2003	PCM	√	√	√	√	0009 0025
EcoSport	1.0L	Zetec Rocam	2003	RCM	√	√	√	√	○
EcoSport	1.0L	Zetec Rocam	2003	RKE	√	√	√	√	○
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	ABS/TCS	√	√	√	√	0008 000B
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	GEM	√	√	√	√	○
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	IC	√	√	√	√	○
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	PCM	√	√	√	√	9
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	RCM	√	√	√	√	○
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	RKE	√	√	√	√	○
EcoSport	1.5L	TiVCT	2012	ABS	√	√	√	√	○
EcoSport	1.5L	TiVCT	2012	ACM	√	√	√	○	○
EcoSport	1.5L	TiVCT	2012	APIM	√	√	√	√	○
EcoSport	1.5L	TiVCT	2012	BCM#1	√	√	√	√	000A
EcoSport	1.5L	TiVCT	2012	DDM	√	√	√	○	○
EcoSport	1.5L	TiVCT	2012	FCDIM	√	√	√	√	○
EcoSport	1.5L	TiVCT	2012	HVAC	√	√	√	√	○
EcoSport	1.5L	TiVCT	2012	IPC	√	√	√	√	○
EcoSport	1.5L	TiVCT	2012	PCM	√	√	√	√	25
EcoSport	1.5L	TiVCT	2012	PSCM	√	√	√	○	00CB 00CC
EcoSport	1.5L	TiVCT	2012	RCM	√	√	√	○	○
EcoSport	1.5L	TiVCT	2012	TCM	√	√	√	√	○
EcoSport	1.6L	FFV	2003 - 2006	GEM	√	√	√	√	○
EcoSport	1.6L	FFV	2003 - 2011	ABS/TCS	√	√	√	√	0008 000B
EcoSport	1.6L	FFV	2003 - 2011	IC	√	√	√	√	○
EcoSport	1.6L	FFV	2003 - 2011	PCM	√	√	√	√	0009 0025
EcoSport	1.6L	FFV	2003 - 2011	RCM	√	√	√	√	○
EcoSport	1.6L	FFV	2003 - 2011	RKE	√	√	√	√	000A
EcoSport	1.6L	FFV	2011	TBM	√	√	√	√	○

EcoSport	1.6L	Sigma	2012	ABS	√	√	√	√	○
EcoSport	1.6L	Sigma	2012	ACM	√	√	√	√	○
EcoSport	1.6L	Sigma	2012	APIM	√	√	√	√	○
EcoSport	1.6L	Sigma	2012	BCM#1	√	√	√	√	000A
EcoSport	1.6L	Sigma	2012	DDM	√	√	√	○	○
EcoSport	1.6L	Sigma	2012	FCDIM	√	√	√	√	○
EcoSport	1.6L	Sigma	2012	HVAC	√	√	√	√	○
EcoSport	1.6L	Sigma	2012	IPC	√	√	√	√	○
EcoSport	1.6L	Sigma	2012	PCM	√	√	√	√	25
EcoSport	1.6L	Sigma	2012	PSCM	√	√	√	○	00CB 00CC
EcoSport	1.6L	Sigma	2012	RCM	√	√	√	○	○
EcoSport	1.6L	Sigma	2012	RFA	√	√	√	○	○
EcoSport	1.6L	Sigma	2012	TBM	√	√	√	√	○
EcoSport	1.6L	Zetec Rocam	2003	GEM	√	√	√	√	○
EcoSport	1.6L	Zetec Rocam	2003 - 2009	ABS/TCS	√	√	√	√	0008 000B
EcoSport	1.6L	Zetec Rocam	2003 - 2009	IC	√	√	√	√	○
EcoSport	1.6L	Zetec Rocam	2003 - 2009	PCM	√	√	√	√	0009 0025
EcoSport	1.6L	Zetec Rocam	2003 - 2009	RCM	√	√	√	√	○
EcoSport	1.6L	Zetec Rocam	2003 - 2009	RKE	√	√	√	√	000A
EcoSport	2.0L	DURATEC-HE / I4	2003 - 2006	GEM	√	√	√	√	○
EcoSport	2.0L	DURATEC-HE / I4	2003 - 2007	ABS/TCS	√	√	√	√	0008 000B
EcoSport	2.0L	DURATEC-HE / I4	2003 - 2007	IC	√	√	√	√	○
EcoSport	2.0L	DURATEC-HE / I4	2003 - 2007	RKE	√	√	√	√	000A
EcoSport	2.0L	DURATEC-HE / I4	2003 - 2012	PCM	√	√	√	√	0009 0025 0023
EcoSport	2.0L	DURATEC-HE / I4	2003 - 2012	RCM	√	√	√	√	○
EcoSport	2.0L	DURATEC-HE / I4	2012	ABS	√	√	√	√	○
EcoSport	2.0L	DURATEC-HE / I4	2012	ACM	√	√	√	√	○
EcoSport	2.0L	DURATEC-HE / I4	2012	APIM	√	√	√	√	○
EcoSport	2.0L	DURATEC-HE / I4	2012	BCM#1	√	√	√	√	000A
EcoSport	2.0L	DURATEC-HE / I4	2012	DDM	√	√	√	○	○
EcoSport	2.0L	DURATEC-HE / I4	2012	FCDIM	√	√	√	√	○
EcoSport	2.0L	DURATEC-HE / I4	2012	HVAC	√	√	√	√	○
EcoSport	2.0L	DURATEC-HE / I4	2012	IPC	√	√	√	√	○
EcoSport	2.0L	DURATEC-HE / I4	2012	PSCM	√	√	√	○	00CB 00CC
EcoSport	2.0L	DURATEC-HE / I4	2012	RFA	√	√	√	○	○
EcoSport	2.0L	DURATEC-HE / I4	2012	TBM	√	√	√	√	○
EcoSport	2.0L	FFV	2009 - 2011	ABS/TCS	√	√	√	√	0008 000B
EcoSport	2.0L	FFV	2009 - 2011	IC	√	√	√	√	○
EcoSport	2.0L	FFV	2009 - 2011	PCM	√	√	√	√	0009 0025 00C5
EcoSport	2.0L	FFV	2009 - 2011	RCM	√	√	√	√	○
EcoSport	2.0L	FFV	2009 - 2011	RKE	√	√	√	√	000A
EcoSport	2.0L	FFV	2011	TBM	√	√	√	√	○
EcoSport	2.0L	Zetec Rocam	2009	ABS/TCS	√	√	√	√	○
EcoSport	2.0L	Zetec Rocam	2009	IC	√	√	√	√	○
EcoSport	2.0L	Zetec Rocam	2009	PCM	√	√	√	√	0009 0025
EcoSport	2.0L	Zetec Rocam	2009	RCM	√	√	√	√	○
EcoSport	2.0L	Zetec Rocam	2009	RKE	√	√	√	√	000A
EcoSport	Other	Other	2012	IPC	√	√	√	√	○
EcoSport	Other	Other	2012	PSCM	√	√	√	○	○
EcoSport	Other	Other	2012	RCM	√	√	√	○	○
Econovan	2.0L	OHC	2008	IC	√	√	√	√	○
Econovan	2.0L	OHC	2008	PCM	√	√	√	√	23
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	TPM	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	ABS	√	√	√	√	0008 0012
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	ACM	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	APIM	√	√	√	○	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	BCM#1	√	√	√	√	000F 0042 000A
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	C-CM	√	√	√	○	○

Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	DCSM	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	DSM	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	DSP	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	FCDIM	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	FCIM	√	√	√	○	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	FLM	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	GPSM	√	√	√	○	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	HUD	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	HVAC	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	IPC	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	LTM	√	√	√	○	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	OCSM	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	PAM	√	√	√	○	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	PCM	√	√	√	√	0023 0025
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	RCM	√	√	√	○	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	RFA	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	RLCM-A	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	SCCM	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	SOD-L	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	SOD-R	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	TBM	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	TCM	√	√	√	√	○
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	√	○	○
Edge	3.5L	4V	2007	EATC	√	√	√	√	○
Edge	3.5L	4V	2007	GEM	√	√	√	√	000A 000F
Edge	3.5L	4V	2007 - 2010	4X4	√	√	√	√	○
Edge	3.5L	4V	2007 - 2010	ABS	√	√	√	√	0012 0008 0005
Edge	3.5L	4V	2007 - 2010	ACM	√	√	√	√	0016 0017 0018 0019 0005
Edge	3.5L	4V	2007 - 2010	DSM	√	√	√	√	5
Edge	3.5L	4V	2007 - 2010	IC	√	√	√	√	0009 0005
Edge	3.5L	4V	2007 - 2010	OCSM	√	√	√	○	000C 0015
Edge	3.5L	4V	2007 - 2010	PAM	√	√	√	√	5
Edge	3.5L	4V	2007 - 2010	PCM	√	√	√	√	0025 0010 0023 0028 0031 0033 00C5

Edge	3.5L	4V	2007 - 2010	RCM	√	√	√	√	5
Edge	3.5L	4V	2007 - 2010	RETM	√	√	√	√	○
Edge	3.5L	4V	2007 - 2010	SASM	√	√	√	√	○
Edge	3.5L	4V	2007 - 2010	SDARS	√	√	√	√	0019 0005
Edge	3.5L	4V	2007 - 2010	TBM	√	√	√	√	00D1 00D2 00D3
Edge	3.5L	4V	2008 - 2010	APIM	√	√	√	√	001C
Edge	3.5L	4V	2008 - 2010	GEM / SJB	√	√	√	√	000A 000F 0042
Edge	3.5L	4V	2008 - 2010	HVAC	√	√	√	√	○
Edge	3.5L	4V	2008 - 2010	LTM	√	√	√	√	○
Edge	3.5L	4V	2010	GPSM	√	√	√	○	○
Edge	3.5L	TiVCT	2011 - 2012	TPM	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	ABS	√	√	√	√	0012 0008
Edge	3.5L	TiVCT	2011 - 2013	ACM	√	√	√	○	○
Edge	3.5L	TiVCT	2011 - 2013	APIM	√	√	√	○	○
Edge	3.5L	TiVCT	2011 - 2013	BCM#1	√	√	√	√	000A 000F 0042
Edge	3.5L	TiVCT	2011 - 2013	C-CM	√	√	√	○	○
Edge	3.5L	TiVCT	2011 - 2013	DCSM	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	DSM	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	DSP	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	FCDIM	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	FCIM	√	√	√	○	○
Edge	3.5L	TiVCT	2011 - 2013	FLM	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	GPSM	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	HUD	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	HVAC	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	IPC	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	LTM	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	OCSM	√	√	√	√	000C 0015
Edge	3.5L	TiVCT	2011 - 2013	PAM	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	PCM	√	√	√	√	0025 0010 0023 0028 0031 0033
Edge	3.5L	TiVCT	2011 - 2013	RCM	√	√	√	○	○
Edge	3.5L	TiVCT	2011 - 2013	RFA	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	RLCM-A	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	SCCM	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	SOD-L	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	SOD-R	√	√	√	√	○
Edge	3.5L	TiVCT	2011 - 2013	TBM	√	√	√	√	○
Edge	3.5L	TiVCT	2013	RTM	√	√	√	○	○
Edge	3.7L	TiVCT	2011 - 2012	TPM	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	ABS	√	√	√	√	0012 0008
Edge	3.7L	TiVCT	2011 - 2013	ACM	√	√	√	○	○
Edge	3.7L	TiVCT	2011 - 2013	APIM	√	√	√	○	○
Edge	3.7L	TiVCT	2011 - 2013	BCM#1	√	√	√	√	000A 000F 0042
Edge	3.7L	TiVCT	2011 - 2013	C-CM	√	√	√	○	○
Edge	3.7L	TiVCT	2011 - 2013	DCSM	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	DSM	√	√	√	√	○

Edge	3.7L	TiVCT	2011 - 2013	DSP	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	FCDIM	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	FCIM	√	√	√	○	○
Edge	3.7L	TiVCT	2011 - 2013	FLM	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	GPSM	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	HUD	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	HVAC	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	IPC	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	LTM	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	OCSM	√	√	√	√	000C 0015
Edge	3.7L	TiVCT	2011 - 2013	PAM	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	PCM	√	√	√	√	0025 0010 0023 0028 0031 0033
Edge	3.7L	TiVCT	2011 - 2013	RCM	√	√	√	○	○
Edge	3.7L	TiVCT	2011 - 2013	RFA	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	RLCM-A	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	SCCM	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	SOD-L	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	SOD-R	√	√	√	√	○
Edge	3.7L	TiVCT	2011 - 2013	TBM	√	√	√	√	○
Edge	3.7L	TiVCT	2013	RTM	√	√	√	○	○
Escape / Marine Hybrid	2.3L	HEV / ATKINSON 4V	2005 - 2007	4X4	√	√	√	√	○
Escape / Marine Hybrid	2.3L	HEV / ATKINSON 4V	2005 - 2007	ABS	√	√	√	√	12
Escape / Marine Hybrid	2.3L	HEV / ATKINSON 4V	2005 - 2007	BCM	√	√	√	√	○
Escape / Marine Hybrid	2.3L	HEV / ATKINSON 4V	2005 - 2007	EPS	√	√	√	√	○
Escape / Marine Hybrid	2.3L	HEV / ATKINSON 4V	2005 - 2007	GEM	√	√	√	√	000A 000F
Escape / Marine Hybrid	2.3L	HEV / ATKINSON 4V	2005 - 2007	IC	√	√	√	√	○
Escape / Marine Hybrid	2.3L	HEV / ATKINSON 4V	2005 - 2007	PAM	√	√	√	√	○
Escape / Marine Hybrid	2.3L	HEV / ATKINSON 4V	2005 - 2007	PCM	√	√	√	√	0023 0025 0009 00C5
Escape / Marine Hybrid	2.3L	HEV / ATKINSON 4V	2005 - 2007	RCM	√	√	√	√	000C
Escape / Marine Hybrid	2.3L	HEV / ATKINSON 4V	2005 - 2007	TCM	√	√	√	√	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006	ABS	√	√	√	√	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006	GEM	√	√	√	√	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006	IC	√	√	√	√	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006	PCM	√	√	√	√	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006	RCM	√	√	√	√	○
Escape / Tribute (2006/3)	2.3L	L3	2003	ABS	√	√	√	√	○
Escape / Tribute (2006/3)	2.3L	L3	2003	GEM	√	√	√	√	○
Escape / Tribute (2006/3)	2.3L	L3	2003	IC	√	√	√	√	○

Escape / Tribute (2006/3)	2.3L	L3	2003	PCM	√	√	√	√	○
Escape / Tribute (2006/3)	2.3L	L3	2003	RCM	√	√	√	√	○
Escape / Tribute / Maverick	2.0L	Zetec	2001 - 2004	ABS/TCS	√	√	√	√	8
Escape / Tribute / Maverick	2.0L	Zetec	2001 - 2004	GEM	√	√	√	√	000A
Escape / Tribute / Maverick	2.0L	Zetec	2001 - 2004	IC	√	√	√	√	○
Escape / Tribute / Maverick	2.0L	Zetec	2001 - 2004	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Escape / Tribute / Maverick	2.0L	Zetec	2001 - 2004	RCM	√	√	√	√	○
Escape / Tribute / Maverick	2.0L	Zetec	2003 - 2004	PAM	√	√	√	√	○
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	4X4	√	√	√	√	○
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	ABS	√	√	√	√	8
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	GEM	√	√	√	√	000A 000F
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	IC	√	√	√	√	○
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	PAM	√	√	√	√	○
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033 00C5
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	RCM	√	√	√	√	000C
Escape / Tribute / Maverick	3.0L	4V	2001 - 2004	ABS/TCS	√	√	√	√	8
Escape / Tribute / Maverick	3.0L	4V	2001 - 2007	GEM	√	√	√	√	000A 000F
Escape / Tribute / Maverick	3.0L	4V	2001 - 2007	IC	√	√	√	√	5
Escape / Tribute / Maverick	3.0L	4V	2001 - 2007	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033 00C5
Escape / Tribute / Maverick	3.0L	4V	2001 - 2007	RCM	√	√	√	√	000C
Escape / Tribute / Maverick	3.0L	4V	2003 - 2007	PAM	√	√	√	√	○
Escape / Tribute / Maverick	3.0L	4V	2006 - 2007	4X4	√	√	√	√	○
Escape / Tribute / Maverick	3.0L	4V	2006 - 2007	ABS	√	√	√	√	0005 0008
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	√	√	√	√	12
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	√	√	√	√	○

Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HVAC	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-B	√	√	√	○	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	√	√	○	○	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	√	√	√	√	0023 0025
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PDM	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	√	√	√	○	00CB 00CC
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	√	√	√	○	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RFA	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RGTM	√	√	√	○	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SASM	√	√	√	○	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	√	√	√	√	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	TRM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	√	√	√	√	12
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HVAC	√	√	√	√	○

Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-B	√	√	√	○	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	√	√	○	○	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	√	√	√	√	0023 0025
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PDM	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	√	√	√	○	00CB 00CC
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	√	√	√	○	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RFA	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RGTM	√	√	√	○	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SASM	√	√	√	○	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	√	√	√	√	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	TRM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	ABS	√	√	√	√	12
Escape/Kuga	2.5L	IVCT	2013	ACM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	APIM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	BCM#1	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	DDM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	DSM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	DSP	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	FCDIM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	FCIM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	GPSM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	HCM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	HVAC	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	IPC	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	IPM-B	√	√	√	○	○
Escape/Kuga	2.5L	IVCT	2013	OCSM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	PAM	√	√	○	○	○
Escape/Kuga	2.5L	IVCT	2013	PCM	√	√	√	√	0023 0025
Escape/Kuga	2.5L	IVCT	2013	PDM	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	PSCM	√	√	√	○	00CB 00CC
Escape/Kuga	2.5L	IVCT	2013	RCM	√	√	√	○	○
Escape/Kuga	2.5L	IVCT	2013	RFA	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	RGTM	√	√	√	○	○
Escape/Kuga	2.5L	IVCT	2013	SASM	√	√	√	○	○
Escape/Kuga	2.5L	IVCT	2013	SOD-L	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	SOD-R	√	√	√	√	○
Escape/Kuga	2.5L	IVCT	2013	TRM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	4X4	√	√	√	√	○

Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	ABS	√	√	√	√	0005 0008 0012
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	ACM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	FCIM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	FDIM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	GEM / SJB	√	√	√	√	000A 000F 0042
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	HVAC	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	IC	√	√	√	√	0005 0009
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	OCSM	√	√	√	○	000C
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	PAM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	PSCM	√	√	○	○	0005 0053
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	RCM	√	√	√	√	5
Escape_/ Tribute / Mariner	2.3L	DURATEC-HE / I4	2008	SDARS	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	4X4	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	ABS	√	√	√	√	0005 0012
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	ACM	√	√	√	√	5
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	BCM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	FCIM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	FDIM	√	√	√	√	5
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	GEM / SJB	√	√	√	√	000A 000F 0042
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	HVAC	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	IC	√	√	√	√	0005 0009
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	OCSM	√	√	√	○	000C
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	PAM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C5
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	PSCM	√	√	○	○	0005 0053
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	RCM	√	√	√	√	5
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	SDARS	√	√	√	√	○
Escape_/ Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008	TCM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009	SDARS	√	√	√	√	○

Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	4X4	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	ABS	√	√	√	√	12
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	ACM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	APIM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	FCIM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	FDIM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	HVAC	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	IC	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	OCSM	√	√	√	○	000C
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	PAM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	PCM	√	√	√	√	25
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	PSCM	√	√	○	○	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	RCM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 - 2012	GPSM	√	√	√	○	○
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009	SDARS	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	4X4	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	ABS	√	√	√	√	5
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	ACM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	APIM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	BCM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	FCIM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	FDIM	√	√	√	√	5
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	HVAC	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	IC	√	√	√	√	0009 0005
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	OCSM	√	√	√	○	000C
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	PAM	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	PSCM	√	√	○	○	0053 0005 00CC
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	RCM	√	√	√	√	5
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	TCM	√	√	√	√	○

Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 - 2012	ACCM#2	√	√	√	√	○
Escape_/ Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 - 2012	GPSM	√	√	√	○	○
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2009	SDARS	√	√	√	√	0005 0019
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	4X4	√	√	√	√	○
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	ABS	√	√	√	√	0005 0008 0012
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	ACM	√	√	√	√	0017 0018
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	FCIM	√	√	√	√	○
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	FDIM	√	√	√	√	5
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	HVAC	√	√	√	√	5
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	IC	√	√	√	√	0009 0005
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	OCSM	√	√	√	○	000C
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	PAM	√	√	√	√	○
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 0009 00C5
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	PSCM	√	√	○	○	0005 0053
Escape_/ Tribute / Mariner	3.0L	4V	2008 - 2012	RCM	√	√	√	√	5
Escape_/ Tribute / Mariner	3.0L	4V	2009 - 2012	APIM	√	√	√	√	001C
Escape_/ Tribute / Mariner	3.0L	4V	2010 - 2012	GPSM	√	√	√	○	○
Escape_/ Tribute / Mariner	Other	Other	2012	4X4	√	√	√	√	○
Escape_/ Tribute / Mariner	Other	Other	2012	ABS	√	√	√	√	○
Escape_/ Tribute / Mariner	Other	Other	2012	ACM	√	√	√	○	○
Escape_/ Tribute / Mariner	Other	Other	2012	APIM	√	√	√	○	○
Escape_/ Tribute / Mariner	Other	Other	2012	FCIM	√	√	√	√	○
Escape_/ Tribute / Mariner	Other	Other	2012	FDIM	√	√	√	√	○
Escape_/ Tribute / Mariner	Other	Other	2012	GEM / SJB	√	√	√	√	42
Escape_/ Tribute / Mariner	Other	Other	2012	GPSM	√	√	√	√	○
Escape_/ Tribute / Mariner	Other	Other	2012	HVAC	√	√	√	√	○
Escape_/ Tribute / Mariner	Other	Other	2012	IC	√	√	√	√	○
Escape_/ Tribute / Mariner	Other	Other	2012	OCSM	√	√	√	○	○
Escape_/ Tribute / Mariner	Other	Other	2012	PAM	√	√	√	○	○
Escape_/ Tribute / Mariner	Other	Other	2012	PSCM	√	√	○	○	○

Escape_/ Tribute / Mariner	Other	Other	2012	RCM	√	√	√	√	○
Escort	1.3L	Endura-E	1995 - 1998	ABS	√	√	√	√	○
Escort	1.3L	Endura-E	1995 - 1998	ABS/TCS	√	√	√	√	○
Escort	1.3L	Endura-E	1995 - 1998	CSM	√	√	√	√	○
Escort	1.3L	Endura-E	1995 - 1998	HEC	√	√	√	√	○
Escort	1.3L	Endura-E	1995 - 1998	PATS	√	√	√	√	○
Escort	1.3L	Endura-E	1995 - 1998	PCM	√	√	√	√	0023 0025
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	ABS/TCS	√	√	√	√	○
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	CSM	√	√	√	√	○
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	HEC	√	√	√	√	○
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	PATS	√	√	√	√	○
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	PCM	√	√	√	√	○
Escort	1.4L	1.4 PT-E SFI	1995 - 1998	ABS	√	√	√	√	○
Escort	1.6L	PT-E	Other	ABS/TCS	√	√	√	√	○
Escort	1.6L	PT-E	Other	CSM	√	√	√	√	○
Escort	1.6L	PT-E	Other	HEC	√	√	√	√	○
Escort	1.6L	PT-E	Other	PATS	√	√	√	√	○
Escort	1.6L	PT-E	Other	PCM	√	√	√	√	○
Escort	1.6L	Zetec	1993 - 1997	PCM	√	√	√	√	25
Escort	1.6L	Zetec	1993 - 1998	ABS/TCS	√	√	√	√	○
Escort	1.6L	Zetec	1993 - 1998	CSM	√	√	√	√	○
Escort	1.6L	Zetec	1993 - 1998	HEC	√	√	√	√	○
Escort	1.6L	Zetec	1993 - 1998	PATS	√	√	√	√	○
Escort	1.6L	Zetec	1995 - 1998	ABS	√	√	√	√	○
Escort	1.6L	Zetec Rocam	2000	ABS/TCS	√	√	√	√	○
Escort	1.6L	Zetec Rocam	2000	CSM	√	√	√	√	○
Escort	1.6L	Zetec Rocam	2000	HEC	√	√	√	√	○
Escort	1.6L	Zetec Rocam	2000	PATS	√	√	√	√	○
Escort	1.6L	Zetec Rocam	2000	PCM	√	√	√	√	0023 0025
Escort	1.8L	Endura-DE	1996 - Other	ABS/TCS	√	√	√	√	○
Escort	1.8L	Endura-DE	1996 - Other	CSM	√	√	√	√	○
Escort	1.8L	Endura-DE	1996 - Other	HEC	√	√	√	√	○
Escort	1.8L	Endura-DE	1996 - Other	PATS	√	√	√	√	○
Escort	1.8L	Endura-DE	1996 - Other	PCM	√	√	√	√	○
Escort	1.8L	Endura-DE	1997	ABS	√	√	√	√	○
Escort	1.8L	Other	1996	ABS/TCS	√	√	√	√	○
Escort	1.8L	Other	1996	CSM	√	√	√	√	○
Escort	1.8L	Other	1996	HEC	√	√	√	√	○
Escort	1.8L	Other	1996	PATS	√	√	√	√	○
Escort	1.8L	Other	1996	PCM	√	√	√	√	○
Escort	1.8L	Zetec	1992 - 1996	PCM	√	√	√	√	25
Escort	1.8L	Zetec	1992 - 1998	ABS/TCS	√	√	√	√	○
Escort	1.8L	Zetec	1992 - 1998	CSM	√	√	√	√	○
Escort	1.8L	Zetec	1992 - 1998	HEC	√	√	√	√	○
Escort	1.8L	Zetec	1992 - 1998	PATS	√	√	√	√	○
Escort	1.8L	Zetec	1995 - 1998	ABS	√	√	√	√	○
Escort	1.9L	Other	1996	ABS/TCS	√	√	√	√	○
Escort	1.9L	Other	1996	PATS	√	√	√	√	○
Escort	1.9L	Other	1996	PCM	√	√	√	√	0023 0025
Escort	2.0L	DOHC Cosworth	1994 - 1995	ABS/TCS	√	√	√	√	○
Escort	2.0L	DOHC Cosworth	1994 - 1995	PATS	√	√	√	√	○
Escort	2.0L	DOHC Cosworth	1994 - 1995	PCM	√	√	√	√	○
Escort	2.0L	DOHC Cosworth	1995	ABS	√	√	√	√	○
Escort	2.0L	SPI	1997 - 2002	ABS/TCS	√	√	√	√	8
Escort	2.0L	SPI	1997 - 2002	PATS	√	√	√	√	○
Escort	2.0L	SPI	1997 - 2002	PCM	√	√	√	√	0023 0025

Escort	2.0L	SPI	1997 - 2002	RAP	√	√	√	√	000A
Escort	2.0L	SPI	1998 - 1999	ABS	√	√	√	√	8
Escort	2.0L	SPI	1998 - 2002	ECS	√	√	√	√	○
Escort	2.0L	Zetec	1998 - 1999	ABS	√	√	√	√	8
Escort	2.0L	Zetec	1998 - 2003	ABS/TCS	√	√	√	√	8
Escort	2.0L	Zetec	1998 - 2003	ECS	√	√	√	√	○
Escort	2.0L	Zetec	1998 - 2003	PATS	√	√	√	√	○
Escort	2.0L	Zetec	1998 - 2003	PCM	√	√	√	√	0023 0025
Escort	2.0L	Zetec	1998 - 2003	RAP	√	√	√	√	000A
Everest / Endeavour	2.5L	WL-CD	2007	ABS/TCS	√	√	√	√	○
Everest / Endeavour	2.5L	WL-CD	2007	PCM	√	√	√	√	○
Everest / Endeavour	2.5L	WL-CD	2007	RCM	√	√	√	√	○
Everest / Endeavour	2.5L	WL-CD	2007	TCM	√	√	√	√	○
Everest / Endeavour	2.6L	G6	2007	ABS/TCS	√	√	√	√	○
Everest / Endeavour	2.6L	G6	2007	PCM	√	√	√	√	○
Everest / Endeavour	2.6L	G6	2007	RCM	√	√	√	√	○
Everest / Endeavour	3.0L	WE-CD	2007	ABS/TCS	√	√	√	√	○
Everest / Endeavour	3.0L	WE-CD	2007	PCM	√	√	√	√	○
Everest / Endeavour	3.0L	WE-CD	2007	RCM	√	√	√	√	○
Everest / Endeavour	3.0L	WE-CD	2007	TCM	√	√	√	√	○
Excursion	5.4L	2V	2004	ECS	√	√	√	√	○
Excursion	5.4L	2V	2004 - 2005	ABS/TCS	√	√	√	√	8
Excursion	5.4L	2V	2004 - 2005	DSM	√	√	√	√	○
Excursion	5.4L	2V	2004 - 2005	EATC	√	√	√	√	○
Excursion	5.4L	2V	2004 - 2005	GEM	√	√	√	√	○
Excursion	5.4L	2V	2004 - 2005	HEC	√	√	√	√	○
Excursion	5.4L	2V	2004 - 2005	OTC	√	√	√	√	○
Excursion	5.4L	2V	2004 - 2005	PAM	√	√	√	√	○
Excursion	5.4L	2V	2004 - 2005	PATS	√	√	√	√	9
Excursion	5.4L	2V	2004 - 2005	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
Excursion	5.4L	2V	2004 - 2005	VSM	√	√	√	√	000A 000F
Excursion	5.4L	2V	2005	RCM	√	√	√	√	○
Excursion	5.4L	Other	2000	MC	√	√	√	√	○
Excursion	5.4L	Other	2000 - 2003	ABS/TCS	√	√	√	√	8
Excursion	5.4L	Other	2000 - 2003	ECS	√	√	√	√	○
Excursion	5.4L	Other	2000 - 2003	GEM	√	√	√	√	000F
Excursion	5.4L	Other	2000 - 2003	PAM	√	√	√	√	○
Excursion	5.4L	Other	2000 - 2003	PATS	√	√	√	√	9
Excursion	5.4L	Other	2000 - 2003	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
Excursion	5.4L	Other	2002	CSM	√	√	√	√	000A 000F

Excursion	5.4L	Other	2002 - 2003	DSM	√	√	√	√	○
Excursion	5.4L	Other	2002 - 2003	EATC	√	√	√	√	○
Excursion	5.4L	Other	2002 - 2003	HEC	√	√	√	√	○
Excursion	5.4L	Other	2002 - 2003	OTC	√	√	√	√	○
Excursion	5.4L	Other	2003	FOH	√	√	√	√	○
Excursion	5.4L	Other	2003	VSM	√	√	√	√	000A 000F
Excursion	6.0L	Direct Injection - Turbo	2003	FOH	√	√	√	√	○
Excursion	6.0L	Direct Injection - Turbo	2003 - 2004	ECS	√	√	√	√	○
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	ABS/TCS	√	√	√	√	8
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	DSM	√	√	√	√	○
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	EATC	√	√	√	√	○
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	GEM	√	√	√	√	○
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	HEC	√	√	√	√	○
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	OTC	√	√	√	√	○
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	PAM	√	√	√	√	○
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	PATS	√	√	√	√	9
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	TCM	√	√	√	√	○
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	VSM	√	√	√	√	000A 000F
Excursion	6.0L	Direct Injection - Turbo	2005	RCM	√	√	√	√	○
Excursion	6.8L	2V	2004	ECS	√	√	√	√	○
Excursion	6.8L	2V	2004 - 2005	ABS/TCS	√	√	√	√	8
Excursion	6.8L	2V	2004 - 2005	DSM	√	√	√	√	○
Excursion	6.8L	2V	2004 - 2005	EATC	√	√	√	√	○
Excursion	6.8L	2V	2004 - 2005	GEM	√	√	√	√	○
Excursion	6.8L	2V	2004 - 2005	HEC	√	√	√	√	○
Excursion	6.8L	2V	2004 - 2005	OTC	√	√	√	√	○
Excursion	6.8L	2V	2004 - 2005	PAM	√	√	√	√	○
Excursion	6.8L	2V	2004 - 2005	PATS	√	√	√	√	9
Excursion	6.8L	2V	2004 - 2005	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
Excursion	6.8L	2V	2004 - 2005	VSM	√	√	√	√	000A 000F
Excursion	6.8L	2V	2005	RCM	√	√	√	√	○
Excursion	6.8L	Other	2000	MC	√	√	√	√	○
Excursion	6.8L	Other	2000 - 2003	ABS/TCS	√	√	√	√	8
Excursion	6.8L	Other	2000 - 2003	ECS	√	√	√	√	○
Excursion	6.8L	Other	2000 - 2003	GEM	√	√	√	√	000F
Excursion	6.8L	Other	2000 - 2003	PAM	√	√	√	√	○
Excursion	6.8L	Other	2000 - 2003	PATS	√	√	√	√	9
Excursion	6.8L	Other	2000 - 2003	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
Excursion	6.8L	Other	2002	CSM	√	√	√	√	000A 000F
Excursion	6.8L	Other	2002 - 2003	DSM	√	√	√	√	○
Excursion	6.8L	Other	2002 - 2003	EATC	√	√	√	√	○
Excursion	6.8L	Other	2002 - 2003	HEC	√	√	√	√	○

Excursion	6.8L	Other	2002 - 2003	OTC	√	√	√	√	○
Excursion	6.8L	Other	2003	FOH	√	√	√	√	○
Excursion	6.8L	Other	2003	VSM	√	√	√	√	000A 000F
Excursion	7.3L	Direct Injection - Turbo	2000	MC	√	√	√	√	○
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	ABS/TCS	√	√	√	√	8
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	ECS	√	√	√	√	○
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	GEM	√	√	√	√	000F
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	PAM	√	√	√	√	○
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	PATS	√	√	√	√	9
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	PCM	√	√	√	√	0010 0025 0028 0031 0033
Excursion	7.3L	Direct Injection - Turbo	2002	CSM	√	√	√	√	000A 000F
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	DSM	√	√	√	√	○
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	EATC	√	√	√	√	○
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	HEC	√	√	√	√	○
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	OTC	√	√	√	√	○
Excursion	7.3L	Direct Injection - Turbo	2003	FOH	√	√	√	√	○
Excursion	7.3L	Direct Injection - Turbo	2003	VSM	√	√	√	√	000A 000F
Expedition	4.6L	2V	2003 - 2004	4X4	√	√	√	√	○
Expedition	4.6L	2V	2003 - 2004	ABS/TCS	√	√	√	√	0008 0012
Expedition	4.6L	2V	2003 - 2004	DCSM	√	√	√	√	○
Expedition	4.6L	2V	2003 - 2004	DSM	√	√	√	√	○
Expedition	4.6L	2V	2003 - 2004	EATC	√	√	√	√	○
Expedition	4.6L	2V	2003 - 2004	HEC	√	√	√	√	○
Expedition	4.6L	2V	2003 - 2004	PAM	√	√	√	√	○
Expedition	4.6L	2V	2003 - 2004	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033 0033
Expedition	4.6L	2V	2003 - 2004	PCSM	√	√	√	√	○
Expedition	4.6L	2V	2003 - 2004	RCM	√	√	√	√	000C
Expedition	4.6L	2V	2003 - 2004	TPM	√	√	√	√	○
Expedition	4.6L	2V	2003 - 2004	VDM	√	√	√	√	○
Expedition	4.6L	2V	2003 - 2004	VSM	√	√	√	√	000A 000F
Expedition	4.6L	Other	1997 - 1998	IAB	√	√	√	√	○
Expedition	4.6L	Other	1997 - 1998	PATS	√	√	√	√	9
Expedition	4.6L	Other	1997 - 2000	4WAS	√	√	√	√	000E
Expedition	4.6L	Other	1997 - 2000	ABS/TCS	√	√	√	√	8
Expedition	4.6L	Other	1997 - 2000	GEM	√	√	√	√	○
Expedition	4.6L	Other	1997 - 2000	PCM	√	√	√	√	0023 0025
Expedition	4.6L	Other	1997 - 2000	RAP	√	√	√	√	000A 000F
Expedition	4.6L	Other	1998	RCC	√	√	√	√	○
Expedition	4.6L	Other	1999 - 2000	EATC	√	√	√	√	○
Expedition	4.6L	Other	1999 - 2000	HEC	√	√	√	√	9
Expedition	4.6L	Other	1999 - 2000	RCM	√	√	√	√	○
Expedition	4.6L	Other	2000	DSM	√	√	√	√	○
Expedition	4.6L	Other	2000	PAM	√	√	√	√	○
Expedition	5.4L	2V	2003 - 2004	4X4	√	√	√	√	○
Expedition	5.4L	2V	2003 - 2004	ABS/TCS	√	√	√	√	0008 0012

Expedition	5.4L	2V	2003 - 2004	DCSM	√	√	√	√	○
Expedition	5.4L	2V	2003 - 2004	DSM	√	√	√	√	○
Expedition	5.4L	2V	2003 - 2004	EATC	√	√	√	√	○
Expedition	5.4L	2V	2003 - 2004	HEC	√	√	√	√	○
Expedition	5.4L	2V	2003 - 2004	PAM	√	√	√	√	○
Expedition	5.4L	2V	2003 - 2004	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033 0033
Expedition	5.4L	2V	2003 - 2004	PCSM	√	√	√	√	○
Expedition	5.4L	2V	2003 - 2004	RCM	√	√	√	√	000C
Expedition	5.4L	2V	2003 - 2004	TPM	√	√	√	√	○
Expedition	5.4L	2V	2003 - 2004	VDM	√	√	√	√	○
Expedition	5.4L	2V	2003 - 2004	VSM	√	√	√	√	000A 000F
Expedition	5.4L	3V	2005 - 2006	VSM	√	√	√	√	000A 000F
Expedition	5.4L	3V	2005 - 2007	EATC	√	√	√	√	○
Expedition	5.4L	3V	2005 - 2010	4X4	√	√	√	√	○
Expedition	5.4L	3V	2005 - 2012	ABS	√	√	√	√	0012 0008 0005
Expedition	5.4L	3V	2005 - 2012	DCSM	√	√	√	√	○
Expedition	5.4L	3V	2005 - 2012	DSM	√	√	√	√	5
Expedition	5.4L	3V	2005 - 2012	IC	√	√	√	√	0009 0005
Expedition	5.4L	3V	2005 - 2012	PAM	√	√	√	√	5
Expedition	5.4L	3V	2005 - 2012	PCM	√	√	√	√	9
Expedition	5.4L	3V	2005 - 2012	RCM	√	√	√	√	000C 0005
Expedition	5.4L	3V	2005 - 2012	VDM	√	√	√	√	000E 0013 0014
Expedition	5.4L	3V	2007	GEM	√	√	√	√	○
Expedition	5.4L	3V	2007 - 2011	TCM	√	√	√	√	25
Expedition	5.4L	3V	2007 - 2012	ACM	√	√	√	√	0005 0016 0017 0018
Expedition	5.4L	3V	2007 - 2012	DSP	√	√	√	√	○
Expedition	5.4L	3V	2007 - 2012	LTM	√	√	√	√	○
Expedition	5.4L	3V	2007 - 2012	RCU	√	√	√	√	○
Expedition	5.4L	3V	2007 - 2012	RETM	√	√	√	√	0005 0018
Expedition	5.4L	3V	2007 - 2012	SDARS	√	√	√	√	5
Expedition	5.4L	3V	2008 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Expedition	5.4L	3V	2008 - 2012	HVAC	√	√	√	√	○
Expedition	5.4L	3V	2008 - 2012	PRB	√	√	√	√	○
Expedition	5.4L	3V	2009 - 2012	APIM	√	√	√	√	○
Expedition	5.4L	3V	2010 - 2012	GPSM	√	√	√	○	○
Expedition	5.4L	3V	2010 - 2012	TCCM	√	√	√	√	○
Expedition	5.4L	Other	1997 - 1998	IAB	√	√	√	√	○
Expedition	5.4L	Other	1997 - 1998	PATS	√	√	√	√	9
Expedition	5.4L	Other	1997 - 2000	4WAS	√	√	√	√	000E
Expedition	5.4L	Other	1997 - 2000	ABS/TCS	√	√	√	√	8
Expedition	5.4L	Other	1997 - 2000	GEM	√	√	√	√	○
Expedition	5.4L	Other	1997 - 2000	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033

Expedition	5.4L	Other	1997 - 2000	RAP	√	√	√	√	000A 000F
Expedition	5.4L	Other	1998	RCC	√	√	√	√	○
Expedition	5.4L	Other	1999 - 2000	EATC	√	√	√	√	○
Expedition	5.4L	Other	1999 - 2000	HEC	√	√	√	√	9
Expedition	5.4L	Other	1999 - 2000	RCM	√	√	√	√	○
Expedition	5.4L	Other	2000	DSM	√	√	√	√	○
Expedition	5.4L	Other	2000	PAM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	TPM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ABS	√	√	√	√	0008 0012
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ACM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	APIM	√	√	√	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ATCM	√	√	√	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	BCM#1	√	√	√	○	000A 000F 0042
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	C-CM	√	√	√	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	CLM#1	√	√	√	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	DCSM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	DSM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	DSP	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FCDIM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FCIM	√	√	√	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FLM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	GPSM	√	√	√	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	HSWM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	HUD	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	HVAC	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	IPC	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	LTM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	OCSM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PAM	√	√	√	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PSCM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	RCM	√	√	√	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	RFA	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	RLCM-A	√	√	√	√	○

Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	SCCM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	SOD-L	√	√	√	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	SOD-R	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	TCM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	√	√	√	√	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	√	√	√	○	○
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	√	√	√	√	0008 0012
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	ATCM	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	○	000A 000F 0042
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	CLM#1	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	DCSM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FLM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HUD	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HVAC	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	LTM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	√	√	√	√	0023 0025
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	√	√	√	○	○

Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RFA	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RLCM-A	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	√	√	√	√	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	√	√	√	○	○
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2012	TPM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	ABS	√	√	√	√	0008 0012
Explorer	3.5L	TiVCT	2011 - 2013	ACM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	APIM	√	√	√	○	○
Explorer	3.5L	TiVCT	2011 - 2013	ATCM	√	√	√	○	○
Explorer	3.5L	TiVCT	2011 - 2013	BCM#1	√	√	√	○	000A 000F 0042
Explorer	3.5L	TiVCT	2011 - 2013	C-CM	√	√	√	○	○
Explorer	3.5L	TiVCT	2011 - 2013	CLM#1	√	√	√	○	○
Explorer	3.5L	TiVCT	2011 - 2013	DCSM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	DSM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	DSP	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	FCDIM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	FCIM	√	√	√	○	○
Explorer	3.5L	TiVCT	2011 - 2013	FLM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	GPSM	√	√	√	○	○
Explorer	3.5L	TiVCT	2011 - 2013	HSWM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	HUD	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	HVAC	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	IPC	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	LTM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	OCSM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	PAM	√	√	√	○	○
Explorer	3.5L	TiVCT	2011 - 2013	PCM	√	√	√	√	0023 0025
Explorer	3.5L	TiVCT	2011 - 2013	PSCM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	RCM	√	√	√	○	○
Explorer	3.5L	TiVCT	2011 - 2013	RFA	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	RLCM-A	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	SCCM	√	√	√	√	○
Explorer	3.5L	TiVCT	2011 - 2013	SOD-L	√	√	√	○	○
Explorer	3.5L	TiVCT	2011 - 2013	SOD-R	√	√	√	√	○
Explorer	3.5L	TiVCT	2013	GFM	√	√	√	√	○
Explorer	3.5L	TiVCT	2013	IPM-A	√	√	√	○	○
Explorer	3.5L	TiVCT	2013	RTM	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	ABS	√	√	√	√	0008 0012
Explorer	3.7L	TiVCT	2013	ACM	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	APIM	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	ATCM	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	BCM#1	√	√	√	○	000A 000F 0042
Explorer	3.7L	TiVCT	2013	C-CM	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	CLM#1	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	DCSM	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	DSM	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	DSP	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	FCDIM	√	√	√	√	○

Explorer	3.7L	TiVCT	2013	FCIM	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	FLM	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	GFM	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	GPSM	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	HSWM	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	HUD	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	HVAC	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	IPC	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	IPM-A	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	LTM	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	OCSM	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	PAM	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	PCM	√	√	√	√	0023 0025
Explorer	3.7L	TiVCT	2013	PSCM	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	RCM	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	RFA	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	RLCM-A	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	RTM	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	SCCM	√	√	√	√	○
Explorer	3.7L	TiVCT	2013	SOD-L	√	√	√	○	○
Explorer	3.7L	TiVCT	2013	SOD-R	√	√	√	√	○
Explorer	4.0L	2V	2006 - 2007	EATC	√	√	√	√	○
Explorer	4.0L	2V	2006 - 2007	GEM	√	√	√	√	000A 000F
Explorer	4.0L	2V	2006 - 2010	4X4	√	√	√	√	○
Explorer	4.0L	2V	2006 - 2010	ABS	√	√	√	√	0008 0012 0005
Explorer	4.0L	2V	2006 - 2010	ACM	√	√	√	√	5
Explorer	4.0L	2V	2006 - 2010	DSM	√	√	√	√	5
Explorer	4.0L	2V	2006 - 2010	IC	√	√	√	√	0009 0005
Explorer	4.0L	2V	2006 - 2010	OCSM	√	√	√	○	000C 0015
Explorer	4.0L	2V	2006 - 2010	PAM	√	√	√	√	○
Explorer	4.0L	2V	2006 - 2010	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C6
Explorer	4.0L	2V	2006 - 2010	PRB	√	√	√	√	○
Explorer	4.0L	2V	2006 - 2010	RCM	√	√	√	√	5
Explorer	4.0L	2V	2006 - 2010	RETM	√	√	√	√	○
Explorer	4.0L	2V	2006 - 2010	SDARS	√	√	√	√	5
Explorer	4.0L	2V	2008 - 2010	APIM	√	√	√	√	○
Explorer	4.0L	2V	2008 - 2010	GEM / SJB	√	√	√	√	0005 000A 000F 0042
Explorer	4.0L	2V	2008 - 2010	HVAC	√	√	√	√	5
Explorer	4.0L	2V	2010	GPSM	√	√	√	○	○
Explorer	4.0L	Other	1996 - 1998	IAB	√	√	√	√	○
Explorer	4.0L	Other	1996 - 2000	ABS/TCS	√	√	√	√	8
Explorer	4.0L	Other	1996 - 2000	ARC	√	√	√	√	○
Explorer	4.0L	Other	1996 - 2000	EATC	√	√	√	√	○
Explorer	4.0L	Other	1996 - 2000	GEM	√	√	√	√	○
Explorer	4.0L	Other	1996 - 2000	PCM	√	√	√	√	0023 0025
Explorer	4.0L	Other	1996 - 2000	RAP	√	√	√	√	000F 000A
Explorer	4.0L	Other	1998 - 2000	DSM	√	√	√	√	○
Explorer	4.0L	Other	1998 - 2000	PAM	√	√	√	√	○
Explorer	4.0L	Other	1998 - 2000	PATS	√	√	√	√	9
Explorer	4.0L	Other	1999 - 2000	RCM	√	√	√	√	○
Explorer	4.0L	V6 OHV	1996 - 1998	IAB	√	√	√	√	○
Explorer	4.0L	V6 OHV	1996 - 1999	ABS/TCS	√	√	√	√	8
Explorer	4.0L	V6 OHV	1996 - 1999	ARC	√	√	√	√	○
Explorer	4.0L	V6 OHV	1996 - 1999	EATC	√	√	√	√	○

Explorer	4.0L	V6 OHV	1996 - 1999	GEM	√	√	√	√	○
Explorer	4.0L	V6 OHV	1996 - 1999	PCM	√	√	√	√	0023 0025
Explorer	4.0L	V6 OHV	1996 - 1999	RAP	√	√	√	√	000F 000A
Explorer	4.0L	V6 OHV	1998 - 1999	DSM	√	√	√	√	○
Explorer	4.0L	V6 OHV	1998 - 1999	PAM	√	√	√	√	○
Explorer	4.0L	V6 OHV	1998 - 1999	PATS	√	√	√	√	9
Explorer	4.0L	V6 OHV	1999	RCM	√	√	√	√	○
Explorer	4.0L	V6 SOHC	1997 - 1998	IAB	√	√	√	√	○
Explorer	4.0L	V6 SOHC	1997 - 2000	ARC	√	√	√	√	000E
Explorer	4.0L	V6 SOHC	1997 - 2000	RAP	√	√	√	√	000A 000F
Explorer	4.0L	V6 SOHC	1997 - 2002	GEM	√	√	√	√	○
Explorer	4.0L	V6 SOHC	1997 - 2003	ABS/TCS	√	√	√	√	0008 0012
Explorer	4.0L	V6 SOHC	1997 - 2005	EATC	√	√	√	√	5
Explorer	4.0L	V6 SOHC	1997 - 2005	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033 0009 00C6
Explorer	4.0L	V6 SOHC	1998 - 2000	PATS	√	√	√	√	9
Explorer	4.0L	V6 SOHC	1998 - 2005	DSM	√	√	√	√	○
Explorer	4.0L	V6 SOHC	1998 - 2005	PAM	√	√	√	√	○
Explorer	4.0L	V6 SOHC	1999	MC	√	√	√	√	○
Explorer	4.0L	V6 SOHC	1999 - 2005	RCM	√	√	√	√	000C
Explorer	4.0L	V6 SOHC	2002	CSM	√	√	√	√	000F
Explorer	4.0L	V6 SOHC	2002 - 2003	HEC	√	√	√	√	○
Explorer	4.0L	V6 SOHC	2002 - 2005	4X4	√	√	√	√	○
Explorer	4.0L	V6 SOHC	2002 - 2005	IC	√	√	√	√	5
Explorer	4.0L	V6 SOHC	2002 - 2005	TPM	√	√	√	√	5
Explorer	4.0L	V6 SOHC	2003 - 2005	VSM	√	√	√	√	000A 000F
Explorer	4.0L	V6 SOHC	2004 - 2005	ABS	√	√	√	√	0008 0012 0005
Explorer	4.6L	2V	2002	CSM	√	√	√	√	000F
Explorer	4.6L	2V	2002	GEM	√	√	√	√	○
Explorer	4.6L	2V	2002 - 2003	ABS/TCS	√	√	√	√	0008 0012
Explorer	4.6L	2V	2002 - 2003	HEC	√	√	√	√	○
Explorer	4.6L	2V	2002 - 2005	4X4	√	√	√	√	○
Explorer	4.6L	2V	2002 - 2005	DSM	√	√	√	√	○
Explorer	4.6L	2V	2002 - 2005	EATC	√	√	√	√	5
Explorer	4.6L	2V	2002 - 2005	IC	√	√	√	√	5
Explorer	4.6L	2V	2002 - 2005	PAM	√	√	√	√	○
Explorer	4.6L	2V	2002 - 2005	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033 00C6
Explorer	4.6L	2V	2002 - 2005	RCM	√	√	√	√	000C
Explorer	4.6L	2V	2002 - 2005	TPM	√	√	√	√	5
Explorer	4.6L	2V	2003 - 2005	VSM	√	√	√	√	000A 000F
Explorer	4.6L	2V	2004 - 2005	ABS	√	√	√	√	0008 0012
Explorer	4.6L	3V	2006 - 2007	EATC	√	√	√	√	5
Explorer	4.6L	3V	2006 - 2007	GEM	√	√	√	√	0005 000A 000F
Explorer	4.6L	3V	2006 - 2010	4X4	√	√	√	√	○
Explorer	4.6L	3V	2006 - 2010	ABS	√	√	√	√	0005 0008 0012

Explorer	4.6L	3V	2006 - 2010	ACM	√	√	√	√	5
Explorer	4.6L	3V	2006 - 2010	DSM	√	√	√	√	5
Explorer	4.6L	3V	2006 - 2010	IC	√	√	√	√	0009 0005
Explorer	4.6L	3V	2006 - 2010	OCSM	√	√	√	○	000C 0015
Explorer	4.6L	3V	2006 - 2010	PAM	√	√	√	√	5
Explorer	4.6L	3V	2006 - 2010	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C5 00C6
Explorer	4.6L	3V	2006 - 2010	PRB	√	√	√	√	○
Explorer	4.6L	3V	2006 - 2010	RCM	√	√	√	√	5
Explorer	4.6L	3V	2006 - 2010	RETM	√	√	√	√	5
Explorer	4.6L	3V	2006 - 2010	SDARS	√	√	√	√	5
Explorer	4.6L	3V	2006 - 2010	TCM	√	√	√	√	25
Explorer	4.6L	3V	2008 - 2010	APIM	√	√	√	√	○
Explorer	4.6L	3V	2008 - 2010	GEM / SJB	√	√	√	√	000A 000F 0042 0005
Explorer	4.6L	3V	2008 - 2010	HVAC	√	√	√	√	5
Explorer	4.6L	3V	2010	GPSM	√	√	√	○	○
Explorer	5.0L	Other	1996 - 1998	IAB	√	√	√	√	○
Explorer	5.0L	Other	1996 - 2000	ABS/TCS	√	√	√	√	8
Explorer	5.0L	Other	1996 - 2000	EATC	√	√	√	√	○
Explorer	5.0L	Other	1996 - 2000	GEM	√	√	√	√	○
Explorer	5.0L	Other	1996 - 2000	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
Explorer	5.0L	Other	1998 - 2000	RAP	√	√	√	√	000F 000A
Explorer	5.0L	Other	1997 - 2000	ARC	√	√	√	√	000E
Explorer	5.0L	Other	1998 - 2000	DSM	√	√	√	√	○
Explorer	5.0L	Other	1998 - 2000	PAM	√	√	√	√	○
Explorer	5.0L	Other	1998 - 2000	PATS	√	√	√	√	9
Explorer	5.0L	Other	1999 - 2000	RCM	√	√	√	√	○
Explorer Sport	4.0L	V6 SOHC	2000	PATS	√	√	√	√	9
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	4X4	√	√	√	√	○
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	ABS/TCS	√	√	√	√	8
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	GEM	√	√	√	√	○
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	PCM	√	√	√	√	0023 0025 0009 0010 0028 0031 0033
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	RAP	√	√	√	√	000A 000F
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	RCM	√	√	√	√	000C
Explorer SportTrac	4.0L	2V	2007	EATC	√	√	√	√	○
Explorer SportTrac	4.0L	2V	2007	GEM	√	√	√	√	000A 000F
Explorer SportTrac	4.0L	2V	2007 - 2010	4X4	√	√	√	√	○
Explorer SportTrac	4.0L	2V	2007 - 2010	ABS	√	√	√	√	0008 0012
Explorer SportTrac	4.0L	2V	2007 - 2010	ACM	√	√	√	√	○
Explorer SportTrac	4.0L	2V	2007 - 2010	IC	√	√	√	√	0009 0005
Explorer SportTrac	4.0L	2V	2007 - 2010	OCSM	√	√	√	○	000C 0015
Explorer SportTrac	4.0L	2V	2007 - 2010	PAM	√	√	√	√	○

Explorer SportTrac	4.0L	2V	2007 - 2010	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C6
Explorer SportTrac	4.0L	2V	2007 - 2010	RCM	√	√	√	√	5
Explorer SportTrac	4.0L	2V	2007 - 2010	RETM	√	√	√	√	○
Explorer SportTrac	4.0L	2V	2007 - 2010	SDARS	√	√	√	√	5
Explorer SportTrac	4.0L	2V	2008 - 2010	APIM	√	√	√	√	○
Explorer SportTrac	4.0L	2V	2008 - 2010	GEM / SJB	√	√	√	√	0005 000A 000F 0042
Explorer SportTrac	4.0L	2V	2008 - 2010	HVAC	√	√	√	√	5
Explorer SportTrac	4.0L	2V	2010	GPSM	√	√	√	○	○
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2003	GEM	√	√	√	√	○
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	4X4	√	√	√	√	○
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	ABS/TCS	√	√	√	√	8
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	PCM	√	√	√	√	0023 0025 0009 0010 0028 0031 0033
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	RAP	√	√	√	√	000A 000F
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	RCM	√	√	√	√	000C
Explorer SportTrac	4.0L	V6 SOHC	2004 - 2005	HEC	√	√	√	√	○
Explorer SportTrac	4.6L	3V	2007	EATC	√	√	√	√	5
Explorer SportTrac	4.6L	3V	2007	GEM	√	√	√	√	0005 000A 000F
Explorer SportTrac	4.6L	3V	2007 - 2010	4X4	√	√	√	√	○
Explorer SportTrac	4.6L	3V	2007 - 2010	ABS	√	√	√	√	0008 0012
Explorer SportTrac	4.6L	3V	2007 - 2010	ACM	√	√	√	√	5
Explorer SportTrac	4.6L	3V	2007 - 2010	IC	√	√	√	√	0009 0005
Explorer SportTrac	4.6L	3V	2007 - 2010	OCSM	√	√	√	○	000C 0015
Explorer SportTrac	4.6L	3V	2007 - 2010	PAM	√	√	√	√	5
Explorer SportTrac	4.6L	3V	2007 - 2010	PCM	√	√	√	√	0010 0023 0028 0031 0033 00C5 00C6
Explorer SportTrac	4.6L	3V	2007 - 2010	RCM	√	√	√	√	5
Explorer SportTrac	4.6L	3V	2007 - 2010	RETM	√	√	√	√	5
Explorer SportTrac	4.6L	3V	2007 - 2010	SDARS	√	√	√	√	5
Explorer SportTrac	4.6L	3V	2007 - 2010	TCM	√	√	√	√	25
Explorer SportTrac	4.6L	3V	2008 - 2010	APIM	√	√	√	√	○
Explorer SportTrac	4.6L	3V	2008 - 2010	GEM / SJB	√	√	√	√	000A 000F 0042 0005
Explorer SportTrac	4.6L	3V	2008 - 2010	HVAC	√	√	√	√	5
Explorer SportTrac	4.6L	3V	2010	GPSM	√	√	√	○	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	ABS	√	√	√	√	0012 0008
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	ACM	√	√	√	○	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	APIM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	BCM#1	√	√	√	√	000A 000F 0042
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	DCSM	√	√	√	√	○

F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	DSM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	DSP	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	FCIM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	FDIM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	GPSM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	HVAC	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	ILCM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	IPC	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	OCSM	√	√	√	√	000C 0015
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	PAM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	PCM	√	√	√	√	0009 0025 0023
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	PRB	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	PSCM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	RCM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	SCCM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	TBC	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	TCCM	√	√	√	√	○
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	TPM	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	ABS	√	√	√	√	0008 0012
F-150	3.7L	TiVCT	2011 - 2012	ACM	√	√	√	○	○
F-150	3.7L	TiVCT	2011 - 2012	APIM	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	BCM#1	√	√	√	√	000A 000F 0042
F-150	3.7L	TiVCT	2011 - 2012	DCSM	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	DSM	√	√	√	√	5
F-150	3.7L	TiVCT	2011 - 2012	DSP	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	FCIM	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	FDIM	√	√	√	√	5
F-150	3.7L	TiVCT	2011 - 2012	GPSM	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	HVAC	√	√	√	√	5
F-150	3.7L	TiVCT	2011 - 2012	ILCM	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	IPC	√	√	√	√	5
F-150	3.7L	TiVCT	2011 - 2012	OCSM	√	√	√	√	000C 0015
F-150	3.7L	TiVCT	2011 - 2012	PAM	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
F-150	3.7L	TiVCT	2011 - 2012	PRB	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	PSCM	√	√	√	√	0005 00CB
F-150	3.7L	TiVCT	2011 - 2012	RCM	√	√	√	√	○

F-150	3.7L	TiVCT	2011 - 2012	SCCM	√	√	√	√	5
F-150	3.7L	TiVCT	2011 - 2012	TBC	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	TCCM	√	√	√	√	○
F-150	3.7L	TiVCT	2011 - 2012	TPM	√	√	√	√	○
F-150	4.2L	2V	2005 - 2007	EATC	√	√	√	√	○
F-150	4.2L	2V	2005 - 2008	4X4	√	√	√	√	○
F-150	4.2L	2V	2005 - 2008	ABS	√	√	√	√	0005 0008 000B
F-150	4.2L	2V	2005 - 2008	DSM	√	√	√	√	○
F-150	4.2L	2V	2005 - 2008	IC	√	√	√	√	○
F-150	4.2L	2V	2005 - 2008	PAM	√	√	√	√	○
F-150	4.2L	2V	2005 - 2008	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
F-150	4.2L	2V	2005 - 2008	RCM	√	√	√	√	000C
F-150	4.2L	2V	2005 - 2008	VSM	√	√	√	√	000A 000F
F-150	4.2L	2V	2008	HVAC	√	√	√	√	○
F-150	4.2L	2V	2008	RETM	√	√	√	√	18
F-150	4.2L	Other	1997 - 2000	IAB	√	√	√	√	○
F-150	4.2L	Other	1997 - 2006	ABS/TCS	√	√	√	√	8
F-150	4.2L	Other	1997 - 2006	GEM	√	√	√	√	○
F-150	4.2L	Other	1997 - 2006	PCM	√	√	√	√	0023 0025
F-150	4.2L	Other	1997 - 2006	RAP	√	√	√	√	000A 000F
F-150	4.2L	Other	1999 - 2006	IC	√	√	√	√	9
F-150	4.2L	Other	2002 - 2006	RCM	√	√	√	√	○
F-150	4.6L	2V	2003 - 2005	ABS/TCS	√	√	√	√	8
F-150	4.6L	2V	2003 - 2005	GEM	√	√	√	√	○
F-150	4.6L	2V	2003 - 2005	RAP	√	√	√	√	000A 000F
F-150	4.6L	2V	2003 - 2010	IC	√	√	√	√	0009 0005
F-150	4.6L	2V	2003 - 2010	PCM	√	√	√	√	0023 0025 0009 0010 0028 0031 0033
F-150	4.6L	2V	2003 - 2010	RCM	√	√	√	√	000C
F-150	4.6L	2V	2004 - 2007	EATC	√	√	√	√	○
F-150	4.6L	2V	2004 - 2008	4X4	√	√	√	√	○
F-150	4.6L	2V	2004 - 2008	VSM	√	√	√	√	000A 000F
F-150	4.6L	2V	2004 - 2010	ABS	√	√	√	√	0008 000B 0005 0012
F-150	4.6L	2V	2004 - 2010	DSM	√	√	√	√	○
F-150	4.6L	2V	2004 - 2010	PAM	√	√	√	√	○
F-150	4.6L	2V	2008	RETM	√	√	√	√	18
F-150	4.6L	2V	2008 - 2010	HVAC	√	√	√	√	○
F-150	4.6L	2V	2009 - 2010	ACM	√	√	√	√	○
F-150	4.6L	2V	2009 - 2010	APIM	√	√	√	√	○
F-150	4.6L	2V	2009 - 2010	DCSM	√	√	√	√	○
F-150	4.6L	2V	2009 - 2010	DSP	√	√	√	√	○
F-150	4.6L	2V	2009 - 2010	FCIM	√	√	√	√	○
F-150	4.6L	2V	2009 - 2010	FDIM	√	√	√	√	○
F-150	4.6L	2V	2009 - 2010	GEM / SJB	√	√	√	√	000A 000F 0042

F-150	4.6L	2V	2009 - 2010	OCSM	√	√	√	√	000C 0015
F-150	4.6L	2V	2009 - 2010	PRB	√	√	√	√	○
F-150	4.6L	2V	2009 - 2010	TBC	√	√	√	√	○
F-150	4.6L	2V	2009 - 2010	TCCM	√	√	√	√	○
F-150	4.6L	2V	2010	GPSM	√	√	√	○	○
F-150	4.6L	2V	2010	ILCM	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	ABS	√	√	√	√	12
F-150	4.6L	3V	2009 - 2010	ACM	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	APIM	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	DCSM	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	DSM	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	DSP	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	FCIM	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	FDIM	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	GEM / SJB	√	√	√	√	000A 000F 0042
F-150	4.6L	3V	2009 - 2010	HVAC	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	IC	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	OCSM	√	√	√	√	000C 0015
F-150	4.6L	3V	2009 - 2010	PAM	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	PCM	√	√	√	√	25
F-150	4.6L	3V	2009 - 2010	PRB	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	RCM	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	TBC	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	TCCM	√	√	√	√	○
F-150	4.6L	3V	2009 - 2010	TCM	√	√	√	√	○
F-150	4.6L	3V	2010	GPSM	√	√	√	○	○
F-150	4.6L	3V	2010	ILCM	√	√	√	√	○
F-150	4.6L	Other	1997 - 2000	IAB	√	√	√	√	○
F-150	4.6L	Other	1997 - 2002	ABS/TCS	√	√	√	√	8
F-150	4.6L	Other	1997 - 2002	GEM	√	√	√	√	○
F-150	4.6L	Other	1997 - 2002	PCM	√	√	√	√	0023 0025
F-150	4.6L	Other	1997 - 2002	RAP	√	√	√	√	000A 000F
F-150	4.6L	Other	1999 - 2002	IC	√	√	√	√	9
F-150	4.6L	Other	2002	RCM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	ABS	√	√	√	√	0012 0008
F-150	5.0L	TiVCT	2011 - 2012	ACM	√	√	√	○	○
F-150	5.0L	TiVCT	2011 - 2012	APIM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	BCM#1	√	√	√	√	000A 000F 0042
F-150	5.0L	TiVCT	2011 - 2012	DCSM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	DSM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	DSP	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	FCIM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	FDIM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	GPSM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	HVAC	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	ILCM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	IPC	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	OCSM	√	√	√	√	000C 0015
F-150	5.0L	TiVCT	2011 - 2012	PAM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	PCM	√	√	√	√	0009 0025 0023

F-150	5.0L	TiVCT	2011 - 2012	PRB	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	PSCM	√	√	√	√	00CB
F-150	5.0L	TiVCT	2011 - 2012	RCM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	SCCM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	TBC	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	TCCM	√	√	√	√	○
F-150	5.0L	TiVCT	2011 - 2012	TPM	√	√	√	√	○
F-150	5.4L	2V	2004	ABS/TCS	√	√	√	√	○
F-150	5.4L	2V	2004	GEM	√	√	√	√	○
F-150	5.4L	2V	2004	IC	√	√	√	√	9
F-150	5.4L	2V	2004	PCM	√	√	√	√	○
F-150	5.4L	2V	2004	RAP	√	√	√	√	000F
F-150	5.4L	2V	2004	RCM	√	√	√	√	○
F-150	5.4L	3V	2004 - 2007	EATC	√	√	√	√	○
F-150	5.4L	3V	2004 - 2008	4X4	√	√	√	√	○
F-150	5.4L	3V	2004 - 2008	VSM	√	√	√	√	000A 000F
F-150	5.4L	3V	2004 - 2010	ABS	√	√	√	√	0005 0008 000B 0012
F-150	5.4L	3V	2004 - 2010	DSM	√	√	√	√	○
F-150	5.4L	3V	2004 - 2010	IC	√	√	√	√	5
F-150	5.4L	3V	2004 - 2010	PAM	√	√	√	√	○
F-150	5.4L	3V	2004 - 2010	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033 00C5
F-150	5.4L	3V	2004 - 2010	RCM	√	√	√	√	000C
F-150	5.4L	3V	2008	RETM	√	√	√	√	○
F-150	5.4L	3V	2008 - 2010	HVAC	√	√	√	√	○
F-150	5.4L	3V	2009 - 2010	ACM	√	√	√	√	○
F-150	5.4L	3V	2009 - 2010	APIM	√	√	√	√	○
F-150	5.4L	3V	2009 - 2010	DCSM	√	√	√	√	○
F-150	5.4L	3V	2009 - 2010	DSP	√	√	√	√	○
F-150	5.4L	3V	2009 - 2010	FCIM	√	√	√	√	○
F-150	5.4L	3V	2009 - 2010	FDIM	√	√	√	√	○
F-150	5.4L	3V	2009 - 2010	GEM / SJB	√	√	√	√	000A 000F 0042
F-150	5.4L	3V	2009 - 2010	OCSM	√	√	√	√	000C 0015
F-150	5.4L	3V	2009 - 2010	PRB	√	√	√	√	○
F-150	5.4L	3V	2009 - 2010	TBC	√	√	√	√	○
F-150	5.4L	3V	2009 - 2010	TCCM	√	√	√	√	○
F-150	5.4L	3V	2009 - 2010	TCM	√	√	√	√	○
F-150	5.4L	3V	2010	GPSM	√	√	√	○	○
F-150	5.4L	3V	2010	ILCM	√	√	√	√	○
F-150	5.4L	BIF	1998 - 2000	ABS/TCS	√	√	√	√	8
F-150	5.4L	BIF	1998 - 2000	AFCM	√	√	√	√	○
F-150	5.4L	BIF	1998 - 2000	GEM	√	√	√	√	○
F-150	5.4L	BIF	1998 - 2000	IAB	√	√	√	√	○
F-150	5.4L	BIF	1998 - 2000	PCM	√	√	√	√	0023 0025
F-150	5.4L	BIF	1998 - 2000	RAP	√	√	√	√	000A 000F
F-150	5.4L	BIF	1999 - 2000	IC	√	√	√	√	9
F-150	5.4L	NGV	2000	ABS/TCS	√	√	√	√	8
F-150	5.4L	NGV	2000	FIM	√	√	√	√	○
F-150	5.4L	NGV	2000	GEM	√	√	√	√	○
F-150	5.4L	NGV	2000	IAB	√	√	√	√	○
F-150	5.4L	NGV	2000	IC	√	√	√	√	9
F-150	5.4L	NGV	2000	PCM	√	√	√	√	23

F-150	5.4L	NGV	2000	RAP	√	√	√	√	000A 000F
F-150	5.4L	Other	1997 - 2000	IAB	√	√	√	√	○
F-150	5.4L	Other	1997 - 2003	ABS/TCS	√	√	√	√	8
F-150	5.4L	Other	1997 - 2003	GEM	√	√	√	√	○
F-150	5.4L	Other	1997 - 2003	PCM	√	√	√	√	0023 0025
F-150	5.4L	Other	1997 - 2003	RAP	√	√	√	√	000A 000F
F-150	5.4L	Other	1999 - 2003	IC	√	√	√	√	9
F-150	5.4L	Other	2002 - 2003	RCM	√	√	√	√	○
F-150	6.2L	2V	2010	GEM / SJB	√	√	√	√	000A 000F 0042
F-150	6.2L	2V	2010	IC	√	√	√	√	○
F-150	6.2L	2V	2010 - 2012	ABS	√	√	√	√	0008 0012
F-150	6.2L	2V	2010 - 2012	ACM	√	√	√	○	○
F-150	6.2L	2V	2010 - 2012	APIM	√	√	√	√	○
F-150	6.2L	2V	2010 - 2012	DCSM	√	√	√	√	○
F-150	6.2L	2V	2010 - 2012	DSM	√	√	√	√	5
F-150	6.2L	2V	2010 - 2012	DSP	√	√	√	√	○
F-150	6.2L	2V	2010 - 2012	FCIM	√	√	√	√	○
F-150	6.2L	2V	2010 - 2012	FDIM	√	√	√	√	5
F-150	6.2L	2V	2010 - 2012	GPSM	√	√	√	○	○
F-150	6.2L	2V	2010 - 2012	HVAC	√	√	√	√	5
F-150	6.2L	2V	2010 - 2012	ILCM	√	√	√	√	○
F-150	6.2L	2V	2010 - 2012	OCSM	√	√	√	√	000C 0015
F-150	6.2L	2V	2010 - 2012	PAM	√	√	√	√	○
F-150	6.2L	2V	2010 - 2012	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 0009
F-150	6.2L	2V	2010 - 2012	PRB	√	√	√	√	○
F-150	6.2L	2V	2010 - 2012	RCM	√	√	√	√	○
F-150	6.2L	2V	2010 - 2012	TBC	√	√	√	√	○
F-150	6.2L	2V	2010 - 2012	TCCM	√	√	√	√	○
F-150	6.2L	2V	2011 - 2012	BCM#1	√	√	√	√	000A 000F 0042
F-150	6.2L	2V	2011 - 2012	IPC	√	√	√	√	5
F-150	6.2L	2V	2011 - 2012	PSCM	√	√	√	√	0005 00CB
F-150	6.2L	2V	2011 - 2012	SCCM	√	√	√	√	5
F-150	6.2L	2V	2011 - 2012	TPM	√	√	√	√	○
F-150	Other	Other	2004	4X4	√	√	√	√	○
F-150	Other	Other	2004	EATC	√	√	√	√	○
F-150	Other	Other	2004	IC	√	√	√	√	○
F-150	Other	Other	2004	PCM	√	√	√	√	○
F-150	Other	Other	2004	VSM	√	√	√	√	000A
F-150	Other	Other	2004 - 2012	ABS	√	√	√	√	○
F-150	Other	Other	2004 - 2012	DSM	√	√	√	√	○
F-150	Other	Other	2004 - 2012	PAM	√	√	√	√	○
F-150	Other	Other	2004 - 2012	RCM	√	√	√	√	○
F-150	Other	Other	2012	ACM	√	√	√	○	○
F-150	Other	Other	2012	BCM#1	√	√	√	○	○
F-150	Other	Other	2012	DCSM	√	√	√	√	○
F-150	Other	Other	2012	DSP	√	√	√	√	○
F-150	Other	Other	2012	FCIM	√	√	√	√	○
F-150	Other	Other	2012	FDIM	√	√	√	√	○
F-150	Other	Other	2012	HVAC	√	√	√	○	○
F-150	Other	Other	2012	ILCM	√	√	√	√	○
F-150	Other	Other	2012	IPC	√	√	√	√	○
F-150	Other	Other	2012	OCSM	√	√	√	√	○
F-150	Other	Other	2012	PRB	√	√	√	√	○

F-150	Other	Other	2012	PSCM	√	√	√	√	○
F-150	Other	Other	2012	SCCM	√	√	√	√	○
F-150	Other	Other	2012	TBC	√	√	√	√	○
F-150	Other	Other	2012	TCCM	√	√	√	√	○
F-150	Other	Other	2012	TPM	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	ABS/TCS	√	√	√	√	8
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	EATC	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	GEM	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	HEC	√	√	√	√	9
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	PCM	√	√	√	√	0023 0025
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	RAP	√	√	√	√	000A 000F
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	RCM	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	ABS/TCS	√	√	√	√	8
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	GEM	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	HEC	√	√	√	√	9
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	PCM	√	√	√	√	0023 0025
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	RAP	√	√	√	√	000A 000F
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	RCM	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	4.6L	Other	2002	EATC	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	ABS/TCS	√	√	√	√	8
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	EATC	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	GEM	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	HEC	√	√	√	√	9

F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	PCM	√	√	√	√	0023 0025
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	RAP	√	√	√	√	000A 000F
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	RCM	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	ABS/TCS	√	√	√	√	8
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	GEM	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	HEC	√	√	√	√	9
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	PCM	√	√	√	√	0023 0025
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	RAP	√	√	√	√	000A 000F
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	RCM	√	√	√	√	○
F-150 SuperCrew (4 full size doors)	5.4L	Other	2002	EATC	√	√	√	√	○
F-250	3.9L	Cummins Diesel	2006	4X4	√	√	√	√	○
F-250	3.9L	Cummins Diesel	2006	ABS/TCS	√	√	√	√	○
F-250	3.9L	Cummins Diesel	2006	GEM	√	√	√	√	○
F-250	3.9L	Cummins Diesel	2006	HEC	√	√	√	√	○
F-250	3.9L	Cummins Diesel	2006	OTC	√	√	√	√	○
F-250	3.9L	Cummins Diesel	2006	PAM	√	√	√	√	○
F-250	3.9L	Cummins Diesel	2006	RCM	√	√	√	√	○
F-250	3.9L	Cummins Diesel	2006	TBM	√	√	√	√	○
F-250 Light Duty	4.2L	Other	1999	ABS/TCS	√	√	√	√	8
F-250 Light Duty	4.2L	Other	1999	GEM	√	√	√	√	○
F-250 Light Duty	4.2L	Other	1999	IC	√	√	√	√	9
F-250 Light Duty	4.2L	Other	1999	PCM	√	√	√	√	0023 0025
F-250 Light Duty	4.2L	Other	1999	RAP	√	√	√	√	000A 000F
F-250 Light Duty	4.2L	Other	1999	RCM	√	√	√	√	○
F-250 Light Duty	4.6L	Other	1997 - 1998	IAB	√	√	√	√	○
F-250 Light Duty	4.6L	Other	1997 - 2000	ABS/TCS	√	√	√	√	8
F-250 Light Duty	4.6L	Other	1997 - 2000	GEM	√	√	√	√	○
F-250 Light Duty	4.6L	Other	1997 - 2000	PCM	√	√	√	√	0023 0025
F-250 Light Duty	4.6L	Other	1997 - 2000	RAP	√	√	√	√	000A
F-250 Light Duty	4.6L	Other	1999 - 2000	IC	√	√	√	√	9
F-250 Light Duty	4.6L	Other	1999 - 2000	RCM	√	√	√	√	○

F-250 Light Duty	5.4L	BIF	1998	IAB	√	√	√	√	○
F-250 Light Duty	5.4L	BIF	1998 - 1999	ABS/TCS	√	√	√	√	8
F-250 Light Duty	5.4L	BIF	1998 - 1999	AFCM	√	√	√	√	○
F-250 Light Duty	5.4L	BIF	1998 - 1999	GEM	√	√	√	√	○
F-250 Light Duty	5.4L	BIF	1998 - 1999	PCM	√	√	√	√	23
F-250 Light Duty	5.4L	BIF	1998 - 1999	RAP	√	√	√	√	000A 000F
F-250 Light Duty	5.4L	BIF	1999	IC	√	√	√	√	9
F-250 Light Duty	5.4L	BIF	1999	RCM	√	√	√	√	○
F-250 Light Duty	5.4L	NGV	1997 - 1998	IAB	√	√	√	√	○
F-250 Light Duty	5.4L	NGV	1997 - 2000	ABS/TCS	√	√	√	√	8
F-250 Light Duty	5.4L	NGV	1997 - 2000	FIM	√	√	√	√	○
F-250 Light Duty	5.4L	NGV	1997 - 2000	GEM	√	√	√	√	○
F-250 Light Duty	5.4L	NGV	1997 - 2000	PCM	√	√	√	√	23
F-250 Light Duty	5.4L	NGV	1997 - 2000	RAP	√	√	√	√	000A 000F
F-250 Light Duty	5.4L	NGV	1999 - 2000	IC	√	√	√	√	9
F-250 Light Duty	5.4L	NGV	1999 - 2000	RCM	√	√	√	√	○
F-250 Light Duty	5.4L	Other	1997 - 1998	IAB	√	√	√	√	○
F-250 Light Duty	5.4L	Other	1997 - 2000	ABS/TCS	√	√	√	√	8
F-250 Light Duty	5.4L	Other	1997 - 2000	GEM	√	√	√	√	○
F-250 Light Duty	5.4L	Other	1997 - 2000	PCM	√	√	√	√	0023 0025
F-250 Light Duty	5.4L	Other	1997 - 2000	RAP	√	√	√	√	000A 000F
F-250 Light Duty	5.4L	Other	1999 - 2000	IC	√	√	√	√	9
F-250 Light Duty	5.4L	Other	1999 - 2000	RCM	√	√	√	√	○
F-650 / F-750	5.9L	Cummins Diesel	2000 - 2007	ABS/TCS	√	√	√	√	○
F-650 / F-750	5.9L	Cummins Diesel	2000 - 2007	GEM	√	√	√	√	○
F-650 / F-750	6.0L	Direct Injection - Turbo	2004 - 2007	GEM	√	√	√	√	○
F-650 / F-750	6.0L	Direct Injection - Turbo	2005 - 2007	ABS/TCS	√	√	√	√	○
F-650 / F-750	6.7L	Cummins Diesel	2008 - 2012	GEM / SJB	√	√	√	○	○
F-650 / F-750	6.7L	Cummins Diesel	2011 - 2012	ACM	√	√	√	○	○
F-650 / F-750	6.7L	Cummins Diesel	2011 - 2012	HVAC	√	√	√	√	○
F-650 / F-750	6.7L	Cummins Diesel	2011 - 2012	IPC	√	√	√	√	○
F-650 / F-750	6.7L	Cummins Diesel	2012	APIM	√	√	√	√	○
F-650 / F-750	6.8L	3V	2012	ACM	√	√	√	○	○
F-650 / F-750	6.8L	3V	2012	APIM	√	√	√	√	○
F-650 / F-750	6.8L	3V	2012	GEM / SJB	√	√	√	○	○
F-650 / F-750	6.8L	3V	2012	HVAC	√	√	√	√	○
F-650 / F-750	6.8L	3V	2012	IPC	√	√	√	√	○
F-650 / F-750	6.8L	3V	2012	PCM	√	√	√	√	0023 0025

F-650 / F-750	7.2L	Caterpillar Diesel	2000 - 2007	ABS/TCS	√	√	√	√	○
F-650 / F-750	7.2L	Caterpillar Diesel	2000 - 2007	GEM	√	√	√	√	○
F-650 / F-750	7.2L	Caterpillar Diesel	2008 - 2010	GEM / SJB	√	√	√	○	○
F-650 / F-750	7.3L	Direct Injection - Turbo	2000 - 2003	ABS/TCS	√	√	√	√	8
F-650 / F-750	7.3L	Direct Injection - Turbo	2000 - 2003	GEM	√	√	√	√	○
F-650 / F-750	7.3L	Direct Injection - Turbo	2000 - 2003	PCM	√	√	√	√	25
F-650 / F-750	Other	Other	2005 - 2006	ABS/TCS	√	√	√	√	○
F-650 / F-750	Other	Other	2005 - 2006	GEM	√	√	√	√	○
F-Series	4.9L	GFP	1996	PCM	√	√	√	√	23
F-Series	4.9L	Other	1996	PCM	√	√	√	√	0023 0025
F-Series	5.0L	Other	1996	PCM	√	√	√	√	0023 0025
F-Series	5.8L	Other	1996 - 1997	PCM	√	√	√	√	0023 0025
F-Series	7.3L	Direct Injection - Turbo	1994 - 1997	PCM	√	√	√	√	25
F-Series	7.5L	Other	1996 - 1997	PCM	√	√	√	√	0023 0025
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	ABS/TCS	√	√	√	√	8
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	FOH	√	√	√	√	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	GEM	√	√	√	√	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	HEC	√	√	√	√	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	OTC	√	√	√	√	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	PAM	√	√	√	√	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	PATS	√	√	√	√	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	PCM	√	√	√	√	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	RCM	√	√	√	√	○
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	VSM	√	√	√	√	000A 000F
F-Series Super Duty	4.2L	Other	2001	ABS/TCS	√	√	√	√	8
F-Series Super Duty	4.2L	Other	2001	ECS	√	√	√	√	○
F-Series Super Duty	4.2L	Other	2001	GEM	√	√	√	√	○
F-Series Super Duty	4.2L	Other	2001	OTC	√	√	√	√	○
F-Series Super Duty	4.2L	Other	2001	PAM	√	√	√	√	○
F-Series Super Duty	4.2L	Other	2001	PCM	√	√	√	√	0023 0025
F-Series Super Duty	4.2L	Other	2001	RCM	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2004	ABS/TCS	√	√	√	√	8
F-Series Super Duty	5.4L	2V	2004	HEC	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2004	OTC	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2004	PATS	√	√	√	√	9
F-Series Super Duty	5.4L	2V	2004 - 2006	GEM	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2004 - 2006	VSM	√	√	√	√	000A 000F

F-Series Super Duty	5.4L	2V	2004 - 2008	PAM	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2004 - 2008	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
F-Series Super Duty	5.4L	2V	2004 - 2008	RCM	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2005 - 2006	EATC	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2005 - 2008	ABS	√	√	√	√	8
F-Series Super Duty	5.4L	2V	2005 - 2008	IC	√	√	√	√	9
F-Series Super Duty	5.4L	2V	2005 - 2008	TBC	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2008	4X4	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2008	ACM	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2008	DSM	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2008	GEM / SJB	√	√	√	√	000A 000F 0042
F-Series Super Duty	5.4L	2V	2008	HVAC	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2008	RETM	√	√	√	√	○
F-Series Super Duty	5.4L	2V	2008	SDARS	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2005 - 2007	EATC	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2005 - 2007	GEM	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2005 - 2007	VSM	√	√	√	√	000A 000F
F-Series Super Duty	5.4L	3V	2005 - 2010	ABS	√	√	√	√	8
F-Series Super Duty	5.4L	3V	2005 - 2010	IC	√	√	√	√	9
F-Series Super Duty	5.4L	3V	2005 - 2010	PAM	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2005 - 2010	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C5
F-Series Super Duty	5.4L	3V	2005 - 2010	RCM	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2005 - 2010	TBC	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2008 - 2010	4X4	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2008 - 2010	ACM	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2008 - 2010	DSM	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2008 - 2010	GEM / SJB	√	√	√	√	000A 000F 0042
F-Series Super Duty	5.4L	3V	2008 - 2010	HVAC	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2008 - 2010	RETM	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2008 - 2010	SDARS	√	√	√	√	○

F-Series Super Duty	5.4L	3V	2009 - 2010	APIM	√	√	√	√	○
F-Series Super Duty	5.4L	3V	2010	GPSM	√	√	√	○	○
F-Series Super Duty	5.4L	BIF	1999	ABS/TCS	√	√	√	√	8
F-Series Super Duty	5.4L	BIF	1999	AFCM	√	√	√	√	○
F-Series Super Duty	5.4L	BIF	1999	ECS	√	√	√	√	○
F-Series Super Duty	5.4L	BIF	1999	GEM	√	√	√	√	○
F-Series Super Duty	5.4L	BIF	1999	OTC	√	√	√	√	○
F-Series Super Duty	5.4L	BIF	1999	PCM	√	√	√	√	23
F-Series Super Duty	5.4L	Other	1999 - 2001	ECS	√	√	√	√	○
F-Series Super Duty	5.4L	Other	1999 - 2003	ABS/TCS	√	√	√	√	8
F-Series Super Duty	5.4L	Other	1999 - 2003	GEM	√	√	√	√	○
F-Series Super Duty	5.4L	Other	1999 - 2003	OTC	√	√	√	√	○
F-Series Super Duty	5.4L	Other	1999 - 2003	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
F-Series Super Duty	5.4L	Other	2000 - 2003	PATS	√	√	√	√	9
F-Series Super Duty	5.4L	Other	2001 - 2003	PAM	√	√	√	√	○
F-Series Super Duty	5.4L	Other	2001 - 2003	RCM	√	√	√	√	○
F-Series Super Duty	5.4L	Other	2002	CSM	√	√	√	√	000A 000F
F-Series Super Duty	5.4L	Other	2002 - 2003	HEC	√	√	√	√	○
F-Series Super Duty	5.4L	Other	2003	FOH	√	√	√	√	○
F-Series Super Duty	5.4L	Other	2003	VSM	√	√	√	√	000A 000F
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	ABS/TCS	√	√	√	√	8
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	FOH	√	√	√	√	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	HEC	√	√	√	√	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	OTC	√	√	√	√	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	PATS	√	√	√	√	9
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	GEM	√	√	√	√	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	PAM	√	√	√	√	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	PCM	√	√	√	√	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	RCM	√	√	√	√	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	TCM	√	√	√	√	0010 0028 0031 0033
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	VSM	√	√	√	√	000A 000F

F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	ABS	√	√	√	√	8
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	EATC	√	√	√	√	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	IC	√	√	√	√	○
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	TBC	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011	APIM	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011	GPSM	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	ABS	√	√	√	√	8
F-Series Super Duty	6.2L	2V	2011 - 2012	ACM	√	√	√	○	○
F-Series Super Duty	6.2L	2V	2011 - 2012	BCM#1	√	√	√	√	000A 000F 0042
F-Series Super Duty	6.2L	2V	2011 - 2012	DCSM	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	DSM	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	HVAC	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	IPC	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	PAM	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
F-Series Super Duty	6.2L	2V	2011 - 2012	RCM	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	SCCM	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	SDARS	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	TBC	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	TCCM	√	√	√	√	○
F-Series Super Duty	6.2L	2V	2011 - 2012	TPM	√	√	√	√	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	4X4	√	√	√	√	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	ABS	√	√	√	√	0005 0008
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	ACM	√	√	√	√	5
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	AHCM	√	√	√	√	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	CDIM	√	√	√	√	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	DSM	√	√	√	√	5
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	GEM / SJB	√	√	√	√	42
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	HVAC	√	√	√	√	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	IC	√	√	√	√	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	PAM	√	√	√	√	○

F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	PCM	√	√	√	√	0023 0025 0047 0048 00A2 00A3
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	RCM	√	√	√	√	5
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	RETM	√	√	√	√	5
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	SDARS	√	√	√	√	5
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	TBC	√	√	√	√	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	TCM	√	√	√	√	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2009 - 2010	APIM	√	√	√	√	○
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2010	GPSM	√	√	√	○	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	AHCM	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	APIM	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	CDIM	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	GPCM	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	GPSM	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	NOx#1	√	√	√	○	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	ABS	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	ACM	√	√	√	○	5
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	BCM#1	√	√	√	√	000A 000F 0042
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	DCSM	√	√	√	√	5
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	DSM	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	HVAC	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	IPC	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	PAM	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	RCM	√	√	√	√	5
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	SCCM	√	√	√	√	5
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	SDARS	√	√	√	√	5
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	TBC	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	TCCM	√	√	√	√	○
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	TPM	√	√	√	√	○

F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2013	PCM	√	√	√	√	0009 0058 0059 0091 0093 0095 009B 009C 009D 009E 009F 00A0 0000 000F 0023
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2013	TCM	√	√	√	√	25
F-Series Super Duty	6.8L	2V	2004	ABS/TCS	√	√	√	√	8
F-Series Super Duty	6.8L	2V	2004	HEC	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2004	OTC	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2004	PATS	√	√	√	√	9
F-Series Super Duty	6.8L	2V	2004 - 2007	GEM	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2004 - 2007	VSM	√	√	√	√	000A 000F
F-Series Super Duty	6.8L	2V	2004 - 2008	PAM	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2004 - 2008	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
F-Series Super Duty	6.8L	2V	2004 - 2008	RCM	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2005 - 2007	EATC	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2005 - 2008	ABS	√	√	√	√	8
F-Series Super Duty	6.8L	2V	2005 - 2008	IC	√	√	√	√	9
F-Series Super Duty	6.8L	2V	2005 - 2008	TBC	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2008	4X4	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2008	ACM	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2008	DSM	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2008	GEM / SJB	√	√	√	√	000A 000F 0042
F-Series Super Duty	6.8L	2V	2008	HVAC	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2008	RETM	√	√	√	√	○
F-Series Super Duty	6.8L	2V	2008	SDARS	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2005 - 2007	EATC	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2005 - 2007	GEM	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2005 - 2007	VSM	√	√	√	√	000A 000F
F-Series Super Duty	6.8L	3V	2005 - 2010	IC	√	√	√	√	9
F-Series Super Duty	6.8L	3V	2005 - 2012	ABS	√	√	√	√	8
F-Series Super Duty	6.8L	3V	2005 - 2012	PAM	√	√	√	√	○

F-Series Super Duty	6.8L	3V	2005 - 2012	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C5 0009
F-Series Super Duty	6.8L	3V	2005 - 2012	RCM	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2005 - 2012	TBC	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2008 - 2010	4X4	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2008 - 2010	GEM / SJB	√	√	√	√	000A 000F 0042
F-Series Super Duty	6.8L	3V	2008 - 2010	RETM	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2008 - 2011	SDARS	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2008 - 2012	ACM	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2008 - 2012	DSM	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2008 - 2012	HVAC	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2009 - 2012	APIM	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2010 - 2012	GPSM	√	√	√	○	○
F-Series Super Duty	6.8L	3V	2011 - 2012	BCM#1	√	√	√	√	000A 000F 0042
F-Series Super Duty	6.8L	3V	2011 - 2012	DCSM	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2011 - 2012	IPC	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2011 - 2012	SCCM	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2011 - 2012	TCCM	√	√	√	√	○
F-Series Super Duty	6.8L	3V	2011 - 2012	TPM	√	√	√	√	○
F-Series Super Duty	6.8L	Other	1999 - 2001	ECS	√	√	√	√	○
F-Series Super Duty	6.8L	Other	1999 - 2003	ABS/TCS	√	√	√	√	8
F-Series Super Duty	6.8L	Other	1999 - 2003	GEM	√	√	√	√	○
F-Series Super Duty	6.8L	Other	1999 - 2003	OTC	√	√	√	√	○
F-Series Super Duty	6.8L	Other	1999 - 2003	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
F-Series Super Duty	6.8L	Other	2000 - 2001	AFCM	√	√	√	√	○
F-Series Super Duty	6.8L	Other	2000 - 2003	PATS	√	√	√	√	9
F-Series Super Duty	6.8L	Other	2001 - 2003	PAM	√	√	√	√	○
F-Series Super Duty	6.8L	Other	2001 - 2003	RCM	√	√	√	√	○
F-Series Super Duty	6.8L	Other	2002	CSM	√	√	√	√	000A 000F
F-Series Super Duty	6.8L	Other	2002 - 2003	HEC	√	√	√	√	○
F-Series Super Duty	6.8L	Other	2003	FOH	√	√	√	√	○

F-Series Super Duty	6.8L	Other	2003	VSM	√	√	√	√	000A 000F
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2001	ECS	√	√	√	√	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	ABS/TCS	√	√	√	√	8
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	GEM	√	√	√	√	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	OTC	√	√	√	√	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	PCM	√	√	√	√	0025 0010 0028 0031 0033
F-Series Super Duty	7.3L	Direct Injection - Turbo	2000 - 2003	PATS	√	√	√	√	9
F-Series Super Duty	7.3L	Direct Injection - Turbo	2001 - 2003	PAM	√	√	√	√	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	2001 - 2003	RCM	√	√	√	√	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	2002	CSM	√	√	√	√	000A 000F
F-Series Super Duty	7.3L	Direct Injection - Turbo	2002 - 2003	HEC	√	√	√	√	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	2003	FOH	√	√	√	√	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	2003	VSM	√	√	√	√	000A 000F
F350/4000	3.9L	Cummins Diesel	2009	4X4	√	√	√	√	○
F350/4000	3.9L	Cummins Diesel	2009	GEM	√	√	√	√	○
F350/4000	3.9L	Cummins Diesel	2009	TBM	√	√	√	√	○
FAMILIA / LASER	1.3L	B3	1998	ABS	√	√	√	√	○
FAMILIA / LASER	1.3L	B3	1998	PCM	√	√	√	√	○
FAMILIA / LASER	1.5L	ZL	1998 - 2000	ABS	√	√	√	√	○
FAMILIA / LASER	1.5L	ZL	1998 - 2002	PCM	√	√	√	√	○
FAMILIA / LASER	1.5L	ZL	2000 - 2002	ABS/TCS	√	√	√	√	○
FAMILIA / LASER	1.8L	FP	1998	ABS	√	√	√	√	○
FAMILIA / LASER	1.8L	FP	1998	PCM	√	√	√	√	○
FAMILIA / LASER	2.0L	FS	1999 - 2000	ABS	√	√	√	√	○
FAMILIA / LASER	2.0L	FS	1999 - 2002	PCM	√	√	√	√	○
FAMILIA / LASER	2.0L	FS	2002	ABS/TCS	√	√	√	√	○
FAMILIA / LASER	2.0L	RF	1998	ABS	√	√	√	√	○
FAMILIA / LASER	2.0L	RF	1998	PCM	√	√	√	√	○
FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2010	ABS/TCS	√	√	√	√	8
FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2010	IC	√	√	√	√	○
FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2010	PCM	√	√	√	√	25
FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2010	RCM	√	√	√	√	○
FIGO	1.4L	DURATEC 16V	2010 - 2011	ABS/TCS	√	√	√	√	8
FIGO	1.4L	DURATEC 16V	2010 - 2011	IC	√	√	√	√	○
FIGO	1.4L	DURATEC 16V	2010 - 2011	PCM	√	√	√	√	25
FIGO	1.4L	DURATEC 16V	2010 - 2011	RCM	√	√	√	√	○
FIGO	1.4L	DURATEC 16V	2011	GEM	√	√	√	√	○
FIGO	1.6L	DURATEC 16V	2011	ABS/TCS	√	√	√	√	8
FIGO	1.6L	DURATEC 16V	2011	GEM	√	√	√	√	○
FIGO	1.6L	DURATEC 16V	2011	IC	√	√	√	√	○
FIGO	1.6L	DURATEC 16V	2011	PCM	√	√	√	√	25
FIGO	1.6L	DURATEC 16V	2011	RCM	√	√	√	√	○
FIGO	1_19L	DURATEC 16V	2010	ABS/TCS	√	√	√	√	8
FIGO	1_19L	DURATEC 16V	2010	IC	√	√	√	√	○
FIGO	1_19L	DURATEC 16V	2010	PCM	√	√	√	√	25
FIGO	1_19L	DURATEC 16V	2010	RCM	√	√	√	√	○

FIGO	Other	DURATEC 16V	2011	ABS/TCS	√	√	√	√	○
FIGO	Other	DURATEC 16V	2011	GEM	√	√	√	√	○
FIGO	Other	DURATEC 16V	2011	IC	√	√	√	√	○
FIGO	Other	DURATEC 16V	2011	RCM	√	√	√	√	○
FORD GT	5.4L	4V	2005 - 2006	ABS/TCS	√	√	√	√	8
FORD GT	5.4L	4V	2005 - 2006	AFCM	√	√	√	√	○
FORD GT	5.4L	4V	2005 - 2006	GEM	√	√	√	√	000A
FORD GT	5.4L	4V	2005 - 2006	IC	√	√	√	√	○
FORD GT	5.4L	4V	2005 - 2006	PATS	√	√	√	√	9
FORD GT	5.4L	4V	2005 - 2006	PCM	√	√	√	√	0023 0025
FORD GT	5.4L	4V	2005 - 2006	RCM	√	√	√	√	○
FRIENDEE / FREDA / BONGO FRIENDEE	2.0L	FE	1997 - 2002	PCM	√	√	√	√	○
FRIENDEE / FREDA / BONGO FRIENDEE	2.0L	FE	2002	TCM	√	√	√	√	○
FRIENDEE / FREDA / BONGO FRIENDEE	2.5L	WL_T	1999	PCM	√	√	√	√	○
Fairlane / LTD	4.0L	DOHC VCT	2003 - 2006	ABS/TCS	√	√	√	√	8
Fairlane / LTD	4.0L	DOHC VCT	2003 - 2006	ACM	√	√	√	√	003B 0040
Fairlane / LTD	4.0L	DOHC VCT	2003 - 2006	BEM	√	√	√	√	0005 0009 0035 0102 0103 0104 0105 0107 0108 0109 010A 010D 010E 0110 0111
Fairlane / LTD	4.0L	DOHC VCT	2003 - 2006	HIM	√	√	√	√	0005 003A
Fairlane / LTD	4.0L	DOHC VCT	2003 - 2006	IC	√	√	√	√	0044 005F 0061 0062 0069 0106 010B 010C 010F
Fairlane / LTD	4.0L	DOHC VCT	2003 - 2006	PAM	√	√	√	√	5
Fairlane / LTD	4.0L	DOHC VCT	2003 - 2006	PCM	√	√	√	√	0023 0025 0045
Fairlane / LTD	4.0L	DOHC VCT	2003 - 2006	RCM	√	√	√	√	○
Fairlane / LTD	4.0L	DOHC VCT	2006	ABS	√	√	√	√	0005 0008
Fairlane / LTD	4.0L	DOHC VCT	2006	TCM	√	√	√	√	○
Fairlane / LTD	4.0L	Other	Other	ABS	√	√	√	√	8
Fairlane / LTD	5.0L	Other	Other	ABS	√	√	√	√	8
Fairlane / LTD	5.4L	3V	2003 - 2006	ABS/TCS	√	√	√	√	8
Fairlane / LTD	5.4L	3V	2003 - 2006	ACM	√	√	√	√	003B 0040

Fairlane / LTD	5.4L	3V	2003 - 2006	BEM	√	√	√	√	0009 0035 0102 0103 0104 0105 0107 0108 0109 010A 010D 010E 0110 0111 0005
Fairlane / LTD	5.4L	3V	2003 - 2006	HIM	√	√	√	√	003A 0005
Fairlane / LTD	5.4L	3V	2003 - 2006	IC	√	√	√	√	0044 005F 0061 0062 0069 0106 010B 010C 010F
Fairlane / LTD	5.4L	3V	2003 - 2006	PAM	√	√	√	√	5
Fairlane / LTD	5.4L	3V	2003 - 2006	PCM	√	√	√	√	0023 0025 0045
Fairlane / LTD	5.4L	3V	2003 - 2006	RCM	√	√	√	√	○
Fairlane / LTD	5.4L	3V	2006	ABS	√	√	√	√	0005 0008
Fairlane / LTD	5.4L	3V	2006	TCM	√	√	√	√	○
Fairmont	4.0L	DOHC VCT	2003 - 2006	ABS/TCS	√	√	√	√	8
Fairmont	4.0L	DOHC VCT	2003 - 2006	ACM	√	√	√	√	003B 0040
Fairmont	4.0L	DOHC VCT	2003 - 2006	BEM	√	√	√	√	0005 0009 0035 0102 0103 0104 0105 0107 0108 0109 010A 010D 010E 0110 0111
Fairmont	4.0L	DOHC VCT	2003 - 2006	HIM	√	√	√	√	0005 003A
Fairmont	4.0L	DOHC VCT	2003 - 2006	IC	√	√	√	√	0044 005F 0061 0062 0069 0106 010B 010C 010F
Fairmont	4.0L	DOHC VCT	2003 - 2006	PAM	√	√	√	√	5
Fairmont	4.0L	DOHC VCT	2003 - 2006	PCM	√	√	√	√	0023 0025 0045
Fairmont	4.0L	DOHC VCT	2003 - 2006	RCM	√	√	√	√	○
Fairmont	4.0L	DOHC VCT	2006	ABS	√	√	√	√	0005 0008
Fairmont	4.0L	DOHC VCT	2006	TCM	√	√	√	√	○
Fairmont	4.0L	Other	Other	ABS	√	√	√	√	8
Fairmont	5.0L	Other	Other	ABS	√	√	√	√	8
Fairmont	5.0L	Other	Other	ABS	√	√	√	√	8
Fairmont	5.4L	3V	2003 - 2006	ABS/TCS	√	√	√	√	8
Fairmont	5.4L	3V	2003 - 2006	ACM	√	√	√	√	003B 0040
Fairmont	5.4L	3V	2003 - 2006	BEM	√	√	√	√	0009 0035 0102 0103 0104 0105 0107 0108 0109 010A 010D 010E 0110 0111 0005

Fairmont	5.4L	3V	2003 - 2006	HIM	√	√	√	√	003A 0005
Fairmont	5.4L	3V	2003 - 2006	IC	√	√	√	√	0044 005F 0061 0062 0069 0106 010B 010C 010F
Fairmont	5.4L	3V	2003 - 2006	PAM	√	√	√	√	5
Fairmont	5.4L	3V	2003 - 2006	PCM	√	√	√	√	0023 0025 0045
Fairmont	5.4L	3V	2003 - 2006	RCM	√	√	√	√	○
Fairmont	5.4L	3V	2006	ABS	√	√	√	√	0005 0008
Fairmont	5.4L	3V	2006	TCM	√	√	√	√	○
Festiva	1.5L	Other	Other	PCM	√	√	√	√	25
Festiva Sedan	1.5L	Other	Other	PCM	√	√	√	√	○
Fiesta	1.25L	DURATEC 16V	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta	1.25L	DURATEC 16V	2002 - 2006	GEM	√	√	√	√	○
Fiesta	1.25L	DURATEC 16V	2002 - 2006	IC	√	√	√	√	○
Fiesta	1.25L	DURATEC 16V	2002 - 2008	PCM	√	√	√	√	0009 0025
Fiesta	1.25L	DURATEC 16V	2002 - 2008	RCM	√	√	√	√	○
Fiesta	1.25L	DURATEC 16V	2006	EATC	√	√	√	√	○
Fiesta	1.25L	DURATEC 16V	2006 - 2008	ACM	√	√	√	√	○
Fiesta	1.25L	DURATEC 16V	2006 - 2008	SRM	√	√	√	√	○
Fiesta	1.25L	DURATEC 16V	2008	ABS	√	√	√	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.25L	DURATEC 16V	2008	BCMii	√	√	√	√	○
Fiesta	1.25L	DURATEC 16V	2008	FCDIM	√	√	√	√	0
Fiesta	1.25L	DURATEC 16V	2008	HVAC	√	√	√	√	○
Fiesta	1.25L	DURATEC 16V	2008	IPC	√	√	√	√	9
Fiesta	1.25L	DURATEC 16V	2008	PSCM	√	√	√	○	00D7 00D8 00DA 00DC
Fiesta	1.25L	DURATEC 16V	2008	RFA	√	√	√	○	○
Fiesta	1.3L	BZ	2008	ABS	√	√	√	○	002B 002C 0054 00D9 00DB
Fiesta	1.3L	BZ	2008	ACM	√	√	√	√	○
Fiesta	1.3L	BZ	2008	BCMii	√	√	√	√	○
Fiesta	1.3L	BZ	2008	FCDIM	√	√	√	√	○
Fiesta	1.3L	BZ	2008	HVAC	√	√	√	√	○
Fiesta	1.3L	BZ	2008	IPC	√	√	√	√	9
Fiesta	1.3L	BZ	2008	PCM	√	√	√	√	○
Fiesta	1.3L	BZ	2008	PSCM	√	√	√	○	00D7 00D8 00DA 00DC
Fiesta	1.3L	BZ	2008	RCM	√	√	√	○	○
Fiesta	1.3L	BZ	2008	RFA	√	√	√	○	○
Fiesta	1.3L	BZ	2008	SRM	√	√	√	○	○
Fiesta	1.3L	DURATEC 8V	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta	1.3L	DURATEC 8V	2002 - 2006	GEM	√	√	√	√	○
Fiesta	1.3L	DURATEC 8V	2002 - 2006	IC	√	√	√	√	○
Fiesta	1.3L	DURATEC 8V	2002 - 2006	PCM	√	√	√	√	0009 0025
Fiesta	1.3L	DURATEC 8V	2002 - 2006	RCM	√	√	√	√	○
Fiesta	1.3L	DURATEC 8V	2006	ACM	√	√	√	√	○
Fiesta	1.3L	DURATEC 8V	2006	EATC	√	√	√	√	○
Fiesta	1.3L	DURATEC 8V	2006	SRM	√	√	√	√	○
Fiesta	1.4L	DURATEC 16V	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta	1.4L	DURATEC 16V	2002 - 2006	GEM	√	√	√	√	○
Fiesta	1.4L	DURATEC 16V	2002 - 2006	IC	√	√	√	√	○
Fiesta	1.4L	DURATEC 16V	2002 - 2006	TCM	√	√	√	√	○
Fiesta	1.4L	DURATEC 16V	2002 - 2008	PCM	√	√	√	√	0009 0025

Fiesta	1.4L	DURATEC 16V	2002 - 2008	RCM	√	√	√	√	○
Fiesta	1.4L	DURATEC 16V	2006	EATC	√	√	√	√	○
Fiesta	1.4L	DURATEC 16V	2006 - 2008	ACM	√	√	√	√	○
Fiesta	1.4L	DURATEC 16V	2006 - 2008	SRM	√	√	√	√	○
Fiesta	1.4L	DURATEC 16V	2008	ABS	√	√	√	○	0.00E+00
Fiesta	1.4L	DURATEC 16V	2008	BCMii	√	√	√	√	○
Fiesta	1.4L	DURATEC 16V	2008	FCDIM	√	√	√	√	0
Fiesta	1.4L	DURATEC 16V	2008	HVAC	√	√	√	√	○
Fiesta	1.4L	DURATEC 16V	2008	IPC	√	√	√	√	9
Fiesta	1.4L	DURATEC 16V	2008	PSCM	√	√	√	○	○
Fiesta	1.4L	DURATEC 16V	2008	RFA	√	√	√	○	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	TCM	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PCM	√	√	√	√	9
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	ACM	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	SRM	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	√	√	√	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	√	√	√	√	0
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	√	√	√	√	9
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	√	√	√	○	00D7 00D8 00DA 00DC
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	√	√	√	○	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	√	√	√	○	002B 0054 00D9 00DB 00E8
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	BCMii	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FCDIM	√	√	√	√	0
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HVAC	√	√	√	√	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IPC	√	√	√	√	9
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	√	√	√	○	0090 0092 0098 0099 009A 00AF 00B0 00B1 00B2 00B8 00B9 00BD
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PSCM	√	√	√	○	00D7 00D8 00DA 00DC
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	√	√	√	○	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RFA	√	√	√	○	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	√	√	√	○	○

Fiesta	1.5L	BZ	2008	ABS	√	√	√	○	002B 002C 0054 00D9 00DB
Fiesta	1.5L	BZ	2008	ACM	√	√	√	√	○
Fiesta	1.5L	BZ	2008	BCMii	√	√	√	√	○
Fiesta	1.5L	BZ	2008	FCDIM	√	√	√	√	○
Fiesta	1.5L	BZ	2008	HVAC	√	√	√	√	○
Fiesta	1.5L	BZ	2008	IPC	√	√	√	√	9
Fiesta	1.5L	BZ	2008	PCM	√	√	√	√	○
Fiesta	1.5L	BZ	2008	PSCM	√	√	√	○	00D7 00D8 00DA 00DC
Fiesta	1.5L	BZ	2008	RCM	√	√	√	○	○
Fiesta	1.5L	BZ	2008	RFA	√	√	√	○	○
Fiesta	1.5L	BZ	2008	SRM	√	√	√	○	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	√	√	√	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	√	√	√	√	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	√	√	√	√	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	√	√	√	√	0
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	√	√	√	√	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	√	√	√	√	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	√	√	√	○	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	√	√	√	○	00D7 00D8 00DA 00DC
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	√	√	√	○	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	√	√	√	○	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	√	√	√	○	○
Fiesta	1.5L	TiVCT	2008	ABS	√	√	√	○	○
Fiesta	1.5L	TiVCT	2008	ACM	√	√	√	√	○
Fiesta	1.5L	TiVCT	2008	BCMii	√	√	√	√	○
Fiesta	1.5L	TiVCT	2008	FCDIM	√	√	√	√	○
Fiesta	1.5L	TiVCT	2008	HVAC	√	√	√	√	○
Fiesta	1.5L	TiVCT	2008	IPC	√	√	√	√	9
Fiesta	1.5L	TiVCT	2008	PCM	√	√	√	√	○
Fiesta	1.5L	TiVCT	2008	PSCM	√	√	√	○	○
Fiesta	1.5L	TiVCT	2008	RCM	√	√	√	○	○
Fiesta	1.5L	TiVCT	2008	RFA	√	√	√	○	○
Fiesta	1.5L	TiVCT	2008	SRM	√	√	√	○	○
Fiesta	1.6L	DURATEC 16V	2002	TCM	√	√	√	√	○
Fiesta	1.6L	DURATEC 16V	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta	1.6L	DURATEC 16V	2002 - 2006	GEM	√	√	√	√	○
Fiesta	1.6L	DURATEC 16V	2002 - 2006	IC	√	√	√	√	○
Fiesta	1.6L	DURATEC 16V	2002 - 2006	PCM	√	√	√	√	0009 0025
Fiesta	1.6L	DURATEC 16V	2002 - 2006	RCM	√	√	√	√	○
Fiesta	1.6L	DURATEC 16V	2006	ACM	√	√	√	√	○
Fiesta	1.6L	DURATEC 16V	2006	EATC	√	√	√	√	○
Fiesta	1.6L	DURATEC 16V	2006	SRM	√	√	√	√	○
Fiesta	1.6L	DURATEC VCT	2008	ABS	√	√	√	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.6L	DURATEC VCT	2008	ACM	√	√	√	√	○
Fiesta	1.6L	DURATEC VCT	2008	BCMii	√	√	√	√	○
Fiesta	1.6L	DURATEC VCT	2008	FCDIM	√	√	√	√	0
Fiesta	1.6L	DURATEC VCT	2008	HVAC	√	√	√	√	○
Fiesta	1.6L	DURATEC VCT	2008	IPC	√	√	√	√	9
Fiesta	1.6L	DURATEC VCT	2008	PCM	√	√	√	√	0025 00BC
Fiesta	1.6L	DURATEC VCT	2008	PSCM	√	√	√	○	00D7 00D8 00DA 00DC
Fiesta	1.6L	DURATEC VCT	2008	RCM	√	√	√	○	○
Fiesta	1.6L	DURATEC VCT	2008	RFA	√	√	√	○	○
Fiesta	1.6L	DURATEC VCT	2008	SRM	√	√	√	○	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012

Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	EPS	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PCM	√	√	√	√	0009 0092 0096 0097 0099 009A 00AD 00AE 0090 0098 00AA 00B0 00B1
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	ACM	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	SRM	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	√	√	√	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	√	√	√	√	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	√	√	√	√	9
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	√	√	√	○	00D7 00D8 00DA 00DC
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	√	√	√	○	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	√	√	√	○	002B 002C 0054 00D9 00DB 00E8
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	BCMii	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FCDIM	√	√	√	√	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HVAC	√	√	√	√	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IPC	√	√	√	√	9
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	√	√	√	○	0090 0092 0098 0099 009A 00AF 00B0 00B1 00B2 00B8 00B9 00BD
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PSCM	√	√	√	○	00D7 00D8 00DA 00DC
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	√	√	√	○	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RFA	√	√	√	○	○
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	√	√	√	○	○
Fiesta	1.6L	Sigma	2011 - 2012	ABS	√	√	√	√	0008 0012
Fiesta	1.6L	Sigma	2011 - 2012	ACM	√	√	√	○	○
Fiesta	1.6L	Sigma	2011 - 2012	APIM	√	√	√	√	○

Fiesta	1.6L	Sigma	2011 - 2012	BCM#1	√	√	√	√	○
Fiesta	1.6L	Sigma	2011 - 2012	FCDIM	√	√	√	√	○
Fiesta	1.6L	Sigma	2011 - 2012	GPSM	√	√	√	○	○
Fiesta	1.6L	Sigma	2011 - 2012	IPC	√	√	√	√	○
Fiesta	1.6L	Sigma	2011 - 2012	OCSM	√	√	√	○	000C
Fiesta	1.6L	Sigma	2011 - 2012	PCM	√	√	√	√	0009 0025
Fiesta	1.6L	Sigma	2011 - 2012	PSCM	√	√	√	○	00CB 00CC
Fiesta	1.6L	Sigma	2011 - 2012	RCM	√	√	√	○	○
Fiesta	1.6L	Sigma	2011 - 2012	RFA	√	√	√	○	○
Fiesta	1.6L	Sigma	2011 - 2012	TBM	√	√	√	√	○
Fiesta	1.6L	Sigma	2011 - 2012	TCM	√	√	√	√	○
Fiesta	1.6L	Sigma	2011 - 2012	VSM	√	√	√	√	42
Fiesta	1.6L	TDCi ECO II	2008	ABS	√	√	√	○	002B 002C 0054 00D9 00DB
Fiesta	1.6L	TDCi ECO II	2008	ACM	√	√	√	√	○
Fiesta	1.6L	TDCi ECO II	2008	BCMii	√	√	√	√	○
Fiesta	1.6L	TDCi ECO II	2008	FCDIM	√	√	√	√	○
Fiesta	1.6L	TDCi ECO II	2008	HVAC	√	√	√	√	○
Fiesta	1.6L	TDCi ECO II	2008	IPC	√	√	√	√	○
Fiesta	1.6L	TDCi ECO II	2008	PCM	√	√	√	√	○
Fiesta	1.6L	TDCi ECO II	2008	PSCM	√	√	√	○	00D7 00D8 00DA 00DC
Fiesta	1.6L	TDCi ECO II	2008	RCM	√	√	√	○	○
Fiesta	1.6L	TDCi ECO II	2008	RFA	√	√	√	○	○
Fiesta	1.6L	TDCi ECO II	2008	SRM	√	√	√	○	○
Fiesta	1.6L	TiVCT	2008	BCMii	√	√	√	√	○
Fiesta	1.6L	TiVCT	2008	HVAC	√	√	√	√	○
Fiesta	1.6L	TiVCT	2008	SRM	√	√	√	○	○
Fiesta	1.6L	TiVCT	2008 - 2013	ABS	√	√	√	√	12
Fiesta	1.6L	TiVCT	2008 - 2013	ACM	√	√	√	○	○
Fiesta	1.6L	TiVCT	2008 - 2013	FCDIM	√	√	√	√	○
Fiesta	1.6L	TiVCT	2008 - 2013	IPC	√	√	√	√	9
Fiesta	1.6L	TiVCT	2008 - 2013	PCM	√	√	√	√	0009 0023
Fiesta	1.6L	TiVCT	2008 - 2013	PSCM	√	√	√	○	00CB 00CC
Fiesta	1.6L	TiVCT	2008 - 2013	RCM	√	√	√	○	○
Fiesta	1.6L	TiVCT	2008 - 2013	RFA	√	√	√	○	000A
Fiesta	1.6L	TiVCT	2008 - 2013	TCM	√	√	√	√	○
Fiesta	1.6L	TiVCT	2011 - 2013	APIM	√	√	√	√	○
Fiesta	1.6L	TiVCT	2011 - 2013	BCM#1	√	√	√	√	○
Fiesta	1.6L	TiVCT	2011 - 2013	GPSM	√	√	√	○	○
Fiesta	1.6L	TiVCT	2011 - 2013	OCSM	√	√	√	○	000C
Fiesta	1.6L	TiVCT	2011 - 2013	VSM	√	√	√	√	42
Fiesta / Ikon	1.4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	√	√	√	√	8
Fiesta / Ikon	1.4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	GEM	√	√	√	√	○
Fiesta / Ikon	1.4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	IC	√	√	√	√	○
Fiesta / Ikon	1.4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	√	√	√	√	9
Fiesta / Ikon	1.4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	√	√	√	√	○
Fiesta / Ikon	1.4L	DURATEC 16V	2006	ABS/TCS	√	√	√	√	8
Fiesta / Ikon	1.4L	DURATEC 16V	2006	GEM	√	√	√	√	○
Fiesta / Ikon	1.4L	DURATEC 16V	2006	IC	√	√	√	√	○
Fiesta / Ikon	1.4L	DURATEC 16V	2006	PCM	√	√	√	√	0009 0025
Fiesta / Ikon	1.4L	DURATEC 16V	2006	RCM	√	√	√	√	○
Fiesta / Ikon	1.6L	DURATEC 16V	2006	ABS/TCS	√	√	√	√	8
Fiesta / Ikon	1.6L	DURATEC 16V	2006	GEM	√	√	√	√	○

Fiesta / Ikon	1.6L	DURATEC 16V	2006	IC	√	√	√	√	○
Fiesta / Ikon	1.6L	DURATEC 16V	2006	PCM	√	√	√	√	0009 0025
Fiesta / Ikon	1.6L	DURATEC 16V	2006	RCM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1996 - 1999	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1996 - 1999	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1996 - 1999	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1996 - 1999	PCM	√	√	√	√	0025 0023
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1999	ECS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999	ECS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999	GEM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999	PCM	√	√	√	√	0023 0025
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1996 - 2000	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1996 - 2000	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1996 - 2000	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1996 - 2000	PCM	√	√	√	√	0023 0025
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1999 - 2000	ECS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1999 - 2000	GEM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	2000	PATS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1996 - 1999	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1996 - 1999	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1996 - 1999	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1996 - 1999	PCM	√	√	√	√	0023 0025 0009
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999	ECS	√	√	√	√	○

Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999	GEM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994 - 1996	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994 - 1996	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994 - 1996	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	PT-E	2000	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	PT-E	2000	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	PT-E	2000	ECS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	PT-E	2000	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	PT-E	2000	PCM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996 - 1999	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996 - 1999	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996 - 1999	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996 - 1999	PCM	√	√	√	√	0023 0025 0009
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999	ECS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999	GEM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	GEM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	PATS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	PCM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	ECS	√	√	√	√	○

Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	GEM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	PCM	√	√	√	√	0023 0025
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	ECS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	GEM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	PCM	√	√	√	√	0009 0023 0025
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	ECS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	FIP	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	GEM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	PATS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	PCM	√	√	√	√	9
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996 - Other	ABS/TCS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996 - Other	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996 - Other	ECS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996 - Other	HEC	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996 - Other	PATS	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996 - Other	PCM	○	○	√	○	○
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1992 - 1994	ABS/TCS	√	√	√	√	○

Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1992 - 1994	CSM	√	√	√	√	○
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1992 - 1994	HEC	√	√	√	√	○
Fiesta 3-Door	1.25L	DURATEC 16V	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta 3-Door	1.25L	DURATEC 16V	2002 - 2006	GEM	√	√	√	√	○
Fiesta 3-Door	1.25L	DURATEC 16V	2002 - 2006	IC	√	√	√	√	○
Fiesta 3-Door	1.25L	DURATEC 16V	2002 - 2006	PCM	√	√	√	√	0009 0025
Fiesta 3-Door	1.25L	DURATEC 16V	2002 - 2006	RCM	√	√	√	√	○
Fiesta 3-Door	1.25L	DURATEC 16V	2006	ACM	√	√	√	√	○
Fiesta 3-Door	1.25L	DURATEC 16V	2006	EATC	√	√	√	√	○
Fiesta 3-Door	1.25L	DURATEC 16V	2006	SRM	√	√	√	√	○
Fiesta 3-Door	1.3L	DURATEC 8V	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta 3-Door	1.3L	DURATEC 8V	2002 - 2006	GEM	√	√	√	√	○
Fiesta 3-Door	1.3L	DURATEC 8V	2002 - 2006	IC	√	√	√	√	○
Fiesta 3-Door	1.3L	DURATEC 8V	2002 - 2006	PCM	√	√	√	√	0009 0025
Fiesta 3-Door	1.3L	DURATEC 8V	2002 - 2006	RCM	√	√	√	√	○
Fiesta 3-Door	1.3L	DURATEC 8V	2006	ACM	√	√	√	√	○
Fiesta 3-Door	1.3L	DURATEC 8V	2006	EATC	√	√	√	√	○
Fiesta 3-Door	1.3L	DURATEC 8V	2006	SRM	√	√	√	√	○
Fiesta 3-Door	1.4L	DURATEC 16V	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta 3-Door	1.4L	DURATEC 16V	2002 - 2006	GEM	√	√	√	√	○
Fiesta 3-Door	1.4L	DURATEC 16V	2002 - 2006	IC	√	√	√	√	○
Fiesta 3-Door	1.4L	DURATEC 16V	2002 - 2006	PCM	√	√	√	√	0009 0025
Fiesta 3-Door	1.4L	DURATEC 16V	2002 - 2006	RCM	√	√	√	√	○
Fiesta 3-Door	1.4L	DURATEC 16V	2002 - 2006	TCM	√	√	√	√	○
Fiesta 3-Door	1.4L	DURATEC 16V	2006	ACM	√	√	√	√	○
Fiesta 3-Door	1.4L	DURATEC 16V	2006	EATC	√	√	√	√	○
Fiesta 3-Door	1.4L	DURATEC 16V	2006	SRM	√	√	√	√	○
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	√	√	√	√	○
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	√	√	√	√	○
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	√	√	√	√	9
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	√	√	√	√	○
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	TCM	√	√	√	√	○
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	√	√	√	√	○
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	√	√	√	√	○
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	√	√	√	√	○
Fiesta 3-Door	1.6L	DURATEC 16V	2002	TCM	√	√	√	√	○
Fiesta 3-Door	1.6L	DURATEC 16V	2002 - 2006	ABS/TCS	√	√	√	√	8
Fiesta 3-Door	1.6L	DURATEC 16V	2002 - 2006	GEM	√	√	√	√	○
Fiesta 3-Door	1.6L	DURATEC 16V	2002 - 2006	IC	√	√	√	√	○
Fiesta 3-Door	1.6L	DURATEC 16V	2002 - 2006	PCM	√	√	√	√	0009 0025
Fiesta 3-Door	1.6L	DURATEC 16V	2002 - 2006	RCM	√	√	√	√	○
Fiesta 3-Door	1.6L	DURATEC 16V	2006	ACM	√	√	√	√	○
Fiesta 3-Door	1.6L	DURATEC 16V	2006	EATC	√	√	√	√	○
Fiesta 3-Door	1.6L	DURATEC 16V	2006	SRM	√	√	√	√	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	EPS	√	√	√	√	○

Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	√	√	√	√	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	√	√	√	√	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	√	√	√	√	0009 0092 0096 0097 0099 009A 00AD 00AE
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	√	√	√	√	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	√	√	√	√	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	√	√	√	√	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	√	√	√	√	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	GEM	√	√	√	√	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	IC	√	√	√	√	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	PCM	√	√	√	√	0009 0025
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	RCM	√	√	√	√	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2006	ACM	√	√	√	√	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2006	EATC	√	√	√	√	○
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2006	SRM	√	√	√	√	○
Five Hundred	3.0L	4V	2006 - 2007	4X4	√	√	√	√	○
Five Hundred	3.0L	4V	2006 - 2007	ABS	√	√	√	√	5
Five Hundred	3.0L	4V	2006 - 2007	ACM	√	√	√	√	5
Five Hundred	3.0L	4V	2006 - 2007	DSM	√	√	√	√	5
Five Hundred	3.0L	4V	2006 - 2007	EATC	√	√	√	√	○
Five Hundred	3.0L	4V	2006 - 2007	GEM	√	√	√	√	5
Five Hundred	3.0L	4V	2006 - 2007	IC	√	√	√	√	5
Five Hundred	3.0L	4V	2006 - 2007	PAM	√	√	√	√	○
Five Hundred	3.0L	4V	2006 - 2007	PCM	√	√	√	√	0009 0023
Five Hundred	3.0L	4V	2006 - 2007	RCM	√	√	√	√	5
Five Hundred	3.0L	4V	2006 - 2007	RETM	√	√	√	√	○
Five Hundred	3.0L	4V	2006 - 2007	TCM	√	√	√	√	○
Five Hundred	3.0L	4V	2007	SDARS	√	√	√	√	○
Five Hundred (MY06) / Montego (MY05)	3.0L	4V	2005	4X4	√	√	√	√	○
Five Hundred (MY06) / Montego (MY05)	3.0L	4V	2005	ABS	√	√	√	√	5
Five Hundred (MY06) / Montego (MY05)	3.0L	4V	2005	ACM	√	√	√	√	5
Five Hundred (MY06) / Montego (MY05)	3.0L	4V	2005	DSM	√	√	√	√	5
Five Hundred (MY06) / Montego (MY05)	3.0L	4V	2005	EATC	√	√	√	√	○
Five Hundred (MY06) / Montego (MY05)	3.0L	4V	2005	GEM	√	√	√	√	○
Five Hundred (MY06) / Montego (MY05)	3.0L	4V	2005	IC	√	√	√	√	5

Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	PAM	√	√	√	√	○
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	PCM	√	√	√	√	0009 0023
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	RCM	√	√	√	√	5
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	RETM	√	√	√	√	○
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	TCM	√	√	√	√	○
Flex	3.5L	4V	2009	SECM	√	√	○	○	○
Flex	3.5L	4V	2009 - 2012	4X4	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	ABS	√	√	√	√	0012 0008
Flex	3.5L	4V	2009 - 2012	ACM	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	APIM	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	DCSM	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	DSM	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	DSP	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	FCIM	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Flex	3.5L	4V	2009 - 2012	HVAC	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	IC	√	√	√	√	9
Flex	3.5L	4V	2009 - 2012	LTM	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	OCSM	√	√	√	○	000C 0015
Flex	3.5L	4V	2009 - 2012	PAM	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	PCM	√	√	√	√	0025 0023
Flex	3.5L	4V	2009 - 2012	RCM	√	√	√	√	○
Flex	3.5L	4V	2009 - 2012	RETM	√	√	√	√	○
Flex	3.5L	4V	2010 - 2011	C-CM	√	√	√	○	○
Flex	3.5L	4V	2010 - 2011	HUD	√	√	√	○	○
Flex	3.5L	4V	2010 - 2012	DDM	√	√	√	√	○
Flex	3.5L	4V	2010 - 2012	GPSM	√	√	√	○	○
Flex	3.5L	4V	2010 - 2012	HCM	√	√	√	√	○
Flex	3.5L	4V	2010 - 2012	HCM-2	√	√	√	√	○
Flex	3.5L	4V	2010 - 2012	ILCM	√	√	√	√	○
Flex	3.5L	4V	2010 - 2012	PSCM	√	√	√	○	○
Flex	3.5L	4V	2010 - 2012	SASM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	4X4	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	HCM-2	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	IC	√	√	√	√	5
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	ILCM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	RETM	√	√	√	√	○

Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	SASM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	ABS	√	√	√	√	0008 0012
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	ACM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	APIM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	C-CM	√	√	√	○	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DCSM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DDM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DSM	√	√	√	√	5
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DSP	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	FCIM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	GPSM	√	√	√	○	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HCM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HUD	√	√	√	○	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HVAC	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	LTM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	OCSM	√	√	√	√	000C 0015
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PAM	√	√	√	○	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PSCM	√	√	√	○	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	RCM	√	√	√	√	5
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	○	000A 000F 0042
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RFA	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	√	○	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	√	√	√	√	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	√	√	√	○	○
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	√	√	√	√	○
Flex	3.5L	TiVCT	2013	ABS	√	√	√	√	○
Flex	3.5L	TiVCT	2013	ACM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	APIM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	BCM#1	√	√	√	○	000A 000F 0042
Flex	3.5L	TiVCT	2013	C-CM	√	√	√	○	○

Flex	3.5L	TiVCT	2013	DCSM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	DDM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	DSM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	DSP	√	√	√	√	○
Flex	3.5L	TiVCT	2013	FCDIM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	FCIM	√	√	√	○	○
Flex	3.5L	TiVCT	2013	GPSM	√	√	√	○	○
Flex	3.5L	TiVCT	2013	HCM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	HUD	√	√	√	√	○
Flex	3.5L	TiVCT	2013	HVAC	√	√	√	√	○
Flex	3.5L	TiVCT	2013	IPC	√	√	√	√	○
Flex	3.5L	TiVCT	2013	LTM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	OCSM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	PAM	√	√	√	○	○
Flex	3.5L	TiVCT	2013	PCM	√	√	√	√	0023 0025
Flex	3.5L	TiVCT	2013	PSCM	√	√	√	○	○
Flex	3.5L	TiVCT	2013	RACM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	RCM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	RFA	√	√	√	√	○
Flex	3.5L	TiVCT	2013	RTM	√	√	√	○	○
Flex	3.5L	TiVCT	2013	SCCM	√	√	√	√	○
Flex	3.5L	TiVCT	2013	SOD-L	√	√	√	○	○
Flex	3.5L	TiVCT	2013	SOD-R	√	√	√	√	○
Flex	Other	Other	2012	4X4	√	√	√	√	○
Flex	Other	Other	2012	ABS	√	√	√	√	○
Flex	Other	Other	2012	ACM	√	√	√	√	○
Flex	Other	Other	2012	APIM	√	√	√	√	○
Flex	Other	Other	2012	DCSM	√	√	√	√	○
Flex	Other	Other	2012	DDM	√	√	√	√	○
Flex	Other	Other	2012	DSM	√	√	√	√	○
Flex	Other	Other	2012	DSP	√	√	√	√	○
Flex	Other	Other	2012	FCIM	√	√	√	√	○
Flex	Other	Other	2012	GEM / SJB	√	√	√	√	42
Flex	Other	Other	2012	GPSM	√	√	√	√	○
Flex	Other	Other	2012	HCM	√	√	√	√	○
Flex	Other	Other	2012	HCM-2	√	√	√	√	○
Flex	Other	Other	2012	HVAC	√	√	√	√	○
Flex	Other	Other	2012	IC	√	√	√	√	○
Flex	Other	Other	2012	ILCM	√	√	√	√	○
Flex	Other	Other	2012	LTM	√	√	√	√	○
Flex	Other	Other	2012	OCSM	√	√	√	√	○
Flex	Other	Other	2012	PAM	√	√	√	○	○
Flex	Other	Other	2012	PSCM	√	√	√	○	○
Flex	Other	Other	2012	RCM	√	√	√	√	○
Flex	Other	Other	2012	RETM	√	√	√	√	○
Flex	Other	Other	2012	SASM	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	√	√	√	○	002B 002C 0053 00D9 00DB
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	√	√	√	√	9
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	CCMii	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCDIM	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDSM	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	√	√	√	○	○

Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-B	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	√	√	√	○	00DC 00DF 00E0 00E1
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	√	√	√	○	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	√	√	√	√	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003	RL_DCU	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003	RR_DCU	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2007	GDM	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2007	NAV	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	ABS	√	√	√	√	0008 0029 002A 002C 00DD 00DE 00E8
Focus	1.4L	DURATEC 16V	2003 - 2008	ACM	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	CDP	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	D_DCU	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	EATC	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	FFH	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	GEM	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	HCM	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	IC	√	√	√	√	9
Focus	1.4L	DURATEC 16V	2003 - 2008	PAM	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	PCM	√	√	√	√	25
Focus	1.4L	DURATEC 16V	2003 - 2008	P_DCU	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	RCM	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	RETM	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	RKE	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2003 - 2008	SRM	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2008	CMR	√	√	√	√	○
Focus	1.4L	DURATEC 16V	2008	EPS	√	√	√	○	○
Focus	1.4L	Zetec-SE	1999	CSM	√	√	√	√	○
Focus	1.4L	Zetec-SE	1999	CTM	√	√	√	√	○
Focus	1.4L	Zetec-SE	1999 - 2002	ABS/TCS	√	√	√	√	0008 0012
Focus	1.4L	Zetec-SE	1999 - 2002	ECS	√	√	√	√	○
Focus	1.4L	Zetec-SE	1999 - 2002	HEC	√	√	√	√	○
Focus	1.4L	Zetec-SE	1999 - 2002	MC	√	√	√	√	○

Focus	1.4L	Zetec-SE	1999 - 2002	PATS	√	√	√	○	○
Focus	1.4L	Zetec-SE	1999 - 2002	PCM	√	√	√	√	0009 0023 0025
Focus	1.4L	Zetec-SE	2002	EATC	√	√	√	√	○
Focus	1.4L	Zetec-SE	2002	GEM	√	√	√	√	○
Focus	1.4L	Zetec-SE	2002	HCM	√	√	√	√	○
Focus	1.4L	Zetec-SE	2002	RCM	√	√	√	√	○
Focus	1.6L	BZ	2005	ABS	√	√	√	√	0012 0029 002A 002C 0054
Focus	1.6L	BZ	2005	D_DCU	√	√	√	√	○
Focus	1.6L	BZ	2005	EATC	√	√	√	√	○
Focus	1.6L	BZ	2005	GEM	√	√	√	√	○
Focus	1.6L	BZ	2005	HCM	√	√	√	√	○
Focus	1.6L	BZ	2005	IC	√	√	√	√	9
Focus	1.6L	BZ	2005	PAM	√	√	√	√	○
Focus	1.6L	BZ	2005	PCM	√	√	√	√	○
Focus	1.6L	BZ	2005	P_DCU	√	√	√	√	○
Focus	1.6L	BZ	2005	RCM	√	√	√	√	○
Focus	1.6L	BZ	2005	RL_DCU	√	√	√	√	○
Focus	1.6L	BZ	2005	RR_DCU	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003	RL_DCU	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003	RR_DCU	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2007	GDM	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2007	NAV	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	ABS	√	√	√	√	0008 0029 002A 002C 00DD 00DE 00E8 002B
Focus	1.6L	DURATEC 16V	2003 - 2008	ACM	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	CDP	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	D_DCU	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	EATC	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	FFH	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	GEM	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	HCM	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	IC	√	√	√	√	9
Focus	1.6L	DURATEC 16V	2003 - 2008	PAM	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	PCM	√	√	√	√	25
Focus	1.6L	DURATEC 16V	2003 - 2008	P_DCU	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	RCM	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	RETM	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	RKE	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2003 - 2008	SRM	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2006	FTCM	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2007	TCM	√	√	√	√	0070 00C5
Focus	1.6L	DURATEC 16V	2008	CMR	√	√	√	√	○
Focus	1.6L	DURATEC 16V	2008	EPS	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2003	RL_DCU	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003	RR_DCU	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2007	GDM	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2007	NAV	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2008	CDP	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2008	D_DCU	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2008	EATC	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2008	FFH	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2008	GEM	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2008	IC	√	√	√	√	9
Focus	1.6L	DURATEC VCT	2003 - 2008	P_DCU	√	√	√	√	○

Focus	1.6L	DURATEC VCT	2003 - 2008	RETM	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2008	RKE	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2011	ABS	√	√	√	○	0008 0029 002A 002C 002B 00DD 00DE
Focus	1.6L	DURATEC VCT	2003 - 2011	ACM	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2011	HCM	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2003 - 2011	PAM	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2003 - 2011	PCM	√	√	√	√	25
Focus	1.6L	DURATEC VCT	2003 - 2011	RCM	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2003 - 2011	SRM	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2008	CMR	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2008	EPS	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	AHCM	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	APIM	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2011	BCMii	√	√	√	√	9
Focus	1.6L	DURATEC VCT	2011	DDM	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	DSP	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	FCDIM	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	FCIM	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2011	HVAC	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	IPC	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2011	IPM-A	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	IPM-B	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	PDM	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	PSCM	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2011	RFA	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	SASM	√	√	√	○	○
Focus	1.6L	DURATEC VCT	2011	SOD-L	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2011	SOD-R	√	√	√	√	○
Focus	1.6L	DURATEC VCT	2011	TRM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003	RL_DCU	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003	RR_DCU	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	GDM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	NAV	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	CDP	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	D_DCU	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EATC	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EPS	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FACM	√	√	√	√	006B 0094 00A1
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FFH	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	GEM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	IC	√	√	√	√	9
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	P_DCU	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RETM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RKE	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ABS	√	√	√	√	0008 0029 002A 002B 002C 00E8 00DD 00DE
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ACM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	HCM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PAM	√	√	√	√	○

Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PCM	√	√	√	√	0090 0092 0096 0097 0098 0099 009A 00B1 00B7 00B9 00BC 00BD 00C1 00C3
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	RCM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	SRM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	APIM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	√	√	√	√	9
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DSP	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	FCIM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	√	√	√	√	120
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	√	√	√	√	0008 0029 002A 002C 00DD 00DE 00E8
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	CDP	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	CMR	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	D_DCU	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EATC	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EPS	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FFH	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	GEM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HCM	√	√	√	○	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IC	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PAM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	√	√	√	√	○

Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	P_DCU	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RETM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RKE	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	√	√	√	√	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	TCM	√	√	√	√	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	√	√	√	○	002B 002C 0053 00D9 00DB
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM	√	√	√	√	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM	√	√	√	√	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	√	√	√	√	9
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCDIM	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM	√	√	√	√	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	√	√	√	√	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-B	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	√	√	√	√	00DC 00DF 00E0 00E1
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	√	√	√	√	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	√	√	√	○	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	√	√	√	√	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	√	√	√	√	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	√	√	√	√	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	√	√	√	√	○
Focus	1.6L	FFV	2007 - 2009	ABS/TCS	√	√	√	√	0012 0008

Focus	1.6L	FFV	2007 - 2010	GEM	√	√	√	√	○
Focus	1.6L	FFV	2007 - 2010	IC	√	√	√	√	9
Focus	1.6L	FFV	2007 - 2010	PCM	√	√	√	√	0009 0025
Focus	1.6L	FFV	2007 - 2010	RCM	√	√	√	√	○
Focus	1.6L	FFV	2009	MC	√	√	√	√	○
Focus	1.6L	FFV	2009 - 2010	EATC	√	√	√	√	○
Focus	1.6L	FFV	2009 - 2010	HCM	√	√	√	√	○
Focus	1.6L	FFV	2010	ABS	√	√	√	√	0008 0029 002A 002C 0053 00DD 00DE
Focus	1.6L	FFV	2010	ACM	√	√	√	√	○
Focus	1.6L	FFV	2010	D_DCU	√	√	√	√	○
Focus	1.6L	FFV	2010	EPS	√	√	√	○	○
Focus	1.6L	FFV	2010	PAM	√	√	√	√	○
Focus	1.6L	FFV	2010	P_DCU	√	√	√	√	○
Focus	1.6L	FFV	2010	RKE	√	√	√	√	○
Focus	1.6L	FFV	2010	SRM	√	√	√	√	○
Focus	1.6L	FFV	2010	TBM	√	√	√	√	○
Focus	1.6L	FFV	2010	TCM	√	√	√	√	0070 00C5
Focus	1.6L	OHC	2009	ABS/TCS	√	√	√	√	12
Focus	1.6L	OHC	2009	EATC	√	√	√	√	○
Focus	1.6L	OHC	2009	GEM	√	√	√	√	○
Focus	1.6L	OHC	2009	HCM	√	√	√	√	○
Focus	1.6L	OHC	2009	IC	√	√	√	√	○
Focus	1.6L	OHC	2009	MC	√	√	√	√	○
Focus	1.6L	OHC	2009	PCM	√	√	√	√	0009 0025
Focus	1.6L	OHC	2009	RCM	√	√	√	√	○
Focus	1.6L	Sigma	2010	ABS	√	√	√	√	0008 0029 002A 002C 0053 00DD 00DE
Focus	1.6L	Sigma	2010	ACM	√	√	√	√	○
Focus	1.6L	Sigma	2010	D_DCU	√	√	√	√	○
Focus	1.6L	Sigma	2010	EATC	√	√	√	√	○
Focus	1.6L	Sigma	2010	EPS	√	√	√	○	○
Focus	1.6L	Sigma	2010	GEM	√	√	√	√	○
Focus	1.6L	Sigma	2010	HCM	√	√	√	○	○
Focus	1.6L	Sigma	2010	IC	√	√	√	√	9
Focus	1.6L	Sigma	2010	PAM	√	√	√	√	○
Focus	1.6L	Sigma	2010	PCM	√	√	√	√	25
Focus	1.6L	Sigma	2010	P_DCU	√	√	√	√	○
Focus	1.6L	Sigma	2010	RCM	√	√	√	√	○
Focus	1.6L	Sigma	2010	RKE	√	√	√	√	○
Focus	1.6L	Sigma	2010	SRM	√	√	√	√	○
Focus	1.6L	Sigma	2010	TBM	√	√	√	√	○
Focus	1.6L	Sigma	2010	TCM	√	√	√	√	0070 00C5
Focus	1.6L	TDCi ECO III	2011	ABS	√	√	√	○	002B 002C 0053 00D9 00DB
Focus	1.6L	TDCi ECO III	2011	ACM	√	√	√	√	○
Focus	1.6L	TDCi ECO III	2011	AHCM	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	APIM	√	√	√	√	○
Focus	1.6L	TDCi ECO III	2011	BCMii	√	√	√	√	9
Focus	1.6L	TDCi ECO III	2011	CCMii	√	√	√	√	○
Focus	1.6L	TDCi ECO III	2011	DDM	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	DSP	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	FCDIM	√	√	√	√	○
Focus	1.6L	TDCi ECO III	2011	FCIM	√	√	√	√	○
Focus	1.6L	TDCi ECO III	2011	FDSM	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	HCM	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	HVAC	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	IPC	√	√	√	√	○
Focus	1.6L	TDCi ECO III	2011	IPM-A	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	IPM-B	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	PAM	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	PCM	√	√	√	√	○
Focus	1.6L	TDCi ECO III	2011	PDM	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	PSCM	√	√	√	○	00DC 00DF 00E0 00E1
Focus	1.6L	TDCi ECO III	2011	RCM	√	√	√	√	○

Focus	1.6L	TDCi ECO III	2011	RFA	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	SASM	√	√	√	○	○
Focus	1.6L	TDCi ECO III	2011	SOD-L	√	√	√	√	○
Focus	1.6L	TDCi ECO III	2011	SOD-R	√	√	√	√	○
Focus	1.6L	TDCi ECO III	2011	SRM	√	√	√	√	○
Focus	1.6L	TDCi ECO III	2011	TRM	√	√	√	√	○
Focus	1.6L	Zetec	1999	CSM	√	√	√	√	○
Focus	1.6L	Zetec	1999	CTM	√	√	√	√	○
Focus	1.6L	Zetec	1999	PATS	√	√	√	○	○
Focus	1.6L	Zetec	1999 - 2002	ABS/TCS	√	√	√	√	0008 0012
Focus	1.6L	Zetec	1999 - 2002	ECS	√	√	√	√	○
Focus	1.6L	Zetec	1999 - 2002	HEC	√	√	√	√	○
Focus	1.6L	Zetec	1999 - 2002	PCM	√	√	√	√	0009 0023 0025
Focus	1.6L	Zetec	2002	EATC	√	√	√	√	○
Focus	1.6L	Zetec	2002	GEM	√	√	√	√	○
Focus	1.6L	Zetec	2002	HCM	√	√	√	√	○
Focus	1.6L	Zetec	2002	MC	√	√	√	√	○
Focus	1.6L	Zetec	2002	RCM	√	√	√	√	○
Focus	1.6L	Zetec Rocam	2002	ABS/TCS	√	√	√	√	0008 0012
Focus	1.6L	Zetec Rocam	2002	EATC	√	√	√	√	○
Focus	1.6L	Zetec Rocam	2002	ECS	√	√	√	√	○
Focus	1.6L	Zetec Rocam	2002	GEM	√	√	√	√	○
Focus	1.6L	Zetec Rocam	2002	HCM	√	√	√	√	○
Focus	1.6L	Zetec Rocam	2002	HEC	√	√	√	√	○
Focus	1.6L	Zetec Rocam	2002	MC	√	√	√	√	○
Focus	1.6L	Zetec Rocam	2002	PCM	√	√	√	√	0009 0023 0025
Focus	1.6L	Zetec Rocam	2002	RCM	√	√	√	√	○
Focus	1.6L	Zetec-SE	1999	CSM	√	√	√	√	○
Focus	1.6L	Zetec-SE	1999	CTM	√	√	√	√	○
Focus	1.6L	Zetec-SE	1999 - 2002	ABS/TCS	√	√	√	√	0008 0012
Focus	1.6L	Zetec-SE	1999 - 2002	ECS	√	√	√	√	○
Focus	1.6L	Zetec-SE	1999 - 2002	HEC	√	√	√	√	○
Focus	1.6L	Zetec-SE	1999 - 2002	MC	√	√	√	√	○
Focus	1.6L	Zetec-SE	1999 - 2002	PATS	√	√	√	○	○
Focus	1.6L	Zetec-SE	1999 - 2002	PCM	√	√	√	√	0023 0025 0009
Focus	1.6L	Zetec-SE	2002	EATC	√	√	√	√	○
Focus	1.6L	Zetec-SE	2002	GEM	√	√	√	√	○
Focus	1.6L	Zetec-SE	2002	HCM	√	√	√	√	○
Focus	1.6L	Zetec-SE	2002	RCM	√	√	√	√	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2005	RL_DCU	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2005	RR_DCU	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2007	GDM	√	√	√	√	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2007	NAV	√	√	√	√	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2007	TCM	√	√	√	√	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	ABS	√	√	√	√	0008 0029 002A 002B 002C 00E8 00DD 00DE 0005 0012 0054
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	ACM	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	CDP	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	D_DCU	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	EATC	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	EPS	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	FFH	√	√	√	√	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	GEM	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	HCM	√	√	√	√	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	IC	√	√	√	√	0009 0005

Focus	1.8L	DURATEC-HE / I4	2003 - 2008	PAM	√	√	√	√	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	PCM	√	√	√	√	25
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	P_DCU	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	RCM	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	RETM	√	√	√	√	5
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	RKE	√	√	√	√	○
Focus	1.8L	DURATEC-HE / I4	2003 - 2008	SRM	√	√	√	√	○
Focus	1.8L	DURATEC-HE / I4	2008	CMR	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001	CTM	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	ABS/TCS	√	√	√	√	0008 0012
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	ECS	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	HEC	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	ICU	○	○	√	○	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	MC	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2008	FFH	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2008	PCM	√	√	√	√	0009 0092 0092 006F 00B4
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	HCM	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003	RL_DCU	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003	RR_DCU	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	GDM	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	NAV	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	ABS	√	√	√	√	0008 0029 002A 002B 002C 00E8 00DD 00DE
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	ACM	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	CDP	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	D_DCU	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EPS	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	IC	√	√	√	√	9
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	PAM	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	P_DCU	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RETM	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RKE	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	SRM	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	√	√	√	√	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	FACM	√	√	√	√	006B
Focus	1.8L	Endura DI	1999	CSM	√	√	√	√	○
Focus	1.8L	Endura DI	1999	CTM	√	√	√	√	○
Focus	1.8L	Endura DI	1999 - 2002	ABS/TCS	√	√	√	√	0008 0012
Focus	1.8L	Endura DI	1999 - 2002	ECS	√	√	√	√	○
Focus	1.8L	Endura DI	1999 - 2002	FFH	√	√	√	√	○
Focus	1.8L	Endura DI	1999 - 2002	FIP	√	√	√	√	○
Focus	1.8L	Endura DI	1999 - 2002	HEC	√	√	√	√	○
Focus	1.8L	Endura DI	1999 - 2002	MC	√	√	√	√	○

Focus	1.8L	Endura DI	1999 - 2002	PATS	√	√	√	○	○
Focus	1.8L	Endura DI	1999 - 2002	PCM	√	√	√	√	9
Focus	1.8L	Endura DI	2002	EATC	√	√	√	√	○
Focus	1.8L	Endura DI	2002	GEM	√	√	√	√	○
Focus	1.8L	Endura DI	2002	HCM	√	√	√	√	○
Focus	1.8L	Endura DI	2002	RCM	√	√	√	√	○
Focus	1.8L	Zetec	1999	CSM	√	√	√	√	○
Focus	1.8L	Zetec	1999	CTM	√	√	√	√	○
Focus	1.8L	Zetec	1999	PATS	√	√	√	○	○
Focus	1.8L	Zetec	1999 - 2002	ABS/TCS	√	√	√	√	0008 0012
Focus	1.8L	Zetec	1999 - 2002	ECS	√	√	√	√	○
Focus	1.8L	Zetec	1999 - 2002	HEC	√	√	√	√	○
Focus	1.8L	Zetec	1999 - 2002	MC	√	√	√	√	○
Focus	1.8L	Zetec	1999 - 2002	PCM	√	√	√	√	0009 0023 0025
Focus	1.8L	Zetec	2002	AFCM	√	√	√	√	○
Focus	1.8L	Zetec	2002	EATC	√	√	√	√	○
Focus	1.8L	Zetec	2002	GEM	√	√	√	√	○
Focus	1.8L	Zetec	2002	HCM	√	√	√	√	○
Focus	1.8L	Zetec	2002	RCM	√	√	√	√	○
Focus	2.0L	DURATEC 16V	2005	ABS/TCS	√	√	√	√	0008 0012
Focus	2.0L	DURATEC 16V	2005	EATC	√	√	√	√	○
Focus	2.0L	DURATEC 16V	2005	GEM	√	√	√	√	○
Focus	2.0L	DURATEC 16V	2005	HCM	√	√	√	√	○
Focus	2.0L	DURATEC 16V	2005	IC	√	√	√	√	○
Focus	2.0L	DURATEC 16V	2005	MC	√	√	√	√	○
Focus	2.0L	DURATEC 16V	2005	PCM	√	√	√	√	0009 0023 0025
Focus	2.0L	DURATEC 16V	2005	RCM	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003	RL_DCU	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003	RR_DCU	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2007	GDM	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2007	NAV	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	CDP	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	D_DCU	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	EATC	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	EPS	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	FFH	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	GEM	√	√	√	√	000A
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	HCM	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	PAM	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	P_DCU	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	RETM	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	RKE	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	SRM	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	ABS	√	√	√	√	0008 0012 0029 002A 002B 002C 00DD 00DE 00E8 0005
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	ACM	√	√	√	√	5
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	IC	√	√	√	√	0009 0005
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	PCM	√	√	√	√	0009 0023 0025 00C5
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	RCM	√	√	√	√	000C 0005
Focus	2.0L	DURATEC-HE / I4	2006	FTCM	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2008	CMR	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2008	SDARS	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	APIM	√	√	√	○	○

Focus	2.0L	DURATEC-HE / I4	2008 - 2011	FCIM	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	FDIM	√	√	√	√	5
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	GEM / SJB	√	√	√	√	000A 000F 0042
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	HVAC	√	√	√	√	○
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	OCSM	√	√	√	○	000C
Focus	2.0L	DURATEC-HE / I4	2010 - 2011	GPSM	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2005	RL_DCU	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2005	RR_DCU	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	GDM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	NAV	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	CDP	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	D_DCU	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EATC	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EPS	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FACM	√	√	√	√	006B 0094 00A1
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FFH	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	GEM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	IC	√	√	√	√	9
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	P_DCU	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RETM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RKE	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ABS	√	√	√	○	00E8 0008 0029 002A 002B 002C 00DD 00DE 0012 0054
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ACM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	HCM	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PAM	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PCM	√	√	√	○	0092 0098 0099 009A 00A4 00B0 00B1 00B3 00B7 00B8 00B9 00BC 00BF 00C1 0090 00AB
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	RCM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	SRM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006	FTCM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008 - 2011	TCM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	APIM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	√	√	√	√	9
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DSP	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	√	√	√	○	○

Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	FCIM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	√	√	√	○	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	√	√	√	√	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	√	√	√	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	√	√	√	√	9
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	CCMii	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDSM	√	√	√	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	√	√	√	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	√	√	√	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ABS	√	√	√	○	002B 002C 0053 00D9 00DB
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ACM	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	APIM	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	DDM	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	DSP	√	√	√	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FCDIM	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FCIM	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	HVAC	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ICM#1	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	IPC	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	IPM-B	√	√	√	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PAM	√	√	○	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PCM	√	√	√	√	0023 0025
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PDM	√	√	√	√	○

Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PSCM	√	√	√	○	00CB 00CC 00DC 00DF 00E0 00E1
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	RCM	√	√	√	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	RFA	√	√	√	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	SASM	√	√	√	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCMi1	√	√	√	√	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	√	√	√	○	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	√	√	√	√	○
Focus	2.0L	FFV	2010	ABS	√	√	√	√	0008 0029 002A 002C 0053 00DD 00DE
Focus	2.0L	FFV	2010	ACM	√	√	√	√	○
Focus	2.0L	FFV	2010	D_DCU	√	√	√	√	○
Focus	2.0L	FFV	2010	EATC	√	√	√	√	○
Focus	2.0L	FFV	2010	EPS	√	√	√	○	○
Focus	2.0L	FFV	2010	GEM	√	√	√	√	○
Focus	2.0L	FFV	2010	HCM	√	√	√	○	○
Focus	2.0L	FFV	2010	IC	√	√	√	√	9
Focus	2.0L	FFV	2010	PAM	√	√	√	√	○
Focus	2.0L	FFV	2010	PCM	√	√	√	√	25
Focus	2.0L	FFV	2010	P_DCU	√	√	√	√	○
Focus	2.0L	FFV	2010	RCM	√	√	√	√	○
Focus	2.0L	FFV	2010	RKE	√	√	√	√	○
Focus	2.0L	FFV	2010	SRM	√	√	√	√	○
Focus	2.0L	FFV	2010	TBM	√	√	√	√	○
Focus	2.0L	FFV	2010	TCM	√	√	√	√	0070 00C5
Focus	2.0L	Gasoline_Direct_injection	2011	AHCM	√	√	√	○	○
Focus	**2.0L**	**Gasoline_Direct_injection**	**2011**	**BCMii**	**√**	**√**	**√**	**√**	**9**
Focus	2.0L	Gasoline_Direct_injection	2011	HCM	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011	IPM-A	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011	SOD-L	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2011	SOD-R	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2011	SRM	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2011	TRM	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	ABS	√	√	√	○	12
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	ACM	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	APIM	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	DDM	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	DSP	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	FCDIM	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	FCIM	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	HVAC	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	IPC	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	IPM-B	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	PAM	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	PCM	√	√	√	√	0025 0023
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	PDM	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	PSCM	√	√	√	√	00CB 00CC
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	RCM	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	RFA	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	SASM	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	TCM	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2012	BCMi1	√	√	√	√	○
Focus	2.0L	Gasoline_Direct_injection	2012	GPSM	√	√	√	○	○
Focus	2.0L	Gasoline_Direct_injection	2012	OCSM	√	√	√	√	○

Focus	2.0L	SPI	2000	CSM	√	√	√	√	○
Focus	2.0L	SPI	2000	CTM	√	√	√	√	000A
Focus	2.0L	SPI	2000 - 2002	ECS	√	√	√	√	○
Focus	2.0L	SPI	2000 - 2004	ABS/TCS	√	√	√	√	0008 0012
Focus	2.0L	SPI	2000 - 2004	HEC	√	√	√	√	○
Focus	2.0L	SPI	2000 - 2004	PCM	√	√	√	√	0009 0023 0025
Focus	2.0L	SPI	2002	EATC	√	√	√	√	○
Focus	2.0L	SPI	2002	HCM	√	√	√	√	○
Focus	2.0L	SPI	2002	MC	√	√	√	√	○
Focus	2.0L	SPI	2002 - 2004	GEM	√	√	√	√	000A
Focus	2.0L	SPI	2002 - 2004	RCM	√	√	√	√	○
Focus	2.0L	ZETEC ST	2002	EATC	√	√	√	√	○
Focus	2.0L	ZETEC ST	2002	ECS	√	√	√	√	○
Focus	2.0L	ZETEC ST	2002	HCM	√	√	√	√	○
Focus	2.0L	ZETEC ST	2002	MC	√	√	√	√	○
Focus	2.0L	ZETEC ST	2002 - 2004	ABS/TCS	√	√	√	√	0008 0012
Focus	2.0L	ZETEC ST	2002 - 2004	GEM	√	√	√	√	000A
Focus	2.0L	ZETEC ST	2002 - 2004	HEC	√	√	√	√	○
Focus	2.0L	ZETEC ST	2002 - 2004	PCM	√	√	√	√	0009 0025
Focus	2.0L	ZETEC ST	2002 - 2004	RCM	√	√	√	√	○
Focus	2.0L	Zetec	1999	PATS	√	√	√	○	○
Focus	2.0L	Zetec	1999 - 2000	CSM	√	√	√	√	○
Focus	2.0L	Zetec	1999 - 2000	CTM	√	√	√	√	000A
Focus	2.0L	Zetec	1999 - 2002	ECS	√	√	√	√	○
Focus	2.0L	Zetec	1999 - 2002	MC	√	√	√	√	○
Focus	2.0L	Zetec	1999 - 2004	ABS/TCS	√	√	√	√	0008 0012
Focus	2.0L	Zetec	1999 - 2004	HEC	√	√	√	√	○
Focus	2.0L	Zetec	1999 - 2004	PCM	√	√	√	√	0009 0023 0025
Focus	2.0L	Zetec	2002	EATC	√	√	√	√	○
Focus	2.0L	Zetec	2002	HCM	√	√	√	√	○
Focus	2.0L	Zetec	2002 - 2004	GEM	√	√	√	√	000A
Focus	2.0L	Zetec	2002 - 2004	RCM	√	√	√	√	○
Focus	2.3L	DURATEC-HE / I4	2003 - 2004	ABS/TCS	√	√	√	√	0008 0012
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	GEM	√	√	√	√	000A
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	IC	√	√	√	√	○
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	PCM	√	√	√	√	0009 0023 0025
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	RCM	√	√	√	√	000C
Focus	2.3L	DURATEC-HE / I4	2004	HEC	√	√	√	√	○
Focus	2.3L	DURATEC-HE / I4	2005 - 2007	ABS	√	√	√	√	0008 0012
Focus	2.5L	Duratec RS	2008	ABS	√	√	√	√	0.00E+00
Focus	2.5L	Duratec RS	2008	ACM	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	CDP	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	CMR	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	D_DCU	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	EATC	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	EPS	√	√	√	○	○
Focus	2.5L	Duratec RS	2008	FFH	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	GEM	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	HCM	√	√	√	○	○
Focus	2.5L	Duratec RS	2008	IC	√	√	√	√	9
Focus	2.5L	Duratec RS	2008	MC	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	PAM	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	PCM	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	P_DCU	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	RCM	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	RETM	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	RKE	√	√	√	√	○
Focus	2.5L	Duratec RS	2008	SRM	√	√	√	√	○
Focus	2.5L	I5	2003	RL_DCU	√	√	√	√	○
Focus	2.5L	I5	2003	RR_DCU	√	√	√	√	○
Focus	2.5L	I5	2003 - 2007	GDM	√	√	√	√	○

Focus	2.5L	I5	2003 - 2007	NAV	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	ABS	√	√	√	√	0029 002A 00DD 00DE 0008 002C
Focus	2.5L	I5	2003 - 2008	ACM	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	CDP	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	D_DCU	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	EATC	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	EPS	√	√	√	○	○
Focus	2.5L	I5	2003 - 2008	FFH	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	GEM	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	HCM	√	√	√	○	○
Focus	2.5L	I5	2003 - 2008	IC	√	√	√	√	9
Focus	2.5L	I5	2003 - 2008	MC	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	PAM	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	PCM	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	P_DCU	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	RCM	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	RETM	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	RKE	√	√	√	√	○
Focus	2.5L	I5	2003 - 2008	SRM	√	√	√	√	○
Focus	2.5L	I5	2008	CMR	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	ABS	√	√	√	○	12
Focus	23kWh	Battery_Electric_Vehicle	2012	ACCM#2	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	ACM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	APIM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	BCCM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	BCM#1	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	BECM	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	DCDC	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	DDM	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	DSP	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	FCDIM	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	FCIM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	GFM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	GPSM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	GWM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	HVAC	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	IPC	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	IPM-B	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	OCSM	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	PAM	√	√	○	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	PCM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	PDM	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	PSCM	√	√	√	√	○
Focus	23kWh	Battery_Electric_Vehicle	2012	RCM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	RFA	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	SASM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	TCM	√	√	√	○	○
Focus	23kWh	Battery_Electric_Vehicle	2012	TCU#1	√	√	√	○	○
Focus	Other	Other	2013	ABS	√	√	√	○	○
Focus	Other	Other	2013	ACM	√	√	√	√	○
Focus	Other	Other	2013	APIM	√	√	√	√	○
Focus	Other	Other	2013	BCM#1	√	√	√	√	○
Focus	Other	Other	2013	DDM	√	√	√	√	○
Focus	Other	Other	2013	DSP	√	√	√	○	○
Focus	Other	Other	2013	FCDIM	√	√	√	√	○
Focus	Other	Other	2013	FCIM	√	√	√	√	○
Focus	Other	Other	2013	GPSM	√	√	√	○	○
Focus	Other	Other	2013	HVAC	√	√	√	√	○
Focus	Other	Other	2013	IPC	√	√	√	√	○
Focus	Other	Other	2013	IPM-B	√	√	√	○	○
Focus	Other	Other	2013	OCSM	√	√	√	√	○
Focus	Other	Other	2013	PAM	√	√	○	○	○
Focus	Other	Other	2013	PDM	√	√	√	√	○
Focus	Other	Other	2013	PSCM	√	√	√	○	00CB 00CC
Focus	Other	Other	2013	RCM	√	√	√	○	○
Focus	Other	Other	2013	RFA	√	√	√	○	○

Focus	Other	Other	2013	SASM	√	√	√	○	○
Focus C-MAX	1.4L	DURATEC 16V	2002	RL_DCU	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002	RR_DCU	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	ABS	√	√	√	√	0008 0029 002A 002C 00DD 00DE 002B 00E8
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	ACM	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	CDP	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	D_DCU	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	EATC	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	EPB	√	√	√	√	001F
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	FFH	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	GDM	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	GEM	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	HCM	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	IC	√	√	√	√	9
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	NAV	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	PAM	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	PCM	√	√	√	√	25
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	P_DCU	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	RCM	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	RETM	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	RKE	√	√	√	√	○
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	SRM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002	RL_DCU	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002	RR_DCU	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2007	EPB	√	√	√	√	001F
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2007	GDM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2007	NAV	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	ABS	√	√	√	√	0008 0029 002A 002C 00DD 00DE 002B 00E8
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	ACM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	CDP	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	D_DCU	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	EATC	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	FFH	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	GEM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	HCM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	IC	√	√	√	√	9
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	PAM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	PCM	√	√	√	√	25
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	P_DCU	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	RCM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	RETM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	RKE	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	SRM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC 16V	2008	CMR	√	√	√	√	○

Focus C-MAX	1.6L	DURATEC 16V	2008	EPS	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2002	RL_DCU	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002	RR_DCU	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2007	EPB	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2007	GDM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2007	NAV	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	CDP	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	D_DCU	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	EATC	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	FFH	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	GEM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	IC	√	√	√	√	9
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	P_DCU	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	RETM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	RKE	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	ABS	√	√	√	○	002B 002C 0053 00D9 00DB 0008 0029 002A 00DD 00DE
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	ACM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	HCM	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	PAM	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	PCM	√	√	√	√	25
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	RCM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	SRM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2008	CMR	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2008	EPS	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	AHCM	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	BCMii	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2011	DDM	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	FCDIM	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	HVAC	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	IPC	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2011	IPM-A	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	IPM-B	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	PDM	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	PSCM	√	√	√	√	00DC
Focus C-MAX	1.6L	DURATEC VCT	2011	RFA	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	RGTM	√	√	√	√	○
Focus C-MAX	1.6L	DURATEC VCT	2011	SASM	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	SOD-L	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	SOD-R	√	√	√	○	○
Focus C-MAX	1.6L	DURATEC VCT	2011	TRM	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002	RL_DCU	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002	RR_DCU	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	EPB	√	√	√	√	001F
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	GDM	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	NAV	√	√	√	√	○

Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	TCM	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	CDP	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	D_DCU	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EPS	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FACM	√	√	√	√	006B 0094 00A1
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FFH	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	IC	√	√	√	√	9
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	P_DCU	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RETM	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RKE	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ABS	√	√	√	√	0008 0029 002A 002B 002C 00E8 00DD 00DE 0053 00D9 00DB
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ACM	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	HCM	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PAM	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PCM	√	√	√	√	0090 0092 0096 0097 0098 0099 009A 00B1 00B3 00B9 00BC 00BD 00C1 00C3
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	RCM	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	SRM	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	√	√	√	√	00DC 00DF 00E0 00E1
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	√	√	√	√	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	√	√	√	○	○
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	√	√	√	○	○

Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	√	√	√	○	002B 002C 0053 00D9 00DB
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM	√	√	√	√	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	√	√	√	√	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCDIM	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	√	√	√	√	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-B	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	√	√	√	√	00DC 00DF 00E0 00E1
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	√	√	√	√	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RGTM	√	√	√	√	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	√	√	√	○	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	√	√	√	√	○
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	√	√	√	○	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002	RL_DCU	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002	RR_DCU	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	EPB	√	√	√	√	001F
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	GDM	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	NAV	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	TCM	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	ABS	√	√	√	√	0008 0029 002A 002B 002C 00E8 00DD 00DE
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	ACM	√	√	√	√	5
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	CDP	√	√	√	√	5
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	D_DCU	√	√	√	√	○

Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	EATC	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	EPS	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	FFH	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	GEM	√	√	√	√	5
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	HCM	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	IC	√	√	√	√	9
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	PAM	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	PCM	√	√	√	√	25
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	P_DCU	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	RCM	√	√	√	√	5
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	RETM	√	√	√	√	5
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	RKE	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	SRM	√	√	√	√	○
Focus C-MAX	1.8L	DURATEC-HE / I4	2008	CMR	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002	RL_DCU	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002	RR_DCU	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	EPB	√	√	√	√	001F
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	GDM	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	NAV	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	ABS	√	√	√	√	0008 0029 002A 002B 002C 00E8 00DD 00DE
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	ACM	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	CDP	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	D_DCU	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EPS	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FFH	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	HCM	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	IC	√	√	√	√	9
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PAM	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PCM	√	√	√	√	006F 00B4
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	P_DCU	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RETM	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RKE	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	SRM	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	√	√	√	√	○
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	FACM	√	√	√	√	006B
Focus C-MAX	2.0L	DURATEC-HE / I4	2002	RL_DCU	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002	RR_DCU	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2007	EPB	√	√	√	√	001F
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2007	GDM	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2007	NAV	√	√	√	√	○

Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	ABS	√	√	√	√	0008 0029 002A 002B 002C 00DD 00DE 00E8
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	ACM	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	CDP	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	D_DCU	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	EATC	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	EPS	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	FFH	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	GEM	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	HCM	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	IC	√	√	√	√	9
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	PAM	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	PCM	√	√	√	√	25
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	P_DCU	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	RCM	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	RETM	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	RKE	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	SRM	√	√	√	√	○
Focus C-MAX	2.0L	DURATEC-HE / I4	2008	CMR	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002	RL_DCU	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002	RR_DCU	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	EPB	√	√	√	√	001F
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	GDM	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	NAV	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	CDP	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	D_DCU	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EPS	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FACM	√	√	√	√	006B 0094 00A1
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FFH	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	IC	√	√	√	√	9
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	P_DCU	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RETM	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RKE	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ABS	√	√	√	○	002B 002C 0053 00D9 00DB 00E8 0008 0029 002A 00DD 00DE
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ACM	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	HCM	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PAM	√	√	√	○	○

Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PCM	√	√	√	○	0092 0098 0099 009A 00A4 00B0 00B1 00B3 00B7 00B8 00B9 00BC 00BF 00C1 0090 00AB
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	RCM	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	SRM	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008 - 2011	TCM	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	√	√	√	√	00DC
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	√	√	√	√	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	√	√	√	○	○
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	√	√	√	○	○
Freestar / Monterey	3.9L	V6 OHV	2004 - 2005	ABS/TCS	√	√	√	√	0008 0012
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	DCSM	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	DSM	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	EATC	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	GEM	√	√	√	√	000A 000F
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	IC	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	LPSDM	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	LTM	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	NGSC	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	PAM	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	PCSM	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	RCM	√	√	√	√	000C
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	RPSDM	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2005	TPM	√	√	√	√	○
Freestar / Monterey	3.9L	V6 OHV	2006 - 2007	ABS	√	√	√	√	0008 0012
Freestar / Monterey	4.2L	V6 OHV	2004 - 2005	ABS/TCS	√	√	√	√	0008 0012
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	DCSM	√	√	√	√	○
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	DSM	√	√	√	√	○

Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	EATC	√	√	√	√	○
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	GEM	√	√	√	√	000A 000F
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	IC	√	√	√	√	○
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	LPSDM	√	√	√	√	○
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	LTM	√	√	√	√	○
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	NGSC	√	√	√	√	○
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	PAM	√	√	√	√	○
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	PCSM	√	√	√	√	○
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	RCM	√	√	√	√	000C
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	RPSDM	√	√	√	√	○
Freestar / Monterey	4.2L	V6 OHV	2005	TPM	√	√	√	√	○
Freestar / Monterey	4.2L	V6 OHV	2006 - 2007	ABS	√	√	√	√	0008 0012
Freestyle	3.0L	4V	2005 - 2007	4X4	√	√	√	√	○
Freestyle	3.0L	4V	2005 - 2007	ABS	√	√	√	√	0005 0008
Freestyle	3.0L	4V	2005 - 2007	ACM	√	√	√	√	5
Freestyle	3.0L	4V	2005 - 2007	DSM	√	√	√	√	5
Freestyle	3.0L	4V	2005 - 2007	EATC	√	√	√	√	○
Freestyle	3.0L	4V	2005 - 2007	GEM	√	√	√	√	0005 000A 000F
Freestyle	3.0L	4V	2005 - 2007	IC	√	√	√	√	5
Freestyle	3.0L	4V	2005 - 2007	PAM	√	√	√	√	○
Freestyle	3.0L	4V	2005 - 2007	PCM	√	√	√	√	0009 0023 0025
Freestyle	3.0L	4V	2005 - 2007	RCM	√	√	√	√	0005 000C
Freestyle	3.0L	4V	2005 - 2007	RETM	√	√	√	√	○
Freestyle	3.0L	4V	2005 - 2007	TCM	√	√	√	√	○
Freestyle	3.0L	4V	2007	SDARS	√	√	√	√	○
Fusion	1.25L	DURATEC 16V	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fusion	1.25L	DURATEC 16V	2002 - 2006	GEM	√	√	√	√	○
Fusion	1.25L	DURATEC 16V	2002 - 2006	IC	√	√	√	√	○
Fusion	1.25L	DURATEC 16V	2002 - 2006	PCM	√	√	√	√	0009 0025
Fusion	1.25L	DURATEC 16V	2002 - 2006	RCM	√	√	√	√	○
Fusion	1.25L	DURATEC 16V	2006	ACM	√	√	√	√	○
Fusion	1.25L	DURATEC 16V	2006	EATC	√	√	√	√	○
Fusion	1.25L	DURATEC 16V	2006	SRM	√	√	√	√	○
Fusion	1.4L	DURATEC 16V	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fusion	1.4L	DURATEC 16V	2002 - 2006	GEM	√	√	√	√	○
Fusion	1.4L	DURATEC 16V	2002 - 2006	IC	√	√	√	√	○
Fusion	1.4L	DURATEC 16V	2002 - 2006	PCM	√	√	√	√	0009 0025
Fusion	1.4L	DURATEC 16V	2002 - 2006	RCM	√	√	√	√	○
Fusion	1.4L	DURATEC 16V	2002 - 2006	TCM	√	√	√	√	○
Fusion	1.4L	DURATEC 16V	2006	ACM	√	√	√	√	○
Fusion	1.4L	DURATEC 16V	2006	EATC	√	√	√	√	○
Fusion	1.4L	DURATEC 16V	2006	SRM	√	√	√	√	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	√	√	√	√	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	√	√	√	√	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	√	√	√	√	9
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	√	√	√	√	○

Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	TCM	√	√	√	√	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	√	√	√	√	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	√	√	√	√	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	√	√	√	√	○
Fusion	1.6L	DURATEC 16V	2002	TCM	√	√	√	√	○
Fusion	1.6L	DURATEC 16V	2002 - 2006	ABS/TCS	√	√	√	√	8
Fusion	1.6L	DURATEC 16V	2002 - 2006	GEM	√	√	√	√	○
Fusion	1.6L	DURATEC 16V	2002 - 2006	IC	√	√	√	√	○
Fusion	1.6L	DURATEC 16V	2002 - 2006	PCM	√	√	√	√	0009 0025
Fusion	1.6L	DURATEC 16V	2002 - 2006	RCM	√	√	√	√	○
Fusion	1.6L	DURATEC 16V	2006	ACM	√	√	√	√	○
Fusion	1.6L	DURATEC 16V	2006	EATC	√	√	√	√	○
Fusion	1.6L	DURATEC 16V	2006	SRM	√	√	√	√	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	√	√	√	√	0008 0012
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	EPS	√	√	√	√	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	√	√	√	√	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	√	√	√	√	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	√	√	√	√	0009 0092 0096 0097 0099 009A 00AD 00AE
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	√	√	√	√	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	√	√	√	√	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	√	√	√	√	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	√	√	√	√	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	√	000F
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DACM-C	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	√	√	√	√	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	√	√	√	√	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GWM	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	√	√	√	√	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HUD	√	√	√	○	○

Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	√	√	√	√	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	√	√	√	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	√	√	√	√	0023 0025
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PDM	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RGTM	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-E	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-G	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-H	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	√	√	○	○	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	VDM	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	√	000F
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DACM-C	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	√	√	√	√	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	√	√	√	√	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GWM	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	√	√	√	○	○

Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	√	√	√	√	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HUD	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	√	√	√	√	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	√	√	√	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	√	√	√	√	0023 0025
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PDM	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RGTM	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-E	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-G	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-H	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	√	√	○	○	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	VDM	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	ABS	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	ACCM#2	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	ACM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	APIM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	BCM#1	√	√	√	√	000F
Fusion	2.0L	HEV / ATKINSON 4V	2013	BECM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	C-CM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	DACM-C	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	DCDC	√	√	√	√	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	DDM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	DSM	√	√	√	√	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	DSP	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	FCDIM	√	√	√	√	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	FCIM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	GFM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	GPSM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	GWM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	HCM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	HSWM	√	√	√	√	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	HUD	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	IPC	√	√	√	√	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	IPM-A	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	OCSM	√	√	√	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	PAM	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	PCM	√	√	√	√	25
Fusion	2.0L	HEV / ATKINSON 4V	2013	PDM	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	PSCM	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RACM	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RCM	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RGTM	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RTM	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCCM	√	√	○	○	○

Fusion	2.0L	HEV / ATKINSON 4V	2013	SCM-E	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCM-G	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCM-H	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SOBDM-C	√	√	√	√	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SOD-L	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SOD-R	√	√	○	○	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	VDM	√	√	○	○	○
Fusion	2.0L	PHEV	2013	ABS	√	√	√	○	○
Fusion	2.0L	PHEV	2013	ACM	√	√	√	○	○
Fusion	2.0L	PHEV	2013	APIM	√	√	√	○	○
Fusion	2.0L	PHEV	2013	BCM#1	√	√	√	√	000F
Fusion	2.0L	PHEV	2013	C-CM	√	√	√	○	○
Fusion	2.0L	PHEV	2013	DACM-C	√	√	√	○	○
Fusion	2.0L	PHEV	2013	DDM	√	√	√	○	○
Fusion	2.0L	PHEV	2013	DSM	√	√	√	√	○
Fusion	2.0L	PHEV	2013	DSP	√	√	√	○	○
Fusion	2.0L	PHEV	2013	FCDIM	√	√	√	√	○
Fusion	2.0L	PHEV	2013	FCIM	√	√	√	○	○
Fusion	2.0L	PHEV	2013	GFM	√	√	√	○	○
Fusion	2.0L	PHEV	2013	GPSM	√	√	√	○	○
Fusion	2.0L	PHEV	2013	GWM	√	√	√	○	○
Fusion	2.0L	PHEV	2013	HCM	√	√	√	○	○
Fusion	2.0L	PHEV	2013	HSWM	√	√	√	√	○
Fusion	2.0L	PHEV	2013	HUD	√	√	√	○	○
Fusion	2.0L	PHEV	2013	IPC	√	√	√	√	○
Fusion	2.0L	PHEV	2013	IPM-A	√	√	√	○	○
Fusion	2.0L	PHEV	2013	OCSM	√	√	√	○	○
Fusion	2.0L	PHEV	2013	PAM	√	√	○	○	○
Fusion	2.0L	PHEV	2013	PCM	√	√	√	√	0023 0025
Fusion	2.0L	PHEV	2013	PDM	√	√	○	○	○
Fusion	2.0L	PHEV	2013	PSCM	√	√	○	○	○
Fusion	2.0L	PHEV	2013	RACM	√	√	○	○	○
Fusion	2.0L	PHEV	2013	RCM	√	√	○	○	○
Fusion	2.0L	PHEV	2013	RGTM	√	√	○	○	○
Fusion	2.0L	PHEV	2013	RTM	√	√	○	○	○
Fusion	2.0L	PHEV	2013	SCCM	√	√	○	○	○
Fusion	2.0L	PHEV	2013	SCM-E	√	√	○	○	○
Fusion	2.0L	PHEV	2013	SCM-G	√	√	○	○	○
Fusion	2.0L	PHEV	2013	SCM-H	√	√	○	○	○
Fusion	2.0L	PHEV	2013	SOBDM-C	√	√	○	○	○
Fusion	2.0L	PHEV	2013	SOD-L	√	√	○	○	○
Fusion	2.0L	PHEV	2013	SOD-R	√	√	○	○	○
Fusion	2.0L	PHEV	2013	VDM	√	√	○	○	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2007	EATC	√	√	√	√	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2007	GEM	√	√	√	√	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	ABS	√	√	√	√	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	ACM	√	√	√	√	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	IC	√	√	√	√	0005 0009
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	OCSM	√	√	√	○	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	PCM	√	√	√	√	23
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	RCM	√	√	√	√	5
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	TBM	√	√	√	√	○
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	TCM	√	√	√	√	○
Fusion	2.3L	DURATEC-HE / I4	2007 - 2009	4X4	√	√	√	√	○
Fusion	2.3L	DURATEC-HE / I4	2007 - 2009	SDARS	√	√	√	√	○
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	APIM	√	√	√	√	○
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	GEM / SJB	√	√	√	√	42
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	HVAC	√	√	√	√	○
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	PAM	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	4X4	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	ABS	√	√	√	√	12
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	ACM	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	APIM	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	DSP	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	FCIM	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	FDIM	√	√	√	√	○

Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	GPSM	√	√	√	○	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	HVAC	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	IPC	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	OCSM	√	√	√	√	000C 0015
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	PAM	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	PCM	√	√	√	√	0009 0025
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	PSCM	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	RCM	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	SOD-L	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	SOD-R	√	√	√	√	○
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	TBM	√	√	√	○	0000 00D2
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	4X4	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	ABS	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	ACCM#2	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	ACM	√	√	√	√	5
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	APIM	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	BECM	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	DCDC	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	DSP	√	√	√	√	5
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	FCIM	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	FDIM	√	√	√	√	5
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	GPSM	√	√	√	○	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	HVAC	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	IPC	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	OCSM	√	√	√	√	000C 0015
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	PAM	√	√	√	√	5
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	PSCM	√	√	√	√	5
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	RCM	√	√	√	√	5
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	SOD-L	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	SOD-R	√	√	√	√	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	TBM	√	√	√	○	○
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	TCM	√	√	√	√	○
Fusion	2.5L	IVCT	2013	ABS	√	√	√	○	○
Fusion	2.5L	IVCT	2013	ACM	√	√	√	○	○
Fusion	2.5L	IVCT	2013	APIM	√	√	√	○	○
Fusion	2.5L	IVCT	2013	BCM#1	√	√	√	√	○
Fusion	2.5L	IVCT	2013	C-CM	√	√	√	○	○
Fusion	2.5L	IVCT	2013	DACM-C	√	√	√	○	○
Fusion	2.5L	IVCT	2013	DDM	√	√	√	○	○
Fusion	2.5L	IVCT	2013	DSM	√	√	√	√	○
Fusion	2.5L	IVCT	2013	DSP	√	√	√	○	○
Fusion	2.5L	IVCT	2013	FCDIM	√	√	√	√	○
Fusion	2.5L	IVCT	2013	FCIM	√	√	√	○	○
Fusion	2.5L	IVCT	2013	GFM	√	√	√	○	○
Fusion	2.5L	IVCT	2013	GPSM	√	√	√	○	○
Fusion	2.5L	IVCT	2013	GWM	√	√	√	○	○
Fusion	2.5L	IVCT	2013	HCM	√	√	√	○	○
Fusion	2.5L	IVCT	2013	HSWM	√	√	√	√	○
Fusion	2.5L	IVCT	2013	HUD	√	√	√	○	○
Fusion	2.5L	IVCT	2013	IPC	√	√	√	√	○

Fusion	2.5L	IVCT	2013	IPM-A	√	√	√	○	○
Fusion	2.5L	IVCT	2013	OCSM	√	√	√	○	○
Fusion	2.5L	IVCT	2013	PAM	√	√	○	○	○
Fusion	2.5L	IVCT	2013	PCM	√	√	√	√	○
Fusion	2.5L	IVCT	2013	PDM	√	√	○	○	○
Fusion	2.5L	IVCT	2013	PSCM	√	√	○	○	○
Fusion	2.5L	IVCT	2013	RACM	√	√	○	○	○
Fusion	2.5L	IVCT	2013	RCM	√	√	○	○	○
Fusion	2.5L	IVCT	2013	RGTM	√	√	○	○	○
Fusion	2.5L	IVCT	2013	RTM	√	√	○	○	○
Fusion	2.5L	IVCT	2013	SCCM	√	√	○	○	○
Fusion	2.5L	IVCT	2013	SCM-E	√	√	○	○	○
Fusion	2.5L	IVCT	2013	SCM-G	√	√	○	○	○
Fusion	2.5L	IVCT	2013	SCM-H	√	√	○	○	○
Fusion	2.5L	IVCT	2013	SOD-L	√	√	○	○	○
Fusion	2.5L	IVCT	2013	SOD-R	√	√	○	○	○
Fusion	2.5L	IVCT	2013	VDM	√	√	○	○	○
Fusion	3.0L	4V	2006 - 2007	EATC	√	√	√	√	○
Fusion	3.0L	4V	2006 - 2007	GEM	√	√	√	√	○
Fusion	3.0L	4V	2006 - 2009	IC	√	√	√	√	5
Fusion	3.0L	4V	2006 - 2009	TCM	√	√	√	√	○
Fusion	3.0L	4V	2006 - 2012	ABS	√	√	√	√	12
Fusion	3.0L	4V	2006 - 2012	ACM	√	√	√	√	○
Fusion	3.0L	4V	2006 - 2012	OCSM	√	√	√	○	000C 0015
Fusion	3.0L	4V	2006 - 2012	PCM	√	√	√	√	0023 0009 0025
Fusion	3.0L	4V	2006 - 2012	RCM	√	√	√	√	5
Fusion	3.0L	4V	2006 - 2012	TBM	√	√	√	√	○
Fusion	3.0L	4V	2007 - 2009	SDARS	√	√	√	√	5
Fusion	3.0L	4V	2007 - 2012	4X4	√	√	√	√	○
Fusion	3.0L	4V	2008 - 2012	APIM	√	√	√	√	○
Fusion	3.0L	4V	2008 - 2012	GEM / SJB	√	√	√	√	0005 000A 000F 0042
Fusion	3.0L	4V	2008 - 2012	HVAC	√	√	√	√	○
Fusion	3.0L	4V	2008 - 2012	PAM	√	√	√	√	5
Fusion	3.0L	4V	2010 - 2012	DSP	√	√	√	√	○
Fusion	3.0L	4V	2010 - 2012	FCIM	√	√	√	√	○
Fusion	3.0L	4V	2010 - 2012	FDIM	√	√	√	√	○
Fusion	3.0L	4V	2010 - 2012	GPSM	√	√	√	○	○
Fusion	3.0L	4V	2010 - 2012	IPC	√	√	√	√	○
Fusion	3.0L	4V	2010 - 2012	PSCM	√	√	√	√	○
Fusion	3.0L	4V	2010 - 2012	SOD-L	√	√	√	√	○
Fusion	3.0L	4V	2010 - 2012	SOD-R	√	√	√	√	○
Fusion	3.5L	4V	2010 - 2012	4X4	√	√	√	√	○
Fusion	3.5L	4V	2010 - 2012	ABS	√	√	√	√	0005 0008 0012
Fusion	3.5L	4V	2010 - 2012	ACM	√	√	√	√	17
Fusion	3.5L	4V	2010 - 2012	APIM	√	√	√	√	0019 001C
Fusion	3.5L	4V	2010 - 2012	DSP	√	√	√	√	○
Fusion	3.5L	4V	2010 - 2012	FCIM	√	√	√	√	○
Fusion	3.5L	4V	2010 - 2012	FDIM	√	√	√	√	5
Fusion	3.5L	4V	2010 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Fusion	3.5L	4V	2010 - 2012	GPSM	√	√	√	○	○
Fusion	3.5L	4V	2010 - 2012	HVAC	√	√	√	√	○
Fusion	3.5L	4V	2010 - 2012	IPC	√	√	√	√	○
Fusion	3.5L	4V	2010 - 2012	OCSM	√	√	√	√	000C 0015
Fusion	3.5L	4V	2010 - 2012	PAM	√	√	√	√	5

Fusion	3.5L	4V	2010 - 2012	PCM	√	√	√	√	0023 0025 0037
Fusion	3.5L	4V	2010 - 2012	PSCM	√	√	√	√	○
Fusion	3.5L	4V	2010 - 2012	RCM	√	√	√	√	5
Fusion	3.5L	4V	2010 - 2012	SOD-L	√	√	√	√	○
Fusion	3.5L	4V	2010 - 2012	SOD-R	√	√	√	√	○
Fusion	3.5L	4V	2010 - 2012	TBM	√	√	√	○	○
Fusion	3.5L	4V	2010 - 2012	TCM	√	√	√	○	○
Fusion	Other	Other	2012	4X4	√	√	√	√	○
Fusion	Other	Other	2012	ABS	√	√	√	√	○
Fusion	Other	Other	2012	ACM	√	√	√	○	○
Fusion	Other	Other	2012	APIM	√	√	√	√	○
Fusion	Other	Other	2012	DSP	√	√	√	√	○
Fusion	Other	Other	2012	FCIM	√	√	√	√	○
Fusion	Other	Other	2012	FDIM	√	√	√	√	○
Fusion	Other	Other	2012	GEM / SJB	√	√	√	√	42
Fusion	Other	Other	2012	GPSM	√	√	√	√	○
Fusion	Other	Other	2012	HVAC	√	√	√	√	○
Fusion	Other	Other	2012	IPC	√	√	√	√	9
Fusion	Other	Other	2012	OCSM	√	√	√	√	○
Fusion	Other	Other	2012	PAM	√	√	√	√	○
Fusion	Other	Other	2012	PSCM	√	√	√	√	○
Fusion	Other	Other	2012	RCM	√	√	√	√	○
Fusion	Other	Other	2012	SOD-L	√	√	√	√	○
Fusion	Other	Other	2012	SOD-R	√	√	√	√	○
Fusion	Other	Other	2012	TBM	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	ABS	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	ACM	√	√	√	√	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	AHCM	√	√	√	√	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	BCMii	√	√	√	√	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	CCMii	√	√	√	√	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	CDP	√	√	√	√	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	CMR	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	DDM	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	DSM	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	HCM	√	√	√	√	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	HVAC	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	IPC	√	√	√	√	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	IPM-A	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	NAV	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PAM	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PBM	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PCM	√	√	√	√	0090 0092 0098 0099 009A 00B1 00B7 00B9 00BC 00BD 00C1 00C3
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PDM	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PSCM	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RCM	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RFA	√	√	√	√	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RGTM	√	√	√	√	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RHVAC	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SASM	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-L	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-R	√	√	√	○	○

GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SRM	√	√	√	○	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	TRM	√	√	√	√	○
GALAXY\ S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	VDM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM	√	√	√	√	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	AHCM	√	√	√	√	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	BCMii	√	√	√	√	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	CCMii	√	√	√	√	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	CDP	√	√	√	√	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	CMR	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM	√	√	√	√	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC	√	√	√	√	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPM-A	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	NAV	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PBM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PDM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA	√	√	√	√	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RGTM	√	√	√	√	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RHVAC	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SRM	√	√	√	○	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	TRM	√	√	√	√	○
GALAXY\ S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	VDM	√	√	√	○	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	√	√	√	√	002B 0053 0054 00D9 00E2

GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	AHCM	√	√	√	○	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	CCMii	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	CDP	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	DDM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	GDM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	HCM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	HVAC	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	NAV	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PBM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	√	√	√	√	006F 0090 0092 0098 0099 009A 00AB 00AC 00B4 00C1
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PDM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PSCM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	√	√	√	○	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RFA	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RGTM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RHVAC	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	SASM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	TRM	√	√	√	√	○
GALAXY\ S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	VDM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006	GDM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	ABS	√	√	√	√	002B 0053 0054 00D9 00E2
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	ACM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	AHCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	BCMii	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	CCMii	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	CDP	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	DDM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	HCM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	HVAC	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	IPC	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	NAV	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PAM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PBM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PCM	√	√	√	√	00AC
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PDM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PSCM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RFA	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RGTM	√	√	√	√	○

GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RHVAC	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	SASM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	SRM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	TRM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	VDM	√	√	√	√	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2010	CMR	√	√	√	○	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2010	DSM	√	√	√	○	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2010	IPM-A	√	√	√	○	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2010	SOD-L	√	√	√	○	○
GALAXY\ S-Max	2.0L	DURATEC-HE / I4	2010	SOD-R	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006	GDM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	ABS	√	√	√	√	002B 0053 0054 00D9 00E2
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	ACM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	AHCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	BCMii	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	CCMii	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	CDP	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	DDM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	HCM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	HVAC	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	IPC	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	NAV	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PAM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PBM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PCM	√	√	√	√	006F 0090 0092 0098 0099 009A 00AB 00AC 00B4 00C1
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PDM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PSCM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RFA	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RGTM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RHVAC	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	SASM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	SRM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	TCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	TRM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	VDM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	CMR	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	DABM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	DSM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	IPM-A	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-L	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-R	√	√	√	○	○

GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ABS	√	√	√	○	002B 0053 0054 00D9 00E2
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ACM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	AHCM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	BCMii	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CCMii	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CDP	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CMR	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DDM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DSM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HCM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HVAC	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPC	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPM-A	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	NAV	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PAM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PBM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PCM	√	√	√	○	0092 0098 0099 009A 00A4 00B0 00B1 00B3 00B7 00B8 00B9 00BC 00BF 00C1
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PDM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PSCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RFA	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RGTM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RHVAC	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SASM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-L	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-R	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SRM	√	√	√	○	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	TCM	√	√	√	○	○

GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	TRM	√	√	√	√	○
GALAXY\ S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	VDM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS	√	√	√	○	002B 0053 0054 00D9 00E2
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM	√	√	√	√	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	AHCM	√	√	√	√	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	BCMii	√	√	√	√	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	CCMii	√	√	√	√	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	CDP	√	√	√	√	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	CMR	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM	√	√	√	√	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC	√	√	√	√	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPM-A	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	NAV	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PBM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PDM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA	√	√	√	√	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RGTM	√	√	√	√	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RHVAC	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SRM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	TCM	√	√	√	○	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	TRM	√	√	√	√	○
GALAXY\ S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	VDM	√	√	√	○	○

GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	√	√	√	√	002B 0053 0054 00D9 00E2
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	AHCM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	CCMii	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	CDP	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	DDM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	GDM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	HCM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	HVAC	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	NAV	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PBM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	√	√	√	√	0090 0092 0098 0099 009A 00A5 00AA 00AF 00B0 00B1 00B2 00B8 00B9 00BB 00C1
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PDM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PSCM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RFA	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RGTM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RHVAC	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	SASM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	TRM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	VDM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ABS	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ACM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	AHCM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	BCMii	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CCMii	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CDP	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CMR	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DDM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DSM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HCM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HVAC	√	√	√	○	○

GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPC	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPM-A	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	NAV	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PAM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PBM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PCM	√	√	√	○	0090 0092 0098 0099 009A 00AF 00B0 00B1 00B2 00B8 00B9 00BE
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PDM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PSCM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RCM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RFA	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RGTM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RHVAC	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SASM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-L	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-R	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SRM	√	√	√	○	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	TRM	√	√	√	√	○
GALAXY\ S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	VDM	√	√	√	○	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006	GDM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	ABS	√	√	√	√	002B 0053 0054 00D9 00E2
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	ACM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	AHCM	√	√	√	○	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	BCMii	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	CCMii	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	CDP	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	DDM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	HCM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	HVAC	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	IPC	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	NAV	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	PAM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	PBM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	PCM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	PDM	√	√	√	√	○

GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	PSCM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	RCM	√	√	√	○	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	RFA	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	RGTM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	RHVAC	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	SASM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	SRM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	TCM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	TRM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2006 - 2010	VDM	√	√	√	√	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2010	CMR	√	√	√	○	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2010	DABM	√	√	√	○	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2010	DSM	√	√	√	○	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2010	IPM-A	√	√	√	○	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2010	SOD-L	√	√	√	○	○
GALAXY\ S-Max	2.3L	DURATEC-HE / I4	2010	SOD-R	√	√	√	○	○
GALAXY\ S-Max	2.5L	I5	2006	ABS	√	√	√	√	002B 0053 0054 00D9 00E2
GALAXY\ S-Max	2.5L	I5	2006	ACM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	AHCM	√	√	√	○	○
GALAXY\ S-Max	2.5L	I5	2006	BCMii	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	CCMii	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	CDP	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	DDM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	GDM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	HCM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	HVAC	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	IPC	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	NAV	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	PAM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	PBM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	PCM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	PDM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	PSCM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	RCM	√	√	√	○	○
GALAXY\ S-Max	2.5L	I5	2006	RFA	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	RGTM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	RHVAC	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	SASM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	SRM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	TRM	√	√	√	√	○
GALAXY\ S-Max	2.5L	I5	2006	VDM	√	√	√	√	○
Galaxy	1.9L	EDC 1.9	2001	FFH	√	√	√	√	○
Galaxy	1.9L	EDC 1.9	2001	LHID	√	√	√	√	○
Galaxy	1.9L	EDC 1.9	2001	MFSW	√	√	√	√	○
Galaxy	1.9L	EDC 1.9	2001	PAM	√	√	√	√	○
Galaxy	1.9L	EDC 1.9	2001	RADIO	√	√	√	√	○
Galaxy	1.9L	EDC 1.9	2001	RCC	√	√	√	√	○
Galaxy	1.9L	EDC 1.9	2001	RHID	√	√	√	√	○
Galaxy	1.9L	EDC 1.9	2001	RNS	√	√	√	√	○
Galaxy	1.9L	EDC 1.9	2001 - Other	ABS	√	√	√	√	○
Galaxy	1.9L	EDC 1.9	2001 - Other	CCM	√	√	√	√	○

Galaxy	1.9L	EDC 1.9	2001 - Other	CJB	√	√	√	√	o
Galaxy	1.9L	EDC 1.9	2001 - Other	IC	√	√	√	√	o
Galaxy	1.9L	EDC 1.9	2001 - Other	PATS	√	√	√	√	o
Galaxy	1.9L	EDC 1.9	2001 - Other	PCM	√	√	√	√	o
Galaxy	1.9L	EDC 1.9	2001 - Other	RCM	√	√	√	√	o
Galaxy	1.9L	EDC 1.9	2001 - Other	TCM	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	ABS	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	CCM	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	CJB	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	IC	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	PATS	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	PCM	√	√	√	√	0025 0009
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	RCM	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	TCM	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	LHID	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	MFSW	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	PAM	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RADIO	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RCC	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RHID	√	√	√	√	o
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RNS	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	ABS	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	CCM	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	CJB	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	IC	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	PATS	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	PCM	√	√	√	√	0025 0009
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	RCM	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	TCM	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	2000	LHID	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	2000	MFSW	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	2000	PAM	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	2000	RADIO	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	2000	RCC	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	2000	RHID	√	√	√	√	o
Galaxy	2.3L	DOHC SFI (16V)	2000	RNS	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001	LHID	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001	MFSW	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001	PAM	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001	RADIO	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001	RCC	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001	RHID	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001	RNS	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001 - Other	ABS	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001 - Other	CCM	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001 - Other	CJB	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001 - Other	IC	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001 - Other	PATS	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001 - Other	PCM	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001 - Other	RCM	√	√	√	√	o
Galaxy	2.8L	2.8 CD-V6	2001 - Other	TCM	√	√	√	√	o
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	ABS/TCS	√	√	√	√	o
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	GEM	√	√	√	√	o
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	PATS	o	o	√	o	o
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	PCM	√	√	√	√	25
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	RCM	√	√	√	√	o
Granada / Scorpio	2.0L	DOHC SFI (16V)	1995	ABS/TCS	√	√	√	√	o
Granada / Scorpio	2.0L	DOHC SFI (16V)	1995	GEM	√	√	√	√	o

Granada / Scorpio	2.0L	DOHC SFI (16V)	1995	PATS	○	○	√	○	○
Granada / Scorpio	2.0L	DOHC SFI (16V)	1995	PCM	√	√	√	√	25
Granada / Scorpio	2.0L	DOHC SFI (16V)	1995	RCM	√	√	√	√	○
Granada / Scorpio	2.0L	Other	1995	ABS/TCS	√	√	√	√	○
Granada / Scorpio	2.0L	Other	1995	GEM	√	√	√	√	○
Granada / Scorpio	2.0L	Other	1995	PATS	√	√	√	√	○
Granada / Scorpio	2.0L	Other	1995	PCM	√	√	√	√	25
Granada / Scorpio	2.0L	Other	1995	RCM	√	√	√	√	○
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996 - 1998	ABS/TCS	√	√	√	√	○
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996 - 1998	GEM	√	√	√	√	○
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996 - 1998	PATS	○	○	√	○	○
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996 - 1998	PCM	√	√	√	√	0023 0025
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996 - 1998	RCM	√	√	√	√	○
Granada / Scorpio	2.5L	Other	Other	ABS/TCS	√	√	√	√	○
Granada / Scorpio	2.5L	Other	Other	GEM	√	√	√	√	○
Granada / Scorpio	2.5L	Other	Other	PATS	√	√	√	√	○
Granada / Scorpio	2.5L	Other	Other	PCM	√	√	√	√	○
Granada / Scorpio	2.5L	Other	Other	RCM	√	√	√	√	○
Granada / Scorpio	2.9L	2.9 V6 24V	1991 - 1998	ABS/TCS	√	√	√	√	○
Granada / Scorpio	2.9L	2.9 V6 24V	1991 - 1998	GEM	√	√	√	√	○
Granada / Scorpio	2.9L	2.9 V6 24V	1991 - 1998	PATS	√	√	√	√	○
Granada / Scorpio	2.9L	2.9 V6 24V	1991 - 1998	PCM	√	√	√	√	0025 0023
Granada / Scorpio	2.9L	2.9 V6 24V	1991 - 1998	RCM	√	√	√	√	○
Grand Marquis	4.6L	2V	1995 - 1997	DSM	√	√	√	√	○
Grand Marquis	4.6L	2V	1995 - 2004	ABS/TCS	√	√	√	√	8
Grand Marquis	4.6L	2V	1995 - 2007	EATC	√	√	√	√	○
Grand Marquis	4.6L	2V	1995 - 2011	DDM	√	√	√	√	000F 000A 0005 0042
Grand Marquis	4.6L	2V	1995 - 2011	LCM	√	√	√	√	○
Grand Marquis	4.6L	2V	1995 - 2011	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033 0009
Grand Marquis	4.6L	2V	1996 - 1998	IAB	√	√	√	√	○
Grand Marquis	4.6L	2V	1998 - 2000	ECS	√	√	√	√	○
Grand Marquis	4.6L	2V	1998 - 2002	PATS	√	√	√	√	9
Grand Marquis	4.6L	2V	2000 - 2011	RCM	√	√	√	√	000C
Grand Marquis	4.6L	2V	2003 - 2006	RASM	√	√	√	√	13
Grand Marquis	4.6L	2V	2003 - 2006	VAPS	√	√	√	√	○
Grand Marquis	4.6L	2V	2004 - 2010	MC	√	√	√	√	○
Grand Marquis	4.6L	2V	2005 - 2011	ABS	√	√	√	√	8
Grand Marquis	4.6L	2V	2006 - 2011	IC	√	√	√	√	5
Grand Marquis	4.6L	2V	2007 - 2011	VDM	√	√	√	√	5
Grand Marquis	4.6L	2V	2008 - 2011	HVAC	√	√	√	√	○
Grand Marquis	4.6L	2V_NGV	1996	ABS/TCS	√	√	√	√	8
Grand Marquis	4.6L	2V_NGV	1996	DDM	√	√	√	√	000F
Grand Marquis	4.6L	2V_NGV	1996	DSM	√	√	√	√	○
Grand Marquis	4.6L	2V_NGV	1996	FIM	√	√	√	√	○
Grand Marquis	4.6L	2V_NGV	1996	IAB	√	√	√	√	○
Grand Marquis	4.6L	2V_NGV	1996	LCM	√	√	√	√	○

Grand Marquis	4.6L	2V_NGV	1996	PCM	√	√	√	√	23
Ikon	1.3L	HCS	2000	PCM	√	√	√	√	0023 0025
Ikon	1.3L	Zetec Rocam	2003	ABS/TCS	√	√	√	√	8
Ikon	1.3L	Zetec Rocam	2003	CSM	√	√	√	√	○
Ikon	1.3L	Zetec Rocam	2003	ECS	√	√	√	√	○
Ikon	1.3L	Zetec Rocam	2003	GEM	√	√	√	√	○
Ikon	1.3L	Zetec Rocam	2003	PCM	√	√	√	√	○
Ikon	1.4L	Duratorq Turbo Diesel Common Rail Injection	2009	IC	√	√	√	○	○
Ikon	1.4L	Duratorq Turbo Diesel Common Rail Injection	2009	PCM	√	√	√	√	0009 0025
Ikon	1.6L	Other	2001	ECS	√	√	√	√	○
Ikon	1.6L	Other	2001	HEC	√	√	√	√	○
Ikon	1.6L	Other	2001	PCM	√	√	√	√	○
Ikon	1.6L	Zetec Rocam	1999 - 2003	ECS	√	√	√	√	○
Ikon	1.6L	Zetec Rocam	1999 - 2003	HEC	√	√	√	√	○
Ikon	1.6L	Zetec Rocam	1999 - 2003	PCM	√	√	√	√	0009 0025
Ikon	1.6L	Zetec Rocam	2003	ABS/TCS	√	√	√	√	8
Ikon	1.6L	Zetec Rocam	2003	CSM	√	√	√	√	○
Ikon	1.6L	Zetec Rocam	2003	GEM	√	√	√	√	○
Ikon	1.6L	Zetec Rocam	2003	TCM	√	√	√	√	○
Ikon	1.8L	Endura-DE	2000	PCM	○	○	√	○	○
KA	1.0L	HCS	1997	PATS	√	√	√	√	○
KA	1.0L	HCS	1997 - 1999	ABS/TCS	√	√	√	√	○
KA	1.0L	HCS	1997 - 1999	CSM	√	√	√	√	○
KA	1.0L	HCS	1997 - 1999	PCM	√	√	√	√	0025 0009
KA	1.0L	HCS	1999	ECS	√	√	√	√	○
KA	1.0L	Zetec Rocam	1999	ABS/TCS	√	√	√	√	○
KA	1.0L	Zetec Rocam	1999	CSM	√	√	√	√	○
KA	1.0L	Zetec Rocam	1999	PCM	√	√	√	√	0009 0023 0025
KA	1.2L	DURATEC 8V	2009	ABS	√	√	√	√	○
KA	1.2L	DURATEC 8V	2009	BCMii	√	√	√	√	○
KA	1.2L	DURATEC 8V	2009	EPS	√	√	√	√	○
KA	1.2L	DURATEC 8V	2009	PAM	√	√	√	○	○
KA	1.3L	DURATEC 8V	2000	ABS/TCS	√	√	√	√	○
KA	1.3L	DURATEC 8V	2000	CSM	√	√	√	√	○
KA	1.3L	DURATEC 8V	2000	ECS	√	√	√	√	○
KA	1.3L	DURATEC 8V	2000	GEM	√	√	√	√	○
KA	1.3L	DURATEC 8V	2000	PCM	√	√	√	√	0009 0025
KA	1.3L	Duratorq-Turbo Diesel Common Rail Injection	2009	ABS	√	√	√	√	○
KA	1.3L	Duratorq-Turbo Diesel Common Rail Injection	2009	BCMii	√	√	√	√	○
KA	1.3L	Duratorq-Turbo Diesel Common Rail Injection	2009	EPS	√	√	√	√	○
KA	1.3L	Duratorq-Turbo Diesel Common Rail Injection	2009	PAM	√	√	√	○	○
KA	1.3L	Endura-E	1997 - 19985	PATS	√	√	√	√	○
KA	1.3L	Endura-E	1997 - 2000	ABS/TCS	√	√	√	√	○
KA	1.3L	Endura-E	1997 - 2000	CSM	√	√	√	√	○
KA	1.3L	Endura-E	1997 - 2000	PCM	√	√	√	√	0009 0023 0025
KA	1.3L	Endura-E	1999 - 2000	ECS	√	√	√	√	○
KA	1.3L	Endura-E	2000	GEM	√	√	√	√	○
KA	1.6L	DURATEC 8V	2000	ABS/TCS	√	√	√	√	○
KA	1.6L	DURATEC 8V	2000	CSM	√	√	√	√	○
KA	1.6L	DURATEC 8V	2000	ECS	√	√	√	√	○
KA	1.6L	DURATEC 8V	2000	GEM	√	√	√	√	○
KA	1.6L	DURATEC 8V	2000	PCM	√	√	√	√	0009 0025
KA	1.6L	Zetec Rocam	2001	ABS/TCS	√	√	√	√	○
KA	1.6L	Zetec Rocam	2001	CSM	√	√	√	√	○
KA	1.6L	Zetec Rocam	2001	ECS	√	√	√	√	○
KA	1.6L	Zetec Rocam	2001	PCM	√	√	√	√	0009 0025
KA	Other	Other	2009	ABS	√	√	√	√	○
KA	Other	Other	2009	BCMii	√	√	√	√	○
KA	Other	Other	2009	EPS	√	√	√	√	○
KA	Other	Other	2009	PAM	√	√	√	○	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	√	√	√	√	0008 0029 002A 002B 002C 00DD 00DE

Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	AWD	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	D_DCU	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	EATC	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	EPS	√	√	√	○	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	FFH	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	GEM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	HCM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	IC	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	PAM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	√	√	√	√	006F 0090 0092 0098 0099 00AB 00AC 00B4 00C1
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	P_DCU	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	RETM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	RKE	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	√	√	√	√	0008 0029 002A 002B 002C 00DD 00DE
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	AWD	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	CMR	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	D_DCU	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EATC	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EPS	√	√	√	○	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FFH	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	GEM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HCM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IC	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PAM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	√	√	√	○	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	P_DCU	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RETM	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RKE	√	√	√	√	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	√	√	√	√	○

Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	TCM	√	√	√	√	○
Kuga	2.5L	I5	2008	ABS	√	√	√	√	0008 0029 002A 002B 002C 00DD 00DE
Kuga	2.5L	I5	2008	ACM	√	√	√	√	○
Kuga	2.5L	I5	2008	AWD	√	√	√	√	○
Kuga	2.5L	I5	2008	CMR	√	√	√	√	○
Kuga	2.5L	I5	2008	D_DCU	√	√	√	√	○
Kuga	2.5L	I5	2008	EATC	√	√	√	√	○
Kuga	2.5L	I5	2008	EPS	√	√	√	○	○
Kuga	2.5L	I5	2008	FFH	√	√	√	√	○
Kuga	2.5L	I5	2008	GEM	√	√	√	√	○
Kuga	2.5L	I5	2008	HCM	√	√	√	√	○
Kuga	2.5L	I5	2008	IC	√	√	√	√	○
Kuga	2.5L	I5	2008	PAM	√	√	√	√	○
Kuga	2.5L	I5	2008	PCM	√	√	√	√	○
Kuga	2.5L	I5	2008	P_DCU	√	√	√	√	○
Kuga	2.5L	I5	2008	RCM	√	√	√	√	○
Kuga	2.5L	I5	2008	RETM	√	√	√	√	○
Kuga	2.5L	I5	2008	RKE	√	√	√	√	○
Kuga	2.5L	I5	2008	SRM	√	√	√	√	○
Kuga	2.5L	I5	2008	TCM	√	√	√	√	○
LASER / 323 / TIERRA	1.3L	B3	1996 - Other	ABS	√	√	√	√	○
LASER / 323 / TIERRA	1.3L	B3	1996 - Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	1.3L	B3	2000	ABS/TCS	√	√	√	√	○
LASER / 323 / TIERRA	1.3L	Other	Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	1.5L	Other	Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	1.5L	Z5	1996 - Other	ABS	√	√	√	√	○
LASER / 323 / TIERRA	1.5L	Z5	1996 - Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	1.5L	ZL	1998 - Other	ABS	√	√	√	√	○
LASER / 323 / TIERRA	1.5L	ZL	1998 - Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	1.6L	B6	1996 - Other	ABS	√	√	√	√	○
LASER / 323 / TIERRA	1.6L	B6	1996 - Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	1.6L	Other	Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	1.6L	ZM	1998 - Other	ABS	√	√	√	√	○
LASER / 323 / TIERRA	1.6L	ZM	1998 - Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	1.6L	ZM	2000	ABS/TCS	√	√	√	√	○
LASER / 323 / TIERRA	1.8L	BP	1996 - Other	ABS	√	√	√	√	○
LASER / 323 / TIERRA	1.8L	BP	1996 - Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	1.8L	FP	1998 - Other	ABS	√	√	√	√	○
LASER / 323 / TIERRA	1.8L	FP	1998 - Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	1.8L	Other	Other	PCM	√	√	√	√	○
LASER / 323 / TIERRA	2.0L	FS	2000	ABS/TCS	√	√	√	√	○
LASER / 323 / TIERRA	2.0L	FS	2000 - 2001	ABS	√	√	√	√	○

LASER / 323 / TIERRA	2.0L	FS	2000 - 2001	PCM	√	√	√	√	○
LASER / 323 / TIERRA	2.0L	RF	1998	PCM	√	√	√	√	○
LASER / 323 / TIERRA	2.0L	RF	1998 - Other	ABS	√	√	√	√	○
LASER / 323 / TIERRA	2.0L	RF-T	1998 - 2000	PCM	√	√	√	√	○
LASER / 323 / TIERRA	2.0L	RF-T	2000	ABS	√	√	√	√	○
LS	3.0L	Other	2000 - 2002	CPM	√	√	√	√	○
LS	3.0L	Other	2000 - 2002	RESCU	√	√	√	√	○
LS	3.0L	Other	2000 - 2005	ABS/TCS	√	√	√	√	0008 0012
LS	3.0L	Other	2000 - 2005	ACM	√	√	√	√	○
LS	3.0L	Other	2000 - 2005	DDM	√	√	√	√	000A 000F
LS	3.0L	Other	2000 - 2005	DSM	√	√	√	√	○
LS	3.0L	Other	2000 - 2005	EATC	√	√	√	√	○
LS	3.0L	Other	2000 - 2005	GEM	√	√	√	√	○
LS	3.0L	Other	2000 - 2005	HEC	√	√	√	√	9
LS	3.0L	Other	2000 - 2005	MC	√	√	√	√	○
LS	3.0L	Other	2000 - 2005	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C6 00C7
LS	3.0L	Other	2000 - 2005	RCM	√	√	√	√	000C
LS	3.0L	Other	2000 - 2005	REM	√	√	√	√	○
LS	3.0L	Other	2003	VEMS	√	√	√	√	○
LS	3.0L	Other	2003 - 2005	DCSM	√	√	√	√	○
LS	3.0L	Other	2003 - 2005	EPB	√	√	√	√	○
LS	3.0L	Other	2003 - 2005	NAV	√	√	√	√	○
LS	3.0L	Other	2003 - 2005	PAM	√	√	√	√	○
LS	3.0L	Other	2003 - 2005	PCSM	√	√	√	√	○
LS	3.0L	Other	2003 - 2005	SCLM	√	√	√	√	○
LS	3.9L	4V	2003	VEMS	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	ABS/TCS	√	√	√	√	0008 0012
LS	3.9L	4V	2003 - 2006	ACM	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	DCSM	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	DDM	√	√	√	√	000A 000F
LS	3.9L	4V	2003 - 2006	DSM	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	EATC	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	EPB	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	GEM	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	HEC	√	√	√	√	9
LS	3.9L	4V	2003 - 2006	MC	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	NAV	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	PAM	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033 00C6
LS	3.9L	4V	2003 - 2006	PCSM	√	√	√	√	○
LS	3.9L	4V	2003 - 2006	RCM	√	√	√	√	000C
LS	3.9L	4V	2003 - 2006	REM	√	√	√	√	○

LS	3.9L	4V	2003 - 2006	SCLM	√	√	√	√	○
LS	3.9L	Other	2000 - 2002	ABS/TCS	√	√	√	√	0008 0012
LS	3.9L	Other	2000 - 2002	ACM	√	√	√	√	○
LS	3.9L	Other	2000 - 2002	CPM	√	√	√	√	○
LS	3.9L	Other	2000 - 2002	DDM	√	√	√	√	000A 000F
LS	3.9L	Other	2000 - 2002	DSM	√	√	√	√	○
LS	3.9L	Other	2000 - 2002	EATC	√	√	√	√	○
LS	3.9L	Other	2000 - 2002	GEM	√	√	√	√	○
LS	3.9L	Other	2000 - 2002	HEC	√	√	√	√	9
LS	3.9L	Other	2000 - 2002	MC	√	√	√	√	○
LS	3.9L	Other	2000 - 2002	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C6 00C7
LS	3.9L	Other	2000 - 2002	RCM	√	√	√	√	○
LS	3.9L	Other	2000 - 2002	REM	√	√	√	√	○
LS	3.9L	Other	2000 - 2002	RESCU	√	√	√	√	○
Liata	1.6L	Other	Other	PCM	√	√	√	√	○
Liata	1.8L	Other	Other	PCM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005	GEM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	ABS	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	EATC	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	EPS	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	IC	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	LPSDM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	PCM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	RCM	√	√	√	√	○

MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	RKE	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	RPSDM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007	TCM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	ABS	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	EATC	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	EPS	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	GEM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	IC	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	PCM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	RCM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	RKE	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007	LPSDM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007	RPSDM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007	TCM	√	√	√	√	○

MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	ABS	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	EATC	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	FFH	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	GEM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	IC	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	PCM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	RCM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	RKE	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007	LPSDM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007	RPSDM	√	√	√	√	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007	TCM	√	√	√	√	○
MILLENIA / EUNOS 800	2.0L	KF	1998 - 2000	ABS	√	√	√	√	○
MILLENIA / EUNOS 800	2.3L	KJ	1998 - 2000	ABS	√	√	√	√	○
MILLENIA / EUNOS 800	2.5L	KL	1998 - 2000	ABS	√	√	√	√	○
MILLENIA / EUNOS 800	2.5L	KL	2002	ABS/TCS	√	√	√	√	○
MILLENIA / EUNOS 800	2.5L	KL	2002	PCM	√	√	√	√	○

MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM	√	√	√	○	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	4X4	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	FDIM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	HD_LVL	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	ILCM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	SASM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	ABS	√	√	√	√	8
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	ACM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	APIM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	C-CM	√	√	√	○	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DCSM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DDM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DSM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DSP	√	√	√	○	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	FCIM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	GPSM	√	√	√	○	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HCM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HCM-2	√	√	√	○	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HUD	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HVAC	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	IPC	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	OCSM	√	√	√	√	000C 0015
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PAM	√	√	√	○	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PSCM	√	√	√	○	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	RCM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	RFA	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	SOD-L	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	SOD-R	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	○	000A 000F 0042

MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	DACM-C	√	√	√	○	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	√	√	√	○	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	√	○	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	√	√	√	√	○
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	VDM	√	√	√	√	○
MKS	3.7L	4V	2009	SECM	√	√	○	○	○
MKS	3.7L	4V	2009 - 2012	4X4	√	√	√	√	○
MKS	3.7L	4V	2009 - 2012	ABS	√	√	√	√	0005 0008
MKS	3.7L	4V	2009 - 2012	ACM	√	√	√	√	5
MKS	3.7L	4V	2009 - 2012	APIM	√	√	√	√	○
MKS	3.7L	4V	2009 - 2012	C-CM	√	√	√	√	○
MKS	3.7L	4V	2009 - 2012	DCSM	√	√	√	√	5
MKS	3.7L	4V	2009 - 2012	DDM	√	√	√	√	○
MKS	3.7L	4V	2009 - 2012	DSM	√	√	√	√	○
MKS	3.7L	4V	2009 - 2012	DSP	√	√	√	○	5
MKS	3.7L	4V	2009 - 2012	FCIM	√	√	√	√	○
MKS	3.7L	4V	2009 - 2012	FDIM	√	√	√	√	5
MKS	3.7L	4V	2009 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
MKS	3.7L	4V	2009 - 2012	HCM	√	√	√	√	○
MKS	3.7L	4V	2009 - 2012	HCM-2	√	√	√	√	5
MKS	3.7L	4V	2009 - 2012	HD_LVL	√	√	√	√	○
MKS	3.7L	4V	2009 - 2012	HVAC	√	√	√	√	○
MKS	3.7L	4V	2009 - 2012	IPC	√	√	√	√	5
MKS	3.7L	4V	2009 - 2012	OCSM	√	√	√	○	000C 0015
MKS	3.7L	4V	2009 - 2012	PAM	√	√	√	√	○
MKS	3.7L	4V	2009 - 2012	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C5 0009
MKS	3.7L	4V	2009 - 2012	RCM	√	√	√	√	5
MKS	3.7L	4V	2009 - 2012	RFA	√	√	√	√	○
MKS	3.7L	4V	2010	RETM	√	√	√	○	○
MKS	3.7L	4V	2010 - 2012	GPSM	√	√	√	○	○
MKS	3.7L	4V	2010 - 2012	HUD	√	√	√	√	○
MKS	3.7L	4V	2010 - 2012	ILCM	√	√	√	√	○
MKS	3.7L	4V	2010 - 2012	PSCM	√	√	√	○	○
MKS	3.7L	4V	2010 - 2012	SASM	√	√	√	√	○
MKS	3.7L	4V	2010 - 2012	SOD-L	√	√	√	√	○
MKS	3.7L	4V	2010 - 2012	SOD-R	√	√	√	√	○
MKS	3.7L	TiVCT	2013	ABS	√	√	√	√	○
MKS	3.7L	TiVCT	2013	ACM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	APIM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	BCM#1	√	√	√	○	000A 000F 0042
MKS	3.7L	TiVCT	2013	C-CM	√	√	√	○	○

MKS	3.7L	TiVCT	2013	DACM-C	√	√	√	○	○
MKS	3.7L	TiVCT	2013	DCSM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	DDM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	DSM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	DSP	√	√	√	○	○
MKS	3.7L	TiVCT	2013	FCDIM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	FCIM	√	√	√	○	○
MKS	3.7L	TiVCT	2013	GPSM	√	√	√	○	○
MKS	3.7L	TiVCT	2013	HCM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	HCM-2	√	√	√	○	○
MKS	3.7L	TiVCT	2013	HSWM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	HUD	√	√	√	√	○
MKS	3.7L	TiVCT	2013	HVAC	√	√	√	√	○
MKS	3.7L	TiVCT	2013	IPC	√	√	√	√	○
MKS	3.7L	TiVCT	2013	IPM-A	√	√	√	○	○
MKS	3.7L	TiVCT	2013	OCSM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	PAM	√	√	√	○	○
MKS	3.7L	TiVCT	2013	PCM	√	√	√	√	0023 0025
MKS	3.7L	TiVCT	2013	PSCM	√	√	√	○	○
MKS	3.7L	TiVCT	2013	RACM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	RCM	√	√	√	○	○
MKS	3.7L	TiVCT	2013	RFA	√	√	√	√	○
MKS	3.7L	TiVCT	2013	RTM	√	√	√	○	○
MKS	3.7L	TiVCT	2013	SCCM	√	√	√	√	○
MKS	3.7L	TiVCT	2013	SOD-L	√	√	√	○	○
MKS	3.7L	TiVCT	2013	SOD-R	√	√	√	√	○
MKS	3.7L	TiVCT	2013	VDM	√	√	√	√	○
MKS	Other	Other	2012	4X4	√	√	√	√	○
MKS	Other	Other	2012	ABS	√	√	√	√	○
MKS	Other	Other	2012	ACM	√	√	√	○	○
MKS	Other	Other	2012	APIM	√	√	√	√	○
MKS	Other	Other	2012	C-CM	√	√	√	√	○
MKS	Other	Other	2012	DCSM	√	√	√	√	○
MKS	Other	Other	2012	DDM	√	√	√	√	○
MKS	Other	Other	2012	DSM	√	√	√	√	○
MKS	Other	Other	2012	DSP	√	√	√	√	○
MKS	Other	Other	2012	FCIM	√	√	√	√	○
MKS	Other	Other	2012	FDIM	√	√	√	√	○
MKS	Other	Other	2012	GEM / SJB	√	√	√	√	42
MKS	Other	Other	2012	GPSM	√	√	√	√	○
MKS	Other	Other	2012	HCM	√	√	√	√	○
MKS	Other	Other	2012	HCM-2	√	√	√	○	○
MKS	Other	Other	2012	HD_LVL	√	√	√	√	○
MKS	Other	Other	2012	HUD	√	√	√	√	○
MKS	Other	Other	2012	HVAC	√	√	√	√	○
MKS	Other	Other	2012	ILCM	√	√	√	√	○
MKS	Other	Other	2012	IPC	√	√	√	√	○
MKS	Other	Other	2012	OCSM	√	√	√	√	○
MKS	Other	Other	2012	PAM	√	√	√	○	○
MKS	Other	Other	2012	PSCM	√	√	√	○	○
MKS	Other	Other	2012	RCM	√	√	√	√	○
MKS	Other	Other	2012	RFA	√	√	√	√	○
MKS	Other	Other	2012	SASM	√	√	√	√	○
MKS	Other	Other	2012	SOD-L	√	√	√	√	○
MKS	Other	Other	2012	SOD-R	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	○	000A 000F 0042
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	√	√	√	○	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DCSM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	√	√	√	○	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	√	√	√	○	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	√	√	√	○	○

MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HUD	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HVAC	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	√	√	√	○	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	LTM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	√	√	√	○	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	√	√	√	√	0023 0025
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCSM-2	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	√	√	√	○	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RFA	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RHVAC	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	√	○	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	√	√	√	○	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	√	√	√	√	○
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	VDM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	4X4	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	HCM-2	√	√	√	○	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	ILCM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	RETM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	SASM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	ABS	√	√	√	√	0008 0012
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	ACM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	APIM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	C-CM	√	√	√	○	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DCSM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DDM	√	√	√	√	○

MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DSM	√	√	√	√	5
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DSP	√	√	√	○	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	FCIM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HCM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HUD	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HVAC	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	IPC	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	LTM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	OCSM	√	√	√	√	000C 0015
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PAM	√	√	√	○	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PCSM-2	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PSCM	√	√	√	○	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	RCM	√	√	√	√	5
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	RFA	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	RHVAC	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	SOD-L	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	SOD-R	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	GPSM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	○	000A 000F 0042
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	√	√	√	○	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	√	○	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	√	√	√	√	○
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	VDM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	4X4	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	ABS	√	√	√	√	0012 0008
MKT	3.7L	4V	2010 - 2012	ACM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	APIM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	C-CM	√	√	√	○	○
MKT	3.7L	4V	2010 - 2012	DCSM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	DDM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	DSM	√	√	√	√	○

MKT	3.7L	4V	2010 - 2012	DSP	√	√	√	○	○
MKT	3.7L	4V	2010 - 2012	FCIM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
MKT	3.7L	4V	2010 - 2012	HCM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	HCM-2	√	√	√	○	○
MKT	3.7L	4V	2010 - 2012	HUD	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	HVAC	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	ILCM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	IPC	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	LTM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	OCSM	√	√	√	√	000C 0015
MKT	3.7L	4V	2010 - 2012	PAM	√	√	√	○	○
MKT	3.7L	4V	2010 - 2012	PCM	√	√	√	√	0025 0023
MKT	3.7L	4V	2010 - 2012	PCSM-2	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	PSCM	√	√	√	○	○
MKT	3.7L	4V	2010 - 2012	RCM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	RETM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	RFA	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	RHVAC	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	SASM	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	SOD-L	√	√	√	√	○
MKT	3.7L	4V	2010 - 2012	SOD-R	√	√	√	√	○
MKT	3.7L	4V	2011 - 2012	GPSM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	ABS	√	√	√	√	○
MKT	3.7L	TiVCT	2013	ACM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	APIM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	BCM#1	√	√	√	○	000A 000F 0042
MKT	3.7L	TiVCT	2013	C-CM	√	√	√	○	○
MKT	3.7L	TiVCT	2013	DCSM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	DDM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	DSM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	DSP	√	√	√	○	○
MKT	3.7L	TiVCT	2013	FCIM	√	√	√	○	○
MKT	3.7L	TiVCT	2013	GPSM	√	√	√	○	○
MKT	3.7L	TiVCT	2013	HCM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	HSWM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	HUD	√	√	√	√	○
MKT	3.7L	TiVCT	2013	HVAC	√	√	√	√	○
MKT	3.7L	TiVCT	2013	IPC	√	√	√	√	○
MKT	3.7L	TiVCT	2013	IPM-A	√	√	√	○	○
MKT	3.7L	TiVCT	2013	LTM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	OCSM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	PAM	√	√	√	○	○
MKT	3.7L	TiVCT	2013	PCM	√	√	√	√	0023 0025
MKT	3.7L	TiVCT	2013	PCSM-2	√	√	√	√	○
MKT	3.7L	TiVCT	2013	PSCM	√	√	√	○	○
MKT	3.7L	TiVCT	2013	RACM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	RCM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	RFA	√	√	√	√	○
MKT	3.7L	TiVCT	2013	RHVAC	√	√	√	√	○
MKT	3.7L	TiVCT	2013	RTM	√	√	√	○	○
MKT	3.7L	TiVCT	2013	SCCM	√	√	√	√	○
MKT	3.7L	TiVCT	2013	SOD-L	√	√	√	○	○
MKT	3.7L	TiVCT	2013	SOD-R	√	√	√	√	○
MKT	3.7L	TiVCT	2013	VDM	√	√	√	√	○
MKT	Other	Other	2012	4X4	√	√	√	√	○
MKT	Other	Other	2012	ABS	√	√	√	√	○
MKT	Other	Other	2012	ACM	√	√	√	√	○
MKT	Other	Other	2012	APIM	√	√	√	√	○
MKT	Other	Other	2012	C-CM	√	√	√	√	○
MKT	Other	Other	2012	DCSM	√	√	√	√	○
MKT	Other	Other	2012	DDM	√	√	√	√	○
MKT	Other	Other	2012	DSM	√	√	√	√	○
MKT	Other	Other	2012	DSP	√	√	√	√	○

MKT	Other	Other	2012	FCIM	√	√	√	√	○
MKT	Other	Other	2012	GEM / SJB	√	√	√	√	42
MKT	Other	Other	2012	GPSM	√	√	√	√	○
MKT	Other	Other	2012	HCM	√	√	√	√	○
MKT	Other	Other	2012	HCM-2	√	√	√	○	○
MKT	Other	Other	2012	HUD	√	√	√	√	○
MKT	Other	Other	2012	HVAC	√	√	√	√	○
MKT	Other	Other	2012	ILCM	√	√	√	√	○
MKT	Other	Other	2012	IPC	√	√	√	√	○
MKT	Other	Other	2012	LTM	√	√	√	√	○
MKT	Other	Other	2012	OCSM	√	√	√	√	○
MKT	Other	Other	2012	PAM	√	√	√	○	○
MKT	Other	Other	2012	PCSM-2	√	√	√	√	○
MKT	Other	Other	2012	PSCM	√	√	√	○	○
MKT	Other	Other	2012	RCM	√	√	√	√	○
MKT	Other	Other	2012	RETM	√	√	√	√	○
MKT	Other	Other	2012	RFA	√	√	√	√	○
MKT	Other	Other	2012	RHVAC	√	√	√	√	○
MKT	Other	Other	2012	SASM	√	√	√	√	○
MKT	Other	Other	2012	SOD-L	√	√	√	√	○
MKT	Other	Other	2012	SOD-R	√	√	√	√	○
MKX	3.5L	4V	2007	EATC	√	√	√	√	○
MKX	3.5L	4V	2007	GEM	√	√	√	√	000A 000F
MKX	3.5L	4V	2007 - 2010	4X4	√	√	√	√	○
MKX	3.5L	4V	2007 - 2010	ABS	√	√	√	√	0012 0008 0005
MKX	3.5L	4V	2007 - 2010	ACM	√	√	√	√	0016 0017 0018 0019 0005
MKX	3.5L	4V	2007 - 2010	DCSM	√	√	√	√	○
MKX	3.5L	4V	2007 - 2010	DSM	√	√	√	√	5
MKX	3.5L	4V	2007 - 2010	DSP	√	√	√	○	5
MKX	3.5L	4V	2007 - 2010	HCM	√	√	√	√	○
MKX	3.5L	4V	2007 - 2010	IC	√	√	√	√	0009 0005
MKX	3.5L	4V	2007 - 2010	LTM	√	√	√	√	○
MKX	3.5L	4V	2007 - 2010	OCSM	√	√	√	○	000C 0015
MKX	3.5L	4V	2007 - 2010	PAM	√	√	√	√	5
MKX	3.5L	4V	2007 - 2010	PCM	√	√	√	√	0025 0010 0023 0028 0031 0033 00C5
MKX	3.5L	4V	2007 - 2010	RCM	√	√	√	√	5
MKX	3.5L	4V	2007 - 2010	RETM	√	√	√	√	○
MKX	3.5L	4V	2007 - 2010	SASM	√	√	√	√	○
MKX	3.5L	4V	2007 - 2010	SDARS	√	√	√	√	0019 0005
MKX	3.5L	4V	2008 - 2010	APIM	√	√	√	√	001C
MKX	3.5L	4V	2008 - 2010	GEM / SJB	√	√	√	√	000A 000F 0042
MKX	3.5L	4V	2008 - 2010	HVAC	√	√	√	√	○
MKX	3.5L	4V	2010	GPSM	√	√	√	○	○
MKX	3.7L	TiVCT	2011 - 2012	TPM	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	ABS	√	√	√	√	0012 0008
MKX	3.7L	TiVCT	2011 - 2013	ACM	√	√	√	○	○
MKX	3.7L	TiVCT	2011 - 2013	APIM	√	√	√	○	○
MKX	3.7L	TiVCT	2011 - 2013	BCM#1	√	√	√	√	000A 000F 0042
MKX	3.7L	TiVCT	2011 - 2013	C-CM	√	√	√	○	○
MKX	3.7L	TiVCT	2011 - 2013	DCSM	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	DSM	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	DSP	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	FCDIM	√	√	√	√	○

MKX	3.7L	TiVCT	2011 - 2013	FCIM	√	√	√	○	○
MKX	3.7L	TiVCT	2011 - 2013	FLM	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	GPSM	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	HCM	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	HSWM	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	HUD	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	HVAC	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	IPC	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	LTM	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	OCSM	√	√	√	√	000C 0015
MKX	3.7L	TiVCT	2011 - 2013	PAM	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	PCM	√	√	√	√	0025 0010 0023 0028 0031 0033
MKX	3.7L	TiVCT	2011 - 2013	RCM	√	√	√	○	○
MKX	3.7L	TiVCT	2011 - 2013	RFA	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	SCCM	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	SOD-L	√	√	√	√	○
MKX	3.7L	TiVCT	2011 - 2013	SOD-R	√	√	√	√	○
MKX	3.7L	TiVCT	2013	RTM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	ABS	√	√	√	○	002B 0053 0054 00D9 00E2
MONDEO	1.6L	DURATEC VCT	2007 - 2011	ACM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	AHCM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	BCMii	√	√	√	√	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	CCMii	√	√	√	√	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	CDP	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	CMR	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	DDM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	DSM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	HCM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	HVAC	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	IPC	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PAM	√	√	√	√	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PBM	√	√	√	√	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PCM	√	√	√	○	25
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PDM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PSCM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	RCM	√	√	√	√	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	RFA	√	√	√	√	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	SASM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	SRM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	TRM	√	√	√	√	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	VDM	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2011	IPM-A	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2011	RGTM	√	√	√	√	○
MONDEO	1.6L	DURATEC VCT	2011	RHVAC	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2011	SOD-L	√	√	√	○	○
MONDEO	1.6L	DURATEC VCT	2011	SOD-R	√	√	√	○	○

MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	√	√	√	○	002B 0054 00E2 00E8
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	√	√	√	√	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	CCMii	√	√	√	√	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	CDP	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	CMR	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DSM	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HCM	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	√	√	√	√	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PBM	√	√	√	√	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	√	√	√	√	0090 0092 0098 0099 009A 00B1 00B7 00B9 00BC 00BD 00C1 00C3
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	√	√	√	√	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	√	√	√	√	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	√	√	√	√	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RHVAC	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	√	√	√	○	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	√	√	√	√	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	VDM	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	√	√	√	○	002B 0053 0054 00D9 00E2
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	√	√	√	√	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	CCMii	√	√	√	√	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	CDP	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	CMR	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM	√	√	√	○	○

MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	√	√	√	√	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PBM	√	√	√	√	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	√	√	√	√	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	√	√	√	√	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RGTM	√	√	√	√	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RHVAC	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	√	√	√	○	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	√	√	√	√	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	VDM	√	√	√	○	○
MONDEO	1.6L	Zetec	1993 - 1999	ABS	√	√	√	√	○
MONDEO	1.6L	Zetec	1993 - 1999	CSM	√	√	√	√	○
MONDEO	1.6L	Zetec	1993 - 1999	PATS	√	√	√	√	○
MONDEO	1.6L	Zetec	1997 - 1999	FFH	√	√	√	√	○
MONDEO	1.6L	Zetec	1997 - 1999	PCM	√	√	√	√	0023 0025
MONDEO	1.6L	Zetec	1998 - 1999	ABS/TCS	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	ABS	√	√	√	√	8
MONDEO	1.8L	DURATEC-HE / I4	2001	ABS/TCS	√	√	√	√	8
MONDEO	1.8L	DURATEC-HE / I4	2001	ACM	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	CDP	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	CSM	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	EATC	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	GDM	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	GEM	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	HEC	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	LHID	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	NAV	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	PATS	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	PCM	√	√	√	√	0009 0025
MONDEO	1.8L	DURATEC-HE / I4	2001	RCM	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	RETM	√	√	√	√	○

MONDEO	1.8L	DURATEC-HE / I4	2001	RHID	√	√	√	√	○
MONDEO	1.8L	DURATEC-HE / I4	2001	SRM	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	ABS	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	ABS/TCS	√	√	√	√	8
MONDEO	1.8L	DURATEC-SCi	2001	ACM	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	CDP	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	CSM	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	EATC	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	GDM	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	GEM	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	HEC	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	LHID	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	NAV	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	PATS	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	PCM	√	√	√	√	0009 0025
MONDEO	1.8L	DURATEC-SCi	2001	RCM	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	RETM	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	RHID	√	√	√	√	○
MONDEO	1.8L	DURATEC-SCi	2001	SRM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	ABS	√	√	√	√	002B 0053 0054 00D9 00E2 00E8
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	ACM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	AHCM	√	√	√	○	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	BCMii	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	CCMii	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	CDP	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	CMR	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	DDM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	DSM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	HCM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	HVAC	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	IPC	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PAM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PBM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PCM	√	√	√	√	006F 0090 0092 0098 0099 009A 00AB 00AC 00B4 00C1
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PDM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PSCM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	RCM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	RFA	√	√	√	○	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	SASM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	SRM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	TRM	√	√	√	√	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	VDM	√	√	√	○	○
MONDEO	1.8L	Endura-DE	1997	FFH	√	√	√	√	○

MONDEO	1.8L	Endura-DE	1997	PCM	○	○	√	○	○
MONDEO	1.8L	Endura-DE	1997 - Other	ABS	√	√	√	√	○
MONDEO	1.8L	Endura-DE	1997 - Other	CSM	√	√	√	√	○
MONDEO	1.8L	Endura-DE	1997 - Other	PATS	√	√	√	√	○
MONDEO	1.8L	Zetec	1993 - 2000	ABS	√	√	√	√	○
MONDEO	1.8L	Zetec	1993 - 2000	CSM	√	√	√	√	○
MONDEO	1.8L	Zetec	1993 - 2000	PATS	√	√	√	√	○
MONDEO	1.8L	Zetec	1997 - 1999	FFH	√	√	√	√	○
MONDEO	1.8L	Zetec	1997 - 2000	PCM	√	√	√	√	0023 0025 0009
MONDEO	1.8L	Zetec	1998 - 2000	ABS/TCS	√	√	√	√	○
MONDEO	1.8L	Zetec	2000	AFCM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2001	ABS/TCS	√	√	√	√	8
MONDEO	2.0L	DURATEC-HE / I4	2001	CSM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2001	EATC	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2001	GDM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2001	GEM	√	√	√	√	5
MONDEO	2.0L	DURATEC-HE / I4	2001	HEC	√	√	√	√	5
MONDEO	2.0L	DURATEC-HE / I4	2001	LHID	√	√	√	√	5
MONDEO	2.0L	DURATEC-HE / I4	2001	NAV	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2001	PATS	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2001	RETM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2001	RHID	√	√	√	√	5
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	ABS	√	√	√	√	0008 002B 0053 0054 00D9 00E2 00E8
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	ACM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	CDP	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	PCM	√	√	√	√	0009 0025 00AC
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	RCM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2001 - 2007	SRM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	AHCM	√	√	√	○	○
MONDEO	2.0L	DURATEC-HE / I4	2007	BCMii	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	CCMii	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	CMR	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	DDM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	DSM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	HCM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	HVAC	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	IPC	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	PAM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	PBM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	PDM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	PSCM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	RFA	√	√	√	○	○
MONDEO	2.0L	DURATEC-HE / I4	2007	SASM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	TRM	√	√	√	√	○
MONDEO	2.0L	DURATEC-HE / I4	2007	VDM	√	√	√	○	○
MONDEO	2.0L	DURATORQ_DI	2001	ABS	√	√	√	○	8

MONDEO	2.0L	DURATORQ_DI	2001	ABS/TCS	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	ACM	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	CDP	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	CSM	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	EATC	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	FFH	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	FIP	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	GDM	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	GEM	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	HEC	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	LHID	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	NAV	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	PATS	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	PCM	√	√	√	√	9
MONDEO	2.0L	DURATORQ_DI	2001	RCM	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	RETM	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	RHID	√	√	√	√	○
MONDEO	2.0L	DURATORQ_DI	2001	SRM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ABS/TCS	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	EATC	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	FFH	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	GDM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	GEM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	HEC	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ICU	○	○	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	LHID	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	NAV	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	PATS	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RETM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RHID	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	ABS	√	√	√	○	002B 0053 0054 00D9 00E2 00E8
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	ACM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	CDP	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	PCM	√	√	√	√	006F 0090 0092 0098 0099 009A 00AB 00AC 00B4 00C1
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	RCM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	SRM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	TCM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	AHCM	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	BCMii	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	CCMii	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	CMR	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	DDM	√	√	√	√	○

MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	DSM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	HCM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	HVAC	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	IPC	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PAM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PBM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PDM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PSCM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	RFA	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	SASM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	TRM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	VDM	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DABM	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RHVAC	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007	TCM	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	ABS	√	√	√	√	002B 0053 0054 00D9 00E2 00E8
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	ACM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	AHCM	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	BCMii	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	CCMii	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	CDP	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	CMR	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	DDM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	DSM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	HCM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	HVAC	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	IPC	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PAM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PBM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PCM	√	√	√	○	0092 0098 0099 009A 00A4 00B0 00B1 00B3 00B7 00B8 00B9 00BC 00BF 00C1 0090

MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PDM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PSCM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	RCM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	RFA	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	SASM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	SRM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	TRM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	VDM	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	IPM-A	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RGTM	√	√	√	√	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RHVAC	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-L	√	√	√	○	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-R	√	√	√	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	ABS	√	√	√	√	002B 0053 0054 00D9 00E2 00E8
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	ACM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	AHCM	√	√	√	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	BCMii	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	CCMii	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	CDP	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	CMR	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	DDM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	DSM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	HCM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	HVAC	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	IPC	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PAM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PBM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PCM	√	√	√	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PDM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PSCM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	RCM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	RFA	√	√	√	○	○

MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	SASM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	SRM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	TCM	√	√	√	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	TRM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	VDM	√	√	√	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	√	√	√	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RGTM	√	√	√	√	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RHVAC	√	√	√	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	√	√	√	○	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	√	√	√	○	○
MONDEO	2.0L	Zetec	1993 - 2000	ABS	√	√	√	√	○
MONDEO	2.0L	Zetec	1993 - 2000	CSM	√	√	√	√	○
MONDEO	2.0L	Zetec	1993 - 2000	PATS	√	√	√	√	○
MONDEO	2.0L	Zetec	1997 - 1999	FFH	√	√	√	√	○
MONDEO	2.0L	Zetec	1997 - 2000	PCM	√	√	√	√	0023 0025 0009
MONDEO	2.0L	Zetec	1998 - 2000	ABS/TCS	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	ABS/TCS	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	EATC	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	FFH	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	GDM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	GEM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	HEC	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	ICU	○	○	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	LHID	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	NAV	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	PATS	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	RETM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	RHID	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2007	ABS	√	√	√	○	0008 002B 0053 0054 00D9 00E2 00E8
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2007	ACM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2007	CDP	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2007	PCM	√	√	√	√	0009 0092 0090 0098 0099 009A 00A5 00AA 00AF 00B0 00B1 00B2 00B8 00B9 00C1
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2007	RCM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2007	SRM	√	√	√	√	○

MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	AHCM	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	BCMii	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	CCMii	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	CMR	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	DDM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	DSM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	HCM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	HVAC	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	IPC	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	PAM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	PBM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	PDM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	PSCM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	RFA	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	SASM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	TRM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	VDM	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	ABS	√	√	√	○	0
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	ACM	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	AHCM	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	BCMii	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	CCMii	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	CDP	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	CMR	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	DDM	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	DSM	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	HCM	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	HVAC	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	IPC	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	IPM-A	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PAM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PBM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PCM	√	√	√	○	0090 0092 0098 0099 009A 00AF 00B0 00B1 00B2 00B8 00B9 00BF
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PDM	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PSCM	√	√	√	○	○

MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RCM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RFA	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RGTM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RHVAC	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SASM	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-L	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-R	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SRM	√	√	√	○	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	TRM	√	√	√	√	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	VDM	√	√	√	○	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	ABS	√	√	√	√	00E8 002B 0053 0054 00D9 00E2
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	ACM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	AHCM	√	√	√	○	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	BCMii	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	CCMii	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	CDP	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	CMR	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	DDM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	DSM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	HCM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	HVAC	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	IPC	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	PAM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	PBM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	PCM	√	√	√	√	0025 00AC
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	PDM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	PSCM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	RCM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	RFA	√	√	√	○	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	SASM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	SRM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	TCM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	TRM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2007 - 2011	VDM	√	√	√	○	○
MONDEO	2.3L	DURATEC-HE / I4	2011	DABM	√	√	√	○	○
MONDEO	2.3L	DURATEC-HE / I4	2011	IPM-A	√	√	√	○	○
MONDEO	2.3L	DURATEC-HE / I4	2011	RGTM	√	√	√	√	○
MONDEO	2.3L	DURATEC-HE / I4	2011	RHVAC	√	√	√	○	○
MONDEO	2.3L	DURATEC-HE / I4	2011	SOD-L	√	√	√	○	○
MONDEO	2.3L	DURATEC-HE / I4	2011	SOD-R	√	√	√	○	○
MONDEO	2.5L	Duratec-VE	1994 - 2001	ABS	√	√	√	√	8
MONDEO	2.5L	Duratec-VE	1994 - 2001	CSM	√	√	√	√	○

MONDEO	2.5L	Duratec-VE	1994 - 2001	PATS	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	1997 - 1999	FFH	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	1997 - 2001	PCM	√	√	√	√	0023 0025 0009
MONDEO	2.5L	Duratec-VE	1998 - 2001	ABS/TCS	√	√	√	√	8
MONDEO	2.5L	Duratec-VE	2001	ACM	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	CDP	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	EATC	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	GDM	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	GEM	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	HEC	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	LHID	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	NAV	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	RCM	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	RETM	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	RHID	√	√	√	√	○
MONDEO	2.5L	Duratec-VE	2001	SRM	√	√	√	√	○
MONDEO	2.5L	I5	2007	ABS	√	√	√	√	002B 0053 0054 00D9 00E2
MONDEO	2.5L	I5	2007	ACM	√	√	√	√	○
MONDEO	2.5L	I5	2007	AHCM	√	√	√	○	○
MONDEO	2.5L	I5	2007	BCMii	√	√	√	√	○
MONDEO	2.5L	I5	2007	CCMii	√	√	√	√	○
MONDEO	2.5L	I5	2007	CDP	√	√	√	√	○
MONDEO	2.5L	I5	2007	CMR	√	√	√	√	○
MONDEO	2.5L	I5	2007	DDM	√	√	√	√	○
MONDEO	2.5L	I5	2007	DSM	√	√	√	√	○
MONDEO	2.5L	I5	2007	HCM	√	√	√	√	○
MONDEO	2.5L	I5	2007	HVAC	√	√	√	√	○
MONDEO	2.5L	I5	2007	IPC	√	√	√	√	○
MONDEO	2.5L	I5	2007	PAM	√	√	√	√	○
MONDEO	2.5L	I5	2007	PBM	√	√	√	√	○
MONDEO	2.5L	I5	2007	PCM	√	√	√	√	○
MONDEO	2.5L	I5	2007	PDM	√	√	√	√	○
MONDEO	2.5L	I5	2007	PSCM	√	√	√	√	○
MONDEO	2.5L	I5	2007	RCM	√	√	√	√	○
MONDEO	2.5L	I5	2007	RFA	√	√	√	○	○
MONDEO	2.5L	I5	2007	SASM	√	√	√	√	○
MONDEO	2.5L	I5	2007	SRM	√	√	√	√	○
MONDEO	2.5L	I5	2007	TRM	√	√	√	√	○
MONDEO	2.5L	I5	2007	VDM	√	√	√	○	○
MONDEO	3.0L	Duratec SE	2001	ABS	√	√	√	√	8
MONDEO	3.0L	Duratec SE	2001	ABS/TCS	√	√	√	√	8
MONDEO	3.0L	Duratec SE	2001	ACM	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	CDP	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	CSM	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	EATC	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	GDM	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	GEM	√	√	√	√	○

MONDEO	3.0L	Duratec SE	2001	HEC	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	LHID	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	NAV	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	PATS	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	PCM	√	√	√	√	0009 0025
MONDEO	3.0L	Duratec SE	2001	RCM	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	RETM	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	RHID	√	√	√	√	○
MONDEO	3.0L	Duratec SE	2001	SRM	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	ABS	√	√	√	√	8
MONDEO	3.0L	Duratec-ST	2001	ABS/TCS	√	√	√	√	8
MONDEO	3.0L	Duratec-ST	2001	ACM	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	CDP	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	CSM	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	EATC	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	GDM	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	GEM	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	HEC	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	LHID	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	NAV	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	PATS	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	PCM	√	√	√	√	0009 0025
MONDEO	3.0L	Duratec-ST	2001	RCM	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	RETM	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	RHID	√	√	√	√	○
MONDEO	3.0L	Duratec-ST	2001	SRM	√	√	√	√	○
Marauder	4.6L	4V	2003 - 2004	ABS/TCS	√	√	√	√	○
Marauder	4.6L	4V	2003 - 2004	DDM	√	√	√	√	000A 000F
Marauder	4.6L	4V	2003 - 2004	EATC	√	√	√	√	○
Marauder	4.6L	4V	2003 - 2004	LCM	√	√	√	√	○
Marauder	4.6L	4V	2003 - 2004	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Marauder	4.6L	4V	2003 - 2004	RASM	√	√	√	√	○
Marauder	4.6L	4V	2003 - 2004	RCM	√	√	√	√	000C
Marauder	4.6L	4V	2003 - 2004	VAPS	√	√	√	√	○
Mariner	2.3L	DURATEC-HE / I4	2006 - 2007	4X4	√	√	√	√	○
Mariner	2.3L	DURATEC-HE / I4	2006 - 2007	ABS	√	√	√	√	8
Mariner	2.3L	DURATEC-HE / I4	2006 - 2007	GEM	√	√	√	√	000A 000F
Mariner	2.3L	DURATEC-HE / I4	2006 - 2007	IC	√	√	√	√	○
Mariner	2.3L	DURATEC-HE / I4	2006 - 2007	PAM	√	√	√	√	○
Mariner	2.3L	DURATEC-HE / I4	2006 - 2007	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033 00C5
Mariner	2.3L	DURATEC-HE / I4	2006 - 2007	RCM	√	√	√	√	000C
Mariner	3.0L	4V	2006 - 2007	4X4	√	√	√	√	○
Mariner	3.0L	4V	2006 - 2007	ABS	√	√	√	√	0005 0008
Mariner	3.0L	4V	2006 - 2007	GEM	√	√	√	√	000A 000F

Mariner	3.0L	4V	2006 - 2007	IC	√	√	√	√	5
Mariner	3.0L	4V	2006 - 2007	PAM	√	√	√	√	○
Mariner	3.0L	4V	2006 - 2007	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033 00C5
Mariner	3.0L	4V	2006 - 2007	RCM	√	√	√	√	000C
Mark LT	5.4L	3V	2006 - 2007	EATC	√	√	√	√	○
Mark LT	5.4L	3V	2006 - 2008	4X4	√	√	√	√	○
Mark LT	5.4L	3V	2006 - 2008	ABS	√	√	√	√	0008 000B 0005
Mark LT	5.4L	3V	2006 - 2008	DSM	√	√	√	√	○
Mark LT	5.4L	3V	2006 - 2008	IC	√	√	√	√	○
Mark LT	5.4L	3V	2006 - 2008	PAM	√	√	√	√	○
Mark LT	5.4L	3V	2006 - 2008	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Mark LT	5.4L	3V	2006 - 2008	RCM	√	√	√	√	000C
Mark LT	5.4L	3V	2006 - 2008	VSM	√	√	√	√	000A 000F
Mark LT	5.4L	3V	2008	HVAC	√	√	√	√	○
Mark LT	5.4L	3V	2008	RETM	√	√	√	√	○
Mark VIII	4.6L	4V	1996 - 1998	ABS/TCS	√	√	√	√	8
Mark VIII	4.6L	4V	1996 - 1998	CPM	√	√	√	√	○
Mark VIII	4.6L	4V	1996 - 1998	DDM	√	√	√	√	000F
Mark VIII	4.6L	4V	1996 - 1998	DSM	√	√	√	√	○
Mark VIII	4.6L	4V	1996 - 1998	HEC	√	√	√	√	○
Mark VIII	**4.6L**	**4V**	1996 - 1998	**PCM**	√	√	√	√	0023 0025
Mark VIII	4.6L	4V	1996 - 1998	PSM	√	√	√	√	○
Mark VIII	4.6L	4V	1996 - 1998	SCIL	√	√	√	√	9
Mark VIII	4.6L	4V	1997 - 1998	EATC	√	√	√	√	○
Mark VIII	4.6L	4V	1997 - 1998	MC	√	√	√	√	○
Milan	2.3L	DURATEC-HE / I4	2006 - 2007	EATC	√	√	√	√	○
Milan	2.3L	DURATEC-HE / I4	2006 - 2007	GEM	√	√	√	√	○
Milan	2.3L	DURATEC-HE / I4	2006 - 2009	ABS	√	√	√	√	○
Milan	2.3L	DURATEC-HE / I4	2006 - 2009	ACM	√	√	√	√	○
Milan	2.3L	DURATEC-HE / I4	2006 - 2009	IC	√	√	√	√	0005 0009
Milan	2.3L	DURATEC-HE / I4	2006 - 2009	OCSM	√	√	√	○	○
Milan	2.3L	DURATEC-HE / I4	2006 - 2009	PCM	√	√	√	√	23
Milan	2.3L	DURATEC-HE / I4	2006 - 2009	RCM	√	√	√	√	5
Milan	2.3L	DURATEC-HE / I4	2006 - 2009	TCM	√	√	√	√	○
Milan	2.3L	DURATEC-HE / I4	2007 - 2009	4X4	√	√	√	√	○
Milan	2.3L	DURATEC-HE / I4	2007 - 2009	SDARS	√	√	√	√	○
Milan	2.3L	DURATEC-HE / I4	2008 - 2009	APIM	√	√	√	√	○
Milan	2.3L	DURATEC-HE / I4	2008 - 2009	GEM / SJB	√	√	√	√	42
Milan	2.3L	DURATEC-HE / I4	2008 - 2009	HVAC	√	√	√	√	○
Milan	2.3L	DURATEC-HE / I4	2008 - 2009	PAM	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	4X4	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	ABS	√	√	√	√	12
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	ACM	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	APIM	√	√	√	√	○

Milan	2.5L	DURATEC-HE / I4	2010 - 2011	DSP	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	FCIM	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	FDIM	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	GEM / SJB	√	√	√	√	000A 000F 0042
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	GPSM	√	√	√	○	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	HVAC	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	IPC	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	OCSM	√	√	√	√	000C 0015
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	PAM	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	PCM	√	√	√	√	0009 0025
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	PSCM	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	RCM	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	SOD-L	√	√	√	√	○
Milan	2.5L	DURATEC-HE / I4	2010 - 2011	SOD-R	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	4X4	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	ABS	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	ACCM#2	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	ACM	√	√	√	√	5
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	APIM	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	BECM	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	DCDC	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	DSP	√	√	√	√	5
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	FCIM	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	FDIM	√	√	√	√	5
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	GEM / SJB	√	√	√	√	000A 000F 0042
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	GPSM	√	√	√	○	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	HVAC	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	IPC	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	OCSM	√	√	√	√	000C 0015
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	PAM	√	√	√	√	5
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	PSCM	√	√	√	√	5
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	RCM	√	√	√	√	5
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	SOD-L	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	SOD-R	√	√	√	√	○
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	TCM	√	√	√	√	○
Milan	3.0L	4V	2006 - 2007	EATC	√	√	√	√	○
Milan	3.0L	4V	2006 - 2007	GEM	√	√	√	√	○
Milan	3.0L	4V	2006 - 2009	IC	√	√	√	√	5
Milan	3.0L	4V	2006 - 2009	TCM	√	√	√	√	○
Milan	3.0L	4V	2006 - 2011	ABS	√	√	√	√	12
Milan	3.0L	4V	2006 - 2011	ACM	√	√	√	√	○
Milan	3.0L	4V	2006 - 2011	OCSM	√	√	√	○	000C 0015
Milan	3.0L	4V	2006 - 2011	PCM	√	√	√	√	0023 0009 0025
Milan	3.0L	4V	2006 - 2011	RCM	√	√	√	√	5

Milan	3.0L	4V	2007 - 2009	SDARS	√	√	√	√	5
Milan	3.0L	4V	2007 - 2011	4X4	√	√	√	√	○
Milan	3.0L	4V	2008 - 2011	APIM	√	√	√	√	○
Milan	3.0L	4V	2008 - 2011	GEM / SJB	√	√	√	√	0005 000A 000F 0042
Milan	3.0L	4V	2008 - 2011	HVAC	√	√	√	√	○
Milan	3.0L	4V	2008 - 2011	PAM	√	√	√	√	5
Milan	3.0L	4V	2010 - 2011	DSP	√	√	√	√	○
Milan	3.0L	4V	2010 - 2011	FCIM	√	√	√	√	○
Milan	3.0L	4V	2010 - 2011	FDIM	√	√	√	√	○
Milan	3.0L	4V	2010 - 2011	GPSM	√	√	√	○	○
Milan	3.0L	4V	2010 - 2011	IPC	√	√	√	√	○
Milan	3.0L	4V	2010 - 2011	PSCM	√	√	√	√	○
Milan	3.0L	4V	2010 - 2011	SOD-L	√	√	√	√	○
Milan	3.0L	4V	2010 - 2011	SOD-R	√	√	√	√	○
Montego	3.0L	4V	2006 - 2007	4X4	√	√	√	√	○
Montego	3.0L	4V	2006 - 2007	ABS	√	√	√	√	5
Montego	3.0L	4V	2006 - 2007	ACM	√	√	√	√	5
Montego	3.0L	4V	2006 - 2007	DSM	√	√	√	√	5
Montego	3.0L	4V	2006 - 2007	EATC	√	√	√	√	○
Montego	3.0L	4V	2006 - 2007	GEM	√	√	√	√	5
Montego	3.0L	4V	2006 - 2007	IC	√	√	√	√	5
Montego	3.0L	4V	2006 - 2007	PAM	√	√	√	√	○
Montego	3.0L	4V	2006 - 2007	PCM	√	√	√	√	0009 0023
Montego	3.0L	4V	2006 - 2007	RCM	√	√	√	√	5
Montego	3.0L	4V	2006 - 2007	RETM	√	√	√	√	○
Montego	3.0L	4V	2006 - 2007	TCM	√	√	√	√	○
Montego	3.0L	4V	2007	SDARS	√	√	√	√	○
Motorhome / Stripped Chassis / Step Van	6.8L	2V	2004	ABS/TCS	√	√	√	√	8
Motorhome / Stripped Chassis / Step Van	6.8L	2V	2004	PCM	√	√	√	√	0010 0023 0028 0031 0033
Motorhome / Stripped Chassis / Step Van	6.8L	3V	2006 - 2011	ABS/TCS	√	√	√	√	8
Motorhome / Stripped Chassis / Step Van	6.8L	3V	2006 - 2012	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
Motorhome / Stripped Chassis / Step Van	6.8L	3V	2006 - 2013	IC	√	√	√	√	○
Motorhome / Stripped Chassis / Step Van	6.8L	3V	2012	ABS	√	√	√	√	○
Mountaineer	4.0L	2V	2006 - 2007	EATC	√	√	√	√	○
Mountaineer	4.0L	2V	2006 - 2007	GEM	√	√	√	√	000A 000F
Mountaineer	4.0L	2V	2006 - 2010	4X4	√	√	√	√	○
Mountaineer	4.0L	2V	2006 - 2010	ABS	√	√	√	√	0008 0012 0005
Mountaineer	4.0L	2V	2006 - 2010	ACM	√	√	√	√	○
Mountaineer	4.0L	2V	2006 - 2010	DSM	√	√	√	√	5

Mountaineer	4.0L	2V	2006 - 2010	IC	√	√	√	√	0009 0005
Mountaineer	4.0L	2V	2006 - 2010	OCSM	√	√	√	○	000C 0015
Mountaineer	4.0L	2V	2006 - 2010	PAM	√	√	√	√	○
Mountaineer	4.0L	2V	2006 - 2010	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C6
Mountaineer	4.0L	2V	2006 - 2010	PRB	√	√	√	√	○
Mountaineer	4.0L	2V	2006 - 2010	RCM	√	√	√	√	5
Mountaineer	4.0L	2V	2006 - 2010	RETM	√	√	√	√	○
Mountaineer	4.0L	2V	2006 - 2010	SDARS	√	√	√	√	5
Mountaineer	4.0L	2V	2008 - 2010	APIM	√	√	√	√	○
Mountaineer	4.0L	2V	2008 - 2010	GEM / SJB	√	√	√	√	0005 000A 000F 0042
Mountaineer	4.0L	2V	2008 - 2010	HVAC	√	√	√	√	5
Mountaineer	4.0L	2V	2010	GPSM	√	√	√	○	○
Mountaineer	4.0L	V6 SOHC	1998 - 2000	ARC	√	√	√	√	000E
Mountaineer	4.0L	V6 SOHC	1998 - 2000	IAB	√	√	√	√	○
Mountaineer	4.0L	V6 SOHC	1998 - 2000	PATS	√	√	√	√	9
Mountaineer	4.0L	V6 SOHC	1998 - 2000	RAP	√	√	√	√	000A 000F
Mountaineer	4.0L	V6 SOHC	1998 - 2002	GEM	√	√	√	√	○
Mountaineer	4.0L	V6 SOHC	1998 - 2003	ABS/TCS	√	√	√	√	0008 0012
Mountaineer	4.0L	V6 SOHC	1998 - 2005	DSM	√	√	√	√	○
Mountaineer	4.0L	V6 SOHC	1998 - 2005	EATC	√	√	√	√	5
Mountaineer	4.0L	V6 SOHC	1998 - 2005	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033 0009 00C6
Mountaineer	4.0L	V6 SOHC	1999 - 2005	PAM	√	√	√	√	○
Mountaineer	4.0L	V6 SOHC	2002	CSM	√	√	√	√	000F
Mountaineer	4.0L	V6 SOHC	2002 - 2003	HEC	√	√	√	√	○
Mountaineer	4.0L	V6 SOHC	2002 - 2005	4X4	√	√	√	√	○
Mountaineer	4.0L	V6 SOHC	2002 - 2005	IC	√	√	√	√	5
Mountaineer	4.0L	V6 SOHC	2002 - 2005	RCM	√	√	√	√	000C
Mountaineer	4.0L	V6 SOHC	2002 - 2005	TPM	√	√	√	√	5
Mountaineer	4.0L	V6 SOHC	2003 - 2005	VSM	√	√	√	√	000A 000F
Mountaineer	4.0L	V6 SOHC	2004 - 2005	ABS	√	√	√	√	0005 0008 0012
Mountaineer	4.6L	2V	2002	CSM	√	√	√	√	000F
Mountaineer	4.6L	2V	2002	GEM	√	√	√	√	○
Mountaineer	4.6L	2V	2002 - 2003	ABS/TCS	√	√	√	√	0008 0012
Mountaineer	4.6L	2V	2002 - 2003	HEC	√	√	√	√	○
Mountaineer	4.6L	2V	2002 - 2005	4X4	√	√	√	√	○
Mountaineer	4.6L	2V	2002 - 2005	DSM	√	√	√	√	○
Mountaineer	4.6L	2V	2002 - 2005	EATC	√	√	√	√	5
Mountaineer	4.6L	2V	2002 - 2005	IC	√	√	√	√	5
Mountaineer	4.6L	2V	2002 - 2005	PAM	√	√	√	√	○

Mountaineer	4.6L	2V	2002 - 2005	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033 00C6
Mountaineer	4.6L	2V	2002 - 2005	RCM	√	√	√	√	000C
Mountaineer	4.6L	2V	2002 - 2005	TPM	√	√	√	√	5
Mountaineer	4.6L	2V	2003 - 2005	VSM	√	√	√	√	000A 000F
Mountaineer	4.6L	2V	2004 - 2005	ABS	√	√	√	√	0005 0012 0008
Mountaineer	4.6L	3V	2006 - 2007	EATC	√	√	√	√	5
Mountaineer	4.6L	3V	2006 - 2007	GEM	√	√	√	√	0005 000A 000F
Mountaineer	4.6L	3V	2006 - 2010	4X4	√	√	√	√	○
Mountaineer	4.6L	3V	2006 - 2010	ABS	√	√	√	√	0005 0008 0012
Mountaineer	4.6L	3V	2006 - 2010	ACM	√	√	√	√	5
Mountaineer	4.6L	3V	2006 - 2010	DSM	√	√	√	√	5
Mountaineer	4.6L	3V	2006 - 2010	IC	√	√	√	√	0009 0005
Mountaineer	4.6L	3V	2006 - 2010	OCSM	√	√	√	○	000C 0015
Mountaineer	4.6L	3V	2006 - 2010	PAM	√	√	√	√	5
Mountaineer	4.6L	3V	2006 - 2010	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C5 00C6
Mountaineer	4.6L	3V	2006 - 2010	PRB	√	√	√	√	○
Mountaineer	4.6L	3V	2006 - 2010	RCM	√	√	√	√	5
Mountaineer	4.6L	3V	2006 - 2010	RETM	√	√	√	√	5
Mountaineer	4.6L	3V	2006 - 2010	SDARS	√	√	√	√	5
Mountaineer	4.6L	3V	2006 - 2010	TCM	√	√	√	√	25
Mountaineer	4.6L	3V	2008 - 2010	APIM	√	√	√	√	○
Mountaineer	4.6L	3V	2008 - 2010	GEM / SJB	√	√	√	√	000A 000F 0042 0005
Mountaineer	4.6L	3V	2008 - 2010	HVAC	√	√	√	√	5
Mountaineer	4.6L	3V	2010	GPSM	√	√	√	○	○
Mountaineer	5.0L	Other	1997 - 2000	ABS/TCS	√	√	√	√	8
Mountaineer	5.0L	Other	1997 - 2000	ARC	√	√	√	√	000E
Mountaineer	5.0L	Other	1997 - 2000	GEM	√	√	√	√	○
Mountaineer	5.0L	Other	1997 - 2000	IAB	√	√	√	√	○
Mountaineer	5.0L	Other	1997 - 2000	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
Mountaineer	5.0L	Other	1997 - 2000	RAP	√	√	√	√	000F 000A
Mountaineer	5.0L	Other	1998 - 2000	DSM	√	√	√	√	○
Mountaineer	5.0L	Other	1998 - 2000	EATC	√	√	√	√	○
Mountaineer	5.0L	Other	1998 - 2000	PATS	√	√	√	√	9
Mountaineer	5.0L	Other	1999 - 2000	PAM	√	√	√	√	○
Mustang	3.7L	TiVCT	2011 - 2013	ABS	√	√	√	√	0012 0008
Mustang	3.7L	TiVCT	2011 - 2013	ACM	√	√	√	○	○
Mustang	3.7L	TiVCT	2011 - 2013	APIM	√	√	√	√	○
Mustang	3.7L	TiVCT	2011 - 2013	BCM-B	√	√	√	√	○
Mustang	3.7L	TiVCT	2011 - 2013	FCIM	√	√	√	√	○

Mustang	3.7L	TiVCT	2011 - 2013	FDIM	√	√	√	√	○
Mustang	3.7L	TiVCT	2011 - 2013	GEM / SJB	√	√	√	√	000A 0042
Mustang	3.7L	TiVCT	2011 - 2013	GPSM	√	√	√	√	○
Mustang	3.7L	TiVCT	2011 - 2013	HVAC	√	√	√	√	○
Mustang	3.7L	TiVCT	2011 - 2013	IPC	√	√	√	√	○
Mustang	3.7L	TiVCT	2011 - 2013	OCSM	√	√	√	○	000C
Mustang	3.7L	TiVCT	2011 - 2013	PCM	√	√	√	√	○
Mustang	3.7L	TiVCT	2011 - 2013	PSCM	√	√	√	○	00CB
Mustang	3.7L	TiVCT	2011 - 2013	RCM	√	√	√	√	○
Mustang	3.7L	TiVCT	2012 - 2013	PAM	√	√	√	√	○
Mustang	3.8L	Other	1994 - 2004	ABS/TCS	√	√	√	√	8
Mustang	3.8L	Other	1994 - 2004	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
Mustang	3.8L	Other	1996 - 1998	IAB	√	√	√	√	○
Mustang	3.8L	Other	1996 - 1998	PATS	√	√	√	√	0009 000A
Mustang	3.8L	Other	1999 - 2004	GEM	√	√	√	√	000A
Mustang	3.8L	Other	1999 - 2004	HEC	√	√	√	√	9
Mustang	3.8L	Other	1999 - 2004	RCM	√	√	√	√	○
Mustang	3.9L	Other	2004	ABS/TCS	√	√	√	√	8
Mustang	3.9L	Other	2004	GEM	√	√	√	√	000A
Mustang	3.9L	Other	2004	HEC	√	√	√	√	9
Mustang	3.9L	Other	2004	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
Mustang	3.9L	Other	2004	RCM	√	√	√	√	○
Mustang	4.0L	V6 SOHC	2005 - 2007	GEM	√	√	√	√	000A 0005
Mustang	4.0L	V6 SOHC	2005 - 2009	IC	√	√	√	√	5
Mustang	4.0L	V6 SOHC	2005 - 2010	ABS	√	√	√	√	0008 0012
Mustang	4.0L	V6 SOHC	2005 - 2010	ACM	√	√	√	√	0005 0017
Mustang	4.0L	V6 SOHC	2005 - 2010	PCM	√	√	√	√	9
Mustang	4.0L	V6 SOHC	2005 - 2010	RCM	√	√	√	√	000C
Mustang	4.0L	V6 SOHC	2007 - 2009	SDARS	√	√	√	√	○
Mustang	4.0L	V6 SOHC	2008 - 2010	GEM / SJB	√	√	√	√	000A 0042
Mustang	4.0L	V6 SOHC	2009 - 2010	APIM	√	√	√	√	○
Mustang	4.0L	V6 SOHC	2010	BCM-B	√	√	√	√	○
Mustang	4.0L	V6 SOHC	2010	FCIM	√	√	√	○	○
Mustang	4.0L	V6 SOHC	2010	FDIM	√	√	√	√	○
Mustang	4.0L	V6 SOHC	2010	GPSM	√	√	√	○	○
Mustang	4.0L	V6 SOHC	2010	HVAC	√	√	√	√	○
Mustang	4.0L	V6 SOHC	2010	IPC	√	√	√	√	○
Mustang	4.0L	V6 SOHC	2010	OCSM	√	√	√	○	000C
Mustang	4.6L	2V	1996 - 1998	IAB	√	√	√	√	○
Mustang	4.6L	2V	1996 - 1998	PATS	√	√	√	√	0009 000A
Mustang	4.6L	2V	1996 - 2004	ABS/TCS	√	√	√	√	8
Mustang	4.6L	2V	1996 - 2004	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
Mustang	4.6L	2V	1999 - 2004	GEM	√	√	√	√	000A
Mustang	4.6L	2V	1999 - 2004	HEC	√	√	√	√	9
Mustang	4.6L	2V	1999 - 2004	RCM	√	√	√	√	○
Mustang	4.6L	3V	2005 - 2007	GEM	√	√	√	√	000A
Mustang	4.6L	3V	2005 - 2009	IC	√	√	√	√	5
Mustang	4.6L	3V	2005 - 2010	ABS	√	√	√	√	0008 0012

Mustang	4.6L	3V	2005 - 2010	ACM	√	√	√	√	○
Mustang	4.6L	3V	2005 - 2010	PCM	√	√	√	√	9
Mustang	4.6L	3V	2005 - 2010	RCM	√	√	√	√	000C
Mustang	4.6L	3V	2007 - 2009	SDARS	√	√	√	√	○
Mustang	4.6L	3V	2008 - 2010	GEM / SJB	√	√	√	√	000A 0042
Mustang	4.6L	3V	2009 - 2010	APIM	√	√	√	√	○
Mustang	4.6L	3V	2010	BCM-B	√	√	√	√	○
Mustang	4.6L	3V	2010	FCIM	√	√	√	○	○
Mustang	4.6L	3V	2010	FDIM	√	√	√	√	○
Mustang	4.6L	3V	2010	GPSM	√	√	√	○	○
Mustang	4.6L	3V	2010	HVAC	√	√	√	√	○
Mustang	4.6L	3V	2010	IPC	√	√	√	√	○
Mustang	4.6L	3V	2010	OCSM	√	√	√	○	000C
Mustang	4.6L	4V	1996 - 1998	IAB	√	√	√	√	○
Mustang	4.6L	4V	1996 - 1998	PATS	√	√	√	√	0009 000A
Mustang	4.6L	4V	1996 - 2004	ABS/TCS	√	√	√	√	8
Mustang	4.6L	4V	1996 - 2004	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
Mustang	4.6L	4V	1999 - 2004	GEM	√	√	√	√	000A
Mustang	4.6L	4V	1999 - 2004	HEC	√	√	√	√	9
Mustang	4.6L	4V	1999 - 2004	RCM	√	√	√	√	○
Mustang	4.6L	Other	1996 - 1997	ABS/TCS	√	√	√	√	○
Mustang	4.6L	Other	1996 - 1997	PATS	√	√	√	√	0009 000A
Mustang	4.6L	Other	1996 - 1997	PCM	√	√	√	√	0023 0025
Mustang	5.0L	BOSS	2012 - 2013	ABS	√	√	√	√	0012 0008
Mustang	5.0L	BOSS	2012 - 2013	ACM	√	√	√	√	○
Mustang	5.0L	BOSS	2012 - 2013	APIM	√	√	√	√	○
Mustang	5.0L	BOSS	2012 - 2013	BCM-B	√	√	√	√	○
Mustang	5.0L	BOSS	2012 - 2013	FCIM	√	√	√	√	○
Mustang	5.0L	BOSS	2012 - 2013	FDIM	√	√	√	√	○
Mustang	5.0L	BOSS	2012 - 2013	GEM / SJB	√	√	√	√	000A 0042
Mustang	5.0L	BOSS	2012 - 2013	GPSM	√	√	√	○	○
Mustang	5.0L	BOSS	2012 - 2013	HVAC	√	√	√	√	○
Mustang	5.0L	BOSS	2012 - 2013	IPC	√	√	√	√	○
Mustang	5.0L	BOSS	2012 - 2013	OCSM	√	√	√	○	000C
Mustang	5.0L	BOSS	2012 - 2013	PAM	√	√	√	√	○
Mustang	5.0L	BOSS	2012 - 2013	PCM	√	√	√	√	○
Mustang	5.0L	BOSS	2012 - 2013	PSCM	√	√	√	○	00CB
Mustang	5.0L	BOSS	2012 - 2013	RCM	√	√	√	√	○
Mustang	5.0L	TiVCT	2011 - 2013	ABS	√	√	√	√	0008 0012
Mustang	5.0L	TiVCT	2011 - 2013	ACM	√	√	√	○	○
Mustang	5.0L	TiVCT	2011 - 2013	APIM	√	√	√	√	○
Mustang	5.0L	TiVCT	2011 - 2013	BCM-B	√	√	√	√	○
Mustang	5.0L	TiVCT	2011 - 2013	FCIM	√	√	√	√	○
Mustang	5.0L	TiVCT	2011 - 2013	FDIM	√	√	√	√	○
Mustang	5.0L	TiVCT	2011 - 2013	GEM / SJB	√	√	√	√	000A 0042
Mustang	5.0L	TiVCT	2011 - 2013	GPSM	√	√	√	√	○
Mustang	5.0L	TiVCT	2011 - 2013	HVAC	√	√	√	√	○
Mustang	5.0L	TiVCT	2011 - 2013	IPC	√	√	√	√	○
Mustang	5.0L	TiVCT	2011 - 2013	OCSM	√	√	√	○	000C
Mustang	5.0L	TiVCT	2011 - 2013	PCM	√	√	√	√	○

Mustang	5.0L	TiVCT	2011 - 2013	PSCM	√	√	√	○	00CB
Mustang	5.0L	TiVCT	2011 - 2013	RCM	√	√	√	√	○
Mustang	5.0L	TiVCT	2012 - 2013	PAM	√	√	√	√	○
Mustang	5.4L	4V	2007	GEM	√	√	√	√	○
Mustang	5.4L	4V	2007 - 2009	IC	√	√	√	√	○
Mustang	5.4L	4V	2007 - 2009	SDARS	√	√	√	√	○
Mustang	5.4L	4V	2007 - 2012	ABS	√	√	√	√	0008 0012
Mustang	5.4L	4V	2007 - 2012	ACM	√	√	√	√	○
Mustang	5.4L	4V	2007 - 2012	PCM	√	√	√	√	9
Mustang	5.4L	4V	2007 - 2012	RCM	√	√	√	√	000C
Mustang	5.4L	4V	2008 - 2012	GEM / SJB	√	√	√	√	000A 0042
Mustang	5.4L	4V	2009 - 2012	APIM	√	√	√	√	○
Mustang	5.4L	4V	2010 - 2012	BCM-B	√	√	√	√	○
Mustang	5.4L	4V	2010 - 2012	FCIM	√	√	√	○	○
Mustang	5.4L	4V	2010 - 2012	FDIM	√	√	√	√	○
Mustang	5.4L	4V	2010 - 2012	GPSM	√	√	√	○	○
Mustang	5.4L	4V	2010 - 2012	HVAC	√	√	√	√	○
Mustang	5.4L	4V	2010 - 2012	IPC	√	√	√	√	○
Mustang	5.4L	4V	2010 - 2012	OCSM	√	√	√	○	000C
Mustang	5.4L	4V	2011 - 2012	PSCM	√	√	√	○	00CB
Mustang	5.4L	4V	2012	PAM	√	√	√	√	○
Mustang	5.4L	Other	2000	ABS/TCS	√	√	√	√	8
Mustang	5.4L	Other	2000	PCM	√	√	√	√	0023 0025
Mustang	5.8L	4V	2013	ABS	√	√	√	√	0008 0012
Mustang	5.8L	4V	2013	ACM	√	√	√	√	○
Mustang	5.8L	4V	2013	APIM	√	√	√	√	○
Mustang	5.8L	4V	2013	BCM-B	√	√	√	√	○
Mustang	5.8L	4V	2013	FCIM	√	√	√	√	○
Mustang	5.8L	4V	2013	FDIM	√	√	√	√	○
Mustang	5.8L	4V	2013	GEM / SJB	√	√	√	√	000A 0042
Mustang	5.8L	4V	2013	GPSM	√	√	√	○	○
Mustang	5.8L	4V	2013	HVAC	√	√	√	√	○
Mustang	5.8L	4V	2013	IPC	√	√	√	√	○
Mustang	5.8L	4V	2013	OCSM	√	√	√	○	○
Mustang	5.8L	4V	2013	PAM	√	√	√	√	○
Mustang	5.8L	4V	2013	PCM	√	√	√	√	○
Mustang	5.8L	4V	2013	PSCM	√	√	√	○	00CB
Mustang	5.8L	4V	2013	RCM	√	√	√	○	○
Mustang	5.8L	4V	2013	VDM	√	√	√	√	○
Mystique	2.0L	Zetec	1996 - 2000	ABS/TCS	√	√	√	√	8
Mystique	2.0L	Zetec	1996 - 2000	CSM	√	√	√	√	○
Mystique	2.0L	Zetec	1996 - 2000	PCM	√	√	√	√	0023 0025 0009
Mystique	2.0L	Zetec	1997 - 1998	PATS	√	√	√	√	9
Mystique	2.0L	Zetec	1999 - 2000	RCM	√	√	√	√	○
Mystique	2.5L	Duratec-VE	1996 - 2000	ABS/TCS	√	√	√	√	8
Mystique	2.5L	Duratec-VE	1996 - 2000	CSM	√	√	√	√	○
Mystique	2.5L	Duratec-VE	1996 - 2000	PCM	√	√	√	√	0023 0025 0009
Mystique	2.5L	Duratec-VE	1997 - 1998	PATS	√	√	√	√	9
Mystique	2.5L	Duratec-VE	1999 - 2000	RCM	√	√	√	√	○
NOVO KA	1.0L	FFV	2008 - 2011	IC	√	√	√	√	○
NOVO KA	1.0L	FFV	2008 - 2011	PCM	√	√	√	√	0009 0023 0025
NOVO KA	1.0L	FFV	2008 - 2011	RCM	√	√	√	√	○
NOVO KA	1.0L	FFV	2008 - 2011	RKE	√	√	√	√	000A
NOVO KA	1.0L	FFV	2009 - 2011	TBM	√	√	√	√	○
NOVO KA	1.0L	Zetec Rocam	2008 - 2009	IC	√	√	√	√	○

NOVO KA	1.0L	Zetec Rocam	2008 - 2009	PCM	√	√	√	√	0009 0023 0025
NOVO KA	1.0L	Zetec Rocam	2008 - 2009	RCM	√	√	√	√	○
NOVO KA	1.0L	Zetec Rocam	2008 - 2009	RKE	√	√	√	√	000A
NOVO KA	1.0L	Zetec Rocam	2009	TBM	√	√	√	√	○
NOVO KA	1.6L	FFV	2008 - 2011	IC	√	√	√	√	○
NOVO KA	1.6L	FFV	2008 - 2011	PCM	√	√	√	√	0009 0023 0025
NOVO KA	1.6L	FFV	2008 - 2011	RCM	√	√	√	√	○
NOVO KA	1.6L	FFV	2008 - 2011	RKE	√	√	√	√	000A
NOVO KA	1.6L	FFV	2009 - 2011	TBM	√	√	√	√	○
NOVO KA	1.6L	Zetec Rocam	2008 - 2009	IC	√	√	√	√	○
NOVO KA	1.6L	Zetec Rocam	2008 - 2009	PCM	√	√	√	√	0009 0023 0025
NOVO KA	1.6L	Zetec Rocam	2008 - 2009	RCM	√	√	√	√	○
NOVO KA	1.6L	Zetec Rocam	2008 - 2009	RKE	√	√	√	√	000A
NOVO KA	1.6L	Zetec Rocam	2009	TBM	√	√	√	√	○
NOVO KA	Other	Other	2008	IC	√	√	√	√	9
NOVO KA	Other	Other	2008	PCM	√	√	√	√	0023 0025
NOVO KA	Other	Other	2008	RCM	√	√	√	√	○
NOVO KA	Other	Other	2008	RKE	√	√	√	√	000A
Navigator	5.4L	3V	2005 - 2006	NAV	√	√	√	√	○
Navigator	5.4L	3V	2005 - 2006	VSM	√	√	√	√	5
Navigator	5.4L	3V	2005 - 2007	EATC	√	√	√	√	5
Navigator	5.4L	3V	2005 - 2010	4X4	√	√	√	√	○
Navigator	5.4L	3V	2005 - 2011	TCM	√	√	√	√	○
Navigator	5.4L	3V	2005 - 2012	ABS	√	√	√	√	0005 0012 0008
Navigator	5.4L	3V	2005 - 2012	DCSM	√	√	√	√	○
Navigator	5.4L	3V	2005 - 2012	DSM	√	√	√	√	5
Navigator	5.4L	3V	2005 - 2012	IC	√	√	√	√	0005 0009
Navigator	5.4L	3V	2005 - 2012	LTM	√	√	√	√	5
Navigator	5.4L	3V	2005 - 2012	PAM	√	√	√	√	○
Navigator	5.4L	3V	2005 - 2012	PCM	√	√	√	√	○
Navigator	5.4L	3V	2005 - 2012	RCM	√	√	√	√	5
Navigator	5.4L	3V	2005 - 2012	VDM	√	√	√	√	○
Navigator	5.4L	3V	2007	GEM	√	√	√	√	○
Navigator	5.4L	3V	2007 - 2012	ACM	√	√	√	○	5
Navigator	5.4L	3V	2007 - 2012	DSP	√	√	√	√	5
Navigator	5.4L	3V	2007 - 2012	PRB	√	√	√	√	○
Navigator	5.4L	3V	2007 - 2012	RCU	√	√	√	√	○
Navigator	5.4L	3V	2007 - 2012	RETM	√	√	√	√	5
Navigator	5.4L	3V	2007 - 2012	SDARS	√	√	√	√	5
Navigator	5.4L	3V	2008 - 2012	APIM	√	√	√	√	○
Navigator	5.4L	3V	2008 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Navigator	5.4L	3V	2008 - 2012	HVAC	√	√	√	√	○
Navigator	5.4L	3V	2010 - 2012	GPSM	√	√	√	○	○
Navigator	5.4L	3V	2010 - 2012	TCCM	√	√	√	√	○
Navigator	5.4L	4V	1999 - 2000	4WAS	√	√	√	√	000E
Navigator	5.4L	4V	1999 - 2000	GEM	√	√	√	√	○
Navigator	5.4L	4V	1999 - 2000	RAP	√	√	√	√	000A 000F

Navigator	5.4L	4V	1999 - 2004	ABS/TCS	√	√	√	√	0008 0012
Navigator	5.4L	4V	1999 - 2004	DSM	√	√	√	√	○
Navigator	5.4L	4V	1999 - 2004	EATC	√	√	√	√	○
Navigator	5.4L	4V	1999 - 2004	HEC	√	√	√	√	9
Navigator	5.4L	4V	1999 - 2004	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033 0009
Navigator	5.4L	4V	1999 - 2004	RCM	√	√	√	√	000C
Navigator	5.4L	4V	2000 - 2004	PAM	√	√	√	√	○
Navigator	5.4L	4V	2003 - 2004	4X4	√	√	√	√	○
Navigator	5.4L	4V	2003 - 2004	DCSM	√	√	√	√	○
Navigator	5.4L	4V	2003 - 2004	LTM	√	√	√	√	○
Navigator	5.4L	4V	2003 - 2004	NAV	√	√	√	√	○
Navigator	5.4L	4V	2003 - 2004	PCSM	√	√	√	√	○
Navigator	5.4L	4V	2003 - 2004	TPM	√	√	√	√	○
Navigator	5.4L	4V	2003 - 2004	VDM	√	√	√	√	○
Navigator	5.4L	4V	2003 - 2004	VSM	√	√	√	√	000A 000F
Navigator	5.4L	Other	1998	4WAS	√	√	√	√	○
Navigator	5.4L	Other	1998	ABS/TCS	√	√	√	√	8
Navigator	5.4L	Other	1998	DSM	√	√	√	√	○
Navigator	5.4L	Other	1998	GEM	√	√	√	√	○
Navigator	5.4L	Other	1998	IAB	√	√	√	√	○
Navigator	5.4L	Other	1998	PATS	√	√	√	√	9
Navigator	5.4L	Other	1998	PCM	√	√	√	√	0023 0025
Navigator	5.4L	Other	1998	RAP	√	√	√	√	000A 000F
Navigator	5.4L	Other	1998	RCC	√	√	√	√	○
PREMACY / IXION	1.8L	FP	1999	ABS	√	√	√	√	○
PREMACY / IXION	1.8L	FP	1999 - 2002	PCM	√	√	√	√	○
PREMACY / IXION	1.8L	FP	2002	ABS/TCS	√	√	√	√	○
PREMACY / IXION	1.8L	FP_DE	1999	ABS	√	√	√	√	○
PREMACY / IXION	1.8L	FP_DE	1999	PCM	√	√	√	√	○
PREMACY / IXION	2.0L	FS	2001	ABS/TCS	√	√	√	√	○
PREMACY / IXION	2.0L	FS	2001	PCM	√	√	√	√	○
PREMACY / IXION	2.0L	RF-T	1999	ABS	√	√	√	√	○
PREMACY / IXION	2.0L	RF-T	1999	PCM	√	√	√	√	○
PROBE / MX-6	2.0L	Other	1996 - 1997	PCM	√	√	√	√	0023 0025
PROBE / MX-6	2.5L	KL	1996 - 1997	PCM	√	√	√	√	○
Puma	1.4L	Zetec-SE	19985 - 1999	ABS/TCS	√	√	√	√	○
Puma	1.4L	Zetec-SE	19985 - 1999	HEC	√	√	√	√	○
Puma	1.4L	Zetec-SE	19985 - 1999	PATS	○	○	√	○	○
Puma	1.4L	Zetec-SE	19985 - 1999	PCM	√	√	√	√	0023 0025
Puma	1.4L	Zetec-SE	1999	GEM	√	√	√	√	○
Puma	1.6L	Zetec-SE	2001	ABS/TCS	√	√	√	√	○
Puma	1.6L	Zetec-SE	2001	GEM	√	√	√	√	○
Puma	1.6L	Zetec-SE	2001	HEC	√	√	√	√	○
Puma	1.6L	Zetec-SE	2001	PATS	√	√	√	√	○
Puma	1.6L	Zetec-SE	2001	PCM	√	√	√	√	0009 0023 0025
Puma	1.7L	Zetec-SE	1997 - 2001	ABS/TCS	√	√	√	√	○
Puma	1.7L	Zetec-SE	1997 - 2001	HEC	√	√	√	√	○
Puma	1.7L	Zetec-SE	1997 - 2001	PATS	√	√	√	√	○
Puma	1.7L	Zetec-SE	1997 - 2001	PCM	√	√	√	√	0023 0025
Puma	1.7L	Zetec-SE	1999 - 2001	GEM	√	√	√	√	○
ROADSTER / MX-5	1.6L	B6	2000	ABS	√	√	√	√	○

ROADSTER / MX-5	1.6L	B6	2002	ABS/TCS	√	√	√	√	○
ROADSTER / MX-5	1.6L	B6	2002	PCM	√	√	√	√	○
ROADSTER / MX-5	1.8L	BP	2000	ABS	√	√	√	√	○
ROADSTER / MX-5	1.8L	BP	2002	ABS/TCS	√	√	√	√	○
ROADSTER / MX-5	1.8L	BP	2002	PCM	√	√	√	√	○
ROADSTER / MX-5	1.8L	BP Turbo	2003	ABS/TCS	√	√	√	√	○
ROADSTER / MX-5	1.8L	BP Turbo	2003	PCM	√	√	√	√	○
ROADSTER / MX-5	2.0L	LF	2005 - 2008	ABS	√	√	√	√	○
ROADSTER / MX-5	2.0L	LF	2005 - 2008	IC	√	√	√	√	○
ROADSTER / MX-5	2.0L	LF	2005 - 2008	PCM	√	√	√	√	○
ROADSTER / MX-5	2.0L	LF	2005 - 2008	RCM	√	√	√	√	○
ROADSTER / MX-5	2.0L	LF	2005 - 2008	RHT	√	√	√	√	○
ROADSTER / MX-5	2.0L	LF	2005 - 2008	RKE	√	√	√	√	○
ROADSTER / MX-5	2.0L	LF	2005 - 2008	TCM	√	√	√	√	○
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	4X4	√	√	√	√	○
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	ABS/TCS	√	√	√	√	8
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	GEM	√	√	√	√	000A
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	IC	√	√	√	√	9
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	PCM	√	√	√	√	0009 0023 0025
Ranger	2.3L	DURATEC-HE / I4	2006 - 2009	RCM	√	√	√	√	○
Ranger	2.3L	DURATEC-HE / I4	2009	TBM	√	√	√	√	○
Ranger	3.0L	I4 DSL Electronic	2005	4X4	√	√	√	√	○
Ranger	3.0L	I4 DSL Electronic	2005	ABS/TCS	√	√	√	√	○
Ranger	3.0L	I4 DSL Electronic	2005	GEM	√	√	√	√	○
Ranger	3.0L	I4 DSL Electronic	2005	IC	√	√	√	√	○
Ranger	3.0L	I4 DSL Electronic	2005	PCM	√	√	√	√	9
Ranger	3.0L	I4 DSL Electronic	2005	RCM	√	√	√	√	○
Ranger	3.0L	I4 DSL Electronic	2005	TBM	√	√	√	√	○
Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	2003	ABS/TCS	√	√	√	√	8
Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	2003	ESOF	√	√	√	√	○
Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	2003	PCM	√	√	√	√	0009 0023 0025
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	√	√	√	○	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	√	√	√	√	○

Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	√	√	√	○	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	√	√	√	○	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	√	√	√	○	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TBM	√	√	√	○	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2007	GEM	√	√	√	√	000A
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2009	ABS/TCS	√	√	√	√	8
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	4X4	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	IC	√	√	√	√	9
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	PCM	√	√	√	√	0009 0023 0025 0010 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	RCM	√	√	√	√	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005	TPM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 - 2011	OCSM	√	√	√	○	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 - 2011	SDARS	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 - 2011	GEM / SJB	√	√	√	√	000A 0042
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 - 2011	ABS	√	√	√	√	0008 0012
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 - 1997	ABS/TCS	√	√	√	√	○

Ranger / Mazda B Series / Courier	2.3L	OHC	1995 - 1997	GEM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 - 1997	PCM	√	√	√	√	0023 0025
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 - 1997	RAP	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 - 1997	IAB	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.3L	Other	1996 - 2003	ABS/TCS	√	√	√	√	8
Ranger / Mazda B Series / Courier	2.3L	Other	1996 - 2003	GEM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.3L	Other	1996 - 2003	PCM	√	√	√	√	0023 0025 0009 0010 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	Other	2001	PATS	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.3L	Other	2001 - 2003	4X4	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.3L	Other	2001 - 2003	RAP	√	√	√	√	000A 000F
Ranger / Mazda B Series / Courier	2.3L	Other	2001 - 2003	RCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	ABS	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	ACM	√	√	√	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	BCMii	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	DDM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	FCDIM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	HVAC	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	IPC	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	PAM	√	√	√	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	PCM	√	√	√	√	25
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	PDM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	RCM	√	√	√	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	SRM	√	√	√	○	○

Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	TBM	√	√	√	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	TCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	TRM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998	IAB	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	ABS/TCS	√	√	√	√	8
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	GEM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	RAP	√	√	√	√	000A
Ranger / Mazda B Series / Courier	2.5L	Other	1999 - 2001	PATS	√	√	√	√	9
Ranger / Mazda B Series / Courier	2.5L	Other	1999 - 2001	RCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.5L	Other	2001	4X4	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	4X4	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	ABS/TCS	√	√	√	√	8
Ranger / Mazda B Series / Courier	2.8L	Other	2001	GEM	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	PATS	√	√	√	√	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	PCM	√	√	√	√	9
Ranger / Mazda B Series / Courier	2.8L	Other	2001	RAP	√	√	√	√	000A
Ranger / Mazda B Series / Courier	2.8L	Other	2001	RCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	ABS/TCS	√	√	√	√	8
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	GEM	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	PATS	√	√	√	√	9
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	RAP	√	√	√	√	000A

Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	RCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2003	RAP	√	√	√	√	000A
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2007	GEM	√	√	√	√	000A
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2008	ABS/TCS	√	√	√	√	8
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2008	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033 0009
Ranger / Mazda B Series / Courier	3.0L	Other	1996 - 1998	IAB	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.0L	Other	1999 - 2008	RCM	√	√	√	√	000C
Ranger / Mazda B Series / Courier	3.0L	Other	2000 - 2001	PATS	√	√	√	√	9
Ranger / Mazda B Series / Courier	3.0L	Other	2001 - 2008	4X4	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.0L	Other	2004 - 2008	IC	√	√	√	√	9
Ranger / Mazda B Series / Courier	3.0L	Other	2005	TPM	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.0L	Other	2007 - 2008	OCSM	√	√	√	○	000C
Ranger / Mazda B Series / Courier	3.0L	Other	2007 - 2008	SDARS	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.0L	Other	2008	GEM / SJB	√	√	√	√	000A 0042
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	√	√	√	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	√	√	√	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	√	√	√	√	○

Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	√	√	√	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	√	√	√	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TBM	√	√	√	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	√	√	√	√	○
Ranger / Mazda B Series / Courier	4.0L	Other	1995 - 2002	ABS/TCS	√	√	√	√	8
Ranger / Mazda B Series / Courier	4.0L	Other	1995 - 2002	GEM	√	√	√	√	○
Ranger / Mazda B Series / Courier	4.0L	Other	1995 - 2002	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033 0009
Ranger / Mazda B Series / Courier	4.0L	Other	1995 - 2002	RAP	√	√	√	√	000A
Ranger / Mazda B Series / Courier	4.0L	Other	1996 - 1998	IAB	√	√	√	√	○
Ranger / Mazda B Series / Courier	4.0L	Other	1999 - 2001	PATS	√	√	√	√	9
Ranger / Mazda B Series / Courier	4.0L	Other	1999 - 2002	RCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	4.0L	Other	2001 - 2002	4X4	√	√	√	√	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003	RAP	√	√	√	√	000A 000F
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 - 2007	GEM	√	√	√	√	000A
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 - 2009	ABS/TCS	√	√	√	√	8
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 - 2011	4X4	√	√	√	√	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 - 2011	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 - 2011	RCM	√	√	√	√	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 - 2011	IC	√	√	√	√	9
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005	TPM	√	√	√	√	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 - 2011	OCSM	√	√	√	○	000C

Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 - 2011	SDARS	√	√	√	√	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 - 2011	GEM / SJB	√	√	√	√	000A 0042
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 - 2011	ABS	√	√	√	√	0008 0012
Ranger / Mazda B Series / Courier	Other	Other	2004	4X4	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2004	ABS/TCS	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2004	GEM	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2004	IC	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2004	PCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2004 - 2011	RCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2011	ABS	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2011	ACM	√	√	√	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	BCMii	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2011	DDM	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2011	FCDIM	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2011	HVAC	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2011	IPC	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2011	PAM	√	√	√	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	PDM	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2011	SRM	√	√	√	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	TBM	√	√	√	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	TCM	√	√	√	√	○
Ranger / Mazda B Series / Courier	Other	Other	2011	TRM	√	√	√	√	○
S. A. Fiesta	1.0L	FFV	2006 - 2010	ABS/TCS	√	√	√	√	0008 000B 000B
S. A. Fiesta	1.0L	FFV	2006 - 2010	IC	√	√	√	√	○
S. A. Fiesta	1.0L	FFV	2006 - 2010	PCM	√	√	√	√	0009 0025
S. A. Fiesta	1.0L	FFV	2006 - 2010	RCM	√	√	√	√	○

S. A. Fiesta	1.0L	FFV	2006 - 2010	RKE	√	√	√	√	000A
S. A. Fiesta	1.0L	FFV	2010	TBM	√	√	√	○	○
S. A. Fiesta	1.0L	Zetec Rocam	2002	ABS/TCS	√	√	√	√	8
S. A. Fiesta	1.0L	Zetec Rocam	2002	IC	√	√	√	√	○
S. A. Fiesta	1.0L	Zetec Rocam	2002	PCM	√	√	√	√	0009 0025
S. A. Fiesta	1.0L	Zetec Rocam	2002	RCM	√	√	√	√	○
S. A. Fiesta	1.0L	Zetec Rocam	2002	RKE	√	√	√	√	○
S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ABS/TCS	√	√	√	√	8
S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	IC	√	√	√	√	○
S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PCM	√	√	√	√	0009 0025
S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	RCM	√	√	√	√	○
S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	RKE	√	√	√	√	○
S. A. Fiesta	1.6L	FFV	2002 - 2011	ABS/TCS	√	√	√	√	0008 000B 000B
S. A. Fiesta	1.6L	FFV	2002 - 2011	IC	√	√	√	√	○
S. A. Fiesta	1.6L	FFV	2002 - 2011	PCM	√	√	√	√	0009 0025
S. A. Fiesta	1.6L	FFV	2002 - 2011	RCM	√	√	√	√	○
S. A. Fiesta	1.6L	FFV	2002 - 2011	RKE	√	√	√	√	000A
S. A. Fiesta	1.6L	FFV	2011	TBM	√	√	√	○	○
S. A. Fiesta	1.6L	Zetec Rocam	2002 - 2009	ABS/TCS	√	√	√	√	8
S. A. Fiesta	1.6L	Zetec Rocam	2002 - 2009	IC	√	√	√	√	○
S. A. Fiesta	1.6L	Zetec Rocam	2002 - 2009	PCM	√	√	√	√	0009 0025
S. A. Fiesta	1.6L	Zetec Rocam	2002 - 2009	RCM	√	√	√	√	○
S. A. Fiesta	1.6L	Zetec Rocam	2002 - 2009	RKE	√	√	√	√	000A
S.A. Courier	1.6L	FFV	2007 - 2011	PCM	√	√	√	√	0009 0025
S.A. Courier	1.6L	FFV	2009 - 2011	IC	√	√	√	√	○
S.A. Courier	1.6L	FFV	2009 - 2011	TBM	√	√	√	√	○
S.A. Courier	1.6L	Zetec Rocam	2009	IC	√	√	√	√	○
S.A. Courier	1.6L	Zetec Rocam	2009	PCM	√	√	√	√	25
S.A. Courier	1.6L	Zetec Rocam	2009	TBM	√	√	√	√	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005	ABS	√	√	√	√	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005	PCM	√	√	√	√	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005	RCM	√	√	√	√	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	ABS	√	√	√	√	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	PCM	√	√	√	√	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	RCM	√	√	√	√	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	TCM	√	√	√	√	○
Sable	3.0L	2V	2003	ABS/TCS	√	√	√	√	8
Sable	3.0L	2V	2003 - 2005	EATC	√	√	√	√	○
Sable	3.0L	2V	2003 - 2005	GEM	√	√	√	√	000A 000F

Sable	3.0L	2V	2003 - 2005	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Sable	3.0L	2V	2003 - 2005	RCM	√	√	√	√	000C
Sable	3.0L	2V	2004 - 2005	ABS	√	√	√	√	8
Sable	3.0L	2V	2004 - 2005	IC	√	√	√	√	5
Sable	3.0L	4V	1996 - 1999	IAB	√	√	√	√	○
Sable	3.0L	4V	1996 - 1999	PATS	√	√	√	√	9
Sable	3.0L	4V	1996 - 1999	RAP	√	√	√	√	000A 000F
Sable	3.0L	4V	1996 - 1999	RCC	√	√	√	√	○
Sable	3.0L	4V	1996 - 2003	ABS/TCS	√	√	√	√	8
Sable	3.0L	4V	1996 - 2005	GEM	√	√	√	√	000A 000F
Sable	3.0L	4V	1996 - 2005	PCM	√	√	√	√	0023 0025 0009 0010 0028 0031 0033
Sable	3.0L	4V	2000 - 2005	EATC	√	√	√	√	○
Sable	3.0L	4V	2000 - 2005	RCM	√	√	√	√	000C
Sable	3.0L	4V	2004 - 2005	ABS	√	√	√	√	8
Sable	3.0L	4V	2004 - 2005	IC	√	√	√	√	5
Sable	3.0L	FFV	2000 - 2003	ABS/TCS	√	√	√	√	8
Sable	3.0L	FFV	2000 - 2003	EATC	√	√	√	√	○
Sable	3.0L	FFV	2000 - 2003	GEM	√	√	√	√	000A 000F
Sable	3.0L	FFV	2000 - 2003	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Sable	3.0L	FFV	2000 - 2003	RCM	√	√	√	√	○
Sable	3.0L	Other	1996 - 1999	IAB	√	√	√	√	○
Sable	3.0L	Other	1996 - 1999	PATS	√	√	√	√	9
Sable	3.0L	Other	1996 - 1999	RAP	√	√	√	√	000A 000F
Sable	3.0L	Other	1996 - 1999	RCC	√	√	√	√	○
Sable	3.0L	Other	1996 - 2002	ABS/TCS	√	√	√	√	8
Sable	3.0L	Other	1996 - 2002	GEM	√	√	√	√	000A 000F
Sable	3.0L	Other	1996 - 2002	PCM	√	√	√	√	0023 0025 0009 0010 0028 0031 0033
Sable	3.0L	Other	2000 - 2002	EATC	√	√	√	√	○
Sable	3.0L	Other	2000 - 2002	RCM	√	√	√	√	○
Sable	3.5L	4V	2008 - 2009	4X4	√	√	√	√	○
Sable	3.5L	4V	2008 - 2009	ABS	√	√	√	√	8
Sable	3.5L	4V	2008 - 2009	ACM	√	√	√	√	○
Sable	3.5L	4V	2008 - 2009	APIM	√	√	√	√	○
Sable	3.5L	4V	2008 - 2009	DSM	√	√	√	√	○
Sable	3.5L	4V	2008 - 2009	GEM / SJB	√	√	√	√	000A 000F 0042
Sable	3.5L	4V	2008 - 2009	HVAC	√	√	√	√	○
Sable	3.5L	4V	2008 - 2009	IC	√	√	√	√	9
Sable	3.5L	4V	2008 - 2009	OCSM	√	√	√	○	000C
Sable	3.5L	4V	2008 - 2009	PAM	√	√	√	√	○

Sable	3.5L	4V	2008 - 2009	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C5
Sable	3.5L	4V	2008 - 2009	RCM	√	√	√	√	○
Sable	3.5L	4V	2008 - 2009	RETM	√	√	√	√	○
Sable	3.5L	4V	2008 - 2009	SDARS	√	√	√	√	○
Sable	3.5L	4V	2008 - 2009	SECM	√	√	√	√	○
Street Ka	1.6L	DURATEC 8V	2003	ABS/TCS	√	√	√	√	○
Street Ka	1.6L	DURATEC 8V	2003	CSM	√	√	√	√	○
Street Ka	1.6L	DURATEC 8V	2003	ECS	√	√	○	○	○
Street Ka	1.6L	DURATEC 8V	2003	GEM	√	√	√	√	○
Street Ka	1.6L	DURATEC 8V	2003	PCM	√	√	√	√	9
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	ABS	√	√	√	√	○
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	GEM	√	√	√	√	○
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	PATS	√	√	√	√	○
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	PCM	√	√	√	√	○
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	RCM	√	√	√	√	○
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	TCM	√	√	√	√	○
TITAN (Isuzu OEM)	3.1L	4JG2	2004	PCM	√	√	√	√	○
TITAN (Isuzu OEM)	3.1L	4JG2 LPG	2004	PCM	√	√	√	√	○
TITAN (Isuzu OEM)	4.3L	4HF1 CNG	2004	PCM	√	√	√	√	○
TITAN (Isuzu OEM)	4.6L	4HG1 LPG	2004	PCM	√	√	√	√	○
TITAN (Isuzu OEM)	4.6L	4HV1 CNG	2004 - 2011	PCM	√	√	√	√	○
TITAN (Isuzu OEM)	4.6L	4HV1 CNG	2004 - 2011	TCM	√	√	√	√	○
TITAN (Isuzu OEM)	4.6L	4HV1 CNG	2007 - 2011	ABS	√	√	√	√	○
TITAN (Isuzu OEM)	4.6L	4HV1 CNG	2007 - 2011	GEM	√	√	√	√	○
TITAN (Isuzu OEM)	4.6L	4HV1 CNG	2007 - 2011	RCM	√	√	√	√	○
TITAN (Isuzu OEM)	4.8L	4HL1	2004	PCM	√	√	√	√	○
TITAN (Isuzu OEM)	4.8L	4HL1	2004	TCM	√	√	√	√	○
TITAN (Isuzu OEM)	4.8L	4HL1_T	2004	PCM	√	√	√	√	○
TITAN (Isuzu OEM)	4.8L	4HL1_T	2004	TCM	√	√	√	√	○
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	ABS	√	√	√	√	○
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	GEM	√	√	√	√	○
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	PATS	√	√	√	√	○
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	PCM	√	√	√	√	○
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	RCM	√	√	√	√	○
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	TCM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	√	√	√	√	○

Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	○	000F 0042
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	√	√	√	○	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DCSM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	√	√	√	○	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	√	√	√	○	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HUD	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HVAC	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	√	√	√	○	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	√	√	√	○	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	√	√	√	○	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	√	√	√	○	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	√	√	√	○	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RFA	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	√	○	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	√	√	√	√	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	√	√	√	○	○
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-R	√	√	√	√	○
Taurus	3.0L	2V	2003	ABS/TCS	√	√	√	√	8
Taurus	3.0L	2V	2003 - 2007	EATC	√	√	√	√	○
Taurus	3.0L	2V	2003 - 2007	GEM	√	√	√	√	000A 000F

Taurus	3.0L	2V	2003 - 2007	PCM	√	√	√	√	0009 0010 0023 0025 0028 0031 0033
Taurus	3.0L	2V	2003 - 2007	RCM	√	√	√	√	000C
Taurus	3.0L	2V	2004 - 2007	ABS	√	√	√	√	8
Taurus	3.0L	2V	2004 - 2007	IC	√	√	√	√	5
Taurus	3.0L	4V	1996 - 1999	IAB	√	√	√	√	○
Taurus	3.0L	4V	1996 - 1999	PATS	√	√	√	√	9
Taurus	3.0L	4V	1996 - 1999	RAP	√	√	√	√	000A 000F
Taurus	3.0L	4V	1996 - 1999	RCC	√	√	√	√	○
Taurus	3.0L	4V	1996 - 2003	ABS/TCS	√	√	√	√	8
Taurus	3.0L	4V	1996 - 2005	GEM	√	√	√	√	000A 000F
Taurus	3.0L	4V	1996 - 2005	PCM	√	√	√	√	0023 0025 0009 0010 0028 0031 0033
Taurus	3.0L	4V	2000 - 2005	EATC	√	√	√	√	○
Taurus	3.0L	4V	2000 - 2005	RCM	√	√	√	√	000C
Taurus	3.0L	4V	2004 - 2005	ABS	√	√	√	√	8
Taurus	3.0L	4V	2004 - 2005	IC	√	√	√	√	5
Taurus	3.0L	FFV	1996 - 1999	IAB	√	√	√	√	○
Taurus	3.0L	FFV	1996 - 1999	PATS	√	√	√	√	9
Taurus	3.0L	FFV	1996 - 1999	RAP	√	√	√	√	000A 000F
Taurus	3.0L	FFV	1996 - 1999	RCC	√	√	√	√	○
Taurus	3.0L	FFV	1996 - 2003	ABS/TCS	√	√	√	√	8
Taurus	3.0L	FFV	1996 - 2003	GEM	√	√	√	√	000A 000F
Taurus	3.0L	FFV	1996 - 2003	PCM	√	√	√	√	0023 0025 0009 0010 0028 0031 0033
Taurus	3.0L	FFV	2000 - 2003	EATC	√	√	√	√	○
Taurus	3.0L	FFV	2000 - 2003	RCM	√	√	√	√	○
Taurus	3.0L	Other	1996 - 1999	IAB	√	√	√	√	○
Taurus	3.0L	Other	1996 - 1999	PATS	√	√	√	√	9
Taurus	3.0L	Other	1996 - 1999	RAP	√	√	√	√	000A 000F
Taurus	3.0L	Other	1996 - 1999	RCC	√	√	√	√	○
Taurus	3.0L	Other	1996 - 2002	ABS/TCS	√	√	√	√	8
Taurus	3.0L	Other	1996 - 2002	GEM	√	√	√	√	000A 000F
Taurus	3.0L	Other	1996 - 2002	PCM	√	√	√	√	0023 0025 0009 0010 0028 0031 0033
Taurus	3.0L	Other	2000 - 2002	EATC	√	√	√	√	○
Taurus	3.0L	Other	2000 - 2002	RCM	√	√	√	√	○
Taurus	3.4L	Other	1997	ABS/TCS	√	√	√	√	8
Taurus	3.4L	Other	1997	GEM	√	√	√	√	○
Taurus	3.4L	Other	1997	PATS	√	√	√	√	9
Taurus	3.4L	Other	1997	PCM	√	√	√	√	0023 0025
Taurus	3.4L	SHO	1996 - 1998	GEM	√	√	√	√	○
Taurus	3.4L	SHO	1996 - 1998	IAB	√	√	√	√	○
Taurus	3.4L	SHO	1996 - 1998	SARC	√	√	√	√	○

Taurus	3.4L	SHO	1996 - 1999	ABS/TCS	√	√	√	√	8
Taurus	3.4L	SHO	1996 - 1999	PATS	√	√	√	√	9
Taurus	3.4L	SHO	1996 - 1999	PCM	√	√	√	√	0023 0025
Taurus	3.4L	SHO	1996 - 1999	RAP	√	√	√	√	000A 000F
Taurus	3.4L	SHO	1996 - 1999	RCC	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2009	IC	√	√	√	√	9
Taurus	3.5L	4V	2008 - 2009	SDARS	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2009	SECM	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2012	4X4	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2012	ABS	√	√	√	√	8
Taurus	3.5L	4V	2008 - 2012	ACM	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2012	APIM	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2012	DSM	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Taurus	3.5L	4V	2008 - 2012	HVAC	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2012	OCSM	√	√	√	○	000C
Taurus	3.5L	4V	2008 - 2012	PAM	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2012	PCM	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2012	RCM	√	√	√	√	○
Taurus	3.5L	4V	2008 - 2012	RETM	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	C-CM	√	√	√	○	○
Taurus	3.5L	4V	2010 - 2012	DCSM	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	DDM	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	DSP	√	√	√	○	○
Taurus	3.5L	4V	2010 - 2012	FCIM	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	FDIM	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	GPSM	√	√	√	○	○
Taurus	3.5L	4V	2010 - 2012	HCM	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	HCM-2	√	√	√	○	○
Taurus	3.5L	4V	2010 - 2012	HUD	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	ILCM	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	IPC	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	PSCM	√	√	√	○	○
Taurus	3.5L	4V	2010 - 2012	RFA	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	SASM	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	SOD-L	√	√	√	√	○
Taurus	3.5L	4V	2010 - 2012	SOD-R	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	4X4	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	FDIM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	HCM-2	√	√	√	○	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	ILCM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	RETM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	SASM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	ABS	√	√	√	√	8

Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	ACM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	APIM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	C-CM	√	√	√	○	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DCSM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DDM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DSM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DSP	√	√	√	○	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	FCIM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	GPSM	√	√	√	○	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HCM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HUD	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HVAC	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	IPC	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	OCSM	√	√	√	√	000C
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PAM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PCM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PSCM	√	√	√	○	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	RCM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	RFA	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	SOD-L	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	SOD-R	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	√	√	√	○	000A 000F 0042
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	√	√	√	○	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	√	√	√	√	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	√	√	√	○	○
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	ABS	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	ACM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	APIM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	BCM#1	√	√	√	○	000F 0042
Taurus	3.5L	TiVCT	2013	C-CM	√	√	√	○	○
Taurus	3.5L	TiVCT	2013	DCSM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	DDM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	DSM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	DSP	√	√	√	√	○

Taurus	3.5L	TiVCT	2013	FCDIM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	FCIM	√	√	√	○	○
Taurus	3.5L	TiVCT	2013	GFM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	GPSM	√	√	√	○	○
Taurus	3.5L	TiVCT	2013	HCM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	HSWM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	HUD	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	HVAC	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	IPC	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	IPM-A	√	√	√	○	○
Taurus	3.5L	TiVCT	2013	OCSM	√	√	√	○	○
Taurus	3.5L	TiVCT	2013	PAM	√	√	√	○	○
Taurus	3.5L	TiVCT	2013	PCM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	PSCM	√	√	√	○	○
Taurus	3.5L	TiVCT	2013	RACM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	RCM	√	√	√	○	○
Taurus	3.5L	TiVCT	2013	RFA	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	RTM	√	√	√	○	○
Taurus	3.5L	TiVCT	2013	SCCM	√	√	√	√	○
Taurus	3.5L	TiVCT	2013	SOD-L	√	√	√	○	○
Taurus	3.5L	TiVCT	2013	SOD-R	√	√	√	√	○
Taurus	Other	Other	2012	4X4	√	√	√	√	○
Taurus	Other	Other	2012	ABS	√	√	√	√	○
Taurus	Other	Other	2012	ACM	√	√	√	○	○
Taurus	Other	Other	2012	APIM	√	√	√	√	○
Taurus	Other	Other	2012	C-CM	√	√	√	√	○
Taurus	Other	Other	2012	DCSM	√	√	√	√	○
Taurus	Other	Other	2012	DDM	√	√	√	√	○
Taurus	Other	Other	2012	DSM	√	√	√	√	○
Taurus	Other	Other	2012	DSP	√	√	√	√	○
Taurus	Other	Other	2012	FCIM	√	√	√	√	○
Taurus	Other	Other	2012	FDIM	√	√	√	√	○
Taurus	Other	Other	2012	GEM / SJB	√	√	√	√	42
Taurus	Other	Other	2012	GPSM	√	√	√	√	○
Taurus	Other	Other	2012	HCM	√	√	√	√	○
Taurus	Other	Other	2012	HCM-2	√	√	√	○	○
Taurus	Other	Other	2012	HUD	√	√	√	√	○
Taurus	Other	Other	2012	HVAC	√	√	√	√	○
Taurus	Other	Other	2012	ILCM	√	√	√	√	○
Taurus	Other	Other	2012	IPC	√	√	√	√	○
Taurus	Other	Other	2012	OCSM	√	√	√	○	○
Taurus	Other	Other	2012	PAM	√	√	√	√	○
Taurus	Other	Other	2012	PCM	√	√	√	√	○
Taurus	Other	Other	2012	PSCM	√	√	√	○	○
Taurus	Other	Other	2012	RCM	√	√	√	√	○
Taurus	Other	Other	2012	RETM	√	√	√	√	○
Taurus	Other	Other	2012	RFA	√	√	√	√	○
Taurus	Other	Other	2012	SASM	√	√	√	√	○
Taurus	Other	Other	2012	SOD-L	√	√	√	√	○
Taurus	Other	Other	2012	SOD-R	√	√	√	√	○
Taurus X	3.5L	4V	2008 - 2009	4X4	√	√	√	√	○
Taurus X	3.5L	4V	2008 - 2009	ABS	√	√	√	√	8
Taurus X	3.5L	4V	2008 - 2009	ACM	√	√	√	√	○
Taurus X	3.5L	4V	2008 - 2009	APIM	√	√	√	○	○
Taurus X	3.5L	4V	2008 - 2009	DSM	√	√	√	√	○
Taurus X	3.5L	4V	2008 - 2009	GEM / SJB	√	√	√	√	000A 000F 0042
Taurus X	3.5L	4V	2008 - 2009	HVAC	√	√	√	√	○
Taurus X	3.5L	4V	2008 - 2009	IC	√	√	√	√	9
Taurus X	3.5L	4V	2008 - 2009	LTM	√	√	√	√	○
Taurus X	3.5L	4V	2008 - 2009	OCSM	√	√	√	○	000C
Taurus X	3.5L	4V	2008 - 2009	PAM	√	√	√	√	○
Taurus X	3.5L	4V	2008 - 2009	PCM	√	√	√	√	0010 0023 0025 0028 0031 0033 00C5
Taurus X	3.5L	4V	2008 - 2009	RCM	√	√	√	√	○
Taurus X	3.5L	4V	2008 - 2009	RETM	√	√	√	√	○
Taurus X	3.5L	4V	2008 - 2009	SDARS	√	√	√	√	○
Taurus X	3.5L	4V	2008 - 2009	SECM	√	√	√	√	○
Telstar	1.8L	Other	Other	PCM	√	√	√	√	○

Telstar	2.0L	Other	Other	PCM	√	√	√	√	○
Telstar	2.5L	Other	Other	PCM	√	√	√	√	○
Thunderbird	3.8L	Other	1996 - 1997	PCM	√	√	√	√	0023 0025
Thunderbird	3.9L	4V	2002 - 2005	ABS/TCS	√	√	√	√	0008 0012
Thunderbird	3.9L	4V	2002 - 2005	ACM	√	√	√	√	○
Thunderbird	3.9L	4V	2002 - 2005	DDM	√	√	√	√	000A 000F
Thunderbird	3.9L	4V	2002 - 2005	EATC	√	√	√	√	○
Thunderbird	3.9L	4V	2002 - 2005	GEM	√	√	√	√	○
Thunderbird	3.9L	4V	2002 - 2005	HEC	√	√	√	√	9
Thunderbird	3.9L	4V	2002 - 2005	PCM	√	√	√	√	0010 0028 0031 0033 00C6 00C7
Thunderbird	3.9L	4V	2002 - 2005	RCM	√	√	√	√	○
Thunderbird	3.9L	4V	2002 - 2005	REM	√	√	√	√	○
Thunderbird	4.6L	2V	1994 - 1997	PCM	√	√	√	√	0023 0025
Thunderbird	4.6L	Other	1996	PCM	√	√	√	√	0023 0025
Titan	4.0L	TF	2000 - 2002	PCM	√	√	√	√	○
Town Car	4.6L	2V	1995 - 2004	ABS/TCS	√	√	√	√	8
Town Car	4.6L	2V	1995 - 2007	EATC	√	√	√	√	○
Town Car	4.6L	2V	1995 - 2011	DDM	√	√	√	√	000F 000A 0005 0042
Town Car	4.6L	2V	1995 - 2011	DSM	√	√	√	√	○
Town Car	4.6L	2V	1995 - 2011	LCM	√	√	√	√	5
Town Car	4.6L	2V	1995 - 2011	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033 0009
Town Car	4.6L	2V	1996 - 1998	IAB	√	√	√	√	○
Town Car	4.6L	2V	1998 - 2003	CPM	√	√	√	√	○
Town Car	4.6L	2V	1998 - 2004	NGSC	√	√	√	√	○
Town Car	4.6L	2V	1998 - 2005	ACM	√	√	√	√	5
Town Car	4.6L	2V	1998 - 2005	HEC	√	√	√	√	9
Town Car	4.6L	2V	1998 - 2006	RASM	√	√	√	√	0013 0005
Town Car	4.6L	2V	1999 - 2011	RCM	√	√	√	√	000C
Town Car	4.6L	2V	2002 - 2003	RESCU	√	√	√	√	○
Town Car	4.6L	2V	2003 - 2010	MC	√	√	√	√	○
Town Car	4.6L	2V	2003 - 2010	NAV	√	√	√	√	○
Town Car	4.6L	2V	2003 - 2011	LTM	√	√	√	√	○
Town Car	4.6L	2V	2003 - 2011	PAM	√	√	√	√	○
Town Car	4.6L	2V	2005 - 2011	ABS	√	√	√	√	0008 0005
Town Car	4.6L	2V	2006 - 2011	IC	√	√	√	√	5
Town Car	4.6L	2V	2006 - 2011	RATC	√	√	√	√	○
Town Car	4.6L	2V	2007 - 2011	VDM	√	√	√	√	○
Town Car	4.6L	2V	2008 - 2011	HVAC	√	√	√	√	○
Tracer	1.9L	1.4 PT-E SFI	1996	ABS/TCS	√	√	√	√	○
Tracer	1.9L	1.4 PT-E SFI	1996	PCM	√	√	√	√	0023 0025
Tracer	1.9L	1.4 PT-E SFI	1996	RAP	√	√	√	√	○
Tracer	2.0L	SPI	1997 - 1999	ABS/TCS	√	√	√	√	8
Tracer	2.0L	SPI	1997 - 1999	PCM	√	√	√	√	0023 0025
Tracer	2.0L	SPI	1997 - 1999	RAP	√	√	√	√	000A
Tracer	2.0L	SPI	1998	ECS	√	√	√	√	○
Tracer	2.0L	SPI	1999	IAB	√	√	√	√	○

Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	PATS	√	√	√	√	○
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	ABS	√	√	√	√	○
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	ABS/TCS	√	√	√	√	○
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	CSM	√	√	√	√	○
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	PCM	√	√	√	√	0023 0025
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1999	AFCM	√	√	√	√	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	ABS	√	√	√	√	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	ACM	√	√	√	√	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	GEM / SJB	√	√	√	√	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	IC	√	√	√	√	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	OCSM	√	√	√	√	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	PAM	√	√	√	√	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	PCM	√	√	√	√	0025 0023
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	RCM	√	√	√	√	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	SRM	√	√	√	○	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	VSM	√	√	√	√	○
Transit Connect	2.0L	DURATEC-HE / I4	2012	APIM	√	√	√	√	○
Transit Connect	2.0L	DURATORQ_DI	2001	ABS/TCS	√	√	√	√	8
Transit Connect	2.0L	DURATORQ_DI	2001	CSM	√	√	√	√	○
Transit Connect	2.0L	DURATORQ_DI	2001	EPB	√	√	√	√	○
Transit Connect	2.0L	DURATORQ_DI	2001	FFH	√	√	√	√	○
Transit Connect	2.0L	DURATORQ_DI	2001	FIP	√	√	√	√	○
Transit Connect	2.0L	DURATORQ_DI	2001	HEC	√	√	√	√	○
Transit Connect	2.0L	DURATORQ_DI	2001	PAM	√	√	√	√	○
Transit Connect	2.0L	DURATORQ_DI	2001	PATS	√	√	√	√	○
Transit Connect	2.0L	DURATORQ_DI	2001	PCM	√	√	√	√	9
Transit Connect	2.0L	DURATORQ_DI	2001	RASM	√	√	√	√	○
Transit Connect	2.0L	DURATORQ_DI	2001	RCM	√	√	√	√	○
Transit Connect	2.0L	DURATORQ_DI	2001	TCM	√	√	√	√	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ABS/TCS	√	√	√	√	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	√	√	√	√	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	FFH	√	√	√	√	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	FIP	√	√	√	√	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	HEC	√	√	√	√	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ICU	○	○	√	○	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	PAM	√	√	√	√	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	PCM	√	√	√	√	92
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RASM	√	√	√	√	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RCM	√	√	√	√	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	TCM	√	√	√	√	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	√	√	√	√	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	√	√	√	√	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	√	√	√	√	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	√	√	√	√	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	CSM	√	√	√	√	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	FFH	√	√	√	√	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	√	√	√	√	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	√	√	√	√	○

Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	√	√	√	√	0090 0092 0098 00A6 00A7 00A8 00A9 00B0 00B1 00B5 00B6 00C0 00C1 00C2 00C4
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	√	√	√	√	○
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	ABS	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	ABS/TCS	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	ACM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	BCMii	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	CSM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	FFH	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	IPC	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	PAM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	PCM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	RCM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	SRM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	ABS	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	ABS/TCS	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	ACM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	BCMii	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	CSM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	FFH	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	IPC	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	PAM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	PCM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	RCM	√	√	√	√	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	SRM	√	√	√	√	○
Transit Connect	2.3L	DOHC SFI (16V)	2001	ABS/TCS	√	√	√	√	8
Transit Connect	2.3L	DOHC SFI (16V)	2001	CSM	√	√	√	√	○
Transit Connect	2.3L	DOHC SFI (16V)	2001	HEC	√	√	√	√	○
Transit Connect	2.3L	DOHC SFI (16V)	2001	PAM	√	√	√	√	○
Transit Connect	2.3L	DOHC SFI (16V)	2001	PATS	√	√	√	√	○
Transit Connect	2.3L	DOHC SFI (16V)	2001	PCM	√	√	√	√	0009 0025
Transit Connect	2.3L	DOHC SFI (16V)	2001	RASM	√	√	√	√	○
Transit Connect	2.3L	DOHC SFI (16V)	2001	RCM	√	√	√	√	○
Transit Connect	2.3L	DURATEC-HE / I4	2006	ABS	√	√	√	√	0053 00DD 00E3 00E4
Transit Connect	2.3L	DURATEC-HE / I4	2006	ABS/TCS	√	√	√	√	○
Transit Connect	2.3L	DURATEC-HE / I4	2006	ACM	√	√	√	√	○
Transit Connect	2.3L	DURATEC-HE / I4	2006	BCMii	√	√	√	√	○
Transit Connect	2.3L	DURATEC-HE / I4	2006	CSM	√	√	√	√	○
Transit Connect	2.3L	DURATEC-HE / I4	2006	FFH	√	√	√	√	○
Transit Connect	2.3L	DURATEC-HE / I4	2006	IPC	√	√	√	√	○
Transit Connect	2.3L	DURATEC-HE / I4	2006	PAM	√	√	√	√	○
Transit Connect	2.3L	DURATEC-HE / I4	2006	PCM	√	√	√	√	25

Transit Connect	2.3L	DURATEC-HE / I4	2006	RCM	√	√	√	√	○
Transit Connect	2.3L	DURATEC-HE / I4	2006	SRM	√	√	√	√	○
Transit Connect	2.4L	DURATORQ_DI	2000	ABS/TCS	√	√	√	√	8
Transit Connect	2.4L	DURATORQ_DI	2000	CSM	√	√	√	√	○
Transit Connect	2.4L	DURATORQ_DI	2000	EPB	√	√	√	√	○
Transit Connect	2.4L	DURATORQ_DI	2000	FFH	√	√	√	√	○
Transit Connect	2.4L	DURATORQ_DI	2000	FIP	√	√	√	√	○
Transit Connect	2.4L	DURATORQ_DI	2000	HEC	√	√	√	√	○
Transit Connect	2.4L	DURATORQ_DI	2000	PAM	√	√	√	√	○
Transit Connect	2.4L	DURATORQ_DI	2000	PATS	√	√	√	√	○
Transit Connect	2.4L	DURATORQ_DI	2000	PCM	√	√	√	√	9
Transit Connect	2.4L	DURATORQ_DI	2000	RASM	√	√	√	√	○
Transit Connect	2.4L	DURATORQ_DI	2000	RCM	√	√	√	√	○
Transit Connect	2.4L	DURATORQ_DI	2000	TCM	√	√	√	√	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000	HEC	√	√	√	√	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000	ICU	○	○	√	○	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	ABS/TCS	√	√	√	√	8
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	CSM	√	√	√	√	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	FFH	√	√	√	√	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	PAM	√	√	√	√	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	PCM	√	√	√	√	0009 0092 0090 0098 00A6 00A7 00A8 00A9 00B0 00B1 00B5 00B6 00C0 00C1 00C2 00C4
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	RCM	√	√	√	√	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	√	√	√	√	0053 00DD 00E3 00E4
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	√	√	√	√	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	√	√	√	√	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	√	√	√	√	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	√	√	√	√	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	TBM	√	√	√	√	○
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	ABS	√	√	√	√	○
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	ABS/TCS	√	√	√	√	○
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	CSM	√	√	√	√	○
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	PCM	√	√	√	√	25
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	ABS	√	√	√	√	○
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	ACCM#2	√	√	√	√	○
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	ACM	√	√	√	√	○
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	GEM / SJB	√	√	√	√	○
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	IC	√	√	√	√	○
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	OCSM	√	√	√	√	○
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	PAM	√	√	√	√	○
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	PSCM	√	√	√	○	○
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	RCM	√	√	√	○	○

Transit Connect	28kWh	Battery_Electric_Vehicle	2011	SRM	√	√	√	○	○
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	VSM	√	√	√	√	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	√	√	√	√	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	√	√	√	√	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	√	√	√	√	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	√	√	√	√	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	CSM	√	√	√	√	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	FFH	√	√	√	√	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	√	√	√	√	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	√	√	√	√	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	√	√	√	√	0090 0092 0098 00A6 00A7 00A8 00A9 00B0 00B1 00B5 00B6 00C0 00C1 00C2 00C4
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	√	√	√	√	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	√	√	√	√	○
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	ABS	√	√	√	√	0053 00DD 00E3 00E4
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	ABS/TCS	√	√	√	√	○
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	ACM	√	√	√	√	○
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	BCMii	√	√	√	√	○
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	CSM	√	√	√	√	○
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	FFH	√	√	√	√	○
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	IPC	√	√	√	√	○
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	PAM	√	√	√	√	○
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	PCM	√	√	√	√	○
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	RCM	√	√	√	√	○
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	SRM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002	HEC	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002	ICU	○	○	√	○	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	ABS/TCS	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	CSM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	ECS	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2009	FFH	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2009	PAM	√	√	√	√	○

Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2009	PCM	√	√	√	√	0009 0092 0092 006F 0098 0099 00AB 00AC 00B4 00C1
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2009	ABS	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2009	ACM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2009	IC	√	√	√	√	9
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2009	SRM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009	GEM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009	RCM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Endura DI	2002	ABS/TCS	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Endura DI	2002	CSM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Endura DI	2002	ECS	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Endura DI	2002	FFH	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Endura DI	2002	FIP	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Endura DI	2002	HEC	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Endura DI	2002	PAM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Endura DI	2002	PCM	√	√	√	√	9
Transit Connect / Tourneo_ Connect	1.8L	Zetec	2002	ABS/TCS	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Zetec	2002	AFCM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Zetec	2002	CSM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Zetec	2002	ECS	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Zetec	2002	FFH	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Zetec	2002	HEC	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Zetec	2002	PAM	√	√	√	√	○
Transit Connect / Tourneo_ Connect	1.8L	Zetec	2002	PCM	√	√	√	√	0009 0023 0025

V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		ABS	√	√	√	○	00DD
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		ACM	√	√	√	○	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		AHCM	√	√	√	○	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		APIM	√	√	√	√	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		BCMii	√	√	√	√	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		CCMii	√	√	√	√	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		FCDIM	√	√	√	√	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		GPSM	√	√	√	○	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		HCM	√	√	√	○	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		HVAC	√	√	√	√	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		IPC	√	√	√	○	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		IPM-A	√	√	√	√	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		IPM-B	√	√	√	○	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		PAM	√	√	√	○	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		PCM	√	√	√	√	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		RCM	√	√	√	○	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		SASM	√	√	√	○	○
V362	2.2L	Duratorq Turbo Diesel Common Rail Injection		TBC	√	√	√	○	○
Villager	3.3L	Other	2001 - 2002	PCM	√	√	√	√	○
Windstar	3.0L	V6 OHV	1995 - 1998	GEM	√	√	√	√	○
Windstar	3.0L	V6 OHV	1995 - 1999	ABS/TCS	√	√	√	√	8
Windstar	3.0L	V6 OHV	1995 - 1999	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033
Windstar	3.0L	V6 OHV	1996 - 1998	IAB	√	√	√	√	○
Windstar	3.0L	V6 OHV	1996 - 1998	PATS	√	√	√	√	○
Windstar	3.0L	V6 OHV	1998	RAP	√	√	√	√	000A
Windstar	3.0L	V6 OHV	1999	DDM	√	√	√	√	000A
Windstar	3.0L	V6 OHV	1999	FEM	√	√	√	√	○
Windstar	3.0L	V6 OHV	1999	IC	√	√	√	√	9
Windstar	3.0L	V6 OHV	1999	MC	√	√	√	√	○
Windstar	3.0L	V6 OHV	1999	NGSC	√	√	√	√	○
Windstar	3.0L	V6 OHV	1999	PAM	√	√	√	√	○
Windstar	3.0L	V6 OHV	1999	RCM	√	√	√	√	○
Windstar	3.0L	V6 OHV	1999	REM	√	√	√	√	○
Windstar	3.8L	V6 OHV	1995 - 1998	GEM	√	√	√	√	○
Windstar	3.8L	V6 OHV	1995 - 2003	ABS/TCS	√	√	√	√	0008 0005 0012
Windstar	3.8L	V6 OHV	1995 - 2003	PCM	√	√	√	√	0023 0025 0010 0028 0031 0033 0009
Windstar	3.8L	V6 OHV	1996 - 1998	IAB	√	√	√	√	○
Windstar	3.8L	V6 OHV	1996 - 1998	PATS	√	√	√	√	○
Windstar	3.8L	V6 OHV	1998	RAP	√	√	√	√	000A
Windstar	3.8L	V6 OHV	1999 - 2003	DDM	√	√	√	√	000A 0005
Windstar	3.8L	V6 OHV	1999 - 2003	FEM	√	√	√	√	5
Windstar	3.8L	V6 OHV	1999 - 2003	IC	√	√	√	√	9
Windstar	3.8L	V6 OHV	1999 - 2003	LPSDM	√	√	√	√	○
Windstar	3.8L	V6 OHV	1999 - 2003	MC	√	√	√	√	○
Windstar	3.8L	V6 OHV	1999 - 2003	NGSC	√	√	√	√	○
Windstar	3.8L	V6 OHV	1999 - 2003	PAM	√	√	√	√	○
Windstar	3.8L	V6 OHV	1999 - 2003	RCM	√	√	√	√	000C
Windstar	3.8L	V6 OHV	1999 - 2003	REM	√	√	√	√	000F

Windstar	3.8L	V6 OHV	1999 - 2003	RPSDM	√	√	√	√	○
Windstar	3.8L	V6 OHV	2000 - 2003	DSM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	4X4	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	ABS	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	ACCM#2	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	ACM	√	√	√	○	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	APIM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	BECM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	DCDC	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	DCSM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	DDM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	DSM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	DSP	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	FCIM	√	√	√	○	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	FDIM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	GEM / SJB	√	√	√	√	000A 000F 0042
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	GPSM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	HCM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	HVAC	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	ILCM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	IPC	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	OCSM	√	√	√	√	000C 0015
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	PAM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	PCM	√	√	√	√	0009 0023 0025
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	PSCM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	RCM	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	SOD-L	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	SOD-R	√	√	√	√	○
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	TCM	√	√	√	○	○
Zephyr/MKZ	3.0L	4V	2006	ABS	√	√	√	√	○
Zephyr/MKZ	3.0L	4V	2006	ACM	√	√	√	√	○
Zephyr/MKZ	3.0L	4V	2006	DCSM	√	√	√	√	○
Zephyr/MKZ	3.0L	4V	2006	DDM	√	√	√	√	○
Zephyr/MKZ	3.0L	4V	2006	DSM	√	√	√	√	○
Zephyr/MKZ	3.0L	4V	2006	DSP	√	√	√	√	○
Zephyr/MKZ	3.0L	4V	2006	EATC	√	√	√	√	○
Zephyr/MKZ	3.0L	4V	2006	GEM	√	√	√	√	○
Zephyr/MKZ	3.0L	4V	2006	IC	√	√	√	√	○
Zephyr/MKZ	3.0L	4V	2006	OCSM	√	√	√	○	○
Zephyr/MKZ	3.0L	4V	2006	PCM	√	√	√	√	23
Zephyr/MKZ	3.0L	4V	2006	RCM	√	√	√	√	5
Zephyr/MKZ	3.0L	4V	2006	TCM	√	√	√	√	○
Zephyr/MKZ	3.5L	4V	2007	EATC	√	√	√	√	○
Zephyr/MKZ	3.5L	4V	2007	GEM	√	√	√	√	○
Zephyr/MKZ	3.5L	4V	2007 - 2009	IC	√	√	√	√	5
Zephyr/MKZ	3.5L	4V	2007 - 2009	SDARS	√	√	√	√	5
Zephyr/MKZ	3.5L	4V	2007 - 2012	4X4	√	√	√	√	○
Zephyr/MKZ	3.5L	4V	2007 - 2012	ABS	√	√	√	√	0005 0012 0008

Zephyr/MKZ	3.5L	4V	2007 - 2012	ACM	√	√	√	√	17
Zephyr/MKZ	3.5L	4V	2007 - 2012	DCSM	√	√	√	√	5
Zephyr/MKZ	3.5L	4V	2007 - 2012	DDM	√	√	√	√	5
Zephyr/MKZ	3.5L	4V	2007 - 2012	DSM	√	√	√	√	5
Zephyr/MKZ	3.5L	4V	2007 - 2012	DSP	√	√	√	√	5
Zephyr/MKZ	3.5L	4V	2007 - 2012	OCSM	√	√	√	○	000C 0015
Zephyr/MKZ	3.5L	4V	2007 - 2012	PCM	√	√	√	√	0023 0025 0037
Zephyr/MKZ	3.5L	4V	2007 - 2012	RCM	√	√	√	√	5
Zephyr/MKZ	3.5L	4V	2007 - 2012	TCM	√	√	√	√	○
Zephyr/MKZ	3.5L	4V	2008 - 2012	APIM	√	√	√	√	0019 001C
Zephyr/MKZ	3.5L	4V	2008 - 2012	GEM / SJB	√	√	√	√	0005 000A 000F 0042
Zephyr/MKZ	3.5L	4V	2008 - 2012	HVAC	√	√	√	√	○
Zephyr/MKZ	3.5L	4V	2008 - 2012	PAM	√	√	√	√	5
Zephyr/MKZ	3.5L	4V	2010 - 2012	FCIM	√	√	√	○	○
Zephyr/MKZ	3.5L	4V	2010 - 2012	FDIM	√	√	√	√	5
Zephyr/MKZ	3.5L	4V	2010 - 2012	GPSM	√	√	√	○	○
Zephyr/MKZ	3.5L	4V	2010 - 2012	HCM	√	√	√	√	○
Zephyr/MKZ	3.5L	4V	2010 - 2012	ILCM	√	√	√	√	○
Zephyr/MKZ	3.5L	4V	2010 - 2012	IPC	√	√	√	√	5
Zephyr/MKZ	3.5L	4V	2010 - 2012	SOD-L	√	√	√	√	○
Zephyr/MKZ	3.5L	4V	2010 - 2012	SOD-R	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	4X4	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	ABS	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	ACM	√	√	√	○	○
Zephyr/MKZ	Other	Other	2012	APIM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	DCSM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	DDM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	DSM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	DSP	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	FCIM	√	√	√	○	○
Zephyr/MKZ	Other	Other	2012	FDIM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	GEM / SJB	√	√	√	√	42
Zephyr/MKZ	Other	Other	2012	GPSM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	HCM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	HVAC	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	ILCM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	IPC	√	√	√	√	9
Zephyr/MKZ	Other	Other	2012	OCSM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	PAM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	RCM	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	SOD-L	√	√	√	√	○
Zephyr/MKZ	Other	Other	2012	SOD-R	√	√	√	√	○
C-MAX	1.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM_1/CCM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
C-MAX	1.5 L	Duratorq Turbo Diesel Common Rail Injection	2015	ABS/ACM/AHCM/APIM/BCM_1/CCM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCM/TRM	√	√	√	○	

C-MAX	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
C-MAX	1.6 L	Duratec VCT	2015	ABS/ACM/AHCM/APIM/BCM#1/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
C-MAX	1.6 L	Duratorq Turbo Diesel Common Rail Injection	2015	ABS/ACM/AHCM/APIM/BCM#1/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
C-MAX	1.6 L	TiVCT	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
C-MAX	2.0 L	Duratorq Turbo Diesel Common Rail Injection	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCM/TRM	√	√	√	○	
C-MAX	2.0 L	Full Hybrid Electric Vehicle	2015	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/DACM-C/DCDC/DDM/FCDIM/FCIM/GPSM/GWM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/RDCM#1	√	√	√	A	0012 0074 010A
C-MAX	2.0 L	Full Hybrid Electric Vehicle	2016	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/DACM-C/DCDC/DDM/FCDIM/FCIM/GPSM/GWM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/RDCM#1	√	√	√	A	0012 0074 010A
C-MAX	2.0 L	Plug-in Hybrid Electric Vehicle	2015	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/DACM-C/DCDC/DDM/FCDIM/FCIM/GFM/GPSM/GWM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/RDCM#1/SOBDM/TCU#1	√	√	√	A	0012 0074 010A
C-MAX	2.0 L	Plug-in Hybrid Electric Vehicle	2016	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/DACM-C/DCDC/DDM/FCDIM/FCIM/GFM/GPSM/GWM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/RDCM#1/SOBDM/TCU#1	√	√	√	A	0012 0074 010A
E-Series	5.4 L	2V	2015	ABS/ACM/APIM/BCM#1/DSM/DSP/FCDIM/FCIM/GPSM/HCM/IC/LTM/PAM/PCM/PRB/PSCM/RACM/RCM/RFA/RHVAC/RLCM-A/RTM/SCCM/DCSM/SOD-L/SOD-R/TBM#1/TCCM/TRM/VDM	√	√	√	○	
E-Series	5.4 L	2V	2016	ABS/ACM/APIM/BEM/GPSM/IPC/PCM/RCM/TBC	√	√	√	○	
E-Series	6.8 L	2V	2014	ABS/ACM/APIM/BEM/GPSM/IPC/PCM/RCM/TBC	√	√	√	○	0008
E-Series	6.8 L	2V	2015	ABS/ACM/APIM/BEM/GPSM/IPC/PCM/RCM/TBC	√	√	√	○	
E-Series	6.8 L	2V	2016	ABS/ACM/APIM/BEM/GPSM/IPC/PCM/RCM/TBC	√	√	√	○	
E-Series	6.8 L	2V	2017	ABS/ACM/APIM/BEM/GPSM/IPC/PCM/RCM/TBC	√	√	√	○	
EcoSport	1.5 L	Duratorq Turbo Diesel Common Rail Injection StgVI	2014	ABS/ACM/APIM/BCMii/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM/RFA	√	√	√	○	00EB
EcoSport	1.6 L	Duratec VCT	2014	ABS/ACM/APIM/BCMii/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM/RFA	√	√	√	○	00EB
EcoSport	2.0 L	Duratec	2014	ABS/ACM/APIM/BCMii/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM/RFA	√	√	√	○	00EB
Edge	2.0 L	Duratorq Turbo Diesel Common Rail Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SASM/SCCM/DCSM/SECM/SOD-L/SOD-R/TRM	√	√	√	○	
Edge	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SASM/SCCM/DCSM/SECM/SOD-L/SOD-R/TRM	√	√	√	○	
Edge	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SASM/SCCM/DCSM/SECM/SOD-L/SOD-R/TRM	√	√	√	○	
Edge	2.7 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SASM/SCCM/DCSM/SECM/SOD-L/SOD-R/TRM	√	√	√	○	
Edge	2.7 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SASM/SCCM/DCSM/SECM/SOD-L/SOD-R/TRM	√	√	√	○	

Edge	3.5 L	TiVCT	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SASM/SCCM/DCSM/SECM/SOD-L/SOD-R/TRM	√	√	√	○	
Edge	3.5 L	TiVCT	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SASM/SCCM/DCSM/SECM/SOD-L/SOD-R/TRM	√	√	√	○	
Edge\Galaxy\S-Max	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RHVAC/RTM/SASM/SCCM/DCSM/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Edge\Galaxy\S-Max	2.0 L	Duratorq Turbo Diesel Common Rail Injection	2015	ABS/ACM/AHCM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RHVAC/RTM/SASM/SCCM/DCSM/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TCM/TRM/VDM	√	√	√	○	
Edge\Galaxy\S-Max	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RHVAC/RTM/SASM/SCCM/DCSM/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Edge\Galaxy\S-Max	2.7 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RHVAC/RTM/SASM/SCCM/DCSM/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Escape	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM_1/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCU_1/TRM	√	√	√	○	
Escape	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/APIM/BCM_1/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCU_1/TRM	√	√	√	○	
Escape	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Escape	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Escape	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Escape	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Escape	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Escape	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/BCM_1/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCU_1/TRM	√	√	√	○	
Escape	2.5 L	IVCT	2014	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Escape	2.5 L	IVCT	2015	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Escape	2.5 L	IVCT	2016	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Escape	2.5 L	IVCT	2017	ABS/ACM/APIM/BCM_1/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCU_1/TRM	√	√	√	○	
Escort	1.5 L	TiVCT	2015	BCM#1/HVAC/IPC/PCM/PSCM/RCM	√	√	√	○	

Everest	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/ATCM/BCM_1/C-CM/DACM-C/DCDC/DDM/FCDIM/FCIM/GPSM/GWM/HCM/HUD/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RGTM/RHVAC/RTM/SCCM/SOD-L/SOD-R/TCCM/TCU_1/TRM	√	√	√	○	
Everest	2.2 L	Duratorq Turbo Diesel Common Rail Injection	2015	ABS/ACM/APIM/ATCM/BCM_1/C-CM/DACM-C/DDM/FCDIM/FCIM/GPSM/GWM/HCM/HUD/IPC/IPM-A/PAM/PCM/PDM/PSCM/RDCM_1/RCM/RGTM/RHVAC/RTM/SCCM/SOD-L/SOD-R/TCCM/TCM/TCU_1/TRM	√	√	√	○	
Everest	3.2 L	Duratorq Turbo Diesel Common Rail Injection	2015	ABS/ACM/APIM/ATCM/BCM_1/C-CM/DACM-C/DDM/FCDIM/FCIM/GPSM/GWM/HCM/HUD/IPC/IPM-A/PAM/PCM/PDM/PSCM/RDCM_1/RCM/RGTM/RHVAC/RTM/SCCM/SOD-L/SOD-R/TCCM/TCM/TCU_1/TRM	√	√	√	○	
Expedition	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/DSM/DSP/FCDIM/FCIM/GPSM/HCM/IC/LTM/PAM/PCM/PRB/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/DCSM/SOD-L/SOD-R/TBM#1/TCCM/TRM/VDM	√	√	√	○	
Expedition	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/DSM/DSP/FCDIM/FCIM/GPSM/HCM/IC/LTM/PAM/PCM/PRB/PSCM/RACM/RCM/RFA/RHVAC/RLCM-A/RTM/SCCM/DCSM/SOD-L/SOD-R/TBM#1/TCCM/TRM/VDM	√	√	√	○	
Expedition	5.4 L	3V	2015	ABS/ACM/APIM/BCM#1/DSM/DSP/FCDIM/FCIM/GPSM/HCM/IC/LTM/PAM/PCM/PRB/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/DCSM/SOD-L/SOD-R/TBM#1/TCCM/TRM/VDM	√	√	√	○	
Explorer	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/ATCM/BCM#1/C-CM/CLM#1/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GFM/GPSM/HSWM/HUD/HVAC/IC/IPM-A/LTM/OCSM/PAM/PCM/PSCM/RCM/RFA/RLCM-A/RTM/SCCM/SOD-L/SOD-R/TCM	√	√	√	A	
Explorer	2.3 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/ATCM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM-B/GFM/GPSM/GWM/HCM/HSWM/HUD/HVAC/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RHVAC/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	○	
Explorer	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/ATCM/BCM#1/C-CM/CLM#1/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GFM/GPSM/HSWM/HUD/HVAC/IC/IPM-A/LTM/OCSM/PAM/PCM/PSCM/RCM/RFA/RLCM-A/RTM/SCCM/SOD-L/SOD-R	√	√	√	A	
Explorer	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/ATCM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM-B/GFM/GPSM/GWM/HCM/HSWM/HUD/HVAC/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RHVAC/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	○	
Explorer	3.5 L	TiVCT	2015	ABS/ACM/APIM/ATCM/BCM#1/C-CM/CLM#1/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GFM/GPSM/HSWM/HUD/HVAC/IC/IPM-A/LTM/OCSM/PAM/PCM/PSCM/RCM/RFA/RLCM-A/RTM/SCCM/SOD-L/SOD-R	√	√	√	A	
Explorer	3.5 L	TiVCT	2016	ABS/ACM/APIM/ATCM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM-B/GFM/GPSM/GWM/HCM/HSWM/HUD/HVAC/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RHVAC/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	○	
Explorer	3.7 L	TiVCT	2015	ABS/ACM/APIM/ATCM/BCM#1/C-CM/CLM#1/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GFM/GPSM/HSWM/HUD/HVAC/IC/IPM-A/LTM/OCSM/PAM/PCM/PSCM/RCM/RFA/RLCM-A/RTM/SCCM/SOD-L/SOD-R	√	√	√	A	
Explorer	3.7 L	TiVCT	2016	ABS/ACM/APIM/ATCM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM-B/GFM/GPSM/GWM/HCM/HSWM/HUD/HVAC/IC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RHVAC/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	○	
F-150	2.7 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PBM/PCM/PDM/PSCM/RBM/RCM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TBM_1/TCCM/TRM	√	√	√	○	
F-150	2.7 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PBM/PCM/PDM/PSCM/RBM/RCM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TBM#1/TCCM/TRM	√	√	√	○	
F-150	2.7 L	EcoBoost - Gas Turbocharged Direct Injection	2017	PCM	√	√	√	○	

F-150	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PBM/PCM/PDM/PSCM/RBM/RCM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TBM#1/TCCM/TRM	√	√	√	○	
F-150	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PBM/PCM/PDM/PSCM/RBM/RCM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TBM#1/TCCM/TRM	√	√	√	○	
F-150	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2017	PCM/TCM	√	√	√	○	
F-150	3.5 L	TiVCT	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PBM/PCM/PDM/PSCM/RBM/RCM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TBM#1/TCCM/TRM	√	√	√	○	
F-150	3.5 L	TiVCT	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PBM/PCM/PDM/PSCM/RBM/RCM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TBM#1/TCCM/TRM	√	√	√	○	
F-150	3.5 L	TiVCT	2017	PCM	√	√	√	○	
F-150	5.0 L	TiVCT	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PBM/PCM/PDM/PSCM/RBM/RCM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TBM#1/TCCM/TRM	√	√	√	○	
F-150	5.0 L	TiVCT	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PBM/PCM/PDM/PSCM/RBM/RCM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TBM#1/TCCM/TRM	√	√	√	○	
F-150	5.0 L	TiVCT	2017	PCM	√	√	√	○	
F-150	Other	Other	2017	PCM/TCM	√	√	√	○	
F-650	6.7 L	Power Stroke - Direct Injection Turbo Diesel	2016	ABS/ACM/AHCM/APIM/BCM#1/GFM/HVAC/IPC/PCM/RTM/SCCM/TCM	√	√	√	○	
F-650	6.7 L	Power Stroke - Direct Injection Turbo Diesel	2017	ABS/ACM/AHCM/APIM/BCM_1/GFM/HVAC/IPC/PCM/RTM/SCCM/TCM	√	√	√	○	
F-650	6.8 L	3V	2016	ABS/ACM/APIM/BCM#1/GFM/HVAC/IPC/PCM/RTM/SCCM	√	√	√	A	0x0108 0x0012 0x020C 0x00F5 0x0074 0x010A
F-650	6.8 L	3V	2017	ABS/ACM/APIM/BCM_1/GFM/HVAC/IPC/PCM/RTM/SCCM	√	√	√	○	
F-750	6.7 L	Power Stroke - Direct Injection Turbo Diesel	2016	ABS/ACM/AHCM/APIM/BCM#1/GFM/HVAC/IPC/PCM/RTM/SCCM/TCM	√	√	√	○	
F-750	6.7 L	Power Stroke - Direct Injection Turbo Diesel	2017	ABS/ACM/AHCM/APIM/BCM_1/GFM/HVAC/IPC/PCM/RTM/SCCM/TCM	√	√	√	○	
F-750	6.8 L	3V	2016	ABS/ACM/APIM/BCM#1/GFM/HVAC/IPC/PCM/RTM/SCCM	√	√	√	○	
F-750	6.8 L	3V	2017	ABS/ACM/APIM/BCM_1/GFM/HVAC/IPC/PCM/RTM/SCCM	√	√	√	○	
F-Series Super Duty	6.2 L	2V	2015	ABS/ACM/APIM/BCM#1/DCSM/DSM/DSP/FCIM/GPSM/HSWM/IPC/PAM/PCM/RCM/RTM/SCCM/TBC/TCCM/TRM	√	√	√	○	
F-Series Super Duty	6.2 L	2V	2016	ABS/ACM/APIM/BCM#1/DCSM/DSM/DSP/FCIM/GPSM/HSWM/IPC/PAM/PCM/RCM/RTM/SCCM/TBC/TCCM/TRM	√	√	√	○	
F-Series Super Duty	6.2 L	2V	2017	ABS/ACM/APIM/BCM-B/BCM_1/BECM-B/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GFM-2/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/PAM/PCM/PDM/RBM/RCM/RTM/SASM/SCCM/SCM-E/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TBM_1/TCCM/TCU_1/TRM	√	√	√	○	
F-Series Super Duty	6.7 L	Power Stroke - Direct Injection Turbo Diesel	2015	ABS/ACM/AHCM/APIM/BCM#1/CDIM/DCSM/DSM/DSP/FCIM/GPSM/HSWM/IPC/PAM/PCM/RCM/RTM/SCCM/TBC/TCCM/TCM/TRM	√	√	√	○	
F-Series Super Duty	6.7 L	Power Stroke - Direct Injection Turbo Diesel	2016	ABS/ACM/AHCM/APIM/BCM#1/CDIM/DCSM/DSM/DSP/FCIM/GPSM/HSWM/IPC/PAM/PCM/RCM/RTM/SCCM/TBC/TCCM/TCM/TRM	√	√	√	○	
F-Series Super Duty	6.7 L	Power Stroke - Direct Injection Turbo Diesel	2017	ABS/ACM/APIM/BCM-B/BCM_1/BECM-B/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GFM-2/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/PAM/PCM/PDM/RBM/RCM/RTM/SASM/SCCM/SCM-E/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TBM_1/TCCM/TCM/TCU_1/TRM	√	√	√	○	
F-Series Super Duty	6.8 L	3V	2015	ABS/ACM/APIM/BCM#1/DCSM/DSM/DSP/FCIM/GPSM/HSWM/IPC/PAM/PCM/RCM/RTM/SCCM/TBC/TCCM/TRM	√	√	√	○	
F-Series Super Duty	6.8 L	3V	2016	ABS/ACM/APIM/BCM#1/DCSM/DSM/DSP/FCIM/GPSM/HSWM/IPC/PAM/PCM/RCM/RTM/SCCM/TBC/TCCM/TRM	√	√	√	○	
F-Series Super Duty	6.8 L	3V	2017	ABS/ACM/APIM/BCM-B/BCM_1/BECM-B/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GFM-2/GPSM/GWM/HSWM/HUD/IPC/IPM-A/IPM-B/PAM/PCM/PDM/RBM/RCM/RTM/SASM/SCCM/SCM-E/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TBM_1/TCCM/TCU_1/TRM	√	√	√	○	

Falcon	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BEM/FCIM/GPSM/GWM/HIM/IPC/PAM/PCM/RCM/TCM	√	√	√	A	00CA 0008 0012
Falcon	4.0 L	DOHC VCT	2014	ABS/ACM/APIM/BEM/FCIM/GPSM/GWM/HIM/IPC/PAM/PCM/RCM	√	√	√	A	00CA 0008 0012
Falcon	4.0 L	DOHC VCT LPG	2014	ABS/ACM/APIM/BEM/FCIM/GPSM/GWM/HIM/IPC/PAM/PCM/RCM	√	√	√	A	
Falcon	5.0 L	4V	2014	ABS/ACM/APIM/BEM/FCIM/GPSM/GWM/HIM/IPC/PAM/PCM/RCM/TCM	√	√	√	A	00CA 0008 0012
Fiesta	1.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/DDM/FCDIM/FCIM/GPSM/HVAC/IPC/OCSM/PCM/PSCM/RCM/RFA	√	√	√	○	
Fiesta	1.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM_1/DDM/FCDIM/FCIM/GPSM/HVAC/IPC/OCSM/PCM/PSCM/RCM/RFA/TCU_1	√	√	√	○	
Fiesta	1.5 L	Duratec_16V	2013	ACM/APIM/BCM_1/DDM/FCDIM/FDSM/GPSM/HVAC/IPC/PCM/PDM/PSCM/RCM/RFA	√	√	√	○	
Fiesta	1.5 L	Duratorq Turbo Diesel Common Rail Injection StgVI	2013	ACM/APIM/BCM_1/DDM/FCDIM/FDSM/GPSM/HVAC/IPC/PCM/PDM/PSCM/RCM/RFA	√	√	√	○	
Fiesta	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/DDM/FCDIM/FCIM/GPSM/HVAC/IPC/OCSM/PCM/PSCM/RCM/RFA	√	√	√	○	
Fiesta	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM_1/DDM/FCDIM/FCIM/GPSM/HVAC/IPC/OCSM/PCM/PSCM/RCM/RFA/TCU_1	√	√	√	○	
Fiesta	1.6 L	Gas Turbocharged Direct Injection	2013	ACM/APIM/BCM_1/DDM/FCDIM/FDSM/GPSM/HVAC/IPC/PCM/PDM/PSCM/RCM/RFA	√	√	√	○	
Fiesta	1.6 L	TiVCT	2015	ABS/ACM/APIM/BCM_1/DDM/FCDIM/FCIM/GPSM/HVAC/IPC/OCSM/PCM/PSCM/RCM/RFA	√	√	√	○	
Fiesta	1.6 L	TiVCT	2016	ABS/ACM/APIM/BCM_1/DDM/FCDIM/FCIM/GPSM/HVAC/IPC/OCSM/PCM/PSCM/RCM/RFA/TCU_1	√	√	√	○	
Figo	1.0 L	TiVCT	2015	ACM/APIM/BCM#1/FCDIM/GPSM/GWM/HVAC/IPC/PCM/EPS/RCM/TCU#1	√	√	√	○	
Figo	1.19 L	Zetec SE	2015	ACM/APIM/BCM#1/FCDIM/GPSM/GWM/HVAC/IPC/PCM/EPS/RCM/TCU#1	√	√	√	○	
Figo	1.5 L	DOHC SFI 16V	2015	ACM/APIM/BCM#1/FCDIM/GPSM/GWM/HVAC/IPC/PCM/EPS/RCM/TCU#1	√	√	√	○	
Figo	1.5 L	DV5D	2015	ACM/APIM/BCM#1/FCDIM/GPSM/GWM/HVAC/IPC/PCM/EPS/RCM/TCU#1	√	√	√	○	
Figo	1.5 L	TiVCT	2015	ACM/APIM/BCM#1/FCDIM/GPSM/GWM/HVAC/IPC/PCM/EPS/RCM/TCM/TCU#1	√	√	√	○	
Flex	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/CCM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/LTM/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	A	
Flex	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/CCM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/LTM/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	A	0008
Flex	3.5 L	TiVCT	2015	ABS/ACM/APIM/BCM#1/CCM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/LTM/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	A	
Flex	3.5 L	TiVCT	2016	ABS/ACM/APIM/BCM#1/CCM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/LTM/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	A	0008
Focus	1.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/DDM/DSP/FCDIM/FCIM/GPSM/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R	√	√	√	○	
Focus	1.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM_1/DDM/DSP/FCDIM/FCIM/GPSM/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R	√	√	√	○	
Focus	1.0 L	Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM_1/CCM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Focus	1.5 L	Duratorq Turbo Diesel Common Rail Injection StgVI	2015	ABS/ACM/AHCM/APIM/BCM_1/CCM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TCM/TRM	√	√	√	○	
Focus	1.5 L	Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM_1/CCM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Focus	1.6 L	Duratec 16V	2015	ABS/ACM/AHCM/APIM/BCM_1/CCM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TCM/TRM	√	√	√	○	
Focus	1.6 L	Duratorq Turbo Diesel Common Rail Injection StgV	2015	ABS/ACM/AHCM/APIM/BCM#1/CCM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TRM	√	√	√	○	

Focus	2.0 L	Duratorq Turbo Diesel Common Rail Injection StgV	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TCM/TRM	√	√	√	○	
Focus	2.0 L	Duratorq Turbo Diesel Common Rail Injection StgVI	2015	ABS/ACM/AHCM/APIM/BCMW1/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TCM/TRM	√	√	√	○	
Focus	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/DDM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/ICM_1/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R	√	√	√	○	
Focus	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM_1/DDM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/ICM_1/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R	√	√	√	○	
Focus	2.0 L	GDI	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TCM/TRM	√	√	√	○	
Focus	2.0 L	Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Focus	2.0 L	Gasoline Direct injection	2015	ABS/ACM/APIM/BCM_1/DDM/DSP/FCDIM/FCIM/GPSM/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TCM	√	√	√	○	
Focus	2.0 L	Gasoline Direct injection	2016	ABS/ACM/APIM/BCM_1/DDM/DSP/FCDIM/FCIM/GPSM/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/TCM	√	√	√	○	
Focus	2.3 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/AWD_1/BCM_1/DDM/DSP/FCDIM/FCIM/GFM-2/GPSM/HCM/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R	√	√	√	○	
Focus	23 kWh	Battery Electric Vehicle	2015	ABS/ACCM_2/ACM/AHCM/APIM/BCM_1/BECM/C-CM/DCDC/DDM/FCDIM/FDSM/GFM/GPSM/GWM/HCM/HVAC/IPC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/SOBDM/TCM/TCU_1/TRM	√	√	√	○	
Focus	23 kWh	Battery Electric Vehicle	2016	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/DCDC/DDM/DSP/FCDIM/FCIM/GFM/GPSM/GWM/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOD-L/SOD-R/SOBDM/TCM/TCU#1	√	√	√	○	
Fusion	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1	√	√	√	A	
Fusion	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1	√	√	√	A	
Fusion	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/BCM_1/BECM-B/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	A	
Fusion	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1	√	√	√	A	
Fusion	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1	√	√	√	A	
Fusion	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1	√	√	√	A	
Fusion	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/BCM_1/BECM-B/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	○	
Fusion	2.0 L	Full Hybrid Electric Vehicle	2015	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/RDCM#1/SOD-L/SOD-R/TCU#1	√	√	√	○	0x0108 0x0012 0x020C 0x00F5 0x0074 0x010A

Fusion	2.0 L	Full Hybrid Electric Vehicle	2016	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/RDCM#1/SOD-L/SOD-R/TCU#1	√	√	√	○	0x0108 0x0012 0x020C 0x00F5 0x0074 0x010A
Fusion	2.0 L	Full Hybrid Electric Vehicle	2017	ABS/ACCM_2/ACM/APIM/BCM_1/BECM/BECM-B/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PACM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SCM-G/SCM-H/RDCM_1/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	○	0x0108 0x0012 0x020C 0x00F5 0x0074 0x010A
Fusion	2.0 L	Plug-in Hybrid Electric Vehicle	2015	ABS/ACCM#/ACM/APIM/BCM#1/BECM/C-CM/DACM-/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/RDCM#/SOD-L/SOD-R/SOBDM/TCU#1	√	√	√	○	0x0108 0x0012 0x020C 0x00F5 0x0074 0x010A
Fusion	2.0 L	Plug-in Hybrid Electric Vehicle	2016	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/RDCM#1/SOD-L/SOD-R/SOBDM/TCU#1	√	√	√	○	0x0108 0x0012 0x020C 0x00F5 0x0074 0x010A
Fusion	2.0 L	Plug-in Hybrid Electric Vehicle	2017	ABS/ACCM_2/ACM/APIM/BCM_1/BECM/BECM-B/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PACM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SCM-G/SCM-H/RDCM_1/SOD-L/SOD-R/SOBDM/TCU_1/TRCM/VDM	√	√	√	○	0x0108 0x0012 0x020C 0x00F5 0x0074 0x010A
Fusion	2.5 L	IVCT	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1	√	√	√	A	
Fusion	2.5 L	IVCT	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1	√	√	√	A	
Fusion	2.5 L	IVCT	2017	ABS/ACM/APIM/BCM_1/BECM-B/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	A	
Fusion	2.7 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/BCM_1/BECM-B/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	A	
Ka	1.0 L	TiVCT	2015	ACM/APIM/BCM#1/FCDIM/GPSM/GWM/HVAC/IPC/PCM/EPS/RCM/TCU#1	√	√	√	○	
Ka	1.19 L	Zetec SE	2015	ACM/APIM/BCM#1/FCDIM/GPSM/GWM/HVAC/IPC/PCM/EPS/RCM/TCU#1	√	√	√	○	
Ka	1.5 L	DOHC SFI 16V	2015	ACM/APIM/BCM#1/FCDIM/GPSM/GWM/HVAC/IPC/PCM/EPS/RCM/TCU#1	√	√	√	○	
Ka	1.5 L	DV5D	2015	ACM/APIM/BCM#1/FCDIM/GPSM/GWM/HVAC/IPC/PCM/EPS/RCM/TCU#1	√	√	√	○	
Ka	1.5 L	TiVCT	2015	ACM/APIM/BCM#1/FCDIM/GPSM/GWM/HVAC/IPC/PCM/EPS/RCM/TCM/TCU#1	√	√	√	○	
Kuga	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/BCM_1/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCU_1/TRM	√	√	√	○	
Kuga	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/APIM/BCM_1/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCU_1/TRM	√	√	√	○	
Kuga	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Kuga	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Kuga	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Kuga	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	

Kuga	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SODR/TRM	√	√	√	○	
Kuga	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/BCM_1/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCU_1/TRM	√	√	√	○	
Kuga	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/APIM/BCM_1/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCU_1/TRM	√	√	√	○	
Kuga	2.5 L	IVCT	2014	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SODR/TRM	√	√	√	○	
Kuga	2.5 L	IVCT	2015	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SODR/TRM	√	√	√	○	
Kuga	2.5 L	IVCT	2016	ABS/ACM/APIM/BCM_1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SODR/TRM	√	√	√	○	
Kuga	2.5 L	IVCT	2017	ABS/ACM/APIM/BCM_1/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCU_1/TRM	√	√	√	○	
Kuga	2.5 L	IVCT	2017	ABS/APIM/BCM_1/C-CM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TCU_1/TRM	√	√	√	○	
Mondeo	1.0 L	GTDI_StgV	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IPC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	1.0 L	Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IPC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	1.5 L	Duratorq Turbo Diesel Common Rail Injection StgVI	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IPC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	1.5 L	GTDI_StgV	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IPC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	1.5 L	Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IPC/IPM-A/PAM/PCM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	1.5 L	TDCi_StgVI_ECO	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IPC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	1.6 L	Duratorq Turbo Diesel Common Rail Injection StgV	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	1.6 L	TDCi_StgV_ECO	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	2.0 L	Duratorq Turbo Diesel Common Rail Injection StgV	2015	ABS/ACM/AHCM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TCM/TRM/VDM	√	√	√	○	
Mondeo	2.0 L	Duratorq Turbo Diesel Common Rail Injection StgVI	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TCM/TRM/VDM	√	√	√	○	

Mondeo	2.0 L	Full Hybrid Electric Vehicle	2015	ABS/ACCM_2/ACM/AHCM/APIM/BCM_1/BECM/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/RDCM_1/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	2.0 L	GTDI_StgV	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	2.0 L	Gas Turbocharged Direct Injection	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Mondeo	2.5 L	IVCT	2015	ABS/ACM/AHCM/APIM/BCM_1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/FDSM/GPSM/GWM/HCM/HSWM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TRM/VDM	√	√	√	○	
Motorhome / Stripped Chassis / Step Van	6.8 L	3V	2015	ABS/IC/PCM	√	√	√	○	
Motorhome / Stripped Chassis / Step Van	6.8 L	3V	2016	ABS/IC/PCM	√	√	√	○	
Mustang	2.3 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IPC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R	√	√	√	○	
Mustang	2.3 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R	√	√	√	○	
Mustang	2.3 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R	√	√	√	○	
Mustang	3.7 L	TiVCT	2015	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IPC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R	√	√	√	○	
Mustang	3.7 L	TiVCT	2016	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R	√	√	√	○	
Mustang	3.7 L	TiVCT	2017	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R	√	√	√	○	
Mustang	5.0 L	TiVCT	2015	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IPC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R	√	√	√	○	
Mustang	5.0 L	TiVCT	2016	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R	√	√	√	○	
Mustang	5.0 L	TiVCT	2017	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R	√	√	√	○	
Mustang	5.2 L	TiVCT	2015	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IPC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R/VDM	√	√	√	○	

Mustang	5.2 L	TiVCT	2016	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IC/MRCM-A/MRCM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R/VDM	√	√	√	○	
Mustang	5.2 L	TiVCT	2017	ABS/ACM/APIM/BCM-B/BCM_1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/ICM_1/IC/MRCM-A/MRCM-B/OCSM/PAM/PDM/PSCM/RCM/RTM/SCCM/DCSM/SOD-L/SOD-R/VDM	√	√	√	○	
Mustang	5.8 L	4V	2014	ABS/ACM/APIM/BCM-B/FCIM/FDIM/BEM/GPSM/HVAC/IPC/OCSM/PAM/PCM/PSCM/RCM/VDM	√	√	√	A	0008 0012
Ranger	2.2 L	Duratorq Turbo Diesel Common Rail Injection	2015	ABS/ACM/APIM/ATCM/BCM_1/C-CM/DDM/FCDIM/FCIM/GPSM/GWM/HCM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SCCM/TBM/TCM/TCU_1/TRM	√	√	√	A	0008 0012
Ranger	2.5 L	IVCT	2015	ABS/ACM/APIM/ATCM/BCM#1/C-CM/DDM/FCDIM/FCIM/GPSM/GWM/HCM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SCCM/TBM/TCU#1/TRM	√	√	√	○	
Ranger	3.2 L	Duratorq Turbo Diesel Common Rail Injection	2015	ABS/ACM/APIM/ATCM/BCM_1/C-CM/DDM/FCDIM/FCIM/GPSM/GWM/HCM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SCCM/TBM/TCM/TCU_1/TRM	√	√	√	○	
Spectron	1.8 L	L8	2016	ABS/IC/PCM/TCM	√	√	√	A	
Taurus	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RHVAC/RTM/SCCM/SCM-C/SCM-D/SCM-F/SCM-E/SCM-G/SCM-H/SFM-A/SFM-B/SOD-L/SOD-R/TRCM	√	√	√	○	
Taurus	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	A	0008
Taurus	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	A	0008
Taurus	2.7 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HUD/IC/IPM-A/PAM/PCM/PDM/PSCM/RACM/RCM/RHVAC/RTM/SCCM/SCM-C/SCM-D/SCM-F/SCM-E/SCM-G/SCM-H/SFM-A/SFM-B/SOD-L/SOD-R/TRCM	√	√	√	○	
Taurus	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	A	0008
Taurus	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	A	0008
Taurus	3.5 L	TiVCT	2015	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	A	
Taurus	3.5 L	TiVCT	2016	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	○	0008
Taurus	3.7 L	TiVCT	2015	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	A	
Taurus	3.7 L	TiVCT	2016	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R	√	√	√	A	0008
Territory	2.7 L	Direct Injection - Turbo	2014	ABS/ACM/APIM/AWD_1/BEM/FCIM/GPSM/GWM/HIM/IPC/PAM/PCM/PSCM/RCM/TCM	√	√	√	A	00CA 0008 0012
Territory	4.0 L	DOHC VCT	2014	ABS/ACM/APIM/BEM/FCIM/GPSM/GWM/HIM/IPC/PAM/PCM/PSCM/RCM/TCM	√	√	√	A	00CA 0008 0012
Transit	2.0 L	Duratorq Turbo Diesel Common Rail Injection	2016	ABS/ACM/BEM/FCDIM/HVAC/IPC/PAM/PCM/RCM/RHVAC/SASM/VDM	√	√	√	○	
Transit	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/BEM/FCDIM/HVAC/IPC/PAM/PCM/RCM/RHVAC/SASM/VDM	√	√	√	○	

Transit	3.2 L	Duratorq Turbo Diesel Common Rail Injection	2015	ABS/ACM/APIM/BCM_1/FCDIM/FCIM/GPSM/IPC/IPM-A/PAM/PCM/RDCM_1/RCM/SASM/TBC/TCM/TRM	√	√	√	○	
Transit	3.2 L	Duratorq Turbo Diesel Common Rail Injection	2016	ABS/ACM/AHCM/APIM/BCM_1/CCM/FCDIM/FCIM/GPSM/IPC/IPM-A/IPM-B/PAM/PCM/RDCM_1/RCM/SASM/TBC/TCM/TRM	√	√	√	○	
Transit	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/FCDIM/FCIM/GPSM/IPC/IPM-A/PAM/PCM/RCM/SASM/TBC/TRM	√	√	√	○	
Transit	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/AHCM/APIM/BCM_1/CCM/FCDIM/FCIM/GPSM/IPC/IPM-A/IPM-B/PAM/PCM/RCM/SASM/TBC/TRM	√	√	√	○	
Transit	3.7 L	TiVCT	2015	ABS/ACM/APIM/BCM_1/FCDIM/FCIM/GPSM/IPC/IPM-A/PAM/PCM/RCM/SASM/TBC/TRM	√	√	√	○	
Transit	3.7 L	TiVCT	2016	ABS/ACM/AHCM/APIM/BCM_1/CCM/FCDIM/FCIM/GPSM/IPC/IPM-A/IPM-B/PAM/PCM/RCM/SASM/TBC/TRM	√	√	√	○	
Transit Connect	1.0 L	Gas Turbocharged Direct Injection	2014	ABS/ACM/AHCM/APIM/BCM_1/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-B/PAM/PCM/PDM/PSCM/RCM/SASM/TRM	√	√	√	○	
Transit Connect	1.5 L	Duratorq Turbo Diesel Common Rail Injection StgVI	2014	ABS/ACM/AHCM/APIM/BCM_1/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-B/PAM/PCM/PDM/PSCM/RCM/SASM/TCM/TRM	√	√	√	○	
Transit Connect	1.5 L	TDCi_StgVI_ECO	2014	ABS/ACM/AHCM/APIM/BCM_1/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-B/PAM/PCM/PDM/PSCM/RCM/SASM/TRM	√	√	√	○	
Transit Connect	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM_1/DDM/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/SASM/TRM	√	√	√	A	
Transit Connect	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM_1/DDM/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	0012
ansit Conne	2.0 L	Duratec HE / I4	2013	ABS,ACM,ACM,APIM,BEM,IC,OCSM,PAM,PCM,RCM,VSM	√	√	√	A	0005
Transit Connect	2.5 L	IVCT	2015	ABS/ACM/APIM/BCM_1/DDM/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/SASM/TRM	√	√	√	A	
Transit Connect	2.5 L	IVCT	2016	ABS/ACM/APIM/BCM_1/DDM/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	0012
Transit Courier	1.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM_1/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM	√	√	√	○	
Transit Courier	1.0 L	Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM_1/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM	√	√	√	○	
Transit Courier	1.5 L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	ABS/ACM/APIM/BCM_1/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM	√	√	√	○	
Transit Courier	1.5 L	Duratorq Turbo Diesel Common Rail Injection StgVI	2014	ABS/ACM/APIM/BCM_1/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM	√	√	√	○	
Transit Courier	1.6 L	TDCi_ECO_II	2014	ABS/ACM/APIM/BCM_1/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM	√	√	√	○	
Continental	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/AWD_1/BCM-B/BCM_1/BECM-B/C-CM/DACM-C/DCM-H/DCM-G/DCM-F/DCM-E/DDM/DSM/DSP/FCIM/GFM/GWM/GSM/HCM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RHVAC/RTM/SASM/SCCM/SCM-B/SCM-C/SCM-D/SCM-F/SCM-E/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	○	
Continental	2.7 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/AWD_1/BCM-B/BCM_1/BECM-B/C-CM/DACM-C/DCM-H/DCM-G/DCM-F/DCM-E/DDM/DSM/DSP/FCIM/GFM/GWM/GSM/HCM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RHVAC/RTM/SASM/SCCM/SCM-B/SCM-C/SCM-D/SCM-F/SCM-E/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	○	
Continental	3.0 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/AWD_1/BCM-B/BCM_1/BECM-B/C-CM/DACM-C/DCM-H/DCM-G/DCM-F/DCM-E/DDM/DSM/DSP/FCIM/GFM/GWM/GSM/HCM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RHVAC/RTM/SASM/SCCM/SCM-B/SCM-C/SCM-D/SCM-F/SCM-E/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	○	
Continental	3.7 L	TiVCT	2017	ABS/ACM/APIM/AWD_1/BCM-B/BCM_1/BECM-B/C-CM/DACM-C/DCM-H/DCM-G/DCM-F/DCM-E/DDM/DSM/DSP/FCIM/GFM/GWM/GSM/HCM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RHVAC/RTM/SASM/SCCM/SCM-B/SCM-C/SCM-D/SCM-F/SCM-E/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	○	

MKC	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1/TRCM/TRM/VDM	√	√	√	○	
MKC	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1/TRCM/TRM/VDM	√	√	√	○	
MKC	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/BCM_1/BECM-B/C-CM/DACM-C/DDM/DSM/DSP/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU_1/TRCM/TRM/VDM	√	√	√	○	
MKC	2.3 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1/TRCM/TRM/VDM	√	√	√	○	
MKC	2.3 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU#1/TRCM/TRM/VDM	√	√	√	○	
MKC	2.3 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/BCM_1/BECM-B/C-CM/DACM-C/DDM/DSM/DSP/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RCM/RGTM/RTM/SCCM/DCSM/SOD-L/SOD-R/TCU_1/TRCM/TRM/VDM	√	√	√	○	
MKS	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R/VDM	√	√	√	A	
MKS	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R/VDM	√	√	√	A	0008
MKS	3.7 L	TiVCT	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R/VDM	√	√	√	A	0008
MKS	3.7 L	TiVCT	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SCM-G/SCM-H/SOD-L/SOD-R/VDM	√	√	√	A	0008
MKT	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PCSM-2/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	A	
MKT	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PCSM-2/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	A	0008
MKT	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PCSM-2/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	A	
MKT	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PCSM-2/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	A	0008
MKT	3.7 L	TiVCT	2015	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PCSM-2/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	A	0008
MKT	3.7 L	TiVCT	2016	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PCSM-2/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	A	0008

MKX	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BEM/GPSM/IPC/PCM/RCM/TBC	√	√	√	○	
MKX	2.7 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SASM/SCCM/SCM-B/SCM-E/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TCU#1/TRCM/TRM/VDM	√	√	√	○	
MKX	3.7 L	TiVCT	2015	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GPSM/HCM/HSWM/HUD/HVAC/IPC/LTM/OCSM/PAM/PCM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	
MKX	3.7 L	TiVCT	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IPC/IPM-A/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SASM/SCCM/SCM-B/SCM-E/SCM-G/SCM-H/SECM/SOD-L/SOD-R/TCU#1/TRCM/TRM/VDM	√	√	√	○	
MKZ	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TCU#1/TRCM/VDM	√	√	√	A	
MKZ	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TCU#1/TRCM/VDM	√	√	√	A	
MKZ	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/BCM_1/BECM-B/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	A	
MKZ	2.0 L	Full Hybrid Electric Vehicle	2015	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/RDCM#1/SOD-L/SOD-R/TCU#1/TRCM/VDM	√	√	√	○	
MKZ	2.0 L	Full Hybrid Electric Vehicle	2016	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/RDCM#1/SOD-L/SOD-R/TCU#1/TRCM/VDM	√	√	√	A	0x0108 0x0012 0x020C 0x00F5 0x0074 0x010A
MKZ	2.0 L	Full Hybrid Electric Vehicle	2017	ABS/ACCM_2/ACM/APIM/BCM_1/BECM/BECM-B/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PACM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/SCM-E/SCM-G/SCM-H/RDCM_1/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	A	0x0108 0x0012 0x020C 0x00F5 0x0074 0x010A
MKZ	3.0 L	EcoBoost - Gas Turbocharged Direct Injection	2017	ABS/ACM/APIM/AWD_1/BCM_1/BECM-B/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R/TCU_1/TRCM/VDM	√	√	√	A	
MKZ	3.7 L	TiVCT	2015	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TCU#1/TRCM/VDM	√	√	√	○	
MKZ	3.7 L	TiVCT	2016	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/GSM/HCM/HSWM/HUD/IC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/DCSM/SCM-G/SCM-H/SOD-L/SOD-R/TCU#1/TRCM/VDM	√	√	√	○	
Navigator	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2015	ABS/ACM/APIM/BCM#1/DSM/DSP/FCDIM/FCIM/GPSM/HCM/IC/LTM/PAM/PCM/PRB/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/DCSM/SOD-L/SOD-R/TBM#1/TCCM/TRM/VDM	√	√	√	○	
Navigator	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2016	ABS/ACM/APIM/BCM#1/DSM/DSP/FCDIM/FCIM/GPSM/HCM/IC/LTM/PAM/PCM/PRB/PSCM/RACM/RCM/RFA/RHVAC/RLCM-A/RTM/SCCM/DCSM/SOD-L/SOD-R/TBM#1/TCCM/TRM/VDM	√	√	√	○	
C-MAX	2.0 L	Full Hybrid Electric Vehicle	2014	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/DACM-C/DCDC/DDM/FCDIM/FCIM/GPSM/GWM/HVAC/IPC/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOBDM-C	√	√	√	○	

C-MAX	2.0 L	Plug-in Hybrid Electric Vehicle	2014	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/DACM-C/DCDC/DDM/FCDIM/FCIM/GFM/GPSM/GWM/HVAC/IPC/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOBDM/SOBDM-C/TCU#1	√	√	√	○	
E-Series	4.6 L	2V	2014	ABS/ACM/APIM/GEM/SJB/GPSM/IPC/PAM/PCM/RCM/TBC	√	√	√	○	
E-Series	5.4 L	2V	2014	ABS/ACM/APIM/GEM/SJB/GPSM/IPC/PAM/PCM/RCM/TBC	√	√	√	○	
E-Series	6.8 L	2V	2014	ABS/ACM/APIM/GEM/SJB/GPSM/IPC/PAM/PCM/RCM/TBC	√	√	√	○	
EcoSport	1.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCMii/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM/RFA	√	√	√	○	
EcoSport	1.5 L	Duratec VCT	2014	ABS/ACM/APIM/BCMii/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM/RFA/TCM	√	√	√	○	
EcoSport	1.5 L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	ACM/APIM/BCMii/FCDIM/GPSM/HVAC/IPC/PCM/PSCM/RCM/RFA	√	√	√	○	
Edge	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/CCM/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GPSM/HUD/HVAC/IPC/LTM/OCSM/PAM/PCM/RCM/RFA/RLCM-A/RTM/SCCM/SOD-L/SOD-R/TBM/TCM	√	√	√	○	
Edge	3.5 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/CCM/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GPSM/HUD/HVAC/IPC/LTM/OCSM/PAM/PCM/RCM/RFA/RLCM-A/RTM/SCCM/SOD-L/SOD-R/TBM	√	√	√	○	
Edge	3.7 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/CCM/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GPSM/HUD/HVAC/IPC/LTM/OCSM/PAM/PCM/RCM/RFA/RLCM-A/RTM/SCCM/SOD-L/SOD-R/TBM	√	√	√	○	
Expedition	5.4 L	3V	2014	ABS/ACM/APIM/DCSM/DSM/DSP/GEM/SJB/GPSM/HVAC/IC/LTM/PAM/PCM/PRB/RCM/RCU/SDARS/TBC/TCCM/VDM	√	√	√	○	
xpedition E	5.4 L	3V	2014	ABS/ACM/APIM/DCSM/DSM/DSP/GEM/SJB/GPSM/HVAC/IC/LTM/PAM/PCM/PRB/RCM/RCU/SDARS/TBC/TCCM/VDM	√	√	√	○	
Explorer	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/ATCM/BCM#1/CCM/CLM#1/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PSCM/RCM/RFA/RLCM-A/RTM/SCCM/SOD-L/SOD-R/TCM	√	√	√	○	
Explorer	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/ATCM/BCM#1/CCM/CLM#1/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PSCM/RCM/RFA/RLCM-A/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	
Explorer	3.5 L	TiVCT	2014	ABS/ACM/APIM/ATCM/BCM#1/CCM/CLM#1/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PSCM/RCM/RFA/RLCM-A/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	
Explorer	3.7 L	TiVCT	2014	ABS/ACM/APIM/ATCM/BCM#1/CCM/CLM#1/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PSCM/RCM/RFA/RLCM-/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	
F-150	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/DCSM/DSM/DSP/FCDIM/FCIM/FDIM/GPSM/HVAC/IPC/OCSM/PAM/PCM/PRB/PSCM/RCM/RTM/SCCM/TBC/TCCM	√	√	√	○	
F-150	3.7 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/DCSM/DSM/DSP/FCDIM/FCIM/FDIM/GPSM/HVAC/IPC/OCSM/PAM/PCM/PRB/PSCM/RCM/RTM/SCCM/TBC/TCCM	√	√	√	○	
F-150	5.0 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/DCSM/DSM/DSP/FCDIM/FCIM/FDIM/GPSM/HVAC/IPC/OCSM/PAM/PCM/PRB/PSCM/RCM/RTM/SCCM/TBC/TCC	√	√	√	○	
F-150	6.2 L	2V	2014	ABS/ACM/APIM/BCM#1/DCSM/DSM/DSP/FCDIM/FCIM/FDIM/GPSM/HVAC/IPC/OCSM/PAM/PCM/PRB/PSCM/RCM/RTM/SCCM/TBC/TCCM	√	√	√	○	
eries Super	6.2 L	2V	2014	ABS/ABS/ACM/ACM/ACM/ACM/APIM/BCM#1/DCSM/DSM/DSP/FCDIM/FCIM/GPSM/HSWM/HVAC/HVAC/IPC/PAM/PCM/RCM/RTM/SCCM/TBC/TCCM	√	√	√	○	
eries Super	6.7 L	Power Stroke - Direct Injection Turbo Diesel	2014	ABS/ACM/AHCM/APIM/BCM#1/CDIM/DCSM/DSM/DSP/FCDIM/FCIM/GPCM/GPSM/HSWM/IPC/PAM/PCM/RCM/RTM/SCCM/TBC/TCCM/TCM/HVAC/NOx11M/NOx12M	√	√	√	○	
eries Super	6.8 L	3V	2014	ABS/ACM/APIM/BCM#1/DCSM/DSM/DSP/FCDIM/FCIM/GPSM/HSWM/HVAC/IPC/PAM/PCM/RCM/RTM/SCCM/TBC/TCCM	√	√	√	○	
Fiesta	1.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/DDM/FCDIM/FCIM/GPSM/HVAC/IPC/OCSM/PCM/PSCM/RCM/RFA	√	√	√	○	
Fiesta	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ACM/APIM/BCM#1/DDM/FCDIM/FCIM/GPSM/HVAC/IPC/OCSM/PCM/PSCM/RCM/RFA	√	√	√	○	
Fiesta	1.6 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/DDM/FCDIM/FCIM/GPSM/HVAC/IPC/OCSM/PCM/PSCM/RCM/RFA	√	√	√	○	

Flex	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/LTM/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	
Flex	3.5 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HUD/HVAC/IPC/LTM/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	
Focus	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/DDM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/ICM#1/IPC/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM	√	√	√	○	
Focus	2.0 L	Gasoline Direct injection	2014	ABS/ACM/APIM/BCM#1/DDM/DSP/FCDIM/FCIM/GPSM/HVAC/IPC/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM	√	√	√	○	
Focus	23 kWh	Battery Electric Vehicle	2014	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/DCDC/DDM/DSP/FCDIM/FCIM/GFM/GPSM/GWM/HCM/HVAC/IPC/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/SASM/SOBDM/TCM/TCU#1	√	√	√	○	
Fusion	1.5 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SOD-L/SOD-R/TCU#1	√	√	√	○	
Fusion	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SOD-L/SOD-R/TCU#1	√	√	√	○	
Fusion	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SOD-L/SOD-R/TCU#1	√	√	√	○	
Fusion	2.0 L	Full Hybrid Electric Vehicle	2014	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SOBDM-C/SOD-L/SOD-R/TCU#1	√	√	√	○	
Fusion	2.0 L	Plug-in Hybrid Electric Vehicle	2014	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/GWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SOBDM/SOBDM-C/SOD-L/SOD-R/TCU#1	√	√	√	○	
Fusion	2.5 L	IVCT	2014	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GPSM/GWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RTM/SCCM/SCM-E/SOD-L/SOD-R/TCU#1	√	√	√	○	
Kuga	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SODR/TRM	√	√	√	○	
Kuga	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SODR/TRM	√	√	√	○	
Kuga	2.5 L	IVCT	2014	ABS/ACM/APIM/BCM#1/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/OCSM/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SODR/TRM	√	√	√	○	
tripped Cha	6.8 L	3V	2014	ABS/IC/PCM	√	√	√	○	
Mustang	3.7 L	TiVCT	2014	ABS/ACM/APIM/BCM-B/FCIM/FDIM/GEM/SJB/GPSM/HVAC/IPC/OCSM/PAM/PCM/PSCM/RCM	√	√	√	○	
Mustang	5.0 L	TiVCT	2014	ACM/ACM/ACM/APIM/BCM-B/FCIM/FDIM/GEM/SJB/GPSM/HVAC/IPC/OCSM/PAM/PCM/PCM/PSCM/RCM	√	√	√	○	
Taurus	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	
Taurus	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	
Taurus	3.5 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	
Taurus	3.7 L	TiVCT	2014	ABS/ACM/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	

Transit	2.2 L	Duratorq Turbo Diesel Common Rail Injection	2014	ABS/ACM/AHCM/APIM/AWD#1/BCMii/CCMii/FCDIM/FCIM/GPSM/HCM/IPC/IPM-A/IPM-B/PAM/PCM/PRB/RCM/SASM/TRM	√	√	√	○	
Transit	2.2 L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	ABS/ACM/AHCM/APIM/AWD#1/BCMii/CCMii/FCDIM/FCIM/GPSM/HCM/IPC/IPM-A/IPM-B/PAM/PCM/PRB/RCM/SASM/TRM	√	√	√	○	
Transit	2.2 L	Duratorq Turbo Diesel Common Rail Injection StgVI	2014	ABS/ACM/AHCM/APIM/AWD#1/BCMii/CCMii/FCDIM/FCIM/GPSM/HCM/IPC/IPM-A/IPM-B/PAM/PCM/PRB/RCM/SASM/TRM	√	√	√	○	
Transit	2.2 L	TDCi StgVI	2014	ABS/ACM/AHCM/APIM/AWD#1/BCMii/CCMii/FCDIM/FCIM/GPSM/HCM/IPC/IPM-A/IPM-B/PAM/PCM/PRB/RCM/SASM/TRM	√	√	√	○	
Transit	3.2 L	Duratorq Turbo Diesel Common Rail Injection	2014	PCM/RDCM#1/TCM	√	√	√	○	
ansit Conne	1.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/AHCM/APIM/BCMii/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-B/PAM/PCM/PDM/PSCM/RCM/SASM/TRM	√	√	√	○	
ansit Conne	1.6 L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	ABS/ACM/AHCM/APIM/BCMii/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-B/PAM/PCM/PDM/PSCM/RCM/SASM/TRM	√	√	√	○	
ansit Conne	1.6 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/AHCM/APIM/BCMii/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-B/PAM/PCM/PDM/PSCM/RCM/SASM/TRM	√	√	√	○	
ansit Conne	1.6 L	TDCi ECO III	2014	ABS/ACM/AHCM/APIM/BCMii/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IPC/IPM-B/PAM/PCM/PDM/PSCM/RCM/SASM/TRM	√	√	√	○	
ansit Conne	2.5 L	IVCT	2014	ABS/ACM/APIM/BCM#1/DDM/FCDIM/FCIM/GPSM/HCM/HVAC/IPC/IPM-B/OCSM/PAM/PCM/PDM/PSCM/RCM/SASM/TRM	√	√	√	○	
MKS	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HCM-2/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	○	
MKS	3.7 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DCSM/DDM/DSM/DSP/FCDIM/FCIM/GPSM/HCM/HCM-2/HSWM/HUD/HVAC/IPC/IPM-A/OCSM/PAM/PCM/PSCM/RACM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	○	
MKT	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PCSM-2/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	○	
MKT	3.5 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PCSM-2/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	○	
MKT	3.7 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DDM/DSM/DSP/FCIM/GPSM/HCM/HSWM/HUD/HVAC/IPC/IPM-A/LTM/OCSM/PAM/PCM/PCSM-2/PSCM/RACM/RCM/RFA/RHVAC/RTM/SCCM/SOD-L/SOD-R/VDM	√	√	√	○	
MKX	3.7 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/C-CM/DCSM/DSM/DSP/FCDIM/FCIM/FLM/GPSM/HCM/HSWM/HUD/HVAC/IPC/LTM/OCSM,/PAM/PCM/RCM/RFA/RTM/SCCM/SOD-L/SOD-R	√	√	√	○	
MKZ	2.0 L	EcoBoost - Gas Turbocharged Direct Injection	2014	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/GSM/GWM/HCM/HSWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R/TRCM/VDM	√	√	√	○	
MKZ	2.0 L	Full Hybrid Electric Vehicle	2014	ABS/ACCM#2/ACM/APIM/BCM#1/BECM/C-CM/DACM-C/DCDC/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/GSM/GWM/HCM/HSWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOBDM-C/SOD-L/SOD-R/TRCM/VDM	√	√	√	○	
MKZ	3.7 L	TiVCT	2014	ABS/ACM/APIM/BCM#1/C-CM/DACM-C/DDM/DSM/DSP/FCDIM/FCIM/GFM/GPSM/GSM/GWM/HCM/HSWM/HUD/IPC/IPM-A/OCSM/PAM/PCM/PDM/PSCM/RACM/RCM/RGTM/RTM/SCCM/SCM-E/SCM-G/SCM-H/SOD-L/SOD-R/TRCM/VDM	√	√	√	○	
Navigator	5.4 L	3V	2014	ABS/ACM/ACM/APIM/DCSM/DSM/DSP/GEM/SJB/GPSM/HVAC/IC/LTM/PAM/PAM/PCM/PCM/PRB/RCM/RCU/SDARS/TBC/TCCM/VDM	√	√	√	○	
Navigator L	5.4 L	3V	2014	ABS/ACM/APIM/DCSM/DSM/DSP/GEM/SJB/GPSM/HVAC/IC/LTM/PAM/PCM/PRB/RCM/RCU/SDARS/TBC/TCCM/VDM	√	√	√	○	
Escape	1.5 L	Gas Turbocharged Direct Injection	2013	ABS/ACM/AHCM/APIM/BCM#1/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
F-650	5.9 L	Cummins Diesel	2000	ABS/TCS/GEM	√	√	√	○	
F-650	5.9 L	Cummins Diesel	2001	ABS/TCS/GEM	√	√	√	○	
F-650	5.9 L	Cummins Diesel	2002	ABS/TCS/GEM	√	√	√	○	

F-650	5.9 L	Cummins Diesel	2003	ABS/TCS/GEM	√	√	√	○	
F-650	5.9 L	Cummins Diesel	2004	GEM	√	√	√	○	
F-650	5.9 L	Cummins Diesel	2005	GEM	√	√	√	○	
F-650	5.9 L	Cummins Diesel	2006	GEM	√	√	√	○	
F-650	5.9 L	Cummins Diesel	2007	GEM	√	√	√	○	
F-650	6.7 L	Cummins Diesel	2008	GEM / SJB	√	√	√	○	
F-650	6.7 L	Cummins Diesel	2009	GEM / SJB	√	√	√	○	
F-650	6.7 L	Cummins Diesel	2010	GEM / SJB	√	√	√	○	
F-650	6.7 L	Cummins Diesel	2011	ACM/GEM / SJB/HVAC/IPC	√	√	√	○	
F-650	6.7 L	Cummins Diesel	2015	ACM/APIM/HVAC/IPC/GEM / SJB	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2000	ABS/TCS/GEM	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2001	ABS/TCS/GEM	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2002	ABS/TCS/GEM	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2003	ABS/TCS/GEM	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2004	GEM	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2005	GEM	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2006	GEM	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2007	GEM	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2008	GEM / SJB	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2009	GEM / SJB	√	√	√	○	
F-650	7.2 L	Caterpillar Diesel	2010	GEM / SJB	√	√	√	○	
F-750	5.9 L	Cummins Diesel	2000	ABS/TCS/GEM	√	√	√	○	
F-750	5.9 L	Cummins Diesel	2001	ABS/TCS/GEM	√	√	√	○	
F-750	5.9 L	Cummins Diesel	2002	ABS/TCS/GEM	√	√	√	○	
F-750	5.9 L	Cummins Diesel	2003	ABS/TCS/GEM	√	√	√	○	
F-750	5.9 L	Cummins Diesel	2004	GEM	√	√	√	○	
F-750	5.9 L	Cummins Diesel	2005	GEM	√	√	√	○	
F-750	5.9 L	Cummins Diesel	2006	GEM	√	√	√	○	
F-750	5.9 L	Cummins Diesel	2007	GEM	√	√	√	○	
F-750	6.7 L	Cummins Diesel	2008	GEM / SJB	√	√	√	○	
F-750	6.7 L	Cummins Diesel	2009	GEM / SJB	√	√	√	○	
F-750	6.7 L	Cummins Diesel	2010	GEM / SJB	√	√	√	○	
F-750	6.7 L	Cummins Diesel	2011	ACM/GEM / SJB/HVAC/IPC	√	√	√	○	
F-750	6.7 L	Cummins Diesel	2015	ACM/APIM/HVAC/IPC/GEM / SJB	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2000	ABS/TCS/GEM	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2001	ABS/TCS/GEM	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2002	ABS/TCS/GEM	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2003	ABS/TCS/GEM	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2004	GEM	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2005	GEM	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2006	GEM	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2007	GEM	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2008	GEM / SJB	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2009	GEM / SJB	√	√	√	○	
F-750	7.2 L	Caterpillar Diesel	2010	GEM / SJB	√	√	√	○	
F350/4000	3.9L	Cummins Diesel	2009	4X4/GEM/TBM	√	√	√	○	
Festiva	1.3 L	B3	2000	ABS/TCS/PCM5	√	√	√	○	
Freda	2.0 L	FE	1999	PCM/TCM	√	√	√	○	
Freda	2.0 L	FE	2002	PCM/TCM	√	√	√	○	
Freda	2.5 L	J5	1999	PCM/TCM	√	√	√	○	
Freda	2.5 L	WL T	1999	PCM/TCM	√	√	√	○	
Ka	1.2 L	Duratec_8V	2009	ABS/BCMii/CTMii/EATC/EPS/IPC/PAM/PCM/RCM/CTMii	√	√	√	○	
Ka	1.3 L	Duratorq Turbo Diesel Common Rail Injection	2009	ABS/BCMii/CTMii/EPS/IPC/PAM/PCM/RCM/CTMii	√	√	√	○	
Kuga	1.5 L	Gas Turbocharged Direct Injection	2013	ABS/ACM/AHCM/APIM/BCMii/C-CM/DDM/FCDIM/FCIM/FDSM/GPSM/HCM/HVAC/IC/IPM-A/PAM/PCM/PDM/PSCM/RCM/RFA/RGTM/SASM/SOD-L/SOD-R/TRM	√	√	√	○	
Mondeo	2.0 L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS/AHCM/BEM/C-CM/CMR/DDM/DSM/HCM/HVAC/IPC/IPM-A/PAM/PBM/PCM/PDM/PSCM/RCM/RFA/RGTM/RHVAC/SASM/SRM/SOD-L/SOD-R/TCM/TRM/VDM	√	√	√	○	
Probe	2.5 L	KL	1996	PCM	√	√	√	○	
Probe	2.5 L	KL	1997	PCM	√	√	√	○	
Ranger	2.6 L	G6	2007	ABS/TCS/PCM/RCM	√	√	√	○	
Ranger	2.8 L	Other	2001	4X4/ABS/TCS/GEM/PCM/RAP/RCM	√	√	√	○	
Scorpio	1.8 L	F8	2002	ABS/TCS/PCM/TCM	√	√	√	○	
Transit	2.2 L	Duratorq Turbo Diesel Common Rail Injection	2012	ABS/ACM/AHCM/APIM/BEM/C-CM/FCDIM/GPSM/HCM/IPC/IPM-A/IPM-B/PAM/PCM/RBM/RCM/SASM/TBC/TRM	√	√	√	○	
Windstar	3.8 L	V6 OHV(Overhead Valve)	1995	ABS/TCS/GEM/PCM	√	√	√	○	
i-MAX	1.8 L	L8	2007	ABS/HIM/EPS/IC/LPSDM/PCM/RCM/RKE/RPSDM/TCM	√	√	√	○	
Bongo Frie	2.0 L	FE	1999	PCM/TCM	√	√	√	○	
Bongo Frie	2.0 L	FE	2002	PCM/TCM	√	√	√	○	
Bongo Frie	2.5 L	J5	1999	PCM/TCM	√	√	√	○	
Bongo Frie	2.5 L	WL T	1999	PCM/TCM	√	√	√	○	
BT-50	2.6 L	G6	2007	ABS/TCS/PCM/RCM	√	√	√	○	
Mazda5	1.8 L	L8	2007	ABS/HIM/EPS/IC/LPSDM/PCM/RCM/RKE/RPSDM/TCM	√	√	√	○	
MX-6	2.5 L	KL	1996	PCM	√	√	√	○	
MX-6	2.5 L	KL	1997	PCM	√	√	√	○	
B-Series	2.8 L	Other	2001	4X4/ABS/TCS/GEM/PCM/RAP/RCM	√	√	√	○	