



Function List

AutoMaker:MAN

NOTES: ✓ This function is supported. ○ This function is not supported. ✖ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle Type	Year	System Name	Bou Info.	Read Codes	Erase Codes	Live Data	Freeze Frame	Actuator	Special Function
UX/UY/UZ - TGE 2017>	2017 (H)	Engine electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Transmission electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Brake Electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Climate Control Module	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Electronic central electric	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Distance regulation	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Airbag	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Steering column electronics system	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Instrument cluster	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Auxiliary/parking heating	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Data Bus OBD Interface	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	All-wheel drive electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Lane change assistance	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Special function	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Driver's door electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Power Steering	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Electric drive	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Passenger's door electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Information electronics 1	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Trip recorder	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Pressure Monitoring System (TPMS)	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Trailer function	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Rear view camera system	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Emergency call module and communication	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Parking aid	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Hybrid battery management	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Driver's side door electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Passenger's side door electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	High-voltage battery charging management	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Actuator for exterior noise	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Thermal management	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	High-voltage battery charger	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Light control left 2	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Light control right 2	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Auxiliary air heating 2	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Airbag 2	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	LED Headlamp Power Output Station	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	LED Headlamp Power Output Station	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Battery Monitoring Control Module	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Battery interrupt switch	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Cell module control module 1	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Cell module control module 2	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Cell module control module 3	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Cell module control module 4	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Cell module control module 5	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Cell module control module 6	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Cell module control module 7	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2017 (H)	Cell module control module 8	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Engine electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Transmission electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Brake Electronics	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Climate Control Module	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Electronic central electric	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Distance regulation	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Airbag	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Steering column electronics system	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Instrument cluster	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Auxiliary/parking heating	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (I)	Data Bus OBD Interface	✓	✓	✓	✓	✓	✖	0001 0002 0003 0004 0006 0009

UX/UY/UZ - TGE 2017>	2018 (J)	All-wheel drive electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Lane change assistance	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Special function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Driver's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Power Steering	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Electric drive	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Passenger's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Information electronics 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Trip recorder	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Pressure Monitoring System (TP	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Trailer function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Rear view camera system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	ncy call module and communicat	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Parking aid	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Hybrid battery management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	it sensor for drivers assistant syst	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Rear drivers side door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	ear passenger side door electroni	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	voltage battery charging manage	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Actuator for exterior noise	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Thermal management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	High-voltage battery charger	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Light control left 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Light control right 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Auxiliary air heating 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Airbag 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	LED Headlamp Power Output Sta	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	: LED Headlamp Power Output St.	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	attery Monitoring Control Modul	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Battery interrupt switch	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Cell module control module 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Cell module control module 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Cell module control module 3	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Cell module control module 4	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Cell module control module 5	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Cell module control module 6	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Cell module control module 7	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2018 (J)	Cell module control module 8	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Engine electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Transmission electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Brake Electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Climate Control Module	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Electronic central electric	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Distance regulation	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Airbag	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	teering column electronics system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	instrument cluster	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Auxiliary/parking heating	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Data Bus OBD Interface	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	All-wheel drive electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Lane change assistance	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Special function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Driver's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Power Steering	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Electric drive	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Passenger's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Information electronics 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Trip recorder	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Pressure Monitoring System (TP	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Trailer function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Rear view camera system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	ncy call module and communicat	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Parking aid	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Hybrid battery management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	it sensor for drivers assistant syst	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Rear drivers side door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	ear passenger side door electroni	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	voltage battery charging manage	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Actuator for exterior noise	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Thermal management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	High-voltage battery charger	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009

UX/UY/UZ - TGE 2017>	2019 (K)	Light control left 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Light control right 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Auxiliary air heating 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Airbag 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	LED Headlamp Power Output Sta	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	: LED Headlamp Power Output St	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	attery Monitoring Control Modul	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Battery interrupt switch	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Cell module control module 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Cell module control module 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Cell module control module 3	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Cell module control module 4	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Cell module control module 5	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Cell module control module 6	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Cell module control module 7	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2019 (K)	Cell module control module 8	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Engine electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Transmission electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Brake Electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Climate Control Module	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Electronic central electric	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Distance regulation	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Airbag	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	teering column electronics system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	instrument cluster	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Auxiliary/parking heating	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Data Bus OBD Interface	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	All-wheel drive electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Lane change assistance	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Special function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Driver's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Power Steering	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Electric drive	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Passenger's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Information electronics 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Trip recorder	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	: Pressure Monitoring System (TP	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Trailer function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Rear view camera system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	ncy call module and communicat	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Parking aid	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Hybrid battery management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	it sensor for drivers assistant syst	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Rear drivers side door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	ear passenger side door electroni	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	voltage battery charging manage	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Actuator for exterior noise	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Thermal management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	High-voltage battery charger	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Light control left 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Light control right 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Auxiliary air heating 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Airbag 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	LED Headlamp Power Output Sta	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	: LED Headlamp Power Output St	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	attery Monitoring Control Modul	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Battery interrupt switch	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Cell module control module 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Cell module control module 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Cell module control module 3	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Cell module control module 4	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Cell module control module 5	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Cell module control module 6	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Cell module control module 7	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2020 (L)	Cell module control module 8	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Engine electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Transmission electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Brake Electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Climate Control Module	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Electronic central electric	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Distance regulation	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009

UX/UY/UZ - TGE 2017>	2021 (M)	Airbag	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Steering column electronics system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Instrument cluster	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Auxiliary/parking heating	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Data Bus OBD Interface	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	All-wheel drive electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Lane change assistance	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Special function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Driver's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Power Steering	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Electric drive	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Passenger's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Information electronics 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Trip recorder	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Pressure Monitoring System (TPMS)	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Trailer function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Rear view camera system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Body control module and communication	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Parking aid	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Hybrid battery management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Seat sensor for driver's assistant system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Rear driver's side door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Front passenger side door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	High-voltage battery charging management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Actuator for exterior noise	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Thermal management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	High-voltage battery charger	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Light control left 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Light control right 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Auxiliary air heating 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Airbag 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	LED Headlamp Power Output Stage	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	LED Headlamp Power Output Stage	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Battery Monitoring Control Module	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Battery interrupt switch	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Cell module control module 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Cell module control module 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Cell module control module 3	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Cell module control module 4	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Cell module control module 5	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Cell module control module 6	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Cell module control module 7	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2021 (M)	Cell module control module 8	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Engine electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Transmission electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Brake Electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Climate Control Module	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Electronic central electric	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Distance regulation	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Airbag	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Steering column electronics system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Instrument cluster	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Auxiliary/parking heating	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Data Bus OBD Interface	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	All-wheel drive electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Lane change assistance	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Special function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Driver's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Power Steering	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Electric drive	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Passenger's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Information electronics 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Trip recorder	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Pressure Monitoring System (TPMS)	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Trailer function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Rear view camera system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Body control module and communication	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Parking aid	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Hybrid battery management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Seat sensor for driver's assistant system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Rear driver's side door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009

UX/UY/UZ - TGE 2017>	2022 (N)	ear passenger side door electroni	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	voltage battery charging manage	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Actuator for exterior noise	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Thermal management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	High-voltage battery charger	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Light control left 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Light control right 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Auxiliary air heating 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Airbag 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	LED Headlamp Power Output Sta	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	: LED Headlamp Power Output St:	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	attery Monitoring Control Modul	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Battery interrupt switch	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Cell module control module 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Cell module control module 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Cell module control module 3	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Cell module control module 4	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Cell module control module 5	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Cell module control module 6	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Cell module control module 7	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2022 (N)	Cell module control module 8	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Engine electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Transmission electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Brake Electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Climate Control Module	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Electronic central electric	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Distance regulation	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Airbag	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	teering column electronics system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	instrument cluster	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Auxiliary/parking heating	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Data Bus OBD Interface	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	All-wheel drive electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Lane change assistance	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Special function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Driver's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Power Steering	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Electric drive	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Passenger's door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Information electronics 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Trip recorder	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	: Pressure Monitoring System (TP	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Trailer function	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Rear view camera system	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	ncy call module and communicat	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Parking aid	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Hybrid battery management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	it sensor for drivers assistant syst	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Rear drivers side door electronics	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	ear passenger side door electroni	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	voltage battery charging manage	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Actuator for exterior noise	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Thermal management	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	High-voltage battery charger	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Light control left 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Light control right 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Auxiliary air heating 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Airbag 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	LED Headlamp Power Output Sta	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	: LED Headlamp Power Output St:	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	attery Monitoring Control Modul	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Battery interrupt switch	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Cell module control module 1	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Cell module control module 2	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Cell module control module 3	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Cell module control module 4	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Cell module control module 5	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Cell module control module 6	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Cell module control module 7	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009
UX/UY/UZ - TGE 2017>	2023 (P)	Cell module control module 8	V	V	V	V	V	※	0001 0002 0003 0004 0006 0009

Function List			
Index	Special Function Name	Index	Special Function Name
0001	Coding	0002	Basic Settings
0003	Adaptation	0004	Security Access
0005	AdvancedDataStream	0006	Single Reading
0007	Login CodingII	0008	Readiness
0009	Advanced ID	000A	OilReset
000B	EPB		