



Function List

AutoMaker:Porsche

NOTES:

- √ This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Model Menu	System Menu	ECU Information	Read Codes	Erase Codes	Live Data	Active Test	Special functions
Cayenne(9PA up to MY 2010)	DME	√	√	√	√	√	0000,0005,0006,0007,0008,0009,0010
Cayenne(9PA up to MY 2010)	Tiptronic	√	√	√	√	○	0000,0011,0012
Cayenne(9PA up to MY 2010)	Airbag	√	√	√	√	√	0013,0014
Cayenne(9PA up to MY 2010)	TPM	√	√	√	√	○	0000,0015,0016,0017,0018
Cayenne(9PA up to MY 2010)	AHK	√	√	√	√	√	0000
Cayenne(9PA up to MY 2010)	Air Conditioning	√	√	√	√	√	0000,0019,0020
Cayenne(9PA up to MY 2010)	AWS	√	√	√	○	○	0021,0022
Cayenne(9PA up to MY 2010)	Gateway	√	√	√	√	○	0000,0021,0023,0024,0025,0026,0027,0028,0029
Cayenne(9PA up to MY 2010)	Auxiliary Heater	√	√	√	√	√	0000,0030
Cayenne(9PA up to MY 2010)	Headlight CU left	√	√	√	√	√	0031,0032,0021,0022
Cayenne(9PA up to MY 2010)	Headlight CU right	√	√	√	√	√	0031,0032,0021
Cayenne(9PA up to MY 2010)	Instrument Cluster	√	√	√	√	√	0033,0034,0035,0036,0037
Cayenne(9PA up to MY 2010)	Left HBA	√	√	√	√	√	0000,0022
Cayenne(9PA up to MY 2010)	Level Control	√	√	√	√	√	0000,0038,0039,0040,0041,0042,0043,0020
Cayenne(9PA up to MY 2010)	Mag.Field Sensor	√	√	√	√	○	○
Cayenne(9PA up to MY 2010)	New HBA	√	○	○	○	○	0000
Cayenne(9PA up to MY 2010)	Kessy	√	√	√	√	√	○
Cayenne(9PA up to MY 2010)	Panorama Roof	√	√	√	√	○	○
Cayenne(9PA up to MY 2010)	Park Assistant	√	√	√	√	√	0000
Cayenne(9PA up to MY 2010)	PDCC/ORS	√	√	√	√	√	0000,0021,0022
Cayenne(9PA up to MY 2010)	PSM	√	√	√	√	√	0000,0044,0045,0046,0047,0048
Cayenne(9PA up to MY 2010)	Rear/Doors	√	√	√	√	√	0049,0050,0012
Cayenne(9PA up to MY 2010)	Right HBA	√	√	√	√	√	0000,0022
Cayenne(9PA up to MY 2010)	Seat Memory,Driver	√	√	√	√	○	0000,0051,0052
Cayenne(9PA up to MY 2010)	Seat Memory,Passenger	√	√	√	√	○	0000
Cayenne(9PA up to MY 2010)	Steering Col. Switch	√	√	√	√	√	0000,0053
Cayenne(9PA up to MY 2010)	Tailgate	√	√	√	√	√	0022,0012
Cayenne(9PA up to MY 2010)	Transfer Case	√	√	√	√	○	○
Cayenne(9PA up to MY 2010)	Transverse Lock	√	√	√	√	○	○
Cayenne(9PA up to MY 2010)	VEH.ELECTRICAL SYS.	√	√	√	√	√	0000,0014
Cayenne(9PA up to MY 2010)	Wiper	√	√	√	√	√	○
Cayenne(92A from MY 2011)	DME	√	√	√	√	√	0054,0055,0056,0057,0058,0059,0060
Cayenne(92A from MY 2011)	Tiptronic transmission control	√	√	√	√	√	○
Cayenne(92A from MY 2011)	PSM	√	√	√	√	√	0061,0062,0063,0064,0065,0066
Cayenne(92A from MY 2011)	Airbag	√	√	√	√	√	0067,0068
Cayenne(92A from MY 2011)	Instrument cluster	√	√	√	√	√	0069,0070,0071,0072,0073
Cayenne(92A from MY 2011)	Parking Brake	√	√	√	√	√	0074,0075,0076,0077
Cayenne(92A from MY 2011)	Tire Pressure Monitoring System	√	√	√	√	√	0078,0079
Cayenne(92A from MY 2011)	A/C compressor	√	√	√	√	√	○
Cayenne(92A from MY 2011)	Adaptive cruise control	√	√	√	√	√	0080
Cayenne(92A from MY 2011)	Additional compass instrument	√	√	√	√	√	○
Cayenne(92A from MY 2011)	Additional instrument-watch	√	√	√	√	√	○
Cayenne(92A from MY 2011)	Air conditioner	√	√	√	√	√	0081,0082
Cayenne(92A from MY 2011)	All-wheel drive	√	√	√	√	√	0083
Cayenne(92A from MY 2011)	Auxiliary heating	√	√	√	√	√	○
Cayenne(92A from MY 2011)	Driver's Door	√	√	√	√	√	0084
Cayenne(92A from MY 2011)	Driver-side seat memory	√	√	√	√	√	0085
Cayenne(92A from MY 2011)	External amplifier	√	√	√	√	√	○
Cayenne(92A from MY 2011)	Front-end electronics	√	√	√	√	√	0086,0087,0088,0089,0090
Cayenne(92A from MY 2011)	Gateway	√	√	√	√	√	0091,0092
Cayenne(92A from MY 2011)	High-voltage battery	√	√	√	√	√	0093,0094
Cayenne(92A from MY 2011)	High-voltage power electronics	√	√	√	√	√	○
Cayenne(92A from MY 2011)	Lane Change Assistant	√	√	√	√	√	○
Cayenne(92A from MY 2011)	Left headlight	√	√	√	√	√	0095
Cayenne(92A from MY 2011)	Level control/PASM	√	√	√	√	√	0096,0097,0098,0099,0100,0101,0102
Cayenne(92A from MY 2011)	Park Assist	√	√	√	√	√	○
Cayenne(92A from MY 2011)	Passenger's Door	√	√	√	√	√	0084
Cayenne(92A from MY 2011)	Passenger-side seat memory	√	√	√	√	√	0085
Cayenne(92A from MY 2011)	PCM/CDR	√	√	√	√	√	0103,0104,0105,0106,0107
Cayenne(92A from MY 2011)	PDCC	√	√	√	√	√	0108,0109
Cayenne(92A from MY 2011)	Rear lid	√	√	√	√	√	0076
Cayenne(92A from MY 2011)	Rear-end electronics	√	√	√	√	√	0110,0111,0112,0113
Cayenne(92A from MY 2011)	Rear differential lock	√	√	√	√	○	○
Cayenne(92A from MY 2011)	Rear left door	√	√	√	√	√	0084
Cayenne(92A from MY 2011)	Rear right door	√	√	√	√	√	0084
Cayenne(92A from MY 2011)	Reversing camera	√	√	√	√	√	○
Cayenne(92A from MY 2011)	Right headlight	√	√	√	√	√	0095,0114

Cayenne(92A from MY 2011)	Steering aid	✓	✓	✓	✓	✓	□
Cayenne(92A from MY 2011)	Steering wheel electronics	✓	✓	✓	✓	✓	0115,0106
Cayenne(92A from MY 2011)	Trailer hitch	✓	✓	✓	✓	✓	□
Cayenne(92A from MY 2011)	TV tuner	✓	✓	✓	✓	✓	□
Cayenne(92A from MY 2011)	Front camera	✓	✓	✓	✓	✓	0116
Cayenne(92A from MY 2011)	Emergency call system	✓	✓	✓	✓	✓	□
Boxster(987)	DME	✓	✓	✓	✓	✓	0000,0009,0005,0008,0010,0006,0117,0007,0118,0119,0120
Boxster(987)	AWS	✓	✓	✓	✓	✓	0000
Boxster(987)	Air Conditioning	✓	✓	✓	✓	✓	0012,0017
Boxster(987)	TPM	✓	✓	✓	✓	□	0000,0012,0018,0121,0015
Boxster(987)	Instrument Cluster	✓	✓	✓	✓	✓	0122,0123,0124,0125,0126,0127,0128,0129,0034,0130
Boxster(987)	Gateway	✓	✓	✓	✓	✓	0000,0012,0023,0024,0131
Boxster(987)	Chronometer	✓	✓	✓	✓	✓	0012
Boxster(987)	Cornering Light	✓	✓	✓	✓	✓	0000,0022
Boxster(987)	Driver's Door	✓	✓	✓	✓	✓	0000,0012
Boxster(987)	Front	✓	✓	✓	✓	✓	0000,0012,0022
Boxster(987)	Park Assistant	✓	✓	✓	✓	✓	0000,0012
Boxster(987)	PAS	✓	✓	✓	✓	□	0000,0012,0132,0133
Boxster(987)	PASM	✓	✓	✓	✓	✓	0012
Boxster(987)	Passenger's Door	✓	✓	✓	✓	✓	0000,0012
Boxster(987)	PCM	✓	✓	✓	✓	✓	□
Boxster(987)	PDK Selector Lever	✓	✓	✓	□	✓	0134
Boxster(987)	PDK(Tiptronic)	✓	✓	✓	✓	✓	0000,0012,0135,0136
Boxster(987)	POSIP	✓	✓	✓	✓	✓	0000,0012
Boxster(987)	PSM	✓	✓	✓	✓	✓	0000,0012,0137,0138,0139,0140,0141,0142,0143
Boxster(987)	Rear	✓	✓	✓	✓	✓	0000,0012,0144,0145
Boxster(987)	Seat Memory	✓	✓	✓	✓	✓	0000,0012
Boxster(987)	Steering Col. Switch	✓	✓	✓	✓	✓	0000,0012
Boxster(987)	VEHELECTRICAL SYS.	✓	✓	✓	✓	✓	0000,0012
Boxster(987)	BOSE amplifier,external	✓	✓	✓	✓	□	□
Boxster(987)	CD autochanger	✓	✓	✓	□	□	□
Boxster(987)	Navigation	✓	✓	✓	✓	✓	□
Boxster(987)	Telephone	✓	✓	✓	✓	□	□
Boxster(987)	TV tuner	✓	✓	✓	✓	✓	□
Boxster(987)	PCM2 MMI	✓	✓	✓	✓	✓	□
Cayman/Boxster(986)	DME	✓	✓	✓	✓	✓	□
Cayman/Boxster(986)	Automatic Transmission-Tiptronic	✓	✓	✓	✓	✓	□
Cayman/Boxster(986)	ABS	✓	✓	✓	✓	□	□
Cayman/Boxster(986)	Air conditioning	✓	✓	✓	✓	✓	□
Cayman/Boxster(986)	Airbag	✓	✓	✓	✓	□	□
Cayman/Boxster(986)	Alarm system	✓	✓	✓	□	□	□
Cayman/Boxster(986)	Instrument cluster	✓	✓	✓	✓	✓	0001,0002,0003,0004
Cayman/Boxster(986)	Park Assistant	✓	✓	✓	✓	✓	□
Cayman/Boxster(986)	Seat Memory	✓	✓	✓	✓	✓	□
Cayman/Boxster(986)	HBA	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	DME	✓	✓	✓	✓	✓	0146,0147,0148,0149,0150,0151
Boxster/Cayman(981)	Transmission control	✓	✓	✓	✓	✓	0152,0153,0154
Boxster/Cayman(981)	PSM	✓	✓	✓	✓	✓	0061,0155,0066,0156,0157
Boxster/Cayman(981)	Airbag	✓	✓	✓	✓	✓	0158
Boxster/Cayman(981)	Instrument cluster	✓	✓	✓	✓	✓	0070,0159,0160,0071
Boxster/Cayman(981)	Parking brake	✓	✓	✓	✓	✓	0076,0074,0077
Boxster/Cayman(981)	Tyre pressure monitoring	✓	✓	✓	✓	✓	0079
Boxster/Cayman(981)	Gateway	✓	✓	✓	✓	✓	0091,0092
Boxster/Cayman(981)	Selector lever	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	Steering wheel electronics	✓	✓	✓	✓	✓	0115,0161
Boxster/Cayman(981)	Additional instrument-clock	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	PCM/CDR	✓	✓	✓	✓	✓	0161,0162
Boxster/Cayman(981)	TV tuner	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	External amplifier	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	Air conditioning	✓	✓	✓	✓	✓	0163,0164
Boxster/Cayman(981)	Park Assist	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	PASM	✓	✓	✓	✓	✓	0076,0165
Boxster/Cayman(981)	Power steering	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	Convertible top	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	Front-end electronics	✓	✓	✓	✓	✓	0166,0167,0088,0089,0090
Boxster/Cayman(981)	Rear-end electronics	✓	✓	✓	✓	✓	0113,0168
Boxster/Cayman(981)	Left headlight	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	headlight,right	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	Driver-side seat memory	✓	✓	✓	✓	✓	0085
Boxster/Cayman(981)	Passenger-side seat memory	✓	✓	✓	✓	✓	0085
Boxster/Cayman(981)	Driver's Door	✓	✓	✓	✓	✓	0084
Boxster/Cayman(981)	Passenger's Door	✓	✓	✓	✓	✓	0084
Boxster/Cayman(981)	Adaptive cruise control(ACC)	✓	✓	✓	✓	✓	0080
Boxster/Cayman(981)	Front camera	✓	✓	✓	✓	✓	□
Boxster/Cayman(981)	Reversing camera	✓	✓	✓	✓	✓	□
Cayman(987)	DME	✓	✓	✓	✓	✓	0000,0009,0005,0008,0010,0006,0117,0007,0118,0119,0120
Cayman(987)	AWS	✓	✓	✓	✓	✓	0000
Cayman(987)	Air Conditioning	✓	✓	✓	✓	✓	0012,0017
Cayman(987)	Instrument Cluster	✓	✓	✓	✓	✓	0122,0123,0124,0125,0126,0127,0128,0129,0034,0130
Cayman(987)	Gateway	✓	✓	✓	✓	✓	0000,0012,0023,0024,0131

Cayman(987)	Chronometer	✓	✓	✓	✓	✓	0012
Cayman(987)	Cornering Light	✓	✓	✓	✓	✓	0000,0022
Cayman(987)	Driver's Door	✓	✓	✓	✓	✓	0000,0012
Cayman(987)	Front	✓	✓	✓	✓	✓	0000,0012,0022
Cayman(987)	Park Assistant	✓	✓	✓	✓	✓	0000,0012
Cayman(987)	PAS	✓	✓	✓	✓	□	0000,0012,0132,0133
Cayman(987)	PASM	✓	✓	✓	✓	✓	0012
Cayman(987)	Passenger's Door	✓	✓	✓	✓	✓	0000,0012
Cayman(987)	PCM	✓	✓	✓	✓	✓	□
Cayman(987)	PDK Selector Lever	✓	✓	✓	□	✓	0134
Cayman(987)	PDK(Tiptronic)	✓	✓	✓	✓	✓	0000,0012,0135,0136
Cayman(987)	POSIP	✓	✓	✓	✓	✓	0000,0012
Cayman(987)	PSM	✓	✓	✓	✓	✓	0000,0012,0137,0138,0139,0140,0141,0142,0143
Cayman(987)	Rear	✓	✓	✓	✓	✓	0000,0012,0144,0145
Cayman(987)	Seat Memory	✓	✓	✓	✓	✓	0000,0012
Cayman(987)	Steering Col. Switch	✓	✓	✓	✓	✓	0000,0012
Cayman(987)	TPM	✓	✓	✓	✓	□	0000,0012,0018,0121,0015
Cayman(987)	VEH.ELECTRICAL SYS.	✓	✓	✓	✓	✓	0000,0012
Cayman(987)	BOSE amplifier,external	✓	✓	✓	✓	□	□
Cayman(987)	CD autochanger	✓	✓	✓	□	□	□
Cayman(987)	Navigation	✓	✓	✓	✓	✓	□
Cayman(987)	Telephone	✓	✓	✓	✓	□	□
Cayman(987)	TV tuner	✓	✓	✓	✓	✓	□
Cayman(987)	PCM2_MMI	✓	✓	✓	✓	✓	□
911(997)	DME	✓	✓	✓	✓	✓	0000,0009,0005,0008,0010,0006,0117,0007,0118,0119,0120
911(997)	PDK(Tiptronic)	✓	✓	✓	✓	✓	0000,0012,0135,0136
911(997)	PDK Selector Lever	✓	✓	✓	□	✓	0134
911(997)	PSM	✓	✓	✓	✓	✓	0000,0012,0137,0138,0139,0140,0141,0142,0143
911(997)	PAS	✓	✓	✓	✓	□	0000,0012,0132,0133
911(997)	Instrument Cluster	✓	✓	✓	✓	✓	0122,0123,0124,0125,0126,0127,0128,0129,0034,0130
911(997)	Gateway	✓	✓	✓	✓	✓	0000,0012,0023,0024,0131
911(997)	Air Conditioning	✓	✓	✓	✓	✓	0012,0017
911(997)	AWS	✓	✓	✓	✓	✓	0000
911(997)	BOSE amplifier,external	✓	✓	✓	✓	□	□
911(997)	CD autochanger	✓	✓	✓	□	□	□
911(997)	Navigation	✓	✓	✓	✓	✓	□
911(997)	Telephone	✓	✓	✓	✓	□	□
911(997)	TV tuner	✓	✓	✓	✓	✓	□
911(997)	PCM2_MMI	✓	✓	✓	✓	✓	□
911(997)	Chronometer	✓	✓	✓	✓	✓	0012
911(997)	Convertible Top	✓	✓	✓	✓	✓	0000,0012,0022
911(997)	Cornering Light	✓	✓	✓	✓	✓	0000,0022
911(997)	Driver's Door	✓	✓	✓	✓	✓	0000,0012
911(997)	Front	✓	✓	✓	✓	✓	0000,0012,0022
911(997)	Park Assistant	✓	✓	✓	✓	✓	0000,0012
911(997)	PASM	✓	✓	✓	✓	✓	0012
911(997)	Passenger's Door	✓	✓	✓	✓	✓	0000,0012
911(997)	PCM	✓	✓	✓	✓	✓	□
911(997)	POSIP	✓	✓	✓	✓	✓	0000,0012
911(997)	PTM	✓	✓	✓	✓	✓	0000,0012
911(997)	Rear	✓	✓	✓	✓	✓	0000,0012,0144,0145
911(997)	Seat Memory	✓	✓	✓	✓	✓	0000,0012
911(997)	Steering Col. Switch	✓	✓	✓	✓	✓	0000,0012
911(997)	Targa Roof	✓	✓	✓	✓	✓	0000
911(997)	TPM	✓	✓	✓	✓	□	0000,0012,0018,0121,0015
911(997)	Unit Support	✓	✓	✓	✓	✓	0000
911(997)	VEH.ELECTRICAL SYS.	✓	✓	✓	✓	✓	0000,0012
911(996)	DME	✓	✓	✓	✓	✓	□
911(996)	Automatic Transmission-Tiptronic	✓	✓	✓	✓	✓	□
911(996)	ABS	✓	✓	✓	✓	□	□
911(996)	Alarm system	✓	✓	✓	✓	✓	0169,0170,0171,0172,0173,0174,0175,0176,0177
911(996)	Airbag	✓	✓	✓	✓	□	□
911(996)	Air conditioning	✓	✓	✓	✓	✓	□
911(996)	Instrument cluster	✓	✓	✓	✓	✓	0001,0002,0003
911(996)	Seat Memory	✓	✓	✓	✓	✓	□
911(996)	Park Assistant	✓	✓	✓	✓	✓	□
911(996)	Convertible top	✓	✓	✓	✓	✓	□
911(996)	Roll-over protection	✓	✓	✓	✓	□	□
911(996)	HBA	✓	✓	✓	✓	✓	□
911(991)	DME	✓	✓	✓	✓	✓	0146,0147,0148,0149,0150,0151
911(991)	Transmission control	✓	✓	✓	✓	✓	0152,0153,0154
911(991)	PSM	✓	✓	✓	✓	✓	0061,0155,0066,0156,0157
911(991)	Airbag	✓	✓	✓	✓	✓	0158
911(991)	Instrument cluster	✓	✓	✓	✓	✓	0070,0159,0160,0071
911(991)	Parking brake	✓	✓	✓	✓	✓	0076,0074,0077
911(991)	TPM	✓	✓	✓	✓	✓	0079
911(991)	Gateway	✓	✓	✓	✓	✓	0091,0092
911(991)	Selector lever	✓	✓	✓	✓	✓	□
911(991)	Steering wheel electronics	✓	✓	✓	✓	✓	0115,0161
911(991)	Additional instrument-clock	✓	✓	✓	✓	✓	□
911(991)	PCM/CDR	✓	✓	✓	✓	✓	0161,0162
911(991)	TV tuner	✓	✓	✓	✓	✓	□

911(991)	External amplifier	✓	✓	✓	✓	✓	□
911(991)	Air conditioning	✓	✓	✓	✓	✓	0163,0164
911(991)	Park Assist	✓	✓	✓	✓	✓	□
911(991)	PASM	✓	✓	✓	✓	✓	0076,0165
911(991)	PDCC	✓	✓	✓	✓	✓	0108,0109
911(991)	EPS(power steering)	✓	✓	✓	✓	✓	□
911(991)	Front-end electronics	✓	✓	✓	✓	✓	0166,0167,0088,0089,0090
911(991)	Rear-end electronics	✓	✓	✓	✓	✓	0113,0168
911(991)	Left headlight	✓	✓	✓	✓	✓	□
911(991)	Right headlight	✓	✓	✓	✓	✓	□
911(991)	Driver-side seat memory	✓	✓	✓	✓	✓	0085
911(991)	Passenger-side seat memory	✓	✓	✓	✓	✓	0085
911(991)	Driver's Door	✓	✓	✓	✓	✓	0084
911(991)	Passenger's Door	✓	✓	✓	✓	✓	0084
911(991)	Rear left door	✓	✓	✓	✓	✓	□
911(991)	Rear right door	✓	✓	✓	✓	✓	□
911(991)	Convertible top	✓	✓	✓	✓	✓	□
911(991)	Adaptive cruise control(ACC)	✓	✓	✓	✓	✓	0080
911(991)	Front camera	✓	✓	✓	✓	✓	□
911(991)	Reversing camera	✓	✓	✓	✓	✓	□
911(991)	Porsche Traction Management(PTM)	✓	✓	✓	✓	✓	0178
911(991)	Rear-axle steering, left	✓	✓	✓	✓	✓	□
911(991)	Rear-axle steering, right	✓	✓	✓	✓	✓	□
911(991)	Front-axle lift	✓	✓	✓	✓	✓	□
Panamera	DME	✓	✓	✓	✓	✓	0146,0148,0147,0153,0151,0150,0149
Panamera	Transmission control	✓	✓	✓	✓	✓	
Panamera	PSM	✓	✓	✓	✓	✓	0061,0155,0157,0179,0066
Panamera	Airbag	✓	✓	✓	✓	✓	□
Panamera	Instrument cluster	✓	✓	✓	✓	✓	0070,0069,0071,0072,0073
Panamera	Parking brake	✓	✓	✓	✓	✓	0074,0075,0076,0077
Panamera	Tire Pressure Monitoring System	✓	✓	✓	✓	✓	0079,0010
Panamera	A/C compressor	✓	✓	✓	✓	✓	□
Panamera	Adaptive cruise control	✓	✓	✓	✓	✓	0080
Panamera	Air conditioner	✓	✓	✓	✓	✓	0081,0082
Panamera	Auxiliary heating	✓	✓	✓	✓	✓	□
Panamera	Driver's Door	✓	✓	✓	✓	✓	□
Panamera	Driver-side seat memory	✓	✓	✓	✓	✓	0085
Panamera	External amplifier	✓	✓	✓	✓	✓	□
Panamera	Front-end electronics	✓	✓	✓	✓	✓	0180,0087,0181,0182,0088,0089,0090
Panamera	Gateway	✓	✓	✓	✓	✓	0091,0092
Panamera	High-voltage battery	✓	✓	✓	✓	✓	0094,0093
Panamera	High-voltage power electronics	✓	✓	✓	✓	✓	□
Panamera	Lane Change Assist	✓	✓	✓	✓	✓	□
Panamera	Left headlight	✓	✓	✓	✓	✓	□
Panamera	Level control/PASM	✓	✓	✓	✓	✓	0097,0098,0183,0184,0185,0186
Panamera	Park Assist	✓	✓	✓	✓	✓	□
Panamera	Passenger's Door	✓	✓	✓	✓	✓	□
Panamera	Passenger-side seat memory	✓	✓	✓	✓	✓	0085
Panamera	PCM/CDR	✓	✓	✓	✓	✓	0104,0103,0105,0161,0162,0107
Panamera	PDCC	✓	✓	✓	✓	✓	0108,0109
Panamera	Rear left door	✓	✓	✓	✓	✓	□
Panamera	Rear lid	✓	✓	✓	✓	✓	0076
Panamera	Rear right door	✓	✓	✓	✓	✓	□
Panamera	Rear-end electronics	✓	✓	✓	✓	✓	0187,0188
Panamera	Reversing camera	✓	✓	✓	✓	✓	□
Panamera	Right headlight	✓	✓	✓	✓	✓	□
Panamera	Selector lever	✓	✓	✓	✓	✓	□
Panamera	Steering aid	✓	✓	✓	✓	✓	□
Panamera	Steering wheel electronics	✓	✓	✓	✓	✓	0115,0161
Panamera	Additional instrument-clock	✓	✓	✓	✓	✓	□
Panamera	Trailer hitch	✓	✓	✓	✓	✓	□
Panamera	TV tuner	✓	✓	✓	✓	✓	□
Panamera	High-voltage charger	✓	✓	✓	✓	✓	□
Panamera	Front camera	✓	✓	✓	✓	✓	□
Panamera	Rear-differential lock	✓	✓	✓	✓	□	□
Carrera GT	DME	□	✓	✓	□	□	□
Carrera GT	TPM	✓	✓	✓	✓	□	□
Carrera GT	ABS	✓	✓	✓	✓	□	□
Carrera GT	Airbag	✓	✓	✓	✓	□	□
Carrera GT	Air conditioning	✓	✓	✓	✓	□	□
Carrera GT	Instrument cluster	✓	✓	✓	✓	✓	0001,0002,0003
Carrera GT	Alarm system	✓	✓	✓	□	□	□
GT3(996)	DME	✓	✓	✓	✓	✓	□
GT3(996)	ABS 5	✓	✓	✓	✓	□	□
GT3(996)	Airbag	✓	✓	✓	✓	□	□
GT3(996)	Air conditioning	✓	✓	✓	✓	✓	□
GT3(996)	Alarm system	✓	✓	✓	□	□	□
GT3(996)	Instrument cluster	✓	✓	✓	✓	✓	0001,0002,0003
GT3(996)	CDR23	□	✓	✓	□	□	□
GT3(996)	HBA	✓	✓	✓	✓	✓	□
GT2(996)	DME	✓	✓	✓	✓	✓	□
GT2(996)	ABS	✓	✓	✓	✓	□	□
GT2(996)	Airbag	✓	✓	✓	✓	□	□

GT2(996)	Air conditioning	✓	✓	✓	✓	✓	□
GT2(996)	Alarm system	✓	✓	✓	□	□	□
GT2(996)	Instrument cluster	✓	✓	✓	✓	✓	0001,0002,0003
GT2(996)	PCM2	□	✓	✓	□	□	□
GT2(996)	HBA	✓	✓	✓	✓	✓	□
Macan	DME	✓	✓	✓	✓	✓	□
Macan	Transmission control	✓	✓	✓	✓	✓	0189,0190,0191,0192
Macan	PSM	✓	✓	✓	✓	✓	0061,0062,0063,0064,0065,0066
Macan	Airbag	✓	✓	✓	✓	✓	0067,0068
Macan	Instrument cluster	✓	✓	✓	✓	✓	0070,0159,0071
Macan	Parking brake	✓	✓	✓	✓	✓	0193,0194,0077
Macan	Tire Pressure Monitoring System	✓	✓	✓	✓	✓	0079
Macan	Gateway	✓	✓	✓	✓	✓	0091,0092
Macan	Reducing agent system	✓	✓	✓	✓	✓	□
Macan	Steering wheel electronics	✓	✓	✓	✓	✓	0106,0115
Macan	Lane change assist(LCA)	✓	✓	✓	✓	✓	□
Macan	Additional compass instrument	✓	✓	✓	✓	✓	□
Macan	Additional instrument:watch	✓	✓	✓	✓	✓	□
Macan	PCM/CDR	✓	✓	✓	✓	✓	0104,0105,0103,0106
Macan	TV tuner	✓	✓	✓	✓	✓	□
Macan	External amplifier	✓	✓	✓	✓	✓	□
Macan	Air conditioner	✓	✓	✓	✓	✓	0081,0082
Macan	Front camera	✓	✓	✓	✓	✓	□
Macan	Reversing camera	✓	✓	✓	✓	✓	□
Macan	Park Assist	✓	✓	✓	✓	✓	□
Macan	Level control/PASM	✓	✓	✓	✓	✓	0195,0097,0098,0099,0101,0102
Macan	Power steering	✓	✓	✓	✓	✓	0196
Macan	Front-end electronics	✓	✓	✓	✓	✓	0086,0087,0088,0089,0090
Macan	Rear-end electronics	✓	✓	✓	✓	✓	0110
Macan	Headlight(central)	✓	✓	✓	✓	✓	0197,0198,0199,0095
Macan	Driver-side seat memory	✓	✓	✓	✓	✓	0085
Macan	Passenger-side seat memory	✓	✓	✓	✓	✓	0085
Macan	Driver's door	✓	✓	✓	✓	✓	0084
Macan	Passenger's door	✓	✓	✓	✓	✓	0084
Macan	Rear left door	✓	✓	✓	✓	✓	0084
Macan	Rear right door	✓	✓	✓	✓	✓	0084
Macan	Adaptive cruise control(ACC)	✓	✓	✓	✓	✓	0080
Macan	Rear lid	✓	✓	✓	✓	✓	0076
Macan	All-wheel drive	✓	✓	✓	✓	✓	0083
Macan	Rear-differential lock	✓	✓	✓	✓	□	□
Macan	Trailer hitch	✓	✓	✓	✓	✓	□
Macan	Auxiliary water heater	✓	✓	✓	✓	✓	□
Macan	Sound symposer	✓	✓	✓	✓	✓	□
Macan	Emergency call system	✓	✓	✓	✓	✓	□

Special Function

Index	Special Function
0000	Programming
0001	Total Distance
0002	Control unit replacement
0003	Reset tank calibration value
0004	Tank calibration
0005	Engine data
0006	Vehicle data
0007	First start
0008	Short test
0009	Ready status
0010	System adaption
0011	Reset adaption values
0012	Control unit replacement
0013	Lock(rollover)
0014	System adaption
0015	System adaption
0016	Write wheel set
0017	System check
0018	Last identification received
0019	Service position
0020	Calibration
0021	Reset
0022	Calibration
0023	Sleep mode
0024	Single-wire test
0025	Read fault bits
0026	General function routines
0027	Wake-Up guardian
0028	Nominal & Actual configuration
0029	Write values
0030	Teach remote control
0031	Write housing part number
0032	Read operating data
0033	Control unit replacement -- Read Value
0034	Total distance
0035	Milage (km) since last inspection
0036	Time (in days) since last inspection
0037	Maintenance interval
0038	Bleed pressure reservoir
0039	Bleed air springs at front axle
0040	Bleed air springs at rear axle
0041	Fill pressure reservoir
0042	Fill air springs at front axle
0043	Fill air springs at rear axle
0044	Lateral acceleration sensor
0045	Axial acceleration sensor
0046	Pressure sensor

0047	Steering - angle sensor
0048	PSM functional state (static):
0049	Installation list
0050	Parameterization
0051	Large memory package
0052	Small memory package
0053	Control unit replacement
0054	Short tests
0055	Adaptations
0056	System test
0057	Delete adaptation data
0058	Ready status
0059	First start
0060	Oil filling
0061	Bleed the brakes
0062	Hydraulic swap test
0063	Calibrate longitudinal acceleration sensor
0064	Calibrate lateral acceleration sensor
0065	Calibrate pressure sensors
0066	Rolling test mode
0067	Calibrate seat occupancy detection
0068	Lock
0069	Calibrate fuel-level sensor
0070	Set total mileage
0071	Reset maintenance interval
0072	Save fuel level sensor comparison values to Rear-end electronics control unit
0073	Restore fuel level sensor comparison values to Rear-end electronics control unit
0074	Check basic setting of parking-brake
0075	Grinding - in
0076	Calibration
0077	Replace brake pads (operating guide)
0078	Teach wheel sensors
0079	Teach wheel IDs during driving
0080	Adjust adaptive cruise control
0081	Teach-in:LIN automatic addressing
0082	LIN control motors measurement run
0083	Transfer-box oil service
0084	Standardizing power windows
0085	Normalize seat motors
0086	Headlight beam adjustment calibration
0087	Steering column adjustment normalizing run
0088	Version of the key software
0089	Kessy antenna path
0090	Radio central locking antenna path
0091	Actual/specified configuration
0092	Battery change
0093	High-voltage battery charging
0094	Battery classification
0095	Headlight beam adjustment calibration
0096	Filling air suspension system/individual components

0097	Height sensor system component test
0098	Height sensor system calibration
0099	Bleeding of complete air suspension system
0100	Bleeding axle by axle
0101	Bleeding an air spring into the pressure accumulator
0102	Filling an air spring from the pressure accumulator
0103	AM field strength
0104	FM field strength
0105	Current FM field strength
0106	Function activation
0107	PCM self-test
0108	Pressure sensor calibration
0109	Valve actuation
0110	Standardization of sliding roof/panorama roof
0111	Teach Vehicle Tracking System(VTS)
0112	PVTS/MOD - teach driver cards
0113	PCC/PVTS - deactivation
0114	Synchronized tests
0115	Steering-angle sensor calibration
0116	Calibration from camera
0117	Empty the tank
0118	Throttle valve adaption
0119	Adaptation of boost-pressure actuator
0120	Valve lift control, large lift
0121	System status
0122	Read out values
0123	Write values
0124	Distance travelled since last service
0125	Time (in days) since last service
0126	Reset on-board computer values
0127	Restore fuel gauge calibration value
0128	Save fuel gauge calibration value
0129	Reset
0130	Reset Service Interval
0131	Basic coding
0132	Teach control unit
0133	Teach electronic steering column lock
0134	Function test, sensors
0135	Fluid fill mode
0136	Backup measures
0137	Static test
0138	Swap test
0139	Front-axle speed sensors
0140	Rear-axle speed sensors
0141	Bleed
0142	Steering-angle sensor
0143	Axial acceleration sensor
0144	Interior monitoring
0145	Activation state memory
0146	Short tests

0147	System test
0148	Adaptations
0149	Ready status
0150	Delete adaptation data
0151	First start
0152	Calibration without previous part replacement
0153	Read permanent fault memory
0154	Oil filling
0155	Speed sensor test
0156	Sensor cluster compensation
0157	Static test
0158	Occupant detection, replacement/commissioning
0159	Tank calibration
0160	Display test images
0161	Function enable
0162	Multimedia interface test
0163	Compressor run-in
0164	Servo motor teaching
0165	Drive link test:damper valves
0166	Activation of key retaining solenoid
0167	Wiping angle adaptation
0168	Sliding/lifting roof standardization
0169	Events
0170	Erase event memory
0171	Activation state memory
0172	Erase activation state memory
0173	Immobilizer
0174	Transponder key
0175	Remote control
0176	System check
0177	Interior contact
0178	Front-axle final drive replacement
0179	Calibration of combination sensor
0180	HBA calibration
0181	Display central locking history
0182	Display Servotronic emergency operation counter
0183	Air spring ventilation
0184	Charge an air-spring
0185	Ventilation of entire system
0186	Inflate total air suspension system
0187	Display history memory for anti-theft alarm system
0188	Sliding-roof standardization
0189	Calibration after replacement of sensor module (selector lever position)
0190	Calibration after replacement of mechatronic components (hydraulics and control unit)
0191	Calibration after removal and installation of the mechatronic components
0192	Calibration after replacement of mechanical transmission components/PDK
0193	Move to installation position
0194	End assembly position
0195	Inflate air suspension system
0196	Calibrate

0197	PDLS (Porsche Dynamic Light system)
0198	Headlight beam adjustment (HBA)
0199	PDLS (Porsche Dynamic Light System) and headlight beam adjustment