



Function List

AutoMaker:MINI

NOTES:

- ✓ This function is supported.
 - This function is not supported.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
 - ✓ This function is the new feature in this version.
- As for special function please refer to the special function table.

Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
R50/R52/R53	Body	MRS/AB Airbag/ACSM	✓	✓	○	✓	✓	○	✓
R50/R52/R53	Body	AIC Automatic Interval control	✓	✓	○	✓	✓	○	○
R50/R52/R53	Body	BM On-board monitor	✓	✓	○	✓	✓	✓	○
R50/R52/R53	Body	CDC CD Changer	✓	✓	○	✓	○	✓	✓
R50/R52/R53	Body	CVM/CVM2 Convertible top module	✓	✓	○	✓	✓	✓	✓
R50/R52/R53	Body	DSP Digital Sound Processor	✓	✓	○	✓	✓	○	○
R50/R52/R53	Body	IHKA Heater/automatic A/C control	✓	✓	○	✓	✓	✓	✓
R50/R52/R53	Body	KOM Instrument cluster	✓	✓	○	✓	✓	✓	○
R50/R52/R53	Body	LRA Automatic headlight vertical aim control	✓	✓	○	✓	✓	✓	○
R50/R52/R53	Body	MFL Multifunction steering wheel I	✓	✓	○	✓	○	○	○
R50/R52/R53	Body	MFL Multifunction steering wheel II	✓	✓	○	✓	○	○	○
R50/R52/R53	Body	NAJ Navigation computer, Japan	✓	✓	○	✓	✓	✓	○
R50/R52/R53	Body	NAV Navigation computer, Europe	✓	✓	○	✓	✓	○	○
R50/R52/R53	Body	PDC Park distance control	✓	✓	○	✓	✓	✓	✓
R50/R52/R53	Body	RAD Radio	✓	✓	○	✓	✓	✓	✓
R50/R52/R53	Body	RLS Rain/Light Sensor	✓	✓	○	✓	✓	○	✓
R50/R52/R53	Body	SBBF Seat occupancy, passenger	✓	✓	○	✓	✓	○	○
R50/R52/R53	Body	SHD Sliding/tilting sunroof	✓	✓	○	✓	✓	✓	✓
R50/R52/R53	Body	ULF Universal charging and hands-free facility	✓	✓	○	✓	✓	✓	✓
R50/R52/R53	Body	VID Video module	✓	✓	○	✓	○	○	○
R50/R52/R53	Body	ZKE Central body electronics BCI	✓	✓	○	✓	✓	✓	○
R50/R52/R53	Body	ZKE Central body electronics BCI (Redesign)	✓	✓	○	✓	✓	✓	○
R50/R52/R53	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	○	✓	✓	✓	✓
R50/R52/R53	Chassis	EHPS Electro-hydraulic steering assistance	✓	✓	○	✓	✓	✓	○
R50/R52/R53	Chassis	LEW Steering-angle sensor	✓	✓	○	✓	✓	○	○
R50/R52/R53	Chassis	RDC Tyre pressure control	✓	✓	○	✓	✓	✓	✓
R50/R52/R53	Chassis	RPW tyre-blowout warning system	✓	✓	○	✓	✓	○	○
R50/R52/R53	Drive	DME/DDE (Engine Electronics)	✓	✓	○	✓	✓	✓	✓
R50/R52/R53	Drive	EGS/AGS (Transmission Control)	✓	✓	○	✓	✓	✓	✓
R50/R52/R53	Drive	EWS Vehicle immobilizer	✓	✓	○	✓	✓	✓	○
R55/R56/R57	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
R55/R56/R57	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	CA Comfort access system	✓	✓	✓	✓	✓	○	✓
R55/R56/R57	Body	CAN communication analysis	✓	✓	✓	○	○	○	○
R55/R56/R57	Body	CCC-A Applications	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	CCC-ANT Aerial tuner	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	CCC-ASK Audio system controller	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	CCC-B0 User interface	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	CCC-GW Gateway	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	CDC CD Changer	✓	✓	✓	✓	○	✓	✓
R55/R56/R57	Body	CID Central information display	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	CVM/CVM2 Convertible top module	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	DAB Digital tuner	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	FRM Footwell module	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	IBOC Digital tuner US	✓	✓	✓	✓	✓	○	✓
R55/R56/R57	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	IHKS Integrated heating/air-conditioning control	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	IHS Integrated heating control	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	JBE Junction-box electronics	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	JNAV Navigation system, Japan	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	MJOY MINI joystick	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	MOST system analysis	✓	✓	✓	✓	○	○	○
R55/R56/R57	Body	PDC Park distance control	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	RAD Radio	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	RAD2-B0 User interface	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	RAD2-GW Gateway	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	SDARS Satellite tuner	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	SHD Sliding/tilting sunroof	✓	✓	✓	✓	✓	✓	✓

R55/R56/R57	Body	SZL Switch centre, steering column	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	ULF-SBX Interface box	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	ULF-SBX-H Interface box High	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Body	VM Video Module	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Chassis	EPS Electronic Power Steering	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Chassis	RDC Tyre pressure control	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Drive	DME/DDE (Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Drive	EGS/AGS (Transmission Control)	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
R58/R59	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	CA Comfort access system	✓	✓	✓	✓	✓	○	✓
R58/R59	Body	CBX-ECALL Combox emergency call	✓	✓	✓	✓	✓	✓	○
R58/R59	Body	CHAMP-BO User interface	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	CHAMP-GW Gateway	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	CID Central information display	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	FRM footwell module	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	IBOC Digital tuner US	✓	✓	✓	✓	✓	○	✓
R58/R59	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	JBE Junction-box electronics	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	MJOY MINI joystick	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	PDC Park distance control	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	SHD Sliding/tilting sunroof	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	SZL Steering column switch centre 2	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	ULF-SBX Interface box	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	ULF-SBX-H Interface box High	✓	✓	✓	✓	✓	✓	✓
R58/R59	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
R58/R59	Chassis	EDC Damper Control	✓	✓	✓	✓	✓	✓	✓
R58/R59	Chassis	EPS Electronic Power Steering	✓	✓	✓	✓	✓	✓	✓
R58/R59	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
R58/R59	Drive	DME/DDE (Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
R58/R59	Drive	EGS/AGS (Transmission Control)	✓	✓	✓	✓	✓	✓	✓
R60	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
R60	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
R60	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
R60	Body	CA Comfort access system	✓	✓	✓	✓	✓	○	✓
R60	Body	CBX-ECALL Combox emergency call	✓	✓	✓	✓	✓	✓	○
R60	Body	CHAMP-BO User interface	✓	✓	✓	✓	✓	✓	✓
R60	Body	CHAMP-GW Gateway	✓	✓	✓	✓	✓	✓	✓
R60	Body	CID Central information display	✓	✓	✓	✓	✓	✓	✓
R60	Body	FRM Footwell module	✓	✓	✓	✓	✓	✓	✓
R60	Body	IBOC Digital tuner US	✓	✓	✓	✓	✓	○	✓
R60	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
R60	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
R60	Body	JBE Junction-box electronics	✓	✓	✓	✓	✓	✓	✓
R60	Body	MJOY MINI joystick	✓	✓	✓	✓	✓	✓	✓
R60	Body	PDC Park distance control	✓	✓	✓	✓	✓	✓	✓
R60	Body	SHD Sliding/tilting sunroof	✓	✓	✓	✓	✓	✓	✓
R60	Body	SZL Steering column switch centre 2	✓	✓	✓	✓	✓	✓	✓
R60	Body	ULF-SBX Interface box	✓	✓	✓	✓	✓	✓	✓
R60	Body	ULF-SBX-H Interface box High	✓	✓	✓	✓	✓	✓	✓
R60	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
R60	Chassis	EDC Damper Control	✓	✓	✓	✓	✓	✓	✓
R60	Chassis	EPS Electronic Power Steering	✓	✓	✓	✓	✓	✓	✓
R60	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
R60	Drive	DME/DDE (Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
R60	Drive	EGS/AGS (Transmission Control)	✓	✓	✓	✓	✓	✓	✓
F56	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
F56	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
F56	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
F56	Body	AMPT Top Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
F56	Body	ASD Active Sound Design	✓	✓	✓	✓	✓	✓	○
F56	Body	CBX-ECALL Combox emergency call	✓	✓	✓	✓	✓	✓	○
F56	Body	CIC Car Information Computer	✓	✓	✓	✓	✓	✓	✓
F56	Body	CON Controller	✓	✓	✓	✓	✓	✓	✓
F56	Body	DVDC DVD Changer	✓	✓	✓	✓	○	✓	✓
F56	Body	FZD Function centre, roof	✓	✓	✓	✓	✓	✓	✓
F56	Body	HKL Rear-lid lift	✓	✓	✓	✓	✓	✓	✓

F56	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
F56	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
F56	Body	KAFAS Camera-based driver- assistance systems	✓	✓	✓	✓	✓	✓	○
F56	Body	PMA Parking assistant	✓	✓	✓	✓	✓	✓	○
F56	Body	SMFA Seat module, driver	✓	✓	✓	✓	✓	✓	✓
F56	Body	SZL Switch centre, steering column	✓	✓	✓	✓	✓	✓	✓
F56	Body	ZGM Central Gateway Module	✓	✓	✓	✓	○	○	✓
F56	Body	TRSVc allround-view camera	✓	✓	✓	✓	✓	✓	○
F56	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
F56	Chassis	AL active steering	✓	✓	✓	✓	✓	○	✓
F56	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
F56	Drive	DME/DDE (Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
F56	Drive	EGS/AGS (Transmission Control)	✓	✓	✓	✓	✓	✓	✓
F55	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
F55	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
F55	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
F55	Body	AMPT Top Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
F55	Body	ASD Active Sound Design	✓	✓	✓	✓	✓	✓	○
F55	Body	CBX-ECALL Combox emergency call	✓	✓	✓	✓	✓	✓	○
F55	Body	CIC Car Information Computer	✓	✓	✓	✓	✓	✓	✓
F55	Body	CON Controller	✓	✓	✓	✓	✓	✓	✓
F55	Body	DVDC DVD Changer	✓	✓	✓	✓	○	✓	✓
F55	Body	FZD Function centre, roof	✓	✓	✓	✓	✓	✓	✓
F55	Body	HKL Rear-lid lift	✓	✓	✓	✓	✓	✓	✓
F55	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
F55	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
F55	Body	KAFAS Camera-based driver- assistance systems	✓	✓	✓	✓	✓	✓	○
F55	Body	PMA Parking assistant	✓	✓	✓	✓	✓	✓	○
F55	Body	SMFA Seat module, driver	✓	✓	✓	✓	✓	✓	✓
F55	Body	SZL Switch centre, steering column	✓	✓	✓	✓	✓	✓	✓
F55	Body	ZGM Central Gateway Module	✓	✓	✓	✓	○	○	✓
F55	Body	TRSVc allround-view camera	✓	✓	✓	✓	✓	✓	○
F55	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
F55	Chassis	AL active steering	✓	✓	✓	✓	✓	○	✓
F55	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
F55	Drive	DME/DDE (Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
F55	Drive	EGS/AGS (Transmission Control)	✓	✓	✓	✓	✓	✓	✓
R61	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
R61	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
R61	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
R61	Body	CA Comfort access system	✓	✓	✓	✓	✓	○	✓
R61	Body	CBX-ECALL Combox emergency call	✓	✓	✓	✓	✓	✓	○
R61	Body	CHAMP-BO User interface	✓	✓	✓	✓	✓	✓	✓
R61	Body	CHAMP-GW Gateway	✓	✓	✓	✓	✓	✓	✓
R61	Body	CID Central information display	✓	✓	✓	✓	✓	✓	✓
R61	Body	FRM footwell module	✓	✓	✓	✓	✓	✓	✓
R61	Body	IBOC Digital tuner US	✓	✓	✓	✓	✓	○	✓
R61	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
R61	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
R61	Body	JBE Junction-box electronics	✓	✓	✓	✓	✓	✓	✓
R61	Body	MJOY MINI joystick	✓	✓	✓	✓	✓	✓	✓
R61	Body	PDC Park distance control	✓	✓	✓	✓	✓	✓	✓
R61	Body	SHD Sliding/tilting sunroof	✓	✓	✓	✓	✓	✓	✓
R61	Body	SZL Steering column switch centre 2	✓	✓	✓	✓	✓	✓	✓
R61	Body	ULF-SBX Interface box	✓	✓	✓	✓	✓	✓	✓
R61	Body	ULF-SBX-H Interface box High	✓	✓	✓	✓	✓	✓	✓
R61	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
R61	Chassis	EDC Damper Control	✓	✓	✓	✓	✓	✓	✓
R61	Chassis	EPS Electronic Power Steering	✓	✓	✓	✓	✓	✓	✓
R61	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
R61	Drive	DME/DDE (Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
R61	Drive	EGS/AGS (Transmission Control)	✓	✓	✓	✓	✓	✓	✓
F57	Drive	CAS Car access system	✓	✓	✓	✓	✓	✓	○
F57	Drive	Engine-DME Digital Motor Electronics	✓	✓	✓	✓	※	※	○
F57	Drive	EGS transmission management	✓	✓	✓	✓	✓	✓	○
F57	Chassis	AL active steering	✓	✓	✓	✓	✓	✓	○
F57	Chassis	ABS-DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	○

F57	Body	Airbag-ACSM Crash Safety Module	✓	✓	✓	✓	✓	✓	○
F57	Body	AHM trailer module	✓	✓	✓	✓	✓	✓	○
F57	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	○
F57	Body	AMPT Top Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	○
F57	Body	ASD Active Sound Design	✓	✓	✓	✓	✓	✓	○
F57	Body	CBX-ECALL ComBox emergency call	✓	✓	✓	✓	✓	✓	○
F57	Body	CIC Car Information Computer	✓	✓	✓	✓	✓	✓	○
F57	Body	CON Controller	✓	✓	✓	✓	✓	✓	○
F57	Body	DSP Digital Sound Processor	✓	✓	✓	✓	✓	✓	○
F57	Body	DVDC DVD changer	✓	✓	✓	✓	✓	✓	○
F57	Body	FZD Function centre, roof	✓	✓	✓	✓	✓	✓	○
F57	Body	HKL Automatic luggage compartment lid actuation	✓	✓	✓	✓	✓	✓	○
F57	Body	IHKA Integrated automatic heating/air conditioning	✓	✓	✓	✓	✓	✓	○
F57	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	○
F57	Body	KAFAS Camera-based driver-assistance systems	✓	✓	✓	✓	✓	✓	○
F57	Body	PMA Parking assistant	✓	✓	✓	✓	✓	✓	○
F57	Body	SMFA Seat module, driver	✓	✓	✓	✓	✓	✓	○
F57	Body	Airbag-SZL Switch centre, steering column	✓	✓	✓	✓	✓	✓	○
F57	Body	TRSVc allround-view camera	✓	✓	✓	✓	✓	✓	○
F57	Body	TBX Touchbox	✓	✓	✓	✓	✓	✓	○
F57	Body	ZGM Central Gateway Control Module	✓	✓	✓	✓	✓	✓	○



Service Function List

Part	Components	Status
Maintenance	CBS reset Key Word Protocol	✓
Maintenance	CBS Reset UDS	✓
Maintenance	CBS reset, engine oil	✓
Maintenance	CBS vehicle data correction	✓
Maintenance	Charging the battery via diagnostic socket	✓
Maintenance	Delete transport mode	✓
Maintenance	Reset pre-delivery check	✓
Maintenance	Setting the transport mode	✓
Engine	Activation fuel pump control module	✓
Engine	Activation/deactivation terminal l5	✓
Engine	Adaptation of fuel quantity control valve	✓
Engine	Adaptation, hot film air mass meter	✓
Engine	Adjusting the starting torque	✓
Engine	Adjustment of exhaust-gas recirculation	✓
Engine	Adjustment of idle speed	✓
Engine	Adjustment, consumption calculation	✓
Engine	Automatic engine start-stop function: Starter exchange	✓
Engine	Automatic engine start-stop function: Teach in zero-gear sensor	✓
Engine	Bleeding the fuel system	✓
Engine	Charging the high-voltage battery: Read out history of last charging procedures	✓
Engine	Composition of the high-voltage battery unit: Read out serial numbers	✓
Engine	Compression test	✓
Engine	Consumption calculation adjustment	✓
Engine	Delete install mode	✓
Engine	Diesel particulate filter: - Request regeneration	✓
Engine	Diesel particulate filter: Replacement	✓
Engine	Diesel particulate filter: Request regeneration	✓
Engine	EGR adaptation	✓
Engine	EGS: Reset adaptation values	✓
Engine	EGS: Teach in neutral position	✓
Engine	EGS: transmission fluid adjustment	✓
Engine	Electronic immobiliser (EWS): Reset starter lock	✓
Engine	EME: Delete install mode	✓
Engine	EME: Read out the adjustment value of the rotor position sensor	✓
Engine	EME: Reset vacuum pump operating time	✓
Engine	EME: Rotor position sensor adjustment	✓
Engine	EME: Teach in parking lock module	✓
Engine	Engine control: Read measured value	✓
Engine	Engine operating values record	✓
Engine	European on-board diagnosis readiness codes	✓
Engine	EWS adjustment	✓
Engine	EWS starting value	✓
Engine	Exhaust-gas recirculation	✓
Engine	Fuel consumption display adjustment	✓
Engine	Fuel quality identification	✓

Engine	Fuel tank pressure sensor adjustment	✓
Engine	Gear sensor	✓
Engine	Idle speed adjustment	✓
Engine	Internal engine pressure	✓
Engine	Learn Valvetronic limit positions	✓
Engine	Mass meter	✓
Engine	Mean quantity adaptation	✓
Engine	MSA: Read history memory	✓
Engine	MSA: System check	✓
Engine	On-board Diagnosis Readiness Codes	✓
Engine	RDME: Delete install mode	✓
Engine	Reading out the readiness codes	✓
Engine	Regulation of switching speed	✓
Engine	Release correction, additive level 1	✓
Engine	Release correction, additive level 2	✓
Engine	REME: Delete install mode	✓
Engine	Reset adaptation values	✓
Engine	Reset production mode	✓
Engine	Reset production mode, preheating control unit	✓
Engine	Reset starter lock	✓
Engine	Reset the internal ELV fault counter	✓
Engine	Service start range extender	✓
Engine	Smooth running control	✓
Engine	Starting torque adjustment	✓
Engine	Starting up the high-voltage battery unit	✓
Engine	Start-up, fuel pump control	✓
Engine	Teach in drive position actuator	✓
Engine	Transmission control unit: Reset adaptation values	✓
Engine	Valvetronic adaptation limit positions	✓
Engine	VANOS adaptation	✓
Engine	Compression test	✓
Chassis	Workshop mode, Automatic Hold brake	✓
Chassis	Adjustment of steering torque sensor	✓
Chassis	Adjustment of the driving dynamics sensors	✓
Chassis	Brake bleeding procedure	✓
Chassis	DSC control unit adjustment	✓
Chassis	DSC: Bleeding routine	✓
Chassis	DSC: Brake line mix-up test	✓
Chassis	DSC: Brake line reversal check	✓
Chassis	DSC: Pressure sensor adjustment	✓
Chassis	DSC: Sensor adjustment	✓
Chassis	DSC: Steering angle sensor adjustment	✓
Chassis	PSC adjustment	✓
Chassis	PSC: Steering start-up	✓
Chassis	Service function, pressure encoding	✓
Chassis	Start-up for brake pedal travel sensor	✓
Chassis	Start-up, Automatic Hold brake	✓
Body	A/C compressor running-in protection	✓
Body	Activate deactivate test card	✓
Body	Activate SDARS	✓
Body	Add tuner section	✓
Body	Analysis of the wake-up control units	✓
Body	Auxiliary heater: Initialisation of the Telestart transmitter	✓

[illegible]

